

# Engine Inspection Brief — Field Checklist

## STATUS 18 Sep 2026 — part of this brief is done

A first visit has happened and photographs came back. **Four register items closed**, and the tasks that closed them are ticked below. What remains is mostly the multimeter work, which is the part that actually gates the design.

**Closed:** U11 engine identity (task 3.1 — the plate reads 3GK550ETA 4SR1 , *not* the model memo 01 inferred) · U1 the connector (tasks 3.4–3.8 — Bosch 1 928 405 192 / 194 , **code C**) · U13 which controller is fitted (DSE4522 MKII AMF, not a KG640C — this was not a task in this brief, it was raised by the evidence itself) · U3 no speed pickup (from DSE's manual).

**UPDATE, later on 18 Sep: U12 is CLOSED, and it closed badly.** Reported from the machine: **the fuel relay cuts a signal, it does not remove power.** That is the outcome task 2.1's table told the reader to flag immediately. §3's second line of defence terminates in the failure it was meant to catch, and the standalone trip module is now the only shutdown path on this machine that does not require the cooperation of the ECU being protected against. Task 1.4's contact-type check is still wanted as confirmation — see [refs/field-evidence-2026-09-18.md](#) §4 for why nothing depends on it.

**Also reported:** the intake throttle and the pre/post-heaters are **battery-fed**. That answers who supplies them, not who commands them — tasks 3.11 and the U14 trace both still stand.

**Also still open and cheap:** task 1.3 (U2, one resistance reading) and task 3.11 (U8, follow one cable by hand).

**New since this brief was written,** worth adding to the next visit: trace the **pre-heat / post-heat** supply — the DSE4522's configuration enables both at 50 °C and this design has no heater output at all (U14).

**Purpose:** close every open unknown that no amount of desk research can close — only a person with a multimeter and a camera, at the machine, can. Closes or advances **U1, U2, U4, U6, U7, U8, U9, U10, U11, U12**, plus the pin 01/02 ground question raised in the reconciled spec.

**Print this. Carry it. Tick boxes as you go — a half-finished visit is still useful if the ticks say which half.**

Sources: reconciled spec `docs/superpowers/specs/2026-09-13-ecu-reconciled-spec-design.md` (§3 safety, §8 unknowns register), `refs/ecu-pinout-extracted.md`, research memos `docs/research/01-engine-identity.md` and `docs/research/03-ecu-connector.md`. Every expected reading below cites one of these. Anything not sourced is marked **inferred**.

---

## SAFETY — read this before touching anything

---

This is a 25 kVA genset: a diesel engine that can start, and a 415 V three-phase alternator. This checklist is bench/inspection work only.

- **Battery disconnected before any continuity or resistance measurement.** Negative terminal off first, isolated, out of reach of the positive post.
- **Nothing inside the alternator output enclosure.** No task here requires it. If you find yourself reaching toward the 415 V output terminals, stop — that is not this checklist.
- **The engine does not run during any of this.** Every task below is done with the engine off. Ignition-on tasks mean the key/master switch position only, never cranking or running.
- **If a measurement needs the set running** (this includes the full CAN log in Group 4, which may need it), **that is a separate supervised activity**, done by someone qualified to run the set, not a solo checklist item. Note it as such and move on.
- Reconnect the battery only after Group 1 is fully complete and you've checked no tools or leads are left on the terminals.

**Materials:** digital multimeter (V,  $\Omega$ , continuity beep), clamp meter if available (safer than breaking a fused circuit for current), phone/camera with flashlight, notebook or voice memo, 10 mm socket for the battery terminal, tape/marker for labelling. **Group 4 additionally needs a USB-CAN adapter and a laptop** — it may warrant its own trip.

---

## Group 1 — Battery disconnected (continuity / resistance)

---

Do these first, in this order, with the battery negative terminal removed and isolated.

- ☐ **1.1 — Pin 01/02 ground hypothesis.** Continuity from ECU connector pins 01 and 02 to battery negative / chassis ground.
- *Why:* the connector drawing places 01/02/05/06 as large power contacts, but 01/02 are labelled `G_G_B AT1 / AT2` — switch-return legs, which wouldn't need a large contact. The alternate reading: `G_G_B` = battery

ground, and these are the ECU's main power grounds (also the only explanation for why no power-ground pin appears anywhere in the 44-pin extraction). (*spec §4 note; pinout "Digital inputs"*)

- **Continuity (near 0  $\Omega$ )** → **hypothesis confirmed**: 01/02 are power grounds, not switch returns. Update the pin map and power/ground plan.
- **Open circuit** → **hypothesis wrong**. They're isolated switch-return legs as originally labelled; the power-ground pin(s) remain unidentified — keep looking during Group 3 tracing.
- [ ] **1.2 — Pin 09 "synchronization ground."** Continuity from pin 09 to (a) battery negative and (b) a known sensor ground pin (e.g. 34 or 08).
- *Why*: pin 09 is named as a ground but drawn in **red** (switched-battery colour class), which is contradictory on its face. (*spec §4, "Power"; pinout, U6 entry*)
- **Continuous to battery negative** → it likely is a ground point, oddly coloured in the diagram for harness-routing reasons, not a live signal. Note this for §4 but treat as resolved.
- **Open to both** → it is *not* a simple ground. Carry to Group 2 (2.3) for a voltage measurement — the red wire colour then means what it usually means.
- [ ] **1.3 — Boost sensor thermistor topology (closes U2 outright)**. Boost P&T sensor unplugged, engine **cold**. Resistance across sensor pins 2 and 1 (ECU pins 79 / 34 per the pinout — temperature signal / sensor ground). (*brief; spec §8 U2; pinout "Analog sensors"*)
- A few k $\Omega$ , falling if you re-check once the engine's warmed a little → NTC thermistor. Design a pull-up divider front-end. U2 closed.
- **Open circuit, or a fixed high reading that doesn't move with temperature** → not a bare NTC — a conditioned/ratiometric output. Design the ratiometric front-end (same as the pressure channel). U2 closed.
- This is a single measurement. Either outcome closes U2 — there is no third case.

---

▣ **1.4 — Ignition relay contact type.** (*Still wanted 18 Sep as confirmation; task 2.1 has since been answered the other way round — see the status banner.*) **Do this BEFORE task 2.1; it decides how 2.1's result is read.** Locate ignition relay -13RB1 on the GCU relay board. With the battery disconnected and the relay coil unpowered, measure continuity across its **load contacts** (not the coil).

*Why this matters and why 2.1 is ambiguous without it:* task 2.1 reads voltage with the ignition switch off, assuming that is the relay's de-energised state. If the relay turns out to be normally-closed, "de-energised" means contacts **made** and power still present — so a battery-voltage reading in 2.1 would mean the test state was wrong, not that the relay only signals. Those two have opposite conclusions and the same reading. This measurement separates them. **Inferred concern, not sourced — raised because the relay's drive logic is not documented anywhere we have.**

| Continuity across load contacts, coil unpowered | Meaning for task 2.1                                                                                                                                                               |
|-------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Open (normally-open, energise to run)           | Expected case. 2.1's table reads as written.                                                                                                                                       |
| Closed (normally-closed, energise to cut)       | 2.1's table is <b>inverted</b> . Battery voltage with the switch off is then normal, and U12 must instead be tested by energising the relay and re-measuring. Note it and flag it. |

## Group 2 — Ignition switch tests (battery connected, engine OFF, not cranking)

Reconnect the battery for this group only. Key/master switch is the only thing that moves. **Do not crank or start.**

- 2.1 — U12, the priority item. Complete task 1.4 first. Ignition/master switch **OFF**. This is assumed to be ignition relay -13RB1 's de-energised state — **task 1.4 confirms that assumption, and if it fails, the table below inverts**. You do not need to pull or force the relay. If you can see or hear the relay (GCU relay board), confirm it looks/sounds unenergised before measuring; photograph its label to confirm 70 A rating.

With the switch OFF, measure voltage (relative to chassis/battery negative) at: - ECU connector pin 21 (battery+ feed) - ECU connector pin 04 ( V\_V\_BAT\_1R ) - ECU connector pin 06 ( V\_V\_BAT\_2R ) - the **fuel metering unit's own pin 2** (its battery-fed pin, via 20 A fuse 8F1 — not ECU pin 88, which is the ECU's PWM output to metering unit pin 1)

*Why this is the whole point of the trip:* spec §3's safety argument — that a hung ECU can't keep injecting because the GCU physically removes fuel-system power — depends entirely on this. (*spec §3, §8 U12*)

| Reading at all four points             | Meaning                                                                                                                                                                                               |
|----------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0 V (no battery voltage present)       | Relay <b>removes power</b> . §3's second line of defence is real. U12 closed in the safe direction.                                                                                                   |
| Battery voltage present at any of them | Relay <b>signals only</b> — power stays up through a hung ECU. §3's relaxation is void: reverts to "standalone MPU trip module mandatory." <b>Flag this immediately, do not wait for the writeup.</b> |

- ▣ 2.2 — U7: are pins 04/06 sense-only or load feeds? Switch ON (engine still off). Re-measure voltage at pins 04 and 06 (expect battery voltage present now, per 2.1's contrast — that alone doesn't answer U7).
- **Then measure current**, preferably with a clamp meter on the wire (safer — no circuit break). If only a multimeter is available, break the circuit at the fuse holder for 04/06 and measure DC current in series, briefly.
- *Why*: sense lines draw milliamps; something that's actually feeding a load draws amps, and each fuse is rated 10 A. (*brief; spec §8 U7; spec §4 "Power" — both pins are 10 A fused*)

| Current                                                      | Meaning                                                                                                       |
|--------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
| mA range                                                     | Sense-only — these just feed the battery-voltage ADC divider. Power sheet needs no extra current rating here. |
| Amps, approaching the 10 A fuse rating under some load state | Load feed — something downstream draws real current through the ECU. Power sheet must size for it.            |

- ▣ 2.3 — Pin 09, if 1.2 left it open. Switch ON. Voltage at pin 09 vs. chassis.
- ~0 V → confirms a ground reference despite the odd wire colour.
- **Switched battery voltage** → it's a real signal wearing a "ground" name — treat as an undocumented discrete/analog input, not a ground. Note whatever else in the harness moves when this changes (if observable) as a clue to its function.

---

## Group 3 — Photography (engine off; battery may be either state, disconnect

---

preferred while working around the engine bay)

For each: square-on unless noted, fill the frame, flash off / raking light for part numbers (on-axis flash washes out shallow embossing).

- ▣ ~~3.1 DONE 18 Sep~~ — **Engine rating plate** (rocker cover / flywheel housing / block side). Get legible: model string (expect something matching **3R550ETA** — anything else means the engine-identity inference in memo 01 is wrong and should be discarded, not patched), serial number, rated output/speed/frequency, any emissions certification mark. **Closes U11.** (*memo 01, "What would close this"*)
- ▣ **3.2 Genset nameplate** (canopy/control panel). **Do not go looking for a string you expect.** This brief originally said to expect **KG4-25WS1**, inferred from memo 01's engine identification — and that identification turned out to be wrong when the engine plate was read. The genset model inference came from the same chain and is equally unsupported. Photograph whatever is actually on the plate, including the serial number. (*memo 01, and its correction*)

- ▣ **3.3 ECU case label.** Flat, well-lit. Hunting a vendor part number — Bosch EDC pattern `0 281 0xx xxx`, Bosch-reseller pattern `F 01R 0xx xxx`, or any Continental/Delphi/Denso mark. **Now more likely to pay off than when this was written:** the connector is confirmed Bosch (`1 928 405 192 / 194`), so a Bosch part number on the case would be consistent and would identify the OEM ECU outright. Would resolve the still-open OEM-ECU-vendor question. (*memo 03 §4 item 4*)
- ▣ **3.4 ~~DONE 18 Sep~~ — ECU connector — full-face, mating side, connector unplugged.** Determines at a glance: flat rectangular multi-row grid (Bosch/Delphi-style) vs. oval/rounded single-lever shell (AMPSEAL-style) — the top-level branch of the connector shortlist. **Advances U1.** (*memo 03 §4 item 1, ranked candidate table*)
- ▣ **3.5 ~~DONE 18 Sep~~ — Connector retention mechanism,** actuated and disengaged, if it can be operated safely with the connector unplugged. Lever vs. slide latch vs. bolt vs. friction/CPA clip. (*memo 03 §4 item 2*)
- ▣ **3.6 ~~DONE 18 Sep~~ — Raking-light pass over every flat face of the connector housing —** top, both sides, cable boot. Hunting molded/raised part number, date code, or logo: Bosch roundel, Delphi/Aptiv wordmark, TE Connectivity mark. Take several shots at different light angles if the first doesn't show text. **Would settle U1's connector-family ranking outright if a logo turns up.** (*memo 03 §4 item 3*)
- ▣ **3.7 ~~DONE 18 Sep~~ — Connector still mated, wide shot —** backshell, cable exit angle, strain relief. Feeds the adapter-harness design even without a family ID. (*memo 03 §4 item 5*)
- ▣ **3.8 ~~DONE 18 Sep~~ — Pin-count/contact-size check, connector unplugged.** Confirm four rows of small pins plus two 2-pin corner blocks (near pins 1 and 5). **Check specifically whether the corner-block contacts (pins 1/2/5/6) are visibly larger/wider than the small-pin grid.** This is the photographic half of the 1.1 pin 01/02 question — larger contacts support "these are power," normal-sized contacts support "these are ordinary switch returns after all." (*memo 03 §4 item 6; spec §4 note*)
- ▣ **3.9 Boost P&T sensor body —** part number, if legible. Backs up 1.3's electrical answer with a datasheet-checkable part.
- ▣ **3.10 Injector body —** part number, if accessible without disturbing the fuel system. Corroborates the Bosch-family injector inference already used in memo 03/04.
- ▣ **3.11 Intake throttle — 6-pin connector and cable run (closes U8).** Photograph the connector, then follow the cable by hand through the loom.
- **Terminates at the ECU's 94-pin connector →** in scope. Photograph which physical position on the ECU housing it plugs into (row/corner), so it can be matched to a pin number once U1 is resolved.



- Joins the XC11/XC1 panel loom instead (same path as fuel level/WIF, per spec §2.3) → out of scope for this ECU; a throttle driver sheet is not needed.
- ▣ 3.12 Catalyst temperature sensor — 2-pin connector and harness run (closes U9). Same method as 3.11: photograph, then trace.
- Terminates at ECU → in scope, an EGT-style front-end is needed.
- Joins the panel/GCU loom → out of scope, same treatment as fuel level/WIF.
- ▣ 3.13 KG640C terminal strip (J1–J8), photographed with terminal labels legible. Reference material for the MPU-input question (U3) and future GCU interface work; not expected to close anything by itself this visit.
- ▣ 3.14 Wire-colour spot check at each analog sensor connector (boost, coolant, EGR, oil pressure, rail pressure) — flag toward U10. SENT and CAN H share the same yellow colour code in this harness's legend (*pinout*, "*Wire colour classes*"), so this can't be resolved by colour alone. Photograph any single yellow wire that is not paired with a green wire (a CAN pair) and is not part of a 3-wire AC bundle — that's the SENT candidate. This will likely only narrow it down, not close it outright — say so in the notes rather than guessing a pin.

---

## Group 4 — Separate trip: CAN bus log (closes U4 in practice, not from a manual)

---

Needs a USB-CAN adapter and a laptop. Do this as its own visit unless you're already bringing the hardware.

- ▣ 4.1 With the OEM ECU still fitted and the harness intact, tap CAN channel 1 (pins 55/77, H/L) and channel 2 (pins 87/86, H/L) via breakout or fly leads. (*pinout*, "*CAN — two channels*"; *spec §4*)
  - ▣ 4.2 Log traffic with the ignition on (ECU and GCU powered). Identify PGNs present, source addresses, and update rates.
  - Basic identification/status broadcasts should appear at key-on. **Engine-state PGNs (speed, load) may not appear, or may read zero/stale, until the engine is actually running** — if you need those, that's the "separate supervised activity" from the safety preamble, not a solo add-on to this trip.
  - ▣ 4.3 Compare the captured PGN set against whatever the KG640C is found to expect (from the log itself, and cross-check against the KG640 manual if it surfaces). This is the practical closure the brief couldn't get from documents — the log is the source, not a spec. (*spec §8 U4*)
-

## What this closes

| #   | Unknown                                  | Closed by                                                                                                                    |
|-----|------------------------------------------|------------------------------------------------------------------------------------------------------------------------------|
| U1  | Connector family                         | 3.4, 3.5, 3.6, 3.7, 3.8 (photographic — narrows the ranked shortlist in memo 03, may not fully settle it without a logo hit) |
| U2  | Boost air-temp topology                  | 1.3 — closes outright                                                                                                        |
| U4  | KG640C PGN set                           | Group 4 — practical answer via live log                                                                                      |
| U6  | Pin 09 function                          | 1.2, 2.3                                                                                                                     |
| U7  | Pins 04/06 sense vs. load                | 2.2                                                                                                                          |
| U8  | Intake throttle on ECU?                  | 3.11                                                                                                                         |
| U9  | Catalyst sensor routing                  | 3.12                                                                                                                         |
| U10 | Which signal is SENT                     | 3.14 — narrows, may not fully close                                                                                          |
| U11 | Engine identity                          | 3.1 — closes outright if plate matches                                                                                       |
| U12 | Ignition relay: power-cut or signal-only | 2.1 — <b>the safety-gate item; closes §3's open question either way</b>                                                      |
| —   | Pin 01/02 ground hypothesis              | 1.1, 3.8                                                                                                                     |

Ten register entries touched, two (U2, U11) closeable outright on the spot, one (U12) resolves the live safety-argument branch either way, the rest narrowed with a clear next step recorded regardless of outcome.