Listing of the FBH HBT Model

Matthias Rudolph

Ferdinand-Braun-Institut für Höchstfrequenztechnik (FBH), Gustav-Kirchhoff-Str. 4, D-12489 Berlin, Germany rudolph@fbh-berlin.de, http://www.fbh-berlin.de/modeling.html

ver 2.1.20050728

```
FBH_HBT model version 2.1.20050728
   Copyright (C) 2005 Ferdinand-Braun-Institut
               im Forschungsverbund Berlin (FBH)
               Gustav-Kirchhoff-Str. 4
               D-12489 Berlin
   All rights reserved.
   By downloading this code, you agree that FBH shall not be held
   to any liability with respect to any claim by you or from any
   third party arising from or on account of the use of this code,
   regardless of the form of action, including negligence. In no event
15 will FBH be liable for consequential or incidental damages of
   any nature whatsoever.
   Model documentation:
      www.fbh-berlin.de/modeling.html
      rudolph@fbh-berlin.de
25 'include "disciplines.vams"
 'include "constants.vams"
 'include "compact.vams"
 'define STDTEMP 20.0
30 'define KDURCHQ 0.861708692e-4
 'define FOUR_K (4 * 1.3806226e-23)
 'define TWO_Q (2 * 1.6021918e-19)
35 'define sqr(x) (x*x)
 // begin of FBH HBT model
 module HBT_Xb(c,b,e,t);
40//external nodes
 inout e,b,c,t;
 electrical e,b,c,t;
 //internal nodes
45 electrical ei, bi, bii, ci, ti, ex, exx, cx, ni, nii;
```

//model parameters

```
parameter integer Mode = 1 from [0:4];
                                                   // Ignored
 parameter integer Noise = 1 from [0:4];
                                                   // Ignored
50 parameter integer Debug = 0 from [0:inf);
                                                   // Ignored
 parameter integer DebugPlus = 0 from [0:inf);
                                                   // Ignored
 parameter real Temp = 25.0 from [-273.15:inf);
   // Device operating temperature, Celsius
55 parameter real Rth = 0.1 from [0.0:inf);
   // Thermal resistance, K/W
 parameter real Cth = 700n
                             from [0.0:inf);
   // Thermal capacitance
60 parameter integer N = 1 from (0:inf);
   // Scaling factor, number of emitter fingers
 parameter real L = 30u from (0.0:inf);
   // Length of emitter finger, m
 parameter real W = 3u from (0.0:inf);
65 // Width of emitter finger, m
 parameter real Jsf = 20e-24 from [0.0:inf);
   // Forward saturation current density, A/um^2
 parameter real nf = 1.0 from [0.0:inf);
70 // Forward current emission coefficient
 parameter real Vg = 1.3 from [-2.0:inf);
    // Forward thermal activation energy, V,
    // (0 == disables temperature dependence)
75 parameter real Jse = 0.0 from [0.0:inf);
   // B-E leakage saturation current density, A/um^2
 parameter real ne = 0.0 from [0.0:inf);
    // B-E leakage emission coefficient
 80 // Limiting resistor of B-E leakage diode, Ohm
 parameter real Vgb = 0.0 from [0.0:inf);
   // B-E leakage thermal activation energy, V,
   // (0 == disables temperature dependence)
85parameter real Jsee = 0.0
                           from [0.0:inf);
   // 2nd B-E leakage saturation current density, A/um^2
 parameter real nee = 0.0 from [0.0:inf);
   // 2nd B-E leakage emission coefficient
 parameter real Rbbxx= 1e6 from (0.0:inf);
90 // 2nd Limiting resistor of B-E leakage diode, Ohm
 parameter real Vgbb = 0.0 from [0.0:inf);
   // 2nd B-E leakage thermal activation energy, V,
   // (0 == disables temperature dependence)
95 parameter real Jsr = 20e-18 from [0.0:inf);
   // Reverse saturation current density, A/um^2
 parameter real nr = 1.0 from [0.0:inf);
   // Reverse current emission coefficient
 parameter real Vgr = 0.0 from [0.0:inf);
100 // Reverse thermal activation energy, V,
   // (0 == disables temperature dependence)
 parameter real XCjc = 0.5 from [0.0:1.0);
   // Fraction of Cjc that goes to internal base node
105parameter real Jsc = 0.0 from [0.0:inf);
   // B-C leakage saturation current density, A/um^2
   // (0. switches off diode)
 parameter real nc = 0.0 from [0.0:inf);
   // B-C leakage emission coefficient (0. switches off diode)
110 parameter real Rcxx = 1e6 from (0.0:inf);
```

```
// Limiting resistor of B-C leakage diode, Ohm
 parameter real Vgc = 0.0 from [0.0:inf);
   // B-C leakage thermal activation energy, V,
   // (0 == disables temperature dependence)
 parameter real Bf = 100.0
                           from [0.0:inf);
   // Ideal forward beta
 parameter real kBeta= 0.0 from [0.0:inf);
   // Temperature coefficient of forward current gain, -1/K,
120 // (0 == disables temperature dependence)
 parameter real Br = 1.0
                           from [0.0:inf);
   // Ideal reverse beta
 parameter real VAF = 0.0
                            from [0.0:inf);
125 // Forward Early voltage, V, (0 == disables Early Effect)
 parameter real VAR = 0.0 from [0.0:inf);
   // Reverse Early voltage, V, (0 == disables Early Effect)
 parameter real IKF = 0.0
                           from [0.0:inf);
130 // Forward high-injection knee current, A,
   // (0 == disables Webster Effect)
 parameter real IKR = 0.0 from [0.0:inf);
   // Reverse high-injection knee current, A,
   // (0 == disables Webster Effect)
 parameter real Mc = 0.0
                         from [0.0:inf);
   // C-E breakdown exponent, (0 == disables collector break-down)
 parameter real BVceo= 0.0 from [0.0:inf);
   // C-E breakdown voltage, V, (0 == disables collector break-down)
140 parameter real kc = 0.0
                         from [0.0:inf);
   // C-E breakdown factor, (0 == disables collector break-down)
 parameter real BVebo= 0.0 from [0.0:inf);
   // B-E breakdown voltage, V, (0 == disables emitter break-down)
 parameter real Tr = 1f
                          from [0.0:inf);
   // Ideal reverse transit time, s
 // Extrinsic BC diffusion capacitance, s
150 parameter real Tf = 1p from [0.0:inf);
   // Ideal forward transit time, s
 parameter real Tft = 0.0 from [0.0:inf);
   // Temperature coefficient of forward transit time
 parameter real Thcs = 0.0 from [0.0:inf);
155 // Excess transit time coefficient at base push-out
 parameter real Ahc = 0.0 from [0.0:inf);
   // Smoothing parameter for Thcs
 parameter real Cje = 1f
                           from [0.0:inf);
160 // B-E zero-bias depletion capacitance, F/um^2
 parameter real mje = 0.5
                           from [0.0:1);
   // B-E junction exponential factor
 parameter real Vje = 1.3 from [0.0:inf);
   // B-E junction built-in potential, V
 parameter real Cjc = 1f
                           from [0.0:inf);
   // B-C zero-bias depletion capacitance, F/um^2
 parameter real mjc = 0.5 from [0.0:inf);
   // B-C junction exponential factor
170 parameter real Vjc = 1.3 from [0.0:inf);
   // B-C junction built-in potential, V
 parameter real kjc = 1.0 from (-inf:inf);
   // not used
```

```
parameter real Cmin = 0.1f from [0.0:inf);
175 // Minimum B-C depletion capacitance (Vbc dependence), F/um^2
 parameter real J0 = 1e-3 from [0.0:inf);
   // Collector current where Cbc reaches Cmin, A/um^2
   // (0 == disables Cbc reduction)
180 parameter real XJ0 = 1.0 from [0.0:1.0];
   // Fraction of Cmin, lower limit of BC capacitance (Ic dependence)
 parameter real Rci0 = 1e-3 from (0.0:inf);
   // Onset of base push-out at low voltages, Ohm*um^2
   // (0 == disables base push-out)
185 parameter real Jk = 4e-4 from [0.0:inf);
   // Onset of base push-out at high voltages, A/um^2,
   // (0 == disables base push-out)
 parameter real RJk = 1e-3 from [0.0:inf);
   // Slope of Jk at high currents , Ohm*um^2
190 parameter real Vces = 1e-3 from [0.0:inf);
   // Voltage shift of base push-out onset, V
                          from (0.0:inf);
 parameter real Rc = 1.0
   // Collector resistance, Ohm/finger
195 parameter real Re = 1.0 from (0.0:inf);
   // Emitter resistance, Ohm/finger
 parameter real Rb = 1.0 from (0.0:inf);
   // Extrinsic base resistance, Ohm/finger
 parameter real Rb2 = 1.0 from (0.0:inf);
200 // Inner Base ohmic resistance, Ohm/finger
 parameter real Lc = 0.0 from [0.0:inf);
   // Collector inductance, H --- not yet implemented
 parameter real Le = 0.0 from [0.0:inf);
205 // Emitter inductance, H --- not yet implemented
 parameter real Lb = 0.0 from [0.0:inf);
   // Base inductance, H
                             --- not yet implemented
 parameter real Cq = 0.0
                          from [0.0:inf);
210 // Extrinsic B-C capacitance, F
 parameter real Cpb = 0.0 from [0.0:inf);
   // Extrinsic base capacitance, F
 parameter real Cpc = 0.0 from [0.0:inf);
   // Extrinsic collector capacitance, F
 parameter real Kfb = 0.0
                            from [0.0:inf);
   // Flicker-noise coefficient
 parameter real Afb = 0.0 from [0.0:inf);
   // Flicker-noise exponent
220 parameter real Ffeb = 0.0 from [0.0:inf);
   // Flicker-noise frequency exponent
 parameter real Kb = 0.0 from [0.0:inf);
   // Burst noise coefficient
 parameter real Ab = 0.0
                           from [0.0:inf);
225 // Burst noise exponent
 parameter real Fb = 0.0
                           from (0.0:inf);
   // Burst noise corner frequency, Hz
 parameter real Kfe = 0.0
                             from [0.0:inf);
   // Flicker-noise coefficient
230 parameter real Afe = 0.0 from [0.0:inf);
   // Flicker-noise exponent
 parameter real Ffee = 0.0 from [0.0:inf);
   // Flicker-noise frequency exponent
235 parameter real Tnom = 20.0
                             from [-273.15:inf);
   // Ambient temperature at which the parameters were determined
```

```
// general functions
 //
240
  // kT/Q
 analog function real Vth;
      input TT;
     real TT, KDURCHQ;
     begin
245
          KDURCHQ=0.861708692e-4;
          Vth = KDURCHQ*(TT +273.15);
      end
 endfunction
 // safe exponential function
 analog function real exp_soft;
      input x;
      real x, maxexp, maxarg;
      begin
          maxexp = 1.0e25;
          maxarg = ln(maxexp);
260
          if (x < maxarg) begin</pre>
              exp\_soft = exp(x);
          end
          else begin
             exp\_soft = (x+1.0-maxarg)*(maxexp);
265
      end
 endfunction
270 // limited internal Voltage
  analog function real Vt;
     input U, Ud;
     real U, Ud, Vch, VF;
     begin
         Vch = 0.1 * Ud;
275
         VF = 0.9 * Ud; // we fix this value for simplicity.
              Vt = U - Vch * ln(1.0 + exp((U-VF)/Vch));
         else
              Vt = VF - Vch * ln(1.0 + exp((VF-U)/Vch));
      end
  endfunction
285// diode function
 analog function real diode;
      input U, Is, Ug, N, AREA, TJ, TNOM;
      real U, Is, Ug, N, AREA, TJ, TNOM, VTHO, VTHJ, VTHNOM, maxi,
            Tmax, TJM, KDURCHQ, lnIs;
     begin
          VTH0=Vth(20.0);
          VTHNOM=Vth(TNOM);
          KDURCHQ = 0.861708692e-4;
          lnIs=ln(Is*AREA);
295
          maxi=ln(1e6);
          if ((maxi<(Ug/VTHNOM)) && (U < 0.0))</pre>
             begin
```

```
Tmax= Ug*VTHNOM/((Ug - maxi*VTHNOM)*KDURCHQ) - 273.15;
300
                TJM=Vt(TJ,Tmax);
             end
          else
             begin
                TJM=TJ;
305
             end
          VTHJ = Vth(TJM);
          if (Ug > 0.0) begin
               diode = exp_soft(U/(N*VTHJ) + Ug/VTHNOM - Ug/VTHJ + lnIs) -
310
                        exp_soft(Ug/VTHNOM - Ug/VTHJ + lnIs);
          end
          else begin
              diode = exp_soft(U/(N*(VTH0)) + lnIs) - Is*AREA;
          end
315
      end
 endfunction
  // CE-breakdown function
320 analog function real MM;
      input VBCI, VCBO, MC, VCBLIN, BF, KC;
      real VBCI, VCBO, MC, VCBLIN, BF, KC;
      real FBD, vcbi;
      begin
325
          if((KC > 0.0) && (MC > 0.0) && (VCBO > 0.0)) begin
              vcbi = VBCI;
              FBD = VCBLIN/VCBO;
              if(VBCI > 0.0)
                  MM = 1.0;
330
              else if(VBCI > (-VCBLIN)) begin
                  if (MC==1)
                      MM = 1.0/(1.0 - (vcbi/(-VCBO)));
                  else
                      MM = 1.0/(1.0 - pow(vcbi/(-VCBO), MC));
335
              end
              else if(VBCI <= (-VCBLIN)) begin</pre>
                  if (MC==1) begin
                      MM = 1.0/(1.0 - FBD) - 1.0/VCBO *
                           1.0/pow(1.0 - FBD,2.0) * (vcbi + FBD*VCBO);
340
                  end
                  else begin
                      MM = 1.0/(1.0 - pow(FBD,MC)) - MC/VCBO *
                           pow(FBD,MC-1.0)/pow(1.0 -
                           pow(FBD,MC),2.0) * (vcbi + FBD*VCBO);
345
                  end
              end
          end
          else
              MM = 1.0;
350
      end
 endfunction
355 // Depletion Charge
  analog function real charge;
       input U, C0, Ud, m, Area;
       real U, CO, Ud, m, Area, Vj, Vjo, VF;
       begin
          Vj = Vt(U,Ud);
360
          Vjo = Vt(0.0,Ud);
          VF = 0.9 * Ud; // we fix this value for simplicity.
```

```
if(m==1.0) begin
365
              charge = Area*(C0)*
                     ( Ud*( ln(1.0 - Vjo/Ud) -
                            ln(1.0 - Vj/Ud)
                       1.0/(1.0 - VF/Ud) * (U - Vj + Vjo));
           end
370
           else begin
            charge = Area*(C0)*
                   ((Ud/(1.0-m))*(pow(1.0 - Vjo/Ud, 1.0-m) -
                                    pow(1.0 - Vj/Ud , 1.0-m)
375
                                   ) +
                     pow(1.0 - VF/Ud, -m) * (U - Vj + Vjo) -
                     Ud*(1.0/(1.0-m)));
           end
        end
   endfunction
   // limited internal Voltage
  analog function real Vceff;
       input U, VCES;
      real U, VCES, Vth0;
      begin
          Vth0 = 0.025;
          if (U < VCES)</pre>
390
             Vceff = Vth0 + Vth0 * ln(1.0 + exp((U-VCES)/Vth0 - 1.0));
          else
             Vceff = (U-VCES) + Vth0 * ln(1.0 + exp(1.0-(U-VCES)/Vth0));
395 endfunction
  // Current for Onset of Kirk effect
  analog function real ICK;
      input U, RCIO, VLIM, InvVPT, VCES;
     real U, RCIO, VLIM, InvVPT, VCES, VC, x;
400
     begin
        VC = Vceff(U,VCES);
         x = (VC - VLIM)*InvVPT;
         ICK = VC/RCIO * (1.0/sqrt(1.0 + (VC/VLIM)*(VC/VLIM)))*(
405
                          1.0 + (x + sqrt((x*x)+0.001))/2.0);
      end
  endfunction
410
 //local variables
 real vbcx, vbci, vbei, vxe, vxxe, vxc, vcei;
 real Ic0, Ic, Ic1, Ic1r, Ib2, Ibx,
       Ib0, Ibdx, Icdx, Ibdxx, Ib1, Ic0a, Ic1ra,
      Ipdiss, Ik, eps, IcIk;
 real qb2;
 real qb2x, qb2med, qb1, xtff, qbe, qbtr,
       qbtra, qbtf;
 real EdBeta, mm;
420real epsi, Vbclin;
 real Texi, Tex, Tj, TjK, Area;
 real RCIO, AHC, Ih, Wh, Vlim, InvVpt, q1, q2, qb, I00;
 real xix;
 real FOUR_K,TWO_Q ;
```

```
analog begin
   //
  // begin of model equations
430
   //
   // Port Voltages
   vbcx = V(bi,ci);
   vbci = V(bii,ci);
vbei = V(bii,ei);
   vxe = V(ex,ei);
   VXC = V(CX,Ci);
   vxxe = V(exx,ei);
   vcei = V(ci,ei);
   Texi = V(ti);
   Tj = Texi + Temp; // Junction temperature
                     // Junction temperature in K
   TjK = Tj+273.15;
   Tex = Tj - Tnom;
                       // Temperature difference to reference
   Area = L*W*(1.0e12) * N;
                                // Transistor area in um^2
   FOUR_K = 4 * 1.3806226e-23; // 4 k for noise
   TWO_Q = 2 * 1.6021918e-19; // 2 q for noise
450
   // Nonlinear Part --- Current Sources
   11
   // Collector Currents
   Ic0a = diode(vbei, Jsf, Vg, nf, Area, Tj, Tnom);
   Iclra = diode(vbci,XCjc*Jsr,Vgr,nr,Area,Tj,Tnom);
   // Early-Effect borrowed from VBIC
   if((VAF >0.0) && (VAR >0.0)) begin
        q1 = (1.0 + (charge(vbei, 1.0, Vje, mje, 1.0) -
                     charge(0.0,1.0,Vje,mje,1.0))/VAR +
                    (charge(vbci,1.0,Vjc,mjc,1.0)-
                     charge(0.0,1.0,Vjc,mjc,1.0))/VAF);
465
   end
   else if((VAF > 0.0) && (VAR == 0.0)) begin
       q1 = (1.0 + (charge(vbci, 1.0, Vjc, mjc, 1.0) -
                     charge(0.0,1.0,Vjc,mjc,1.0))/VAF);
   end
   else if((VAF ==0.0) && (VAR > 0.0)) begin
       q1 = (1.0 + (charge(vbei, 1.0, Vje, mje, 1.0) -
                     charge(0.0,1.0,Vje,mje,1.0))/VAR);
   end
   else begin
       q1 = 1.0;
475
   // Webster Effect borrowed from VBIC
   if((IKF > 0.0) && (IKR > 0.0)) begin
       q2 = Ic0a/(Area*IKF) + Ic1ra/(Area*IKR);
   end
   else if((IKF > 0.0) && (IKR == 0.0)) begin
       q2 = Ic0a/(Area*IKF);
   else if((IKF == 0.0) && (IKR > 0.0)) begin
       q2 = Ic1ra/(Area*IKR);
   end
   else begin
```

```
q2 = 0.0;
    end
    qb = (q1 + sqrt((q1*q1) + 4.0 * q2))/2.0;
    Ic0 = Ic0a/qb;
   Ic1r= Ic1ra/qb;
495
    Ic1 = (Ic0 - Ic1r);
    Ib2 = diode(vbci, XCjc*Jsr, Vgr, nr, Area, Tj, Tnom) / (Br);
    Ibx = diode(vbcx,(1.0-XCjc)*Jsr,Vgr,nr,Area,Tj,Tnom)/(Br);
    // Base Currents
    epsi = 1.0e-6;
    Vbclin = BVceo * pow(1.0 - epsi , 1/Mc);
   mm = MM(vbci, BVceo, Mc, Vbclin, Bf, kc);
    if(mm >1.0) begin
        if(kBeta > 0.0) begin
            if((Bf - kBeta*Tex) > 1e-6) begin
510
                EdBeta = (1/(Bf - kBeta*Tex) -
                          kc*(mm - 1)) / (kc*(mm - 1) + 1);
            end
            else begin
                EdBeta = (1e6 - kc*(mm - 1))/(kc*(mm - 1)+1);
515
            end
        end
        else begin
            EdBeta = (1/(Bf) - kc*(mm - 1))/(kc*(mm - 1)+1);
520
    end
    else begin
        if(kBeta > 0.0) begin
            if((Bf - kBeta*Tex) > 1e-6) begin
                EdBeta = (1/(Bf - kBeta*Tex));
525
            end
            else begin
                EdBeta = (1e6);
            end
530
        end
        else begin
            EdBeta = (1/(Bf));
        end
    end
535
    Ib0 = Ic0a * EdBeta;
    // no Break-Down
    if (BVebo>0) begin
        Ib1 = Ib0 -
540
            diode((-BVebo - vbei), Jsf, 0.0, 1.0, Area, 0.0, 0.0);
    end else
        Ib1 = Ib0;
   // Emitter Currents
    if((Jse>0.0) && (ne>0))
        Ibdx = diode(vxe,Jse,Vgb,ne,Area,Tj,Tnom);
    else
        Ibdx = vxe*1e-12;
    if((Jsee>0.0) && (nee>0))
```

```
Ibdxx = diode(vxxe,Jsee,Vgbb,nee,Area,Tj,Tnom);
    else
        Ibdxx = vxxe*1e-12;
    if((Jsc>0.0) && (nc>0))
       Icdx = diode(vxc,Jsc,Vgc,nc,Area,Tj,Tnom);
    else
        Icdx = vxc * 1e-12;
560
    // Dissipated Power
    Ipdiss = (Ic1 * (vcei)) + (Ib1 * (vbei)) +
             (Ib2 * vbci) + (Ibx * vbcx);
   if (Ipdiss < 0.0)
        Ipdiss = 0;
    // Nonlinear Part --- Charge Sources
   //
    // qb2med: Base-Collector-Capacitance at medium currents
    I00=(J0*Area);
    // qb2med: Base-Collector-Capacitance at medium currents
    if ((XCjc < 1.0) && (XCjc > 0.0)) begin
        if ((J0<=0.0) | (Ic0<0.0)) begin</pre>
            // Qbc independent of current C = Cjc
            qb2med = XCjc * charge(vbci,(Cjc-Cmin),Vjc,mjc,Area) +
580
                XCjc * Area * Cmin * vbci;
        end
        else begin
            // C = (1-(2 Ic/I0)/(1+(Ic0/Ia00)^2))*Cjc
585
                xix = Ic0/I00;
                qb2med = XCjc * (1.0 - tanh(xix)) *
                    (charge(vbci,(Cjc-Cmin),Vjc,mjc,Area) +
                     (1.0-XJ0) * Area * Cmin*vbci) +
590
                     XJ0 * XCjc * Area * Cmin*vbci;
        end
    end
    else begin
        // if XCjc not within (0,1), sets extrinsic capacitance to zero
        if ((J0<0.0) | (Ic0<0.0)) begin
            // Qbc independent of current C = Cjc
            qb2med = charge(vbci,(Cjc-Cmin),Vjc,mjc,Area) +
                Area * Cmin*vbci;
        end
600
        else begin
            // C = (1-(2 Ic/I0)/(1+(Ic0/Ia00)^2))*Cjc
                xix = Ic0/I00;
605
                qb2med = (1.0 - tanh(xix)) *
                    (charge(vbci,(Cjc-Cmin),Vjc,mjc,Area) +
                    (1.0 - XJ0)*Area * Cmin*vbci) +
                    XJ0*Area * Cmin*vbci;
610
         end
    end
    // qb1: Cex
```

```
if ((XCjc < 1.0) && (XCjc > 0.0)) begin
        qb1 = (1.0-XCjc) * charge(vbcx,(Cjc-Cmin),Vjc,mjc,Area) +
           (1.0-XCjc) * Area * Cmin* vbcx;
    end
    else begin
      qb1 = 0.0;
    end
    // qbtr: Tfr*Ic
      gbtr = Tr * Ic1r;
       qbtra = Trx * Ibx;
    // qb2: Cbc
    qb2 = qb2med + qbtr;
630 // Base push-out borrowed from HICUM
    if ((Jk > 0.0) \&\& (Rci0 > 0.0)) begin
       if (RJk > 0.0) begin
         Vlim = Jk * Rci0 / (1.0 - Rci0/RJk);
         InvVpt = (1.0 - Rci0/RJk)/(Jk*RJk);
635
       else begin
         Vlim = Jk * Rci0 / (1.016);
          InvVpt = 0.0;
640
       end
    end
    if ((Thcs>0.0) && (Ahc>0.0) && (Jk>0.0) && (Ic0>0.0)) begin
       RCIO = Rci0/Area;
       AHC = Area*Ahc;
645
        if ((Rci0<RJk) | (RJk <= 0.0))
                  = 1.0 - ICK(vcei, RCIO, Vlim, InvVpt, Vces)/Ic0;
           end
650
        else
          begin
            Ih = 1.0 - Vceff(vcei,Vces)/(RCIO*Ic0);
          end
        Wh = ((Ih + sqrt((Ih*Ih)+AHC)))/(1.0 + sqrt(1.0+AHC));
       xtff = Thcs * Ic0 *(Wh*Wh);
655
    end
    else begin
      xtff = 0;
    end
660
    // diffusion capacitance
    qbtf = (Tf + Tft * Tex) * Ic0;
   // total capacitance
gbe = xtff + qbtf + charge(vbei, Cje, Vje, mje, Area);
    // Deliver Branch currents
    //
    // nonlinear part
    I(bi, ci) <+ Ibx + ddt(qb1 + qbtra);</pre>
   I(bii,ci) <+ Ib2 + ddt(qb2);
    I(bii,ei) <+ Ib1 + ddt(qbe);</pre>
675 I(ci, ei) <+ Ic1;
    I(ex ,ei) <+ Ibdx;</pre>
```

```
I(exx,ei) <+ Ibdxx;</pre>
    I(cx ,ci) <+ Icdx;</pre>
    // shot noise
    I(bii,ei) <+ white_noise( (TWO_Q *Ib1), "Ib");</pre>
             <+ V(ni) + white_noise( (TWO_Q *Ic0), "Ic");</pre>
    I(ni)
              // collector noise; dummy node to generate correlation
   I(bii,ei) <+ V(ni);</pre>
    I(bii,ci) <+ (-absdelay(V(ni),Tf));</pre>
    // low-frequency noise
    I(e, ei) <+ flicker_noise(Kfe* pow(Ib1,Afe) , Ffee,</pre>
                               "Hooge_noise_of_emitter_resistance");
              <+ V(nii) + ddt(V(nii)/(2.0*3.1415*Fb)) +
    I(nii)
                 white_noise( Kb*pow(Ib1,Ab));
                 // be-noise; dummy node to generate Lorentz spectrum
    I(bii,ei) <+ V(nii) + flicker_noise(Kfb* pow(Ib1,Afb) , Ffeb,</pre>
                            "Flicker noise base-emitter junction (a)");
    // linear part
    I(b, bi) <+ V(b, bi)/(Rb/N) +
                 white_noise( (FOUR_K*TjK)/(Rb/N), "thermal") ;
700 I(e, ei) <+ V(e, ei)/(Re/N) +
                 white_noise( (FOUR_K*TjK)/(Re/N), "thermal") ;
    I(c, ci) \leftarrow V(c, ci)/(Rc/N) +
                 white_noise( (FOUR_K*TjK)/(Rc/N), "thermal");
    I(bii,bi) <+ V(bii, bi)/(Rb2/N)+</pre>
                  white_noise( (FOUR_K*TjK)/(Rb2/N), "thermal");
705
    if((Jse>0.0) && (ne>0)) begin
       I(ex, bii) <+ V(ex, bii)/(Rbxx/N) +
                      white_noise( (FOUR_K*TjK)/(Rbxx/N), "thermal");
710 end
    else begin
      I(ex, bii) <+ V(ex, bii)*1e-12;
   if((Jsee>0.0) && (nee>0)) begin
      I(exx,bii) <+ V(exx, bii)/(Rbbxx/N) +</pre>
                      white_noise( (FOUR_K*TjK)/(Rbbxx/N), "thermal");
    else begin
     I(exx, bii) <+ V(exx, bii)*1e-12;
    if((Jsc>0.0) && (nc>0)) begin
      I(cx, bii) <+ V(cx, bii)/(Rcxx/N) +
                      white_noise( (FOUR_K*TjK)/(Rcxx/N), "thermal");
725
    end
    else begin
      I(cx, bii) <+ V(cx, bii)*1e-12;
    I(b)
         <+ ddt(Cpb * V(b));
    I(c)
         <+ ddt(Cpc * V(c));
    I(b,c) \leftarrow ddt(Cq * V(b,c));
735 I(ti) <+ -Ipdiss;
    if (Rth) begin
        I(t,ti) <+ V(t,ti) / Rth;
        I(t,ti) \leftarrow Cth * ddt(V(t,ti));
    end
740 else begin
```

```
I(t,ti) <+ V(t,ti) * 1e12;
end

end

745//
    // end of model equations
    //</pre>
```

endmodule