Listing of the FBH HBT Model

Matthias Rudolph

Ferdinand-Braun-Institut für Höchstfrequenztechnik (FBH), Gustav-Kirchhoff-Str. 4, D-12489 Berlin, Germany rudolph@fbh-berlin.de, http://www.fbh-berlin.de/modeling.html

ver 2.3.20070711

```
FBH_HBT model version 2.3.20070111
   Copyright (C) 2007 Ferdinand-Braun-Institut
               im Forschungsverbund Berlin (FBH)
               Gustav-Kirchhoff-Str. 4
               D-12489 Berlin
   All rights reserved.
   By downloading this code, you agree that FBH shall not be held
   to any liability with respect to any claim by you or from any
   third party arising from or on account of the use of this code,
   regardless of the form of action, including negligence. In no event
15 will FBH be liable for consequential or incidental damages of
   any nature whatsoever.
   Model documentation:
      www.fbh-berlin.de/modeling.html
      rudolph@fbh-berlin.de
 'include "disciplines.vams"
25 'include "constants.vams"
 'define STDTEMP
                    20.0
                    0.861708692e-4
 'define KDURCHQ
30 'define FOUR_K
                    (4 * 1.3806226e-23)
                    (2 * 1.6021918e-19)
 'define TWO_Q
 'define sqr(x) (x*x)
35// begin of FBH HBT model
 module HBT_X(c,b,e,t);
 //external nodes
 inout e,b,c,t;
40 electrical e,b,c;
 thermal t;
 //internal nodes
 electrical ei, bi, bii, biii, ci, ex, exx, cx, nii,\
            niix, niiy, niii, niiix, niiiy,\
            niia, niib, niiia, niiib, niv, nivx, nivy, niva, nivb, gnd;
 thermal ti;
```

```
ground gnd;
50//model parameters
 parameter integer Mode = 1 from [0:4];
 // Ignored
 parameter integer Noise = 1 from [0:4];
 // Ignored
55parameter integer Debug = 0 from [0:inf);
 // Ignored
 parameter integer DebugPlus = 0 from [0:inf);
 // Ignored
60 parameter real Temp = 25.0
                             from [-273.15:inf);
 // Device operating temperature, Celsius
 parameter real Rth = 0.1 from [0.0:inf);
 // Thermal resistance, K/W
 parameter real Cth = 700n
                            from [0.0:inf);
65// Thermal capacitance
 // Scaling factor, number of emitter fingers
 parameter real L = 30u from (0.0:inf);
70// Length of emitter finger, m
 parameter real W = 3u from (0.0:inf);
 // Width of emitter finger, m
 parameter real Jsf = 20e-24 from [0.0:inf);
75// Forward saturation current density, A/um^2
 parameter real nf = 1.0 from [0.0:inf);
 // Forward current emission coefficient
 parameter real Vg = 1.3
                          from [-2.0:inf);
 // Forward thermal activation energy, V,
80// (0 == disables temperature dependence)
 parameter real Jse = 0.0 from [0.0:inf);
 // B-E leakage saturation current density, A/um^2
 parameter real ne = 0.0 from [0.0:inf);
85// B-E leakage emission coefficient
 // Limiting resistor of B-E leakage diode, Ohm
 parameter real Vgb = 0.0 from [0.0:inf);
 // B-E leakage thermal activation energy, V,
90// (0 == disables temperature dependence)
 parameter real Jsee = 0.0
                           from [0.0:inf);
 // 2nd B-E leakage saturation current density, A/um^2
 parameter real nee = 0.0 from [0.0:inf);
95// 2nd B-E leakage emission coefficient
 parameter real Rbbxx= 1e6 from (0.0:inf);
 // 2nd Limiting resistor of B-E leakage diode, Ohm
 parameter real Vgbb = 0.0 from [0.0:inf);
 // 2nd B-E leakage thermal activation energy, V,
100// (0 == disables temperature dependence)
 parameter real Jsr = 20e-18 from [0.0:inf);
 // Reverse saturation current density, A/um^2
 parameter real nr = 1.0 from [0.0:inf);
105// Reverse current emission coefficient
 parameter real Vgr = 0.0 from [0.0:inf);
 // Reverse thermal activation energy, V, (0 == disables temperature dependence)
 parameter real XCjc = 0.5 from [0.0:1.0);
 // Fraction of Cjc that goes to internal base node
```

```
parameter real Jsc = 0.0
                           from [0.0:inf);
 // B-C leakage saturation current density, A/um^2 (0. switches off diode)
 parameter real nc = 0.0 from [0.0:inf);
 // B-C leakage emission coefficient (0. switches off diode)
115parameter real Rcxx = 1e6 from (0.0:inf);
 // Limiting resistor of B-C leakage diode, Ohm
 parameter real Vgc = 0.0 from [0.0:inf);
 // B-C leakage thermal activation energy, V,
 // (0 == disables temperature dependence)
 parameter real Bf = 100.0 from [0.0:inf);
 // Ideal forward beta
 parameter real kBeta= 0.0 from [0.0:inf);
 // Temperature coefficient of forward current gain, -1/K,
125// (0 == disables temperature dependence)
 parameter real Br = 1.0
                         from [0.0:inf);
 // Ideal reverse beta
 parameter real VAF = 0.0 from [0.0:inf);
130// Forward Early voltage, V, (0 == disables Early Effect)
 parameter real VAR = 0.0 from [0.0:inf);
 // Reverse Early voltage, V, (0 == disables Early Effect)
 parameter real IKF = 0.0
                           from [0.0:inf);
195// Forward high-injection knee current, A, (0 == disables Webster Effect)
 parameter real IKR = 0.0 from [0.0:inf);
 // Reverse high-injection knee current, A, (0 == disables Webster Effect)
 parameter real Mc = 0.0 from [0.0:inf);
140// C-E breakdown exponent, (0 == disables collector break-down)
 parameter real BVceo= 0.0 from [0.0:inf);
 // C-E breakdown voltage, V, (0 == disables collector break-down)
 parameter real kc = 0.0 from [0.0:inf);
 // C-E breakdown factor, (0 == disables collector break-down)
 parameter real BVebo= 0.0 from [0.0:inf);
 // B-E breakdown voltage, V, (0 == disables emitter break-down)
 parameter real Tr = 1f
                          from [0.0:inf);
150// Ideal reverse transit time, s
 parameter real Trx = 1f from [0.0:inf);
 // Extrinsic BC diffusion capacitance, s
 // Ideal forward transit time, s
155 parameter real Tft = 0.0 from [0.0:inf);
 // Temperature coefficient of forward transit time
 parameter real Thcs = 0.0 from [0.0:inf);
 // Excess transit time coefficient at base push-out
 parameter real Ahc = 0.0 from [0.0:inf);
160// Smoothing parameter for Thcs
 parameter real Cje = 1f
                           from [0.0:inf);
 // B-E zero-bias depletion capacitance, F/um^2
 parameter real mje = 0.5 from [0.0:1);
165// B-E junction exponential factor
 parameter real Vje = 1.3 from [0.0:inf);
 // B-E junction built-in potential, V
 parameter real kje = 1.0 from [0.0:1.0];
 // Qbe charge partitioning.
 parameter real Cjc = 1f
                           from [0.0:inf);
 // B-C zero-bias depletion capacitance, F/um^2
 parameter real mjc = 0.5
                          from [0.0:inf);
```

```
// B-C junction exponential factor
175 parameter real Vjc = 1.3 from [0.0:inf);
 // B-C junction built-in potential, V
 parameter real Cmin = 0.1f from [0.0:inf);
 // Minimum B-C depletion capacitance (Vbc dependence), F/um^2
 parameter real kjc = 1.0 from [0.0:1.0];
180// Qbc charge partitioning.
 parameter real J0 = 1e-3 from [0.0:inf);
 // Collector current where Cbc reaches Cmin, A/um^2 (0 == disables Cbc reduction)
 185// Fraction of Cmin, lower limit of BC capacitance (Ic dependence)
 parameter real Rci0 = 1e-3 from (0.0:inf);
 // Onset of base push-out at low voltages, Ohm*um^2 (0 == disables base push-out)
 parameter real Jk = 4e-4 from [0.0:inf);
 // Onset of base push-out at high voltages, A/um^2, (0 == disables base push-out)
190 parameter real RJk = 1e-3 from [0.0:inf);
 // Slope of Jk at high currents , Ohm*um^2
 parameter real Vces = 1e-3 from [0.0:inf);
 // Voltage shift of base push-out onset, V
195 parameter real Rc = 1.0
                           from (0.0:inf);
 // Collector resistance, Ohm/finger
 parameter real Re = 1.0
                         from (0.0:inf);
 // Emitter resistance, Ohm/finger
 parameter real Rb = 1.0 from (0.0:inf);
200// Extrinsic base resistance, Ohm/finger
 parameter real Rb2 = 1.0 from (0.0:inf);
 // Inner Base ohmic resistance, Ohm/finger
 parameter real Lc = 0.0
                         from [0.0:inf);
205// Collector inductance, H
 parameter real Le = 0.0
                           from [0.0:inf);
 // Emitter inductance, H
 parameter real Lb = 0.0 from [0.0:inf);
 // Base inductance, H
 parameter real Cq = 0.0
                         from [0.0:inf);
 // Extrinsic B-C capacitance, F
 parameter real Cpb = 0.0 from [0.0:inf);
 // Extrinsic base capacitance, F
215 parameter real Cpc = 0.0
                          from [0.0:inf);
 // Extrinsic collector capacitance, F
 parameter real Kfb = 0.0
                            from [0.0:inf);
 // Flicker-noise coefficient
220 parameter real Afb = 0.0
                           from [0.0:inf);
 // Flicker-noise exponent
 parameter real Ffeb = 0.0
                            from [0.0:inf);
 // Flicker-noise frequency exponent
 parameter real Kb = 0.0 from [0.0:inf);
225// Burst noise coefficient
 parameter real Ab = 0.0
                           from [0.0:inf);
 // Burst noise exponent
 parameter real Fb = 0.0
                           from (0.0:inf);
 // Burst noise corner frequency, Hz
230 parameter real Kfe = 0.0
                            from [0.0:inf);
 // Flicker-noise coefficient
 parameter real Afe = 0.0 from [0.0:inf);
 // Flicker-noise exponent
 parameter real Ffee = 0.0
                           from [0.0:inf);
235// Flicker-noise frequency exponent
```

```
parameter real Tnom = 20.0
                               from [-273.15:inf);
  // Ambient temperature at which the parameters were determined
 parameter real Fcorr = 1e6 from [0.0:inf);
240// Corner frequency for LF noise correlation
 parameter real LFc = 1.0
                             from [0.0:1];
 // Correlation coefficient for LF noise sources
245// general functions
 //
  // safe exponential function
 analog function real exp_soft;
      input x;
     real x, maxexp, maxarg;
     begin
          maxexp = 1.0e25;
          maxarg = ln(maxexp);
          if (x < maxarg) begin</pre>
255
              exp\_soft = exp(x);
          end
          else begin
              exp\_soft = (x+1.0-maxarg)*(maxexp);
          end
      end
 endfunction
  // limited internal Voltage
265 analog function real Vt;
      input U, Ud;
      real U, Ud, Vch, VF;
         Vch = 0.1 * Ud;
         VF = 0.9 * Ud; // we fix this value for simplicity.
270
         if (U < VF)
              Vt = U - Vch * ln(1.0 + exp((U-VF)/Vch));
         else
             Vt = VF - Vch * ln(1.0 + exp((VF-U)/Vch));
275
      end
  endfunction
  // diode function
280 analog function real diode;
      input U, Is, Ug, N, AREA, TJ, TNOM;
      real U, Is, Ug, N, AREA, TJ, TNOM, VTHO, VTHJ, VTHNOM,\
           maxi, Tmax, TJM, KDURCHQ, lnIs;
     begin
285
          VTH0=$vt(20.0+273.15);
          VTHNOM=$vt(TNOM+273.15);
          KDURCHQ = 0.861708692e-4;
          lnIs=ln(Is*AREA);
          maxi=ln(1e6);
          if ((maxi<(Ug/VTHNOM)) && (U < 0.0))</pre>
                Tmax= Ug*VTHNOM/((Ug - maxi*VTHNOM)*KDURCHQ) - 273.15;
                TJM=Vt(TJ,Tmax);
295
             end
          else
             begin
                TJM=TJ;
```

```
end
300
          VTHJ = vt(TJM+273.15);
          if (Ug > 0.0) begin
               diode = exp_soft(U/(N*VTHJ) + Ug/VTHNOM - Ug/VTHJ + lnIs) -
                       exp_soft(Ug/VTHNOM - Ug/VTHJ + lnIs);
305
          end
          else begin
              diode = exp_soft(U/(N*(VTH0)) + lnIs) - Is*AREA;
      end
  endfunction
 // CE-breakdown function
 analog function real MM;
      input VBCI, VCBO, MC, VCBLIN, BF, KC;
      real VBCI, VCBO, MC, VCBLIN, BF, KC;
      real FBD, vcbi;
      begin
          if((KC > 0.0) && (MC > 0.0) && (VCBO > 0.0)) begin
              vcbi = VBCI;
              FBD = VCBLIN/VCBO;
              if(VBCI > 0.0)
                  MM = 1.0;
              else if(VBCI > (-VCBLIN)) begin
325
                  if (MC==1)
                      MM = 1.0/(1.0 - (vcbi/(-VCBO)));
                  else
                      MM = 1.0/(1.0 - pow(vcbi/(-VCBO), MC));
330
              end
              else if(VBCI <= (-VCBLIN)) begin</pre>
                  if (MC==1) begin
                      MM = 1.0/(1.0 - FBD) - 1.0/VCBO *
                          1.0/pow(1.0 - FBD, 2.0) * (vcbi + FBD*VCBO);
335
                  end
                  else begin
                      MM = 1.0/(1.0 - pow(FBD,MC)) - MC/VCBO *
                          pow(FBD,MC-1.0)/pow(1.0 -
                          pow(FBD,MC),2.0) * (vcbi + FBD*VCBO);
                  end
340
              end
          end
          else
              MM = 1.0;
      end
 endfunction
  // Depletion Charge
350 analog function real charge;
       input U, C0, Ud, m, Area;
       real U, CO, Ud, m, Area, Vj, Vjo, VF;
       begin
          Vj = Vt(U,Ud);
355
          Vjo = Vt(0.0,Ud);
          VF = 0.9 * Ud; // we fix this value for simplicity.
          if(m==1.0) begin
              charge = Area*(C0)*
                     ( Ud*( ln(1.0 - Vjo/Ud) -
360
                             ln(1.0 - Vj/Ud)
```

```
1.0/(1.0 - VF/Ud) * (U - Vj + Vjo));
           end
365
           else begin
            charge = Area*(C0)*
                   ((Ud/(1.0-m))*(pow(1.0 - Vjo/Ud, 1.0-m) -
                                     pow(1.0 - Vj/Ud , 1.0-m)
                     pow(1.0 - VF/Ud, -m) * (U - Vj + Vjo) -
370
                     Ud*(1.0/(1.0-m)));
           end
        end
    endfunction
375
  // limited internal Voltage
  analog function real Vceff;
       input U, VCES;
       real U, VCES, Vth0;
       begin
          Vth0 = 0.025;
          if (U < VCES)</pre>
             \label{eq:Vceff}  \mbox{Vceff = Vth0 + Vth0 * ln(1.0 + exp((U-VCES)/Vth0 - 1.0));} 
385
             Vceff = (U-VCES) + Vth0 * ln(1.0 + exp(1.0-(U-VCES)/Vth0));
       end
  endfunction
 // Current for Onset of Kirk effect
  analog function real ICK;
      input U, RCIO, VLIM, InvVPT, VCES;
      real U, RCIO, VLIM, InvVPT, VCES, VC, x;
      begin
         VC = Vceff(U,VCES);
         x = (VC - VLIM)*InvVPT;
         ICK = VC/RCIO * (1.0/sqrt(1.0 + (VC/VLIM)*(VC/VLIM)))*
                         (1.0 + (x + sqrt((x*x)+0.001))/2.0);
      end
400
  endfunction
405//local variables
 real vbcx, vbci, vbei, vbeii, vxe, vxxe, vxc, vcei;
 real Ic0, Ic0cbc, Ic, Ic1, Ic1r, Ib2, Ibx,
       Ib0, Ibdx, Icdx, Ibdxx, Ib1, Ic0a, Ic0acbc, Ic1ra,
       Ipdiss, Ik, eps, IcIk;
410 real qb2, qb2be;
 real qb2x, qb2med, qb2medbe, qb1, xtff, xtffcbc, qbe, qbtr,
      qbtra, qbtf, qbtfcbc;
 real EdBeta, mm;
 real epsi, Vbclin;
415 real Texi, Tex, Tj, TjK, Area;
 real RCIO, AHC, Ih, Wh, Ihebe, Whebe, Vlim, InvVpt, q1, q2, qb, I00;
 real xix, xixbe;
 real FOUR_K,TWO_Q, Iniix, Iniix, Inivx;
 real Kboltz, Qelectron;
  // linearization boundary for CE-breakdown
425 analog begin
```

```
// begin of model equations
      //
      // Port Voltages
430
      vbcx = V(bi,ci);
      vbci = V(bii,ci);
      vbei = V(bii,ei);
      vbeii= V(biii,ei);
      vxe = V(ex,ei);
435
      vxc = V(cx,ci);
      vxxe = V(exx,ei);
      vcei = V(ci,ei);
      Texi = Temp(ti);
440
      Tj = Texi + Temp;
                          // Junction temperature
      TjK = Tj+273.15;
                         // Junction temperature in K
                           // Temperature difference to reference
      Tex = Tj - Tnom;
      Area = L*W*(1.0e12) * N;
                                      // Emitter area in um^2
445
     FOUR_K = 4 * 1.3806226e-23; // 4 k for noise TWO_Q = 2 * 1.6021918e-19; // 2 q for noise Kboltz = 1.3806226e-23; // k for noise
      Qelectron = 1.6021918e-19; // q for noise
450
      //
      // Nonlinear Part --- Current Sources
      //
      // Collector Currents
455
      Ic0a = diode(vbeii, Jsf, Vg, nf, Area, Tj, Tnom);
      IcOacbc = diode(vbei,Jsf,Vg,nf,Area,Tj,Tnom); // for Cbc-calculation only
460
      Iclra = diode(vbci,XCjc*Jsr,Vgr,nr,Area,Tj,Tnom);
      // Early-Effect borrowed from VBIC
      if((VAF >0.0) && (VAR >0.0)) begin
          q1 = (1.0 + (charge(vbeii, 1.0, Vje, mje, 1.0) -
                        charge(0.0,1.0,Vje,mje,1.0))/VAR +
465
                        (charge(vbci,1.0,Vjc,mjc,1.0)-
                        charge(0.0,1.0,Vjc,mjc,1.0))/VAF);
      else if((VAF > 0.0) && (VAR == 0.0)) begin
470
          q1 = (1.0 + (charge(vbci, 1.0, Vjc, mjc, 1.0) -
                        charge(0.0,1.0,Vjc,mjc,1.0))/VAF);
      else if((VAF ==0.0) && (VAR > 0.0)) begin
          q1 = (1.0 + (charge(vbeii, 1.0, Vje, mje, 1.0) -
                        charge(0.0,1.0,Vje,mje,1.0))/VAR);
475
      end
      else begin
          q1 = 1.0;
      end
      // Webster Effect borrowed from VBIC
      if((IKF > 0.0) && (IKR > 0.0)) begin
          q2 = Ic0a/(Area*IKF) + Ic1ra/(Area*IKR);
      end
      else if((IKF > 0.0) && (IKR == 0.0)) begin
485
          q2 = Ic0a/(Area*IKF);
      end
      else if((IKF == 0.0) && (IKR > 0.0)) begin
```

```
q2 = Ic1ra/(Area*IKR);
      end
490
      else begin
         q2 = 0.0;
      end
      qb = (q1 + sqrt((q1*q1) + 4.0 * q2))/2.0;
495
      Ic0
            = Ic0a/qb;
      IcOcbc = IcOacbc/qb; // for Cbc-calculation only
      Iclr = Iclra/qb;
      Ic1
            = (Ic0 - Ic1r);
      Ib2 = diode(vbci,XCjc*Jsr,Vgr,nr,Area,Tj,Tnom)/(Br);
      Ibx = diode(vbcx,(1.0-XCjc)*Jsr,Vgr,nr,Area,Tj,Tnom)/(Br);
      // Base Currents
505
      epsi = 1.0e-6;
      Vbclin = BVceo * pow(1.0 - epsi , 1/Mc);
     mm = MM(vbci, BVceo, Mc, Vbclin, Bf, kc);
510
      if(mm >1.0) begin
          if(kBeta > 0.0) begin
              if((Bf - kBeta*Tex) > 1e-6) begin
                  EdBeta = (1/(Bf - kBeta*Tex) - kc*(mm - 1)) / (kc*(mm - 1) + 1);
515
              else begin
                  EdBeta = (1e6 - kc*(mm - 1))/(kc*(mm - 1)+1);
              end
          end
520
          else begin
              EdBeta = (1/(Bf) - kc*(mm - 1))/(kc*(mm - 1)+1);
          end
      end
      else begin
525
          if(kBeta > 0.0) begin
              if((Bf - kBeta*Tex) > 1e-6) begin
                  EdBeta = (1/(Bf - kBeta*Tex));
              end
530
              else begin
                  EdBeta = (1e6);
              end
          end
          else begin
535
              EdBeta = (1/(Bf));
          end
      end
      Ib0 = Ic0a * EdBeta;
540
      // no Break-Down
      if (BVebo>0) begin
          Ib1 = Ib0 -
              diode((-BVebo - vbeii), Jsf, 0.0, 1.0, Area, 0.0, 0.0);
545
      end else
          Ib1 = Ib0;
      // Emitter Currents
      if((Jse>0.0) && (ne>0))
          Ibdx = diode(vxe,Jse,Vgb,ne,Area,Tj,Tnom);
550
      else
```

```
Ibdx = vxe*1e-12;
      if((Jsee>0.0) && (nee>0))
555
          Ibdxx = diode(vxxe, Jsee, Vgbb, nee, Area, Tj, Tnom);
      else
          Ibdxx = vxxe*1e-12;
      if((Jsc>0.0) && (nc>0))
          Icdx = diode(vxc,Jsc,Vgc,nc,Area,Tj,Tnom);
560
          Icdx = vxc * 1e-12;
      // Dissipated Power
      Ipdiss = (Ic1 * (vcei)) + (Ib1 * (vbeii)) + (Ib2 * vbci) + (Ibx * vbcx);
      if (Ipdiss < 0.0)
          Ipdiss = 0;
570
      //
      // Nonlinear Part --- Charge Sources
      //
      // qb2med: Base-Collector-Capacitance at medium currents
575
      I00=(J0*Area);
      // qb2med: Base-Collector-Capacitance at medium currents
      if ((XCjc < 1.0) && (XCjc > 0.0)) begin
          if ((J0<=0.0) | (Ic0<0.0)) begin</pre>
580
              // Qbc independent of current C = Cjc
              qb2med = XCjc * charge(vbci,(Cjc-Cmin),Vjc,mjc,Area) +
                  XCjc * Area * Cmin * vbci;
              qb2medbe = qb2med;
          end
585
          else begin
              // C = (1-(2 Ic/I0)/(1+(Ic0/Ia00)^2))*Cjc
                  xix = Ic0/I00;
                  xixbe = Ic0cbc/I00;
590
                   qb2med = XCjc * (1.0 - tanh(xix)) *
                       (charge(vbci,(Cjc-Cmin),Vjc,mjc,Area) +
                        (1.0-XJ0) * Area * Cmin*vbci) +
                  XJ0 * XCjc * Area * Cmin*vbci;
qb2medbe = XCjc * (1.0 - tanh( xixbe )) *
595
                       (charge(vbci,(Cjc-Cmin),Vjc,mjc,Area) +
                        (1.0-XJ0) * Area * Cmin*vbci) +
                        XJ0 * XCjc * Area * Cmin*vbci;
600
          end
      end
      else begin
          // if XCjc not within (0,1), sets extrinsic capacitance to zero
          if ((J0<0.0) | | (Ic0<0.0)) begin
              // Qbc independent of current C = Cjc
              qb2med = charge(vbci,(Cjc-Cmin),Vjc,mjc,Area) +
                  Area * Cmin*vbci;
              qb2medbe = qb2med;
          end
          else begin
610
              // C = (1-(2 Ic/I0)/(1+(Ic0/Ia00)^2))*Cjc
                  xix = Ic0/I00;
                  xixbe = Ic0cbc/I00;
```

```
615
                  qb2med = (1.0 - tanh(xix)) *
                      (charge(vbci,(Cjc-Cmin),Vjc,mjc,Area) +
                      (1.0 - XJ0)*Area * Cmin*vbci) +
                      XJ0*Area * Cmin*vbci;
                  qb2medbe = (1.0 - tanh(xixbe)) *
620
                      (charge(vbci,(Cjc-Cmin),Vjc,mjc,Area) +
                      (1.0 - XJ0)*Area * Cmin*vbci) +
                      XJ0*Area * Cmin*vbci;
          end
625
     end
     // qb1: Cex
     if ((XCjc < 1.0) && (XCjc > 0.0)) begin
         qb1 = (1.0-XCjc) * charge(vbcx,(Cjc-Cmin),Vjc,mjc,Area) +
630
              (1.0-XCjc) * Area * Cmin* vbcx;
     end
     else begin
         qb1 = 0.0;
      end
635
     // qbtr: Tfr*Ic
        qbtr = Tr * Ic1r;
        qbtra = Trx * Ibx;
640
     // qb2: Cbc
     ab2 =
                   kjc * qb2med + qbtr;
     qb2be = (1.0-kjc) * qb2medbe;
645
     // Base push-out borrowed from HICUM
     if ((Jk > 0.0) && (Rci0 > 0.0)) begin
        if (RJk > 0.0) begin
          Vlim = Jk * Rci0 / (1.0 - Rci0/RJk);
           InvVpt = (1.0 - Rci0/RJk)/(Jk*RJk);
650
         end
        else begin
           Vlim = Jk * Rci0 / (1.016);
            InvVpt = 0.0;
         end
655
      end
      if ((Thcs>0.0) && (Ahc>0.0) && (Jk>0.0) && (Ic0>0.0)) begin
         RCIO = Rci0/Area;
          AHC = Area*Ahc;
660
          if ((Rci0<RJk) || (RJk <= 0.0))</pre>
            begin
                  = 1.0 - ICK(vcei, RCIO, Vlim, InvVpt, Vces)/IcOcbc;
               Ihcbc= 1.0 - ICK(vcei, RCIO, Vlim, InvVpt, Vces)/Ic0;
             end
665
          else
                   = 1.0 - Vceff(vcei, Vces)/(RCIO*Ic0cbc);
               Ihcbc= 1.0 - Vceff(vcei,Vces)/(RCIO*Ic0);
670
             end
                 = ((Ihcbc + sqrt((Ihcbc*Ihcbc)+AHC)))/(1.0 + sqrt(1.0+AHC));
         Whcbc
                 = ((Ih + sqrt((Ih*Ih)+AHC)))/(1.0 + sqrt(1.0+AHC));
                 = kje * Thcs * IcOcbc *(Wh*Wh);
         xtffcbc = (1.0-kje) * Thcs * Ic0 *(Whcbc*Whcbc);
     end
675
     else begin
        xtff = 0;
```

```
xtffcbc = 0;
      end
680
      // diffusion capacitance
      qbtf = kje * (Tf + Tft * Tex) * Ic0cbc;
      qbtfcbc = (1.0-kje) * (Tf + Tft * Tex) * Ic0;
      // total capacitance
685
      qbe = xtff + qbtf + charge(vbei, Cje, Vje, mje, Area);
      // Deliver Branch currents
      //
690
      // nonlinear part
      I(bi, ci) <+ Ibx + ddt(qb1 + qbtra);</pre>
      I(bii,ci)
                 <+ Ib2 + ddt(qb2) + ddt(xtffcbc) + ddt(qbtfcbc);</pre>
695
      I(bii,ei) <+ ddt(qbe) + ddt(qb2be);</pre>
      I(biii,ei) <+ Ib1;</pre>
      I(ci, ei) <+ Ic1;
      I(ex ,ei) <+ Ibdx;</pre>
      I(exx,ei) <+ Ibdxx;</pre>
      I(cx ,ci) <+ Icdx;</pre>
      // shot noise
705
      I(bii,biii) <+ V(bii,biii)*1e5;</pre>
      V(bii,biii) <+ white_noise(abs(2*(nf*Kboltz*TjK)*</pre>
                                       (nf*Kboltz*TjK)/(Qelectron*Ic1)) , "Vbe");
                  <+ white_noise(abs(TWO_Q *(Ibdx+Ibdxx+Ib0)), "Ic");</pre>
      I(bii,ci)
      // linear part
      I(bii,bi) <+ V(bii, bi)/(Rb2/N)+
                    white_noise( (FOUR_K*TjK)/(Rb2/N), "thermal");
715
      V(b,bi) \leftarrow I(b,bi)*(Rb/N) + ddt(I(b,bi)*Lb) +
                 white_noise( (FOUR_K*TjK)*(Rb/N), "thermal") ;
      V(e,ei) \leftarrow I(e,ei)*(Re/N) + ddt(I(e,ei) * Le) +
720
                 white_noise( (FOUR_K*TjK)*(Re/N), "thermal") ;
      V(c,ci) \leftarrow I(c,ci)*(Rc/N) + ddt(I(c,ci)*Lc) +
                 white_noise( (FOUR_K*TjK)*(Rc/N), "thermal") ;
      if((Jse>0.0) && (ne>0)) begin
         I(ex, bii) <+ V(ex, bii)/(Rbxx/N) +
725
                         white_noise( (FOUR_K*TjK)/(Rbxx/N), "thermal");
      end
      else begin
        I(ex, bii) <+ V(ex, bii)*1e-12;</pre>
      if((Jsee>0.0) && (nee>0)) begin
         I(exx,bii) <+ V(exx, bii)/(Rbbxx/N) +
                         white_noise( (FOUR_K*TjK)/(Rbbxx/N), "thermal");
      end
735
      else begin
         I(exx, bii) <+ V(exx, bii)*1e-12;</pre>
      if((Jsc>0.0) && (nc>0)) begin
```

```
I(cx, bii) <+ V(cx, bii)/(Rcxx/N) +
                         white_noise( (FOUR_K*TjK)/(Rcxx/N), "thermal");
      end
      else begin
       I(cx, bii) <+ V(cx, bii)*1e-12;</pre>
745
           <+ ddt(Cpb * V(b));
      I(b)
      I(c) <+ ddt(Cpc * V(c));</pre>
      I(b,c) \leftarrow ddt(Cq * V(b,c));
750
      Pwr(ti) <+ -Ipdiss;</pre>
      if (Rth) begin
          Pwr(t,ti) <+ Temp(t,ti) / Rth;</pre>
          Pwr(t,ti) <+ Cth * ddt(Temp(t,ti));</pre>
755
      end
      else begin
          Pwr(t,ti) \leftarrow Temp(t,ti) * 1e3;
760
      // low-frequency noise
      // BE Noise
      if(Ib0<=0) begin</pre>
         Iniix = 0;
         Iniiix = 0;
765
      end
      if((Ib0+Ic1)<=0) begin</pre>
         Inivx = 0;
      end
      else begin
770
         if (Ab == 2) begin
            Iniix = Ib0;
         end
         else begin
            Iniix = pow(Ib0,(Ab*0.5));
775
         end
         if (Afb == 2) begin
            Iniiix = Ib0;
         end
         else begin
780
            Iniiix = pow(Ib0,(Afb*0.5));
         if (Afe == 2) begin
            Inivx = (Ib0+Ic1);
785
         end
         else begin
            Inivx = pow((Ib0+Ic1),(Afe*0.5));
         end
      end
790
 // 1/f noise sources.
 // == Partly Correlated Cyclostationary Sources ==
           // Base-Emitter
      // correlated noise sources
      I(niib,gnd)
                      <+ V(niib,gnd)
                                       + ddt(V(niib,gnd)/(2.0*3.1415*Fb)) +
                         white_noise(LFc* Area*Kb );
      I(niiib,gnd)
                      <+ V(niiib,gnd) +
                         flicker_noise(LFc* Area*Kfb, Ffeb,
                                        "Flicker_noise_base-emitter_junction_(a)");
                      <+ V(nivb,gnd)
      I(nivb,qnd)
800
                                       +
                         flicker_noise(LFc* Area*Kfe , Ffee,
                                        "Hooge_noise_of_emitter_resistance");
```

```
// Lorentz-spectrum part
      I(nii,gnd)
                    <+ V(nii,gnd)
                                     + ddt(V(nii,gnd)/(2.0*3.1415*Fb)) +
                       white_noise( (1.0-LFc)*Area*Kb );
      I(niia,gnd)
                    <+ V(niia,gnd) + ddt(V(niia,gnd)/(2.0*3.1415*Fb)) +
                       white_noise( (1.0-LFc)*Area*Kb );
      if (Fcorr==0) begin
810
        I(niiy, gnd) <+ Iniix;</pre>
       V(niiy,gnd) <+ I(niiy,gnd);</pre>
       I(niix,gnd) <+ le-9*V(niix,gnd); // we dont need this node now
      end
      else begin
      // low-pass -- high-pass
       V(niiy,gnd) <+ Iniix;</pre>
        I(niiy,niix) <+ ddt(V(niiy,niix))/Fcorr;</pre>
        I(niix,gnd) <+ V(niix,gnd);</pre>
      end;
820
      // 1/f spectrum part
      I(niii,gnd)
                    <+ V(niii,gnd) +
                       flicker_noise((1.0-LFc)*Area*Kfb, Ffeb,
                                       "Flicker_noise_base-emitter_junction_(a)");
                    <+ V(niiia,gnd) +
      I(niiia,gnd)
                        flicker_noise((1.0-LFc)*Area*Kfb, Ffeb,
                                       "Flicker_noise_base-emitter_junction_(a)");
830
      if (Fcorr==0) begin
      I(niiiy,gnd) <+ Iniiix;</pre>
      V(niiiy,gnd) <+ I(niiiy,gnd);</pre>
      I(niiix,gnd) <+ le-9*V(niiix); // we dont need this node now
835
      else begin
      // low-pass -- high-pass
      V(niiiy,gnd) <+ Iniiix;</pre>
      I(niiiy,niiix) <+ ddt(V(niiiy,niiix))/Fcorr;</pre>
      I(niiix,gnd) <+ V(niiix);</pre>
840
      end;
      // Together
      if (Fcorr==0) begin
845
        I(bii,ei) <+ (V(nii)+V(niia)+V(niib))*V(niiy,gnd) +</pre>
                      (V(niii)+V(niiia)+V(niiib))*V(niiiy,gnd);
      end
      else begin
       I(bii,ei) <+ (V(nii)+V(niib))*V(niix) + (V(niia)+V(niib))*V(niiy,niix) +
850
                      (V(niii)+V(niiib))*V(niiix,gnd) +
                      (V(niiia)+V(niiib))*V(niiiy,niiix);
      end;
      // Emitter
855
      I(niv,gnd)
                    <+ V(niv,gnd)
                        flicker_noise((1.0-LFc)*Area*Kfe , Ffee,
                                       "Hooge_noise_of_emitter_resistance");
      I(niva,gnd)
                    <+ V(niva,gnd) +
860
                        flicker_noise((1.0-LFc)*Area*Kfe , Ffee,
                                       "Hooge_noise_of_emitter_resistance");
      if (Fcorr==0) begin
      I(nivy,gnd) <+ Inivx;</pre>
                      <+ I(nivy,gnd);</pre>
       V(nivy,gnd)
865
       I(nivx,gnd)
                      <+ le-9*V(nivx); // we dont need this node now</pre>
```

```
end
       else begin
       // low-pass -- high-pass
V(nivy,gnd) <+ Inivx;
I(nivy,nivx) <+ ddt(V(nivy,nivx))/Fcorr;
I(nivx,gnd) <+ V(nivx);</pre>
870
       end;
       // Together
875
       if (Fcorr==0) begin
         V(e, ei) <+ (V(niv)+V(niva)+V(nivb))*V(nivx)*(Re/N);</pre>
       else begin
        V(e, ei) <+ (V(niv)+V(nivb))*V(nivx)*(Re/N) +
                          (V(niva)+V(nivb))*V(nivy,nivx)*(Re/N);
       end;
  end
885 / /
  // end of model equations
```

endmodule