

Host integration decisions

Companion to `H0ST_2HZ_WIRING.m`. Records what the host's 2 Hz function does with the operational KF, the `trialKF` and the gate outputs in every case, and what each gate mode compares against. `GAIN` is the host's constant feedback gain (0.4). "Mode" is the gate mode **after** this epoch's call to `SPF_gate`; "in probation" is the mode **before** it.

1. Definitions

Symbol	Meaning
<code>xPrior</code>	<code>activeKF.states</code> captured before calling <code>kfUpdate</code> (extrapolated at 100 Hz)
<code>xPost</code>	<code>kfUpdate</code> output: <code>activeKF.states + K*y</code>
<code>PPrior</code> , <code>PPost</code>	<code>activeKF.covariance</code> before, <code>kfUpdate</code> covariance after
<code>y</code> , <code>H</code> , <code>R</code> , <code>numMeas</code>	innovation <code>z - h(xPrior)</code> , Jacobian, measurement noise, valid rows as the filter used them (pressure row included; <code>numMeas = 1</code> on a GNSS outage)
increment	<code>xPost - xPrior = K*y</code> : the only thing the monitors consume
separation	sum of Phi-propagated increments since a reference epoch = host solution minus the coast of that reference
anchor	last alarm-free closed window: <code>separation</code> (kept live) and coast covariance
<code>probSep</code>	sum of the trial's increments since probation opened
<code>nav.state</code> , <code>nav.covar</code>	a complete <code>(x+, P+)</code> for the operational KF, same definition as the <code>kfUpdate</code> outputs
active filter	operational KF in NOMINAL and COAST, <code>trialKF</code> in PROBATION

The gate never stores an absolute state. Every quantity it keeps is a difference between two solutions that share the same mechanization history, which is what makes it invariant to how `setKF` splits `xPost` between `stateFB` and `KF.states` (verified: `tests/test_feedback_split.m`, identical estimate for `GAIN` 0.1, 0.4 and 1.0).

2. Operational KF: what `setKF` sets in every case

Exactly one `setKF` call per epoch on the operational KF. `stateFB` rows are position/velocity/attitude; bias and clock feedback follow the existing cumulative rule in every case.

Case	Gate flags	<code>stateFB</code>	<code>KF.states</code>	<code>KF.covariance</code>	Scratch <code>xPost</code> , <code>PPost</code>
NOMINAL, normal update	none	<code>GAIN * xPost</code>	<code>xPost - GAIN * xPost</code>	<code>PPost</code>	used
NOMINAL, no satellite	none	zero except biases	<code>xPost</code> except pressure-alt <code>(1-GAIN)*xPost</code>	<code>PPost</code>	used (existing rule)
NOMINAL, invalid update	none	zero	zero	as today	to the gate: <code>numMeas = 0</code> , <code>xPost = xPrior</code> , <code>PPost = PPrior</code>

Case	Gate flags	stateFB	KF.states	KF.covariance	Scratch xPost, PPost
LATCH (NOMINAL -> COAST)	nav.applyCorrection, info.eventLatched	GAIN * nav.state	nav.state - GAIN * nav.state	nav.covar (anchor coast covariance)	discarded
COAST (stays)	none	GAIN * states_extrap (drain)	states_extrap - GAIN * states_extrap	input KF.covariance unchanged (extrapolated)	discarded; only y, H, R, numMeas feed the gate
COAST -> PROBATION	kfCommand.startTrial, info.eventProbationStarted	drain, as COAST	drain, as COAST	input unchanged	discarded; next epoch trialKF = KF (states and covariance, already extrapolated)
PROBATION (stays)	none	drain, as COAST	drain, as COAST	input unchanged	belongs to the trial (see section 3)
VETO (PROBATION -> COAST)	info.eventProbationVetoed	drain, as COAST	drain, as COAST	input unchanged	trial discarded
COMMIT (PROBATION -> NOMINAL)	nav.applyCorrection, info.eventHandback	GAIN * nav.state	nav.state - GAIN * nav.state	nav.covar (trial PPost)	nav.state is the trial's xPost
No usable anchor at alarm	info.anchorMissing, no correction	as COAST	as COAST	input unchanged	discarded
Alignment (navActive = false)	gate called, returns zeroTel and re-arms itself	as today	as today	as today	as today
GNSS outage in navigation (pressure row only)	gate called with numMeas = 1; cannot pass re- validation (REVAL_MIN_MEAS = 4)	as today (no-satellite case)	as today	as today	used

Implementation: setKF itself is unchanged. The host selects its input before the one call per epoch: nav.state / nav.covar on latch and commit, the extrapolated KF.states / KF.covariance on COAST and PROBATION (the normal case on the prior is the drain), kfPost otherwise. On the two overriding branches the fields that select the case (failed, satellite count) are forced to the normal case, so a failed or no-satellite scratch update can neither zero the clean state nor trigger the 100 Hz reset. Rules behind the table:

- Whatever is fed to the mechanization is removed from KF.states in the same call. The drain applies the normal split to the extrapolated state, so the leftover of the latch correction reaches the output smoothly, by (1-GAIN) per epoch, instead of sitting in KF.states for the whole coast.
- The covariance in COAST and PROBATION is never the scratch PPost (it was reduced by a measurement being refused) and never the gate's output (only meaningful on latch and commit epochs; equal to the extrapolated covariance otherwise).
- The coast is pure INS for now: no baro update in COAST or PROBATION. A baro-only aiding loop during the coast is a later gate extension.
- The latch correction is bounded by the protection level, since the monitors fire before the spoofer gets further; it is not the size of the attack.

3. Trial KF (PROBATION only)

Step	Action
Probation opens (startTrial, acted on at the start of the next epoch)	trialKF = KF, states and covariance as the 100 Hz side extrapolated them; no propagation on that epoch. The operational KF keeps draining meanwhile (negligible by then)
Start of each PROBATION epoch	trialKF.states = accumPhi * trialKF.states; trialKF.covariance = accumPhi * P * accumPhi' + accumQ, symmetrised (the trial has no 100 Hz extrapolation of its own)
Update	kfUpdate(measurement, trialKF); h(x) must use the states of the struct passed in
After the gate call	trialKF = kfUpdate result (states and covariance). No setKF, no feedback, no drain: the trial has no mechanization of its own and its states must keep the full increments
Veto	trial dropped
Commit	trial xPost, PPost go through the normal setKF as nav.state, nav.covar; trial no longer used

4. What each mode compares, and against what

Mode	Active filter	Test	Compares	Against	Statistic and threshold	Result
NOMINAL, warm-up (info.armed = false)	operational KF, updated normally	none: the monitors arm after ARM_EPOCHS (10) consecutive epochs with numMeas >= REVAL_MIN_MEAS and K_MISSED_DETECTION * sigma_pos(P+) < ARM_PL_MAX (100 m); a PL above the limit restarts the count, a row dropout with the PL inside pauses it; sticky once armed (until a gate re-initialisation)				no windows, no alarms, no latch; the anchor follows the current solution so it is fresh when the monitors start
NOMINAL	operational KF, updated normally	SS, every open window, every monitored axis, every epoch	window separation (increments since the window opened)	that window's INS-only coast	abs(d_axis) > K_FALSE_ALERT * sqrt(P_C - P_KF)	any alarm: LATCH to the anchor
NOMINAL	same	CPI, when a window reaches N = 10	normalised innovation projections on the axis, $\xi = f'S^{-1}y / \sqrt{f'S^{-1}f}$	N(0,1) under no attack	sum(xi^2) > CPI_THRESHOLD (Gamma, 45.64)	any alarm: LATCH; a window alarm-free for its whole life refreshes the anchor
COAST	operational KF not updated (scratch update feeds y, H, R only)	re-validation, every epoch	raw innovation y (all rows)	the INS-only coast (the operational KF's own prior) with its grown covariance	$y' (H P_C H' + R)^{-1} y < \chi^2_{inv}(1 - 1e-3, \text{numMeas})$ and numMeas >= REVAL_MIN_MEAS (4); baro-only epochs cannot pass	10 consecutive passes: PROBATION; a fail resets the dwell. Monitors do not run

Mode	Active filter	Test	Compares	Against	Statistic and threshold	Result
PROBATION	trial KF, updated	SS and CPI on the trial, same as NOMINAL	trial increments (probSep)	the coast ($P_C - P_{\text{trial}}$)	as NOMINAL	any alarm: VETO to COAST (dwell reset); 18 quiet epochs: COMMIT
PROBATION	same	re-validation, diagnostic only	$y - H * (-\Phi * \text{probSep})$	the coast	same statistic, logged as <code>info.qReval</code>	no decision

Why two stages: the COAST test is coarse and its gate widens as the coast covariance grows, so a spoofer resuming with an offset inside that band passes it. PROBATION lets a filter follow the GNSS and runs the full monitor bank on it, with NOMINAL sensitivity, without touching the operational solution. None of these tests reads `KF.states`; the residual shrinking during the coast is the estimate having no information, not a sign that the attack ended.

5. Gate outputs per event

Event	Flags	nav.state	nav.covar	kfCommand
Latch	<code>applyCorrection</code> , <code>eventLatched</code> , <code>eventAnchorEpoch</code>	<code>operational</code> <code>xPost</code> - <code>anchor.separation</code>	<code>anchor.covariance</code>	none
Probation opens	<code>eventProbationStarted</code>	none	none	<code>startTrial = true</code>
Veto	<code>eventProbationVetoed</code>	none	none	none
Commit	<code>applyCorrection</code> , <code>eventHandback</code>	<code>trial</code> <code>xPost</code>	<code>trial</code> <code>PPost</code>	none
Alarm without usable anchor	<code>eventLatched</code> , <code>anchorMissing</code>	none	none	none; mode still COAST
Every epoch	<code>mode</code> , <code>ssAlarm</code> , <code>cpiAlarm</code> , <code>alarmPerAxis</code> , <code>maxProtectionLevel</code> , <code>qReval</code> , <code>dwellCount</code> , <code>coastEpochs</code> , <code>ssRatio</code> (SS margin per axis, alarm > 1), <code>cpiRatio</code> (CPI margin per axis, alarm > 1), <code>armed</code> (monitors active; false during the warm-up after init), <code>resetInhibit</code> (gate in COAST / PROBATION or alarming: the host must not apply its protective reset on the GNSS-vs-INS discrepancy), <code>coastBudgetExceeded</code> (COAST + PROBATION longer than <code>COAST_BUDGET_EPOCHS</code> : the host may reset, integrity not assured)		<code>coastCov</code> (diagnostic)	
Fault telemetry	<code>inputFault</code> (non-finite input: epoch dropped, gate re-initialises on the next good epoch), <code>numMeasClamped</code> (host passed more than <code>MAX_MEAS</code> rows), <code>solveFault</code> (an S or residual covariance was not positive definite: that CPI epoch counts <code>xi = 0</code> , re-validation cannot pass)			

After a commit the anchor is the committed solution (separation zero, covariance the trial's `PPost`), the probation windows carry over, and a new attack goes through the same cycle with no limit on the number of cycles.

6. Exception handlers (audit of the runtime path)

Hazard	Where	Handling
$S^{-1} y$, $S^{-1} f$ on the padded S	SPF_cpiMonitor	live-row variances must be positive; padding diagonal filled with the largest live variance so the matrix is non-singular; then the host's <code>matrixInv</code> (flags non-finite / singular input); a flagged epoch is dropped (<code>xi = 0</code>), <code>solveFault</code>
$r' S_r^{-1} r$ on an unusable residual covariance	SPF_revalidation	live-row variances must be positive, then the host's <code>matrixInv</code> ; <code>q</code> must be finite and ≥ 0 to pass; flagged: no pass, <code>solveFault</code>
<code>numMeas > MAX_MEAS</code> slicing fixed buffers	<code>setKfMeas</code> , <code>kfMeasFromUpdate</code> , SPF_cpiMonitor, SPF_revalidation	clamped at ingress and defensively at use; <code>numMeasClamped</code>
NaN / Inf in any input (failed host update, uninitialised <code>propTel</code>)	SPF_gate	<code>isfinite</code> check on every input; epoch dropped with <code>inputFault</code> , state and epoch counter reset, re-init on the next good epoch (mirrors the host's own failed-update reset)
<code>sqrt</code> of a negative variance (<code>P_C - P_KF</code> , <code>P_C</code> , <code>coastCov</code> diagonal)	SPF_ssMonitor, SPF_protectedNav	guarded: test reported undefined (no alarm), sigma 0
division <code>gamma / sqrt(sigma2)</code> with <code>sigma2 = 0</code> (axis unobservable)	SPF_cpiMonitor	guarded: <code>xi = 0</code>
startup anchor stamped with epoch 0 (the "no anchor" sentinel) and propagated once too often	SPF_protectedNav	during the warm-up the anchor is re-seeded every epoch with that epoch's (<code>x+</code> , <code>P+</code>) and stamp, so the first armed epoch starts from a fresh anchor
false latch on an unconverged filter right after (re)initialisation (few rows, large P , interval matrices just reset)	SPF_protectedNav	warm-up arming: no window and no latch until <code>ARM_EPOCHS</code> consecutive epochs qualify (<code>numMeas >= REVAL_MIN_MEAS</code> , <code>PL < ARM_PL_MAX</code>); <code>info.armed</code>
<code>uint32</code> epoch differences, <code>uint8</code> counters and loop variables	all	checked: no wrap possible (<code>anchor.epoch <= epoch</code>), classes consistent
<code>REVAL_THRESHOLD_TABLE(numMeas)</code> index	SPF_revalidation	<code>numMeas</code> clamped to <code>MAX_MEAS</code> (= <code>CST_gnssHybrid.MAX_MEASURES</code>), table has 60 entries and the index is clamped to its length

Covered by `tests/test_error_handlers.m`. On a host update flagged `failed`, pass the epoch as `numMeas = 0`, `xPost = xPrior`, `PPost = PPrior`, or set `resetRequest = true` on that call; a NaN slipping through is caught by the input check.

7. Deferred

- Baro-only aiding during COAST and PROBATION (vertical channel).
- Coast-time budget (Implementation Guide rule 4): reported only (`COAST_BUDGET_EPOCHS`, `info.coastBudgetExceeded`); the host decides what to do beyond it (its protective reset). The gate does not declare dead reckoning itself. Each cycle still costs a coast and widens the coarse re-validation gate.
- `MAX_ANCHOR_AGE` is a startup-only guard today.

- Warm-up arming uses a fixed protection-level limit (`ARM_PL_MAX`); a convergence test on the filter's own covariance rate could replace it. `ARM_EPOCHS` is 10 in the repository (simulation references); the host runs with 120 (60 s) because its post-reset bias convergence takes that long (see `docs/CONCEPTS.md` section 6). A row dropout pauses the count; only a PL above `ARM_PL_MAX` restarts it.
- Outage re-arm (disarm after a long GNSS outage so re-acquisition goes through the warm-up): not needed on the jammed data set, where the host's own reset already re-initialises the gate; relevant only for outages that end below the host's reset limit.