Natalia de León Bercián

Electrónica Digital 2 carne: 18193

Mayo 2021 sección: 20

Laboratorio #7

ISR - TMR0 y UART

Link del video:

https://youtu.be/167QisWAL5g

Link del GitHub:

https://github.com/nataliadlb/LABS_REPOSITORIO.git

Código

```
Laboratorio # 7
Natalia de León Bericán
<u>carne</u>: 18193
Digital 2
Sección 20
Mayo 2021
#include <stdint.h>
#include <stdbool.h>
#include "inc/tm4c123gh6pm.h"
#include "inc/hw_memmap.h"
#include "driverlib/debug.h"
#include "inc/hw_types.h"
#include "inc/hw_ints.h"
#include "driverlib/sysctl.h"
#include "driverlib/systick.h"
#include "driverlib/interrupt.h"
#include "driverlib/gpio.h"
#include "driverlib/timer.h"
#include "driverlib/uart.h"
#include "driverlib/rom.h"
#include <string.h>
#include "grlib/grlib.h"
#include "driverlib/pin_map.h"
//#define XTAL 16000000
#define LED ROJO GPIO PIN 1
#define LED_VERDE GPIO_PIN_3
#define LED_AZUL GPIO_PIN_2
// VARIABLES
```

```
uint32 t ui32Period; //periodo para TMR0
uint32 t ui32Status; //Status de UART
uint8 t Ban rojo = 0;
uint8 t Ban verde = 0;
uint8 t Ban azul = 0;
char letra;
// PROTOTIPOS DE FUNCIONES
void Timer0IntHandler(void);
void InitUART(void);
void UARTIntHandler(void);
//
// The error routine that is called if the driver library encounters an error.
#ifdef DEBUG
void
 _error__(char *pcFilename, uint32_t ui32Line)
  while(1);
#endif
// CONFIGURACION
int main(void){
  //Config de reloj a 40MHz
  SysCtlClockSet(SYSCTL_SYSDIV_5 | SYSCTL_USE_PLL | SYSCTL_XTAL_16MHZ |
SYSCTL OSC MAIN);
  // Config reloj para habilitar puerto F
  SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOF);
  // <u>Verificar que</u> <u>se</u> <u>habilitó</u> <u>puerto</u> F
  while(!SysCtlPeripheralReady(SYSCTL_PERIPH_GPIOF)){
   }
  // Configurar OUTPUTS/INPUTS
  GPIOPinTypeGPIOOutput(GPIO_PORTF_BASE, GPIO_PIN_1 | GPIO_PIN_2 | GPIO_PIN_3);
     CONFIGURACION UART
  // <u>Se inicializa la comunicación</u> UART
  InitUART();
```

```
CONFIGURACION TIMER
   */
   SysCtlPeripheralEnable(SYSCTL PERIPH TIMER0);
   while(!SysCtlPeripheralReady(SYSCTL PERIPH TIMER0)){
   }
   // Configuración del Timer 0 como temporizador períodico
   TimerConfigure(TIMER0_BASE, TIMER_CFG_PERIODIC);
   // Se calcula el período para el temporizador (1 seg)
   ui32Period = (SysCtlClockGet()) / 2;
   // Establecer el periodo del temporizador
   TimerLoadSet(TIMER0 BASE, TIMER A, ui32Period - 1);
   TimerEnable (TIMER0 BASE, TIMER A|TIMER B);
   // Se establece que exista la interrupción por Timeout
   TimerIntEnable(TIMER0 BASE, TIMER TIMA TIMEOUT);
   //Establecemos <u>la</u> ISR
   TimerIntRegister(TIMER0_BASE, TIMER_A, Timer0IntHandler);
   // Se habilita la interrupción por el TIMEROA
   IntEnable(INT_TIMER0A);
   // <u>Se habilita</u> el Timer
   TimerEnable(TIMERO_BASE, TIMER_A);
   // Se manda mensajes por UART
   UARTCharPut(UART0_BASE, 'C');
   UARTCharPut(UARTO_BASE, 'o');
   UARTCharPut(UART0_BASE, 'm');
   UARTCharPut(UARTO_BASE, 'e');
   UARTCharPut(UARTO_BASE, 'n');
   UARTCharPut(UART0_BASE, 'z');
   UARTCharPut(UART0_BASE, 'a');
   UARTCharPut(UART0_BASE, 'm');
   UARTCharPut(UART0_BASE, 'o');
   UARTCharPut(UART0_BASE, 's');
   UARTCharPut(UARTO_BASE, 10);
   UARTCharPut(UARTO BASE, 13);
   // Loop forever.
   while(1){
//
// FUNCIONES
```

/**

}

```
// Handler de la interrupcion del TIMER 0 - Recordar modificar el archivo
tm4c123ght6pm startup css.c
void Timer0IntHandler(void){
   // Clear the timer interrupt
   TimerIntClear(TIMER0_BASE, TIMER_TIMA_TIMEOUT);
   //LED ROJO
   if (letra == 'r' & Ban_rojo == 1){ //activar toggle led rojo
      if (GPIOPinRead(GPIO_PORTF_BASE, LED_ROJO)){
         GPIOPinWrite(GPIO_PORTF_BASE, LED_ROJO, 0);
      else {
         GPIOPinWrite(GPIO PORTF BASE, LED ROJO , LED ROJO);
      }
   else if (letra == 'r' & Ban rojo == 2){ //desactivar toggle led rojo
      GPIOPinWrite(GPIO PORTF BASE, LED ROJO , 0);
      Ban_rojo = 0;
   //LED VERDE
   else if (letra == 'g' & Ban_verde == 1){ //activar toggle led verde
      if (GPIOPinRead(GPIO_PORTF_BASE, LED_VERDE)){
         GPIOPinWrite(GPIO_PORTF_BASE, LED_VERDE, 0);
      else {
         GPIOPinWrite(GPIO_PORTF_BASE, LED_VERDE , LED_VERDE);
   else if (letra == 'g' & Ban_verde == 2){ //desactivar toggle led verde
      GPIOPinWrite(GPIO_PORTF_BASE, LED_VERDE , 0);
      Ban verde = 0;
   }
   //LED AZUL
   if (letra == 'b' & Ban_azul == 1){ //activar toggle led azul
      if (GPIOPinRead(GPIO_PORTF_BASE, LED_AZUL)){
         GPIOPinWrite(GPIO PORTF BASE, LED AZUL, 0);
      }
      else {
         GPIOPinWrite(GPIO PORTF BASE, LED AZUL , LED AZUL);
   else if (letra == 'b' & Ban_azul == 2){ //desactivar toggle led azul
      GPIOPinWrite(GPIO_PORTF_BASE, LED_AZUL , 0);
      Ban_azul = 0;
   }
}
// Handler <u>de la interrupcion del</u> UART - <u>Recordar modificar</u> el <u>archivo</u>
tm4c123ght6pm startup css.c
*******
void UARTIntHandler(void){
      // Get the interrupt status
```

```
ui32Status = UARTIntStatus(UARTO BASE, true);
       // Clear the asserted interrupts.
       UARTIntClear(UARTO BASE, ui32Status);
       // Loop while there are characters in the receive FIFO.
       while(UARTCharsAvail(UART0 BASE)){
           letra = UARTCharGet(UARTO BASE);
           UARTCharPutNonBlocking(UARTO_BASE,letra); //manda a un puerto especifico
           if (letra == 'r'){ //depende el caracter se aumenta la bandera de ese led
               Ban_rojo++;
           else if (letra == 'g'){
               Ban verde++;
           else if (letra == 'b'){
               Ban azul++;
       }
}
*******
// <u>Inicialización de UART - Tomado del ejemplo que subio Pablo Mazariegos</u>
*********
void InitUART(void){
   /*Enable the peripheral UART Module 0*/
   SysCtlPeripheralEnable(SYSCTL_PERIPH_UART0);
   while(!SysCtlPeripheralReady(SYSCTL_PERIPH_UART0)){
   /*Enable the GPIO Port A*/
   SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOA);
   GPIOPinConfigure(GPIO PA0 U0RX);
   GPIOPinConfigure(GPIO PA1 U0TX);
   // <u>Se habilitan las interrupciones Globales</u>
   IntMasterEnable();
   /* Make the UART pins be peripheral controlled. */
   GPIOPinTypeUART(GPIO_PORTA_BASE, GPIO_PIN_0 | GPIO_PIN_1);
   UARTDisable(UART0_BASE);
   /* Sets the configuration of a UART. */
   UARTConfigSetExpClk(
           UARTO_BASE, SysCtlClockGet(), 115200,
           (UART_CONFIG_WLEN_8 | UART_CONFIG_STOP_ONE | UART_CONFIG_PAR_NONE));
   IntEnable (INT_UART0);
   UARTIntEnable(UARTO BASE, UART INT RX | UART INT RT);
   UARTEnable (UART0 BASE);
}
```