

### **DESIGNDOCUMENT**

## **DSP/BIOS™ LINK**

# **Configurable TSK and SWI approach**

**LNK 207 DES** 

**Version <1.00>** 



Thispagehasbeenintentionallyleftblank.



#### **IMPORTANT NOTICE**

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third–party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Mailing Address: Texas Instruments Post Office Box 655303 Dallas, Texas 75265

Copyright ©. 2003, Texas Instruments Incorporated



Thispagehasbeenintentionallyleftblank.



## **TABLEOFCONTENTS**

1	Introduction					
	1.1	Purpose & Scope				
	1.2	Terms & Abbreviations	6			
	1.3	References	6			
	1.4	Overview	$\ldots \ldots \in$			
2	Requirements					
3	Assu	ımptions	7			
4		straints				
5	Low Level Design					
	5.1	Following functionality added to support TSK mode:				
	5.2	Initializes the semaphore object				
	5.3	Wait and signal a semaphore				
	5.4	ZCPYMQT and ZCPYDATA in TSK context	11			
	5.5	Delete a task (TSK_delete)	13			
	5.6	Configuration and make system changes	13			
6	Typedefs & Data Structures					
	6.1	ZCPYMQT_State				
7	API Definition					
	7.1	ZCPYMQT_tskFxn	16			
	7.2	ZCPYDATA_TSK				
8	Impa	act and Backward Compatibility:	18			



### 1 Introduction

### 1.1 Purpose&Scope

This document describes the design to configure the TSK or SWI mode for the existing SWI functions of ZCPYMQT and ZCPYDATA. If MPCS protection is TSK-base, then DSPLink MSGQ and CHNL drivers will use TSK Mode on DSP-side. If MPCS protection is SWI-base, then DSPLink MSGQ and CHNL drivers will use SWI Mode. So that systems are fully TSK-based or SWI based.

### 1.2 Terms&Abbreviations

DSPLINK	DSP/BIOS™ LINK
SWI	Software interrupt manager
TSK	Task manager
P.	This bullet indicates important information.
	Please read such text carefully.
	This bullet indicates additional information.

#### 1.3 References

1.	Spru404n.pdf	TMS320C55x DSP/BIOS 5.32 Application Programming Interface (API) Reference Guide
2.	LNK_041_DES.pdf	ZERO COPY LINK DRIVER

#### 1.4 Overview

DSP/BIOS<sup>TM</sup> LINK is runtime software, analysis tools, and an associated porting kit that simplifies the development of embedded applications in which a general-purpose microprocessor (GPP) controls and communicates with a TI DSP. DSP/BIOS<sup>TM</sup> LINK provides control and communication paths between GPP OS threads and DSP/BIOS<sup>TM</sup> tasks, along with analysis instrumentation and tools.

This document gives an overview of the SWI and TSK mode detailed design for DSPLINK.

## 2 Requirements

DSPLN00001021:- DSPLink should use configurable TSK-Sem or SWI-enable and SWI-disable approach for MPCS.

Presently, DSPLINK MSGQ and CHNL components work in SWI mode only. For TSK mode the components should work in context of a Task.

To support this feature following changes are required within DSPLink:

- Select the mode while configure the DSPLINK.
   Mode can be SWI or TSK (DSP\_SWI\_MODE or DSP\_TSK\_MODE).
- Handle the components properly for both modes.
   Don't disable the scheduler by calling TSK\_disable. Use semaphore SEM\_pend and SEM\_post.



## 3 Assumptions

The MPCS design makes the following assumptions:

1. The hardware allows provision of a buffer pool, to which both the GPP and the DSP have access.

### 4 Constraints

The MPCS object must be allocated and freed through POOL APIs provided by DSPLINK. Elements allocated through the POOL API can be accessed by multiple processors. Any other means for memory allocation (for example: standard OS calls) will fail as the elements cannot be accessed across processors.

The user has to use unique identifier to identify individual MPCS objects across the system.



## 5 LowLevelDesign

The zero-copy driver provides a fast physical link between the GPP and the DSP, based on the concept of pointer exchange between the GPP and DSP applications. For data transfer, the link driver manages a configurable number of logical channels. The IPS component manages the transfer of data and messages across the two processors. For this, it uses the shared memory control structure and interrupts between the processors to inform about any changes in status of buffer/message availability on the channels.

The IPS component shall maintain lists of messages, which are shared between the GPP and the DSP. There shall be two unidirectional lists of messages, for messages to and from the DSP. Similar lists shall also be used for data transfer. To protect these shared lists, the IPS component shall utilize the services of a generic component that shall provide critical section protection between the two processors.

In a multiprocessor system having shared access to a memory region, a multiprocessor critical section between GPP and DSP can be implemented. This MPCS object can be used by applications to provide mutually exclusive access to a shared region between multiple processors, and multiple processes on each processor.

### 5.1 FollowingfunctionalityaddedtosupportTSKmo de:-

- 1. Create a task to execute (Using TSK create call).
- 2. Initialize the semaphore object.
- 3. Wait and signal a semaphore (Using SEM pend and SEM post).
- 4. Use the functionality in ZCPYMQT and ZCPYDATA functions in TSK context.
- 5. Delete the task ( Using TSK delete call).
- 6. Configuration and make system changes.

#### 5.1.1 Createatasktoexecute(UsingTSK createca II)

The TSK objects are created during the ZCPYMQT\_open phase for TSK mode by calling TSK\_Create. Create the task in the initial ZCPYMQT\_open function.

```
Static Int ZCPYMQT_open (MSGQ_TransportHandle mqtHandle)
{
.
.
#if defined (USE_TSK)
tskAttrs. priority =15 ;
mqtState->tskHandle = TSK_create(ZCPYMQT_tskFxn, &tskAttrs,0) ;
if (mqtState->swiHandle == NULL) {
    status = SYS_EALLOC ;
    SET_FAILURE_REASON (status) ;
}
#endif
```

Create the static TSK objects for ZCPYDATA, use the following steps.

```
var ZCPYLINK_TSK_OBJ= bios.TSK.create("ZCPYLINK_TSK_OBJ");
/* To create a TSK object*/
ZCPYLINK_TSK_OBJ.comment = " This TSK handles the data transfer in DSPLINK";
```



```
ZCPYLINK_TSK_OBJ.autoAllocateStack = true;
/* Check this box if you want the task's private stack space to be
allocated automatically */
ZCPYLINK_TSK_OBJ.priority = 15;
/* The priority level for this task. */
ZCPYLINK_TSK_OBJ.fxn = prog.extern("ZCPYDATA_TSK");
/* The function to be executed when the task runs. */
ZCPYLINK_TSK_OBJ.arg0 = 0;
/* Task function argument 0-7 */
```

### 5.2 Initializesthesemaphoreobject

SEM\_new () initializes the semaphore object pointed to by sem with count. The function should be used on a statically created semaphore for initialization purposes only.

Create and initialize the semaphore for MPCS:-

```
Int
MPCS_create (IN
                    Uint16
                                   procId,
                    Char *
             IN
                                   name,
             IN OPT MPCS_ShObj *
                                   mpcsObj,
             IN MPCS_Attrs *
                                   attrs)
{
#if defined (USE_TSK)
    SEM_Obj
                      mpcsSem ;
    #if defined (USE TSK)
        SEM_new (&mpcsSem, 0);
    #endif
#endif
Create and initialize the semaphore for ZCPYMQT:-
Static Int ZCPYMOT open (MSGO TransportHandle mqtHandle)
```

Create and initialize the semaphore for ZCPYDATA:-



### 5.3 Waitandsignalasemaphore

In case of TSK context. SEM\_pend and SEM\_post will control the task processing. Initially it calls SEM\_pend to acquire the semaphore if it is available and tries to get the multiprocessor lock. SEM\_pend and SEM\_post are use with counting semaphores, which keep track of the number of times the semaphore has been posted.

The MPCS component in TSK context:-

MPCS\_enter calls SEM\_pend to acquire the semaphore.

MPCS\_leave will call SEM\_post to post the semaphore to allow the others that are waiting or blocked in MPCS\_enter.



### 5.4 ZCPYMQTandZCPYDATAinTSKcontext

When either the GPP or DSP is ready to send a message to the other processor, it sends the notification to the IPS component. On receiving a message from the other processor, the IPS component makes a call back to the ZCPY MQT and DATA component, which places the received message onto the appropriate local message queue.

The callback functions (ZCPYDATA\_callback and ZCPYMQT\_callback) are registered with IPS component. These callback functions will call SEM\_post to post the semaphore to allow the others that are waiting or blocked in ZCPYMQT\_tskFxn and ZCPYDATA tskFxn.

```
In case of ZCPYMQT:-
Static Void ZCPYMQT_callback (Uint32 eventNo, Ptr arg, Ptr info)
{
    ZCPYMQT_State * mqtState = (ZCPYMQT_State *) arg ;
    (void) eventNo ;
    (void) info ;
    DBC assert (mqtState != NULL) ;
#if defined (USE_TSK)
    SEM post(zcpyMqtSem) ;
#endif
#if defined (USE SWI)
    SWI_post (mqtState->swiHandle) ;
#endif
In case of ZCPYDATA:-
Static Void ZCPYDATA callback (Uint32 eventNo, Ptr arg, Ptr info)
    (void) eventNo ;
    (void) arg ;
    (void) info ;
#if defined (USE_TSK)
    SEM_post((&ZCPYDATA_TSK_OBJ) ;
#endif
#if defined (USE_SWI)
```



```
SWI_inc (&ZCPYDATA_SWI_OBJ) ;
#endif
}
```

ZCPYMQT\_tskFxn and ZCPYDATA\_TSK are register for TSK mode and both functions will call the SEM\_pend to wait the semaphore.

```
In case of ZCPYMQT:-
static
Void
ZCPYMQT_swiFxn (Arg arg0, Arg arg1)
    Int
                            status = SYS_OK ;
   DBC_require (arg0 != NULL) ;
    (Void) arg1;
   mqtState = (ZCPYMQT_State *) arg0 ;
   HAL_cacheInv ((Ptr) &(ctrlPtr->toDspList), sizeof (ctrlPtr-
>toDspList)) ;
#if defined (USE_TSK)
    While(1) {
        SEM_pend(&zcpyMqtSem, SYS_FOREVER) ;
#endif
In case of ZCPYDATA:-
Void ZCPYDATA_TSK (Arg arg0, Arg arg1)
{
    ZCPYDATA_DevObject * dev = (ZCPYDATA_DevObject *) arg0 ;
    (Void) arg1 ;
   DBC_require (dev != NULL) ;
#if defined (USE_TSK)
   While(1) {
        SEM pend(&zcpyDataSem, SYS FOREVER) ;
#endif
```



### 5.5 Deleteatask(TSK\_delete)

The TSK and SWI objects are deleted by calling SWI\_delete and TSK\_delete. When ZCPYMQT\_close is called delete the objects. ZCPYMQT\_close Closes the ZCPY MQT, and cleans up its state object.

```
In case of ZCPYMQT:-
static
Int
ZCPYMQT_close (MSGQ_TransportHandle mqtHandle)
                     status = SYS_OK ;
    QUE_Handle
                     queHandle ;
    ZCPYMQT_State * mqtState ;
                    msg ;
   MSGQ Msq
   DBC require (mqtHandle != NULL) ;
#if defined (USE_SWI)
    if (mqtState->swiHandle != NULL) {
       SWI_delete (mqtState->swiHandle) ;
#endif /* if defined (USE SWI) */
#if defined (USE_TSK)
if (mqtState->tskHandle != NULL) {
   TSK delete (mgtState->tskHandle) ;
#endif
```

### 5.6 Configurationandmakesystemchanges

To make it configurable need to export the mode e.g DSP\_SWI\_MODE or DSP\_TSK\_MODE. Using dsplinkcfg.pl mode can be exported For e.g.







## 6 Typedefs&DataStructures

### 6.1 ZCPYMQT State

This structure defines the ZCPYMQT state object, which contains all the component-specific information.

#### **Definition**

```
typedef struct ZCPYMQT_State_tag {
    Uint16          poolId    ;
    QUE_Obj          ackMsgQueue ;
    Uint32          ipsId    ;
    Uint32          ipsEventNo ;
    ZCPYMQT_Ctrl * ctrlPtr ;
#if defined (USE_SWI)
    SWI_Handle          swiHandle ;
#endif /* if defined (USE_SWI) */
#if defined (USE_TSK)
    TSK_Handle          tskHandle ;
#endif /* if defined (USE_TSK) */
} ZCPYMQT_State ;
```

#### **Fields**

poolId	Pool ID used for allocating control messages. This pool is also used in case the ID within the message received from the DSP is invalid. This can occur in case of a mismatch between pools configured on the GPP and the DSP.
ackMsgQueue	Queue of locateAck messages received from the GPP.
ipsId	IPS ID associated with MQT.
ipsEventNo	IPS Event no associated with MQT.
swiHandle	SWI for processing of locate functionality in non-ISR context.  Only defined if callback processing is to be performed within a SWI instead of interrupt context.
tskHandle	Only defined if callback processing is to be performed within a TSK context.

#### **Comments**

An instance of this object is created and initialized during  ${\tt ZCPYMQT\_open}$  (), and its handle is returned to the caller. It contains all information required for maintaining the state of the MQT.

#### **Constraints**

None.

### **SeeAlso**

ZCPYMQT open ()



### 7 APIDefinition

### 7.1 ZCPYMQT tskFxn

Implements the TSK function for the ZCPYMQT.

#### **Syntax**

Static Void ZCPYMQT\_tskFxn (Arg arg0, Arg arg1);

#### **Arguments**

IN Arg arg0;

ZCPYMQT state object, which contains all the component-specific information.

#### ReturnValue

void

#### Comments

Make locate request to remote MQT by sending event to SHMIPS containing control message. If the locate call is synchronous, wait for receiving locate acknowledgement message from remote MQT as an SHMIPS event containing control message. If the locate call is asynchronous, return from the function without blocking. When the locate acknowledgement arrives from the remote processor, allocate and send an asynchronous locate message to the reply message queue specified by the caller.

#### **Constraints**

None.

#### **SeeAlso**

None.

#### 7.2 ZCPYDATA TSK

TSK function for data transfer in DSPLINK...

#### **Syntax**

Static Void ZCPYDATA\_TSK (Arg arg0, Arg arg1);

#### **Arguments**

IN Arg arg0;

Pointer to LINK device structure.

#### ReturnValue

void

#### Comments

Functionality will remain same as ZCPYDATA\_SWI. Only the change is waiting for semaphore.



_						
r -	$\boldsymbol{\smallfrown}$	n	et	ra	ın	ıts
u	u		Э.	ıa		ıLə

None.

### SeeAlso

None.



## 8 ImpactandBackwardCompatibility:

By default, the DSP-side of DSPLink uses SWIs for MSGQ and CHNL physical transports for communication with the peer transports on the GPP-side. Accordingly, the MPCS (Multi-processor critical section) protection uses SWI\_disable/SWI\_enable to protect from other local threads, since the DSPLink APIs need to be callable from SWI context.

In pure TSK-only systems, this release now supports applications that wish to reduce the scheduler disable latency. For this, the MPCS implementation supports usage of semaphore for protection from other local threads. Accordingly, the MSGQ and CHNL modules use TSK based servers instead of SWIs for communication with the peer transport on GPP. With this change, the scheduler disable latency gets reduced; however applications must not make any DSPLink calls from SWI context.

In both modes, DSPLink calls from HWI context continue to not be supported. The choice of whether TSK mode or SWI mode is to be used, is selectable for each DSP in the system from the DSPLink static build configuration script dsplinkcfg.pl."

If application writer is using the DSPLink build system and the DSPLink shipped to files, the application writer can look at the <sample\_tsk> files for reference

The changes that application needs to make to move from the default SWI mode to task mode are as follows:

• Remove static creation of SWI related configuration from application TCF file i.e. the code shown below.

 Add the following TSK mode related code in the application TCF file for CHNL component

```
var dsplink = prog.module("UDEV").create("dsplink");
dsplink.initFxn = prog.decl("ZCPYDATA_init");
dsplink.fxnTable = prog.decl("ZCPYDATA_FXNS");
```



```
dsplink.fxnTableType = "IOM_Fxns";
dsplink.comment = "DSP/BIOS LINK - IOM Driver";

var ZCPYLINK_TSK_OBJ = bios.TSK.create("ZCPYLINK_TSK_OBJ");
    ZCPYLINK_TSK_OBJ.comment = "This tsk handles the data transfer in DSPLINK";
    ZCPYLINK_TSK_OBJ.autoAllocateStack = true;
    ZCPYLINK_TSK_OBJ.priority = 15;
    ZCPYLINK_TSK_OBJ.fxn = prog.extern("ZCPYDATA_tskFxn");
    ZCPYLINK_TSK_OBJ.arg0 = prog.decl("ZCPYDATA_devObj");
```

• Ensure that the creation of the DIO driver remains unchanged in the application TCF file

```
var dio_dsplink = prog.module("DIO").create("dio_dsplink");
dio_dsplink.comment = "DSP/BIOS LINK - DIO Driver";
dio_dsplink.deviceName = prog.get("dsplink");
```

- Update priorities of the ZCPYMQT and ZCPYDATA task as per application integrator and system requirements.
- The application writer may need to set the STACKSEG for dynamic TSK\_create calls in the application TCF file.

```
bios.TSK.STACKSEG = <some memory seq>;    // for dynamic TSK stacks
```

• Ensure that the applications do not call DSPLink API's from ISR or SWI context.

In TSK mode, it is not permitted to call DSPLink APIs from ISR or SWI context. In default SWI mode, it is not permitted to call DSPLink APIs from ISR context.

Calling DSPLink API's from ISR or SWI context could lead to system deadlock

System deadlock could occur when:

- DSP-side executing in a task, takes an MPCS lock (through DSPLink API call), gets preempted by a SWI, which also tries to take an MPCS lock by calling a DSPLink API (not allowed)
- DSP-side executing in a task, takes an MPCS lock (through DSPLink API call), gets preempted by an ISR, which also tries to take an MPCS lock by calling a DSPLink API (not allowed)
- DSP-side executing in a SWI, takes an MPCS lock (through DSPLink API call), gets preempted by an ISR, which also tries to take an MPCS lock by calling a DSPLink API (not allowed)