

G9II

C1

FRENTE

Street / General

Walk-around photography. Markets, parks, towns, beaches. Point and shoot.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR

[] Mode dial

C1

[] Focus lever

AFS

front of camera

[] Drive mode

Single Shot

button + dial if needed

AJUSTAR NO CAMPO

> Rear dial

= Aperture

the ONLY thing you adjust

> f/2.8-4 → blurs background, isolates subject

> f/8-11 → everything sharp (street, architecture)

> Bright sun: close down (f/8+). Shade: open up (f/2.8-4)

> Camera sets shutter speed automatically — just shoot

--- fold here --- cut along card borders --- front above, back below (inverted) ---

G9II

C1

VERSO

Street / General

PARÂMETRO SALVO VALOR RACIONAL

Exposure mode	A (Aperture)	You pick DoF; camera handles speed
ISO	AUTO	Adapts to light
Af Mode	Full Area	Camera picks best focus point
Af Detection	ON	Auto subject detection
IS	ON Mode 1	Standard stabilization
Shutter Type	Auto (CSHTR)	Electronic 1st curtain
Photo Style	Standard	Neutral, balanced
WB	AWB	Adapts to lighting
Metering	Multi	Evaluative, whole frame
Flash	Forced Off	Available light only

DICAS

- Tap touchscreen to move Af point to your subject

- Phase-detect Af on Mkl is faster — more 'point and shoot' reliable

POR QUE ESTE MODO FUNCIONA

Aperture Priority: control the one creative decision (blur vs. sharpness), let the camera handle speed and ISO. The G9II's phase-detect Af is faster and more accurate than the Mkl, making this mode extremely reliable.

G9II

C2

FRENTE

Portrait / People

People, environmental portraits, group photos. Face/eye detection.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR

[] Mode dial

C2

[] Focus lever

AFS

front of camera

[] Drive mode

Single Shot

button + dial if needed

AJUSTAR NO CAMPO

> Rear dial

= Aperture

controls background blur (bokeh)

> f/1.7-2.8 → creamy blur for individual portraits

> f/5.6-8 → group photos (everyone in focus)

> Camera detects faces/eyes automatically — trust the AF

> Move your feet, don't zoom — step closer or farther

--- fold here --- cut along card borders --- front above, back below (inverted) ---

G9II

C2

VERSO

Portrait / People

PARÂMETRO SALVO VALOR RACIONAL

Exposure mode	A (Aperture)	Aperture controls bokeh
ISO	AUTO	Adapts to light
Af Mode	Full Area	Finds faces across frame
Af Detection	ON — Human	Face/eye detection
IS	ON Mode 1	Standard stabilization
Shutter Type	Auto (CSHTR)	Sharper, no vibration
Photo Style	Standard	Balanced skin tones
WB	AWB	Adapts to scene
Metering	Multi	Evaluative metering
Flash	Forced Off	Natural light

DICAS

- Open shade = most flattering portrait light

- Check eyes are sharp after each shot — re-shoot if AF missed

POR QUE ESTE MODO FUNCIONA

The G9II's phase-detect AF with Human detection locks onto eyes with sub-second precision, even at wide apertures. Wide aperture separates person from background. For groups, close to f/5.6 so everyone is in the focal plane.

G9II

C3-1

FRENTE

Landscape

Scenery, vistas, nature. Maximum sharpness, enhanced colors.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR

[] Mode dial

C3

then rear dial to select C3-1

[] Focus lever

AFS

front of camera

[] Drive mode

Single Shot

button + dial if needed

AJUSTAR NO CAMPO

> Rear dial

= Aperture

controls depth of field

> f/8-11 → SWEET SPOT — sharpest landscapes on MFT

> Never go past f/16 — diffraction softens the image

> Focus 1/3 into the scene, NOT on the horizon

> Golden hour (sunrise/sunset) = best landscape light

--- fold here --- cut along card borders --- front above, back below (inverted) ---

G9II

C3-1

VERSO

Landscape

PARÂMETRO SALVO VALOR RACIONAL

Exposure mode	A (Aperture)	You control DoF
ISO	AUTO	Stays at ISO 200 in good light
Af Mode	Full Area	Tap screen for focus point
Af Detection	OFF	No subject to detect
IS	ON Mode 1	Stabilized handheld
Shutter Type	Auto (CSHTR)	Sharper at slow speeds
Photo Style	Scenery	Enhanced greens, blues
WB	AWB	Or set Daylight for golden hour
Metering	Multi	Evaluative, whole frame
Flash	Forced OFF	Natural light

DICAS

- If shutter drops below 1/60, use tripod or brace firmly

- Scenery photo style boosts greens and blues for nature

POR QUE ESTE MODO FUNCIONA

On MFT, f/8-11 gives deep DoF without diffraction (starts at f/16). Focus 1/3 into the scene for maximum DoF coverage. Af Detection OFF because you're focusing on a distance, not a subject. Scenery style enhances landscape colors.

G9II

C3-2

FRENTE

Macro + Flash

Handheld close-ups: insects, frogs, small creatures. Off-camera flash.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR

[] Mode dial

[] Focus lever

[] Drive mode

[] Lens

[] Flash: X3 trigger

[] Flash: AD100Pro

[] Flash: ML-CD15

[] Const Preview

C3

MF

Single Shot

Olympus 60mm f/2.8

Mount on hot shoe

Turn ON

Attach to AD100Pro

Verify OFF

then rear dial to select C3-2

front of camera, bottom position

Costa Rica baseline

turn ON, check channel

match channel/group

diffuser

MENU — or EVF goes BLACK

AJUSTAR NO CAMPO

!! DO NOT TOUCH camera dials — all exposure settings are FIXED

> Flash power

> TTL OVEREXPOSES on MkII — always use X3 in Manual mode

> Too bright → lower power. Too dark → raise power

> Focus: rock your body in/out. Focus ring for coarse adjust

Adjust on X3 only

Manual mode, start 1/128

--- fold here --- cut along card borders --- front above, back below (inverted) ---

G9II

C3-2

VERSO

Macro + Flash

PARÁMETRO SALVO VALOR RACIONAL

Exposure mode

M (Manual)

Flash is the light

Aperture

f/20

Max DoF for tiny subjects. Go down to f/11 if you can focus easily

Shutter Speed

1/200s

Max flash sync speed

ISO

200 (fixed)

Low noise; flash provides light

Focus

MF

Rock to focus at macro distance

Shutter Type

Mechanical

Required for flash sync

Flash

ON / TTL

Flash fires every shot

IS

ON Mode 1

Helps frame while rocking

Const Preview

OFF

MkII EVF goes black with flash

Photo Style

Natural

Accurate nature colors

DICAS

- TTL overexposes because metering sees dark background and overcompensates

- Constant Preview simulates ambient in M mode — near-black with flash as main light

POR QUE ESTE MODO FUNCIONA

MkII CRITICAL: TTL overexposes at all macro distances. Use Manual 1/128 on X3. Constant Preview MUST be Off — MkII simulates ambient exposure in EVF, which is near-zero when flash is the main light. Flash fires at ~1/100000s, freezing all motion.

G9II

C3-3

FRENTE

Wildlife / Action

Birds, animals in motion. Continuous tracking, high-speed burst.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR

[] Mode dial

[] Focus lever

[] Drive mode

[] Lens

C3

AFC

Burst I (H)

Leica 100-400mm

then rear dial to select C3-3

front of camera, middle position

high-speed burst

f/4-6.3

AJUSTAR NO CAMPO

> Front dial

= Aperture

open wider in shade for less noise

> Rear dial

= Shutter speed

raise for faster subjects

> f/6.3 at 400mm (max). Open wider at shorter focal lengths

> 1/1000 baseline. Raise to 1/2000-1/4000 if enough light

> Half-press and HOLD to track — AF locks on animal

> Zoom out slightly — crop later. In frame > missed

> Accept ISO 6400-12800. Noisy sharp > clean blurry

--- fold here --- cut along card borders --- front above, back below (inverted) ---

G9II

C3-3

VERSO

Wildlife / Action

PARAMETRO SALVO VALOR RACIONAL

Exposure mode	M (Manual)	Lock aperture + speed; ISO floats
Aperture	f/6.3	Matched to lens max at 400mm
Shutter Speed	1/1000s	Freezes animal motion
ISO	AUTO (max 12800)	Camera adjusts
Min SS	1/1000s	Floor — won't go slower
AF Detection	ON — Animal	Detects animals/birds
AF Mode	Zone	Large tracking area
Shutter Type	Electronic	Max burst fps
IS	ON Mode 1	Standard stabilization
Photo Style	Standard	Balanced processing

DICAS

- Phase-detect Af on MklI recognizes birds/animals by shape, locks on eyes

- Zone Af gives generous area — no surgical framing needed in the heat of action

POR QUE ESTE MODO FUNCIONA

f/6.3 matches the Leica 100-400's max at 400mm. M + Auto ISO: lock both critical variables (aperture for light, speed for freezing), let ISO float. Phase-detect Af with Animal Detection tracks through the frame automatically.

C3-4
Tripod Macro Stack

Focus bracketing on tripod. Multiple shots merged in post for full sharpness.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR		
[] Mode dial	C3	then rear dial to select C3-4
[] Focus lever	MF	front of camera, bottom position
[] Drive mode	Single Shot	
[] Lens	90mm f/3.5 Macro	MC-20 is field variant
[] Tripod	REQUIRED	camera must be rock-steady
[] Flash: X3 trigger	Mount on hot shoe	turn ON
[] Flash: AD100Pro	Turn ON	match channel/group
[] Bracket settings	My Menu #6	set step + frame count
[] Const Preview	Verify OFF	or EVF goes BLACK

AJUSTAR NO CAMPO		
> Focus on the NEAREST point of the subject before starting		
> Flash power	Adjust on X3	start 1/128, raise if dark
> Don't touch camera after pressing shutter — 2s delay		
> ~2 fps mechanical shutter — 5 frames takes ~3 sec (hardware limit)		
> Stack in software after — camera captures the raw frames		

--- fold here --- cut along card borders --- front above, back below (inverted) ---

POR QUE ESTE MODO FUNCIONA		
Focus stacking: multiple shots at different focus distances, merged for full sharpness. At 1:1, f/8 gives ~0.5mm DoF per frame. f/8 over f/11 for sharper frames — stacking adds depth. IS Off prevents micro-shifts.		
DICAS		
- f/8 (not f/11): sharper individual frames — stacking provides the depth		
- IS Off on tripod: stabilizer micro-corrections shift frames out of alignment		
VALOR		
Exposure mode	M (Manual)	All fixed; flash is the light
Aperture	f/8	Sharper per-frame; stacking adds DoF
Shutter Speed	1/200s	Max flash sync speed
ISO	400 (fixed)	Consistent exposure across stack
Shutter Type	Mechanical	Required for flash
Flash	ON / TTL	Flash fires each frame
IS	OFF	IS causes micro-shifts on tripod
Bracketing	Focus Bracket ON	Camera shifts focus each frame
Shutter Delay	2s	Eliminates press vibration
Const Preview	OFF	MkII flash/EVF issue
i.Dynamic	OFF	Prevents per-frame differences

G9II

C3-5

FRENTE

Birds + Crop Zoom

Extra reach for distant birds. Digital 2x crop = 800mm equivalent at 400mm.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR

[] Mode dial

[] Focus lever

[] Drive mode

[] Lens

C3

AFC

Burst I (H)

Leica 100-400mm

then rear dial to select C3-5

front of camera, middle position

high-speed burst

f/4-6.3

AJUSTAR NO CAMPO

> Front dial

> Rear dial

> Use zoom lever to engage Crop Zoom (up to 2.0x)

> 400mm + 2.0x crop = 800mm MFT equivalent — extreme reach

> JPEG ONLY — no RAW available with Crop Zoom

> Same shooting technique as C3-3: half-press, track, burst

= Aperture

= Shutter speed

same as C3-3

same as C3-3

--- fold here --- cut along card borders --- front above, back below (inverted) ---

G9II

C3-5

VERSO

Birds + Crop Zoom

PARÂMETRO SALVO

VALOR

RACIONAL

Exposure mode	M (Manual)	Lock aperture + speed; ISO floats
Aperture	f/6.3	Matched to lens max at 400mm
Shutter Speed	1/1000s	Freezes bird motion. Raise if light allows
ISO	AUTO (max 12800)	Camera adjusts
Af Detection	ON — Animal	Bird detection
Af Mode	Zone	Large tracking area
Shutter Type	Electronic	Max fps
IS	ON Mode 1	Stabilization
Quality	FINE (JPEG)	Crop Zoom requires JPEG
Crop Zoom	ON (max 2.0x)	Digital magnification

DICAS

- Identical to C3-3 except for Crop Zoom ON and JPEG-only output

- Use C3-3 when you have enough reach; switch to C3-5 when you don't

POR QUE ESTE MODO FUNCIONA

Crop Zoom trades resolution for reach: camera uses center of sensor, doubling focal length. 400mm becomes 800mm equivalent. Trade-off: JPEG only, smaller file. Otherwise identical to C3-3.

G9II

C3-6
Lightning

FRENTE

Live View Composite on tripod. Each bolt is added to the image. Press Q to stop.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR

[] Mode dial

[] Focus lever

[] Drive mode

[] Tripod

[] Lens IS switch

C3

MF

Single Shot

REQUIRED

OFF

then rear dial to select C3-6

front of camera, bottom position

camera must be rock-steady

tripod — IS would cause shifts

AJUSTAR NO CAMPO

> Frame the scene. Pre-focus on landscape/horizon with MF

> Press shutter to START — camera takes continuous 4s frames

> Watch the screen: each bolt is ADDED (only new bright pixels)

> Press Q button to STOP when you have enough bolts

> If sky gets too bright, stop sooner — it builds up over time

!! DO NOT touch camera during session

--- fold here --- cut along card borders --- front above, back below (inverted) ---

G9II

C3-6
Lightning

PARÁMETRO SALVO VALOR RACIONAL

Exposure mode	M (Manual)	Full control for composite
Aperture	f/8	Landscape sharpness
Shutter Speed	4s per frame	Each sub-exposure duration
ISO	400 (max 1600)	Low noise; sky builds up
Shutter Type	Mechanical	LVC forces mechanical
LVC	ON	Keeps only new bright pixels
LVC Delay	2s	Prevents press vibration
IS	OFF	Tripod required
WB	Daylight	Fixed — prevents color shift
Aspect	16:9	Cinematic storm format
Long Exp NR	ON	Forced by LVC

DICAS

- LVC only adds pixels BRIGHTER than previous frame — sky stays dark, bolts accumulate

- Daylight WB is fixed (not AWB) to prevent color shifts between frames

POR QUE ESTE MODO FUNCIONA

Live View Composite: repeated 4s exposures, only adding brighter pixels. Sky stays dark while each bolt accumulates. One image with multiple bolts. Press Q to end.

G9II

C3-7

FRENTE

Indoor / Low Light

Museums, churches, quiet venues. Completely silent — no flash, no shutter sound.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR

[] Mode dial

[] Focus lever

[] Drive mode

[] Lens

C3

AFC

Single Shot

Lumix 12-35mm f/2.8

then rear dial to select C3-7

front of camera, middle position

AJUSTAR NO CAMPO

> Front dial

= Aperture

keep f/2.8 unless you need DoF

> Rear dial

= Shutter speed

don't go below 1/60 handheld

> Camera is COMPLETELY SILENT — safe for museums and quiet spaces

> Brace against wall, pillar, or doorframe in very low light

> If photos are blurry: accept higher ISO rather than slower shutter

--- fold here --- cut along card borders --- front above, back below (inverted) ---

G9II

C3-7

VERSO

Indoor / Low Light

PARÁMETRO SALVO VALOR RACIONAL

Exposure mode	M (Manual)	Control in tricky indoor light
Aperture	f/2.8	Wide open for max light
Shutter Speed	1/125s	Safe handheld speed
ISO	AUTO (max 12800)	Compensates for dim scenes
AF Detection	ON — Human	Detects people
AF Mode	Full Area	Finds subjects across frame
IS	ON Mode 1	Critical in low light
Silent Mode	ON	Zero mechanical noise
Shutter Type	Electronic	Forced by Silent Mode
Photo Style	Natural	Subtle processing

DICAS

- Silent Mode = truly invisible. Zero noise. Essential for museums/churches

- If subjects are static (paintings), can drop to 1/30 with good bracing

POR QUE ESTE MODO FUNCIONA

Silent Mode: zero mechanical noise, essential where shutter clicks are disruptive. f/2.8 wide open gathers max light. Auto ISO floats to 12800. Key field adjustment: shutter speed —

static subjects allow 1/30-1/60.

G9II

C3-8

FRENTE

Birds in Flight (BIF)

Fast-moving birds. 1/4000s freeze, tracking AF, panning stabilization.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR

[] Mode dial

[] Focus lever

[] Drive mode

[] Lens

C3

AFC

Burst I (H)

Leica 100-400mm

then rear dial to select C3-8

front of camera, middle position

high-speed burst

f/4-6.3

AJUSTAR NO CAMPO

> Front dial

> Rear dial

> IS Mode 2 = PANNING — only vertical axis stabilized

> 1/4000 baseline. Raise to 1/6000+ for hummingbirds

> Pre-focus on area where bird will fly. Track with smooth body motion

> Overcast sky is easier — harsh sun creates extreme contrast

= Aperture

= Shutter speed

usually leave at f/6.3 (max)

raise for very fast species

--- fold here --- cut along card borders --- front above, back below (inverted) ---

G9II

C3-8

PARÁMETRO SALVO VALOR RACIONAL

Birds in Flight (BIF)

VERSO

POR QUE ESTE MODO FUNCIONA

BIF is the most demanding scenario. 1/4000s freezes wing beats. Tracking AF follows across frame. IS Mode 2: vertical-only stabilization allows smooth panning without fighting horizontal tracking.

DICAS

- Tracking AF (not Zone) is more aggressive — follows across entire frame

- IS Mode 2 allows smooth horizontal panning. Mode 1 would fight the pan

Photo Style	Standard	Balanced
Drive	Burst I (H)	Captures wing positions
Shutter Type	Electronic	Max fps
IS	ON Mode 2 (pan)	Vertical stabilization only
AF Mode	Tracking	Follows bird across entire frame
AF Detection	ON — Animal	Bird detection + tracking
ISO	AUTO (max 12800)	Camera adjusts
Shutter Speed	1/4000s	Freezes wing beats
Aperture	f/6.3	Lens max at 400mm
Exposure mode	M (Manual)	Lock speed + aperture, ISO floats

G9II

C3-9

FRENTE

Video — Travel

Documentary, travel clips, vlogs. Fully automatic exposure — just press record.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR

[] Mode dial

[] Focus lever

[] Drive mode

[] Lens

C3

AFC

N/A

Lumix 12-35mm f/2.8

then rear dial to select C3-9

front of camera, middle position

video mode — drive not applicable

AJUSTAR NO CAMPO

> P mode — camera handles EVERYTHING automatically

> Just press the red record button and go

> Keep movements slow and smooth — jerky pans look amateur

> Avoid zooming while recording — almost never looks good

> Tap screen to shift AF to a different person

> Record 10-15 second clips. Shorter is better for editing

--- fold here --- cut along card borders --- front above, back below (inverted) ---

G9II

C3-9

Video — Travel

PARÁMETRO SALVO

VALOR

RACIONAL

Mode	Creative Video	Dedicated video mode
Exp Mode	P (Program)	Camera handles all exposure
Rec Quality	4K 30p	High res, natural frame rate
AF Detection	ON — Human	Follows people
AF Mode	Full Area	Camera picks focus
IS	ON Mode 1	Standard stabilization
E-Stab Video	STANDARD	Digital stab layer
Boost IS	OFF	Avoids excessive crop
Photo Style	Standard	Balanced look
Audio	Internal mic	Default levels

DICAS

- P mode = zero decisions while recording. Camera adjusts everything

- 4K 30p: high res for cropping. 30fps is natural for documentary

POR QUE ESTE MODO FUNCIONA

Program mode for video: zero decisions during recording. 4K 30p balances resolution with natural documentary look. E-Stab STANDARD adds digital stabilization without excessive crop.

G9II

C3-10

FRENTE

Video — Wildlife

Animals in motion. Manual exposure, tracking AF, strong stabilization.

!! SETUP FISICO -- VERIFICAR ANTES DE FOTOGRAFAR

[] Mode dial

[] Focus lever

[] Drive mode

[] Lens

C3

AFC

N/A

Leica 100-400mm

then rear dial to select C3-10

front of camera, middle position

video mode — drive not applicable

f/4-6.3

AJUSTAR NO CAMPO

> Front dial

> Rear dial

> Tracking AF follows the animal — tap screen to select target

> E-Stab HIGH crops slightly but gives much smoother footage

> Start recording BEFORE the action — you can trim, can't rewind

> Keep steady — at 400mm every shake is magnified

= Aperture

= Shutter speed

keep at 1/500 minimum

--- fold here --- cut along card borders --- front above, back below (inverted) ---

G9II

C3-10

VERSO

Video — Wildlife

PARÁMETRO SALVO VALOR RACIONAL

Mode	Creative Video	Dedicated video mode
Exp Mode	M (Manual)	Consistent exposure across clip
Rec Quality	4K 30p	High resolution
Aperture	f/6.3	Lens max at 400mm
Shutter Speed	1/500s	Freezes motion per frame
ISO	AUTO (max 12800)	Camera compensates
AF Detection	ON — Animal	Tracks animals
AF Mode	Tracking	Follows across frame
IS	ON Mode 1	Optical stabilization
E-Stab Video	HIGH	Strong digital stab (slight crop)

DICAS

- Manual exposure prevents brightness jumps when panning sky — forest

- 1/500s video balance: freezes per-frame motion without stuttery look

POR QUE ESTE MODO FUNCIONA

Manual for wildlife video: prevents exposure jumps across brightness zones. 1/500s balances motion freeze without stuttery look. E-Stab HIGH: slight crop, essential for handheld telephoto.