


Wireless Fidelity with bwfm(4)

Patrick Wildt

September 22, 2019


Who am I?

- OpenBSD developer
- ARM64-subtree maintainer
- LLVM-subtree updater
- SBC hoarder




Collection of devices

- Cubox-i
- Macbook
- Raspberry Pi 3
- Z83 Mini-PC



Milestones



Study

① Find documentation


- Search the web for datasheets (by chip name)
- git grep in various OS (chip name, vendor/product ID)
- Neither code nor datasheet? Quit now.
- Alternative: reverse engineering

② Study code and/or documentation to grasp concepts

- Attention: license concerns!

③ Realize it's going to be a long project

Full vs Soft (simplified)



brcm80211

ISC-licensed brcm80211 drivers (Linux):

brcmfmac	brcmsmac
FullMAC	SoftMAC
35 496 LoC	75 177 LoC

brcmsmac/phy/phy_n.c: 28 624 Lines Of Magic

Jobs


What do we **not** have to do?

- No beacons
- No frequency changes
- No MCS handling

What do we have to do?

- Initiate scan
- Configure SSID
- Configure keys
- Handle events
- Handle network packets

Skeleton



Dongle

① Started with SDIO

- But realized testing kernels will take too long
- Unsure if SDIO layer actually worked

② Bought a USB device

③ Started with the lower layers

④ Added PCIe/SDIO backend later



Write code that compiles


- ➊ Skeleton-driver
- ➋ Initialize bus access
- ➌ Try to figure out whether the device is alive
 - ➎ read chip id
 - ➎ read MAC address
 - ➎ receive an interrupt

USB


Configuration



Data



Data+Events



Configuration


Initiate Scan:

```
struct bwfm_escan_params *params;  
[...]  
bwfm_fwvar_var_set_data(sc, "escan",  
    params, params_size);
```


Connect to SSID:

```
struct bwfm_ext_join_params *params;  
[...]  
bwfm_fwvar_var_set_data(sc, "join",  
    params, sizeof(*params));
```

Connect to SSID



BCDC Packets




SDIO




SDIO Interrupt

- Shared pin: DAT[1]/IRQ
- Sampled as IRQ during *Interrupt Period*
- Some host controllers have troubles
- Workaround: externally routed GPIO




PCIe

- Packet-based
- Multiple Ringbuffers
 - TX Control Ring
 - TX RX-Post Ring
 - (Control, TX, RX) Complete Rings
 - n Flowrings



Package

- Read/write access to backplane
- Write Firmware & NVRAM
- Turn on/off ARM core
- Read dmesg



dmesg

```
hndarm_armr addr: 0x18002000, cr4_idx: 0
000000.001 RTE (SDIO-MSG BUF) 7.35.180.119 (r594535) on BCM4350 r8
@ 37.4/240.8/240.8MHz
000000.001 allocating a max of 255 rxcplid buffers
000000.002 pcimsgbuf0: Broadcom PCIE MSGBUF driver
000000.003 reclaim section 0: Returned 59036 bytes to the heap
000000.131 enable 1: q0 frmcnt 0, wrdcnt 0, q1 frmcnt 0, wrdcnt 0
000000.131 enable 1: q0 frmcnt 0, wrdcnt 0, q1 frmcnt 0, wrdcnt 0
000000.175 wl0: Broadcom BCM4350 802.11 Wireless Controller 7.35.180.119
(r594535)
000000.175 TCAM: 256 used: 255 exceed:0
000000.176 reclaim section 1: Returned 147512 bytes to the heap
000005.375 wl0: wlc_enable_probe_req: state down, deferring setting of
host flags
000005.413 wlc_bmac_switch_macfreq: 4350 need fix for 37.4Mhz
000005.421 wl0: wlc_enable_probe_req: state down, deferring setting of
host flags
000005.421 enable 1: q0 frmcnt 0, wrdcnt 0, q1 frmcnt 0, wrdcnt 0
```

Firmware Features

4356a2-roml/**pcie-ag-msgbuf-splitrx-p2p-pno-aoe-pktfilter-keepalive-sr-mchan-pktctx-proptxstatus-ampduhostreorder-lpc-pwropt-txbf-wl11u-mfp-tdls-amsdutx-sarctrl-proxd-hs20sta-rcc-wepso-ndoe-linkstat-gscan-hchk-logtrace-roamexp-rmon**

Version: 7.35.101.6 (r702795)

CRC: 4f3f65c5

Date: Sun 2017-06-04 16:51:38 PDT

Ucode Ver: 963.316

FWID: 01-5e8eb735


Tricky bits

- Flow-control
- Asynchronous control messages
- Asynchronous creation of flowrings
- net80211 Integration

Firmware

- Remote Control Message Injection (CVE-2016-0801):
Updated firmware in November 2017
- KRACK (October 2017):
Updated firmware in June 2018

(based on linux-firmware.git)



KRACK

```
/*
 * The firmware supplicant can handle the WPA
 * handshake for us, but we honestly want to
 * do this ourselves, so disable the firmware
 * supplicant and let our stack handle it.
 */
bwfm_fwvar_var_set_int(sc, "sup_wpa", 0);
```

NVRAM

Purpose:

- Provides configuration for the specific package
- Sets up antenna configuration, max dB, etc.


Needed on:

- PCIe (sometimes)
- SDIO (always)
- USB (not yet?)

Provided by:

- Hardware designer (in their git repo)
- EFI BIOS (in an EFI variable)

Current Status




Current Status

- Works as client
- Properly fast 802.11ac (Wi-Fi 5)
- Implemented on recent Macbooks
- Implemented on raspberry Pis
- Available as *official raspberry Pi USB Dongle* (while supplies last)
- Works as access point often enough

Future

- Better AP support
- Multi-AP support
- Suspend/Resume
- Firmware Signals
- Support for more devices

Questions?



OpenBSD