

## AUTO RS232 → ••) REL 🖽 DC AC f b % MkΩ Hz unF mAV


## ms8226.pdf (Mastech official document)

Mastech MS8226 serial protocol

2400 8n1

14 Bytes , watch out for serial IR receiver sending junk 15byte strings

First four bits of each byte are position in message , from 1-14 Last four bits are data , each bit represents one element on LCD  $\,$ 



Digits										
0	10			20	)		30	40	50	
01234	5678901	2	3456789	0	1234567	8	9012345	67890123456	789012345	
00110	1111101	0	0011111	0	0100111	1	1111111	000000000000000000000000000000000000000	00000100	034.8
00110	1111101	0	1011011	0	0111110	1	0011111	000000000000000000000000000000000000000	00000100	025.3
00110	1111101	0	1011011	0	0100111	1	0011111	000000000000000000000000000000000000000	00000100	024.3
00110	1111101	0	1011011	0	0000101	1	0111111	000000000000000000000000000000000000000	00000100	021.9
00110	1111101	0	1011011	0	0000101	1	0010101	000000000000000000000000000000000000000	00000100	021.7
00110	1111101	0	1011011	0	0000101	1	1111110	000000000000000000000000000000000000000	00000100	021.6
	444444	Ρ	3333333	Ρ	222222	Ρ	1111111			
	efadcgb	3	efadcgb	2	efadcgb	1	efadcgb	disp	lay	

Display

1 z 2 4.2.2014 12:27

(D)

C

```
20
 10
   30
    40
01234567890123456789012345678901234567890123456789012345
ADAR-|||||||||||||||||||unKDm%MBFORHAVHXXCXX
03
    d
    р
```

51 is probably low battery





## **Digital Multimeter**

pce-instruments.com/english

Order directly at the specialist. A huge range of measuring tools

2 z 2 4.2.2014 12:27