# Generic SR-IOV Device Support for Kernel Live Upgrade in Cloud Environment

jason.zeng@intel.com

### Disclaimers

No license (express or implied, by estoppel or otherwise) to any intellectual property rights is granted by this document.

Intel disclaims all express and implied warranties, including without limitation, the implied warranties of merchantability, fitness for a particular purpose, and non-infringement, as well as any warranty arising from course of performance, course of dealing, or usage in trade.

This document contains information on products, services and/or processes in development. All information provided here is subject to change without notice. Contact your Intel representative to obtain the latest forecast, schedule, specifications and roadmaps.

The products and services described may contain defects or errors known as errata which may cause deviations from published specifications. Current characterized errata are available on request. No product or component can be absolutely secure.

Copies of documents which have an order number and are referenced in this document may be obtained by calling 1-800-548-4725 or by visiting www.intel.com/design/literature.htm.

Intel and the Intel logo are trademarks of Intel Corporation or its subsidiaries in the U.S. and/or other countries.


\*Other names and brands may be claimed as the property of others.

© Intel Corporation

# Agenda

- Kernel Live Upgrade Recap
- SR-IOV Device Support
- Implementation

### Kernel Live Upgrade Recap



- Passthrough Device Support
  - Keep upstream devices alive
    - IOMMU
    - PCle switch/root-port
  - Keep Device HW alive
    - DMA/Interrupt
    - Other HW states


### SR-IOV Device Support – The problem

SR-IOV PF usually managed by host

PF HW state need to be preserved across kernel upgrade

- There are many PF vendors
  - Huge effort of vendor specific PF driver code change to preserve PF HW state

# The Generic Way – Put PF in a Special VM




- Passthrough PF to Special VM
- When kernel live upgrade happens
  - PF HW states preserved together with the Special VM

#### Steps:

- 1. From Host
  - Passthrough PF to Special VM
- 2. From Special VM
  - Create VFs
  - Bind VF driver to pci-stub driver
- 3. From Host
  - Assign VF to Normal VM
- I. From Normal VM
  - Bind VF driver to vendor's VF driver

## Implementation - Passthrough SR-IOV PF




#### Kernel VFIO driver

- Intercept NumVFs
- Intercept VF\_Enable & VF\_MSE in Control Register
- SR-IOV VF BAR support
  - VFIO device region
- Qemu
  - Enable SR-IOV capability handling in VFIO driver
  - SR-IOV VF BAR support
  - VF creation/destroy upon VM SR-IOV cap read/write

| Next Capability<br>Offset            | Capabilities<br>Version             | PCI Express Extended<br>Capability ID |
|--------------------------------------|-------------------------------------|---------------------------------------|
| SR-IOV Capabilities                  |                                     |                                       |
| SR-IOV Status                        |                                     | SR-IOV Control                        |
| TotalVFs(RO)                         |                                     | InitialVFs(RO)                        |
| RsvdP                                | Function<br>Dependency<br>Link (RO) | NumVFs(RW)                            |
| VF Stride(RO)                        |                                     | First VF Offset(RO)                   |
| VF Device ID                         |                                     | RsvdP                                 |
| Supported Page Size(RO)              |                                     |                                       |
| System Page Size(RW)                 |                                     |                                       |
| VF BAR0 (RW)                         |                                     |                                       |
| VF BAR1 (RW)                         |                                     |                                       |
| VF BAR2 (RW)                         |                                     |                                       |
| VF BAR3 (RW)                         |                                     |                                       |
| VF BAR4 (RW)                         |                                     |                                       |
| VF BAR5 (RW)                         |                                     |                                       |
| VF Migration State Array Offset (RO) |                                     |                                       |

### Flow: Create VFs from VM



### Status & Plan

- PF Passthrough POC
  - https://gitee.com/x56Jason/vmmfr-linux/tree/pfpt/
  - https://gitee.com/x56Jason/vmmfr-qemu/tree/pfpt/
- Next
  - ARI capability support?
  - Target openEuler-22.03-LTS-SP3?