.

.

-

.

•

.

```
BASIC MCS 8080 GATES/ALLEN/DAVIDUFF
F3 MAC 6=SEP=64 03:11
                                                                                   MACRO 47(113) 03:12 10-SEP-75 PAGE 13-3
RUN,GOTO,GOSUB,RETURN
    3408 004113' 001000 000312
3409 004114' 000000 004100'
3410 004115' 000000 004067'
3411 3412
                                                                                    49560
                                                                                                                                                                      FIF SO TIME TO TRADE
                                                                                                                     JZ
                                                                                                                                     EXCHOT
                                                                                    49580 IFE LENGTH=2.<
                                                                                    49600
49620
49640
49660
                                                                                                     ; HHEN AN "IF" TAKES A FALSE BRANCH IT MUST FIND THE APPROPRIATE "ELSE"; TO START EXECUTION AT, "DATA" COUNTS THE NUMBER OF "IF"S; IT SEES SO THAT THE "ELSE" CODE CAN MATCH "ELSE"S WITH; "IF"S, THE COUNT IS KEPT IN [0]
     3412
3413
3414
3415
    3416
3417
3418
3419
3420
                                                                                     49680
                                                                                     49700
               084116' 001000 000326
084117' 000000 000322
084120' 001000 000302
084121' 000000 004103'
084122' 001000 004103'
                                                                                                                                                                         IS IT AN "IF"
                                                                                    49740
                                                                                                                     JNZ
                                                                                                                                       REMER
                                                                                                                                                                       IF NOT, CONTINUE ON
     3421
3422
3423
3424
                                                                                                                                                                         ;SINCE "REN" CAN'T SMASH
;[D,E] WE HAVE TO BE CAREFUL
;SO ONLY IF B DOESN'T EGUAL
;ZERO WE INCREMENT D. (THE "IF" COUNT)
;CARRY ON IF (B) NOT ZERO
;JUPDATE [D);
                                                                                    49760
                                                                                                                                       В
     3425
3426
3427
3428
                                                                                    49800
49820
49840
49860
    5926
5927
204124' 001000 000212
5928
004125' 001000 000127
5929
004126' 001000 000305
3450 004127' 000000 004105'
3451 004130' 000000 004121'
5452
                                                                                                                      ADC
MOV
JMP
                                                                                                                                       D,A>
REMER>
                                                                                   49982 | MITHOUT STRINGS THERE IS NO NEED TO MATCH QUOTATIONS 49982 | MO A SEAN IS MADE FOR (8) OR ZERO 49988 | AND A SEAN IS MADE FOR (9) OR ZERO 49980 | DATA! XUN.
    3433
3434
3435
3436
                                                                                                                     3437
3438
     3439
3440
3441
                                                                                                                                       -01000,16
                                                                                                                                                                         ; MAKE [C] =0
; ZERO AND NO-OPERATION
                                                                                                    REM:
                                                                                     50000
                                                                                                                       XWD
     3442
                                                                                                     LOOPDR: MOV
     3442
3443
3444
3445
                                                                                                                      ORA
RZ
CMP
                                                                                                                                                                         JALWAYS STOP ON ZERU
                                                                                                                                       C
                                                                                                                                                                         ICHECK FOR ":" IN DATA
                                                                                     50080
     3446
                                                                                     50100
                                                                                                                       RZ
    3447
3448
3449
                                                                                                                                        H
LOOPDR>
                                                                                                                                                                         JLOOK AT NEXT CHARACTER
                                                                                                     PAGE
                                                                                     50160
```

F3	MAC	6=SEP=	64 03:11	"LET"				
3450				50180	SUBTTL	"LET"		
3451	004131	001000	000315	50200	LET:	CALL	PTRGET	IGET THE POINTER TO THE VARIABLE
3452	004132		006505*					
3453			004127					
3454				50220				INAMED IN TEXT AND PUT
3455				50240				IIT ON THE STACK. [H,L] REMAINS
3456				50260				THE TEXT POINTER AND A PSW ARE SETUP
3457				50280			Marie Mr.	; AS THE TERMINATING CHARACTER.
3458		001000		50300		SYNCHK	EQULTK	CHECK FOR "="
3459		000000	000560					
3460	004136			50320	REDINP:			
3461				50340	IFN	STRING,	<	
3462	004136	001000	000072	50360		LDA	VALTYP	
3463	0041374	999999	001543*					
3464	0041401	000000	004132*					
3465		001000		50380		PUSH	PSW>	
3466	004142		000325	50400		PUSH	D	
3467	0041431		000315	50420		CALL	FRMEVL	IGET THE VALUE OF THE FORMULA
3468	004144*		005336*	30460		CHEC	FRIETE	Age the target of the rounder
3469								
	004145	000000	004137	50000				ATURO FIG
3470				50440				INTO FAC
3471	004146	001000	000343	50460		XTHL		(H,L) =POINTER TO VARIABLE
3472				50480				TEXT POINTER TO ON TOP OF STACK
3473	004147		000042	50500		SHLD	TEMP	SAVE VARIABLE POINTER FOR "FOR"
3474	004150	000000	001603*					
3475	004151	999999	004144*					
3476				50520	IFN	STRING,	<	
3477	004152*	001000	000321	50540		POP	D	GET TEXT POINTER OFF
3478	004153*		000361	50560		POP	PSW	GET THE VALTYP OF THE
3479				50580				VARIABLE INTO (A)
3480	004154	001000	000325	50581		PUSH	D	IRESAVE THE TEXT-POINTER
3481	004134	001000	000223	50582	IFE	LENGTH-		The text of text
	0004554	001000	000376	50584	41.5	CPI	3	ISEE IF ITS A STRING
3482		001000		20204		CFI	3	ISEE IF ITS A STRING
3483		000000			*			
3484		001000		50586	INPCOM:		Н	SAVE THE POINTER AT THE VALUE POSITION
3485		001000		50588		JNZ	COPNUM	NUMERIC, SO FORCE IT AND COPY
3486	004161		004237					
3487	0041621	000000	004150					
3488	0041631	001000	000315	50590		CALL	CHKSTR>	MAKE SURE THE FORMULA WAS A STRING
3489	004164*	000000	000000×					
3490	004165		004161*					
3491				50600	IFN	LENGTH-	2.4	
3492				50620	** "	RAR		CARRY SET FOR STRING OFF
3493				50640		NAN		FOR NUMERIC
							CHKVAL	
3494				50660		CALL	LHKVAL	MAKE SURE VALTYP MATCHES CARRY
3495				50680				AND SET THE ZERO FLAG
3496				50700				JON A NUMERIC VALTYP
3497				50860		JZ	COPNUM	F A NUMBER COPY
3498				50880	INPCOM:		H>	ISAVE POINTER AT VARIABLE
3499	004166	001000	000052	50900		LHLD	FACLO	GET POINTER TO THE DESCRIPTOR OF THE RESUL
3500			001637					
3501	004170		004164					
3502	004171	901999	000345	50920		PUSH	н	SAVE THE POINTER AT THE DESCRIPTOR

BASIC MCS 8080 GATES/ALLEN/DAVIDUFF MACRO 47(113) 03:12 10-SEP-75 PAGE 14

•

- 3	MAC	6=SEP=	64 03:11	"LET"			EP#75 PAGE 1	
3503	004172*	001000	000043	50940		INX	н	
3504	004173	001000	000043	50960		INX	Н	
3505	004174	001000	000367	50980		PUSHM		
3506	004175*	001000	000321	51000		POP .	D	
3507	004176	001000	000052	51020		LHLD	STKTOP	SEE IF IT POINTS INTO STRING SPACE
3508	004177*	000000	001615*					
3509	004200	000000	004167*					
3510	004201*		000347	51040		COMPAR		JIF NOT DON'T COPY
3511	994292	001000	000321	51060		POP	D	GET BACK THE POINTER AT THE DESCRIPTOR
3512	0042031	001000	000322	51080		JNC	DNTCPY	JOON'T COPY LITERALS
3513	004204*	000000	004217*					
3514	004205*		004177*					
3515	9942961		000052	51100		LHLD	VARTAB	; NOW, SEE IF ITS A VARIABLE
3516	994207		001621					,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
3517	004210		004204*					
3518	004211		000347	51120		COMPAR		BY SEEING IF THE DESCRIPTOR
3519	004212		000153	51140		MOV	L,E	701
3520	0042131		000142	51160		MOV	H.O	
3521	004214	001000	000334	51180		CC	STRCPY	IS BEYOND [VARTAB], IF SO COPY
3522	004215		007601*	31100				110 OC. OLD TANKINGS 1 TO COLL
3523	004216		004207					
3524	004217		000032	51200	DNTCPY:	LDAY	D	JGET THE LENGTH AND SAVE IT
3525	004220*		000365	51220	DIVICETA	PUSH	PSW	ISINCE WE ARE GOING TO SET IT TO
3526	804558	001000	000363	51240		FUOR	FOW	10 SO FRETHP DOESN'T UPDATE FRETOP
3527	0000011	001000	000257	51260		XRA	A	
3528	004221	001000	SESESI	51280		***	^	SET IT TO 0 == ELIMINATING NULL STRING IN FRETMP IS HARMLESS
	0000001	0-1-00	000000			0.7.4.4	D	
3529	0042221	001000	000055	51300		STAX		PUT 0 IN THE LENGTH FIELD
3530	004223		000315	51320		CALL	FRETMP	FREE IT UP
3531	004224		010440*					
3532	004225		004215*			POP	8.011	
3533	994556		000361	51340			PSW	GET LENGTH BACK
3534	004227		000167	51360		MOV	M, A	REPLACE IT (FRETMP RETURNS (D,E) IN (H,L)
3535	004230		000353	51380		XCHG		PUT THE DESCRIPTOR POINTER BACK IN (D,E)
3536	004231	001000	000341	51400		POP	н	IGET THE PLACE OF THE NEW VARIABLE
3537				51420	IFN	LENGTH-		
3538				51440		CALL	MOVE>	COPY THE DESCRIPTOR
3539				51460	IFE	LENGTH=		
3540	004232		000315	51480		CALL	VMOVE>	
3541	004233		000000×					
3542	004234		004224					
3543	004235		000341	51500		POP	н	GET THE TEXT POINTER BACK
3544	004236	001000	000311	51520		RET>		
3545	004237			51540	COPNUM:			
3546				51560	IFE	LENGTH-	, <	
3547	004237		000346	51580		ANI	6	SETUP DISPATCH TO FORCE
3548	004240	000000	000006					
3549				51600				FORMULA TYPE TO CONFORM
3550				51620				ITO THE VARIABLE ITS BEING ASSIGNED TO
3551	004241	001000	000041	51640		LXI	H, FRCTBL	TABLE OF FORCE ROUTINES
3552	994242		000664			THE CONTRACT OF THE CONTRACT O		
3553	004243*		0042331					
3554	004244		000117	51660		MOV	C.A	; (B,C) =TWO BYTE OFFSET
3555	004245*		000006	51680		MVI	8,0	
2223		-0.000					-,-	

	CS 8080		LLEN/DAVIDOFF		47(113)	3112	10-SEP-75 PAGE	14-2
F3	MAC	6=SEP=	64 03:11	"LET"				
3556	004246		000000					
3557	004247	001000	000011	51700		DAD	В	
3558	0042501	001000	000176	51720		MOV	A,M	; [H,L] =ADDRESS TO GO TO
3559	004251	001000	000043	51740		INX	н	
3560	004252	001000	000146	51760		MOV	H,M	
3561	004253*	001000	000157	51780		MOV	L, A	
3562	004254*	001000	000001	51800		LXI	B, PUTVAL	RETURN TO PUTVAL
3563	004255	000000	004261*					
3564	004256	000000	004242*					
3565	004257	001000	000305	51820		PUSH	В	
3566	004260	001000	000351	51840		PCHL		DISPATCH TO FORCE
3567	004261	001000	000341	51860	PUTVAL	: POP	н	GET THE POINTER OF WHERE TO STORE
3568				51880				THE VALUE
3569	004262	001000	000345	51900		PUSH	н	ISAVE IT BACK
3570	0042631		000315	51920		CALL	VMOVMF>	MOVE THE VALUE IN
3571	004264	000000	000000×					
3572	004265	000000	004255*					
3573				51940	IFN	LENG	TH=2,<	
3574				51960		PUSH		ISAVE THE VARIABLE POINTER FOR "FOR"
3575				51980		CALL	MOVMF>	TRANSFER THE VALUE
3576	004266	001000	000321	52000		POP	0	"FOR" WANTS VARIABLE POINTER IN
3577	-			52020				(D,E) FOR FNDFOR
3578	004267*	001000	000341	52040		POP	н	GET THE TEXT POINTER
3579	004270		000311	52060		RET		
3580				52080	PAGE			

F3	MAC	6=SEP=	64 03:11	ON GOT	CODE			
3581				52100	SUBTTL	ON GOTO	CODE	
3582				52120	IFN	LENGTH,	<	
3583								
3584	0042711	001000	000315	52160	ONGOTO:	CALL	GETBYT	GET VALUE INTO (E)
3585	004272	000000	011020*					
3586	004273	000000	004264*					
3587	004274	001000	000176	52180		MOV	A.M	JGET THE TERMINATOR BACK
3588	004275	001000	000107	52200		MOV	B. A	ISAVE THIS CHARACTER FOR LATER
3589	904276	001000	000376	52220		CPI	GUSUTK	AN "DN GUSUB" PERHAPS?
3590	004277*	000000	000214					
3591	004300*	001000	000312	52240		JZ	ISGOSU	IYES, SOME FEATURE USE
3592	004301*	000000	004306					
3593	0043021	000000	004272*					
3594	004303*	001000	000317	52260		SYNCHK	GOTOTK	IOTHERWISE MUST BE "GOTO"
3595	004304*	999999	000210					
3596	004305*	001000	000053	52280		DCX	н	BACK UP CHARACTER POINTER
3597	004306*	001000	000113	52300	ISGOSU:	MOV	C.E	JGET COUNT INTO (C)
3598	004307	001000	000015	52320	LOOPON:	DCR	C	ISEE IF ENOUGH SKIPS
3599	004310*	001000	000170	52340		MOV	A,B	IPUT DISPATCH CHARACTER IN PLACE
3600	004311		000312	52360		JZ	GONES	IIF DONE, GO OFF
3601	0043121		003376*					
3602	004313		004301*					
3603	004314	001000	000315	52380		CALL	LINGTZ	JSKIP OVER A LINE #
3604	004315	999999	003643*					
3605	004316		0043121					
3606	004317		000376	52400		CPI	44	A COMMA
3607	0043201		000054					
3608	004321		000300	52420		RNZ		FIF A COMMA DOESN'T DELIMIT THE END OF
3609				52440				THE LAST LINE # MUST BE THE END OF THE LINE
3610	004322*	001000	000303	52460		JMP	LOOPON>	CONTINUE GOBBLING LINE #S
3611	0043231		004307*	-2100		-		,
3612	004324		004315*					
3613								
3614				52500	PAGE			

3	MAC	6=SEP=	64 03:11	IF	THEN COD	E		
3615				52520		IF T		
3616	004325	001000	000315	52540	IF:	CALL	FRMEVL	JEVALUATE A FORMULA
3617	004326	000000	005336*					
3618	0043271	000000	004323*					
3619				52560	IFE	LENGTH,		
3620				52580	IFN	STRING,		
3621				52600		LDA	VALTYP	GET VALUE TYPE INTO [A]
3622				52620		PUSH	PSW>>	ISAVE THE VALUE TYPE ON THE STACK
3623	004330	001000	000176	52640		MOV	A,M	IGET TERMINATING CHARACTER OF FORMULA
3624				52660	IFE	LENGTH,		
3625				52680		CALL	PUSHF	JONTO THE STACK
3626				52700		MVI	0.0	KEEPS RELATIONAL OPERATOR MEMORIES
3627				52720				ILESS THAN =4
3628				52740				JEQUAL =2
3629				52760				IGREATER THAN #1
3630				52780	LOOPIF:	SUI	GREATK	CHECK FOR A RELATIONAL OPERATOR
3631				52800		JC	ENDREL	INOPE
3632				52820	NUMREL	LESSTK-GF		NUMBER OF RELATIONAL OPERATORS
3633				52840		CPI	NUMREL	IIS THIS ONE OF THEM?
3634				52860		JNC	ENDREL	IND SEE WHAT WE HAVE
3635				52880		CPI	1	ISETUP BITS BY MAPPING
3636				52900		RAL	•	10 TO 1, 1 TO 2 AND 2 TO 4
3637				52920		ORA	D	JOR WITH EARLIER BITS
3638				52940		MOV	D.A	ISTORE NEW BITS
3639				52960		CHRGET		JGET NEW CHARACTER
3640				52980		JMP	LOOPIF	ISEE IF RELATIONAL
3641				53000	ENDREL:		A,D	JGET REALTIONAL MEMORIES
3642				53020		DRA	A	ISEE IF THERE ARE ANY
3643				53040		JZ	SNERR	INO RELATIONAL OPERATORS!
3644				53060		PUSH	PSW	SAVE RELATIONAL MEMORIES
3645				53080		CALL	FRMEVL>	PICK UP FIRST NON-RELATIONAL
3646				53100				CHARACTER AGAIN AND INTERPRET FORMUL
3647				53120				IANSWER LEFT IN FAC
3648	004331	001000	000376	53140	IFE	LENGTH-	2. <cpi 44<="" td=""><td>IA COMMA?</td></cpi>	IA COMMA?
3649	004332		000054	33140	***	Fritalines	11-014	I A COMMA
3650	0043331		000314	53160		CZ	CHRGTR>	IIF SO SKIP IT
3651	004334		003426*	33100		02	CHING IN P	III on out II
3652	004335		004326*					
3653	664333.	SABBABA	004350	53180	IFN	LENGTH,		
3654	004336	001000	000376	53200	71.14	CPI	GOTOTK	FALLOW "GOTO" AS WELL
			000210	33500		0.1	GOIUIK	AMPROM - GOLD. NO MEER
3655 3656	004337			53220		JZ	OKGOTO>	
				22550		3.2	0.0010>	
3657	004341		004346					
3658	004342		004334*			- CHAIRING	***************************************	
3659	004343		000317	53240		SYNCHK	THENTK	MUST HAVE A THEN
3660	004344		000245	E2245		DEN	u	
3661	004345	001000	000053	53260		DCX	н	
3662	004346"			53280	OKGOTO:			
3663				53300	IFE	LENGTH,		
3664				53320		POP	PSW	
3665				53340		POPR		POP OFF NUMBER
3666				53360	IFN	STRING,	4	
3667				53380		XTHL>		COMPARE FORMULA TYPES

•

F3	MAC	6=SEP=	64 03:11	IF	THEN CODE	E			
3668				53400	IFE	STRING.	401164	н>	SAVE THE TEXT POINTER
3669				53420	TLE	PUSH	PSW	H>	FRESAVE RELATIONAL MEMORIES
3670				53440	IFN	STRING,			THE DAVE HELATIONAL HENDRIES
3671				53460	TEM	LDA	VALTYP		JGET VALUE TYPE
3672				53480		CMP	H		I(H) HAS OLD VALTYP ARE THEY =?
3673				53500		JNZ	TMERR		IF NOT ITS A TYPE ERROR
3674				53520		ORA	A		ISEE WHAT TYPE IT WAS
3675				53540		JZ	NUMERE		ZERO MEANS IT WAS NUMERIC
3676				53560		CALL	STREMP		MUST BE STRING, SO STRING COMPARE
3677				53580		JMP	SKPNCM>		ISKIP OVER NUMERIC COMPARE
3678				53600	NUMCMP:		FCOMP		ICOMPARE THE 2 SIDE OF THE RELATION STATEMENT
3679				53620	SKPNCM:		A		BUILD RELATIONAL BITS
3680				53640	ON HOME	RAL			:LESS=4 EQUAL=2 GREATER=1
3681				53660					ISINCE CARRY IS ON DNLY IN
3682				53680					1377 CASE (FCOMP & STRCMP)
3683				53700		POP	В		IPOP OFF WHAT RELATIONAL OPERATOR WAS
3684				53720		ANA	8>		ISEE IF WE MATCHED
3685				53740	IFN	LENGTH.			Your I'm I I'm I'm I'm I'm I'm I'm I'm I'm I
3686				53742	IFE	LENGTH-			
3687	004346*	001000	000315	53744		CALL	VSIGN##>		
3688	004347	000000	000000×						
3689	004350*	999999	004341						
3690				53746	IFN	LENGTH-	2,4		
3691				53760		FSIGN>>			# 0=FALSE ALL OTHERS=TRUE
3692				53780	IFE	LENGTH,	<		70.0.00
3693				53800		POP	H>		POP OFF TEXT POINTER
3694				53820	IFE	LENGTH-			
3695	004351		000312	53840		JZ	FALSIF>		JHANDLE POSSIBLE "ELSE"
3696	004352								
3697	004353*	000000	004347*						
3698				53860	IFN	LENGTH-			
3699				53880		JZ	REM>		JIF TEST FAILED JUST SKIP REST OF THE LINE
3700	004354		000327	53900	DOCOND:				IPICK UP THE FIRST LINE # CHARACTER
3701	004355		000332	53920		JC	GOTO		ILINE NUMBER MEANS "GOTO"
3702	004356		004010						
	004357		004352'						
	004360		000303	53940		JMP	GONE 3		INTERPRET NEW STATEMENT
	004361								
3706	004362	000000	004356				420		
3707				53960	IFE	LENGTH-	2,4		
3708				53980	,				
3709				54000	, "ELSE	" HANDLE	R. HERE U	N PALSE	"IF" CONDITION
3710				54020					
3711	004363			54040	FALSIF:	MAI	D, 1		NUMBER OF "ELSE"S THAT MUST
3712	004364*	000000	000001	E0060					*DE CEEN MOATAN THEDEMENTS THE
3713 3714				54060 54080					BE SEEN. "DATA" INCREMENTS THIS
	0000164	001000	000716		expune.		DATA		COUNT EVERY TIME AN "IF" IS SEEN
	004365		000315 004072	54100	SKPMRF:	CALL	UATA		SKIP A STATEMENT
3716 3717	004366		004072						
3717	204367	RABBAR	864361°	E4434					THER TO STUCK THE PROMY OF BELGERO
				54120					;":" IS STUCK IN FRONT OF "ELSE"S ;SO THAT "DATA" WILL STOP BEFORE "ELSE" CLAUS
3719									

	BASIL	CS 8086	GATES/A	LLEN/DAVIDUFF	MACRO	17(113) 03:12 10-	SEP=75 PAGE	16=2						
•	F3	MAC		6-SEP-64 03:11		IF THEN CODE								
	3721	004370	001000	000267	54160	DRA	A	JEND OF LINE?						
•	3722	004371	001000	000310	54180	RZ		IF SO, NO "ELSE" CLAUSE						
	3723	0043721	001000	000327	54200	CHRGET		ISEE IF WE HIT AN "ELSE"						
	3724	004373*	001000	000376	54220	CPI	ELSETK							
•	3725	0043741	000000	0808580										
	3726	004375*	001000	000302	54240	JNZ	SKPMRF	INO, STILL IN THE "THEN" CLAUSE						
	3727	004376*	000000	004365*										
•	3728	004377*	000000	004366*										
	3729	004400*	001000	999925	54260	DCR	0	DECREMENT THE NUMBER OF "ELSE"S THAT						
	3730				54280			MUST BE SEEN						
•	3731	004401*	001000	000302	54300	JNZ	SKPMRF	ISKIP MORE IF HAVEN'T SEEN						
	3732	0044021	000000	004365*										
	3733	004403*	000000	004376*										
•	3734				54320			; ENOUGH						
	3735	004404*	001000	000303	54340	JMP	DOCOND>	FOUND THE RIGHT "ELSE" GO EXECUTE						
	3736		000000	004354*										
9	3737		000000	004402*										
	3738													
	3739				54380	PAGE								
-	3,0,													