plan9-hardware

Synthesizing and building the plan9-hardware component requires the Convey PDK to be installed. The design is implemented in Chisel, with some VHDL blackboxes down the module hierarchy. All configuration and parameterization happens in CarpParameters.scala. The ChiselParameters trait is an interface specifying the parameters required for the design to synthesize. It also provides semi-sane defaults. Instead of changing the values in the trait directly, it is recommended to create a new object implementing the trait and change only the necessary values on a per-need basis, as shown below.

package plan9

```
object SpecificExperimentParams extends CarpParameters {
   SNNTopology = Array(4,2,1)
}
```

To have the new parameters be used during synthesis, SpecificExperimentParams has to be passed as a parameter when instantiating the Carp-module in Plan9.scala.

```
val carpParams = SpecificExperimentParams
...
val carp = Module(new Carp(carpParams))
```

Make targets

make gen_verilog

make gen_verilog invokes the Scala Build Tool and generates Verilog based on the Chisel code.

make all

Invokes the gen_verilog target before starting the Xilinx flow, incorporating the plan9-design into the Convey Application Engine wrapper and generating a bitfile. This takes a while.

make release

Moves the bitfile resulting from the previous run of make all to the hardware.released directory. Useful for archiving separate versions of the design.

make install

Deploys the most recently synthesized bitfile to the Convey personalities folder. This target requires the following variables to be set in phys/Makefile:

- PERSONALITY: Personality ID.
- RELEASE_DIR: Path to the folder into which make release moves bitfiles.
- CNY_DIR: Path to the root Convey directory, usually /opt/convey.

make test

Run all simulation tests in src/test/scala/.

Setup on NTNU servers

moog.idi.ntnu.no has been used for synthesis. The Convey cards are installed on lobo.idi.ntnu.no. This means that the bitfile resulting from make all will have to be manually moved between the two, instead of using the make install target. This can be done with the following commands:

```
$ scp moog.idi.ntnu.no:/home/<your_user>/<path_to_plan9>/\
    hardware.released/<release_tag>/ae_fpga.tgz ./
$ scp ae_fpga.tgz lobo.idi.ntnu.no:/opt/convey/\
    personalities/65002.0.0.4.0/
```