```
DATA
                                   :00
188 C683 00
189
                     *****************
190
                     * part of READ BLOCK (D340) *
191
                     *****************
192
193
194
                     * Exit if no loading errors.
195
                    MPT26
                             XTHL
196 C6B4 E3
197 C6B5 37
                             STC
                                             CY=1: no error
                             POP
                                   H
198 C686 E1
                    LBK30
                                   D
199 C6B7 D1
                             POP
200 C6B8 C1
                             POP
                                   B
201 C6B9 C9
                             RET
202
203
                     ***********
                     * part of 2E8DE *
204
                     ***********
205
206
                                             Go and set screen bits for
207 C6BA CD91CE
                    SPT02
                            CALL
                                   :CE91
                                             mode 1
208
                             JMP
                                             (2) Pop all, ret.
209 C6BD C338E1
                                   :E138
                     *
210
                     *
211
212
                       *** BANK SWITCHING ***
213
                       214
215
216
                    ***************
217
                    * MATH. RESTART (RST 4) *
218
                    ****************
219
220
221
                    * This, and the following routines, switch the
                    * paged banks of ROM. They are entered via
222
                    * RST x: DATA xx instructions.
223
224
                    MARST
                            POP
225 C6C0 E1
                                  н
226 C6C1 F3
                            DI
                                             Save HL
227 C6C2 224300
                            SHLD
                                   :0043
228 C6C5 F5
                            PUSH
                                  PSW
229 C6C6 E1
                            POP
                                             Save PSW
230 C6C7 224100
                            SHLD
                                   :0041
                                             ROM bank 1 select bits
231 C6CA 2640
                            MVI
                                  H.: 40
                                             Offset of start HW/SW vector
232 C6CC 3AD400
                            LDA
                                   : 00D4
233
                    * ROM BANK SWITCHING:
234
235
                    * This routine is generally used by all Restarts
236
                    * using ROM bank switching.
237
238
                    MRS10
                            XTHL
239 CACE E3
                                             Add entry number
240 C6D0 86
                            ADD
                                  M
                                  H
241 C6D1 23
                            INX
242 C6D2 E3
                            XTHL
                                             Complete entry point address
243 C6D3 6F
                            VOM
                                  L.A
                                             Old bank select port status
244 C6D4 3A4000
                            LDA
                                  :0040
                                  PSW
                                             Save it
                            PUSH
245 C6D7 F5
                            ANI
                                  : 3F
                                             Keep other bits
246 C6D8 E63F
247 C6DA B4
                                             Add new select bits
                            ORA
                                  H
                                            Update memory
248 C6DB 324000
                            STA
                                  :0040
```

:FD06

Update port

STA

249 CADE 3206FD

311

```
MVI
                                   H,: E0
250 C6E1 26E0
                                             Restore HL, PSW; switch bank
                            CALL
                                   : C6F2
251 C6E3 CDF2C6
252
                    * Return from switched bank:
253
254
                            XTHL
                                             Return to old bank
255 C6E6 E3
                            PUSH
                                   PSW
256 C6E7 F5
                                             Get old bank
                            MOV
                                   A,H
257 C6E8 7C
                                             Reinstate memory
                            STA
                                   :0040
258 C6E9 324000
                                   :FD06
                                             Re-instate port
                            STA
259 C6EC 3206FD
                            POP
                                   PSW
260 C6EF F1
                                  H
                            POP
261 C6F0 E1
                                             Return to caller
                            RET
262 C6F1 C9
263
                    * SWITCH TO ROM BANK:
264
265
                    * HL and PSW are restored. On exit, the
266
                    * program switches to the selected ROM bank.
267
                    * After return from this bank, the program
268
                    * continues on C6E6.
269
270
                    MRDCL
                            PUSH
                                 Н
271 C6F2 E5
                            LHLD
                                  :0041
272 C6F3 2A4100
                            PUSH
                                  H
273 C6F6 E5
                            POP
                                  PSW
                                             Restore A,F
274 C6F7 F1
                            LHLD
                                   :0043
                                             Restore H, L
275 C6F8 2A4300
276 C6FB FB
                            EI
                                             Switch to selected bank
                            RET
277 C6FC C9
278
                    *********
279
                    * SCREEN RESTART (RST 5) *
280
                    ****************
281
282
                    * From SRS10 also used by RST 1.
283
284
                    SCRST
                            POP
                                  H
285 C6FD E1
286 C6FE F3
                            DI
                            SHLD
                                  :0043
                                             Save HL
287 C6FF 224300
                                  PSW
288 C702 F5
                            PUSH
                                             ROM bank 2 select bits
                            MVI
                                   A,:80
289 C703 3E80
                            POP
                                  H
290 C705 E1
                    SRS10
                                             Save PSW
                                   :0041
291 0706 224100
                            SHLD
                            MOV
                                  H, A
292 C709 67
                            XRA
                                  A
293 C70A AF
                                   : C6CF
                                             Switch to new bank
                            JMP
294 C70B C3CFC6
295
                    **************
296
                    * UTILITY/ENCODE (RST 1) *
297
                    ***************
298
299
                            POP
                    UTRST
                                  H
300 C70E E1
301 C70F F3
                            DI
                                  :0043
                                             Save HL
302 C710 224300
                            SHLD
                                  PSW
                            PUSH
303 C713 F5
                                             ROM bank 3 select bits
                            MVI
                                  A. : CO
304 C714 3EC0
                                             Switch to ROM bank 3
                                   : C705
305 C716 C305C7
                            JMP
306
307
308
                       -----------
                    *** BASIC HANDLER ***
309
                       ______
310
                    *
```