IO.Bindings Namespace

Wrapper classes for C shared libraries.

Classes

	Class	Description
	libsimpleio	Wrapper class for the Linux Simple I/O Library `libsimpleio.so`

libsimpleio Class

Wrapper class for the Linux Simple I/O Library `libsimpleio.so`

Inheritance Hierarchy

SystemObject IO.Bindingslibsimpleio

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static class libsimpleio
```

The libsimpleio type exposes the following members.

Methods

	Name	Description
	ADC_close	Close a Linux IIO A/D converter input device.
	ADC_get_name	Get the subsystem name for the specified Linux IIO A/D converter device.
	ADC_open	Open a Linux IIO A/D converter input device.

	ADC_read	Read a Linux IIO A/D converter input device.
S	DAC_close	Close a Linux IIO D/A converter output device.
S	DAC_get_name	Get the subsystem name for the specified Linux IIO D/A converter device.
S	DAC_open	Open a Linux IIO D/A converter output device.
S	DAC_write	Write to a Linux IIO D/A converter output device.
S	EVENT_close	Close an `epoll` event dispatcher.
S	EVENT_modify_fd	Modify a file registration.
S	EVENT_open	Open an `epoll` event dispatcher.
S	EVENT_register_fd	Register a file descriptor with an `epoll` event dispatcher.
S	EVENT_unregister_fd	Unregister a file from an `epoll` dispatcher.
S	EVENT_wait	Wait for events from an `epoll` dispatcher.
S	GPIO_chip_info	Get GPIO chip information.

	GPIO_close	Close a Linux GPIO pin device.
	GPIO_configure	Configure a Linux GPIO pin.
	GPIO_line_close	Close a single GPIO line.
	GPIO_line_event	Read an edge trigger event from single GPIO line.
	GPIO_line_info	Get GPIO line information.
	GPIO_line_open	Open a single GPIO line.
	GPIO_line_read	Read the state of a single GPIO line.
	GPIO_line_write	Write the state of a single GPIO line.
	GPIO_open	Open a Linux GPIO pin device.
	GPIO_read	Read a Linux GPIO pin.
	GPIO_write	Write a Linux GPIO pin.
	HIDRAW_close	Close a Linux raw HID.
	HIDRAW_get_info	Get Linux raw HID bus type, vendor ID, and product ID.

	HIDRAW_get_name	Get Linux raw HID name string.
S	HIDRAW_open1	Open a Linux raw HID device by device node name.
S	HIDRAW_open2	Open a Linux raw HID device by vendor ID and product ID.
S	HIDRAW_open3	Open a Linux raw HID device by vendor ID and product ID and serial number.
S	HIDRAW_receive	Get a 64-byte report from a Linux HID.
S	HIDRAW_send	Send a 64-byte report to a Linux HID.
S	I2C_close	Close a Linux I^2C bus controller device.
S	I2C_open	Open a Linux I^2C bus controller device.
S	I2C_transaction	Send bytes to and/or receive bytes from an I^2C slave device.
S	IPV4_ntoa	Convert an IPv4 address to a dotted notation string (*e.g.* 1.2.3.4).

	IPV4_resolve	Resolve a domain name to an IPv4 host address.
	LINUX_closelog	Close the connection to the `syslog` service.
	LINUX_command	Execute a shell command string.
	LINUX_detach	Detach the process and run it in the background.
	LINUX_drop_privileges	Drop process privileges to those of the specified user. **Remarks** Only a process running at superuser privilege is allowed to drop privileges.
	LINUX_errno	Fetch the value of `errno`.
	LINUX_openlog	Open a connection to the `syslog` service.
	LINUX_poll	Wait for an event on one or more files.
	LINUX_strerror	Retrieve the error message for a particular `errno` error code.

	LINUX_syslog	Send a message to the `syslog` service.
S	LINUX_usleep	Sleep for the specified number of microseconds.
S	PWM_close	Close a Linux PWM output device.
S	PWM_configure	Configure a Linux PWM output device.
S	PWM_open	Open a Linux PWM output device.
S	PWM_write	Set a Linux PWM output device duty cycle.
S	SERIAL_close	Close a Linux serial port device.
S	SERIAL_open	Open a Linux serial port device.
S	SERIAL_receive	Receive data from a Linux serial port device.
S	SERIAL_send	Send data to a Linux serial port device.
S	SPI_close	Close a Linux SPI device.
S	SPI_open	Open a Linux SPI device.
S	SPI_transaction	Send bytes to and/or

		receive bytes from a Linux SPI device.
S	STREAM_decode_frame	Decode a frame.
S	STREAM_encode_frame	Encode a frame.
S	STREAM_receive_frame	Receive an encoded frame.
S	STREAM_send_frame	Send an encoded frame.
S	TCP4_accept	Start TCP server and wait for a single connection.
S	TCP4_close	Close a TCP connection.
S	TCP4_connect	Connect to a TCP server.
S	TCP4_receive	Receive bytes from TCP peer.
S	TCP4_send	Send bytes to TCP peer.
S	TCP4_server	Start a TCP server and fork for each connection.
S	UDP4_close	Close a UDP socket.
S	UDP4_open	Open a UDP socket.
S	UDP4_receive	Receive a UDP datagram.
S	UDP4_send	Send a UDP datagram.
S	WATCHDOG_close	Close a Linux watchdog

		timer device.
S	WATCHDOG_get_timeout	Query a Linux watchdog timer device.
S	WATCHDOG_kick	Reset the watchdog timer.
S	WATCHDOG_open	Open a Linux watchdog timer device.
S	WATCHDOG_set_timeout	Change the watchdog timer period.

Top

Fields

	Name	Description
S	GPIO_DIRECTION_INPUT	Input data direction.
S	GPIO_DIRECTION_OUTPUT	Out data direction.
S	GPIO_DRIVER_OPENDRAIN	Open drain (sink only) output driver.
S	GPIO_DRIVER_OPENSOURCE	Open source (source only) output driver
S	GPIO_DRIVER_PUSHPULL	Push-pull (source and sink) output driver.
S	GPIO_EDGE_BOTH	Interrupt on both edges.
S	GPIO_EDGE_FALLING	Interrupt on falling

		edge.
S	GPIO_EDGE_NONE	Interrupts are disabled.
S	GPIO_EDGE_RISING	Interrupt on rising edge.
S	GPIO_EVENT_REQUEST_BOTH	Enable GPIO input interrupt on both edges.
S	GPIO_EVENT_REQUEST_FALLING	Enable GPIO input interrupt on falling edge.
S	GPIO_EVENT_REQUEST_NONE	Disable GPIO input interrupt.
S	GPIO_EVENT_REQUEST_RISING	Enable GPIO input interrupt on rising edge.
S	GPIO_LINE_INFO_ACTIVE_LOW	GPIO line is configured as active low (inverted).
S	GPIO_LINE_INFO_KERNEL	GPIO line is being used by the kernel.
S	GPIO_LINE_INFO_OPEN_DRAIN	GPIO line is configured as open drain (current sink only).
S	GPIO_LINE_INFO_OPEN_SOURCE	GPIO line is

		configured as open source (current source only).
S	GPIO_LINE_INFO_OUTPUT	GPIO line is configured as an output.
S	GPIO_LINE_REQUEST_ACTIVE_HIGH	Select GPIO line polarity active high (normal).
S	GPIO_LINE_REQUEST_ACTIVE_LOW	Select GPIO line polarity active low (inverted).
S	GPIO_LINE_REQUEST_INPUT	Select GPIO line direction input.
S	GPIO_LINE_REQUEST_OPEN_DRAIN	Select GPIO line driver open drain (current sink only).
S	GPIO_LINE_REQUEST_OPEN_SOURCE	Select GPIO line driver open source (current source only).
S	GPIO_LINE_REQUEST_OUTPUT	Select GPIO line direction output.
S	GPIO_LINE_REQUEST_PUSH_PULL	Select GPIO line driver push-pull (current source and sink).
S	GPIO_POLARITY_ACTIVEHIGH	Active high (normal)

		polarity.
S	GPIO_POLARITY_ACTIVELOW	Active low (inverted) polarity.
S	INADDR_ANY	IPv4 address for binding to all network interfaces.
S	INADDR_BROADCAST	IPv4 broadcast address.
S	INADDR_LOOPBACK	IPv4 address for binding to the loopback interface (aka `localhost`).
S	LOG_ALERT	Action must be taken immediately.
S	LOG_AUTH	Security/authorization messages.
S	LOG_AUTHPRIV	Securit/authorization messages.
S	LOG_CONS	Write directly to the system console if there is an error while sending to the system logger.
S	LOG_CRIT	Critical condition.
S	LOG_CRON	`cron` daemon messages.

S	LOG_DAEMON	System daemons.
S	LOG_DEBUG	Debug message.
S	LOG_EMERG	System is unusable.
S	LOG_ERR	Error condition.
S	LOG_FTP	`FTP` daemon messages.
S	LOG_INFO	Informational message.
S	LOG_KERN	Kernel messages.
S	LOG_LOCAL0	Reserved for local use.
S	LOG_LOCAL1	Reserved for local use.
S	LOG_LOCAL2	Reserved for local use.
S	LOG_LOCAL3	Reserved for local use.
S	LOG_LOCAL4	Reserved for local use.
S	LOG_LOCAL5	Reserved for local use.
S	LOG_LOCAL6	Reserved for local use.

S	LOG_LOCAL7	Reserved for local use.
S	LOG_LPR	Line printer subsystem
S	LOG_MAIL	Mail system.
S	LOG_NDELAY	Open the connection immediately. Do not wait until `syslog()` is called for the first time.
S	LOG_NEWS	Network news subsystem
S	LOG_NOTICE	Normal but significant condition.
S	LOG_NOWAIT	Don't wait for child processes that may have been created while logging the message. (Not applicable to `glibc`.)
S	LOG_ODELAY	Do not open the connection immediately. Wait until `syslog()` is called for the first time.
S	LOG_PERROR	Also log the message

		to `stderr`.
	LOG_PID	Include the caller's PID (process ID) with each message.
	LOG_PROGNAME	Use the program name for the identity string.
	LOG_SYSLOG	Messages generated internally by syslogd
	LOG_USER	Random user-level messages.
	LOG_UUCP	UUCP subsystem
	LOG_WARNING	Warning condition.
	MSG_DONTROUTE	Don't use a gateway to send out the packet, send to hosts only on directly connected networks.
	MSG_DONTWAIT	Enables nonblocking operation; if the operation would block, `EAGAIN` or `EWOULDBLOCK` is returned.
	MSG_MORE	The caller has more data to send. This flag informs the kernel to

		package all of the data sent in calls with this flag set into a single datagram which is transmitted only when a call is performed that does not specify this flag.
S	POLLERR	An error occurred.
S	POLLHUP	Peer closed connection.
S	POLLIN	There is data to read.
S	POLLNVAL	File descriptor is invalid.
S	POLLOUT	Writing is now possible.
S	POLLPRI	There is urgent data to read.
S	PWM_POLARITY_ACTIVEHIGH	Configure the PWM output as active high (normal).
S	PWM_POLARITY_ACTIVELOW	Configure the PWM output as active low (inverted).
S	SERIAL_PARITY_EVEN	Request even parity checking.

	SERIAL_PARITY_NONE	Disable parity checking.
	SERIAL_PARITY_ODD	Request odd parity checking.
	SPI_AUTO_CS	Use hardware slave select.

Top

See Also

Reference

IO.Bindings Namespace

libsimpleio Methods

The libsimpleio type exposes the following members.

Methods

	Name	Description
	ADC_close	Close a Linux IIO A/D converter input device.
	ADC_get_name	Get the subsystem name for the specified Linux IIO A/D converter device.
	ADC_open	Open a Linux IIO A/D converter input device.
	ADC_read	Read a Linux IIO A/D converter input device.
	DAC_close	Close a Linux IIO D/A converter output device.
	DAC_get_name	Get the subsystem name for the specified Linux IIO D/A converter device.
	DAC_open	Open a Linux IIO D/A

		converter output device.
S	DAC_write	Write to a Linux IIO D/A converter output device.
S	EVENT_close	Close an `epoll` event dispatcher.
S	EVENT_modify_fd	Modify a file registration.
S	EVENT_open	Open an `epoll` event dispatcher.
S	EVENT_register_fd	Register a file descriptor with an `epoll` event dispatcher.
S	EVENT_unregister_fd	Unregister a file from an `epoll` dispatcher.
S	EVENT_wait	Wait for events from an `epoll` dispatcher.
S	GPIO_chip_info	Get GPIO chip information.
S	GPIO_close	Close a Linux GPIO pin device.
S	GPIO_configure	Configure a Linux GPIO pin.
S	GPIO_line_close	Close a single GPIO line.

S	GPIO_line_event	Read an edge trigger event from single GPIO line.
S	GPIO_line_info	Get GPIO line information.
S	GPIO_line_open	Open a single GPIO line.
S	GPIO_line_read	Read the state of a single GPIO line.
S	GPIO_line_write	Write the state of a single GPIO line.
S	GPIO_open	Open a Linux GPIO pin device.
S	GPIO_read	Read a Linux GPIO pin.
S	GPIO_write	Write a Linux GPIO pin.
S	HIDRAW_close	Close a Linux raw HID.
S	HIDRAW_get_info	Get Linux raw HID bus type, vendor ID, and product ID.
S	HIDRAW_get_name	Get Linux raw HID name string.
S	HIDRAW_open1	Open a Linux raw HID device by device node name.
S		

	HIDRAW_open2	Open a Linux raw HID device by vendor ID and product ID.
S	HIDRAW_open3	Open a Linux raw HID device by vendor ID and product ID and serial number.
S	HIDRAW_receive	Get a 64-byte report from a Linux HID.
S	HIDRAW_send	Send a 64-byte report to a Linux HID.
S	I2C_close	Close a Linux I^2C bus controller device.
S	I2C_open	Open a Linux I^2C bus controller device.
S	I2C_transaction	Send bytes to and/or receive bytes from an I^2C slave device.
S	IPV4_ntoa	Convert an IPv4 address to a dotted notation string (*e.g.* 1.2.3.4).
S	IPV4_resolve	Resolve a domain name to an IPv4 host address.
S	LINUX_closelog	Close the connection to the `syslog` service.
S		

	LINUX_command	Execute a shell command string.
S	LINUX_detach	Detach the process and run it in the background.
S	LINUX_drop_privileges	Drop process privileges to those of the specified user. **Remarks** Only a process running at superuser privilege is allowed to drop privileges.
S	LINUX_errno	Fetch the value of `errno`.
S	LINUX_openlog	Open a connection to the `syslog` service.
S	LINUX_poll	Wait for an event on one or more files.
S	LINUX_strerror	Retrieve the error message for a particular `errno` error code.
S	LINUX_syslog	Send a message to the `syslog` service.
S	LINUX_usleep	Sleep for the specified

		number of microseconds.
S	PWM_close	Close a Linux PWM output device.
S	PWM_configure	Configure a Linux PWM output device.
S	PWM_open	Open a Linux PWM output device.
S	PWM_write	Set a Linux PWM output device duty cycle.
S	SERIAL_close	Close a Linux serial port device.
S	SERIAL_open	Open a Linux serial port device.
S	SERIAL_receive	Receive data from a Linux serial port device.
S	SERIAL_send	Send data to a Linux serial port device.
S	SPI_close	Close a Linux SPI device.
S	SPI_open	Open a Linux SPI device.
S	SPI_transaction	Send bytes to and/or receive bytes from a Linux SPI device.
S		

	STREAM_decode_frame	Decode a frame.
S	STREAM_encode_frame	Encode a frame.
S	STREAM_receive_frame	Receive an encoded frame.
S	STREAM_send_frame	Send an encoded frame.
S	TCP4_accept	Start TCP server and wait for a single connection.
S	TCP4_close	Close a TCP connection.
S	TCP4_connect	Connect to a TCP server.
S	TCP4_receive	Receive bytes from TCP peer.
S	TCP4_send	Send bytes to TCP peer.
S	TCP4_server	Start a TCP server and fork for each connection.
S	UDP4_close	Close a UDP socket.
S	UDP4_open	Open a UDP socket.
S	UDP4_receive	Receive a UDP datagram.
S	UDP4_send	Send a UDP datagram.

	WATCHDOG_close	Close a Linux watchdog timer device.
	WATCHDOG_get_timeout	Query a Linux watchdog timer device.
	WATCHDOG_kick	Reset the watchdog timer.
	WATCHDOG_open	Open a Linux watchdog timer device.
	WATCHDOG_set_timeout	Change the watchdog timer period.

Top

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioADC_close Method

Close a Linux IIO A/D converter input device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static void ADC_close(
        int fd,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioADC_get_name Method

Get the subsystem name for the specified Linux IIO A/D converter device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void ADC_get_name(
        int chip,
        StringBuilder name,
        int size,
        out int error
)
```

Parameters

chip
Type: SystemInt32
Linux IIO device number.

name
Type: System.TextStringBuilder
Destination buffer.

size
Type: SystemInt32
Size of destination buffer.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioADC_open Method

Open a Linux IIO A/D converter input device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void ADC_open(
        int chip,
        int channel,
        out int fd,
        out int error
)
```

Parameters

chip
Type: SystemInt32
Linux IIO device number.

channel
Type: SystemInt32
Input channel number.

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioADC_read Method

Read a Linux IIO A/D converter input device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void ADC_read(
        int fd,
        out int sample,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

sample
Type: SystemInt32
Analog sample data.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioDAC_close Method

Close a Linux IIO D/A converter output device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public static void DAC_close(
        int fd,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioDAC_get_name Method

Get the subsystem name for the specified Linux IIO D/A converter device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void DAC_get_name(
        int chip,
        StringBuilder name,
        int size,
        out int error
)
```

Parameters

chip
Type: SystemInt32
Linux IIO device number.

name
Type: System.TextStringBuilder
Destination buffer.

size
Type: SystemInt32
Size of destination buffer.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioDAC_open Method

Open a Linux IIO D/A converter output device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static void DAC_open(
        int chip,
        int channel,
        out int fd,
        out int error
)
```

Parameters

chip
Type: SystemInt32
Linux IIO device number.

channel
Type: SystemInt32
Output channel number.

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioDAC_write Method

Write to a Linux IIO D/A converter output device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void DAC_write(
        int fd,
        int sample,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

sample
Type: SystemInt32
Analog sample data.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioEVENT_close Method

Close an `epoll` event dispatcher.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void EVENT_close(
        int epfd,
        out int error
)
```

Parameters

epfd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioEVENT_modify_fd Method

Modify a file registration.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void EVENT_modify_fd(
        int epfd,
        int fd,
        int events,
        int handle,
        out int error
)
```

Parameters

epfd
Type: SystemInt32
File descriptor for the dispatcher.

fd
Type: SystemInt32
File descriptor to register for events.

events
Type: SystemInt32
Events to register for. May be a sum of the individual event flags.

handle

Type: SystemInt32
Event handle.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioEVENT_open Method

Open an `epoll` event dispatcher.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static void EVENT_open(
        out int epfd,
        out int error
)
```

Parameters

epfd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioEVENT_register_fd Method

Register a file descriptor with an `epoll` event dispatcher.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void EVENT_register_fd(
        int epfd,
        int fd,
        int events,
        int handle,
        out int error
)
```

Parameters

epfd
Type: SystemInt32
File descriptor for the dispatcher.

fd
Type: SystemInt32
File descriptor to register for events.

events
Type: SystemInt32
Events to register for. May be a sum of the individual event flags.

handle

Type: SystemInt32
Event handle.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioEVENT_unregister_fd Method

Unregister a file from an `epoll` dispatcher.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void EVENT_unregister_fd(
        int epfd,
        int fd,
        out int error
)
```

Parameters

epfd
Type: SystemInt32
File descriptor for the dispatcher.>

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioEVENT_wait Method

Wait for events from an `epoll` dispatcher.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void EVENT_wait(
        int epfd,
        out int fd,
        out int events,
        out int handle,
        int timeoutms,
        out int error
)
```

Parameters

epfd
Type: SystemInt32
File descriptor for the displatcher.

fd
Type: SystemInt32
File descriptor the event is applicable to.

events
Type: SystemInt32
Events that occurred. May be a sum of the individual event flags.

handle

Type: SystemInt32
Event handle provided whent the file descriptor was registered.

timeoutms

Type: SystemInt32
Time in milliseconds to wait for an event.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_chip_info Method

Get GPIO chip information.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void GPIO_chip_info(
        int chip,
        StringBuilder name,
        int namesize,
        StringBuilder label,
        int labelsize,
        out int lines,
        out int error
)
```

Parameters

chip
Type: SystemInt32
GPIO chip number.

name
Type: System.TextStringBuilder
GPIO chip name.

namesize

Type: SystemInt32
Maximum size of name.

label

Type: System.TextStringBuilder
GPIO chip label.

labelsize

Type: SystemInt32
Maximum size of label.

lines

Type: SystemInt32
Number of GPIO lines.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_close Method

Close a Linux GPIO pin device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static void GPIO_close(
        int fd,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_configure Method

Configure a Linux GPIO pin.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static void GPIO_configure(
        int pin,
        int direction,
        int state,
        int edge,
        int polarity,
        out int error
)
```

Parameters

pin
Type: SystemInt32
Pin number.

direction
Type: SystemInt32
Data direction.

state
Type: SystemInt32
Initial GPIO output state.

edge

Type: SystemInt32

Interrupt edge for input pin.

polarity

Type: SystemInt32

Polarity

error

Type: SystemInt32

Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioGPIO_line_close Method

Close a single GPIO line.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void GPIO_line_close(
        int fd,
        out int error
)
```

Parameters

fd
Type: SystemInt32
Linux file descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_line_event Method

Read an edge trigger event from single GPIO line.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void GPIO_line_event(
        int fd,
        out int state,
        out int error
)
```

Parameters

fd
Type: SystemInt32
Linux file descriptor.

state
Type: SystemInt32
State of the GPIO line after the edge trigger event.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioGPIO_line_info Method

Get GPIO line information.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static void GPIO_line_info(
        int chip,
        int line,
        StringBuilder name,
        int namesize,
        StringBuilder label,
        int labelsize,
        out int error
)
```

Parameters

chip
Type: SystemInt32
GPIO chip number.

line
Type: SystemInt32
GPIO line number.

name

Type: System.TextStringBuilder
GPIO line name.

namesize

Type: SystemInt32
Maximum size of name.

label

Type: System.TextStringBuilder
GPIO line label.

labelsize

Type: SystemInt32
Maximum size of label.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_line_open Method

Open a single GPIO line.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void GPIO_line_open(
        int chip,
        int line,
        int flags,
        int events,
        int state,
        out int fd,
        out int error
)
```

Parameters

chip
Type: SystemInt32
GPIO chip number.

line
Type: SystemInt32
GPIO line number.

flags

Type: SystemInt32
GPIO line configuration flags.

events

Type: SystemInt32
GPIO line event flags.

state

Type: SystemInt32
Initial GPIO output state.

fd

Type: SystemInt32
Linux file descriptor.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_line_read Method

Read the state of a single GPIO line.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void GPIO_line_read(
        int fd,
        out int state,
        out int error
)
```

Parameters

fd
Type: SystemInt32
Linux file descriptor.

state
Type: SystemInt32
State of the GPIO line.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioGPIO_line_write Method

Write the state of a single GPIO line.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void GPIO_line_write(
        int fd,
        int state,
        out int error
)
```

Parameters

fd
Type: SystemInt32
Linux file descriptor.

state
Type: SystemInt32
State of the GPIO line.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioGPIO_open Method

Open a Linux GPIO pin device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void GPIO_open(
        int pin,
        out int fd,
        out int error
)
```

Parameters

pin
Type: SystemInt32
Pin number.

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioGPIO_read Method

Read a Linux GPIO pin.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void GPIO_read(
        int fd,
        out int state,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

state
Type: SystemInt32
Pin state.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioGPIO_write Method

Write a Linux GPIO pin.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void GPIO_write(
        int fd,
        int state,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

state
Type: SystemInt32
Pin state.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioHIDRAW_close Method

Close a Linux raw HID.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void HIDRAW_close(
        int fd,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioHIDRAW_get_info Method

Get Linux raw HID bus type, vendor ID, and product ID.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void HIDRAW_get_info(
        int fd,
        out int bustype,
        out int vendor,
        out int product,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

bustype
Type: SystemInt32
Bus type.

vendor
Type: SystemInt32
Vendor ID.

product

Type: SystemInt32
Product ID.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioHIDRAW_get_name Method

Get Linux raw HID name string.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void HIDRAW_get_name(
        int fd,
        StringBuilder name,
        int size,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

name
Type: System.TextStringBuilder
Destination buffer.

size
Type: SystemInt32
Size of destination buffer.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioHIDRAW_open1 Method

Open a Linux raw HID device by device node name.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void HIDRAW_open1(
        string devname,
        out int fd,
        out int error
)
```

Parameters

devname
Type: SystemString
Device node name.

fd
Type: SystemInt32
Device node name.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioHIDRAW_open2 Method

Open a Linux raw HID device by vendor ID and product ID.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void HIDRAW_open2(
        int VID,
        int PID,
        out int fd,
        out int error
)
```

Parameters

VID
Type: SystemInt32
Vendor ID.

PID
Type: SystemInt32
Product ID.

fd
Type: SystemInt32
File descriptor.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioHIDRAW_open3 Method

Open a Linux raw HID device by vendor ID and product ID and serial number.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void HIDRAW_open3(
        int VID,
        int PID,
        string serial,
        out int fd,
        out int error
)
```

Parameters

VID
Type: SystemInt32
Vendor ID.

PID
Type: SystemInt32
Product ID.

serial
Type: SystemString
Serial number.

fd

Type: SystemInt32

File descriptor.

error

Type: SystemInt32

Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioHIDRAW_receive Method

Get a 64-byte report from a Linux HID.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void HIDRAW_receive(
        int fd,
        byte[] buf,
        int bufsize,
        out int count,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

buf
Type: SystemByte
Destination buffer.

bufsize
Type: SystemInt32
Destination buffer size.

count

Type: SystemInt32
Number of bytes actually received.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioHIDRAW_send Method

Send a 64-byte report to a Linux HID.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void HIDRAW_send(
        int fd,
        byte[] buf,
        int bufsize,
        out int count,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

buf
Type: SystemByte
Source buffer.

bufsize
Type: SystemInt32
Source buffer size.

count
Type: SystemInt32
Number of bytes actually sent.

error

Type: SystemInt32

Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioI2C_close Method

Close a Linux I²C bus controller device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void I2C_close(
        int fd,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioI2C_open Method

Open a Linux I²C bus controller device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void I2C_open(
        string devname,
        out int fd,
        out int error
)
```

Parameters

devname
Type: SystemString
Device node name.

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioI2C_transaction Method

Send bytes to and/or receive bytes from an I^2C slave device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void I2C_transaction(
        int fd,
        int slaveaddr,
        byte[] cmd,
        int cmdlen,
        byte[] resp,
        int resplen,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

slaveaddr
Type: SystemInt32
Slave address.

cmd

Type: SystemByte
Source buffer.

cmdlen

Type: SystemInt32
Source buffer size.

resp

Type: SystemByte
Response buffer.

resplen

Type: SystemInt32
Response buffer size.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioIPV4_ntoa Method

Convert an IPv4 address to a dotted notation string (*e.g.* 1.2.3.4).

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void IPV4_ntoa(
        int host,
        StringBuilder buf,
        int bufsize,
        out int error
)
```

Parameters

host
Type: SystemInt32
IPv4 host address

buf
Type: System.TextStringBuilder
Destination buffer.

bufsize
Type: SystemInt32
Destination buffer size.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioIPV4_resolve Method

Resolve a domain name to an IPv4 host address.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void IPV4_resolve(
        string hostname,
        out int host,
        out int error
)
```

Parameters

hostname
Type: SystemString
Host name to resolve.

host
Type: SystemInt32
IPv4 host address.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioLINUX_closelog Method

Close the connection to the `syslog` service.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void LINUX_closelog(
        out int error
)
```

Parameters

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLINUX_command Method

Execute a shell command string.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void LINUX_command(
        string cmd,
        out int error
)
```

Parameters

cmd
Type: SystemString
Command string.

error
Type: SystemInt32
Error code.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLINUX_detach Method

Detach the process and run it in the background.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static void LINUX_detach(
        out int error
)
```

Parameters

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLINUX_drop_privileges Method

Drop process privileges to those of the specified user.

Remarks

Only a process running at superuser privilege is allowed to drop privileges.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void LINUX_drop_privileges(
        string username,
        out int error
)
```

Parameters

username
Type: SystemString
User privileges to assume.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioLINUX_errno Method

Fetch the value of `errno`.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static int LINUX_errno()
```

Return Value

Type: Int32
Current value of `errno`.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLINUX_openlog Method

Open a connection to the `syslog` service.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void LINUX_openlog(
        string id,
        int options,
        int facility,
        out int error
)
```

Parameters

id
Type: SystemString
Program identifier.

options
Type: SystemInt32
Logging options.

facility
Type: SystemInt32
Logging facility identifier.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLINUX_poll Method

Wait for an event on one or more files.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static void LINUX_poll(
        int numfiles,
        int[] files,
        int[] events,
        int[] results,
        int timeoutms,
        out int error
)
```

Parameters

numfiles
Type: SystemInt32
Number elements in each of the following arrays.

files
Type: SystemInt32
File descriptors.

events
Type: SystemInt32
Events to wait for on each file descriptor.

results

Type: SystemInt32
Events that occurred on each file descriptor.

timeoutms

Type: SystemInt32
Milliseconds to wait for an event to occur. A value of -1 means wait forever and a value of 0 means do not wait at all.

error

Type: SystemInt32
Error code.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLINUX_strerror Method

Retrieve the error message for a particular `errno` error code.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void LINUX_strerror(
        int error,
        StringBuilder buf,
        int bufsize
)
```

Parameters

error
Type: SystemInt32
Error code.

buf
Type: System.TextStringBuilder
Destination buffer.

bufsize
Type: SystemInt32
Destination buffer size.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioLINUX_syslog Method

Send a message to the `syslog` service.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void LINUX_syslog(
        int priority,
        string msg,
        out int error
)
```

Parameters

priority
Type: SystemInt32
Message priority

msg
Type: SystemString
Message to send.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioLINUX_usleep Method

Sleep for the specified number of microseconds.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static void LINUX_usleep(
        int microsecs,
        out int error
)
```

Parameters

microsecs
Type: SystemInt32
Number of microseconds to sleep.

error
Type: SystemInt32
Error code.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioPWM_close Method

Close a Linux PWM output device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void PWM_close(
        int fd,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioPWM_configure Method

Configure a Linux PWM output device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void PWM_configure(
        int chip,
        int channel,
        int period,
        int ontime,
        int polarity,
        out int error
)
```

Parameters

chip
Type: SystemInt32
Chip number.

channel
Type: SystemInt32
Channel number.

period
Type: SystemInt32
Pulse period in microseconds.

ontime

Type: SystemInt32

Initial on time in microseconds.

polarity

Type: SystemInt32

PWM output polarity (0 for active low/inverted or 1 for active high/normal).

error

Type: SystemInt32

Error code. Zero upon success or an `errno` value upon failure.

Remarks

On many platforms two more more PWM outputs may share the same clock generator, so configuring different PWM pulse periods may not be possible.

Remarks

Not all platforms support active low (inverted) PWM outputs.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioPWM_open Method

Open a Linux PWM output device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void PWM_open(
        int chip,
        int channel,
        out int fd,
        out int error
)
```

Parameters

chip
Type: SystemInt32
Chip number.

channel
Type: SystemInt32
Channel number.

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioPWM_write Method

Set a Linux PWM output device duty cycle.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void PWM_write(
        int fd,
        int ontime,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

ontime
Type: SystemInt32
On time in microseconds.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioSERIAL_close Method

Close a Linux serial port device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static void SERIAL_close(
        int fd,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioSERIAL_open Method

Open a Linux serial port device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void SERIAL_open(
        string devname,
        int baudrate,
        int parity,
        int databits,
        int stopbits,
        out int fd,
        out int error
)
```

Parameters

devname
Type: SystemString
Device node name.

baudrate
Type: SystemInt32
Baud rate.

parity
Type: SystemInt32
Parity setting (0 to 2).

databits

Type: SystemInt32
Word size setting (5 to 8).

stopbits

Type: SystemInt32
Number of stop bits (1 or 2).

fd

Type: SystemInt32
File descriptor.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioSERIAL_receive Method

Receive data from a Linux serial port device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void SERIAL_receive(
        int fd,
        byte[] buf,
        int bufsize,
        out int count,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

buf
Type: SystemByte
Destination buffer.

bufsize
Type: SystemInt32
Destination buffer size.

count

Type: SystemInt32
Number of bytes actually received.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioSERIAL_send Method

Send data to a Linux serial port device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void SERIAL_send(
        int fd,
        byte[] buf,
        int bufsize,
        out int count,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

buf
Type: SystemByte
Source buffer.

bufsize
Type: SystemInt32
Source buffer size.

count
Type: SystemInt32
Number of bytes actually sent.

error

Type: SystemInt32

Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioSPI_close Method

Close a Linux SPI device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void SPI_close(
        int fd,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioSPI_open Method

Open a Linux SPI device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void SPI_open(
        string devname,
        int mode,
        int wordsize,
        int speed,
        out int fd,
        out int error
)
```

Parameters

devname
Type: SystemString
Device node name.

mode
Type: SystemInt32
SPI transfer mode (0 .. 3)

wordsize
Type: SystemInt32
SPI transfer word size (8, 16, or 32).

speed

Type: SystemInt32
SPI transfer speed in Hz.

fd

Type: SystemInt32
File descriptor.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

Remarks

The Linux kernel create a device nodes for each SPI slave device, of the form `/dev/spidevX.Y` where `X` is the SPI bus controller number and `Y` is the SPI slave select number.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioSPI_transaction Method

Send bytes to and/or receive bytes from a Linux SPI device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void SPI_transaction(
        int fd,
        int csfd,
        byte[] cmd,
        int cmdlen,
        int delayus,
        byte[] resp,
        int resplen,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

csfd
Type: SystemInt32
Chip select file descriptor.

cmd

Type: SystemByte
Source buffer.

cmdlen

Type: SystemInt32
Source buffer size.

delayus

Type: SystemInt32
Delay in microseconds between the write and read operations.

resp

Type: SystemByte
Destination buffer.

resplen

Type: SystemInt32
Destination buffer size.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioSTREAM_decode_frame Method

Decode a frame.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void STREAM_decode_frame(
        byte[] src,
        int srclen,
        byte[] dst,
        int dstsize,
        out int dstlen,
        out int error
)
```

Parameters

src
Type: SystemByte
Source buffer.

srclen
Type: SystemInt32
Source buffer size.

dst
Type: SystemByte
Destination buffer.

dstsize

Type: SystemInt32

Destination buffer size.

dstlen

Type: SystemInt32

Size of decoded frame.

error

Type: SystemInt32

Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioSTREAM_encode_frame Method

Encode a frame.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void STREAM_encode_frame(
        byte[] src,
        int srclen,
        byte[] dst,
        int dstsize,
        out int dstlen,
        out int error
)
```

Parameters

src
Type: SystemByte
Source buffer.

srclen
Type: SystemInt32
Source buffer size.

dst
Type: SystemByte
Destination buffer.

dstsize

Type: SystemInt32

Destination buffer size.

dstlen

Type: SystemInt32

Size of encoded frame.

error

Type: SystemInt32

Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioSTREAM_receive_frame Method

Receive an encoded frame.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void STREAM_receive_frame(
        int fd,
        byte[] buf,
        int bufsize,
        out int count,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptior.

buf
Type: SystemByte
Destination buffer.

bufsize
Type: SystemInt32
Destination buffer size.

count

Type: SystemInt32
Number of bytes actually received.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioSTREAM_send_frame Method

Send an encoded frame.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void STREAM_send_frame(
        int fd,
        byte[] buf,
        int bufsize,
        out int count,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

buf
Type: SystemByte
Source buffer.

bufsize
Type: SystemInt32
Source buffer size.

count

Type: SystemInt32
Number of bytes actually sent.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioTCP4_accept Method

Start TCP server and wait for a single connection.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void TCP4_accept(
        int host,
        int port,
        out int fd,
        out int error
)
```

Parameters

host
Type: SystemInt32
IPv4 address, of the interface to listen on. Use 0.0.0.0 to listen on all interfaces.

port
Type: SystemInt32
TCP port number.

fd
Type: SystemInt32
File descriptor.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioTCP4_close Method

Close a TCP connection.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void TCP4_close(
        int fd,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioTCP4_connect Method

Connect to a TCP server.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void TCP4_connect(
        int host,
        int port,
        out int fd,
        out int error
)
```

Parameters

host
Type: SystemInt32
IPv4 host address.

port
Type: SystemInt32
TCP port number.

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioTCP4_receive Method

Receive bytes from TCP peer.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void TCP4_receive(
        int fd,
        byte[] buf,
        int bufsize,
        out int count,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

buf
Type: SystemByte
Destination buffer.

bufsize
Type: SystemInt32
Destination buffer size.

count
Type: SystemInt32
Number of bytes actually received.

error

Type: SystemInt32

Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioTCP4_send Method

Send bytes to TCP peer.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void TCP4_send(
        int fd,
        byte[] buf,
        int bufsize,
        out int count,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

buf
Type: SystemByte
Source buffer.

bufsize
Type: SystemInt32
Source buffer size.

count
Type: SystemInt32
Number of bytes actually sent.

error

Type: SystemInt32

Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioTCP4_server Method

Start a TCP server and fork for each connection.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void TCP4_server(
        int host,
        int port,
        out int fd,
        out int error
)
```

Parameters

host
Type: SystemInt32
IPv4 address, of the interface to listen on. Use 0.0.0.0 to listen on all interfaces.

port
Type: SystemInt32
TCP port number.

fd
Type: SystemInt32
File descriptor.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioUDP4_close Method

Close a UDP socket.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static void UDP4_close(
        int fd,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioUDP4_open Method

Open a UDP socket.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void UDP4_open(
        int host,
        int port,
        out int fd,
        out int error
)
```

Parameters

host
Type: SystemInt32
IPv4 host address.

port
Type: SystemInt32
UDP port number.

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioUDP4_receive Method

Receive a UDP datagram.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void UDP4_receive(
        int fd,
        out int host,
        out int port,
        byte[] buf,
        int bufsize,
        int flags,
        out int count,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

host
Type: SystemInt32
Source IPv4 host address.

port
Type: SystemInt32
Source UDP port number.

buf

Type: SystemByte

Destination buffer.

bufsize

Type: SystemInt32

Destination buffer size.

flags

Type: SystemInt32

Flags for the Linux `recvfrom()` system call.

count

Type: SystemInt32

Number of bytes actually received.

error

Type: SystemInt32

Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioUDP4_send Method

Send a UDP datagram.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void UDP4_send(
        int fd,
        int host,
        int port,
        byte[] buf,
        int bufsize,
        int flags,
        out int count,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

host
Type: SystemInt32
Destination IPv4 host address.

port
Type: SystemInt32
Destination UDP port number.

buf

Type: SystemByte

Source buffer.

bufsize

Type: SystemInt32

Source buffer size.

flags

Type: SystemInt32

Flags for the Linux `sendto()` system call.

count

Type: SystemInt32

Number of bytes actually sent.

error

Type: SystemInt32

Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioWATCHDOG_close Method

Close a Linux watchdog timer device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void WATCHDOG_close(
        int fd,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioWATCHDOG_get_timeout Method

Query a Linux watchdog timer device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void WATCHDOG_get_timeout(
        int fd,
        out int timeout,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

timeout
Type: SystemInt32
Timeout period in seconds.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioWATCHDOG_kick Method

Reset the watchdog timer.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void WATCHDOG_kick(
        int fd,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioWATCHDOG_open Method

Open a Linux watchdog timer device.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void WATCHDOG_open(
        string devname,
        out int fd,
        out int error
)
```

Parameters

devname
Type: SystemString
Device node name.

fd
Type: SystemInt32
File descriptor.

error
Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioWATCHDOG_set_timeout Method

Change the watchdog timer period.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void WATCHDOG_set_timeout(
        int fd,
        int newtimeout,
        out int timeout,
        out int error
)
```

Parameters

fd
Type: SystemInt32
File descriptor.

newtimeout
Type: SystemInt32
Requested timeout period in seconds.

timeout
Type: SystemInt32
Actual timeout period in seconds.

error

Type: SystemInt32
Error code. Zero upon success or an `errno` value upon failure.

Remarks

Not all platforms allow changing the timeout period. Some platforms may not allow *increasing* the period.

See Also

Reference
libsimpleio Class
IO.Bindings Namespace

libsimpleio Fields

The libsimpleio type exposes the following members.

Fields

	Name	Description
S	GPIO_DIRECTION_INPUT	Input data direction.
S	GPIO_DIRECTION_OUTPUT	Out data direction.
S	GPIO_DRIVER_OPENDRAIN	Open drain (sink only) output driver.
S	GPIO_DRIVER_OPENSOURCE	Open source (source only) output driver
S	GPIO_DRIVER_PUSHPULL	Push-pull (source and sink) output driver.
S	GPIO_EDGE_BOTH	Interrupt on both edges.
S	GPIO_EDGE_FALLING	Interrupt on falling edge.
S	GPIO_EDGE_NONE	Interrupts are disabled.
S	GPIO_EDGE_RISING	Interrupt on rising edge.

S	GPIO_EVENT_REQUEST_BOTH	Enable GPIO input interrupt on both edges.
S	GPIO_EVENT_REQUEST_FALLING	Enable GPIO input interrupt on falling edge.
S	GPIO_EVENT_REQUEST_NONE	Disable GPIO input interrupt.
S	GPIO_EVENT_REQUEST_RISING	Enable GPIO input interrupt on rising edge.
S	GPIO_LINE_INFO_ACTIVE_LOW	GPIO line is configured as active low (inverted).
S	GPIO_LINE_INFO_KERNEL	GPIO line is being used by the kernel.
S	GPIO_LINE_INFO_OPEN_DRAIN	GPIO line is configured as open drain (current sink only).
S	GPIO_LINE_INFO_OPEN_SOURCE	GPIO line is configured as open source (current source only).
S	GPIO_LINE_INFO_OUTPUT	GPIO line is configured as an output.

S	GPIO_LINE_REQUEST_ACTIVE_HIGH	Select GPIO line polarity active high (normal).
S	GPIO_LINE_REQUEST_ACTIVE_LOW	Select GPIO line polarity active low (inverted).
S	GPIO_LINE_REQUEST_INPUT	Select GPIO line direction input.
S	GPIO_LINE_REQUEST_OPEN_DRAIN	Select GPIO line driver open drain (current sink only).
S	GPIO_LINE_REQUEST_OPEN_SOURCE	Select GPIO line driver open source (current source only).
S	GPIO_LINE_REQUEST_OUTPUT	Select GPIO line direction output.
S	GPIO_LINE_REQUEST_PUSH_PULL	Select GPIO line driver push-pull (current source and sink).
S	GPIO_POLARITY_ACTIVEHIGH	Active high (normal) polarity.
S	GPIO_POLARITY_ACTIVELOW	Active low (inverted) polarity.
S	INADDR_ANY	IPv4 address for binding to all network interfaces.

S	INADDR_BROADCAST	IPv4 broadcast address.
S	INADDR_LOOPBACK	IPv4 address for binding to the loopback interface (aka `localhost`).
S	LOG_ALERT	Action must be taken immediately.
S	LOG_AUTH	Security/authorization messages.
S	LOG_AUTHPRIV	Securit/authorization messages.
S	LOG_CONS	Write directly to the system console if there is an error while sending to the system logger.
S	LOG_CRIT	Critical condition.
S	LOG_CRON	`cron` daemon messages.
S	LOG_DAEMON	System daemons.
S	LOG_DEBUG	Debug message.
S	LOG_EMERG	System is unusable.
S	LOG_ERR	Error condition.

s	LOG_FTP	FTP daemon messages.
s	LOG_INFO	Informational message.
s	LOG_KERN	Kernel messages.
s	LOG_LOCAL0	Reserved for local use.
s	LOG_LOCAL1	Reserved for local use.
s	LOG_LOCAL2	Reserved for local use.
s	LOG_LOCAL3	Reserved for local use.
s	LOG_LOCAL4	Reserved for local use.
s	LOG_LOCAL5	Reserved for local use.
s	LOG_LOCAL6	Reserved for local use.
s	LOG_LOCAL7	Reserved for local use.
s	LOG_LPR	Line printer subsystem
s	LOG_MAIL	Mail system.

S	LOG_NDELAY	Open the connection immediately. Do not wait until `syslog()` is called for the first time.
S	LOG_NEWS	Network news subsystem
S	LOG_NOTICE	Normal but significant condition.
S	LOG_NOWAIT	Don't wait for child processes that may have been created while logging the message. (Not applicable to `glibc`.)
S	LOG_ODELAY	Do not open the connection immediately. Wait until `syslog()` is called for the first time.
S	LOG_PERROR	Also log the message to `stderr`.
S	LOG_PID	Include the caller's PID (process ID) with each message.
S	LOG_PROGNAME	Use the program name for the identity

		string.
	LOG_SYSLOG	Messages generated internally by syslogd
	LOG_USER	Random user-level messages.
	LOG_UUCP	UUCP subsystem
	LOG_WARNING	Warning condition.
	MSG_DONTROUTE	Don't use a gateway to send out the packet, send to hosts only on directly connected networks.
	MSG_DONTWAIT	Enables nonblocking operation; if the operation would block, `EAGAIN` or `EWOULDBLOCK` is returned.
	MSG_MORE	The caller has more data to send. This flag informs the kernel to package all of the data sent in calls with this flag set into a single datagram which is transmitted only when a call is

		performed that does not specify this flag.
S	POLLERR	An error occurred.
S	POLLHUP	Peer closed connection.
S	POLLIN	There is data to read.
S	POLLNVAL	File descriptor is invalid.
S	POLLOUT	Writing is now possible.
S	POLLPRI	There is urgent data to read.
S	PWM_POLARITY_ACTIVEHIGH	Configure the PWM output as active high (normal).
S	PWM_POLARITY_ACTIVELOW	Configure the PWM output as active low (inverted).
S	SERIAL_PARITY_EVEN	Request even parity checking.
S	SERIAL_PARITY_NONE	Disable parity checking.
S	SERIAL_PARITY_ODD	Request odd parity checking.
S		

SPI_AUTO_CS	Use hardware slave select.

Top

See Also

Reference

libsimpleio Class

IO.Bindings Namespace

libsimpleioGPIO_DIRECTION_INPUT Field

Input data direction.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_DIRECTION_INPUT = 0
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_DIRECTION_OUTPUT Field

Out data direction.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_DIRECTION_OUTPUT = 1
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_DRIVER_OPENDRAIN Field

Open drain (sink only) output driver.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_DRIVER_OPENDRAIN = 1
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_DRIVER_OPENSOURCE Field

Open source (source only) output driver

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_DRIVER_OPENSOURCE = 2
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_DRIVER_PUSHPULL Field

Push-pull (source and sink) output driver.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int GPIO_DRIVER_PUSHPULL = 0
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_EDGE_BOTH Field

Interrupt on both edges.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int GPIO_EDGE_BOTH = 3
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_EDGE_FALLING Field

Interrupt on falling edge.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int GPIO_EDGE_FALLING = 2
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_EDGE_NONE Field

Interrupts are disabled.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int GPIO_EDGE_NONE = 0
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_EDGE_RISING Field

Interrupt on rising edge.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_EDGE_RISING = 1
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_EVENT_REQUEST_BOTH Field

Enable GPIO input interrupt on both edges.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_EVENT_REQUEST_BOTH = 3
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_EVENT_REQUEST_FALLING Field

Enable GPIO input interrupt on falling edge.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int GPIO_EVENT_REQUEST_FALLING = 2
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_EVENT_REQUEST_NONE Field

Disable GPIO input interrupt.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_EVENT_REQUEST_NONE = 0
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_EVENT_REQUEST_RISING Field

Enable GPIO input interrupt on rising edge.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int GPIO_EVENT_REQUEST_RISING = 1
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_LINE_INFO_ACTIVE_LOW Field

GPIO line is configured as active low (inverted).

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_LINE_INFO_ACTIVE_LOW = 4
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_LINE_INFO_KERNEL Field

GPIO line is being used by the kernel.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int GPIO_LINE_INFO_KERNEL = 1
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_LINE_INFO_OPEN_DRAIN Field

GPIO line is configured as open drain (current sink only).

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int GPIO_LINE_INFO_OPEN_DRAIN = 8
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_LINE_INFO_OPEN_SOURCE Field

GPIO line is configured as open source (current source only).

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_LINE_INFO_OPEN_SOURCE = 16
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_LINE_INFO_OUTPUT Field

GPIO line is configured as an output.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_LINE_INFO_OUTPUT = 2
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_LINE_REQUEST_ACTIVE_HIGH Field

Select GPIO line polarity active high (normal).

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_LINE_REQUEST_ACTIVE_HIGH = 0
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_LINE_REQUEST_ACTIVE_LOW Field

Select GPIO line polarity active low (inverted).

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_LINE_REQUEST_ACTIVE_LOW = 4
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_LINE_REQUEST_INPUT Field

Select GPIO line direction input.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_LINE_REQUEST_INPUT = 1
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_LINE_REQUEST_OPEN_DRAIN Field

Select GPIO line driver open drain (current sink only).

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_LINE_REQUEST_OPEN_DRAIN = 8
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_LINE_REQUEST_OPEN_SOURCE Field

Select GPIO line driver open source (current source only).

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_LINE_REQUEST_OPEN_SOURCE = 16
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_LINE_REQUEST_OUTPUT Field

Select GPIO line direction output.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_LINE_REQUEST_OUTPUT = 2
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_LINE_REQUEST_PUSH_PULL Field

Select GPIO line driver push-pull (current source and sink).

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_LINE_REQUEST_PUSH_PULL = 0
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_POLARITY_ACTIVEHIGH Field

Active high (normal) polarity.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_POLARITY_ACTIVEHIGH = 1
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioGPIO_POLARITY_ACTIVELOW Field

Active low (inverted) polarity.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO_POLARITY_ACTIVELOW = 0
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioINADDR_ANY Field

IPv4 address for binding to all network interfaces.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int INADDR_ANY = 0
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioINADDR_BROADCAST Field

IPv4 broadcast address.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int INADDR_BROADCAST = -1
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioINADDR_LOOPBACK Field

IPv4 address for binding to the loopback interface (aka `localhost`).

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int INADDR_LOOPBACK = 2130706433
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_ALERT Field

Action must be taken immediately.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_ALERT = 1
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_AUTH Field

Security/authorization messages.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_AUTH = 32
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_AUTHPRIV Field

Securit/authorization messages.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_AUTHPRIV = 80
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_CONS Field

Write directly to the system console if there is an error while sending to the system logger.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_CONS = 2
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_CRIT Field

Critical condition.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_CRIT = 2
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_CRON Field

`cron` daemon messages.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_CRON = 72
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_DAEMON Field

System daemons.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_DAEMON = 24
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_DEBUG Field

Debug message.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_DEBUG = 7
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_EMERG Field

System is unusable.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_EMERG = 0
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_ERR Field

Error condition.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_ERR = 3
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_FTP Field

`FTP` daemon messages.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_FTP = 88
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_INFO Field

Informational message.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_INFO = 6
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_KERN Field

Kernel messages.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_KERN = 0
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_LOCAL0 Field

Reserved for local use.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LOCAL0 = 128
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_LOCAL1 Field

Reserved for local use.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LOCAL1 = 136
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_LOCAL2 Field

Reserved for local use.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LOCAL2 = 144
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_LOCAL3 Field

Reserved for local use.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LOCAL3 = 152
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_LOCAL4 Field

Reserved for local use.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LOCAL4 = 160
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_LOCAL5 Field

Reserved for local use.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LOCAL5 = 168
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_LOCAL6 Field

Reserved for local use.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LOCAL6 = 176
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_LOCAL7 Field

Reserved for local use.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LOCAL7 = 184
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_LPR Field

Line printer subsystem

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LPR = 48
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_MAIL Field

Mail system.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_MAIL = 16
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_NDELAY Field

Open the connection immediately. Do not wait until `syslog()` is called for the first time.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_NDELAY = 8
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_NEWS Field

Network news subsystem

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_NEWS = 56
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_NOTICE Field

Normal but significant condition.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_NOTICE = 5
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_NOWAIT Field

Don't wait for child processes that may have been created while logging the message. (Not applicable to `glibc`.)

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_NOWAIT = 16
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_ODELAY Field

Do not open the connection immediately. Wait until `syslog()` is called for the first time.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_ODELAY = 4
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_PERROR Field

Also log the message to `stderr`.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_PERROR = 32
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_PID Field

Include the caller's PID (process ID) with each message.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_PID = 1
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_PROGNAME Field

Use the program name for the identity string.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const string LOG_PROGNAME = ""
```

Field Value

Type: String

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_SYSLOG Field

Messages generated internally by syslogd

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_SYSLOG = 40
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_USER Field

Random user-level messages.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_USER = 8
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_UUCP Field

UUCP subsystem

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_UUCP = 64
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioLOG_WARNING Field

Warning condition.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_WARNING = 4
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioMSG_DONTROUTE Field

Don't use a gateway to send out the packet, send to hosts only on directly connected networks.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int MSG_DONTROUTE = 4
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioMSG_DONTWAIT Field

Enables nonblocking operation; if the operation would block, `EAGAIN` or `EWOULDBLOCK` is returned.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int MSG_DONTWAIT = 64
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioMSG_MORE Field

The caller has more data to send. This flag informs the kernel to package all of the data sent in calls with this flag set into a single datagram which is transmitted only when a call is performed that does not specify this flag.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int MSG_MORE = 32768
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioPOLLERR Field

An error occurred.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int POLLERR = 8
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioPOLLHUP Field

Peer closed connection.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int POLLHUP = 16
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioPOLLIN Field

There is data to read.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int POLLIN = 1
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioPOLLNVAL Field

File descriptor is invalid.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int POLLNVAL = 32
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioPOLLOUT Field

Writing is now possible.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int POLLOUT = 4
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioPOLLPRI Field

There is urgent data to read.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int POLLPRI = 2
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioPWM_POLARITY_ACTIVEHIGH Field

Configure the PWM output as active high (normal).

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int PWM_POLARITY_ACTIVEHIGH = 1
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioPWM_POLARITY_ACTIVELOW Field

Configure the PWM output as active low (inverted).

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int PWM_POLARITY_ACTIVELOW = 0
```

Field Value

Type: Int32

Remarks

Not all platforms support active low (inverted) PWM outputs.

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioSERIAL_PARITY_EVEN Field

Request even parity checking.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int SERIAL_PARITY_EVEN = 1
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioSERIAL_PARITY_NONE Field

Disable parity checking.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int SERIAL_PARITY_NONE = 0
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioSERIAL_PARITY_ODD Field

Request odd parity checking.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int SERIAL_PARITY_ODD = 2
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

libsimpleioSPI_AUTO_CS Field

Use hardware slave select.

Namespace: IO.Bindings
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int SPI_AUTO_CS = -1
```

Field Value

Type: Int32

See Also

Reference

libsimpleio Class
IO.Bindings Namespace

IO.Devices.A4988 Namespace

A4988 Stepper Motor Controller Services.

Classes

	Class	Description
	Device	Encapsulates the A4988 Stepper Motor Controller.

Device Class

Encapsulates the A4988 Stepper Motor Controller.

Inheritance Hierarchy

SystemObject IO.Devices.A4988Device

Namespace: IO.Devices.A4988
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Device : Output
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device	Constructor for a single A4988 device.

Top

Properties

	Name	Description
	StepsPerRotation	Read-only property returning the number of steps a stepper

motor has.

Top

Methods

	Name	Description
	Disable	Disable the A4988 device.
	Enable	Enable the A4988 device.
	Move	Move the stepper motor a specified number of steps at a specified rate.
	Reset	Reset the A4988 device.
	Sleep	Put the A4988 device to sleep.
	Spin	Spin (i.e. continuous rotation) the stepper moter at a specified rate.
	Wakeup	Wake up the A4988 device.

Top

See Also

Reference

IO.Devices.A4988 Namespace

Device Constructor

Constructor for a single A4988 device.

Namespace: IO.Devices.A4988
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Device(
        int StepsPerRotation,
        Pin Step,
        Pin Dir,
        Pin Enable = null,
        Pin Reset = null,
        Pin Sleep = null
)
```

Parameters

StepsPerRotation
Type: SystemInt32
The number of steps per rotation. This is a physical characteristic of the particular stepper motor being driven.

Step
Type: IO.Interfaces.GPIOPin
GPIO pin object for the `STEP` signal.

Dir
Type: IO.Interfaces.GPIOPin
GPIO pin object for the `DIR` signal.

Enable **(Optional)**

Type: IO.Interfaces.GPIOPin
GPIO pin object for the `-ENABLE` signal.

Reset **(Optional)**
Type: IO.Interfaces.GPIOPin
GPIO pin object for the `-RESET` signal.

Sleep **(Optional)**
Type: IO.Interfaces.GPIOPin
GPIO pin object for the `-SLEEP` signal.

See Also

Reference

Device Class
IO.Devices.A4988 Namespace

Device Properties

The Device type exposes the following members.

Properties

	Name	Description
	StepsPerRotation	Read-only property returning the number of steps a stepper motor has.

Top

See Also

Reference

Device Class

IO.Devices.A4988 Namespace

DeviceStepsPerRotation Property

Read-only property returning the number of steps a stepper motor has.

Namespace: IO.Devices.A4988
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int StepsPerRotation { get; }
```

Property Value

Type: Int32

Implements

OutputStepsPerRotation

See Also

Reference

Device Class
IO.Devices.A4988 Namespace

Device Methods

The Device type exposes the following members.

Methods

	Name	Description
	Disable	Disable the A4988 device.
	Enable	Enable the A4988 device.
	Move	Move the stepper motor a specified number of steps at a specified rate.
	Reset	Reset the A4988 device.
	Sleep	Put the A4988 device to sleep.
	Spin	Spin (i.e. continuous rotation) the stepper moter at a specified rate.
	Wakeup	Wake up the A4988 device.

Top

See Also

Reference

Device Class

IO.Devices.A4988 Namespace

DeviceDisable Method

Disable the A4988 device.

Namespace: IO.Devices.A4988
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Disable()
```

See Also

Reference

Device Class
IO.Devices.A4988 Namespace

DeviceEnable Method

Enable the A4988 device.

Namespace: IO.Devices.A4988
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Enable()
```

See Also

Reference

Device Class
IO.Devices.A4988 Namespace

DeviceMove Method

Move the stepper motor a specified number of steps at a specified rate.

Namespace: IO.Devices.A4988
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Move(
        int steps,
        float rate
)
```

Parameters

steps
Type: SystemInt32
Number of steps to move. Negative values indicate reverse motion and positive values indicate forward motion. (The directions are nominal and depend on how the stepper motor coils are wired). Zero indicates the stepper motor should be stopped.

rate
Type: SystemSingle
The rate of motion, in steps per second. Negative values indicate reverse motion and positive values indicate forward motion. (The directions are nominal and depend on how the stepper motor coils are wired). Zero indicates the stepper motor should be stopped.

Implements
OutputMove(Int32, Single)

Remarks

This implementation supports a maximum rate of 500 steps per second.

See Also

Reference
Device Class
IO.Devices.A4988 Namespace

DeviceReset Method

Reset the A4988 device.

Namespace: IO.Devices.A4988
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public void Reset()
```

See Also

Reference

Device Class
IO.Devices.A4988 Namespace

DeviceSleep Method

Put the A4988 device to sleep.

Namespace: IO.Devices.A4988
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Sleep()
```

See Also

Reference

Device Class
IO.Devices.A4988 Namespace

DeviceSpin Method

Spin (i.e. continuous rotation) the stepper moter at a specified rate.

Namespace: IO.Devices.A4988
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Spin(
        float rate
)
```

Parameters

rate
Type: SystemSingle
The rate of motion, in steps per second. Negative values indicate reverse motion and positive values indicate forward motion. (The directions are nominal and depend on how the stepper motor coils are wired). Zero indicates the stepper motor should be stopped.

Implements

OutputSpin(Single)

Remarks

The A4988 stepper motor driver does not support continuous rotation and this method will always throw an exception.

See Also

Reference

Device Class

IO.Devices.A4988 Namespace

DeviceWakeup Method

Wake up the A4988 device.

Namespace: IO.Devices.A4988
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public void Wakeup()
```

See Also

Reference

Device Class
IO.Devices.A4988 Namespace

IO.Devices.AD5593R Namespace

AD5593 Analog/Digital I/O Device Services.

Classes

	Class	Description
	Device	Enscapsulates the AD5593R I^2C Analog/Digital I/O device.

Enumerations

	Enumeration	Description
	PinMode	AD5593R I/O Pin Modes.
	ReferenceMode	ADC5593R ADC and DAC reference settings.

Device Class

Enscapsulates the AD5593R I^{2}C Analog/Digital I/O device.

Inheritance Hierarchy

SystemObject IO.Devices.AD5593RDevice

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Device
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device	Constructor for a single AD5593R device.

Top

Properties

	Name	Description
	ADC_Reference	Write-only property for setting the AD5593R ADC reference

		mode.
	DAC_Reference	Write-only property for setting the AD5593R DAC reference mode.
	GPIO_Inputs	GPIO input register state. Any I/O pin that is not configured as a GPIO input will read as zero.
	GPIO_Outputs	GPIO output register state. Any I/O pin that is not configured as a GPIO output will be written as zero.

Top

Methods

	Name	Description
	ADC_Create	Create an AD5593R ADC input object.
	ConfigureChannel	Configure a single ADC5593R I/O pin.
	DAC_Create	Create an AD5593R DAC output object.
	GPIO_Create	Create an AD5593R GPIO pin object.
	Read_ADC	Read from an ADC channel.
	Write_DAC	Write to a DAC channel.

Top

Fields

	Name	Description
S	ADC_Resolution	ADC resolution in bits.
S	DAC_Resolution	DAC resolution in bits.
S	MaxChannel	Maximum I/O channel number.
S	MinChannel	Minimum I/O channel number.

Top

See Also

Reference

IO.Devices.AD5593R Namespace

Device Constructor

Constructor for a single AD5593R device.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public Device(
        Bus bus,
        int addr
)
```

Parameters

bus
Type: IO.Interfaces.I2CBus
I^2C bus controller object.

addr
Type: SystemInt32
I^2C slave address.

See Also

Reference

Device Class
IO.Devices.AD5593R Namespace

Device Properties

The Device type exposes the following members.

Properties

	Name	Description
	ADC_Reference	Write-only property for setting the AD5593R ADC reference mode.
	DAC_Reference	Write-only property for setting the AD5593R DAC reference mode.
	GPIO_Inputs	GPIO input register state. Any I/O pin that is not configured as a GPIO input will read as zero.
	GPIO_Outputs	GPIO output register state. Any I/O pin that is not configured as a GPIO output will be written as zero.

Top

See Also

Reference

Device Class

IO.Devices.AD5593R Namespace

DeviceADC_Reference Property

Write-only property for setting the AD5593R ADC reference mode.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public ReferenceMode ADC_Reference { set; }
```

Property Value

Type: ReferenceMode

See Also

Reference

Device Class
IO.Devices.AD5593R Namespace

DeviceDAC_Reference Property

Write-only property for setting the AD5593R DAC reference mode.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public ReferenceMode DAC_Reference { set; }
```

Property Value

Type: ReferenceMode

See Also

Reference

Device Class
IO.Devices.AD5593R Namespace

DeviceGPIO_Inputs Property

GPIO input register state. Any I/O pin that is not configured as a GPIO input will read as zero.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public byte GPIO_Inputs { get; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.AD5593R Namespace

DeviceGPIO_Outputs Property

GPIO output register state. Any I/O pin that is not configured as a GPIO output will be written as zero.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public byte GPIO_Outputs { get; set; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.AD5593R Namespace

Device Methods

The Device type exposes the following members.

Methods

	Name	Description
	ADC_Create	Create an AD5593R ADC input object.
	ConfigureChannel	Configure a single ADC5593R I/O pin.
	DAC_Create	Create an AD5593R DAC output object.
	GPIO_Create	Create an AD5593R GPIO pin object.
	Read_ADC	Read from an ADC channel.
	Write_DAC	Write to a DAC channel.

Top

See Also

Reference

Device Class

IO.Devices.AD5593R Namespace

DeviceADC_Create Method

Create an AD5593R ADC input object.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Sample ADC_Create(
        int channel
)
```

Parameters

channel
Type: SystemInt32
AD5593R ADC channel number (0 to 7).

Return Value

Type: Sample
ADC input object.

See Also

Reference

Device Class
IO.Devices.AD5593R Namespace

DeviceConfigureChannel Method

Configure a single ADC5593R I/O pin.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void ConfigureChannel(
        int channel,
        PinMode mode
)
```

Parameters

channel
Type: SystemInt32
ADC5593R I/O channel number (0 to 7).

mode
Type: IO.Devices.AD5593RPinMode
ADC5593R I/O pin mode.

See Also

Reference

Device Class
IO.Devices.AD5593R Namespace

DeviceDAC_Create Method

Create an AD5593R DAC output object.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Sample DAC_Create(
        int channel,
        int sample = 0
)
```

Parameters

channel
Type: SystemInt32
AD5593R DAC channel number (0 to 7).

sample **(Optional)**
Type: SystemInt32
Initial DAC output sample.

Return Value

Type: Sample
DAC output object.

See Also

Reference

Device Class

IO.Devices.AD5593R Namespace

DeviceGPIO_Create Method

Create an AD5593R GPIO pin object.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Pin GPIO_Create(
        int channel,
        Direction dir,
        bool state = false
)
```

Parameters

channel
Type: SystemInt32
AD5593R GPIO channel number (0 to 7).

dir
Type: IO.Interfaces.GPIODirection
GPIO pin data direction.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

Return Value

Type: Pin
GPIO pin object.

See Also

Reference

Device Class

IO.Devices.AD5593R Namespace

DeviceRead_ADC Method

Read from an ADC channel.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int Read_ADC(
        int channel
)
```

Parameters

channel
Type: SystemInt32
ADC channel number (0 to 7).

Return Value

Type: Int32
ADC input sample data (0 to 4095).

See Also

Reference

Device Class
IO.Devices.AD5593R Namespace

DeviceWrite_DAC Method

Write to a DAC channel.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Write_DAC(
        int channel,
        int data
)
```

Parameters

channel
Type: SystemInt32
DAC channel number (0 to 7).

data
Type: SystemInt32
DAC output sample data (0 to 4095).

See Also

Reference

Device Class
IO.Devices.AD5593R Namespace

Device Fields

The Device type exposes the following members.

Fields

	Name	Description
S	ADC_Resolution	ADC resolution in bits.
S	DAC_Resolution	DAC resolution in bits.
S	MaxChannel	Maximum I/O channel number.
S	MinChannel	Minimum I/O channel number.

Top

See Also

Reference

Device Class

IO.Devices.AD5593R Namespace

DeviceADC_Resolution Field

ADC resolution in bits.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int ADC_Resolution = 12
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.AD5593R Namespace

DeviceDAC_Resolution Field

DAC resolution in bits.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int DAC_Resolution = 12
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.AD5593R Namespace

DeviceMaxChannel Field

Maximum I/O channel number.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int MaxChannel = 7
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.AD5593R Namespace

DeviceMinChannel Field

Minimum I/O channel number.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int MinChannel = 0
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.AD5593R Namespace

PinMode Enumeration

AD5593R I/O Pin Modes.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public enum PinMode
```

Members

Member name	Value	Description
ADC_Input	0	Analog input.
DAC_Output	1	Analog output.
GPIO_Input	2	GPIO input.
GPIO_Output	3	GPIO output.
GPIO_Output_OpenDrain	4	GPIO open drain output.

See Also

Reference

IO.Devices.AD5593R Namespace

ReferenceMode Enumeration

ADC5593R ADC and DAC reference settings.

Namespace: IO.Devices.AD5593R
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public enum ReferenceMode
```

Members

Member name	Value	Description
Internalx1	0	The reference voltage is 2.5V using the internal reference.
Internalx2	1	The reference voltage is 5.0V using the internal reference.
Externalx1	2	The reference voltage is 1.0*Vref, using an external reference.
Externalx2	3	The reference voltage is 2.0*Vref, using an external reference.

See Also

Reference

IO.Devices.AD5593R Namespace

IO.Devices.AD5593R.ADC Namespace

AD5593 Analog/Digital I/O Device ADC Input Services.

Classes

	Class	Description
	Sample	Encapsulates AD5593R ADC inputs.

Sample Class

Encapsulates AD5593R ADC inputs.

Inheritance Hierarchy

SystemObject IO.Devices.AD5593R.ADCSample

Namespace: IO.Devices.AD5593R.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Sample : Sample
```

The Sample type exposes the following members.

Constructors

	Name	Description
	Sample	Create an AD5593R ADC input.

Top

Properties

	Name	Description
	resolution	Read-only property returning the number of bits of resolution.

	sample	Read-only property returning an integer analog sample value.

Top

See Also

Reference

IO.Devices.AD5593R.ADC Namespace

Sample Constructor

Create an AD5593R ADC input.

Namespace: IO.Devices.AD5593R.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public Sample(
        Device dev,
        int channel
)
```

Parameters

dev
Type: IO.Devices.AD5593RDevice
AD5593R device object.

channel
Type: SystemInt32
AD5593R I/O channel number (0 to 7).

See Also

Reference

Sample Class
IO.Devices.AD5593R.ADC Namespace

Sample Properties

The Sample type exposes the following members.

Properties

	Name	Description
	resolution	Read-only property returning the number of bits of resolution.
	sample	Read-only property returning an integer analog sample value.

Top

See Also

Reference

Sample Class

IO.Devices.AD5593R.ADC Namespace

Sampleresolution Property

Read-only property returning the number of bits of resolution.

Namespace: IO.Devices.AD5593R.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int resolution { get; }
```

Property Value

Type: Int32

Implements

Sampleresolution

See Also

Reference

Sample Class
IO.Devices.AD5593R.ADC Namespace

Samplesample Property

Read-only property returning an integer analog sample value.

Namespace: IO.Devices.AD5593R.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int sample { get; }
```

Property Value

Type: Int32

Implements

Samplesample

See Also

Reference

Sample Class
IO.Devices.AD5593R.ADC Namespace

IO.Devices.AD5593R.DAC Namespace

AD5593 Analog/Digital I/O Device DAC Output Services.

Classes

	Class	Description
	Sample	Encapsulates AD5593R DAC outputs.

Sample Class

Encapsulates AD5593R DAC outputs.

Inheritance Hierarchy

SystemObject IO.Devices.AD5593R.DACSample

Namespace: IO.Devices.AD5593R.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Sample : Sample
```

The Sample type exposes the following members.

Constructors

	Name	Description
	Sample	Create an AD5593R DAC output.

Top

Properties

	Name	Description
	resolution	Read-only property returning the number of bits of resolution.

	sample	Write-only property for writing an integer analog sample to a DAC output.

Top

See Also

Reference

IO.Devices.AD5593R.DAC Namespace

Sample Constructor

Create an AD5593R DAC output.

Namespace: IO.Devices.AD5593R.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Sample(
        Device dev,
        int channel,
        int sample = 0
)
```

Parameters

dev
Type: IO.Devices.AD5593RDevice
AD5593R device object.

channel
Type: SystemInt32
AD5593R I/O channel number (0 to 7).

sample **(Optional)**
Type: SystemInt32
Initial DAC output sample.

See Also

Reference

Sample Class

IO.Devices.AD5593R.DAC Namespace

Sample Properties

The Sample type exposes the following members.

Properties

	Name	Description
	resolution	Read-only property returning the number of bits of resolution.
	sample	Write-only property for writing an integer analog sample to a DAC output.

Top

See Also

Reference

Sample Class

IO.Devices.AD5593R.DAC Namespace

Sampleresolution Property

Read-only property returning the number of bits of resolution.

Namespace: IO.Devices.AD5593R.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int resolution { get; }
```

Property Value

Type: Int32

Implements

Sampleresolution

See Also

Reference

Sample Class
IO.Devices.AD5593R.DAC Namespace

Samplesample Property

Write-only property for writing an integer analog sample to a DAC output.

Namespace: IO.Devices.AD5593R.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int sample { set; }
```

Property Value

Type: Int32

Implements

Samplesample

See Also

Reference

Sample Class
IO.Devices.AD5593R.DAC Namespace

IO.Devices.AD5593R.GPIO Namespace

AD5593 Analog/Digital I/O Device GPIO Pin Services.

Classes

	Class	Description
	Pin	Encapsulates AD5593R GPIO pins.

Pin Class

Encapsulates AD5593R GPIO pins.

Inheritance Hierarchy

SystemObject IO.Devices.AD5593R.GPIOPin

Namespace: IO.Devices.AD5593R.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Pin : Pin
```

The Pin type exposes the following members.

Constructors

	Name	Description
	Pin	Create an AD5593R GPIO pin.

Top

Properties

	Name	Description
	state	Read/Write GPIO state property.

Top

See Also

Reference

IO.Devices.AD5593R.GPIO Namespace

Pin Constructor

Create an AD5593R GPIO pin.

Namespace: IO.Devices.AD5593R.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Pin(
        Device dev,
        int channel,
        Direction dir,
        bool state = false
)
```

Parameters

dev
Type: IO.Devices.AD5593RDevice
AD5593R device object.

channel
Type: SystemInt32
AD5593R I/O channel number (0 to 7).

dir
Type: IO.Interfaces.GPIODirection
GPIO pin data direction.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

See Also

Reference

Pin Class

IO.Devices.AD5593R.GPIO Namespace

Pin Properties

The Pin type exposes the following members.

Properties

	Name	Description
	state	Read/Write GPIO state property.

Top

See Also

Reference

Pin Class
IO.Devices.AD5593R.GPIO Namespace

Pinstate Property

Read/Write GPIO state property.

Namespace: IO.Devices.AD5593R.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public bool state { get; set; }
```

Property Value

Type: Boolean

Implements

Pinstate

See Also

Reference

Pin Class
IO.Devices.AD5593R.GPIO Namespace

IO.Devices.ADC121C021 Namespace

ADC121C021 I^2C A/D Converter Services

Classes

	Class	Description
	Sample	Encapsulates the ADC121C021 I^2C A/D converter.

Sample Class

Encapsulates the ADC121C021 I^2C A/D converter.

Inheritance Hierarchy

SystemObject IO.Devices.ADC121C021Sample

Namespace: IO.Devices.ADC121C021
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Sample : Sample
```

The Sample type exposes the following members.

Constructors

	Name	Description
	Sample	Constructor for an ADC121C021 analog input.

Top

Properties

	Name	Description
	resolution	Return the number of bits of A/D

		resolution.
	sample	Returns a single 12-bit analog sample.

Top

See Also

Reference

IO.Devices.ADC121C021 Namespace

Sample Constructor

Constructor for an ADC121C021 analog input.

Namespace: IO.Devices.ADC121C021
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Sample(
        Bus bus,
        byte addr
)
```

Parameters

bus
Type: IO.Interfaces.I2CBus
I^2C bus controller.

addr
Type: SystemByte
I^2C slave address.

See Also

Reference

Sample Class
IO.Devices.ADC121C021 Namespace

Sample Properties

The Sample type exposes the following members.

Properties

	Name	Description
	resolution	Return the number of bits of A/D resolution.
	sample	Returns a single 12-bit analog sample.

Top

See Also

Reference

Sample Class

IO.Devices.ADC121C021 Namespace

Sampleresolution Property

Return the number of bits of A/D resolution.

Namespace: IO.Devices.ADC121C021
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int resolution { get; }
```

Property Value

Type: Int32

Implements

Sampleresolution

See Also

Reference

Sample Class
IO.Devices.ADC121C021 Namespace

Samplesample Property

Returns a single 12-bit analog sample.

Namespace: IO.Devices.ADC121C021
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int sample { get; }
```

Property Value

Type: Int32

Implements

Samplesample

See Also

Reference

Sample Class
IO.Devices.ADC121C021 Namespace

IO.Devices.ClickBoards.RemoteIO.ADAC Namespace

Mikroelektronika ADAC Click MIKROE-2690 Services

Classes

	Class	Description
	Board	Encapsulates the Mikroelektronika ADAC Click Board. MIKROE-2690.

Board Class

Encapsulates the Mikroelektronika ADAC Click Board. MIKROE-2690.

Inheritance Hierarchy

SystemObject IO.Devices.ClickBoards.RemoteIO.ADACBoard

Namespace: IO.Devices.ClickBoards.RemoteIO.ADAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Board
```

The Board type exposes the following members.

Constructors

	Name	Description
	Board	Constructor for a single ADAC click.

Top

Properties

	Name	Description
	device	Returns the underlying AD5593R device object.

Top

Methods

	Name	Description
	ADC	Factory function for creating ADC inputs.
	DAC	Factory function for creating DAC outputs.
	GPIO	Factory function for creating GPIO pins.
	Reset	Issue hardware reset to the AD5593R.

Top

Fields

	Name	Description
S	DefaultAddress	Default I^2C slave address.

Top

See Also

Reference

IO.Devices.ClickBoards.RemoteIO.ADAC Namespace

Board Constructor

Constructor for a single ADAC click.

Namespace: IO.Devices.ClickBoards.RemoteIO.ADAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Board(
        int socknum,
        int addr = 16,
        Device remdev = null
)
```

Parameters

socknum
Type: SystemInt32
mikroBUS socket number.

addr **(Optional)**
Type: SystemInt32
I^2C slave address.

remdev **(Optional)**
Type: IO.Objects.RemoteIODevice
Remote I/O server device object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.ADAC Namespace

Board Properties

The Board type exposes the following members.

Properties

	Name	Description
	device	Returns the underlying AD5593R device object.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.ADAC Namespace

Boarddevice Property

Returns the underlying AD5593R device object.

Namespace: IO.Devices.ClickBoards.RemoteIO.ADAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Device device { get; }
```

Property Value

Type: Device

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.ADAC Namespace

Board Methods

The Board type exposes the following members.

Methods

	Name	Description
	ADC	Factory function for creating ADC inputs.
	DAC	Factory function for creating DAC outputs.
	GPIO	Factory function for creating GPIO pins.
	Reset	Issue hardware reset to the AD5593R.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.ADAC Namespace

BoardADC Method

Factory function for creating ADC inputs.

Namespace: IO.Devices.ClickBoards.RemoteIO.ADAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public Sample ADC(
        int channel
)
```

Parameters

channel
Type: SystemInt32
AD5593R I/O channel number (0 to 7).

Return Value

Type: Sample
ADC input object.

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.ADAC Namespace

BoardDAC Method

Factory function for creating DAC outputs.

Namespace: IO.Devices.ClickBoards.RemoteIO.ADAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Sample DAC(
        int channel,
        int sample = 0
)
```

Parameters

channel
Type: SystemInt32
AD5593R I/O channel number (0 to 7).

sample **(Optional)**
Type: SystemInt32
Initial DAC output sample.

Return Value

Type: Sample
DAC output object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.ADAC Namespace

BoardGPIO Method

Factory function for creating GPIO pins.

Namespace: IO.Devices.ClickBoards.RemoteIO.ADAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Pin GPIO(
        int channel,
        Direction dir,
        bool state = false
)
```

Parameters

channel
Type: SystemInt32
AD5593R I/O channel number (0 to 7).

dir
Type: IO.Interfaces.GPIODirection
GPIO pin direction.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

Return Value

Type: Pin
GPIO pin object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.ADAC Namespace

BoardReset Method

Issue hardware reset to the AD5593R.

Namespace: IO.Devices.ClickBoards.RemoteIO.ADAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public void Reset()
```

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.ADAC Namespace

Board Fields

The Board type exposes the following members.

Fields

	Name	Description
	DefaultAddress	Default I^2C slave address.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.ADAC Namespace

BoardDefaultAddress Field

Default I^{2}C slave address.

Namespace: IO.Devices.ClickBoards.RemoteIO.ADAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte DefaultAddress = 16
```

Field Value

Type: Byte

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.ADAC Namespace

IO.Devices.ClickBoards.RemoteIO.Expand Namespace

Mikroelektronika Expand Click MIKROE-951 Services

Classes

	Class	Description
	Board	Encapsulates the Mikroelektronika Expand Click Board.

Board Class

Encapsulates the Mikroelektronika Expand Click Board.

Inheritance Hierarchy

SystemObject IO.Devices.ClickBoards.RemoteIO.ExpandBoard

Namespace: IO.Devices.ClickBoards.RemoteIO.Expand
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Board
```

The Board type exposes the following members.

Constructors

	Name	Description
	Board	Constructor for a single Expand click.

Top

Properties

	Name	Description
	device	Returns the underlying MCP23S17 device object.

Top

Methods

	Name	Description
	GPIO	Factory function for creating GPIO pins.
	Reset	Issue hardware reset to the MCP23S17.

Top

See Also

Reference

IO.Devices.ClickBoards.RemoteIO.Expand Namespace

Board Constructor

Constructor for a single Expand click.

Namespace: IO.Devices.ClickBoards.RemoteIO.Expand
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Board(
        int socknum,
        Device remdev = null
)
```

Parameters

socknum
Type: SystemInt32
mikroBUS socket number.

remdev **(Optional)**
Type: IO.Objects.RemoteIODevice
Remote I/O server device object.

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.Expand Namespace

Board Properties

The Board type exposes the following members.

Properties

	Name	Description
	device	Returns the underlying MCP23S17 device object.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.Expand Namespace

Boarddevice Property

Returns the underlying MCP23S17 device object.

Namespace: IO.Devices.ClickBoards.RemoteIO.Expand
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Device device { get; }
```

Property Value

Type: Device

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.Expand Namespace

Board Methods

The Board type exposes the following members.

Methods

	Name	Description
	GPIO	Factory function for creating GPIO pins.
	Reset	Issue hardware reset to the MCP23S17.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.Expand Namespace

BoardGPIO Method

Factory function for creating GPIO pins.

Namespace: IO.Devices.ClickBoards.RemoteIO.Expand
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Pin GPIO(
        int channel,
        Direction dir,
        bool state = false
)
```

Parameters

channel
Type: SystemInt32
MCP23S17 channel number (0 to 15).

dir
Type: IO.Interfaces.GPIODirection
GPIO pin direction.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

Return Value

Type: Pin
GPIO pin object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.Expand Namespace

BoardReset Method

Issue hardware reset to the MCP23S17.

Namespace: IO.Devices.ClickBoards.RemoteIO.Expand
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public void Reset()
```

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.Expand Namespace

IO.Devices.ClickBoards.RemoteIO.Expand2 Namespace

Mikroelektronika Expand 2 Click MIKROE-1838 Services

Classes

	Class	Description
	Board	Encapsulates the Mikroelektronika Expand 2 Click Board.

Board Class

Encapsulates the Mikroelektronika Expand 2 Click Board.

Inheritance Hierarchy

SystemObject IO.Devices.ClickBoards.RemoteIO.Expand2Board

Namespace: IO.Devices.ClickBoards.RemoteIO.Expand2
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Board
```

The Board type exposes the following members.

Constructors

	Name	Description
	Board	Constructor for a single Expand 2 click.

Top

Properties

	Name	Description
	device	Returns the underlying MCP23017 device object.

Top

Methods

	Name	Description
	GPIO	Factory function for creating GPIO pins.
	Reset	Issue hardware reset to the MCP23017.

Top

Fields

	Name	Description
S	DefaultAddress	Default I^2C slave address.

Top

See Also

Reference

IO.Devices.ClickBoards.RemoteIO.Expand2 Namespace

Board Constructor

Constructor for a single Expand 2 click.

Namespace: IO.Devices.ClickBoards.RemoteIO.Expand2
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Board(
        int socknum,
        int addr = 32,
        Device remdev = null
)
```

Parameters

socknum
Type: SystemInt32
mikroBUS socket number.

addr **(Optional)**
Type: SystemInt32
I^2C slave address.

remdev **(Optional)**
Type: IO.Objects.RemoteIODevice
Remote I/O server device object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.Expand2 Namespace

Board Properties

The Board type exposes the following members.

Properties

	Name	Description
	device	Returns the underlying MCP23017 device object.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.Expand2 Namespace

Boarddevice Property

Returns the underlying MCP23017 device object.

Namespace: IO.Devices.ClickBoards.RemoteIO.Expand2
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Device device { get; }
```

Property Value

Type: Device

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.Expand2 Namespace

Board Methods

The Board type exposes the following members.

Methods

	Name	Description
	GPIO	Factory function for creating GPIO pins.
	Reset	Issue hardware reset to the MCP23017.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.Expand2 Namespace

BoardGPIO Method

Factory function for creating GPIO pins.

Namespace: IO.Devices.ClickBoards.RemoteIO.Expand2
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Pin GPIO(
        int channel,
        Direction dir,
        bool state = false
)
```

Parameters

channel
Type: SystemInt32
MCP23017 channel number (0 to 15).

dir
Type: IO.Interfaces.GPIODirection
GPIO pin direction.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

Return Value

Type: Pin
GPIO pin object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.Expand2 Namespace

BoardReset Method

Issue hardware reset to the MCP23017.

Namespace: IO.Devices.ClickBoards.RemoteIO.Expand2
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Reset()
```

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.Expand2 Namespace

Board Fields

The Board type exposes the following members.

Fields

	Name	Description
	DefaultAddress	Default I^2C slave address.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.Expand2 Namespace

BoardDefaultAddress Field

Default I^{2}C slave address.

Namespace: IO.Devices.ClickBoards.RemoteIO.Expand2
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int DefaultAddress = 32
```

Field Value

Type: Int32

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.Expand2 Namespace

IO.Devices.ClickBoards.RemoteIO.PWM Namespace

Mikroelektronika PWM Click MIKROE-1898 Services

Classes

	Class	Description
	Board	Encapsulates the Mikroelektronika PWM Click Board. MIKROE-1898.

Board Class

Encapsulates the Mikroelektronika PWM Click Board. MIKROE-1898.

Inheritance Hierarchy

SystemObject IO.Devices.ClickBoards.RemoteIO.PWMBoard

Namespace: IO.Devices.ClickBoards.RemoteIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Board
```

The Board type exposes the following members.

Constructors

	Name	Description
	Board	Constructor for a single PWM click.

Top

Properties

	Name	Description
	dev	Returns the underlying PCA9685 device object.

Top

Methods

	Name	Description
	GPIO	Factory function for creating GPIO output pins.
	PWM	Factory function for creating PWM outputs.
	Servo	Factory function for creating servo outputs.

Top

Fields

	Name	Description
S	DefaultAddress	Default I^2C slave address.

Top

See Also

Reference

IO.Devices.ClickBoards.RemoteIO.PWM Namespace

Board Constructor

Constructor for a single PWM click.

Namespace: IO.Devices.ClickBoards.RemoteIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Board(
        int socknum,
        int freq,
        int addr = 64,
        Device remdev = null
)
```

Parameters

socknum
Type: SystemInt32
mikroBUS socket number.

freq
Type: SystemInt32
PWM pulse frequency in Hz.

addr **(Optional)**
Type: SystemInt32
I^2C slave address.

remdev **(Optional)**
Type: IO.Objects.RemoteIODevice
Remote I/O device object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.PWM Namespace

Board Properties

The Board type exposes the following members.

Properties

	Name	Description
	dev	Returns the underlying PCA9685 device object.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.PWM Namespace

Boarddev Property

Returns the underlying PCA9685 device object.

Namespace: IO.Devices.ClickBoards.RemoteIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Device dev { get; }
```

Property Value

Type: Device

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.PWM Namespace

Board Methods

The Board type exposes the following members.

Methods

	Name	Description
	GPIO	Factory function for creating GPIO output pins.
	PWM	Factory function for creating PWM outputs.
	Servo	Factory function for creating servo outputs.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.PWM Namespace

BoardGPIO Method

Factory function for creating GPIO output pins.

Namespace: IO.Devices.ClickBoards.RemoteIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Pin GPIO(
        int channel,
        bool state = false
)
```

Parameters

channel
Type: SystemInt32
PCA9685 output channel number.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

Return Value

Type: Pin
GPIO output pin object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.PWM Namespace

BoardPWM Method

Factory function for creating PWM outputs.

Namespace: IO.Devices.ClickBoards.RemoteIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Output PWM(
        int channel,
        double dutycycle = 0
)
```

Parameters

channel
Type: SystemInt32
PCA9685 output channel number.

dutycycle **(Optional)**
Type: SystemDouble
Initial PWM output duty cycle.

Return Value

Type: Output
PWM output object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.PWM Namespace

BoardServo Method

Factory function for creating servo outputs.

Namespace: IO.Devices.ClickBoards.RemoteIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Output Servo(
        int channel,
        double position = 0
)
```

Parameters

channel
Type: SystemInt32
PCA9685 output channel number.

position **(Optional)**
Type: SystemDouble
Initial servo position.>

Return Value

Type: Output
Servo output object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.PWM Namespace

Board Fields

The Board type exposes the following members.

Fields

	Name	Description
	DefaultAddress	Default I^2C slave address.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.PWM Namespace

BoardDefaultAddress Field

Default I^{2}C slave address.

Namespace: IO.Devices.ClickBoards.RemoteIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte DefaultAddress = 64
```

Field Value

Type: Byte

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.PWM Namespace

IO.Devices.ClickBoards.RemoteIO.SevenSegment Namespace

Mikroelektronika 7Seg Click MIKROE-1201 Services

Classes

	Class	Description
	Board	Encapsulates the Mikroelektronika 7Seg Click Board. MIKROE-1201.

Enumerations

	Enumeration	Description
	BoardBase	Numeral systems.
	BoardZeroBlanking	Zero blanking modes.

Board Class

Encapsulates the Mikroelektronika 7Seg Click Board. MIKROE-1201.

Inheritance Hierarchy

SystemObject IO.Devices.ClickBoards.RemoteIO.SevenSegmentBoard

Namespace: IO.Devices.ClickBoards.RemoteIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public class Board
```

The Board type exposes the following members.

Constructors

	Name	Description
	Board	Constructor for a single 7seg click.

Top

Properties

	Name	Description
	blanking	Zero blanking mode. Allowed values are `None`, `Leading`, and `Full`.

	brightness	Write-only property for setting the brightness of the display. Allowed values are 0.0 to 100.0 percent.
	leftdp	Write-only property for setting the left digit decimal point.
	radix	Numerical base or radix. Allowed values are `Decimal` and `Hexadecimal`.
	rightdp	Write-only property for setting the right digit decimal point.
	state	Write-only property for setting the state of the display. Allowed values are 0 to 99 for decimal mode and 0 to 255 for hexadecimal mode.

Top

Methods

	Name	Description
	Clear	Clear the display.
	Reset	Issue hardware reset to the 74HC595 shift register chain.

Top

Remarks

The `MISO`*aka*`SDI` pin should be removed from the 7seg click, because it is not tri-state and will interfere with other devices on the same SPI

bus.

See Also

Reference

IO.Devices.ClickBoards.RemoteIO.SevenSegment Namespace

Board Constructor

Constructor for a single 7seg click.

Namespace: IO.Devices.ClickBoards.RemoteIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Board(
        int socket,
        BoardBase radix = BoardBase.Decimal,
        BoardZeroBlanking blanking = BoardZeroBlanking
        int pwmfreq = 100,
        Device remdev = null
)
```

Parameters

socket
Type: SystemInt32
mikroBUS socket number.

radix **(Optional)**
Type: IO.Devices.ClickBoards.RemoteIO.SevenSegmentBoardBase
Numerical base or radix. Allowed values are `Decimal` and `Hexadecimal`.

blanking **(Optional)**
Type: IO.Devices.ClickBoards.RemoteIO.SevenSegmentBoardZeroBlanking
Zero blanking. Allowed values are `None`, `Leading`, and `Full`.

pwmfreq **(Optional)**

Type: SystemInt32

PWM frequency. Set to zero to use GPIO instead of PWM.

remdev **(Optional)**

Type: IO.Objects.RemoteIODevice

Remote I/O server device object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.SevenSegment Namespace

Board Properties

The Board type exposes the following members.

Properties

	Name	Description
	blanking	Zero blanking mode. Allowed values are `None`, `Leading`, and `Full`.
	brightness	Write-only property for setting the brightness of the display. Allowed values are 0.0 to 100.0 percent.
	leftdp	Write-only property for setting the left digit decimal point.
	radix	Numerical base or radix. Allowed values are `Decimal` and `Hexadecimal`.
	rightdp	Write-only property for setting the right digit decimal point.
	state	Write-only property for setting the state of the display. Allowed values are 0 to 99 for decimal mode and 0 to 255 for hexadecimal mode.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.SevenSegment Namespace

Boardblanking Property

Zero blanking mode. Allowed values are `None`, `Leading`, and `Full`.

Namespace: IO.Devices.ClickBoards.RemoteIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public BoardZeroBlanking blanking { get; set; }
```

Property Value

Type: BoardZeroBlanking

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.SevenSegment Namespace

Boardbrightness Property

Write-only property for setting the brightness of the display. Allowed values are 0.0 to 100.0 percent.

Namespace: IO.Devices.ClickBoards.RemoteIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public double brightness { set; }
```

Property Value

Type: Double

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.SevenSegment Namespace

Boardleftdp Property

Write-only property for setting the left digit decimal point.

Namespace: IO.Devices.ClickBoards.RemoteIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public bool leftdp { set; }
```

Property Value

Type: Boolean

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.SevenSegment Namespace

Boardradix Property

Numerical base or radix. Allowed values are `Decimal` and `Hexadecimal`.

Namespace: IO.Devices.ClickBoards.RemoteIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public BoardBase radix { get; set; }
```

Property Value

Type: BoardBase

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.SevenSegment Namespace

Boardrightdp Property

Write-only property for setting the right digit decimal point.

Namespace: IO.Devices.ClickBoards.RemoteIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public bool rightdp { set; }
```

Property Value

Type: Boolean

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.SevenSegment Namespace

Boardstate Property

Write-only property for setting the state of the display. Allowed values are 0 to 99 for decimal mode and 0 to 255 for hexadecimal mode.

Namespace: IO.Devices.ClickBoards.RemoteIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int state { set; }
```

Property Value

Type: Int32

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.SevenSegment Namespace

Board Methods

The Board type exposes the following members.

Methods

	Name	Description
	Clear	Clear the display.
	Reset	Issue hardware reset to the 74HC595 shift register chain.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.RemoteIO.SevenSegment Namespace

BoardClear Method

Clear the display.

Namespace: IO.Devices.ClickBoards.RemoteIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Clear()
```

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.SevenSegment Namespace

BoardReset Method

Issue hardware reset to the 74HC595 shift register chain.

Namespace: IO.Devices.ClickBoards.RemoteIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Reset()
```

See Also

Reference

Board Class
IO.Devices.ClickBoards.RemoteIO.SevenSegment Namespace

BoardBase Enumeration

Numeral systems.

Namespace: IO.Devices.ClickBoards.RemoteIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public enum Base
```

Members

Member name	Value	Description
Decimal	0	Base 10.
Hexadecimal	1	Base 16.

See Also

Reference

IO.Devices.ClickBoards.RemoteIO.SevenSegment Namespace

BoardZeroBlanking Enumeration

Zero blanking modes.

Namespace: IO.Devices.ClickBoards.RemoteIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public enum ZeroBlanking
```

Members

Member name	Value	Description
None	0	No zero blanking.
Leading	1	Leading zero blanking.
Full	2	Full zero blanking.

See Also

Reference

IO.Devices.ClickBoards.RemoteIO.SevenSegment Namespace

IO.Devices.ClickBoards.SimpleIO.ADAC Namespace

Mikroelektronika ADAC Click MIKROE-2690 Services

Classes

	Class	Description
	Board	Encapsulates the Mikroelektronika ADAC Click Board. MIKROE-2690.

Board Class

Encapsulates the Mikroelektronika ADAC Click Board. MIKROE-2690.

Inheritance Hierarchy

SystemObject IO.Devices.ClickBoards.SimpleIO.ADACBoard

Namespace: IO.Devices.ClickBoards.SimpleIO.ADAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Board
```

The Board type exposes the following members.

Constructors

	Name	Description
	Board	Constructor for a single ADAC click.

Top

Properties

	Name	Description
	device	Returns the underlying AD5593R device object.

Top

Methods

	Name	Description
	ADC	Factory function for creating ADC inputs.
	DAC	Factory function for creating DAC outputs.
	GPIO	Factory function for creating GPIO pins.
	Reset	Issue hardware reset to the AD5593R.

Top

Fields

	Name	Description
S	DefaultAddress	Default I^2C slave address.

Top

See Also

Reference

IO.Devices.ClickBoards.SimpleIO.ADAC Namespace

Board Constructor

Constructor for a single ADAC click.

Namespace: IO.Devices.ClickBoards.SimpleIO.ADAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Board(
        int socknum,
        int addr = 16
)
```

Parameters

socknum
Type: SystemInt32
mikroBUS socket number.

addr **(Optional)**
Type: SystemInt32
I^2C slave address.

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.ADAC Namespace

Board Properties

The Board type exposes the following members.

Properties

	Name	Description
	device	Returns the underlying AD5593R device object.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.ADAC Namespace

Boarddevice Property

Returns the underlying AD5593R device object.

Namespace: IO.Devices.ClickBoards.SimpleIO.ADAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Device device { get; }
```

Property Value

Type: Device

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.ADAC Namespace

Board Methods

The Board type exposes the following members.

Methods

	Name	Description
	ADC	Factory function for creating ADC inputs.
	DAC	Factory function for creating DAC outputs.
	GPIO	Factory function for creating GPIO pins.
	Reset	Issue hardware reset to the AD5593R.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.ADAC Namespace

BoardADC Method

Factory function for creating ADC inputs.

Namespace: IO.Devices.ClickBoards.SimpleIO.ADAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public Sample ADC(
        int channel
)
```

Parameters

channel
Type: SystemInt32
AD5593R I/O channel number (0 to 7).

Return Value

Type: Sample
ADC input object.

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.ADAC Namespace

BoardDAC Method

Factory function for creating DAC outputs.

Namespace: IO.Devices.ClickBoards.SimpleIO.ADAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Sample DAC(
        int channel,
        int sample = 0
)
```

Parameters

channel
Type: SystemInt32
AD5593R I/O channel number (0 to 7).

sample **(Optional)**
Type: SystemInt32
Initial DAC output sample.

Return Value

Type: Sample
DAC output object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.ADAC Namespace

BoardGPIO Method

Factory function for creating GPIO pins.

Namespace: IO.Devices.ClickBoards.SimpleIO.ADAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Pin GPIO(
        int channel,
        Direction dir,
        bool state = false
)
```

Parameters

channel
Type: SystemInt32
AD5593R I/O channel number (0 to 7).

dir
Type: IO.Interfaces.GPIODirection
GPIO pin direction.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

Return Value

Type: Pin
GPIO pin object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.ADAC Namespace

BoardReset Method

Issue hardware reset to the AD5593R.

Namespace: IO.Devices.ClickBoards.SimpleIO.ADAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public void Reset()
```

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.ADAC Namespace

Board Fields

The Board type exposes the following members.

Fields

	Name	Description
	DefaultAddress	Default I^2C slave address.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.ADAC Namespace

BoardDefaultAddress Field

Default I^{2}C slave address.

Namespace: IO.Devices.ClickBoards.SimpleIO.ADAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte DefaultAddress = 16
```

Field Value

Type: Byte

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.ADAC Namespace

IO.Devices.ClickBoards.SimpleIO.Expand Namespace

Mikroelektronika Expand Click MIKROE-951 Services

Classes

	Class	Description
	Board	Encapsulates the Mikroelektronika Expand Click Board.

Board Class

Encapsulates the Mikroelektronika Expand Click Board.

Inheritance Hierarchy

SystemObject IO.Devices.ClickBoards.SimpleIO.ExpandBoard

Namespace: IO.Devices.ClickBoards.SimpleIO.Expand
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Board
```

The Board type exposes the following members.

Constructors

	Name	Description
	Board	Constructor for a single Expand 2 click.

Top

Properties

	Name	Description
	device	Returns the underlying MCP23S17 device object.

Top

Methods

	Name	Description
	GPIO	Factory function for creating GPIO pins.
	Reset	Issue hardware reset to the MCP23S17.

Top

See Also

Reference

IO.Devices.ClickBoards.SimpleIO.Expand Namespace

Board Constructor

Constructor for a single Expand 2 click.

Namespace: IO.Devices.ClickBoards.SimpleIO.Expand
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Board(
        int socknum
)
```

Parameters

socknum
Type: SystemInt32
mikroBUS socket number.

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.Expand Namespace

Board Properties

The Board type exposes the following members.

Properties

	Name	Description
	device	Returns the underlying MCP23S17 device object.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.Expand Namespace

Boarddevice Property

Returns the underlying MCP23S17 device object.

Namespace: IO.Devices.ClickBoards.SimpleIO.Expand
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Device device { get; }
```

Property Value

Type: Device

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.Expand Namespace

Board Methods

The Board type exposes the following members.

Methods

	Name	Description
	GPIO	Factory function for creating GPIO pins.
	Reset	Issue hardware reset to the MCP23S17.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.Expand Namespace

BoardGPIO Method

Factory function for creating GPIO pins.

Namespace: IO.Devices.ClickBoards.SimpleIO.Expand
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Pin GPIO(
        int channel,
        Direction dir,
        bool state = false
)
```

Parameters

channel
Type: SystemInt32
MCP23S17 channel number (0 to 15).

dir
Type: IO.Interfaces.GPIODirection
GPIO pin direction.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

Return Value

Type: Pin
GPIO pin object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.Expand Namespace

BoardReset Method

Issue hardware reset to the MCP23S17.

Namespace: IO.Devices.ClickBoards.SimpleIO.Expand
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Reset()
```

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.Expand Namespace

IO.Devices.ClickBoards.SimpleIO.Expand2 Namespace

Mikroelektronika Expand 2 Click MIKROE-1838 Services

Classes

	Class	Description
	Board	Encapsulates the Mikroelektronika Expand 2 Click Board.

Board Class

Encapsulates the Mikroelektronika Expand 2 Click Board.

Inheritance Hierarchy

SystemObject IO.Devices.ClickBoards.SimpleIO.Expand2Board

Namespace: IO.Devices.ClickBoards.SimpleIO.Expand2
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Board
```

The Board type exposes the following members.

Constructors

	Name	Description
	Board	Constructor for a single Expand 2 click.

Top

Properties

	Name	Description
	device	Returns the underlying MCP23017 device object.

Top

Methods

	Name	Description
	GPIO	Factory function for creating GPIO pins.
	Reset	Issue hardware reset to the MCP23017.

Top

Fields

	Name	Description
S	DefaultAddress	Default I^2C slave address.

Top

See Also

Reference

IO.Devices.ClickBoards.SimpleIO.Expand2 Namespace

Board Constructor

Constructor for a single Expand 2 click.

Namespace: IO.Devices.ClickBoards.SimpleIO.Expand2
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Board(
        int socknum,
        int addr = 32
)
```

Parameters

socknum
Type: SystemInt32
mikroBUS socket number.

addr **(Optional)**
Type: SystemInt32
I^2C slave address.

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.Expand2 Namespace

Board Properties

The Board type exposes the following members.

Properties

	Name	Description
	device	Returns the underlying MCP23017 device object.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.Expand2 Namespace

Boarddevice Property

Returns the underlying MCP23017 device object.

Namespace: IO.Devices.ClickBoards.SimpleIO.Expand2
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Device device { get; }
```

Property Value

Type: Device

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.Expand2 Namespace

Board Methods

The Board type exposes the following members.

Methods

	Name	Description
	GPIO	Factory function for creating GPIO pins.
	Reset	Issue hardware reset to the MCP23017.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.Expand2 Namespace

BoardGPIO Method

Factory function for creating GPIO pins.

Namespace: IO.Devices.ClickBoards.SimpleIO.Expand2
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Pin GPIO(
        int channel,
        Direction dir,
        bool state = false
)
```

Parameters

channel
Type: SystemInt32
MCP23017 channel number (0 to 15).

dir
Type: IO.Interfaces.GPIODirection
GPIO pin direction.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

Return Value

Type: Pin
GPIO pin object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.Expand2 Namespace

BoardReset Method

Issue hardware reset to the MCP23017.

Namespace: IO.Devices.ClickBoards.SimpleIO.Expand2
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Reset()
```

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.Expand2 Namespace

Board Fields

The Board type exposes the following members.

Fields

	Name	Description
	DefaultAddress	Default I^2C slave address.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.Expand2 Namespace

BoardDefaultAddress Field

Default I^{2}C slave address.

Namespace: IO.Devices.ClickBoards.SimpleIO.Expand2
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int DefaultAddress = 32
```

Field Value

Type: Int32

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.Expand2 Namespace

IO.Devices.ClickBoards.SimpleIO.PWM Namespace

Mikroelektronika PWM Click MIKROE-1898 Services

Classes

	Class	Description
	Board	Encapsulates the Mikroelektronika PWM Click Board. MIKROE-1898.

Board Class

Encapsulates the Mikroelektronika PWM Click Board. MIKROE-1898.

Inheritance Hierarchy

SystemObject IO.Devices.ClickBoards.SimpleIO.PWMBoard

Namespace: IO.Devices.ClickBoards.SimpleIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Board
```

The Board type exposes the following members.

Constructors

	Name	Description
	Board	Constructor for a single PWM click.

Top

Properties

	Name	Description
	dev	Returns the underlying PCA9685 device object.

Top

Methods

	Name	Description
	GPIO	Factory function for creating GPIO output pins.
	PWM	Factory function for creating PWM outputs.
	Servo	Factory function for creating servo outputs.

Top

Fields

	Name	Description
S	DefaultAddress	Default I^2C slave address.

Top

See Also

Reference

IO.Devices.ClickBoards.SimpleIO.PWM Namespace

Board Constructor

Constructor for a single PWM click.

Namespace: IO.Devices.ClickBoards.SimpleIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Board(
        int socknum,
        int freq,
        int addr = 64
)
```

Parameters

socknum
Type: SystemInt32
mikroBUS socket number.

freq
Type: SystemInt32
PWM pulse frequency in Hz.

addr **(Optional)**
Type: SystemInt32
I^2C slave address.

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.PWM Namespace

Board Properties

The Board type exposes the following members.

Properties

	Name	Description
	dev	Returns the underlying PCA9685 device object.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.PWM Namespace

Boarddev Property

Returns the underlying PCA9685 device object.

Namespace: IO.Devices.ClickBoards.SimpleIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Device dev { get; }
```

Property Value

Type: Device

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.PWM Namespace

Board Methods

The Board type exposes the following members.

Methods

	Name	Description
	GPIO	Factory function for creating GPIO output pins.
	PWM	Factory function for creating PWM outputs.
	Servo	Factory function for creating servo outputs.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.PWM Namespace

BoardGPIO Method

Factory function for creating GPIO output pins.

Namespace: IO.Devices.ClickBoards.SimpleIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Pin GPIO(
        int channel,
        bool state = false
)
```

Parameters

channel
Type: SystemInt32
PCA9685 output channel number.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

Return Value

Type: Pin
GPIO output pin object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.PWM Namespace

BoardPWM Method

Factory function for creating PWM outputs.

Namespace: IO.Devices.ClickBoards.SimpleIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Output PWM(
        int channel,
        double dutycycle = 0
)
```

Parameters

channel
Type: SystemInt32
PCA9685 output channel number.

dutycycle **(Optional)**
Type: SystemDouble
Initial PWM output duty cycle.

Return Value

Type: Output
PWM output object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.PWM Namespace

BoardServo Method

Factory function for creating servo outputs.

Namespace: IO.Devices.ClickBoards.SimpleIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Output Servo(
        int channel,
        double position = 0
)
```

Parameters

channel
Type: SystemInt32
PCA9685 output channel number.

position **(Optional)**
Type: SystemDouble
Initial servo position.>

Return Value

Type: Output
Servo output object.

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.PWM Namespace

Board Fields

The Board type exposes the following members.

Fields

	Name	Description
	DefaultAddress	Default I^2C slave address.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.PWM Namespace

BoardDefaultAddress Field

Default I^{2}C slave address.

Namespace: IO.Devices.ClickBoards.SimpleIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte DefaultAddress = 64
```

Field Value

Type: Byte

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.PWM Namespace

IO.Devices.ClickBoards.SimpleIO.SevenSegment Namespace

Mikroelektronika 7Seg Click MIKROE-1201 Services

Classes

	Class	Description
	Board	Encapsulates the Mikroelektronika 7Seg Click Board. MIKROE-1201.

Enumerations

	Enumeration	Description
	BoardBase	Numeral systems.
	BoardZeroBlanking	Zero blanking modes.

Board Class

Encapsulates the Mikroelektronika 7Seg Click Board. MIKROE-1201.

Inheritance Hierarchy

SystemObject IO.Devices.ClickBoards.SimpleIO.SevenSegmentBoard

Namespace: IO.Devices.ClickBoards.SimpleIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public class Board
```

The Board type exposes the following members.

Constructors

	Name	Description
	Board	Constructor for a single 7seg click.

Top

Properties

	Name	Description
	blanking	Zero blanking mode. Allowed values are `None`, `Leading`, and `Full`.

	brightness	Write-only property for setting the brightness of the display. Allowed values are 0.0 to 100.0 percent.
	leftdp	Write-only property for setting the left digit decimal point.
	radix	Numerical base or radix. Allowed values are `Decimal` and `Hexadecimal`.
	rightdp	Write-only property for setting the right digit decimal point.
	state	Write-only property for setting the state of the display. Allowed values are 0 to 99 for decimal mode and 0 to 255 for hexadecimal mode.

Top

Methods

	Name	Description
	Clear	Clear the display.
	Reset	Issue hardware reset to the 74HC595 shift register chain.

Top

Remarks

The `MISO`*aka*`SDI` pin should be removed from the 7seg click, because it is not tri-state and will interfere with other devices on the same SPI

bus.

See Also

Reference

IO.Devices.ClickBoards.SimpleIO.SevenSegment Namespace

Board Constructor

Constructor for a single 7seg click.

Namespace: IO.Devices.ClickBoards.SimpleIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Board(
        int socket,
        BoardBase radix = BoardBase.Decimal,
        BoardZeroBlanking blanking = BoardZeroBlanking
        int pwmfreq = 100
)
```

Parameters

socket
Type: SystemInt32
mikroBUS socket number.

radix **(Optional)**
Type: IO.Devices.ClickBoards.SimpleIO.SevenSegmentBoardBase
Numerical base or radix. Allowed values are `Decimal` and `Hexadecimal`.

blanking **(Optional)**
Type: IO.Devices.ClickBoards.SimpleIO.SevenSegmentBoardZeroBlanking
Zero blanking. Allowed values are `None`, `Leading`, and `Full`.

pwmfreq **(Optional)**

Type: SystemInt32
PWM frequency. Set to zero to use GPIO instead of PWM.

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.SevenSegment Namespace

Board Properties

The Board type exposes the following members.

Properties

	Name	Description
	blanking	Zero blanking mode. Allowed values are `None`, `Leading`, and `Full`.
	brightness	Write-only property for setting the brightness of the display. Allowed values are 0.0 to 100.0 percent.
	leftdp	Write-only property for setting the left digit decimal point.
	radix	Numerical base or radix. Allowed values are `Decimal` and `Hexadecimal`.
	rightdp	Write-only property for setting the right digit decimal point.
	state	Write-only property for setting the state of the display. Allowed values are 0 to 99 for decimal mode and 0 to 255 for hexadecimal mode.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.SevenSegment Namespace

Boardblanking Property

Zero blanking mode. Allowed values are `None`, `Leading`, and `Full`.

Namespace: IO.Devices.ClickBoards.SimpleIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public BoardZeroBlanking blanking { get; set; }
```

Property Value

Type: BoardZeroBlanking

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.SevenSegment Namespace

Boardbrightness Property

Write-only property for setting the brightness of the display. Allowed values are 0.0 to 100.0 percent.

Namespace: IO.Devices.ClickBoards.SimpleIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public double brightness { set; }
```

Property Value

Type: Double

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.SevenSegment Namespace

Boardleftdp Property

Write-only property for setting the left digit decimal point.

Namespace: IO.Devices.ClickBoards.SimpleIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public bool leftdp { set; }
```

Property Value

Type: Boolean

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.SevenSegment Namespace

Boardradix Property

Numerical base or radix. Allowed values are `Decimal` and `Hexadecimal`.

Namespace: IO.Devices.ClickBoards.SimpleIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public BoardBase radix { get; set; }
```

Property Value

Type: BoardBase

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.SevenSegment Namespace

Boardrightdp Property

Write-only property for setting the right digit decimal point.

Namespace: IO.Devices.ClickBoards.SimpleIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public bool rightdp { set; }
```

Property Value

Type: Boolean

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.SevenSegment Namespace

Boardstate Property

Write-only property for setting the state of the display. Allowed values are 0 to 99 for decimal mode and 0 to 255 for hexadecimal mode.

Namespace: IO.Devices.ClickBoards.SimpleIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int state { set; }
```

Property Value

Type: Int32

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.SevenSegment Namespace

Board Methods

The Board type exposes the following members.

Methods

	Name	Description
	Clear	Clear the display.
	Reset	Issue hardware reset to the 74HC595 shift register chain.

Top

See Also

Reference

Board Class

IO.Devices.ClickBoards.SimpleIO.SevenSegment Namespace

BoardClear Method

Clear the display.

Namespace: IO.Devices.ClickBoards.SimpleIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Clear()
```

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.SevenSegment Namespace

BoardReset Method

Issue hardware reset to the 74HC595 shift register chain.

Namespace: IO.Devices.ClickBoards.SimpleIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Reset()
```

See Also

Reference

Board Class
IO.Devices.ClickBoards.SimpleIO.SevenSegment Namespace

BoardBase Enumeration

Numeral systems.

Namespace: IO.Devices.ClickBoards.SimpleIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public enum Base
```

Members

Member name	Value	Description
Decimal	0	Base 10.
Hexadecimal	1	Base 16.

See Also

Reference

IO.Devices.ClickBoards.SimpleIO.SevenSegment Namespace

BoardZeroBlanking Enumeration

Zero blanking modes.

Namespace: IO.Devices.ClickBoards.SimpleIO.SevenSegment
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public enum ZeroBlanking
```

Members

Member name	Value	Description
None	0	No zero blanking.
Leading	1	Leading zero blanking.
Full	2	Full zero blanking.

See Also

Reference

IO.Devices.ClickBoards.SimpleIO.SevenSegment Namespace

IO.Devices.Grove.ADC Namespace

Seeed Studio Grove I^{2}C ADC (ADC121C021) Services

Classes

	Class	Description
	Device	Encapsulates the Seeed Studio Grove I^{2}C ADC (ADC121C021).

Device Class

Encapsulates the Seeed Studio Grove I^{2}C ADC (ADC121C021).

Inheritance Hierarchy

SystemObject IO.Devices.Grove.ADCDevice

Namespace: IO.Devices.Grove.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Device
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device	Constructor for a Seeed Studio Grove I^{2}C ADC (ADC121C021).

Top

Properties

	Name	Description
	voltage	Read-only property returning an analog

input voltage measurement.

Top

See Also

Reference

IO.Devices.Grove.ADC Namespace

Device Constructor

Constructor for a Seeed Studio Grove I^{2}C ADC (ADC121C021).

Namespace: IO.Devices.Grove.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Device(
        Bus bus,
        byte addr = 80
)
```

Parameters

bus
Type: IO.Interfaces.I2CBus
I^{2}C bus object.

addr **(Optional)**
Type: SystemByte
I^{2}C device address.

See Also

Reference

Device Class
IO.Devices.Grove.ADC Namespace

Device Properties

The Device type exposes the following members.

Properties

	Name	Description
	voltage	Read-only property returning an analog input voltage measurement.

Top

See Also

Reference

Device Class

IO.Devices.Grove.ADC Namespace

Devicevoltage Property

Read-only property returning an analog input voltage measurement.

Namespace: IO.Devices.Grove.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public double voltage { get; }
```

Property Value

Type: Double

See Also

Reference

Device Class
IO.Devices.Grove.ADC Namespace

IO.Devices.Grove.Temperature Namespace

Seeed Studio Grove Temperature Sensor (thermistor) Services

Classes

	Class	Description
	Device	Encapsulates the Seeed Studio Grove Temperature Sensor (thermistor).

Device Class

Encapsulates the Seeed Studio Grove Temperature Sensor (thermistor).

Inheritance Hierarchy

SystemObject IO.Devices.Grove.TemperatureDevice

Namespace: IO.Devices.Grove.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Device : Sensor
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device	Constructor for a Seeed Studio Grove Temperature Sensor (thermistor).

Top

Properties

	Name	Description
	Celsius	Read-only property returning the

		temperature in degrees Celsius.
	Fahrenheit	Read-only property returning the temperature in degrees Fahrenheit.
	Kelvins	Read-only property returning the temperature in Kelvins.

Top

See Also

Reference

IO.Devices.Grove.Temperature Namespace

Device Constructor

Constructor for a Seeed Studio Grove Temperature Sensor (thermistor).

Namespace: IO.Devices.Grove.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Device(
        Voltage Vin,
        double Vcc = 3.3
)
```

Parameters

Vin
Type: IO.Interfaces.ADCVoltage
Voltage input object.

Vcc **(Optional)**
Type: SystemDouble
Reference voltage.

See Also

Reference

Device Class
IO.Devices.Grove.Temperature Namespace

Device Properties

The Device type exposes the following members.

Properties

	Name	Description
	Celsius	Read-only property returning the temperature in degrees Celsius.
	Fahrenheit	Read-only property returning the temperature in degrees Fahrenheit.
	Kelvins	Read-only property returning the temperature in Kelvins.

Top

See Also

Reference

Device Class

IO.Devices.Grove.Temperature Namespace

DeviceCelsius Property

Read-only property returning the temperature in degrees Celsius.

Namespace: IO.Devices.Grove.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public double Celsius { get; }
```

Property Value

Type: Double

Implements

SensorCelsius

See Also

Reference

Device Class
IO.Devices.Grove.Temperature Namespace

DeviceFahrenheit Property

Read-only property returning the temperature in degrees Fahrenheit.

Namespace: IO.Devices.Grove.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public double Fahrenheit { get; }
```

Property Value

Type: Double

Implements

SensorFahrenheit

See Also

Reference

Device Class
IO.Devices.Grove.Temperature Namespace

DeviceKelvins Property

Read-only property returning the temperature in Kelvins.

Namespace: IO.Devices.Grove.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public double Kelvins { get; }
```

Property Value

Type: Double

Implements

SensorKelvins

See Also

Reference

Device Class
IO.Devices.Grove.Temperature Namespace

IO.Devices.Grove.Temperature_Humidity Namespace

Seeed Studio Grove Temperature and Humdity Sensor (TH02) Services.

Classes

	Class	Description
	Device	Encapsulate the Seeed Studio Grove Temperature and Humidity Sensor (TH02).

Device Class

Encapsulate the Seeed Studio Grove Temperature and Humidity Sensor (TH02).

Inheritance Hierarchy

SystemObject IO.Devices.TH02Device
IO.Devices.Grove.Temperature_HumidityDevice

Namespace: IO.Devices.Grove.Temperature_Humidity
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public class Device : Device
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device	Constructor for a Seeed Studio Grove Temperature and Humidity Sensor (TH02).

Top

Properties

	Name	Description
	Celsius	Read-only property returning the temperature in degrees Celsius. (Inherited from Device.)
	DeviceID	Read-only property returning the device ID. (Inherited from Device.)
	Fahrenheit	Read-only property returning the temperature in degrees Fahrenheit. (Inherited from Device.)
	Humidity	Read-only property returning the percentage relative humidity. (Inherited from Device.)
	Kelvins	Read-only property returning the temperature in Kelvins. (Inherited from Device.)

Top

See Also

Reference

IO.Devices.Grove.Temperature_Humidity Namespace

Device Constructor

Constructor for a Seeed Studio Grove Temperature and Humidity Sensor (TH02).

Namespace: IO.Devices.Grove.Temperature_Humidity
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public Device(
        Bus bus
)
```

Parameters

bus
Type: IO.Interfaces.I2CBus
I^2 bus object.

See Also

Reference

Device Class
IO.Devices.Grove.Temperature_Humidity Namespace

Device Properties

The Device type exposes the following members.

Properties

	Name	Description
	Celsius	Read-only property returning the temperature in degrees Celsius. (Inherited from Device.)
	DeviceID	Read-only property returning the device ID. (Inherited from Device.)
	Fahrenheit	Read-only property returning the temperature in degrees Fahrenheit. (Inherited from Device.)
	Humidity	Read-only property returning the percentage relative humidity. (Inherited from Device.)
	Kelvins	Read-only property returning the temperature in Kelvins. (Inherited from Device.)

Top

See Also

Reference

Device Class

IO.Devices.Grove.Temperature_Humidity Namespace

IO.Devices.HDC1080 Namespace

HDC1080 I^2C Temperature/Humidity Sensor Services

Classes

	Class	Description
	Device	Encapsulates the HDC1080 temperature and humidity sensor.

Device Class

Encapsulates the HDC1080 temperature and humidity sensor.

Inheritance Hierarchy

SystemObject IO.Devices.HDC1080Device
IO.Devices.Pmod.HYGRODevice

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Device : Sensor, Sensor
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device	Constructor for an HDC1080 temperature and humidity sensor object.

Top

Properties

	Name	Description

	Celsius	Read-only property returning the temperature in degrees Celsius.
	DeviceID	Read-only property returning the device ID.
	Fahrenheit	Read-only property returning the temperature in degrees Fahrenheit.
	Humidity	Read-only property returning the percentage relative humidity.
	Kelvins	Read-only property returning the temperature in Kelvins.
	ManufacturerID	Read-only property returning the manufacturer ID.

Top

Methods

	Name	Description
	Read	Read from an HDC1080 device register.
	Write	Write to an HDC1080 device register.

Top

Fields

	Name	Description
S	RegConfiguration	Configuration Register

		address.
S	RegDeviceID	Device ID Register address.
S	RegHumidity	Humidity Register address.
S	RegManufacturerID	Manufacturer ID Register address.
S	RegSerialNumberFirst	Serial Number First Bits Register address.
S	RegSerialNumberLast	Serial Number Last Bits Register address.
S	RegSerialNumberMid	Serial Number Middle Bits Register address.
S	RegTemperature	Temperature Register address.

Top

See Also

Reference

IO.Devices.HDC1080 Namespace

Device Constructor

Constructor for an HDC1080 temperature and humidity sensor object.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Device(
        Bus bus
)
```

Parameters

bus
Type: IO.Interfaces.I2CBus
I^2C bus controller.

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

Device Properties

The Device type exposes the following members.

Properties

	Name	Description
	Celsius	Read-only property returning the temperature in degrees Celsius.
	DeviceID	Read-only property returning the device ID.
	Fahrenheit	Read-only property returning the temperature in degrees Fahrenheit.
	Humidity	Read-only property returning the percentage relative humidity.
	Kelvins	Read-only property returning the temperature in Kelvins.
	ManufacturerID	Read-only property returning the manufacturer ID.

Top

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

DeviceCelsius Property

Read-only property returning the temperature in degrees Celsius.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public double Celsius { get; }
```

Property Value

Type: Double

Implements

SensorCelsius

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

DeviceDeviceID Property

Read-only property returning the device ID.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public ushort DeviceID { get; }
```

Property Value

Type: UInt16

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

DeviceFahrenheit Property

Read-only property returning the temperature in degrees Fahrenheit.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public double Fahrenheit { get; }
```

Property Value

Type: Double

Implements

SensorFahrenheit

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

DeviceHumidity Property

Read-only property returning the percentage relative humidity.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public double Humidity { get; }
```

Property Value

Type: Double

Implements

SensorHumidity

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

DeviceKelvins Property

Read-only property returning the temperature in Kelvins.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public double Kelvins { get; }
```

Property Value

Type: Double

Implements

SensorKelvins

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

DeviceManufacturerID Property

Read-only property returning the manufacturer ID.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public ushort ManufacturerID { get; }
```

Property Value

Type: UInt16

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

Device Methods

The Device type exposes the following members.

Methods

	Name	Description
	Read	Read from an HDC1080 device register.
	Write	Write to an HDC1080 device register.

Top

See Also

Reference

Device Class

IO.Devices.HDC1080 Namespace

DeviceRead Method

Read from an HDC1080 device register.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public ushort Read(
        byte reg
)
```

Parameters

reg
Type: SystemByte
8-bit register address.

Return Value

Type: UInt16
16-bit register data

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

DeviceWrite Method

Write to an HDC1080 device register.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Write(
        byte reg,
        ushort data
)
```

Parameters

reg
Type: SystemByte
8-bit register address.

data
Type: SystemUInt16
16-bit register data.

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

Device Fields

The Device type exposes the following members.

Fields

	Name	Description
	RegConfiguration	Configuration Register address.
	RegDeviceID	Device ID Register address.
	RegHumidity	Humidity Register address.
	RegManufacturerID	Manufacturer ID Register address.
	RegSerialNumberFirst	Serial Number First Bits Register address.
	RegSerialNumberLast	Serial Number Last Bits Register address.
	RegSerialNumberMid	Serial Number Middle Bits Register address.
	RegTemperature	Temperature Register address.

Top

See Also

Reference

Device Class

IO.Devices.HDC1080 Namespace

DeviceRegConfiguration Field

Configuration Register address.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte RegConfiguration = 2
```

Field Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

DeviceRegDeviceID Field

Device ID Register address.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte RegDeviceID = 255
```

Field Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

DeviceRegHumidity Field

Humidity Register address.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte RegHumidity = 1
```

Field Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

DeviceRegManufacturerID Field

Manufacturer ID Register address.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte RegManufacturerID = 254
```

Field Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

DeviceRegSerialNumberFirst Field

Serial Number First Bits Register address.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte RegSerialNumberFirst = 251
```

Field Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

DeviceRegSerialNumberLast Field

Serial Number Last Bits Register address.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte RegSerialNumberLast = 253
```

Field Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

DeviceRegSerialNumberMid Field

Serial Number Middle Bits Register address.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte RegSerialNumberMid = 252
```

Field Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

DeviceRegTemperature Field

Temperature Register address.

Namespace: IO.Devices.HDC1080
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte RegTemperature = 0
```

Field Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.HDC1080 Namespace

IO.Devices.MCP23017 Namespace

MCP23017 I^2C GPIO Expander Device Services.

Classes

	Class	Description
	Device	Encapsulates the MCP23017 I^2C I/O GPIO Expander.

Device Class

Encapsulates the MCP23017 I^{2}C I/O GPIO Expander.

Inheritance Hierarchy

SystemObject IO.Devices.MCP23017Device

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Device
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device	Constructor for a single MCP23017 device.

Top

Properties

	Name	Description
	Direction	Data Direction Property (16 bits). Bits 0

		to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=input and 1=output.
	DirectionA	Port A Data Direction Property (8 bits). For each bit, 0=input and 1=output.
	DirectionB	Port B Data Direction Property (8 bits). For each bit, 0=input and 1=output.
	Polarity	Data Polarity Property (16 bits). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=input and 1=output.
	PolarityA	Port A Data Polarity Property (8 bits). For each bit, 0=input and 1=output.
	PolarityB	Port B Data Polarity Property (8 bits). For each bit, 0=input and 1=output.
	Port	Port Data Property (16 bites). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B.
	PortA	Port A Data Property (8 bits).
	PortB	Port B Data Property (8 bits).
	Pullups	Input Pullup Property (16 bits). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=high impedance and 1=100k pullup.

	PullupsA	Port A Input Pullup Property (16 bits). For each bit, 0=high impedance and 1=100k pullup.
	PullupsB	Port B Input Pullup Property (16 bits). For each bit, 0=high impedance and 1=100k pullup.

Top

Methods

	Name	Description
	GPIO_Create	Create an MCP23017 GPIO pin object.

Top

Fields

	Name	Description
S	MaxChannel	Maximum I/O channel number.
S	MinChannel	Minimum I/O channel number.

Top

See Also

Reference

IO.Devices.MCP23017 Namespace

Device Constructor

Constructor for a single MCP23017 device.

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public Device(
        Bus bus,
        int addr
)
```

Parameters

bus
Type: IO.Interfaces.I2CBus
I^2C bus controller object.

addr
Type: SystemInt32
I^2C slave address.

See Also

Reference

Device Class
IO.Devices.MCP23017 Namespace

Device Properties

The Device type exposes the following members.

Properties

	Name	Description
	Direction	Data Direction Property (16 bits). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=input and 1=output.
	DirectionA	Port A Data Direction Property (8 bits). For each bit, 0=input and 1=output.
	DirectionB	Port B Data Direction Property (8 bits). For each bit, 0=input and 1=output.
	Polarity	Data Polarity Property (16 bits). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=input and 1=output.
	PolarityA	Port A Data Polarity Property (8 bits). For each bit, 0=input and 1=output.
	PolarityB	Port B Data Polarity Property (8 bits). For each bit, 0=input and 1=output.
	Port	Port Data Property (16 bites). Bits 0 to 7 correspond to PORT A and bits 8 to

		15 correspond to PORT B.
	PortA	Port A Data Property (8 bits).
	PortB	Port B Data Property (8 bits).
	Pullups	Input Pullup Property (16 bits). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=high impedance and 1=100k pullup.
	PullupsA	Port A Input Pullup Property (16 bits). For each bit, 0=high impedance and 1=100k pullup.
	PullupsB	Port B Input Pullup Property (16 bits). For each bit, 0=high impedance and 1=100k pullup.

Top

See Also

Reference

Device Class

IO.Devices.MCP23017 Namespace

DeviceDirection Property

Data Direction Property (16 bits). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=input and 1=output.

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public uint Direction { get; set; }
```

Property Value

Type: UInt32

Remarks

This property follows the industry standard convention for data direction bit polarity (1=output) rather than the MCP23017 `IODIR` register polarity (0=output).

See Also

Reference

Device Class
IO.Devices.MCP23017 Namespace

DeviceDirectionA Property

Port A Data Direction Property (8 bits). For each bit, 0=input and 1=output.

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public byte DirectionA { get; set; }
```

Property Value

Type: Byte

Remarks

This property follows the industry standard convention for data direction bit polarity (1=output) rather than the MCP23017 `IODIRA` register polarity (0=output).

See Also

Reference

Device Class
IO.Devices.MCP23017 Namespace

DeviceDirectionB Property

Port B Data Direction Property (8 bits). For each bit, 0=input and 1=output.

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public byte DirectionB { get; set; }
```

Property Value

Type: Byte

Remarks

This property follows the industry standard convention for data direction bit polarity (1=output) rather than the MCP23017 `IODIRA` register polarity (0=output).

See Also

Reference

Device Class
IO.Devices.MCP23017 Namespace

DevicePolarity Property

Data Polarity Property (16 bits). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=input and 1=output.

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public uint Polarity { get; set; }
```

Property Value

Type: UInt32

See Also

Reference

Device Class
IO.Devices.MCP23017 Namespace

DevicePolarityA Property

Port A Data Polarity Property (8 bits). For each bit, 0=input and 1=output.

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public byte PolarityA { get; set; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.MCP23017 Namespace

DevicePolarityB Property

Port B Data Polarity Property (8 bits). For each bit, 0=input and 1=output.

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public byte PolarityB { get; set; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.MCP23017 Namespace

DevicePort Property

Port Data Property (16 bites). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B.

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public uint Port { get; set; }
```

Property Value

Type: UInt32

See Also

Reference

Device Class
IO.Devices.MCP23017 Namespace

DevicePortA Property

Port A Data Property (8 bits).

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public byte PortA { get; set; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.MCP23017 Namespace

DevicePortB Property

Port B Data Property (8 bits).

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public byte PortB { get; set; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.MCP23017 Namespace

DevicePullups Property

Input Pullup Property (16 bits). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=high impedance and 1=100k pullup.

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public uint Pullups { get; set; }
```

Property Value

Type: UInt32

See Also

Reference

Device Class
IO.Devices.MCP23017 Namespace

DevicePullupsA Property

Port A Input Pullup Property (16 bits). For each bit, 0=high impedance and 1=100k pullup.

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public byte PullupsA { get; set; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.MCP23017 Namespace

DevicePullupsB Property

Port B Input Pullup Property (16 bits). For each bit, 0=high impedance and 1=100k pullup.

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public byte PullupsB { get; set; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.MCP23017 Namespace

Device Methods

The Device type exposes the following members.

Methods

	Name	Description
	GPIO_Create	Create an MCP23017 GPIO pin object.

Top

See Also

Reference

Device Class

IO.Devices.MCP23017 Namespace

DeviceGPIO_Create Method

Create an MCP23017 GPIO pin object.

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Pin GPIO_Create(
        int channel,
        Direction dir,
        bool state = false
)
```

Parameters

channel
Type: SystemInt32
MCP23017 channel number (0 to 15).

dir
Type: IO.Interfaces.GPIODirection
GPIO pin data direction.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

Return Value

Type: Pin
GPIO pin object.

See Also

Reference

Device Class

IO.Devices.MCP23017 Namespace

Device Fields

The Device type exposes the following members.

Fields

	Name	Description
	MaxChannel	Maximum I/O channel number.
	MinChannel	Minimum I/O channel number.

Top

See Also

Reference

Device Class

IO.Devices.MCP23017 Namespace

DeviceMaxChannel Field

Maximum I/O channel number.

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int MaxChannel = 15
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.MCP23017 Namespace

DeviceMinChannel Field

Minimum I/O channel number.

Namespace: IO.Devices.MCP23017
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int MinChannel = 0
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.MCP23017 Namespace

IO.Devices.MCP23017.GPIO Namespace

MCP23017 I^{2}C GPIO Expander GPIO Pin Services.

Classes

	Class	Description
	Pin	Encapsulates MCP23017 GPIO pins.

Pin Class

Encapsulates MCP23017 GPIO pins.

Inheritance Hierarchy

SystemObject IO.Devices.MCP23017.GPIOPin

Namespace: IO.Devices.MCP23017.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Pin : Pin
```

The Pin type exposes the following members.

Constructors

	Name	Description
	Pin	Create a single MCP23017 GPIO pin.

Top

Properties

	Name	Description
	state	Read/Write GPIO state property.

Top

See Also

Reference

IO.Devices.MCP23017.GPIO Namespace

Pin Constructor

Create a single MCP23017 GPIO pin.

Namespace: IO.Devices.MCP23017.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Pin(
        Device dev,
        int channel,
        Direction dir,
        bool state = false
)
```

Parameters

dev
Type: IO.Devices.MCP23017Device
MCP23017 device object.

channel
Type: SystemInt32
MCP23017 I/O channel number.

dir
Type: IO.Interfaces.GPIODirection
GPIO pin data direction.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

See Also

Reference

Pin Class

IO.Devices.MCP23017.GPIO Namespace

Pin Properties

The Pin type exposes the following members.

Properties

	Name	Description
	state	Read/Write GPIO state property.

Top

See Also

Reference

Pin Class

IO.Devices.MCP23017.GPIO Namespace

Pinstate Property

Read/Write GPIO state property.

Namespace: IO.Devices.MCP23017.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public bool state { get; set; }
```

Property Value

Type: Boolean

Implements

Pinstate

See Also

Reference

Pin Class
IO.Devices.MCP23017.GPIO Namespace

IO.Devices.MCP23S17 Namespace

MCP23S17 SPI GPIO Expander Device Services.

Classes

	Class	Description
	Device	Encapsulates the MCP23S17 SPI I/O GPIO Expander.

Device Class

Encapsulates the MCP23S17 SPI I/O GPIO Expander.

Inheritance Hierarchy

SystemObject IO.Devices.MCP23S17Device

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Device
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device	Constructor for a single MCP23S17 device.

Top

Properties

	Name	Description
	Direction	Data Direction Property (16 bits). Bits 0

		to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=input and 1=output.
	DirectionA	Port A Data Direction Property (8 bits). For each bit, 0=input and 1=output.
	DirectionB	Port B Data Direction Property (8 bits). For each bit, 0=input and 1=output.
	Polarity	Data Polarity Property (16 bits). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=input and 1=output.
	PolarityA	Port A Data Polarity Property (8 bits). For each bit, 0=input and 1=output.
	PolarityB	Port B Data Polarity Property (8 bits). For each bit, 0=input and 1=output.
	Port	Port Data Property (16 bites). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B.
	PortA	Port A Data Property (8 bits).
	PortB	Port B Data Property (8 bits).
	Pullups	Input Pullup Property (16 bits). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=high impedance and 1=100k pullup.

	PullupsA	Port A Input Pullup Property (16 bits). For each bit, 0=high impedance and 1=100k pullup.
	PullupsB	Port B Input Pullup Property (16 bits). For each bit, 0=high impedance and 1=100k pullup.

Top

Methods

	Name	Description
	GPIO_Create	Create an MCP23S17 GPIO pin object.

Top

Fields

	Name	Description
S	MaxChannel	Maximum I/O channel number.
S	MinChannel	Minimum I/O channel number.
S	SPI_Frequency	SPI maximum clock frequency in Hz.
S	SPI_Mode	SPI transfer mode.
S	SPI_WordSize	SPI transaction word size.

Top

See Also

Reference

IO.Devices.MCP23S17 Namespace

Device Constructor

Constructor for a single MCP23S17 device.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public Device(
        Device dev
)
```

Parameters

dev
Type: IO.Interfaces.SPIDevice
SPI slave device object.

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

Device Properties

The Device type exposes the following members.

Properties

	Name	Description
	Direction	Data Direction Property (16 bits). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=input and 1=output.
	DirectionA	Port A Data Direction Property (8 bits). For each bit, 0=input and 1=output.
	DirectionB	Port B Data Direction Property (8 bits). For each bit, 0=input and 1=output.
	Polarity	Data Polarity Property (16 bits). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=input and 1=output.
	PolarityA	Port A Data Polarity Property (8 bits). For each bit, 0=input and 1=output.
	PolarityB	Port B Data Polarity Property (8 bits). For each bit, 0=input and 1=output.
	Port	Port Data Property (16 bites). Bits 0 to 7 correspond to PORT A and bits 8 to

		15 correspond to PORT B.
	PortA	Port A Data Property (8 bits).
	PortB	Port B Data Property (8 bits).
	Pullups	Input Pullup Property (16 bits). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=high impedance and 1=100k pullup.
	PullupsA	Port A Input Pullup Property (16 bits). For each bit, 0=high impedance and 1=100k pullup.
	PullupsB	Port B Input Pullup Property (16 bits). For each bit, 0=high impedance and 1=100k pullup.

Top

See Also

Reference

Device Class

IO.Devices.MCP23S17 Namespace

DeviceDirection Property

Data Direction Property (16 bits). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=input and 1=output.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public uint Direction { get; set; }
```

Property Value

Type: UInt32

Remarks

This property follows the industry standard convention for data direction bit polarity (1=output) rather than the MCP23S17 `IODIR` register polarity (0=output).

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

DeviceDirectionA Property

Port A Data Direction Property (8 bits). For each bit, 0=input and 1=output.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public byte DirectionA { get; set; }
```

Property Value

Type: Byte

Remarks

This property follows the industry standard convention for data direction bit polarity (1=output) rather than the MCP23S17 `IODIRA` register polarity (0=output).

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

DeviceDirectionB Property

Port B Data Direction Property (8 bits). For each bit, 0=input and 1=output.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public byte DirectionB { get; set; }
```

Property Value

Type: Byte

Remarks

This property follows the industry standard convention for data direction bit polarity (1=output) rather than the MCP23S17 `IODIRA` register polarity (0=output).

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

DevicePolarity Property

Data Polarity Property (16 bits). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=input and 1=output.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public uint Polarity { get; set; }
```

Property Value

Type: UInt32

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

DevicePolarityA Property

Port A Data Polarity Property (8 bits). For each bit, 0=input and 1=output.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public byte PolarityA { get; set; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

DevicePolarityB Property

Port B Data Polarity Property (8 bits). For each bit, 0=input and 1=output.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public byte PolarityB { get; set; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

DevicePort Property

Port Data Property (16 bites). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public uint Port { get; set; }
```

Property Value

Type: UInt32

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

DevicePortA Property

Port A Data Property (8 bits).

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public byte PortA { get; set; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

DevicePortB Property

Port B Data Property (8 bits).

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public byte PortB { get; set; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

DevicePullups Property

Input Pullup Property (16 bits). Bits 0 to 7 correspond to PORT A and bits 8 to 15 correspond to PORT B. For each bit, 0=high impedance and 1=100k pullup.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public uint Pullups { get; set; }
```

Property Value

Type: UInt32

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

DevicePullupsA Property

Port A Input Pullup Property (16 bits). For each bit, 0=high impedance and 1=100k pullup.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public byte PullupsA { get; set; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

DevicePullupsB Property

Port B Input Pullup Property (16 bits). For each bit, 0=high impedance and 1=100k pullup.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public byte PullupsB { get; set; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

Device Methods

The Device type exposes the following members.

Methods

	Name	Description
	GPIO_Create	Create an MCP23S17 GPIO pin object.

Top

See Also

Reference

Device Class

IO.Devices.MCP23S17 Namespace

DeviceGPIO_Create Method

Create an MCP23S17 GPIO pin object.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Pin GPIO_Create(
        int channel,
        Direction dir,
        bool state = false
)
```

Parameters

channel
Type: SystemInt32
MCP23S17 channel number (0 to 15).

dir
Type: IO.Interfaces.GPIODirection
GPIO pin data direction.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

Return Value

Type: Pin
GPIO pin object.

See Also

Reference

Device Class

IO.Devices.MCP23S17 Namespace

Device Fields

The Device type exposes the following members.

Fields

	Name	Description
S	MaxChannel	Maximum I/O channel number.
S	MinChannel	Minimum I/O channel number.
S	SPI_Frequency	SPI maximum clock frequency in Hz.
S	SPI_Mode	SPI transfer mode.
S	SPI_WordSize	SPI transaction word size.

Top

See Also

Reference

Device Class

IO.Devices.MCP23S17 Namespace

DeviceMaxChannel Field

Maximum I/O channel number.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int MaxChannel = 15
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

DeviceMinChannel Field

Minimum I/O channel number.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int MinChannel = 0
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

DeviceSPI_Frequency Field

SPI maximum clock frequency in Hz.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int SPI_Frequency = 10000000
```

Field Value

Type: Int32

Remarks

Guaranteed only for 2.7V to 5.5V and -40°C to +85°C.

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

DeviceSPI_Mode Field

SPI transfer mode.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int SPI_Mode = 0
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

DeviceSPI_WordSize Field

SPI transaction word size.

Namespace: IO.Devices.MCP23S17
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int SPI_WordSize = 8
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.MCP23S17 Namespace

IO.Devices.MCP23S17.GPIO Namespace

MCP23S17 SPI GPIO Expander GPIO Pin Services.

Classes

	Class	Description
	Pin	Encapsulates MCP23S17 GPIO pins.

Pin Class

Encapsulates MCP23S17 GPIO pins.

Inheritance Hierarchy

SystemObject IO.Devices.MCP23S17.GPIOPin

Namespace: IO.Devices.MCP23S17.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Pin : Pin
```

The Pin type exposes the following members.

Constructors

	Name	Description
	Pin	Create a single MCP23S17 GPIO pin.

Top

Properties

	Name	Description
	state	Read/Write GPIO state property.

Top

See Also

Reference

IO.Devices.MCP23S17.GPIO Namespace

Pin Constructor

Create a single MCP23S17 GPIO pin.

Namespace: IO.Devices.MCP23S17.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Pin(
        Device dev,
        int channel,
        Direction dir,
        bool state = false
)
```

Parameters

dev
Type: IO.Devices.MCP23S17Device
MCP23S17 device object.

channel
Type: SystemInt32
MCP23S17 I/O channel number.

dir
Type: IO.Interfaces.GPIODirection
GPIO pin data direction.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

See Also

Reference

Pin Class

IO.Devices.MCP23S17.GPIO Namespace

Pin Properties

The Pin type exposes the following members.

Properties

	Name	Description
	state	Read/Write GPIO state property.

Top

See Also

Reference

Pin Class

IO.Devices.MCP23S17.GPIO Namespace

Pinstate Property

Read/Write GPIO state property.

Namespace: IO.Devices.MCP23S17.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public bool state { get; set; }
```

Property Value

Type: Boolean

Implements

Pinstate

See Also

Reference

Pin Class
IO.Devices.MCP23S17.GPIO Namespace

IO.Devices.PCA8574 Namespace

PCA8574 (and similar) I^2C GPIO Expander Device Services

Classes

	Class	Description
	Device	Encapsulates PCA8574 (and similar) I^2C GPIO Expanders.

Device Class

Encapsulates PCA8574 (and similar) I^{2}C GPIO Expanders.

Inheritance Hierarchy

SystemObject IO.Devices.PCA8574Device

Namespace: IO.Devices.PCA8574
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Device
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device	Constructor for a PCA8574 (or similar) GPIO Expander.

Top

Properties

	Name	Description
	Latch	This read-only property returns the last

value written to the output latch.

Top

Methods

	Name	Description
	Read	Return actual state of the GPIO pins.
	Write	Write all GPIO pins.

Top

Fields

	Name	Description
S	MAX_PINS	The number of available GPIO pins per chip.

Top

See Also

Reference

IO.Devices.PCA8574 Namespace

Device Constructor

Constructor for a PCA8574 (or similar) GPIO Expander.

Namespace: IO.Devices.PCA8574
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Device(
        Bus bus,
        int addr,
        byte states = 255
)
```

Parameters

bus
Type: IO.Interfaces.I2CBus
I^2C bus controller.

addr
Type: SystemInt32
I^2C slave address.

states **(Optional)**
Type: SystemByte
Initial output states.

See Also

Reference

Device Class
IO.Devices.PCA8574 Namespace

Device Properties

The Device type exposes the following members.

Properties

	Name	Description
	Latch	This read-only property returns the last value written to the output latch.

Top

See Also

Reference

Device Class

IO.Devices.PCA8574 Namespace

DeviceLatch Property

This read-only property returns the last value written to the output latch.

Namespace: IO.Devices.PCA8574
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public byte Latch { get; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.PCA8574 Namespace

Device Methods

The Device type exposes the following members.

Methods

	Name	Description
	Read	Return actual state of the GPIO pins.
	Write	Write all GPIO pins.

Top

See Also

Reference

Device Class

IO.Devices.PCA8574 Namespace

DeviceRead Method

Return actual state of the GPIO pins.

Namespace: IO.Devices.PCA8574
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public byte Read()
```

Return Value

Type: Byte
Pin states (MSB = GPIO7).

See Also

Reference

Device Class
IO.Devices.PCA8574 Namespace

DeviceWrite Method

Write all GPIO pins.

Namespace: IO.Devices.PCA8574
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Write(
        byte data
)
```

Parameters

data
Type: SystemByte
Data to write to pins (MSB = GPIO7).

See Also

Reference

Device Class
IO.Devices.PCA8574 Namespace

Device Fields

The Device type exposes the following members.

Fields

	Name	Description
	MAX_PINS	The number of available GPIO pins per chip.

Top

See Also

Reference

Device Class

IO.Devices.PCA8574 Namespace

DeviceMAX_PINS Field

The number of available GPIO pins per chip.

Namespace: IO.Devices.PCA8574
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int MAX_PINS = 8
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.PCA8574 Namespace

IO.Devices.PCA8574.GPIO Namespace

PCA8574 (and similar) I^{2}C GPIO Expander GPIO Pin Services

Classes

	Class	Description
	Pin	Encapsulates PCA8574 (and similar) I^{2}C GPIO Expander pins.

Pin Class

Encapsulates PCA8574 (and similar) I^{2}C GPIO Expander pins.

Inheritance Hierarchy

SystemObject IO.Devices.PCA8574.GPIOPin

Namespace: IO.Devices.PCA8574.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Pin : Pin
```

The Pin type exposes the following members.

Constructors

	Name	Description
	Pin	Constructor for a single GPIO pin.

Top

Properties

	Name	Description
	state	Read/Write GPIO state property.

Top

See Also

Reference

IO.Devices.PCA8574.GPIO Namespace

Pin Constructor

Constructor for a single GPIO pin.

Namespace: IO.Devices.PCA8574.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Pin(
        Device dev,
        int num,
        Direction dir,
        bool state = false
)
```

Parameters

dev
Type: IO.Devices.PCA8574Device
PCA8574 (or similar) device.

num
Type: SystemInt32
GPIO pin number.

dir
Type: IO.Interfaces.GPIODirection
Data direction.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

See Also

Reference

Pin Class

IO.Devices.PCA8574.GPIO Namespace

Pin Properties

The Pin type exposes the following members.

Properties

	Name	Description
	state	Read/Write GPIO state property.

Top

See Also

Reference

Pin Class

IO.Devices.PCA8574.GPIO Namespace

Pinstate Property

Read/Write GPIO state property.

Namespace: IO.Devices.PCA8574.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public bool state { get; set; }
```

Property Value

Type: Boolean

Implements

Pinstate

See Also

Reference

Pin Class
IO.Devices.PCA8574.GPIO Namespace

IO.Devices.PCA9534 Namespace

PCA9534 (and similar) I^2C GPIO Expander Device Services

Classes

	Class	Description
	Device	Encapsulates PCA9534 (and similar) I^2C GPIO Expanders.

Device Class

Encapsulates PCA9534 (and similar) I^{2}C GPIO Expanders.

Inheritance Hierarchy

SystemObject IO.Devices.PCA9534Device

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Device
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device	Constructor for a PCA9534 (or similar) GPIO Expander.

Top

Properties

	Name	Description
	Config	This read-only property returns the last

		value written to the configuration register.
	Latch	This read-only property returns the last value written to the output port register.

Top

Methods

	Name	Description
	Read	Return actual state of the GPIO pins.
	Read(Byte)	Read from the specified PCA9534 device register.
	Write(Byte)	Write all GPIO pins.
	Write(Byte, Byte)	Write to the specified PCA9534 device register.

Top

Fields

	Name	Description
S	AllInputs	Configure all pins as inputs.
S	AllNormal	Configure all inputs as normal polarity.
S	AllOff	Turn all outputs off.
S	AllOutputs	Configure all pins as outputs.

S	ConfigurationReg	Configuration Register address.
S	InputPolarityReg	Input Port Polarity Register address.
S	InputPortReg	Input Port Register address.
S	MAX_PINS	The number of available GPIO pins per chip.
S	OutputPortReg	Output Port Register address.

Top

See Also

Reference

IO.Devices.PCA9534 Namespace

Device Constructor

Constructor for a PCA9534 (or similar) GPIO Expander.

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Device(
        Bus bus,
        int addr,
        byte config = 255,
        byte states = 0
)
```

Parameters

bus
Type: IO.Interfaces.I2CBus
I^2C bus controller.

addr
Type: SystemInt32
I^2C slave address.

config **(Optional)**
Type: SystemByte
GPIO pin configuration.

states **(Optional)**
Type: SystemByte
Initial output states.

See Also

Reference

Device Class

IO.Devices.PCA9534 Namespace

Device Properties

The Device type exposes the following members.

Properties

	Name	Description
	Config	This read-only property returns the last value written to the configuration register.
	Latch	This read-only property returns the last value written to the output port register.

Top

See Also

Reference

Device Class

IO.Devices.PCA9534 Namespace

DeviceConfig Property

This read-only property returns the last value written to the configuration register.

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public byte Config { get; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.PCA9534 Namespace

DeviceLatch Property

This read-only property returns the last value written to the output port register.

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public byte Latch { get; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.PCA9534 Namespace

Device Methods

Methods

	Name	Description
	Read	Return actual state of the GPIO pins.
	Read(Byte)	Read from the specified PCA9534 device register.
	Write(Byte)	Write all GPIO pins.
	Write(Byte, Byte)	Write to the specified PCA9534 device register.

Top

See Also

Reference

Device Class

IO.Devices.PCA9534 Namespace

DeviceRead Method

Overload List

	Name	Description
	Read	Return actual state of the GPIO pins.
	Read(Byte)	Read from the specified PCA9534 device register.

Top

See Also

Reference

Device Class

IO.Devices.PCA9534 Namespace

DeviceRead Method

Return actual state of the GPIO pins.

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public byte Read()
```

Return Value

Type: Byte
Pin states (MSB = GPIO7).

See Also

Reference

Device Class
Read Overload
IO.Devices.PCA9534 Namespace

DeviceRead Method (Byte)

Read from the specified PCA9534 device register.

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public byte Read(
        byte addr
)
```

Parameters

addr
Type: SystemByte
Register address.

Return Value

Type: Byte
Register contents.

See Also

Reference

Device Class
Read Overload
IO.Devices.PCA9534 Namespace

DeviceWrite Method

Overload List

	Name	Description
	Write(Byte)	Write all GPIO pins.
	Write(Byte, Byte)	Write to the specified PCA9534 device register.

Top

See Also

Reference

Device Class

IO.Devices.PCA9534 Namespace

DeviceWrite Method (Byte)

Write all GPIO pins.

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public void Write(
        byte data
)
```

Parameters

data
Type: SystemByte
Data to write to pins (MSB = GPIO7).

See Also

Reference

Device Class
Write Overload
IO.Devices.PCA9534 Namespace

DeviceWrite Method (Byte, Byte)

Write to the specified PCA9534 device register.

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Write(
        byte addr,
        byte data
)
```

Parameters

addr
Type: SystemByte
Register address.

data
Type: SystemByte
Data to written.

See Also

Reference

Device Class
Write Overload
IO.Devices.PCA9534 Namespace

Device Fields

The Device type exposes the following members.

Fields

	Name	Description
S	AllInputs	Configure all pins as inputs.
S	AllNormal	Configure all inputs as normal polarity.
S	AllOff	Turn all outputs off.
S	AllOutputs	Configure all pins as outputs.
S	ConfigurationReg	Configuration Register address.
S	InputPolarityReg	Input Port Polarity Register address.
S	InputPortReg	Input Port Register address.
S	MAX_PINS	The number of available GPIO pins per chip.
S	OutputPortReg	Output Port Register address.

Top

See Also

Reference

Device Class

IO.Devices.PCA9534 Namespace

DeviceAllInputs Field

Configure all pins as inputs.

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte AllInputs = 255
```

Field Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.PCA9534 Namespace

DeviceAllNormal Field

Configure all inputs as normal polarity.

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte AllNormal = 0
```

Field Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.PCA9534 Namespace

DeviceAllOff Field

Turn all outputs off.

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte AllOff = 0
```

Field Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.PCA9534 Namespace

DeviceAllOutputs Field

Configure all pins as outputs.

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte AllOutputs = 0
```

Field Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.PCA9534 Namespace

DeviceConfigurationReg Field

Configuration Register address.

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte ConfigurationReg = 3
```

Field Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.PCA9534 Namespace

DeviceInputPolarityReg Field

Input Port Polarity Register address.

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte InputPolarityReg = 2
```

Field Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.PCA9534 Namespace

DeviceInputPortReg Field

Input Port Register address.

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte InputPortReg = 0
```

Field Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.PCA9534 Namespace

DeviceMAX_PINS Field

The number of available GPIO pins per chip.

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int MAX_PINS = 8
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.PCA9534 Namespace

DeviceOutputPortReg Field

Output Port Register address.

Namespace: IO.Devices.PCA9534
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const byte OutputPortReg = 1
```

Field Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.PCA9534 Namespace

IO.Devices.PCA9534.GPIO Namespace

PCA9534 (and similar) I^2C GPIO Expander GPIO Pin Services

Classes

	Class	Description
	Pin	Encapsulates PCA9534 (and similar) I^2C GPIO Expander pins.

Pin Class

Encapsulates PCA9534 (and similar) I^{2}C GPIO Expander pins.

Inheritance Hierarchy

SystemObject IO.Devices.PCA9534.GPIOPin

Namespace: IO.Devices.PCA9534.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Pin : Pin
```

The Pin type exposes the following members.

Constructors

	Name	Description
	Pin	Constructor for a single GPIO pin.

Top

Properties

	Name	Description
	state	Read/Write GPIO state property.

Top

See Also

Reference

IO.Devices.PCA9534.GPIO Namespace

Pin Constructor

Constructor for a single GPIO pin.

Namespace: IO.Devices.PCA9534.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Pin(
        Device dev,
        int num,
        Direction dir,
        bool state = false
)
```

Parameters

dev
Type: IO.Devices.PCA9534Device
PCA9534 (or similar) device.

num
Type: SystemInt32
GPIO pin number.

dir
Type: IO.Interfaces.GPIODirection
Data direction.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

See Also

Reference

Pin Class

IO.Devices.PCA9534.GPIO Namespace

Pin Properties

The Pin type exposes the following members.

Properties

	Name	Description
	state	Read/Write GPIO state property.

Top

See Also

Reference

Pin Class

IO.Devices.PCA9534.GPIO Namespace

Pinstate Property

Read/Write GPIO state property.

Namespace: IO.Devices.PCA9534.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public bool state { get; set; }
```

Property Value

Type: Boolean

Implements

Pinstate

See Also

Reference

Pin Class
IO.Devices.PCA9534.GPIO Namespace

IO.Devices.PCA9685 Namespace

PCA9685 I^{2}C PWM Controller Device Services

Classes

	Class	Description
	Device	Encapsulates the PCA9685 I^{2}C PWM Controller.

Device Class

Encapsulates the PCA9685 I^{2}C PWM Controller.

Inheritance Hierarchy

SystemObject IO.Devices.PCA9685Device

Namespace: IO.Devices.PCA9685
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Device
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device	Constructor for a single PCA9685 device.

Top

Properties

	Name	Description
	Frequency	Read-only property returning the configured PWM pulse frequency.

Top

Methods

	Name	Description
	ReadChannel	Read PCA9685 output channel data.
	WriteChannel	Write PCA9685 output channel data.

Top

Fields

	Name	Description
S	INTERNAL_CLOCK	Select internal 25 MHz clock oscillator.
S	MAX_CHANNEL	Maximum PCA9685 output channel number.
S	MAX_CLOCK	Maximum clock frequency.
S	MIN_CHANNEL	Minimum PCA9685 output channel number.
S	MIN_CLOCK	Minimum clock frequency.

Top

See Also

Reference

IO.Devices.PCA9685 Namespace

Device Constructor

Constructor for a single PCA9685 device.

Namespace: IO.Devices.PCA9685
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Device(
        Bus bus,
        int addr,
        int freq = 50,
        int clock = 0
)
```

Parameters

bus
Type: IO.Interfaces.I2CBus
I²C bus controller object.

addr
Type: SystemInt32
I²C slave address.

freq **(Optional)**
Type: SystemInt32
PWM pulse frequency. Default is 50 Hz.

clock **(Optional)**
Type: SystemInt32
PCA9685 clock source. Use `INTERNAL_CLOCK`c> to select the

internal 25 MHz clock generator.

See Also

Reference

Device Class

IO.Devices.PCA9685 Namespace

Device Properties

The Device type exposes the following members.

Properties

	Name	Description
	Frequency	Read-only property returning the configured PWM pulse frequency.

Top

See Also

Reference

Device Class

IO.Devices.PCA9685 Namespace

DeviceFrequency Property

Read-only property returning the configured PWM pulse frequency.

Namespace: IO.Devices.PCA9685
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int Frequency { get; }
```

Property Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.PCA9685 Namespace

Device Methods

The Device type exposes the following members.

Methods

	Name	Description
	ReadChannel	Read PCA9685 output channel data.
	WriteChannel	Write PCA9685 output channel data.

Top

See Also

Reference

Device Class

IO.Devices.PCA9685 Namespace

DeviceReadChannel Method

Read PCA9685 output channel data.

Namespace: IO.Devices.PCA9685
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public void ReadChannel(
        byte channel,
        ref byte[] data
)
```

Parameters

channel
Type: SystemByte
Output channel number.

data
Type: SystemByte
Output channel data (4 bytes).

See Also

Reference

Device Class
IO.Devices.PCA9685 Namespace

DeviceWriteChannel Method

Write PCA9685 output channel data.

Namespace: IO.Devices.PCA9685
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public void WriteChannel(
        byte channel,
        byte[] data
)
```

Parameters

channel
Type: SystemByte
Output channel number.

data
Type: SystemByte
Output channel data.

See Also

Reference

Device Class
IO.Devices.PCA9685 Namespace

Device Fields

The Device type exposes the following members.

Fields

	Name	Description
S	INTERNAL_CLOCK	Select internal 25 MHz clock oscillator.
S	MAX_CHANNEL	Maximum PCA9685 output channel number.
S	MAX_CLOCK	Maximum clock frequency.
S	MIN_CHANNEL	Minimum PCA9685 output channel number.
S	MIN_CLOCK	Minimum clock frequency.

Top

See Also

Reference

Device Class

IO.Devices.PCA9685 Namespace

DeviceINTERNAL_CLOCK Field

Select internal 25 MHz clock oscillator.

Namespace: IO.Devices.PCA9685
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int INTERNAL_CLOCK = 0
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.PCA9685 Namespace

DeviceMAX_CHANNEL Field

Maximum PCA9685 output channel number.

Namespace: IO.Devices.PCA9685
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int MAX_CHANNEL = 15
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.PCA9685 Namespace

DeviceMAX_CLOCK Field

Maximum clock frequency.

Namespace: IO.Devices.PCA9685
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int MAX_CLOCK = 50000000
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.PCA9685 Namespace

DeviceMIN_CHANNEL Field

Minimum PCA9685 output channel number.

Namespace: IO.Devices.PCA9685
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int MIN_CHANNEL = 0
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.PCA9685 Namespace

DeviceMIN_CLOCK Field

Minimum clock frequency.

Namespace: IO.Devices.PCA9685
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int MIN_CLOCK = 1
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.PCA9685 Namespace

IO.Devices.PCA9685.GPIO Namespace

PCA9685 I^{2}C PWM Controller GPIO Pin Services

Classes

	Class	Description
	Pin	Encapsulates PCA9685 GPIO outputs.

Pin Class

Encapsulates PCA9685 GPIO outputs.

Inheritance Hierarchy

SystemObject IO.Devices.PCA9685.GPIOPin

Namespace: IO.Devices.PCA9685.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Pin : Pin
```

The Pin type exposes the following members.

Constructors

	Name	Description
	Pin	Constructor for a single GPIO output pin.

Top

Properties

	Name	Description
	state	Read/Write GPIO output state property.

Top

See Also

Reference

IO.Devices.PCA9685.GPIO Namespace

Pin Constructor

Constructor for a single GPIO output pin.

Namespace: IO.Devices.PCA9685.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Pin(
        Device dev,
        int channel,
        bool state = false
)
```

Parameters

dev
Type: IO.Devices.PCA9685Device
PCA9685 device object.

channel
Type: SystemInt32
Output channel number.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

See Also

Reference

Pin Class

IO.Devices.PCA9685.GPIO Namespace

Pin Properties

The Pin type exposes the following members.

Properties

	Name	Description
	state	Read/Write GPIO output state property.

Top

See Also

Reference

Pin Class

IO.Devices.PCA9685.GPIO Namespace

Pinstate Property

Read/Write GPIO output state property.

Namespace: IO.Devices.PCA9685.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public bool state { get; set; }
```

Property Value

Type: Boolean

Implements

Pinstate

See Also

Reference

Pin Class
IO.Devices.PCA9685.GPIO Namespace

IO.Devices.PCA9685.PWM Namespace

PCA9685 I^{2}C PWM Controller PWM Output Services

Classes

	Class	Description
	Output	Encapsulates PCA9685 PWM outputs.

Output Class

Encapsulates PCA9685 PWM outputs.

Inheritance Hierarchy

SystemObject IO.Devices.PCA9685.PWMOutput

Namespace: IO.Devices.PCA9685.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Output : Output
```

The Output type exposes the following members.

Constructors

	Name	Description
	Output	Constructor for a single PWM output.

Top

Properties

	Name	Description
	dutycycle	Write-only property for setting the PWM output duty cycle. Allowed values

are 0.0 to 100.0 percent.

Top

See Also

Reference

IO.Devices.PCA9685.PWM Namespace

Output Constructor

Constructor for a single PWM output.

Namespace: IO.Devices.PCA9685.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Output(
        Device dev,
        int channel,
        double dutycycle = 0
)
```

Parameters

dev
Type: IO.Devices.PCA9685Device
PCA9685 device object.

channel
Type: SystemInt32
Output channel number.

dutycycle **(Optional)**
Type: SystemDouble
Initial PWM output duty cycle.

See Also

Reference

Output Class

IO.Devices.PCA9685.PWM Namespace

Output Properties

The Output type exposes the following members.

Properties

	Name	Description
	dutycycle	Write-only property for setting the PWM output duty cycle. Allowed values are 0.0 to 100.0 percent.

Top

See Also

Reference

Output Class
IO.Devices.PCA9685.PWM Namespace

Outputdutycycle Property

Write-only property for setting the PWM output duty cycle. Allowed values are 0.0 to 100.0 percent.

Namespace: IO.Devices.PCA9685.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public double dutycycle { set; }
```

Property Value

Type: Double

Implements

Outputdutycycle

See Also

Reference

Output Class
IO.Devices.PCA9685.PWM Namespace

IO.Devices.PCA9685.Servo Namespace

PCA9685 I^{2}C PWM Controller Servo Output Services

Classes

	Class	Description
	Output	Encapsulates PCA9685 servo outputs.

Output Class

Encapsulates PCA9685 servo outputs.

Inheritance Hierarchy

SystemObject IO.Devices.PCA9685.ServoOutput

Namespace: IO.Devices.PCA9685.Servo
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Output : Output
```

The Output type exposes the following members.

Constructors

	Name	Description
	Output	Constructor for a single servo output.

Top

Properties

	Name	Description
	position	Write-only property for setting the normalized servo position. Allowed

values are -0.0 to+1.0.

Top

See Also

Reference

IO.Devices.PCA9685.Servo Namespace

Output Constructor

Constructor for a single servo output.

Namespace: IO.Devices.PCA9685.Servo
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Output(
        Device dev,
        int channel,
        double position = 0
)
```

Parameters

dev
Type: IO.Devices.PCA9685Device
PCA9685 device object.

channel
Type: SystemInt32
Output channel number.

position **(Optional)**
Type: SystemDouble
Initial servo position.

See Also

Reference

Output Class

IO.Devices.PCA9685.Servo Namespace

Output Properties

The Output type exposes the following members.

Properties

	Name	Description
	position	Write-only property for setting the normalized servo position. Allowed values are -0.0 to+1.0.

Top

See Also

Reference

Output Class
IO.Devices.PCA9685.Servo Namespace

Outputposition Property

Write-only property for setting the normalized servo position. Allowed values are -0.0 to+1.0.

Namespace: IO.Devices.PCA9685.Servo
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public double position { set; }
```

Property Value

Type: Double

Implements

Outputposition

See Also

Reference

Output Class
IO.Devices.PCA9685.Servo Namespace

IO.Devices.Pmod.HYGRO Namespace

Digilent Pmod HYGRO Temperature and Humdity Sensor (HDC1080) Services.

Classes

	Class	Description
	Device	Encapsulate the Digilent Pmod HYGRO Temperature and Humidity Sensor (HDC1080).

Device Class

Encapsulate the Digilent Pmod HYGRO Temperature and Humidity Sensor (HDC1080).

Inheritance Hierarchy

SystemObject IO.Devices.HDC1080Device
IO.Devices.Pmod.HYGRODevice

Namespace: IO.Devices.Pmod.HYGRO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Device : Device
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device	Constructor for a Digilent Pmod HYGRO Temperature and Humidity Sensor (HDC1080).

Top

Properties

	Name	Description
	Celsius	Read-only property returning the temperature in degrees Celsius. (Inherited from Device.)
	DeviceID	Read-only property returning the device ID. (Inherited from Device.)
	Fahrenheit	Read-only property returning the temperature in degrees Fahrenheit. (Inherited from Device.)
	Humidity	Read-only property returning the percentage relative humidity. (Inherited from Device.)
	Kelvins	Read-only property returning the temperature in Kelvins. (Inherited from Device.)
	ManufacturerID	Read-only property returning the manufacturer ID. (Inherited from Device.)

Top

Methods

	Name	Description
	Read	Read from an HDC1080 device register. (Inherited from Device.)

	Write	Write to an HDC1080 device register. (Inherited from Device.)

Top

See Also

Reference

IO.Devices.Pmod.HYGRO Namespace

Device Constructor

Constructor for a Digilent Pmod HYGRO Temperature and Humidity Sensor (HDC1080).

Namespace: IO.Devices.Pmod.HYGRO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public Device(
        Bus bus
)
```

Parameters

bus
Type: IO.Interfaces.I2CBus
I^2 bus object.

See Also

Reference

Device Class
IO.Devices.Pmod.HYGRO Namespace

Device Properties

The Device type exposes the following members.

Properties

	Name	Description
	Celsius	Read-only property returning the temperature in degrees Celsius. (Inherited from Device.)
	DeviceID	Read-only property returning the device ID. (Inherited from Device.)
	Fahrenheit	Read-only property returning the temperature in degrees Fahrenheit. (Inherited from Device.)
	Humidity	Read-only property returning the percentage relative humidity. (Inherited from Device.)
	Kelvins	Read-only property returning the temperature in Kelvins. (Inherited from Device.)
	ManufacturerID	Read-only property returning the manufacturer ID.

(Inherited from Device.)

Top

See Also

Reference

Device Class
IO.Devices.Pmod.HYGRO Namespace

Device Methods

The Device type exposes the following members.

Methods

	Name	Description
	Read	Read from an HDC1080 device register. (Inherited from Device.)
	Write	Write to an HDC1080 device register. (Inherited from Device.)

Top

See Also

Reference

Device Class

IO.Devices.Pmod.HYGRO Namespace

IO.Devices.SN74HC595 Namespace

SN74HC595 8-Bit Shift Register Device Services

Classes

	Class	Description
	Device	Encapsulates a chain of one or more SN74HC595 8-bit shift registers.

Device Class

Encapsulates a chain of one or more SN74HC595 8-bit shift registers.

Inheritance Hierarchy

SystemObject IO.Devices.SN74HC595Device

Namespace: IO.Devices.SN74HC595
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Device
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device	Constructor for a chain of one or more SN74HC595 shift registers.

Top

Properties

	Name	Description
	Length	Read-only property returning the

		number of stages in the chain.
	state	Read/Write shift register chain state property.

Top

Methods

	Name	Description
	ClrBit	Clear a single bit in the shift register chain.
	ReadBit	Read a single bit in the shift register chain.
	SetBit	Set a single bit in the shift register chain.

Top

Fields

	Name	Description
S	SPI_MaxFreq	SPI maximum clock frequency for the SNHC74HC595 shift register. (Most pessimistic datasheet limit at 2V.)
S	SPI_Mode	SPI clock mode for the SNHC74HC595 shift register.

Top

See Also

Reference

IO.Devices.SN74HC595 Namespace

Device Constructor

Constructor for a chain of one or more SN74HC595 shift registers.

Namespace: IO.Devices.SN74HC595
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Device(
        Device dev,
        int stages = 1,
        byte[] initialstate = null
)
```

Parameters

dev
Type: IO.Interfaces.SPIDevice
SPI device object.

stages **(Optional)**
Type: SystemInt32
Number of stages in the chain.

initialstate **(Optional)**
Type: SystemByte
Initial shift register chain state.

See Also

Reference

Device Class

IO.Devices.SN74HC595 Namespace

Device Properties

The Device type exposes the following members.

Properties

	Name	Description
	Length	Read-only property returning the number of stages in the chain.
	state	Read/Write shift register chain state property.

Top

See Also

Reference

Device Class

IO.Devices.SN74HC595 Namespace

DeviceLength Property

Read-only property returning the number of stages in the chain.

Namespace: IO.Devices.SN74HC595
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int Length { get; }
```

Property Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.SN74HC595 Namespace

Devicestate Property

Read/Write shift register chain state property.

Namespace: IO.Devices.SN74HC595
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public byte[] state { get; set; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.SN74HC595 Namespace

Device Methods

The Device type exposes the following members.

Methods

	Name	Description
	ClrBit	Clear a single bit in the shift register chain.
	ReadBit	Read a single bit in the shift register chain.
	SetBit	Set a single bit in the shift register chain.

Top

See Also

Reference

Device Class

IO.Devices.SN74HC595 Namespace

DeviceClrBit Method

Clear a single bit in the shift register chain.

Namespace: IO.Devices.SN74HC595
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void ClrBit(
        int index,
        byte mask
)
```

Parameters

index
Type: SystemInt32
Shift register stage number. Zero indicates the first register stage.

mask
Type: SystemByte
Shift register bit mask.

See Also

Reference

Device Class
IO.Devices.SN74HC595 Namespace

DeviceReadBit Method

Read a single bit in the shift register chain.

Namespace: IO.Devices.SN74HC595
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public bool ReadBit(
        int index,
        byte mask
)
```

Parameters

index
Type: SystemInt32
Shift register stage number. Zero indicates the first register stage.

mask
Type: SystemByte
Shift register bit mask.

Return Value

Type: Boolean
Boolean bit value.

See Also

Reference

Device Class

IO.Devices.SN74HC595 Namespace

DeviceSetBit Method

Set a single bit in the shift register chain.

Namespace: IO.Devices.SN74HC595
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public void SetBit(
        int index,
        byte mask
)
```

Parameters

index
Type: SystemInt32
Shift register stage number. Zero indicates the first register stage.

mask
Type: SystemByte
Shift register bit mask.

See Also

Reference

Device Class
IO.Devices.SN74HC595 Namespace

Device Fields

The Device type exposes the following members.

Fields

	Name	Description
	SPI_MaxFreq	SPI maximum clock frequency for the SNHC74HC595 shift register. (Most pessimistic datasheet limit at 2V.)
	SPI_Mode	SPI clock mode for the SNHC74HC595 shift register.

Top

See Also

Reference

Device Class

IO.Devices.SN74HC595 Namespace

DeviceSPI_MaxFreq Field

SPI maximum clock frequency for the SNHC74HC595 shift register. (Most pessimistic datasheet limit at 2V.)

Namespace: IO.Devices.SN74HC595
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int SPI_MaxFreq = 4000000
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.SN74HC595 Namespace

DeviceSPI_Mode Field

SPI clock mode for the SNHC74HC595 shift register.

Namespace: IO.Devices.SN74HC595
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int SPI_Mode = 0
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Devices.SN74HC595 Namespace

IO.Devices.SN74HC595.GPIO Namespace

SN74HC595 8-Bit Shift Register GPIO Pin Services

Classes

	Class	Description
	Pin	Encapsulates SN74HC595 GPIO outputs.

Pin Class

Encapsulates SN74HC595 GPIO outputs.

Inheritance Hierarchy

SystemObject IO.Devices.SN74HC595.GPIOPin

Namespace: IO.Devices.SN74HC595.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Pin : Pin
```

The Pin type exposes the following members.

Constructors

	Name	Description
	Pin	Constructor for a single GPIO output pin.

Top

Properties

	Name	Description
	state	Read/Write GPIO pin state property.

Top

See Also

Reference

IO.Devices.SN74HC595.GPIO Namespace

Pin Constructor

Constructor for a single GPIO output pin.

Namespace: IO.Devices.SN74HC595.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Pin(
        Device dev,
        int pos,
        bool state = false
)
```

Parameters

dev
Type: IO.Devices.SN74HC595Device
SN74HC595 device object.

pos
Type: SystemInt32
Bit position, numbered left to right. Zero indicates the most significant bit of the first shift register stage.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

See Also

Reference

Pin Class
IO.Devices.SN74HC595.GPIO Namespace

Pin Properties

The Pin type exposes the following members.

Properties

	Name	Description
	state	Read/Write GPIO pin state property.

Top

See Also

Reference

Pin Class

IO.Devices.SN74HC595.GPIO Namespace

Pinstate Property

Read/Write GPIO pin state property.

Namespace: IO.Devices.SN74HC595.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public bool state { get; set; }
```

Property Value

Type: Boolean

Implements

Pinstate

See Also

Reference

Pin Class
IO.Devices.SN74HC595.GPIO Namespace

IO.Devices.TH02 Namespace

TH02 I^2C Temperature/Humidity Sensor Services

Classes

	Class	Description
	Device	Encapsulates the TH02 temperature and humidity sensor.

Device Class

Encapsulates the TH02 temperature and humidity sensor.

Inheritance Hierarchy

SystemObject IO.Devices.TH02Device
IO.Devices.Grove.Temperature_HumidityDevice

Namespace: IO.Devices.TH02
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Device : Sensor, Sensor
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device	Constructor for an TH02 temperature and humidity sensor object.

Top

Properties

	Name	Description

	Celsius	Read-only property returning the temperature in degrees Celsius.
	DeviceID	Read-only property returning the device ID.
	Fahrenheit	Read-only property returning the temperature in degrees Fahrenheit.
	Humidity	Read-only property returning the percentage relative humidity.
	Kelvins	Read-only property returning the temperature in Kelvins.

Top

See Also

Reference

IO.Devices.TH02 Namespace

Device Constructor

Constructor for an TH02 temperature and humidity sensor object.

Namespace: IO.Devices.TH02
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public Device(
        Bus bus
)
```

Parameters

bus
Type: IO.Interfaces.I2CBus
I^2C bus controller.

See Also

Reference

Device Class
IO.Devices.TH02 Namespace

Device Properties

The Device type exposes the following members.

Properties

	Name	Description
	Celsius	Read-only property returning the temperature in degrees Celsius.
	DeviceID	Read-only property returning the device ID.
	Fahrenheit	Read-only property returning the temperature in degrees Fahrenheit.
	Humidity	Read-only property returning the percentage relative humidity.
	Kelvins	Read-only property returning the temperature in Kelvins.

Top

See Also

Reference

Device Class
IO.Devices.TH02 Namespace

DeviceCelsius Property

Read-only property returning the temperature in degrees Celsius.

Namespace: IO.Devices.TH02
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public double Celsius { get; }
```

Property Value

Type: Double

Implements

SensorCelsius

See Also

Reference

Device Class
IO.Devices.TH02 Namespace

DeviceDeviceID Property

Read-only property returning the device ID.

Namespace: IO.Devices.TH02
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public byte DeviceID { get; }
```

Property Value

Type: Byte

See Also

Reference

Device Class
IO.Devices.TH02 Namespace

DeviceFahrenheit Property

Read-only property returning the temperature in degrees Fahrenheit.

Namespace: IO.Devices.TH02
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public double Fahrenheit { get; }
```

Property Value

Type: Double

Implements

SensorFahrenheit

See Also

Reference

Device Class
IO.Devices.TH02 Namespace

DeviceHumidity Property

Read-only property returning the percentage relative humidity.

Namespace: IO.Devices.TH02
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public double Humidity { get; }
```

Property Value

Type: Double

Implements

SensorHumidity

See Also

Reference

Device Class
IO.Devices.TH02 Namespace

DeviceKelvins Property

Read-only property returning the temperature in Kelvins.

Namespace: IO.Devices.TH02
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public double Kelvins { get; }
```

Property Value

Type: Double

Implements

SensorKelvins

See Also

Reference

Device Class
IO.Devices.TH02 Namespace

IO.Devices.Thermistor Namespace

Thermistor Modeling Services

Classes

	Class	Description
	NTC_B	Encapsulate an NTC thermistor.

NTC_B Class

Encapsulate an NTC thermistor.

Inheritance Hierarchy

SystemObject IO.Devices.ThermistorNTC_B

Namespace: IO.Devices.Thermistor
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class NTC_B
```

The NTC_B type exposes the following members.

Constructors

	Name	Description
	NTC_B	Constructor for a single NTC thermistor object instance.

Top

Methods

	Name	Description
	Kelvins	Kelvin temperature as a function of the

thermistor resistance.

Top

See Also

Reference

IO.Devices.Thermistor Namespace

NTC_B Constructor

Constructor for a single NTC thermistor object instance.

Namespace: IO.Devices.Thermistor
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public NTC_B(
        double B,
        double R0,
        double T0 = 298.15
)
```

Parameters

B
Type: SystemDouble
Thermistor B parameter.

R0
Type: SystemDouble
Thermistor resistance in ohms at the specified reference temperature.

T0 **(Optional)**
Type: SystemDouble
Thermistor reference temperature in Kelvins.

See Also

Reference

NTC_B Class
IO.Devices.Thermistor Namespace

NTC_B Methods

The NTC_B type exposes the following members.

Methods

	Name	Description
	Kelvins	Kelvin temperature as a function of the thermistor resistance.

Top

See Also

Reference

NTC_B Class

IO.Devices.Thermistor Namespace

NTC_BKelvins Method

Kelvin temperature as a function of the thermistor resistance.

Namespace: IO.Devices.Thermistor
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public double Kelvins(
        double R
)
```

Parameters

R
Type: SystemDouble
Thermistor resistance in ohms.

Return Value

Type: Double
Temperature in Kelvins.

See Also

Reference

NTC_B Class
IO.Devices.Thermistor Namespace

IO.Devices.USB.Munts Namespace

Vendor and Product Identifiers for Munts Technologies (http://tech.munts.com) USB devices

Classes

	Class	Description
	HID	USB device constants for Munts Technologies USB HID devices.
	Serial	USB device constants for Munts Technologies USB serial port devices.

HID Class

USB device constants for Munts Technologies USB HID devices.

Inheritance Hierarchy

SystemObject IO.Devices.USB.MuntsHID

Namespace: IO.Devices.USB.Munts
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static class HID
```

The HID type exposes the following members.

Fields

	Name	Description
	Product	Product ID for Munts Technologies USB hid devices.
	Vendor	Vendor ID for Munts Technologies

Top

See Also

Reference

IO.Devices.USB.Munts Namespace

HID Fields

The HID type exposes the following members.

Fields

	Name	Description
	Product	Product ID for Munts Technologies USB hid devices.
	Vendor	Vendor ID for Munts Technologies

Top

See Also

Reference

HID Class

IO.Devices.USB.Munts Namespace

HIDProduct Field

Product ID for Munts Technologies USB hid devices.

Namespace: IO.Devices.USB.Munts
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int Product = 2810
```

Field Value

Type: Int32

See Also

Reference

HID Class
IO.Devices.USB.Munts Namespace

HIDVendor Field

Vendor ID for Munts Technologies

Namespace: IO.Devices.USB.Munts
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int Vendor = 5840
```

Field Value

Type: Int32

See Also

Reference

HID Class
IO.Devices.USB.Munts Namespace

Serial Class

USB device constants for Munts Technologies USB serial port devices.

Inheritance Hierarchy

SystemObject IO.Devices.USB.MuntsSerial

Namespace: IO.Devices.USB.Munts
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static class Serial
```

The Serial type exposes the following members.

Fields

	Name	Description
	Product	Product ID for Munts Technologies USB serial port devices.
	Vendor	Vendor ID for Munts Technologies

Top

See Also

Reference

IO.Devices.USB.Munts Namespace

Serial Fields

The Serial type exposes the following members.

Fields

	Name	Description
	Product	Product ID for Munts Technologies USB serial port devices.
	Vendor	Vendor ID for Munts Technologies

Top

See Also

Reference

Serial Class

IO.Devices.USB.Munts Namespace

SerialProduct Field

Product ID for Munts Technologies USB serial port devices.

Namespace: IO.Devices.USB.Munts
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int Product = 2811
```

Field Value

Type: Int32

See Also

Reference

Serial Class
IO.Devices.USB.Munts Namespace

SerialVendor Field

Vendor ID for Munts Technologies

Namespace: IO.Devices.USB.Munts
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int Vendor = 5840
```

Field Value

Type: Int32

See Also

Reference

Serial Class
IO.Devices.USB.Munts Namespace

IO.Interfaces.ADC Namespace

Abstract Interface for ADC (Analog to Digital Converter) Inputs

Classes

	Class	Description
	Input	Encapsulates ADC voltage inputs.

Interfaces

	Interface	Description
	Sample	Abstract interface for ADC inputs returning an integer sample value.
	Voltage	Abstract interface for ADC inputs returning a floating point voltage value.

Input Class

Encapsulates ADC voltage inputs.

Inheritance Hierarchy

SystemObject IO.Interfaces.ADCInput

Namespace: IO.Interfaces.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Input : Voltage
```

The Input type exposes the following members.

Constructors

	Name	Description
	Input	Create an ADC voltage input.

Top

Properties

	Name	Description
	voltage	Read-only property returning the analog input voltage.

Top

See Also

Reference

IO.Interfaces.ADC Namespace

Input Constructor

Create an ADC voltage input.

Namespace: IO.Interfaces.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Input(
        Sample input,
        double reference,
        double gain = 1
)
```

Parameters

input
Type: IO.Interfaces.ADCSample
ADC sample object.

reference
Type: SystemDouble
ADC reference in volts.

gain **(Optional)**
Type: SystemDouble
ADC input gain in volts per volt.

See Also

Reference

Input Class

IO.Interfaces.ADC Namespace

Input Properties

The Input type exposes the following members.

Properties

	Name	Description
	voltage	Read-only property returning the analog input voltage.

Top

See Also

Reference

Input Class

IO.Interfaces.ADC Namespace

Inputvoltage Property

Read-only property returning the analog input voltage.

Namespace: IO.Interfaces.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public double voltage { get; }
```

Property Value

Type: Double

Implements

Voltagevoltage

See Also

Reference

Input Class
IO.Interfaces.ADC Namespace

Sample Interface

Abstract interface for ADC inputs returning an integer sample value.

Namespace: IO.Interfaces.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public interface Sample
```

The Sample type exposes the following members.

Properties

	Name	Description
	resolution	Read-only property returning the number of bits of resolution.
	sample	Read-only property returning an integer analog sample value.

Top

See Also

Reference

IO.Interfaces.ADC Namespace

Sample Properties

The Sample type exposes the following members.

Properties

	Name	Description
	resolution	Read-only property returning the number of bits of resolution.
	sample	Read-only property returning an integer analog sample value.

Top

See Also

Reference

Sample Interface

IO.Interfaces.ADC Namespace

Sampleresolution Property

Read-only property returning the number of bits of resolution.

Namespace: IO.Interfaces.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
int resolution { get; }
```

Property Value

Type: Int32

See Also

Reference

Sample Interface
IO.Interfaces.ADC Namespace

Samplesample Property

Read-only property returning an integer analog sample value.

Namespace: IO.Interfaces.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
int sample { get; }
```

Property Value

Type: Int32

See Also

Reference

Sample Interface
IO.Interfaces.ADC Namespace

Voltage Interface

Abstract interface for ADC inputs returning a floating point voltage value.

Namespace: IO.Interfaces.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public interface Voltage
```

The Voltage type exposes the following members.

Properties

	Name	Description
	voltage	Read-only property returning a floating point analog voltage value.

Top

See Also

Reference

IO.Interfaces.ADC Namespace

Voltage Properties

The Voltage type exposes the following members.

Properties

	Name	Description
	voltage	Read-only property returning a floating point analog voltage value.

Top

See Also

Reference

Voltage Interface
IO.Interfaces.ADC Namespace

Voltagevoltage Property

Read-only property returning a floating point analog voltage value.

Namespace: IO.Interfaces.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
double voltage { get; }
```

Property Value

Type: Double

See Also

Reference

Voltage Interface
IO.Interfaces.ADC Namespace

IO.Interfaces.DAC Namespace

Abstract Interface for DAC (Digital to Analog Converter) Outputs

Classes

	Class	Description
	Output	Encapsulates DAC voltage outputs.

Interfaces

	Interface	Description
	Sample	Abstract interface for DAC outputs accepting an integer output sample value.
	Voltage	Abstract interface for DAC outputs accepting a floating point output voltage value.

Output Class

Encapsulates DAC voltage outputs.

Inheritance Hierarchy

SystemObject IO.Interfaces.DACOutput

Namespace: IO.Interfaces.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Output : Voltage
```

The Output type exposes the following members.

Constructors

	Name	Description
	Output	Create an DAC voltage output.

Top

Properties

	Name	Description
	voltage	Write-only for setting the DAC output voltage.

Top

See Also

Reference

IO.Interfaces.DAC Namespace

Output Constructor

Create an DAC voltage output.

Namespace: IO.Interfaces.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Output(
        Sample output,
        double reference,
        double gain = 1
)
```

Parameters

output
Type: IO.Interfaces.DACSample
DAC output object.

reference
Type: SystemDouble
DAC output reference in volts.

gain **(Optional)**
Type: SystemDouble
DAC output gain in volts per volt.

See Also

Reference

Output Class

IO.Interfaces.DAC Namespace

Output Properties

The Output type exposes the following members.

Properties

	Name	Description
	voltage	Write-only for setting the DAC output voltage.

Top

See Also

Reference

Output Class

IO.Interfaces.DAC Namespace

Outputvoltage Property

Write-only for setting the DAC output voltage.

Namespace: IO.Interfaces.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public double voltage { set; }
```

Property Value

Type: Double

Implements

Voltagevoltage

See Also

Reference

Output Class
IO.Interfaces.DAC Namespace

Sample Interface

Abstract interface for DAC outputs accepting an integer output sample value.

Namespace: IO.Interfaces.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public interface Sample
```

The Sample type exposes the following members.

Properties

	Name	Description
	resolution	Read-only property returning the number of bits of resolution.
	sample	Write-only property for setting the DAC output level.

Top

See Also

Reference

IO.Interfaces.DAC Namespace

Sample Properties

The Sample type exposes the following members.

Properties

	Name	Description
	resolution	Read-only property returning the number of bits of resolution.
	sample	Write-only property for setting the DAC output level.

Top

See Also

Reference

Sample Interface

IO.Interfaces.DAC Namespace

Sampleresolution Property

Read-only property returning the number of bits of resolution.

Namespace: IO.Interfaces.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
int resolution { get; }
```

Property Value

Type: Int32

See Also

Reference

Sample Interface
IO.Interfaces.DAC Namespace

Samplesample Property

Write-only property for setting the DAC output level.

Namespace: IO.Interfaces.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
int sample { set; }
```

Property Value

Type: Int32

See Also

Reference

Sample Interface
IO.Interfaces.DAC Namespace

Voltage Interface

Abstract interface for DAC outputs accepting a floating point output voltage value.

Namespace: IO.Interfaces.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public interface Voltage
```

The Voltage type exposes the following members.

Properties

	Name	Description
	voltage	Write-only property for setting the DAC output voltage.

Top

See Also

Reference

IO.Interfaces.DAC Namespace

Voltage Properties

The Voltage type exposes the following members.

Properties

	Name	Description
	voltage	Write-only property for setting the DAC output voltage.

Top

See Also

Reference

Voltage Interface
IO.Interfaces.DAC Namespace

Voltagevoltage Property

Write-only property for setting the DAC output voltage.

Namespace: IO.Interfaces.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
double voltage { set; }
```

Property Value

Type: Double

See Also

Reference

Voltage Interface
IO.Interfaces.DAC Namespace

IO.Interfaces.GPIO Namespace

Abstract Interface for GPIO (General Purpose Input/Output) Pins

Interfaces

	Interface	Description
	Pin	Abstract interface for GPIO pins.

Enumerations

	Enumeration	Description
	Direction	GPIO pin data direction settings.

Direction Enumeration

GPIO pin data direction settings.

Namespace: IO.Interfaces.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public enum Direction
```

Members

Member name	Value	Description
Input	0	Input pin (read only)
Output	1	Output pin (read or write)

See Also

Reference

IO.Interfaces.GPIO Namespace

Pin Interface

Abstract interface for GPIO pins.

Namespace: IO.Interfaces.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public interface Pin
```

The Pin type exposes the following members.

Properties

	Name	Description
	state	Read/Write GPIO state property.

Top

See Also

Reference

IO.Interfaces.GPIO Namespace

Pin Properties

The Pin type exposes the following members.

Properties

	Name	Description
	state	Read/Write GPIO state property.

Top

See Also

Reference

Pin Interface

IO.Interfaces.GPIO Namespace

Pinstate Property

Read/Write GPIO state property.

Namespace: IO.Interfaces.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
bool state { get; set; }
```

Property Value

Type: Boolean

See Also

Reference

Pin Interface
IO.Interfaces.GPIO Namespace

IO.Interfaces.Humidity Namespace

Abstract Interface for Humidity Sensors

Interfaces

	Interface	Description
	Sensor	Abstract interface for humidity sensors.

Sensor Interface

Abstract interface for humidity sensors.

Namespace: IO.Interfaces.Humidity
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public interface Sensor
```

The Sensor type exposes the following members.

Properties

	Name	Description
	Humidity	Read-only property returning the percentage relative humidity.

Top

See Also

Reference

IO.Interfaces.Humidity Namespace

Sensor Properties

The Sensor type exposes the following members.

Properties

	Name	Description
	Humidity	Read-only property returning the percentage relative humidity.

Top

See Also

Reference

Sensor Interface

IO.Interfaces.Humidity Namespace

SensorHumidity Property

Read-only property returning the percentage relative humidity.

Namespace: IO.Interfaces.Humidity
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
double Humidity { get; }
```

Property Value

Type: Double

See Also

Reference

Sensor Interface
IO.Interfaces.Humidity Namespace

IO.Interfaces.I2C Namespace

Abstract Interface for I²C (Inter-Integrated Circuit) Bus Controllers

Classes

	Class	Description
	Device	Encapsulates a single I²C slave device.
	Speeds	I²C bus speed constants.

Interfaces

	Interface	Description
	Bus	Abstract interface for I²C bus controllers.

Bus Interface

Abstract interface for I²C bus controllers.

Namespace: IO.Interfaces.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public interface Bus
```

The Bus type exposes the following members.

Methods

	Name	Description
	Read	Read bytes from an I²C slave device.
	Transaction	Write and read bytes to and from an I²C slave device.
	Write	Write bytes to an I²C slave device.

Top

See Also

Reference

IO.Interfaces.I2C Namespace

Bus Methods

The Bus type exposes the following members.

Methods

	Name	Description
	Read	Read bytes from an I^2C slave device.
	Transaction	Write and read bytes to and from an I^2C slave device.
	Write	Write bytes to an I^2C slave device.

Top

See Also

Reference

Bus Interface

IO.Interfaces.I2C Namespace

BusRead Method

Read bytes from an I²C slave device.

Namespace: IO.Interfaces.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
void Read(
        int slaveaddr,
        byte[] resp,
        int resplen
)
```

Parameters

slaveaddr
Type: SystemInt32
I²C slave address.

resp
Type: SystemByte
Response buffer.

resplen
Type: SystemInt32
Number of bytes to read.

See Also

Reference

Bus Interface
IO.Interfaces.I2C Namespace

BusTransaction Method

Write and read bytes to and from an I²C slave device.

Namespace: IO.Interfaces.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
void Transaction(
        int slaveaddr,
        byte[] cmd,
        int cmdlen,
        byte[] resp,
        int resplen,
        int delayus = 0
)
```

Parameters

slaveaddr
Type: SystemInt32
I²C slave address.

cmd
Type: SystemByte
Command buffer.

cmdlen
Type: SystemInt32
Number of bytes to write.

resp

Type: SystemByte
Response buffer.

resplen

Type: SystemInt32
Number of bytes to read.

delayus **(Optional)**

Type: SystemInt32
Delay in microseconds between the I^2C write and read cycles.
Allowed values are 0 to 65535 microseconds.

See Also

Reference

Bus Interface
IO.Interfaces.I2C Namespace

BusWrite Method

Write bytes to an I²C slave device.

Namespace: IO.Interfaces.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
void Write(
        int slaveaddr,
        byte[] cmd,
        int cmdlen
)
```

Parameters

slaveaddr
Type: SystemInt32
I²C slave address.

cmd
Type: SystemByte
Command buffer.

cmdlen
Type: SystemInt32
Number of bytes to write.

See Also

Reference

Bus Interface
IO.Interfaces.I2C Namespace

Device Class

Encapsulates a single I²C slave device.

Inheritance Hierarchy

SystemObject IO.Interfaces.I2CDevice

Namespace: IO.Interfaces.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Device
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device	Create an I²C slave device.

Top

Methods

	Name	Description
	Read	Read bytes from an I²C slave device.

	Transaction	Write and read bytes to and from an I^2C slave device.
	Write	Write bytes to an I^2C slave device.

Top

See Also

Reference

IO.Interfaces.I2C Namespace

Device Constructor

Create an I²C slave device.

Namespace: IO.Interfaces.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Device(
        Bus bus,
        int slaveaddr
)
```

Parameters

bus
Type: IO.Interfaces.I2CBus
I²C bus controller object.

slaveaddr
Type: SystemInt32
I²C slave address.

See Also

Reference

Device Class
IO.Interfaces.I2C Namespace

Device Methods

The Device type exposes the following members.

Methods

	Name	Description
	Read	Read bytes from an I^2C slave device.
	Transaction	Write and read bytes to and from an I^2C slave device.
	Write	Write bytes to an I^2C slave device.

Top

See Also

Reference

Device Class

IO.Interfaces.I2C Namespace

DeviceRead Method

Read bytes from an I²C slave device.

Namespace: IO.Interfaces.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public void Read(
        byte[] resp,
        int resplen
)
```

Parameters

resp
Type: SystemByte
Response buffer.

resplen
Type: SystemInt32
Number of bytes to read.

See Also

Reference

Device Class
IO.Interfaces.I2C Namespace

DeviceTransaction Method

Write and read bytes to and from an I²C slave device.

Namespace: IO.Interfaces.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Transaction(
        byte[] cmd,
        int cmdlen,
        byte[] resp,
        int resplen,
        int delayus = 0
)
```

Parameters

cmd
Type: SystemByte
Command buffer.

cmdlen
Type: SystemInt32
Number of bytes to write.

resp
Type: SystemByte
Response buffer.

resplen
Type: SystemInt32
Number of bytes to read.

delayus **(Optional)**

Type: SystemInt32

Delay in microseconds between the I^2C write and read cycles. Allowed values are 0 to 65535 microseconds.

See Also

Reference

Device Class

IO.Interfaces.I2C Namespace

DeviceWrite Method

Write bytes to an I²C slave device.

Namespace: IO.Interfaces.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public void Write(
        byte[] cmd,
        int cmdlen
)
```

Parameters

cmd
Type: SystemByte
Command buffer.

cmdlen
Type: SystemInt32
Number of bytes to write.

See Also

Reference

Device Class
IO.Interfaces.I2C Namespace

Speeds Class

I^2C bus speed constants.

Inheritance Hierarchy

SystemObject IO.Interfaces.I2CSpeeds

Namespace: IO.Interfaces.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static class Speeds
```

The Speeds type exposes the following members.

Fields

	Name	Description
S	FastMode	Fast Mode
S	FastModePlus	Fast Mode Plus
S	StandardMode	Standard Mode

Top

See Also

Reference

IO.Interfaces.I2C Namespace

Speeds Fields

The Speeds type exposes the following members.

Fields

	Name	Description
	FastMode	Fast Mode
	FastModePlus	Fast Mode Plus
	StandardMode	Standard Mode

Top

See Also

Reference

Speeds Class

IO.Interfaces.I2C Namespace

SpeedsFastMode Field

Fast Mode

Namespace: IO.Interfaces.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int FastMode = 400000
```

Field Value

Type: Int32

See Also

Reference

Speeds Class
IO.Interfaces.I2C Namespace

SpeedsFastModePlus Field

Fast Mode Plus

Namespace: IO.Interfaces.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int FastModePlus = 1000000
```

Field Value

Type: Int32

See Also

Reference

Speeds Class
IO.Interfaces.I2C Namespace

SpeedsStandardMode Field

Standard Mode

Namespace: IO.Interfaces.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int StandardMode = 100000
```

Field Value

Type: Int32

See Also

Reference

Speeds Class
IO.Interfaces.I2C Namespace

IO.Interfaces.Message.Text Namespace

Abstract Interface for Text Message Relays

Interfaces

	Interface	Description
	Relay	Abstract interface for a text message relay.

Relay Interface

Abstract interface for a text message relay.

Namespace: IO.Interfaces.Message.Text
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public interface Relay
```

The Relay type exposes the following members.

Methods

	Name	Description
	Send	Method for sending a text message.

Top

See Also

Reference

IO.Interfaces.Message.Text Namespace

Relay Methods

The Relay type exposes the following members.

Methods

	Name	Description
	Send	Method for sending a text message.

Top

See Also

Reference

Relay Interface

IO.Interfaces.Message.Text Namespace

RelaySend Method

Method for sending a text message.

Namespace: IO.Interfaces.Message.Text
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
void Send(
        string sender,
        string recipient,
        string subject,
        string message
)
```

Parameters

sender
Type: SystemString
Message originator.

recipient
Type: SystemString
Message recipient.

subject
Type: SystemString
Message subject.

message
Type: SystemString
Message text.

See Also

Reference

Relay Interface

IO.Interfaces.Message.Text Namespace

IO.Interfaces.Message64 Namespace

Abstract Interface for 64-Byte Message Services

Classes

	Class	Description
	Message	Encapsulates 64-byte messages.

Interfaces

	Interface	Description
	Messenger	Abstract interface for sending and receiving 64-byte messages.

Message Class

Encapsulates 64-byte messages.

Inheritance Hierarchy

SystemObject IO.Interfaces.Message64Message

Namespace: IO.Interfaces.Message64
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Message
```

The Message type exposes the following members.

Constructors

	Name	Description
	Message	Create a message object without initializing the payload.
	Message(Byte)	Create a message object with an initialized payload.

Top

Fields

	Name	Description
	payload	Message payload.
S	Size	Message payload size.

Top

See Also

Reference

IO.Interfaces.Message64 Namespace

Message Constructor

Overload List

	Name	Description
	Message	Create a message object without initializing the payload.
	Message(Byte)	Create a message object with an initialized payload.

Top

See Also

Reference

Message Class

IO.Interfaces.Message64 Namespace

Message Constructor

Create a message object without initializing the payload.

Namespace: IO.Interfaces.Message64
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Message()
```

See Also

Reference

Message Class
Message Overload
IO.Interfaces.Message64 Namespace

Message Constructor (Byte)

Create a message object with an initialized payload.

Namespace: IO.Interfaces.Message64
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Message(
        byte fill
)
```

Parameters

fill

Type: SystemByte
Value to initialize the payload with.

See Also

Reference

Message Class
Message Overload
IO.Interfaces.Message64 Namespace

Message Fields

The Message type exposes the following members.

Fields

	Name	Description
	payload	Message payload.
S	Size	Message payload size.

Top

See Also

Reference

Message Class

IO.Interfaces.Message64 Namespace

Messagepayload Field

Message payload.

Namespace: IO.Interfaces.Message64
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public byte[] payload
```

Field Value

Type: Byte

See Also

Reference

Message Class
IO.Interfaces.Message64 Namespace

MessageSize Field

Message payload size.

Namespace: IO.Interfaces.Message64
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int Size = 64
```

Field Value

Type: Int32

See Also

Reference

Message Class
IO.Interfaces.Message64 Namespace

Messenger Interface

Abstract interface for sending and receiving 64-byte messages.

Namespace: IO.Interfaces.Message64
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public interface Messenger
```

The Messenger type exposes the following members.

Methods

	Name	Description
	Receive	Receive a 64-byte message.
	Send	Send a 64-byte message.
	Transaction	Send a 64-byte command and receive a 64-byte response.

Top

See Also

Reference

IO.Interfaces.Message64 Namespace

Messenger Methods

The Messenger type exposes the following members.

Methods

	Name	Description
	Receive	Receive a 64-byte message.
	Send	Send a 64-byte message.
	Transaction	Send a 64-byte command and receive a 64-byte response.

Top

See Also

Reference

Messenger Interface
IO.Interfaces.Message64 Namespace

MessengerReceive Method

Receive a 64-byte message.

Namespace: IO.Interfaces.Message64
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
void Receive(
        Message resp
)
```

Parameters

resp
Type: IO.Interfaces.Message64Message
Message received.

See Also

Reference

Messenger Interface
IO.Interfaces.Message64 Namespace

MessengerSend Method

Send a 64-byte message.

Namespace: IO.Interfaces.Message64
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
void Send(
        Message cmd
)
```

Parameters

cmd
Type: IO.Interfaces.Message64Message
Message to be sent.

See Also

Reference

Messenger Interface
IO.Interfaces.Message64 Namespace

MessengerTransaction Method

Send a 64-byte command and receive a 64-byte response.

Namespace: IO.Interfaces.Message64
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
void Transaction(
        Message cmd,
        Message resp
)
```

Parameters

cmd
Type: IO.Interfaces.Message64Message
Command to be sent.

resp
Type: IO.Interfaces.Message64Message
Response to be received.

See Also

Reference

Messenger Interface
IO.Interfaces.Message64 Namespace

IO.Interfaces.Motor Namespace

Abstract Interface For Variable Speed Motor Outputs

Classes

	Class	Description
	Velocities	Motor velocity contants.

Interfaces

	Interface	Description
	Output	Abstract interface for variable speed motor outputs.

Output Interface

Abstract interface for variable speed motor outputs.

Namespace: IO.Interfaces.Motor
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public interface Output
```

The Output type exposes the following members.

Properties

	Name	Description
	velocity	Write-only motor velocity property.

Top

See Also

Reference

IO.Interfaces.Motor Namespace

Output Properties

The Output type exposes the following members.

Properties

	Name	Description
	velocity	Write-only motor velocity property.

Top

See Also

Reference

Output Interface
IO.Interfaces.Motor Namespace

Outputvelocity Property

Write-only motor velocity property.

Namespace: IO.Interfaces.Motor
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
double velocity { set; }
```

Property Value

Type: Double

See Also

Reference

Output Interface
IO.Interfaces.Motor Namespace

Velocities Class

Motor velocity contants.

Inheritance Hierarchy

SystemObject IO.Interfaces.MotorVelocities

Namespace: IO.Interfaces.Motor
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static class Velocities
```

The Velocities type exposes the following members.

Fields

	Name	Description
S	Maximum	Maximum velocity (full speed forward).
S	Minimum	Minimum velocity (full speed reverse).
S	Stop	Zero velocity (motor stopped).

Top

See Also

Reference

IO.Interfaces.Motor Namespace

Velocities Fields

The Velocities type exposes the following members.

Fields

	Name	Description
	Maximum	Maximum velocity (full speed forward).
	Minimum	Minimum velocity (full speed reverse).
	Stop	Zero velocity (motor stopped).

Top

See Also

Reference

Velocities Class

IO.Interfaces.Motor Namespace

VelocitiesMaximum Field

Maximum velocity (full speed forward).

Namespace: IO.Interfaces.Motor
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const double Maximum = 1
```

Field Value

Type: Double

See Also

Reference

Velocities Class
IO.Interfaces.Motor Namespace

VelocitiesMinimum Field

Minimum velocity (full speed reverse).

Namespace: IO.Interfaces.Motor
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const double Minimum = -1
```

Field Value

Type: Double

See Also

Reference

Velocities Class
IO.Interfaces.Motor Namespace

VelocitiesStop Field

Zero velocity (motor stopped).

Namespace: IO.Interfaces.Motor
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const double Stop = 0
```

Field Value

Type: Double

See Also

Reference

Velocities Class
IO.Interfaces.Motor Namespace

IO.Interfaces.PWM Namespace

Abstract Interface for PWM (Pulse Width Modulated) Outputs

Classes

	Class	Description
	DutyCycles	PWM dutycycle contants.

Interfaces

	Interface	Description
	Output	Abstract interface for PWM outputs.

DutyCycles Class

PWM dutycycle contants.

Inheritance Hierarchy

SystemObject IO.Interfaces.PWMDutyCycles

Namespace: IO.Interfaces.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static class DutyCycles
```

The DutyCycles type exposes the following members.

Fields

	Name	Description
s	Maximum	Maximum duty cycle (percent).
s	Minimum	Minimum duty cycle (percent).

Top

See Also

Reference

IO.Interfaces.PWM Namespace

DutyCycles Fields

The DutyCycles type exposes the following members.

Fields

	Name	Description
	Maximum	Maximum duty cycle (percent).
	Minimum	Minimum duty cycle (percent).

Top

See Also

Reference

DutyCycles Class
IO.Interfaces.PWM Namespace

DutyCyclesMaximum Field

Maximum duty cycle (percent).

Namespace: IO.Interfaces.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const double Maximum = 100
```

Field Value

Type: Double

See Also

Reference

DutyCycles Class
IO.Interfaces.PWM Namespace

DutyCyclesMinimum Field

Minimum duty cycle (percent).

Namespace: IO.Interfaces.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const double Minimum = 0
```

Field Value

Type: Double

See Also

Reference

DutyCycles Class
IO.Interfaces.PWM Namespace

Output Interface

Abstract interface for PWM outputs.

Namespace: IO.Interfaces.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public interface Output
```

The Output type exposes the following members.

Properties

	Name	Description
	dutycycle	Write-only PWM duty cycle property.

Top

See Also

Reference

IO.Interfaces.PWM Namespace

Output Properties

The Output type exposes the following members.

Properties

	Name	Description
	dutycycle	Write-only PWM duty cycle property.

Top

See Also

Reference

Output Interface
IO.Interfaces.PWM Namespace

Outputdutycycle Property

Write-only PWM duty cycle property.

Namespace: IO.Interfaces.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
double dutycycle { set; }
```

Property Value

Type: Double

See Also

Reference

Output Interface
IO.Interfaces.PWM Namespace

IO.Interfaces.Servo Namespace

Abstract Interface for Servo Outputs

Classes

	Class	Description
	Positions	Servo position contants.

Interfaces

	Interface	Description
	Output	Abstract interface for servo outputs.

Output Interface

Abstract interface for servo outputs.

Namespace: IO.Interfaces.Servo
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public interface Output
```

The Output type exposes the following members.

Properties

	Name	Description
	position	Write-only servo position property.

Top

See Also

Reference

IO.Interfaces.Servo Namespace

Output Properties

The Output type exposes the following members.

Properties

	Name	Description
	position	Write-only servo position property.

Top

See Also

Reference

Output Interface
IO.Interfaces.Servo Namespace

Outputposition Property

Write-only servo position property.

Namespace: IO.Interfaces.Servo
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
double position { set; }
```

Property Value

Type: Double

See Also

Reference

Output Interface
IO.Interfaces.Servo Namespace

Positions Class

Servo position contants.

Inheritance Hierarchy

SystemObject IO.Interfaces.ServoPositions

Namespace: IO.Interfaces.Servo
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static class Positions
```

The Positions type exposes the following members.

Fields

	Name	Description
s	Maximum	Maximum displacement position.
s	Minimum	Minimum displacement position.
s	Neutral	Zero displacement (neutral) position.

Top

See Also

Reference

IO.Interfaces.Servo Namespace

Positions Fields

The Positions type exposes the following members.

Fields

	Name	Description
S	Maximum	Maximum displacement position.
S	Minimum	Minimum displacement position.
S	Neutral	Zero displacement (neutral) position.

Top

See Also

Reference

Positions Class

IO.Interfaces.Servo Namespace

PositionsMaximum Field

Maximum displacement position.

Namespace: IO.Interfaces.Servo
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const double Maximum = 1
```

Field Value

Type: Double

See Also

Reference

Positions Class
IO.Interfaces.Servo Namespace

PositionsMinimum Field

Minimum displacement position.

Namespace: IO.Interfaces.Servo
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const double Minimum = -1
```

Field Value

Type: Double

See Also

Reference

Positions Class
IO.Interfaces.Servo Namespace

PositionsNeutral Field

Zero displacement (neutral) position.

Namespace: IO.Interfaces.Servo
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const double Neutral = 0
```

Field Value

Type: Double

See Also

Reference

Positions Class
IO.Interfaces.Servo Namespace

IO.Interfaces.SPI Namespace

Abstract Interface for SPI (Serial Peripheral Interconnect) Slave Devices

Interfaces

	Interface	Description
	Device	Abstract interface for SPI slave devices.

Device Interface

Abstract interface for SPI slave devices.

Namespace: IO.Interfaces.SPI
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public interface Device
```

The Device type exposes the following members.

Methods

	Name	Description
	Read	Read bytes from an SPI slave device.
	Transaction	Write bytes to and read bytes from an SPI slave device.
	Write	Write bytes to an SPI slave device.

Top

See Also

Reference

IO.Interfaces.SPI Namespace

Device Methods

The Device type exposes the following members.

Methods

	Name	Description
	Read	Read bytes from an SPI slave device.
	Transaction	Write bytes to and read bytes from an SPI slave device.
	Write	Write bytes to an SPI slave device.

Top

See Also

Reference

Device Interface

IO.Interfaces.SPI Namespace

DeviceRead Method

Read bytes from an SPI slave device.

Namespace: IO.Interfaces.SPI
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
void Read(
        byte[] resp,
        int resplen
)
```

Parameters

resp
Type: SystemByte
Response buffer.

resplen
Type: SystemInt32
Number of bytes to read.

See Also

Reference

Device Interface
IO.Interfaces.SPI Namespace

DeviceTransaction Method

Write bytes to and read bytes from an SPI slave device.

Namespace: IO.Interfaces.SPI
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
void Transaction(
        byte[] cmd,
        int cmdlen,
        byte[] resp,
        int resplen,
        int delayus = 0
)
```

Parameters

cmd
Type: SystemByte
Command buffer.

cmdlen
Type: SystemInt32
Number of bytes to write.

resp
Type: SystemByte
Response buffer.

resplen
Type: SystemInt32
Number of bytes to read.

delayus **(Optional)**

Type: SystemInt32

Delay in microseconds between write and read operations.

See Also

Reference

Device Interface

IO.Interfaces.SPI Namespace

DeviceWrite Method

Write bytes to an SPI slave device.

Namespace: IO.Interfaces.SPI
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
void Write(
        byte[] cmd,
        int cmdlen
)
```

Parameters

cmd
Type: SystemByte
Command buffer.

cmdlen
Type: SystemInt32
Number of bytes to write.

See Also

Reference

Device Interface
IO.Interfaces.SPI Namespace

IO.Interfaces.Stepper Namespace

Abstract Interface for Stepper Motor Outputs

Interfaces

	Interface	Description
	Output	Abstract interface for stepper motor outputs.

Output Interface

Abstract interface for stepper motor outputs.

Namespace: IO.Interfaces.Stepper
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public interface Output
```

The Output type exposes the following members.

Properties

	Name	Description
	StepsPerRotation	Read-only property returning the number of steps a stepper motor has.

Top

Methods

	Name	Description
	Move	Move the stepper motor a specified number of steps at a specified rate.
	Spin	Spin (i.e. continuous rotation) the stepper

moter at a specified rate.

Top

See Also

Reference

IO.Interfaces.Stepper Namespace

Output Properties

The Output type exposes the following members.

Properties

	Name	Description
	StepsPerRotation	Read-only property returning the number of steps a stepper motor has.

Top

See Also

Reference

Output Interface
IO.Interfaces.Stepper Namespace

OutputStepsPerRotation Property

Read-only property returning the number of steps a stepper motor has.

Namespace: IO.Interfaces.Stepper
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
int StepsPerRotation { get; }
```

Property Value

Type: Int32

See Also

Reference

Output Interface
IO.Interfaces.Stepper Namespace

Output Methods

The Output type exposes the following members.

Methods

	Name	Description
	Move	Move the stepper motor a specified number of steps at a specified rate.
	Spin	Spin (i.e. continuous rotation) the stepper moter at a specified rate.

Top

See Also

Reference

Output Interface
IO.Interfaces.Stepper Namespace

OutputMove Method

Move the stepper motor a specified number of steps at a specified rate.

Namespace: IO.Interfaces.Stepper
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
void Move(
        int steps,
        float rate
)
```

Parameters

steps
Type: SystemInt32
Number of steps to move. Negative values indicate reverse motion and positive values indicate forward motion. (The directions are nominal and depend on how the stepper motor coils are wired). Zero indicates the stepper motor should be stopped.

rate
Type: SystemSingle
The rate of motion, in steps per second. Negative values indicate reverse motion and positive values indicate forward motion. (The directions are nominal and depend on how the stepper motor coils are wired). Zero indicates the stepper motor should be stopped.

See Also

Reference

Output Interface

IO.Interfaces.Stepper Namespace

OutputSpin Method

Spin (i.e. continuous rotation) the stepper moter at a specified rate.

Namespace: IO.Interfaces.Stepper
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
void Spin(
        float rate
)
```

Parameters

rate

Type: SystemSingle
The rate of motion, in steps per second. Negative values indicate reverse motion and positive values indicate forward motion. (The directions are nominal and depend on how the stepper motor coils are wired). Zero indicates the stepper motor should be stopped.

Remarks

Not all stepper motor drivers support continuous rotation.

See Also

Reference

Output Interface

IO.Interfaces.Stepper Namespace

IO.Interfaces.Temperature Namespace

Abstract Interface for Temperature Sensors

Classes

	Class	Description
	Conversions	Temperature conversion functions.

Interfaces

	Interface	Description
	Sensor	Abstract interface for temperature sensors.

Conversions Class

Temperature conversion functions.

Inheritance Hierarchy

SystemObject IO.Interfaces.TemperatureConversions

Namespace: IO.Interfaces.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Conversions
```

The Conversions type exposes the following members.

Constructors

	Name	Description
	Conversions	Initializes a new instance of the Conversions class

Top

Methods

	Name	Description
S	CelsiusToFahrenheit	Convert degrees Celsius to

		degrees Fahrenheit.
	CelsiusToKelvins	Convert degrees Celsius to Kelvins.
	FahrenheitToCelsius	Convert degrees Fahrenheit to degrees Celsius.
	FahrenheitToKelvins	Convert degrees Fahrenheit to Kelvins.
	KelvinsToCelsius	Convert Kelvins to degrees Celsius.
	KelvinsToFahrenheit	Convert Kelvins to degrees Fahrenheit.

Top

See Also

Reference

IO.Interfaces.Temperature Namespace

Conversions Constructor

Initializes a new instance of the Conversions class

Namespace: IO.Interfaces.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Conversions()
```

See Also

Reference

Conversions Class
IO.Interfaces.Temperature Namespace

Conversions Methods

The Conversions type exposes the following members.

Methods

	Name	Description
	CelsiusToFahrenheit	Convert degrees Celsius to degrees Fahrenheit.
	CelsiusToKelvins	Convert degrees Celsius to Kelvins.
	FahrenheitToCelsius	Convert degrees Fahrenheit to degrees Celsius.
	FahrenheitToKelvins	Convert degrees Fahrenheit to Kelvins.
	KelvinsToCelsius	Convert Kelvins to degrees Celsius.
	KelvinsToFahrenheit	Convert Kelvins to degrees Fahrenheit.

Top

See Also

Reference

Conversions Class

IO.Interfaces.Temperature Namespace

ConversionsCelsiusToFahrenheit Method

Convert degrees Celsius to degrees Fahrenheit.

Namespace: IO.Interfaces.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static double CelsiusToFahrenheit(
        double celsius
)
```

Parameters

celsius
Type: SystemDouble
Temperature in degrees Celsius.

Return Value

Type: Double
Temperature in degrees Fahrenheit.

See Also

Reference

Conversions Class
IO.Interfaces.Temperature Namespace

ConversionsCelsiusToKelvins Method

Convert degrees Celsius to Kelvins.

Namespace: IO.Interfaces.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static double CelsiusToKelvins(
        double celsius
)
```

Parameters

celsius
Type: SystemDouble
Temperature in degrees Celsius.

Return Value

Type: Double
Temperature in Kelvins.

See Also

Reference

Conversions Class
IO.Interfaces.Temperature Namespace

ConversionsFahrenheitToCelsius Method

Convert degrees Fahrenheit to degrees Celsius.

Namespace: IO.Interfaces.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static double FahrenheitToCelsius(
        double fahrenheit
)
```

Parameters

fahrenheit
Type: SystemDouble
Temperature in degrees Fahrenheit.

Return Value

Type: Double
Temperature in degrees Celsius.

See Also

Reference

Conversions Class
IO.Interfaces.Temperature Namespace

ConversionsFahrenheitToKelvins Method

Convert degrees Fahrenheit to Kelvins.

Namespace: IO.Interfaces.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static double FahrenheitToKelvins(
        double fahrenheit
)
```

Parameters

fahrenheit
Type: SystemDouble
Temperature in degrees Fahrenheit.

Return Value

Type: Double
Temperature in Kelvins.

See Also

Reference

Conversions Class
IO.Interfaces.Temperature Namespace

ConversionsKelvinsToCelsius Method

Convert Kelvins to degrees Celsius.

Namespace: IO.Interfaces.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public static double KelvinsToCelsius(
        double kelvins
)
```

Parameters

kelvins
Type: SystemDouble
Temperature in Kelvins.

Return Value

Type: Double
Temperature in degrees Celsius.

See Also

Reference

Conversions Class
IO.Interfaces.Temperature Namespace

ConversionsKelvinsToFahrenheit Method

Convert Kelvins to degrees Fahrenheit.

Namespace: IO.Interfaces.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static double KelvinsToFahrenheit(
        double kelvins
)
```

Parameters

kelvins
Type: SystemDouble
Temperature in Kelivns.

Return Value

Type: Double
Temperature in degrees Fahrenheit.

See Also

Reference

Conversions Class
IO.Interfaces.Temperature Namespace

Sensor Interface

Abstract interface for temperature sensors.

Namespace: IO.Interfaces.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public interface Sensor
```

The Sensor type exposes the following members.

Properties

	Name	Description
	Celsius	Read-only property returning the temperature in degrees Celsius.
	Fahrenheit	Read-only property returning the temperature in degrees Fahrenheit.
	Kelvins	Read-only property returning the temperature in Kelvins.

Top

See Also

Reference

IO.Interfaces.Temperature Namespace

Sensor Properties

The Sensor type exposes the following members.

Properties

	Name	Description
	Celsius	Read-only property returning the temperature in degrees Celsius.
	Fahrenheit	Read-only property returning the temperature in degrees Fahrenheit.
	Kelvins	Read-only property returning the temperature in Kelvins.

Top

See Also

Reference

Sensor Interface

IO.Interfaces.Temperature Namespace

SensorCelsius Property

Read-only property returning the temperature in degrees Celsius.

Namespace: IO.Interfaces.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
double Celsius { get; }
```

Property Value

Type: Double

See Also

Reference

Sensor Interface
IO.Interfaces.Temperature Namespace

SensorFahrenheit Property

Read-only property returning the temperature in degrees Fahrenheit.

Namespace: IO.Interfaces.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
double Fahrenheit { get; }
```

Property Value

Type: Double

See Also

Reference

Sensor Interface
IO.Interfaces.Temperature Namespace

SensorKelvins Property

Read-only property returning the temperature in Kelvins.

Namespace: IO.Interfaces.Temperature
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
double Kelvins { get; }
```

Property Value

Type: Double

See Also

Reference

Sensor Interface
IO.Interfaces.Temperature Namespace

IO.Interfaces.Watchdog Namespace

Abstract Interface for Watchdog Timers

Interfaces

	Interface	Description
	Timer	Abstract interface for watchdog timers.

Timer Interface

Abstract interface for watchdog timers.

Namespace: IO.Interfaces.Watchdog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public interface Timer
```

The Timer type exposes the following members.

Properties

	Name	Description
	timeout	Read/Write watchdog timer period property.

Top

Methods

	Name	Description
	Kick	Reset the watchdog timer.

Top

See Also

Reference

IO.Interfaces.Watchdog Namespace

Timer Properties

The Timer type exposes the following members.

Properties

	Name	Description
	timeout	Read/Write watchdog timer period property.

Top

See Also

Reference

Timer Interface

IO.Interfaces.Watchdog Namespace

Timertimeout Property

Read/Write watchdog timer period property.

Namespace: IO.Interfaces.Watchdog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
int timeout { get; set; }
```

Property Value

Type: Int32

See Also

Reference

Timer Interface
IO.Interfaces.Watchdog Namespace

Timer Methods

The Timer type exposes the following members.

Methods

	Name	Description
	Kick	Reset the watchdog timer.

Top

See Also

Reference

Timer Interface

IO.Interfaces.Watchdog Namespace

TimerKick Method

Reset the watchdog timer.

Namespace: IO.Interfaces.Watchdog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
void Kick()
```

See Also

Reference

Timer Interface
IO.Interfaces.Watchdog Namespace

IO.Objects.Email.Mail Namespace

Email Sending Services using `/usr/bin/mail`

Classes

	Class	Description
	Relay	This class implements the `IO.Interfaces.Messaging.Text.Relay` interface, for sending an email message via the Unix program `/usr/bin/mail`.

Relay Class

This class implements the `IO.Interfaces.Messaging.Text.Relay` interface, for sending an email message via the Unix program `/usr/bin/mail`.

Inheritance Hierarchy

SystemObject IO.Objects.Email.MailRelay

Namespace: IO.Objects.Email.Mail
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Relay : Relay
```

The Relay type exposes the following members.

Constructors

	Name	Description
	Relay	Constructor for a single mail relay.

Top

Methods

	Name	Description

	Send(String, String, String)	Method for sending an email message.
	Send(String, String, String, String)	Method for sending an email message.
	Send(String, String, String, String, String)	Method for sending an email message with an attachment.

Top

See Also

Reference

IO.Objects.Email.Mail Namespace

Relay Constructor

Constructor for a single mail relay.

Namespace: IO.Objects.Email.Mail
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Relay()
```

See Also

Reference

Relay Class
IO.Objects.Email.Mail Namespace

Relay Methods

Methods

	Name	Description
	Send(String, String, String)	Method for sending an email message.
	Send(String, String, String, String)	Method for sending an email message.
	Send(String, String, String, String, String)	Method for sending an email message with an attachment.

Top

See Also

Reference

Relay Class

IO.Objects.Email.Mail Namespace

RelaySend Method

Overload List

	Name	Description
	Send(String, String, String)	Method for sending an email message.
	Send(String, String, String, String)	Method for sending an email message.
	Send(String, String, String, String, String)	Method for sending an email message with an attachment.

Top

See Also

Reference

Relay Class

IO.Objects.Email.Mail Namespace

RelaySend Method (String, String, String)

Method for sending an email message.

Namespace: IO.Objects.Email.Mail
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Send(
        string recipient,
        string subject,
        string message
)
```

Parameters

recipient
Type: SystemString
Originator email address.

subject
Type: SystemString
Recipient email address.

message
Type: SystemString
Email message body.

See Also

Reference

Relay Class

Send Overload

IO.Objects.Email.Mail Namespace

RelaySend Method (String, String, String, String)

Method for sending an email message.

Namespace: IO.Objects.Email.Mail
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Send(
        string sender,
        string recipient,
        string subject,
        string message
)
```

Parameters

sender
Type: SystemString
Originator email address.

recipient
Type: SystemString
Recipient email address.

subject
Type: SystemString
Subject of the email message.

message

Type: SystemString
Email message body.

Implements

RelaySend(String, String, String, String)

See Also

Reference

Relay Class
Send Overload
IO.Objects.Email.Mail Namespace

RelaySend Method (String, String, String, String, String)

Method for sending an email message with an attachment.

Namespace: IO.Objects.Email.Mail
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Send(
        string sender,
        string recipient,
        string subject,
        string message,
        string attachment
)
```

Parameters

sender
Type: SystemString
Originator email address.

recipient
Type: SystemString
Recipient email address.

subject
Type: SystemString
Subject of the email message.

message

Type: SystemString
Email message body.

attachment

Type: SystemString
Attachment file name.

See Also

Reference

Relay Class
Send Overload
IO.Objects.Email.Mail Namespace

IO.Objects.Email.SMTP Namespace

Email Sending Services using SMTP to `localhost:25`

Classes

	Class	Description
	Relay	This class implements the `IO.Interfaces.Messaging.Text.Relay` interface, for sending an email message via SMTP (Simple Mail Transfer Protocol).

Relay Class

This class implements the `IO.Interfaces.Messaging.Text.Relay` interface, for sending an email message via SMTP (Simple Mail Transfer Protocol).

Inheritance Hierarchy

SystemObject IO.Objects.Email.SMTPRelay

Namespace: IO.Objects.Email.SMTP
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Relay : Relay
```

The Relay type exposes the following members.

Constructors

	Name	Description
	Relay	Constructor for a single SMTP mail relay.

Top

Methods

	Name	Description

	Send(String, String, String)	Method for sending an email message.
	Send(String, String, String, String)	Method for sending an email message.
	Send(String, String, String, String, String)	Method for sending an email message with an attachment.

Top

See Also

Reference

IO.Objects.Email.SMTP Namespace

Relay Constructor

Constructor for a single SMTP mail relay.

Namespace: IO.Objects.Email.SMTP
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Relay(
        string server = "localhost",
        int port = 25
)
```

Parameters

server **(Optional)**
Type: SystemString
SMTP server domain name or IP addaress.

port **(Optional)**
Type: SystemInt32
SMTP server TCP port number.

See Also

Reference

Relay Class
IO.Objects.Email.SMTP Namespace

Relay Methods

Methods

	Name	Description
	Send(String, String, String)	Method for sending an email message.
	Send(String, String, String, String)	Method for sending an email message.
	Send(String, String, String, String, String)	Method for sending an email message with an attachment.

Top

See Also

Reference

Relay Class

IO.Objects.Email.SMTP Namespace

RelaySend Method

Overload List

	Name	Description
	Send(String, String, String)	Method for sending an email message.
	Send(String, String, String, String)	Method for sending an email message.
	Send(String, String, String, String, String)	Method for sending an email message with an attachment.

Top

See Also

Reference

Relay Class

IO.Objects.Email.SMTP Namespace

RelaySend Method (String, String, String)

Method for sending an email message.

Namespace: IO.Objects.Email.SMTP
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Send(
        string recipient,
        string subject,
        string message
)
```

Parameters

recipient
Type: SystemString
Originator email address.

subject
Type: SystemString
Recipient email address.

message
Type: SystemString
Email message body.

See Also

Reference

Relay Class

Send Overload

IO.Objects.Email.SMTP Namespace

RelaySend Method (String, String, String, String)

Method for sending an email message.

Namespace: IO.Objects.Email.SMTP
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Send(
        string sender,
        string recipient,
        string subject,
        string message
)
```

Parameters

sender
Type: SystemString
Originator email address.

recipient
Type: SystemString
Recipient email address.

subject
Type: SystemString
Subject of the email message.

message

Type: SystemString
Email message body.

Implements

RelaySend(String, String, String, String)

See Also

Reference

Relay Class
Send Overload
IO.Objects.Email.SMTP Namespace

RelaySend Method (String, String, String, String, String)

Method for sending an email message with an attachment.

Namespace: IO.Objects.Email.SMTP
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Send(
        string sender,
        string recipient,
        string subject,
        string message,
        string attachment
)
```

Parameters

sender
Type: SystemString
Originator email address.

recipient
Type: SystemString
Recipient email address.

subject
Type: SystemString
Subject of the email message.

message

Type: SystemString
Email message body.

attachment

Type: SystemString
Attachment file name.

See Also

Reference

Relay Class
Send Overload
IO.Objects.Email.SMTP Namespace

IO.Objects.GPIO.PWM Namespace

PWM Controlled GPIO Output Services

Classes

	Class	Description
	Pin	Encapsulates GPIO output pins implemented with PWM outputs.

Pin Class

Encapsulates GPIO output pins implemented with PWM outputs.

Inheritance Hierarchy

SystemObject IO.Objects.GPIO.PWMPin

Namespace: IO.Objects.GPIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Pin : Pin
```

The Pin type exposes the following members.

Constructors

	Name	Description
	Pin	Constructor for a single GPIO pin.

Top

Properties

	Name	Description
	state	Read/Write GPIO state property.

Top

Remarks

Use cases for this class include ON/OFF things like an LED or a solenoid valve driven from a PWM output.

Remarks

Depending on the PWM hardware implementation, the OFF duty cycle may be slightly greater than 0 % and/or the ON duty cycle may be slightly less than 100 %.

See Also

Reference

IO.Objects.GPIO.PWM Namespace

Pin Constructor

Constructor for a single GPIO pin.

Namespace: IO.Objects.GPIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Pin(
        Output outp,
        bool state = false,
        double dutycycle = 100
)
```

Parameters

outp
Type: IO.Interfaces.PWMOutput
PWM output instance.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

dutycycle **(Optional)**
Type: SystemDouble
Initial PWM output duty cycle. Allowed values are 0.0 to 100.0 percent.

See Also

Reference

Pin Class
IO.Objects.GPIO.PWM Namespace

Pin Properties

The Pin type exposes the following members.

Properties

	Name	Description
	state	Read/Write GPIO state property.

Top

See Also

Reference

Pin Class
IO.Objects.GPIO.PWM Namespace

Pinstate Property

Read/Write GPIO state property.

Namespace: IO.Objects.GPIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public bool state { get; set; }
```

Property Value

Type: Boolean

Implements

Pinstate

See Also

Reference

Pin Class
IO.Objects.GPIO.PWM Namespace

IO.Objects.Message64.UDP Namespace

64-Byte Message Services over UDP

Classes

	Class	Description
	Messenger	64-Byte Message Transport Client Services using UDP (User Datagram Protocol).

Messenger Class

64-Byte Message Transport Client Services using UDP (User Datagram Protocol).

Inheritance Hierarchy

SystemObject IO.Objects.Message64.UDPMessenger

Namespace: IO.Objects.Message64.UDP
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public class Messenger : Messenger
```

The Messenger type exposes the following members.

Constructors

	Name	Description
	Messenger	Constructor for a 64-byte Messenger instance using UDP.

Top

Methods

	Name	Description

	Receive	Receive a 64-byte response message from a raw HID device.
	Send	Send a 64-byte command message to a raw HID device.
	Transaction	Send a 64-byte command message and receive a 64-byte response message.

Top

See Also

Reference

IO.Objects.Message64.UDP Namespace

Messenger Constructor

Constructor for a 64-byte Messenger instance using UDP.

Namespace: IO.Objects.Message64.UDP
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Messenger(
        string host,
        int port,
        int timeoutms = 1000
)
```

Parameters

host
Type: SystemString
UDP server domain name or IP address.

port
Type: SystemInt32
UDP server port number.

timeoutms **(Optional)**
Type: SystemInt32
Receive timeout in milliseconds. Zero indicates wait forever.

See Also

Reference

Messenger Class

IO.Objects.Message64.UDP Namespace

Messenger Methods

The Messenger type exposes the following members.

Methods

	Name	Description
	Receive	Receive a 64-byte response message from a raw HID device.
	Send	Send a 64-byte command message to a raw HID device.
	Transaction	Send a 64-byte command message and receive a 64-byte response message.

Top

See Also

Reference

Messenger Class

IO.Objects.Message64.UDP Namespace

MessengerReceive Method

Receive a 64-byte response message from a raw HID device.

Namespace: IO.Objects.Message64.UDP
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public void Receive(
        Message resp
)
```

Parameters

resp
Type: IO.Interfaces.Message64Message
64-byte response message.

Implements

MessengerReceive(Message)

See Also

Reference

Messenger Class
IO.Objects.Message64.UDP Namespace

MessengerSend Method

Send a 64-byte command message to a raw HID device.

Namespace: IO.Objects.Message64.UDP
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public void Send(
        Message cmd
)
```

Parameters

cmd
Type: IO.Interfaces.Message64Message
64-byte command message.

Implements

MessengerSend(Message)

See Also

Reference

Messenger Class
IO.Objects.Message64.UDP Namespace

MessengerTransaction Method

Send a 64-byte command message and receive a 64-byte response message.

Namespace: IO.Objects.Message64.UDP
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Transaction(
        Message cmd,
        Message resp
)
```

Parameters

cmd
Type: IO.Interfaces.Message64Message
64-byte command message.

resp
Type: IO.Interfaces.Message64Message
64-byte response message.

Implements

MessengerTransaction(Message, Message)

See Also

Reference

Messenger Class

IO.Objects.Message64.UDP Namespace

IO.Objects.Motor.PWM Namespace

PWM Controlled Motor Services

Classes

	Class	Description
	Output	Encapsulates motors controlled by PWM and GPIO outputs.

Output Class

Encapsulates motors controlled by PWM and GPIO outputs.

Inheritance Hierarchy

SystemObject IO.Objects.Motor.PWMOutput

Namespace: IO.Objects.Motor.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Output : Output
```

The Output type exposes the following members.

Constructors

	Name	Description
	Output(Output, Output, Double)	Constructor for a single motor, using two PWM outputs for clockwise and counterclockwise rotation control.
	Output(Pin, Output, Double)	Constructor for a single motor, using one GPIO pin for direction control, and one PWM output for speed control.

Top

Properties

	Name	Description
	velocity	Write-only property for setting the normalized motor velocity. Allowed values are -1.0 (full speed reverse) to +1.0 (full speed forward).

Top

See Also

Reference

IO.Objects.Motor.PWM Namespace

Output Constructor

Overload List

	Name	Description
	Output(Output, Output, Double)	Constructor for a single motor, using two PWM outputs for clockwise and counterclockwise rotation control.
	Output(Pin, Output, Double)	Constructor for a single motor, using one GPIO pin for direction control, and one PWM output for speed control.

Top

See Also

Reference

Output Class

IO.Objects.Motor.PWM Namespace

Output Constructor (Output, Output, Double)

Constructor for a single motor, using two PWM outputs for clockwise and counterclockwise rotation control.

Namespace: IO.Objects.Motor.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Output(
        Output clockwise,
        Output counterclockwise,
        double velocity = 0
)
```

Parameters

clockwise
Type: IO.Interfaces.PWMOutput
PWM output instance (for clockwise rotation control).

counterclockwise
Type: IO.Interfaces.PWMOutput
PWM output instance (for counterclockwise rotation control).

velocity **(Optional)**
Type: SystemDouble
Initial motor velocity.

See Also

Reference

Output Class
Output Overload
IO.Objects.Motor.PWM Namespace

Output Constructor (Pin, Output, Double)

Constructor for a single motor, using one GPIO pin for direction control, and one PWM output for speed control.

Namespace: IO.Objects.Motor.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Output(
        Pin direction,
        Output speed,
        double velocity = 0
)
```

Parameters

direction
Type: IO.Interfaces.GPIOPin
GPIO pin instance (for direction control).

speed
Type: IO.Interfaces.PWMOutput
PWM output instance (for speed control).

velocity **(Optional)**
Type: SystemDouble
Initial motor velocity.

See Also

Reference

Output Class
Output Overload
IO.Objects.Motor.PWM Namespace

Output Properties

The Output type exposes the following members.

Properties

	Name	Description
	velocity	Write-only property for setting the normalized motor velocity. Allowed values are -1.0 (full speed reverse) to +1.0 (full speed forward).

Top

See Also

Reference

Output Class

IO.Objects.Motor.PWM Namespace

Outputvelocity Property

Write-only property for setting the normalized motor velocity. Allowed values are -1.0 (full speed reverse) to +1.0 (full speed forward).

Namespace: IO.Objects.Motor.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public double velocity { set; }
```

Property Value

Type: Double

Implements

Outputvelocity

See Also

Reference

Output Class
IO.Objects.Motor.PWM Namespace

IO.Objects.Motor.Servo Namespace

Servo Controlled Motor (e.g. continuous rotation servo) Services

Classes

	Class	Description
	Output	Encapsulates motors controlled by servo outputs (e.g. continuous rotation servos).

Output Class

Encapsulates motors controlled by servo outputs (e.g. continuous rotation servos).

Inheritance Hierarchy

SystemObject IO.Objects.Motor.ServoOutput

Namespace: IO.Objects.Motor.Servo
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Output : Output
```

The Output type exposes the following members.

Constructors

	Name	Description
	Output	Constructor for a single motor output.

Top

Properties

	Name	Description
	velocity	Write-only property for setting the

	normalized motor velocity. Allowed values are -1.0 (full speed reverse) to +1.0 (full speed forward.

Top

See Also

Reference

IO.Objects.Motor.Servo Namespace

Output Constructor

Constructor for a single motor output.

Namespace: IO.Objects.Motor.Servo
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Output(
        Output servo,
        double velocity = 0
)
```

Parameters

servo
Type: IO.Interfaces.ServoOutput
Servo output instance.

velocity **(Optional)**
Type: SystemDouble
Initial motor velocity.

See Also

Reference

Output Class
IO.Objects.Motor.Servo Namespace

Output Properties

The Output type exposes the following members.

Properties

	Name	Description
	velocity	Write-only property for setting the normalized motor velocity. Allowed values are -1.0 (full speed reverse) to +1.0 (full speed forward.

Top

See Also

Reference

Output Class

IO.Objects.Motor.Servo Namespace

Outputvelocity Property

Write-only property for setting the normalized motor velocity. Allowed values are -1.0 (full speed reverse) to +1.0 (full speed forward.

Namespace: IO.Objects.Motor.Servo
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public double velocity { set; }
```

Property Value

Type: Double

Implements

Outputvelocity

See Also

Reference

Output Class
IO.Objects.Motor.Servo Namespace

IO.Objects.RemoteIO Namespace

Remote I/O Device Framework, for sending commands and receiving response to/from Remote I/O Protocol devices.

Classes

	Class	Description
	ADC	Encapsulates remote A/D inputs.
	DAC	Encapsulates remote D/A outputs.
	Device	Encasulates a remote I/O device.
	GPIO	Encapsulates remote GPIO pins.
	I2C	Encapsulates remote I^2C buses.
	PWM	Encapsulates remote PWM outputs.
	SPI	Encapsulates remote SPI slave devices.

Enumerations

	Enumeration	Description
	MessageTypes	Remote I/O protocol message types
	PeripheralTypes	Types of remote peripherals

ADC Class

Encapsulates remote A/D inputs.

Inheritance Hierarchy

SystemObject IO.Objects.RemoteIOADC

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class ADC : Sample
```

The ADC type exposes the following members.

Constructors

	Name	Description
	ADC	Create a remote A/D input.

Top

Properties

	Name	Description
	resolution	Read-only property returning the number of bits of resolution.

	sample	Read-only property returning an integer analog input sample.

Top

See Also

Reference

IO.Objects.RemoteIO Namespace

ADC Constructor

Create a remote A/D input.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public ADC(
        Device dev,
        int num
)
```

Parameters

dev
Type: IO.Objects.RemoteIODevice
Remote I/O device object.

num
Type: SystemInt32
A/D input number: 0 to 127.

Remarks

Use `Device.ADC_Create()` instead of this constructor.

See Also

Reference

ADC Class

IO.Objects.RemoteIO Namespace

ADC Properties

The ADC type exposes the following members.

Properties

	Name	Description
	resolution	Read-only property returning the number of bits of resolution.
	sample	Read-only property returning an integer analog input sample.

Top

See Also

Reference

ADC Class

IO.Objects.RemoteIO Namespace

ADCresolution Property

Read-only property returning the number of bits of resolution.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int resolution { get; }
```

Property Value

Type: Int32

Implements

Sampleresolution

See Also

Reference

ADC Class
IO.Objects.RemoteIO Namespace

ADCsample Property

Read-only property returning an integer analog input sample.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int sample { get; }
```

Property Value

Type: Int32

Implements

Samplesample

See Also

Reference

ADC Class
IO.Objects.RemoteIO Namespace

DAC Class

Encapsulates remote D/A outputs.

Inheritance Hierarchy

SystemObject IO.Objects.RemoteIODAC

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class DAC : Sample
```

The DAC type exposes the following members.

Constructors

	Name	Description
	DAC	Create a remote D/A output.

Top

Properties

	Name	Description
	resolution	Read-only property returning the number of bits of resolution.

	sample	Write-only property for writing an integer analog sample to a DAC output.

Top

See Also

Reference

IO.Objects.RemoteIO Namespace

DAC Constructor

Create a remote D/A output.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public DAC(
        Device dev,
        int num,
        int sample = 0
)
```

Parameters

dev
Type: IO.Objects.RemoteIODevice
Remote I/O device object.

num
Type: SystemInt32
D/A output number: 0 to 127.

sample **(Optional)**
Type: SystemInt32
Initial DAC output sample.

Remarks

Use `Device.DAC_Create()` instead of this constructor.

See Also

Reference

DAC Class

IO.Objects.RemoteIO Namespace

DAC Properties

The DAC type exposes the following members.

Properties

	Name	Description
	resolution	Read-only property returning the number of bits of resolution.
	sample	Write-only property for writing an integer analog sample to a DAC output.

Top

See Also

Reference

DAC Class

IO.Objects.RemoteIO Namespace

DACresolution Property

Read-only property returning the number of bits of resolution.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int resolution { get; }
```

Property Value

Type: Int32

Implements

Sampleresolution

See Also

Reference

DAC Class
IO.Objects.RemoteIO Namespace

DACsample Property

Write-only property for writing an integer analog sample to a DAC output.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int sample { set; }
```

Property Value

Type: Int32

Implements

Samplesample

See Also

Reference

DAC Class
IO.Objects.RemoteIO Namespace

Device Class

Encasulates a remote I/O device.
Encasulates a remote I/O device.

Inheritance Hierarchy

SystemObject IO.Objects.RemoteIODevice

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public class Device
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device(Messenger)	Create a Remote I/O device object.
	Device(Int32, Int32, String, Int32)	Create a Remote I/O Device object instance for the specified USB Raw HID Remote I/O Server.

Top

Properties

	Name	Description
	Capabilities	Capability string from the Remote I/O device.
	Version	Version string from the Remote I/O device.

Top

Methods

	Name	Description
	ADC_Available	Query available A/D inputs.
	ADC_Create	Create a remote A/D input.
	DAC_Available	Query available D/A outputs.
	DAC_Create	Create a remote D/A output.
	Dispatcher	Command dispatcher.
	GPIO_Available	Query available GPIO pins.
	GPIO_Create	Create a remote GPIO pin object.
	I2C_Available	Query available I^2C buses.
	I2C_Create	Create a remote I^2C bus controller.
	PWM_Available	Query available PWM outputs.

	PWM_Create	Create a remote PWM output.
	SPI_Available	Query available SPI slave devices.
	SPI_Create	Create a remote SPI slave device.

Top

Fields

	Name	Description
S	MAX_CHANNELS	Maximum number of channels each subsystem can support.
S	Unavailable	Designator for an unavailable channel.

Top

See Also

Reference

IO.Objects.RemoteIO Namespace

Device Constructor

Overload List

	Name	Description
	Device(Messenger)	Create a Remote I/O device object.
	Device(Int32, Int32, String, Int32)	Create a Remote I/O Device object instance for the specified USB Raw HID Remote I/O Server.

Top

See Also

Reference

Device Class

IO.Objects.RemoteIO Namespace

Device Constructor (Messenger)

Create a Remote I/O device object.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public Device(
        Messenger m
)
```

Parameters

m
Type: IO.Interfaces.Message64Messenger
Message transport object

See Also

Reference

Device Class
Device Overload
IO.Objects.RemoteIO Namespace

Device Constructor (Int32, Int32, String, Int32)

Create a Remote I/O Device object instance for the specified USB Raw HID Remote I/O Server.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Device(
        int VID = 5840,
        int PID = 2810,
        string serialnumber = null,
        int timeoutms = 1000
)
```

Parameters

VID **(Optional)**
Type: SystemInt32
Vendor ID

PID **(Optional)**
Type: SystemInt32
Product

serialnumber **(Optional)**
Type: SystemString
Serial number

timeoutms **(Optional)**

Type: SystemInt32
Time in milliseconds to wait for read and write operations to complete. Zero means wait forever.

See Also

Reference

Device Class
Device Overload
IO.Objects.RemoteIO Namespace

Device Properties

The Device type exposes the following members.

Properties

	Name	Description
	Capabilities	Capability string from the Remote I/O device.
	Version	Version string from the Remote I/O device.

Top

See Also

Reference

Device Class

IO.Objects.RemoteIO Namespace

DeviceCapabilities Property

Capability string from the Remote I/O device.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public string Capabilities { get; }
```

Property Value

Type: String

See Also

Reference

Device Class
IO.Objects.RemoteIO Namespace

DeviceVersion Property

Version string from the Remote I/O device.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public string Version { get; }
```

Property Value

Type: String

See Also

Reference

Device Class
IO.Objects.RemoteIO Namespace

Device Methods

The Device type exposes the following members.

Methods

	Name	Description
	ADC_Available	Query available A/D inputs.
	ADC_Create	Create a remote A/D input.
	DAC_Available	Query available D/A outputs.
	DAC_Create	Create a remote D/A output.
	Dispatcher	Command dispatcher.
	GPIO_Available	Query available GPIO pins.
	GPIO_Create	Create a remote GPIO pin object.
	I2C_Available	Query available I^2C buses.
	I2C_Create	Create a remote I^2C bus controller.
	PWM_Available	Query available PWM outputs.
	PWM_Create	Create a remote PWM output.
	SPI_Available	Query available SPI slave devices.

SPI_Create	Create a remote SPI slave device.

Top

See Also

Reference

Device Class
IO.Objects.RemoteIO Namespace

DeviceADC_Available Method

Query available A/D inputs.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public List<int> ADC_Available()
```

Return Value

Type: ListInt32
List of available A/D input numbers.

See Also

Reference

Device Class
IO.Objects.RemoteIO Namespace

DeviceADC_Create Method

Create a remote A/D input.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Sample ADC_Create(
        int num
)
```

Parameters

num
Type: SystemInt32
A/D input number: 0 to 127.

Return Value

Type: Sample
A/D input object.

See Also

Reference

Device Class
IO.Objects.RemoteIO Namespace

DeviceDAC_Available Method

Query available D/A outputs.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public List<int> DAC_Available()
```

Return Value

Type: ListInt32
List of available D/A output numbers.

See Also

Reference

Device Class
IO.Objects.RemoteIO Namespace

DeviceDAC_Create Method

Create a remote D/A output.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Sample DAC_Create(
        int num,
        int sample = 0
)
```

Parameters

num
Type: SystemInt32
D/A output number: 0 to 127.

sample **(Optional)**
Type: SystemInt32
Initial DAC output sample.

Return Value

Type: Sample
D/A output object.

See Also

Reference

Device Class

IO.Objects.RemoteIO Namespace

DeviceDispatcher Method

Command dispatcher.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Dispatcher(
        Message cmd,
        Message resp
)
```

Parameters

cmd
Type: IO.Interfaces.Message64Message
Command to be sent.

resp
Type: IO.Interfaces.Message64Message
Response to be received.

See Also

Reference

Device Class
IO.Objects.RemoteIO Namespace

DeviceGPIO_Available Method

Query available GPIO pins.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public List<int> GPIO_Available()
```

Return Value

Type: ListInt32
List of available GPIO pin numbers.

See Also

Reference

Device Class
IO.Objects.RemoteIO Namespace

DeviceGPIO_Create Method

Create a remote GPIO pin object.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Pin GPIO_Create(
        int num,
        Direction dir,
        bool state = false
)
```

Parameters

num
Type: SystemInt32
GPIO pin number: 0 to 127.

dir
Type: IO.Interfaces.GPIODirection
GPIO pin data direction: Input or Output.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

Return Value

Type: Pin
GPIO pin object.

See Also

Reference

Device Class

IO.Objects.RemoteIO Namespace

DeviceI2C_Available Method

Query available I²C buses.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public List<int> I2C_Available()
```

Return Value

Type: ListInt32
List of available I²C bus numbers.

See Also

Reference

Device Class
IO.Objects.RemoteIO Namespace

DeviceI2C_Create Method

Create a remote I²C bus controller.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Bus I2C_Create(
        int num,
        int speed = 100000
)
```

Parameters

num
Type: SystemInt32
I²C bus number: 0 to 127.

speed **(Optional)**
Type: SystemInt32
I²C bus clock frequency in Hz

Return Value

Type: Bus
I²C bus controller object.

See Also

Reference

Device Class

IO.Objects.RemoteIO Namespace

DevicePWM_Available Method

Query available PWM outputs.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public List<int> PWM_Available()
```

Return Value

Type: ListInt32
List of available PWM output numbers.

See Also

Reference

Device Class
IO.Objects.RemoteIO Namespace

DevicePWM_Create Method

Create a remote PWM output.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Output PWM_Create(
        int num,
        int freq,
        double duty = 0
)
```

Parameters

num
Type: SystemInt32
PWM output number: 0 to 127.

freq
Type: SystemInt32
PWM pulse frequency in Hz.

duty **(Optional)**
Type: SystemDouble
Initial PWM output duty cycle.

Return Value

Type: Output
PWM output object.

See Also

Reference

Device Class

IO.Objects.RemoteIO Namespace

DeviceSPI_Available Method

Query available SPI slave devices.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public List<int> SPI_Available()
```

Return Value

Type: ListInt32
List of available SPI slave device numbers.

See Also

Reference

Device Class
IO.Objects.RemoteIO Namespace

DeviceSPI_Create Method

Create a remote SPI slave device.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Device SPI_Create(
        int num,
        int mode,
        int wordsize,
        int speed
)
```

Parameters

num
Type: SystemInt32
SPI slave device number: 0 to 127.

mode
Type: SystemInt32
SPI transfer mode: 0 to 3.

wordsize
Type: SystemInt32
SPI transfer word size: 8, 16, or 32.

speed
Type: SystemInt32
SPI transfer speed in bits per second.

Return Value

Type: Device

SPI slave device object.

Remarks

The actual SPI transfer rate will be the highest realizable rate that does not exceed the value specified in `speed`.

See Also

Reference

Device Class

IO.Objects.RemoteIO Namespace

Device Fields

The Device type exposes the following members.

Fields

	Name	Description
	MAX_CHANNELS	Maximum number of channels each subsystem can support.
	Unavailable	Designator for an unavailable channel.

Top

See Also

Reference

Device Class

IO.Objects.RemoteIO Namespace

DeviceMAX_CHANNELS Field

Maximum number of channels each subsystem can support.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int MAX_CHANNELS = 128
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Objects.RemoteIO Namespace

DeviceUnavailable Field

Designator for an unavailable channel.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int Unavailable = -1
```

Field Value

Type: Int32

See Also

Reference

Device Class
IO.Objects.RemoteIO Namespace

GPIO Class

Encapsulates remote GPIO pins.

Inheritance Hierarchy

SystemObject IO.Objects.RemoteIOGPIO

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class GPIO : Pin
```

The GPIO type exposes the following members.

Constructors

	Name	Description
	GPIO	Create a remote GPIO pin.

Top

Properties

	Name	Description
	state	Read/Write GPIO state property.

Top

See Also

Reference

IO.Objects.RemoteIO Namespace

GPIO Constructor

Create a remote GPIO pin.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public GPIO(
        Device dev,
        int num,
        Direction dir,
        bool state = false
)
```

Parameters

dev
Type: IO.Objects.RemoteIODevice
Remote I/O device object.

num
Type: SystemInt32
GPIO pin number: 0 to 127.

dir
Type: IO.Interfaces.GPIODirection
GPIO pin data direction: Input or Output.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

Remarks

Use `Device.GPIO_Create()` instead of this constructor.

See Also

Reference

GPIO Class
IO.Objects.RemoteIO Namespace

GPIO Properties

The GPIO type exposes the following members.

Properties

	Name	Description
	state	Read/Write GPIO state property.

Top

See Also

Reference

GPIO Class

IO.Objects.RemoteIO Namespace

GPIOstate Property

Read/Write GPIO state property.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public bool state { get; set; }
```

Property Value

Type: Boolean

Implements

Pinstate

See Also

Reference

GPIO Class
IO.Objects.RemoteIO Namespace

I2C Class

Encapsulates remote I²C buses.

Inheritance Hierarchy

SystemObject IO.Objects.RemoteIOI2C

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class I2C : Bus
```

The I2C type exposes the following members.

Constructors

	Name	Description
	I2C	Create a remote I²C bus controller.

Top

Methods

	Name	Description
	Read	Read bytes from an I²C slave device.

	Transaction	Write and read bytes to and from an I^2C slave device.
	Write	Write bytes to an I^2C slave device.

Top

See Also

Reference

IO.Objects.RemoteIO Namespace

I2C Constructor

Create a remote I²C bus controller.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public I2C(
        Device dev,
        int num,
        int speed = 100000
)
```

Parameters

dev
Type: IO.Objects.RemoteIODevice
Remote I/O device object.

num
Type: SystemInt32
I²C bus number: 0 to 127.

speed **(Optional)**
Type: SystemInt32
I²C bus clock frequency in Hz

Remarks

Use `Device.I2C_Create()` instead of this constructor.

See Also

Reference

I2C Class

IO.Objects.RemoteIO Namespace

I2C Methods

The I2C type exposes the following members.

Methods

	Name	Description
	Read	Read bytes from an I^2C slave device.
	Transaction	Write and read bytes to and from an I^2C slave device.
	Write	Write bytes to an I^2C slave device.

Top

See Also

Reference

I2C Class

IO.Objects.RemoteIO Namespace

I2CRead Method

Read bytes from an I²C slave device.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Read(
        int slaveaddr,
        byte[] resp,
        int resplen
)
```

Parameters

slaveaddr
Type: SystemInt32
I²C slave address.

resp
Type: SystemByte
Response buffer.

resplen
Type: SystemInt32
Number of bytes to read.

Implements

BusRead(Int32, Byte, Int32)

See Also

Reference

I2C Class

IO.Objects.RemoteIO Namespace

I2CTransaction Method

Write and read bytes to and from an I²C slave device.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Transaction(
        int slaveaddr,
        byte[] cmd,
        int cmdlen,
        byte[] resp,
        int resplen,
        int delayus
)
```

Parameters

slaveaddr
Type: SystemInt32
I²C slave address.

cmd
Type: SystemByte
Command buffer.

cmdlen
Type: SystemInt32
Number of bytes to write.

resp

Type: SystemByte
Response buffer.

resplen

Type: SystemInt32
Number of bytes to read.

delayus

Type: SystemInt32
Delay in microseconds between the I^2C write and read cycles.
Allowed values are 0 to 65535 microseconds.

Implements

BusTransaction(Int32, Byte, Int32, Byte, Int32, Int32)

See Also

Reference

I2C Class
IO.Objects.RemoteIO Namespace

I2CWrite Method

Write bytes to an I²C slave device.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Write(
        int slaveaddr,
        byte[] cmd,
        int cmdlen
)
```

Parameters

slaveaddr
Type: SystemInt32
I²C slave address.

cmd
Type: SystemByte
Command buffer.

cmdlen
Type: SystemInt32
Number of bytes to write.

Implements

BusWrite(Int32, Byte, Int32)

See Also

Reference

I2C Class

IO.Objects.RemoteIO Namespace

MessageTypes Enumeration

Remote I/O protocol message types

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public enum MessageTypes
```

Members

Member name	Value	Description
LOOPBACK_REQUEST	0	Loopback request
LOOPBACK_RESPONSE	1	Loopback response
VERSION_REQUEST	2	Version string request
VERSION_RESPONSE	3	Version string response
CAPABILITY_REQUEST	4	Capability

			string request
	CAPABILITY_RESPONSE	5	Capability string response
	GPIO_PRESENT_REQUEST	6	GPIO pins available request
	GPIO_PRESENT_RESPONSE	7	GPIO pins available response
	GPIO_CONFIGURE_REQUEST	8	GPIO pins configure request
	GPIO_CONFIGURE_RESPONSE	9	GPIO pins configure response
	GPIO_READ_REQUEST	10	GPIO pins read request
	GPIO_READ_RESPONSE	11	GPIO pins read response
	GPIO_WRITE_REQUEST	12	GPIO pins write request

	GPIO_WRITE_RESPONSE	13	GPIO pins write response
	I2C_PRESENT_REQUEST	14	I^2C buses available request
	I2C_PRESENT_RESPONSE	15	I^2C buses available response
	I2C_CONFIGURE_REQUEST	16	I^2C bus configure request
	I2C_CONFIGURE_RESPONSE	17	I^2C bus configure response
	I2C_TRANSACTION_REQUEST	18	I^2C bus transaction request
	I2C_TRANSACTION_RESPONSE	19	I^2C bus transaction response
	SPI_PRESENT_REQUEST	20	SPI slave devices available request
	SPI_PRESENT_RESPONSE	21	SPI slave devices

			available response
	SPI_CONFIGURE_REQUEST	22	SPI slave device configure request
	SPI_CONFIGURE_RESPONSE	23	SPI slave device configure response
	SPI_TRANSACTION_REQUEST	24	SPI bus transaction request
	SPI_TRANSACTION_RESPONSE	25	SPI bus transaction response
	ADC_PRESENT_REQUEST	26	ADC inputs available request
	ADC_PRESENT_RESPONSE	27	ADC inputs available response
	ADC_CONFIGURE_REQUEST	28	ADC input configure request
	ADC_CONFIGURE_RESPONSE	29	ADC input configure

			response
	ADC_READ_REQUEST	30	ADC input read request
	ADC_READ_RESPONSE	31	ADC input read response
	DAC_PRESENT_REQUEST	32	DAC outputs available request
	DAC_PRESENT_RESPONSE	33	DAC outputs available response
	DAC_CONFIGURE_REQUEST	34	DAC input configure request
	DAC_CONFIGURE_RESPONSE	35	DAC input configure response
	DAC_WRITE_REQUEST	36	DAC output write request
	DAC_WRITE_RESPONSE	37	DAC output write response

	PWM_PRESENT_REQUEST	38	PWM outputs available request
	PWM_PRESENT_RESPONSE	39	PWM outputs available response
	PWM_CONFIGURE_REQUEST	40	PWM input configure request
	PWM_CONFIGURE_RESPONSE	41	PWM input configure response
	PWM_WRITE_REQUEST	42	PWM output write request
	PWM_WRITE_RESPONSE	43	PWM output write response

See Also

Reference

IO.Objects.RemoteIO Namespace

PeripheralTypes Enumeration

Types of remote peripherals

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public enum PeripheralTypes
```

Members

Member name	Value	Description
ADC	0	A/D inputs
DAC	1	D/A outputs
GPIO	2	GPIO pins
I2C	3	I^2C bus controllers
PWM	4	SPI slave devices
SPI	5	PWM outputs

See Also

Reference

IO.Objects.RemoteIO Namespace

PWM Class

Encapsulates remote PWM outputs.

Inheritance Hierarchy

SystemObject IO.Objects.RemoteIOPWM

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class PWM : Output
```

The PWM type exposes the following members.

Constructors

	Name	Description
	PWM	Create a remote PWM output.

Top

Properties

	Name	Description
	dutycycle	Write-only property for setting the PWM output duty cycle.

Top

See Also

Reference

IO.Objects.RemoteIO Namespace

PWM Constructor

Create a remote PWM output.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public PWM(
        Device dev,
        int num,
        int freq,
        double duty = 0
)
```

Parameters

dev
Type: IO.Objects.RemoteIODevice
Remote I/O device object.

num
Type: SystemInt32
PWM output number: 0 to 127.

freq
Type: SystemInt32
PWM pulse frequency in Hz.

duty **(Optional)**
Type: SystemDouble
Initial PWM output duty cycle.

Remarks

Use `Device.PWM_Create()` instead of this constructor.

See Also

Reference

PWM Class
IO.Objects.RemoteIO Namespace

PWM Properties

The PWM type exposes the following members.

Properties

	Name	Description
	dutycycle	Write-only property for setting the PWM output duty cycle.

Top

See Also

Reference

PWM Class

IO.Objects.RemoteIO Namespace

PWMdutycycle Property

Write-only property for setting the PWM output duty cycle.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public double dutycycle { set; }
```

Property Value

Type: Double

Implements

Outputdutycycle

See Also

Reference

PWM Class
IO.Objects.RemoteIO Namespace

SPI Class

Encapsulates remote SPI slave devices.

Inheritance Hierarchy

SystemObject IO.Objects.RemoteIOSPI

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class SPI : Device
```

The SPI type exposes the following members.

Constructors

	Name	Description
	SPI	Create a remote SPI slave device.

Top

Methods

	Name	Description
	Read	Read bytes from an SPI slave device.

	Transaction	Write and read bytes to and from an SPI slave device.
	Write	Write bytes to an SPI slave device.

Top

See Also

Reference

IO.Objects.RemoteIO Namespace

SPI Constructor

Create a remote SPI slave device.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public SPI(
        Device dev,
        int num,
        int mode,
        int wordsize,
        int speed
)
```

Parameters

dev
Type: IO.Objects.RemoteIODevice
Remote I/O device object.

num
Type: SystemInt32
SPI slave device number: 0 to 127.

mode
Type: SystemInt32
SPI transfer mode: 0 to 3.

wordsize
Type: SystemInt32
SPI transfer word size: 8, 16, or 32.

speed

Type: SystemInt32

SPI transfer speed in bits per second.

Remarks

Use `Device.SPI_Create()` instead of this constructor.

The actual SPI transfer rate will be the highest realizable rate that does not exceed the value specified in `speed`.

See Also

Reference

SPI Class

IO.Objects.RemoteIO Namespace

SPI Methods

The SPI type exposes the following members.

Methods

	Name	Description
	Read	Read bytes from an SPI slave device.
	Transaction	Write and read bytes to and from an SPI slave device.
	Write	Write bytes to an SPI slave device.

Top

See Also

Reference

SPI Class

IO.Objects.RemoteIO Namespace

SPIRead Method

Read bytes from an SPI slave device.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public void Read(
        byte[] resp,
        int resplen
)
```

Parameters

resp
Type: SystemByte
Response buffer.

resplen
Type: SystemInt32
Number of bytes to read: 1 to 60.

Implements

DeviceRead(Byte, Int32)

See Also

Reference

SPI Class
IO.Objects.RemoteIO Namespace

SPITransaction Method

Write and read bytes to and from an SPI slave device.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Transaction(
        byte[] cmd,
        int cmdlen,
        byte[] resp,
        int resplen,
        int delayus = 0
)
```

Parameters

cmd
Type: SystemByte
Command buffer.

cmdlen
Type: SystemInt32
Number of bytes to write: 0 to 57.

resp
Type: SystemByte
Response buffer.

resplen
Type: SystemInt32
Number of bytes to read: 0 to 60.

delayus **(Optional)**

Type: SystemInt32

Delay in microseconds between write and read operations: 0 to 65535.

Implements

DeviceTransaction(Byte, Int32, Byte, Int32, Int32)

See Also

Reference

SPI Class

IO.Objects.RemoteIO Namespace

SPIWrite Method

Write bytes to an SPI slave device.

Namespace: IO.Objects.RemoteIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Write(
        byte[] cmd,
        int cmdLen
)
```

Parameters

cmd
Type: SystemByte
Command buffer.

cmdlen
Type: SystemInt32
Number of bytes to write: 1 to 57.

Implements

DeviceWrite(Byte, Int32)

See Also

Reference

SPI Class
IO.Objects.RemoteIO Namespace

IO.Objects.RemoteIO.mikroBUS Namespace

Mikroelektronika mikroBUS (https://www.mikroe.com/mikrobus) Remote I/O protocol Server and Socket Services

Classes

	Class	Description
	Shield	Encapsulates mikroBUS shields on Remote I/O Protocol servers providing mikroBUS sockets).
	Socket	Encapsulates mikroBUS sockets.

Enumerations

	Enumeration	Description
	ShieldKinds	Supported mikroBUS shields.

Shield Class

Encapsulates mikroBUS shields on Remote I/O Protocol servers providing mikroBUS sockets).

Inheritance Hierarchy

SystemObject IO.Objects.RemoteIO.mikroBUSShield

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static class Shield
```

The Shield type exposes the following members.

Properties

	Name	Description
	kind	Returns the kind of mikroBUS shield that is installed on the Remote I/O Protocol server, as obtained from the `SHIELDNAME` environment variable.

Top

Fields

	Name	Description
	I2CBus	Shared I^2C bus that is common to all sockets on this shield.

Top

See Also

Reference

IO.Objects.RemoteIO.mikroBUS Namespace

Shield Properties

The Shield type exposes the following members.

Properties

	Name	Description
	kind	Returns the kind of mikroBUS shield that is installed on the Remote I/O Protocol server, as obtained from the `SHIELDNAME` environment variable.

Top

See Also

Reference

Shield Class

IO.Objects.RemoteIO.mikroBUS Namespace

Shieldkind Property

Returns the kind of mikroBUS shield that is installed on the Remote I/O Protocol server, as obtained from the `SHIELDNAME` environment variable.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static ShieldKinds kind { get; }
```

Property Value

Type: ShieldKinds

See Also

Reference

Shield Class
IO.Objects.RemoteIO.mikroBUS Namespace

Shield Fields

The Shield type exposes the following members.

Fields

	Name	Description
	I2CBus	Shared I^2C bus that is common to all sockets on this shield.

Top

See Also

Reference

Shield Class

IO.Objects.RemoteIO.mikroBUS Namespace

ShieldI2CBus Field

Shared I^2C bus that is common to all sockets on this shield.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static Bus I2CBus
```

Field Value

Type: Bus

See Also

Reference

Shield Class
IO.Objects.RemoteIO.mikroBUS Namespace

ShieldKinds Enumeration

Supported mikroBUS shields.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public enum Kinds
```

Members

Member name	Value	Description
Clicker	0	Mikroelektronika STM32F4 Clicker with MUNTS-0011 Remote I/O Server firmware, with one mikroBUS socket.
PiClick1	1	Raspberry Pi with Mikroelektronika Pi Click Shield MIKROE-1512/1513 for 26-pin expansion header, with one mikroBUS socket (Obsolete.)

	PiClick2	2	Raspberry Pi with Mikroelektronika Pi 2 Click Shield MIKROE-1879 for 40-pin expansion header, with two mikroBUS sockets.
	PiClick3	3	Mikroelektronika Pi 3 Click Shield MIKROE-2756 for 40-pin expansion header, with selectable on-board A/D converter and two mikroBUS sockets.
	PocketBeagle	4	PocketBeagle with female headers on top, with two mikroBUS sockets.
	Unknown	2147483647	No known mikroBUS shield installed.

See Also

Reference

IO.Objects.RemoteIO.mikroBUS Namespace

Socket Class

Encapsulates mikroBUS sockets.

Inheritance Hierarchy

SystemObject IO.Objects.RemoteIO.mikroBUSSocket

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Socket
```

The Socket type exposes the following members.

Constructors

	Name	Description
	Socket	Constructor for a single mikroBUS socket.

Top

Properties

	Name	Description
	AIN	Returns the ADC input designator for AN.

	AN	Returns the GPIO pin designator for AN.
	CS	Returns the GPIO pin designator for CS.
	I2CBus	Returns the I^2C bus designator for this socket.
	INT	Returns the GPIO pin designator for INT.
	MISO	Returns the GPIO pin designator for MISO.
	MOSI	Returns the GPIO pin designator for MOSI.
	PWM	Returns the GPIO pin designator for PWM.
	PWMOut	Returns the PWM output designator for PWM.
	RST	Returns the GPIO pin designator for RST.
	RX	Returns the GPIO pin designator for RX.
	SCK	Returns the GPIO pin designator for SCK.
	SCL	Returns the GPIO pin designator for SCL.
	SDA	Returns the GPIO pin designator for SDA.
	SPIDev	Returns the SPI device designator for

		this socket.
	TX	Returns the GPIO pin designator for TX.

Top

See Also

Reference

IO.Objects.RemoteIO.mikroBUS Namespace

Socket Constructor

Constructor for a single mikroBUS socket.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Socket(
        int num,
        ShieldKinds shield = ShieldKinds.Unknown
)
```

Parameters

num
Type: SystemInt32
Socket number.

shield **(Optional)**
Type: IO.Objects.RemoteIO.mikroBUSShieldKinds
mikroBUS shield kind. Zero indicates automatic detection using the `Shield.kind` property.

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

Socket Properties

The Socket type exposes the following members.

Properties

	Name	Description
	AIN	Returns the ADC input designator for AN.
	AN	Returns the GPIO pin designator for AN.
	CS	Returns the GPIO pin designator for CS.
	I2CBus	Returns the I^2C bus designator for this socket.
	INT	Returns the GPIO pin designator for INT.
	MISO	Returns the GPIO pin designator for MISO.
	MOSI	Returns the GPIO pin designator for MOSI.
	PWM	Returns the GPIO pin designator for PWM.
	PWMOut	Returns the PWM output designator for PWM.

	RST	Returns the GPIO pin designator for RST.
	RX	Returns the GPIO pin designator for RX.
	SCK	Returns the GPIO pin designator for SCK.
	SCL	Returns the GPIO pin designator for SCL.
	SDA	Returns the GPIO pin designator for SDA.
	SPIDev	Returns the SPI device designator for this socket.
	TX	Returns the GPIO pin designator for TX.

Top

See Also

Reference

Socket Class

IO.Objects.RemoteIO.mikroBUS Namespace

SocketAIN Property

Returns the ADC input designator for AN.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int AIN { get; }
```

Property Value

Type: Int32

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

SocketAN Property

Returns the GPIO pin designator for AN.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int AN { get; }
```

Property Value

Type: Int32

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

SocketCS Property

Returns the GPIO pin designator for CS.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int CS { get; }
```

Property Value

Type: Int32

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

SocketI2CBus Property

Returns the I^{2}C bus designator for this socket.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int I2CBus { get; }
```

Property Value

Type: Int32

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

SocketINT Property

Returns the GPIO pin designator for INT.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int INT { get; }
```

Property Value

Type: Int32

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

SocketMISO Property

Returns the GPIO pin designator for MISO.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int MISO { get; }
```

Property Value

Type: Int32

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

SocketMOSI Property

Returns the GPIO pin designator for MOSI.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int MOSI { get; }
```

Property Value

Type: Int32

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

SocketPWM Property

Returns the GPIO pin designator for PWM.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int PWM { get; }
```

Property Value

Type: Int32

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

SocketPWMOut Property

Returns the PWM output designator for PWM.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int PWMOut { get; }
```

Property Value

Type: Int32

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

SocketRST Property

Returns the GPIO pin designator for RST.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int RST { get; }
```

Property Value

Type: Int32

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

SocketRX Property

Returns the GPIO pin designator for RX.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int RX { get; }
```

Property Value

Type: Int32

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

SocketSCK Property

Returns the GPIO pin designator for SCK.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int SCK { get; }
```

Property Value

Type: Int32

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

SocketSCL Property

Returns the GPIO pin designator for SCL.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int SCL { get; }
```

Property Value

Type: Int32

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

SocketSDA Property

Returns the GPIO pin designator for SDA.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int SDA { get; }
```

Property Value

Type: Int32

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

SocketSPIDev Property

Returns the SPI device designator for this socket.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int SPIDev { get; }
```

Property Value

Type: Int32

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

SocketTX Property

Returns the GPIO pin designator for TX.

Namespace: IO.Objects.RemoteIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int TX { get; }
```

Property Value

Type: Int32

See Also

Reference

Socket Class
IO.Objects.RemoteIO.mikroBUS Namespace

IO.Objects.RemoteIO.Platforms Namespace

I/O Resource Definitions for particular Remote I/O Protocol Server Platforms

Classes

	Class	Description
	MUNTS_0018	I/O resources (channel numbers) available on a MUNTS-0018 Tutorial I/O Board Remote I/O Protocol Server.
	RaspberryPi	I/O resources (channel numbers) available on a Raspberry Pi Remote I/O Protocol Server

MUNTS_0018 Class

I/O resources (channel numbers) available on a MUNTS-0018 Tutorial I/O Board Remote I/O Protocol Server.

Inheritance Hierarchy

SystemObject IO.Objects.RemoteIO.PlatformsMUNTS_0018

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static class MUNTS_0018
```

The MUNTS_0018 type exposes the following members.

Fields

	Name	Description
s	D1	GPIO channel number for the on-board LED `D1`.
s	J10A0	Analog input channel number for Grove Connector `J10` pin `A0`.
s	J10A1	Analog input channel number for Grove Connector `J10` pin `A1`.

S	J11A0	Analog input channel number for Grove Connector `J11` pin `A0`.
S	J11A1	Analog input channel number for Grove Connector `J11` pin `A1`.
S	J2PWM	PWM channel number for Servo Header `J2`.
S	J3PWM	PWM channel number for Servo Header `J3`.
S	J4D0	GPIO channel number for Digital I/O Grove Connector `J4` pin `D0`.
S	J4D1	GPIO channel number for Digital I/O Grove Connector `J4` pin `D1`.
S	J5D0	GPIO channel number for Digital I/O Grove Connector `J5` pin `D0`.
S	J5D1	GPIO channel number for Digital I/O Grove Connector `J5` pin `D1`.
S	J6D0	GPIO channel number for DC Motor Driver Grove Connector `J6` pin `D0`.
S	J6D1	GPIO channel number for DC Motor Driver Grove Connector `J6` pin `D1`.
S	J6DIR	GPIO channel number for DC Motor Driver Grove Connector `J6` pin `D1`.
S	J6PWM	PWM channel number for DC Motor Driver Grove Connector `J6` pin `D0`.

	J7D0	GPIO channel number for DC Motor Driver Grove Connector `J7` pin `D0`.
	J7D1	GPIO channel number for DC Motor Driver Grove Connector `J7` pin `D1`.
	J7DIR	GPIO channel number for DC Motor Driver Grove Connector `J6` pin `D1`.
	J7PWM	PWM channel number for DC Motor Driver Grove Connector `J7` pin `D0`.
	J9I2C	I^2C bus channel number for Grove Connector `J9`.
	SW1	GPIO channel number for the on-board momentary switch `SW1`.
	USERLED	GPIO channel number for the remote Raspberry Pi user LED.

Top

Remarks

The following device tree overlay commands must be added to `config.txt` on the Raspberry Pi hosting the MUNTS-0018 Tutorial I/O Board Remote I/O Protocol Server:

Copy

```
dtoverlay=anyspi,spi0-1,dev="microchip,mcp3204",speed=
dtoverlay=pwm-2chan,pin=12,func=4,pin2=19,func2=2
```

See Also

Reference

IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018 Fields

The MUNTS_0018 type exposes the following members.

Fields

	Name	Description
s	D1	GPIO channel number for the on-board LED `D1`.
s	J10A0	Analog input channel number for Grove Connector `J10` pin `A0`.
s	J10A1	Analog input channel number for Grove Connector `J10` pin `A1`.
s	J11A0	Analog input channel number for Grove Connector `J11` pin `A0`.
s	J11A1	Analog input channel number for Grove Connector `J11` pin `A1`.
s	J2PWM	PWM channel number for Servo Header `J2`.
s	J3PWM	PWM channel number for Servo Header `J3`.
s	J4D0	GPIO channel number for Digital I/O Grove Connector `J4` pin `D0`.
s		

	J4D1	GPIO channel number for Digital I/O Grove Connector `J4` pin `D1`.
S	J5D0	GPIO channel number for Digital I/O Grove Connector `J5` pin `D0`.
S	J5D1	GPIO channel number for Digital I/O Grove Connector `J5` pin `D1`.
S	J6D0	GPIO channel number for DC Motor Driver Grove Connector `J6` pin `D0`.
S	J6D1	GPIO channel number for DC Motor Driver Grove Connector `J6` pin `D1`.
S	J6DIR	GPIO channel number for DC Motor Driver Grove Connector `J6` pin `D1`.
S	J6PWM	PWM channel number for DC Motor Driver Grove Connector `J6` pin `D0`.
S	J7D0	GPIO channel number for DC Motor Driver Grove Connector `J7` pin `D0`.
S	J7D1	GPIO channel number for DC Motor Driver Grove Connector `J7` pin `D1`.
S	J7DIR	GPIO channel number for DC Motor Driver Grove Connector `J6` pin `D1`.
S	J7PWM	PWM channel number for DC Motor Driver Grove Connector `J7` pin `D0`.
S	J9I2C	I^2C bus channel number for Grove Connector `J9`.

	SW1	GPIO channel number for the on-board momentary switch `SW1`.
	USERLED	GPIO channel number for the remote Raspberry Pi user LED.

Top

See Also

Reference

MUNTS_0018 Class

IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018D1 Field

GPIO channel number for the on-board LED `D1`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int D1 = 26
```

Field Value

Type: Int32

Remarks

This GPIO pin cannot be configured as an input.

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J10A0 Field

Analog input channel number for Grove Connector `J10` pin `A0`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J10A0 = 2
```

Field Value

Type: Int32

Remarks

MCP3204 input `CH2`.

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J10A1 Field

Analog input channel number for Grove Connector `J10` pin `A1`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J10A1 = 3
```

Field Value

Type: Int32

Remarks

MCP3204 input `CH3`.

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J11A0 Field

Analog input channel number for Grove Connector `J11` pin `A0`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J11A0 = 0
```

Field Value

Type: Int32

Remarks

MCP3204 input `CH0`.

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J11A1 Field

Analog input channel number for Grove Connector `J11` pin `A1`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J11A1 = 1
```

Field Value

Type: Int32

Remarks

MCP3204 input `CH1`.

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J2PWM Field

PWM channel number for Servo Header `J2`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J2PWM = 0
```

Field Value

Type: Int32

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J3PWM Field

PWM channel number for Servo Header `J3`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J3PWM = 1
```

Field Value

Type: Int32

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J4D0 Field

GPIO channel number for Digital I/O Grove Connector `J4` pin `D0`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J4D0 = 23
```

Field Value

Type: Int32

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J4D1 Field

GPIO channel number for Digital I/O Grove Connector `J4` pin `D1`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J4D1 = 24
```

Field Value

Type: Int32

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J5D0 Field

GPIO channel number for Digital I/O Grove Connector `J5` pin `D0`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J5D0 = 5
```

Field Value

Type: Int32

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J5D1 Field

GPIO channel number for Digital I/O Grove Connector `J5` pin `D1`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J5D1 = 4
```

Field Value

Type: Int32

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J6D0 Field

GPIO channel number for DC Motor Driver Grove Connector `J6` pin `D0`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J6D0 = 12
```

Field Value

Type: Int32

Remarks

This GPIO channel is normally unusable because `GPIO12` is mapped to PWM output `PWM0`.

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J6D1 Field

GPIO channel number for DC Motor Driver Grove Connector `J6` pin `D1`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J6D1 = 13
```

Field Value

Type: Int32

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J6DIR Field

GPIO channel number for DC Motor Driver Grove Connector `J6` pin `D1`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J6DIR = 13
```

Field Value

Type: Int32

Remarks

`J6DIR` controls the motor **direction**.

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J6PWM Field

PWM channel number for DC Motor Driver Grove Connector `J6` pin `D0`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J6PWM = 0
```

Field Value

Type: Int32

Remarks

`J6PWM` controls the motor **speed**.

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J7D0 Field

GPIO channel number for DC Motor Driver Grove Connector `J7` pin `D0`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J7D0 = 19
```

Field Value

Type: Int32

Remarks

This GPIO channel is normally unusable because `GPIO19` is mapped to PWM output `PWM1`.

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J7D1 Field

GPIO channel number for DC Motor Driver Grove Connector `J7` pin `D1`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J7D1 = 18
```

Field Value

Type: Int32

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J7DIR Field

GPIO channel number for DC Motor Driver Grove Connector `J6` pin `D1`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J7DIR = 18
```

Field Value

Type: Int32

Remarks

`J7DIR` controls the motor **direction**.

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J7PWM Field

PWM channel number for DC Motor Driver Grove Connector `J7` pin `D0`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J7PWM = 1
```

Field Value

Type: Int32

Remarks

`J7PWM` controls the motor **speed**.

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018J9I2C Field

I^2C bus channel number for Grove Connector `J9`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int J9I2C = 0
```

Field Value

Type: Int32

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018SW1 Field

GPIO channel number for the on-board momentary switch `SW1`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int SW1 = 6
```

Field Value

Type: Int32

Remarks

This GPIO pin cannot be configured as an output.

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

MUNTS_0018USERLED Field

GPIO channel number for the remote Raspberry Pi user LED.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int USERLED = 0
```

Field Value

Type: Int32

Remarks

This GPIO pin cannot be configured as an input.

See Also

Reference

MUNTS_0018 Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPi Class

I/O resources (channel numbers) available on a Raspberry Pi Remote I/O Protocol Server

Inheritance Hierarchy

SystemObject IO.Objects.RemoteIO.PlatformsRaspberryPi

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static class RaspberryPi
```

The RaspberryPi type exposes the following members.

Fields

	Name	Description
S	AIN0	Analog input channel number for the remote Raspberry Pi analog input `AIN0`.
S	AIN1	Analog input channel number for the remote Raspberry Pi analog input `AIN1`.
S	GPIO10	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO10`.

S	GPIO11	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO11`.
S	GPIO12	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO12`.
S	GPIO13	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO13`.
S	GPIO14	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO14`.
S	GPIO15	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO15`.
S	GPIO16	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO16`.
S	GPIO17	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO17`.
S	GPIO18	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO18`.
S	GPIO19	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO19`.
S	GPIO2	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO2`.
S	GPIO20	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO20`.
S	GPIO21	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO21`.

S	GPIO22	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO22`.
S	GPIO23	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO23`.
S	GPIO24	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO24`.
S	GPIO25	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO25`.
S	GPIO26	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO26`.
S	GPIO27	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO27`.
S	GPIO3	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO3`.
S	GPIO4	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO4`.
S	GPIO5	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO5`.
S	GPIO6	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO6`.
S	GPIO7	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO7`.
S	GPIO8	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO8`.

S	GPIO9	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO9`.
S	I2C1	I^2C bus channel number for the remote Raspberry Pi I^2C bus controller `I2C1`.
S	PWM0	PWM output channel number for the remote Raspberry Pi PWM output `PWM0`.
S	PWM1	PWM output channel number for the remote Raspberry Pi PWM output `PWM1`.
S	SPI0	SPI slave device channel number for the remote Raspberry Pi SPI slave device `/dev/spidev0.0`.
S	SPI1	SPI slave device channel number for the remote Raspberry Pi SPI slave device `/dev/spidev0.1`.
S	USERLED	GPIO channel number for the remote Raspberry Pi user LED.

Top

See Also

Reference

IO.Objects.RemoteIO.Platforms Namespace

RaspberryPi Fields

The RaspberryPi type exposes the following members.

Fields

	Name	Description
s	AIN0	Analog input channel number for the remote Raspberry Pi analog input `AIN0`.
s	AIN1	Analog input channel number for the remote Raspberry Pi analog input `AIN1`.
s	GPIO10	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO10`.
s	GPIO11	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO11`.
s	GPIO12	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO12`.
s	GPIO13	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO13`.
s	GPIO14	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO14`.
s	GPIO15	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO15`.
s		

	GPIO16	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO16`.
S	GPIO17	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO17`.
S	GPIO18	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO18`.
S	GPIO19	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO19`.
S	GPIO2	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO2`.
S	GPIO20	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO20`.
S	GPIO21	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO21`.
S	GPIO22	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO22`.
S	GPIO23	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO23`.
S	GPIO24	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO24`.
S	GPIO25	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO25`.
S	GPIO26	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO26`.

S	GPIO27	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO27`.
S	GPIO3	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO3`.
S	GPIO4	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO4`.
S	GPIO5	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO5`.
S	GPIO6	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO6`.
S	GPIO7	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO7`.
S	GPIO8	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO8`.
S	GPIO9	GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO9`.
S	I2C1	I^2C bus channel number for the remote Raspberry Pi I^2C bus controller `I2C1`.
S	PWM0	PWM output channel number for the remote Raspberry Pi PWM output `PWM0`.
S	PWM1	PWM output channel number for the remote Raspberry Pi PWM output `PWM1`.
S	SPI0	SPI slave device channel number for the remote Raspberry Pi SPI slave device `/dev/spidev0.0`.

	SPI1	SPI slave device channel number for the remote Raspberry Pi SPI slave device `/dev/spidev0.1`.
	USERLED	GPIO channel number for the remote Raspberry Pi user LED.

Top

See Also

Reference

RaspberryPi Class

IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiAIN0 Field

Analog input channel number for the remote Raspberry Pi analog input `AIN0`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int AIN0 = 0
```

Field Value

Type: Int32

Remarks

This analog input is only available if a Mikroelektronika Pi 3 Click Shield (MIKROE-2756) is installed and the following device tree overlay command added to config.txt:

Copy

```
dtoverlay=Pi3ClickShield
```

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiAIN1 Field

Analog input channel number for the remote Raspberry Pi analog input `AIN1`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int AIN1 = 1
```

Field Value

Type: Int32

Remarks

This analog input is only available if a Mikroelektronika Pi 3 Click Shield (MIKROE-2756) is installed and the following device tree overlay command added to config.txt:

Copy

```
dtoverlay=Pi3ClickShield
```

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO10 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO10`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO10 = 10
```

Field Value

Type: Int32

Remarks

This GPIO channel is normally unusable because `GPIO10` is mapped to SPI signal `SPI0_MOSI`.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO11 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO11`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO11 = 11
```

Field Value

Type: Int32

Remarks

This GPIO channel is normally unusable because `GPIO11` is mapped to SPI signal `SPI0_SCLK`.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO12 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO12`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO12 = 12
```

Field Value

Type: Int32

Remarks

This GPIO channel is not usable when the Remote I/O server is running on an original Raspberry Pi 1 Model A or B with a 26-pin expansion header.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO13 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO13`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO13 = 13
```

Field Value

Type: Int32

Remarks

This GPIO channel is not usable when the Remote I/O server is running on an original Raspberry Pi 1 Model A or B with a 26-pin expansion header.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO14 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO14`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO14 = 14
```

Field Value

Type: Int32

Remarks

This GPIO channel is normally unusable because `GPIO14` is mapped to UART signal `UART0_TXD`.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO15 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO15`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO15 = 15
```

Field Value

Type: Int32

Remarks

This GPIO channel is normally unusable because `GPIO15` is mapped to UART signal `UART0_RXD`.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO16 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO16`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO16 = 16
```

Field Value

Type: Int32

Remarks

This GPIO channel is not usable when the Remote I/O server is running on an original Raspberry Pi 1 Model A or B with a 26-pin expansion header.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO17 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO17`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO17 = 17
```

Field Value

Type: Int32

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO18 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO18`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO18 = 18
```

Field Value

Type: Int32

Remarks

This GPIO channel is normally unusable because `GPIO18` is mapped to PWM output `PWM0`.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO19 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO19`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO19 = 19
```

Field Value

Type: Int32

Remarks

This GPIO channel is not usable when the Remote I/O server is running on an original Raspberry Pi 1 Model A or B with a 26-pin expansion header.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO2 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO2`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO2 = 2
```

Field Value

Type: Int32

Remarks

This GPIO channel is normally unusable because `GPIO2` is mapped to I^2C signal `SDA1`.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO20 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO20`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO20 = 20
```

Field Value

Type: Int32

Remarks

This GPIO channel is not usable when the Remote I/O server is running on an original Raspberry Pi 1 Model A or B with a 26-pin expansion header.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO21 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO21`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO21 = 21
```

Field Value

Type: Int32

Remarks

This GPIO channel is not usable when the Remote I/O server is running on an original Raspberry Pi 1 Model A or B with a 26-pin expansion header.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO22 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO22`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO22 = 22
```

Field Value

Type: Int32

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO23 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO23`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO23 = 23
```

Field Value

Type: Int32

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO24 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO24`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO24 = 24
```

Field Value

Type: Int32

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO25 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO25`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO25 = 25
```

Field Value

Type: Int32

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO26 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO26`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO26 = 26
```

Field Value

Type: Int32

Remarks

This GPIO channel is not usable when the Remote I/O server is running on an original Raspberry Pi 1 Model A or B with a 26-pin expansion header.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO27 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO27`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO27 = 27
```

Field Value

Type: Int32

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO3 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO3`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO3 = 3
```

Field Value

Type: Int32

Remarks

This GPIO channel is normally unusable because `GPIO3` is mapped to to I^2C signal `SCL1`.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO4 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO4`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO4 = 4
```

Field Value

Type: Int32

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO5 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO5`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO5 = 5
```

Field Value

Type: Int32

Remarks

This GPIO channel is not usable when the Remote I/O server is running on an original Raspberry Pi 1 Model A or B with a 26-pin expansion header.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO6 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO6`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO6 = 6
```

Field Value

Type: Int32

Remarks

This GPIO channel is not usable when the Remote I/O server is running on an original Raspberry Pi 1 Model A or B with a 26-pin expansion header.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO7 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO7`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO7 = 7
```

Field Value

Type: Int32

Remarks

This GPIO channel is normally unusable because `GPIO7` is mapped to SPI signal `SPI0_CE1`.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO8 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO8`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO8 = 8
```

Field Value

Type: Int32

Remarks

This GPIO channel is normally unusable because `GPIO8` is mapped to SPI signal `SPI0_CE0`.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiGPIO9 Field

GPIO channel number for the remote Raspberry Pi GPIO pin `GPIO9`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int GPIO9 = 9
```

Field Value

Type: Int32

Remarks

This GPIO channel is normally unusable because `GPIO9` is mapped to SPI signal `SPI0_MISO`.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiI2C1 Field

I²C bus channel number for the remote Raspberry Pi I²C bus controller `I2C1`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int I2C1 = 0
```

Field Value

Type: Int32

Remarks

The following device tree overlay command must be added to `config.txt` on the Raspberry Pi Remote I/O server to enable I²C bus controller `I2C1`:

Copy

```
dtparam=i2c=on
```

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiPWM0 Field

PWM output channel number for the remote Raspberry Pi PWM output `PWM0`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int PWM0 = 0
```

Field Value

Type: Int32

Remarks

The following device tree overlay command must be added to `config.txt` on the Raspberry Pi Remote I/O server to enable PWM output `PWM0`:

Copy

```
dtoverlay=pwm
```

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiPWM1 Field

PWM output channel number for the remote Raspberry Pi PWM output `PWM1`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int PWM1 = 1
```

Field Value

Type: Int32

Remarks

`PWM1` is not normally enabled. You can enable it with one of the device tree overlay command variationss described in https://github.com/raspberrypi/firmware/blob/master/boot/overlays/README.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiSPI0 Field

SPI slave device channel number for the remote Raspberry Pi SPI slave device `/dev/spidev0.0`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int SPI0 = 0
```

Field Value

Type: Int32

Remarks

`/dev/spidev0.0` uses `GPIO8` for slave select. The following device tree overlay command must be added to `config.txt` on the Raspberry Pi Remote I/O server to enable SPI bus controller `SPI0`:

Copy

```
dtparam=spi=on
```

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiSPI1 Field

SPI slave device channel number for the remote Raspberry Pi SPI slave device `/dev/spidev0.1`.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int SPI1 = 1
```

Field Value

Type: Int32

Remarks

`/dev/spidev0.1` uses `GPIO7` for slave select. The following device tree overlay command must be added to `config.txt` on the Raspberry Pi Remote I/O server to enable SPI bus controller `SPI0`:

Copy

```
dtparam=spi=on
```

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

RaspberryPiUSERLED Field

GPIO channel number for the remote Raspberry Pi user LED.

Namespace: IO.Objects.RemoteIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int USERLED = 0
```

Field Value

Type: Int32

Remarks

This GPIO pin cannot be configured as an input.

See Also

Reference

RaspberryPi Class
IO.Objects.RemoteIO.Platforms Namespace

IO.Objects.Servo.PWM Namespace

PWM Controlled Servo Services

Classes

	Class	Description
	Output	Encapsulates servo outputs using PWM outputs.

Output Class

Encapsulates servo outputs using PWM outputs.

Inheritance Hierarchy

SystemObject IO.Objects.Servo.PWMOutput

Namespace: IO.Objects.Servo.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Output : Output
```

The Output type exposes the following members.

Constructors

	Name	Description
	Output	Constructor for a single servo output.

Top

Properties

	Name	Description
	position	Write-only property for setting the servo position. Allowed values are -1.0 to +1.0.

Top

See Also

Reference

IO.Objects.Servo.PWM Namespace

Output Constructor

Constructor for a single servo output.

Namespace: IO.Objects.Servo.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Output(
        Output pwm,
        int freq = 50,
        double position = 0
)
```

Parameters

pwm
Type: IO.Interfaces.PWMOutput
PWM output instance.

freq **(Optional)**
Type: SystemInt32
PWM pulse frequency.

position **(Optional)**
Type: SystemDouble
Initial servo position.

See Also

Reference

Output Class

IO.Objects.Servo.PWM Namespace

Output Properties

The Output type exposes the following members.

Properties

	Name	Description
	position	Write-only property for setting the servo position. Allowed values are -1.0 to +1.0.

Top

See Also

Reference

Output Class

IO.Objects.Servo.PWM Namespace

Outputposition Property

Write-only property for setting the servo position. Allowed values are -1.0 to +1.0.

Namespace: IO.Objects.Servo.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public double position { set; }
```

Property Value

Type: Double

Implements

Outputposition

See Also

Reference

Output Class
IO.Objects.Servo.PWM Namespace

IO.Objects.SimpleIO.ADC Namespace

ADC (Analog to Digital Converter) Input Services

Classes

	Class	Description
	Sample	Encapsulates Linux Industrial I/O Subsystem ADC inputs usingi `libsimpleio`.

Sample Class

Encapsulates Linux Industrial I/O Subsystem ADC inputs usingi `libsimpleio`.

Inheritance Hierarchy

SystemObject IO.Objects.SimpleIO.ADCSample

Namespace: IO.Objects.SimpleIO.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Sample : Sample
```

The Sample type exposes the following members.

Constructors

	Name	Description
	Sample	Constructor for a single ADC input.

Top

Properties

	Name	Description
	fd	Read-only property returning the Linux

		file descriptor for the ADC input.
	resolution	Read-only property returning the number of bits of resolution.
	sample	Read-only property returning an integer analog sample from an ADC input.

Top

Methods

	Name	Description
	name	Retrieve the subsystem name string for a Linux Industrial I/O Subsystem ADC device.

Top

See Also

Reference

IO.Objects.SimpleIO.ADC Namespace

Sample Constructor

Constructor for a single ADC input.

Namespace: IO.Objects.SimpleIO.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Sample(
        Designator desg,
        int resolution
)
```

Parameters

desg
Type: IO.Objects.SimpleIO.DeviceDesignator
ADC input designator.

resolution
Type: SystemInt32
Bits of resolution.

See Also

Reference

Sample Class
IO.Objects.SimpleIO.ADC Namespace

Sample Properties

The Sample type exposes the following members.

Properties

	Name	Description
	fd	Read-only property returning the Linux file descriptor for the ADC input.
	resolution	Read-only property returning the number of bits of resolution.
	sample	Read-only property returning an integer analog sample from an ADC input.

Top

See Also

Reference

Sample Class

IO.Objects.SimpleIO.ADC Namespace

Samplefd Property

Read-only property returning the Linux file descriptor for the ADC input.

Namespace: IO.Objects.SimpleIO.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int fd { get; }
```

Property Value

Type: Int32

See Also

Reference

Sample Class
IO.Objects.SimpleIO.ADC Namespace

Sampleresolution Property

Read-only property returning the number of bits of resolution.

Namespace: IO.Objects.SimpleIO.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int resolution { get; }
```

Property Value

Type: Int32

Implements

Sampleresolution

See Also

Reference

Sample Class
IO.Objects.SimpleIO.ADC Namespace

Samplesample Property

Read-only property returning an integer analog sample from an ADC input.

Namespace: IO.Objects.SimpleIO.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int sample { get; }
```

Property Value

Type: Int32

Implements

Samplesample

See Also

Reference

Sample Class
IO.Objects.SimpleIO.ADC Namespace

Sample Methods

The Sample type exposes the following members.

Methods

	Name	Description
	name	Retrieve the subsystem name string for a Linux Industrial I/O Subsystem ADC device.

Top

See Also

Reference

Sample Class

IO.Objects.SimpleIO.ADC Namespace

Samplename Method

Retrieve the subsystem name string for a Linux Industrial I/O Subsystem ADC device.

Namespace: IO.Objects.SimpleIO.ADC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static string name(
        int chip
)
```

Parameters

chip
Type: SystemInt32
ADC chip number.

Return Value

Type: String
Subsystem name.

See Also

Reference

Sample Class
IO.Objects.SimpleIO.ADC Namespace

IO.Objects.SimpleIO.DAC Namespace

DAC (Digital to Analog Converter) Output Services

Classes

	Class	Description
	Sample	Encapsulates Linux Industrial I/O Subsystem DAC outputs using `libsimpleio`.

Sample Class

Encapsulates Linux Industrial I/O Subsystem DAC outputs using `libsimpleio`.

Inheritance Hierarchy

SystemObject IO.Objects.SimpleIO.DACSample

Namespace: IO.Objects.SimpleIO.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Sample : Sample
```

The Sample type exposes the following members.

Constructors

	Name	Description
	Sample	Constructor for a single DAC output.

Top

Properties

	Name	Description
	fd	Read-only property returning the Linux

		file descriptor for the DAC output.
	resolution	Read-only property returning the number of bits of resolution.
	sample	Write-only property for writing an integer analog sample to a DAC output.

Top

Methods

	Name	Description
	name	Retrieve the subsystem name string for a Linux Industrial I/O Subsystem DAC device.

Top

See Also

Reference

IO.Objects.SimpleIO.DAC Namespace

Sample Constructor

Constructor for a single DAC output.

Namespace: IO.Objects.SimpleIO.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Sample(
        Designator desg,
        int resolution,
        int sample = 0
)
```

Parameters

desg
Type: IO.Objects.SimpleIO.DeviceDesignator
DAC output designator.

resolution
Type: SystemInt32
Bits of resolution.

sample **(Optional)**
Type: SystemInt32
Initial DAC output sample.

See Also

Reference

Sample Class

IO.Objects.SimpleIO.DAC Namespace

Sample Properties

The Sample type exposes the following members.

Properties

	Name	Description
	fd	Read-only property returning the Linux file descriptor for the DAC output.
	resolution	Read-only property returning the number of bits of resolution.
	sample	Write-only property for writing an integer analog sample to a DAC output.

Top

See Also

Reference

Sample Class

IO.Objects.SimpleIO.DAC Namespace

Samplefd Property

Read-only property returning the Linux file descriptor for the DAC output.

Namespace: IO.Objects.SimpleIO.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int fd { get; }
```

Property Value

Type: Int32

See Also

Reference

Sample Class
IO.Objects.SimpleIO.DAC Namespace

Sampleresolution Property

Read-only property returning the number of bits of resolution.

Namespace: IO.Objects.SimpleIO.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int resolution { get; }
```

Property Value

Type: Int32

Implements

Sampleresolution

See Also

Reference

Sample Class
IO.Objects.SimpleIO.DAC Namespace

Samplesample Property

Write-only property for writing an integer analog sample to a DAC output.

Namespace: IO.Objects.SimpleIO.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int sample { set; }
```

Property Value

Type: Int32

Implements

Samplesample

See Also

Reference

Sample Class
IO.Objects.SimpleIO.DAC Namespace

Sample Methods

The Sample type exposes the following members.

Methods

	Name	Description
	name	Retrieve the subsystem name string for a Linux Industrial I/O Subsystem DAC device.

Top

See Also

Reference

Sample Class

IO.Objects.SimpleIO.DAC Namespace

Samplename Method

Retrieve the subsystem name string for a Linux Industrial I/O Subsystem DAC device.

Namespace: IO.Objects.SimpleIO.DAC
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static string name(
        int chip
)
```

Parameters

chip
Type: SystemInt32
DAC chip number.

Return Value

Type: String
Subsystem name.

See Also

Reference

Sample Class
IO.Objects.SimpleIO.DAC Namespace

IO.Objects.SimpleIO.Device Namespace

Common device declarations

Structures

	Structure	Description
	Designator	Linux kernel I/O device designator..

Designator Structure

Linux kernel I/O device designator..

Namespace: IO.Objects.SimpleIO.Device
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public struct Designator
```

The Designator type exposes the following members.

Constructors

	Name	Description
	Designator	device pin designator constructor.

Top

Properties

	Name	Description
	available	Returns `true` if this device designator is not equal to `Unavailable`.

Top

Fields

	Name	Description
	chan	Linux kernel I/O device channel number.
	chip	Linux kernel I/O device chip number.
S	Unavailable	Linux kernel I/O device designator for an unavailable device.

Top

Remarks

Many Linux kernel I/O devices, including ADC inputs, DAC outputs, GPIO pins, I2C buses, PWM outputs, and SPI devices, are selected by a tuple of integers: chip and channel.

See Also

Reference

IO.Objects.SimpleIO.Device Namespace

Designator Constructor

device pin designator constructor.

Namespace: IO.Objects.SimpleIO.Device
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Designator(
        uint chip,
        uint chan
)
```

Parameters

chip
Type: SystemUInt32
Linux kernel I/O device chip number.

chan
Type: SystemUInt32
Linux kernel I/O device channel number.

See Also

Reference

Designator Structure
IO.Objects.SimpleIO.Device Namespace

Designator Properties

The Designator type exposes the following members.

Properties

	Name	Description
	available	Returns `true` if this device designator is not equal to `Unavailable`.

Top

See Also

Reference

Designator Structure
IO.Objects.SimpleIO.Device Namespace

Designatoravailable Property

Returns `true` if this device designator is not equal to `Unavailable`.

Namespace: IO.Objects.SimpleIO.Device
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public bool available { get; }
```

Property Value

Type: Boolean

See Also

Reference

Designator Structure
IO.Objects.SimpleIO.Device Namespace

Designator Fields

The Designator type exposes the following members.

Fields

	Name	Description
	chan	Linux kernel I/O device channel number.
	chip	Linux kernel I/O device chip number.
S	Unavailable	Linux kernel I/O device designator for an unavailable device.

Top

See Also

Reference

Designator Structure

IO.Objects.SimpleIO.Device Namespace

Designatorchan Field

Linux kernel I/O device channel number.

Namespace: IO.Objects.SimpleIO.Device
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public uint chan
```

Field Value

Type: UInt32

See Also

Reference

Designator Structure
IO.Objects.SimpleIO.Device Namespace

Designatorchip Field

Linux kernel I/O device chip number.

Namespace: IO.Objects.SimpleIO.Device
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public uint chip
```

Field Value

Type: UInt32

See Also

Reference

Designator Structure
IO.Objects.SimpleIO.Device Namespace

DesignatorUnavailable Field

Linux kernel I/O device designator for an unavailable device.

Namespace: IO.Objects.SimpleIO.Device
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator Unavailable
```

Field Value

Type: Designator

See Also

Reference

Designator Structure
IO.Objects.SimpleIO.Device Namespace

IO.Objects.SimpleIO.GPIO Namespace

GPIO (General Purpose Input/Output) Pin Services

Classes

	Class	Description
	Pin	Encapsulates Linux GPIO pins using `libsimpleio`.

Enumerations

	Enumeration	Description
	PinDriver	GPIO output driver settings.
	PinEdge	GPIO input interrupt edge settings.
	PinPolarity	GPIO polarity settings

Pin Class

Encapsulates Linux GPIO pins using `libsimpleio`.

Inheritance Hierarchy

SystemObject IO.Objects.SimpleIO.GPIOPin

Namespace: IO.Objects.SimpleIO.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Pin : Pin
```

The Pin type exposes the following members.

Constructors

	Name	Description
	Pin	Constructor for a single GPIO pin.

Top

Properties

	Name	Description
	fd	Read-only property returning the Linux file descriptor for the GPIO pin.

	state	Read/Write GPIO state property.

Top

See Also

Reference

IO.Objects.SimpleIO.GPIO Namespace

Pin Constructor

Constructor for a single GPIO pin.

Namespace: IO.Objects.SimpleIO.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Pin(
        Designator desg,
        Direction dir,
        bool state = false,
        PinDriver driver = PinDriver.PushPull,
        PinEdge edge = PinEdge.None,
        PinPolarity polarity = PinPolarity.ActiveHigh
)
```

Parameters

desg
Type: IO.Objects.SimpleIO.DeviceDesignator
GPIO pin designator.

dir
Type: IO.Interfaces.GPIODirection
Data direction.

state **(Optional)**
Type: SystemBoolean
Initial GPIO output state.

driver **(Optional)**

Type: IO.Objects.SimpleIO.GPIOPinDriver
Output driver setting.

edge **(Optional)**
Type: IO.Objects.SimpleIO.GPIOPinEdge
Interrupt edge setting.

polarity **(Optional)**
Type: IO.Objects.SimpleIO.GPIOPinPolarity
Polarity setting.

See Also

Reference

Pin Class
IO.Objects.SimpleIO.GPIO Namespace

Pin Properties

The Pin type exposes the following members.

Properties

	Name	Description
	fd	Read-only property returning the Linux file descriptor for the GPIO pin.
	state	Read/Write GPIO state property.

Top

See Also

Reference

Pin Class

IO.Objects.SimpleIO.GPIO Namespace

Pinfd Property

Read-only property returning the Linux file descriptor for the GPIO pin.

Namespace: IO.Objects.SimpleIO.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int fd { get; }
```

Property Value

Type: Int32

See Also

Reference

Pin Class
IO.Objects.SimpleIO.GPIO Namespace

Pinstate Property

Read/Write GPIO state property.

Namespace: IO.Objects.SimpleIO.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public bool state { get; set; }
```

Property Value

Type: Boolean

Implements

Pinstate

See Also

Reference

Pin Class
IO.Objects.SimpleIO.GPIO Namespace

PinDriver Enumeration

GPIO output driver settings.

Namespace: IO.Objects.SimpleIO.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public enum Driver
```

Members

Member name	Value	Description
PushPull	0	Push Pull (current source/sink) output driver.
OpenDrain	1	Open Drain (current sink) output driver.
OpenSource	2	Open Source (current source) output driver.

See Also

Reference
IO.Objects.SimpleIO.GPIO Namespace

PinEdge Enumeration

GPIO input interrupt edge settings.

Namespace: IO.Objects.SimpleIO.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public enum Edge
```

Members

Member name	Value	Description
None	0	Configure GPIO input pin with interrupt disabled.
Rising	1	Configure GPIO input pin to interrupt on rising edge.
Falling	2	Configure GPIO pin to interrupt on falling edge.
Both	3	Configure GPIO pin to interrupt on both edges.

See Also

Reference

IO.Objects.SimpleIO.GPIO Namespace

PinPolarity Enumeration

GPIO polarity settings

Namespace: IO.Objects.SimpleIO.GPIO
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public enum Polarity
```

Members

	Member name	Value	Description
	ActiveLow	0	Configure GPIO pin as active low (inverted logic).
	ActiveHigh	1	Configure GPIO pin as active high (normal logic).

See Also

Reference

IO.Objects.SimpleIO.GPIO Namespace

IO.Objects.SimpleIO.HID Namespace

Raw HID (Human Interface Device) Services

Classes

	Class	Description
	Messenger	Encapsulates Linux raw HID devices using `libsimpleio`.

Messenger Class

Encapsulates Linux raw HID devices using `libsimpleio`.

Inheritance Hierarchy

SystemObject IO.Objects.SimpleIO.HIDMessenger

Namespace: IO.Objects.SimpleIO.HID
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Messenger : Messenger
```

The Messenger type exposes the following members.

Constructors

	Name	Description
	Messenger(String, Int32)	Constructor for a single raw HID device.
	Messenger(Int32, Int32, String, Int32)	Constructor for a single raw HID device.

Top

Properties

	Name	Description
	bustype	Read-only property returning the bus type identifier for a raw HID device.
	fd	Read-only property returning the Linux file descriptor for a raw HID device.
	name	Read-only property returning the device information string for a raw HID device.
	product	Read-only property returning the product identifier for a raw HID device.
	vendor	Read-only property returning the vendor identifier for a raw HID device.

Top

Methods

	Name	Description
	Receive	Receive a 64-byte response message from a raw HID device.
	Send	Send a 64-byte command message to a raw HID device.
	Transaction	Send a 64-byte command message and receive a 64-byte response message.

Top

See Also

Reference

IO.Objects.SimpleIO.HID Namespace

Messenger Constructor

Overload List

	Name	Description
	Messenger(String, Int32)	Constructor for a single raw HID device.
	Messenger(Int32, Int32, String, Int32)	Constructor for a single raw HID device.

Top

See Also

Reference

Messenger Class

IO.Objects.SimpleIO.HID Namespace

Messenger Constructor (String, Int32)

Constructor for a single raw HID device.

Namespace: IO.Objects.SimpleIO.HID
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public Messenger(
        string devname,
        int timeoutms = 1000
)
```

Parameters

devname
Type: SystemString
Device node name.

timeoutms **(Optional)**
Type: SystemInt32
Time in milliseconds to wait for read and write operations to complete. Zero means wait forever.

See Also

Reference

Messenger Class
Messenger Overload

IO.Objects.SimpleIO.HID Namespace

Messenger Constructor (Int32, Int32, String, Int32)

Constructor for a single raw HID device.

Namespace: IO.Objects.SimpleIO.HID
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Messenger(
        int VID = 5840,
        int PID = 2810,
        string serial = null,
        int timeoutms = 1000
)
```

Parameters

VID **(Optional)**
Type: SystemInt32
Vendor ID.

PID **(Optional)**
Type: SystemInt32
Product ID.

serial **(Optional)**
Type: SystemString
Serial Number.

timeoutms **(Optional)**

Type: SystemInt32
Time in milliseconds to wait for read and write operations to complete. Zero means wait forever.

See Also

Reference

Messenger Class
Messenger Overload
IO.Objects.SimpleIO.HID Namespace

Messenger Properties

The Messenger type exposes the following members.

Properties

	Name	Description
	bustype	Read-only property returning the bus type identifier for a raw HID device.
	fd	Read-only property returning the Linux file descriptor for a raw HID device.
	name	Read-only property returning the device information string for a raw HID device.
	product	Read-only property returning the product identifier for a raw HID device.
	vendor	Read-only property returning the vendor identifier for a raw HID device.

Top

See Also

Reference

Messenger Class
IO.Objects.SimpleIO.HID Namespace

Messengerbustype Property

Read-only property returning the bus type identifier for a raw HID device.

Namespace: IO.Objects.SimpleIO.HID
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int bustype { get; }
```

Property Value

Type: Int32

See Also

Reference

Messenger Class
IO.Objects.SimpleIO.HID Namespace

Messengerfd Property

Read-only property returning the Linux file descriptor for a raw HID device.

Namespace: IO.Objects.SimpleIO.HID
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int fd { get; }
```

Property Value

Type: Int32

See Also

Reference

Messenger Class
IO.Objects.SimpleIO.HID Namespace

Messengername Property

Read-only property returning the device information string for a raw HID device.

Namespace: IO.Objects.SimpleIO.HID
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public string name { get; }
```

Property Value

Type: String

See Also

Reference

Messenger Class
IO.Objects.SimpleIO.HID Namespace

Messengerproduct Property

Read-only property returning the product identifier for a raw HID device.

Namespace: IO.Objects.SimpleIO.HID
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int product { get; }
```

Property Value

Type: Int32

See Also

Reference

Messenger Class
IO.Objects.SimpleIO.HID Namespace

Messengervendor Property

Read-only property returning the vendor identifier for a raw HID device.

Namespace: IO.Objects.SimpleIO.HID
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int vendor { get; }
```

Property Value

Type: Int32

See Also

Reference

Messenger Class
IO.Objects.SimpleIO.HID Namespace

Messenger Methods

The Messenger type exposes the following members.

Methods

	Name	Description
	Receive	Receive a 64-byte response message from a raw HID device.
	Send	Send a 64-byte command message to a raw HID device.
	Transaction	Send a 64-byte command message and receive a 64-byte response message.

Top

See Also

Reference

Messenger Class

IO.Objects.SimpleIO.HID Namespace

MessengerReceive Method

Receive a 64-byte response message from a raw HID device.

Namespace: IO.Objects.SimpleIO.HID
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public void Receive(
        Message resp
)
```

Parameters

resp
Type: IO.Interfaces.Message64Message
64-byte response message.

Implements

MessengerReceive(Message)

See Also

Reference

Messenger Class
IO.Objects.SimpleIO.HID Namespace

MessengerSend Method

Send a 64-byte command message to a raw HID device.

Namespace: IO.Objects.SimpleIO.HID
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public void Send(
        Message cmd
)
```

Parameters

cmd
Type: IO.Interfaces.Message64Message
64-byte command message.

Implements

MessengerSend(Message)

See Also

Reference

Messenger Class
IO.Objects.SimpleIO.HID Namespace

MessengerTransaction Method

Send a 64-byte command message and receive a 64-byte response message.

Namespace: IO.Objects.SimpleIO.HID
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Transaction(
        Message cmd,
        Message resp
)
```

Parameters

cmd
Type: IO.Interfaces.Message64Message
64-byte command message.

resp
Type: IO.Interfaces.Message64Message
64-byte response message.

Implements

MessengerTransaction(Message, Message)

See Also

Reference

Messenger Class

IO.Objects.SimpleIO.HID Namespace

IO.Objects.SimpleIO.I2C Namespace

I^2C (Inter-Integrated Circuit) Bus Controller Services

Classes

	Class	Description
	Bus	Encapsulates Linux I^2C bus controllers using `libsimpleio`.

Bus Class

Encapsulates Linux I²C bus controllers using `libsimpleio`.

Inheritance Hierarchy

SystemObject IO.Objects.SimpleIO.I2CBus

Namespace: IO.Objects.SimpleIO.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Bus : Bus
```

The Bus type exposes the following members.

Constructors

	Name	Description
	Bus(Designator)	Constructor for a single I²C bus controller.
	Bus(String)	Constructor for a single I²C bus controller.

Top

Properties

	Name	Description
	fd	Read-only property returning the Linux file descriptor for the I^2C bus controller.

Top

Methods

	Name	Description
	Read	Read bytes from an I^2C device.
	Transaction	Write and receive bytes to/from an I^2C device.
	Write	Write bytes to an I^2C device.

Top

See Also

Reference

IO.Objects.SimpleIO.I2C Namespace

Bus Constructor

Overload List

	Name	Description
	Bus(Designator)	Constructor for a single I^{2}C bus controller.
	Bus(String)	Constructor for a single I^{2}C bus controller.

Top

See Also

Reference

Bus Class

IO.Objects.SimpleIO.I2C Namespace

Bus Constructor (Designator)

Constructor for a single I²C bus controller.

Namespace: IO.Objects.SimpleIO.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Bus(
        Designator desg
)
```

Parameters

desg
Type: IO.Objects.SimpleIO.DeviceDesignator
I² bus designator.

See Also

Reference

Bus Class
Bus Overload
IO.Objects.SimpleIO.I2C Namespace

Bus Constructor (String)

Constructor for a single I²C bus controller.

Namespace: IO.Objects.SimpleIO.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Bus(
        string devname
)
```

Parameters

devname
Type: SystemString
Device node name.

See Also

Reference

Bus Class
Bus Overload
IO.Objects.SimpleIO.I2C Namespace

Bus Properties

The Bus type exposes the following members.

Properties

	Name	Description
	fd	Read-only property returning the Linux file descriptor for the I^2C bus controller.

Top

See Also

Reference

Bus Class

IO.Objects.SimpleIO.I2C Namespace

Busfd Property

Read-only property returning the Linux file descriptor for the I²C bus controller.

Namespace: IO.Objects.SimpleIO.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int fd { get; }
```

Property Value

Type: Int32

See Also

Reference

Bus Class
IO.Objects.SimpleIO.I2C Namespace

Bus Methods

The Bus type exposes the following members.

Methods

	Name	Description
	Read	Read bytes from an I^{2}C device.
	Transaction	Write and receive bytes to/from an I^{2}C device.
	Write	Write bytes to an I^{2}C device.

Top

See Also

Reference

Bus Class

IO.Objects.SimpleIO.I2C Namespace

BusRead Method

Read bytes from an I²C device.

Namespace: IO.Objects.SimpleIO.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Read(
        int slaveaddr,
        byte[] resp,
        int resplen
)
```

Parameters

slaveaddr
Type: SystemInt32
Slave device address.

resp
Type: SystemByte
Response buffer.

resplen
Type: SystemInt32
Number of bytes to read.

Implements

BusRead(Int32, Byte, Int32)

See Also

Reference

Bus Class

IO.Objects.SimpleIO.I2C Namespace

BusTransaction Method

Write and receive bytes to/from an I^{2}C device.

Namespace: IO.Objects.SimpleIO.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Transaction(
        int slaveaddr,
        byte[] cmd,
        int cmdlen,
        byte[] resp,
        int resplen,
        int delayus = 0
)
```

Parameters

slaveaddr
Type: SystemInt32
Device slave address.

cmd
Type: SystemByte
Command buffer.

cmdlen
Type: SystemInt32
Number of bytes to write.

resp

Type: SystemByte
Response buffer.

resplen

Type: SystemInt32
Number of bytes to read.

delayus **(Optional)**

Type: SystemInt32
Delay in microseconds between the I^2C write and read cycles.
Allowed values are 0 to 65535 microseconds.

Implements

BusTransaction(Int32, Byte, Int32, Byte, Int32, Int32)

See Also

Reference

Bus Class
IO.Objects.SimpleIO.I2C Namespace

BusWrite Method

Write bytes to an I²C device.

Namespace: IO.Objects.SimpleIO.I2C
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Write(
        int slaveaddr,
        byte[] cmd,
        int cmdlen
)
```

Parameters

slaveaddr
Type: SystemInt32
Slave device address.

cmd
Type: SystemByte
Command buffer.

cmdlen
Type: SystemInt32
Number of bytes to write.

Implements

BusWrite(Int32, Byte, Int32)

See Also

Reference

Bus Class

IO.Objects.SimpleIO.I2C Namespace

IO.Objects.SimpleIO.mikroBUS Namespace

Mikroelektronika mikroBUS (https://www.mikroe.com/mikrobus) Shield and Socket Services

Classes

	Class	Description
	Shield	Encapsulates mikroBUS shields (add-on boards providing mikroBUS sockets).
	Socket	Encapsulates mikroBUS sockets.

Enumerations

	Enumeration	Description
	ShieldKinds	Supported mikroBUS shields.

Shield Class

Encapsulates mikroBUS shields (add-on boards providing mikroBUS sockets).

Inheritance Hierarchy

SystemObject IO.Objects.SimpleIO.mikroBUSShield

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static class Shield
```

The Shield type exposes the following members.

Properties

	Name	Description
	kind	Returns the kind of mikroBUS shield that is installed on the target board, as obtained from the `SHIELDNAME` environment variable or guessed from the `BOARDNAME` environment variable. The guessed value for BeagleBone family target boards (`BOARDNAME` == "BeagleBone*") is `BeagleBoneClick4`.

	The guessed value for Raspberry Pi family target boards (`BOARDNAME` == "RaspberryPi*") is `PiClick3`.

Top

Fields

	Name	Description
	I2CBus	Shared I^2C bus that is common to all sockets on this shield.

Top

See Also

Reference

IO.Objects.SimpleIO.mikroBUS Namespace

Shield Properties

The Shield type exposes the following members.

Properties

	Name	Description
	kind	Returns the kind of mikroBUS shield that is installed on the target board, as obtained from the `SHIELDNAME` environment variable or guessed from the `BOARDNAME` environment variable. The guessed value for BeagleBone family target boards (`BOARDNAME` == "BeagleBone*") is `BeagleBoneClick4`. The guessed value for Raspberry Pi family target boards (`BOARDNAME` == "RaspberryPi*") is `PiClick3`.

Top

See Also

Reference

Shield Class

IO.Objects.SimpleIO.mikroBUS Namespace

Shieldkind Property

Returns the kind of mikroBUS shield that is installed on the target board, as obtained from the `SHIELDNAME` environment variable or guessed from the `BOARDNAME` environment variable. The guessed value for BeagleBone family target boards (`BOARDNAME` == "BeagleBone*") is `BeagleBoneClick4`. The guessed value for Raspberry Pi family target boards (`BOARDNAME` == "RaspberryPi*") is `PiClick3`.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public static ShieldKinds kind { get; }
```

Property Value

Type: ShieldKinds

See Also

Reference

Shield Class
IO.Objects.SimpleIO.mikroBUS Namespace

Shield Fields

The Shield type exposes the following members.

Fields

	Name	Description
	I2CBus	Shared I^2C bus that is common to all sockets on this shield.

Top

See Also

Reference

Shield Class

IO.Objects.SimpleIO.mikroBUS Namespace

ShieldI2CBus Field

Shared I^2C bus that is common to all sockets on this shield.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static Bus I2CBus
```

Field Value

Type: Bus

See Also

Reference

Shield Class
IO.Objects.SimpleIO.mikroBUS Namespace

ShieldKinds Enumeration

Supported mikroBUS shields.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public enum Kinds
```

Members

Member name	Value	Description
BeagleBoneClick2	0	Mikroelektronika BeagleBone Click Shield MIKROE-1596, with two mikroBUS sockets. (Obsolete, but still useful.)
BeagleBoneClick4	1	Mikroelektronika mikroBUS Cape MIKROE-1857 with four mikroBUS sockets.

	PiClick1	2	Mikroelektronika Pi Click Shield MIKROE-1512/1513 for 26-pin expansion header, with one mikroBUS socket (Obsolete.)
	PiClick2	3	Mikroelektronika Pi 2 Click Shield MIKROE-1879 for 40-pin expansion header, with two mikroBUS sockets.
	PiClick3	4	Mikroelektronika Pi 3 Click Shield MIKROE-2756 for 40-pin expansion header, with selectable on-board A/D converter and two mikroBUS sockets.
	PocketBeagle	5	PocketBeagle with female headers on top, with two

		mikroBUS sockets.
Unknown	2147483647	No known mikroBUS shield installed.

See Also

Reference

IO.Objects.SimpleIO.mikroBUS Namespace

Socket Class

Encapsulates mikroBUS sockets.

Inheritance Hierarchy

SystemObject IO.Objects.SimpleIO.mikroBUSSocket

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Socket
```

The Socket type exposes the following members.

Constructors

	Name	Description
	Socket	Constructor for a single mikroBUS socket.

Top

Properties

	Name	Description
	AIN	Returns the ADC input designator for AN.

	AN	Returns the GPIO pin designator for AN.
	CS	Returns the GPIO pin designator for CS.
	I2CBus	Returns the I^2C bus designator for this socket.
	INT	Returns the GPIO pin designator for INT.
	MISO	Returns the GPIO pin designator for MISO.
	MOSI	Returns the GPIO pin designator for MOSI.
	PWM	Returns the GPIO pin designator for PWM.
	PWMOut	Returns the PWM output designator for this socket.
	RST	Returns the GPIO pin designator for RST.
	RX	Returns the GPIO pin designator for RX.
	SCK	Returns the GPIO pin designator for SCK.
	SCL	Returns the GPIO pin designator for SCL.
	SDA	Returns the GPIO pin designator for SDA.
	SPIDev	Returns the SPI device designator for

		this socket.
	TX	Returns the GPIO pin designator for TX.
	UART	Returns the UART device name for this socket.

Top

See Also

Reference

IO.Objects.SimpleIO.mikroBUS Namespace

Socket Constructor

Constructor for a single mikroBUS socket.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Socket(
        int num,
        ShieldKinds shield = ShieldKinds.Unknown
)
```

Parameters

num
Type: SystemInt32
Socket number.

shield **(Optional)**
Type: IO.Objects.SimpleIO.mikroBUSShieldKinds
mikroBUS shield kind. `Shield.Kinds.Unknown` indicates automatic detection using using the `Shield.kind` property.

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

Socket Properties

The Socket type exposes the following members.

Properties

	Name	Description
	AIN	Returns the ADC input designator for AN.
	AN	Returns the GPIO pin designator for AN.
	CS	Returns the GPIO pin designator for CS.
	I2CBus	Returns the I^2C bus designator for this socket.
	INT	Returns the GPIO pin designator for INT.
	MISO	Returns the GPIO pin designator for MISO.
	MOSI	Returns the GPIO pin designator for MOSI.
	PWM	Returns the GPIO pin designator for PWM.
	PWMOut	Returns the PWM output designator for this socket.

	RST	Returns the GPIO pin designator for RST.
	RX	Returns the GPIO pin designator for RX.
	SCK	Returns the GPIO pin designator for SCK.
	SCL	Returns the GPIO pin designator for SCL.
	SDA	Returns the GPIO pin designator for SDA.
	SPIDev	Returns the SPI device designator for this socket.
	TX	Returns the GPIO pin designator for TX.
	UART	Returns the UART device name for this socket.

Top

See Also

Reference

Socket Class

IO.Objects.SimpleIO.mikroBUS Namespace

SocketAIN Property

Returns the ADC input designator for AN.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Designator AIN { get; }
```

Property Value

Type: Designator

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

SocketAN Property

Returns the GPIO pin designator for AN.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Designator AN { get; }
```

Property Value

Type: Designator

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

SocketCS Property

Returns the GPIO pin designator for CS.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Designator CS { get; }
```

Property Value

Type: Designator

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

SocketI2CBus Property

Returns the I^{2}C bus designator for this socket.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Designator I2CBus { get; }
```

Property Value

Type: Designator

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

SocketINT Property

Returns the GPIO pin designator for INT.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Designator INT { get; }
```

Property Value

Type: Designator

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

SocketMISO Property

Returns the GPIO pin designator for MISO.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Designator MISO { get; }
```

Property Value

Type: Designator

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

SocketMOSI Property

Returns the GPIO pin designator for MOSI.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Designator MOSI { get; }
```

Property Value

Type: Designator

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

SocketPWM Property

Returns the GPIO pin designator for PWM.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Designator PWM { get; }
```

Property Value

Type: Designator

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

SocketPWMOut Property

Returns the PWM output designator for this socket.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Designator PWMOut { get; }
```

Property Value

Type: Designator

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

SocketRST Property

Returns the GPIO pin designator for RST.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Designator RST { get; }
```

Property Value

Type: Designator

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

SocketRX Property

Returns the GPIO pin designator for RX.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Designator RX { get; }
```

Property Value

Type: Designator

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

SocketSCK Property

Returns the GPIO pin designator for SCK.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Designator SCK { get; }
```

Property Value

Type: Designator

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

SocketSCL Property

Returns the GPIO pin designator for SCL.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Designator SCL { get; }
```

Property Value

Type: Designator

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

SocketSDA Property

Returns the GPIO pin designator for SDA.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Designator SDA { get; }
```

Property Value

Type: Designator

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

SocketSPIDev Property

Returns the SPI device designator for this socket.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Designator SPIDev { get; }
```

Property Value

Type: Designator

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

SocketTX Property

Returns the GPIO pin designator for TX.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public Designator TX { get; }
```

Property Value

Type: Designator

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

SocketUART Property

Returns the UART device name for this socket.

Namespace: IO.Objects.SimpleIO.mikroBUS
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public string UART { get; }
```

Property Value

Type: String

See Also

Reference

Socket Class
IO.Objects.SimpleIO.mikroBUS Namespace

IO.Objects.SimpleIO.Platforms Namespace

Platform Definition Classes

Classes

	Class	Description
	BeagleBone	This class defines identifiers for the devices provided by the BeagleBone hardware platform.
	MUNTS_0018	This class provides `Designator`s for I/O resources available on the MUNTS-0018 Tutorial I/O Board.
	PocketBeagle	This class defines identifiers for the devices provided by the PocketBeagle hardware platform.
	RaspberryPi	This class defines identifiers for the devices provided by the Raspberry Pi hardware platform.

BeagleBone Class

This class defines identifiers for the devices provided by the BeagleBone hardware platform.

Inheritance Hierarchy

SystemObject IO.Objects.SimpleIO.PlatformsBeagleBone

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static class BeagleBone
```

The BeagleBone type exposes the following members.

Fields

	Name	Description
s	AIN0	ADC input designator for P9.39 (1.8V)
s	AIN1	ADC input designator for P9.40 (1.8V)
s	AIN2	ADC input designator for P9.37 (1.8V)
s	AIN3	ADC input designator for P9.38 (1.8V)
s	AIN4	ADC input designator for P9.33 (1.8V)

S	AIN5	ADC input designator for P9.36 (1.8V)
S	AIN6	ADC input designator for P9.35 (1.8V)
S	GPIO10	Legacy GPIO pin designator for P8.31
S	GPIO11	Legacy GPIO pin designator for P8.32
S	GPIO110	Legacy GPIO pin designator for P9.31
S	GPIO111	Legacy GPIO pin designator for P9.29
S	GPIO112	Legacy GPIO pin designator for P9.30
S	GPIO113	Legacy GPIO pin designator for P9.28
S	GPIO115	Legacy GPIO pin designator for P9.27
S	GPIO117	Legacy GPIO pin designator for P9.25
S	GPIO12	Legacy GPIO pin designator for P9.20
S	GPIO13	Legacy GPIO pin designator for P9.19
S	GPIO14	Legacy GPIO pin designator for P9.26
S	GPIO15	Legacy GPIO pin designator for P9.24
S	GPIO2	Legacy GPIO pin designator for P9.22
S	GPIO20	Legacy GPIO pin designator for P9.41
S	GPIO22	Legacy GPIO pin designator for P8.19
S	GPIO23	Legacy GPIO pin designator for P8.13
S	GPIO26	Legacy GPIO pin designator for P8.14

S	GPIO27	Legacy GPIO pin designator for P8.17
S	GPIO3	Legacy GPIO pin designator for P9.21
S	GPIO30	Legacy GPIO pin designator for P9.11
S	GPIO31	Legacy GPIO pin designator for P9.13
S	GPIO32	Legacy GPIO pin designator for P8.25
S	GPIO33	Legacy GPIO pin designator for P8.24
S	GPIO34	Legacy GPIO pin designator for P8.5
S	GPIO35	Legacy GPIO pin designator for P8.6
S	GPIO36	Legacy GPIO pin designator for P8.23
S	GPIO37	Legacy GPIO pin designator for P8.22
S	GPIO38	Legacy GPIO pin designator for P8.3
S	GPIO39	Legacy GPIO pin designator for P8.4
S	GPIO4	Legacy GPIO pin designator for P9.18
S	GPIO44	Legacy GPIO pin designator for P8.12
S	GPIO45	Legacy GPIO pin designator for P8.11
S	GPIO46	Legacy GPIO pin designator for P8.16
S	GPIO47	Legacy GPIO pin designator for P8.15
S	GPIO48	Legacy GPIO pin designator for P9.15
S	GPIO49	Legacy GPIO pin designator for P9.23

S	GPIO5	Legacy GPIO pin designator for P9.17
S	GPIO50	Legacy GPIO pin designator for P9.14
S	GPIO51	Legacy GPIO pin designator for P9.16
S	GPIO60	Legacy GPIO pin designator for P9.12
S	GPIO61	Legacy GPIO pin designator for P8.26
S	GPIO62	Legacy GPIO pin designator for P8.21
S	GPIO63	Legacy GPIO pin designator for P8.20
S	GPIO65	Legacy GPIO pin designator for P8.18
S	GPIO66	Legacy GPIO pin designator for P8.7
S	GPIO67	Legacy GPIO pin designator for P8.8
S	GPIO68	Legacy GPIO pin designator for P8.10
S	GPIO69	Legacy GPIO pin designator for P8.9
S	GPIO7	Legacy GPIO pin designator for P9.42
S	GPIO70	Legacy GPIO pin designator for P8.45
S	GPIO71	Legacy GPIO pin designator for P8.46
S	GPIO72	Legacy GPIO pin designator for P8.43
S	GPIO73	Legacy GPIO pin designator for P8.44
S	GPIO74	Legacy GPIO pin designator for P8.41
S	GPIO75	Legacy GPIO pin designator for P8.42

S	GPIO76	Legacy GPIO pin designator for P8.39
S	GPIO77	Legacy GPIO pin designator for P8.40
S	GPIO78	Legacy GPIO pin designator for P8.37
S	GPIO79	Legacy GPIO pin designator for P8.38
S	GPIO8	Legacy GPIO pin designator for P8.35
S	GPIO80	Legacy GPIO pin designator for P8.36
S	GPIO81	Legacy GPIO pin designator for P8.34
S	GPIO86	Legacy GPIO pin designator for P8.27
S	GPIO87	Legacy GPIO pin designator for P8.29
S	GPIO88	Legacy GPIO pin designator for P8.28
S	GPIO89	Legacy GPIO pin designator for P8.30
S	GPIO9	Legacy GPIO pin designator for P8.33
S	I2C2	I2C bus designator for P9.19 and P9.20
S	SPI2_0	SPI slave select designator for P9.28
S	SPI2_1	SPI slave select designator for P9.42

Top

See Also

Reference

IO.Objects.SimpleIO.Platforms Namespace

BeagleBone Fields

The BeagleBone type exposes the following members.

Fields

	Name	Description
S	AIN0	ADC input designator for P9.39 (1.8V)
S	AIN1	ADC input designator for P9.40 (1.8V)
S	AIN2	ADC input designator for P9.37 (1.8V)
S	AIN3	ADC input designator for P9.38 (1.8V)
S	AIN4	ADC input designator for P9.33 (1.8V)
S	AIN5	ADC input designator for P9.36 (1.8V)
S	AIN6	ADC input designator for P9.35 (1.8V)
S	GPIO10	Legacy GPIO pin designator for P8.31
S	GPIO11	Legacy GPIO pin designator for P8.32
S	GPIO110	Legacy GPIO pin designator for P9.31
S	GPIO111	Legacy GPIO pin designator for P9.29
S	GPIO112	Legacy GPIO pin designator for P9.30
S	GPIO113	Legacy GPIO pin designator for P9.28

S	GPIO115	Legacy GPIO pin designator for P9.27
S	GPIO117	Legacy GPIO pin designator for P9.25
S	GPIO12	Legacy GPIO pin designator for P9.20
S	GPIO13	Legacy GPIO pin designator for P9.19
S	GPIO14	Legacy GPIO pin designator for P9.26
S	GPIO15	Legacy GPIO pin designator for P9.24
S	GPIO2	Legacy GPIO pin designator for P9.22
S	GPIO20	Legacy GPIO pin designator for P9.41
S	GPIO22	Legacy GPIO pin designator for P8.19
S	GPIO23	Legacy GPIO pin designator for P8.13
S	GPIO26	Legacy GPIO pin designator for P8.14
S	GPIO27	Legacy GPIO pin designator for P8.17
S	GPIO3	Legacy GPIO pin designator for P9.21
S	GPIO30	Legacy GPIO pin designator for P9.11
S	GPIO31	Legacy GPIO pin designator for P9.13
S	GPIO32	Legacy GPIO pin designator for P8.25
S	GPIO33	Legacy GPIO pin designator for P8.24
S	GPIO34	Legacy GPIO pin designator for P8.5
S	GPIO35	Legacy GPIO pin designator for P8.6

s	GPIO36	Legacy GPIO pin designator for P8.23
s	GPIO37	Legacy GPIO pin designator for P8.22
s	GPIO38	Legacy GPIO pin designator for P8.3
s	GPIO39	Legacy GPIO pin designator for P8.4
s	GPIO4	Legacy GPIO pin designator for P9.18
s	GPIO44	Legacy GPIO pin designator for P8.12
s	GPIO45	Legacy GPIO pin designator for P8.11
s	GPIO46	Legacy GPIO pin designator for P8.16
s	GPIO47	Legacy GPIO pin designator for P8.15
s	GPIO48	Legacy GPIO pin designator for P9.15
s	GPIO49	Legacy GPIO pin designator for P9.23
s	GPIO5	Legacy GPIO pin designator for P9.17
s	GPIO50	Legacy GPIO pin designator for P9.14
s	GPIO51	Legacy GPIO pin designator for P9.16
s	GPIO60	Legacy GPIO pin designator for P9.12
s	GPIO61	Legacy GPIO pin designator for P8.26
s	GPIO62	Legacy GPIO pin designator for P8.21
s	GPIO63	Legacy GPIO pin designator for P8.20
s	GPIO65	Legacy GPIO pin designator for P8.18

S	GPIO66	Legacy GPIO pin designator for P8.7
S	GPIO67	Legacy GPIO pin designator for P8.8
S	GPIO68	Legacy GPIO pin designator for P8.10
S	GPIO69	Legacy GPIO pin designator for P8.9
S	GPIO7	Legacy GPIO pin designator for P9.42
S	GPIO70	Legacy GPIO pin designator for P8.45
S	GPIO71	Legacy GPIO pin designator for P8.46
S	GPIO72	Legacy GPIO pin designator for P8.43
S	GPIO73	Legacy GPIO pin designator for P8.44
S	GPIO74	Legacy GPIO pin designator for P8.41
S	GPIO75	Legacy GPIO pin designator for P8.42
S	GPIO76	Legacy GPIO pin designator for P8.39
S	GPIO77	Legacy GPIO pin designator for P8.40
S	GPIO78	Legacy GPIO pin designator for P8.37
S	GPIO79	Legacy GPIO pin designator for P8.38
S	GPIO8	Legacy GPIO pin designator for P8.35
S	GPIO80	Legacy GPIO pin designator for P8.36
S	GPIO81	Legacy GPIO pin designator for P8.34
S	GPIO86	Legacy GPIO pin designator for P8.27

S	GPIO87	Legacy GPIO pin designator for P8.29
S	GPIO88	Legacy GPIO pin designator for P8.28
S	GPIO89	Legacy GPIO pin designator for P8.30
S	GPIO9	Legacy GPIO pin designator for P8.33
S	I2C2	I2C bus designator for P9.19 and P9.20
S	SPI2_0	SPI slave select designator for P9.28
S	SPI2_1	SPI slave select designator for P9.42

Top

See Also

Reference

BeagleBone Class

IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneAIN0 Field

ADC input designator for P9.39 (1.8V)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator AIN0
```

Field Value

Type: Designator

Remarks

Requires the `BB-ADC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneAIN1 Field

ADC input designator for P9.40 (1.8V)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator AIN1
```

Field Value

Type: Designator

Remarks

Requires the `BB-ADC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneAIN2 Field

ADC input designator for P9.37 (1.8V)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator AIN2
```

Field Value

Type: Designator

Remarks

Requires the `BB-ADC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneAIN3 Field

ADC input designator for P9.38 (1.8V)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator AIN3
```

Field Value

Type: Designator

Remarks

Requires the `BB-ADC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneAIN4 Field

ADC input designator for P9.33 (1.8V)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator AIN4
```

Field Value

Type: Designator

Remarks

Requires the `BB-ADC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneAIN5 Field

ADC input designator for P9.36 (1.8V)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator AIN5
```

Field Value

Type: Designator

Remarks

Requires the `BB-ADC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneAIN6 Field

ADC input designator for P9.35 (1.8V)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator AIN6
```

Field Value

Type: Designator

Remarks

Requires the `BB-ADC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO10 Field

Legacy GPIO pin designator for P8.31

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO10
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO11 Field

Legacy GPIO pin designator for P8.32

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO11
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO110 Field

Legacy GPIO pin designator for P9.31

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO110
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO111 Field

Legacy GPIO pin designator for P9.29

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO111
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO112 Field

Legacy GPIO pin designator for P9.30

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO112
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO113 Field

Legacy GPIO pin designator for P9.28

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO113
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO115 Field

Legacy GPIO pin designator for P9.27

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO115
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO117 Field

Legacy GPIO pin designator for P9.25

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO117
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO12 Field

Legacy GPIO pin designator for P9.20

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO12
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO13 Field

Legacy GPIO pin designator for P9.19

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO13
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO14 Field

Legacy GPIO pin designator for P9.26

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static readonly Designator GPIO14
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO15 Field

Legacy GPIO pin designator for P9.24

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO15
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO2 Field

Legacy GPIO pin designator for P9.22

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO2
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO20 Field

Legacy GPIO pin designator for P9.41

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO20
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO22 Field

Legacy GPIO pin designator for P8.19

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO22
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO23 Field

Legacy GPIO pin designator for P8.13

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO23
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO26 Field

Legacy GPIO pin designator for P8.14

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO26
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO27 Field

Legacy GPIO pin designator for P8.17

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO27
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO3 Field

Legacy GPIO pin designator for P9.21

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO3
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO30 Field

Legacy GPIO pin designator for P9.11

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO30
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO31 Field

Legacy GPIO pin designator for P9.13

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO31
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO32 Field

Legacy GPIO pin designator for P8.25

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO32
```

Field Value

Type: Designator

Remarks

Requires the BeagleBone White and the `BB-NOEMMC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO33 Field

Legacy GPIO pin designator for P8.24

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO33
```

Field Value

Type: Designator

Remarks

Requires the BeagleBone White and the `BB-NOEMMC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO34 Field

Legacy GPIO pin designator for P8.5

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO34
```

Field Value

Type: Designator

Remarks

Requires the BeagleBone White and the `BB-NOEMMC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO35 Field

Legacy GPIO pin designator for P8.6

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO35
```

Field Value

Type: Designator

Remarks

Requires the BeagleBone White and the `BB-NOEMMC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO36 Field

Legacy GPIO pin designator for P8.23

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO36
```

Field Value

Type: Designator

Remarks

Requires the BeagleBone White and the `BB-NOEMMC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO37 Field

Legacy GPIO pin designator for P8.22

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO37
```

Field Value

Type: Designator

Remarks

Requires the BeagleBone White and the `BB-NOEMMC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO38 Field

Legacy GPIO pin designator for P8.3

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO38
```

Field Value

Type: Designator

Remarks

Requires the BeagleBone White and the `BB-NOEMMC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO39 Field

Legacy GPIO pin designator for P8.4

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO39
```

Field Value

Type: Designator

Remarks

Requires the BeagleBone White and the `BB-NOEMMC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO4 Field

Legacy GPIO pin designator for P9.18

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO4
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO44 Field

Legacy GPIO pin designator for P8.12

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO44
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO45 Field

Legacy GPIO pin designator for P8.11

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO45
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO46 Field

Legacy GPIO pin designator for P8.16

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO46
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO47 Field

Legacy GPIO pin designator for P8.15

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO47
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO48 Field

Legacy GPIO pin designator for P9.15

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO48
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO49 Field

Legacy GPIO pin designator for P9.23

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO49
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO5 Field

Legacy GPIO pin designator for P9.17

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO5
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO50 Field

Legacy GPIO pin designator for P9.14

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO50
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO51 Field

Legacy GPIO pin designator for P9.16

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO51
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO60 Field

Legacy GPIO pin designator for P9.12

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO60
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO61 Field

Legacy GPIO pin designator for P8.26

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO61
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO62 Field

Legacy GPIO pin designator for P8.21

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO62
```

Field Value

Type: Designator

Remarks

Requires the BeagleBone White and the `BB-NOEMMC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO63 Field

Legacy GPIO pin designator for P8.20

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO63
```

Field Value

Type: Designator

Remarks

Requires the BeagleBone White and the `BB-NOEMMC` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO65 Field

Legacy GPIO pin designator for P8.18

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO65
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO66 Field

Legacy GPIO pin designator for P8.7

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO66
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO67 Field

Legacy GPIO pin designator for P8.8

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO67
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO68 Field

Legacy GPIO pin designator for P8.10

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO68
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO69 Field

Legacy GPIO pin designator for P8.9

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO69
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO7 Field

Legacy GPIO pin designator for P9.42

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO7
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO70 Field

Legacy GPIO pin designator for P8.45

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO70
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO71 Field

Legacy GPIO pin designator for P8.46

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO71
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO72 Field

Legacy GPIO pin designator for P8.43

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO72
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO73 Field

Legacy GPIO pin designator for P8.44

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO73
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO74 Field

Legacy GPIO pin designator for P8.41

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO74
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO75 Field

Legacy GPIO pin designator for P8.42

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static readonly Designator GPIO75
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO76 Field

Legacy GPIO pin designator for P8.39

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO76
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO77 Field

Legacy GPIO pin designator for P8.40

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO77
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO78 Field

Legacy GPIO pin designator for P8.37

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO78
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO79 Field

Legacy GPIO pin designator for P8.38

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO79
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO8 Field

Legacy GPIO pin designator for P8.35

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO8
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO80 Field

Legacy GPIO pin designator for P8.36

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO80
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO81 Field

Legacy GPIO pin designator for P8.34

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO81
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO86 Field

Legacy GPIO pin designator for P8.27

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO86
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO87 Field

Legacy GPIO pin designator for P8.29

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO87
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO88 Field

Legacy GPIO pin designator for P8.28

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO88
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO89 Field

Legacy GPIO pin designator for P8.30

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO89
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneGPIO9 Field

Legacy GPIO pin designator for P8.33

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO9
```

Field Value

Type: Designator

Remarks

Requires the `BB-GPIO` device tree overlay.

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneI2C2 Field

I2C bus designator for P9.19 and P9.20

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator I2C2
```

Field Value

Type: Designator

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneSPI2_0 Field

SPI slave select designator for P9.28

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator SPI2_0
```

Field Value

Type: Designator

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

BeagleBoneSPI2_1 Field

SPI slave select designator for P9.42

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator SPI2_1
```

Field Value

Type: Designator

See Also

Reference

BeagleBone Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018 Class

This class provides `Designator`s for I/O resources available on the MUNTS-0018 Tutorial I/O Board.

Inheritance Hierarchy

SystemObject IO.Objects.SimpleIO.PlatformsMUNTS_0018

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static class MUNTS_0018
```

The MUNTS_0018 type exposes the following members.

Fields

	Name	Description
	D1	GPIO pin `Designator` for the on-board LED `D1`.
	J10A0	Analog input `Designator` for Analog Input Grove Connector `J10` pin `A0` (MCP3204 input `CH2`.
	J10A1	Analog input `Designator` for Analog Input Grove Connector `J10` pin `A1`

		(MCP3204 input `CH3`.
s	J11A0	Analog input `Designator` for Analog Input Grove Connector `J11` pin `A0` (MCP3204 input `CH0`.
s	J11A1	Analog input `Designator` for Analog Input Grove Connector `J11` pin `A1` (MCP3204 input `CH1`.
s	J2PWM	PWM output `Designator` for Servo Header `J2`.
s	J3PWM	PWM output `Designator` for Servo Header `J3`.
s	J4D0	GPIO pin `Designator` for Digital I/O Grove Connector `J4` pin `D0`.
s	J4D1	GPIO pin `Designator` for Digital I/O Grove Connector `J4` pin `D1`.
s	J5D0	GPIO pin `Designator` for Digital I/O Grove Connector `J5` pin `D0`.
s	J5D1	GPIO pin `Designator` for Digital I/O Grove Connector `J5` pin `D1`.
s	J5I2C	I^2C bus `Designator` for `/dev/i2c3` on Digital I/O Grove Connector `J5`.
s	J6D0	GPIO pin `Designator` for DC Motor Driver Grove Connector `J6` pin `D0`.
s	J6D1	GPIO pin `Designator` for DC Motor Driver Grove Connector `J6` pin `D1`.

S	J6DIR	GPIO pin `Designator` for DC Motor Driver Grove Connector `J6` pin `D1`.
S	J6PWM	PWM output `Designator` for DC Motor Driver Grove Connector `J6` pin `D0`.
S	J7D0	GPIO pin `Designator` for DC Motor Driver Grove Connector `J7` pin `D0`.
S	J7D1	GPIO pin `Designator` for DC Motor Driver Grove Connector `J7` pin `D1`.
S	J7DIR	GPIO pin `Designator` for DC Motor Driver Grove Connector `J7` pin `D1`.
S	J7PWM	PWM output `Designator` for DC Motor Driver Grove Connector `J7` pin `D0`.
S	J9I2C	I^2C bus `Designator` for `/dev/i2c-1` on I^2C Grove Connector `J9`.
S	SW1	GPIO pin `Designator` for the on-board momentary switch `SW1`.

Top

Remarks

The following device tree overlay commands must be added to `/boot/config.txt`:

Copy

```
dtoverlay=anyspi,spi0-1,dev="microchip,mcp3204",speed=
dtoverlay=pwm-2chan,pin=12,func=4,pin2=19,func2=2
```

See Also

Reference

IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018 Fields

The MUNTS_0018 type exposes the following members.

Fields

	Name	Description
S	D1	GPIO pin `Designator` for the on-board LED `D1`.
S	J10A0	Analog input `Designator` for Analog Input Grove Connector `J10` pin `A0` (MCP3204 input `CH2`.
S	J10A1	Analog input `Designator` for Analog Input Grove Connector `J10` pin `A1` (MCP3204 input `CH3`.
S	J11A0	Analog input `Designator` for Analog Input Grove Connector `J11` pin `A0` (MCP3204 input `CH0`.
S	J11A1	Analog input `Designator` for Analog Input Grove Connector `J11` pin `A1` (MCP3204 input `CH1`.
S	J2PWM	PWM output `Designator` for Servo Header `J2`.
S	J3PWM	PWM output `Designator` for Servo Header `J3`.

S	J4D0	GPIO pin `Designator` for Digital I/O Grove Connector `J4` pin `D0`.
S	J4D1	GPIO pin `Designator` for Digital I/O Grove Connector `J4` pin `D1`.
S	J5D0	GPIO pin `Designator` for Digital I/O Grove Connector `J5` pin `D0`.
S	J5D1	GPIO pin `Designator` for Digital I/O Grove Connector `J5` pin `D1`.
S	J5I2C	I^2C bus `Designator` for `/dev/i2c3` on Digital I/O Grove Connector `J5`.
S	J6D0	GPIO pin `Designator` for DC Motor Driver Grove Connector `J6` pin `D0`.
S	J6D1	GPIO pin `Designator` for DC Motor Driver Grove Connector `J6` pin `D1`.
S	J6DIR	GPIO pin `Designator` for DC Motor Driver Grove Connector `J6` pin `D1`.
S	J6PWM	PWM output `Designator` for DC Motor Driver Grove Connector `J6` pin `D0`.
S	J7D0	GPIO pin `Designator` for DC Motor Driver Grove Connector `J7` pin `D0`.
S	J7D1	GPIO pin `Designator` for DC Motor Driver Grove Connector `J7` pin `D1`.
S	J7DIR	GPIO pin `Designator` for DC Motor Driver Grove Connector `J7` pin `D1`.

	J7PWM	PWM output `Designator` for DC Motor Driver Grove Connector `J7` pin `D0`.
	J9I2C	I^2C bus `Designator` for `/dev/i2c-1` on I^2C Grove Connector `J9`.
	SW1	GPIO pin `Designator` for the on-board momentary switch `SW1`.

Top

See Also

Reference

MUNTS_0018 Class

IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018D1 Field

GPIO pin `Designator` for the on-board LED `D1`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator D1
```

Field Value

Type: Designator

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J10A0 Field

Analog input `Designator` for Analog Input Grove Connector `J10` pin `A0` (MCP3204 input `CH2`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J10A0
```

Field Value

Type: Designator

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J10A1 Field

Analog input `Designator` for Analog Input Grove Connector `J10` pin `A1` (MCP3204 input `CH3`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J10A1
```

Field Value

Type: Designator

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J11A0 Field

Analog input `Designator` for Analog Input Grove Connector `J11` pin `A0` (MCP3204 input `CH0`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J11A0
```

Field Value

Type: Designator

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J11A1 Field

Analog input `Designator` for Analog Input Grove Connector `J11` pin `A1` (MCP3204 input `CH1`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J11A1
```

Field Value

Type: Designator

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J2PWM Field

PWM output `Designator` for Servo Header `J2`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J2PWM
```

Field Value

Type: Designator

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J3PWM Field

PWM output `Designator` for Servo Header `J3`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J3PWM
```

Field Value

Type: Designator

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J4D0 Field

GPIO pin `Designator` for Digital I/O Grove Connector `J4` pin `D0`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J4D0
```

Field Value

Type: Designator

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J4D1 Field

GPIO pin `Designator` for Digital I/O Grove Connector `J4` pin `D1`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J4D1
```

Field Value

Type: Designator

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J5D0 Field

GPIO pin `Designator` for Digital I/O Grove Connector `J5` pin `D0`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J5D0
```

Field Value

Type: Designator

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J5D1 Field

GPIO pin `Designator` for Digital I/O Grove Connector `J5` pin `D1`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J5D1
```

Field Value

Type: Designator

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J5I2C Field

I²C bus `Designator` for `/dev/i2c3` on Digital I/O Grove Connector `J5`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J5I2C
```

Field Value

Type: Designator

Remarks

This optional I²C bus is only available on a Raspberry Pi 4, and only if the following is added to `/boot/config.txt`:

Copy

```
dtoverlay=i2c3
```

You may also need to install I²C bus 4.7K or 10K pull-up resistors on the MUNTS-0018 Tutorial I/O Board, at positions `R5` and `R6`.

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J6D0 Field

GPIO pin `Designator` for DC Motor Driver Grove Connector `J6` pin `D0`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J6D0
```

Field Value

Type: Designator

Remarks

This GPIO pin is normally unusable because `GPIO12` is mapped to PWM output `PWM0`.

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J6D1 Field

GPIO pin `Designator` for DC Motor Driver Grove Connector `J6` pin `D1`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J6D1
```

Field Value

Type: Designator

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J6DIR Field

GPIO pin `Designator` for DC Motor Driver Grove Connector `J6` pin `D1`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J6DIR
```

Field Value

Type: Designator

Remarks

`J6DIR` controls the motor **direction**.

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J6PWM Field

PWM output `Designator` for DC Motor Driver Grove Connector `J6` pin `D0`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static readonly Designator J6PWM
```

Field Value

Type: Designator

Remarks

`J6PWM` controls the motor **speed**.

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J7D0 Field

GPIO pin `Designator` for DC Motor Driver Grove Connector `J7` pin `D0`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J7D0
```

Field Value

Type: Designator

Remarks

This GPIO pin is normally unusable because `GPIO19` is mapped to PWM output `PWM1`.

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J7D1 Field

GPIO pin `Designator` for DC Motor Driver Grove Connector `J7` pin `D1`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J7D1
```

Field Value

Type: Designator

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J7DIR Field

GPIO pin `Designator` for DC Motor Driver Grove Connector `J7` pin `D1`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J7DIR
```

Field Value

Type: Designator

Remarks

`J7DIR` controls the motor **direction**.

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J7PWM Field

PWM output `Designator` for DC Motor Driver Grove Connector `J7` pin `D0`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static readonly Designator J7PWM
```

Field Value

Type: Designator

Remarks

`J7PWM` controls the motor **speed**.

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018J9I2C Field

I²C bus `Designator` for `/dev/i2c-1` on I²C Grove Connector `J9`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator J9I2C
```

Field Value

Type: Designator

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

MUNTS_0018SW1 Field

GPIO pin `Designator` for the on-board momentary switch `SW1`.

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator SW1
```

Field Value

Type: Designator

See Also

Reference

MUNTS_0018 Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagle Class

This class defines identifiers for the devices provided by the PocketBeagle hardware platform.

Inheritance Hierarchy

SystemObject IO.Objects.SimpleIO.PlatformsPocketBeagle

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static class PocketBeagle
```

The PocketBeagle type exposes the following members.

Fields

	Name	Description
S	AIN0	ADC input designator for P1.19 (1.8V)
S	AIN1	ADC input designator for P1.21 (1.8V)
S	AIN2	ADC input designator for P1.23 (1.8V)
S	AIN3	ADC input designator for P1.25 (1.8V)
S	AIN4	ADC input designator for P1.27 (1.8V)

s	AIN5	ADC input designator for P2.35 (3.6V)
s	AIN6	ADC input designator for P1.2 (3.6V)
s	AIN7	ADC input designator for P2.36 (1.8V)
s	GPIO110	Legacy GPIO pin designator for P1.36
s	GPIO111	Legacy GPIO pin designator for P1.33
s	GPIO112	Legacy GPIO pin designator for P2.32
s	GPIO113	Legacy GPIO pin designator for P2.30
s	GPIO114	Legacy GPIO pin designator for P1.31
s	GPIO115	Legacy GPIO pin designator for P2.34
s	GPIO116	Legacy GPIO pin designator for P2.28
s	GPIO117	Legacy GPIO pin designator for P1.29
s	GPIO12	Legacy GPIO pin designator for P1.26
s	GPIO13	Legacy GPIO pin designator for P1.28
s	GPIO14	Legacy GPIO pin designator for P2.11
s	GPIO15	Legacy GPIO pin designator for P2.9
s	GPIO19	Legacy GPIO pin designator for P2.31
s	GPIO2	Legacy GPIO pin designator for P1.8
s	GPIO20	Legacy GPIO pin designator for P1.20
s	GPIO23	Legacy GPIO pin designator for P2.3

S	GPIO26	Legacy GPIO pin designator for P1.34
S	GPIO27	Legacy GPIO pin designator for P2.19
S	GPIO3	Legacy GPIO pin designator for P1.10
S	GPIO30	Legacy GPIO pin designator for P2.5
S	GPIO31	Legacy GPIO pin designator for P2.7
S	GPIO4	Legacy GPIO pin designator for P1.12
S	GPIO40	Legacy GPIO pin designator for P2.27
S	GPIO41	Legacy GPIO pin designator for P2.25
S	GPIO42	Legacy GPIO pin designator for P1.32
S	GPIO43	Legacy GPIO pin designator for P1.30
S	GPIO44	Legacy GPIO pin designator for P2.24
S	GPIO45	Legacy GPIO pin designator for P2.33
S	GPIO46	Legacy GPIO pin designator for P2.22
S	GPIO47	Legacy GPIO pin designator for P2.18
S	GPIO5	Legacy GPIO pin designator for P1.6
S	GPIO50	Legacy GPIO pin designator for P2.1
S	GPIO52	Legacy GPIO pin designator for P2.10
S	GPIO57	Legacy GPIO pin designator for P2.6
S	GPIO58	Legacy GPIO pin designator for P2.4

S	GPIO59	Legacy GPIO pin designator for P2.2
S	GPIO60	Legacy GPIO pin designator for P2.8
S	GPIO64	Legacy GPIO pin designator for P2.20
S	GPIO65	Legacy GPIO pin designator for P2.17
S	GPIO7	Legacy GPIO pin designator for P2.29
S	GPIO86	Legacy GPIO pin designator for P2.35
S	GPIO87	Legacy GPIO pin designator for P1.2
S	GPIO88	Legacy GPIO pin designator for P1.35
S	GPIO89	Legacy GPIO pin designator for P1.4
S	I2C1	I2C bus designator for P1.26 and P1.28
S	I2C2	I2C bus designator for P2.9 and P2.11
S	PWM0_0	PWM output designator for P1.36
S	PWM2_0	PWM output designator for P2.1
S	SPI0_0	SPI slave select designator for P1.6
S	SPI1_1	SPI slave select designator for P2.31

Top

See Also

Reference

IO.Objects.SimpleIO.Platforms Namespace

PocketBeagle Fields

The PocketBeagle type exposes the following members.

Fields

	Name	Description
s	AIN0	ADC input designator for P1.19 (1.8V)
s	AIN1	ADC input designator for P1.21 (1.8V)
s	AIN2	ADC input designator for P1.23 (1.8V)
s	AIN3	ADC input designator for P1.25 (1.8V)
s	AIN4	ADC input designator for P1.27 (1.8V)
s	AIN5	ADC input designator for P2.35 (3.6V)
s	AIN6	ADC input designator for P1.2 (3.6V)
s	AIN7	ADC input designator for P2.36 (1.8V)
s	GPIO110	Legacy GPIO pin designator for P1.36
s	GPIO111	Legacy GPIO pin designator for P1.33
s	GPIO112	Legacy GPIO pin designator for P2.32
s	GPIO113	Legacy GPIO pin designator for P2.30
s	GPIO114	Legacy GPIO pin designator for P1.31

S	GPIO115	Legacy GPIO pin designator for P2.34
S	GPIO116	Legacy GPIO pin designator for P2.28
S	GPIO117	Legacy GPIO pin designator for P1.29
S	GPIO12	Legacy GPIO pin designator for P1.26
S	GPIO13	Legacy GPIO pin designator for P1.28
S	GPIO14	Legacy GPIO pin designator for P2.11
S	GPIO15	Legacy GPIO pin designator for P2.9
S	GPIO19	Legacy GPIO pin designator for P2.31
S	GPIO2	Legacy GPIO pin designator for P1.8
S	GPIO20	Legacy GPIO pin designator for P1.20
S	GPIO23	Legacy GPIO pin designator for P2.3
S	GPIO26	Legacy GPIO pin designator for P1.34
S	GPIO27	Legacy GPIO pin designator for P2.19
S	GPIO3	Legacy GPIO pin designator for P1.10
S	GPIO30	Legacy GPIO pin designator for P2.5
S	GPIO31	Legacy GPIO pin designator for P2.7
S	GPIO4	Legacy GPIO pin designator for P1.12
S	GPIO40	Legacy GPIO pin designator for P2.27
S	GPIO41	Legacy GPIO pin designator for P2.25

S	GPIO42	Legacy GPIO pin designator for P1.32
S	GPIO43	Legacy GPIO pin designator for P1.30
S	GPIO44	Legacy GPIO pin designator for P2.24
S	GPIO45	Legacy GPIO pin designator for P2.33
S	GPIO46	Legacy GPIO pin designator for P2.22
S	GPIO47	Legacy GPIO pin designator for P2.18
S	GPIO5	Legacy GPIO pin designator for P1.6
S	GPIO50	Legacy GPIO pin designator for P2.1
S	GPIO52	Legacy GPIO pin designator for P2.10
S	GPIO57	Legacy GPIO pin designator for P2.6
S	GPIO58	Legacy GPIO pin designator for P2.4
S	GPIO59	Legacy GPIO pin designator for P2.2
S	GPIO60	Legacy GPIO pin designator for P2.8
S	GPIO64	Legacy GPIO pin designator for P2.20
S	GPIO65	Legacy GPIO pin designator for P2.17
S	GPIO7	Legacy GPIO pin designator for P2.29
S	GPIO86	Legacy GPIO pin designator for P2.35
S	GPIO87	Legacy GPIO pin designator for P1.2
S	GPIO88	Legacy GPIO pin designator for P1.35

S	GPIO89	Legacy GPIO pin designator for P1.4
S	I2C1	I2C bus designator for P1.26 and P1.28
S	I2C2	I2C bus designator for P2.9 and P2.11
S	PWM0_0	PWM output designator for P1.36
S	PWM2_0	PWM output designator for P2.1
S	SPI0_0	SPI slave select designator for P1.6
S	SPI1_1	SPI slave select designator for P2.31

Top

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleAIN0 Field

ADC input designator for P1.19 (1.8V)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator AIN0
```

Field Value

Type: Designator

Remarks

Requires the `PB-ADC` device tree overlay.

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleAIN1 Field

ADC input designator for P1.21 (1.8V)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator AIN1
```

Field Value

Type: Designator

Remarks

Requires the `PB-ADC` device tree overlay.

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleAIN2 Field

ADC input designator for P1.23 (1.8V)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator AIN2
```

Field Value

Type: Designator

Remarks

Requires the `PB-ADC` device tree overlay.

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleAIN3 Field

ADC input designator for P1.25 (1.8V)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator AIN3
```

Field Value

Type: Designator

Remarks

Requires the `PB-ADC` device tree overlay.

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleAIN4 Field

ADC input designator for P1.27 (1.8V)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator AIN4
```

Field Value

Type: Designator

Remarks

Requires the `PB-ADC` device tree overlay.

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleAIN5 Field

ADC input designator for P2.35 (3.6V)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator AIN5
```

Field Value

Type: Designator

Remarks

Requires the `PB-ADC` device tree overlay.

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleAIN6 Field

ADC input designator for P1.2 (3.6V)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator AIN6
```

Field Value

Type: Designator

Remarks

Requires the `PB-ADC` device tree overlay.

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleAIN7 Field

ADC input designator for P2.36 (1.8V)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator AIN7
```

Field Value

Type: Designator

Remarks

Requires the `PB-ADC` device tree overlay.

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO110 Field

Legacy GPIO pin designator for P1.36

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO110
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO111 Field

Legacy GPIO pin designator for P1.33

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO111
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO112 Field

Legacy GPIO pin designator for P2.32

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO112
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO113 Field

Legacy GPIO pin designator for P2.30

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO113
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO114 Field

Legacy GPIO pin designator for P1.31

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO114
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO115 Field

Legacy GPIO pin designator for P2.34

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO115
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO116 Field

Legacy GPIO pin designator for P2.28

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO116
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO117 Field

Legacy GPIO pin designator for P1.29

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO117
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO12 Field

Legacy GPIO pin designator for P1.26

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO12
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO13 Field

Legacy GPIO pin designator for P1.28

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO13
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO14 Field

Legacy GPIO pin designator for P2.11

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO14
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO15 Field

Legacy GPIO pin designator for P2.9

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO15
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO19 Field

Legacy GPIO pin designator for P2.31

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO19
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO2 Field

Legacy GPIO pin designator for P1.8

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO2
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO20 Field

Legacy GPIO pin designator for P1.20

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO20
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO23 Field

Legacy GPIO pin designator for P2.3

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO23
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO26 Field

Legacy GPIO pin designator for P1.34

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO26
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO27 Field

Legacy GPIO pin designator for P2.19

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO27
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO3 Field

Legacy GPIO pin designator for P1.10

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO3
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO30 Field

Legacy GPIO pin designator for P2.5

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO30
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO31 Field

Legacy GPIO pin designator for P2.7

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO31
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO4 Field

Legacy GPIO pin designator for P1.12

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO4
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO40 Field

Legacy GPIO pin designator for P2.27

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO40
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO41 Field

Legacy GPIO pin designator for P2.25

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO41
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO42 Field

Legacy GPIO pin designator for P1.32

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO42
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO43 Field

Legacy GPIO pin designator for P1.30

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO43
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO44 Field

Legacy GPIO pin designator for P2.24

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO44
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO45 Field

Legacy GPIO pin designator for P2.33

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO45
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO46 Field

Legacy GPIO pin designator for P2.22

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO46
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO47 Field

Legacy GPIO pin designator for P2.18

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO47
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO5 Field

Legacy GPIO pin designator for P1.6

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO5
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO50 Field

Legacy GPIO pin designator for P2.1

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO50
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO52 Field

Legacy GPIO pin designator for P2.10

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO52
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO57 Field

Legacy GPIO pin designator for P2.6

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO57
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO58 Field

Legacy GPIO pin designator for P2.4

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO58
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO59 Field

Legacy GPIO pin designator for P2.2

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO59
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO60 Field

Legacy GPIO pin designator for P2.8

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO60
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO64 Field

Legacy GPIO pin designator for P2.20

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO64
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO65 Field

Legacy GPIO pin designator for P2.17

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO65
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO7 Field

Legacy GPIO pin designator for P2.29

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO7
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO86 Field

Legacy GPIO pin designator for P2.35

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO86
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO87 Field

Legacy GPIO pin designator for P1.2

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO87
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO88 Field

Legacy GPIO pin designator for P1.35

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO88
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleGPIO89 Field

Legacy GPIO pin designator for P1.4

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO89
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleI2C1 Field

I2C bus designator for P1.26 and P1.28

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator I2C1
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleI2C2 Field

I2C bus designator for P2.9 and P2.11

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator I2C2
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeaglePWM0_0 Field

PWM output designator for P1.36

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator PWM0_0
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeaglePWM2_0 Field

PWM output designator for P2.1

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator PWM2_0
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleSPI0_0 Field

SPI slave select designator for P1.6

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator SPI0_0
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

PocketBeagleSPI1_1 Field

SPI slave select designator for P2.31

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator SPI1_1
```

Field Value

Type: Designator

See Also

Reference

PocketBeagle Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPi Class

This class defines identifiers for the devices provided by the Raspberry Pi hardware platform.

Inheritance Hierarchy

SystemObject IO.Objects.SimpleIO.PlatformsRaspberryPi

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static class RaspberryPi
```

The RaspberryPi type exposes the following members.

Fields

	Name	Description
s	AIN0	Analog input designator
s	AIN1	Analog input designator
s	GPIO10	GPIO pin designator
s	GPIO11	GPIO pin designator
s	GPIO12	GPIO pin designator

S	GPIO13	GPIO pin designator
S	GPIO14	GPIO pin designator
S	GPIO15	GPIO pin designator
S	GPIO16	GPIO pin designator
S	GPIO17	GPIO pin designator
S	GPIO18	GPIO pin designator
S	GPIO19	GPIO pin designator
S	GPIO2	GPIO pin designator
S	GPIO20	GPIO pin designator
S	GPIO21	GPIO pin designator
S	GPIO22	GPIO pin designator
S	GPIO23	GPIO pin designator
S	GPIO24	GPIO pin designator
S	GPIO25	GPIO pin designator
S	GPIO26	GPIO pin designator
S	GPIO27	GPIO pin designator
S	GPIO3	GPIO pin designator
S	GPIO4	GPIO pin designator
S	GPIO5	GPIO pin designator

S	GPIO6	GPIO pin designator
S	GPIO7	GPIO pin designator
S	GPIO8	GPIO pin designator
S	GPIO9	GPIO pin designator
S	I2C1	I2C bus designator for `/dev/i2c-1` on GPIO2 and GPIO3
S	I2C3	I2C bus designator for `/dev/i2c-3` (Raspberry Pi 4 only, with device tree overlay)
S	I2C4	I2C bus designator for `/dev/i2c-4` (Raspberry Pi 4 only, with device tree overlay)
S	I2C5	I2C bus designator for `/dev/i2c-5` (Raspberry Pi 4 only, with device tree overlay)
S	I2C6	I2C bus designator for `/dev/i2c-6` (Raspberry Pi 4 only, with device tree overlay)
S	PWM0_0	PWM output designator for GPIO18
S	PWM0_1	PWM output designator for GPIO19
S	SPI0_0	SPI slave select designator for GPIO8
S	SPI0_1	SPI slave select designator for GPIO7

Top

See Also

Reference

IO.Objects.SimpleIO.Platforms Namespace

RaspberryPi Fields

The RaspberryPi type exposes the following members.

Fields

	Name	Description
S	AIN0	Analog input designator
S	AIN1	Analog input designator
S	GPIO10	GPIO pin designator
S	GPIO11	GPIO pin designator
S	GPIO12	GPIO pin designator
S	GPIO13	GPIO pin designator
S	GPIO14	GPIO pin designator
S	GPIO15	GPIO pin designator
S	GPIO16	GPIO pin designator
S	GPIO17	GPIO pin designator
S	GPIO18	GPIO pin designator
S	GPIO19	GPIO pin designator
S	GPIO2	GPIO pin designator

S	GPIO20	GPIO pin designator
S	GPIO21	GPIO pin designator
S	GPIO22	GPIO pin designator
S	GPIO23	GPIO pin designator
S	GPIO24	GPIO pin designator
S	GPIO25	GPIO pin designator
S	GPIO26	GPIO pin designator
S	GPIO27	GPIO pin designator
S	GPIO3	GPIO pin designator
S	GPIO4	GPIO pin designator
S	GPIO5	GPIO pin designator
S	GPIO6	GPIO pin designator
S	GPIO7	GPIO pin designator
S	GPIO8	GPIO pin designator
S	GPIO9	GPIO pin designator
S	I2C1	I2C bus designator for `/dev/i2c-1` on GPIO2 and GPIO3
S	I2C3	I2C bus designator for `/dev/i2c-3` (Raspberry Pi 4 only, with device tree overlay)

S	I2C4	I2C bus designator for `/dev/i2c-4` (Raspberry Pi 4 only, with device tree overlay)
S	I2C5	I2C bus designator for `/dev/i2c-5` (Raspberry Pi 4 only, with device tree overlay)
S	I2C6	I2C bus designator for `/dev/i2c-6` (Raspberry Pi 4 only, with device tree overlay)
S	PWM0_0	PWM output designator for GPIO18
S	PWM0_1	PWM output designator for GPIO19
S	SPI0_0	SPI slave select designator for GPIO8
S	SPI0_1	SPI slave select designator for GPIO7

Top

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiAIN0 Field

Analog input designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static readonly Designator AIN0
```

Field Value

Type: Designator

Remarks

Requires the Mikroelektronika Pi 3 Click Shield and the `Pi3ClickShield` device tree overlay.

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiAIN1 Field

Analog input designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static readonly Designator AIN1
```

Field Value

Type: Designator

Remarks

Requires the Mikroelektronika Pi 3 Click Shield and the `Pi3ClickShield` device tree overlay.

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO10 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO10
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO11 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO11
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO12 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO12
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO13 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO13
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO14 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO14
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO15 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO15
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO16 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO16
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO17 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO17
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO18 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO18
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO19 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO19
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO2 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO2
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO20 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO20
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO21 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO21
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO22 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO22
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO23 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO23
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO24 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO24
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO25 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO25
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO26 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO26
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO27 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO27
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO3 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO3
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO4 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO4
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO5 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO5
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO6 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO6
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO7 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO7
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO8 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO8
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiGPIO9 Field

GPIO pin designator

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator GPIO9
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiI2C1 Field

I2C bus designator for `/dev/i2c-1` on GPIO2 and GPIO3

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator I2C1
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiI2C3 Field

I2C bus designator for `/dev/i2c-3` (Raspberry Pi 4 only, with device tree overlay)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator I2C3
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiI2C4 Field

I2C bus designator for `/dev/i2c-4` (Raspberry Pi 4 only, with device tree overlay)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator I2C4
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiI2C5 Field

I2C bus designator for `/dev/i2c-5` (Raspberry Pi 4 only, with device tree overlay)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator I2C5
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiI2C6 Field

I2C bus designator for `/dev/i2c-6` (Raspberry Pi 4 only, with device tree overlay)

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator I2C6
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiPWM0_0 Field

PWM output designator for GPIO18

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator PWM0_0
```

Field Value

Type: Designator

Remarks

Requires the `pwm` device tree overlay.

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiPWM0_1 Field

PWM output designator for GPIO19

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator PWM0_1
```

Field Value

Type: Designator

Remarks

Requires the `pwm` device tree overlay.

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiSPI0_0 Field

SPI slave select designator for GPIO8

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator SPI0_0
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

RaspberryPiSPI0_1 Field

SPI slave select designator for GPIO7

Namespace: IO.Objects.SimpleIO.Platforms
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public static readonly Designator SPI0_1
```

Field Value

Type: Designator

See Also

Reference

RaspberryPi Class
IO.Objects.SimpleIO.Platforms Namespace

IO.Objects.SimpleIO.PWM Namespace

PWM (Pulse Width Modulated) Output Services

Classes

	Class	Description
	Output	Encapsulates Linux PWM outputs using `libsimpleio`.

Output Class

Encapsulates Linux PWM outputs using `libsimpleio`.

Inheritance Hierarchy

SystemObject IO.Objects.SimpleIO.PWMOutput

Namespace: IO.Objects.SimpleIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Output : Output
```

The Output type exposes the following members.

Constructors

	Name	Description
	Output	Constructor for a single PWM output.

Top

Properties

	Name	Description
	dutycycle	Write-only property for setting the PWM output duty cycle. Allowed values

		are 0.0 to 100.0 percent.
	fd	Read-only property returning the Linux file descriptor for the PWM output.

Top

See Also

Reference

IO.Objects.SimpleIO.PWM Namespace

Output Constructor

Constructor for a single PWM output.

Namespace: IO.Objects.SimpleIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Output(
        Designator desg,
        int frequency,
        double dutycycle = 0,
        int polarity = 1
)
```

Parameters

desg
Type: IO.Objects.SimpleIO.DeviceDesignator
PWM output designator.

frequency
Type: SystemInt32
PWM pulse frequency.

dutycycle **(Optional)**
Type: SystemDouble
Initial PWM output duty cycle. Allowed values are 0.0 to 100.0 percent.

polarity **(Optional)**

Type: SystemInt32
PWM output polarity.

See Also

Reference

Output Class
IO.Objects.SimpleIO.PWM Namespace

Output Properties

The Output type exposes the following members.

Properties

	Name	Description
	dutycycle	Write-only property for setting the PWM output duty cycle. Allowed values are 0.0 to 100.0 percent.
	fd	Read-only property returning the Linux file descriptor for the PWM output.

Top

See Also

Reference

Output Class

IO.Objects.SimpleIO.PWM Namespace

Outputdutycycle Property

Write-only property for setting the PWM output duty cycle. Allowed values are 0.0 to 100.0 percent.

Namespace: IO.Objects.SimpleIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public double dutycycle { set; }
```

Property Value

Type: Double

Implements

Outputdutycycle

See Also

Reference

Output Class
IO.Objects.SimpleIO.PWM Namespace

Outputfd Property

Read-only property returning the Linux file descriptor for the PWM output.

Namespace: IO.Objects.SimpleIO.PWM
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int fd { get; }
```

Property Value

Type: Int32

See Also

Reference

Output Class
IO.Objects.SimpleIO.PWM Namespace

IO.Objects.SimpleIO.Servo Namespace

Servo Output Services

Classes

	Class	Description
	Output	Encapsulates Linux servo outputs using `libsimpleio`.

Output Class

Encapsulates Linux servo outputs using `libsimpleio`.

Inheritance Hierarchy

SystemObject IO.Objects.SimpleIO.ServoOutput

Namespace: IO.Objects.SimpleIO.Servo
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# **VB** **F#** Copy

```
public class Output : Output
```

The Output type exposes the following members.

Constructors

	Name	Description
	Output	Constructor for a single servo output.

Top

Properties

	Name	Description
	fd	Read-only property returning the Linux file descriptor for the servo output.

position	Write-only property for setting the servo position. Allowed values are -1.0 to +1.0.

Top

See Also

Reference

IO.Objects.SimpleIO.Servo Namespace

Output Constructor

Constructor for a single servo output.

Namespace: IO.Objects.SimpleIO.Servo
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Output(
        Designator desg,
        int frequency = 50,
        double position = 0
)
```

Parameters

desg
Type: IO.Objects.SimpleIO.DeviceDesignator
PWM output designator.

frequency **(Optional)**
Type: SystemInt32
PWM pulse frequency.

position **(Optional)**
Type: SystemDouble
Initial servo position.

See Also

Reference

Output Class

IO.Objects.SimpleIO.Servo Namespace

Output Properties

The Output type exposes the following members.

Properties

	Name	Description
	fd	Read-only property returning the Linux file descriptor for the servo output.
	position	Write-only property for setting the servo position. Allowed values are -1.0 to +1.0.

Top

See Also

Reference

Output Class

IO.Objects.SimpleIO.Servo Namespace

Outputfd Property

Read-only property returning the Linux file descriptor for the servo output.

Namespace: IO.Objects.SimpleIO.Servo
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public int fd { get; }
```

Property Value

Type: Int32

See Also

Reference

Output Class
IO.Objects.SimpleIO.Servo Namespace

Outputposition Property

Write-only property for setting the servo position. Allowed values are -1.0 to +1.0.

Namespace: IO.Objects.SimpleIO.Servo
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public double position { set; }
```

Property Value

Type: Double

Implements

Outputposition

See Also

Reference

Output Class
IO.Objects.SimpleIO.Servo Namespace

IO.Objects.SimpleIO.SPI Namespace

SPI (Serial Peripheral Interconnect) Device Services

Classes

	Class	Description
	Device	Encapsulates Linux SPI devices using `libsimpleio`.

Device Class

Encapsulates Linux SPI devices using `libsimpleio`.

Inheritance Hierarchy

SystemObject IO.Objects.SimpleIO.SPIDevice

Namespace: IO.Objects.SimpleIO.SPI
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Device : Device
```

The Device type exposes the following members.

Constructors

	Name	Description
	Device(Designator, Int32, Int32, Int32, Pin)	Constructor for a single SPI device.
	Device(String, Int32, Int32, Int32, Pin)	Constructor for a single SPI device.

Top

Properties

	Name	Description
	fd	Read-only property returning the Linux file descriptor for the SPI slave device.

Top

Methods

	Name	Description
	Read	Read bytes from an SPI slave device.
	Transaction	Write and read bytes to and from an SPI slave device.
	Write	Write bytes to an SPI slave device.

Top

Fields

	Name	Description
S	AUTOCHIPSELECT	Use hardware slave select.

Top

See Also

Reference

IO.Objects.SimpleIO.SPI Namespace

Device Constructor

Overload List

	Name	Description
	Device(Designator, Int32, Int32, Int32, Pin)	Constructor for a single SPI device.
	Device(String, Int32, Int32, Int32, Pin)	Constructor for a single SPI device.

Top

See Also

Reference

Device Class

IO.Objects.SimpleIO.SPI Namespace

Device Constructor (Designator, Int32, Int32, Int32, Pin)

Constructor for a single SPI device.

Namespace: IO.Objects.SimpleIO.SPI
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Device(
        Designator desg,
        int mode,
        int wordsize,
        int speed,
        Pin cspin = null
)
```

Parameters

desg
Type: IO.Objects.SimpleIO.DeviceDesignator
SPI device designator.

mode
Type: SystemInt32
SPI clock mode.

wordsize
Type: SystemInt32
SPI transfer word size.

speed

Type: SystemInt32
SPI transfer speed.

cspin **(Optional)**
Type: IO.Objects.SimpleIO.GPIOPin
SPI slave select GPIO pin number, or `AUTOCHIPSELECT`.

See Also

Reference

Device Class
Device Overload
IO.Objects.SimpleIO.SPI Namespace

Device Constructor (String, Int32, Int32, Int32, Pin)

Constructor for a single SPI device.

Namespace: IO.Objects.SimpleIO.SPI
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Device(
        string devname,
        int mode,
        int wordsize,
        int speed,
        Pin cspin = null
)
```

Parameters

devname
Type: SystemString
SPI device node name.

mode
Type: SystemInt32
SPI clock mode.

wordsize
Type: SystemInt32
SPI transfer word size.

speed

Type: SystemInt32
SPI transfer speed.

cspin **(Optional)**
Type: IO.Objects.SimpleIO.GPIOPin
SPI slave select GPIO pin number, or `AUTOCHIPSELECT`.

See Also

Reference

Device Class
Device Overload
IO.Objects.SimpleIO.SPI Namespace

Device Properties

The Device type exposes the following members.

Properties

	Name	Description
	fd	Read-only property returning the Linux file descriptor for the SPI slave device.

Top

See Also

Reference

Device Class

IO.Objects.SimpleIO.SPI Namespace

Devicefd Property

Read-only property returning the Linux file descriptor for the SPI slave device.

Namespace: IO.Objects.SimpleIO.SPI
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int fd { get; }
```

Property Value

Type: Int32

See Also

Reference

Device Class
IO.Objects.SimpleIO.SPI Namespace

Device Methods

The Device type exposes the following members.

Methods

	Name	Description
	Read	Read bytes from an SPI slave device.
	Transaction	Write and read bytes to and from an SPI slave device.
	Write	Write bytes to an SPI slave device.

Top

See Also

Reference

Device Class

IO.Objects.SimpleIO.SPI Namespace

DeviceRead Method

Read bytes from an SPI slave device.

Namespace: IO.Objects.SimpleIO.SPI
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Read(
        byte[] resp,
        int resplen
)
```

Parameters

resp
Type: SystemByte
Response buffer.

resplen
Type: SystemInt32
Number of bytes to read.

Implements

DeviceRead(Byte, Int32)

See Also

Reference

Device Class
IO.Objects.SimpleIO.SPI Namespace

DeviceTransaction Method

Write and read bytes to and from an SPI slave device.

Namespace: IO.Objects.SimpleIO.SPI
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Transaction(
        byte[] cmd,
        int cmdlen,
        byte[] resp,
        int resplen,
        int delayus = 0
)
```

Parameters

cmd
Type: SystemByte
Command buffer.

cmdlen
Type: SystemInt32
Number of bytes to write.

resp
Type: SystemByte
Response buffer.

resplen
Type: SystemInt32
Number of bytes to read.

delayus **(Optional)**

Type: SystemInt32

Delay in microseconds between write and read operations.

Implements

DeviceTransaction(Byte, Int32, Byte, Int32, Int32)

See Also

Reference

Device Class

IO.Objects.SimpleIO.SPI Namespace

DeviceWrite Method

Write bytes to an SPI slave device.

Namespace: IO.Objects.SimpleIO.SPI
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Write(
        byte[] cmd,
        int cmdlen
)
```

Parameters

cmd
Type: SystemByte
Command buffer.

cmdlen
Type: SystemInt32
Number of bytes to write.

Implements

DeviceWrite(Byte, Int32)

See Also

Reference

Device Class
IO.Objects.SimpleIO.SPI Namespace

Device Fields

The Device type exposes the following members.

Fields

	Name	Description
	AUTOCHIPSELECT	Use hardware slave select.

Top

See Also

Reference

Device Class

IO.Objects.SimpleIO.SPI Namespace

DeviceAUTOCHIPSELECT Field

Use hardware slave select.

Namespace: IO.Objects.SimpleIO.SPI
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const Pin AUTOCHIPSELECT = null
```

Field Value

Type: Pin

See Also

Reference

Device Class
IO.Objects.SimpleIO.SPI Namespace

IO.Objects.SimpleIO.syslog Namespace

Error Logging Services Using the Linux `syslog` Subsystem

Classes

	Class	Description
	Logger	Encapsulates system logging services using `libsimpleio`.

Enumerations

	Enumeration	Description
	LoggerRegistration	`TraceListener` registration options.

Logger Class

Encapsulates system logging services using `libsimpleio`.

Inheritance Hierarchy

System.DiagnosticsTraceListener IO.Objects.SimpleIO.syslogLogger

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Logger : TraceListener
```

The Logger type exposes the following members.

Constructors

	Name	Description
	Logger	Constructor for a logging object that uses the Linux `syslog` service.

Top

Methods

	Name	Description
	Error(String)	Log an error message.

	Error(String, Int32)	Log an error message, including an `errno` error string.
	Note	Log a notification message.
S	Register	Register a new `Logger` instance as a `TraceListener`.
	Warning	Log a warning message.
	Write	Trace interface method for posting a message. This method implementation is identical to `WriteLine()`, because `syslog` is not a stream oriented service.
	WriteLine	Trace interface method for posting a message.

Top

Fields

	Name	Description
S	LOG_ALERT	Alert condition message.
S	LOG_AUTH	Authentication facility.
S	LOG_CRIT	Critical condition message.
S	LOG_DAEMON	System daemon/background process facility.
S	LOG_DEBUG	Debug message.

s	LOG_EMERG	Emergency condition message.
s	LOG_ERR	Error message.
s	LOG_INFO	Informational message.
s	LOG_LOCAL0	Locally defined facility.
s	LOG_LOCAL1	Locally defined facility.
s	LOG_LOCAL2	Locally defined facility.
s	LOG_LOCAL3	Locally defined facility.
s	LOG_LOCAL4	Locally defined facility.
s	LOG_LOCAL5	Locally defined facility.
s	LOG_LOCAL6	Locally defined facility.
s	LOG_LOCAL7	Locally defined facility.
s	LOG_MAIL	Mail subsystem facility.
s	LOG_NDELAY	Open the connection to the `syslog` service immediately. Recommended.
s	LOG_NOTICE	Normal condition message.
s	LOG_ODELAY	Do not open the connection to the `syslog` service before logging the first message. Not recommended.
s	LOG_PERROR	Write message to both `syslog` service AND `stderr`.

	LOG_PID	Prepend the caller's process ID to the message.
	LOG_USER	User program facility. Use `LOG_LOCALx` instead.
	LOG_WARNING	Warning message.

Top

Remarks

An instance of this class can be used either standalone or as a `System.Diagnostics.TraceListener`. The static methods `Systems.Diagnostics.Trace.Write()` and `Systems.Diagnostics.Trace.WriteIf()` most naturally fit the Linux `syslog` facility.

Examples

Copy

```
using static System.Diagnostics.Trace;

Listeners.RemoveAt(0);
Listeners.Add(new IO.Objects.SimpleIO.syslog.Logger("H

Write("Hello, World!");
```

See Also

Reference

IO.Objects.SimpleIO.syslog Namespace

Logger Constructor

Constructor for a logging object that uses the Linux `syslog` service.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Logger(
        string id = "@@APPNAME@@",
        int facility = 128,
        int options = 32,
        int severity = 6
)
```

Parameters

id **(Optional)**
Type: SystemString
Program identifier string.

facility **(Optional)**
Type: SystemInt32
`syslog` facility.

options **(Optional)**
Type: SystemInt32
`syslog` options.

severity **(Optional)**
Type: SystemInt32
`syslog` severity level.

See Also

Reference

Logger Class

IO.Objects.SimpleIO.syslog Namespace

Logger Methods

The Logger type exposes the following members.

Methods

	Name	Description
	Error(String)	Log an error message.
	Error(String, Int32)	Log an error message, including an `errno` error string.
	Note	Log a notification message.
	Register	Register a new `Logger` instance as a `TraceListener`.
	Warning	Log a warning message.
	Write	Trace interface method for posting a message. This method implementation is identical to `WriteLine()`, because `syslog` is not a stream oriented service.
	WriteLine	Trace interface method for posting a message.

Top

See Also

Reference

Logger Class

IO.Objects.SimpleIO.syslog Namespace

LoggerError Method

Overload List

	Name	Description
	Error(String)	Log an error message.
	Error(String, Int32)	Log an error message, including an `errno` error string.

Top

See Also

Reference

Logger Class

IO.Objects.SimpleIO.syslog Namespace

LoggerError Method (String)

Log an error message.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Error(
        string message
)
```

Parameters

message
Type: SystemString
Error message.

See Also

Reference

Logger Class
Error Overload
IO.Objects.SimpleIO.syslog Namespace

LoggerError Method (String, Int32)

Log an error message, including an `errno` error string.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Error(
        string message,
        int errnum
)
```

Parameters

message
Type: SystemString
Error Message.

errnum
Type: SystemInt32
`errno` error number.

See Also

Reference

Logger Class
Error Overload
IO.Objects.SimpleIO.syslog Namespace

LoggerNote Method

Log a notification message.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public void Note(
        string message
)
```

Parameters

message
Type: SystemString
Notification message.

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerRegister Method

Register a new `Logger` instance as a `TraceListener`.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public static void Register(
        string id = "@@APPNAME@@",
        int facility = 128,
        int options = 32,
        int severity = 6,
        LoggerRegistration reghow = LoggerRegistration
)
```

Parameters

id **(Optional)**
Type: SystemString
Program identifier string.

facility **(Optional)**
Type: SystemInt32
`syslog` facility.

options **(Optional)**
Type: SystemInt32
`syslog` options.

severity **(Optional)**

Type: SystemInt32
`syslog` severity level.

reghow **(Optional)**
Type: IO.Objects.SimpleIO.syslogLoggerRegistration
How to register the `TraceListener` instance.

Examples

Copy

```
using static System.Diagnostics.Trace;

IO.Objects.SimpleIO.syslog.Logger.Register("HelloWorld

Write("Hello, World!");
```

See Also

Reference
Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerWarning Method

Log a warning message.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public void Warning(
        string message
)
```

Parameters

message
Type: SystemString
Warning message.

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerWrite Method

Trace interface method for posting a message. This method implementation is identical to `WriteLine()`, because `syslog` is not a stream oriented service.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public virtual void Write(
        string message
)
```

Parameters

message
Type: SystemString
Trace message.

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerWriteLine Method

Trace interface method for posting a message.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public virtual void WriteLine(
        string message
)
```

Parameters

message
Type: SystemString
Trace message.

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

Logger Fields

The Logger type exposes the following members.

Fields

	Name	Description
S	LOG_ALERT	Alert condition message.
S	LOG_AUTH	Authentication facility.
S	LOG_CRIT	Critical condition message.
S	LOG_DAEMON	System daemon/background process facility.
S	LOG_DEBUG	Debug message.
S	LOG_EMERG	Emergency condition message.
S	LOG_ERR	Error message.
S	LOG_INFO	Informational message.
S	LOG_LOCAL0	Locally defined facility.
S	LOG_LOCAL1	Locally defined facility.
S	LOG_LOCAL2	Locally defined facility.
S	LOG_LOCAL3	Locally defined facility.

s	LOG_LOCAL4	Locally defined facility.
s	LOG_LOCAL5	Locally defined facility.
s	LOG_LOCAL6	Locally defined facility.
s	LOG_LOCAL7	Locally defined facility.
s	LOG_MAIL	Mail subsystem facility.
s	LOG_NDELAY	Open the connection to the `syslog` service immediately. Recommended.
s	LOG_NOTICE	Normal condition message.
s	LOG_ODELAY	Do not open the connection to the `syslog` service before logging the first message. Not recommended.
s	LOG_PERROR	Write message to both `syslog` service AND `stderr`.
s	LOG_PID	Prepend the caller's process ID to the message.
s	LOG_USER	User program facility. Use `LOG_LOCALx` instead.
s	LOG_WARNING	Warning message.

Top

See Also

Reference

Logger Class

IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_ALERT Field

Alert condition message.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_ALERT = 1
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_AUTH Field

Authentication facility.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_AUTH = 32
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_CRIT Field

Critical condition message.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int LOG_CRIT = 2
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_DAEMON Field

System daemon/background process facility.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_DAEMON = 24
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_DEBUG Field

Debug message.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_DEBUG = 7
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_EMERG Field

Emergency condition message.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public const int LOG_EMERG = 0
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_ERR Field

Error message.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_ERR = 3
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_INFO Field

Informational message.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_INFO = 6
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_LOCAL0 Field

Locally defined facility.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LOCAL0 = 128
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_LOCAL1 Field

Locally defined facility.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LOCAL1 = 136
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_LOCAL2 Field

Locally defined facility.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LOCAL2 = 144
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_LOCAL3 Field

Locally defined facility.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LOCAL3 = 152
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_LOCAL4 Field

Locally defined facility.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LOCAL4 = 160
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_LOCAL5 Field

Locally defined facility.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LOCAL5 = 168
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_LOCAL6 Field

Locally defined facility.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LOCAL6 = 176
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_LOCAL7 Field

Locally defined facility.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_LOCAL7 = 184
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_MAIL Field

Mail subsystem facility.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_MAIL = 16
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_NDELAY Field

Open the connection to the `syslog` service immediately. Recommended.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_NDELAY = 8
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_NOTICE Field

Normal condition message.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_NOTICE = 5
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_ODELAY Field

Do not open the connection to the `syslog` service before logging the first message. Not recommended.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_ODELAY = 8
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_PERROR Field

Write message to both `syslog` service AND `stderr`.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_PERROR = 32
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_PID Field

Prepend the caller's process ID to the message.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_PID = 1
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_USER Field

User program facility. Use `LOG_LOCALx` instead.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_USER = 8
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerLOG_WARNING Field

Warning message.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int LOG_WARNING = 4
```

Field Value

Type: Int32

See Also

Reference

Logger Class
IO.Objects.SimpleIO.syslog Namespace

LoggerRegistration Enumeration

`TraceListener` registration options.

Namespace: IO.Objects.SimpleIO.syslog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public enum Registration
```

Members

	Member name	Value	Description
	Append	0	Add to the `TraceListener` list.
	Replace	1	Replace all `TraceListener` list items.

See Also

Reference

IO.Objects.SimpleIO.syslog Namespace

IO.Objects.SimpleIO.Watchdog Namespace

Watchdog Timer Services

Classes

	Class	Description
	Timer	Encapsulates Linux watchdog timers using `libsimpleio`.

Timer Class

Encapsulates Linux watchdog timers using `libsimpleio`.

Inheritance Hierarchy

SystemObject IO.Objects.SimpleIO.WatchdogTimer

Namespace: IO.Objects.SimpleIO.Watchdog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public class Timer : Timer
```

The Timer type exposes the following members.

Constructors

	Name	Description
	Timer	Constructor for a single watchdog timer.

Top

Properties

	Name	Description
	fd	Read-only property returning the Linux file descriptor for the watchdog timer.

	timeout	Get or set the watchdog timeout. Not all platforms may support this. Even if supported, there may be constraints. For example, some platforms allow shortening the timeout but not lengthening it.

Top

Methods

	Name	Description
	Kick	Reset the watchdog timer.

Top

Fields

	Name	Description
S	DefaultDevice	Default watchdog timer device name.
S	DefaultTimeout	Default watchdog timer timeout value (disabled).

Top

See Also

Reference

IO.Objects.SimpleIO.Watchdog Namespace

Timer Constructor

Constructor for a single watchdog timer.

Namespace: IO.Objects.SimpleIO.Watchdog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public Timer(
        string devname = "/dev/watchdog",
        int timeout = 0
)
```

Parameters

devname **(Optional)**
Type: SystemString
Device node name.

timeout **(Optional)**
Type: SystemInt32
Watchdog timeout setting in seconds, or `DefaultTimeout`.

See Also

Reference

Timer Class
IO.Objects.SimpleIO.Watchdog Namespace

Timer Properties

The Timer type exposes the following members.

Properties

	Name	Description
	fd	Read-only property returning the Linux file descriptor for the watchdog timer.
	timeout	Get or set the watchdog timeout. Not all platforms may support this. Even if supported, there may be constraints. For example, some platforms allow shortening the timeout but not lengthening it.

Top

See Also

Reference

Timer Class

IO.Objects.SimpleIO.Watchdog Namespace

Timerfd Property

Read-only property returning the Linux file descriptor for the watchdog timer.

Namespace: IO.Objects.SimpleIO.Watchdog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int fd { get; }
```

Property Value

Type: Int32

See Also

Reference

Timer Class
IO.Objects.SimpleIO.Watchdog Namespace

Timertimeout Property

Get or set the watchdog timeout. Not all platforms may support this. Even if supported, there may be constraints. For example, some platforms allow shortening the timeout but not lengthening it.

Namespace: IO.Objects.SimpleIO.Watchdog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F# Copy

```
public int timeout { get; set; }
```

Property Value

Type: Int32

Implements

Timertimeout

See Also

Reference

Timer Class
IO.Objects.SimpleIO.Watchdog Namespace

Timer Methods

The Timer type exposes the following members.

Methods

	Name	Description
	Kick	Reset the watchdog timer.

Top

See Also

Reference

Timer Class

IO.Objects.SimpleIO.Watchdog Namespace

TimerKick Method

Reset the watchdog timer.

Namespace: IO.Objects.SimpleIO.Watchdog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public void Kick()
```

Implements

TimerKick

See Also

Reference

Timer Class
IO.Objects.SimpleIO.Watchdog Namespace

Timer Fields

The Timer type exposes the following members.

Fields

	Name	Description
	DefaultDevice	Default watchdog timer device name.
	DefaultTimeout	Default watchdog timer timeout value (disabled).

Top

See Also

Reference

Timer Class

IO.Objects.SimpleIO.Watchdog Namespace

TimerDefaultDevice Field

Default watchdog timer device name.

Namespace: IO.Objects.SimpleIO.Watchdog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const string DefaultDevice = "/dev/watchdog"
```

Field Value

Type: String

See Also

Reference

Timer Class
IO.Objects.SimpleIO.Watchdog Namespace

TimerDefaultTimeout Field

Default watchdog timer timeout value (disabled).

Namespace: IO.Objects.SimpleIO.Watchdog
Assembly: libsimpleio (in libsimpleio.dll) Version: 2.2023.56.1

Syntax

C# VB F#

Copy

```
public const int DefaultTimeout = 0
```

Field Value

Type: Int32

See Also

Reference

Timer Class
IO.Objects.SimpleIO.Watchdog Namespace

Index

IO.Bindings 1
libsimpleio Class 2
libsimpleio Methods 18
ADC_close Method 26
ADC_get_name Method 27
ADC_open Method 29
ADC_read Method 31
DAC_close Method 33
DAC_get_name Method 34
DAC_open Method 36
DAC_write Method 38
EVENT_close Method 40
EVENT_modify_fd Method 41
EVENT_open Method 43
EVENT_register_fd Method 44
EVENT_unregister_fd Method 46
EVENT_wait Method 48
GPIO_chip_info Method 50
GPIO_close Method 52
GPIO_configure Method 53
GPIO_line_close Method 55
GPIO_line_event Method 57
GPIO_line_info Method 59
GPIO_line_open Method 61
GPIO_line_read Method 63
GPIO_line_write Method 65
GPIO_open Method 67

GPIO_read Method 69
GPIO_write Method 71
HIDRAW_close Method 73
HIDRAW_get_info Method 75
HIDRAW_get_name Method 77
HIDRAW_open1 Method 79
HIDRAW_open2 Method 81
HIDRAW_open3 Method 83
HIDRAW_receive Method 85
HIDRAW_send Method 87
I2C_close Method 89
I2C_open Method 90
I2C_transaction Method 92
IPV4_ntoa Method 94
IPV4_resolve Method 96
LINUX_closelog Method 98
LINUX_command Method 99
LINUX_detach Method 101
LINUX_drop_privileges Method 102
LINUX_errno Method 104
LINUX_openlog Method 105
LINUX_poll Method 107
LINUX_strerror Method 109
LINUX_syslog Method 111
LINUX_usleep Method 113
PWM_close Method 114
PWM_configure Method 115
PWM_open Method 117
PWM_write Method 119

SERIAL_close Method 121
SERIAL_open Method 122
SERIAL_receive Method 124
SERIAL_send Method 126
SPI_close Method 128
SPI_open Method 129
SPI_transaction Method 131
STREAM_decode_frame Method 133
STREAM_encode_frame Method 135
STREAM_receive_frame Method 137
STREAM_send_frame Method 139
TCP4_accept Method 141
TCP4_close Method 143
TCP4_connect Method 144
TCP4_receive Method 146
TCP4_send Method 148
TCP4_server Method 150
UDP4_close Method 152
UDP4_open Method 153
UDP4_receive Method 155
UDP4_send Method 157
WATCHDOG_close Method 159
WATCHDOG_get_timeout Method 161
WATCHDOG_kick Method 163
WATCHDOG_open Method 165
WATCHDOG_set_timeout Method 167
libsimpleio Fields 169
GPIO_DIRECTION_INPUT Field 178
GPIO_DIRECTION_OUTPUT Field 179

GPIO_DRIVER_OPENDRAIN Field 180
GPIO_DRIVER_OPENSOURCE Field 181
GPIO_DRIVER_PUSHPULL Field 182
GPIO_EDGE_BOTH Field 183
GPIO_EDGE_FALLING Field 184
GPIO_EDGE_NONE Field 185
GPIO_EDGE_RISING Field 186
GPIO_EVENT_REQUEST_BOTH Field 187
GPIO_EVENT_REQUEST_FALLING Field 188
GPIO_EVENT_REQUEST_NONE Field 189
GPIO_EVENT_REQUEST_RISING Field 190
GPIO_LINE_INFO_ACTIVE_LOW Field 191
GPIO_LINE_INFO_KERNEL Field 192
GPIO_LINE_INFO_OPEN_DRAIN Field 193
GPIO_LINE_INFO_OPEN_SOURCE Field 194
GPIO_LINE_INFO_OUTPUT Field 195
GPIO_LINE_REQUEST_ACTIVE_HIGH Field 196
GPIO_LINE_REQUEST_ACTIVE_LOW Field 197
GPIO_LINE_REQUEST_INPUT Field 198
GPIO_LINE_REQUEST_OPEN_DRAIN Field 199
GPIO_LINE_REQUEST_OPEN_SOURCE Field 200
GPIO_LINE_REQUEST_OUTPUT Field 201
GPIO_LINE_REQUEST_PUSH_PULL Field 202
GPIO_POLARITY_ACTIVEHIGH Field 203
GPIO_POLARITY_ACTIVELOW Field 204
INADDR_ANY Field 205
INADDR_BROADCAST Field 206
INADDR_LOOPBACK Field 207
LOG_ALERT Field 208

LOG_AUTH Field 209
LOG_AUTHPRIV Field 210
LOG_CONS Field 211
LOG_CRIT Field 212
LOG_CRON Field 213
LOG_DAEMON Field 214
LOG_DEBUG Field 215
LOG_EMERG Field 216
LOG_ERR Field 217
LOG_FTP Field 218
LOG_INFO Field 219
LOG_KERN Field 220
LOG_LOCAL0 Field 221
LOG_LOCAL1 Field 222
LOG_LOCAL2 Field 223
LOG_LOCAL3 Field 224
LOG_LOCAL4 Field 225
LOG_LOCAL5 Field 226
LOG_LOCAL6 Field 227
LOG_LOCAL7 Field 228
LOG_LPR Field 229
LOG_MAIL Field 230
LOG_NDELAY Field 231
LOG_NEWS Field 232
LOG_NOTICE Field 233
LOG_NOWAIT Field 234
LOG_ODELAY Field 235
LOG_PERROR Field 236
LOG_PID Field 237

LOG_PROGNAME Field 238
LOG_SYSLOG Field 239
LOG_USER Field 240
LOG_UUCP Field 241
LOG_WARNING Field 242
MSG_DONTROUTE Field 243
MSG_DONTWAIT Field 244
MSG_MORE Field 245
POLLERR Field 246
POLLHUP Field 247
POLLIN Field 248
POLLNVAL Field 249
POLLOUT Field 250
POLLPRI Field 251
PWM_POLARITY_ACTIVEHIGH Field 252
PWM_POLARITY_ACTIVELOW Field 253
SERIAL_PARITY_EVEN Field 254
SERIAL_PARITY_NONE Field 255
SERIAL_PARITY_ODD Field 256
SPI_AUTO_CS Field 257
IO.Devices.A4988 258
Device Class 259
Device Constructor 261
Device Properties 263
StepsPerRotation Property 264
Device Methods 265
Disable Method 266
Enable Method 267
Move Method 268

Reset Method 270
Sleep Method 271
Spin Method 272
Wakeup Method 274
IO.Devices.AD5593R 275
Device Class 276
Device Constructor 279
Device Properties 280
ADC_Reference Property 282
DAC_Reference Property 283
GPIO_Inputs Property 284
GPIO_Outputs Property 285
Device Methods 286
ADC_Create Method 287
ConfigureChannel Method 288
DAC_Create Method 289
GPIO_Create Method 291
Read_ADC Method 293
Write_DAC Method 294
Device Fields 295
ADC_Resolution Field 296
DAC_Resolution Field 297
MaxChannel Field 298
MinChannel Field 299
PinMode Enumeration 300
ReferenceMode Enumeration 302
IO.Devices.AD5593R.ADC 304
Sample Class 305
Sample Constructor 307

Sample Properties 308
resolution Property 309
sample Property 310
IO.Devices.AD5593R.DAC 311
Sample Class 312
Sample Constructor 314
Sample Properties 316
resolution Property 317
sample Property 318
IO.Devices.AD5593R.GPIO 319
Pin Class 320
Pin Constructor 322
Pin Properties 324
state Property 325
IO.Devices.ADC121C021 326
Sample Class 327
Sample Constructor 329
Sample Properties 330
resolution Property 331
sample Property 332
IO.Devices.ClickBoards.RemoteIO.ADAC 333
Board Class 334
Board Constructor 336
Board Properties 338
device Property 339
Board Methods 340
ADC Method 341
DAC Method 342
GPIO Method 344

Reset Method 346
Board Fields 347
DefaultAddress Field 348
IO.Devices.ClickBoards.RemoteIO.Expand 349
Board Class 350
Board Constructor 352
Board Properties 353
device Property 354
Board Methods 355
GPIO Method 356
Reset Method 358
IO.Devices.ClickBoards.RemoteIO.Expand2 359
Board Class 360
Board Constructor 362
Board Properties 364
device Property 365
Board Methods 366
GPIO Method 367
Reset Method 369
Board Fields 370
DefaultAddress Field 371
IO.Devices.ClickBoards.RemoteIO.PWM 372
Board Class 373
Board Constructor 375
Board Properties 377
dev Property 378
Board Methods 379
GPIO Method 380
PWM Method 382

Servo Method 384
Board Fields 386
DefaultAddress Field 387
IO.Devices.ClickBoards.RemoteIO.SevenSegment 388
Board Class 389
Board Constructor 392
Board Properties 394
blanking Property 396
brightness Property 397
leftdp Property 398
radix Property 399
rightdp Property 400
state Property 401
Board Methods 402
Clear Method 403
Reset Method 404
Board.Base Enumeration 405
Board.ZeroBlanking Enumeration 406
IO.Devices.ClickBoards.SimpleIO.ADAC 407
Board Class 408
Board Constructor 410
Board Properties 411
device Property 412
Board Methods 413
ADC Method 414
DAC Method 415
GPIO Method 417
Reset Method 419
Board Fields 420

DefaultAddress Field 421
IO.Devices.ClickBoards.SimpleIO.Expand 422
Board Class 423
Board Constructor 425
Board Properties 426
device Property 427
Board Methods 428
GPIO Method 429
Reset Method 431
IO.Devices.ClickBoards.SimpleIO.Expand2 432
Board Class 433
Board Constructor 435
Board Properties 436
device Property 437
Board Methods 438
GPIO Method 439
Reset Method 441
Board Fields 442
DefaultAddress Field 443
IO.Devices.ClickBoards.SimpleIO.PWM 444
Board Class 445
Board Constructor 447
Board Properties 449
dev Property 450
Board Methods 451
GPIO Method 452
PWM Method 454
Servo Method 456
Board Fields 458

DefaultAddress Field 459
IO.Devices.ClickBoards.SimpleIO.SevenSegment 460
Board Class 461
Board Constructor 464
Board Properties 466
blanking Property 468
brightness Property 469
leftdp Property 470
radix Property 471
rightdp Property 472
state Property 473
Board Methods 474
Clear Method 475
Reset Method 476
Board.Base Enumeration 477
Board.ZeroBlanking Enumeration 478
IO.Devices.Grove.ADC 479
Device Class 480
Device Constructor 482
Device Properties 483
voltage Property 484
IO.Devices.Grove.Temperature 485
Device Class 486
Device Constructor 488
Device Properties 489
Celsius Property 490
Fahrenheit Property 491
Kelvins Property 492
IO.Devices.Grove.Temperature_Humidity 493

Device Class 494
Device Constructor 496
Device Properties 497
IO.Devices.HDC1080 499
Device Class 500
Device Constructor 503
Device Properties 504
Celsius Property 506
DeviceID Property 507
Fahrenheit Property 508
Humidity Property 509
Kelvins Property 510
ManufacturerID Property 511
Device Methods 512
Read Method 513
Write Method 514
Device Fields 515
RegConfiguration Field 517
RegDeviceID Field 518
RegHumidity Field 519
RegManufacturerID Field 520
RegSerialNumberFirst Field 521
RegSerialNumberLast Field 522
RegSerialNumberMid Field 523
RegTemperature Field 524
IO.Devices.MCP23017 525
Device Class 526
Device Constructor 529
Device Properties 530

Direction Property 532
DirectionA Property 533
DirectionB Property 534
Polarity Property 535
PolarityA Property 536
PolarityB Property 537
Port Property 538
PortA Property 539
PortB Property 540
Pullups Property 541
PullupsA Property 542
PullupsB Property 543
Device Methods 544
GPIO_Create Method 545
Device Fields 547
MaxChannel Field 548
MinChannel Field 549
IO.Devices.MCP23017.GPIO 550
Pin Class 551
Pin Constructor 553
Pin Properties 555
state Property 556
IO.Devices.MCP23S17 557
Device Class 558
Device Constructor 562
Device Properties 563
Direction Property 565
DirectionA Property 566
DirectionB Property 567

Polarity Property 568
PolarityA Property 569
PolarityB Property 570
Port Property 571
PortA Property 572
PortB Property 573
Pullups Property 574
PullupsA Property 575
PullupsB Property 576
Device Methods 577
GPIO_Create Method 578
Device Fields 580
MaxChannel Field 581
MinChannel Field 582
SPI_Frequency Field 583
SPI_Mode Field 584
SPI_WordSize Field 585
IO.Devices.MCP23S17.GPIO 586
Pin Class 587
Pin Constructor 589
Pin Properties 591
state Property 592
IO.Devices.PCA8574 593
Device Class 594
Device Constructor 596
Device Properties 598
Latch Property 599
Device Methods 600
Read Method 601

Write Method 602
Device Fields 603
MAX_PINS Field 604
IO.Devices.PCA8574.GPIO 605
Pin Class 606
Pin Constructor 608
Pin Properties 610
state Property 611
IO.Devices.PCA9534 612
Device Class 613
Device Constructor 616
Device Properties 618
Config Property 619
Latch Property 620
Device Methods 621
Read Method 622
Read Method 623
Read Method (Byte) 624
Write Method 625
Write Method (Byte) 626
Write Method (Byte, Byte) 627
Device Fields 628
AllInputs Field 630
AllNormal Field 631
AllOff Field 632
AllOutputs Field 633
ConfigurationReg Field 634
InputPolarityReg Field 635
InputPortReg Field 636

MAX_PINS Field 637
OutputPortReg Field 638
IO.Devices.PCA9534.GPIO 639
Pin Class 640
Pin Constructor 642
Pin Properties 644
state Property 645
IO.Devices.PCA9685 646
Device Class 647
Device Constructor 650
Device Properties 652
Frequency Property 653
Device Methods 654
ReadChannel Method 655
WriteChannel Method 656
Device Fields 657
INTERNAL_CLOCK Field 658
MAX_CHANNEL Field 659
MAX_CLOCK Field 660
MIN_CHANNEL Field 661
MIN_CLOCK Field 662
IO.Devices.PCA9685.GPIO 663
Pin Class 664
Pin Constructor 666
Pin Properties 668
state Property 669
IO.Devices.PCA9685.PWM 670
Output Class 671
Output Constructor 673

Output Properties 675
dutycycle Property 676
IO.Devices.PCA9685.Servo 677
Output Class 678
Output Constructor 680
Output Properties 682
position Property 683
IO.Devices.Pmod.HYGRO 684
Device Class 685
Device Constructor 688
Device Properties 689
Device Methods 691
IO.Devices.SN74HC595 692
Device Class 693
Device Constructor 696
Device Properties 698
Length Property 699
state Property 700
Device Methods 701
ClrBit Method 702
ReadBit Method 703
SetBit Method 705
Device Fields 706
SPI_MaxFreq Field 707
SPI_Mode Field 708
IO.Devices.SN74HC595.GPIO 709
Pin Class 710
Pin Constructor 712
Pin Properties 714

state Property 715
IO.Devices.TH02 716
Device Class 717
Device Constructor 719
Device Properties 720
Celsius Property 721
DeviceID Property 722
Fahrenheit Property 723
Humidity Property 724
Kelvins Property 725
IO.Devices.Thermistor 726
NTC_B Class 727
NTC_B Constructor 729
NTC_B Methods 731
Kelvins Method 732
IO.Devices.USB.Munts 733
HID Class 734
HID Fields 736
Product Field 737
Vendor Field 738
Serial Class 739
Serial Fields 741
Product Field 742
Vendor Field 743
IO.Interfaces.ADC 744
Input Class 745
Input Constructor 747
Input Properties 749
voltage Property 750

Sample Interface 751
Sample Properties 752
resolution Property 753
sample Property 754
Voltage Interface 755
Voltage Properties 756
voltage Property 757
IO.Interfaces.DAC 758
Output Class 759
Output Constructor 761
Output Properties 763
voltage Property 764
Sample Interface 765
Sample Properties 767
resolution Property 768
sample Property 769
Voltage Interface 770
Voltage Properties 771
voltage Property 772
IO.Interfaces.GPIO 773
Direction Enumeration 774
Pin Interface 775
Pin Properties 776
state Property 777
IO.Interfaces.Humidity 778
Sensor Interface 779
Sensor Properties 780
Humidity Property 781
IO.Interfaces.I2C 782

Bus Interface 783
Bus Methods 785
Read Method 786
Transaction Method 788
Write Method 790
Device Class 792
Device Constructor 794
Device Methods 795
Read Method 796
Transaction Method 797
Write Method 799
Speeds Class 800
Speeds Fields 802
FastMode Field 803
FastModePlus Field 804
StandardMode Field 805
IO.Interfaces.Message.Text 806
Relay Interface 807
Relay Methods 808
Send Method 809
IO.Interfaces.Message64 811
Message Class 812
Message Constructor 814
Message Constructor 815
Message Constructor (Byte) 816
Message Fields 817
payload Field 818
Size Field 819
Messenger Interface 820

Messenger Methods 822
Receive Method 823
Send Method 824
Transaction Method 825
IO.Interfaces.Motor 826
Output Interface 827
Output Properties 828
velocity Property 829
Velocities Class 830
Velocities Fields 832
Maximum Field 833
Minimum Field 834
Stop Field 835
IO.Interfaces.PWM 836
DutyCycles Class 837
DutyCycles Fields 839
Maximum Field 840
Minimum Field 841
Output Interface 842
Output Properties 843
dutycycle Property 844
IO.Interfaces.Servo 845
Output Interface 846
Output Properties 847
position Property 848
Positions Class 849
Positions Fields 851
Maximum Field 852
Minimum Field 853

Neutral Field 854
IO.Interfaces.SPI 855
Device Interface 856
Device Methods 858
Read Method 859
Transaction Method 860
Write Method 862
IO.Interfaces.Stepper 863
Output Interface 864
Output Properties 866
StepsPerRotation Property 867
Output Methods 868
Move Method 869
Spin Method 871
IO.Interfaces.Temperature 873
Conversions Class 874
Conversions Constructor 876
Conversions Methods 877
CelsiusToFahrenheit Method 879
CelsiusToKelvins Method 880
FahrenheitToCelsius Method 881
FahrenheitToKelvins Method 882
KelvinsToCelsius Method 883
KelvinsToFahrenheit Method 884
Sensor Interface 885
Sensor Properties 887
Celsius Property 888
Fahrenheit Property 889
Kelvins Property 890

IO.Interfaces.Watchdog 891
Timer Interface 892
Timer Properties 894
timeout Property 895
Timer Methods 896
Kick Method 897
IO.Objects.Email.Mail 898
Relay Class 899
Relay Constructor 901
Relay Methods 902
Send Method 903
Send Method (String, String, String) 904
Send Method (String, String, String, String) 906
Send Method (String, String, String, String, String) 908
IO.Objects.Email.SMTP 910
Relay Class 911
Relay Constructor 913
Relay Methods 914
Send Method 915
Send Method (String, String, String) 916
Send Method (String, String, String, String) 918
Send Method (String, String, String, String, String) 920
IO.Objects.GPIO.PWM 922
Pin Class 923
Pin Constructor 925
Pin Properties 927
state Property 928
IO.Objects.Message64.UDP 929
Messenger Class 930

Messenger Constructor 932
Messenger Methods 934
Receive Method 935
Send Method 936
Transaction Method 937
IO.Objects.Motor.PWM 939
Output Class 940
Output Constructor 942
Output Constructor (Output, Output, Double) 943
Output Constructor (Pin, Output, Double) 945
Output Properties 947
velocity Property 948
IO.Objects.Motor.Servo 949
Output Class 950
Output Constructor 952
Output Properties 953
velocity Property 954
IO.Objects.RemoteIO 955
ADC Class 957
ADC Constructor 959
ADC Properties 961
resolution Property 962
sample Property 963
DAC Class 964
DAC Constructor 966
DAC Properties 968
resolution Property 969
sample Property 970
Device Class 971

Device Constructor 974
Device Constructor (Messenger) 975
Device Constructor (Int32, Int32, String, Int32) 976
Device Properties 978
Capabilities Property 979
Version Property 980
Device Methods 981
ADC_Available Method 983
ADC_Create Method 984
DAC_Available Method 985
DAC_Create Method 986
Dispatcher Method 988
GPIO_Available Method 989
GPIO_Create Method 990
I2C_Available Method 992
I2C_Create Method 993
PWM_Available Method 995
PWM_Create Method 996
SPI_Available Method 998
SPI_Create Method 999
Device Fields 1001
MAX_CHANNELS Field 1002
Unavailable Field 1003
GPIO Class 1004
GPIO Constructor 1006
GPIO Properties 1008
state Property 1009
I2C Class 1010
I2C Constructor 1012

I2C Methods 1014
Read Method 1015
Transaction Method 1017
Write Method 1019
MessageTypes Enumeration 1021
PeripheralTypes Enumeration 1027
PWM Class 1029
PWM Constructor 1031
PWM Properties 1033
dutycycle Property 1034
SPI Class 1035
SPI Constructor 1037
SPI Methods 1039
Read Method 1040
Transaction Method 1042
Write Method 1044
IO.Objects.RemoteIO.mikroBUS 1046
Shield Class 1047
Shield Properties 1049
kind Property 1050
Shield Fields 1051
I2CBus Field 1052
Shield.Kinds Enumeration 1053
Socket Class 1055
Socket Constructor 1058
Socket Properties 1059
AIN Property 1061
AN Property 1062
CS Property 1063

I2CBus Property 1064
INT Property 1065
MISO Property 1066
MOSI Property 1067
PWM Property 1068
PWMOut Property 1069
RST Property 1070
RX Property 1071
SCK Property 1072
SCL Property 1073
SDA Property 1074
SPIDev Property 1075
TX Property 1076
IO.Objects.RemoteIO.Platforms 1077
MUNTS_0018 Class 1078
MUNTS_0018 Fields 1082
D1 Field 1085
J10A0 Field 1086
J10A1 Field 1087
J11A0 Field 1088
J11A1 Field 1089
J2PWM Field 1090
J3PWM Field 1091
J4D0 Field 1092
J4D1 Field 1093
J5D0 Field 1094
J5D1 Field 1095
J6D0 Field 1096
J6D1 Field 1097

J6DIR Field 1098
J6PWM Field 1099
J7D0 Field 1100
J7D1 Field 1101
J7DIR Field 1102
J7PWM Field 1103
J9I2C Field 1104
SW1 Field 1105
USERLED Field 1106
RaspberryPi Class 1107
RaspberryPi Fields 1111
AIN0 Field 1115
AIN1 Field 1116
GPIO10 Field 1117
GPIO11 Field 1118
GPIO12 Field 1119
GPIO13 Field 1120
GPIO14 Field 1121
GPIO15 Field 1122
GPIO16 Field 1123
GPIO17 Field 1124
GPIO18 Field 1125
GPIO19 Field 1126
GPIO2 Field 1127
GPIO20 Field 1128
GPIO21 Field 1129
GPIO22 Field 1130
GPIO23 Field 1131
GPIO24 Field 1132

GPIO25 Field 1133
GPIO26 Field 1134
GPIO27 Field 1135
GPIO3 Field 1136
GPIO4 Field 1137
GPIO5 Field 1138
GPIO6 Field 1139
GPIO7 Field 1140
GPIO8 Field 1141
GPIO9 Field 1142
I2C1 Field 1143
PWM0 Field 1144
PWM1 Field 1145
SPI0 Field 1146
SPI1 Field 1147
USERLED Field 1148
IO.Objects.Servo.PWM 1149
Output Class 1150
Output Constructor 1152
Output Properties 1154
position Property 1155
IO.Objects.SimpleIO.ADC 1156
Sample Class 1157
Sample Constructor 1159
Sample Properties 1160
fd Property 1161
resolution Property 1162
sample Property 1163
Sample Methods 1164

name Method 1165
IO.Objects.SimpleIO.DAC 1166
Sample Class 1167
Sample Constructor 1169
Sample Properties 1171
fd Property 1172
resolution Property 1173
sample Property 1174
Sample Methods 1175
name Method 1176
IO.Objects.SimpleIO.Device 1177
Designator Structure 1178
Designator Constructor 1180
Designator Properties 1181
available Property 1182
Designator Fields 1183
chan Field 1184
chip Field 1185
Unavailable Field 1186
IO.Objects.SimpleIO.GPIO 1187
Pin Class 1188
Pin Constructor 1190
Pin Properties 1192
fd Property 1193
state Property 1194
Pin.Driver Enumeration 1195
Pin.Edge Enumeration 1196
Pin.Polarity Enumeration 1198
IO.Objects.SimpleIO.HID 1199

Messenger Class 1200
Messenger Constructor 1203
Messenger Constructor (String, Int32) 1204
Messenger Constructor (Int32, Int32, String, Int32) 1206
Messenger Properties 1208
bustype Property 1209
fd Property 1210
name Property 1211
product Property 1212
vendor Property 1213
Messenger Methods 1214
Receive Method 1215
Send Method 1216
Transaction Method 1217
IO.Objects.SimpleIO.I2C 1219
Bus Class 1220
Bus Constructor 1222
Bus Constructor (Designator) 1223
Bus Constructor (String) 1224
Bus Properties 1225
fd Property 1226
Bus Methods 1227
Read Method 1228
Transaction Method 1230
Write Method 1232
IO.Objects.SimpleIO.mikroBUS 1234
Shield Class 1235
Shield Properties 1237
kind Property 1238

Shield Fields 1239
I2CBus Field 1240
Shield.Kinds Enumeration 1241
Socket Class 1244
Socket Constructor 1247
Socket Properties 1248
AIN Property 1250
AN Property 1251
CS Property 1252
I2CBus Property 1253
INT Property 1254
MISO Property 1255
MOSI Property 1256
PWM Property 1257
PWMOut Property 1258
RST Property 1259
RX Property 1260
SCK Property 1261
SCL Property 1262
SDA Property 1263
SPIDev Property 1264
TX Property 1265
UART Property 1266
IO.Objects.SimpleIO.Platforms 1267
BeagleBone Class 1268
BeagleBone Fields 1274
AIN0 Field 1279
AIN1 Field 1280
AIN2 Field 1281

AIN3 Field 1282
AIN4 Field 1283
AIN5 Field 1284
AIN6 Field 1285
GPIO10 Field 1286
GPIO11 Field 1287
GPIO110 Field 1288
GPIO111 Field 1289
GPIO112 Field 1290
GPIO113 Field 1291
GPIO115 Field 1292
GPIO117 Field 1293
GPIO12 Field 1294
GPIO13 Field 1295
GPIO14 Field 1296
GPIO15 Field 1297
GPIO2 Field 1298
GPIO20 Field 1299
GPIO22 Field 1300
GPIO23 Field 1301
GPIO26 Field 1302
GPIO27 Field 1303
GPIO3 Field 1304
GPIO30 Field 1305
GPIO31 Field 1306
GPIO32 Field 1307
GPIO33 Field 1308
GPIO34 Field 1309
GPIO35 Field 1310

GPIO36 Field 1311
GPIO37 Field 1312
GPIO38 Field 1313
GPIO39 Field 1314
GPIO4 Field 1315
GPIO44 Field 1316
GPIO45 Field 1317
GPIO46 Field 1318
GPIO47 Field 1319
GPIO48 Field 1320
GPIO49 Field 1321
GPIO5 Field 1322
GPIO50 Field 1323
GPIO51 Field 1324
GPIO60 Field 1325
GPIO61 Field 1326
GPIO62 Field 1327
GPIO63 Field 1328
GPIO65 Field 1329
GPIO66 Field 1330
GPIO67 Field 1331
GPIO68 Field 1332
GPIO69 Field 1333
GPIO7 Field 1334
GPIO70 Field 1335
GPIO71 Field 1336
GPIO72 Field 1337
GPIO73 Field 1338
GPIO74 Field 1339

GPIO75 Field 1340
GPIO76 Field 1341
GPIO77 Field 1342
GPIO78 Field 1343
GPIO79 Field 1344
GPIO8 Field 1345
GPIO80 Field 1346
GPIO81 Field 1347
GPIO86 Field 1348
GPIO87 Field 1349
GPIO88 Field 1350
GPIO89 Field 1351
GPIO9 Field 1352
I2C2 Field 1353
SPI2_0 Field 1354
SPI2_1 Field 1355
MUNTS_0018 Class 1356
MUNTS_0018 Fields 1360
D1 Field 1363
J10A0 Field 1364
J10A1 Field 1365
J11A0 Field 1366
J11A1 Field 1367
J2PWM Field 1368
J3PWM Field 1369
J4D0 Field 1370
J4D1 Field 1371
J5D0 Field 1372
J5D1 Field 1373

J5I2C Field 1374
J6D0 Field 1375
J6D1 Field 1376
J6DIR Field 1377
J6PWM Field 1378
J7D0 Field 1379
J7D1 Field 1380
J7DIR Field 1381
J7PWM Field 1382
J9I2C Field 1383
SW1 Field 1384
PocketBeagle Class 1385
PocketBeagle Fields 1390
AIN0 Field 1394
AIN1 Field 1395
AIN2 Field 1396
AIN3 Field 1397
AIN4 Field 1398
AIN5 Field 1399
AIN6 Field 1400
AIN7 Field 1401
GPIO110 Field 1402
GPIO111 Field 1403
GPIO112 Field 1404
GPIO113 Field 1405
GPIO114 Field 1406
GPIO115 Field 1407
GPIO116 Field 1408
GPIO117 Field 1409

GPIO12 Field 1410
GPIO13 Field 1411
GPIO14 Field 1412
GPIO15 Field 1413
GPIO19 Field 1414
GPIO2 Field 1415
GPIO20 Field 1416
GPIO23 Field 1417
GPIO26 Field 1418
GPIO27 Field 1419
GPIO3 Field 1420
GPIO30 Field 1421
GPIO31 Field 1422
GPIO4 Field 1423
GPIO40 Field 1424
GPIO41 Field 1425
GPIO42 Field 1426
GPIO43 Field 1427
GPIO44 Field 1428
GPIO45 Field 1429
GPIO46 Field 1430
GPIO47 Field 1431
GPIO5 Field 1432
GPIO50 Field 1433
GPIO52 Field 1434
GPIO57 Field 1435
GPIO58 Field 1436
GPIO59 Field 1437
GPIO60 Field 1438

GPIO64 Field 1439
GPIO65 Field 1440
GPIO7 Field 1441
GPIO86 Field 1442
GPIO87 Field 1443
GPIO88 Field 1444
GPIO89 Field 1445
I2C1 Field 1446
I2C2 Field 1447
PWM0_0 Field 1448
PWM2_0 Field 1449
SPI0_0 Field 1450
SPI1_1 Field 1451
RaspberryPi Class 1452
RaspberryPi Fields 1456
AIN0 Field 1459
AIN1 Field 1460
GPIO10 Field 1461
GPIO11 Field 1462
GPIO12 Field 1463
GPIO13 Field 1464
GPIO14 Field 1465
GPIO15 Field 1466
GPIO16 Field 1467
GPIO17 Field 1468
GPIO18 Field 1469
GPIO19 Field 1470
GPIO2 Field 1471
GPIO20 Field 1472

GPIO21 Field 1473
GPIO22 Field 1474
GPIO23 Field 1475
GPIO24 Field 1476
GPIO25 Field 1477
GPIO26 Field 1478
GPIO27 Field 1479
GPIO3 Field 1480
GPIO4 Field 1481
GPIO5 Field 1482
GPIO6 Field 1483
GPIO7 Field 1484
GPIO8 Field 1485
GPIO9 Field 1486
I2C1 Field 1487
I2C3 Field 1488
I2C4 Field 1489
I2C5 Field 1490
I2C6 Field 1491
PWM0_0 Field 1492
PWM0_1 Field 1493
SPI0_0 Field 1494
SPI0_1 Field 1495
IO.Objects.SimpleIO.PWM 1496
Output Class 1497
Output Constructor 1499
Output Properties 1501
dutycycle Property 1502
fd Property 1503

IO.Objects.SimpleIO.Servo 1504
Output Class 1505
Output Constructor 1507
Output Properties 1509
fd Property 1510
position Property 1511
IO.Objects.SimpleIO.SPI 1512
Device Class 1513
Device Constructor 1515
Device Constructor (Designator, Int32, Int32, Int32, Pin) 1516
Device Constructor (String, Int32, Int32, Int32, Pin) 1518
Device Properties 1520
fd Property 1521
Device Methods 1522
Read Method 1523
Transaction Method 1525
Write Method 1527
Device Fields 1529
AUTOCHIPSELECT Field 1530
IO.Objects.SimpleIO.syslog 1531
Logger Class 1532
Logger Constructor 1536
Logger Methods 1538
Error Method 1540
Error Method (String) 1541
Error Method (String, Int32) 1542
Note Method 1544
Register Method 1545
Warning Method 1547

Write Method 1548
WriteLine Method 1549
Logger Fields 1550
LOG_ALERT Field 1553
LOG_AUTH Field 1554
LOG_CRIT Field 1555
LOG_DAEMON Field 1556
LOG_DEBUG Field 1557
LOG_EMERG Field 1558
LOG_ERR Field 1559
LOG_INFO Field 1560
LOG_LOCAL0 Field 1561
LOG_LOCAL1 Field 1562
LOG_LOCAL2 Field 1563
LOG_LOCAL3 Field 1564
LOG_LOCAL4 Field 1565
LOG_LOCAL5 Field 1566
LOG_LOCAL6 Field 1567
LOG_LOCAL7 Field 1568
LOG_MAIL Field 1569
LOG_NDELAY Field 1570
LOG_NOTICE Field 1571
LOG_ODELAY Field 1572
LOG_PERROR Field 1573
LOG_PID Field 1574
LOG_USER Field 1575
LOG_WARNING Field 1576
Logger.Registration Enumeration 1577
IO.Objects.SimpleIO.Watchdog 1578

Timer Class 1579
Timer Constructor 1581
Timer Properties 1582
fd Property 1583
timeout Property 1584
Timer Methods 1585
Kick Method 1586
Timer Fields 1587
DefaultDevice Field 1588
DefaultTimeout Field 1589