```
13 #define BG96 AT NWKSCANSEQ "AT+QCFG=\"nwscanseq\",030201,1\r\n"
14 #define BG96 AT IOT OPMODE NB1 "AT+QCFG=\"iotopmode\",1,1\r\n"
                                                                      // Activate NB-IoT
15 #define BG96 AT IOT OPMODE CATM1 "AT+QCFG=\"iotopmode\",0,1\r\n" // Activate LTE Cat-M1
16 #define BG96 AT IOT OPMODE AUTO "AT+QCFG=\"iotopmode\",2,1\r\n" //
17 #define BG96 AT CREG 2 "AT+CREG=2\r\n"
                                              // Check network info
18 #define BG96 AT CREG ASK "AT+CREG?\r\n"
19 #define BG96 AT QNWINFO "AT+QNWINFO\r\n"
20 #define BG96 AT CSQ "AT+CSQ\r\n"
21 #define BG96 AT AP "AT+QICSGP=1,1,\"NB-IOT\",\"\",\"\",0\r\n"
22 //#define BG96 AT AP "AT+QICSGP=1,1,\"NBIOT.TELIA.EE\",\"\",\"\",0\r\n"
23 #define BG96 AT QIACT 1 "AT+QIACT=1\r\n"
24 #define BG96 AT QIACT ASK "AT+QIACT?\r\n"
25 #define BG96 AT QIDEACT "AT+QIDEACT=1\r\n" //drop context;
26 #define BG96 AT SERVICE MODE "AT+QCFG=\"servicedomain\",1,1\r\n"
27 #define BLE BUAD "AT+BAUD\r\n"
28 #define BG96 AT COPS ASK "AT+COPS?\r\n"
29 #define BG96 AT "AT\r\n"
30 #define BG96 ATI3 "ATI\r\n"
31 #define BG96 URL CHARACTERS "AT+QHTTPURL=95,80\r\n"
32 //I changed the API here
33 #define BG96 URL TOKEN "http://industrial.api.ubidots.com/api/devices/device 4?teke
                                                                                      ==aVlo3Bug6KIJgeQM0bjIpkKkOtfe07\r\n"
34 //#derine BG96 UKL 10KEN "http://things.ubidots.com/api/vi.6/devices/bg96?token=AlE-g3U10M5WB/M/s82/HqtAgsUWNWmnnp\r\n
35 #define BG96 HTTP POST "AT+QHTTPPOST=7,80,80\r\n"
36 #define BG96 HTTP POST RSSI "AT+QHTTPPOST=8,80,80\r\n"
37 #define BG96 HTTP POST RSRP "AT+QHTTPPOST=8,80,80\r\n"
38 #define BG96 HTTP POST RSRQ "AT+QHTTPPOST=8,80,80\r\n"
39 #define BG96 HTTP POST SNR "AT+QHTTPPOST=7,80,80\r\n"
40 #define BG96 HTTP POST TECH "AT+QHTTPPOST=12,80,80\r\n"
41 #define BG96 TEMP "AT+QTEMP\r\n"
42 #define BG96 HTTP RESPONSE CODE "AT+QHTTPREAD=80\r\n"
43 #define BG96 AIRPLANE MODE ON "AT+CFUN=4\r\n"
44 #define BG96 AIRPLANE MODE OFF "AT+CFUN=1\r\n"
45 #define BG96 POWER DOWN "AT+QPOWD=1\r\n" //Normal power down 1, Immediately power down 0
46 #define BG96 SIGNAL STRENGTH "AT+QCSQ\r\n"
47 #define BG96 AT AP INTERNET "AT+QICSGP=1,1,\"NBIOT.TELIA.EE\",\"\",\"\",0\r\n"
48
49 //#define BG96 AT AP INTERNET "AT+QICSGP=1,1,\"internet.emt.ee\",\"\",\"\",0\r\n"
50 #define BG96 AT PIN "AT+CPIN=0000\r\n"
51 #define BG96 AT BAND NB 20 "AT+QCFG=\"band\",f,8000,a0e189f\r\n" //GSM,NB,CATM -> all,band20,all
53 #define BG96 AT PREPARE UDP PCKT "AT+QIOPEN=1,0,\"UDP\",\"169.55.61.243\",9012,0,1\r\n"
54
55 #define BG96 AT SEND UDP PCKT "AT+QISEND=0\r\n"
56 #define BG96 DATA STRING "Test/1.0|POST|BBFF-aVlo3Bug6KIJgeQM0bjIpkKkOtfe07|device 6:Device 6=>"
57
58 #define BG96 AT CRTL Z "\x1A"
59 #define BG96 AT CLOSE "AT+QICLOSE=0\r\n"
60 #define BG96 ID "157036"//(157039) 18\n\n201,-10,-75,157030"; 18= Lenght of the packets, 201=ID in middleware, -10 data, -75, data, 57030 ID.
61 #define BG96 Distance "148"//meters
62 #define BG96 AT PING "AT+QPING=1,\"169.55.61.243\"\r\n"
63
```