ENPM 667 Final Project

Controller Design for Double Pendulum Crane System




Pooja Kabra 117032444 December 2020

Table of Contents

System Model	3
State Space Representation	
Linearization of the Non-Linear System	10
Controllability of the Linearized System	12
Linear Quadratic Regulator Design	14
Observability of the Linearized System	20
Luenberger Observer Design	22
Linear Quadratic Gaussian Controller Design	25

System Model




Kinetic Energy for Mass M

$$T_C = \frac{1}{2}M\dot{x^2}$$

Kinetic Energy for Mass m_1

Angular velocity of m_1 is given by $l_1\dot{\theta_1}$ in the tangential direction.

 \dot{x} is the forward velocity of support.



$$v_1 = (\dot{x} - l_1 \dot{\theta_1} \cos \theta_1) \hat{\imath} + (l_1 \dot{\theta_1} \sin \theta_1) \hat{\jmath}$$

$$v_1^2 = (\dot{x} - l_1\dot{\theta}_1\cos\theta_1)^2 + (l_1\dot{\theta}_1\sin\theta_1)^2$$

$$= \dot{x}^2 + l_1^2\dot{\theta}_1^2\cos^2\theta_1 - 2\dot{x}\,l_1\dot{\theta}_1\cos\theta_1 + l_1^2\dot{\theta}_1^2\sin^2\theta_1$$

$$= \dot{x}^2 + l_1^2\dot{\theta}_1^2 - 2\dot{x}\,l_1\dot{\theta}_1\cos\theta_1$$

$$T_{1} = \frac{1}{2}m_{1}v_{1}^{2}$$

$$T_{1} = \frac{1}{2}m_{1}\dot{x}^{2} + \frac{1}{2}m_{1}l_{1}^{2}\dot{\theta}_{1}^{2} - m_{1}\dot{x}l_{1}\dot{\theta}_{1}\cos\theta_{1}$$

Kinetic Energy for Mass m_2

On the same lines as m_1 , we obtain for m_2

$$T_2 = \frac{1}{2}m_2 \dot{x}^2 + \frac{1}{2}m_2 l_2^2 \dot{\theta_2}^2 - m_2 \dot{x} l_2 \dot{\theta_2} \cos \theta_2$$

Total Kinetic Energy of the System

$$T = T_C + T_1 + T_2$$

$$T = \frac{1}{2}(M + m_1 + m_2)\dot{x}^2 + \frac{1}{2}m_1l_1^2\dot{\theta}_1^2 + \frac{1}{2}m_2l_2^2\dot{\theta}_2^2 - \dot{x}(m_1 l_1\dot{\theta}_1\cos\theta_1 + m_2 l_2\dot{\theta}_2\cos\theta_2)$$

Potential Energy for Mass M

$$U_C = 0$$

Potential Energy for Mass m_1

0.2

0.3

0.4

0.5

We assume the cart height as reference for calculating potential energy.

$$U_1 = -m_1 g \ l_1 \cos \theta_1$$

Potential Energy for Mass m_2

$$U_2 = -m_2 g \, l_2 \cos \theta_2$$

0.7

Total Potential Energy of the System

$$U = U_C + U_1 + U_2 = -m_1 g l_1 \cos \theta_1 - m_2 g l_2 \cos \theta_2$$

0.8

Lagrangian Function

$$L = T - U$$

$$L = \frac{1}{2}\bar{M}\dot{x}^2 + \frac{1}{2}m_1l_1^2\dot{\theta_1}^2 + \frac{1}{2}m_2l_2^2\dot{\theta_2}^2 - \dot{x}(m_1l_1\dot{\theta_1}\cos\theta_1 + m_2l_2\dot{\theta_2}\cos\theta_2) - m_1gl_1\cos\theta_1 - m_2gl_2\cos\theta_2$$

where
$$\overline{M} = M + m_1 + m_2$$

0.9

The generalized coordinates in our given system are x, θ_1 , θ_2

The Euler - Lagrangian equations are given as

$$\frac{d}{dt}\left(\frac{\partial L}{\partial \dot{x}}\right) - \frac{\partial L}{\partial x} = F$$

0.10

$$\frac{\partial L}{\partial \dot{x}} = \overline{M}\ddot{x} - m_1 \, l_1 \dot{\theta_1} \cos \theta_1 - m_2 \, l_2 \dot{\theta_2} \cos \theta_2$$

$$\frac{d}{dt} \left(\frac{\partial L}{\partial \dot{x}} \right) = \overline{M} \ddot{x} - m_1 \, l_1 \, \dot{\theta_1} \, \cos \theta_1 + m_1 \, l_1 \dot{\theta_1}^2 \sin \theta_1 - m_2 \, l_2 \dot{\theta_2} \, \cos \theta_2 + m_2 \, l_2 \dot{\theta_2}^2 \sin \theta_2$$

$$\frac{\partial L}{\partial x} = 0$$

$$\bar{M}\ddot{x} - m_1 \, l_1 \, \dot{\theta_1} \, \cos \theta_1 + m_1 \, l_1 \dot{\theta_1}^2 \sin \theta_1 - m_2 \, l_2 \dot{\theta_2} \, \cos \theta_2 + m_2 \, l_2 \dot{\theta_2}^2 \sin \theta_2 = F$$

$$\frac{d}{dt}\left(\frac{\partial L}{\partial \dot{\theta_1}}\right) - \frac{\partial L}{\partial \theta_1} = 0$$

0.12

$$\frac{\partial L}{\partial \dot{\theta_1}} = m_1 \, l_1^2 \dot{\theta_1} - \dot{x} m_1 l_1 \cos \theta_1$$

$$\frac{d}{dt}\left(\frac{\partial L}{\partial \dot{\theta_1}}\right) = m_1 l_1^2 \dot{\theta_1} - \ddot{x} m_1 l_1 \dot{\theta_1} \cos \theta_1 + \dot{x} m_1 l_1 \dot{\theta_1} \sin \theta_1$$

$$\frac{\partial L}{\partial \theta_1} = \dot{x} m_1 l_1 \dot{\theta_1} \sin \theta_1 - m_1 g \ l_1 \sin \theta_1$$

$$m_1 l_1^2 \ddot{\theta_1} - \ddot{x} m_1 l_1 \dot{\theta_1} \cos \theta_1 + m_1 g l_1 \sin \theta_1 = 0$$

0.13

$$\frac{d}{dt}\left(\frac{\partial L}{\partial \dot{\theta_2}}\right) - \frac{\partial L}{\partial \theta_2} = 0$$

0.14

$$m_2 l_2^2 \dot{\theta_2} - \ddot{x} m_2 l_2 \dot{\theta_2} \cos \theta_2 + m_2 g l_2 \sin \theta_2 = 0$$

0.15

Solving **1.11** for \ddot{x} ,

$$\ddot{x} = \frac{F + m_1 l_1 \ddot{\theta_1} \cos \theta_1 - m_1 l_1 \dot{\theta_1}^2 \sin \theta_1 + m_2 l_2 \ddot{\theta_2} \cos \theta_2 - m_2 l_2 \dot{\theta_2}^2 \sin \theta_2}{\overline{M}}$$

0.16

Solving **1.13** for $\dot{\theta_1}$

$$\ddot{\theta_1} = \frac{\ddot{x}\cos\theta_1 - g\sin\theta_1}{l_1}$$

Solving **1.15** for $\ddot{\theta_2}$,

$$\ddot{\theta_2} = \frac{\ddot{x}\cos\theta_2 - g\sin\theta_2}{l_2}$$

State Space Representation

The state vector can be written as

$$X = \begin{bmatrix} x \\ \dot{x} \\ \theta_1 \\ \dot{\theta_1} \\ \theta_2 \\ \dot{\theta_2} \end{bmatrix} \qquad \text{Hence, } \dot{X} = \begin{bmatrix} \dot{x} \\ \ddot{x} \\ \dot{\theta_1} \\ \ddot{\theta_1} \\ \dot{\theta_2} \\ \dot{\theta_2} \end{bmatrix} = \begin{bmatrix} f_1 \\ f_2 \\ f_3 \\ f_4 \\ f_5 \\ f_6 \end{bmatrix}$$

 f_1 , f_2 , f_3 are readily in terms of state variables.

Substituting for $\ddot{\theta_1}$ and $\ddot{\theta_2}$ in the equation for \ddot{x} , we can write \ddot{x} in terms of state variables.

From **1.16**, **1.17** and **1.18**, we obtain

$$\ddot{x} = \frac{F - m_1 g \sin \theta_1 \cos \theta_1 - m_2 g \sin \theta_2 \cos \theta_2 - m_1 l_1 \dot{\theta_1}^2 \sin \theta_1 - m_2 l_2 \dot{\theta_2}^2 \sin \theta_2}{\overline{M} - m_1 \cos^2 \theta_1 - m_2 \cos^2 \theta_2}$$

$$= f_2$$

0.1

We can compute functions for f_4 and f_6 by substituting \ddot{x} obtained in **1.19** back in **1.16** and **1.17**.

Below is the MATLAB code snippet to find $f_4 = \ddot{\theta_1}$ and $f_6 = \ddot{\theta_2}$

```
clc

syms M m1 m2 g 11 12 x xd th1 th1d th1dd th2 th2dd F

syms f1 f2 f3 f4 f5 f6

xdd_num = F- m1*g*sin(th1)*cos(th1)- m2*g*sin(th2)*cos(th2)-
    m1*11*(th1d^2)*sin(th1)- m2*12*(th2d^2)*sin(th2);
    xdd_den = (M+m1+m2) - m1*(cos(th1))^2 - m2*(cos(th2))^2;
    xdd = xdd_num/xdd_den;

th1dd= (xdd*cos(th1)-g*sin(th1))/11;
disp('th1dd = ');
pretty(th1dd);

th2dd= (xdd*cos(th2)-g*sin(th2))/12;
disp('th2dd = ');
```

pretty(th2dd);

Linearization of the Non-Linear System

We now compute A_f matrix for the linearized system by taking the gradient of \dot{X} with respect to the state variables

Af =
$$\begin{bmatrix} \frac{\partial f_1}{\partial x_1} & \frac{\partial f_1}{\partial x_2} & \frac{\partial f_1}{\partial x_3} & \frac{\partial f_1}{\partial x_4} & \frac{\partial f_1}{\partial x_5} & \frac{\partial f_1}{\partial x_6} \\ \frac{\partial f_2}{\partial x_1} & \frac{\partial f_2}{\partial x_2} & \frac{\partial f_2}{\partial x_3} & \frac{\partial f_2}{\partial x_4} & \frac{\partial f_2}{\partial x_5} & \frac{\partial f_2}{\partial x_6} \\ \frac{\partial f_3}{\partial x_1} & \frac{\partial f_3}{\partial x_2} & \frac{\partial f_3}{\partial x_3} & \frac{\partial f_3}{\partial x_4} & \frac{\partial f_3}{\partial x_5} & \frac{\partial f_3}{\partial x_6} \\ \frac{\partial f_4}{\partial x_1} & \frac{\partial f_4}{\partial x_2} & \frac{\partial f_4}{\partial x_3} & \frac{\partial f_4}{\partial x_4} & \frac{\partial f_4}{\partial x_5} & \frac{\partial f_4}{\partial x_6} \\ \frac{\partial f_5}{\partial x_1} & \frac{\partial f_5}{\partial x_2} & \frac{\partial f_5}{\partial x_3} & \frac{\partial f_5}{\partial x_4} & \frac{\partial f_5}{\partial x_5} & \frac{\partial f_5}{\partial x_6} \\ \frac{\partial f_6}{\partial x_1} & \frac{\partial f_6}{\partial x_2} & \frac{\partial f_6}{\partial x_3} & \frac{\partial f_6}{\partial x_4} & \frac{\partial f_6}{\partial x_5} & \frac{\partial f_6}{\partial x_6} \\ \frac{\partial f_6}{\partial x_1} & \frac{\partial f_6}{\partial x_2} & \frac{\partial f_6}{\partial x_3} & \frac{\partial f_6}{\partial x_4} & \frac{\partial f_6}{\partial x_5} & \frac{\partial f_6}{\partial x_6} \\ \frac{\partial f_6}{\partial x_1} & \frac{\partial f_6}{\partial x_2} & \frac{\partial f_6}{\partial x_3} & \frac{\partial f_6}{\partial x_4} & \frac{\partial f_6}{\partial x_5} & \frac{\partial f_6}{\partial x_6} \\ \frac{\partial f_6}{\partial x_1} & \frac{\partial f_6}{\partial x_2} & \frac{\partial f_6}{\partial x_3} & \frac{\partial f_6}{\partial x_4} & \frac{\partial f_6}{\partial x_5} & \frac{\partial f_6}{\partial x_6} \\ \frac{\partial f_6}{\partial x_1} & \frac{\partial f_6}{\partial x_2} & \frac{\partial f_6}{\partial x_3} & \frac{\partial f_6}{\partial x_4} & \frac{\partial f_6}{\partial x_5} & \frac{\partial f_6}{\partial x_6} \\ \frac{\partial f_6}{\partial x_1} & \frac{\partial f_6}{\partial x_2} & \frac{\partial f_6}{\partial x_3} & \frac{\partial f_6}{\partial x_4} & \frac{\partial f_6}{\partial x_5} & \frac{\partial f_6}{\partial x_6} \\ \frac{\partial f_6}{\partial x_1} & \frac{\partial f_6}{\partial x_2} & \frac{\partial f_6}{\partial x_3} & \frac{\partial f_6}{\partial x_4} & \frac{\partial f_6}{\partial x_5} & \frac{\partial f_6}{\partial x_6} \\ \frac{\partial f_6}{\partial x_1} & \frac{\partial f_6}{\partial x_2} & \frac{\partial f_6}{\partial x_3} & \frac{\partial f_6}{\partial x_4} & \frac{\partial f_6}{\partial x_5} & \frac{\partial f_6}{\partial x_5} \\ \frac{\partial f_6}{\partial x_1} & \frac{\partial f_6}{\partial x_2} & \frac{\partial f_6}{\partial x_3} & \frac{\partial f_6}{\partial x_4} & \frac{\partial f_6}{\partial x_5} & \frac{\partial f_6}{\partial x_5} \\ \frac{\partial f_6}{\partial x_1} & \frac{\partial f_6}{\partial x_2} & \frac{\partial f_6}{\partial x_3} & \frac{\partial f_6}{\partial x_4} & \frac{\partial f_6}{\partial x_5} & \frac{\partial f_6}{\partial x_5} \\ \frac{\partial f_6}{\partial x_1} & \frac{\partial f_6}{\partial x_2} & \frac{\partial f_6}{\partial x_3} & \frac{\partial f_6}{\partial x_4} & \frac{\partial f_6}{\partial x_5} & \frac{\partial f_6}{\partial x_5} \\ \frac{\partial f_6}{\partial x_1} & \frac{\partial f_6}{\partial x_2} & \frac{\partial f_6}{\partial x_3} & \frac{\partial f_6}{\partial x_4} & \frac{\partial f_6}{\partial x_5} & \frac{\partial f_6}{\partial x_5} \\ \frac{\partial f_6}{\partial x_1} & \frac{\partial f_6}{\partial x_2} & \frac{\partial f_6}{\partial x_3} & \frac{\partial f_6}{\partial x_4} & \frac{\partial f_6}{\partial x_5} & \frac{\partial f_6}{\partial x_5} \\ \frac{\partial f_6}{\partial x_1} & \frac{\partial f_6}{\partial x_2} & \frac{\partial f_6}{\partial x_3} & \frac{\partial f_6}{\partial x_4} & \frac{\partial f_6}{\partial x_5} & \frac{\partial$$

and $\boldsymbol{B_f}$ matrix by taking the gradient of \dot{X} with respect to input F

$$B_{f} = \begin{bmatrix} \frac{\partial f_{1}}{\partial F} \\ \frac{\partial f_{2}}{\partial F} \\ \frac{\partial f_{3}}{\partial F} \\ \frac{\partial f_{4}}{\partial F} \\ \frac{\partial f_{5}}{\partial F} \\ \frac{\partial f_{6}}{\partial F} \end{bmatrix}_{(\dot{x}=0,\theta_{1}=0,\theta_{2}=0)}$$

Below is the MATLAB code snippet to obtain A_f and B_f .

```
f1=xd;
f2 = xdd;
f3 = th1d;
f4= th1dd;
f5= th2d;
f6= th2dd;
f = [f1 \ f2 \ f3 \ f4 \ f5 \ f6];
q = [x xd th1 th1d th2 th2d];
u = [F];
q val = [0 0 0 0 0 0];
A j = jacobian(f, q);
A_f = subs(A_j, q, q_val);
% A f in symbolic form
disp('A f = ');
disp(A f);
B j = jacobian(f, u);
B f = subs(B j, q, q val);
% B f in symbolic form
disp('B f = ');
disp(B f);
```

Command Window

```
Af =
[ 0, 1,
                       0, 0,
                                             0, 0]
[ 0, 0,
                -(g*m1)/M, 0,
                                     -(g*m2)/M, 0]
[ 0, 0,
                       0, 1,
                                             0, 0]
[0, 0, -(g + (g*m1)/M)/11, 0, -(g*m2)/(M*11), 0]
[ 0, 0,
                       0, 0,
                                             0, 1]
[ 0, 0,
         -(g*m1)/(M*12), 0, -(g + (g*m2)/M)/12, 0]
Bf =
       0
     1/M
       0
 1/(M*11)
 1/(M*12)
```

Controllability of the Linearized System

$$C = [B AB A^2B \dots A^{n-1}B]$$

A continuous time-invariant linear state-space model is controllable if and only if

$$rank(C) = n$$

where n is the number of state variables.

Here because we have only one input, our C matrix will be a square matrix of $n \times n$ dimension. A square matrix is full rank if and only if its determinant is nonzero

```
CO = [B_f A_f*B_f (A_f^2)*B_f (A_f^3)*B_f (A_f^4)*B_f (A_f^5)*B_f];
disp('det(CO) = ');
pretty(det(CO))
```

Command Window

It is easy to observe that

$$l_1^2 - 2l_1l_2 + l_2^2 \neq 0$$

 $(l_1 - l_2)^2 \neq 0$
 $\therefore l_1 \neq l_2$

Thus, for the system to be controllable lengths of cables should not be same for the two masses.

Below is the MATLAB code snippet to check controllability. As we have 6 state variables, Rank = 6 implies our system is controllable.

```
p = [M m1 m2 l1 l2 g];
p_val = [1000 100 100 20 10 10];
% A_f in double form
A_f = double(subs(A_f, p, p_val));
% B_f in double form
B_f = double(subs(B_f, p, p_val));

Co = ctrb(A_f,B_f);
disp('Co = ');
disp(Co);
disp('rank(Co) = ');
disp(rank(Co));
```

Command Window

```
Co =
 1.0e-03 *
        1.0000 0 -0.1500 0 0.1475
     0
        0 -0.1500 0 0.1475
  1.0000
       0.0500
              0 -0.0325
                          0 0.0236
  0.0500
        0 -0.0325 0
                          0.0236
        0.1000 0 -0.1150 0 0.1298
     0
  0.1000
        0 -0.1150
                    0 0.1298
rank(Co) =
   6
```

Linear Quadratic Regulator Design

The objective of LQR control design is to minimize the quadratic cost function given as

$$J = \int_0^\infty x(\tau)^T Q x(\tau) + u(\tau)^T R u(\tau) d\tau$$

where x and u are the state and control of the LTI system.

$$Q \succeq 0$$
, $R \succ 0$;

(A, B) are stabilizable

Regardless of the values of Q and R

matrices *J* has a unique minimum that can be obtained by solving the Algebraic Riccati Equation:

$$A^{T}X + XA - XBR^{-1}B^{T}X + Q = 0.$$

 $for u(t) = -kx(t),$
 $K = R^{-1}B^{T}P$

Q and R are our design parameters that we adjust depending on whether we want to penalize state variables or control variables. A large value of Q implies we want the system to stabilize with minimum changes in state variables. On the other hand, a small R means our input is inexpensive and we can afford to spend large(weighted) energy to stabilize our system.[1]

The eigen values of the linearized system matrix $\boldsymbol{A_f}$ before applying LQR are:

```
poles = eigs(A_f);
disp(poles);
```

```
0.0000 + 1.0531i

0.0000 - 1.0531i

0.0000 + 0.7356i

0.0000 - 0.7356i

0.0000 + 0.0000i

0.0000 + 0.0000i
```

All eigen values are on the imaginary axis. Thus, the system will produce sustained oscillations on the output.

MATLAB Code snippet and Simulation For Linearized System:

```
% Q matrix
Q = zeros(6);
Q(1,1) = 100; % moderate penalty on x
Q(2,2) = 1;
Q(3,3) = 10000000; % high penalty on th1
Q(4,4) = 1;
Q(5,5) = 1000000; % high penalty on th2
Q(6,6) = 1;
% R matrix
R = 0.01; % inexpensive F
% full state feedback gain
K = lqr(A f, B f, Q, R);
% closed loop system gain
Ac = (A_f - B_f*K);
% output variables: x,th1,th2
C = [1 \ 0 \ 0 \ 0 \ 0; \ 0 \ 0 \ 1 \ 0 \ 0; \ 0 \ 0 \ 0 \ 1 \ 0];
D = [0];
% Plant + LQR
LQR sys = ss(Ac, B f, C, D);
```

The eigen values of the linearized system matrix A_f before applying LQR are:

```
% initial conditions
X0 = [10 0 pi/2 0 pi/6 0]


time= 0:0.1:100
[y,t,x]=initial(LQR_sys,X0,time);
plot(t,y);

% Lyapunov's indirect method after LQR
poles_c = eigs(Ac);
disp(poles_c);
```


The eigen values of the linearized system matrix $A_f - B_f K$ after applying LQR are:

```
Command Window


-0.4762 + 1.1385i
-0.4762 - 1.1385i
-0.1233 + 0.7700i
-0.1233 - 0.7700i
-0.1599 + 0.1686i
-0.1599 - 0.1686i
```



MATLAB Code snippet and Simulation For Non-Linear System:



```
MATLAB Function × +
     2
 3 -
        M = 1000; % mass of cart
 4 - 5 -
       m1 = 100; % mass 1
        m2 = 100; % mass 2
 6 -
       11 = 20; % cable length of first pendulum 20
 7 –
8 –
       12 = 10; % cable length of second pendulum 10
        g = 10; % acceleration due to gravity
9
10
11 -
12 -
13 -
         \text{xdd num} = \text{F-} \ \text{m1*g*sin(th1)*cos(th1)} - \ \text{m2*g*sin(th2)*cos(th2)} - \ \text{m1*11*(th1d^2)} \\ \text{*sin(th1)} - \ \text{m2*12*(th2d^2)*sin(th2)}; 
        xdd_{den} = (M+m1+m2) - m1*(cos(th1))^2 - m2*(cos(th2))^2;
        xdd = xdd_num/xdd_den;
14
15 -
16
17 -
18
        th1dd= (xdd*cos(th1)-g*sin(th1))/l1;
        th2dd= (xdd*cos(th2)-g*sin(th2))/12;
19
20 -
        f1= xd;
21 -
        f2= xdd;
22 -
        f3= th1d;
23 -
        f4= th1dd;
24 -
        f5= th2d;
25 -
      f6= th2dd;
```



Observability of the Linearized System

For time-invariant linear systems, if the row rank of the observability matrix, defined as

is equal to \boldsymbol{n} , then the system is observable.

$$rank(0) = n$$

where n is the number of state variables.

We have four cases of the output variables.

Case 1: *x*

$$C_1 = \begin{bmatrix} 1 & 0 & 0 & 0 & 0 \end{bmatrix}$$

Case 2: θ_1 , θ_2

$$C_2 = \begin{bmatrix} 0 & 0 & 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 1 & 0 \end{bmatrix}$$

Case 3: x, θ_2

$$C_3 = \begin{bmatrix} 1 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 1 & 0 \end{bmatrix}$$

Case 4: x, θ_1 , θ_2

$$C_4 = \begin{bmatrix} 1 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 & 0 \end{bmatrix}$$

```
C1 = [1 0 0 0 0 0];
C2 = [0 \ 0 \ 1 \ 0 \ 0 \ 0; \ 0 \ 0 \ 0 \ 1 \ 0];
C3 = [1 \ 0 \ 0 \ 0 \ 0; \ 0 \ 0 \ 0 \ 1 \ 0];
C4 = [1 \ 0 \ 0 \ 0 \ 0; \ 0 \ 0 \ 1 \ 0 \ 0; \ 0 \ 0 \ 0 \ 1 \ 0];
O1 = obsv(A f,C1);
disp('rank(O1) = ');
disp(rank(01));
O2 = obsv(A_f,C2);
disp('rank(O2) = ');
disp(rank(02));
O3 = obsv(A f,C3);
disp('rank(O3) = ');
disp(rank(03));
O4 = obsv(A f,C4);
disp('rank(O4) = ');
disp(rank(04));
```

```
Command Window

rank(O1) = 6

rank(O2) = 4

rank(O3) = 6

rank(O4) = 6
```

Thus, the system is not observable for output vector [$oldsymbol{ heta}_1$, $oldsymbol{ heta}_2$].


Luenberger Observer Design

MATLAB Code snippet and Simulation For Linearized System:

```
Poles_Luen = [-200 -300 -100 -60 -20 -4]';


% Output variables: x
C1 = [1 0 0 0 0 0];
L = place(A_f',C1',Poles_Luen)';
Luen_sys = ss(A_f-L*C1,B_f,C1,D);
% initial conditions
X0 = [10 0 pi/2 0 pi/6 0];

time= 0:0.1:100;
[y,~,x]=initial(Luen_sys,X0,time);
step(Luen_sys);
title('Luenberger Observer on Linearized System: y=[x]')
```




```
% Output variables: x, th2
C3 = [1 0 0 0 0 0; 0 0 0 0 1 0];
L = place(A_f',C3',Poles_Luen)';
Luen_sys = ss(A_f-L*C3,B_f,C3,D);
% initial conditions
X0 = [10 0 pi/2 0 pi/6 0];


time= 0:0.1:100;
[y,~,x]=initial(Luen_sys,X0,time);
step(Luen_sys);
title('Luenberger Observer on Linearized System: y=[x th2]')
```




```
% Output variables: x, th1, th2
C4 = [1 0 0 0 0 0; 0 0 1 0 0 0; 0 0 0 0 1 0];
L = place(A_f',C4',Poles_Luen)';
Luen_sys = ss(A_f-L*C4,B_f,C4,D);
% initial conditions
X0 = [10 0 pi/2 0 pi/6 0];
time= 0:0.1:100;
[y,~,x]=initial(Luen_sys,X0,time);
step(Luen_sys);
title('Luenberger Observer on Linearized System: y=[x th1 th2]')
```



Linear Quadratic Gaussian Controller Design



Inside the subsystem:



References

 $[1] https://www.researchgate.net/post/how_to_determine_the_values_of_the_control_matrices_Q_and_R_for_the_LQR_strategy_when_numerically_simulating_the_semi-active_TLCD#:~:text=The%20parameters%20Q%20and%20R,with%20less%20(weighted)%20energy$