

5432 Bent Pine Rd. Athens, AL 35614 256-777-4002



Hydraulic Telescopic Crane

	Hydraulic Telescopi	c Crane		Date Wed 4/29/2009
Manufacturer: GROVE	Model: RT-530E	Seria	No: 220262	Unit No: N/A
HrsUp: 5058 HrsLo: p90	Inspector: Greg Beam	Certif	ication: 08-6333	No: T610001898
Location: At their shop in Decatur, A	L byt Owner/Use	r: ER's o	company	
KEY: OK - Satisfactory	X - Unsatisfactory, recommend	l repair o	r replacement N	/A - Not Applicable
(1) General Appearance		Key		Remarks
A. Paint		OK	Solley Grove 220262	
B. Sheet Metal		OK	Take #2	
C. Walkway, Ladder, Steps		OK	Test #3	
D. House Keeping		OK		
(2) Safety Items				
A. Load charts (are they readable)		X	See Deficiences Report Item No) 2-A
B. Boom angle indicators		OK		
C. A2B System (TEST)		OK		
D. LMI System (TEST)		OK		
E. Crane controls (are they labeled)		OK		
F. Neutral start switch		OK		
G. Back up alarm		OK		
H. Operation of horn		OK		
I. Lights		OK		
J. Safety decals		OK		
K. Fire extinguishers		X	See Deficiences Report Item No) 2-K
L. Machinery guards		OK		
M. Condition & operation of A2B reel		OK		
(3) Power Plants				
A. Condition of fan		OK		
B. Condition of radiator		OK		
C. Belts & Hoses		OK		
D. Filters: oil, fuel, air		OK		
E. Engine oil level		OK		
F. Mounting of engine (motor mounts)		OK		
G. Exhaust system (check all connection	ns & muffler	OK		
H. Leaks (water, oil, fuel)		OK		
(4) Air Compressor				
A. Safety valve		N/A		
B. Belts		N/A		
C. Filters (connected to air cleaner)		N/A		
D. General condition		N/A		
E. Pressure check (gauge in cab)		N/A		
F. Moisture ejectors		N/A		

A. Condition of hoist brake & brake control system

(5) Main Hoist Winch

OK

Hydraulic Telescopic Crane

(5) Main Hoist Winch (Continued)	Key	Remarks
B. Condition of hoist two speed & control system	X	See Deficiences Report Item No 5-B
C. Condition of hoist hydraulic motor or motors (leaks)	OK	
D. Operation of Hoist	OK	
E. Hoist hydraulic circuit pressure	OK	
F. Check for abnormal noises, look for leaks, look at cable spooling	OK	
G. Check drum feeler mounting & operation	OK	
H. Condition & operation of cable follower	X	See Deficiences Report Item No 5-H
I. Condition & function of main hoist paw	N/A	
(6) Auxiliary Hoist Winch		
A. Condition of hoist brake & brake control system	N/A	
B. Condition of hoist two speed & control system	N/A	
C. Condition of hoist hydraulic motor or motors (leaks)	N/A	
D. Operation of Hoist	N/A	
E. Hoist hydraulic circuit pressure	N/A	
F. Check for abnormal noises, look for leaks, look at cable spooling	N/A	
G. Check drum feeler mounting & operation	N/A	
H. Condition & operation of cable follower	N/A	
I. Condition & function of auxiliary main hoist paw	N/A	
(7) Swing	1	
A. Condition of house lock	OK	
B. Condition of swing brake	OK	
C. Control linkage & pins	OK	
D. Condition of swing hydraulic motor	OK	
E. Condition of swing reduction gear box & mounting	X	See Deficiences Report Item No 7-E
F. Condition of rotex bearing	OK	
G. Randomly check bearing bolts for torque	OK	
H. Check condition of pinion gear & rotex gear	OK	
I. Check lubrication of rotex bearing & pinion gear	OK	
J. Condition of 360 degree swing lock	X	See Deficiences Report Item No 7-J
(8) Swivel Area (Air, Electrical, HYD.)		
A. Condition of each swivel	OK	
B. Mounting of each swivel	OK	
C. Are all lines routed properly	OK	
D. Are all lines tight and not leaking	X	See Deficiences Report Item No 8-D
E. Are electrical connection tight	OK	
F. Are any wire exposed or rubbing	OK	
(9) Boom & Jib		
A. Pivot pins & bushings	OK	
B. Boom pinning sections	N/A	
C. Sheaves & guards	OK	
D. Cable guide rollers	OK	
	1	See Deficiences Report Item No 9-E
E. Cable retaining pins F. Boom sections (Bends, Bows, Kinks, Ect.)	X	See Deficiences Report ficht No 7-E

Hydraulic Telescopic Crane

G. Upper frame work that holds boom H. Boom extension cylinders & holding valves OK Uverr pask inside & out including cable rollers or cable wear pads on top of boom. J. Boom cylinder & holding valve OK C. Check boom leaking in / down (Do brakes hold the boom, friction crane.) L. Counterweight bolts & pins OK M. Condition of jib O. Condition of Juffing jib O. Condition of laring, cords, & welds P. Boom alignment OK Q. Auxiliary boom head N/A R. Hydraulic leaks inside boom S. Condition of jib pins C. Condition of jib pins OK C. Condition of pins OK C. Condition of pins OK C. Condition & porration of hydraulic hose reel at back of boom N/A W. Condition & operation of hydraulic hose reel at back of boom N/A C. Condition of one peration of dead section N/A C. Condition of onlarger boxes and beams OK C. Condition of onlarger boxes and beams OK C. Condition of onlarger cylinders & holding valves F. Condition of all stabilizer pads & flodius E. Condition of all stabilizer pads & flodius B. Condition of our leacting subserved the subserved in an out OK C. Condition of all stabilizer pads & flodius C. Condition of electrical Control System A. Main hydraulic, and Electrical Control System A. Main hydraulic, and Electrical Control System A. Main hydraulic, and Electrical Control System A. Main hydraulic & circuit system pressures (test optional) OK C. Condition of electrical switches & solenoids (functional) OK C. Condition of olectrical switches & solenoids (functional) OK C. Condition of electrical switches & solenoids (functional) OK C. Condition of electrical switches & solenoids (functional) OK C. Condition of olectrical switches & solenoids (functional) OK C. Condition of olectrical switches & solenoids (functional) OK C. Condition of olectrical switches & solenoids (functional) OK C. Condition of olectrical switches & solenoids (functional) OK C. Condition of olectrical switches & solenoids (functional) OK C. Condition of bydraulic hose & piping (visual) OK C. Condition of hydraulic hose & piping (visual) OK	(9) Boom & Jib (Continued)	Key	Remarks
I. Wear pads inside & out including cable rollers or cable wear pads on top of boom. J. Boom cylinder & holding valve K. Check boom leaking in / down (Do brakes hold the boom, friction crane.) L. Counterweight bolts & pins M. Condition of jib N. Condition of luffing jib O. Condition of luffing jib O. Condition of lacing, cords, & welds O. Condition of lacing, cords, & welds O. Auxiliary boom head N. A R. Hydraulic leaks inside boom O. Condition of jip pins O. Condition of pinp pins O. Condition of function of boom kick out switch U. Condition of counter weight cylinders (leaking) V. Condition & operation of hydraulic hose reel at back of boom N/A W. Condition & operation of hydraulic hose reel at back of boom N/A W. Condition & operation of hydraulic hose reel at back of boom N/A W. Condition & operation of dead section N/A (10) Outrigger System A. Condition of pins, bushings, bolts, and welds C. Condition of pins, bushings, bolts, and welds D. Condition of pins, bushings, bolts, and welds C. Condition of all stabilizer pads & floats F. Condition of all stabilizer pads & floats F. Condition of outrigger boxes where beams slide in and out Ok G. Half outrigger lock area A. Main hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) O. Condition of air & hydraulic valves (functional) O. Condition of electrical swirtes & solenoids (functional) O. Condition of electrical wiring & wiring harness (visual) D. Condition of phydraulic hydraulic hoses & piping (visual) O. Condition of phydraulic pumps	G. Upper frame work that holds boom	OK	
I, Boom cylinder & holding valve K. Check boom leaking in / down (Do brakes hold the boom, friction crane.) L. Counterweight bolts & pins M. Condition of jib N. Condition of Juffing jib O. Condition of lading, cords, & welds O. Condition of lacing, cords, & welds O. Condition of lacing, cords, & welds O. R. Hydraulic leaks inside boom O. Auxiliary boom head N. Hydraulic leaks inside boom S. Condition of jib pins OK J. Condition of jib pins OK S. Condition & function of boom kick out switch U. Condition & function of boom kick out switch V. Condition of counter weight cylinders (leaking) N/A W. Condition of counter weight cylinders (leaking) N/A W. Condition & operation of hydraulic hose reel at back of boom N/A W. Condition & operation of dead section N/A III Outrigger System A. Condition of outrigger boxes and beams B. Condition of outrigger boxes and beams D. Condition of outrigger boxes and beams D. Condition of all stabilizer pads & floats E. Condition of all stabilizer pads & floats E. Condition of all stabilizer cylinders & holding valves OK D. Condition of all stabilizer pads & floats E. Condition of all stabilizer cylinders & holding valves OK D. Half ourigger boxes where beams slide in and out OK OK A. Main hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) OK C. Condition of electrical switness & solenoids (functional) OK D. Condition of electrical switness & solenoids (functional) OK C. Condition of electrical switness & solenoids (functional) OK D. Condition of playdraulic hoses & piping (visual) OK E. Condition of hydraulic pumps	H. Boom extension cylinders & holding valves	OK	
K. Check boom leaking in / down (Do brakes hold the boom, friction crane.) L. Counterweight bolts & pins M. Condition of Jib N. Condition of luffing jib N. Condition of luffing jib N. Condition of laufing, cords, & welds P. Boom alignment OK Q. Auxiliary boom head N. A R. Hydraulic leaks inside boom S. Condition of jib pins OK C. Condition of function of boom kick out switch U. Condition & function of boom kick out switch W. Condition & function of boom kick out switch W. Condition of counter weight cylinders (leaking) W. Condition & operation of hydraulic hose reel at back of boom N. A W. Condition & operation of dead section W. Condition & operation of dead section N. A W. Condition of outrigger System A. Condition of outrigger boxes and beams B. Condition of outrigger cylinders & holding valves C. Condition of all stabilizer pads & floats E. Condition of all stabilizer cylinders & holding valves D. Condition of all stabilizer cylinders & holding valves OK C. Auxiliary boom head N. A Main hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) OK D. Condition of electrical swiring & wiring harness (visual) OK D. Condition of electrical swiring & wiring harness (visual) OK D. Condition of hydraulic hoses & piping (visual) OK D. Condition of hydraulic pumps		OK	
crane.) L. Counterweight bolts & pins OK N. Condition of jib N. Condition of luffing jib N. Condition of luffing jib O. Condition of lacing, cords, & welds O. Condition of lacing, cords, & welds P. Boom alignment Ok Q. Auxiliary boom head N. Ma R. Hydraulic leaks inside boom OK S. Condition of jib pins OK T. Condition & function of boom kick out switch U. Condition & function of boom kick out switch U. Condition & of counter weight cylinders (leaking) V. Condition & operation of hydraulic hose reel at back of boom N. A W. Condition & operation of hydraulic hose reel at back of boom N. A W. Condition & operation of hydraulic hose reel at back of boom N. A W. Condition & operation of dead section V. A Condition of outrigger System A. Condition of outrigger boxes and beams OK B. Condition of outrigger boxes and beams OK C. Condition of of all stabilizer pads & floats D. Condition of all stabilizer pads & floats F. Condition of outrigger boxes where beams slide in and out OK G. Half outrigger lock area OK D. Condition of electrical control Systems A. Main hydraulic, and Electrical Control Systems A. Main hydraulic, and Electrical Control Systems A. Main hydraulic ard system pressures (test optional) OK C. Condition of electrical switches & solenoids (functional) OK C. Condition of electrical switches & solenoids (functional) OK C. Condition of hydraulic hydraulic hydraulic hoses & piping (visual) OK E. Condition of hydraulic pumps	J. Boom cylinder & holding valve	OK	
M. Condition of jib N. Condition of luffing jib N. Condition of lacing, cords, & welds P. Boom alignment OK P. Boom alignment OK N. Condition of power and N. Condition of jib pins OK S. Condition of jib pins OK S. Condition of jib pins OK T. Condition & function of boom kick out switch OK U. Condition of counter weight cylinders (leaking) N. Condition of counter weight cylinders (leaking) N. Condition of counter weight cylinders (leaking) N. Condition of operation of hydraulic hose reel at back of boom N. Condition & operation of hydraulic hose reel at back of boom N. Condition & operation of dead section N. Condition of operation of dead section N. Condition of outrigger boxes and beams OK D. Condition of outrigger boxes and beams OK C. Condition of outrigger cylinders & holding valves OK D. Condition of all stabilizer pads & floats E. Condition of all stabilizer cylinders & holding valves OK F. Condition of outrigger boxes where beams slide in and out OK G. Half outrigger lock area OK D. Condition of air & hydraulic calves (functional) OK B. Condition of air & hydraulic valves (functional) OK C. Condition of electrical switches & solenoids (functional) OK D. Condition of electrical switches & solenoids (functional) OK E. Condition of all air & hydraulic hoses & piping (visual) OK E. Condition of hydraulic pumps		OK	
N. Condition of luffing jib O. Condition of lacing, cords, & welds O. Condition of lacing, cords, & welds P. Boom alignment O. Auxiliary boom head R. Hydraulic leaks inside boom S. Condition of jib pins T. Condition & function of boom kick out switch U. Condition & function of boom kick out switch U. Condition & operation of hydraulic hose reel at back of boom W. Condition & operation of hydraulic hose reel at back of boom W. Condition & operation of dead section N/A W. Condition & operation of dead section N/A (10) Outrigger System A. Condition of outrigger boxes and beams B. Condition of opins, bushings, bolts, and welds C. Condition of outrigger cylinders & holding valves D. Condition of all stabilizer pads & floats F. Condition of all stabilizer cylinders & holding valves C. Condition of outrigger boxes where beams slide in and out G. Half outrigger lock area A. Main hydraulic & circuit system pressures (test optional) B. Condition of electrical Switches & solenoids (functional) C. Condition of electrical switches & solenoids (functional) D. Condition of electrical switches & solenoids (functional) D. Condition of electrical switches & solenoids (functional) OK E. Condition of all air & hydraulic walves & piping (visual) OK E. Condition of all air & hydraulic hoses & piping (visual) OK C. Condition of hydraulic pumps	L. Counterweight bolts & pins	OK	
O. Condition of lacing, cords, & welds P. Boom alignment Q. Auxiliary boom head N/A R. Hydraulic leaks inside boom OK S. Condition of jib pins OK T. Condition of pib pins OK U. Condition of counter weight cylinders (leaking) N/A V. Condition & operation of hydraulic hose reel at back of boom W. Condition of cable/chains inside of boom (visual check) N. Condition & operation of dead section N/A W. Condition of ourtigger boxes and beams OK B. Condition of ourtigger boxes and beams OK C. Condition of ourtigger cylinders & holding valves OK D. Condition of all stabilizer pads & floats T. Condition of all stabilizer cylinders & holding valves OK F. Condition of ourtigger boxes where beams slide in and out G. Half outrigger lock area OK D. Condition of ourtigger boxes where beams slide in and out G. Half outrigger lock area OK D. Condition of oir all & hydraulic valves (functional) C. Condition of electrical switches & solenoids (functional) C. Condition of electrical switches & solenoids (functional) D. Condition of electrical wiring & wiring harness (visual) C. Condition of hydraulic pumps OK C. Condition of hydraulic pumps	M. Condition of jib	OK	
P. Boom alignment Q. Auxiliary boom head N/A R. Hydraulic leaks inside boom S. Condition of jib pins OK T. Condition & function of boom kick out switch U. Condition & function of boom kick out switch V. Condition of counter weight cylinders (leaking) N/A V. Condition & operation of hydraulic hose reel at back of boom N/A W. Condition of cable/chains inside of boom (visual check) X. Condition & operation of dead section N/A (10) Outrigger System A. Condition of outrigger boxes and beams B. Condition of outrigger boxes and beams B. Condition of outrigger cylinders & holding valves D. Condition of all stabilizer pads & floats X. See Deficiences Report Item No 10-D E. Condition of all stabilizer cylinders & holding valves C. Condition of outrigger boxes where beams slide in and out C. Half outrigger lock area (11) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of electrical switches & solenoids (functional) D. Condition of electrical wiring & wiring harness (visual) C. Condition of all air & hydraulic hoses & piping (visual) C. Condition of hydraulic pumps OK	N. Condition of luffing jib	N/A	
Q. Auxiliary boom head R. Hydraulic leaks inside boom OK S. Condition of jib pins OK U. Condition & function of boom kick out switch W. Condition of counter weight cylinders (leaking) V. Condition & operation of hydraulic hose reel at back of boom W. Condition & operation of dead section W. Condition & operation of dead section W. Condition & operation of dead section W. Condition of outrigger System A. Condition of outrigger boxes and beams B. Condition of pins, bushings, bolts, and welds C. Condition of outrigger cylinders & holding valves D. Condition of all stabilizer pads & floats E. Condition of all stabilizer cylinders & holding valves D. Condition of outrigger boxes where beams slide in and out G. Half outrigger lock area (11) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of electrical switches & solenoids (functional) D. Condition of electrical wiring & wiring harness (visual) D. Condition of all air & hydraulic hoses & piping (visual) OK E. Condition of hydraulic pumps OK E. Condition of hydraulic pumps OK E. Condition of hydraulic pumps OK	O. Condition of lacing, cords, & welds	OK	
R. Hydraulic leaks inside boom S. Condition of jib pins OK S. Condition of jib pins OK T. Condition & function of boom kick out switch OK U. Condition of counter weight cylinders (leaking) N/A V. Condition & operation of hydraulic hose reel at back of boom N/A W. Condition & operation of hydraulic hose reel at back of boom N/A W. Condition & operation of dead section N/A Ito Outrigger System A. Condition of outrigger boxes and beams B. Condition of pins, bushings, bolts, and welds C. Condition of outrigger cylinders & holding valves D. Condition of all stabilizer pads & floats E. Condition of all stabilizer cylinders & holding valves D. Condition of outrigger boxes where beams slide in and out G. Half outrigger lock area OK Ito Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of electrical switches & solenoids (functional) C. Condition of electrical wiring & wiring harness (visual) D. Condition of all air & hydraulic hoses & piping (visual) C. Condition of hydraulic pumps OK F. Condition of hydraulic pumps OK	P. Boom alignment	OK	
S. Condition of jib pins OK T. Condition & function of boom kick out switch U. Condition & function of boom kick out switch W. Condition of counter weight cylinders (leaking) V. Condition & operation of hydraulic hose reel at back of boom W. Condition of cable/chains inside of boom (visual check) W. Condition & operation of dead section W. Condition & operation of dead section N/A (10) Outrigger System A. Condition of outrigger boxes and beams B. Condition of pins, bushings, bolts, and welds C. Condition of outrigger cylinders & holding valves D. Condition of all stabilizer pads & floats E. Condition of all stabilizer pads & floats F. Condition of outrigger boxes where beams slide in and out G. Half outrigger lock area OK (11) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of electrical switches & solenoids (functional) OK C. Condition of electrical wiring & wiring harness (visual) D. Condition of all air & hydraulic hoses & piping (visual) F. Condition of hydraulic pumps OK	Q. Auxiliary boom head	N/A	
T. Condition & function of boom kick out switch U. Condition of counter weight cylinders (leaking) V. Condition & operation of hydraulic hose reel at back of boom W. Condition of cable/chains inside of boom (visual check) W. Condition & operation of dead section W. Condition & operation of dead section N/A (10) Outrigger System A. Condition of outrigger boxes and beams B. Condition of outrigger boxes and beams OK C. Condition of outrigger cylinders & holding valves D. Condition of all stabilizer pads & floats E. Condition of all stabilizer cylinders & holding valves OK F. Condition of outrigger boxes where beams slide in and out G. Half outrigger lock area (11) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of electrical switches & solenoids (functional) C. Condition of electrical wiring & wiring harness (visual) D. Condition of all air & hydraulic hoses & piping (visual) OK F. Condition of hydraulic pumps OK	R. Hydraulic leaks inside boom	OK	
U. Condition of counter weight cylinders (leaking) V. Condition & operation of hydraulic hose reel at back of boom W. Condition of cable/chains inside of boom (visual check) W. Condition & operation of dead section N/A (10) Outrigger System A. Condition of outrigger boxes and beams B. Condition of outrigger boxes and beams B. Condition of pins, bushings, bolts, and welds C. Condition of outrigger cylinders & holding valves D. Condition of all stabilizer pads & floats E. Condition of all stabilizer pads & holding valves OK F. Condition of outrigger boxes where beams slide in and out G. Half outrigger lock area (II) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of air & hydraulic valves (functional) C. Condition of electrical wiring & wiring harness (visual) D. Condition of all air & hydraulic hoses & piping (visual) OK F. Condition of hydraulic pumps OK	S. Condition of jib pins	OK	
V. Condition & operation of hydraulic hose reel at back of boom W. Condition of cable/chains inside of boom (visual check) X. Condition & operation of dead section N/A (10) Outrigger System A. Condition of outrigger boxes and beams B. Condition of pins, bushings, bolts, and welds C. Condition of outrigger cylinders & holding valves D. Condition of all stabilizer pads & floats E. Condition of all stabilizer yelinders & holding valves OK F. Condition of outrigger boxes where beams slide in and out G. Half outrigger lock area (11) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of electrical switches & solenoids (functional) C. Condition of electrical wiring & wiring harness (visual) D. Condition of all air & hydraulic hoses & piping (visual) OK F. Condition of hydraulic pumps OK	T. Condition & function of boom kick out switch	OK	
W. Condition of cable/chains inside of boom (visual check) X. Condition & operation of dead section (10) Outrigger System A. Condition of outrigger boxes and beams B. Condition of pins, bushings, bolts, and welds C. Condition of outrigger cylinders & holding valves D. Condition of all stabilizer pads & floats E. Condition of all stabilizer cylinders & holding valves OK F. Condition of outrigger boxes where beams slide in and out G. Half outrigger lock area OK (11) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of electrical switches & solenoids (functional) C. Condition of electrical wiring & wiring harness (visual) D. Condition of all air & hydraulic hoses & piping (visual) OK F. Condition of hydraulic pumps OK	U. Condition of counter weight cylinders (leaking)	N/A	
X. Condition & operation of dead section N/A (10) Outrigger System A. Condition of outrigger boxes and beams B. Condition of pins, bushings, bolts, and welds C. Condition of outrigger cylinders & holding valves D. Condition of all stabilizer pads & floats E. Condition of all stabilizer cylinders & holding valves OK F. Condition of outrigger boxes where beams slide in and out G. Half outrigger lock area OK (11) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of air & hydraulic valves (functional) C. Condition of electrical switches & solenoids (functional) D. Condition of electrical wiring & wiring harness (visual) E. Condition of all air & hydraulic hoses & piping (visual) OK F. Condition of hydraulic pumps OK	V. Condition & operation of hydraulic hose reel at back of boom	N/A	
A. Condition of outrigger boxes and beams B. Condition of pins, bushings, bolts, and welds C. Condition of outrigger cylinders & holding valves D. Condition of all stabilizer pads & floats E. Condition of all stabilizer cylinders & holding valves OK F. Condition of outrigger boxes where beams slide in and out G. Half outrigger lock area (II) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of electrical switches & solenoids (functional) C. Condition of electrical wiring & wiring harness (visual) C. Condition of all air & hydraulic hoses & piping (visual) C. Condition of hydraulic pumps OK	W. Condition of cable/chains inside of boom (visual check)	OK	
A. Condition of outrigger boxes and beams B. Condition of pins, bushings, bolts, and welds C. Condition of outrigger cylinders & holding valves D. Condition of all stabilizer pads & floats E. Condition of all stabilizer cylinders & holding valves OK F. Condition of outrigger boxes where beams slide in and out G. Half outrigger lock area OK (11) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of air & hydraulic valves (functional) C. Condition of electrical switches & solenoids (functional) D. Condition of electrical wiring & wiring harness (visual) E. Condition of hydraulic pumps OK OK C. Condition of hydraulic pumps OK	X. Condition & operation of dead section	N/A	
A. Condition of outrigger boxes and beams B. Condition of pins, bushings, bolts, and welds C. Condition of outrigger cylinders & holding valves D. Condition of all stabilizer pads & floats E. Condition of all stabilizer cylinders & holding valves OK F. Condition of outrigger boxes where beams slide in and out G. Half outrigger lock area OK (11) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of air & hydraulic valves (functional) C. Condition of electrical switches & solenoids (functional) D. Condition of electrical wiring & wiring harness (visual) E. Condition of hydraulic pumps OK OK C. Condition of hydraulic pumps OK	(10) Outrigger System		
B. Condition of pins, bushings, bolts, and welds C. Condition of outrigger cylinders & holding valves D. Condition of all stabilizer pads & floats E. Condition of all stabilizer cylinders & holding valves OK F. Condition of outrigger boxes where beams slide in and out G. Half outrigger lock area OK (11) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of air & hydraulic valves (functional) C. Condition of electrical switches & solenoids (functional) D. Condition of electrical wiring & wiring harness (visual) C. Condition of all air & hydraulic hoses & piping (visual) C. Condition of hydraulic pumps OK		OK	
D. Condition of all stabilizer pads & floats E. Condition of all stabilizer cylinders & holding valves F. Condition of outrigger boxes where beams slide in and out G. Half outrigger lock area OK (11) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of air & hydraulic valves (functional) C. Condition of electrical switches & solenoids (functional) D. Condition of electrical wiring & wiring harness (visual) E. Condition of all air & hydraulic hoses & piping (visual) F. Condition of hydraulic pumps OK OK OK OK OK OK OK OK OK O		OK	
E. Condition of all stabilizer cylinders & holding valves F. Condition of outrigger boxes where beams slide in and out G. Half outrigger lock area OK (11) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of air & hydraulic valves (functional) C. Condition of electrical switches & solenoids (functional) D. Condition of electrical wiring & wiring harness (visual) E. Condition of hydraulic hoses & piping (visual) F. Condition of hydraulic pumps OK	C. Condition of outrigger cylinders & holding valves	OK	
E. Condition of all stabilizer cylinders & holding valves F. Condition of outrigger boxes where beams slide in and out G. Half outrigger lock area OK (11) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of air & hydraulic valves (functional) C. Condition of electrical switches & solenoids (functional) D. Condition of electrical wiring & wiring harness (visual) E. Condition of all air & hydraulic hoses & piping (visual) F. Condition of hydraulic pumps OK	D. Condition of all stabilizer pads & floats	X	See Deficiences Report Item No 10-D
G. Half outrigger lock area OK (11) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of air & hydraulic valves (functional) C. Condition of electrical switches & solenoids (functional) D. Condition of electrical wiring & wiring harness (visual) E. Condition of all air & hydraulic hoses & piping (visual) F. Condition of hydraulic pumps OK	E. Condition of all stabilizer cylinders & holding valves	OK	
(11) Air, Hydraulic, and Electrical Control Systems A. Main hydraulic & circuit system pressures (test optional) B. Condition of air & hydraulic valves (functional) C. Condition of electrical switches & solenoids (functional) D. Condition of electrical wiring & wiring harness (visual) E. Condition of all air & hydraulic hoses & piping (visual) F. Condition of hydraulic pumps OK	F. Condition of outrigger boxes where beams slide in and out	OK	
A. Main hydraulic & circuit system pressures (test optional) B. Condition of air & hydraulic valves (functional) C. Condition of electrical switches & solenoids (functional) D. Condition of electrical wiring & wiring harness (visual) E. Condition of all air & hydraulic hoses & piping (visual) F. Condition of hydraulic pumps OK OK	G. Half outrigger lock area	OK	
A. Main hydraulic & circuit system pressures (test optional) B. Condition of air & hydraulic valves (functional) C. Condition of electrical switches & solenoids (functional) D. Condition of electrical wiring & wiring harness (visual) E. Condition of all air & hydraulic hoses & piping (visual) F. Condition of hydraulic pumps OK OK	(11) Air, Hydraulic, and Electrical Control Systems	1	
C. Condition of electrical switches & solenoids (functional) D. Condition of electrical wiring & wiring harness (visual) E. Condition of all air & hydraulic hoses & piping (visual) F. Condition of hydraulic pumps OK OK		OK	
D. Condition of electrical wiring & wiring harness (visual) E. Condition of all air & hydraulic hoses & piping (visual) F. Condition of hydraulic pumps OK OK	B. Condition of air & hydraulic valves (functional)	OK	
E. Condition of all air & hydraulic hoses & piping (visual) F. Condition of hydraulic pumps OK OK	C. Condition of electrical switches & solenoids (functional)	OK	
E. Condition of all air & hydraulic hoses & piping (visual) F. Condition of hydraulic pumps OK OK	D. Condition of electrical wiring & wiring harness (visual)	OK	
		OK	
	F. Condition of hydraulic pumps	OK	
(12) RT & Truck Crane Carrier & Cab(s)	(12) RT & Truck Crane Carrier & Cab(s)	1	
A. Brakes (inspect) OK		OK	
B. Condition of parking brake X See Deficiences Report Item No 12-B	B. Condition of parking brake	X	See Deficiences Report Item No 12-B
C. Condition of all steering linkage, pins, bushings, and hydraulic cylinders, tie rods, and ends		OK	
D. Condition of hydraulic pump, mounting, leaks OK	·	OK	
E. Condition of tires, wheels, and lug nuts	E. Condition of tires, wheels, and lug nuts	OK	
F. Condition of differential and drive shafts and "U" joints OK	F. Condition of differential and drive shafts and "U" joints	OK	
G. Condition of carrier main frame (visible cracks) OK	G. Condition of carrier main frame (visible cracks)	OK	

My Inspection Company Hydraulic Telescopic Crane

(12) RT & Truck Crane Carrier & Cab(s) (Continued)	Key	Remarks
H. Condition of axle mountings and suspension	OK	
I. Condition of hydraulic suspension, leaks	OK	
J. Level of hydraulic fluid	X	See Deficiences Report Item No 12-J
K. Condition of frame support blocks (Boom Trucks)	N/A	
L. Condition of boom rest	N/A	
M. Abnormal noises & vibrations	OK	
N. Condition of tie off point at front of crane for block/ball to latch for transportation purposes	OK	
O. Air leaks	N/A	
P. Glass	OK	
Q. Condition of bubble level	OK	
R. Windshield wipers	X	See Deficiences Report Item No 12-R
S. Condition of doors, latch, open & close	X	See Deficiences Report Item No 12-S
T. Condition of mirrors, side mirrors, spot mirrors	X	See Deficiences Report Item No 12-T
U. Seat mounting	X	See Deficiences Report Item No 12-U
V. Seat belts	OK	
W. Air pressure warning device	N/A	
X. Gauges in cab (are they working)	OK	
Y. Control Identified	OK	
Z. Condition of grab rails & steps	OK	
AA. Adjustment of clutch	N/A	
AB. Condition & operation of throttle cables at right & left stations (boom trucks)	OK	
AC. Condition & operation of arm rest switch	OK	
AD. Condition & operation of cab fans	OK	
(13) Lubrication		
A. Does machine appear to be receiving adequate service and lubrication	OK	
B. Is proper oil level being maintained on all reservoirs and gear cases	OK	
(14) Miscellaneous		
A.	N/A	
B.	N/A	
C.	N/A	
(15) Wire Rope Main Hoist	'	
A. Kinks or Birdcaging	OK	
B. Correct Length	OK	
C. Rope Damage	OK	
D. Measured Wear	.652"	
E. Type of wire rope	Rot	
F. Construction	Resistant 12X16 Class	
G. Grade	EIP	
H. Core	IWRC	
I. Size	5/8"	
1. DILC	3/0	

My Inspection Company Hydraulic Telescopic Crane

Trydraulie Telescopie Crane						
(15) Wire Rope Main Hoist (Continued)	Key	Remarks				
J. Status	In					
	Servivce					
K. Size correct for this model of crane	OK					
L. Broken Wires	OK					
M. Lubrication	OK					
N. End Connections	OK					
O. Spooling condition	OK					
P. Socket wedge condition & installation	X	See Deficiences Report Item No 15-P				
(16) Wire Rope Auxiliary Hoist						
A. Kinks or Birdcaging	N/A					
B. Correct Length	N/A					
C. Rope Damage	N/A					
D. Measured Wear	N/A					
E. Type of wire rope	N/A					
F. Construction	N/A					
G. Grade	N/A					
H. Core	N/A					
I. Size	N/A					
J. Status	N/A					
K. Size correct for this model of crane	N/A					
L. Broken Wires	N/A					
M. Lubrication	N/A					
N. End Connections	N/A					
O. Spooling condition	N/A					
P. Socket wedge condition & installation	N/A					
(17) Record Keeping						
A. Load test reports	N/A					
B. Daily & monthly inspection reports	OK					
C. Repair records	OK					



5432 Bent Pine Rd. Athens, AL 35614 256-777-4002





Date Wed 4/29/2009

Manufacturer: GR	OVE	Model: RT-530E	Serial No: 220262	Unit No: N/A
HrsUp: 5058	HrsLo: p90	Inspector: Greg Beam	Certification: 08-6333	No: T610001898
Location: At their	shon in Decatur A	byt Owner/I	Isar: FR's company	•

HrsUp: 5058	HrsLo: p	90 Ins p	ector: Greg	Beam		Certification	າ: 08-6333	No: T	610001898
Location: At their	shop in Deca	itur, AL byt		Owne	er/User:	ER's compar	ny		
KEY:	OK - Satisfa	actory	X - Unsat	tisfactory	, recomn	nend repair or i	replacement	N/A	- Not Applicable
Main Block N	Model:		Make:		S	erial No:	Capacity:		Weight:
ORJ3016R	TB	JOI	HNSON 3 SH	V	ç	99-13548	30 TON		583 LBS.
(18) Main Block Con	nponent Identi	fication		Key	Remar	ks			
A. Throat Latch				X	See Defic	ciences Report Iter	n No 18-A		
B. Capacity & Weight	t Labeled			OK			1	that	
C. Sheaves & Reeving	3			OK			б		
D. Spacers				OK				Mais II	
E. Hook & Hook Shar	nks			OK			000		
F. Hook Swivel & Be	aring			OK			/m/		//
G. Total Weights (Mo	ounting)			OK			3110		//
H. Hook Throat Meas	urement			6.055"			[0 /]		/
I. 10° Hook Twist				OK			Z.	1	
J. 15% Throat Openin	g			OK			(J.	
K. 10% Hook Wear				OK					
Method used for Chec	king: Magnetic	:		Pass	Results	of Magnetic T	est: Pass		
Headache Ball	Model:		Make:		S	erial No:	Capacity:		Weight:
N/A			N/A			N/A	N/A		N/A
19) Headache Ball C	Component Ide	ntification		Key	Remar	ks			
A. Throat Latch				N/A					
B. Capacity & Weight	t Labeled			N/A					
C. Hook & Hook Sha	nks			N/A					
D. Hook Swivel & Be	aring			N/A					
E. Total Weights (Mo	unting)			X	See Defic	ciences Report Iter	n No 19-E	0	
F. Hook Throat Meast	urement			N/A					/
G. 10° Hook Twist				N/A			T	01	
H. 15% Throat Openi	ng			N/A				7	
I. 10% Hook Wear				N/A				9	
Method used for Cl	necking:			N/A					
Auxiliary M	odel:		Make:		S	erial No:	Capacity:		Weight:
N/A			N/A			N/A	N/A		N/A
20) Auxiliary Compo	onent Identific	ation		Key	Remar	ks			
A. Throat Latch				N/A					
B. Capacity & Weight				N/A					
C. Sheaves & Reeving	9			N/A					
D. Spacers				N/A			1101		49
E. Hook & Hook Shar	nks			N/A			all		PILL
F. Hook Swivel & Be	aring			N/A					
G. Total Weights (Mo	ounting)			N/A				(0)
H. Hook Throat Meas	urement			N/A			116/5	1	
I. 10° Hook Twist				N/A			W L	((0)
J. 15% Throat Openin	g			N/A			7:00	1	2/2
K. 10% Hook Wear				N/A					
H. Hook Throat Meas I. 10° Hook Twist J. 15% Throat Openin	urement			N/A N/A N/A					

Method used for Checking:

N/A



5432 Bent Pine Rd. Athens, AL 35614 256-777-4002



Date Wed 4/29/2009

Hydraulic Telescor	oic Crane
II) GIGGIE	ore Cruire

wanutad	cturer: G	ROVE		Model: RT-530E	Serial No: 220262	Unit No: N/A	
HrsUp	5058	HrsLo:	p90	Inspector Greg Beam	Certification: 08-6333	No: T610001898	

Location: At their shop in Decatur, AL byt **Owner/User:** ER's company

Model:	Make:	Serial No:	Capacity:	Weight:
ORJ3016RTB	JOHNSON 3 SHV	99-13548	30 TON	583 LBS.

Main Block

MAGNETIC PARTICLE INSPECTION

TECHNIQUE / PROCEDURE: In accordance with ASME section V article 7 and VIP-MT-V1 Rev7

ACCEPTANCE / REJECTION CRITERIA: ASME B30.10

EQUIPMENT USED FOR MAGNETIZATION: Magnaflux Y-6 Hand-Yoke / Parker Hand Yoke

MAGNETIZATION METHOD: Continuous FERROMAGNETIC PARTICLES USED: Gray

COLOR: Non-Fluorescent/Visible WET OR DRY: Dry MAGNETIZATION CURRENT: A/C

TEMPERATURE OF ITEMS INSPECTED: 75° F

TYPE OF MATERIAL AND THICKNESS: Carbon Steel – Various Thickness

LIGHTING USED: Droplight with 100 Watt Bulb and sunlight





5432 Bent Pine Rd. Athens, AL 35614 256-777-4002 Inspection Deficiency Report



Date Wed 4/29/2009

Note: Any deficiency noted by an asterisk (*) should be corrected before the machine is returned to service and all other deficiencies should be corrected within 30 days from the date this form has been completed.

Location: At their shop in Decatur, AL byt Owner/User: ER's company Item Inspected (OSHA, PCSA, ANSI/ASME reference) Corrective Action (2) Safety Items - A. Load charts (are they readable) (B30.5-1.1.3) 2-A The load charts have been ripped out of the crane, and must be reinstalled. (2) Safety Items - K. Fire extinguishers (1926.550(a)(14)(i)) 2-K There is no fire extinguisher on the crane. (5) Main Hoist Winch - B. Condition of hoist two speed & control system 5-B The hoist 2 speed does not work at times. (5) Main Hoist Winch - H. Condition & operation of cable follower 5-H The cable follower is broken and is not working and must be repaired. (7) Swing - E. Condition of swing reduction gear box & mounting (B30.5-2.1.3.(a)(4)) 7-E The upper will not swing, it acts like the gear box is locked up or the brake is sticking, it will have to be trouble shoot to see what the problem is . (7) Swing - J. Condition of 360 degree swing lock 7-J The 360 degree swing lock is not engaging the gear teeth and needs to be adjusted or replaced. (8) Swivel Area (Air, Electrical, HYD.) - D. Are all lines tight and not leaking 8-D There are some leaks coming off of the swivel that need to be fixed. (9) Boom & Jib - E. Cable retaining pins 9-E There is a cable retaining pin missing from the jib head. (10) Outrigger System - D. Condition of all stabilizer pads & floats (B30.5-1.9.3.(d)) 10-D All 4 stabilizer pads are missing and must be replaced.	lo: T6100018	
Item Inspected (OSHA, PCSA, ANSI/ASME reference) Corrective Deficiency Deficiency Action	10: 10100016	98
Item No Deficiency		
2-A The load charts have been ripped out of the crane, and must be reinstalled. (2) Safety Items - K. Fire extinguishers (1926.550(a)(14)(i)) 2-K There is no fire extinguisher on the crane. (5) Main Hoist Winch - B. Condition of hoist two speed & control system 5-B The hoist 2 speed does not work at times. (5) Main Hoist Winch - H. Condition & operation of cable follower 5-H The cable follower is broken and is not working and must be repaired. (7) Swing - E. Condition of swing reduction gear box & mounting (B30.5-2.1.3.(a)(4)) 7-E The upper will not swing, it acts like the gear box is locked up or the brake is sticking, it will have to be trouble shoot to see what the problem is . (7) Swing - J. Condition of 360 degree swing lock 7-J The 360 degree swing lock is not engaging the gear teeth and needs to be adjusted or replaced. (8) Swivel Area (Air, Electrical, HYD.) - D. Are all lines tight and not leaking 8-D There are some leaks coming off of the swivel that need to be fixed. (9) Boom & Jib - E. Cable retaining pins 9-E There is a cable retaining pin missing from the jib head. (10) Outrigger System - D. Condition of all stabilizer pads & floats (B30.5-1.9.3.(d)) 10-D All 4 stabilizer pads are missing and must be replaced.	Date Corrected	Repaired By
(2) Safety Items - K. Fire extinguishers (1926.550(a)(14)(i)) 2-K There is no fire extinguisher on the crane. (5) Main Hoist Winch - B. Condition of hoist two speed & control system 5-B The hoist 2 speed does not work at times. (5) Main Hoist Winch - H. Condition & operation of cable follower 5-H The cable follower is broken and is not working and must be repaired. (7) Swing - E. Condition of swing reduction gear box & mounting (B30.5-2.1.3.(a)(4)) 7-E The upper will not swing, it acts like the gear box is locked up or the brake is sticking, it will have to be trouble shoot to see what the problem is . (7) Swing - J. Condition of 360 degree swing lock 7-J The 360 degree swing lock is not engaging the gear teeth and needs to be adjusted or replaced. (8) Swivel Area (Air, Electrical, HYD.) - D. Are all lines tight and not leaking 8-D There are some leaks coming off of the swivel that need to be fixed. (9) Boom & Jib - E. Cable retaining pins 9-E There is a cable retaining pin missing from the jib head. (10) Outrigger System - D. Condition of all stabilizer pads & floats (B30.5-1.9.3.(d)) 10-D All 4 stabilizer pads are missing and must be replaced.		
2-K There is no fire extinguisher on the crane. (5) Main Hoist Winch - B. Condition of hoist two speed & control system 5-B The hoist 2 speed does not work at times. (5) Main Hoist Winch - H. Condition & operation of cable follower 5-H The cable follower is broken and is not working and must be repaired. (7) Swing - E. Condition of swing reduction gear box & mounting (B30.5-2.1.3.(a)(4)) 7-E The upper will not swing, it acts like the gear box is locked up or the brake is sticking, it will have to be trouble shoot to see what the problem is . (7) Swing - J. Condition of 360 degree swing lock 7-J The 360 degree swing lock is not engaging the gear teeth and needs to be adjusted or replaced. (8) Swivel Area (Air, Electrical, HYD.) - D. Are all lines tight and not leaking 8-D There are some leaks coming off of the swivel that need to be fixed. (9) Boom & Jib - E. Cable retaining pins 9-E There is a cable retaining pin missing from the jib head. (10) Outrigger System - D. Condition of all stabilizer pads & floats (B30.5-1.9.3.(d)) 10-D All 4 stabilizer pads are missing and must be replaced.		
5) Main Hoist Winch - B. Condition of hoist two speed & control system 5-B The hoist 2 speed does not work at times. (5) Main Hoist Winch - H. Condition & operation of cable follower 5-H The cable follower is broken and is not working and must be repaired. (7) Swing - E. Condition of swing reduction gear box & mounting (B30.5-2.1.3.(a)(4)) 7-E The upper will not swing, it acts like the gear box is locked up or the brake is sticking, it will have to be trouble shoot to see what the problem is . (7) Swing - J. Condition of 360 degree swing lock 7-J The 360 degree swing lock is not engaging the gear teeth and needs to be adjusted or replaced. (8) Swivel Area (Air, Electrical, HYD.) - D. Are all lines tight and not leaking 8-D There are some leaks coming off of the swivel that need to be fixed. (9) Boom & Jib - E. Cable retaining pins 9-E There is a cable retaining pin missing from the jib head. (10) Outrigger System - D. Condition of all stabilizer pads & floats (B30.5-1.9.3.(d)) 10-D All 4 stabilizer pads are missing and must be replaced.		
The hoist 2 speed does not work at times. Some		
(5) Main Hoist Winch - H. Condition & operation of cable follower 5-H The cable follower is broken and is not working and must be repaired. (7) Swing - E. Condition of swing reduction gear box & mounting (B30.5-2.1.3.(a)(4)) 7-E The upper will not swing, it acts like the gear box is locked up or the brake is sticking, it will have to be trouble shoot to see what the problem is . (7) Swing - J. Condition of 360 degree swing lock 7-J The 360 degree swing lock is not engaging the gear teeth and needs to be adjusted or replaced. (8) Swivel Area (Air, Electrical, HYD.) - D. Are all lines tight and not leaking 8-D There are some leaks coming off of the swivel that need to be fixed. (9) Boom & Jib - E. Cable retaining pins 9-E There is a cable retaining pin missing from the jib head. (10) Outrigger System - D. Condition of all stabilizer pads & floats (B30.5-1.9.3.(d)) 10-D All 4 stabilizer pads are missing and must be replaced.		
The cable follower is broken and is not working and must be repaired. The cable follower is broken and is not working and must be repaired. The upper will not swing, it acts like the gear box is locked up or the brake is sticking, it will have to be trouble shoot to see what the problem is . The 360 degree swing lock The 360 degree swing lock is not engaging the gear teeth and needs to be adjusted or replaced. Swivel Area (Air, Electrical, HYD.) - D. Are all lines tight and not leaking There are some leaks coming off of the swivel that need to be fixed. Some & Jib - E. Cable retaining pins There is a cable retaining pin missing from the jib head. To Outrigger System - D. Condition of all stabilizer pads & floats (B30.5-1.9.3.(d)) All 4 stabilizer pads are missing and must be replaced.		
(7) Swing - E. Condition of swing reduction gear box & mounting (B30.5-2.1.3.(a)(4)) 7-E The upper will not swing, it acts like the gear box is locked up or the brake is sticking, it will have to be trouble shoot to see what the problem is . (7) Swing - J. Condition of 360 degree swing lock 7-J The 360 degree swing lock is not engaging the gear teeth and needs to be adjusted or replaced. (8) Swivel Area (Air, Electrical, HYD.) - D. Are all lines tight and not leaking 8-D There are some leaks coming off of the swivel that need to be fixed. (9) Boom & Jib - E. Cable retaining pins 9-E There is a cable retaining pin missing from the jib head. (10) Outrigger System - D. Condition of all stabilizer pads & floats (B30.5-1.9.3.(d)) 10-D All 4 stabilizer pads are missing and must be replaced.		
7-E The upper will not swing, it acts like the gear box is locked up or the brake is sticking, it will have to be trouble shoot to see what the problem is . (7) Swing - J. Condition of 360 degree swing lock 7-J The 360 degree swing lock is not engaging the gear teeth and needs to be adjusted or replaced. (8) Swivel Area (Air, Electrical, HYD.) - D. Are all lines tight and not leaking 8-D There are some leaks coming off of the swivel that need to be fixed. (9) Boom & Jib - E. Cable retaining pins 9-E There is a cable retaining pin missing from the jib head. (10) Outrigger System - D. Condition of all stabilizer pads & floats (B30.5-1.9.3.(d)) 10-D All 4 stabilizer pads are missing and must be replaced.		
is sticking, it will have to be trouble shoot to see what the problem is . (7) Swing - J. Condition of 360 degree swing lock 7-J The 360 degree swing lock is not engaging the gear teeth and needs to be adjusted or replaced. (8) Swivel Area (Air, Electrical, HYD.) - D. Are all lines tight and not leaking 8-D There are some leaks coming off of the swivel that need to be fixed. (9) Boom & Jib - E. Cable retaining pins 9-E There is a cable retaining pin missing from the jib head. (10) Outrigger System - D. Condition of all stabilizer pads & floats (B30.5-1.9.3.(d)) 10-D All 4 stabilizer pads are missing and must be replaced.		
7-J The 360 degree swing lock is not engaging the gear teeth and needs to be adjusted or replaced. (8) Swivel Area (Air, Electrical, HYD.) - D. Are all lines tight and not leaking 8-D There are some leaks coming off of the swivel that need to be fixed. (9) Boom & Jib - E. Cable retaining pins 9-E There is a cable retaining pin missing from the jib head. (10) Outrigger System - D. Condition of all stabilizer pads & floats (B30.5-1.9.3.(d)) 10-D All 4 stabilizer pads are missing and must be replaced.		
adjusted or replaced. (8) Swivel Area (Air, Electrical, HYD.) - D. Are all lines tight and not leaking 8-D There are some leaks coming off of the swivel that need to be fixed. (9) Boom & Jib - E. Cable retaining pins 9-E There is a cable retaining pin missing from the jib head. (10) Outrigger System - D. Condition of all stabilizer pads & floats (B30.5-1.9.3.(d)) 10-D All 4 stabilizer pads are missing and must be replaced.		
8-D There are some leaks coming off of the swivel that need to be fixed. (9) Boom & Jib - E. Cable retaining pins 9-E There is a cable retaining pin missing from the jib head. (10) Outrigger System - D. Condition of all stabilizer pads & floats (B30.5-1.9.3.(d)) 10-D All 4 stabilizer pads are missing and must be replaced.		
(9) Boom & Jib - E. Cable retaining pins 9-E There is a cable retaining pin missing from the jib head. (10) Outrigger System - D. Condition of all stabilizer pads & floats (B30.5-1.9.3.(d)) 10-D All 4 stabilizer pads are missing and must be replaced.		
9-E There is a cable retaining pin missing from the jib head. (10) Outrigger System - D. Condition of all stabilizer pads & floats (B30.5-1.9.3.(d)) 10-D All 4 stabilizer pads are missing and must be replaced.		
(10) Outrigger System - D. Condition of all stabilizer pads & floats (B30.5-1.9.3.(d)) 10-D All 4 stabilizer pads are missing and must be replaced.		
10-D All 4 stabilizer pads are missing and must be replaced.		
(12) RT & Truck Crane Carrier & Cab(s) - B. Condition of parking brake (1926.601(b)(1))		
12-B The parking brake does not work and must be repaired.		
(12) RT & Truck Crane Carrier & Cab(s) - J. Level of hydraulic fluid (PCSA#2 8.1.12.7)		
12-J We had to put 50 gallons of fluid in the crane just to be able to get the boom scoped all the way out and up and it still needs about 25 gallons more fluid.		
(12) RT & Truck Crane Carrier & Cab(s) - R. Windshield wipers (1926.601(b)(2)(i)&(ii))		
Top windshield wiper has been removed from the crane and needs to be reinstalled.		
(12) RT & Truck Crane Carrier & Cab(s) - S. Condition of doors, latch, open & close (PCSA#2 8.1.11.2)		
12-S The operators door is very hard to open after it has been shut, door needs to be adjusted.		
(12) RT & Truck Crane Carrier & Cab(s) - T. Condition of mirrors, side mirrors, spot mirrors (1926.601(b)(4))		
12-T There are 2 spot mirrors that are missing and need to be replaced. (1 at the right front fender, and 1 at the main hoist.)		
(12) RT & Truck Crane Carrier & Cab(s) - U. Seat mounting (1926.601(b)(8))		
12-U The seat adjustment lever is pulled out of the seat and must be repaired or replaced.		

NO: T610001898

Inspection Deficiency Report

Item No	Item Inspected (OSHA, PCSA, ANSI/ASME reference) Deficiency	Corrective Action	Date Corrected	Repaired By
(15) Wire	e Rope Main Hoist - P. Socket wedge condition & installation			
15-P	The wedge is in the socket backwards and needs to be redone.			
(18) Mai	n Block Component Identification - A. Throat Latch			
18-A	The throat latch spring is bad and must be replaced.			
(19) Hea	dache Ball Component Identification - E. Total Weights (Mounting)			
19-E	There is no ball with the machine. It did not come back with the machine.			

18 Deficiencies were reviewed with the customer

Any unusual conditions observed during the inspection should be noted in the remarks section. Whenever possible, the crane operator should be present to start and operate the crane for various portions of the inspection. Summarize all required adjustments or repairs in the remarks section. This report is based on visual inspection only. This is not a take apart inspection, and is not intended in any way, to replace the daily & periodic maintenance that is recommended by the manufacture, or that may be dictated by job conditions or machine performance. The information on this report is as we see the condition of the machine/equipment today, and is not intended to be a guarantee for any use or purpose.

Inspector Signature:	Langung & Barn	Date: 4/29/2009
Customer Signature:		Date: 4/29/2009

NO: T610001898



5432 Bent Pine Rd. Athens, AL 35614 256-777-4002 <u>Pictures</u>



Date Wed 4/29/2009

Manufacturer: GROVE		Model: RT-530E		Serial No: 220262	Unit No: N/A
HrsUp: 5058	HrsLo: p90	Inspector: Greg Beam		Certification: 08-6333	No: T610001898
Location: At their shop in Decatur, AL byt Owner/User: E				ER's company	



General picture of right side of crane.



Picture of right front side of the crane.

My Inspection Company Pictures



Picture of front crane.



Picture of left side of crane.

Pictures



Picture of boom scoped out and down.



Picture of boom scoped out and down (view from tip back towards the crane)

Pictures



Picture of cable follower that is not working (froze up)



Picture of top view of boom out and down.

Pictures



Picture of pin missing from rooster sheave on the jib.



Picture of cable retaining pin that is missing from the tip of the jib.



Picture of boom alignment



Picture of cable that is pulled out from the front of the seat, this cable works the back rest forwards or backwards.