Reverse Engineering the Apollo 11 Guidance Computer (AGC) Source Code

Edited by Gary Young

proudindiv@gmail.com

July 21, 2016

Contents

1 Introduction and Notes **11**
1.1 References 14

2 Oddities Spotted **15**

I Apollo 11 Guidance Computers Source Code **17**

3 Comanche055 **19**
3.1 main headers 19
3.1.1 contract and approvals 19
3.1.2 assembly and operation information 21
3.1.3 tags for relative setloc 56
3.2 comerase routine 74
3.2.1 erasable assignments 75
3.3 comaid routines 245
3.3.1 interrupt lead ins 246
3.3.2 t4rupt program 250
3.3.3 downlink lists 293
3.3.4 fresh start and restart 306
3.3.5 restart tables 361
3.3.6 sctmark code 381
3.3.7 extended verbs 404
3.3.8 pinball noun tables 449
3.3.9 csm geometry 480
3.3.10 imu compensation package 492
3.3.11 pinball game buttons and lights 504
3.3.12 r60-62 code 646
3.3.13 anglfind code 659
3.3.14 gimbal lock avoidance 681
3.3.15 kalcmanu steering 683
3.3.16 system test standard lead ins 691
3.3.17 imu calibration and alignment 695
3.4 comekiss routines 744

3.4.1 ground tracking determination program 744
3.4.2 p34-35 p74-75 code 751
3.4.3 r31 code 809
3.4.4 p76 code 819
3.4.5 r30 code 824
3.4.6 stable orbit 841
3.5 trouble routines 857
3.5.1 p11 code 857
3.5.2 tpi search 892
3.5.3 p20 p25 code 913
3.5.4 p30 p37 code 1042
3.5.5 p32-p33 p72-p73 code 1062
3.5.6 p40-p47 code 1093
3.5.7 p51-p53 code 1146
3.5.8 lunar and solar ephemerides subroutines 1194
3.5.9 p61-p67 code 1199
3.5.10 servicer207 code 1226
3.5.11 entry lexicon 1244
3.5.12 reentry control 1255
3.5.13 cm body attitude 1290
3.5.14 p37 p70 code 1300
3.5.15 s-band antenna for cm 1343
3.5.16 lunar landmark selection for cm 1346
3.6 tvcdaps routines 1346
3.6.1 tvcinitialize code 1346
3.6.2 tvcexecutive code 1355
3.6.3 tvcmassprop code 1361
3.6.4 tvcrestarts code 1366
3.6.5 tvcdaps code 1372
3.6.6 tvcstroketest code 1389
3.6.7 tvcrolldap code 1395
3.6.8 mysubs code 1409
3.6.9 rcs-csm digital autopilot 1411
3.6.10 automatic maneuvers 1433
3.6.11 rcs-csm dap executive programs 1450
3.6.12 jet selection logic 1452
3.6.13 cm entry digital autopilot 1480
3.7 chieftan routines 1523
3.7.1 down-telemetry program 1523
3.7.2 inter-bank communication 1539
3.7.3 interpreter code 1544
3.7.4 fixed fixed constant pool 1637
3.7.5 interpretive constants 1645
3.7.6 single precision subroutines 1646
3.7.7 executive code 1648
3.7.8 waitlist code 1662

3.7.9 latitude longitude subroutines . . . 1674
3.7.10 planetary inertial orientation . . . 1683
3.7.11 measurement incorporation . . . 1692
3.7.12 conic subroutines . . . 1710
3.7.13 integration initialization . . . 1771
3.7.14 orbital integration . . . 1813
3.7.15 inflight alignment routines . . . 1834
3.7.16 powered flight subroutines . . . 1843
3.7.17 time of free fall . . . 1851
3.7.18 star tables . . . 1867
3.7.19 agc block two self check . . . 1871
3.7.20 phase table maintenance . . . 1890
3.7.21 restarts routine . . . 1904
3.7.22 imu mode switching routines . . . 1916
3.7.23 keyrupt uprupt . . . 1944
3.7.24 display interface routines . . . 1948
3.7.25 service routines . . . 2000
3.7.26 alarm and abort . . . 2006
3.7.27 update program . . . 2014
3.7.28 rt8 op codes . . . 2027
3.7.29 rtb op codes . . . 2034

4 Luminary099 2041
4.1 controlled constants . . . 2042
4.2 input output channel bit descriptions . . . 2058
4.3 flagword assignments . . . 2065
4.4 rcs failure monitor . . . 2108
4.5 ags initialization . . . 2111
4.6 aotmark routine . . . 2120
4.7 lem geometry . . . 2143
4.8 r63 routine . . . 2148
4.9 attitude maneuver routine . . . 2151
4.10 imu performance test 2 . . . 2188
4.11 imu performance tests 4 . . . 2202
4.12 s band antenna for lm . . . 2213
4.13 radar leadin routines . . . 2217
4.14 p30-p37 routines . . . 2218
4.15 p32-p35 p72-p75 routines . . . 2223
4.16 lambert aimpoint guidance . . . 2253
4.17 burn-baby-burn master ignition routine . . . 2259
4.18 the lunar landing . . . 2299
4.19 throttle control routines . . . 2306
4.20 lunar landing guidance equations . . . 2311
4.21 p70-p71 routines . . . 2343
4.22 p12 routine . . . 2353
4.23 ascent guidance . . . 2358

4.24 servicer routine . . . 2382
4.25 landing analog displays . . . 2419
4.26 findcduw-guidap interface . . . 2439
4.27 lm down-telemetry program . . . 2460
4.28 interpretive constant . . . 2475
4.29 agc block two self-check . . . 2477
4.30 lm rtb op codes . . . 2495
4.31 t6 rupt programs . . . 2496
4.32 dap interface subroutines . . . 2499
4.33 dapidler program . . . 2503
4.34 p axis rcs autopilot . . . 2519
4.35 q-r axis rcs autopilot . . . 2542
4.36 tjet law . . . 2561
4.37 kalman filter . . . 2571
4.38 trim gimbal cntrol system . . . 2574
4.39 aostask and aosjob . . . 2587
4.40 sps back up rcs control . . . 2625

II Suplimentary Material 2629

Appendices 2631

A Original Files 2633
A.1 README.md . . . 2633
A.2 HeaderTemplate . . . 2635
A.3 AGC BLOCK TWO SELF CHECK . . . 2636
A.4 AGC BLOCK TWO SELF-CHECK . . . 2638
A.5 AGS INITIALIZATION . . . 2639
A.6 ALARM AND ABORT . . . 2640
A.7 ANGLFIND . . . 2641
A.8 AOSTASK AND AOSJOB . . . 2643
A.9 AOTMARK . . . 2645
A.10 ASCENT GUIDANCE . . . 2647
A.11 ASSEMBLY AND OPERATION INFORMATION . . . 2649
A.12 ATTITUDE MANEUVER ROUTINE . . . 2651
A.13 AUTOMATIC MANEUVERS . . . 2653
A.14 BURN BABY BURN–MASTER IGNITION ROUTINE . . . 2655
A.15 CM BODY ATTITUDE . . . 2657
A.16 CM ENTRY DIGITAL AUTOPILOT . . . 2659
A.17 CONIC SUBROUTINES . . . 2662
A.18 CONTRACT AND APPROVALS . . . 2665
A.19 CONTROLLED CONSTANTS . . . 2666
A.20 CSM GEOMETRY . . . 2668
A.21 DAPIDLER PROGRAM . . . 2670
A.22 DAP INTERFACE SUBROUTINES . . . 2672

A.23 DISPLAY INTERFACE ROUTINES 2673
A.24 DOWNLINK LISTS 2676
A.25 DOWN TELEMETRY PROGRAM 2678
A.26 DOWN-TELEMETRY PROGRAM 2680
A.27 ENTRY LEXICON 2682
A.28 ERASABLE ASSIGNMENTS 2684
A.29 EXECUTIVE 2690
A.30 EXTENDED VERBS 2692
A.31 FINDCDUW–GUIDAP INTERFACE 2695
A.32 FIXED FIXED CONSTANT POOL 2697
A.33 FLAGWORD ASSIGNMENTS 2698
A.34 FRESH START AND RESTART 2700
A.35 GIMBAL LOCK AVOIDANCE 2702
A.36 GROUND TRACKING DETERMINATION PROGRAM 2703
A.37 IMU CALIBRATION AND ALIGNMENT 2704
A.38 IMU COMPENSATION PACKAGE 2707
A.39 IMU MODE SWITCHING ROUTINES 2709
A.40 IMU PERFORMANCE TEST 2 2711
A.41 IMU PERFORMANCE TESTS 4 2713
A.42 INFLIGHT ALIGNMENT ROUTINES 2715
A.43 INPUT OUTPUT CHANNEL BIT DESCRIPTIONS 2717
A.44 INTEGRATION INITIALIZATION 2718
A.45 INTER-BANK COMMUNICATION 2720
A.46 INTERPRETER 2721
A.47 INTERPRETIVE CONSTANT 2726
A.48 INTERPRETIVE CONSTANTS 2727
A.49 INTERRUPT LEAD INS 2728
A.50 JET SELECTION LOGIC 2729
A.51 KALCMANU STEERING 2731
A.52 KALMAN FILTER 2732
A.53 KEYRUPT UPRUPT 2733
A.54 LAMBERT AIMPOINT GUIDANCE 2734
A.55 LANDING ANALOG DISPLAYS 2735
A.56 LATITUDE LONGITUDE SUBROUTINES 2737
A.57 LEM GEOMETRY 2738
A.58 LUNAR AND SOLAR EPHEMERIDES SUBROUTINES 2739
A.59 LUNAR LANDING GUIDANCE EQUATIONS 2740
A.60 LUNAR LANDMARK SELECTION FOR CM 2741
A.61 MAIN 2742
A.62 MEASUREMENT INCORPORATION 2746
A.63 MYSUBS 2747
A.64 ORBITAL INTEGRATION 2748
A.65 P11 2749
A.66 P12 2751
A.67 P20-P25 2752
A.68 P30 P37 2756

A.69 P30-P37 2757
A.70 P32-P33 P72-P73 2759
A.71 P32-P35 P72-P75 2760
A.72 P34-35 P74-75 2761
A.73 P37 P70 2764
A.74 P40-P47 2765
A.75 P51-P53 2766
A.76 P61-P67 2767
A.77 P70-P71 2768
A.78 P76 2769
A.79 P-AXIS RCS AUTOPILOT 2770
A.80 PHASE TABLE MAINTENANCE 2771
A.81 PINBALL GAME BUTTONS AND LIGHTS 2773
A.82 PINBALL NOUN TABLES 2778
A.83 PLANETARY INERTIAL ORIENTATION 2780
A.84 POWERED FLIGHT SUBROUTINES 2781
A.85 Q R-AXIS RCS AUTOPILOT 2782
A.86 R30 2783
A.87 R31 2785
A.88 R60 62 2787
A.89 R63 2788
A.90 RADAR LEADIN ROUTINES 2789
A.91 RCS-CSM DAP EXECUTIVE PROGRAMS 2790
A.92 RCS-CSM DIGITAL AUTOPILOT 2791
A.93 RCS FAILURE MONITOR 2792
A.94 REENTRY CONTROL 2793
A.95 RESTARTS ROUTINE 2794
A.96 RESTART TABLES 2796
A.97 RT8 OP CODES 2798
A.98 RTB OP CODES 2799
A.99 S-BAND ANTENNA FOR CM 2800
A.100 S-BAND ANTENNA FOR LM 2801
A.101 SERVICER207 2802
A.102 SERVICE ROUTINES 2803
A.103 SERVICER 2804
A.104 SINGLE PRECISION SUBROUTINES 2805
A.105 SPS BACK-UP RCS CONTROL 2806
A.106 STABLE ORBIT 2807
A.107 STAR TABLES 2808
A.108 SXTMARK 2809
A.109 SYSTEM TEST STANDARD LEAD INS 2811
A.110 T4RUPT PROGRAM 2812
A.111 T6-RUPT PROGRAMS 2815
A.112 TAGS FOR RELATIVE SETLOC 2816
A.113 THE LUNAR LANDING 2818
A.114 THROTTLE CONTROL ROUTINES 2819

A.115 TIME OF FREE FALL 2820
A.116 TJET LAW 2821
A.117 TPI SEARCH 2822
A.118 TRIM GIMBAL CNTROL SYSTEM 2823
A.119 TVCDAPS 2824
A.120 TVCEXECUTIVE 2825
A.121 TVCINITIALIZE 2826
A.122 TVCMASSPROP 2827
A.123 TVCRESTARTS 2828
A.124 TVCROLLDAP 2829
A.125 TVCSTROKETEST 2830
A.126 UPDATE PROGRAM 2831
A.127 WAITLIST 2832

B Miscellaneous Files 2833

C Notes, Bibliography and Indexes 2841
C.1 Chunks 2841
C.2 Index 2876

Chapter 1

Introduction and Notes

#140 Apollo-11 sources as Literate Programs Jul 16 chrislgarry/Apollo-11

I'm literating Apollo-11 for documentation, chunk and page descriptions and indexing, and memory label indexing. So far I've been working on this early experiment for a week, and the structure and contents will change drastically as my ideas evolve.

I've started a typeset book for the Apollo-11 source in my clone at https://github.com/proudindiv/Apollo-11. The original sources were not "files" in any sense, but about 45 boxes of hollerith punch cards (2000 cards to a box) on a large cart, with the listings produced by the assembler which have been imaged. So I'm looking at the code as virtual card decks.

The main output is currently in my Apollo-11.pdf, which is better downloaded and examined because the github pdf viewer doesn't show the massive internal linkages.

I just wanted to make this early announcement, so others were aware of and could think about it.

Thanks,

Gary Young

aka proudindiv

Sat Jul 16, 2016

So far, I'm breaking the code into chunks, organizing and structuring the chunks, indexing the memory labels and all references to them by chunks, making notes and comments, and adding the table of contents, bookmarks, chunk index, and general and label indices. I do the markup and noweb and LaTeX do the type-

setting.

I don't know how much time I'm going to spend on this, nor how far I'll take it, but I'll collect my notes here. I started putting comments on my facebook account, and I'll initially copy them here to keep them together.

- Original Apollo 11 guidance computer (AGC) source code, I wrote programs like this in the same time period, however I started using more abstraction with macros and defines in the assembler. (chrislgarry/Apollo-11)
- Today, I would create a literate program in noweb to reverse engineer the code, integrating the documentation and code into a version of the Forth programming language. Forth would be more compact to fit in the small memories of the computers of those days, but I would have to emulate the stack because those old computers hadn't implemented them in the hardware yet. (wikipedia)
- I wrote assemblers in forth to compile (assemble) this type of code on machines before personal computers that didn't have operating systems.
- Such a macro-assembler could be written in several pages of machine code almost directly from the processor reference card.
- I've cloned the Apollo-11 repository and made my first change to the README.md: (link)
- Well, I've got my first stub reverse engineering of the Apollo-11 code in last night. (link)
- There were no file systems with 80 (or more) characters in a file name. There were no file systems at all. The source had to have been on punch cards or paper tape. I worked at the Federal Reserve Bank in Seattle then on an IBM 360 main frame and we had to order a select chain to put on the printer for the characters that we could print. We had 26 capital letters "A-Z", 10 digits "0-9", and 6 "special characters". In our case the special characters were chosen for accounting applications: "$", "#", "-", period, comma, and space. (I think, I can't remember if we had the pound sign.) Notice that there are no lower case letters. That came later, at Bell Labs with UNIX and such, I think.
- There was no floating point arithmetic, only 16 bit integers, from 0 to 65535, or -32767 to 0 to 32767 or possibly -32768 to 32767 depending on whether 0 has a sign and is different

from minus zero. Heck there may not have been an integer "divide" operation implemented in the hardware, and probably not even a 16 bit integer multiply. I'll have to look through the source to see. We had to implement multiply and divide in software. Also there was a distinction between "scientific" and "business" computers. My memory is not too good on the details and I have no reference in front of me.

- Aha! I just looked at the first file in my "Apollo-11" book that I just started AND ... "S-ZERO EQUALS NEG0" so plus zero and negative zero were two different numbers!

- I could clone the entire repository and then download it to my Intel Skull Canyon computer from the internet in a fraction of a second. It's 2MB, including all the boiler plate that has been recently added.
- It originally takes about five seconds to typeset this book. It takes longer as I create complex indexing and add structure to the listing, but still less than a minute. It probably took all night to print the original source listing once.
- The release of the Apollo 11 software and the extreme popularity, with over 2000 clones already, has much larger significance than just a fad. If you look at the IoT phenomenon and the computers that are used there, the Apollo 11 software is a training guide and a huge inspiration on what can be done. Imagine how you could program a self driving car modeling it on the Apollo 11. The Apollo 11 software shows a new generation how computers work at the low level and how they integrate into the real world. The next huge changes to society aren't coming from the corporate world.
- I think the biggest difficulty in recreating the card decks is going to be white space. In creating the files from the page listing images, tabs were used. The original programmers in the 1960's used card punches to create the input to the assembler. I think the assembler only accepted fixed format cards and that's why if you were to scan the listings there probably aren't any errors in the spacing on the cards. Those card punch machines had a method of setting tab stops and there was a key to advance the current card being punched to the next tab stop. Characters being typed or duped then continued from that location. There was no tab character punched into any column of the card. Similarly, the advancement to the next page was controlled by the assembler program. The programmer could force a short page by inserting a control pseudo-op into the second field of the card, something like "newpage", but I don't remember what it was. There was also an "end" pseudo-op in the last card. Some pseudo-ops weren't printed by the assembler.

- The line numbers on the left side of the listings also seem to indicate other pseudo-ops, such as begin comment block and end comment block. We used columns 72-80 for a card sequence number, but they were hard to keep consistent because of card insertions and replacements.

1.1 References

- QUARTZ: "BURN, BABY! BURN!" The code that took America to the moon was just published to GitHub, and its like a 1960s time capsule, Written by Keith Collins, July 09, 2016.
- Apollo Guidance Computer emulation by Dean Koska This Palm Centro program is running the computer software used on the Apollo moon landings. It utilizes Ron Burkey's Virtual AGC engine for the emulation (www.ibiblio.org/apollo).
- Virtual AGC Home Page - Ibiblio
- slashdot: Assembly Code That Took America to the Moon Now Published On GitHub
- Skylab quick-reference card
- Space Guidance Analysis (SGA) memos

Chapter 2

Oddities Spotted

Files that are versions of each other:

- AGC_BLOCK_TWO_SELF_CHECK.s and AGC_BLOCK_TWO_SELF-CHECK.s
- DOWN_TELEMETRY_PROGRAM.s and DOWN-TELEMETRY_PROGRAM.s
- P30_P37.s and P30-P37.s (Luminary vs Colossus)

Line 66 of Luminary099/AOTMARK.agc has junk control characters.

15 ⟨*tmpline line 66 of AOTMARK.agc* 15⟩≡

```
                    TS      MARKSTAT        # STORE VAC ADR IN LOW 9 OF MARKSTAT
```

Uses `MARKSTAT` 163.

Part I

Apollo 11 Guidance Computers Source Code

Chapter 3

Comanche055

19a ⟨*Comanche055.agc* 19a⟩≡
⟨*main headers* 19b⟩
⟨*comerase routine* 74b⟩
⟨*comaid routines* 245b⟩
⟨*comekiss routines* 744b⟩
⟨*trouble routines* 857a⟩
⟨*tvcdaps routines* 1346c⟩
⟨*chieftan routines* 1523a⟩

This code is written to file `Comanche055.agc`.

3.1 main headers

19b ⟨*main headers* 19b⟩≡ (19a)
⟨*contract and approvals* 19c⟩
⟨*assembly and operation information* 21⟩
⟨*tags for relative setloc* 56b⟩

3.1.1 contract and approvals

19c ⟨*contract and approvals* 19c⟩≡ (19b)
⟨*Page CM0001* 20⟩

20 ⟨*Page CM0001* 20⟩≡ (19c 2665)

```
#************************************************************************
#                                                                       *
#               THIS AGC PROGRAM SHALL ALSO BE REFERRED TO AS:          *
#                                                                       *
#                                                                       *
#                               COLOSSUS 2A                             *
#                                                                       *
#                                                                       *
#       THIS PROGRAM IS INTENDED FOR USE IN THE CM AS SPECIFIED         *
#       IN REPORT R-577.  THIS PROGRAM WAS PREPARED UNDER DSR           *
#       PROJECT 55-23870, SPONSORED BY THE MANNED SPACECRAFT            *
#       CENTER OF THE NATIONAL AERONAUTICS AND SPACE                    *
#       ADMINISTRATION THROUGH CONTRACT NAS 9-4065 WITH THE             *
#       INSTRUMENTATION LABORATORY, MASSACHUSETTS INSTITUTE OF          *
#       TECHNOLOGY, CAMBRIDGE, MASS.                                    *
#                                                                       *
#************************************************************************


#       SUBMITTED:      MARGARET H. HAMILTON            DATE:   28 MAR 69
#               M.H.HAMILTON, COLOSSUS PROGRAMMING LEADER
#               APOLLO GUIDANCE AND NAVIGATION

#       APPROVED:       DANIEL J. LICKLY                DATE:   28 MAR 69
#               D.J.LICKLY, DIRECTOR, MISSION PROGRAM DEVELOPMENT
#               APOLLO GUIDANCE AND NAVIGATION PROGRAM

#       APPROVED:       FRED H. MARTIN                  DATE:   28 MAR 69
#               FRED H. MARTIN, COLOSSUS PROJECT MANAGER
#               APOLLO GUIDANCE AND NAVIGATION PROGRAM

#       APPROVED:       NORMAN E. SEARS                 DATE:   28 MAR 69
#               N.E. SEARS, DIRECTOR, MISSION DEVELOPMENT
#               APOLLO GUIDANCE AND NAVIGATION PROGRAM

#       APPROVED:       RICHARD H. BATTIN               DATE:   28 MAR 69
#               R.H. BATTIN, DIRECTOR, MISSION DEVELOPMENT
#               APOLLO GUIDANCE AND NAVIGATION PROGRAM

#       APPROVED:       DAVID G. HOAG                   DATE:   28 MAR 69
#               D.G. HOAG, DIRECTOR
#               APOLLO GUIDANCE AND NAVIGATION PROGRAM

#       APPROVED:       RALPH R. RAGAN                  DATE:   28 MAR 69
#               R.R. RAGAN, DEPUTY DIRECTOR
```

```
#                INSTRUMENTATION LABORATORY
```

Uses D 226, H 177, MASS 200, and N 206.

3.1.2 assembly and operation information

21 ⟨*assembly and operation information* 21⟩≡ (19b)

⟨*Page CM0002* 22⟩
⟨*Page CM0003* 24⟩
⟨*Page CM0004* 25⟩
⟨*Page CM0005* 26⟩
⟨*Page CM0006* 28⟩
⟨*Page CM0007* 29⟩
⟨*Page CM0008* 30⟩
⟨*Page CM0009* 31⟩
⟨*Page CM0010* 32⟩
⟨*Page CM0011* 33⟩
⟨*Page CM0012* 35⟩
⟨*Page CM0013* 37⟩
⟨*Page CM0014* 38⟩
⟨*Page CM0015* 40⟩
⟨*Page CM0016* 42⟩
⟨*Page CM0017* 44⟩
⟨*Page CM0018* 45⟩
⟨*Page CM0019* 46⟩
⟨*Page CM0020* 48⟩
⟨*Page CM0021* 50⟩
⟨*Page CM0022* 51⟩
⟨*Page CM0023* 52⟩
⟨*Page CM0024* 54⟩
⟨*Page CM0025* 55⟩
⟨*Page CM0026* 56a⟩

22 ⟨*Page CM0002* 22⟩≡ (21 2649)

```
# ASSEMBLY AND OPERATIONS INFORMATION
# TAGS FOR RELATIVE SETLOC AND BLANK BANK CARDS
# SUBROUTINE CALLS
#
#
#       COMERASE
#               ERASABLE ASSIGNMENTS
#       COMAID
#               INTERRUPT LEAD INS
#               T4RUPT PROGRAM
#               DOWNLINK LISTS
#               FRESH START AND RESTART
#               RESTART TABLES
#               SXTMARK
#               EXTENDED VERBS
#               PINBALL NOUN TABLES
#               CSM GEOMETRY
#               IMU COMPENSATION PACKAGE
#               PINBALL GAME BUTTONS AND LIGHTS
#               R60,R62
#               ANGLFIND
#               GIMBAL LOCK AVOIDANCE
#               KALCMANU STEERING
#               SYSTEM TEST STANDARD LEAD INS
#               IMU CALIBRATION AND ALIGNMENT
#       COMEKISS
#               GROUND TRACKING DETERMINATION PROGRAM - P21
#               P34-P35, P74-P75
#               R31
#               P76
#               R30
#               STABLE ORBIT - P38-P39
#       TROUBLE
#               P11
#               TP1 SEARCH
#               P20-P25
#               P30,P37
#               P40-P47
#               P51-P53
#               LUNAR AND SOLAR EPHEMERIDES SUBROUTINES
#               P61-P67
#               SERVICER207
#               ENTRY LEXICON
#               REENTRY CONTROL
#               CM BODY ATTITUDE
```

```
#               P37,P70
#               S-BAND ANTENNA FOR CM
#       TVCDAPS
#               TVC INITIALIZE
```

Uses P21 219, R31 67, REENTRY 65, and RESTART 57.

24 ⟨*Page CM0003* 24⟩≡ (21 2649)

```
#               TVC EXECUTIVE
#               TVC MASSPROP
#               TVC RESTARTS
#               TVC DAPS
#               TVC STROKE TEST
#               TVC ROLLDAP
#               MYSUBS
#               RCS-CSM DIGITAL AUTOPILOT
#               AUTOMATIC MANEUVERS
#               RCS-CSM DAP EXECUTIVE PROGRAMS
#               JET SELECTION LOGIC
#               CM ENTRY DIGITAL AUTOPILOT
#       CHIEFTAN
#               DOWN-TELEMETRY PROGRAM
#               INTER-BANK COMMUNICATION
#               INTERPRETER
#               FIXED-FIXED CONSTANT POOL
#               INTERPRETIVE CONSTANTS
#               SINGLE PRECISION SUBROUTINES
#               EXECUTIVE
#               WAITLIST
#               LATITUDE LONGITUDE SUBROUTINES
#               PLANETARY INERTIAL ORIENTATION
#               MEASUREMENT INCORPORATION
#               CONIC SUBROUTINES
#               INTEGRATION INITIALIZATION
#               ORBITAL INTEGRATION
#               INFLIGHT ALIGNMENT ROUTINES
#               POWERED FLIGHT SUBROUTINES
#               TIME OF FREE FALL
#               STAR TABLES
#               AGC BLOCK TWO SELF-CHECK
#               PHASE TABLE MAINTENANCE
#               RESTARTS ROUTINE
#               IMU MODE SWITCHING ROUTINES
#               KEYRUPT, UPRUPT
#               DISPLAY INTERFACE ROUTINES
#               SERVICE ROUTINES
#               ALARM AND ABORT
#               UPDATE PROGRAM
#               RTB OP CODES
#
#
#       SYMBOL TABLE LISTING
#       UNREFERANCED SYMBOL LISTING
```

```
#       ERASABLE & EQUALS CROSS-REFERENCE TABLE
#       SUMMARY OF SYMBOL TABLE LISTINGS
#       MEMORY TYPE & AVAILABILITY DISPLAY
#       COUNT TABLE
#       PARAGRAPHS GENERATED FOR THIS ASSEMBLY
```

Uses COUNT 142, INFLIGHT 65, KEYRUPT 59, LATITUDE 191, MODE 145, MYSUBS 63, ORBITAL 59, and STAR 186.

25 ⟨*Page CM0004* 25⟩≡ (21 2649)

```
#       OCTAL LISTING
#       OCCUPIED LOCATIONS TABLE
#       SUBROS CALLED & PROGRAM STATUS
```

26 ⟨*Page CM0005* 26⟩≡ (21 2649)

```
# VERB LIST FOR CSM

# REGULAR VERBS

# 00    NOT IN USE
# 01    DISPLAY OCTAL COMP 1 IN R1
# 02    DISPLAY OCTAL COMP 2 IN R1
# 03    DISPLAY OCTAL COMP 3 IN R1
# 04    DISPLAY OCTAL COMP 1,2 IN R1,R2
# 05    DISPLAY OCTAL COMP 1,2,3 IN R1,R2,R3
# 06    DISPLAY DECIMAL IN R1 OR R1,R2 OR R1,R2,R3
# 07    DISPLAY DP DECIMAL IN R1,R2 (TEST ONLY)
# 08
# 09
# 10
# 11    MONITOR OCTAL COMP 1 IN R1
# 12    MONITOR OCTAL COMP 2 IN R1
# 13    MONITOR OCTAL COMP 3 IN R1
# 14    MONITOR OCTAL COMP 1,2, IN R1,R2
# 15    MONITOR OCTAL COMP 1,2,3 IN R1,R2,R3
# 16    MONITOR DECIMAL IN R1 OR R1,R2 OR R1,R2,R3
# 17    MONITOR DP DECIMAL IN R1,R2 (TEST ONLY)
# 18
# 19
# 20
# 21    LOAD COMPONENT 1 INTO R1
# 22    LOAD COMPONENT 2 INTO R2
# 23    LOAD COMPONENT 3 INTO R3
# 24    LOAD COMPONENT 1,2 INTO R1,R2
# 25    LOAD COMPONENT 1,2,3 INTO R1,R2,R3
# 26
# 27    DISPLAY FIXED MEMORY
# 28
# 29
# 30    REQUEST EXECUTIVE
# 31    REQUEST WAITLIST
# 32    RECYCLE PROGRAM
# 33    PROCEED WITHOUT DSKY INPUTS
# 34    TERMINATE FUNCTION
# 35    TEST LIGHTS
# 36    REQUEST FRESH START
# 37    CHANGE PROGRAM (MAJOR MODE)
# 38
# 39
```

Uses `MODE` 145 and `R2` 188.

28 ⟨*Page CM0006* 28⟩≡ (21 2649)

```
# EXTENDED VERBS

# 40    ZERO CDU-S
# 41    COARSE ALIGN CDU-S
# 42    FINE ALIGN IMU-S
# 43    LOAD IMU ATT ERROR METERS
# 44    SET   SURFACE FLAG
# 45    RESET SURFACE FLAG
# 46    ESTABLISH G&C CONTROL
# 47    MOVE LM STATE VECTOR INTO CM STATE VECTOR.
# 48    REQUEST DAP DATA LOAD ROUTINE (R03)
# 49    REQUEST CREW DEFINED MANEUVER ROUTINE (R62)
# 50    PLEASE PERFORM
# 51    PLEASE MARK
# 52    MARK ON OFFSET LANDING SITE
# 53    PLEASE PERFORM ALTERNATE LOS MARK
# 54    REQUEST RENDEZVOUS BACKUP SIGHTING MARK ROUTINE (R23)
# 55    INCREMENT AGC TIME (DECIMAL)
# 56    TERMINATE TRACKING (P20 + P25)
# 57    REQUEST RENDEZVOUS SIGHTING MARK ROUTINE (R21)
# 58    RESET STICK FLAG
# 59    PLEASE CALIBRATE
# 60    SET ASTRONAUT TOTAL ATTITUDE (N17) TO PRESENT ATTITUDE
# 61    DISPLAY DAP ATTITUDE ERROR
# 62    DISPLAY TOTAL ATTITUDE ERROR (WRT N22 (THETAD))
# 63    DISPLAY TOTAL ASTRONAUT ATTITUDE ERROR (WRT N17 (CPHIX))
# 64    REQUEST S-BAND ANTENNA ROUTINE
# 65    OPTICAL VERIFICATION OF PRELAUNCH ALIGNMENT
# 66    VEHICLES ARE ATTACHED.  MOVE THIS VEHICLE STATE TO OTHER VEHICLE.
# 67
# 68    CSM STROKE TEST ON
# 69    CAUSE RESTART
# 70    UPDATE LIFTOFF TIME
# 71    UNIVERSAL UPDATE-BLOCK  ADR
# 72    UNIVERSAL UPDATE-SINGLE ADR
# 73    UPDATE AGC TIME (OCTAL)
# 74    INITIALIZE ERASABLE DUMP VIA DOWNLINK
# 75    BACKUP LIFTOFF
# 76    SET PREFERRED ATTITUDE FLAG
# 77    RESET PREFERRED ATTITUDE FLAG
# 78    UPDATE PRELAUNCH AZIMUTH
# 79    REQUEST LUNAR LANDMARK SELECTION ROUTINE (R35)
# 80    UPDATE LEM STATE VECTOR
# 81    UPDATE CSM STATE VECTOR
```

```
# 82    REQUEST ORBIT PARAM DISPLAY (R30)
# 83    REQUEST REND  PARAM DISPLAY (R31)
# 84    START TARGET DELTA V (R32)
# 85    REQUEST RENDEZVOUS PARAMETER DISPLAY NO. 2 (R34)
# 86    REJECT RENDEZVOUS BACKUP SIGHTING MARK
# 87    SET VHF RANGE FLAG
```

Uses AZIMUTH 191, CPHIX 163, LANDMARK 190, R31 67, R34 67, R35 67, RANGE 179, RESTART 57, STATE 138, THETAD 157, and V 229.

29 ⟨*Page CM0007* 29⟩≡ (21 2649)

```
# 88    RESET VHF RANGE FLAG
# 89    REQUEST RENDEZVOUS FINAL ATTITUDE ROUTINE (R63)
# 90    REQUEST RENDEZVOUS OUT OF PLANE DISPLAY ROUTINE (R36)
# 91    DISPLAY BANK SUM
# 92    OPERATE IMU PERFORMANCE TEST (P07)
# 93    ENABLE W MATRIX INITIALIZATION
# 94    PERFORM CYSLUNAR ATTITUDE MANEUVER (P23)
# 95    NO UPDATE OF EITHER STATE VECTOR (P20 OR P22)
# 96    TERMINATE INTEGRATION AND GO TO P00
# 97    PERFORM ENGINE FAIL PROCEDURE
# 98    ENABLE TRANSLUNAR INJECT
# 99    PLEASE ENABLE ENGINE
```

Uses RANGE 179, STATE 138, and W 183.

30 ⟨*Page CM0008* 30⟩≡ (21 2649)

```
# IN THE FOLLOWING NOUN LIST THE :NO LOAD: RESTRICTION MEANS THE NOUN
# CONTAINS AT LEAST ONE COMPONENT WHICH CANNOT BE LOADED, I.E. OF
# SCALE TYPE L (MIN/SEC) OR PP (2 INTEGERS).
# IN THIS CASE VERBS 24 AND 25 ARE NOT ALLOWED, BUT VERBS 21, 22, OR 23
# MAY BE USED TO LOAD ANY OF THE NOUN:S COMPONENTS WHICH ARE NOT OF THE
# ABOVE SCALE TYPES.
# THE :DEC ONLY: RESTRICTION MEANS ONLY DECIMAL OPERATION IS ALLOWED ON
# EVERY COMPONENT IN THE NOUN. (NOTE THAT :NO LOAD: IMPLIES :DEC ONLY:.)

# NORMAL NOUNS                              COMPONENTS   SCALE & DECIMAL POINT   RESTR
#
# 00    NOT IN USE
# 01    SPECIFY MACHINE ADDRESS (FRACTIONAL)    3COMP   .XXXXX FOR EACH
# 02    SPECIFY MACHINE ADDRESS (WHOLE)         3COMP   XXXXX. FOR EACH
# 03    SPECIFY MACHINE ADDRESS (DEGREES)       3COMP   XXX.XX DEG FOR EACH
# 04    SPARE
# 05    ANGULAR ERROR/DIFFERENCE                1COMP   XXX.XX DEG
# 06    OPTION CODE                             2COMP   OCTAL ONLY FOR EACH
# LOADING NOUN 07 WILL SET OR RESET SELECTED BITS IN ANY ERASABLE REGISTER
# 07    ECADR OF WORD TO BE MODIFIED            3COMP   OCTAL ONLY FOR EACH
#       ONES FOR BITS TO BE MODIFIED
#       1 TO SET OR 0 TO RESET SELECTED BITS
# 08    ALARM DATA                              3COMP   OCTAL ONLY FOR EACH
# 09    ALARM CODES                             3COMP   OCTAL ONLY FOR EACH
# 10    CHANNEL TO BE SPECIFIED                 1COMP   OCTAL ONLY
# 11    TIG OF CSI                              3COMP   00XXX. HRS              DEC (
#                                                       000XX. MIN              MUST
#                                                       0XX.XX SEC
# 12    OPTION CODE                             2COMP   OCTAL ONLY FOR EACH
#       (USED BY EXTENDED VERBS ONLY)
# 13    TIG OF CDH                              3COMP   00XXX. HRS              DEC (
#                                                       000XX. MIN              MUST
#                                                       0XX.XX SEC
# 14    SPARE
# 15    INCREMENT MACHINE ADDRESS               1COMP   OCTAL ONLY
# 16    TIME OF EVENT                           3COMP   00XXX. HRS              DEC (
#       (USED BY EXTENDED VERBS ONLY)                   000XX. MIN              MUST
#                                                       0XX.XX SEC
# 17    ASTRONAUT TOTAL ATTITUDE                3COMP   XXX.XX DEG FOR EACH
# 18    AUTO MANEUVER BALL ANGLES               3COMP   XXX.XX DEG FOR EACH
# 19    BYPASS ATTITUDE TRIM MANEUVER           3COMP   XXX.XX DEG FOR EACH
# 20    ICDU ANGLES                             3COMP   XXX.XX DEG FOR EACH
# 21    PIPAS                                   3COMP   XXXXX. PULSES FOR EACH
# 22    NEW ICDU ANGLES                         3COMP   XXX.XX DEG FOR EACH
# 23    SPARE
```

```
# 24    DELTA TIME FOR AGC CLOCK                3COMP   00XXX. HRS.             DEC ONLY
#                                                       000XX. MIN              MUST LOAD 3 COM
#                                                       0XX.XX SEC
# 25    CHECKLIST                               3COMP   XXXXX. FOR EACH
#        (USED WITH PLEASE PERFORM ONLY)
```

Uses CODE 140, I 206, L 80, and TIG 224.

31 ⟨*Page CM0009* 31⟩≡ (21 2649)

```
# 26    PRIORITY/DELAY, ADRES, BBCON            3COMP   OCTAL ONLY FOR EACH
# 27    SELF TEST ON/OFF SWITCH                 1COMP   XXXXX.
# 28    SPARE
# 29    XSM LAUNCH AZIMUTH                      1COMP   XXX.XX DEG              DEC ONLY
```

Uses AZIMUTH 191, PRIORITY 145, and XSM 186.

32 ⟨*Page CM0010* 32⟩≡ (21 2649)

```
# 30    TARGET CODES                          3COMP   XXXXX. FOR EACH
# 31    TIME OF LANDING SITE                  3COMP   00XXX. HRS              DEC (
#                                                     000XX. MIN              MUST
#                                                     0XX.XX SEC
# 32    TIME FROM PERIGEE                     3COMP   00XXX. HRS              DEC (
#                                                     000XX. MIN              MUST
#                                                     0XX.XX SEC
# 33    TIME OF IGNITION                      3COMP   00XXX. HRS              DEC (
#                                                     000XX. MIN              MUST
#                                                     0XX.XX SEC
# 34    TIME OF EVENT                         3COMP   00XXX. HRS              DEC (
#                                                     000XX. MIN              MUST
#                                                     0XX.XX SEC
# 35    TIME FROM EVENT                       3COMP   00XXX. HRS              DEC (
#                                                     000XX. MIN              MUST
#                                                     0XX.XX SEC
# 36    TIME OF AGC CLOCK                     3COMP   00XXX. HRS              DEC (
#                                                     000XX. MIN              MUST
#                                                     0XX.XX SEC
# 37    TIG OF TPI                            3COMP   00XXX. HRS              DEC (
#                                                     000XX. MIN              MUST
#                                                     0XX.XX SEC
# 38    TIME OF STATE VECTOR                  3COMP   00XXX. HRS              DEC (
#                                                     000XX. MIN              MUST
#                                                     0XX.XX SEC
# 39    DELTA TIME FOR TRANSFER               3COMP   00XXX. HRS              DEC (
#                                                     000XX. MIN              MUST
#                                                     0XX.XX SEC
```

Uses STATE 138 and TIG 224.

33 ⟨*Page CM0011* 33⟩≡ (21 2649)

```
# MIXED NOUNS                              COMPONENTS   SCALE & DECIMAL POINT   RESTRICTIONS
#
# 40    TIME FROM IGNITION/CUTOFF               3COMP   XXBXX  MIN/SEC          NO LOAD, DEC ON
#       VG,                                             XXXX.X FT/SEC
#       DELTA V (ACCUMULATED)                           XXXX.X FT/SEC
# 41    TARGET  AZIMUTH,                        2COMP   XXX.XX DEG
#               ELEVATION                               XX.XXX DEG
# 42    APOGEE,                                 3COMP   XXXX.X NAUT MI          DEC ONLY
#       PERIGEE,                                        XXXX.X NAUT MI
#       DELTA V (REQUIRED)                              XXXX.X FT/SEC
# 43    LATITUDE,                               3COMP   XXX.XX DEG              DEC ONLY
#       LONGITUDE,                                      XXX.XX DEG
#       ALTITUDE                                        XXXX.X NAUT MI
# 44    APOGEE,                                 3COMP   XXXX.X NAUT MI          NO LOAD, DEC ON
#       PERIGEE,                                        XXXX.X NAUT MI
#       TFF                                             XXBXX  MIN/SEC
# 45    MARKS (VHF - OPTICS)                    3COMP   +XXBXX                  NO LOAD, DEC ON
#       TFI OF NEXT BURN                                XXBXX  MIN/SEC
#       MGA                                             XXX.XX DEG
# 46    AUTOPILOT CONFIGURATION                 2COMP   OCTAL ONLY FOR EACH
# 47    THIS VEHICLE WEIGHT                     2COMP   XXXXX. LBS              DEC ONLY
#       OTHER VEHICLE WEIGHT                            XXXXX. LBS
# 48    PITCH TRIM                              2COMP   XXX.XX DEG              DEC ONLY
#       YAW TRIM,                                       XXX.XX DEG
# 49    DELTA R                                 3COMP   XXXX.X NAUT MI          DEC ONLY
#       DELTA V                                         XXXX.X FT/SEC
#       VHF OR OPTICS CODE                              XXXXX.
# 50    SPLASH ERROR,                           3COMP   XXXX.X NAUT MI          NO LOAD, DEC ON
#       PERIGEE,                                        XXXX.X NAUT MI
#       TFF                                             XXBXX  MIN/SEC
# 51    S-BAND ANTENNA ANGLES PITCH             2COMP   XXX.XX DEG              DEC ONLY
#                              YAW                      XXX.XX DEG
# 52    CENTRAL ANGLE OF ACTIVE VEHICLE         1COMP   XXX.XX DEG
# 53    RANGE,                                  3COMP   XXX.XX NAUT MI          DEC ONLY
#       RANGE RATE,                                     XXXX.X FT/SEC
#       PHI                                             XXX.X DEG
# 54    RANGE,                                  3COMP   XXX.XX NAUT MI          DEC ONLY
#       RANGE RATE,                                     XXXX.X FT/SEC
#       THETA                                           XXX.XX DEG
# 55    PERIGEE CODE                            3COMP   XXXXX.                  DEC ONLY
#       ELEVATION ANGLE                                 XXX.XX DEG
#       CENTRAL ANGLE OF PASSIVE VEHICLE                XXX.XX DEG
# 56    REENTRY ANGLE,                          2COMP   XXX.XX DEG              DEC ONLY
#       DELTA V                                         XXXXX. FT/SEC
```

```
# 57    DELTA R                                1COMP   XXXX.X NAUT MI          DEC (
# 58    PERIGEE ALT (POST TPI)                 3COMP   XXXX.X NAUT MI          DEC (
#       DELTA V TPI                                    XXXX.X FT/SEC
#       DELTA V TPF                                    XXXX.X FT/SEC
# 59    DELTA VELOCITY LOS                     3COMP   XXXX.X FT/SEC FOR EA.   DEC (
# 60    GMAX,                                  3COMP   XXX.XX G                DEC (
```

Uses ALT 157, AZIMUTH 191, CODE 140, GMAX 229, LATITUDE 191, RANGE 179, REENTRY 65, TFF 179, TFI 185, THETA 148, V 229, and VG 234.

35 ⟨*Page CM0012* 35⟩≡ (21 2649)

```
#       VPRED,                                  XXXXX. FT/SEC
#       GAMMA EI                                XXX.XX DEG
# 61    IMPACT LATITUDE,                3COMP   XXX.XX DEG            DEC ONLY
#       IMPACT LONGITUDE,                       XXX.XX DEG
#       HEADS UP/DOWN                           +/- 00001
# 62    INERTIAL VEL MAG (VI),          3COMP   XXXXX. FT/SEC         DEC ONLY
#       ALT RATE CHANGE (HDOT),                 XXXXX. FT/SEC
#       ALT ABOVE PAD RADIUS (H)                XXXX.X NAUT MI
# 63    RANGE 297,431 TO SPLASH (RTGO),         3COMP   XXXX.X NAUT MI        NO LOAD, DEC ON
#       PREDICTED INERT VEL (VIO),              XXXXX. FT/SEC
#       TIME FROM 297,431 (TFE),                XXBXX  MIN/SEC
# 64    DRAG ACCELERATION,              3COMP   XXX.XX G              DEC ONLY
#       INERTIAL VELOCITY (VI),                 XXXXX. FT/SEC
#       RANGE TO SPLASH                         XXXX.X NAUT MI
# 65    SAMPLED AGC TIME                3COMP   00XXX. HRS            DEC ONLY
#        (FETCHED IN INTERRUPT)                 000XX. MIN            MUST LOAD 3 COM
#                                               0XX.XX SEC
# 66    COMMAND BANK ANGLE (BETA),      3COMP   XXX.XX DEG            DEC ONLY
#       CROSS RANGE ERROR,                      XXXX.X NAUT MI
#       DOWN RANGE ERROR                        XXXX.X NAUT MI
# 67    RANGE TO TARGET,                3COMP   XXXX.X NAUT MI        DEC ONLY
#       PRESENT LATITUDE,                       XXX.XX DEG
#       PRESENT LONGITUDE                       XXX.XX DEG
# 68    COMMAND BANK ANGLE (BETA),      3COMP   XXX.XX DEG            DEC ONLY
#       INERTIAL VELOCITY (VI),                 XXXXX. FT/SEC
#      ALT RATE CHANGE (RDOT)                   XXXXX. FT/SEC
# 69   BETA                            3COMP   XXX.XX DEG
#      DL                                      XXX.XX G
#      VL                                      XXXXX. FT/SEC
# 70    STAR CODE,                      3COMP   OCTAL ONLY
#       LANDMARK DATA,                          OCTAL ONLY
#       HORIZON DATA                            OCTAL ONLY
# 71    STAR CODE                       3COMP   OCTAL ONLY
#       LANDMARK DATA                           OCTAL ONLY
#       HORIZON DATA                            OCTAL ONLY
# 72    DELT ANG                        3COMP   XXX.XX DEG            DEC ONLY
# 73    ALTITUDE                        3COMP   XXXXXB. NAUT MI
#       VELOCITY                                XXXXX.  FT/SEC
#       FLIGHT PATH ANGLE                       XXX.XX  DEG
# 74    COMMAND BANK ANGLE (BETA)       3COMP   XXX.XX DEG
#       INERTIAL VELOCITY (VI)                  XXXXX. FT/SEC
#       DRAG ACCELERATION                       XXX.XX G
# 75    DELTA ALTITUDE CDH              3COMP   XXXX.X NAUT MI        NO LOAD, DEC ON
#       DELTA TIME (CDH-CSI OR TPI-CDH)         XXBXX  MIN/SEC
```

```
#       DELTA TIME (TPI-CDH OR TPI-NOMTPI)              XXBXX  MIN/SEC
# 76    SPARE
# 77    SPARE
# 78    SPARE
# 79    SPARE
# 80    TIME FROM IGNITION/CUTOFF               3COMP   XXBXX  MIN/SEC          NO LO
```

Uses ALT 157, CODE 140, COMMAND 169, DELT 188, GAMMA 232, H 177, HDOT 231, HORIZON 190, LANDMARK 190, LATITUDE 191, NOMTPI 181, RANGE 179, RDOT 229, RTGO 229, STAR 186, VEL 226, VIO 229, VL 229, and VPRED 231.

37 ⟨*Page CM0013* 37⟩≡ (21 2649)

```
#       VG                                          XXXXX. FT/SEC
#       DELTA V (ACCUMULATED)                       XXXXX. FT/SEC
# 81    DELTA V (LV)                        3COMP   XXXX.X FT/SEC FOR EACH  DEC ONLY
# 82    DELTA V (LV)                        3COMP   XXXX.X FT/SEC FOR EACH  DEC ONLY
# 83    DELTA V (BODY)                      3COMP   XXXX.X FT/SEC FOR EACH  DEC ONLY
# 84    DELTA V (OTHER VEHICLE)             3COMP   XXXX.X FT/SEC FOR EACH  DEC ONLY
# 85    VG (BODY)                           3COMP   XXXX.X FT/SEC FOR EACH  DEC ONLY
# 86    DELTA V (LV)                        3COMP   XXXXX. FT/SEC FOR EACH  DEC ONLY
# 87    MARK DATA       SHAFT,              2COMP   XXX.XX DEG
#                       TRUNION                     XX.XXX DEG
# 88    HALF UNIT SUN OR PLANET VECTOR      3COMP   .XXXXX FOR EACH         DEC ONLY
# 89    LANDMARK        LATITUDE,           3COMP   XX.XXX DEG              DEC ONLY
#                       LONGITUDE/2,                XX.XXX DEG
#                       ALTITUDE                    XXX.XX NAUT MI
# 90    Y                                   3COMP   XXX.XX NM               DEC ONLY
#       Y DOT                                       XXXX.X FPS
#       PSI                                         XXX.XX DEG
# 91    OCDU ANGLES     SHAFT,              2COMP   XXX.XX DEG
#                       TRUNION                     XX.XXX DEG
# 92    NEW OPTICS ANGLES       SHAFT,      2COMP   XXX.XX DEG
#                               TRUNON              XX.XXX DEG
# 93    DELTA GYRO ANGLES                   3COMP   XX.XXX DEG FOR EACH
# 94    NEW OPTICS ANGLES       SHAFT       2COMP   XXX.XX DEG
#                               TRUNION             XX.XXX DEG
# 95    PREFERRED ATTITUDE ICDU ANGLES      3COMP   XXX.XX FOR EACH
# 96    +X-AXIS ATTITUDE ICDU ANGLES        3COMP   XXX.XX DEG FOR EACH
# 97    SYSTEM TEST INPUTS                  3COMP   XXXXX. FOR EACH
# 98    SYSTEM TEST RESULTS AND INPUTS      3COMP   XXXXX.
#                                                   .XXXXX
#                                                   XXXXX.
# 99    RMS IN POSITION                     3COMP   XXXXX.FT                DEC ONLY
#       RMS IN VELOCITY                             XXXX.X FT/SEC
#       RMS OPTION                                  XXXXX.
```

Uses LANDMARK 190, LATITUDE 191, LV 85, TRUNION 190, V 229, and VG 234.

38 ⟨*Page CM0014* 38⟩≡ (21 2649)

```
# REGISTERS AND SCALING  FOR NORMAL NOUNS
#
# NOUN          REGISTER        SCALE TYPE
#
# 00    NOT IN USE
# 01    SPECIFY ADDRESS         B
# 02    SPECIFY ADDRESS         C
# 03    SPECIFY ADDRESS         D
# 04    SPARE
# 05            DSPTEM1         H
# 06            OPTION1         A
# 07            XREG            A
# 08            ALMCADR         A
# 09            FAILREG         A
# 10    SPECIFY CHANNEL         A
# 11            TCSI            K
# 12            OPTIONX         A
# 13            TCDH            K
# 14    SPARE
# 15    INCREMENT ADDRESS       A
# 16            DSPTEMX         C
# 17            CPHIX           D
# 18            THETAD          D
# 19            THETAD          D
# 20            CDUX            D
# 21            PIPAX           C
# 22            THETAD          D
# 23    SPARE
# 24            DSPTEM2 +1      K
# 25            DSPTEM1         C
# 26            DSPTEM1         A
# 27            SMODE           C
# 28    SPARE
# 29            DSPTEM1         D
# 30            DSPTEM1         C
# 31            DSPTEM1         K
# 32            -TPER           K
# 33            TIG             K
# 34            DSPTEM1         K
# 35            TTOGO           K
# 36            TIME2           K
# 37            TTP1            K
# 38            TET             K
# 39            T3TOT4          K
```

Uses -TPER 179, A 80, ALMCADR 165, CDUX 80, CPHIX 163, D 226, DSPTEM1 154, DSPTEM2 154, DSPTEMX 154, FAILREG 150, H 177, OPTION1 157, OPTIONX 154, PIPAX 80, SMODE 165, T3TOT4 185, TCDH 197, TCSI 197, TET 169, THETAD 157, TIG 224, TIME2 80, TTOGO 236, and XREG 152.

40 ⟨*Page CM0015* 40⟩≡ (21 2649)

```
# REGISTERS AND SCALING FOR MIXED NOUNS
#
# NOUN  COMP    REGISTER        SCALE TYPE
#
# 40    1       TTOGO           L
#       2       VGDISP          S
#       3       DVTOTAL         S
# 41    1       DSPTEM1         D
#       2       DSPTEM1 +1      E
# 42    1       HAPO            Q
#       2       HPER            Q
#       3       VGDISP          S
# 43    1       LAT             H
#       2       LONG            H
#       3       ALT             Q
# 44    1       HAPOX           Q
#       2       HPERX           Q
#       3       TFF             L
# 45    1       VHFCNT          PP
#       2       TTOGO           L
#       3       +MGA            H
# 46    1       DAPDATR1        A
#       2       DAPDATR2        A
# 47    1       CSMMASS         KK
#       2       LEMMASS         KK
# 48    1       PACTOFF         FF
#       2       YACTOFF         FF
# 49    1       N49DISP         Q
#       2       N49DISP +2      S
#       3       N49DISP +4      C
# 50    1       RSP-RREC        LL
#       2       HPERX           Q
#       3       TFF             L
# 51    1       RHOSB           H
#       2       GAMMASB         H
# 52    1       ACTCENT         H
# 53    1       RANGE           JJ
#       2       RRATE           S
#       3       RTHETA          H
# 54    1       RANGE           JJ
#       2       RRATE           S
#       3       RTHETA          H
# 55    1       NN1             C
#       2       ELEV            H
```

```
#        3        CENTANG          H
# 56     1        RTEGAM2D         H
#        2        RTEDVD           P
# 57     1        DELTAR           Q
# 58     1        POSTTPI          Q
#        2        DELVTPI          S
```

Uses +MGA 234, A 80, ACTCENT 183, ALT 157, CSMMASS 200, D 226, DAPDATR1 200, DAPDATR2 200, DELTAR 183, DELVTPI 183, DSPTEM1 154, DVTOTAL 224, GAMMASB 179, H 177, HAPO 181, HAPOX 181, HPER 181, HPERX 181, JJ 229, L 80, LAT 157, LEMMASS 200, LONG 157, N49DISP 232, NN1 241, P 188, PACTOFF 198, POSTTPI 183, Q 80, RANGE 179, RHOSB 179, RRATE 179, RSP-RREC 181, RTEDVD 241, RTEGAM2D 241, RTHETA 179, TFF 179, TTOGO 236, VGDISP 231, VHFCNT 157, and YACTOFF 198.

42 ⟨*Page CM0016* 42⟩≡ (21 2649)

```
#       3       DELVTPF         S
# 59    1       DVLOS           S
#       2       DVLOS +2        S
#       3       DVLOS +4        S
# 60    1       GMAX            T
#       2       VPRED           P
#       3       GAMMAEI         H
# 61    1       LAT(SPL)        H
#       2       LNG(SPL)        H
#       3       HEADSUP         C
# 62    1       VMAGI           P
#       2       HDOT            P
#       3       ALTI            Q
# 63    1       RTGO            LL
#       2       VIO             P
#       3       TTE             L
# 64    1       D               MM
#       2       VMAGI           P
#       3       RTGON64         LL
# 65    1       SAMPTIME        K
#       2       SAMPTIME        K
#       3       SAMPTIME        K
# 66    1       ROLLC           H
#       2       XRNGERR         VV
#       3       DNRNGERR        LL
# 67    1       RTGON67         LL
#       2       LAT             H
#       3       LONG            H
# 68    1       ROLLC           H
#       2       VMAGI           P
#       3       RDOT            UU
# 69    1       ROLLC           H
#       2       Q7              MM
#       3       VL              UU
# 70    1       STARCODE        A
#       2       LANDMARK        A
#       3       HORIZON         A
# 71    1       STARCODE        A
#       2       LANDMARK        A
#       3       HORIZON         A
# 72    1       THETZERO        H
# 73    1       P21ALT          Q (MEMORY/100 TO DISPLAY TENS N.M.)
#       2       P21VEL          P
#       3       P21GAM          H
```

```
# 74    1       ROLLC           H
#       2       VMAGI           P
#       3       D               MM
# 75    1       DIFFALT         Q
#       2       T1TOT2          L
#       3       T2TOT3          L
```

Uses A 80, ALTI 231, D 226, DELVTPF 183, DIFFALT 197, DNRNGERR 229, DVLOS 183, GAMMAEI 231, GMAX 229, H 177, HDOT 231, HEADSUP 216, HORIZON 190, L 80, LANDMARK 190, LAT 157, LAT(SPL) 224, LNG(SPL) 224, LONG 157, MM 226, N 206, P 188, P21ALT 244, P21GAM 244, P21VEL 244, Q 80, Q7 223, RDOT 229, ROLLC 214, RTGO 229, RTGON64 229, RTGON67 231, SAMPTIME 80, STARCODE 150, T1TOT2 197, T2TOT3 244, THETZERO 185, TTE 229, VIO 229, VL 229, VMAGI 229, VPRED 231, and XRNGERR 229.

44 ⟨*Page CM0017* 44⟩≡ (21 2649)

```
# 76    SPARE
# 77    SPARE
# 78    SPARE
# 79    SPARE
# 80    1       TTOGO           L
#       2       VGDISP          P
#       3       DVTOTAL         P
# 81    1       DELVLVC         S
#       2       DELVLVC +2      S
#       3       DELVLVC +4      S
# 82    1       DELVLVC         S
#       2       DELVLVC +2      S
#       3       DELVLVC +4      S
# 83    1       DELVIMU         S
#       2       DELVIMU +2      S
#       3       DELVIMU +4      S
# 84    1       DELVOV          S
#       2       DELVOV +2       S
#       3       DELVOV +4       S
# 85    1       VGBODY          S
#       2       VGBODY +2       S
#       3       VGBODY +4       S
# 86    1       DELVLVC         P
#       2       DELVLVC +2      P
#       3       DELVLVC +4      P
# 87    1       MRKBUF1 +3      D
#       2       MRKBUF1 +5      J
# 88    1       STARSAV         ZZ
#       2       STARSAV +2      ZZ
#       3       STARSAV +4      ZZ
# 89    1       LANDLAT         G
#       2       LANDLONG        G
#       3       LANDALT         JJ
# 90    1       RANGE           JJ
#       2       RRATE           S
#       3       RTHETA          H
# 91    1       CDUS            D
#       2       CDUT            J
# 92    1       SAC             D
#       2       PAC             J
# 93    1       OGC             G
#       2       OGC +2          G
#       3       OGC +4          G
# 94    1       MRKBUF1 +3      D
```

```
#       2       MRKBUF1 +5      J
# 95    1       PRAXIS          D
#       2       PRAXIS +1       D
#       3       PRAXIS +2       D
# 96    1       CPHIX           D
#       2       CPHIX +1        D
```

Uses CDUS 80, CDUT 80, CPHIX 163, D 226, DELVIMU 238, DELVLVC 224, DELVOV 234, DVTOTAL 224, H 177, JJ 229, L 80, LANDALT 181, LANDLAT 157, LANDLONG 181, OGC 186, P 188, PAC 186, RANGE 179, RRATE 179, RTHETA 179, SAC 186, TTOGO 236, VGBODY 238, and VGDISP 231.

45 ⟨*Page CM0018* 45⟩≡ (21 2649)

```
#       3       CPHIX +2        D
# 97    1       DSPTEM1         C
#       2       DSPTEM1 +1      C
#       3       DSPTEM1 +2      C
# 98    1       DSPTEM2         C
#       2       DSPTEM2 +1      B
#       3       DSPTEM2 +2      C
# 99    1       WWPOS           XX
#       2       WWVEL           YY
#       3       WWOPT           C
```

Uses CPHIX 163, D 226, DSPTEM1 154, and DSPTEM2 154.

46 ⟨*Page CM0019* 46⟩≡ (21 2649)

```
# NOUN SCALES AND FORMATS
#
# -SCALE TYPE-                              PRECISION
# UNITS                 DECIMAL FORMAT          --      AGC FORMAT
# ------------          --------------          --      ----------
#
# -A-
# OCTAL                 XXXXX                   SP      OCTAL
#
# -B-                                                            -14
# FRACTIONAL            .XXXXX                  SP      BIT 1 = 2    UNITS
#                       (MAX .99996)
#
# -C-
# WHOLE                 XXXXX.                  SP      BIT 1 = 1 UNIT
#                       (MAX 16383.)
#
# -D-                                                              15
# CDU DEGREES           XXX.XX DEGREES          SP      BIT 1 = 360/2   DEGREES
#                       (MAX 359.99)                    (USES 15 BITS FOR MAGNI-
#                                                        TUDE AND 2-S COMP.)
#
# -E-                                                             14
# ELEVATION DEGREES     XX.XXX DEGREES          SP      BIT 1 = 90/2   DEGREES
#                       (MAX 89.999)
#
# -F-                                                              14
# DEGREES (180)         XXX.XX DEGREES          SP      BIT 1 = 180/2   DEGREES
#                       (MAX 179.99)
#
# -G-
# DP DEGREES(90)        XX.XXX DEGREES          DP      BIT 1 OF LOW REGISTER =
#                                                            28
#                                                       360/2   DEGREES
#
# -H-
# DP DEGREES (360)      XXX.XX DEGREES          DP      BIT 1 OF LOW REGISTER =
#                                                            28
#                       (MAX 359.99)                    360/2   DEGREES
#
# -J-                                                             15
# Y OPTICS DEGREES      XX.XXX DEGREES          SP      BIT 1 = 90/2   DEGREES
#                       (BIAS OF 19.775                 (USES 15 BITS FOR MAGNI-
#                       DEGREES ADDED FOR               TUDE AND 2-S COMP.)
```

```
#                       DISPLAY, SUBTRACTED
#                       FOR LOAD.)
#                       NOTE: NEGATIVE NUM-
#                       BERS CANNOT BE
#                       LOADED.
#
# -K-
```

Uses `A` 80, `BIAS` 211, `D` 226, `F` 238, and `H` 177.

48 ⟨*Page CM0020* 48⟩≡ (21 2649)

```
# TIME (HR, MIN, SEC)   00XXX. HR               DP      BIT 1 OF LOW REGISTER =
#                       000XX. MIN                        -2
#                       0XX.XX SEC                      10   SEC
#                       (DECIMAL ONLY.
#                       MAX MIN COMP=59
#                       MAX SEC COMP=59.99
#                       MAX CAPACITY=745 HRS
#                                    39 MINS
#                                    14.55 SECS.
#                       WHEN LOADING, ALL 3
#                       COMPONENTS MUST BE
#                       SUPPLIED.)
#
# -L-
# TIME (MIN/SEC)        XXBXX MIN/SEC           DP      BIT 1 OF LOW REGISTER =
#                       (B IS A BLANK                     -2
#                       POSITION, DECIMAL               10   SEC
#                       ONLY, DISPLAY OR
#                       MONITOR ONLY. CANNOT
#                       BE LOADED.
#                       MAX MIN COMP=59
#                       MAX SEC COMP=59
#                       VALUES GREATER THAN
#                       59 MIN 59 SEC
#                       ARE DISPLAYED AS
#                       59 MIN 59 SEC.)
#
# -M-                                                           -2
# TIME (SEC)            XXX.XX SEC              SP      BIT 1 = 10   SEC
#                       (MAX 163.83)
#
# -N-
# TIME(SEC) DP          XXX.XX SEC              DP      BIT 1 OF LOW REGISTER =
#                                                         -2
#                                                       10   SEC
#
# -P-
# VELOCITY 2            XXXXX. FEET/SEC         DP      BIT 1 OF HIGH REGISTER =
#                       (MAX 41994.)                     -7
#                                                       2   METERS/CENTI-SEC
#
# -Q-
# POSITION 4            XXXX.XX NAUTICAL MILES  DP      BIT 1 OF LOW REGISTER =
#                                                       2 METERS
```

```
#
# -S-
# VELOCITY 3            XXXX.X FT/SEC           DP      BIT 1 OF HIGH REGISTER =
#                                                        -7
#                                                       2   METERS/CENTI-SEC
```

Uses A 80, L 80, N 206, P 188, and Q 80.

50 ⟨*Page CM0021* 50⟩≡ (21 2649)

```
# -T-                                                          -2
# G                    XXX.XX G                SP      BIT 1 = 10   G
#                      (MAX 163.83)
#
# -FF-
# TRIM DEGREES         XXX.XX DEG.             SP      LOW ORDER BIT = 85.41 SEC
#                      (MAX 388.69)                    OF ARC
#
# -GG-
# INERTIA              XXXXXBB. SLUG FT SQ     SP      FRACTIONAL PART OF
#                      (MAX 07733BB.)                   20     2
#                                                      2   KG M
#
# -II-                                                                     20
# THRUST MOMENT        XXXXXBB. FT LBS         SP      FRACTIONAL PART OF 2
#                      (MAX 07733BB.)                  NEWTON METER
#
# -JJ-
# POSITION5            XXX.XX NAUT MI          DP      BIT 1 OF LOW REGISTER =
#                                                      2 METERS
#
# -KK-                                                                     16
# WEIGHT2              XXXXX. LBS              SP      FRACTIONAL PART OF 2   KG
#
# -LL-
# POSITION6            XXXX.X NAUT MI          DP      BIT 1 OF LOW REG =
#                                                                         -28
#                                                      (6,373,338)(2(PI))X2
#                                                      -----------------------
#                                                               1852
#                                                      NAUT. MI.
#
# -MM-
# DRAG ACCELERATION    XXX.XX G                DP      BIT 1 OF LOW REGISTER =
#                      MAX (024.99)                        -28
#                                                      25X2    G
#
# -PP-
# 2 INTEGERS           +XXBYY                  DP      BIT 1 OF HIGH REGISTER =
#                      (B IS A BLANK                    1 UNIT OF XX
#                      POSITION.  DECIMAL              BIT 1 OF LOW REGISTER =
#                      ONLY, DISPLAY, OR                1 UNIT OF YY
#                      MONITOR ONLY. CANNOT            (EACH REGISTER MUST
#                      BE LOADED.)                     CONTAIN A POSITIVE INTEGER
```

```
#                        (MAX 99B99)                      LESS THAN 100)
#
# -UU-
# VELOCITY/2VS           XXXXX. FEET/SEC         DP      FRACTIONAL PART OF
#                        (MAX 51532.)                    2VS FEET/SEC
#                                                        (VS = 25766.1973)
```

Uses A 80, JJ 229, MM 226, SQ 156, THRUST 85, and X2 85.

51 ⟨*Page CM0022* 51⟩≡ (21 2649)

```
# -VV-
# POSITION8              XXXX.X NAUT MI          DP      BIT 1 OF LOW REGISTER =
#                                                                          -28
#                                                        4 X 6,373,338 X 2
#                                                        --------------------
#                                                              1852
#                                                        NAUT MI.
#
# -XX-
# POSITION 9             XXXXX. FEET             DP      BIT 1 OF LOW REGISTER =
#                                                         -9
#                                                        2   METERS
#
# -YY-
# VELOCITY 4             XXXX.X FEET/SEC         DP      FRACTIONAL PART OF
#                        (MAX 328.0)                     METERS/CENTI-SEC
#
# -ZZ-
# DP FRACTIONAL          .XXXXX                  DP      BIT 1 OF HIGH REGISTER =
#                                                         -14
#                                                        2    UNITS

# THAT-S ALL ON THE NOUNS.
```

52 ⟨*Page CM0023* 52⟩≡ (21 2649)

```
# ALARM CODES FOR 504

# REPORT DEFICIENCIES TO JOHN SUTHERLAND @ MIT 617-864-6900 X1458

# *9            *18                                          *60
#
# CODE       *  TYPE                                         SET BY
#
# 00110         NO MARK SINCE LAST MARK REJECT               SXTMARK
# 00112         MARK NOT BEING ACCEPTED                      SXTMARK
# 00113         NO INBITS                                    SXTMARK
# 00114         MARK MADE BUT NOT DESIRED                    SXTMARK
# 00115         OPTICS TORQUE REQUESTWITH SWITCH NOT AT      EXT VERB OPTICS CDU
#                CGC
# 00116         OPTICS SWITCH ALTERED BEFORE 15 SEC ZERO     T4RUPT
#                TIME ELAPSED.
# 00117         OPTICS TORQUE REQUEST WITH OPTICS NOT        EXT VERB OPTICS CDU
#                AVAILABLE (OPTIND=-0)
# 00120         OPTICS TORQUE REQUEST WITH OPTICS            T4RUPT
#                NOT ZEROED
# 00121         CDUS NO GOOD AT TIME OF MARK                 SXTMARK
# 00122         MARKING NOT CALLED FOR                       SXTMARK
# 00124         P17 TPI SEARCH - NO SAFE PERICTR HERE.       TPI SEARCH
# 00205         BAD PIPA READING                             SERVICER
# 00206         ZERO ENCODE NOT ALLOWED WITH COARSE ALIGN    IMU MODE SWITCHING
#                + GIMBAL LOCK
# 00207         ISS TURNON REQUEST NOT PRESENT FOR 90 SEC    T4RUPT
# 00210         IMU NOT OPERATING                            IMU MODE SWITCH, IMU-
# 00211         COARSE ALIGN ERROR - DRIVE > 2 DEGREES       IMU MODE SWITCH
# 00212         PIPA FAIL BUT PIPA IS NOT BEING USED         IMU MODE SWITCH,T4RUP
# 00213         IMU NOT OPERATING WITH TURN-ON REQUEST       T4RUPT
# 00214         PROGRAM USING IMU WHEN TURNED OFF            T4RUPT
# 00215         PREFERRED ORIENTATION NOT SPECIFIED          P52,P54
# 00217         BAD RETURN FROM STALL ROUTINES.              CURTAINS
# 00220         IMU NOT ALIGNED - NO REFSMMAT                R02,P51
# 00401         DESIRED GIMBAL ANGLES YIELD GIMBAL LOCK      IMF ALIGN, IMU-2
# 00404         TARGET OUT OF VIEW - TRUN ANGLE > 90 DEG     R52
# 00405         TWO STARS NOT AVAILABLE                      P52,P54
# 00406         REND NAVIGATION NOT OPERATING                P21,R23
# 00407         AUTO OPTICS REQUEST TRUN ANGLE > 50 DEG.     R52
# 00421         W-MATRIX OVERFLOW                            INTEGRV
# 00430      *  INTEG. ABORT DUE TO SUBSURFACE S. V.         ALL CALLS TO INTEG
# 00600         IMAGINARY ROOTS ON FIRST ITERATION           P32, P72
# 00601         PERIGEE ALTITUDE LT PMIN1                    P32,P72,
```

```
# 00602         PERIGEE ALTITUDE LT PMIN2                      P32,P72,
# 00603         CSI TO CDH TIME LT PMIN22                      P32,P72,P33,P73
# 00604         CDH TO TPI TIME LT PMIN23                      P32,P72
# 00605         NUMBER OF ITERATIONS EXCEEDS LOOP MAXIMUM      P32,P72,P37
# 00606         DV EXCEEDS MAXIMUM                             P32,P72
# 00607      *  NO SOLN FROM TIME-THETA OR TIME-RADIUS         TIMETHET,TIMERAD
```

Uses CDUS 80, CODE 140, DV 241, MODE 145, OPTIND 161, P21 219, RO2 59, REFSMMAT 172, THETA 148, V 229, and W 183.

54 ⟨*Page CM0024* 54⟩≡ (21 2649)

```
# 00610      *  LAMBDA LESS THAN UNITY                          P37
# 00611         NO TIG FOR GIVEN ELEV ANGLE                     P34,P74
# 00612         STATE VECTOR IN WRONG SPHERE OF INFLUENCE       P37
# 00613         REENTRY ANGLE OUT OF LIMITS                     P37
# 00777         PIPA FAIL CAUSED ISS WARNING.                   T4RUPT
# 01102         CMC SELF TEST ERROR
# 01103      *  UNUSED CCS BRANCH EXECUTED                      ABORT
# 01104      *  DELAY ROUTINE BUSY                              EXEC
# 01105         DOWNLINK TOO FAST                               T4RUPT
# 01106         UPLINK TOO FAST                                 T4RUPT
# 01107         PHASE TABLE FAILURE. ASSUME                     RESATRT
#               ERASABLE MEMORY IS DESTROYED
# 01201      *  EXECUTIVE OVERFLOW-NO VAC AREAS                 EXEC
# 01202      *  EXECUTIVE OVERFLOW-NO CORE SETS                 EXEC
# 01203      *  WAITLIST OVERFLOW-TOO MANY TASKS                WAITLIST
# 01204      *  NEGATIVE OR ZERO WAITLIST CALL                  WAITLIST
# 01206      *  SECOND JOB ATTEMPTS TO GO TO SLEEP              PINBALL
#               VIA KEYBOARD AND DISPLAY PROGRAM
# 01207      *  NO VAC AREA FOR MARKS                           SXTMARK
# 01210      *  TWO PROGRAMS USING DEVICE AT SAME TIME          IMU MODE SWITCH
# 01211      *  ILLEGAL INTERRUPT OF EXTENDED VERB              SXTMARK
# 01301         ARCSIN-ARCCOS ARGUMENT TOO LARGE                INTERPRETER
# 01302      *  SQRT CALLED WITH NEGATIVE ARGUMENT.ABORT        INTERPRETER
# 01407         VG INCREASING                                   S40.8
# 01426         IMU UNSATISFACTORY                              P61, P62
# 01427         IMU REVERSED                                    P61, P62
# 01501      *  KEYBOARD AND DISPLAY ALARM DURING               PINBALL
#                INTERNAL USE (NVSUB). ABORT.
# 01502      *  ILLEGAL FLASHING DISPLAY                        GOPLAY
# 01520         V37 REQUEST NOT PERMITTED AT THIS TIME          V37
# 01521      *  P01 ILLEGALLY SELECTED                          P01, P07
# 01600         OVERFLOW IN DRIFT TEST                          OPT PRE ALIGN CALIB
# 01601         BAD IMU TORQUE                                  OPT PRE ALIGN CALIB
# 01602         BAD OPTICS DURING VERIFICATION                  OPTALGN CALIB (CSM)
# 01703         INSUF. TIME FOR INTEG., TIG WAS SLIPPED         R41
# 03777         ICDU FAIL CAUSED THE ISS WARNING                T4RUPT
# 04777         ICDU , PIPA FAILS CAUSED THE ISS WARNING        T4RUPT
# 07777         IMU FAIL CAUSED THE ISS WARNING                 T4RUPT
# 10777         IMU , PIPA FAILS CAUSED THE ISS WARNING         T4RUPT
# 13777         IMU , ICDU FAILS CAUSED THE ISS WARNING         T4RUPT
# 14777         IMU,ICDU,PIPA FAILS CAUSED THE ISSWNING         T4RUPT
#            *  INDICATES ABORT TYPE.ALL OTHERS ARE NON-ABORTIVE
```

Uses MODE 145, REENTRY 65, STATE 138, TIG 224, and VG 234.

55 ⟨*Page CM0025* 55⟩≡ (21 2649)

```
#               CHECKLIST CODES FOR 504

#               PLEASE REPORT ANY DEFICIENCIES IN THIS LIST TO JOHN SUTHERLAND

# *9            *17             *26  COLUMN
#
# R1 CODE          ACTION TO BE EFFECTED
#
# 00014         KEY IN          FINE ALIGNMENT OPTION
# 00015         PERFORM         CELESTIAL BODY ACQUISITION
# 00016         KEY IN          TERMINATE MARK SEQUENCE
# 00041         SWITCH          CM/SM SEPARATION TO UP
# 00062         SWITCH          AGC POWER DOWN
# 00202         PERFORM         GNCS AUTOMATIC MANEUVER
# 00203         SWITCH          TO CMC-AUTO
# 00204         PERFORM         SPS GIMBAL TRIM
# 00403         SWITCH          OPTICS TO MANUAL OR ZERO
#                                 SWITCH DENOTES CHANGE POSITION OF A CONSOLE SWITCH
#                                 PERFORM DENOTES START OF END OF A TASK
#                                 KEY IN DENOTES KEY IN OF DATA THRU THE DSKY
```

Uses `A` 80 and `CODE` 140.

56a ⟨*Page CM0026* 56a⟩≡ (21 2649)

```
#          OPTION CODES FOR 504

#          PLEASE REPORT ANY DEFICIENCIES IN THIS LIST TO JOHN SUTHERLAND

# THE SPECIFIED OPTION CODES WILL BE FLASHED IN COMPONENT R1 IN
# CONJUNCTION WITH VERB04NOUN06 TO REQUEST THE ASTRONAUT TO LOAD INTO
# COMPONENT R2 THE OPTION HE DESIRES.

# *9            *17                            #52                            #11
#
# OPTION
# CODE          PURPOSE                        INPUT FOR COMPONENT 2          PROGR
#
# 00001         SPECIFY IMU ORIENTATION        1=PREF 2=NOM 3=REFSMMAT        P50'S
# 00002         SPECIFY VEHICLE                1=THIS 2=OTHER                 P21,P
# 00003         SPECIFY TRACKING ATTITUDE      1=PREFERRED 2=OTHER            R63
# 00004         SPECIFY RADAR                  1=RR 2=LR                      R04
# 00005         SPECIFY SOR PHASE              1=FIRST 2=SECOND               P38
# 00006         SPECIFY RR COARSE ALIGN OPTION 1=LOCKON 2=CONTINUOUS DESIG.   V41N7
# 00007         SPECIFY PROPULSION SYSTEM      1=SPS 2=RCS                    P37
# 00010         SPECIFY ALIGNMENT MODE         0=ANY TIME 1=REFSMMAT +G       P57
#                                              2=TWO BODIES 3=ONE BODY + G
# 00011         SPEC. SEPARATION MONITOR PHASE 1=DELTAV 2=STATE VECTOR UPDATE P46
# 00012         SPECIFY CSM ORBIT OPTION       1=NO ORBIT CHANGE 2=CHANGE     P22
#                                              ORBIT TO PASS OVER LM
```

Uses CODE 140, MODE 145, P21 219, R2 188, REFSMMAT 172, and STATE 138.

3.1.3 tags for relative setloc

56b ⟨*tags for relative setloc* 56b⟩≡ (19b)

⟨*Page CM0027* 57⟩
⟨*Page CM0028* 59⟩
⟨*Page CM0029* 61⟩
⟨*Page CM0030* 63⟩
⟨*Page CM0031* 65⟩
⟨*Page CM0032* 67⟩
⟨*Page CM0033* 69⟩
⟨*Page CM0034* 71⟩
⟨*Page CM0035* 73⟩
⟨*Page CM0036* 74a⟩

57 ⟨*Page CM0027* 57⟩≡ (56b 2816)

```
# TAGS FOR RELATIVE SETLOC AND BLANK BANK CARDS

FIXED           MEMORY  120000 - 167777
                COUNT   BANKSUM

# MODULE 1 CONTAINS BANKS 0 THROUGH 5

                BLOCK   02
FFTAG1          EQUALS
FFTAG2          EQUALS
FFTAG3          EQUALS
FFTAG4          EQUALS
FFTAG7          EQUALS
FFTAG8          EQUALS
FFTAG9          EQUALS
FFTAG10         EQUALS
FFTAG12         EQUALS
P30SUBS         EQUALS
STOPRAT         EQUALS
P23S            EQUALS
                BNKSUM  02

                BLOCK   03
FFTAG5          EQUALS
FFTAG6          EQUALS
DAPS9           EQUALS
FFTAG13         EQUALS
                BNKSUM  03

                BANK    00
DLAYJOB         EQUALS
                BNKSUM  00

                BANK    01
RESTART         EQUALS
                BNKSUM  01

                BANK    4
VERB37          EQUALS
CONICS1         EQUALS
PINBALL4        EQUALS
CSI/CDH1        EQUALS
INTPRET2        EQUALS
IMUCAL1         EQUALS
```

Defines:
CONICS1, used in chunks 1742, 1743, 1765, and 2050.
CSI/CDH1, used in chunks 1063, 2223, and 2759.
DAPS9, never used.
DLAYJOB, used in chunk 2001.
FFTAG1, used in chunks 380, 1891, 1892, 1903, and 2001.
FFTAG10, used in chunks 331 and 335.
FFTAG12, used in chunks 251 and 1063.
FFTAG13, used in chunk 2011.
FFTAG2, used in chunks 1039, 1907, and 1911.
FFTAG3, used in chunk 1917.
FFTAG4, used in chunks 1963 and 2001.
FFTAG5, used in chunk 2045.
FFTAG6, used in chunks 1663, 2001, 2295, and 2542.
FFTAG7, used in chunks 2007 and 2011.
FFTAG8, used in chunk 595.
FFTAG9, used in chunk 2496.
IMUCAL1, used in chunk 737.
INTPRET2, used in chunks 1646a and 2477a.
P23S, never used.
P30SUBS, used in chunks 782 and 1062a.
PINBALL4, used in chunk 627.
RESTART, used in chunks 22, 28, 103, 150, 157, 167, 185, 206, 208, 223, 249, 257, 259, 265, 267, 269, 270, 272, 274, 277, 285, 307, 309, 317, 319, 321, 323, 331, 333, 335, 341, 343, 345, 362, 364, 366, 368, 374, 376, 405, 425, 434, 436, 446, 508, 644, 649, 710, 712, 714, 717, 864, 870, 959, 979, 1094, 1147, 1200, 1227, 1256, 1299, 1347, 1356, 1367, 1373, 1412, 1481, 1485, 1487, 1489, 1493, 1504, 1524, 1536, 1774, 1802, 1872, 1874, 1880, 1882, 1893, 1894, 1896, 1905, 1907, 1909, 1911, 1913, 1936, 1941, 1949, 1950, 1962, 1995, 2009, 2015, 2059, 2064, 2076, 2107a, 2108, 2265, 2267, 2269, 2273, 2275, 2281, 2285, 2289, 2291, 2311, 2382, 2461, 2472, 2478, 2480, 2486, 2488, 2504, 2505, 2519, 2588, 2590, 2833, and 2837.
STOPRAT, used in chunk 690.
VERB37, used in chunks 331, 335, 351, and 357.
Uses COUNT 142.

59 ⟨*Page CM0028* 59⟩≡ (56b 2816)

```
STBLEORB        EQUALS
E/PROG          EQUALS
MIDDGIM         EQUALS

                BNKSUM  04

                BANK    5
FRANDRES        EQUALS
DOWNTELM        EQUALS
DAPMASS         EQUALS
CDHTAG          EQUALS
                BNKSUM  05

# MODULE 2 CONTAINS BANKS 6 THROUGH 13

                BANK    6
IMUCOMP         EQUALS
T4RUP           EQUALS
IMUCAL2         EQUALS
CSIPROG         EQUALS
                BNKSUM  06

                BANK    7
SXTMARKE        EQUALS
R02             EQUALS
MODESW          EQUALS
XANG            EQUALS
KEYRUPT         EQUALS
CSIPROG6        EQUALS
                BNKSUM  07

                BANK    10
DISPLAYS        EQUALS
PHASETAB        EQUALS
COMGEOM2        EQUALS
SXTMARK1        EQUALS
P60S4           EQUALS
OPTDRV          EQUALS
CSIPROG8        EQUALS
                BNKSUM  10

                BANK    11
ORBITAL         EQUALS
ORBITAL1        EQUALS                  # CONSTANTS
```

Defines:

CDHTAG, used in chunks 1063 and 2759.
COMGEOM2, used in chunk 485.
CSIPROG, used in chunks 1063 and 2759.
CSIPROG6, used in chunk 1063.
CSIPROG8, used in chunk 1063.
DAPMASS, used in chunk 1362.
DISPLAYS, used in chunks 113, 161, 253, 329, 438, 451, 506, 519, 551, 559, 567, 599, 601, 603, 607, 612, 613, 647, 711, 753, 760, 860, 874, 927, 936, 1011, 1015, 1045, 1063, 1147, 1200, 1256, 1412, 1616, 1852, 1872, 1874, 1949–51, 1955–59, 1961–63, 1979, 1983, 1989, 2009, 2084, 2091, 2094, 2148, 2213, 2223, 2254, 2275, 2281, 2293, 2311, 2371, 2382, 2420, 2422, 2424, 2432, 2478, 2480, 2509, 2542, 2833, and 2837.
DOWNTELM, used in chunks 294, 1528, and 2465.
E/PROG, used in chunk 694.
FRANDRES, used in chunks 311 and 2048.
IMUCAL2, never used.
IMUCOMP, used in chunk 493.
KEYRUPT, used in chunks 24, 515, 1945, 2833, and 2837.
MIDDGIM, used in chunk 795.
MODESW, used in chunk 1918.
OPTDRV, used in chunk 288.
ORBITAL, used in chunks 24, 107, 359, 360, 754, 784, 820, 822, 823, 825, 827, 831, 835–37, 842, 919, 921, 943, 977, 1015, 1200, 1256, 1713, 1714, 1772, 1778, 1788, 1814, 1852, 2015, 2081, 2299, 2833, and 2837.
ORBITAL1, used in chunk 1814.
P60S4, used in chunk 1200.
PHASETAB, used in chunks 1891 and 1900.
RO2, used in chunks 52, 198, 1939, 2219, and 2299.
STBLEORB, used in chunk 844.
SXTMARK1, used in chunk 402.
SXTMARKE, used in chunk 382.
T4RUP, used in chunks 251 and 252.
XANG, used in chunk 907.

61 ⟨*Page CM0029* 61⟩≡ (56b 2816)

```
INTVEL          EQUALS
S52/2           EQUALS
CSIPROG5        EQUALS
INTINIT1        EQUALS
                BNKSUM  11

                BANK    12
CONICS          EQUALS
CSIPROG2        EQUALS
CSI/CDH2        EQUALS
MODCHG2         EQUALS
                BNKSUM  12

                BANK    13
P76LOC          EQUALS
LATLONG         EQUALS
INTINIT         EQUALS
SR52/1          EQUALS
ORBITAL2        EQUALS
CDHTAGS         EQUALS
E/PROG1         EQUALS
MODCHG3         EQUALS
                BNKSUM  13

# MODULE 3 CONTAINS BANKS 14 THROUGH 21

                BANK    14
STARTAB         EQUALS
RT53            EQUALS
P50S1           EQUALS
MEASINC2        EQUALS
CSI/CDH3        EQUALS
                BNKSUM  14

                BANK    15
P50S            EQUALS
ETRYDAP         EQUALS
S52/3           EQUALS
                BNKSUM  15

                BANK    16
P40S1           EQUALS
```

Defines:
`CDHTAGS`, used in chunk 1063.
`CONICS`, used in chunks 159, 181, 188, 240, 241, 1301, 1726, 1743, 1746, and 1852.

CSI/CDH2, used in chunk 1063.
CSI/CDH3, used in chunks 1063 and 2759.
CSIPROG2, used in chunk 1063.
CSIPROG5, used in chunk 1063.
E/PROG1, used in chunk 692.
ETRYDAP, used in chunks 1481, 1484, and 1489.
INTINIT, used in chunks 359, 1780, 1794, 1806, and 2051.
INTINIT1, used in chunk 1794.
INTVEL, used in chunk 786.
LATLONG, used in chunk 1675.
MEASINC2, used in chunk 1707.
MODCHG2, used in chunk 2027.
MODCHG3, used in chunk 2027.
ORBITAL2, used in chunks 1814 and 2051.
P40S1, used in chunks 1094, 2043, 2049, and 2295.
P50S, used in chunks 1147, 2128, and 2766.
P50S1, used in chunks 1147 and 2050.
P76LOC, used in chunk 820.
RT53, used in chunks 1037 and 1147.
S52/2, used in chunk 1147.
S52/3, never used.
SR52/1, used in chunk 1147.
STARTAB, used in chunks 1868 and 2052.

63 ⟨*Page CM0030* 63⟩≡ (56b 2816)

```
DAPROLL         EQUALS
P50S2           EQUALS
P23S1           EQUALS
RTE2            EQUALS
                BNKSUM  16

                BANK    17
DAPS4           EQUALS
DAPS5           EQUALS
DAPS7           EQUALS
P50S3           EQUALS
                BNKSUM  17

                BANK    20
DAPS6           EQUALS
DAPS1           EQUALS
DAPS2           EQUALS
MANUSTUF        EQUALS
R36CM           EQUALS
VAC5LOC         EQUALS
                BNKSUM  20

                BANK    21
DAPS3           EQUALS
MYSUBS          EQUALS
KALCMON3        EQUALS
                BNKSUM  21

# MODULE 4 CONTAINS BANKS 22 THROUGH 27

                BANK    22
RTBCODES        EQUALS
RTBCODE1        EQUALS
DAPS8           EQUALS
APOPERI         EQUALS
P40S5           EQUALS
KALCMON2        EQUALS
KALCMON1        EQUALS
CSIPROG3        EQUALS
                BNKSUM  22
```

Defines:
`APOPERI`, used in chunk 798.
`CSIPROG3`, used in chunk 1063.
`DAPROLL`, used in chunks 1356, 1367, and 1396.
`DAPS1`, used in chunks 1485, 2504, 2519, 2572, and 2574.
`DAPS2`, used in chunks 1373, 1390, 2496, 2542, and 2561.

DAPS3, used in chunks 1094, 1412, 1434, 2047, 2048, 2499b, 2510, 2590, and 2607.
DAPS4, used in chunks 1453, 2574, and 2625.
DAPS5, used in chunk 1477.
DAPS6, used in chunk 1094.
DAPS7, used in chunks 1094 and 1347.
DAPS8, used in chunk 1451.
KALCMON1, used in chunks 660, 674, 682, 684, 691a, 2167, and 2177.
KALCMON2, used in chunks 670 and 2175.
KALCMON3, used in chunk 690.
MANUSTUF, used in chunks 686 and 690.
MYSUBS, used in chunks 24, 1410, 2742, 2747, 2833, and 2837.
P23S1, used in chunk 1037.
P40S5, used in chunk 1094.
P50S2, used in chunk 1147.
P50S3, used in chunks 1147 and 2766.
R36CM, used in chunk 802.
RTBCODE1, never used.
RTBCODES, used in chunks 2027 and 2035.
RTE2, used in chunk 1301.
VAC5LOC, used in chunk 349.

65 ⟨*Page CM0031* 65⟩≡ (56b 2816)

```
                BANK    23
P20S2           EQUALS
INFLIGHT        EQUALS
COMGEOM1        EQUALS
POWFLITE        EQUALS
POWFLIT1        EQUALS
RENDGUID        EQUALS
POWFLIT2        EQUALS
R30LOC          EQUALS
P11FOUR         EQUALS
CSIPROG4        EQUALS
                BNKSUM  23

                BANK    24
LOADDAP         EQUALS
P40S            EQUALS
CSIPROG7        EQUALS
                BNKSUM  24

                BANK    25
REENTRY         EQUALS
CDHTAG1         EQUALS
                BNKSUM  25

                BANK    26
INTPRET1        EQUALS
REENTRY1        EQUALS
P60S            EQUALS
P60S1           EQUALS
P60S2           EQUALS
P60S3           EQUALS
PLANTIN         EQUALS                  # LUNAR ROT
EPHEM           EQUALS
P05P06          EQUALS
26P50S          EQUALS
                BNKSUM  26

                BANK    27
TOF-FF          EQUALS
TOF-FF1         EQUALS
MANUVER         EQUALS
MANUVER1        EQUALS
```

Defines:
`26P50S`, used in chunk 1147.
`CDHTAG1`, never used.

COMGEOM1, used in chunk 481.
CSIPROG4, used in chunk 1063.
CSIPROG7, used in chunk 1063.
EPHEM, used in chunks 175, 1195, and 2056.
INFLIGHT, used in chunks 24, 710, 1835, 2138, 2139, 2141, 2143, 2833, and 2837.
INTPRET1, used in chunks 1645b and 2476.
LOADDAP, never used.
MANUVER, used in chunks 647 and 658a.
MANUVER1, used in chunk 657.
P05P06, used in chunk 1941.
P11FOUR, used in chunk 890.
P20S2, used in chunks 936 and 1009.
P40S, used in chunks 370, 1094, 2043, 2045, 2260, 2281, and 2294.
P60S, used in chunk 1200.
P60S1, used in chunk 1200.
P60S2, used in chunk 1200.
P60S3, used in chunk 1200.
PLANTIN, used in chunk 1684.
POWFLIT1, used in chunk 1844.
POWFLIT2, used in chunk 487.
POWFLITE, used in chunk 1844.
R30LOC, used in chunks 827 and 2049.
REENTRY, used in chunks 22, 33, 54, 145, 181, 223, 226, 231, 241, 458, 1200, 1256, 1301, 2833, and 2837.
REENTRY1, used in chunk 1256.
RENDGUID, used in chunk 794.
TOF-FF, used in chunk 1852.
TOF-FF1, used in chunks 1852 and 2051.

67 ⟨*Page CM0032* 67⟩≡ (56b 2816)

```
VECPT           EQUALS
UPDATE1         EQUALS
UPDATE2         EQUALS
R22S1           EQUALS
P60S5           EQUALS
P40S2           EQUALS
                BNKSUM  27

# MODULE 5 CONTAINS BANKS 30 THROUGH 35

                BANK    30
IMUSUPER        EQUALS
LOWSUPER        EQUALS
FCSTART         EQUALS                  # STANDARD LOCATION FOR THIS. (FOR EXTV8)
LOPC            EQUALS
P20S1           EQUALS
P20S6           EQUALS
P40S3           EQUALS
R35A            EQUALS
                BNKSUM  30

                BANK    31
R35             EQUALS
RT23            EQUALS
P30S1A          EQUALS
R34             EQUALS
CDHTAG2         EQUALS
CSIPROG9        EQUALS
R31             EQUALS
P22S            EQUALS
RTE3            EQUALS
                BNKSUM  31

                BANK    32
MSGSCAN1        EQUALS
RTE             EQUALS
DELRSPL1        EQUALS
IMUCAL3         EQUALS
                BNKSUM  32

                BANK    33
TESTLEAD        EQUALS
```

Defines:
`CDHTAG2`, used in chunk 1063.
`CSIPROG9`, used in chunk 1063.

DELRSPL1, used in chunk 1054.
FCSTART, never used.
IMUCAL3, used in chunk 706.
IMUSUPER, used in chunk 419.
LOPC, never used.
LOWSUPER, used in chunks 71, 430, 438, 479, 630, 645, 698, 747, 808, 890, 1042a, 1094, 1147, 1344, 1889, 2015, 2119, 2143, and 2213.
MSGSCAN1, never used.
P20S1, used in chunks 919 and 921.
P20S6, used in chunks 977 and 1001.
P22S, used in chunk 999.
P30S1A, used in chunk 1049.
P40S2, used in chunks 1094 and 2293.
P40S3, used in chunks 1094 and 2279.
P60S5, used in chunk 1200.
R22S1, used in chunk 953.
R31, used in chunks 22, 28, 131, 177, 407, 430, 431, 810, 812, 2742, 2785, 2816, 2833, and 2837.
R34, used in chunks 28, 131, 431, 810, 812, 818, and 2091.
R35, used in chunk 28.
R35A, never used.
RT23, used in chunk 1015.
RTE, used in chunks 1245, 1301, and 1412.
RTE3, used in chunk 1301.
TESTLEAD, used in chunk 694.
UPDATE1, never used.
UPDATE2, used in chunks 1810 and 2015.
VECPT, used in chunks 651 and 653.

69 ⟨*Page CM0033* 69⟩≡ (56b 2816)

```
IMUCAL          EQUALS
                BNKSUM  33

                BANK    34
P11ONE          EQUALS
P20S3           EQUALS
P20S4           EQUALS
RTECON          EQUALS
                BNKSUM  34

                BANK    35
RTECON1         EQUALS
CSI/CDH         EQUALS
P30S1           EQUALS
P30S            EQUALS
P17S1           EQUALS
MEASINC3        EQUALS
INTINIT2        EQUALS
                BNKSUM  35

# MODULE 6 CONTAINS BANKS 36 THROUGH 43

                BANK    36
MEASINC         EQUALS
MEASINC1        EQUALS
P17S            EQUALS
RTE1            EQUALS
S3435LOC        EQUALS
                BNKSUM  36

                BANK    37
P20S            EQUALS
BODYATT         EQUALS
RENDEZ          EQUALS
SERVICES        EQUALS
P11TWO          EQUALS
CDHTAG3         EQUALS
                BNKSUM  37

                BANK    40
PINSUPER        EQUALS
```

Defines:
BODYATT, used in chunk 1291.
CDHTAG3, used in chunk 1063.
CSI/CDH, used in chunks 756, 771, 783, 1063, 2223, and 2759.

IMUCAL, used in chunks 696, 706, 712, 735, 739, and 741.
INTINIT2, used in chunk 1804.
MEASINC, used in chunk 1693.
MEASINC1, used in chunk 1699.
MEASINC3, used in chunk 1707.
P11ONE, used in chunks 862 and 880.
P11TWO, used in chunk 878.
P17S, used in chunks 895 and 2822.
P17S1, used in chunks 893, 909, and 2822.
P20S, used in chunks 747, 915, 921, 927, 1638, and 2752.
P20S3, used in chunk 941.
P20S4, used in chunks 965 and 1013.
P30S, used in chunks 238, 239, 1054, and 2219.
P30S1, used in chunks 1043 and 2219.
PINSUPER, used in chunks 416, 424, 437, 446, 890, and 1094.
RENDEZ, used in chunk 930.
RTE1, used in chunk 1301.
RTECON, never used.
RTECON1, used in chunk 1301.
S3435LOC, used in chunk 770b.
SERVICES, used in chunks 1227, 2044, 2046, 2049, and 2382.

71 ⟨*Page CM0034* 71⟩≡ (56b 2816)

```
SELFSUPR        EQUALS
PINBALL1        EQUALS
R36CM1          EQUALS
                BNKSUM  40

                BANK    41
PINBALL2        EQUALS
R36LM           EQUALS
                BNKSUM  41

                BANK    42
SBAND           EQUALS
PINBALL3        EQUALS
EXTVBS          EQUALS
R36LM1          EQUALS
                BNKSUM  42

                BANK    43
SELFCHEC        EQUALS
EXTVERBS        EQUALS
                BNKSUM  43

HI6ZEROS        EQUALS  ZEROVECS                # ZERO VECTOR ALWAYS IN HIGH MEMORY
LO6ZEROS        EQUALS  ZEROVEC                 # ZERO VECTOR ALWAYS IN LOW MEMORY
HIDPHALF        EQUALS  UNITX
LODPHALF        EQUALS  XUNIT
HIDP1/4         EQUALS  DP1/4TH
LODP1/4         EQUALS  D1/4                    # 2DEC .25
HIUNITX         EQUALS  UNITX
HIUNITY         EQUALS  UNITY
HIUNITZ         EQUALS  UNITZ
LOUNITX         EQUALS  XUNIT                   # 2DEC .5
LOUNITY         EQUALS  YUNIT                   # 2DEC 0
LOUNITZ         EQUALS  ZUNIT                   # 2DEC 0
3/4LOWDP        EQUALS  3/4                     # 2DEC 3.0 B-2

                SBANK=  LOWSUPER

# ROPE-SPECIFIC ASSIGNS OBVIATING NEED TO CHECK COMPUTER FLAG IN DETERMINING(?) INTEGRATION ARE

OTHPREC         EQUALS  LEMPREC
ATOPOTH         EQUALS  ATOPLEM
ATOPTHIS        EQUALS  ATOPCSM
MOONTHIS        EQUALS  CMOONFLG
```

Defines:

3/4LOWDP, never used.
ATOPOTH, used in chunk 823.
ATOPTHIS, never used.
EXTVBS, used in chunks 426 and 1094.
EXTVERBS, used in chunks 405, 428, 890, and 2015.
HI6ZEROS, used in chunks 840a, 866, 872, 901, 1001, 1003, 1005, 1007, 1054, 1056, 1094, 1200, 1256, 1344, 1684, 1835, 1852, 2213, 2299, 2353, 2365, 2367, and 2369.
HIDP1/4, used in chunks 1200, 1256, 1344, and 1852.
HIDPHALF, used in chunks 491, 657, 732a, 921, 983, 997, 1056, 1200, 1256, 1684, 1837, and 2213.
HIUNITX, used in chunks 482, 657, 1344, and 2213.
HIUNITY, used in chunks 482, 1344, and 2213.
HIUNITZ, used in chunks 482, 1344, and 2213.
LO6ZEROS, used in chunks 1094, 1742, 2125, 2126, and 2143.
LODP1/4, used in chunk 1680.
LODPHALF, used in chunks 1094, 1762, and 2143.
LOUNITX, never used.
LOUNITY, never used.
LOUNITZ, never used.
MOONTHIS, used in chunks 442, 444, 816, 949, 1705, and 2718.
OTHPREC, used in chunks 428, 745, 806, 820, 825, and 829.
PINBALL1, used in chunk 519.
PINBALL2, used in chunk 535.
PINBALL3, used in chunks 452 and 561.
R36CM1, used in chunk 806.
R36LM, used in chunks 804 and 808.
R36LM1, used in chunk 804.
SBAND, used in chunks 1344, 2051, and 2213.
SELFCHEC, used in chunks 1874 and 2480.
SELFSUPR, never used.

Uses CMOONFLG 125, COMPUTER 115, and LOWSUPER 67.

73 ⟨*Page CM0035* 73⟩≡ (56b 2816)

```
MOONOTH         EQUALS  LMOONFLG
MOVATHIS        EQUALS  MOVEACSM
STATEST         EQUALS  V83CALL                 # * TEMPORARY
THISPREC        EQUALS  CSMPREC
THISAXIS        =       UNITX
ERASID          EQUALS  LOW10                   # DOWNLINK ERASABLE DUMP ID
DELAYNUM        EQUALS  THREE

#*****************************************************************************************

# THE FOLLOWING ECADRS ARE DEFINED TO FACILITATE EBANK SWITCHING.  THEY ALSO MAKE IT EASIER FOR
# ERASABLE CONTROL TO REARRANGE ERASABLE MEMORY WITHOUT DISRUPTING THE PROGRAMS WHICH SET EBANK
# PRIOR TO ROPE RELEASE FIXED MEMORY CAN BE SAVED BY SETTING EACH EBXXXX =EBANKX (X=4,5,6,7).
# WILL BE THE BANK WHERE THE ERASABLES REFERENCED IN EBXXXX WILL BE STORED.

                BANK    7
                EBANK=  MARKDOWN
EBMARKDO        ECADR   MARKDOWN
                EBANK=  MRKBUF1
EBMRKBUF        ECADR   MRKBUF1

                BANK    24
                EBANK=  DVCNTR
EBDVCNTR        ECADR   DVCNTR
                EBANK=  P40TMP
EBP40TMP        ECADR   P40TMP

                BANK    34
                EBANK=  DVCNTR
EBDVCNT         ECADR   DVCNTR
                EBANK=  QPLACES
EBQPLACE        ECADR   QPLACES

                BANK    37
                EBANK=  RN1
EBRN1           ECADR   RN1

#*****************************************************************************************
```

Defines:
DELAYNUM, used in chunk 2001.
EBDVCNT, used in chunk 864.
EBDVCNTR, never used.
EBMARKDO, never used.
EBMRKBUF, never used.
EBP40TMP, never used.
EBQPLACE, used in chunk 864.

EBRN1, never used.
ERASID, used in chunks 1536, 1538, 2472, and 2474.
MOONOTH, used in chunks 442 and 444.
MOVATHIS, used in chunk 1804.
STATEST, never used.
THISAXIS, used in chunk 812.
THISPREC, used in chunks 428, 745, 806, 825, 829, 831, 1049, and 1094.
Uses DVCNTR 224, EBANK 80, IT 185, LMOONFLG 125, MARKDOWN 239, P4OTMP 238, QPLACES 191, and RN1 159.

74a ⟨*Page CM0036* 74a⟩≡ (56b 2816)

```
# *** END OF MAIN PROGRAM ***
```

3.2 comerase routine

74b ⟨*comerase routine* 74b⟩≡ (19a)

⟨*erasable assignments* 75⟩

3.2.1 erasable assignments

75 ⟨*erasable assignments* 75⟩≡ (74b)

⟨*Page CM0037* 78⟩
⟨*Page CM0038* 79⟩
⟨*Page CM0039* 80⟩
⟨*Page CM0040* 85⟩
⟨*Page CM0041* 87⟩
⟨*Page CM0042* 89⟩
⟨*Page CM0043* 91⟩
⟨*Page CM0044* 93⟩
⟨*Page CM0045* 94⟩
⟨*Page CM0046* 95⟩
⟨*Page CM0047* 97⟩
⟨*Page CM0048* 99⟩
⟨*Page CM0049* 101⟩
⟨*Page CM0050* 103⟩
⟨*Page CM0051* 105⟩
⟨*Page CM0052* 107⟩
⟨*Page CM0053* 109⟩
⟨*Page CM0054* 111⟩
⟨*Page CM0055* 113⟩
⟨*Page CM0056* 115⟩
⟨*Page CM0057* 117⟩
⟨*Page CM0058* 119⟩
⟨*Page CM0059* 121⟩
⟨*Page CM0060* 123⟩
⟨*Page CM0061* 125⟩
⟨*Page CM0062* 127⟩
⟨*Page CM0063* 129⟩
⟨*Page CM0064* 131⟩
⟨*Page CM0065* 133⟩
⟨*Page CM0066* 135⟩
⟨*Page CM0067* 137⟩
⟨*Page CM0068* 138⟩
⟨*Page CM0069* 140⟩
⟨*Page CM0070* 142⟩
⟨*Page CM0071* 144⟩
⟨*Page CM0072* 145⟩
⟨*Page CM0073* 148⟩
⟨*Page CM0074* 150⟩
⟨*Page CM0075* 152⟩
⟨*Page CM0076* 154⟩
⟨*Page CM0077* 156⟩
⟨*Page CM0078* 157⟩
⟨*Page CM0079* 159⟩

⟨*Page CM0080* 161⟩
⟨*Page CM0081* 163⟩
⟨*Page CM0082* 165⟩
⟨*Page CM0083* 166⟩
⟨*Page CM0084* 167⟩
⟨*Page CM0085* 169⟩
⟨*Page CM0086* 172⟩
⟨*Page CM0087* 174⟩
⟨*Page CM0088* 175⟩
⟨*Page CM0089* 177⟩
⟨*Page CM0090* 179⟩
⟨*Page CM0091* 181⟩
⟨*Page CM0092* 182⟩
⟨*Page CM0093* 183⟩
⟨*Page CM0094* 185⟩
⟨*Page CM0095* 186⟩
⟨*Page CM0096* 188⟩
⟨*Page CM0097* 190⟩
⟨*Page CM0098* 191⟩
⟨*Page CM0099* 194⟩
⟨*Page CM0100* 196⟩
⟨*Page CM0101* 197⟩
⟨*Page CM0102* 198⟩
⟨*Page CM0103* 200⟩
⟨*Page CM0104* 202⟩
⟨*Page CM0105* 204⟩
⟨*Page CM0106* 206⟩
⟨*Page CM0107* 208⟩
⟨*Page CM0108* 209⟩
⟨*Page CM0109* 211⟩
⟨*Page CM0110* 213⟩
⟨*Page CM0111* 214⟩
⟨*Page CM0112* 216⟩
⟨*Page CM0113* 218⟩
⟨*Page CM0114* 219⟩
⟨*Page CM0115* 221⟩
⟨*Page CM0116* 223⟩
⟨*Page CM0117* 224⟩
⟨*Page CM0118* 226⟩
⟨*Page CM0119* 229⟩
⟨*Page CM0120* 231⟩
⟨*Page CM0121* 232⟩
⟨*Page CM0122* 234⟩
⟨*Page CM0123* 236⟩
⟨*Page CM0124* 238⟩
⟨*Page CM0125* 239⟩

⟨*Page CM0126* 240⟩
⟨*Page CM0127* 241⟩
⟨*Page CM0128* 243⟩
⟨*Page CM0129* 244⟩
⟨*Page CM0130* 245a⟩

78 ⟨*Page CM0037* 78⟩≡ (75 2684)

```
# CONVENTIONS AND NOTATIONS UTILIZED FOR ERASABLE ASSIGNMENTS.

#       EQUALS  IS USED IN TWO WAYS.  IT IS OFTEN USED TO CHAIN A GROUP
#               OF ASSIGNMENTS SO THAT THE GROUP MAY BE MOVED WITH THE
#               CHANGING OF ONLY ONE CARD.  EXAMPLE:
#
#                       X       EQUALS  START
#                       Y       EQUALS  X       +SIZE.X
#                       Z       EQUALS  Y       +SIZE.Y
#
#               (X, Y, AND Z ARE CONSECUTIVE AND BEGIN AT START.
#               SIZE.X AND SIZE.Y ARE THE RESPECTIVE SIZES OF X AND Y.
#               USUALLY NUMERIC, IE. 1, 2, 6, 18D, ETC.)

#       EQUALS  OFTEN IMPLIES THE SHARING OF REGISTERS (DIFFERENT NAMES
#               AND DIFFERENT DATA).  EXAMPLE:
#
#                       X       EQUALS  Y

#       =       MEANS THAT MULTIPLE NAMES HAVE BEEN GIVEN TO THE SAME DATA.
#               (THIS IS LOGICAL EQUIVALENCE, NOT SHARING.)  EXAMPLE:
#
#                       X       =       Y

#       THE SIE AND UTILIZATION OF AN ERASABLE ARE OFTEN INCLUDED IN
#       THE COMMENTS IN THE FOLLOWING FORM:  M(SIZE)N.
#
#               M       REFERS TO THE MOBILITY OF THE ASSIGNMENT.
#                       B       MEANS THAT THE SYMBOL IS REFERENCED BY BASIC
#                               INSTRUCTIONS AND THUS IS E-BANK SENSITIVE.
#                       I       MEANS THAT THE SYMBOL IS REFERENCED ONLY BY
#                               INTERPRETIVE INSTRUCTIONS, AND IS THUS E-BANK
#                               INSENSITIVE AND MAY APPEAR IN ANY E-BANK.
#
#               SIZE    IS THE NUMBER OF REGISTERS INCLUDED BY THE SYMBOL.
#
#               N       INDICATES THE NATURE OF PERMANENCE OF THE CONTENTS.
#                       PL      MEANS THAT THE CONTENTS ARE PAD LOADED.
#                       DSP     MEANS THAT THE REGISTER IS USED FOR A DISPLAY.
#                       PRM     MEANS THAT THE REGISTER IS PERMANENT.  IE., IT
#                               IS USED DURING THE ENTIRE MISSION FOR ONE
#                               PURPOSE AND CANNOT BE SHARED.
#                       TMP     MEANS THAT THE REGISTER IS USED TEMPORARILY OR
#                               IS A SCRATCH REGISTER FOR THE ROUTINE TO WHICH
#                               IT IS ASSIGNED.  THAT IS, IT NEED NOT BE SET
```

```
#                                   PRIOR TO INVOCATION OF THE ROUTINE NOR DOES IT
#                                   CONTAIN USEFUL OUTPUT TO ANOTHER ROUTINE.  THUS
```

Uses A 80, CARD 206, I 206, IT 185, N 206, and Z 80.

79 ⟨*Page CM0038* 79⟩≡ (75 2684)

```
#                                   IT MAY BE SHARED WITH ANY OTHER ROUTINE WHICH
#                                   IS NOT ACTIVE IN PARALLEL
#                           IN      MEANS INPUT TO THE ROUTINE AND IT IS PROBABLY
#                                   TEMPORARY FOR A HIGHER-LEVEL ROUTINE/PROGRAM.
#                           OUT     MEANS OUTPUT FROM THE ROUTINE, PROBABLY
#                                   TEMPORARY FOR A HIGHER-LEVEL ROUTINE/PROGRAM.
```

Uses A 80 and IT 185.

80 ⟨*Page CM0039* 80⟩≡ (75 2684)

```
# SPECIAL REGISTERS.

A               EQUALS  0
L               EQUALS  1               # L AND Q ARE BOTH CHANNELS AND REGISTERS
Q               EQUALS  2
EBANK           EQUALS  3
FBANK           EQUALS  4
Z               EQUALS  5               # ADJACENT TO FBANK AND BBANK FOR DXCH Z
BBANK           EQUALS  6               # (DTCB) AND DXCH FBANK (DTCF).
                                        # REGISTER 7 IS A ZERO-SOURCE, USED BY ZL.

ARUPT           EQUALS  10              # INTERRUPT STORAGE
LRUPT           EQUALS  11
QRUPT           EQUALS  12
SAMPTIME        EQUALS  13              # SAMPLED TIME 1 & 2.
ZRUPT           EQUALS  15              # (13 AND 14 ARE SPARES.)
BANKRUPT        EQUALS  16              # USUALLY HOLDS FBANK OR BBANK.
BRUPT           EQUALS  17              # RESUME ADDRESS AS WELL.

CYR             EQUALS  20
SR              EQUALS  21
CYL             EQUALS  22
EDOP            EQUALS  23              # EDITS INTERPRETIVE OPERATION CODE PAIRS.

TIME2           EQUALS  24
TIME1           EQUALS  25
TIME3           EQUALS  26
TIME4           EQUALS  27
TIME5           EQUALS  30
TIME6           EQUALS  31
CDUX            EQUALS  32
CDUY            EQUALS  33
CDUZ            EQUALS  34
CDUT            EQUALS  35              # OPTICS TRUNNION CDU (WAS OPTY).
OPTY            =       CDUT
CDUS            EQUALS  36              # OPTICS SHAFT CDU (WAS OPTX).
OPTX            =       CDUS
PIPAX           EQUALS  37
PIPAY           EQUALS  40
PIPAZ           EQUALS  41
BMAGX           EQUALS  42
BMAGY           EQUALS  43
BMAGZ           EQUALS  44
INLINK          EQUALS  45
```

```
RNRAD           EQUALS  46
GYROCTR         EQUALS  47
GYROCMD         EQUALS  47
CDUXCMD         EQUALS  50
CDUYCMD         EQUALS  51
```

Defines:

`A`, used in chunks 38, 40, 42, 46, 48, 50, 55, 78, 79, 95, 117, 148, 152, 165, 183, 186, 209, 224, 239, 243, 244, 251, 254, 257–59, 261, 263–70, 272, 274, 276–78, 281, 282, 287, 288, 290, 292, 294, 307, 309, 311, 313, 315, 317, 319, 321, 323, 331, 333, 335, 337, 339, 341, 343, 345, 347, 362, 378, 380, 382, 384, 386, 388–90, 394, 396–98, 400, 403, 405, 407, 410, 414, 416, 421, 423, 425, 426, 430, 446, 448, 451, 452, 454, 481–83, 487, 497, 498, 501, 506, 508, 510, 512, 515, 517, 519, 521, 523, 525, 529, 531, 535, 539, 541, 545, 547, 549, 551, 553, 555, 557, 559, 561, 563, 567, 573, 575, 577, 579, 581, 583, 585, 587, 590, 591, 596, 597, 599, 601, 603, 605, 607, 611, 613, 615, 617, 619, 623, 625, 627, 631, 633, 635, 637, 638, 644, 645, 647, 649, 651, 655, 657, 662, 668, 674, 676, 678, 681a, 682, 688, 692–94, 696, 698, 710, 716, 717, 724, 725, 731, 732a, 741, 747, 752, 753, 760, 765, 784, 794, 797, 802, 804, 806, 808, 814, 820, 829, 833, 835, 842, 850, 858, 870, 874, 876, 882, 888, 893, 899, 921, 925, 927, 936, 941, 963, 967, 969, 997, 1031, 1033, 1035, 1045, 1063, 1094, 1147, 1195, 1200, 1227, 1256, 1291, 1299, 1301, 1347, 1356, 1362, 1367, 1373, 1390, 1396, 1410, 1412, 1434, 1441, 1445, 1447, 1453, 1455–58, 1460, 1461, 1463, 1465, 1466, 1470b, 1471, 1473–75, 1481, 1483, 1484, 1487, 1489, 1491, 1495, 1497, 1498, 1500, 1502, 1504, 1506, 1508, 1513, 1514, 1516, 1518, 1521, 1522, 1524, 1526, 1528, 1530, 1532, 1534, 1536, 1538–42, 1547–50, 1552–54, 1556–58, 1560, 1561, 1563, 1565, 1566, 1570, 1572, 1574–78, 1584, 1585, 1588–90, 1592–97, 1600–1604, 1608–10, 1612, 1613, 1616, 1618, 1620, 1621, 1623, 1625, 1627, 1629, 1632, 1633, 1635–37, 1647, 1649, 1651–55, 1657, 1659–61, 1663, 1679, 1681, 1684, 1693, 1697, 1698, 1712–17, 1719, 1720, 1722–25, 1772, 1774, 1778, 1788, 1792, 1794, 1796, 1798, 1800, 1802, 1804, 1806, 1810, 1812, 1814, 1838, 1841, 1844, 1852, 1872, 1874, 1878, 1880, 1882, 1886, 1891, 1893–96, 1898, 1900, 1902, 1903, 1905, 1907, 1909, 1911, 1915, 1918, 1921, 1923, 1925–29, 1931, 1932, 1934–37, 1939, 1941, 1943, 1946, 1947, 1949–53, 1955–59, 1961–63, 1965, 1967, 1969, 1971, 1973, 1975, 1977, 1983, 1985, 1987, 1989, 1991, 1993, 1995, 1997, 2001, 2007, 2009, 2011, 2015, 2027, 2035, 2043, 2044, 2059, 2061, 2062, 2064a, 2075, 2082, 2098, 2106, 2108, 2112, 2114, 2116, 2118, 2121, 2122, 2128, 2132, 2134, 2136, 2138–40, 2142, 2143, 2152, 2154, 2156, 2158, 2160, 2162, 2164, 2165, 2175, 2181, 2183, 2185, 2189, 2191, 2202b, 2204, 2217, 2219, 2223, 2254, 2260, 2267, 2269, 2277, 2283, 2285, 2287, 2289, 2291, 2293, 2295, 2297, 2299, 2306, 2311, 2343, 2353, 2367, 2369, 2371, 2375, 2377, 2382, 2420, 2422, 2424, 2428, 2430, 2438, 2440–43, 2445, 2448, 2453–58, 2461, 2463, 2465, 2467, 2469, 2471, 2472, 2474, 2475a, 2478, 2480, 2484, 2486, 2488, 2492, 2496, 2499b, 2500, 2502–5, 2510, 2512, 2514, 2517, 2519, 2542, 2561, 2574, 2588, 2590, 2594, 2596, 2600, 2601, 2603, 2606, 2607, 2611, 2613, 2615, 2623, 2625, 2790, and 2828.

`ARUPT`, used in chunks 247, 249, 1663, 2496, 2519, and 2542.

`BANKRUPT`, used in chunks 251, 388, 890, 891, 959, 1094, 1347, 1367, 1373, 1396, 1412, 1453, 1477, 1493, 1528, 1663, 1945, 1946, 2134, 2311, 2465, 2496, 2505, and 2519.

`BBANK`, used in chunks 145, 247, 249, 617, 625, 692, 953, 1542, 1546, 1547, 1565, 1567, 1649–51, 1654, 1656, 1657, 1661, 1663, 1788, 1876, 1891, 1898, 1900, 1938, 1977, 2001, 2007, 2295, 2311, and 2482.

`BMAGX`, never used.

`BMAGY`, never used.

`BMAGZ`, never used.

`BRUPT`, used in chunks 2011, 2343, 2519, and 2542.

`CDUS`, used in chunks 44, 52, 264, 285, 286, 288, 290, 297, 377, 388, 390, 412, 476, 818, 961, 963, 1147, 1227, 1373, 1412, 1918, 2027, 2128, 2132, 2134, 2136, 2382, 2504, 2514, and 2519.

`CDUT`, used in chunks 44, 286, 290, 292, 295, 388, 390, 476, 818, 1147, 1487, and 1488.

CDUX, used in chunks 38, 297, 388, 390, 403, 416, 454, 670, 691a, 702, 722, 866, 874, 876, 880, 882, 930, 932, 963, 965, 967, 1094, 1147, 1227, 1293, 1347, 1356, 1373, 1396, 1412, 1436, 1438, 1451, 1481, 1844, 1917, 1919–21, 2134, 2139, 2152, 2177, 2196, 2209, 2382, 2443, 2454, 2502, 2507, 2510, 2513, and 2519.
CDUXCMD, used in chunks 272, 888, 890, 1412, 1921, 2514, 2515, and 2517.
CDUY, used in chunks 297, 388, 390, 691a, 866, 874, 880, 930, 932, 1094, 1147, 1293, 1373, 1412, 1436, 1481, 1844, 1917, 1919, 2128, 2134, 2139, 2382, 2443, 2454, 2502, 2510, 2512, 2513, 2519, and 2542.
CDUYCMD, used in chunks 272, 888, 890, 1412, 2514, and 2515.
CDUZ, used in chunks 267, 295, 307, 388, 390, 416, 670, 691a, 866, 874, 876, 880, 882, 930, 932, 1094, 1147, 1293, 1373, 1412, 1436, 1438, 1451, 1481, 1844, 1917, 1919, 2134, 2139, 2177, 2382, 2443, 2454, 2502, 2507, 2510, 2512, 2519, and 2542.
CYL, used in chunks 523, 591, 601, 603, 631, 633, 1624, 1884, 1959, and 2490.
CYR, used in chunks 345, 603, 631, 1547–53, 1557, 1560, 1588, 1590, 1591, 1597, 1632–34, 1884, 1909, and 2490.
EBANK, used in chunks 73, 167, 169, 175, 183, 188, 190, 191, 197, 198, 221, 224, 226, 229, 232, 234, 239, 241, 244, 249, 254, 261, 263, 264, 268, 285, 294, 311, 317, 319, 321, 325, 329, 337, 345, 347, 349, 351, 355, 357, 359, 364, 366, 368, 370, 372, 374, 376, 377, 382, 384, 390, 392, 394, 396, 397, 400, 402, 405, 412, 419–21, 423–26, 430, 432–34, 436–38, 442, 444, 446, 448, 487, 491, 493, 497, 508, 537, 541, 553, 571, 577, 579, 593, 595, 617, 625, 627, 631, 640, 642, 647, 653, 658b, 660, 681a, 682, 684, 686, 688, 689, 692, 694, 696, 698, 700, 711, 712, 714, 716, 722, 747, 756, 762, 804, 810, 820, 827, 829, 833, 835, 844, 862, 864, 866, 868, 870, 872, 890, 891, 893, 911, 915, 917–19, 927, 929, 930, 934, 936, 953, 965, 977, 1013, 1015, 1037, 1039, 1043, 1062a, 1063, 1094, 1147, 1195, 1200, 1227, 1256, 1291, 1297, 1299–1301, 1344, 1347, 1356, 1362, 1367, 1373, 1390, 1396, 1410, 1412, 1434, 1450a, 1451, 1453, 1475, 1481, 1483, 1485, 1487–89, 1492, 1498, 1516, 1521, 1526, 1528, 1532, 1534, 1536, 1538, 1549, 1550, 1557, 1558, 1565, 1566, 1585, 1632, 1655, 1657, 1661, 1663, 1675, 1693, 1727, 1780, 1782, 1788, 1806, 1810, 1835, 1844, 1876, 1878, 1880, 1882, 1889, 1891, 1898, 1900, 1905, 1917, 1918, 1920, 1924, 1927, 1930, 1932, 1938, 1941, 1945, 1959, 1961, 1962, 1967, 1977, 1979, 1983, 1989, 1997, 1999, 2001, 2007, 2015, 2027, 2035, 2108, 2112, 2121, 2132, 2141, 2143, 2148, 2167, 2175, 2177, 2188a, 2189, 2191, 2193, 2202–4, 2209, 2211, 2213, 2217, 2219, 2223, 2256, 2260, 2262, 2265, 2267, 2271, 2273, 2275, 2277, 2279, 2285, 2289, 2291, 2294, 2295, 2299, 2306, 2311, 2343, 2353, 2359, 2375, 2377, 2382, 2420, 2430, 2442, 2452, 2463, 2465, 2469, 2471, 2472, 2474, 2482, 2484, 2486, 2488, 2495a, 2496, 2499b, 2500, 2502–5, 2509, 2510, 2514, 2518, 2519, 2542, 2561, 2572, 2574, 2588, 2590, 2600, 2607, 2625, and 2747.
EDOP, used in chunks 595, 619, 1542, 1546, 1547, 1884, and 2490.
FBANK, used in chunks 294, 623, 638, 692, 782, 1540–42, 1546, 1549, 1550, 1553, 1556, 1565, 1566, 1585, 1586, 1642, 1649, 1651, 1663, 1844, 1936, 2001, 2059, 2297, and 2600.
GYROCMD, used in chunks 272, 1923, 1932, and 1933.
GYROCTR, never used.
INLINK, used in chunks 329, 1946, and 1947.
L, used in chunks 30, 40, 42, 44, 48, 87, 198, 226, 229, 265, 282, 287, 288, 290, 292, 302, 321, 329, 331, 341, 345, 378, 380, 382, 384, 410, 418, 452, 493, 497, 498, 503, 529, 533, 535, 537, 539, 541, 543, 545, 549, 551, 555, 563, 575, 587, 590, 596, 601, 603, 612, 617, 621, 623, 627, 629, 637, 638, 688, 692, 693, 705, 708, 733, 747, 784, 794, 797, 802, 804, 808, 831, 833, 840a, 858, 872, 874, 876, 882, 929, 936, 937, 939, 957, 963, 977, 1025, 1049, 1052, 1054, 1094, 1147, 1200, 1227, 1247, 1248, 1250, 1252, 1256, 1297, 1299–1301, 1347, 1356, 1362, 1373, 1396, 1410, 1412, 1434, 1471, 1473, 1484, 1487, 1491, 1492, 1497, 1498, 1500, 1502, 1504, 1506, 1508, 1512, 1513, 1516, 1518, 1530, 1534, 1538–42, 1567, 1570, 1573, 1575, 1577, 1578a, 1584, 1589, 1595, 1602, 1603, 1610, 1612, 1615, 1623, 1625, 1635, 1649, 1650, 1654, 1659, 1661, 1663, 1675, 1677, 1679, 1681, 1682, 1684, 1693, 1699, 1717, 1720, 1723, 1726, 1776, 1778, 1780, 1782, 1784, 1790, 1792, 1800, 1802, 1842a, 1844, 1880, 1884, 1886, 1889, 1891, 1893, 1894, 1907, 1909, 1913, 1920, 1931, 1936, 1939, 1943, 1959, 1977, 1979, 1985, 1989, 2001, 2007, 2009, 2013, 2015, 2027, 2035, 2059, 2074–76, 2079–81, 2086, 2089, 2091, 2092, 2094, 2096, 2098,

2100, 2102, 2103, 2108, 2130, 2139, 2156, 2198, 2201, 2219, 2269, 2285, 2291, 2295, 2297, 2306, 2311, 2343, 2361, 2363, 2365, 2367, 2382, 2438, 2446, 2448, 2452, 2453, 2455, 2456, 2458, 2467, 2471, 2474, 2475a, 2486, 2490, 2492, 2494–96, 2499b, 2500, 2502, 2503a, 2510, 2514, 2517, 2519, 2542, 2561, 2572–74, 2588, 2594, 2596, 2600, 2601, 2607, 2613, 2615, 2621, 2623, and 2625.

`LRUPT`, never used.

`OPTX`, never used.

`OPTY`, used in chunk 163.

`PIPAX`, used in chunks 38, 297, 454, 493, 495, 496, 498, 499, 700, 704, 712, 716, 1227, 1926, 2027, 2193, 2197, 2198, 2203, 2204, 2311, 2382, and 2426.

`PIPAY`, used in chunks 297, 493, 495, 496, 498, 499, 712, 716, 1227, 1926, 2027, 2203, 2204, 2311, 2382, and 2426.

`PIPAZ`, used in chunks 297, 493, 495, 496, 498, 499, 712, 716, 1227, 1926, 2027, 2203, 2204, 2311, 2382, and 2428.

`Q`, used in chunks 40, 42, 48, 87, 167, 181, 214, 239, 253, 257, 278, 279, 282, 286, 287, 292, 315, 317, 325, 329, 380, 382, 388, 403, 407, 409, 423, 437, 452, 493, 497, 503, 525, 527, 529, 531, 533, 541, 543, 547, 549, 551, 555, 557, 559, 565, 567, 575, 577, 585, 587, 589, 590, 597, 599, 601, 603, 605, 609, 617, 621, 623, 625, 627, 631, 633, 635, 638, 639a, 649, 655, 686, 690–92, 705, 708, 714, 716, 732a, 747, 782, 794, 802, 886, 934, 1047, 1094, 1147, 1227, 1299, 1300a, 1347, 1362, 1373, 1390, 1410, 1412, 1479, 1484, 1489, 1492, 1497, 1498, 1510, 1512, 1521, 1526, 1528, 1532, 1538, 1540–43, 1559, 1567, 1570, 1572, 1573, 1575, 1577, 1578a, 1584, 1589, 1595, 1603, 1604b, 1608, 1609, 1614, 1620, 1621, 1623, 1632, 1633, 1635–37, 1647, 1649, 1651, 1660, 1663, 1788, 1802, 1812, 1814, 1876, 1878, 1886, 1891, 1896, 1898, 1900, 1902, 1917, 1923, 1925, 1930, 1934, 1939, 1945–47, 1959, 1963, 1967, 1979, 1989, 1995, 2001, 2007, 2011, 2013, 2015, 2027, 2035, 2059, 2108, 2134, 2139, 2198, 2201, 2217, 2283, 2285, 2295, 2297, 2306, 2311, 2343, 2382, 2422, 2455–58, 2463, 2465, 2469, 2474, 2482, 2484, 2492, 2496, 2500, 2502, 2509, 2512–14, 2517–19, 2542, 2561, 2572–74, 2594, 2598, 2600, 2601, 2621, 2625, 2749, 2833, and 2837.

`QRUPT`, used in chunks 251, 388, 890, 891, 959, 1094, 1347, 1367, 1373, 1412, 1453, 1477, 1493, 1528, 1663, 1945, 1946, 2134, 2311, 2465, 2496, 2505, and 2519.

`RNRAD`, used in chunk 959.

`SAMPTIME`, used in chunks 42, 388, 474, 635, 2112, and 2114.

`SR`, used in chunks 144, 152, 448, 533, 567, 575, 603, 682, 796, 905, 947, 991, 993, 995, 1029, 1031, 1035, 1063, 1094, 1195, 1256, 1301, 1491–93, 1504, 1506, 1508, 1510, 1521, 1588, 1590, 1591, 1594, 1596, 1602, 1623, 1624, 1684, 1738, 1744, 1752, 1754, 1756, 1814, 1838, 1844, 1852, 1884, 1889, 1911, 2223, 2299, 2343, 2353, 2363, 2457, 2490, 2495a, and 2574.

`TIME1`, used in chunks 249, 295, 298, 300, 302, 304, 377, 378, 380, 388, 390, 501, 688, 712, 714, 716, 860, 870, 876, 878, 930, 965, 1094, 1147, 1248, 1487, 1504, 1514, 1521, 1536, 1538, 1663, 1902, 1909, 1941, 1943, 1944a, 1973, 1993, 2015, 2027, 2035, 2114, 2154, 2269, 2285, 2306, 2382, 2420, 2426, 2472, and 2474.

`TIME2`, used in chunks 38, 294, 295, 298, 300, 302, 304, 377, 388, 390, 418, 456, 635, 686, 688, 862, 870, 876, 930, 932, 957, 965, 967, 1094, 1147, 1227, 1248, 1528, 1530, 1663, 1808, 1902, 1913, 1941, 1943, 1944a, 2015, 2027, 2035, 2114, 2134, 2154, 2273, 2275, 2283, 2285, 2287, 2311, 2343, 2382, 2465, and 2467.

`TIME3`, used in chunks 309, 325, 1514, and 1663.

`TIME4`, used in chunks 253, 255, 309, and 325.

`TIME5`, used in chunks 247, 309, 325, 890, 891, 1094, 1347, 1367, 1373, 1412, 1453, 1492, 2343, 2382, 2507, 2519, and 2574.

`TIME6`, used in chunks 1396, 1412, 1453, 1477, 1479, 2496, 2507, 2542, and 2561.

`Z`, used in chunks 78, 142, 302, 438, 452, 454, 482, 501, 514, 531, 537, 543, 553, 569, 571, 573, 579, 651, 655, 688, 710, 725, 775, 779, 780, 858, 874, 878, 880, 961, 963, 965, 1011, 1094, 1147, 1200, 1227, 1250, 1373, 1453, 1458, 1460, 1461, 1463, 1465, 1469, 1471, 1473, 1574, 1580–82, 1591, 1595, 1607, 1612, 1618, 1620, 1663, 1699, 1814, 1835, 1836, 1844, 1852, 1868, 1891, 1929, 2011, 2015, 2027, 2052–56, 2062, 2063, 2102, 2126, 2128, 2143, 2148, 2152, 2160, 2162, 2164, 2195, 2213, 2275, 2277, 2281, 2289, 2311, 2361,

2363, 2371, 2382, 2420, 2428, 2430, 2440, 2441, 2445, 2448, 2453, 2454, 2512, 2519, 2542, 2596, 2600, and 2606.

`ZRUPT`, used in chunks 2519 and 2542.

Uses `CODE` 140.

85 ⟨*Page CM0040* 85⟩≡ (75 2684)

```
CDUZCMD         EQUALS  52
CDUTCMD         EQUALS  53              # OPTICS TRUNNION COMMAND (WAS OPTYCMD)
OPTYCMD         =       CDUTCMD
TVCYAW          EQUALS  CDUTCMD         # SPS YAW COMMAND IN TVC MODE
CDUSCMD         EQUALS  54              # OPTICS SHAFT COMMAND (WAS OPTXCMD).
TVCPITCH        EQUALS  CDUSCMD         # SPS PITCH COMMAND IN TVC MODE
OPTXCMD         =       CDUSCMD
EMSD            EQUALS  55
THRUST          EQUALS  55
LEMONM          EQUALS  56
LOCALARM        EQUALS  57
BANKALRM        EQUALS  60

# INTERPRETIVE REGISTERS ADDRESSED RELATIVE TO VAC AREA.

LVSQUARE        EQUALS  34D             # SQUARE OF VECTOR INPUT TO ABVAL AND UNIT
LV              EQUALS  36D             # LENGTH OF VECTOR INPUT TO UNIT.
X1              EQUALS  38D             # INTERPRETIVE SPECIAL REGISTER RELATIVE
X2              EQUALS  39D             # TO THE WORK AREA.
S1              EQUALS  40D
S2              EQUALS  41D
QPRET           EQUALS  42D
```

Defines:
`BANKALRM`, used in chunk 2007.
`CDUSCMD`, never used.
`CDUTCMD`, used in chunks 292 and 2438.
`CDUZCMD`, used in chunks 272, 888, 890, 1412, 2514, and 2515.
`EMSD`, never used.
`LEMONM`, never used.
`LOCALARM`, used in chunk 2007.
`LV`, used in chunks 37, 121, 460, 753, 762, 794, 795, 820, 850, 854, 1045, 1049, 1052, 1063, 1094, 1301, 1610, 1612, 2219, and 2223.
`LVSQUARE`, used in chunks 1610 and 1615.
`OPTXCMD`, never used.
`OPTYCMD`, never used.
`QPRET`, used in chunks 382, 384, 390, 394, 396–98, 400, 444, 489, 741, 823, 827, 837, 893, 921, 1042a, 1049, 1054, 1094, 1147, 1200, 1555, 1565, 1618, 1633, 1634, 1649, 1651, 1707, 1794, 1796, 1802, 1814, 1844, 1852, 2219, and 2343.
`S1`, used in chunks 483, 484, 670, 678, 680, 717, 939, 959, 963, 969, 977, 979, 983, 985, 993, 1003, 1007, 1035, 1041, 1056, 1058, 1147, 1195, 1200, 1291, 1301, 1631, 1684, 1693, 1697, 1701, 1703, 1814, 1841, 1844, 1852, 1876, 1884, 2160, 2177, 2185, 2187, 2205, 2482, and 2490.
`S2`, used in chunks 706, 733, 735, 837, 839, 840a, 866, 999, 1041, 1042a, 1147, 1200, 1682, 1684, 1693, 1697, 1698, 1701, 1703, 1739, 1746, 1782, 1784, 1786, 1814, 1835, 1836, 1839–41, 1852, 1876, 1884, 2143, 2199, 2482, 2490, 2574, 2609, 2615, 2621, 2623, and 2624.
`THRUST`, used in chunks 50, 166, 174, 238, 451, 468, 470, 651, 653, 1094, 1227, 1301, 1367, 1508, 1510, 1512, 1804, 2043–45, 2061, 2062, 2079, 2152, 2279, 2306, 2343, 2382, 2440,

2441, 2444, 2445, 2453, 2459, 2496, and 2596.
TVCPITCH, used in chunks 1094, 1367, 1373, and 1390.
TVCYAW, used in chunks 1094, 1367, and 1373.
X1, used in chunks 481, 678, 722, 735, 758, 767, 790, 797, 810, 818, 848, 897, 901, 903, 907, 909, 937, 939, 945, 969, 971, 991, 1035, 1056, 1058, 1063, 1094, 1147, 1195, 1200, 1227, 1291, 1301, 1550, 1558, 1582, 1623, 1630–32, 1684, 1697, 1709, 1714, 1716, 1719, 1723, 1725, 1729, 1731, 1735, 1738, 1739, 1741, 1744, 1746, 1748, 1750–52, 1754, 1759, 1760, 1763, 1776, 1788, 1790, 1814, 1841, 1852, 2027, 2035, 2130, 2158, 2160, 2185, 2209, 2223, 2311, 2343, and 2382.
X2, used in chunks 50, 485, 735, 749, 792, 799, 823, 829, 831, 903, 947, 985, 1063, 1094, 1195, 1200, 1227, 1301, 1344, 1558, 1582, 1623, 1632, 1697, 1701, 1703, 1731, 1735, 1739, 1776, 1812, 1814, 1841, 1844, 1852, 2143, 2158, 2160, 2213, 2223, and 2382.
Uses COMMAND 169 and MODE 145.

87 ⟨*Page CM0041* 87⟩≡ (75 2684)

```
# INPUT/OUTPUT CHANNELS

# *** CHANNEL ZERO IS TO BE USED IN AN INDEXED OPERATION ONLY. ***
LCHAN           EQUALS  L
QCHAN           EQUALS  Q
HISCALAR        EQUALS  3
LOSCALAR        EQUALS  4
PYJETS          EQUALS  5
ROLLJETS        EQUALS  6
SUPERBNK        EQUALS  7
OUT0            EQUALS  10
DSALMOUT        EQUALS  11
CHAN12          EQUALS  12
CHAN13          EQUALS  13
CHAN14          EQUALS  14
MNKEYIN         EQUALS  15
NAVKEYIN        EQUALS  16
CHAN30          EQUALS  30
CHAN31          EQUALS  31
CHAN32          EQUALS  32
CHAN33          EQUALS  33
DNTM1           EQUALS  34
DNTM2           EQUALS  35

# END OF CHANNEL ASSIGNMENTS
```

Defines:

`CHAN12`, used in chunks 263, 264, 267, 270, 272, 279, 282, 284, 285, 288, 293a, 311, 313, 386, 421, 642, 884, 890, 1094, 1367, 1412, 1918–20, 1922–25, 1932, 2060, 2299, 2382, 2424, 2438, 2509, 2515, 2519, 2574, and 2598.

`CHAN13`, used in chunks 311, 325, 640, 642, 644, 955, 957, 1396, 1412, 1453, 1479, 1528, 1532, 1941, 1943, 2061, 2311, 2465, 2467, 2475a, 2496, 2519, and 2542.

`CHAN14`, used in chunks 272, 293a, 311, 1094, 1367, 1373, 1390, 1412, 1922, 1923, 1927, 1929, 1931–33, 2061, 2279, 2306, 2343, 2420, 2422, 2438, 2515, and 2517.

`CHAN30`, used in chunks 257, 281, 287, 423, 731, 876, 2293, 2311, 2343, 2424, 2443, 2504, and 2588.

`CHAN31`, used in chunks 649, 891, 967, 1094, 1412, 1434, 1453, 2311, 2443, 2504, 2519, and 2542.

`CHAN32`, used in chunks 254, 1434, 2108, and 2382.

`CHAN33`, used in chunks 265, 281, 317, 959, 2064a, 2299, and 2382.

`DNTM1`, used in chunks 1534 and 2471.

`DNTM2`, used in chunks 1534 and 2471.

`DSALMOUT`, used in chunks 269, 272, 278, 279, 311, 321, 325, 335, 613, 633, 635, 639a, 640, 642, 644, 969, 1094, 1227, 1347, 1356, 1656, 1661, 1934, 1946, 1989, 2015, 2059, 2273, 2343, and 2382.

`HISCALAR`, used in chunks 708, 1568, 2059, and 2201.

`LCHAN`, used in chunks 254, 257, 265, 278, 281, 287, 290, 321, 1412, 1500, 1502, 1568, 2001, 2015, 2130, 2140, 2283, 2510, and 2519.

LOSCALAR, used in chunks 708, 2059, 2201, and 2542.
MNKEYIN, used in chunks 325, 1945, and 2062.
NAVKEYIN, used in chunks 323, 389, 2062, 2134, and 2136.
OUTO, used in chunks 252, 253, 255, 256, 517, and 2059.
PYJETS, used in chunks 1484, 1496, and 2059.
QCHAN, used in chunk 1636.
ROLLJETS, used in chunks 1484, 1500, 1502, 1518, and 2059.
SUPERBNK, used in chunks 317, 416, 617, 623, 625, 957, 1541, 1543, 1640, 1654, 1656, 1661, 1663, 1898, 1975, 1977, 2007, and 2059.

Uses L 80 and Q 80.

89 ⟨*Page CM0042* 89⟩≡ (75 2684)

```
# FLAGWORDS
#
# FLAGWRD0      STATE +0        (000-014)
# FLAGWRD1      STATE +1        (015-029)
# FLAGWRD2      STATE +2        (030-044)
# FLAGWRD3      STATE +3        (045-059)
# FLAGWRD4      STATE +4        (060-074)
# FLAGWRD5      STATE +5        (075-089)
# FLAGWRD6      STATE +6        (090-104)
# FLAGWRD7      STATE +7        (105-119)
# FLAGWRD8      STATE +8D       (120-134)
# FLAGWRD9      STATE +9D       (135-149)

#       SORTED LIST OF
#       INTERPRETIVE SWITCH BIT ASSIGNMENTS

# INTERPRETIVE SWITCH BIT ASSIGNMENTS
#
# FLAGWORD      DEC NUM         BIT & FLAG      EQUIVALENT FLAGWORDS
#
# 22DSPFLG      032D            BIT 13 FLAG 2
# 360SW         134D            BIT 1 FLAG 8
# 3AXISFLG      084D            BIT 6 FLAG 5
# ADVTRK        125D            BIT 10 FLAG 8
# AMOONFLG      13D             BIT 2 FLAG 0
# APSESW        130D            BIT 5 FLAG 8
# ASTNFLAG      108D            BIT 12 FLAG 7
# ATTCHFLG      118D            BIT 2 FLAG 7
# AVEGFLAG      029D            BIT 1 FLAG 1
# AVEMIDSW      149D            BIT 1 FLAG 9
# AVFLAG        040D            BIT 5 FLAG 2
# CALCMAN2      043D            BIT 2 FLAG 2
# CMDAPARM      093D            BIT 12 FLAG 6
# CMOONFLG      123D            BIT 12 FLAG 8
# CM/DSTBY      103D            BIT 2 FLAG 6
# COGAFLAG      131D            BIT 4 FLAG 8
# COMPUTER      082D            BIT 8 FLAG 5
# CPHIFLAG      000D            BIT 15 FLAG 0
# CULTFLAG      053D            BIT 7 FLAG 3
# D6OR9FLG      058D            BIT 2 FLAG 3
# DAPBIT1       090D            BIT 15 FLAG 6
# DAPBIT2       091D            BIT 14 FLAG 6
# DIMOFLAG      059D            BIT 1 FLAG 3
# DMENFLAG      081D            BIT 9 FLAG 5
```

```
# DRIFTFLG      030D            BIT 15 FLAG 2
# DSKYFLAG      075D            BIT 15 FLAG 5
# EGSW          097D            BIT 8 FLAG 6    KNOTNFLG R57FLAG
```

Uses 22DSPFLG 103, 3AXISFLG 115, ADVTRK 127, AMOONFLG 97, APSESW 127, ASTNFLAG 123, ATTCHFLG 125, AVEGFLAG 101, AVEMIDSW 133, AVFLAG 105, CALCMAN2 105, CM/DSTBY 121, CMDAPARM 117, CMOONFLG 125, COGAFLAG 127, COMPUTER 115, CPHIFLAG 95, CULTFLAG 107, D6OR9FLG 109, DAPBIT1 117, DAPBIT2 117, DIMOFLAG 109, DRIFTFLG 101, DSKYFLAG 113, EGSW 119, FLAGWRD0 95, FLAGWRD1 97, FLAGWRD2 101, FLAGWRD3 105, FLAGWRD4 109, FLAGWRD5 113, FLAGWRD6 117, FLAGWRD7 121, FLAGWRD8 125, R57FLAG 119, and STATE 138.

91 ⟨*Page CM0043* 91⟩≡ (75 2684)

```
# ENG1FLAG      018D            BIT 12 FLAG 1
# ENG2FLAG      019D            BIT 11 FLAG 1
# ENGONFLG      083D            BIT 7 FLAG 5
# ERADFLAG      017D            BIT 13 FLAG 1
# ETPIFLAG      038D            BIT 7 FLAG 2    FIRSTFLG OPTNSW
# F2RTE         010D            BIT 5 FLAG 0
# FINALFLG      039D            BIT 6 FLAG 2
# FIRSTFLG      038D            BIT 7 FLAG 2    ETPIFLAG OPTNSW
# FREEFLAG      012D            BIT 3 FLAG 0
# GAMDIFSW      094D            BIT 11 FLAG 6
# GLOKFAIL      046D            BIT 14 FLAG 3
# GONEBY        112D            BIT 8 FLAG 7
# GONEPAST      095D            BIT 10 FLAG 6
# GRRBKFLG      085D            BIT 5 FLAG 5
# GUESSW        028D            BIT 2 FLAG 1
# GYMDIFSW      104D            BIT 1 FLAG 6
# .05GSW        102D            BIT 3 FLAG 6
# HIND          099D            BIT 6 FLAG 6
# IDLEFAIL      024D            BIT 6 FLAG 1
# IDLEFLAG      113D            BIT 7 FLAG 7
# IGNFLAG       107D            BIT 13 FLAG 7
# IMPULSW       036D            BIT 9 FLAG 2
# IMUSE         007D            BIT 8 FLAG 0
# INCORFLG      079D            BIT 11 FLAG 5
# INFINFLG      128D            BIT 7 FLAG 8
# INRLSW        100D            BIT 5 FLAG 6
# INTFLAG       151D            BIT 14 FLAG 10
# INTYPFLG      056D            BIT 4 FLAG 3
# ITSWICH       106D            BIT 14 FLAG 7
# KFLAG         014D            BIT 1 FLAG 0
# KNOWNFLG      097D            BIT 8 FLAG 6    EGSW R57FLAG
# LATSW         101D            BIT 4 FLAG 6
# LMOONFLG      124D            BIT 11 FLAG 8
# LUNAFLAG      048D            BIT 12 FLAG 3
# MAXDBFLG      138D            BIT 12 FLAG 9
# MGLVFLAG      088D            BIT 2 FLAG 5
# MID1FLAG      147D            BIT 3 FLAG 9
# MIDAVFLG      148D            BIT 2 FLAG 9
# MIDFLAG       002D            BIT 13 FLAG 0
# MKOVFLAG      072D            BIT 3 FLAG 4
# MOONFLAG      003D            BIT 12 FLAG 0
# MRKIDFLG      060D            BIT 15 FLAG 4
# MRKNVFLG      066D            BIT 9 FLAG 4
# MRUPTFLG      070D            BIT 5 FLAG 4
```

```
# MWAITFLG      064D            BIT 11 FLAG 4
# N22ORN17      144D            BIT 6 FLAG 9
# NEEDLFLG      006D            BIT 9 FLAG 0
# NEWIFLG       122D            BIT 13 FLAG 8
# NJETSFLG      015D            BIT 15 FLAG 1
# NODOFLAG      044D            BIT 1 FLAG 2
```

Uses .05GSW 121, EGSW 119, ENG2FLAG 99, ENGONFLG 115, ERADFLAG 99, ETPIFLAG 103, F2RTE 97, FINALFLG 105, FIRSTFLG 103, FREEFLAG 97, GAMDIFSW 119, GLOKFAIL 105, GONEBY 123, GONEPAST 119, GRRBKFLG 115, GUESSW 101, GYMDIFSW 121, HIND 119, IDLEFAIL 101, IGNFLAG 123, IMPULSW 103, IMUSE 95, INCORFLG 115, INFINFLG 127, INRLSW 121, INTFLAG 133, INTYPFLG 107, ITSWICH 121, KFLAG 97, KNOWNFLG 119, LATSW 121, LMOONFLG 125, LUNAFLAG 107, MGLVFLAG 117, MID1FLAG 131, MIDAVFLG 131, MIDFLAG 95, MKOVFLAG 113, MOONFLAG 95, MRKIDFLG 109, MRKNVFLG 111, MRUPTFLG 111, MWAITFLG 109, N22ORN17 131, NEEDLFLG 95, NEWIFLG 125, NJETSFLG 97, NODOFLAG 105, OPTNSW 105, and R57FLAG 119.

93 ⟨*Page CM0044* 93⟩≡ (75 2684)

```
# NODOP01       018D            BIT 12 FLAG 1
# NORFHOR       004D            BIT 11 FLAG 0
# NORMSW        110D            BIT 10 FLAG 7
# NOSWITCH      098D            BIT 7 FLAG 6
# NRMIDFLG      062D            BIT 13 FLAG 4
# NRMNVFLG      067D            BIT 8 FLAG 4
# NRUPTFLG      071D            BIT 4 FLAG 4
# NWAITFLG      065D            BIT 10 FLAG 4
# OPTNSW        038D            BIT 7 FLAG 2    ETPIFLAG FIRSTFLG
# ORBWFLAG      054D            BIT 6 FLAG 3
# ORDERSW       129D            BIT 6 FLAG 8
# P21FLAG       033D            BIT 12 FLAG 2
# P22MKFLG      049D            BIT 11 FLAG 3
# P39/79SW      126D            BIT 9 FLAG 8
# PDSPFLAG      063D            BIT 12 FLAG 4
# PFRATFLG      041D            BIT 4 FLAG 2
# PINBRFLG      069D            BIT 6 FLAG 4
# PRECIFLG      052D            BIT 8 FLAG 3
# PRFTRKAT      060D            BIT 10 FLAG 5
# PRIODFLG      061D            BIT 14 FLAG 4
# PRONVFLG      068D            BIT 7 FLAG 4
# QUITFLAG      145D            BIT 5 FLAG 9
# R21MARK       031D            BIT 14 FLAG 2
# R22CAFLG      143D            BIT 7 FLAG 9
# R23FLG        021D            BIT 9 FLAG 1
# R31FLAG       146D            BIT 4 FLAG 9
# R53FLAG       009D            BIT 6 FLAG 0
# R57FLAG       097D            BIT 8 FLAG 6    KNOWNFLG EGSW
# R60FLAG       086D            BIT 4 FLAG 5
# REFSMFLG      047D            BIT 13 FLAG 3
# REINTFLG      158D            BIT 7 FLAG 10
# RELVELSW      096D            BIT 9 FLAG 6
# RENDWFLG      089D            BIT 1 FLAG 5
# RNDVZFLG      008D            BIT 7 FLAG 0
# RPQFLAG       120D            BIT 15 FLAG 6
# RVSW          111D            BIT 9 FLAG 7
# SAVECFLG      140D            BIT 10 FLAG 9
# SKIPVHF       035D            BIT 10 FLAG 2
# SLOPESW       027D            BIT 3 FLAG 1
# SOLNSW        087D            BIT 3 FLAG 5
# SOURCFLG      142D            BIT 8 FLAG 9
# STATEFLG      055D            BIT 5 FLAG 3
# STEERSW       034D            BIT 11 FLAG 2
# STIKFLAG      016D            BIT 14 FLAG 1
```

```
# STRULLSW      092D            BIT 13 FLAG 6
# SURFFLAG      127D            BIT 8 FLAG 8
# SWTOVER       135D            BIT 15 FLAG 9
# TARG1FLG      020D            BIT 10 FLAG 1
```

Uses EGSW 119, ETPIFLAG 103, FIRSTFLG 103, KNOWNFLG 119, NODOP01 99, NORFHOR 95, NORMSW 123, NOSWITCH 119, NRMIDFLG 109, NRMNVFLG 111, NRUPTFLG 113, NWAITFLG 111, OPTNSW 105, ORBWFLAG 107, ORDERSW 127, P21FLAG 103, P22MKFLG 107, P39/79SW 127, PDSPFLAG 109, PFRATFLG 105, PINBRFLG 111, PRECIFLG 107, PRFTRKAT 115, PRIODFLG 109, PRONVFLG 111, QUITFLAG 131, R21MARK 103, R22CAFLG 131, R23FLG 99, R31FLAG 131, R53FLAG 97, R57FLAG 119, R60FLAG 115, REFSMFLG 107, REINTFLG 135, RELVELSW 119, RENDWFLG 117, RNDVZFLG 97, RPQFLAG 125, RVSW 123, SKIPVHF 103, SLOPESW 101, SOLNSW 115, SOURCFLG 131, STATEFLG 107, STEERSW 103, STIKFLAG 99, STRULLSW 117, SURFFLAG 127, and TARG1FLG 99.

94 ⟨*Page CM0045* 94⟩≡ (75 2684)

```
# TARG2FLG      021D            BIT 9 FLAG 1
# TERMIFLG      105D            BIT 15 FLAG 7
# TFFSW         119D            BIT 1 FLAG 7
# TIMRFLAG      109D            BIT 11 FLAG 7
# TRACKFLG      025D            BIT 5 FLAG 1
# TRM03FLG      026D            BIT 4 FLAG 1
# TRUNFLAG      011D            BIT 4 FLAG 0
# UPDATFLG      023D            BIT 7 FLAG 1
# UPLOCKFL      116D            BIT 4 FLAG 7
# V37FLAG       114D            BIT 6 FLAG 7
# V59FLAG       078D            BIT 12 FLAG 5
# V67FLAG       136D            BIT 14 FLAG 9
# V82EMFLG      137D            BIT 13 FLAG 9
# V94FLAG       139D            BIT 11 FLAG 9
# V96ONFLG      132D            BIT 3 FLAG 8
# VEHUPFLG      022D            BIT 8 FLAG 1
# VERIFLAG      117D            BIT 3 FLAG 7
# VFLAG         050D            BIT 10 FLAG 3
# VHFRFLAG      141D            BIT 9 FLAG 9
# VINTFLAG      057D            BIT 3 FLAG 3
# XDELVFLG      037D            BIT 8 FLAG 2
# XDSPFLAG      074D            BIT 1 FLAG 4
```

Uses TARG2FLG 99, TERMIFLG 121, TFFSW 125, TIMRFLAG 123, TRACKFLG 101, TRM03FLG 101, TRUNFLAG 97, UPDATFLG 99, UPLOCKFL 125, V37FLAG 123, V59FLAG 113, VEHUPFLG 99, VERIFLAG 125, VFLAG 107, VHFRFLAG 131, VINTFLAG 109, XDELVFLG 103, and XDSPFLAG 113.

95 ⟨*Page CM0046* 95⟩≡ (75 2684)

```
# INTERPRETIVE SWITCH BIT ASSIGNMENTS
FLAGWRD0        =       STATE +0        # (000-014)
                                        # (SET)                 (RESET)
# BIT 15 FLAG 0
CPHIFLAG        =       000D            # OUTPUT OF CALCGA IS   OUTPUT OF CALCGA IS
                                        # CPHIX                 THETAD
CPHIBIT         =       BIT15

# BIT 14 FLAG 0
JSWITCH         =       001D            # INTEGRATION OF W      INTEGRATION OF STATE
                                        # MATRIX                VECTOR
JSWCHBIT        =       BIT14

# BIT 13 FLAG 0
MIDFLAG         =       002D            # INTEGRATION WITH      INTEGRATION WITHOUT
                                        # SOLAR PERTURBATIONS   SOLAR PERTURBATIONS

MIDFLBIT        =       BIT13

# BIT 12 FLAG 0
MOONFLAG        =       003D            # MOON IS SPHERE OF     EARTH IS SPHERE OF
                                        # INFLUENCE             INFLUENCE

MOONBIT         =       BIT12

# BIT 11 FLAG 0
NORFHOR         =       004D            # FAR HORIZON           NEAR HORIZON

NORFBIT         =       BIT11

# BIT 10 FLAG 0
ZMEASURE        =       005D            # MEASUREMENT PLANET    MEASUREMENT PLANET
                                        # AND PRIMARY PLANET    AND PRIMARY PLANET
                                        # DIFFERENT             SAME

ZMEASBIT        =       BIT10

# BIT 9 FLAG 0
NEEDLFLG        =       006D            # TOTAL ATTITUDE        A/P FOLLOWING ERROR
                                        # ERROR DISPLAYED       DISPLAYED

NEEDLBIT        =       BIT9

# BIT 8 FLAG 0
```

```
IMUSE           =       007D            # IMU IN USE            IMU NOT IN USE
```

Defines:
CPHIBIT, never used.
CPHIFLAG, used in chunks 89, 1200, and 1840.
FLAGWRD0, used in chunks 89, 297, 335, 341, 343, 345, 347, 416, 432, 434, 1227, 1412, 2001, 2068, 2074, 2116, 2343, 2424, 2428, 2438, and 2510.
IMUSE, used in chunks 91, 341, 345, 434, 703, 1940a, 1941, 2068, 2075, 2116, 2196, and 2211.
JSWCHBIT, used in chunks 2068 and 2074.
JSWITCH, used in chunks 1814, 2068, and 2074.
MIDFLAG, used in chunks 91, 359, 1772, 1774, 1776, 1778, 1780, 1794, 1798, 1814, 2070, and 2074.
MIDFLBIT, used in chunks 2070 and 2074.
MOONBIT, used in chunks 2070 and 2074.
MOONFLAG, used in chunks 91, 749, 775, 790, 816, 820, 822, 823, 1301, 1772, 1774, 1776, 1778, 1780, 1784, 1786, 1788, 1792, 1796, 1812, 1814, 2027, 2070, 2074, and 2299.
NEEDLBIT, used in chunks 2070, 2075, and 2512.
NEEDLFLG, used in chunks 91, 416, 2070, 2075, and 2510.
NORFBIT, never used.
NORFHOR, used in chunks 93, 1019, and 1033.
ZMEASBIT, never used.
ZMEASURE, used in chunks 1023 and 1035.
Uses A 80, CPHIX 163, HORIZON 190, P 188, STATE 138, THETAD 157, and W 183.

97 ⟨*Page CM0047* 97⟩≡ (75 2684)

```
IMUSEBIT        =       BIT8

# BIT 7 FLAG 0
RNDVZFLG        =       008D            # P20 RUNNING           P20 NOT RUNNING

RNDVZBIT        =       BIT7

# BIT 6 FLAG 0
R53FLAG         =       009D            # V51 INITIATED         V51 NOT INITIATED

R53FLBIT        =       BIT8

# BIT 5 FLAG 0
F2RTE           =       010D            # IN TIME CRITICAL      NOT IN TIME CRITICAL
                                        # MODE                  MODE

F2RTEBIT        =       BIT5

# BIT 4 FLAG 0
TRUNFLAG        =       011D            # DRIVING OF TRUNNION   DRIVING OF TRUNNION
                                        # ALLOWED               NOT ALLOWED

TRUNBIT         =       BIT4

# BIT 3 FLAG 0
FREEFLAG        =       012D            # (TEMPORARY FLAG USED IN MANY ROUTINES)

FREEFBIT        =       BIT3

# BIT 2 FLAG 0
AMOONFLG        =       13D             # STATE VECTOR IN       STATE VECTOR IN
AMOONBIT        =       BIT2            # LUNAR SPHERE AT       EARTH SPHERE AT
                                        # MIDTOAVE              MIDTOAVE

# BIT 1 FLAG 0
KFLAG           =       014D            # SEARCH SECTOR MORE    SEARCH SECTOR LESS
                                        # THAN 180 DEGREES      THAN 180 DEGREES

KBIT            =       BIT1

FLAGWRD1        =       STATE +1        # (015-029)
                                        # (SET)                 (RESET)

# BIT 15 FLAG 1
```

```
NJETSFLG        =       015D            # TWO JET RCS BURN      FOUR JET RCS BURN

NJETSBIT        =       BIT15
```

Defines:
- AMOONBIT, never used.
- AMOONFLG, used in chunks 89, 835, 884, 1804, 1805, 1808, and 2718.
- F2RTE, used in chunks 91 and 1301.
- F2RTEBIT, never used.
- FLAGWRD1, used in chunks 89, 313, 335, 339, 341, 343, 419, 432, 434, 649, 724, 741, 930, 967, 1094, 1227, 1412, 1923, 2068, 2075, 2311, 2424, 2438, and 2692.
- FREEFBIT, used in chunks 2068 and 2075.
- FREEFLAG, used in chunks 91, 1147, 2068, and 2075.
- IMUSEBIT, used in chunks 2068, 2075, and 2116.
- KBIT, never used.
- KFLAG, used in chunks 91, 895, 897, 899, 903, 907, 909, and 911.
- NJETSBIT, used in chunks 2070 and 2076.
- NJETSFLG, used in chunks 91, 1094, 1301, 2070, and 2076.
- R53FLAG, used in chunks 93 and 1147.
- R53FLBIT, never used.
- RNDVZBIT, used in chunks 343, 345, 432, 434, 2072, and 2075.
- RNDVZFLG, used in chunks 93, 434, 915, 917, 919, 1015, 1147, 1941, 2072, 2075, 2299, and 2353.
- TRUNBIT, never used.
- TRUNFLAG, used in chunks 94 and 1147.

Uses MODE 145 and STATE 138.

99 ⟨*Page CM0048* 99⟩≡ (75 2684)

```
# BIT 14 FLAG 1
STIKFLAG        =       016D            # RHC CONTROL           CMC CONTROL
STIKBIT         =       BIT14

# BIT 13 FLAG 1
ERADFLAG        =       017D            # EARTH, COMPUTE        EARTH, USED FIXED
                                        #   FISCHER ELLIPSOID     RADIUS
                                        #   RADIUS
                                        # MOON, USE FIXED       MOON, USE RLS FOR
                                        #   RADIUS                LUNAR RADIUS

ERADFBIT        =       BIT13

# BIT 12 FLAG 1
NODOP01         =       018D            # P01 NOT ALLOWED       P01 ALLOWED
NOP01BIT        =       BIT12

# BIT 11 FLAG 1
ENG2FLAG        =       019D            # RCS BURN              SPS BURN

ENG2BIT         =       BIT11

# BIT 10 FLAG 1
TARG1FLG        =       020D            # SIGHTING LEM          NOT SIGHTING LEM

TARG1BIT        =       BIT10

# BIT 9 FLAG 1
TARG2FLG        =       021D            # SIGHTING LANDMARK     SIGHTING STAR

TARG2BIT        =       BIT9

# BIT 9 FLAG 1
R23FLG          =       021D            # R23 MARKING

R23BIT          =       BIT9

# BIT 8 FLAG 1
VEHUPFLG        =       022D            # CSM STATE VECTOR      LEM STATE VECTOR
                                        # BEING UPDATED         BEING UPDATED

VEHUPBIT        =       BIT8

# BIT 7 FLAG 1
```

```
UPDATFLG        =       023D            # UPDATING BY MARKS     UPDATING BY MARKS
                                        # ALLOWED               NOT ALLOWED
```

Defines:
ENG2BIT, never used.
ENG2FLAG, used in chunks 91 and 1094.
ERADFBIT, used in chunks 2068 and 2076.
ERADFLAG, used in chunks 91, 749, 862, 866, 919, 923, 981, 995, 1024, 1056, 1147, 1200, 1256, 1301, 1675, 1677, 1682, 2068, and 2076.
NODOPO1, used in chunks 93, 313, 419, and 864.
NOPO1BIT, used in chunks 313, 419, and 724.
R23BIT, used in chunks 432 and 930.
R23FLG, used in chunks 93, 432, 930, and 945.
STIKBIT, used in chunk 967.
STIKFLAG, used in chunks 93, 339, 423, 915, 967, 969, and 1412.
TARG1BIT, never used.
TARG1FLG, used in chunks 93, 649, 915, 918, 921, 926, 1015, and 1147.
TARG2BIT, never used.
TARG2FLG, used in chunks 94, 921, 926, 1015, and 1147.
UPDATFLG, used in chunks 94, 434, 756, 762, 777, 780, 844, 846, 850, 852, 909, 911, 912, 915, 917, 955, 1045, 1047, 1062a, 1063, 1147, 2072, 2076, 2219, 2223, and 2256.
VEHUPBIT, used in chunks 2072 and 2076.
VEHUPFLG, used in chunks 94, 436, 915, 917, 943, 945, 949, 959, 991, 1027, 1699, 1705, 2072, and 2076.
Uses LANDMARK 190, RLS 175, STAR 186, and STATE 138.

101 ⟨*Page CM0049* 101⟩≡ (75 2684)

```
UPDATBIT        =       BIT7

# BIT 6 FLAG 1
IDLEFAIL        =       024D            # INHIBIT R41           ENABLE R41 (ENGFAIL)

IDLEBIT         =       BIT6

# BIT 5 FLAG 1
TRACKFLG        =       025D            # TRACKING ALLOWED      TRACKING NOT ALLOWED

TRACKBIT        =       BIT5

# BIT 4 FLAG 1
TRM03FLG        =       026D            # REQUEST TO            NO REQUEST TO
                                        # TERMINATE P03 HAS     TERMINATE P03 HAS
                                        # BEEN ENTERED          BEEN ENTERED

TRM03BIT        =       BIT4

# BIT 3 FLAG 1
SLOPESW         =       027D            # ITERATE WITH BIAS     ITERATE WITH REGULA
                                        # METHOD IN ITERATOR    FALSI METHOD IN
                                        #                       ITERATOR

SLOPEBIT        =       BIT3

# BIT 2 FLAG 1
GUESSW          =       028D            # NO STARTING VALUE     STARTING VALUE FOR
                                        # FOR ITERATION         ITERATION EXISTS

GUESSBIT        =       BIT2

# BIT 1 FLAG 1
AVEGFLAG        =       029D            # AVERAGEG (SERVICER)   AVERAGEG (SERVICER)
                                        # TO CONTINUE           TO CEASE

AVEGBIT         =       BIT1

FLAGWRD2        =       STATE +2        # (030-044)

                                        # (SET)                 (RESET)

# BIT 15 FLAG 2
DRIFTFLG        =       030D            # T3RUPT CALLS GYRO     T3RUPT DOES NO GYRO
```

```
                                        # COMPENSATION          COMPENSATION

  DRFTBIT         =       BIT15
```

Defines:
AVEGBIT, used in chunk 339.
AVEGFLAG, used in chunks 89, 827, 1200, 1227, 2066, 2092, and 2382.
DRFTBIT, used in chunks 2066, 2078, and 2382.
DRIFTFLG, used in chunks 89, 1147, 1227, 2066, 2078, and 2382.
FLAGWRD2, used in chunks 89, 325, 333, 335, 337, 341, 501, 780, 1094, 1227, 1486, 1663, 1923, 2068, 2078, 2277, 2311, and 2382.
GUESSBIT, used in chunks 2068 and 2078.
GUESSW, used in chunks 91, 786, 790, 1094, 1716, 1717, 1754, 1767, 2068, and 2078.
IDLEBIT, never used.
IDLEFAIL, used in chunks 91, 347, and 1094.
SLOPEBIT, used in chunks 2072 and 2078.
SLOPESW, used in chunks 93, 1718, 1739, 1752, 2072, and 2078.
TRACKBIT, used in chunks 432, 434, 2072, and 2078.
TRACKFLG, used in chunks 94, 434, 756, 762, 820, 844, 852, 915, 917, 955, 1047, 1062a, 1147, 2072, 2078, 2219, and 2223.
TRM03BIT, used in chunk 741.
TRM03FLG, used in chunks 94, 398, and 737.
UPDATBIT, used in chunks 959, 2072, and 2076.
Uses BIAS 211 and STATE 138.

103 ⟨*Page CM0050* 103⟩≡ (75 2684)

```
# BIT 14 FLAG 2
R21MARK         =       031D            # OPTION ONE FOR        OPTION TWO FOR
                                        # MARKRUPT              MARKRUPT

R21BIT          =       BIT14

# BIT 13 FLAG 2
22DSPFLG        =       032D            # DISPLAY DR,DV         DO NOT DISPLAY DR,DV

22DSPBIT        =       BIT13

# BIT 12 FLAG 2
P21FLAG         =       033D            # SUCCEEDING PASS       1ST PASS THRU P21,
                                        # THRU P21, USE BASE    CALCULATE BASE
P21BIT          =       BIT12           # VECTOR FOR CALC.      VECTOR

STEERSW         =       034D            # STEERING TO BE DONE   STEERING OMITTED

STEERBIT        =       BIT11

# BIT 10 FLAG 2
SKIPVHF         =       035D            # DISREGARD RADAR       RADAR READ TO
                                        # READ BECAUSE OF       PROCEED NORMALLY
SKIPVBIT        =       BIT10           # SFTWRE OR HDWRE
                                        # RESTART

# BIT 9 FLAG 2
IMPULSW         =       036D            # MINIMUM IMPULSE       STEERING BURN (NO
                                        # BURN (CUTOFF TIME     CUTOFF TIME YET
                                        # SPECIFIED)            AVAILABLE)

IMPULBIT        =       BIT9

# BIT 8 FLAG 2
XDELVFLG        =       037D            # EXTERNAL DELTAV VG    LAMBERT (AIMPOINT)
                                        # COMPUTATION           VG COMPUTATION

XDELVBIT        =       BIT8

# BIT 7 FLAG 2
ETPIFLAG        =       038D            # ELEVATION ANGLE       TPI TIME SUPPLIED
                                        # SUPPLIED FOR P34,74   FOR P34,74

# BIT 7 FLAG 2
```

```
FIRSTFLG        =       ETPIFLAG        # FIRST PASS            SUCCEEDING PASS THRU
                                        # THRU S40.9            S40.9

FIRSTBIT        =       BIT7

# BIT 7 FLAG 2
```

Defines:
22DSPBIT, never used.
22DSPFLG, used in chunks 89, 981, and 991.
ETPIFLAG, used in chunks 91, 93, 105, 756, 758, 769, 2068, 2070, and 2079.
FIRSTBIT, never used.
FIRSTFLG, used in chunks 91, 93, and 1094.
IMPULBIT, used in chunks 2068, 2079, and 2277.
IMPULSW, used in chunks 91, 347, 1094, 2068, and 2079.
P21BIT, never used.
P21FLAG, used in chunks 93, 325, 347, 747, 749, 2070, and 2074.
R21BIT, never used.
R21MARK, used in chunks 93, 325, 341, 930, and 932.
SKIPVBIT, used in chunks 325 and 959.
SKIPVHF, used in chunks 93, 325, 957, and 959.
STEERBIT, used in chunks 2072, 2079, 2311, and 2382.
STEERSW, used in chunks 93, 347, 1094, 2072, 2079, 2311, 2382, and 2441.
XDELVBIT, used in chunks 2074 and 2079.
XDELVFLG, used in chunks 94, 754, 761, 777, 850, 1047, 1063, 1094, 1301, 2074, 2079, 2219, 2223, 2256, and 2258.
Uses DV 241, P21 219, RESTART 57, and VG 234.

105 ⟨*Page CM0051* 105⟩≡ (75 2684)

```
OPTNSW          =       ETPIFLAG        # SOI PHASE P38/P78     SOR PHASE OF P38/P78

FINALBIT        =       BIT6

# BIT 6 FLAG 2
FINALFLG        =       039D            # LAST PASS THROUGH     INTERIM PASS THROUGH
                                        # RENDEZVOUS PROGRAM    RENDEZVOUS PROGRAM
                                        # COMPUTATIONS          COMPUTATIONS

AVFLBIT         =       BIT5

# BIT 5 FLAG 2
AVFLAG          =       040D            # LEM IS ACTIVE         CSM IS ACTIVE
                                        # VEHICLE               VEHICLE

# BIT 4 FLAG 2
PFRATFLG        =       041D            # PREFERRED ATTITUDE    PREFERRED ATTITUDE
                                        # COMPUTED              NOT COMPUTED

PFRATBIT        =       BIT4

# BIT 3 FLAG 2
                =       042D

# BIT 2 FLAG 2
CALCMAN2        =       043D            # PERFORM MANEUVER      BYPASS STARTING
                                        # STARTING PROCEDURE    PROCEDURE

CALC2BIT        =       BIT2

# BIT 1 FLAG 2
NODOFLAG        =       044D            # V37 NOT PERMITTED     V37 PERMITTED

NODOBIT         =       BIT1

FLAGWRD3        =       STATE +3        # (045-059)
                                        # (SET)                 (RESET)

# BIT 15 FLAG 3
                =       045D

# BIT 14 FLAG 3
GLOKFAIL        =       046D            # GIMBAL LOCK HAS       NOT IN GIMBAL LOCK
                                        # OCCURRED
```

```
GLOKFBIT        =       BIT14
```

Defines:
- AVFLAG, used in chunks 89, 794, 795, 800a, 854, 901, 909, 1053, 1062a, 1094, 2066, 2079, and 2223.
- AVFLBIT, used in chunks 2066 and 2079.
- CALC2BIT, used in chunks 2066 and 2080.
- CALCMAN2, used in chunks 89, 682, 684, 2066, and 2080.
- FINALBIT, used in chunks 2068 and 2079.
- FINALFLG, used in chunks 91, 777, 779, 780, 796, 846, 850, 852, 1063, 1301, 2068, 2079, 2223, and 2258.
- FLAGWRD3, used in chunks 89, 313, 315, 698, 1923, 2068, 2080, 2112, 2191, and 2382.
- GLOKFAIL, used in chunks 91, 698, 1840, 2068, 2080, and 2191.
- GLOKFBIT, used in chunks 698, 2068, and 2080.
- NODOBIT, used in chunks 337, 341, 2070, and 2080.
- NODOFLAG, used in chunks 91, 333, 341, 360, 1200, 1486, 1782, 1941, 1944a, 2013, 2070, 2080, 2114, and 2116.
- OPTNSW, used in chunks 91, 93, 846, 848, 2070, and 2079.
- PFRATBIT, used in chunks 2070 and 2079.
- PFRATFLG, used in chunks 93, 1094, 1147, 2070, and 2079.

Uses ETPIFLAG 103 and STATE 138.

107 ⟨*Page CM0052* 107⟩≡ (75 2684)

```
# BIT 13 FLAG 3
REFSMFLG        =       047D            # REFSMMAT GOOD         REFSMMAT NO GOOD

REFSMBIT        =       BIT13

# BIT 12 FLAG 3
LUNAFLAG        =       048D            # LUNAR LAT-LONG        EARTH LAT-LONG

LUNABIT         =       BIT12

# BIT 11 FLAG 3
P22MKFLG        =       049D            # P22 DOWNLINKED MARK   P22 DOWNLINK MARK
                                        # DATA WAS JUST TAKEN   DATA NOT JUST TAKEN

P22MKBIT        =       BIT11

# BIT 10 FLAG 3
VFLAG           =       050D            # LESS THAN TWO STARS   TWO STARS IN FIELD
                                        # IN FIELD OF VIEW      OF VIEW

VFLAGBIT        =       BIT10

# BIT 9 FLAG 3
                =       051D

# BIT 8 FLAG 3
PRECIFLG        =       052D            # CSMPREC OR LEMPREC    INTEGRV
                                        # OR INTEGRVS CALLED    CALLED

PRECIBIT        =       BIT8

# BIT 7 FLAG 3
CULTFLAG        =       053D            # STAR OCCULTED         STAR NOT OCCULTED

CULTBIT         =       BIT7

# BIT 6 FLAG 3
ORBWFLAG        =       054D            # W MATRIX VALID FOR    W MATRIX INVALID FOR
                                        # ORBITAL NAVIGATION    ORBITAL NAVIGATION

ORBWFBIT        =       BIT6

# BIT 5 FLAG 3
STATEFLG        =       055D            # PERMANENT STATE       PERMANENT STATE
```

```
                                        # VECTOR UPDATED        VECTOR NOT UPDATED

STATEBIT        =       BIT5

# BIT 4 FLAG 3
INTYPFLG        =       056D            # CONIC INTEGRATION     ENCKE INTEGRATION
```

Defines:
- CULTBIT, used in chunks 2066 and 2081.
- CULTFLAG, used in chunks 89, 484, 1147, 2066, and 2081.
- INTYPFLG, used in chunks 91, 747, 775, 792, 816, 818, 820, 822, 955, 1001, 1301, 1772, 1780, 1782, 1788, 1790, 1792, 1794, 1808, 2068, 2081, and 2299.
- LUNABIT, used in chunks 2070 and 2080.
- LUNAFLAG, used in chunks 91, 749, 919, 921, 923, 983, 995, 997, 1017, 1029, 1035, 1147, 1200, 1256, 1301, 1675, 1677, 1681, 1682, 2070, 2080, and 2299.
- ORBWFBIT, used in chunks 2070 and 2081.
- ORBWFLAG, used in chunks 93, 360, 440, 943, 977, 979, 981, 989, 1009, 1015, 1023, 1041, 1804, 1812, 1814, 2070, and 2081.
- P22MKBIT, never used.
- P22MKFLG, used in chunks 93, 919, and 979.
- PRECIBIT, used in chunks 2070 and 2081.
- PRECIFLG, used in chunks 93, 360, 1790, 1792, 1796, 1800, 2070, and 2081.
- REFSMBIT, used in chunks 2072, 2080, and 2112.
- REFSMFLG, used in chunks 93, 779, 862, 868, 918, 955, 1015, 1017, 1147, 1301, 1939, 2072, 2080, and 2112.
- STATEBIT, used in chunks 2072 and 2081.
- STATEFLG, used in chunks 93, 955, 1001, 1772, 1778, 1780, 1782, 1792, 1794, 1798, 1814, 2011, 2072, and 2081.
- VFLAG, used in chunks 94, 1147, 2072, and 2080.
- VFLAGBIT, used in chunks 2072 and 2080.

Uses LAT 157, LONG 157, ORBITAL 59, REFSMMAT 172, STAR 186, STATE 138, and W 183.

109 ⟨*Page CM0053* 109⟩≡ (75 2684)

```
INTYBIT         =       BIT4

# BIT 3 FLAG 3
VINTFLAG        =       057D            # CSM STATE VECTOR      LEM STATE VECTOR
                                        # BEING INTEGRATED      BEING INTEGRATED

VINTFBIT        =       BIT3

# BIT 2 FLAG 3
D6OR9FLG        =       058D            # DIMENSION OF W IS 9   DIMENSION OF W IS 6
                                        # FOR INTEGRATION       FOR INTEGRATION

D6OR9BIT        =       BIT2

# BIT 1 FLAG 3
DIMOFLAG        =       059D            # W MATRIX IS TO BE     W MATRIX IS NOT TO
                                        # USED                  BE USED

FLAGWRD4        =       STATE +4        # (060-074)
                                        # (SET)                 (RESET)

DIMOBIT         =       BIT1

# BIT 15 FLAG 4
MRKIDFLG        =       060D            # MARK DISPLAY IN       NO MARK DISPLAY IN
                                        # ENDIDLE               ENDIDLE

MRKIDBIT        =       BIT15

# BIT 14 FLAG 4
PRIODFLG        =       061D            # PRIORITY DISPLAY IN   NO PRIORITY DISPLAY
                                        # ENDIDLE               IN ENDIDLE

PRIODBIT        =       BIT14

# BIT 13 FLAG 4
NRMIDFLG        =       062D            # NORMAL DISPLAY IN     NO NORMAL DISPLAY
                                        # ENDIDLE               IN ENDIDLE

NRMIDBIT        =       BIT13

# BIT 12 FLAG 4
PDSPFLAG        =       063D            # CAN'T INTERRUPT       SEE M. HAMILTON
                                        # PRIORITY DISPLAY
```

```
PDSPFBIT        =       BIT12

# BIT 11 FLAG 4
MWAITFLG        =       064D            # HIGHER PRIORITY       NO HIGHER PRIORITY
```

Defines:
D6OR9BIT, used in chunks 2068 and 2081.
D6OR9FLG, used in chunks 89, 955, 979, 989, 1001, 1780, 1782, 1792, 1805, 1814, 2068, and 2081.
DIMOBIT, used in chunk 2081.
DIMOFLAG, used in chunks 89, 360, 747, 749, 915, 917, 943, 955, 979, 989, 1001, 1023, 1778, 1780, 1782, 1788, 1790, 1792, 1805, 1808, 1814, 2081, and 2703.
FLAGWRD4, used in chunks 89, 329, 407, 649, 650, 1959, 1961, 1963, 1965, 1967, 1969, 1971, 1973, 1975, 1983, 1985, 1989, 1991, 1995, 1997, 2068, and 2081.
INTYBIT, never used.
MRKIDBIT, used in chunks 2070 and 2082.
MRKIDFLG, used in chunks 91, 2070, and 2082.
MWAITFLG, used in chunks 91, 2070, and 2082.
NRMIDBIT, used in chunks 2070 and 2082.
NRMIDFLG, used in chunks 93, 2070, and 2082.
PDSPFBIT, used in chunks 959, 2070, and 2082.
PDSPFLAG, used in chunks 93, 649, 936, 959, 2070, and 2082.
PRIODBIT, used in chunks 2070 and 2082.
PRIODFLG, used in chunks 93, 2070, and 2082.
VINTFBIT, used in chunks 2072 and 2081.
VINTFLAG, used in chunks 94, 359, 360, 747, 915, 917, 943, 949, 955, 1001, 1780, 1788, 1790, 1792, 1794, 1805, 1814, 2072, and 2081.
Uses PRIORITY 145, STATE 138, and W 183.

111 ⟨*Page CM0054* 111⟩≡ (75 2684)

```
                                        # DISPLAY OPERATING     DISPLAY OPERATING
                                        # WHEN MARK DISPLAY     WHEN MARK DISPLAY
                                        # INITIATED             INITIATED
MWAITBIT        =       BIT11

# BIT 10 FLAG 4
NWAITFLG        =       065D            # HIGHER PRIORITY       NO HIGHER PRIORITY
                                        # DISPLAY OPERATING     DISPLAY OPERATING
                                        # WHEN NORMAL           WHEN NORMAL DISPLAY
                                        # DISPLAY INITIATED     INITIATED

NWAITBIT        =       BIT10

# BIT 9 FLAG 4
MRKNVFLG        =       066D            # ASTRONAUT USING       ASTRONAUT NOT USING
                                        # KEYBOARD WHEN MARK    KEYBOARD WHEN MARK
                                        # DISPLAY INITIATED     DISPLAY INITIATED

MRKNVBIT        =       BIT9

# BIT 8 FLAG 4
NRMNVFLG        =       067D            # ASTRONAUT USING       ASTRONAUT NOT USING
                                        # KEYBOARD WHEN         KEYBOARD WHEN
                                        # NORMAL DISPLAY        NORMAL DISPLAY
                                        # INITIATED             INITIATED

NRMNVBIT        =       BIT8

# BIT 7 FLAG 4
PRONVFLG        =       068D            # ASTRONAUT USING       ASTRONAUT NOT USING
                                        # KEYBOARD WHEN         KEYBOARD WHEN
                                        # PRIORITY DISPLAY      PRIORITY DISPLAY
                                        # INITIATED             INITIATED

PRONVBIT        =       BIT7

# BIT 6 FLAG 4
PINBRFLG        =       069D            # ASTRONAUT HAS         ASTRONAUT HAS NOT
                                        # INTERFERED WITH       INTERFERED WITH
                                        # EXISTING DISPLAY      EXISTING DISPLAY

PINBRBIT        =       BIT6

# BIT 5 FLAG 4
MRUPTFLG        =       070D            # MARK DISPLAY          MARK DISPLAY NOT
```

```
                                        # INTERRUPTED BY        INTERRUPTED BY
                                        # PRIORITY DISPLAY      PRIORITY DISPLAY

  MRUPTBIT        =       BIT5
```

Defines:
MRKNVBIT, used in chunks 2070 and 2082.
MRKNVFLG, used in chunks 91, 1985, 2070, and 2082.
MRUPTBIT, used in chunks 2070 and 2084.
MRUPTFLG, used in chunks 91, 2070, and 2084.
MWAITBIT, used in chunks 2070 and 2082.
NRMNVBIT, used in chunks 2070 and 2082.
NRMNVFLG, used in chunks 93, 1987, 2070, and 2082.
NWAITBIT, used in chunks 2070 and 2082.
NWAITFLG, used in chunks 93, 2070, and 2082.
PINBRBIT, used in chunks 2070 and 2084.
PINBRFLG, used in chunks 93, 1985, 1989, 2070, and 2084.
PRONVBIT, used in chunks 2070 and 2084.
PRONVFLG, used in chunks 93, 1987, 2070, and 2082.
Uses PRIORITY 145.

113 ⟨*Page CM0055* 113⟩≡ (75 2684)

```
# BIT 4 FLAG 4
NRUPTFLG        =       071D            # NORMAL DISPLAY        NORMAL DISPLAY NOT
                                        # INTERRUPTED BY        INTERRUPTED BY
                                        # PRIORITY OR MARK      PRIORITY OR MARK
                                        # DISPLAY               DISPLAY

NRUPTBIT        =       BIT4

# BIT 3 FLAG 4
MKOVFLAG        =       072D            # MARK DISPLAY OVER     NO MARK DISPLAY OVER
                                        # NORMAL                NORMAL

MKOVBIT         =       BIT3

# BIT 2 FLAG 4                          # DISPLAY BIT
                =       073D            # CLEARED AT INTERVALS

# BIT 1 FLAG 4
XDSPFLAG        =       074D            # MARK DISPLAY NOT TO   NO SPECIAL MARK
                                        # BE INTERRUPTED        INFORMATION

XDSPBIT         =       BIT1

FLAGWRD5        =       STATE +5        # (075-099)
                                        # (SET)                 (RESET)

# BIT 15 FLAG 5
DSKYFLAG        =       075D            # DISPLAYS SENT TO      NO DISPLAYS TO DSKY
                                        # DSKY
DSKYBIT         =       BIT15

# BIT 14 FLAG 5
RETROFLG        =       076D            # P37 PREMANEUVER       ORBIT NOT RETROGRADE
RETROBIT        =       BIT14           # ORBIT IS RETROGRADE

# BIT 13 FLAG 5
SLOWFLG         =       077D            # P37 TRANSEARTH        SLOW DOWN IS NOT
SLOWBIT         =       BIT13           # COAST SLOW DOWN       DESIRED
                                        # IS DESIRED

# BIT 12 FLAG 5
V59FLAG         =       078D            # CALIBRATING FOR       NORMAL MARKING FOR
                                        # P23                   P23
```

```
V59FLBIT        =       BIT12

# BIT 11 FLAG 5
```

Defines:
DSKYBIT, never used.
DSKYFLAG, used in chunks 89, 2066, and 2084.
FLAGWRD5, used in chunks 89, 253, 307, 319, 423, 647, 732a, 1094, 1945, 2015, 2068, 2084, 2217, 2273, 2275, 2343, 2382, 2447, and 2542.
MKOVBIT, used in chunks 2070 and 2084.
MKOVFLAG, used in chunks 91, 2070, and 2084.
NRUPTBIT, used in chunks 2070 and 2084.
NRUPTFLG, used in chunks 93, 2070, and 2084.
RETROBIT, never used.
RETROFLG, used in chunks 1301 and 2684.
SLOWBIT, never used.
SLOWFLG, used in chunk 1301.
V59FLAG, used in chunks 94, 347, 392, 927, and 929.
V59FLBIT, never used.
XDSPBIT, used in chunks 2074 and 2084.
XDSPFLAG, used in chunks 94, 2074, 2084, and 2114.
Uses DISPLAYS 59, PRIORITY 145, and STATE 138.

115 ⟨*Page CM0056* 115⟩≡ (75 2684)

```
INCORFLG        =       079D            # FIRST INCORPORATION   SECOND INCORPORATION

INCORBIT        =       BIT11

# BIT 10 FLAG 5
RNGSCFLG        =       080D            # ANOTHER TAG FOR PRFTRKAT

# BIT 10 FLAG 5
PRFTRKAT        =       RNGSCFLG        # PREF TRACK ATT        +K AXIS TRACK ATT

PRFTRBIT        =       BIT10

# BIT 9 FLAG 5
DMENFLG         =       081D            # DIMENSION OF W IS 9   DIMENSION OF W IS 6
                                        # FOR INCORPORATION     FOR INCORPORATION

DMENFBIT        =       BIT9

# BIT 8 FLAG 5
COMPUTER        =       082D            # COMPUTER IS CMC       COMPUTER IS LGC

COMPTBIT        =       BIT8

# BIT 7 FLAG 5
ENGONFLG        =       083D            # ENGINE TURNED ON      ENGINE TURNED OFF

ENGONBIT        =       BIT7

# BIT 6 FLAG 5
3AXISFLG        =       084D            # MANEUVER SPECIFIED    MANEUVER SPECIFIED
                                        # BY THREE AXES         BY ONE AXIS

3AXISBIT        =       BIT6

# BIT 5 FLAG 5
GRRBKFLG        =       085D            # BACKUP GRR RECEIVED   BACKUP GRR NOT
                                        #                       RECEIVED

GRRBKBIT        =       BIT5

# BIT 4 FLAG 5
R60FLAG         =       086D            # R61 MUST USE R60      NORMAL R61

R60FLBIT        =       BIT4
```

```
# BIT 3 FLAG 5
SOLNSW          =       087D            # LAMBERT DOES NOT      LAMBERT CONVERGES OR
```

Defines:
3AXISBIT, used in chunks 2074 and 2086.
3AXISFLG, used in chunks 89, 347, 425, 438, 649, 658b, 934, 1011, 1013, 1021, 2074, 2086, and 2148.
COMPTBIT, never used.
COMPUTER, used in chunks 71, 89, 254, 259, 412, 418, 485, 506, 615, 794, 795, 965, 1147, 1195, 1245, 1250, 1252, 1449, 1524, 1661, 1872, 1940b, 2015, 2059, 2061–63, 2143, 2461, and 2478.
DMENFBIT, used in chunks 2066 and 2086.
DMENFLG, used in chunks 947, 981, 989, 991, 1027, 1693, 1695, 1698, 1699, 1701, 1703, 1707, 2066, and 2086.
ENGONBIT, used in chunks 319, 2068, 2086, 2273, 2343, and 2447.
ENGONFLG, used in chunks 91, 347, 1094, 2068, 2086, 2273, and 2343.
GRRBKBIT, used in chunks 423 and 732a.
GRRBKFLG, used in chunks 91 and 436.
INCORBIT, never used.
INCORFLG, used in chunks 91, 943, 945, 947, 949, 991, and 993.
PRFTRBIT, never used.
PRFTRKAT, used in chunks 93, 440, 915, 975, and 1147.
R60FLAG, used in chunks 93 and 915.
R60FLBIT, never used.
RNGSCFLG, used in chunks 1013, 1014, 2072, 2086, and 2382.
SOLNSW, used in chunks 93, 1717, 1718, 1723, 1724, 1758, 1759, 1762, 1769, 2072, and 2087.
Uses W 183.

117 ⟨*Page CM0057* 117⟩≡ (75 2684)

```
                                        # CONVERGE, OR TIME-    TIME-RADIUS NON
                                        # RADIUS NEARLY CIRC.   CIRCULAR.
SOLNSBIT        =       BIT3

# BIT 2 FLAG 5
MGLVFLAG        =       088D            # LOCAL VERTICAL        MIDDLE GIMBAL ANGLE
                                        # COORDINATES           COMPUTED
                                        # COMPUTED

MGLVFBIT        =       BIT2

# BIT 1 FLAG 5
RENDWFLG        =       089D            # W MATRIX VALID        W MATRIX INVALID
                                        # FOR RENDEZVOUS        FOR RENDEZVOUS
                                        # NAVIGATION            NAVIGATION

RENDWBIT        =       BIT1

FLAGWRD6        =       STATE +6        # (090-104)
                                        # (SET)                 (RESET)

# BIT 15 FLAG 6
DAPBIT1         =       090D            # 1 SATURN 1 TVC        0 RCS   0 NO

DAP1BIT         =       BIT15

# BIT 14 FLAG 6
DAPBIT2         =       091D            # 1 A/P    0 A/P        1 A/P   0 A/P

DAP2BIT         =       BIT14

# BIT 13 FLAG 6
STRULLSW        =       092D            # DO STEERULL           DO ULAGEOFF ONLY

STRULBIT        =       BIT13

# BIT 13 FLAG 6
ENTRYDSP        =       STRULLSW        # DO ENTRY DISPLAY      OMIT ENTRY DISPLAY
                                        # VIA ENTRYVN.

ENDSPBIT        =       BIT13

# BIT 12 FLAG 6
CMDAPARM        =       093D            # ALLOW ENTRY FIRINGS   INHIBIT ENTRY FIRING
                                        # AND CALCULATIONS      AND CONTROL FUNCTION
```

Defines:
CMDAPARM, used in chunks 89, 1486, 1487, and 1492.
DAP1BIT, never used.
DAP2BIT, never used.
DAPBIT1, used in chunks 89, 1094, and 1485.
DAPBIT2, used in chunks 89, 1094, and 1485.
ENDSPBIT, never used.
ENTRYDSP, used in chunks 1200, 1250, 1256, and 1487.
FLAGWRD6, used in chunks 89, 319, 321, 335, 424, 426, 437, 876, 890, 1094, 1347, 1356, 1367, 1373, 1451, 2068, 2087, 2311, and 2382.
MGLVFBIT, used in chunks 2070 and 2087.
MGLVFLAG, used in chunks 91, 794, 795, 2070, and 2087.
RENDWBIT, used in chunks 2072 and 2087.
RENDWFLG, used in chunks 93, 360, 407, 438, 917, 919, 943, 945, 979, 1015, 1023, 1041, 1804, 1812, 1814, 2072, 2087, and 2359.
SOLNSBIT, used in chunks 2072 and 2087.
STRULBIT, never used.
STRULLSW, used in chunks 93, 347, and 1094.
Uses A 80, ENTRYVN 161, P 188, STATE 138, and W 183.

119 ⟨*Page CM0058* 119⟩≡ (75 2684)

```
CMDARMBIT       =       BIT12

# BIT 11 FLAG 6
GAMDIFSW        =       094D            # CALCULATE GAMDOT      GAMDOT NOT TO BE
                                        #                       CALCULATED

GMDIFBIT        =       BIT11

# BIT 10 FLAG 6
GONEPAST        =       095D            # LATERAL CONTROL       LATERAL CONTROL
                                        # CALCULATIONS TO BE    CALCULATIONS TO BE
                                        # OMITTED               DONE

GONEBIT         =       BIT10

# BIT 9 FLAG 6
RELVELSW        =       096D            # TARGETING USES        TARGETING USES
                                        # EARTH-RELATIVE        INERTIAL VELOCITY
                                        # VELOCITY.

RELVBIT         =       BIT9

# BIT 8 FLAG 6
EGSW            =       097D            # IN FINAL PHASE        NOT IN FINAL PHASE

EGFLGBIT        =       BIT8

# BIT 8 FLAG 6
KNOWNFLG        =       EGSW            # LANDMARK KNOWN        LANDMARK UNKNOWN

KNOWNBIT        =       BIT8

# BIT 8 FLAG 6
R57FLAG         =       KNOWNFLG        # DO NOT DO R57         DO R57, TRUNION
                                        # TRUNION BIAS HAS      BIAS NEEDED
                                        # BEEN OBTAINED.

R57BIT          =       BIT8

# BIT 7 FLAG 6
NOSWITCH        =       098D            # LATERAL ROLL          LATERAL ROLL MANEUVER
                                        # MANEUVER INHIBITED    PERMITTED IN ENTRY
                                        # IN ENTRY

NOSWBIT         =       BIT7
```

```
# BIT 6 FLAG 6
HIND            =       099D            # ITERATING HUNTEST     ITERATING OF HUNTEST
                                        # CALCULATIONS TO BE    CALCULATIONS TO BE
                                        # DONE AFTER RANGE      OMITTED AFTER RANGE
                                        # PREDICTION            PREDICTION
```

Defines:
CMDARMBIT, never used.
EGFLGBIT, never used.
EGSW, used in chunks 89, 91, 93, 1250, and 1256.
GAMDIFSW, used in chunks 91, 1200, 1297, 1485, and 1487.
GMDIFBIT, never used.
GONEBIT, never used.
GONEPAST, used in chunks 91, 1250, 1256, and 1852.
HIND, used in chunks 91, 1250, and 1256.
KNOWNBIT, never used.
KNOWNFLG, used in chunks 91, 93, 921, 925, and 981.
NOSWBIT, never used.
NOSWITCH, used in chunks 93 and 1256.
R57BIT, never used.
R57FLAG, used in chunks 89, 91, 93, 1015, and 1021.
RELVBIT, never used.
RELVELSW, used in chunks 93, 1250, and 1256.
Uses BIAS 211, GAMDOT 216, LANDMARK 190, RANGE 179, and TRUNION 190.

121 ⟨*Page CM0059* 121⟩≡ (75 2684)

```
HINDBIT         =       BIT6

# BIT 5 FLAG 6
INRLSW          =       100D            # INITIAL ROLL          INITIAL ROLL
                                        # V(LV)                 V(LV)

INRLBIT         =       BIT5

                                        # ATTITUDE NOT HELD     ATTITUDE HELD

# BIT 4 FLAG 6
LATSW           =       101D            # DOWNLIFT NOT          DOWNLIFT INHIBITED
                                        # INHIBITED

LATSWBIT        =       BIT4

# BIT 3 FLAG 6
.05GSW          =       102D            # DRAG OVER .05G        DRAG LESS THAN .05G

.05GBIT         =       BIT3

# BIT 3 FLAG 6
                =       102D

# BIT 2 FLAG 6
CM/DSTBY        =       103D            # ENTRY DAP ACTIVATED   ENTRY DAP NOT
                                        #                       ACTIVATED

CM/DSBIT        =       BIT2

# BIT 1 FLAG 6
GYMDIFSW        =       104D            # CDU DIFFERENCES AND   CDU DIFFERENCES AND
                                        # BODY RATES COMPUTED   BODY RATES NOT
                                        #                       COMPUTED

GYMDIBIT        =       BIT1

FLAGWRD7        =       STATE +7        # (105-119)
                                        # (SET)                 (RESET)

# BIT 15 FLAG 7
TERMIFLG        =       105D            # TERMINATE R52         DO NOT TERMINATE R52

TERMIBIT        =       BIT15
```

```
# BIT 14 FLAG 7
ITSWICH         =       106D            # ACCEPT NEXT LAMBERT   TEST LAMBERT ANSWER
                                        # TPI SEARCH SOLUTION   AGAINST LIMITS
```

Defines:
- `.05GBIT`, never used.
- `.05GSW`, used in chunks 91, 1250, 1256, 1487, and 1495.
- `CM/DSBIT`, never used.
- `CM/DSTBY`, used in chunks 89, 1200, 1227, 1481, 1483, 1487, 1488, and 1518.
- `FLAGWRD7`, used in chunks 89, 339, 1094, 1227, 1946, 1947, 2011, 2015, 2068, 2091, 2273, 2275, 2277, 2291, 2343, 2382, and 2420.
- `GYMDIBIT`, never used.
- `GYMDIFSW`, used in chunks 91, 1481, 1483, and 1487.
- `HINDBIT`, never used.
- `INRLBIT`, never used.
- `INRLSW`, used in chunks 91, 1250, and 1256.
- `ITSWICH`, used in chunks 91, 756, 758, 763, 899, 903, 1063, 2068, 2091, and 2223.
- `LATSW`, used in chunks 91, 1250, 1256, 1487, 1488, and 1504.
- `LATSWBIT`, never used.
- `TERMIBIT`, never used.
- `TERMIFLG`, used in chunks 94 and 1147.

Uses `LV` 85, `STATE` 138, and `V` 229.

123 ⟨*Page CM0060* 123⟩≡ (75 2684)

```
ITSWBIT         =       BIT14

# BIT 13 FLAG 7
IGNFLAG         =       107D            # TIG HAS ARRIVED       TIG HAS NOT ARRIVED

IGNFLBIT        =       BIT13

# BIT 12 FLAG 7
ASTNFLAG        =       108D            # ASTRONAUT HAS         ASTRONAUT HAS NOT
                                        # OKAYED IGNITION       OKAYED IGNITION

ASTNBIT         =       BIT12

# BIT 11 FLAG 7
TIMRFLAG        =       109D            # CLOKTASK OPERATING    CLOKTASK INOPERATIVE

TIMRBIT         =       BIT11

# BIT 10 FLAG 7
NORMSW          =       110D            # UNIT NORMAL INPUT     LAMBERT COMPUTE ITS
                                        # TO LAMBERT.           OWN UNIT NORMAL.

NORMSBIT        =       BIT10

# BIT 9 FLAG 7
RVSW            =       111D            # DO NOT COMPUTE FINAL  COMPUTE FINAL STATE
                                        # STATE VECTOR IN       VECTOR IN TIME-THETA
                                        # TIME-THETA

RVSWBIT         =       BIT9

# BIT 8 FLAG 7
GONEBY          =       112D            # PASSED TARGET         APPROACHING TARGET

GONBYBIT        =       BIT8

# BIT 7 FLAG 7
                =       113D

# BIT 6 FLAG 7
V37FLAG         =       114D            # AVERAGEG (SERVICER)   AVERAGEG (SERVICER)
                                        # RUNNING               OFF

V37FLBIT        =       BIT6
```

```
# BIT 5 FLAG 7
                    =        115D
```

Defines:
ASTNBIT, used in chunks 2066, 2091, and 2273.
ASTNFLAG, used in chunks 89, 1094, 2066, 2091, 2271, 2273, 2277, and 2289.
GONBYBIT, never used.
GONEBY, used in chunks 91, 1250, and 1256.
IGNFLAG, used in chunks 91, 1094, 2068, 2091, 2271, 2273, and 2277.
IGNFLBIT, used in chunks 2068, 2091, 2273, and 2291.
ITSWBIT, used in chunks 2068 and 2091.
NORMSBIT, used in chunks 2070 and 2091.
NORMSW, used in chunks 93, 788, 1047, 1094, 1301, 1717, 1721, 1724, 1726, 1743, 1745, 1767, 2070, and 2091.
RVSW, used in chunks 93, 758, 854, 897, 1063, 1301, 1719, 1720, 1723, 1724, 1743, 1769, 2072, 2091, and 2223.
RVSWBIT, used in chunks 2072 and 2091.
TIMRBIT, never used.
TIMRFLAG, used in chunks 94, 1043, and 1094.
V37FLAG, used in chunks 94, 814, 1056, 1227, 2074, 2092, and 2382.
V37FLBIT, used in chunks 339, 2011, 2074, and 2092.
Uses STATE 138, THETA 148, and TIG 224.

125 ⟨*Page CM0061* 125⟩≡ (75 2684)

```
                =       BIT5

# BIT 4 FLAG 7
UPLOCKFL        =       116D            # K-KBAR-K FAIL         NO K-KBAR-K FAIL

UPLOCBIT        =       BIT4

# BIT 3 FLAG 7
VERIFLAG        =       117D            # CHANGED WHEN V33E OCCURS AT END OF P27

VERIFBIT        =       BIT3

# BIT 2 FLAG 7
ATTCHFLG        =       118D            # LM,CM ATTACHED        LM,CM NOT ATTACHED

ATTCHBIT        =       BIT2

# BIT 1 FLAG 7
TFFSW           =       119D            # CALCULATE TPERIGEE    CALCULATE TFF

TFFSWBIT        =       BIT1

FLAGWRD8        =       STATE +8D       # (120-134)
                                        # (SET)                 (RESET)

# BIT 15 FLAG 8
RPQFLAG         =       120D            # RPQ NOT COMPUTED      RPQ COMPUTED

RPQFLBIT        =       BIT15

# BIT 14 FLAG 8
                =       121D

# BIT 13 FLAG 8
NEWIFLG         =       122D            # FIRST PASS THROUGH    SUCCEEDING ITERATION
                                        # INTEGRATION           OF INTEGRATION

NEWIBIT         =       BIT13

# BIT 12 FLAG 8
CMOONFLG        =       123D            # PERMANENT CSM STATE   PERMANENT CSM STATE
                                        # IN LUNAR SPHERE       IN EARTH SPHERE

CMOONBIT        =       BIT12
```

```
# BIT 11 FLAG 8
LMOONFLG        =       124D            # PERMANENT LM STATE    PERMANENT LM STATE
                                        # IN LUNAR SPHERE       IN EARTH SPHERE

LMOONBIT        =       BIT11
```

Defines:
ATTCHBIT, never used.
ATTCHFLG, used in chunk 89.
CMOONBIT, used in chunks 2066 and 2094.
CMOONFLG, used in chunks 71, 89, 315, 775, 796, 820, 919, 959, 979, 983, 985, 995, 997, 999, 1024, 1027, 1035, 1063, 1776, 1784, 1804, 1805, 2066, 2094, and 2223.
FLAGWRD8, used in chunks 89, 315, 2068, 2092, 2139, 2275, 2311, 2371, and 2382.
LMOONBIT, used in chunks 2068 and 2094.
LMOONFLG, used in chunks 73, 91, 315, 959, 1776, 1786, 2068, and 2094.
NEWIBIT, used in chunks 2070 and 2094.
NEWIFLG, used in chunks 91, 1792, 1794, 1800, 2070, and 2094.
RPQFLAG, used in chunks 93, 1792, 1794, 1814, 2072, and 2092.
RPQFLBIT, used in chunks 2072 and 2092.
TFFSW, used in chunks 94, 1852, 2072, and 2092.
TFFSWBIT, used in chunks 2072 and 2092.
UPLOCBIT, used in chunks 2072 and 2092.
UPLOCKFL, used in chunks 94, 1946, 2072, and 2092.
VERIFBIT, used in chunks 2072 and 2092.
VERIFLAG, used in chunks 94, 2015, 2072, and 2092.
Uses STATE 138 and TFF 179.

127 ⟨*Page CM0062* 127⟩≡ (75 2684)

```
# BIT 10 FLAG 8
ADVTRK          =       125D            # ADVANCE GROUND TRACK  NOT ADVANCED
                                        # SIGHTING WANTED       GROUND TRACK

ADVTKBIT        =       BIT10

# BIT 9 FLAG 8
P39/79SW        =       126D            # P39/79 OPERATING      P38/78 OPERATING

P39SWBIT        =       BIT9

# BIT 8 FLAG 8
SURFFLAG        =       127D            # LM ON LUNAR SURFACE   LM NOT ON LUNAR
                                        #                       SURFACE

SURFFBIT        =       BIT8

# BIT 7 FLAG 8
INFINFLG        =       128D            # NO CONIC SOLUTION     CONIC SOLUTION
                                        # (CLOSURE THROUGH      EXISTS.
                                        # INFINITY REQUIRED).

INFINBIT        =       BIT7

# BIT 6 FLAG 8
ORDERSW         =       129D            # ITERATOR USES 2ND     ITERATOR USES 1ST
                                        # ORDER MINIMUM MODE    ORDER STANDARD MODE

ORDERBIT        =       BIT6

# BIT 5 FLAG 8
APSESW          =       130D            # RDESIRED OUTSIDE      RDESIRED INSIDE
                                        # PERICENTER-APOCENTER  PERICENTER-APOCENTER
                                        # RANGE IN TIME-RAD     RANGE IN TIME-RADIUS

APSESBIT        =       BIT5

# BIT 4 FLAG 8
COGAFLAG        =       131D            # NO CONIC SOLUTION     CONIC SOLUTION
                                        # TOO CLOSE TO          EXISTS (COGA DOES
                                        # RECTILINEAR (COGA     NOT OVERFLOW).
                                        # OVERFLOWS).
COGAFBIT        =       BIT4
```

Defines:
ADVTKBIT, never used.
ADVTRK, used in chunks 89 and 1147.
APSESBIT, used in chunks 2066 and 2094.
APSESW, used in chunks 89, 1722, 1723, 1760, 1762, 1769, 2066, and 2094.
COGAFBIT, used in chunks 2066 and 2096.
COGAFLAG, used in chunks 89, 1720, 1723, 1743, 1769, 2066, and 2094.
INFINBIT, used in chunks 2068 and 2094.
INFINFLG, used in chunks 91, 1718, 1720, 1723, 1743, 1748, 1751, 1756, 1769, 2068, and 2094.
ORDERBIT, used in chunks 2070 and 2094.
ORDERSW, used in chunks 93, 1718, 1739, 1740, 1769, 2070, and 2094.
P39/79SW, used in chunks 93, 846, 850, 852, 2070, and 2094.
P39SWBIT, used in chunks 2070 and 2094.
SURFFBIT, used in chunks 2072, 2094, and 2382.
SURFFLAG, used in chunks 93, 360, 448, 814, 816, 1776, 1786, 1805, 2072, 2094, 2132, 2139, 2299, and 2359.
Uses MODE 145, RAD 219, RANGE 179, and RDESIRED 188.

129 ⟨*Page CM0063* 129⟩≡ (75 2684)

```
# BIT 3 FLAG 8
V96ONFLG        =       132D            # P00 INTEGRATION HAS   P00 INTEGRATION IS
                                        # BEEN INHIBITED BY     PROCEEDING REGULARLY
                                        # V96

# BIT 2 FLAG 8
                =       133D

# BIT 1 FLAG 8
360SW           =       134D            # TRANSFER ANGLE NEAR   TRANSFER ANGLE NOT
                                        # 360 DEGREES           NEAR 360 DEGREES

360SWBIT        =       BIT1

FLAGWRD9        =       STATE +9D       # (135-149)
                                        # (SET)                 (RESET)

# BIT 15 FLAG 9
SWTOVER         =       135D            # SWITCHOVER HAS        NO SWITCHOVER YET
                                        # OCCURRED.

SWTOVBIT        =       BIT15

# BIT 14 FLAG 9
                =       136D

V67FLBIT        =       BIT14

# BIT 13 FLAG 9
V82EMFLG        =       137D            # MOON VICINITY         EARTH VICINITY

V82EMBIT        =       BIT13

# BIT 12 FLAG 9
MAXDBFLG        =       138D            # MAX DB SELECTED       MIN DB SELECTED

MAXDBBIT        =       BIT12

# BIT 11 FLAG 9
V94FLAG         =       139D            # V94 ALLOWED DURING    V94 NOT ALLOWED
                                        # P23

V94FLBIT        =       BIT11
```

```
# BIT 10 FLAG 9
SAVECFLG        =       140D            # P23 DISPLAY AND       P23 DISPLAY AND
                                        # DATA STORAGE AFTER    DATA STORAGE BEFORE
```

Uses STATE 138.

131 ⟨*Page CM0064* 131⟩≡ (75 2684)

```
                                        # MARK IS DONE          MARK IS DONE

SAVECBIT        =       BIT10

# BIT 9 FLAG 9
VHFRFLAG        =       141D            # ALLOW R22 TO          STOP ACCEPTANCE
                                        # ACCEPT RANGE          OF RANGE DATA
                                        # DATA

VHFRBIT         =       BIT9

# BIT 8 FLAG 9
SOURCFLG        =       142D            # SOURCE OF INPUT       SOURCE OF INPUT
                                        # DATA IS FROM          DATA IS FROM
                                        # VHF RADAR             OPTICS MARK

SOURCBIT        =       BIT8

# BIT 7 FLAG 9
R22CAFLG        =       143D            # R-22 CALCULATIONS     R-22 CALCULATIONS
                                        # ARE GOING ON          ARE NOT GOING ON

R22CABIT        =       BIT7

# BIT 6 FLAG 9
N22ORN17        =       144D            # COMPUTE TOTAL         COMPUTE TOTAL
                                        # ATTITUDE ERRORS       ATTITUDE ERRORS
                                        # W.R.T. N22 (V62)      W.R.T. N17 (V63)

N2217BIT        =       BIT6

# BIT 5 FLAG 9
QUITFLAG        =       145D            # TERMINATE AND EXIT    CONTINUE INTEGRATION
QUITBIT         =       BIT5            # FROM INTEGRATION

# BIT 4 FLAG 9
R31FLAG         =       146D            # R31 SELECTED (V63)    R34 SELECTED (V65)

R31FLBIT        =       BIT4

# BIT 3 FLAG 9
MID1FLAG        =       147D            # INTEGRATE TO TDEC     INTEGRATE TO THE
                                        #                       THEN-PRESENT TIME

MID1FBIT        =       BIT3
```

```
# BIT 2 FLAG 9
MIDAVFLG        =       148D            # INTEGRATION ENTERED   INTEGRATION WAS
                                        # FROM ONE OF MIDTOAV   NOT ENTERED VIA
                                        # PORTALS               MIDTOAV
```

Defines:
MID1FBIT, used in chunk 2098.
MID1FLAG, used in chunks 91, 1806, 1808, 1810, 2070, and 2098.
MIDAVFLG, used in chunks 91, 1796, 1808, 1814, 2070, and 2098.
N2217BIT, never used.
N22ORN17, used in chunks 91, 416, 417, and 1412.
QUITBIT, used in chunks 2070 and 2098.
QUITFLAG, used in chunks 93, 407, 446, 1780, 1782, 1798, 2070, and 2098.
R22CABIT, never used.
R22CAFLG, used in chunk 93.
R31FLAG, used in chunks 93, 810, and 812.
R31FLBIT, used in chunks 430, 431, and 2684.
SAVECBIT, never used.
SOURCBIT, used in chunk 951.
SOURCFLG, used in chunks 93, 941, 945, 947, 949, 953, and 957.
VHFRBIT, never used.
VHFRFLAG, used in chunks 94, 341, 442, and 943.
Uses R31 67, R34 67, RANGE 179, TDEC 157, and W 183.

133 ⟨*Page CM0065* 133⟩≡ (75 2684)

```
MIDAVBIT        =       BIT2

# BIT 1 FLAG 9
AVEMIDSW        =       149D            # AVETOMID CALLING      NO AVETOMID W INTEGER
                                        # FOR W MATRIX INTEGR   ALLOW SET UP RN,VN,
                                        # DON'T WRITE OVER RN,  PIPTIME
                                        # VN,PIPTIME

AVEMDBIT        =       BIT1

FLGWRD10        =       STATE   +10D    # (150-164)
                                        # (SET)                 (RESET)

RASFLAG         =       STATE   +10D

# BIT 15 FLAG 10
                =       150D

# BIT 14 FLAG 10
INTFLAG         =       151D            # INTEGRATION IN        INTEGRATION NOT IN
                                        # PROGRESS              PROGRESS

INTFLBIT        =       BIT14

# BIT 13 FLAG 10
                =       152D

# BIT 12 FLAG 10
                =       153D

# BIT 11 FLAG 10
                =       154D

# BIT 10 FLAG 10
                =       155D

# BIT 9 FLAG 10
                =       156D

# BIT 8 FLAG 10
                =       157D
```

Defines:
AVEMDBIT, used in chunks 2066 and 2098.
AVEMIDSW, used in chunks 89, 485, 1796, 1805, 2066, 2098, and 2143.

FLGWRD10, used in chunks 2068, 2070, 2098, 2100, 2269, 2293, 2343, 2382, 2542, and 2590.
INTFLAG, used in chunks 91, 2068, and 2100.
INTFLBIT, used in chunks 319, 1802, 2068, and 2100.
MIDAVBIT, used in chunks 2070 and 2098.
RASFLAG, used in chunks 319, 321, 820, 1800, 1802, 2070, and 2098.
Uses PIPTIME 159, RN 159, STATE 138, VN 159, and W 183.

135 ⟨*Page CM0066* 135⟩≡ (75 2684)

```
# BIT 7 FLAG 10
REINTFLG        =       158D            # INTEGRATION ROUTINE   INTEGRATION ROUTINE
                                        # TO BE RESTARTED       NOT TO BE RESTARTED
REINTBIT        =       BIT7

# BIT 6 FLAG 10
                =       159D

# BIT 5 FLAG 10
                =       160D

# BIT 4 FLAG 10
                =       161D

# BIT 3 FLAG 10
                =       162D

# BIT 2 FLAG 10
                =       163D

# BIT 1 FLAG 10
                =       164D

FLGWRD11        =       STATE   +11D    # (165-179)
                                        # (SET)                 (RESET)

# BIT 15 FLAG 11
S32.1F1         =       165D            # DELTAN AT CSI TIME    DVT1 LESS THAN MAX
S32BIT1         =       BIT15           # ONE EXCEEDS MAX

# BIT 14 FLAG 11
S32.1F2         =       166D            # FIRST PASS OF         REITERATION OF
S32BIT2         =       BIT14           # NEWTON INTEGRATION    NEWTON

# BIT 13 FLAG 11
S32.1F3A        =       167D            # BIT 13 AND BIT 12 FUNCTION AS AN ORDERED
S32BIT3A        =       BIT13           # PAIR (13,12) INDICATING THE POSSIBLE OC-
                                        # CURRENCE OF 2NEWTON ITERATIONS FOR S32.1
# BIT 12 FLAG 11                        # IN THE PROGRAM IN THE FOLLOWING ORDER:
S32.1F3B        =       168D            # (0,1) (I.E. BIT 13 RESET, BIT 12 SET)
```

Defines:
FLGWRD11, used in chunks 2068, 2102, 2343, and 2382.
REINTBIT, used in chunks 1802, 2072, and 2100.
REINTFLG, used in chunks 93, 823, 1701, 1794, 1814, 2013, 2015, 2072, and 2100.

S32.1F1, used in chunks 1063, 2072, 2087, and 2223.
S32.1F2, used in chunks 1063, 2072, 2087, and 2223.
S32.1F3A, used in chunks 1063, 2072, 2087, and 2223.
S32.1F3B, used in chunks 1063, 2072, 2087, and 2223.
S32BIT1, used in chunks 2072 and 2087.
S32BIT2, used in chunks 2072 and 2087.
S32BIT3A, used in chunks 2072 and 2087.
Uses I 206 and STATE 138.

137 ⟨*Page CM0067* 137⟩≡ (75 2684)

```
S3229T3B        =       BIT12           #       = FIRST NEWTON ITERATION BEING DONE
                                        # (0,0)= FIRST PASS OF 2ND NEWTON ITER.
                                        # (1,1)= 50 FPS STAGE OF 2ND NEWT ITER.
                                        # (1,0)= REMAINDER OF 2ND NEWT ITER.

# BIT 11 FLAG 11
                =       169D

# BIT 10 FLAG 11
                =       170D

# BIT 9 FLAG 11
                =       171D

# BIT 8 FLAG 11
                =       172D

# BIT 7 FLAG 11
                =       173D

# BIT 6 FLAG 11
                =       174D

# BIT 5 FLAG 11
                =       175D

# BIT 4 FLAG 11
                =       176D

# BIT 3 FLAG 11
                =       177D

# BIT 2 FLAG 11
                =       178D

# BIT 1 FLAG 11
                =       179D
```

Defines:
S3229T3B, never used.

138 ⟨*Page CM0068* 138⟩≡ (75 2684)

```
# GENERAL ERASABLE ASSIGNMENTS

                SETLOC  61
# INTERRUPT TEMPORARY STORAGE POOL.     (11D)

# (ITEMP1 THROUGH RUPTREG4)

# ANY OF THESE MAY BE USED AS TEMPORARIES DURING INTERRUPT OR WITH INTERRUPT INHIBITE
# IS USED DURING CALLS TO THE EXECUTIVE AND WAITLIST -- THE RUPTREGS ARE NOT.

ITEMP1          ERASE
WAITEXIT        EQUALS  ITEMP1
EXECTEM1        EQUALS  ITEMP1

ITEMP2          ERASE
WAITBANK        EQUALS  ITEMP2
EXECTEM2        EQUALS  ITEMP2

ITEMP3          ERASE
RUPTSTOR        EQUALS  ITEMP3
WAITADR         EQUALS  ITEMP3
NEWPRIO         EQUALS  ITEMP3

ITEMP4          ERASE
LOCCTR          EQUALS  ITEMP4
WAITTEMP        EQUALS  ITEMP4

ITEMP5          ERASE
NEWLOC          EQUALS  ITEMP5

ITEMP6          ERASE
NEWLOC+1        EQUALS  ITEMP6          # DP ADDRESS.

                SETLOC  67
NEWJOB          ERASE                   # MUST BE AT LOC 67 DUE TO WIRING.

RUPTREG1        ERASE
RUPTREG2        ERASE
RUPTREG3        ERASE
RUPTREG4        ERASE
KEYTEMP1        EQUALS  RUPTREG4
DSRUPTEM        EQUALS  RUPTREG4

# FLAGWORD RESERVATIONS.                (12D)
```

```
STATE           ERASE   +11D

# PAD LOAD FOR DAPS
EMDOT           ERASE                   # I(1)PL (SPS FLOW RATE, SC AT B+3 KG/CS)
```

Defines:
DSRUPTEM, used in chunk 253.
EMDOT, used in chunks 1094, 1301, 1347, and 2684.
EXECTEM1, used in chunks 1649, 1651, 1652, and 1657.
EXECTEM2, used in chunks 1652, 1653, and 1657.
ITEMP1, used in chunks 290, 292, 349, 351, 390, 394, 396, 397, 965, 1227, 1844, 1900, 1920–22, 1927, 1930–33, 2001, 2007, 2009, 2134, 2139, 2295, 2297, 2382, 2428, 2430, 2509, 2512, 2513, and 2519.
ITEMP2, used in chunks 349, 351, 394, 1227, 1844, 1900, 1931, 1932, 2001, 2295, 2297, 2428, 2430, and 2574.
ITEMP3, used in chunks 1900, 2001, 2134, 2139, 2297, 2428, 2430, and 2574.
ITEMP4, used in chunks 1900, 1930, 1931, 1933b, 2134, 2139, 2295, 2297, and 2430.
ITEMP5, used in chunks 1900, 2134, 2139, 2426, 2428, 2432, 2434, 2436, and 2438.
ITEMP6, used in chunks 279, 1900, 2432, 2434, and 2574.
KEYTEMP1, used in chunks 249, 1945, and 1946.
LOCCTR, used in chunks 629, 694, 1652, 1653, 1657, 1802, 1935, 1945, 1961, 1977, 1981, and 1989.
NEWJOB, used in chunks 327, 351, 704, 835, 1256, 1547, 1653–56, 1660, 1661, 1878, 1888, 1889, 2197, 2484, 2494, 2495a, 2590, and 2623.
NEWLOC, used in chunks 351, 1649, 1651, 1653, and 1657.
NEWLOC+1, never used.
NEWPRIO, used in chunks 345, 351, 690, 1649, 1651–53, 1657, 1658, and 1977.
RUPTREG1, used in chunks 251, 255, 257, 258, 265, 266, 281, 382, 384, 390, 1227, 1891, 1900, 1930, 1931, 1933b, 2001, 2136, 2139, 2311, 2420, 2428, 2430, 2432, 2500, and 2502.
RUPTREG2, used in chunks 258, 266, 269, 390, 1900, 1930, 1931, 1933b, 1935–37, 1995, 2139, 2311, 2502, 2503a, and 2574.
RUPTREG3, used in chunks 388, 390, 402, 694, 1542, 1900, 1935, 1959, 1977, 1979, 2311, 2434, 2436, 2438, and 2574.
RUPTREG4, used in chunks 390, 1542, 1900, 1945, and 1959.
RUPTSTOR, used in chunks 388, 390, and 402.
STATE, used in chunks 28, 29, 32, 54, 56a, 89, 95, 97, 99, 101, 105, 107, 109, 113, 117, 121, 123, 125, 129, 133, 135, 159, 169, 172, 241, 254, 257, 263–65, 268, 270, 274, 294, 295, 297, 298, 300, 302, 304, 311, 313, 315, 317, 359, 360, 390, 392, 396, 405, 407, 428, 430, 436, 438, 442, 444, 456, 485, 613, 625, 627, 682, 753, 760, 784, 802, 810, 814, 820, 825, 827, 829, 831, 835, 837, 893, 909, 915, 917, 918, 937, 941, 949, 959, 961, 973, 977, 1011, 1015, 1023, 1048, 1063, 1094, 1147, 1200, 1227, 1250, 1256, 1301, 1396, 1557, 1635, 1636, 1693, 1699, 1703, 1705, 1707, 1713, 1719, 1720, 1722, 1723, 1725, 1772, 1774, 1778, 1780, 1788, 1796, 1804, 1806, 1812, 1814, 1852, 1937, 1939, 2001, 2015, 2068, 2074–76, 2078, 2080, 2081, 2084, 2087, 2091, 2092, 2094, 2096, 2100, 2102, 2104, 2106, 2108, 2112, 2114, 2143, 2148, 2154, 2156, 2164, 2165, 2219, 2223, 2256, 2299, 2311, 2353, 2382, 2519, 2561, 2590, and 2625.
WAITADR, used in chunk 1663.
WAITBANK, used in chunk 1663.
WAITEXIT, used in chunks 515, 1663, and 2001.
WAITTEMP, used in chunk 1663.
Uses I 206 and LOC 145.

140 ⟨*Page CM0069* 140⟩≡ (75 2684)

```
# EXIT FOR V83
STATEXIT        ERASE                   # I(1) STQ ADDRESS FOR STATEXIT

# UNUSED ERASABLES ********(2)
ERASFILL        ERASE   +1

# EXEC TEMPORARIES WHICH MAY BE USED BETWEEN CCS NEWJOBS
# (INTB15+ THROUGH RUPTMXTM)            (32D)
INTB15+         ERASE                   # REFLECTS 15TH BIT OF INDEXABLE ADDRESSES
DSEXIT          EQUALS  INTB15+         # RETURN FOR DSPIN
EXITEM          EQUALS  INTB15+         # RETURN FOR SCALE FACTOR ROUTINE SELECT
BLANKRET        EQUALS  INTB15+         # RETURN FOR 2BLANK

INTBIT15        ERASE                   # SIMILAR TO ABOVE.
WRDRET          EQUALS  INTBIT15        # RETURN FOR 5BLANK.
WDRET           EQUALS  INTBIT15        # RETURN FOR DSPWD
DECRET          EQUALS  INTBIT15        # RETURN FOR PUTCOM(DEC LOAD)
21/22REG        EQUALS  INTBIT15        # TEMP FOR CHARIN

# THE REGISTERS BETWEEN ADDRWD AND PRIORITY MUST STAY IN THE FOLLOWING ORDER FOR INTE

ADDRWD          ERASE                   # 12 BIT INTERPRETIVE OPERAND SUB-ADDRESS.
POLISH          ERASE                   # HOLDS CADR MADE FROM POLISH ADDRESSE.
UPDATRET        EQUALS  POLISH          # RETURN FOR UPDATNN, UPDATVB
CHAR            EQUALS  POLISH          # TEMP FOR CHARIN
ERCNT           EQUALS  POLISH          # COUNTER FOR ERROR LIGHT RESET
DECOUNT         EQUALS  POLISH          # COUNTER FOR SCALING AND DISPLAY (DEC)

FIXLOC          ERASE                   # WORK AREA ADDRESS
OVFIND          ERASE                   # SET NON-ZERO ON OVERFLOW.

VBUF            ERASE   +5              # TEMPORARY STORAGE USED FOR VECTORS.
SGNON           EQUALS  VBUF            # TEMP FOR +,- ON
NOUNTEM         EQUALS  VBUF            # COUNTER FOR MIXNOUN FETCH
DISTEM          EQUALS  VBUF            # COUNTER FOR OCTAL DISPLAY VERB
DECTEM          EQUALS  VBUF            # COUNTER FOR FETCH (DEC DISPLAY VERBS)

SGNOFF          EQUALS  VBUF +1         # TEMP FOR +,- ON
NVTEMP          EQUALS  VBUF +1         # TEMP FOR NVSUB
SFTEMP1         EQUALS  VBUF +1         # STORAGE FOR SF CONST HI PART (=SFTEMP2-1)
HITEMIN         EQUALS  VBUF +1         # TEMP FOR LOAD OF HRS,MIN,SEC
                                        # MUST = LOTEMIN-1.

CODE            EQUALS  VBUF +2         # FOR DSPIN
```

```
SFTEMP2          EQUALS  VBUF +2          # STORAGE FOR SF CONST LO PART (=SFTEMP1+1)
LOTEMIN          EQUALS  VBUF +2          # TEMP FOR LOAD OF HRS,MIN,SEC
```

Defines:

21/22REG, used in chunks 519, 613, and 644.
ADDRWD, used in chunks 515, 1546, 1548–50, 1552, 1556, 1558, 1559, 1561–63, 1565, 1566, 1568, 1570–72, 1574, 1575, 1579, 1581, 1582, 1585–87, 1594, 1596, 1597, 1616, 1844, and 2455.
BLANKRET, used in chunk 2213.
CHAR, used in chunks 142, 514, 517, 519, 521, 523, 531, 533, 535, 537, 565, 597, 599, 601, 603, 609, and 1946.
CODE, used in chunks 30, 33, 35, 52, 55, 56a, 80, 148, 150, 152, 154, 161, 179, 251, 277, 294, 309, 330, 341, 388, 389, 450, 451, 454, 456, 458, 474, 506, 508, 510, 512, 517, 519, 521, 527, 529, 533, 535, 545, 549, 565, 597, 599, 601, 603, 605, 607, 609, 615, 617, 619, 623, 625, 627, 629, 637, 745, 820, 835, 844, 846, 893, 911, 1147, 1502, 1503, 1514, 1516, 1526, 1528, 1530, 1532, 1539a, 1546, 1547, 1549, 1552–58, 1565, 1616, 1634, 1636, 1637a, 1642, 1720, 1723, 1778, 1844, 1939, 1945–47, 1951, 1952, 1979, 2009, 2013, 2027, 2035, 2061, 2062, 2112, 2123, 2382, 2463, 2465, 2467, 2475a, 2519, and 2542.
DECOUNT, used in chunks 541, 551, 553, 559, 565, 573, 575, 577, 579, and 585.
DECRET, used in chunks 577, 579, and 581.
DECTEM, used in chunk 551.
DISTEM, used in chunk 547.
DSEXIT, used in chunks 603 and 605.
ERASFILL, never used.
ERCNT, used in chunks 640, 644, and 645.
EXITEM, used in chunks 575 and 577.
FIXLOC, used in chunks 444, 818, 886, 963, 971, 973, 1147, 1297, 1549, 1550, 1558, 1565, 1566, 1610, 1612, 1615, 1618, 1630, 1632, 1634, 1649, 1653, 1654, 1740, 1796, 1802, 2027, 2035, 2123, 2124, 2130, 2175, 2311, 2382, 2454, 2455, 2588, and 2624.
HITEMIN, used in chunks 142, 514, 587, and 589.
INTB15+, used in chunks 514 and 2624.
INTBIT15, used in chunks 514, 1546, 1549, and 1550.
LOTEMIN, used in chunk 514.
NOUNTEM, used in chunk 541.
NVTEMP, used in chunks 617, 619, 625, 627, and 638.
OVFIND, used in chunks 491, 559, 585, 635, 653, 1200, 1256, 1301, 1568, 1570, 1571b, 1573, 1574, 1590, 1598, 1610, 1620, 1633, 1653–55, 1695, 1713, 1714, 1717, 1720, 1723, 1726, 1762, 1852, 2311, and 2588.
POLISH, used in chunks 514, 1553a, 1565, 1566, 1575, 1576, 1618, 1630–33, and 1635–37.
SFTEMP1, used in chunks 452, 454, 514, 547, 549, 553, 555, 557, 559, 579, 581, 583, and 585.
SFTEMP2, used in chunks 452, 454, 514, 553, 555, 557, 579, 583, 585, and 587.
SGNOFF, used in chunks 527 and 529.
SGNON, used in chunks 527 and 529.
STATEXIT, used in chunk 2684.
UPDATRET, used in chunks 543 and 544.
VBUF, used in chunks 142, 497, 501, 514, 1553b, 1575, 1576, 1579, 1582, 1584, 1606, 1608, 1610, 1612, 1613, 1844, and 2623.
WDRET, used in chunks 597, 599, 601, and 603.
WRDRET, never used.

Uses FACTOR 226, I 206, PRIORITY 145, and TEMP 191.

142 ⟨*Page CM0070* 142⟩≡ (75 2684)

```
                                        #       MUST = HITEMIN+1
MIXTEMP         EQUALS  VBUF +3         # FOR MIXNOUN DATA
SIGNRET         EQUALS  VBUF +3         # RETURN FOR +,- ON

# ALSO MIXTEMP+1 = VBUF+4, MIXTEMP+2 = VBUF+5

BUF             ERASE   +2              # TEMPORARY SCALAR STORAGE
BUF2            ERASE   +1
INDEXLOC        EQUALS  BUF             # CONTAINS ADDRESS OF SPECIFIED INDEX.
SWWORD          EQUALS  BUF             # ADDRESS OF SWITCH WORD
SWBIT           EQUALS  BUF +1          # SWITCH BIT WITHIN THE SWITCH WORD
MPTEMP          ERASE                   # TEMPORARY USED IN MULTIPLY AND SHIFT
DMPNTEMP        EQUALS  MPTEMP          # DMPSUB TEMPORARY
DOTINC          ERASE                   # COMPONENT INCREMENT FOR DOT SUBROUTINE
DVSIGN          EQUALS  DOTINC          # DETERMINES SIGN OF DDV RESULT
ESCAPE          EQUALS  DOTINC          # USED IN ARCSIN/ARCCOS.
ENTRET          EQUALS  DOTINC          # EXIT FROM ENTER

DOTRET          ERASE                   # RETURN FROM DOT SUBROUTINE
DVNORMCT        EQUALS  DOTRET          # DIVIDEND NORMALIZATION COUNT IN DDV.
ESCAPE2         EQUALS  DOTRET          # ALTERNATE ARCSIN/ARCCOS SWITCH
WDCNT           EQUALS  DOTRET          # CHAR COUNTER FOR DSPWD
INREL           EQUALS  DOTRET          # INPUT BUFFER SELECTOR ( X,Y,Z, REG )

MATINC          ERASE                   # VECTOR INCREMENT IN MXV AND VXM
MAXDVSW         EQUALS  MATINC          # +0 IF DP QUOTIENT IS NEAR ONE -- ELSE -1.
POLYCNT         EQUALS  MATINC          # POLYNOMIAL LOOP COUNTER
DSPMMTEM        EQUALS  MATINC          # DSPCOUNT SAVE FOR DSPMM
MIXBR           EQUALS  MATINC          # INDICATOR FOR MIXED OR NORMAL NOUN

TEM1            ERASE                   # EXEC TEMP
POLYRET         EQUALS  TEM1
DSREL           EQUALS  TEM1            # REL ADDRESS FOR DSPIN

TEM2            ERASE                   # EXEC TEMP
DSMAG           EQUALS  TEM2            # MAGNITUDE STORE FOR DSPIN
IDADDTEM        EQUALS  TEM2            # MIXNOUN INDIRECT ADDRESS STORAGE

TEM3            ERASE                   # EXEC TEMP
COUNT           EQUALS  TEM3            # FOR DSPIN

TEM4            ERASE                   # EXEC TEMP
LSTPTR          EQUALS  TEM4            # LIST POINTER FOR GRABUSY
RELRET          EQUALS  TEM4            # RETURN FOR RELDSP
FREERET         EQUALS  TEM4            # RETURN FOR FREEDSP
```

```
DSPWDRET        EQUALS  TEM4            # RETURN FOR DSPSIGN
SEPSCRET        EQUALS  TEM4            # RETURN FOR SEPSEC
SEPMNRET        EQUALS  TEM4            # RETURN FOR SEPMIN

TEM5            ERASE                   # EXEC TEMP
```

Defines:

BUF, used in chunks 493, 495, 497–99, 501, 503, 515, 547, 551, 625, 627, 1570, 1574, 1585, 1586, 1598–1601, 1603–8, 1612, 1616, 1620, 1623, 1656, 1658–60, 1844, 2027, 2035, 2306, 2311, 2381, and 2382.
BUF2, used in chunks 144, 515, 649, 692, 1540, 1541, 1579, 1600, 1607, 1608, 1626–28, 1844, 1928, 1936–38, 2009, 2121, 2122, 2217, 2382, and 2590.
COUNT, used in chunks 24, 57, 148, 247, 251, 252, 288, 290, 292, 294, 311, 331, 335, 341, 359, 364, 380, 382, 402, 405, 418, 419, 426, 428, 452, 481, 485, 487, 493, 519, 521, 533, 535, 555, 561, 565, 567, 569, 581, 587, 591, 595, 597, 601, 603, 605, 607, 609, 611, 617, 621, 625, 627, 629, 631, 638, 640, 644, 647, 653, 658b, 660, 670, 674, 684, 692, 694, 708, 712, 718, 724, 727, 733, 735, 739, 741, 743, 747, 756, 762, 786, 795, 798, 804, 810, 820, 827, 839, 844, 862, 878, 880, 890, 893, 907, 909, 915, 919, 927, 930, 934, 937, 941, 951, 965, 967, 977, 1013, 1015, 1039, 1043, 1045, 1049, 1054, 1059, 1063, 1094, 1147, 1195, 1200, 1227, 1256, 1291, 1301, 1344, 1347, 1356, 1362, 1367, 1373, 1390, 1396, 1410, 1412, 1434, 1451, 1453, 1481, 1484, 1485, 1489, 1528, 1530, 1534, 1540, 1546, 1555b, 1556, 1588, 1590, 1591, 1593–98, 1601, 1606, 1610, 1612, 1613, 1621, 1624, 1630, 1638, 1642, 1645–47, 1649, 1652, 1661, 1663, 1675, 1684, 1693, 1697, 1699, 1707, 1727, 1742, 1743, 1746, 1765, 1780, 1804, 1812, 1814, 1835, 1844, 1852, 1868, 1874, 1891, 1896, 1900, 1903, 1905, 1907, 1911, 1913, 1917, 1918, 1939, 1941, 1943, 1945, 1963, 2001, 2007, 2009, 2011, 2015, 2027, 2035, 2043–52, 2056, 2057a, 2108, 2112, 2121, 2126, 2128, 2129, 2142, 2143, 2148, 2167, 2189, 2201, 2203, 2213, 2217, 2219, 2223, 2256, 2260, 2279, 2281, 2283, 2293–95, 2299, 2306, 2311, 2343, 2353, 2359, 2361, 2373, 2375, 2379, 2380, 2382, 2420, 2442, 2465, 2467, 2471, 2476, 2477a, 2480, 2496, 2499b, 2504, 2510, 2519, 2542, 2561, 2572, 2574, 2590, 2607, and 2625.
DMPNTEMP, used in chunk 1578a.
DOTINC, used in chunks 514, 1574, 1578b, and 1579.
DOTRET, used in chunks 514, 1574, and 1620.
DSMAG, used in chunk 605.
DSPMMTEM, used in chunk 629.
DSPWDRET, used in chunk 597.
DSREL, used in chunks 603 and 605.
DVNORMCT, used in chunks 1598, 1601, and 1606–8.
DVSIGN, used in chunks 1598, 1599, 1604b, 1606, 1608, and 1614.
ENTRET, used in chunks 527, 535, 593, 595, 607, 617, and 619.
ESCAPE, used in chunks 1627–29.
ESCAPE2, used in chunks 1627 and 1628.
FREERET, never used.
IDADDTEM, never used.
INDEXLOC, used in chunks 1550 and 1630–32.
INREL, used in chunks 523, 525, 527, 529, 531, and 533.
LSTPTR, never used.
MATINC, used in chunks 514, 1578b, and 1579.
MAXDVSW, used in chunks 1598, 1600, 1602, 1608, and 1612.
MIXBR, used in chunks 452, 537, 549, 551, 553, 559, 567, 575, 577, 579, and 585.
MIXTEMP, used in chunks 514, 531, and 541.
MPTEMP, used in chunks 515, 635, 1541, 1572, 1577, 1588–97, 1610, 1612–14, 1616, 1621, 1624, 1627, 1629, and 2382.
POLYCNT, used in chunks 1575 and 1576.
POLYRET, used in chunks 1575 and 1576.
RELRET, used in chunk 639a.
SEPMNRET, used in chunk 567.

SEPSCRET, used in chunks 565 and 567.
SIGNRET, never used.
SWBIT, used in chunks 1635–37.
SWWORD, used in chunks 1635 and 1636.
TEM1, used in chunks 514, 1610, 1985, 2454, 2455, 2457, and 2458.
TEM2, used in chunks 144, 514, 1844, 2027, 2035, 2446, 2452, 2453, and 2456.
TEM3, used in chunks 144, 514, 1844, 2453, and 2456.
TEM4, used in chunks 144, 515, 559, 561, and 2456.
TEM5, used in chunks 144, 515, 2454, and 2455.
WDCNT, used in chunks 597, 599, 601, and 603.
Uses CHAR 140, DSPCOUNT 152, HITEMIN 140, SAVE 191, TEMP 191, VBUF 140, and Z 80.

144 ⟨*Page CM0071* 144⟩≡ (75 2684)

```
NOUNADD         EQUALS  TEM5            # TEMP STORAGE FOR NOUN ADDRESS

NNADTEM         ERASE                   # TEMP FOR NOUN ADDRESS TABLE ENTRY
NNTYPTEM        ERASE                   # TEMP FOR NOUN TYPE TABLE ENTRY
IDAD1TEM        ERASE                   # TEMP FOR INDIR ADDRESS TABLE ENTRY (MIXNN)
                                        # MUST = IDAD2TEM-1, = IDAD3TEM-2
IDAD2TEM        ERASE                   # TEMP FOR INDIR ADDRESS TABLE ENTRY (MIXNN)
                                        # MUST = IDAD1TEM+1, IDAD3TEM-1.
IDAD3TEM        ERASE                   # TEMP FOR INDIR ADDRESS TABLE ENTRY (MIXNN)
                                        # MUST = IDAD1TEM+2, IDAD2TEM+1.
RUTMXTEM        ERASE                   # TEMP FOR SF ROUT TABLE ENTRY (MIXNN ONLY)

# AX*SR*T STORAGE.                      (6D)
DEXDEX          EQUALS  TEM2            # B(1)TMP
DEX1            EQUALS  TEM3            # B(1)TMP
DEX2            EQUALS  TEM4            # B(1)TMP
RTNSAVER        EQUALS  TEM5            # B(1)TMP
TERM1TMP        EQUALS  BUF2            # B(2)TMP

DEXI            =       DEX1
```

Defines:
DEX1, used in chunk 1844.
DEX2, never used.
DEXDEX, used in chunk 1844.
DEXI, used in chunk 1844.
IDAD1TEM, used in chunks 452, 515, 541, 559, and 577.
IDAD2TEM, used in chunks 452 and 515.
IDAD3TEM, used in chunks 452 and 515.
NNADTEM, used in chunks 452, 537, 541, 543, 549, 551, and 579.
NNTYPTEM, used in chunks 452, 551, 575, and 577.
NOUNADD, used in chunks 537, 539, 541, 543, 547, 551, 561, 567, 569, 571, 573, 577, 585, 589, 595, and 631.
RTNSAVER, used in chunk 1844.
RUTMXTEM, used in chunks 452 and 575.
TERM1TMP, used in chunk 1844.
Uses BUF2 142, SR 80, TEM2 142, TEM3 142, TEM4 142, TEM5 142, and TEMP 191.

145 ⟨*Page CM0072* 145⟩≡ (75 2684)

```
# DYNAMICALLY ALLOCATED CORE SETS FOR JOBS      (84D)

MPAC            ERASE   +6              # MULTI-PURPOSE ACCUMULATOR.
MODE            ERASE                   # +1 FOR TP, +0 FOR DP, OR -1 FOR VECTOR.
LOC             ERASE                   # LOCATION ASSOCIATED WITH JOB.
BANKSET         ERASE                   # USUALLY CONTAINS BBANK SETTING.
PUSHLOC         ERASE                   # WORD OF PACKED INTERPRETIVE PARAMETERS.
PRIORITY        ERASE                   # PRIORITY OF PRESENT JOB AND WORK AREA.

                ERASE   +71D            # SEVEN SETS OF 12 REGISTERS EACH

# SPECIAL DOWNLINK BUFFER. -- OVERLAYED BY P27 STORAGE --

# P27 (UPDATE PROGRAM) STORAGE. -- OVERLAYS SPEC DNLNK BUFF -- (24D)

COMPNUMB        ERASE   +23D           # B(1)TMP NUMBER OF ITEMS TO BE UPLINKED.
UPOLDMOD        EQUALS  COMPNUMB +1     # B(1)TMP HOLDS INTERRUPTED PROGRAM NUMBER
UPVERB          EQUALS  UPOLDMOD +1     # B(1)TMP VERB NUMBER
UPCOUNT         EQUALS  UPVERB +1       # B(1)TMP UPBUFF INDEX
UPBUFF          EQUALS  UPCOUNT +1      # B(20D)

# MORE P27 STORAGE.                     (2D)

UPTEMP          ERASE                   # B(1)TMP SCRATCH
UPVERBSV        ERASE                   # B(1)TMP
INTWAK1Q        EQUALS  UPTEMP          # (06D)
# (20 REGISTERS OF ENTRY DOWNLINK WILL GO HERE.)

# THE FOLLOWING ARE INDEXED FOR TM. IN ENTRY DAP.

CMTMTIME        =       UPBUFF          # B(1) (VEHICLE BODY RATE INFO IS
SW/NDX          =       CMTMTIME +1     # B(1)  TELEMETERED EACH 0.2 SEC. DURING
ENDBUF          =       CMTMTIME +16D   # B(1)  ENTRY.)

V1              =       ENDBUF +1       # I(2) REENTRY, P64-P65
A0              =       V1 +2           # I(2) REENTRY, P64-P65
                                        # HI-ORDER WORD ONLY ON DNLNK.

# ALIGNMENT STORAGE.                    (5D)
# (CANNOT SHARE WITH PRECISION INTEGRATION OR KEPLER STORAGE.)

QMAJ            EQUALS  COMPNUMB        # B(1)TMP
MARKINDX        EQUALS  QMAJ    +1      # B(1)TMP
BESTI           EQUALS  MARKINDX +1     # I(1)TMP
BESTJ           EQUALS  BESTI   +1      # I(1)TMP
```

```
STARIND         EQUALS  BESTJ   +1      # I(1)TMP
```

Defines:

A0, used in chunks 874, 1245, and 1256.
BANKSET, used in chunks 1542, 1546, 1547, 1556, 1565–67, 1651, 1654, 1656, 1657, 1959, 1999, 2007, and 2588.
BESTI, used in chunks 298, 357, 370, 1015, 1019, and 1147.
BESTJ, used in chunks 298 and 1147.
CMTMTIME, used in chunk 1521.
COMPNUMB, used in chunks 302 and 2015.
ENDBUF, used in chunks 226, 229, 1519, and 1521.
INTWAK1Q, used in chunk 1812.
LOC, used in chunks 138, 183, 190, 191, 224, 232, 236, 238, 349, 364, 380, 597, 599, 603, 609, 615, 617, 625, 629, 638, 693, 694, 891, 989, 1063, 1094, 1367, 1504, 1540, 1542, 1546–48, 1550, 1553a, 1556, 1563, 1565–67, 1575, 1637a, 1649, 1651, 1653–58, 1661, 1684, 1852, 1935, 1950, 1957, 1959, 1963, 1989, 1995, 1999, 2007, 2009, 2139, 2223, 2311, 2382, and 2574.
MARKINDX, used in chunks 357, 921, 926, 1015, and 1147.
MODE, used in chunks 24, 26, 52, 54, 56a, 85, 97, 127, 152, 154, 163, 181, 267, 281, 284, 307, 321, 323, 331, 333, 335, 351, 353, 355, 378, 382, 386, 388, 390, 396, 405, 411, 414, 430, 493, 497, 508, 510, 512, 517, 540, 607, 615, 619, 627, 629, 647, 711, 794, 825, 836, 837, 858, 860, 876, 888, 934, 963, 967, 991, 1049, 1052, 1094, 1147, 1200, 1256, 1301, 1347, 1356, 1373, 1390, 1412, 1481, 1486, 1495, 1500, 1502, 1524, 1536, 1547, 1552, 1553b, 1559, 1561–63, 1567, 1573, 1578b, 1580, 1581, 1586–88, 1595, 1597, 1615, 1616, 1618, 1663, 1684, 1714, 1717, 1720, 1723, 1726, 1852, 1891, 1919, 1920, 1924, 1934–36, 1938, 1959, 1999, 2015, 2027, 2035, 2063, 2064a, 2094, 2096, 2104–6, 2108, 2143, 2156, 2177, 2219, 2275, 2293, 2295, 2311, 2371, 2382, 2420, 2422, 2424, 2443, 2461, 2472, 2496, 2499b, 2504, 2507, 2519, 2542, 2561, 2625, 2833, and 2837.
MPAC, used in chunks 321, 323, 327, 335, 337, 339, 347, 351, 390, 405, 407, 418, 440, 481, 487, 489, 495–98, 501, 503, 506, 515, 519, 523, 525, 539, 543, 549, 551, 553, 555, 557, 559, 561, 563, 565, 567, 577, 579, 581, 583, 585, 587, 589–91, 593, 595, 597, 599, 601, 609, 611, 615, 619, 621, 627, 629, 635, 649, 651, 670, 674, 678, 714, 716, 717, 720, 733, 739, 743, 749, 763, 765, 786, 788, 792, 794, 795, 804, 812, 820, 822, 839, 840a, 876, 886, 911, 919, 921, 923, 934, 939, 947, 953, 957, 961, 963, 965, 967, 969, 971, 973, 975, 983, 985, 991, 1001, 1019, 1021, 1025, 1029, 1031, 1049, 1056, 1063, 1094, 1147, 1195, 1200, 1227, 1256, 1296, 1297, 1299, 1301, 1546, 1547, 1554–56, 1559, 1561–63, 1565, 1567, 1568, 1570–82, 1584–96, 1598–1610, 1612–16, 1618, 1620, 1621, 1623–29, 1633, 1649, 1651, 1653, 1654, 1675, 1677, 1679, 1680, 1684, 1697, 1714, 1717, 1720, 1723, 1724, 1726, 1729, 1733, 1737, 1740, 1743, 1745, 1746, 1752, 1756, 1763, 1767, 1796, 1798, 1803, 1806, 1808, 1814, 1835, 1837, 1844, 1852, 1905, 1915, 1927, 1928, 1941, 1943–45, 1959, 1962, 1963, 1967, 1977, 1983, 1985, 1987, 1991, 1993, 1997, 1999, 2000a, 2015, 2027, 2035, 2114, 2118, 2142, 2143, 2148, 2158, 2160, 2164, 2175, 2177, 2181, 2185, 2189, 2205, 2209, 2219, 2223, 2265, 2283, 2285, 2299, 2306, 2311, 2359, 2365, 2367, 2375, 2381, 2382, 2441, 2442, 2444, 2446, 2454, 2588, 2590, 2592, 2594, 2596, 2598, 2600, 2603, 2605, 2606, 2624, and 2747.
PRIORITY, used in chunks 31, 109, 111, 113, 140, 327, 335, 345, 349, 353, 355, 362, 364, 382, 419, 424–26, 430, 432, 446, 508, 573, 609, 613, 633, 647, 649, 650, 732a, 825, 860, 936, 953, 1094, 1547, 1649, 1651–54, 1656–60, 1872, 1894–96, 1898, 1903, 1909, 1915, 1938, 1949, 1950, 1957, 1959, 1961, 1962, 1973, 1977, 1983, 1993, 1995, 2015, 2082, 2084, 2152, 2154, 2287, 2289, 2311, 2382, 2478, and 2496.
PUSHLOC, used in chunks 489, 784, 797, 991, 1200, 1301, 1552, 1562, 1563, 1585, 1618, 1653–55, 1684, 1852, 2130, 2311, and 2382.
QMAJ, used in chunks 1147 and 2299.
STARIND, used in chunks 357, 1015, 1147, and 2289.
SW/NDX, used in chunks 1487, 1513, 1519, and 1521.
UPBUFF, used in chunks 148, 294, 302, 1487, 1513, 1521, and 2015.
UPCOUNT, used in chunks 302 and 2015.

UPOLDMOD, used in chunks 302 and 2015.
UPTEMP, used in chunk 2015.
UPVERB, used in chunks 302 and 2015.
UPVERBSV, used in chunk 2015.
V1, used in chunks 458, 858, 901, 1248, 1256, and 1301.
Uses BBANK 80, I 206, REENTRY 65, and TM 219.

148 ⟨*Page CM0073* 148⟩≡ (75 2684)

```
# ALIGNMENT/S40.2,3 COMMON STORAGE.     (18D)

XSMD            EQUALS  UPBUFF  +2      # I(6)TMP
YSMD            EQUALS  XSMD    +6      # I(6)TMP
ZSMD            EQUALS  YSMD    +6      # I(6)TMP

XSCREF          =       XSMD            # SPACE CRAFT AXES IN REF COORDS.
YSCREF          =       YSMD
ZSCREF          =       ZSMD
ZPRIME          =       22D
PDA             =       22D
COSTH           =       16D
SINTH           =       18D
THETA           =       20D
STARM           =       32D

# DOWNLINK STORAGE                      (18D)

DNLSTADR        EQUALS  DNLSTCOD        # CONTENTS NO LONGER AN ADDR BUT A CODE

DNLSTCOD        ERASE                   # B(1)PRM ID CODE OF DOWNLIST
DUMPCNT         ERASE                   # B(1)PRM
LDATALST        ERASE                   # B(1)
DNTMGOTO        ERASE                   # B(1)
TMINDEX         ERASE                   # B(1)
DUMPLOC         EQUALS  TMINDEX         # CONTAINS ECADR OF AGC DP WORD BEING DUMPED
                                        # AND COUNT OF COMPLETE DUMPS ALREADY
                                        # SENT.
DNQ             ERASE                   # B(1)
DNTMBUFF        ERASE   +11D            # B(12)PRM DOWNLINK SNAPSHOT BUFFER

# OPTICS MARKING, UNSHARED.             (8D)

MKNDX           ERASE
MKT2T1          ERASE   +1
MKCDUY          ERASE
MKCDUS          ERASE
MKCDUZ          ERASE
MKCDUT          ERASE
MKCDUX          ERASE

# FOR EXCLUSIVE USE OF SYS TEST STANDARD LEAD INS       (2)
EBUF2           ERASE   +1              # B(2) UNSHARED
```

Defines:

COSTH, used in chunks 483, 899, 1295, 1676, 1680, 1835–37, 1839, and 2143.
DNLSTADR, used in chunks 1524, 1528, 2461, and 2465.
DNLSTCOD, used in chunks 311, 341, 864, 1200, 1530, 2015, 2116, and 2467.
DNQ, used in chunks 1524, 1534, 2461, and 2471.
DNTMBUFF, used in chunks 249, 294, 295, 298, 300, 302, 304, 1524, 1528, 1532, 1534, 1538, 2461, 2465, 2469, 2471, and 2474.
DNTMGOTO, used in chunks 325, 436, 1524, 1528, 1536, 1538, 2461, 2465, 2472, 2474, and 2475a.
DUMPCNT, used in chunks 1536, 1538, 2472, and 2474.
DUMPLOC, used in chunks 1536, 1538, 2472, and 2474.
EBUF2, used in chunks 692 and 693.
LDATALST, used in chunks 1524, 1534, 2461, and 2471.
MKCDUS, used in chunks 388, 394, and 400.
MKCDUT, used in chunks 388, 394, and 400.
MKCDUX, used in chunks 388, 394, 400, and 402.
MKCDUY, used in chunks 388, 394, 400, and 402.
MKCDUZ, used in chunks 388, 394, 400, and 402.
MKNDX, used in chunk 402.
MKT2T1, used in chunks 388, 392, 394, and 400.
PDA, used in chunks 483 and 2181.
SINTH, used in chunks 483, 899, 1295, 1676, 1680, 1835–37, 1839, 1840, and 2143.
STARM, used in chunks 481 and 1147.
THETA, used in chunks 33, 52, 123, 179, 181, 430, 458, 670, 672, 674, 678, 680, 812, 893, 899, 969, 1054, 1056, 1147, 1200, 1248, 1256, 1412, 1680, 1719, 1720, 1837, 1852, 2027, 2091, 2179, 2181, 2185, 2187, 2515, and 2574.
TMINDEX, used in chunks 1524, 1532, 1534, 2461, 2469, and 2471.
XSCREF, used in chunk 1094.
XSMD, used in chunk 1147.
YSCREF, used in chunk 1094.
YSMD, used in chunk 1147.
ZPRIME, used in chunks 1835, 1836, and 2448.
ZSCREF, used in chunk 1094.
ZSMD, used in chunk 1147.

Uses A 80, CODE 140, COUNT 142, I 206, and UPBUFF 145.

150 ⟨*Page CM0074* 150⟩≡ (75 2684)

```
# UNSWITCHED FOR DISPLAY INTERFACE ROUTINES.    (10D)

RESTREG         ERASE                   # B(1)PRM FOR DISPLAY RESTARTS.
NVWORD          ERASE
MARKNV          ERASE
NVSAVE          ERASE
# (RETAIN THE ORDER OF CADRFLSH TO FAILREG +2 FOR DOWNLINK PURPOSES)
CADRFLSH        ERASE                   # B(1)TMP
CADRMARK        ERASE                   # B(1)TMP
TEMPFLSH        ERASE                   # B(1)TMP
FAILREG         ERASE   +2              # B(3)PRM 3 ALARM CODE REGISTERS

                SETLOC  400

# VAC AREAS. -- BE CAREFUL OF PLACEMENT --      (220D)

VAC1USE         ERASE                   # B(1)PRM
VAC1            ERASE   +42D            # B(43)PRM
VAC2USE         ERASE                   # B(1)PRM
VAC2            ERASE   +42D            # B(43)PRM
VAC3USE         ERASE                   # B(1)PRM
VAC3            ERASE   +42D            # B(43)PRM
VAC4USE         ERASE                   # B(1)PRM
VAC4            ERASE   +42D            # B(43)PRM
VAC5USE         ERASE                   # B(1)PRM
VAC5            ERASE   +42D            # B(43)PRM

# WAITLIST REPEAT FLAG.                 (1D)
RUPTAGN         ERASE                   # B(1)PRM
KEYTEMP2        =       RUPTAGN

# STARALIGN ERASABLES.                          (13D)

STARCODE        ERASE                   # B(1)DSP NOUN 70 FOR P22,51 AND R52,53
STARALGN        ERASE   +11D
SINCDU          =       STARALGN
COSCDU          =       STARALGN +6

SINCDUX         =       SINCDU +4
SINCDUY         =       SINCDU
SINCDUZ         =       SINCDU +2
COSCDUX         =       COSCDU +4
COSCDUY         =       COSCDU
COSCDUZ         =       COSCDU +2
```

```
# PHASE TABLE AND RESTART COUNTERS              (12D)
```

Defines:
CADRFLSH, used in chunks 297, 302, 1959, 1981, 1987, 1993, and 1995.
CADRMARK, never used.
COSCDU, used in chunks 482, 1147, and 1844.
COSCDUX, used in chunks 880, 882, 1147, 1373, 2441, and 2450.
COSCDUY, used in chunks 1147 and 1844.
COSCDUZ, used in chunks 880, 1147, 1373, 1844, 2448, and 2450.
FAILREG, used in chunks 38, 297, 302, 311, 454, 645, 1874, 2007, 2009, and 2480.
KEYTEMP2, used in chunk 1946.
MARKNV, used in chunks 1959, 1967, 1969, and 1985.
NVSAVE, used in chunks 313, 1959, 1989, and 1997.
NVWORD, used in chunks 1959, 1977, 1981, 1985, 1987, 1997, and 2287.
RESTREG, used in chunks 313, 335, 1959, 1962, 1975, and 1983.
RUPTAGN, used in chunks 515, 959, and 1663.
SINCDU, used in chunks 482, 1147, and 1844.
SINCDUX, used in chunks 882, 1147, 1373, 2441, and 2450.
SINCDUY, used in chunks 1147 and 1844.
SINCDUZ, used in chunks 880, 1147, 1844, 2448, and 2450.
STARALGN, never used.
STARCODE, used in chunks 42, 474, 735, 737, 1017, 1019, and 1147.
TEMPFLSH, used in chunks 339, 343, 1021, 1959, and 1983.
VAC1, never used.
VAC1USE, used in chunks 327, 330, 384, 1652, and 2121.
VAC2, never used.
VAC2USE, used in chunks 327, 384, 1652, and 2121.
VAC3, never used.
VAC3USE, used in chunks 327, 384, 1652, and 2121.
VAC4, never used.
VAC4USE, used in chunks 327, 384, 1652, and 2121.
VAC5, used in chunks 349, 351, and 1915.
VAC5USE, used in chunks 327, 384, 1652, and 2121.
Uses CODE 140 and RESTART 57.

152 ⟨*Page CM0075* 152⟩≡ (75 2684)

```
-PHASE1         ERASE                   # B(1)PRM
PHASE1          ERASE                   # B(1)PRM
-PHASE2         ERASE                   # B(1)PRM
PHASE2          ERASE                   # B(1)PRM
-PHASE3         ERASE                   # B(1)PRM
PHASE3          ERASE                   # B(1)PRM
-PHASE4         ERASE                   # B(1)PRM
PHASE4          ERASE                   # B(1)PRM
-PHASE5         ERASE                   # B(1)PRM
PHASE5          ERASE                   # B(1)PRM
-PHASE6         ERASE                   # B(1)PRM
PHASE6          ERASE                   # B(1)PRM

# A**SR*T STORAGE                       (6D)

CDUSPOT         ERASE   +5              # B(6)

CDUSPOTY        =       CDUSPOT
CDUSPOTZ        =       CDUSPOT +2
CDUSPOTX        =       CDUSPOT +4

# VERB 37 STORAGE                       (2D)

MINDEX          ERASE                   # B(1)TMP INDEX FOR MAJOR MODE
MMNUMBER        ERASE                   # B(1)TMP MAJOR MODE REQUESTED BY V37

# PINBALL INTERRUPT ACTION              (1D)

DSPCNT          ERASE                   # B(1)PRM COUNTER FOR DSPOUT

# PINBALL EXECUTIVE ACTION              (44D)

DSPCOUNT        ERASE                   # DISPLAY POSITION INDICATOR
DECBRNCH        ERASE                   # +DEC, -DEC, OCT INDICATOR
VERBREG         ERASE                   # VERB CODE
NOUNREG         ERASE                   # NOUN CODE
XREG            ERASE                   # R1 INPUT BUFFER
YREG            ERASE                   # R2 INPUT BUFFER
ZREG            ERASE                   # R3 INPUT BUFFER
XREGLP          ERASE                   # LO PART OF XREG (FOR DEC CONV ONLY)
YREGLP          ERASE                   # LO PART OF YREG (FOR DEC CONV ONLY)
HITEMOUT        =       YREGLP          # TEMP FOR DISPLAY OF HRS,MIN,SEC
                                        #       MUST = LOTEMOUT-1.
ZREGLP          ERASE                   # LO PART OF ZREG (FOR DEC CONV ONLY)
```

```
LOTEMOUT        =       ZREGLP          # TEMP FOR DISPLAY OF HRS,MIN,SEC
                                        #       MUST = HITEMOUT+1
```

Defines:
-PHASE1, used in chunks 315, 321, 343, 378, 380, 1902, 2269, 2343, and 2382.
-PHASE2, used in chunks 315, 335, 341, 343, 378, 2271, and 2382.
-PHASE3, used in chunks 315, 862, 2271, 2311, 2343, and 2382.
-PHASE4, used in chunks 315, 335, 343, 1094, 2269, 2279, 2291, 2343, and 2382.
-PHASE5, used in chunks 315, 378, 862, 1227, and 2382.
-PHASE6, used in chunks 315, 1094, 2015, 2285, 2343, and 2382.
CDUSPOT, used in chunks 743, 880, 1844, 2128, 2132, and 2382.
CDUSPOTX, used in chunks 1094, 2382, and 2443.
CDUSPOTY, used in chunks 1094, 2382, and 2443.
CDUSPOTZ, used in chunks 1094, 2382, and 2443.
DECBRNCH, used in chunks 521, 523, 527, 529, 533, 535, 537, 573, 577, 579, 590, 609, and 645.
DSPCNT, used in chunks 253 and 329.
DSPCOUNT, used in chunks 142, 254, 329, 508, 514, 517, 521, 523, 525, 527, 529, 531, 533, 535, 537, 539, 543, 544, 547, 551, 553, 559, 561, 563, 565, 567, 573, 579, 593, 596, 597, 599, 601, 603, 607, 609, 612, 617, 619, 623, 625, 627, 629, and 1945.
HITEMOUT, used in chunks 512, 561, 565, and 567.
LOTEMOUT, used in chunks 512, 561, 563, 565, and 567.
MINDEX, used in chunks 335, 339, and 345.
MMNUMBER, used in chunks 335, 337, 341, 343, and 2343.
NOUNREG, used in chunks 329, 409, 452, 508, 525, 527, 543, 569, 591, 595, 609, 619, 629, 1961, and 1997.
PHASE1, used in chunks 315, 321, 323, 343, 349, 378, 380, 712, 1412, 1453, 1475, 1902, 1903, 2269, 2343, and 2382.
PHASE2, used in chunks 315, 335, 341, 343, 378, 1412, 2271, and 2382.
PHASE3, used in chunks 315, 862, 1412, 1450a, 2271, 2311, 2343, and 2382.
PHASE4, used in chunks 315, 335, 343, 378, 1094, 2269, 2279, 2291, 2343, and 2382.
PHASE5, used in chunks 315, 378, 862, 870, 1094, 1227, 2271, and 2382.
PHASE6, used in chunks 315, 1094, 2015, 2281, 2285, 2343, and 2382.
VERBREG, used in chunks 329, 333, 398, 508, 523, 525, 527, 531, 537, 539, 541, 543, 544, 547, 591, 595, 607, 619, 629, 1961, and 1991.
XREG, used in chunks 38, 454, 512, 521, 525, 529, 531, 551, 571, 577, and 587.
XREGLP, used in chunks 521, 525, 533, 577, and 587.
YREG, used in chunks 512, 521, 525, 529, 531, 571, and 587.
YREGLP, used in chunks 512, 521, and 587.
ZREG, used in chunks 512, 521, 525, 529, 531, 537, 571, and 589.
ZREGLP, used in chunks 512, 521, and 589.
Uses A 80, CODE 140, MODE 145, R2 188, SR 80, and TEMP 191.

154 ⟨*Page CM0076* 154⟩≡ (75 2684)

```
MODREG          ERASE                   # MODE CODE
DSPLOCK         ERASE                   # KEYBOARD/SUBROUTINE CALL INTERLOCK
REQRET          ERASE                   # RETURN REGISTER FOR LOAD
LOADSTAT        ERASE                   # STATUS INDICATOR FOR LOADTST
CLPASS          ERASE                   # PASS INDICATOR FOR CLEAR
NOUT            ERASE                   # ACTIVITY COUNTER FOR DSPTAB
NOUNCADR        ERASE                   # MACHINE CADR FOR NOUN
MONSAVE         ERASE                   # N/V CODE FOR MONITOR. (= MONSAVE1-1)
MONSAVE1        ERASE                   # NOUNCADR FOR MONITOR (MATBS) = MONSAVE+1
MONSAVE2        ERASE                   # B(1)PRM NVMONOPT OPTIONS
DSPTAB          ERASE   +11D            # 0-100, DISPLAY PANEL BUFF.  11D, C/S LTS.
NVQTEM          ERASE                   # NVSUB STORAGE FOR CALLING ADDRESS
                                        # MUST = NVBNKTEM-1.
NVBNKTEM        ERASE                   # NVSUB STORAGE FOR CALLING BANK
                                        # MUST = NVQTEM+1
VERBSAVE        ERASE                   # NEEDED FOR RECYCLE
CADRSTOR        ERASE                   # ENDIDLE STORAGE
DSPLIST         ERASE                   # WAITING REG FOR DSP SYST INTERNAL USE
EXTVBACT        ERASE                   # EXTENDED VERB ACTIVITY INTERLOCK
DSPTEM1         ERASE   +2              # BUFFER STORAGE AREA 1 (MOSTLY FOR TIME)
DSPTEM2         ERASE   +2              # BUFFER STORAGE AREA 2 (MOSTLY FOR DEG)

DSPTEMX         EQUALS  DSPTEM2 +1      # B(2) S-S DISPLAY BUFFER FOR EXT. VERBS
NORMTEM1        EQUALS  DSPTEM1         # B(3)DSP NORMAL DISPLAY REGISTERS.

# DISPLAY FOR EXTENDED VERBS            (2D)

OPTIONX         EQUALS  DSPTEMX         # B(2) EXTENDED VERB OPTION CODE  N12(V82)

# TBASE'S AND PHSPRDT'S.                (12D)

TBASE1          ERASE                   # B(1)PRM
PHSPRDT1        ERASE                   # B(1)PRM
TBASE2          ERASE                   # B(1)PRM
PHSPRDT2        ERASE                   # B(1)PRM
TBASE3          ERASE                   # B(1)PRM
PHSPRDT3        ERASE                   # B(1)PRM
TBASE4          ERASE                   # B(1)PRM
PHSPRDT4        ERASE                   # B(1)PRM
TBASE5          ERASE                   # B(1)PRM
PHSPRDT5        ERASE                   # B(1)PRM
TBASE6          ERASE                   # B(1)PRM
PHSPRDT6        ERASE                   # B(1)PRM

# UNSWITCHED FOR DISPLAY INTERFACE ROUTINES.    (5D)
```

Defines:
CADRSTOR, used in chunks 329, 508, 519, 537, 593, 613, 623, 629, 637, 638, 1959, 1989, and 1991.
CLPASS, used in chunks 329, 508, 521, 527, 529, 531, 535, 537, 573, 619, 621, and 645.
DSPLIST, used in chunks 329, 508, 593, 613, 623, 629, 637–39, and 1959.
DSPLOCK, used in chunks 329, 508, 519, 591, 593, 613, 615, 617, 625, 629, 638–40, 644, and 1995.
DSPTAB, used in chunks 252, 253, 268, 279, 287, 294, 297, 298, 311, 313, 319, 327, 508, 512, 517, 533, 603, 605, 619, 640, 642, 644, 645, 1918, 1923, 1925, 2001, and 2009.
DSPTEM1, used in chunks 38, 40, 45, 398, 400, 418, 454, 456, 470, 478, 596, 611, 733, 739, 743, 747, 750, 844, 846, 977, 1147, 1959, 2189, and 2191.
DSPTEM2, used in chunks 38, 45, 418, 454, 478, 700, 702, 703, 708, 2193, 2195, 2196, and 2201.
DSPTEMX, used in chunks 38, 454, 804, 808, and 2114.
EXTVBACT, used in chunks 313, 329, 382, 384, 392, 407, 810, 812, 813, 833, 835, 836, 927, 1200, 1344, 1963, 2001, 2121, 2123, and 2213.
LOADSTAT, used in chunks 573, 611, 612, 621, and 629.
MODREG, used in chunks 313, 323, 333, 335, 343, 345, 437, 619, 627, 629, 642, 650, 731, 782, 831, 836, 1094, 1147, 1800, 1891, 2015, 2306, 2311, 2343, and 2382.
MONSAVE, used in chunks 329, 508, 512, 591, 593, and 595.
MONSAVE1, used in chunks 329, 508, 512, 591, 593, 595, 613, 617, 621, 625, 638, 639a, and 1961.
MONSAVE2, used in chunks 591, 595, and 617.
NORMTEM1, used in chunks 1147, 1975, and 1979.
NOUNCADR, used in chunks 512, 537, 539, 543, 551, 577, 579, 591, 595, 596, 621, and 631.
NOUT, used in chunks 253, 255, 329, 508, 533, 605, 619, and 640.
NVBNKTEM, used in chunks 512 and 617.
NVQTEM, used in chunks 512 and 617.
OPTIONX, used in chunks 38, 454, 804, 827, 829, and 2148.
PHSPRDT1, used in chunks 1898, 1903, 1907, 1909, and 1913.
PHSPRDT2, used in chunks 341, 941, 1015, and 2343.
PHSPRDT3, used in chunk 351.
PHSPRDT4, used in chunk 345.
PHSPRDT5, used in chunk 1256.
PHSPRDT6, used in chunk 1043.
REQRET, used in chunks 329, 508, 527, 531, 535, 543, 595, 607, 609, 612, 619, 621, 623, and 625.
TBASE1, used in chunks 378, 380, 649, 650, 1902, 1907, and 2269.
TBASE2, used in chunks 378, 1802, 2382, and 2420.
TBASE3, used in chunks 1894 and 1896.
TBASE4, used in chunks 351, 378, 1893, 2269, 2283, and 2285.
TBASE5, used in chunks 378, 782, 870, and 2382.
TBASE6, used in chunks 1094, 1227, 1487, and 2285.
VERBSAVE, used in chunks 537, 590, and 607.
Uses CODE 140, MODE 145, N 206, and V 229.

156 ⟨*Page CM0077* 156⟩≡ (75 2684)

```
EBANKSAV        ERASE
MARKEBAN        ERASE
EBANKTEM        ERASE
MARK2PAC        ERASE
R1SAVE          ERASE

# IMU COMPENSATION UNSWITCHED ERASABLE. (1D)

1/PIPADT        ERASE                   # B(1)PRM
OLDBT1          =       1/PIPADT

# SINGLE PRECISION SUBROUTINE TEMPORARIES       (3D)
                                        # SPSIN, SPCOS, SPROOT VARIABLES.
                                        # DO NOT SHARE.  THESE ARE USED BY DAPS IN IN
                                        # AND CURRENTLY ARE NOT PROTECTED.  IF OTHER
                                        # MATERIALIZE, THEN THIS CAN BE CHANGED.

HALFY           ERASE
ROOTRET         ERASE
SQRARG          ERASE
TEMK            EQUALS  HALFY
SQ              EQUALS  ROOTRET
```

Defines:
`1/PIPADT`, used in chunks 493, 498, 501, 503, 696, 725, 868, 1147, 1227, and 2382.
`EBANKSAV`, used in chunks 1959, 1967, 1979, and 1999.
`EBANKTEM`, used in chunks 313, 341, 1959, 1962, 1973, 1983, 1997, and 1999.
`HALFY`, never used.
`MARK2PAC`, used in chunks 1961, 1983, and 1985.
`MARKEBAN`, used in chunks 1959 and 1999.
`OLDBT1`, used in chunk 1227.
`R1SAVE`, used in chunks 329, 1959, 1961, 1991, 1993, and 1999.
`ROOTRET`, never used.
`SQ`, used in chunks 50, 182, 953, 985, 987, 999, 1063, 1200, 1227, 1256, 1347, 1362, 1396, 1483, 1492, 1493, 1521, 1647, 1814, 1852, 2223, and 2382.
`SQRARG`, never used.
`TEMK`, used in chunks 1483, 1492, 1493, 1521, and 1647.

157 ⟨*Page CM0078* 157⟩≡ (75 2684)

```
# UNSWITCHED FOR ORBIT INTEGRATION      (21D)

TDEC            ERASE   +20D            # I(2)
COLREG          EQUALS  TDEC +2         # I(1)
LAT             EQUALS  COLREG +1       # I(2)DSP NOUN 43,67 FOR P20,22,51 R52,53.
LANDLAT         =       LAT             #         NOUN 89    FOR P22.
LONG            EQUALS  LAT +2          # I(2)DSP NOUN 43,67 FOR P20,22,51 R52,53
ALT             EQUALS  LONG +2         # I(2)DSP NOUN 43    FOR P20,22,51 R52,53.
YV              EQUALS  ALT +2          # I(6)
ZV              EQUALS  YV +6           # I(6)

# MARK STORAGE.                         (2)

VHFCNT          ERASE                   # B(1)PRM NO. OF VHF MARKS (P20 (R22)).
TRKMKCNT        ERASE                   # B(1)PRM NO. OF VHF MARKS (P20 (R22)).

MARKCTR         =       TRKMKCNT        # B(1) MARK COUNTER USED BY R32

# MISCELLANEOUS UNSWITCHED.             (16D)

IRETURN1        ERASE                   # B(1) RET ADDR USED BY MIDTOAV1 AND 2
                                        # CALLED BY P40,P41,P42, P61,P62
RATEINDX        ERASE                   #  (1) USED BY KALCMANU
OPTION1         ERASE                   # B(1) NOUN 06 USES THIS.
OPTION2         ERASE                   # B(1) NOUN 06 USES THIS.
LONGCADR        ERASE   +1              # B(2) LONGCALL REGISTER.
LONGBASE        ERASE   +1              # B(2) LONGCALL REGISTER.
LONGTIME        ERASE   +1              # B(2) LONGCALL REGISTER.
DELAYLOC        ERASE   +3
NVWORD1         ERASE                   # B(1)
TEMPR60         ERASE                   # B(1)
PRIOTIME        ERASE                   # B(1)
P30/RET         EQUALS  IRETURN1

# MISC. INCLUDING RESTART COUNTER, GIMBAL ANGLE SAVE AND
# STANDBY VERB ERASABLES.  REDOCTR BEFORE THETAD (DWNLNK)       (16D)

TIME2SAV        ERASE   +1              # B(2)TMP
SCALSAVE        ERASE   +1              # B(2)TMP
REDOCTR         ERASE                   # B(1)PRM CONTAINS NUMBER OF RESTARTS
THETAD          ERASE   +2              # B(3)PRM DESIRED GIM ANGLES FOR MANEUVER
CPHI            =       THETAD          #       (OUTER)
CTHETA          =       THETAD +1       #       (INNER)
CPSI            =       THETAD +2       #       (MIDDLE)
```

Defines:

ALT, used in chunks 33, 35, 40, 305, 458, 470, 745, 749, 750, 837, 866, 872, 903, 921, 923, 925, 926, 932, 951, 977, 995, 997, 1001, 1015, 1049, 1051, 1052, 1054, 1147, 1200, 1254, 1256, 1675–77, 1679, 2219, 2382, 2420, 2422, 2424, and 2453.
COLREG, used in chunk 1814.
CPHI, used in chunks 425, 647, 658b, 660, 690, 691a, 963, 965, 973, 1200, 1412, 2148, 2152, 2156, 2165, 2167, 2169, 2441, 2446, 2510, and 2513.
CPSI, used in chunks 647, 653, 691a, 965, 973, 2148, 2152, 2156, 2165, 2167, 2510, and 2512.
CTHETA, used in chunks 647, 658b, 691a, 965, 973, 1412, 2148, 2152, 2156, 2165, 2167, 2510, 2512, and 2513.
DELAYLOC, used in chunks 327, 329, and 2001.
IRETURN1, used in chunks 1806, 1808, and 1810.
LANDLAT, used in chunks 44, 476, 923, and 1001.
LAT, used in chunks 40, 42, 107, 175, 224, 300, 302, 305, 470, 472, 474, 722, 745, 747, 749, 750, 866, 921, 923, 925, 926, 977, 995, 997, 1001, 1015, 1054, 1147, 1200, 1254, 1256, 1301, 1675–77, 1679, 1681, 2080, and 2299.
LONG, used in chunks 40, 42, 107, 175, 305, 370, 470, 474, 745, 747, 749, 750, 866, 921, 923, 925, 926, 977, 995, 997, 1001, 1015, 1147, 1200, 1227, 1254, 1256, 1301, 1460, 1616, 1675–77, 1681, 1931, 1961, 2080, 2299, 2542, and 2561.
LONGBASE, used in chunks 1893, 1894, 1896, 1902, and 1913.
LONGCADR, used in chunk 1663.
LONGTIME, used in chunks 1663 and 1913.
MARKCTR, used in chunks 820 and 823.
NVWORD1, used in chunks 1043, 1094, 1989, and 2287.
OPTION1, used in chunks 38, 454, 844, 1013, 1301, 1951, 1959, 1979, and 2148.
OPTION2, used in chunks 474, 747, 844, 846, 911, 1147, and 1301.
P30/RET, used in chunk 1047.
PRIOTIME, used in chunks 1959, 1973, and 1993.
RATEINDX, used in chunks 313, 682, 688, 1094, 1412, and 2165.
REDOCTR, used in chunks 297, 302, 311, and 317.
SCALSAVE, used in chunks 1941 and 1943.
TDEC, used in chunks 131, 747, 1794, 1796, 1798, 1800, 1808, 1810, 1814, and 2098.
TEMPR60, used in chunks 647, 649, 1094, 2293, and 2353.
THETAD, used in chunks 28, 38, 95, 159, 229, 297, 302, 410, 423, 454, 704, 967, 975, 1013, 1094, 1147, 1200, 1839, 1840, 1920, 1921, 2027, and 2197.
TIME2SAV, used in chunks 159, 357, 1941, and 1944a.
TRKMKCNT, used in chunks 313, 754, 761, 779, 842, 850, 852, 915, 945, 951, 1063, 1227, 1301, 1804, 2219, 2223, 2258, 2279, and 2353.
VHFCNT, used in chunks 40, 300, 313, 470, 823, 915, 945, 951, 1227, and 1301.
YV, used in chunk 1814.
ZV, used in chunk 1814.

Uses I 206, RESTART 57, and SAVE 191.

159 ⟨*Page CM0079* 159⟩≡ (75 2684)

```
# ENTRY VARIABLES SHARED FOR TM.
RDOTREF         =       THETAD          # I(2)  P65
VREF            =       RDOTREF +2      # I(2)  P65     HI-ORDER WORD ONLY DNLNK'D
DESOPTT         ERASE                   # B(1)DSP NOUN 92 FOR P20,22,52, R52.
DESOPTS         ERASE                   # B(1)DSP NOUN 92 FOR P20,22,52, R52.

DELV            ERASE   +5              # I(6)
DELVX           =       DELV
DELVY           =       DELV    +2
DELVZ           =       DELV    +4

# P20, CONICS   (SHARING WITH TIME 2 SAV AND SCAL SAV ONLY)     (3D)
POINTEX         EQUALS  TIME2SAV        # I(1) POINT AXS EXIT
VHFTIME         EQUALS  POINTEX +1      # I(2) DOWNLINK OF VHF RANGE TIME +1M

# PERM STATE VECTORS FOR BOOST AND DOWNLINK -- WHOLE MISSION -- (14D)

RN              ERASE   +5              # B(6)PRM
VN              ERASE   +5              # B(6)PRM
PIPTIME         ERASE   +1              # B(2)PRM (MUST BE FOLLOWED BY GDT/2)

# SERVICER STORAGE.                             (45D)

# (SERVICER STORAGE AND P11 STORAGE IN UNSWITCHED SHOULD NOT
# OVERLAY EACH OTHER AND THE TOTAL ERASABLE REQUIRED SHOULD NOT
# EXCEED THE ERASABLE STORAGE REQUIRED BY RENDEZVOUS GUIDANCE.)

GDT/2           EQUALS  PIPTIME +2      # B(6)TMP       ** MUST FOLLOW PIPTIME **
GOBL/2          EQUALS  GDT/2   +6      # B(6)TMP
AVEGEXIT        EQUALS  GOBL/2  +6      # B(2)TMP
AVGEXIT         =       AVEGEXIT
TEMX            EQUALS  AVEGEXIT +2     # B(1)TMP
TEMY            EQUALS  TEMX +1         # B(1)TMP
TEMZ            EQUALS  TEMY +1         # B(1)TMP
PIPCTR          EQUALS  TEMZ +1         # B(1)TMP
PIPAGE          EQUALS  PIPCTR +1       # B(1)TMP
RN1             EQUALS  PIPAGE +1       # B(6)TMP
VN1             EQUALS  RN1 +6          # B(6)TMP
PIPTIME1        EQUALS  VN1 +6          # B(2)TMP
GDT1/2          EQUALS  PIPTIME1 +2     # B(6)TMP
GOBL1/2         EQUALS  GDT1/2 +6       # B(6)TMP
```

Defines:
`AVEGEXIT`, used in chunks 1094, 1200, 1291, 1487, 2260, 2269, and 2279.
`AVGEXIT`, used in chunks 858, 868, 1227, 2275, 2277, 2343, and 2382.

DELV, used in chunks 197, 224, 232, 295, 303, 1045, 1049, 1051, 1052, 1227, 1245, 1256, 1484, 2046, 2047, 2219, 2382, 2426, and 2444.
DELVX, used in chunks 493, 495, 496, 712, 716, 717, 1227, 2203–5, and 2382.
DELVY, used in chunks 495, 716, 1227, 2204, and 2382.
DELVZ, used in chunks 495, 496, 716, 1227, 2204, and 2382.
DESOPTS, used in chunks 191, 290, 292, 412, 739, and 1147.
DESOPTT, used in chunks 191, 290, 292, 412, 741, and 1147.
GDT/2, used in chunks 1094, 1227, 1245, 2299, 2311, 2382, 2426, and 2428.
GDT1/2, used in chunks 1227, 2353, 2361, and 2382.
GOBL/2, used in chunks 1094 and 1227.
GOBL1/2, used in chunks 161 and 1227.
PIPAGE, used in chunks 1227 and 2382.
PIPCTR, used in chunks 1227, 1250, 2343, 2382, and 2420.
PIPTIME, used in chunks 133, 295, 485, 814, 818, 1054, 1094, 1200, 1227, 1256, 1481, 1487, 1804, 1805, 2098, 2143, 2299, 2306, 2311, 2371, 2373, 2375, 2382, and 2426.
PIPTIME1, used in chunks 295, 303, 503, 1094, 1200, 1227, 1806, 1808, 2265, 2299, 2311, and 2382.
POINTEX, used in chunks 955, 1023, and 1024.
RDOTREF, used in chunks 1248, 1250, and 1256.
RN, used in chunks 133, 295, 442, 485, 814, 818, 835, 858, 884, 1094, 1200, 1227, 1245, 1256, 1804, 1805, 1852, 2098, 2143, 2299, and 2382.
RN1, used in chunks 73, 866, 1200, 1227, 1808, and 2382.
TEMX, used in chunks 1227, 2311, and 2382.
TEMY, used in chunks 1227, 2311, and 2382.
TEMZ, used in chunks 1227, 2311, and 2382.
VHFTIME, used in chunks 300, 941, 943, and 957.
VN, used in chunks 133, 161, 295, 332, 400, 411, 412, 414, 418, 428, 440, 442, 485, 499, 619, 650, 708, 733, 737, 739, 743, 750, 783, 804, 808, 813, 814, 818, 829, 835, 856, 858, 884, 886, 912, 921, 929, 932, 953, 1009, 1014, 1037, 1042a, 1048, 1063, 1094, 1147, 1200, 1227, 1245, 1256, 1291, 1299, 1301, 1344, 1640, 1804, 1805, 1852, 1999, 2000a, 2015, 2098, 2118, 2132, 2141, 2143, 2148, 2201, 2213, 2219, 2223, 2260, 2262, 2263, 2294, 2299, 2311, 2379, 2380, 2382, and 2426.
VN1, used in chunks 868, 1200, 1227, 1806, 1808, 2267, and 2382.
VREF, used in chunks 1248 and 1256.

Uses CONICS 61, I 206, RANGE 179, STATE 138, THETAD 157, TIME2SAV 157, and TM 219.

161 ⟨*Page CM0080* 161⟩≡ (75 2684)

```
# ENTRY STORAGE                          (1D)
ENTRYVN         EQUALS  GOBL1/2 +6      # B(1)TMP VN CODE FOR ENTRY DISPLAYS P60'S.

# P11 STORAGE.                           (9D)
PADLONG         EQUALS  ENTRYVN         # (2)PL LONGITUDE OF LAUNCH PAD.
LIFTTEMP        EQUALS  PADLONG +2      # (2)TMP
TEPHEM1         EQUALS  LIFTTEMP +2     # (3)TMP
PGNCSALT        EQUALS  TEPHEM1 +3      # (2)PL ALTITUDE

# RENDEZVOUS NAVIGATION STORAGE.  (SEE COMMENT IN SERVICER STORAGE)     (58D)
CSMPOS          ERASE   +57D            # I(6)TMP
LEMPOS          EQUALS  CSMPOS  +6      # I(6)TMP
RCL             EQUALS  LEMPOS  +6      # I(2)TMP
MARKTIME        EQUALS  RCL     +2      # B(2)TMP
VTEMP           EQUALS  MARKTIME +2     # B(6)TMP
UM              EQUALS  VTEMP   +6      # I(6)TMP
MARKDATA        EQUALS  UM      +6      # B(2)TMP
USTAR           EQUALS  MARKDATA +2     # I(6)TMP
WIXA            EQUALS  USTAR   +6      # B(1)TMP
WIXB            EQUALS  WIXA    +1      # B(1)TMP
ZIXA            EQUALS  WIXB    +1      # B(1)TMP
ZIXB            EQUALS  ZIXA    +1      # B(1)TMP
DELTAX          EQUALS  ZIXB    +1      # I(18)TMP

VHFRANGE        EQUALS  DELTAX          # (2)
UCL             EQUALS  DELTAX  +12D    # (6)   LM-CSM LINE OF SIGHT 1/2 UNIT V

# **** CONICSEX (MEAS INC) ****
TRIPA           EQUALS  DELTAX
TEMPVAR         EQUALS  DELTAX  +3

TEMPOR1         ERASE   +1              # B(2)TMP

# T4RUPT ERASABLE                        (6D)

DSRUPTSW        ERASE
OPTIND          ERASE
LGYRO           ERASE
COMMANDO        ERASE   +1
```

Defines:
COMMANDO, used in chunks 290, 292, and 293a.
CSMPOS, used in chunks 945, 949, 951, 977, 981, 991, 993, 995, 997, and 999.
DELTAX, used in chunks 947, 993, 1009, 1027, 1693, 1698, 1699, and 1705.
DSRUPTSW, used in chunks 249, 251, 253, 255, 256, 311, and 327.
ENTRYVN, used in chunks 117, 1200, and 1256.

LEMPOS, used in chunks 945, 949, 951, and 1009.
LGYRO, used in chunks 329, 729, 1927–30, and 1932.
LIFTTEMP, used in chunks 862 and 870.
MARKDATA, used in chunks 224, 939, 941, 981, 1021, and 1023.
MARKTIME, used in chunks 300, 917, 941, 943, 955, 957, 1021, 1023, 1024, and 2139.
OPTIND, used in chunks 52, 281, 284, 285, 288, 290, 292, 293a, 313, 347, 386, 412, 434, 650, 741, 1094, and 1147.
PADLONG, used in chunks 860 and 866.
PGNCSALT, used in chunks 860 and 866.
RCL, used in chunks 991 and 993.
TEMPOR1, used in chunks 937, 953, 977, and 989.
TEMPVAR, used in chunks 1695 and 1697.
TEPHEM1, used in chunks 862 and 864.
TRIPA, used in chunks 1695 and 1697.
UCL, used in chunks 937 and 945.
UM, used in chunks 937, 939, 945, 977, 981, 983, 985, 989, 991, 995, and 999.
USTAR, used in chunks 937, 945, 977, and 991.
VHFRANGE, used in chunks 949, 957, and 959.
VTEMP, used in chunk 941.
WIXA, used in chunks 1699, 1701, and 1703.
WIXB, used in chunks 1699, 1701, and 1703.
ZIXA, used in chunks 1699, 1701, and 1703.
ZIXB, used in chunks 1699, 1701, and 1703.

Uses CODE 140, DISPLAYS 59, GOBL1/2 159, I 206, V 229, and VN 159.

163 ⟨*Page CM0081* 163⟩≡ (75 2684)

```
ZONE            ERASE                   # B(1)PRM USED IN SHAFT STOP MONITOR
LASTYCMD        =       OPTY            # DUMMY TO MAKE RR BENCH TEST ASSEMBLE
LASTXCMD        =       OPTY            # DUMMY TO MAKE RR BENCH TEST ASSEMBLE

# UNSWITCHED DAP ERASABLE.              (4D)
T6LOC           ERASE
T6ADR           ERASE
T5LOC           ERASE   +1

# MODE SWITCHING ERASABLE               (14D)
SWSAMPLE        ERASE                   # B(1)PRM
DESOPMOD        ERASE                   # B(1)PRM
WTOPTION        ERASE                   # B(1)PRM
ZOPTCNT         ERASE                   # B(1)PRM
IMODES30        ERASE                   # B(1)PRM
IMODES33        ERASE                   # B(1)PRM
MODECADR        ERASE   +2              # B(3)TMP
IMUCADR         =       MODECADR
OPTCADR         =       MODECADR +1
RADCADR         =       MODECADR +2
ATTCADR         ERASE   +2              # B(3)PRM
ATTPRIO         =       ATTCADR +2
MARKSTAT        ERASE                   # B(1)PRM
OPTMODES        ERASE                   # B(1)PRM

# RCSDAP ERASABLE                       (1D)
HOLDFLAG        ERASE                   # B(1)PRM

# CRS61.1 STORAGE.  -- USED IN R63 (VERB 89) -- (5D)
CPHIX           ERASE   +2              # B(3)DSP NOUN 95 CALCULATED BY CRS61.1

TEVENT          ERASE   +1              # B(2) TIME OF EVENT FOR DOWNLIST
TLIFTOFF        =       TEVENT
```

Defines:
ATTCADR, used in chunks 329, 690, and 1938.
ATTPRIO, used in chunks 690 and 1938.
CPHIX, used in chunks 28, 38, 44, 45, 95, 405, 416, 454, 478, 973, 975, and 1412.
DESOPMOD, used in chunks 281 and 285.
HOLDFLAG, used in chunks 295, 298, 300, 302, 304, 662, 684, 688, 915, 918, 963, 965, 973, 1094, 1412, 1434, 1436, 1438, and 1441.
IMODES30, used in chunks 257–59, 261, 263, 267–72, 274, 276, 278, 279, 297, 302, 313, 319, 335, 642, 644, 1147, 1918, 1919, 1923, 1925, 1926, 1934, and 1939.
IMODES33, used in chunks 254, 263, 265–67, 274, 277–80, 287, 297, 302, 313, 319, 640, 642, 644, 1412, 1481, 1918, 1919, 1923–25, 2343, 2420, 2422, 2424, 2426, 2438, and 2504.
IMUCADR, used in chunks 329, 1663, 1934, and 2116.
LASTXCMD, never used.

LASTYCMD, never used.
MARKSTAT, used in chunks 15, 329, 382, 384, 386, 390, 392, 394, 396–98, 400, 448, 741, 743, 921, 929, 977, 979, 1021, 1147, 2121–23, 2130, 2134, 2136, and 2138–42.
MODECADR, used in chunks 414, 416, and 1935–37.
OPTCADR, used in chunks 329, 412, and 1147.
OPTMODES, used in chunks 264, 281, 282, 285–88, 295, 298, 300, 302, 304, 313, 319, 386, 642, 644, and 2001.
RADCADR, used in chunk 329.
SWSAMPLE, used in chunks 281, 282, 284, 285, 288, 412, and 1147.
T5LOC, used in chunks 249, 313, 319, 437, 890, 891, 1094, 1347, 1367, 1373, 1412, 1450a, 1475, 1485, 1488, 1492, and 1521.
T6ADR, used in chunk 2496.
T6LOC, used in chunks 247, 1396, 1412, and 1485.
TEVENT, used in chunks 295, 298, 1094, 2273, and 2343.
TLIFTOFF, used in chunks 860, 862, 864, 866, and 870.
WTOPTION, used in chunks 282, 284, 286, and 311.
ZONE, used in chunks 286, 288, 290, 754, 761, 1497, 1508, 1518, 2152, 2154, 2561, 2574, 2588, and 2625.
ZOPTCNT, used in chunks 282, 284, and 285.

Uses MODE 145 and OPTY 80.

165 ⟨*Page CM0082* 165⟩≡ (75 2684)

```
# P34-P35 STORAGE                        (1D)
NORMEX          ERASE

# SELF-CHECK ASSIGNMENTS                 (17D)

SELFERAS        ERASE   1357 - 1377     # *** MUST NOT BE MOVED *** #
SFAIL           EQUALS  SELFERAS        # B(1)
ERESTORE        EQUALS  SFAIL +1        # B(1)
SELFRET         EQUALS  ERESTORE +1     # B(1) RETURN
SMODE           EQUALS  SELFRET +1      # B(1)
ALMCADR         EQUALS  SMODE +1        # B(2) ALARM ABORD USER'S 2CADR
ERCOUNT         EQUALS  ALMCADR +2      # B(1)
SCOUNT          EQUALS  ERCOUNT +1      # B(3)
SKEEP1          EQUALS  SCOUNT +3       # B(1)
SKEEP2          EQUALS  SKEEP1 +1       # B(1)
SKEEP3          EQUALS  SKEEP2 +1       # B(1)
SKEEP4          EQUALS  SKEEP3 +1       # B(1)
SKEEP5          EQUALS  SKEEP4 +1       # B(1)
SKEEP6          EQUALS  SKEEP5 +1       # B(1)
SKEEP7          EQUALS  SKEEP6 +1       # B(1)

# USED BY P30 ROUTINES TO WRITE ONLY NEVER READ IN COLOSSUS

DISPDEX         EQUALS  A

# ERASABLE FOR SXTMARK CDU CHECK DELAY.  -- PAD LOADED --       (1D)

CDUCHKWD        ERASE                   # B(1)PL

# R57 STORAGE. -- MUST BE UNSHARED EXCEPT IN BOOST OR ENTRY --  (1D)

TRUNBIAS        ERASE                   # B(1)PRM RESULT OF R57 CALIBR OF TRUNION

# KEPLER STORAGE                                 (6D)

XMODULO         ERASE   +1              # I(2) GREATER 2PI KEPLER
TMODULO         ERASE   +1              # I(2) GREATER 2 KEPLER
EPSILONT        ERASE   +1              # I(2)TMP
```

Defines:
ALMCADR, used in chunks 38, 454, 1876, 2007, 2009, 2011, 2013, and 2482.
CDUCHKWD, used in chunks 400 and 402.
DISPDEX, used in chunks 779, 780, 2223, 2267, 2269, 2271, 2275, 2277, 2281, 2283, 2285, 2287, 2289, 2291, and 2343.
EPSILONT, used in chunks 1731, 1769, and 1770.
ERCOUNT, used in chunks 311, 1876, and 2482.

ERESTORE, used in chunks 311, 317, 1876, 1880, 1882, 2482, 2486, and 2488.
NORMEX, used in chunks 763, 765, 770a, 773, 774, 781, 786, 793, 798, 800a, 895, 897, 1063, and 2223.
SCOUNT, used in chunks 1878, 1884, 2484, and 2490.
SELFERAS, used in chunk 166.
SELFRET, used in chunks 329, 440, 1661, 1876, 1878, 2482, and 2484.
SFAIL, used in chunks 645, 1876, 1878, 2482, and 2484.
SKEEP1, used in chunks 440, 1876, 1878, 1884, 1886, 1889, 2482, 2484, 2490, 2492, and 2495a.
SKEEP2, used in chunks 440, 1880, 1882, 1884, 1886, 2486, 2488, 2490, and 2492.
SKEEP3, used in chunks 440, 1880, 1882, 1884, 1886, 1888, 2484, 2486, 2488, 2490, 2492, and 2494.
SKEEP4, used in chunks 317, 1878, 1880, 1882, 1884, 1888, 1889, 2484, 2486, 2488, 2490, 2494, and 2495a.
SKEEP5, used in chunks 317, 1876, 1878, 1880, 1882, 1884, 1886, 1888, 2482, 2484, 2486, 2488, 2490, 2492, and 2494.
SKEEP6, used in chunks 317, 440, 1878, 1880, 1884, 1888, 1889, 2484, 2486, 2490, 2494, and 2495a.
SKEEP7, used in chunks 317, 1876, 1878, 1880, 1882, 1884, 1886, 1888, 2482, 2484, 2486, 2488, 2490, 2492, and 2494.
SMODE, used in chunks 38, 311, 440, 454, 1872, 1874, 1876, 1878, 2478, 2480, 2482, and 2484.
TMODULO, used in chunk 1715.
TRUNBIAS, used in chunks 929 and 1025.
XMODULO, used in chunk 1715.

Uses A 80, I 206, and TRUNION 190.

166 ⟨*Page CM0083* 166⟩≡ (75 2684)

```
# P37   ** RETURN TO EARTH (PAD LOAD ****       (2D)

RTED1           ERASE   +1              # I(2)PL VGAMMA POLY COEF              B-3

# P40   *** STEERING ROUTINE *** PAD LOAD       (1D)

DVTHRESH        ERASE                   # I(1)PL DELTA VTHRESHOLD FOR LOW THRUST
                                        #        ROUTINE                       B-2

# P23   *** PAD LOAD ****               (2D)

HORIZALT        ERASE   +1              # I(2)PL HORIZON ALTITUDE           M B-29

# P20   ALTERNATE LOS VARIANCE  PAD LOAD ****   (1D)
                                                                            -16
ALTVAR          ERASE                   # I(2)PL MILLARD, SQUARED SCALED 2
END-UE          EQUALS  SELFERAS +16D   # LAST USED UNSWITCHED ERASABLE
```

Defines:
ALTVAR, used in chunk 951.
DVTHRESH, used in chunk 1094.
END-UE, never used.
HORIZALT, used in chunk 1029.
RTED1, used in chunk 1301.

Uses HORIZON 190, I 206, SELFERAS 165, THRUST 85, and VARIANCE 232.

167 ⟨*Page CM0084* 167⟩≡ (75 2684)

```
# EBANK-3 ASSIGNMENTS

                SETLOC  1400

# WAITLIST TASK LISTS.                  (26D)

LST1            ERASE   +7              # B(8D)PRM DELTA T'S.
LST2            ERASE   +17D            # B(18D)PRM TASK 2CADR ADDRESSES.

# RESTART STORAGE.                      (2D)

RSBBQ           ERASE   +1              # B(2)PRM SAVE BB AND Q FOR RESTARTS

# MORE LONGCALL STORAGE.  (MUST BE IN LST1'S BANK.      (2D)

LONGEXIT        ERASE   +1              # B(2)TMP MAY BE SELDOM OVERLAYED

# PHASE-CHANGE LISTS PART II.           (12D)


PHSNAME1        ERASE                   # B(1)PRM
PHSBB1          ERASE                   # B(1)PRM
PHSNAME2        ERASE                   # B(1)PRM
PHSBB2          ERASE                   # B(1)PRM
PHSNAME3        ERASE                   # B(1)PRM
PHSBB3          ERASE                   # B(1)PRM
PHSNAME4        ERASE                   # B(1)PRM
PHSBB4          ERASE                   # B(1)PRM
PHSNAME5        ERASE                   # B(1)PRM
PHSBB5          ERASE                   # B(1)PRM
PHSNAME6        ERASE                   # B(1)PRM
PHSBB6          ERASE                   # B(1)PRM

# IMU COMPENSATION PARAMETERS           (22D)

PBIASX          ERASE                   # B(1)  PIPA BIAS, PIPA SCALE FACTOR TERMS
PIPABIAS        =       PBIASX          #       INTERMIXED.
PIPASCFX        ERASE
PIPASCF         =       PIPASCFX
PBIASY          ERASE
PIPASCFY        ERASE
PBIASZ          ERASE
PIPASCFZ        ERASE

NBDX            ERASE                   # GYRO BIAS DRIFT
```

```
GBIASX          =       NBDX
NBDY            ERASE
```

Defines:
GBIASX, never used.
LONGEXIT, used in chunk 1663.
LST1, used in chunks 249, 311, 325, 330, 1663, 1876, 1898, 1905, and 2482.
LST2, used in chunks 325, 327, 1663, 2295, and 2297.
NBDX, used in chunks 493, 495, 497, 501, 1227, 1663, and 2382.
NBDY, used in chunks 495 and 501.
PBIASX, used in chunk 2311.
PBIASY, used in chunk 2311.
PBIASZ, used in chunk 2311.
PHSBB1, never used.
PHSBB2, never used.
PHSBB3, never used.
PHSBB4, never used.
PHSBB5, never used.
PHSBB6, never used.
PHSNAME1, used in chunks 349, 1900, 1903, 1905, and 1909.
PHSNAME2, used in chunk 2311.
PHSNAME3, used in chunk 2311.
PHSNAME4, never used.
PHSNAME5, used in chunks 1299 and 2382.
PHSNAME6, never used.
PIPABIAS, used in chunk 493.
PIPASCF, used in chunk 493.
PIPASCFX, never used.
PIPASCFY, never used.
PIPASCFZ, never used.
RSBBQ, used in chunks 297, 302, and 317.
Uses BIAS 211, EBANK 80, FACTOR 226, Q 80, RESTART 57, and SAVE 191.

169 ⟨*Page CM0085* 169⟩≡ (75 2684)

```
NBDZ            ERASE

ADIAX           ERASE                   # ACCELERATION SENSITIVE DRIFT ALONG THE
ADIAY           ERASE                   # INPUT AXIS
ADIAZ           ERASE

ADSRAX          ERASE                   # ACCELERATION SENSITIVE DRIFT ALONG THE
ADSRAY          ERASE                   # SPIN REFERENCE AXIS
ADSRAZ          ERASE

GCOMP           ERASE   +5              # CONTAINS COMPENSATING TORQUES

GCOMPSW         ERASE
COMMAND         EQUALS  GCOMP
CDUIND          EQUALS  GCOMP   +3

# STATE VECTORS FOR ORBIT INTEGRATION.  (44D)

#               (DIFEQCNT THUR XKEP MUST BE IN THE SAME
#               EBANK AS RRECTCSM, RRECTLEM ETC
#               BECAUSE THE COPY CYCLES (ATOPCSM,
#               PTOACSM ETC) ARE EXECUTED IN BASIC.
#               ALL OTHER REFERENCES TO THIS GROUP
#               ARE BY INTERPRETIVE INSTRUCTIONS.)
#

DIFEQCNT        ERASE   +43D            # B(1)TMP
# (UPSVFLAG...XKEP MUST BE KEPT IN ORDER).

UPSVFLAG        EQUALS  DIFEQCNT +1     # B(1)PRM UPDATE FLAG
RRECT           EQUALS  UPSVFLAG +1     # B(6)TMP POS AT RECT           KM*2(-14)
VRECT           EQUALS  RRECT   +6      # B(6)TMP VEL AT RECT           KM(-1/2)*2(6)
TET             EQUALS  VRECT   +6      # B(2)TMP TIME OF STATE VECT    CSPCS*2(-28)
TDELTAV         EQUALS  TET     +2      # B(6)TMP POSITION DEVIATION    KM*2(14)
TNUV            EQUALS  TDELTAV +6      # B(6)TMP VEL DEVIATION         KM(-1/2)*2(14)
RCV             EQUALS  TNUV    +6      # B(6)TMP CONIC POSITION        KM*2(-14)
VCV             EQUALS  RCV     +6      # B(6)TMP CONIC VELOCITY        KM(-1/2)*2(6)
TC              EQUALS  VCV     +6      # B(2)TMP TIME SINCE RECTIFICATION
XKEP            EQUALS  TC      +2      # B(2)TMP ROOT OF KEPLER EQ     KM(1/2)*2(-10)

# **** TEMP -- IN VAC AREA ****
RRECT1          EQUALS  18D
VRECT1          EQUALS  24D
TET1            EQUALS  30D
```

```
# PERMANENT STATE VECTORS AND TIMES.    (101D)

# (DO NOT OVERLAY WITH ANYTHING AFTER BOOST)
```

Defines:
ADIAX, used in chunk 495.
ADIAY, used in chunk 495.
ADIAZ, used in chunk 496.
ADSRAX, used in chunk 495.
ADSRAY, used in chunk 495.
ADSRAZ, used in chunks 495 and 496.
CDUIND, used in chunks 261, 263, 268, 319, 1918, 1920–22, 1924, 1927, and 1932.
COMMAND, used in chunks 35, 85, 272, 290, 292, 293a, 307, 421, 458, 460, 658b, 691a, 888, 1094, 1200, 1248, 1254, 1256, 1356, 1373, 1412, 1460, 1468, 1504, 1518, 1917, 1920–22, 1927, 1930–33, 2060, 2061, 2063, 2064a, 2106, 2281, 2306, 2420, 2440, 2441, 2509, 2515, 2519, 2542, 2590, and 2592.
DIFEQCNT, used in chunks 1784, 1786, 1814, and 2748.
GCOMP, used in chunks 497–99, 503, 712, 1147, and 2203.
GCOMPSW, used in chunks 493, 495, 497, 498, 501–3, 712, and 2203.
NBDZ, used in chunks 496 and 501.
RCV, used in chunks 485, 749, 775, 792, 816, 822, 1301, 1705, 1714, 1735, 1736, 1765, 1774, 1778, 1788, 1798, 1804, 1812, 1814, 2143, and 2299.
RRECT, used in chunks 822, 1713, 1727, 1765, 1782, 1784, 1786, 1796, 1804, 1812, and 1814.
RRECT1, never used.
TC, used in chunks 252–56, 258, 261, 263, 264, 266–70, 272, 274, 276–79, 281, 282, 284–88, 292, 293a, 309, 311, 313, 315, 317, 319, 321, 323, 325, 329, 331, 333, 335, 337, 339, 341, 343, 345, 347, 349, 351, 364, 378, 380, 382, 384, 386, 389, 392, 394, 396–98, 400, 402, 403, 405, 407–12, 414, 416–21, 423–26, 428, 430–34, 436–38, 440, 442, 444, 446, 448, 452, 481, 487, 495–99, 501, 503, 519, 521, 523, 525, 527, 529, 531, 533, 535, 537, 539, 541, 543, 544, 547, 549, 551, 553, 555, 557, 559, 561, 563, 565, 567–69, 571, 573, 575, 577, 579, 581, 583, 585, 587, 589–91, 593, 595–97, 599, 601, 603, 605, 607, 609, 611–13, 615, 617, 619, 621, 623, 625, 627, 629–31, 633, 635, 637–40, 642, 644, 645, 647, 649, 650, 658b, 660, 662, 681a, 684, 686, 688–94, 696, 698, 700, 702–6, 708, 712–14, 716, 717, 722, 724, 725, 729, 731–33, 735, 737, 739, 741, 743, 747, 750, 756, 758, 759, 762, 777, 779–82, 804, 808, 810, 818, 820, 822, 823, 825, 827, 829, 831, 833, 835, 836, 844, 846, 850, 852, 856, 864, 866, 868, 870, 872, 876, 882, 884, 886, 888, 890, 891, 909, 911, 912, 915, 917–19, 921, 923, 925–27, 929, 930, 932, 934, 936, 941, 951, 953, 955, 957, 959, 967, 969, 973, 979, 989, 993, 995, 997, 1013–15, 1017, 1019, 1021, 1023, 1025, 1027, 1029, 1037, 1039, 1042a, 1043, 1045, 1047, 1048, 1062a, 1063, 1094, 1147, 1200, 1227, 1256, 1291, 1297, 1299–1301, 1344, 1347, 1356, 1362, 1367, 1373, 1390, 1410, 1412, 1434, 1441, 1449, 1451, 1477, 1479, 1481, 1483–87, 1489, 1491–93, 1495–98, 1500, 1502, 1504, 1506, 1508, 1510, 1512, 1516, 1518, 1519, 1521, 1528, 1530, 1532, 1538–43, 1546, 1557, 1559, 1567–70, 1572–82, 1584, 1585, 1588–96, 1598, 1601, 1604b, 1606–10, 1612, 1614–16, 1618, 1620, 1621, 1623, 1625–34, 1637a, 1647, 1652, 1653, 1659–61, 1663, 1699, 1701, 1703, 1707, 1714, 1731, 1733, 1735–37, 1740, 1748, 1764, 1765, 1772, 1780, 1782, 1784, 1786, 1788, 1794, 1796, 1802, 1808, 1810, 1812–14, 1840, 1844, 1852, 1876, 1878, 1880, 1882, 1884, 1886, 1888, 1889, 1891, 1893, 1894, 1896, 1905, 1907, 1909, 1913, 1917–27, 1929, 1932, 1934–41, 1943–47, 1950–59, 1962, 1963, 1965, 1967, 1969, 1971, 1973, 1975, 1977, 1979, 1981, 1983, 1985, 1987, 1989, 1991, 1993, 1995, 1997, 2001, 2007, 2009, 2011, 2013, 2015, 2027, 2035, 2108, 2114, 2116, 2121–24, 2130, 2132, 2134, 2136–39, 2141–43, 2148, 2156, 2167, 2177, 2188a, 2189, 2191, 2193, 2195–99, 2201, 2203–5, 2209, 2211, 2213, 2217, 2219, 2223, 2256, 2258, 2263, 2265, 2267, 2269, 2271, 2273, 2275, 2277, 2279, 2281, 2283, 2285, 2287, 2289, 2291, 2293, 2295, 2299, 2306, 2311, 2343, 2353, 2359, 2371, 2375, 2377, 2379, 2381, 2382, 2420, 2422, 2424, 2428, 2438, 2443, 2444, 2446, 2448, 2452–58, 2465, 2467, 2469, 2474, 2475a, 2482, 2484, 2486, 2488, 2490, 2492, 2494–96, 2499b, 2500, 2502, 2503a, 2505, 2509, 2512–14, 2517–19,

2542, 2561, 2574, 2588, 2590, 2596, 2598–2601, 2605, 2607, 2609, 2611, 2613, 2615, 2617, 2621, 2625, 2641, 2692, 2700, 2749, 2765, and 2766.
TDELTAV, used in chunks 485, 1705, 1788, 1792, 1812, 1814, and 2143.
TET, used in chunks 38, 424, 456, 485, 749, 775, 792, 816, 822, 1301, 1774, 1778, 1780, 1788, 1796–98, 1800, 1804, 1810, 1814, 2143, and 2299.
TET1, never used.
TNUV, used in chunks 485, 486, 1705, 1788, 1792, 1812, 1814, and 2143.
UPSVFLAG, used in chunks 311, 1812, and 1813a.
VCV, used in chunks 485, 486, 749, 775, 792, 816, 822, 1301, 1705, 1714, 1736, 1765, 1774, 1778, 1788, 1812, 1814, 2143, and 2299.
VRECT, used in chunks 1714, 1727, 1735, 1736, 1765, 1796, 1812, and 1814.
VRECT1, never used.
XKEP, used in chunks 188, 1731, 1765, 1767, 1812, and 1814.
Uses EBANK 80, RRECTCSM 172, RRECTLEM 172, STATE 138, TEMP 191, and VEL 226.

172 ⟨*Page CM0086* 172⟩≡ (75 2684)

```
# (RRECTCSM...XKEPCSM MUST BE KEPT IN THIS ORDER)

RRECTCSM        ERASE   +5              # B(6)PRM CSM VARIABLES
RRECTHIS        =       RRECTCSM
VRECTCSM        ERASE   +5              # B(6)PRM
TETCSM          ERASE   +1              # B(2)PRM
TETTHIS         =       TETCSM
DELTACSM        ERASE   +5              # B(6)PRM
NUVCSM          ERASE   +5              # B(6)PRM
RCVCSM          ERASE   +5              # B(6)PRM
VCVCSM          ERASE   +5              # B(6)PRM
TCCSM           ERASE   +1              # B(2)PRM
XKEPCSM         ERASE   +1              # B(2)PRM

# (RRECTLEM...XKEPLEM MUST BE KEPT IN THIS ORDER)

RRECTLEM        ERASE   +5              # B(6)PRM LEM VARIABLES
RRECTOTH        =       RRECTLEM
VRECTLEM        ERASE   +5              # B(6)PRM
TETLEM          ERASE   +1              # B(2)PRM
TETOTHER        =       TETLEM
DELTALEM        ERASE   +5              # B(6)PRM
NUVLEM          ERASE   +5              # B(6)PRM
RCVLEM          ERASE   +5              # B(6)PRM
VCVLEM          ERASE   +5              # B(6)PRM
TCLEM           ERASE   +1              # B(2)PRM
XKEPLEM         ERASE   +1              # B(2)PRM

X789            ERASE   +5
TEPHEM          ERASE   +2
AZO             ERASE   +1
UNITW           ERASE   +5
-AYO            EQUALS  UNITW           # (2)
AXO             EQUALS  UNITW +2        # (2)

# STATE VECTORS FOR DOWNLINK            (12D)

R-OTHER         ERASE   +5              # B(6)PRM POS VECT (OTHER VECH) FOR DNLINK
V-OTHER         ERASE   +5              # B(6)PRM VEL VECT (OTHER VECH) FOR DNLINK

T-OTHER         =       TETLEM          #             TIME (OTHER VECH) FOR DNLINK

# REFSMMAT.                             (18D)

REFSMMAT        ERASE   +17D            # I(18D)PRM
```

Defines:
- `-AYO`, used in chunks 860, 1029, 1675, and 1684.
- `AXO`, used in chunks 860, 1029, 1675, 1677, and 1684.
- `AZO`, used in chunks 860, 1675, 1677, and 1684.
- `DELTACSM`, used in chunks 951, 999, and 1035.
- `DELTALEM`, used in chunk 951.
- `NUVCSM`, used in chunks 1035 and 1774.
- `NUVLEM`, never used.
- `R-OTHER`, used in chunks 297, 442, 485, 486, and 2143.
- `RCVCSM`, used in chunks 951, 999, and 1035.
- `RCVLEM`, used in chunk 951.
- `REFSMMAT`, used in chunks 52, 56a, 107, 272, 274, 295, 298, 315, 795, 812, 858, 860, 866, 868, 919, 939, 955, 961, 965, 969, 973, 977, 1021, 1094, 1147, 1200, 1227, 1293, 1295, 1344, 1923, 2015, 2080, 2112, 2114, 2116, 2118, 2148, 2213, 2265, 2299, 2311, 2353, and 2382.
- `RRECTCSM`, used in chunks 169, 359, 366, 1774, 1776, 1780, 1782, 1784, 1788, and 2353.
- `RRECTHIS`, used in chunks 442, 444, and 1782.
- `RRECTLEM`, used in chunks 169 and 1786.
- `RRECTOTH`, used in chunks 442 and 444.
- `T-OTHER`, used in chunks 297, 485, and 2143.
- `TCCSM`, used in chunks 1774 and 1776.
- `TCLEM`, never used.
- `TEPHEM`, used in chunks 174, 294, 366, 377, 858, 860, 862, 864, 870, 1195, 1675, 1677, 1684, and 2015.
- `TETCSM`, used in chunks 360, 1774, and 2015.
- `TETLEM`, used in chunks 2015 and 2223.
- `TETOTHER`, never used.
- `TETTHIS`, used in chunk 822.
- `UNITW`, used in chunks 489, 491, 868, 1200, 1227, 1245, 1256, and 1291.
- `V-OTHER`, used in chunks 297, 442, 485, 486, and 2143.
- `VCVCSM`, used in chunks 1035 and 1776.
- `VCVLEM`, never used.
- `VRECTCSM`, used in chunks 1774, 1776, and 2353.
- `VRECTLEM`, never used.
- `X789`, used in chunks 977, 983, 989, 991, 993, 995, 997, 999, 1705, and 1707.
- `XKEPCSM`, used in chunk 1776.
- `XKEPLEM`, never used.

Uses `I` 206, `STATE` 138, `V` 229, and `VEL` 226.

174 ⟨*Page CM0087* 174⟩≡ (75 2684)

```
# AVERAGEG INTEGRATOR STORAGE.          (8D)
UNITR           ERASE   +5
RMAG            ERASE   +1

# P40 PAD LOADS                         (6D)
EK1VAL          ERASE   +1              # I(2)PL 1-SEC SPS IMPULSE NEWTSEC/100/B23
EK2VAL          ERASE   +1              # I(2)PL  B+23 NEWTON-SEC/E+2
EK3VAL          ERASE                   # I(1)PL  B+09 NEWTONS/E+4
FANG            ERASE                   # I(1)PL SPS THRUST USED BY IMPULSIVE BURN

# **********LUNAR MODULE CHANGE  ***********
E3J22R2M        EQUALS  FANG    +2
E32C31RM        EQUALS  E3J22R2M +1

# **** CONICSEX (PLANETARY INERT. ORIEN.) ****
TIMSUBO         EQUALS  TEPHEM          # CSEC B-14 (TRIPLE PREC)
END-E3          EQUALS  E32C31RM        # NEXT UNUSED E3 ADDRESS
```

Defines:
E32C31RM, used in chunk 1814.
E3J22R2M, used in chunk 2027.
EK1VAL, used in chunk 1094.
EK2VAL, used in chunk 1094.
EK3VAL, used in chunk 1094.
END-E3, never used.
FANG, used in chunk 1094.
RMAG, used in chunks 1200, 1227, and 1852.
TIMSUBO, used in chunk 1684.
UNITR, used in chunks 1200, 1227, 1250, 1256, 1291, and 1295.
Uses I 206, TEPHEM 172, and THRUST 85.

175 ⟨*Page CM0088* 175⟩≡ (75 2684)

```
# EBANK-4 ASSIGNMENTS

                SETLOC  2000

# P20 STORAGE.  -- PAD LOADED --        (4D)

WRENDPOS        ERASE                   # B(1)PL        M B-14
WRENDVEL        ERASE                   # B(1)PL        M/CSECB0
RMAX            ERASE                   # B(1)PL        METERS*2(-19)
VMAX            ERASE                   # B(1)PL        M/CSEC*2(-7)

# P22 STORAGE.  -- PAD LOADED --        (5D)
WORBPOS         ERASE                   # B(1)PL        M B-14
WORBVEL         ERASE                   # B(1)PL        M/CSECB0
S22WSUBL        ERASE                   # B(1)PL        M B-14
RPVAR           ERASE   +1              # B(2)PL

# CONISEX STORAGE.  -- PAD LOADED --    (6D)

504LM           ERASE   +5              # I(6) MOON LIBRATION VECTOR

# ENTRY STORAGE     -- PAD LOADED --    (2D)
EMSALT          ERASE   +1              # I(2)PL

# P35 CONSTANTS.    -- PAD LOADED --    (4D)
ATIGINC         ERASE   +1              # B(2)PL
PTIGINC         ERASE   +1              # B(2)PL

# LUNAR LANDING SIGHT DATA.  -- PAD LOADED --   (6D)
# (USED BY INTEGRATION INITIALIZATION, LAT-LONG SUBROUTINES, P30'S)

RLS             ERASE   +5              # I(6) LANDING SIGHT VECTOR

# CONISEX (LUNAR AND SOLAR EPHEM) STORAGE.  -- PAD LOADED --    (77D)
TIMEMO          ERASE   +76D
VECOEM          EQUALS  TIMEMO  +3
RESO            EQUALS  VECOEM  +60D
```

Defines:
`504LM`, used in chunks 745, 1684, and 1814.
`ATIGINC`, used in chunks 762, 852, and 2209.
`EMSALT`, used in chunks 1200, 1254, and 1344.
`PTIGINC`, used in chunks 762 and 852.
`RESO`, used in chunks 177 and 1195.
`RLS`, used in chunks 99, 304, 799, 831, 835, 884, 921, 923, 925, 926, 997, 1147, 1682, 1786, 2299, and 2353.
`RMAX`, used in chunk 947.

RPVAR, used in chunk 985.
S22WSUBL, used in chunk 993.
TIMEMO, used in chunk 1195.
VECOEM, used in chunk 1195.
VMAX, used in chunks 947 and 2382.
WORBPOS, used in chunks 981 and 1039.
WORBVEL, used in chunks 981 and 1039.
WRENDPOS, used in chunks 943 and 1039.
WRENDVEL, used in chunks 943 and 1039.
Uses EBANK 80, EPHEM 65, I 206, LAT 157, and LONG 157.

177 ⟨*Page CM0089* 177⟩≡ (75 2684)

```
VESO            EQUALS  RESO    +6
OMEGAES         EQUALS  VESO    +6

# INTEGRATION STORAGE.                  (95D)

PBODY           ERASE                   # I(1)
ALPHAV          EQUALS  PBODY   +1      # I(6)TMP
BETAV           EQUALS  ALPHAV  +6      # I(6)TMP
PHIV            EQUALS  BETAV   +6      # I(6)TMP
PSIV            EQUALS  PHIV    +6      # I(6)TMP
FV              EQUALS  PSIV    +6      # I(6)TMP
BETAM           EQUALS  FV      +6      # I(6)TMP
H               EQUALS  BETAM   +2      # I(2)TMP
GMODE           EQUALS  H       +2              # I(1)TMP
IRETURN         EQUALS  GMODE   +1      # I(1)TMP
NORMGAM         EQUALS  IRETURN +1      # I(1)TMP
VECTAB          EQUALS  NORMGAM +1      # I(36)TMP
RPQV            EQUALS  VECTAB  +36D    #  (6)TMP VECTOR PRIMARY TO SECONDARY BODY
ORIGEX          EQUALS  RPQV    +6      # B(1)TMP QSAVE FOR COORD. SWITCH ROUTINE
KEPRTN          EQUALS  ORIGEX          #         QSAVE FOR KEPLER
RQVV            EQUALS  ORIGEX  +1      #  (6)    SEC. BODY TO VEH.VETOR (USED P23)
RPSV            EQUALS  RQVV    +6              #  (6)TMP SUN TO PRIMARY BODY VECTOR
XKEPNEW         EQUALS  RPSV    +6              #  (2)TMP ROOT OF KEPLER'S EQU FOR TIME TAU

# THESE PROBABLY CAN SHARE INTEGRATION VARIABLES        (9D)

VACX            EQUALS  VECTAB  +6      # I(2)TMP
VACY            EQUALS  VACX    +2      # I(2)TMP
VACZ            EQUALS  VACY    +2      # I(2)TMP

ERADM           EQUALS  VECTAB  +18D    # I(2)TMP
INCORPEX        EQUALS  ERADM   +2      # I(1)TMP

# R31 (V83) STORAGE. -- SHARES WITH INTEGRATION STORAGE --      (24D)

BASEOTP         EQUALS  VECTAB +6       # I(6) BASE POS VECTOR OTHER VEH
BASEOTV         EQUALS  VECTAB +18D     # I(6) BASE VEL VECTOR OTHER VEH
BASETHP         EQUALS  VECTAB +30D     # I(6) BASE POS VECTOR THIS VEH
BASETHV         EQUALS  RPQV            # I(6) BASE VEL VECTOR THIS VEH

# CONIC INTEGRATION STORAGE. -- MAY NOT SHARE WITH SERVICER --  (6D)
ALPHAM          EQUALS  XKEPNEW +2      # I(2)TMP
TAU.            EQUALS  ALPHAM  +2      # I(2)TMP
DT/2            EQUALS  TAU.    +2      # I(2)TMP
```

Defines:
ALPHAM, used in chunks 1675, 1676, and 1814.
ALPHAV, used in chunks 749, 923, 977, 981, 995, 997, 1029, 1056, 1147, 1200, 1256, 1301, 1675–77, 1679, 1682, 1814, and 2299.
BASEOTP, used in chunks 814 and 816.
BASEOTV, used in chunks 814 and 816.
BASETHP, used in chunk 814.
BASETHV, used in chunks 814 and 816.
BETAM, used in chunk 1814.
BETAV, used in chunk 1814.
DT/2, used in chunks 179, 1256, 1798, 1800, and 1814.
ERADM, used in chunks 977, 983, 985, 995, 999, 1200, 1676, 1677, 1679, and 1682.
FV, used in chunk 1814.
GMODE, never used.
H, used in chunks 20, 35, 38, 40, 42, 44, 46, 458, 858, 872, 901, 909, 911, 1063, 1094, 1200, 1439, 1443, 1445, 1663, 1814, 1852, 2223, 2306, 2343, 2361, 2371, 2382, 2561, and 2633.
INCORPEX, used in chunks 872, 1675–77, and 1679.
IRETURN, used in chunks 1790, 1792, 1794, and 1796.
KEPRTN, used in chunks 1714, 1735, 1736, and 1814.
NORMGAM, used in chunks 1697, 1701, 1703, and 1709.
OMEGAES, used in chunk 1195.
ORIGEX, used in chunk 1814.
PBODY, used in chunks 444, 1705, 1784, 1788, 1792, 1798, and 1814.
PHIV, used in chunk 1814.
PSIV, used in chunk 1814.
RPQV, used in chunk 1814.
RPSV, used in chunk 1814.
RQVV, used in chunk 1778.
TAU., used in chunks 1714, 1715, 1729, 1731, 1733, 1765, 1796, and 1814.
VACX, never used.
VACY, never used.
VACZ, never used.
VECTAB, used in chunk 1814.
VESO, used in chunks 1025 and 1195.
XKEPNEW, used in chunks 1714, 1729, and 1814.
Uses I 206, R31 67, RESO 175, TAU 211, and VEL 226.

179 ⟨*Page CM0090* 179⟩≡ (75 2684)

```
# P21, R61 STORAGE.                    (2D)
P21TIME         EQUALS  DT/2    +2      # B(2)TMP

# INTEGRATION STORAGE                  (1D)
EGRESS          EQUALS  P21TIME +2      # I(1)TMP SAVES RETURNS.

# VERB 83 STORAGE.                     (20D)

RANGE           EQUALS  EGRESS  +1      # I(2)DSP NOUN 54 DISTANCE TO OPTICAL SUBJ
RRATE           EQUALS  RANGE   +2      # I(2)DSP NOUN 54 RATE OF APPROACH
RTHETA          EQUALS  RRATE   +2      # I(2)DSP NOUN 54.
RONE            EQUALS  RTHETA  +2      # I(6)TMP VECTOR STORAGE.  (SCRATCH)
VONE            EQUALS  RONE    +6      # I(6)TMP VECTOR STORAGE.  (SCRATCH)
BASETIME        EQUALS  VONE    +6      # I(2)    BASE TIME ASSOC WITH BASE VECS

# S-BAND ANTENNA GIMBAL ANGLES.  DISPLAYED BY R05 (V64).        (4D)
#                        (OPERATES DURING P00 ONLY)
RHOSB           EQUALS  RANGE           # B(2)DSP NOUN 51. PITCH ANGLE
GAMMASB         EQUALS  RHOSB   +2      # B(2)DSP NOUN 51. YAWANGLE

# R36 SCRATCHPAD STORAGE               (13D)
RPASS36         EQUALS  RONE            # I(6) S-S
UNP36           EQUALS  RPASS36 +6      # I(6) S-S
OPTIONY         EQUALS  UNP36   +6      # I(1)TMP VEHICLE CODE

# EXTENDED VERB 82 STORAGE.            (6D)

HPERMIN         EQUALS  RANGE           # I(2) SET TO 300KFT OR 35KFT FOR SR30.1
RPADTEM         EQUALS  HPERMIN +2      # I(2) PAD OR LANDING RADIUS FOR SR30.1
TSTART82        EQUALS  RPADTEM +2      # I(2) TEMP TIME STORAGE VOR V82.

# MORE VERB 82 NOT SHARING WITH VERB 83 (9D)
V82FLAGS        EQUALS  VONE    +6      #  (1) FOR V 82 BITS
TFF             EQUALS  V82FLAGS +1     # I(2)DSP NOUN 50,44
-TPER           EQUALS  TFF     +2      # I(2)DSP NOUN 32
THETA(1)        EQUALS  -TPER   +2      # I(2)TMP SET AT END OF V82
```

Defines:
`-TPER`, used in chunks 38, 456, 827, 831, 833, 837, and 840a.
`BASETIME`, used in chunks 814 and 816.
`EGRESS`, used in chunks 927, 929, 937–39, 955, 1693, 1698, 1699, 1707, 1804, and 1805.
`GAMMASB`, used in chunks 40, 472, and 1344.
`HPERMIN`, used in chunks 827, 829, 831, 835, 837, 839, 840a, 903, 905, and 911.
`OPTIONY`, used in chunks 804 and 806.
`P21TIME`, used in chunks 438, 747, 749, 750, 965, 967, 969, 973, and 1013.
`RANGE`, used in chunks 28, 29, 33, 35, 40, 44, 119, 127, 131, 159, 229, 239, 300, 407, 430,

442, 456, 458, 472, 476, 555, 583, 802, 806, 810, 812, 943, 957, 959, 1042a, 1054, 1056, 1195, 1200, 1245, 1248, 1252, 1254, 1256, 1301, 1506, 1550, 1553a, 1623, 1627, 1676, 1680, 1852, 2046, 2064, 2094, 2103, 2105, 2311, 2353, 2382, 2420, 2428, 2430, and 2590.

`RHOSB`, used in chunks 40, 423, 472, and 1344.

`RONE`, used in chunks 810, 812, 814, 816, 818, 827, 829, 835, 837, 839, 1056, 1200, 1852, and 2148.

`RPADTEM`, used in chunks 827, 829, 831, 835, 837, 839, and 840a.

`RPASS36`, used in chunks 446, 804, and 806.

`RRATE`, used in chunks 40, 44, 300, 472, 476, 802, 806, 812, and 1042a.

`RTHETA`, used in chunks 40, 44, 300, 472, 476, 802, 808, 812, 814, 816, 818, and 1042a.

`TFF`, used in chunks 33, 40, 125, 240, 430, 456, 470, 472, 825, 827, 829, 831, 833, 835–37, 840a, 860, 1054, 1200, 1256, 1852, 2051, and 2092.

`THETA(1)`, used in chunks 181, 1054, and 1056.

`TSTART82`, used in chunks 827, 829, 831, 833, 1056, and 2148.

`UNP36`, used in chunk 806.

`V82FLAGS`, used in chunks 181, 827, 829, and 833.

`VONE`, used in chunks 182, 812, 814, 816, 818, 827, 829, 835, 837, 839, 1200, and 1852.

Uses `CODE` 140, `DT/2` 177, `I` 206, `P21` 219, `TEMP` 191, `THETA` 148, and `V` 229.

181 ⟨*Page CM0091* 181⟩≡ (75 2684)

```
RSP-RREC        EQUALS  AOPTIME         # DSP NOUN 50 FOR V82 DURING P00 AND P11

# REENTRY CONICS                        (6D)
URONE           EQUALS  V82FLAGS        # I(6) SAVE ACTUAL FOR CALCULATIONS

# V82 DISPLAY                           (4D)
HAPOX           EQUALS  THETA(1) +2     # I(2)DSP NOUN 44
HPERX           EQUALS  HAPOX   +2      # I(2)DSP NOUN 44

# P22 DISPLAY REGISTERS                 (06D)
AOPTIME         EQUALS  HPERX   +2      # I(2)TMP FOR SR52.1.ADVTRACK
LANDLONG        EQUALS  AOPTIME +2      # I(2)DSP NOUN 89 FOR P22
LANDALT         EQUALS  LANDLONG +2     # I(2)DSP NOUN 89 FOR P22

# S34/35.5,P34-P35 STORAGE.             (6D)
KT              EQUALS  LANDALT +2      # B(2)
VERBNOUN        EQUALS  KT      +2      # B(1)TMP
QSAVED          EQUALS  VERBNOUN +1     # B(1)TMP HOLDS RETURN
RTRN            EQUALS  QSAVED  +1      # B(1) RETURN
SUBEXIT         EQUALS  RTRN    +1      # B(1)TMP
                                        # RGEXIT CAN'T SHARE WITH HPER,HAPO
RGEXIT          EQUALS  SUBEXIT         # I(1)TMP Q SAVE MODE 1 AND 2 TO RTRN MAIN

# P30 DISPLAY                           (4D)
HAPO            EQUALS  KT              # I(2)DSP NOUN 42, FOR P30.
HPER            EQUALS  HAPO    +2      # I(2)DSP NOUN 42, FOR P30.

# SOME P34 STORAGE.     (OVERLAYS P35.1 STORAGE)        (2D)
NOMTPI          EQUALS  KT              # I(2)TMP NOMINAL TPI TIME FOR RECYCLE.

# THE FOLLOWING ARE ERASABLES USED BY THE SYSTEM TESTS.  205 USES TRANSM1.  G'S ARE NOT USED IN
# WHILE 504 USES TRANSM1 AND ALFDK.
```

Defines:
AOPTIME, used in chunk 1147.
HAPO, used in chunks 40, 430, 470, 825, 829, 835, 837, 839, 1049, 1051, 1052, 2219, 2256, and 2258.
HAPOX, used in chunks 40, 298, 430, 470, 825, 827, 837, and 839.
HPER, used in chunks 40, 430, 470, 825, 829, 831, 835, 837, 839, 840a, 1049, 1051, 1052, 2219, 2256, and 2258.
HPERX, used in chunks 40, 430, 470, 472, 825, 837, and 840a.
KT, used in chunks 357, 762, 852, 1256, 1522, and 2363.
LANDALT, used in chunks 44, 476, and 1001.
LANDLONG, used in chunks 44, 476, 923, and 1001.
NOMTPI, used in chunks 35, 460, 758, 769, 775, 1063, and 2223.
QSAVED, used in chunks 779, 780, and 911.
RGEXIT, used in chunks 182 and 1043.
RSP-RREC, used in chunks 40, 472, 827, 1054, and 1056.
RTRN, used in chunks 775, 782, 854, 856, 911, 1063, and 2223.

SUBEXIT, used in chunks 357, 430, 756, 771, 772, 777, 779, 810, 844, 848, 907, 909, 1062a, 1063, 2223, and 2256.
URONE, used in chunk 1200.
VERBNOUN, used in chunks 241, 782, 856, 911, 1063, and 2223.
Uses ALFDK 182, CONICS 61, I 206, MODE 145, Q 80, REENTRY 65, SAVE 191, THETA 148, THETA(1) 179, TRANSM1 182, and V82FLAGS 179.

182 ⟨*Page CM0092* 182⟩≡ (75 2684)

```
# RSB 2009.  The definition of TRANSM1 was previously just "TRANSM1 EQUALS 2000",
# this messes up the label typing system in yaYUL.
                SETLOC  2000
TRANSM1         EQUALS                  # (18) INITIALIZATION FOR IMU TESTS
ALFDK           =       TRANSM1 +18D    # (144) ERASABLE LOAD IN 504

# END OF PERF. TEST ERASABLE IN BANK 4

# *-*-* V82 *-*-*                       (6D)

VONE'           EQUALS  RGEXIT  +1      # I(6)TMP NORMAL VELOCITY VONE/ SQ RT MU

# PAD LOAD INTEGRATION ERROR INCLUDED IN VARIANCE BY P20        (1D)

INTVAR          EQUALS  VONE'   +6      # I(1)PL        SQUARE OF EXPECTED INTEGRATI
                                        #               POSITION EXTRAPOLATION ERROR
                                        #               SCALED METERS(2) 2(15)
END-E4          EQUALS  INTVAR          # LAST USED ERASABLE IN E4.
```

Defines:
ALFDK, used in chunks 181, 718, and 2205.
END-E4, never used.
INTVAR, used in chunk 947.
TRANSM1, used in chunks 181, 720, and 2207.
VONE', used in chunk 1852.
Uses I 206, RGEXIT 181, RT 226, SQ 156, VARIANCE 232, and VONE 179.

183 ⟨*Page CM0093* 183⟩≡ (75 2684)

```
# EBANK-5 ASSIGNMENTS

                SETLOC  2400

# *-*-*-*- OVERLAY 1 IN EBANK 5 -*-*-*-*

# W-MATRIX STORAGE.                     (162D)

# RSB 2009.  The following 3 lines have been replaced to be consistent with yaYUL's
# label-typing system.  They *were* "W EQUALS 2400", "9X9LOC1 EQUALS 2444",
# "9X9LOC2 EQUALS 2532".
W               EQUALS                  # B(162)
9X9LOC1         EQUALS  W       +44
9X9LOC2         EQUALS  9X9LOC1 +66

EMATRIX         =       W       +120D   # B(42) USED TO CONVERT W TO 6X6
END-W           EQUALS  W       +162D   # **NEXT AVAILABLE LOC AFTER W MATRIX**

# AUTO-OPTICS STORAGE -R52-

# DO NOT MOVE FROM E5,1554.  A DELICATE BALANCE EXISTS BETWEEN THIS AND P03
XNB1            EQUALS  W       +108D   # B(6D)TMP
YNB1            EQUALS  XNB1    +6      # B(6)TMP
ZNB1            EQUALS  YNB1    +6      # B(6)TMP
SAVQR52         EQUALS  ZNB1    +6      # I(2)TMP
PLANVEC         EQUALS  SAVQR52 +2      # B(6) S-S SIGHTING VECTOR IN REF. COOR.
TSIGHT          EQUALS  PLANVEC +6      # B(2) S-S TIME OF SIGHTING

# RENDEZVOUS -P34-35                    (26D)
DVLOS           EQUALS  TSIGHT  +2      # I(6) S-S DELTA VELOCITY, LOS COORD-DISPLAY
DELTAR          EQUALS  DVLOS           # I(2)
TINTSOI         EQUALS  DELTAR          # I(2) INTERCEPT TIME FOR SOI MANEUVER
DELTTIME        EQUALS  DVLOS   +2      # I(2)
TARGTIME        EQUALS  DVLOS   +4      # I(2)
UNRM            EQUALS  DVLOS   +6      # I(6) S-S
ULOS            EQUALS  UNRM    +6      # I(6) S-S UNIT LINE OF SIGHT VECTOR
ACTCENT         EQUALS  ULOS    +6      # I(2) S-S CENTRAL ANGLE BETWEEN ACTIVE
                                        #      VEH AT TPI IGNITION TIME AND
                                        #      TARGET VECTOR.
DELVTPI         EQUALS  ACTCENT +2      # I(2) NOUN 58 FOR P34
DELVTPF         EQUALS  DELVTPI +2      # I(2) NOUN 58,59 FOR P34,35
POSTTPI         EQUALS  DELVTPF +2      # I(2) NOUN 58 FOR P34.
TDEC2           EQUALS  DELVTPI         #  (2)

# ALIGNMENT                             (12D)
```

Defines:
- 9X9LOC1, used in chunks 197 and 2684.
- 9X9LOC2, used in chunks 197 and 2684.
- ACTCENT, used in chunks 40, 472, and 771.
- DELTAR, used in chunks 40, 295, 300, 472, 842, 848, and 2382.
- DELTTIME, used in chunks 842 and 848.
- DELVTPF, used in chunks 42, 300, 472, 754, 759, 844, and 850.
- DELVTPI, used in chunks 40, 472, 754, 759, 844, and 850.
- DVLOS, used in chunks 42, 185, 197, 472, 754, 761, 773, and 777.
- EMATRIX, used in chunks 1003, 1005, and 1007.
- END-W, used in chunks 186, 188, and 190.
- PLANVEC, used in chunk 1147.
- POSTTPI, used in chunks 40, 472, 754, 759, 844, 850, and 907.
- SAVQR52, used in chunk 1147.
- TARGTIME, used in chunks 848, 852, and 854.
- TDEC2, used in chunks 800a and 2223.
- TINTSOI, used in chunks 846 and 848.
- TSIGHT, used in chunks 1147 and 2139.
- ULOS, used in chunks 763, 770b, and 773.
- UNRM, used in chunks 765, 767, 770b, 771, 773, 775, and 1051.
- W, used in chunks 29, 52, 95, 107, 109, 115, 117, 131, 133, 186, 188, 190, 197, 198, 360, 405, 448, 485, 491, 802, 820, 874, 917, 943, 947, 955, 960, 977, 979, 981, 983, 985, 987, 989, 991, 993, 995, 997, 999, 1003, 1005, 1007, 1009, 1015, 1023, 1041, 1094, 1147, 1356, 1449, 1536, 1663, 1693, 1695, 1697, 1699, 1701, 1703, 1746, 1750, 1772, 1774, 1778, 1780, 1788, 1804, 1805, 1808, 1814, 1852, 1893, 2074, 2081, 2086, 2087, 2091, 2098, 2143, 2306, 2382, 2472, and 2499b.
- XNB1, used in chunks 482, 483, and 2027.
- YNB1, used in chunks 482 and 483.
- ZNB1, used in chunks 482–84.

Uses A 80, EBANK 80, I 206, and LOC 145.

185 ⟨*Page CM0094* 185⟩≡ (75 2684)

```
STARSAV1        EQUALS  DVLOS           # I(6)TMP RESTART STAR SAVE.
STARSAV2        EQUALS  STARSAV1 +6     # I(6)TMP RESTART STAR SAVE.
US              =       STARSAV2        #         (CISLUNAR TAG FOR STARSAV2).

# TPI SEARCH                            (26D)
IT              EQUALS  DVLOS           #  (6)
THETZERO        EQUALS  IT      +6      #  (2)
TFI             EQUALS  THETZERO +2     #  (2)
DELVEE          EQUALS  TFI     +2      #  (2)
HP              EQUALS  DELVEE  +2      #  (2)
TFO             EQUALS  HP      +2      #  (2)
HPO             EQUALS  TFO     +2      #  (2)
DELVEO          EQUALS  HPO     +2      #  (2)
MAGVTPI         EQUALS  DELVEO  +2      # I(2)TMP MAG OF DELTAVTPI OR VMID
RELDELV         EQUALS  MAGVTPI +2      # I(2)TMP MAG OF DELTAVTPF
T3TOT4          EQUALS  RELDELV +2      # I(2)DSP NOUN 39 FOR P34,35.  TPI TO TINT
                                        # (CANNOT SHARE WITH RETURN TO EARTH)
```

Defines:
DELVEE, used in chunks 899, 901, and 905.
DELVEO, used in chunks 901 and 905.
HP, used in chunks 850, 899, 901, 903, 905, and 907.
HPO, used in chunks 901, 903, and 905.
IT, used in chunks 73, 78, 79, 221, 257, 259, 261, 263, 265, 267, 270, 274, 276, 278, 288, 313, 317, 329, 333, 341, 353, 362, 378, 384, 386, 400, 402, 419–21, 423, 430, 434, 446, 451, 482, 487, 508, 510, 521, 527, 531, 541, 549, 551, 553, 559, 567, 569, 575, 591, 595–97, 599, 601, 607, 609, 611–13, 615, 617, 621, 623, 625, 627, 629, 631, 635, 637, 638, 640, 644, 655, 693, 710, 729, 825, 831, 837, 870, 872, 876, 884, 886, 893, 895, 897, 899, 927, 932, 947, 995, 1063, 1094, 1147, 1195, 1200, 1227, 1256, 1347, 1367, 1390, 1396, 1412, 1436, 1470b, 1524, 1526, 1530, 1532, 1534, 1536, 1538, 1541, 1543, 1547, 1548, 1556, 1563, 1565, 1577, 1580, 1584, 1586, 1598, 1602, 1603, 1618, 1625, 1635, 1638, 1644, 1652, 1663, 1693, 1712, 1714, 1739, 1772, 1774, 1780, 1804, 1814, 1844, 1852, 1876, 1893, 1894, 1896, 1898, 1902, 1903, 1905, 1907, 1911, 1913, 1915, 1924, 1925, 1934, 1935, 1939, 1943, 1947, 1949, 1957, 1961, 1973, 1975, 1987, 1989, 1995, 1997, 2001, 2007, 2015, 2027, 2035, 2089, 2103, 2108, 2132, 2134, 2137, 2139, 2142, 2143, 2152, 2154, 2156, 2202b, 2223, 2260, 2265, 2269, 2271, 2281, 2283, 2287, 2289, 2297, 2299, 2306, 2311, 2353, 2382, 2448, 2455, 2457, 2461, 2463, 2465, 2467, 2469, 2471, 2472, 2474, 2482, 2496, 2500, 2510, 2519, 2542, 2561, 2574, 2590, 2611, 2617, and 2621.
MAGVTPI, used in chunk 901.
RELDELV, used in chunks 901, 905, and 907.
STARSAV1, used in chunk 1147.
STARSAV2, used in chunks 1019, 1037, 1147, and 2132.
T3TOT4, used in chunks 38, 456, and 1301.
TFI, used in chunks 33 and 899.
TFO, used in chunk 899.
THETZERO, used in chunks 42, 474, and 897.
US, used in chunks 937, 1019, 1025, 1029, 1147, 1344, 1528, and 2465.
Uses DVLOS 183, I 206, RESTART 57, SAVE 191, STAR 186, and TINT 236.

186 ⟨*Page CM0095* 186⟩≡ (75 2684)

```
# ALIGNMENT/SYSTEST/CALCSMSC/CRS61.1 COMMON STORAGE     (36D)
# (CALCSMSC IS A SUBSET OF S41.1 AT LEAST)
# (CRS61.1 IS A SUBSET OF P20)

XSM             EQUALS  END-W   +23D    # B(6)
YSM             EQUALS  XSM     +6      # B(6)TMP
ZSM             EQUALS  YSM     +6      # B(6)TMP

XDC             EQUALS  ZSM     +6      # B(6)TMP
YDC             EQUALS  XDC     +6      # B(6)TMP
ZDC             EQUALS  YDC     +6      # B(6)TMP

XNB             =       XDC
YNB             =       YDC
ZNB             =       ZDC

# OVERLAYS WITHIN ALIGNMENT/SYSTEST/CALCSMSC COMMON STORAGE

-COSB           EQUALS  XSM     +2      # (2)TMP
SINB            EQUALS  -COSB   +2      # (2)TMP

# ALIGNMENT/SYSTEST COMMON STORAGE      (18D)

STARAD          EQUALS  ZDC     +6      # I(18D)TMP

# ALIGNMENT/SYSTEST/AUTO OPTICS COMMON STORAGE. (17D)

OGC             EQUALS  STARAD  +18D    # I(2)TMP
IGC             EQUALS  OGC     +2      # I(2)TMP
MGC             EQUALS  IGC     +2      # I(2)TMP
STAR            EQUALS  MGC     +2      # I(6)TMP
SAC             EQUALS  STAR    +6      # I(2)TMP
PAC             EQUALS  SAC     +2      # I(2)TMP
QMIN            EQUALS  PAC     +2      # B(1)TMP

# **** COLP50'S ****                    (1D)
CULTRIX         EQUALS  VEARTH          # VEARTH, VSUN, VMOON

# OVERLAYS WITHIN ALIGNMENT/SYSTEST COMMON STORAGE      (24D)

VEARTH          EQUALS  STARAD          # (6)TMP
VSUN            EQUALS  VEARTH  +6      # (6)TMP
VMOON           EQUALS  VSUN    +6      # (6)TMP
SAX             EQUALS  VMOON   +6      # (6)TMP
```

Defines:
- `-COSB`, never used.
- `CULTRIX`, used in chunk 1147.
- `IGC`, used in chunks 298, 866, 874, 880, 1147, 1835, and 1840.
- `MGC`, used in chunks 298, 866, 874, 880, 1147, 1835, 1836, and 1839.
- `OGC`, used in chunks 44, 298, 368, 405, 414, 476, 708, 722, 737, 866, 874, 880, 1147, 1835, 1836, 1839, 1840, 2201, 2202b, and 2211.
- `PAC`, used in chunks 44, 412, 476, 482–84, 741, and 1147.
- `QMIN`, used in chunks 197, 918, 1147, and 2542.
- `SAC`, used in chunks 44, 412, 476, 482–84, 739, and 1147.
- `SAX`, used in chunk 1147.
- `SINB`, never used.
- `STAR`, used in chunks 24, 35, 99, 107, 185, 339, 370, 382, 390, 458, 482–84, 739, 937, 1015, 1017, 1019, 1037, 1147, 1868, 2052–56, 2081, 2123, 2125, 2128–30, 2132, 2833, and 2837.
- `STARAD`, used in chunks 735, 1147, 1841, 1842a, 2125, and 2132.
- `VEARTH`, used in chunk 1147.
- `VMOON`, used in chunks 1147 and 2213.
- `VSUN`, used in chunk 1147.
- `XDC`, used in chunks 874, 878, 880, 1147, 1835, 1841, and 1842a.
- `XNB`, used in chunks 483, 698, 708, 1147, 1200, 1839, 2027, 2035, 2189, and 2201.
- `XSM`, used in chunks 31, 370, 374, 376, 420, 456, 692, 700, 702, 706, 708, 710–12, 717, 722, 725, 729, 735, 866, 1147, 1200, 1835, 1839, 1840, 2143, 2193, 2199, 2201–5, and 2211.
- `YDC`, used in chunks 874, 878, 880, 1147, 1835, 1836, and 1842a.
- `YNB`, used in chunks 483, 698, 1147, 1200, 1839, 2191, and 2311.
- `YSM`, used in chunks 725, 1200, and 1839.
- `ZDC`, used in chunks 874, 878, 880, 1147, 1835, 1836, and 1842a.
- `ZNB`, used in chunks 483, 484, 698, 710, 1094, 1147, 1200, 1839, 2191, and 2445.
- `ZSM`, used in chunks 725, 1200, and 1839.

Uses `A` 80, `END-W` 183, `I` 206, and `W` 183.

188 ⟨*Page CM0096* 188⟩≡ (75 2684)

```
# *-*-*-*- OVERLAY NUMBER 2 IN EBANK 5 -*-*-*-*

# CONICS ROUTINE STORAGE.                        (87D)

DELX            EQUALS  END-W           # I(2)TMP
DELT            EQUALS  DELX    +2      # I(2)TMP
URRECT          EQUALS  DELT    +2      # I(6)TMP
RCNORM          EQUALS  URRECT  +6      # I(2)TMP
XPREV           EQUALS  XKEP            # I(2)TMP
R1VEC           EQUALS  RCNORM  +2      # I(6)TMP
R2VEC           EQUALS  R1VEC   +6      # I(6)TMP
TDESIRED        EQUALS  R2VEC   +6      # I(2)TMP
GEOMSGN         EQUALS  TDESIRED +2     # I(1)TMP
UN              EQUALS  GEOMSGN +1      # I(6)TMP
VTARGTAG        EQUALS  UN      +6      # I(1)TMP
VTARGET         EQUALS  VTARGTAG +1     # I(6)TMP
RTNLAMB         EQUALS  VTARGET +6      # I(1)TMP
U2              EQUALS  RTNLAMB +1      # I(6)TMP
MAGVEC2         EQUALS  U2      +6      # I(2)TMP
UR1             EQUALS  MAGVEC2 +2      # I(6)TMP
SNTH            EQUALS  UR1     +6      # I(2)TMP
CSTH            EQUALS  SNTH    +2      # I(2)TMP
1-CSTH          EQUALS  CSTH    +2      # I(2)TMP
CSTH-RHO        EQUALS  1-CSTH  +2      # I(2)TMP
P               EQUALS  CSTH-RHO +2     # I(2)TMP
R1A             EQUALS  P       +2      # I(2)TMP
RVEC            EQUALS  R1VEC           # I(6)TMP
VVEC            EQUALS  R1A     +2      # I(6)TMP
RTNTT           EQUALS  RTNLAMB         # I(1)TMP
ECC             EQUALS  VVEC    +6      # I(2)TMP
RTNTR           EQUALS  RTNLAMB         # I(1)TMP
RTNAPSE         EQUALS  RTNLAMB         # I(1)TMP
R2              EQUALS  MAGVEC2         # I(2)TMP
RTNPRM          EQUALS  ECC     +2      # I(1)TMP
SGNRDOT         EQUALS  RTNPRM +1       # I(1)TMP
RDESIRED        EQUALS  SGNRDOT +1      # I(2)TMP
DELDEP          EQUALS  RDESIRED +2     # I(2)TMP
DEPREV          EQUALS  DELDEP  +2      # I(2)TMP
TERRLAMB        EQUALS  DELDEP          # I(2)TMP
TPREV           EQUALS  DEPREV          # I(2)TMP
```

Defines:
1-CSTH, used in chunks 1718, 1752, 1754, and 1767.
CSTH, used in chunks 758, 854, 897, 899, 1063, 1301, 1718, 1719, 1724, 1745, 1746, 1750, 1752, 1754, 1758, 1762, 1767, and 2223.

CSTH-RHO, used in chunks 1718, 1754, and 1767.
DELDEP, used in chunks 1739, 1740, 1769, and 1770.
DELT, used in chunks 35, 458, 1715, 1731, 1767, 1814, 2452, and 2459.
DELX, used in chunks 1715, 1731, 1733, 1735, and 1767.
DEPREV, used in chunks 1739, 1769, and 1770.
ECC, used in chunks 797, 1063, 1726, 1760, 1763, 1769, 1852, and 2223.
GEOMSGN, used in chunks 790, 1716, 1721, 1724, 1743, 1745, 1754, and 1767.
MAGVEC2, used in chunks 1721, 1724, 1726, 1744, 1745, 1752, 1759, 1767, and 1769.
P, used in chunks 40, 42, 44, 48, 95, 117, 214, 241, 243, 353, 355, 405, 416, 493, 752, 760, 784, 797, 806, 874, 876, 878, 880, 1001, 1003, 1005, 1009, 1062a, 1063, 1094, 1200, 1301, 1367, 1396, 1489, 1491, 1495, 1498, 1502, 1503, 1514, 1516, 1521, 1627, 1717, 1718, 1721, 1724, 1726, 1744, 1746, 1748, 1750, 1754, 1756, 1759, 1760, 1762, 1763, 1767, 1776, 1788, 1814, 1844, 1852, 2059, 2075, 2107a, 2108, 2154, 2156, 2165, 2213, 2223, 2254, 2293, 2500, 2509, 2512, 2513, 2519, 2542, 2561, 2574, 2588, 2590, 2592, 2607, 2609, 2619, 2625, 2770, 2833, and 2837.
R1A, used in chunks 1063, 1301, 1718, 1721, 1724, 1726, 1744, 1746, 1748, 1750, 1751, 1754, 1756, 1760, 1763, 1769, and 2223.
R1VEC, used in chunks 786, 788, 790, 1716–18, 1743, 1745, 1752, 1767, and 1769.
R2, used in chunks 26, 56a, 152, 200, 241, 244, 327, 426, 428, 430, 438, 450, 510, 512, 517, 518, 523, 527, 529, 531, 539, 540, 567, 599, 625, 627, 747, 804, 825, 844, 846, 858, 860, 872, 911, 919, 929, 1011, 1019, 1094, 1718, 1721, 1724, 1741, 1752, 1769, 1874, 1951–53, 1955, 1956, 1961, 1963, 1975, 1979, 1997, 2114, 2148, and 2480.
R2VEC, used in chunks 788, 792, 1716–18, 1752, and 1767.
RCNORM, used in chunks 1715, 1735, 1736, and 1767.
RDESIRED, used in chunks 127, 1301, 1722–24, 1760, 1769, 2094, and 2223.
RTNAPSE, used in chunks 1726, 1763, and 1769.
RTNLAMB, used in chunks 1718, 1752, 1758, 1759, 1767, and 1769.
RTNPRM, used in chunks 1721, 1724, 1726, 1743, 1744, and 1769.
RTNTR, used in chunks 1760 and 1769.
RTNTT, used in chunks 1721, 1724, 1743, and 1769.
RVEC, used in chunks 758, 797, 798, 854, 897, 903, 1063, 1147, 1301, 1719, 1721, 1722, 1724–26, 1743, 1760, 1763, 1769, and 2223.
SGNRDOT, used in chunks 1301, 1722, 1723, and 1760.
SNTH, used in chunks 758, 854, 897, 899, 1063, 1301, 1718, 1719, 1724, 1745, 1746, 1750, 1752, 1754, 1762, 1767, and 2223.
TDESIRED, used in chunks 788, 1716, 1717, 1752, 1756, 1758, and 1767.
TERRLAMB, used in chunks 1718, 1756, 1758, and 1770.
TPREV, used in chunks 1718, 1756, 1758, and 1770.
U2, used in chunks 1675, 1718, 1721, 1724, 1726, 1745, 1760, 1762, and 1767.
UN, used in chunks 763, 765, 767, 788, 1291, 1616, 1627, 1717, 1721, 1724, 1726, 1745, 1759, 1762, 1767, 1804, and 2311.
UR1, used in chunks 241, 1301, 1718, 1721, 1724, 1726, 1727, 1741, 1745, 1759, 1760, 1762, and 1767.
URRECT, used in chunks 1715, 1727, 1735, 1736, and 1767.
VTARGET, used in chunks 792, 1717, 1718, 1759, and 1767.
VTARGTAG, used in chunks 786, 790, 792, 1717, 1759, and 1767.
VVEC, used in chunks 759, 790, 797, 798, 854, 897, 903, 907, 1063, 1301, 1717–19, 1721, 1722, 1724–26, 1741, 1743, 1759, 1760, 1763, 1769, and 2223.
XPREV, used in chunks 1714, 1731, 1736, 1765, and 1767.

Uses CONICS 61, EBANK 80, END-W 183, I 206, RHO 211, W 183, and XKEP 169.

190 ⟨*Page CM0097* 190⟩≡ (75 2684)

```
# *-*-*-*- OVERLAY NUMBER 3 IN EBANK 5 -*-*-*-*

# MEASUREMENT INCORPORATION STORAGE.    (66D)
# (CALLED BY P20, P22, P23)

OMEGAM1         EQUALS  END-W           # I(6)TMP
OMEGAM2         EQUALS  OMEGAM1 +6      # I(6)TMP
OMEGAM3         EQUALS  OMEGAM2 +6      # I(6)TMP
HOLDW           EQUALS  OMEGAM3 +6      # I(18)TMP
TDPOS           EQUALS  HOLDW   +18D    # I(6)TMP
TDVEL           EQUALS  TDPOS   +6      # I(6)TMP

ZI              EQUALS  TDVEL   +6      # I(18)

# P22-P23 STORAGE.                      (8D)

22SUBSCL        EQUALS  ZI      +18D    # DE OF ABCDE LANDMARK ID NO.
CXOFF           EQUALS  22SUBSCL +1     # B OF ABCDE OFFSET INDICATOR
8KK             EQUALS  CXOFF   +1      # B(1)TMP INDEX OF PRESENT MARK
8NN             EQUALS  8KK     +1      # B(1)TMP
S22LOC          EQUALS  8NN     +1      # I(1)TMP MARK DATA LOC
LANDMARK        EQUALS  S22LOC +1       # B(1)DSP NOUN 70 FOR P22,51, R52,53
HORIZON         EQUALS  LANDMARK +1     # B(1)DSP NOUN 70 FOR P22,51, R52,53
IDOFLMK         EQUALS  HORIZON +1      # B(1)

# ******P23***                           (1D)
TRUNION         EQUALS  IDOFLMK +1      # B(1)
```

Defines:
22SUBSCL, used in chunks 925, 977, and 2752.
8KK, used in chunks 923, 925, 977, 981, and 989.
8NN, used in chunks 304, 921, 977, 989, and 995.
CXOFF, used in chunks 925, 977, 981, and 995.
HOLDW, used in chunks 1701 and 1703.
HORIZON, used in chunks 35, 42, 95, 166, 458, 474, 1015, 1017, 1019, 1301, and 2311.
IDOFLMK, never used.
LANDMARK, used in chunks 28, 35, 37, 42, 99, 119, 304, 357, 366, 382, 446, 448, 458, 460, 474, 919, 921, 925, 927, 977, 1015, 1017, 1024, 1147, 1693, 2833, and 2837.
OMEGAM1, used in chunks 1699 and 1701.
OMEGAM2, used in chunks 1699 and 1701.
OMEGAM3, used in chunks 1699 and 1703.
S22LOC, used in chunks 977, 981, 989, and 1001.
TDPOS, never used.
TDVEL, never used.
TRUNION, used in chunks 37, 119, 165, 290, 460, 484, 1021, 1025, and 1147.
ZI, used in chunks 1693, 1695, 1697, 1699, 1701, 1707, and 1709.
Uses EBANK 80, END-W 183, I 206, LOC 145, and W 183.

191 ⟨*Page CM0098* 191⟩≡ (75 2684)

```
# *-*-*-*- OVERLAY NUMBER 0 IN EBANK 5 -*-*-*-*

# SYSTEM TEST STORAGE.                          (174)

AZIMUTH         ERASE   +1
LATITUDE        ERASE   +1

TRUNA           EQUALS  DESOPTT
SHAFTA          EQUALS  DESOPTS

ERVECTOR        ERASE   +5
LENGTHOT        ERASE
LOSVEC          ERASE   +5

SXTOPTN         =       LOSVEC
NDXCTR          ERASE
PIPINDEX        ERASE
POSITON         ERASE
QPLAC           ERASE
QPLACE          ERASE
QPLACES         ERASE
RUN             ERASE
STOREPL         ERASE
SOUTHDR         ERASE
TARG1/2         =       SOUTHDR
TAZEL1          ERASE   +5
TEMPTIME        ERASE   +1
TMARK           ERASE   +1
GENPL           ERASE   +134D
CDUTIMEI        =       GENPL
CDUTIMEF        =       GENPL +2
IMU/OPT         =       GENPL +4
CDUREADF        =       GENPL +5
CDUREADI        =       GENPL +6
CDULIMIT        =       GENPL +7

TEMPADD         =       GENPL +4
TEMP            =       GENPL +5
NOBITS          =       GENPL +6
CHAN            =       GENPL +7

LOS1            =       GENPL +8D
LOS2            =       GENPL +14D
```

```
CALCDIR         EQUALS  GENPL +20D
CDUFLAG         EQUALS  GENPL +21D
GYTOBETQ        EQUALS  GENPL +22D
OPTNREG         EQUALS  GENPL +23D
SAVE            EQUALS  GENPL +24D      # THREE CONSEC LOC
SFCONST1        EQUALS  GENPL +27D
```

Defines:

AZIMUTH, used in chunks 28, 31, 33, 407, 420, 456, 698, 710, 714, 733, 735, 739, 858, 868, 874, 878, 2063, 2124–26, 2189, 2191, and 2209.
CALCDIR, never used.
CDUFLAG, never used.
CDULIMIT, never used.
CDUREADF, never used.
CDUREADI, never used.
CDUTIMEF, never used.
CDUTIMEI, never used.
CHAN, used in chunks 257, 266, 281, 400, 579, 642, 644, 645, 1933b, and 2108.
ERVECTOR, used in chunks 702, 706, 2196, and 2199.
GENPL, used in chunk 194.
GYTOBETQ, never used.
IMU/OPT, never used.
LATITUDE, used in chunks 24, 33, 35, 37, 456, 458, 460, 696, 706, 710, 739, 860, 866, 1147, 1248, 1254, 1256, 1301, 1675, 1677, 2189, 2191, 2199, 2833, and 2837.
LENGTHOT, used in chunks 696, 700, 702, 710, 712, 714, 722, 725, 729, 731, 2193, 2195, 2202b, 2204, 2209, and 2211.
LOS1, never used.
LOS2, never used.
LOSVEC, used in chunks 702, 722, 735, 737, 2196, 2209, and 2375.
NDXCTR, used in chunks 696, 698, 700, 702, 2189, 2191, 2193, and 2195.
NOBITS, never used.
OPTNREG, never used.
PIPINDEX, used in chunks 700, 704, 2193, 2195, 2197, and 2198.
POSITON, used in chunks 696, 698, 700, 702, 708, 2189, 2191, 2193, 2195, and 2201.
QPLAC, used in chunks 739, 741, and 743.
QPLACE, used in chunks 357, 419, 694, 704, 705, 708, 725, 2197, 2198, and 2201.
QPLACES, used in chunks 73, 706, 866, and 2199.
RUN, used in chunks 412, 593, 694, 722, 733, 860, 1362, 1390, 1657, 2076, 2154, 2209, and 2382.
SAVE, used in chunks 142, 157, 167, 181, 185, 218, 219, 221, 239, 241, 257, 258, 265, 294, 335, 339, 380, 394, 452, 493, 498, 514, 519, 537, 561, 565, 617, 625, 627, 629, 638, 649, 653, 692, 710, 747, 749, 773, 777, 804, 806, 831, 839, 876, 895, 897, 899, 901, 905, 934, 957, 959, 967, 969, 973, 989, 991, 993, 997, 1017, 1094, 1147, 1200, 1227, 1256, 1291, 1293, 1344, 1347, 1390, 1412, 1487, 1493, 1495, 1497, 1502, 1504, 1506, 1510, 1516, 1518, 1521, 1528, 1530, 1532, 1534, 1538, 1540–42, 1556, 1572, 1574, 1576, 1579, 1581, 1584, 1591, 1609, 1610, 1620, 1623, 1652, 1656, 1663, 1675, 1684, 1709, 1812, 1852, 1876, 1878, 1891, 1905, 1907, 1909, 1927, 1928, 1937, 1938, 1973, 1975, 1977, 1983, 2001, 2009, 2013, 2015, 2108, 2143, 2148, 2269, 2283, 2295, 2382, 2420, 2424, 2426, 2442, 2448, 2453, 2465, 2467, 2469, 2471, 2474, 2482, 2484, 2500, 2502, 2503a, 2512, 2519, 2542, 2561, 2574, 2590, 2600, 2607, 2609, 2611, 2613, 2615, 2617, and 2621.
SFCONST1, never used.
SHAFTA, never used.
SOUTHDR, used in chunks 700, 702, 2193, and 2195.
STOREPL, never used.
SXTOPTN, never used.
TARG1/2, used in chunk 739.
TAZEL1, used in chunks 733 and 735.

TEMP, used in chunks 140, 142, 144, 152, 169, 179, 221, 229, 257, 258, 269, 325, 407, 452, 512, 514, 515, 525, 531, 591, 611, 619, 621, 640, 642, 788, 925, 945, 965, 969, 985, 995, 1007, 1049, 1063, 1094, 1147, 1227, 1248, 1396, 1502, 1512, 1684, 1695, 1701, 1703, 1804, 1852, 1872, 2015, 2059, 2075, 2219, 2223, 2382, 2478, 2590, and 2623.
TEMPADD, never used.
TEMPTIME, used in chunks 706 and 2199.
TMARK, used in chunks 706, 729, and 2199.
TRUNA, never used.
Uses DESOPTS 159, DESOPTT 159, EBANK 80, and LOC 145.

194 ⟨*Page CM0099* 194⟩≡ (75 2684)

```
TIMER           EQUALS  GENPL   +28D

DATAPL          EQUALS  GENPL   +30D
RDSP            EQUALS  GENPL           # FIX LATER     POSSIBLY KEEP1
MASKREG         EQUALS  GENPL   +64D
CDUNDX          EQUALS  GENPL   +66D
RESULTCT        EQUALS  GENPL   +67D
COUNTPL         EQUALS  GENPL   +70D

CDUANG          EQUALS  GENPL   +71D
AINLA           =       GENPL           # OPTIMUM CALIB. AND ALIGNMENT
WANGO           EQUALS  AINLA
WANGI           EQUALS  AINLA   +2D
WANGT           EQUALS  AINLA   +4D
TORQNDX         =       WANGT
DRIFTT          EQUALS  AINLA   +6D
ALX1S           EQUALS  AINLA   +8D
CMPX1           EQUALS  AINLA   +9D
ALK             EQUALS  AINLA   +10D
VLAUNS          EQUALS  AINLA   +22D
THETAX          =       ALK     +2
WPLATO          EQUALS  AINLA   +24D
INTY            EQUALS  AINLA   +28D
THETAN          =       THETAX  +6
ANGZ            EQUALS  AINLA   +30D
INTZ            EQUALS  AINLA   +32D
ANGY            EQUALS  AINLA   +34D
ANGX            EQUALS  AINLA   +36D
DRIFTO          EQUALS  AINLA   +38D
DRIFTI          EQUALS  AINLA   +40D
VLAUN           EQUALS  AINLA   +44D
FILDELV         =       THETAN  +6
ACCWD           EQUALS  AINLA   +46D
INTVEC          =       FILDELV +2
POSNV           EQUALS  AINLA   +52D
DPIPAY          EQUALS  AINLA   +54D
DPIPAZ          EQUALS  AINLA   +58D
ALTIM           EQUALS  AINLA   +60D
ALTIMS          EQUALS  AINLA   +61D
ALDK            EQUALS  AINLA   +62D
DELM            EQUALS  AINLA   +76D
WPLATI          EQUALS  AINLA   +84D
RESTARPT        =       AINLA   +91D
GEOSAVED        =       AINLA   +117D
PREMTRXC        =       AINLA   +118D
```

```
LAUNCHAZ        =       AINLA   +119D
NEWAZMTH        =       AINLA   +121D
OLDAZMTH        =       AINLA   +123D
```

Defines:
ACCWD, used in chunks 720, 2207, and 2209.
AINLA, used in chunk 196.
ALDK, used in chunks 718, 720, 2205, and 2207.
ALK, used in chunks 196, 718, 720, 729, and 2207.
ALTIM, used in chunks 714, 716, and 2204.
ALTIMS, used in chunks 716, 718, 2204, and 2205.
ALX1S, used in chunks 712, 718, 724, 2203, 2205, and 2212.
ANGX, used in chunks 720, 722, 2209, and 2211.
ANGY, used in chunks 722 and 2211.
ANGZ, used in chunks 722 and 2211.
CDUANG, never used.
CDUNDX, never used.
CMPX1, used in chunks 718 and 2207.
COUNTPL, never used.
DATAPL, used in chunks 700, 702, 704, 705, 2193, 2195, and 2198.
DELM, used in chunks 718, 720, and 2207.
DPIPAY, used in chunks 717, 718, 727, and 2205.
DPIPAZ, used in chunks 717 and 2205.
DRIFTI, used in chunks 700 and 2193.
DRIFTO, used in chunks 703 and 2196.
DRIFTT, used in chunks 696, 702, and 2195.
FILDELV, never used.
GEOSAVED, never used.
INTVEC, never used.
INTY, used in chunks 718, 720, 2205, and 2207.
INTZ, never used.
LAUNCHAZ, used in chunks 298, 710, 729, 731, 743, 868, 874, and 878.
MASKREG, never used.
NEWAZMTH, used in chunks 731 and 743.
OLDAZMTH, used in chunks 725, 729, and 731.
POSNV, used in chunks 720, 2207, and 2209.
PREMTRXC, used in chunks 729, 731, and 743.
RDSP, never used.
RESTARPT, used in chunk 714.
RESULTCT, used in chunks 700, 702, 704, 705, 2193, 2195, and 2198.
THETAN, used in chunk 866.
THETAX, never used.
TIMER, used in chunk 2287.
TORQNDX, used in chunks 696, 702, 714, 722, 2189, 2196, 2203, 2209, and 2211.
VLAUN, used in chunks 718, 720, 2207, and 2209.
VLAUNS, never used.
WANGI, used in chunks 696 and 2191.
WANGO, used in chunks 696 and 2191.
WANGT, never used.
WPLATI, never used.
WPLATO, never used.
Uses GENPL 191.

196 ⟨*Page CM0100* 196⟩≡ (75 2684)

```
TOLDAZMT        =       AINLA   +125D
GEOCOMPS        =       AINLA   +127D
1SECXT          =       AINLA   +128D
GTSXTLST        =       AINLA   +129D
ERECTIME        =       AINLA   +130D
ERCOMP          =       AINLA   +131D
ZERONDX         =       AINLA   +137D
GTSOPNDZ        =       ZERONDX

# THE FOLLOWING TAGS ARE USED BY THE 504 IMU CALIBRATION AND ALIGNMENT PROGRAM ONLY.

THETAX1         EQUALS  ALK     +2
THETAN1         EQUALS  THETAX1 +6
FILDELV1        EQUALS  THETAN1 +6
INTVEC1         EQUALS  FILDELV1 +2
GEOSAVE1        EQUALS  AINLA   +117D
PREMTRX1        EQUALS  AINLA   +118D
LUNCHAZ1        EQUALS  AINLA   +119D
NEWAZ1          EQUALS  LUNCHAZ1 +2
OLDAZ1          EQUALS  LUNCHAZ1 +4
TOLDAZ1         EQUALS  LUNCHAZ1 +6
GEOCOMP1        EQUALS  AINLA   +127D
1SECXT1         EQUALS  AINLA   +128D
GTSWTLT1        EQUALS  AINLA   +129D
ERECTIM1        EQUALS  AINLA   +130D
ERCOMP1         EQUALS  AINLA   +131D   # I(6)
ZERONDX1        EQUALS  AINLA   +137D
PERFDLAY        EQUALS  AINLA   +138D   # B(2)..........

# END OF 504 + ALIGN ERASE.
```

Defines:
`1SECXT`, used in chunks 2203 and 2204.
`1SECXT1`, used in chunks 696, 714, and 725.
`ERCOMP`, used in chunks 731, 732a, 866, 2195, and 2199.
`ERCOMP1`, used in chunks 702, 706, 729, and 737.
`ERECTIM1`, used in chunks 727, 729, and 731.
`ERECTIME`, used in chunk 712.
`FILDELV1`, used in chunk 727.
`GEOCOMP1`, used in chunks 696, 712, 717, and 725.
`GEOCOMPS`, used in chunks 2204 and 2205.
`GEOSAVE1`, used in chunks 716, 729, and 731.
`GTSOPNDZ`, never used.
`GTSWTLT1`, used in chunks 712, 714, and 716.
`GTSXTLST`, never used.
`INTVEC1`, used in chunk 727.
`LUNCHAZ1`, used in chunk 725.
`NEWAZ1`, used in chunk 725.

OLDAZ1, never used.
PERFDLAY, used in chunks 698, 725, and 2191.
PREMTRX1, used in chunk 725.
THETAN1, used in chunks 727 and 729.
THETAX1, used in chunks 714, 716, and 729.
TOLDAZ1, never used.
TOLDAZMT, never used.
ZERONDX, used in chunks 704, 2189, 2197, 2198, and 2203.
ZERONDX1, used in chunks 696, 705, 712, and 725.
Uses AINLA 194, ALK 194, and I 206.

197 ⟨*Page CM0101* 197⟩≡ (75 2684)

```
# *-*-*-*-  OVERLAY 4 IN EBANK 5  -*-*-*-*
#
# P32 --- P33                          (26D)
UP1             EQUALS  DVLOS           # I(6)
VPASS2          EQUALS  UP1     +6      # I(6)
RPASS2          EQUALS  VPASS2  +6      # I(6)
DIFFALT         EQUALS  RPASS2  +6      # I(2)
TCDH            EQUALS  DIFFALT +2      # I(2)
TCSI            EQUALS  TCDH    +2      # I(2)
TTPIO           EQUALS  TCSI    +2      # I(2)

# P32,P33 STORAGE OVERLAYING 9X9 W-MATRIX LOCATIONS     (26D)
DELVEET1        EQUALS  9X9LOC1         # I(6) DELV FOR CSI
RACT2           EQUALS  DELVEET1 +6     # I(6) POS. ACTIVE VEH. AT CDH TIME
VACT2           EQUALS  9X9LOC2         # I(6) VEL. ACTIVE VEH. AT CDH TIME
RACT1           EQUALS  VACT2   +6      # I(6) POS. ACTIVE VEH. AT CSI TIME
T1TOT2          EQUALS  RACT1   +6      # I(2) TCDH - TCSI
END-E5          EQUALS  QMIN            # LAST USED E5 ADDRESS
```

Defines:
DELVEET1, used in chunks 295, 1063, and 2223.
DIFFALT, used in chunks 42, 300, 474, 1063, and 2223.
END-E5, never used.
RACT1, used in chunks 1063 and 2223.
RACT2, used in chunks 1063 and 2223.
RPASS2, used in chunks 1063 and 2223.
T1TOT2, used in chunks 42, 474, 1063, and 2223.
TCDH, used in chunks 38, 244, 300, 454, 1063, and 2223.
TCSI, used in chunks 38, 454, 1063, and 2223.
TTPIO, used in chunks 1063 and 2223.
UP1, used in chunks 1063 and 2223.
VACT2, used in chunks 244, 1063, and 2223.
VPASS2, used in chunks 1063 and 2223.
Uses 9X9LOC1 183, 9X9LOC2 183, DELV 159, DVLOS 183, EBANK 80, I 206, QMIN 186, VEL 226, and W 183.

198 ⟨*Page CM0102* 198⟩≡ (75 2684)

```
# EBANK-6 ASSIGNMENTS.

                SETLOC  3000
# P23   PAD LOADS ***                   (2D).
WMIDPOS         ERASE                   # I(1)PL INITIAL VALUES FOR W-MATRIX IN
WMIDVEL         ERASE                   # I(1)PL CISLUNAR (P23) NAVIGATION

# R22   PAD LOADS                       (5D).
RVAR            ERASE   +1              # I(2)PL VHF RADAR
RVARMIN         ERASE   +2              # I(3)PL VHF RADAR

# ***** PAD LOADED ENTRY DAP STEERING VARIABLES *****   (3D)
LADPAD          ERASE                   # I(1)PL FOR ENTRY. HOLDS CM NOMINAL L/D
LODPAD          ERASE                   # I(1)PL FOR ENTRY. HOLDS CM NOMINAL LOD
ALFAPAD         ERASE                   # B(1)PL ALFA TRIM / 180

# ***** PAD LOADED TVC DAP VARIABLES ****************   (26D)
ETDECAY         ERASE                   # I(1)PL
ESTROKER        ERASE                   # B(1)PL
EKPRIME         ERASE   +1              # B(2)PL
EKTLX/I         ERASE   +2              # B(3)PL
EREPFRAC        ERASE   +1              # B(2)PL
PACTOFF         ERASE                   # B(1)PL, DSP N48 R01 = PTRIM, R02 = YTRIM
YACTOFF         ERASE                   # B(1)PL, CONSECUTIVE WITH PACTOFF
HBN10           ERASE                   # B(1)
HBN11/2         ERASE                   # B(1)
HBN12           ERASE                   # B(1)
HBD11/2         ERASE                   # B(1)
HBD12           ERASE                   # B(1)
HBN20           ERASE                   # B(1)
HBN21/2         ERASE                   # B(1)
HBN22           ERASE                   # B(1)
HBD21/2         ERASE                   # B(1)
HBD22           ERASE                   # B(1)
HBN30           ERASE                   # B(1)
HBN31/2         ERASE                   # B(1)
HBN32           ERASE                   # B(1)
```

Defines:
`ALFAPAD`, used in chunk 1200.
`EKPRIME`, used in chunk 1347.
`EKTLX/I`, used in chunk 1347.
`EREPFRAC`, used in chunks 1094, 1347, and 1356.
`ESTROKER`, used in chunks 357, 364, 915, and 1390.
`ETDECAY`, used in chunk 1094.
`HBD11/2`, never used.

HBD12, never used.
HBD21/2, never used.
HBD22, never used.
HBN10, used in chunk 1347.
HBN11/2, never used.
HBN12, never used.
HBN20, never used.
HBN21/2, never used.
HBN22, never used.
HBN30, never used.
HBN31/2, never used.
HBN32, never used.
LADPAD, used in chunks 1200, 1248, and 1256.
LODPAD, used in chunks 1200, 1248, and 1256.
PACTOFF, used in chunks 40, 295, 298, 351, 368, 370, 372, 374, 437, 472, 1094, 1347, 1356, 1367, and 2765.
RVAR, used in chunk 951.
RVARMIN, used in chunk 947.
WMIDPOS, used in chunks 1023 and 1041.
WMIDVEL, used in chunk 1041.
YACTOFF, used in chunks 40, 295, 298, 472, 1094, 1347, 1356, and 1367.

Uses D 226, EBANK 80, I 206, L 80, L/D 226, LOD 226, RO2 59, and W 183.

200 ⟨*Page CM0103* 200⟩≡ (75 2684)

```
HBD31/2         ERASE                   # B(1)
HBD32           ERASE                   # B(1)

# **** EXCLUSIVE TVC DAP VARIABLES. *****************   (5D)
V97VCNTR        ERASE                   # B(1)
TEMPDAP         ERASE   +1              # B(2)
MRKRTMP         =       TEMPDAP         #       ((B(1)))
CNTR            ERASE                   # B(1)
OGAD            ERASE                   # B(1)

# **** EXCLUSIVE RCS DAP VARIABLES ******************   (13D)
RWORD1          ERASE   +12D            # B(1)
RWORD2          EQUALS  RWORD1  +1      # B(1)
PWORD1          EQUALS  RWORD2  +1      # B(1)
PWORD2          EQUALS  PWORD1  +1      # B(1)
YWORD1          EQUALS  PWORD2  +1      # B(1)
YWORD2          EQUALS  YWORD1  +1      # B(1)
BLAST           EQUALS  YWORD2  +1      # B(2)
BLAST1          EQUALS  BLAST   +2      # B(2)
BLAST2          EQUALS  BLAST1  +2      # B(2)
T5PHASE         EQUALS  BLAST2  +2      # B(1)

# **** RCS/TVC DAP COMMON STORAGE. ******************   (16D)
DAPDATR1        ERASE                   # B(1)DSP NOUN 46(R1)
DAPDATR2        ERASE                   # B(1)DSP NOUN 46(R2)

IXX             ERASE                   # B(1) CONSECUTIVE WITH IAVG, IAVG/TLX FOR
IAVG            ERASE                   # B(1)                            MASSPROP
IAVG/TLX        ERASE                   # B(1)

LEMMASS         ERASE                   # B(1)DSP NOUN 47 (R2)
CSMMASS         ERASE                   # B(1)DSP NOUN 47 (R1)
WEIGHT/G        ERASE                   # B(1)
MASS            =       WEIGHT/G

AK              ERASE
AK1             ERASE
AK2             ERASE

RCSFLAGS        ERASE                   # B(1) CONSECUTIVE WITH AK2 DOWNLINK
T5TEMP          ERASE                   # B(1)
EDRIVEX         ERASE
EDRIVEY         ERASE
```

Defines:
AK, used in chunks 218, 297, 302, 376, 421, 423, 876, 880, 882, 886, 891, 1256, 1356, 1396,

1412, 1436, 1441, 2509, 2510, 2512–15, and 2517.
AK1, used in chunks 218, 297, 302, 876, 882, 891, 1373, 1412, 1436, 1495, 2510, 2514, and 2515.
AK2, used in chunks 218, 297, 302, 876, 882, 884, 891, 1373, 1412, 1436, 1495, 1500, 2510, 2514, and 2515.
BLAST, used in chunks 1412, 1469, 1471, 1473, 1475–77, and 1479.
BLAST1, used in chunks 1412, 1466, 1467, 1470b, 1475–77, and 1479.
BLAST2, used in chunks 1412, 1468, 1474–77, and 1479.
CNTR, used in chunks 272, 1094, 1347, 1356, 1367, 1373, and 2130.
CSMMASS, used in chunks 40, 297, 302, 337, 372, 472, 1094, 1347, 1356, 1362, 2590, 2592, and 2603.
DAPDATR1, used in chunks 40, 297, 302, 337, 351, 357, 364, 368, 370, 372, 424, 426, 428, 472, 886, 888, 1094, 1347, 1356, 1362, 1373, 1390, 1412, 1453, and 1485.
DAPDATR2, used in chunks 40, 297, 302, 426, 472, 1094, and 1412.
EDRIVEX, used in chunks 221, 1412, 2514, 2515, and 2517.
EDRIVEY, used in chunks 221, 1412, 2514, and 2515.
HBD31/2, never used.
HBD32, never used.
IAVG, used in chunks 428, 1094, 1347, 1356, 1362, and 1412.
IAVG/TLX, used in chunks 428, 1347, 1356, and 1362.
IXX, used in chunks 428, 1094, 1347, 1356, 1362, 1412, and 2596.
LEMMASS, used in chunks 40, 297, 302, 472, 1347, 1362, 2590, 2592, 2603, and 2605.
MASS, used in chunks 20, 428, 1094, 1227, 1347, 1356, 1362, 1712, 1716, 2044, 2048, 2306, 2311, 2343, 2382, 2588, 2590, 2592, 2594, 2596, 2601, 2605, and 2633.
MRKRTMP, used in chunk 1094.
OGAD, used in chunks 1094, 1356, and 1396.
PWORD1, used in chunks 1412, 1456, 1470b, 1475, and 1477.
PWORD2, used in chunks 1412, 1470b, 1475, and 1479.
RCSFLAGS, used in chunks 297, 302, 688, 690, 868, 872, 884, 890, 1094, 1347, 1412, 1434, 1438, 1447, 1475, 1477, 1485, 2504, 2505, 2507, 2510, 2514, 2515, 2517, 2519, 2542, and 2574.
RWORD1, used in chunks 1412, 1458, 1460–62, 1473, 1475, and 1477.
RWORD2, used in chunks 1412, 1471, 1473, 1475, and 1479.
T5PHASE, used in chunks 1094, 1412, and 1475.
T5TEMP, used in chunks 1412, 1436, 1441, 1443, 1445, 1453, 1460, 1461, 2514, and 2517.
TEMPDAP, used in chunk 1356.
V97VCNTR, used in chunks 372, 1094, 1347, and 1356.
WEIGHT/G, used in chunks 1094, 1301, and 1362.
YWORD1, used in chunks 1412, 1457, 1474, 1475, and 1477.
YWORD2, used in chunks 1412, 1474, 1475, and 1479.
Uses R2 188.

202 ⟨*Page CM0104* 202⟩≡ (75 2684)

```
EDRIVEZ         ERASE

# INTEMP THRU INTEMP+14D ARE RESERVED FOR OVERLAYED TVC/RCS INTERUP TRUE TEMPORARIES
INTTEMP         ERASE   +14D            # (15)

# TVC/RCS THRU TVCRCS +11D RESERVED FOR DOWNLINKED VARIABLES
TVCRCS          ERASE   +11D            # (12)
                                        # RCS (WBODYS,ADOTS)
                                        # TVC(OMEGACS,OMEGABS)

# TVC DAP TEMPORARY VARIABLES*******************************

# TVC DAP INTERRUPT TRUE TEMPORARIES************************

PHI333          EQUALS  INTTEMP         # B(1) TEMPORARY REGISTER
PSI333          EQUALS  PHI333  +1      # B(1) COUNTING REGISTER
TEMP333         EQUALS  PSI333  +1      # B(1) COUNTING REGISTER
VARST0          EQUALS  TEMP333 +1      # B(8) BREAKPOINTS AND SLOPES
VARST5          =       VARST0  +5
LASTMASP        EQUALS  VARST0  +9D     # LAST VARST0 WORD
TVCTMP1         EQUALS  LASTMASP +1     # B(1)

# *******REGULAR TVC TEMPORARIES*************

# TVC ZEROING STARTS HERE

OMEGAC          EQUALS  TVCRCS          # I(6)
OMEGAXC         =       OMEGAC
OMEGAYC         =       OMEGAC  +2
OMEGAZC         =       OMEGAC  +4

OMEGAB          EQUALS  TVCRCS  +6      # B(6)
OMEGAXB         =       OMEGAB
OMEGAYB         =       OMEGAB  +2
OMEGAZB         =       OMEGAB  +4

PTMP1           EQUALS  OMEGAC  +12D    # B(2)
PTMP2           EQUALS  PTMP1   +2      # B(2)
PTMP3           EQUALS  PTMP2   +2      # B(2)
PTMP4           EQUALS  PTMP3   +2      # B(2)
PTMP5           EQUALS  PTMP4   +2      # B(2)
```

Defines:
`EDRIVEZ`, used in chunks 221, 1412, 2514, and 2515.
`INTTEMP`, used in chunk 209.
`LASTMASP`, never used.

OMEGAB, used in chunks 208 and 297.
OMEGAC, used in chunks 297, 302, and 1094.
OMEGAXB, never used.
OMEGAXC, used in chunk 1094.
OMEGAYB, used in chunk 1373.
OMEGAYC, used in chunks 1347 and 1373.
OMEGAZB, used in chunk 1373.
OMEGAZC, used in chunk 1373.
PHI333, used in chunk 1362.
PSI333, used in chunk 1362.
PTMP1, used in chunks 1347 and 1373.
PTMP2, used in chunk 1373.
PTMP3, used in chunk 1373.
PTMP4, used in chunk 1373.
PTMP5, used in chunks 204 and 1373.
TEMP333, used in chunk 1362.
TVCRCS, used in chunk 209.
TVCTMP1, never used.
VARST0, used in chunk 1362.
VARST5, used in chunk 1362.
Uses I 206.

204 ⟨*Page CM0105* 204⟩≡ (75 2684)

```
PTMP6           EQUALS  PTMP5   +2      # B(2)

YTMP1           EQUALS  PTMP6   +2      # B(2)
YTMP2           EQUALS  YTMP1   +2      # B(2)
YTMP3           EQUALS  YTMP2   +2      # B(2)
YTMP4           EQUALS  YTMP3   +2      # B(2)
YTMP5           EQUALS  YTMP4   +2      # B(2)
YTMP6           EQUALS  YTMP5   +2      # B(2)

ROLLFIRE        EQUALS  YTMP6   +2      # B(1)
ROLLWORD        EQUALS  ROLLFIRE +1     # B(1)
TEMREG          EQUALS  ROLLWORD +1     # B(1)

STROKER         EQUALS  TEMREG  +1      # B(1)

PERRB           EQUALS  STROKER +1      # B(2)
YERRB           EQUALS  PERRB   +2      # B(2)

DELPBAR         EQUALS  YERRB   +2      # B(2)
DELYBAR         EQUALS  DELPBAR +2      # B(2)

PDELOFF         EQUALS  DELYBAR +2      # B(2)
YDELOFF         EQUALS  PDELOFF +2      # B(2)

# TVC ZEROING LOOP ENDS HERE
TTMP1           EQUALS  YDELOFF +2      # B(2)
TTMP2           EQUALS  TTMP1   +2      # B(2)
DAP1            EQUALS  TTMP2   +2      # B(2)
DAP2            EQUALS  DAP1    +2      # B(2)
DAP3            EQUALS  DAP2    +2      # B(2)

PCMD            EQUALS  DAP3    +2      # B(1)
YCMD            EQUALS  PCMD    +1      # B(1), CONSECUTIVE WITH PCMD
T5TVCDT         EQUALS  YCMD    +1      # B(1)
MDT             EQUALS  T5TVCDT +1      # I(6)
KPRIMEDT        EQUALS  MDT     +6      # I(2)
KTLX/I          EQUALS  KPRIMEDT +2     # B(1)
TENMDOT         EQUALS  KTLX/I  +1      # B(1)
1/CONACC        EQUALS  TENMDOT +1      # B(1)
VARK            EQUALS  1/CONACC +1     # B(1)
REPFRAC         EQUALS  VARK    +1      # B(1)
VCNTR           EQUALS  REPFRAC +1      # B(1)
TVCPHASE        EQUALS  VCNTR   +1      # B(1)
PCDUYPST        EQUALS  TVCPHASE +1     # B(1)
PCDUZPST        EQUALS  PCDUYPST +1     # B(1)
```

```
MCDUYDOT        EQUALS  PCDUZPST +1     # B(1)
MCDUZDOT        EQUALS  MCDUYDOT +1     # B(1)
```

Defines:
1/CONACC, used in chunks 1347, 1356, 1373, and 1396.
DAP1, used in chunk 1373.
DAP2, used in chunk 1373.
DAP3, used in chunk 1373.
DELPBAR, used in chunks 1094, 1347, 1356, and 1373.
DELYBAR, used in chunks 1094, 1347, 1356, and 1373.
KPRIMEDT, used in chunks 1094 and 1347.
KTLX/I, used in chunk 1347.
MCDUYDOT, used in chunk 1373.
MCDUZDOT, used in chunks 206 and 1373.
MDT, never used.
PCDUYPST, used in chunk 1373.
PCDUZPST, used in chunk 1373.
PCMD, used in chunks 295, 1347, 1367, and 1373.
PDELOFF, used in chunks 1347, 1356, and 1373.
PERRB, used in chunks 1347 and 1373.
PTMP6, used in chunk 1373.
REPFRAC, used in chunks 1094, 1347, and 1356.
ROLLFIRE, used in chunk 1396.
ROLLWORD, used in chunk 1396.
STROKER, used in chunks 424, 1367, 1373, and 1390.
T5TVCDT, used in chunks 424, 1347, and 1373.
TEMREG, used in chunk 1396.
TENMDOT, used in chunks 1347 and 1356.
TTMP1, used in chunks 208, 1347, 1356, and 1373.
TTMP2, used in chunks 208 and 1373.
TVCPHASE, used in chunks 1094, 1347, 1367, 1373, and 2828.
VARK, used in chunks 1347, 1356, and 1373.
VCNTR, used in chunks 1094, 1347, and 1356.
YCMD, used in chunks 295, 1347, 1367, and 1373.
YDELOFF, used in chunks 1347, 1356, and 1373.
YERRB, used in chunks 1347 and 1373.
YTMP1, used in chunk 1373.
YTMP2, used in chunk 1373.
YTMP3, used in chunk 1373.
YTMP4, used in chunk 1373.
YTMP5, used in chunk 1373.
YTMP6, used in chunk 1373.
Uses I 206 and PTMP5 202.

206 ⟨*Page CM0106* 206⟩≡ (75 2684)

```
TVCEXPHS        EQUALS  MCDUZDOT +1     # B(1)
MASSTMP         EQUALS  TVCEXPHS +1     # B(1)  PROTECT
VCNTRTMP        EQUALS  MASSTMP +1      # B(1)    *PROTECT***

# STROKE TEST VARIABLES
STRKTIME        EQUALS  VCNTRTMP +1     # B(1)
CADDY           EQUALS  STRKTIME +1     # B(1)
N               EQUALS  CADDY   +1      # B(1)
BUNKER          EQUALS  N       +1      # B(1)
REVS            EQUALS  BUNKER  +1      # B(1)
CARD            EQUALS  REVS    +1      # B(1)

# TVC ROLL DAP VARIABLES
OGANOW          EQUALS  CARD    +1      # B(1)
OGAPAST         EQUALS  OGANOW  +1      # B(1)
OGA             EQUALS  OGAPAST +1      # B(1)TMP
OGAERR          =       OGA             # (ROLL DAP USES OGA, MEANS OGAERROR)
DELOGART        EQUALS  OGA     +1      # B(1)TMP
SGNRT           EQUALS  DELOGART +1     # SIGN OF CGA RATE
DELOGA          EQUALS  SGNRT   +1      # USED IN ROLL LOGIC
I               EQUALS  DELOGA  +1      # USED IN ROLL LOGIC
IOGARATE        EQUALS  I       +1      # USED IN ROLL LOGIC

# TVC DAP RESTART TEMPORARIES.
PACTTMP         EQUALS  IOGARATE +1     # B(2)
YACTTMP         EQUALS  PACTTMP +2      # B(2)
CNTRTMP         EQUALS  YACTTMP +2      # B(1)
STRKTTMP        EQUALS  CNTRTMP +1      # B(1)
DELBRTMP        EQUALS  STRKTTMP +1     # B(2)
ERRBTMP         EQUALS  DELBRTMP +2     # B(2)
CMDTMP          EQUALS  ERRBTMP +2      # B(2)

TMP1            EQUALS  CMDTMP  +2      # B(2)
TMP2            EQUALS  TMP1    +2      # B(2)
TMP3            EQUALS  TMP2    +2      # B(2)
TMP4            EQUALS  TMP3    +2      # B(2)
TMP5            EQUALS  TMP4    +2      # B(2)
TMP6            EQUALS  TMP5    +2      # B(2)

# TVC DAP FILTER COEFFICIENTS TEMPORARIES
COEFFADR        EQUALS  TMP6    +2      # B(1)
N10             EQUALS  COEFFADR +1     # I(15)
```

Defines:
BUNKER, used in chunk 1390.
CADDY, used in chunk 1390.

CARD, used in chunks 78 and 1390.
CMDTMP, used in chunks 208 and 1373.
CNTRTMP, used in chunks 1347 and 1356.
COEFFADR, used in chunk 1347.
DELBRTMP, used in chunks 1373, 2684, and 2824.
DELOGA, used in chunk 1396.
DELOGART, used in chunk 1396.
ERRBTMP, used in chunks 208, 1094, 1347, and 1373.
I, used in chunks 30, 78, 135, 138, 140, 145, 148, 157, 159, 161, 165, 166, 172, 174, 175, 177, 179, 181–83, 185, 186, 188, 190, 196–98, 202, 204, 208, 219, 221, 223, 224, 229, 232, 234, 236, 238–41, 243, 244, 276, 339, 357, 405, 419, 428, 482, 583, 647, 653, 655, 657, 893, 897, 961, 967, 977, 981, 983, 989, 993, 1001, 1003, 1005, 1007, 1009, 1045, 1147, 1200, 1347, 1396, 1412, 1436, 1449, 1524, 1526, 1536, 1543, 1616, 1625, 1628, 1651, 1684, 1774, 1935, 1936, 1946, 1947, 2001, 2087, 2104, 2116, 2152, 2156, 2158, 2162, 2311, 2424, 2461, 2463, 2472, 2496, 2515, 2519, 2561, 2596, 2609, and 2742.
IOGARATE, used in chunk 1396.
MASSTMP, used in chunks 337, 1094, 1347, and 1356.
N, used in chunks 20, 42, 48, 78, 154, 231, 317, 390, 424, 430, 438, 487, 489, 508, 512, 527, 585, 593, 599, 635, 637, 638, 640, 642, 651, 745, 788, 804, 825, 827, 829, 893, 909, 915, 930, 934, 941, 969, 989, 993, 1003, 1005, 1007, 1009, 1011, 1013, 1054, 1147, 1195, 1200, 1254, 1301, 1347, 1373, 1390, 1412, 1456, 1481, 1498, 1526, 1538, 1575, 1576, 1640, 1663, 1852, 1872, 1874, 1932, 1939, 1961, 2001, 2132, 2141, 2148, 2154, 2219, 2258, 2293, 2299, 2311, 2382, 2463, 2472, 2474, 2478, 2480, 2519, 2633, 2721, 2767, 2790, and 2826.
N10, used in chunks 208, 1347, 1373, 1951, and 2826.
OGA, used in chunks 680, 1200, 1356, 1396, 1839, and 2187.
OGAERR, used in chunks 1356 and 1396.
OGANOW, used in chunks 329, 1347, 1356, and 1396.
OGAPAST, used in chunks 1356 and 1396.
PACTTMP, used in chunk 1356.
REVS, used in chunks 241, 750, 874, 961, 963, 965, 971, 975, 1094, 1147, 1301, 1356, 1373, 1390, 1675–77, 1684, 2057b, and 2128.
SGNRT, used in chunk 1396.
STRKTIME, used in chunk 1347.
STRKTTMP, never used.
TMP1, used in chunk 1373.
TMP2, used in chunk 1373.
TMP3, used in chunk 1373.
TMP4, used in chunk 1373.
TMP5, used in chunk 1373.
TMP6, used in chunk 1373.
TVCEXPHS, used in chunks 1094, 1356, and 1367.
VCNTRTMP, used in chunks 1094 and 1356.
YACTTMP, used in chunk 1356.

Uses MCDUZDOT 204 and RESTART 57.

208 ⟨*Page CM0107* 208⟩≡ (75 2684)

```
# OVERLAYS WITHIN TVC DAP

OGARATE         =       OMEGAB          # B(2)

PHASETMP        =       TTMP1           # B(1) RESTART FOR CSM/LM V46 SWITCH-OVER
RTRNLOC         =       TTMP2           # B(1) RESTART FOR CSM/LM V46 SWITCH-OVER
BZERO           =       ERRBTMP
CZERO           =       ERRBTMP
JZERO           =       CMDTMP
YZERO           =       CMDTMP

# 540.9 STORAGE .............

NBRCYCLS        EQUALS  N10     +15D    # B(1) COUNTER FOR P40,41 STEERING
NBRCYCLP        EQUALS  NBRCYCLS +1     # B(1) MAINTAIN ORDER
DELVSUM         EQUALS  NBRCYCLP +1     # I(6) P40,P41
DELVSUMP        EQUALS  DELVSUM +6      # I(6) P40,P41
```

Defines:
BZERO, used in chunks 321, 1347, 1356, 1362, 1373, and 1396.
CZERO, never used.
DELVSUM, used in chunk 1094.
DELVSUMP, used in chunk 1094.
JZERO, never used.
NBRCYCLP, used in chunk 1094.
NBRCYCLS, used in chunk 1094.
OGARATE, used in chunks 297 and 1396.
PHASETMP, used in chunk 1347.
RTRNLOC, used in chunk 1347.
YZERO, never used.
Uses CMDTMP 206, ERRBTMP 206, I 206, N10 206, OMEGAB 202, RESTART 57, TTMP1 204, and TTMP2 204.

209 ⟨*Page CM0108* 209⟩≡ (75 2684)

```
# **** RCS DAP TEMPORARY VARIABLES. ********************        (95D)

# ** RCS INTERRUPT TRUE TEMPS ***************   (15D)
SPNDX           EQUALS  INTTEMP         # B(1)
DPNDX           EQUALS  SPNDX   +1      # B(1)TMP
KMPAC           EQUALS  DPNDX   +1      # B(2)TMP
KMPTEMP         EQUALS  KMPAC   +2      # B(1)TMP

XNDX1           EQUALS  KMPTEMP +1      # B(1)TMP XNDX1 THRU NYJETS ARE OVERLAYED
XNDX2           EQUALS  XNDX1   +1      # B(1)TMP BY OTHER DAP ERASABLES SO
YNDX            EQUALS  XNDX2   +1      # B(1)TMP SHOULD ALWAYS BE DEFINED IN
ZNDX            EQUALS  YNDX    +1      # B(1)TMP A BLOCK
RINDEX          EQUALS  ZNDX    +1      # B(1)TMP
PINDEX          EQUALS  RINDEX  +1      # B(1)TMP
YINDEX          EQUALS  PINDEX  +1      # B(1)TMP
NRJETS          EQUALS  YINDEX  +1      # B(1)TMP
NPJETS          EQUALS  NRJETS  +1      # B(1)TMP
NYJETS          EQUALS  NPJETS  +1      # B(1)TMP

WTEMP           EQUALS  XNDX1           # B(2)TMP WTEMP THRU DELTEMPZ OVERLAY
DELTEMPX        EQUALS  WTEMP   +2      # B(2)TMP XNDX1 THRU NRJETS AND EDOT THRU
DELTEMPY        EQUALS  DELTEMPX +2     # B(2)TMP ADBVEL
DELTEMPZ        EQUALS  DELTEMPY +2     # B(2)TMP

EDOT            EQUALS  YNDX            # B(2)TMP EDOT THRU ADBVEL OVERLAY
AERR            EQUALS  EDOT    +2      # B(1)TMP YNDX THRU NPJETS AND DELTEMPX
EDOTVEL         EQUALS  AERR    +1      # B(2)TMP THRU DELTEMPZ
AERRVEL         EQUALS  EDOTVEL +2      # B(1)TMP
ADBVEL          EQUALS  AERRVEL +1      # B(1)TMP

# *** REGULAR RCS TEMPS ********************   (   ).

# *** RCS ZEROING LOOP STARTS HERE **********   (37)
WBODY           EQUALS  TVCRCS          # B(2)TMP
WBODY1          EQUALS  WBODY   +2      # B(2)TMP
WBODY2          EQUALS  WBODY   +4      # B(2)TMP
ADOT            EQUALS  WBODY2  +2      # B(2)TMP
ADOT1           EQUALS  ADOT    +2      # B(2)TMP
ADOT2           EQUALS  ADOT1   +2      # B(2)TMP

MERRORX         EQUALS  ADOT2   +2      #  (2)
MERRORY         EQUALS  MERRORX +2      #  (2)
MERRORZ         EQUALS  MERRORY +2      #  (2)
DFT             EQUALS  MERRORZ +2      # B(1)TMP
DFT1            EQUALS  DFT     +1      # B(1)TMP
```

```
DFT2            EQUALS  DFT1    +1      # B(1)TMP
DRHO            EQUALS  DFT2    +1      # B(2)TMP
DRHO1           EQUALS  DRHO    +2      # B(2)TMP
```

Defines:
ADBVEL, used in chunks 1441, 1445, and 1447.
ADOT, used in chunks 223, 297, 1412, and 1441.
ADOT1, used in chunk 1412.
ADOT2, used in chunk 1412.
AERR, used in chunks 1441, 1445, and 1447.
AERRVEL, used in chunks 1441, 1443, and 1445.
DELTEMPX, used in chunk 1412.
DELTEMPY, used in chunk 1412.
DELTEMPZ, used in chunk 1412.
DFT, used in chunks 1412, 1466, 1469, 1471, and 1473.
DFT1, used in chunks 1412, 1466, and 1467.
DFT2, used in chunks 1412 and 1468.
DPNDX, used in chunks 1412 and 1441.
DRHO, used in chunk 1412.
DRHO1, used in chunks 211 and 1412.
EDOT, used in chunks 1441, 1445, 1447, 1448, 2542, 2561, and 2625.
EDOTVEL, used in chunks 1441, 1443, and 1445.
KMPAC, used in chunks 357, 1410, 1412, 1434, 1445, 1447–51, 1453, 1475, and 2747.
KMPTEMP, used in chunk 1410.
MERRORX, used in chunk 1412.
MERRORY, used in chunk 1412.
MERRORZ, used in chunk 1412.
NPJETS, used in chunks 1456, 1466, and 1467.
NRJETS, used in chunks 1460–62, 1469, 1471, and 1473.
NYJETS, used in chunks 1457 and 1468.
PINDEX, used in chunks 1455 and 1456.
RINDEX, used in chunks 1458 and 1461.
SPNDX, used in chunks 216, 1412, 1441, 1447, and 1449.
WBODY, used in chunks 223, 297, 302, 688, 690, 915, 963, 965, 969, 971, 1412, 1438, and 1441.
WBODY1, used in chunks 688, 690, 915, 965, 971, 1412, and 1438.
WBODY2, used in chunks 688, 690, 915, 965, 971, 1412, and 1438.
WTEMP, used in chunks 1412, 1443, and 1445.
XNDX1, used in chunks 1453, 1455, 1456, and 1470b.
XNDX2, used in chunks 1453, 1455, 1457, and 1474.
YINDEX, used in chunks 1456 and 1457.
YNDX, used in chunks 1453, 1455, 1458, 1461, and 1471.
ZNDX, used in chunks 1453, 1455, 1458, 1460, 1461, 1471, and 1473.
Uses A 80, INTTEMP 202, and TVCRCS 202.

211 ⟨*Page CM0109* 211⟩≡ (75 2684)

```
DRHO2           EQUALS  DRHO1   +2      # B(2)TMP
ATTSEC          EQUALS  DRHO2   +2      # B(1)TMP
TAU             EQUALS  ATTSEC  +1      # B(1)TMP
TAU1            EQUALS  TAU     +1      # B(1)TMP
TAU2            EQUALS  TAU1    +1      # B(1)TMP
BIAS            EQUALS  TAU2    +1      # B(1)TMP
BIAS1           EQUALS  BIAS    +1      # B(1)TMP
BIAS2           EQUALS  BIAS1   +1      # B(1)TMP
ERRORX          EQUALS  BIAS2   +1      # B(1)TMP
ERRORY          EQUALS  ERRORX  +1      # B(1)TMP
ERRORZ          EQUALS  ERRORY  +1      # B(1)TMP

# RCS ZERO LOOP ENDS HERE
#       MORE RCS                        (69D)
THETADX         EQUALS  ERRORZ  +1      # B(1)TMP MUST BE CONSECUTIVE WITH ERRORZ
THETADY         EQUALS  THETADX +1      # B(1)TMP
THETADZ         EQUALS  THETADY +1      # B(1)TMP

DELCDUX         EQUALS  THETADZ +1      # B(2)TMP
DELCDUY         EQUALS  DELCDUX +2      # B(2)TMP
DELCDUZ         EQUALS  DELCDUY +2      # B(2)TMP

DCDU            EQUALS  DELCDUZ +2      # B(6)TMP USED DURING P20
DTHETASM        EQUALS  DCDU    +6      # B(6)TMP STEER LOW OUTPUT.

ATTKALMN        EQUALS  DTHETASM +6     # B(1)TMP
KMJ             EQUALS  ATTKALMN +1     # B(1)TMP
KMJ1            EQUALS  KMJ     +1      # B(1)TMP
KMJ2            EQUALS  KMJ1    +1      # B(1)TMP
J/M             EQUALS  KMJ2    +1      # B(1)TMP
J/M1            EQUALS  J/M     +1      # B(1)TMP
J/M2            EQUALS  J/M1    +1      # B(1)TMP
RACFAIL         EQUALS  J/M2    +1      # B(1)TMP
RBDFAIL         EQUALS  RACFAIL +1      # B(1)TMP
ACORBD          EQUALS  RBDFAIL +1      # B(1)TMP
XTRANS          EQUALS  ACORBD  +1      # B(1)TMP
CH31TEMP        EQUALS  XTRANS  +1      # B(1)TMP
CHANTEMP        EQUALS  CH31TEMP +1     # B(1)TMP
T5TIME          EQUALS  CHANTEMP +1     # B(1)TMP
RHO             EQUALS  T5TIME  +1      # B(1)TMP
RHO1            EQUALS  RHO     +1      # B(1)TMP
RHO2            EQUALS  RHO1    +1      # B(1)TMP
AMGB1           EQUALS  RHO2    +1      # B(1)TMP
AMGB4           EQUALS  AMGB1   +1      # B(1)TMP
```

Defines:

ACORBD, used in chunks 1094, 1458, 1471, and 1473.
AMGB1, used in chunks 1412, 1436, and 1451.
AMGB4, used in chunks 213, 1412, 1436, and 1451.
ATTKALMN, used in chunks 1412, 1453, and 1455.
ATTSEC, used in chunk 1412.
BIAS, used in chunks 46, 101, 119, 167, 493, 555, 557, 583, 682, 688, 690, 882, 927, 1094, 1252, 1412, 1436, 1438, 1441, 1457, 1463, 1465, 1497, 1502, 1693, 2046, 2078, 2277, and 2441.
BIAS1, used in chunks 688, 690, 1412, 1436, and 1438.
BIAS2, used in chunks 688, 690, 1412, 1436, and 1438.
CH31TEMP, used in chunks 1412, 2519, and 2542.
CHANTEMP, used in chunks 1412 and 1434.
DCDU, used in chunks 216, 686, 963, 967, 969, 971, 973, and 1844.
DELCDUX, used in chunks 684, 690, 915, 961, 963, 965, 971, 1412, 2441, 2452, 2502, and 2519.
DELCDUY, used in chunks 690, 915, 965, 973, 1412, 2502, and 2519.
DELCDUZ, used in chunks 690, 915, 965, 973, 1412, 2502, and 2519.
DRHO2, used in chunk 1412.
DTHETASM, used in chunks 961, 963, 965, 967, 969, and 1844.
ERRORX, used in chunks 218, 297, 302, 1412, 1436, 1438, and 1441.
ERRORY, used in chunks 218, 297, 1094, 1347, 1412, 1436, and 1438.
ERRORZ, used in chunks 297, 1347, 1412, 1436, 1438, and 1506.
J/M, used in chunks 1094 and 1449.
J/M1, used in chunks 1094 and 1449.
J/M2, used in chunks 1094 and 1449.
KMJ, used in chunks 1094 and 1412.
KMJ1, used in chunk 1094.
KMJ2, used in chunk 1094.
RACFAIL, used in chunks 1094, 1455, 1458, 1461, 1470b, and 1471.
RBDFAIL, used in chunks 1094, 1456, 1460, 1461, 1473, and 1474.
RHO, used in chunks 188, 985, 999, 1412, 1718, 1754, 1767, and 1814.
RHO1, used in chunk 1412.
RHO2, used in chunk 1412.
T5TIME, used in chunks 1412 and 1453.
TAU, used in chunks 177, 1412, 1434, 1449, 1450a, 1458, 1460, 1461, 1466, 1469, 1714, 1715, 1729, 1731, 1733, 1765, 1796, 1814, 2045, 2311, and 2367.
TAU1, used in chunks 1412, 1434, 1449, 1450a, 1455, 1466, and 1467.
TAU2, used in chunks 1412, 1435, 1449, 1450a, 1456, and 1468.
THETADX, used in chunks 218, 297, 302, 1094, 1412, 1436, and 1438.
THETADY, used in chunks 297, 1094, 1412, and 1436.
THETADZ, used in chunks 223, 297, 1412, 1436, and 1438.
XTRANS, used in chunks 1094, 1455, and 2542.

Uses DRHO1 209.

213 ⟨*Page CM0110* 213⟩≡ (75 2684)

```
AMGB5           EQUALS  AMGB4   +1      # B(1)TMP
AMGB7           EQUALS  AMGB5   +1      # B(1)TMP
AMGB8           EQUALS  AMGB7   +1      # B(1)TMP
CAPSI           EQUALS  AMGB8   +1      # B(1)TMP
CDUXD           EQUALS  CAPSI   +1      # B(2)TMP
CDUYD           EQUALS  CDUXD   +2      # B(2)TMP
CDUZD           EQUALS  CDUYD   +2      # B(2)TMP
SLOPE           EQUALS  CDUZD   +2      # B(1)TMP
ADB             EQUALS  SLOPE   +1      # B(1)TMP
RMANNDX         EQUALS  ADB     +1      # B(1)TMP
PMANNDX         EQUALS  RMANNDX +1      # B(1)TMP
YMANNDX         EQUALS  PMANNDX +1      # B(1)TMP MUST BE LAST VARIABLE IN RCS
```

Defines:
ADB, used in chunks 1094, 1439, 1441, 1443, and 1445.
AMGB5, used in chunks 1412, 1436, and 1451.
AMGB7, used in chunks 1412, 1436, and 1451.
AMGB8, used in chunks 1412, 1436, and 1451.
CAPSI, used in chunk 1451.
CDUXD, used in chunks 686, 690, 691a, 963, 965, 971, 1412, 2152, 2169, 2441, 2443, 2446, 2448, 2496, 2499b, 2502, 2519, and 2542.
CDUYD, used in chunks 691a, 965, 971, 1412, 2152, 2441, 2443, 2502, 2519, and 2542.
CDUZD, used in chunks 691a, 965, 971, 1412, 2152, 2441, 2443, 2448, 2502, 2519, and 2542.
PMANNDX, used in chunks 891, 1412, and 1434.
RMANNDX, used in chunks 891, 1412, and 1434.
SLOPE, used in chunks 241, 1063, 1362, 1390, 1396, 1412, 1439, 1443, 1445, 1447, and 2223.
YMANNDX, used in chunks 219, 891, 1412, and 1434.
Uses AMGB4 211.

214 ⟨*Page CM0111* 214⟩≡ (75 2684)

```
# ********** ENTRY DAP TEMPORARY VARIABLES. ********************       (69D)

# ANGLE REGISTERS FOR ENTRY DAPS
AOG             EQUALS  BCDU            # 1P
AIG             EQUALS  AOG     +1      # 1P
AMG             EQUALS  AIG     +1      # 1P
ROLL/180        EQUALS  AMG     +1      # 1P
ALFA/180        EQUALS  ROLL/180 +1     # 1P
BETA/180        EQUALS  ALFA/180 +1     # 1P
AOG/PIP         EQUALS  BETA/180 +1     # 1P
AIG/PIP         EQUALS  AOG/PIP +1      # 1P
AMG/PIP         EQUALS  AIG/PIP +1      # 1P
ROLL/PIP        EQUALS  AMG/PIP +1      # 1P
ALFA/PIP        EQUALS  ROLL/PIP +1     # 1P
BETA/PIP        EQUALS  ALFA/PIP +1     # 1P

# GYMBAL DIFFERENCES OVER INTERNAL TCDU = .1 SEC.
-DELAOG         EQUALS  BETA/PIP +1     # 1P
-DELAIG         EQUALS  -DELAOG +1      # 1P
-DELAMG         EQUALS  -DELAIG +1      # 1P

# ESTIMATED BODY RATES
CMDAPMOD        EQUALS  -DELAMG +1      # 1P GOES BEFORE PREL FOR TM.

PREL            EQUALS  CMDAPMOD +1     # 1P P TCDU/180         (ROLLDOT)
QREL            EQUALS  PREL    +1      # 1P Q TCDU/180         (PITCHDOT)
RREL            EQUALS  QREL    +1      # 1P R TCDU/180         (YAWDOT)

BETADOT         EQUALS  RREL    +1      # 1P MUST FOLLOW RREL. BETADOT TCDU/180
PHIDOT          EQUALS  BETADOT +1      # 1P

# OLD (UNAVERAGED) BODY RATE MEASURE
OLDELP          EQUALS  PHIDOT  +1      # 1P
OLDELQ          EQUALS  OLDELP  +1      # 1P
OLDELR          EQUALS  OLDELQ  +1      # 1P

JETAG           EQUALS  OLDELR  +1      # 1P
TUSED           EQUALS  JETAG   +1      # 1P ELAPSED TIME SINCE NOMINAL UPDATE.

# FOLLOWING 3 SP WORDS IN DOWNLINK.  ROLLTM SENT EACH 1 SEC.
PAXERR1         EQUALS  TUSED   +1      # 1P INTEGRATED ROLL ERROR/360.
ROLLTM          EQUALS  PAXERR1 +1      # 1P ROLL/180 FOR TM.
ROLLC           EQUALS  ROLLTM  +1      # 2P ROLLCOM/360 FROM ENTRY (FOR TM)
                                        # KEEP ROLLC & ROLLHOLD ADJACENT FOR TP
```

Defines:

-DELAIG, used in chunks 1481, 1489, and 1491.
-DELAMG, used in chunks 1481, 1489, and 1491.
-DELAOG, used in chunks 1481 and 1491.
AIG, used in chunks 977, 1293, 1481, and 2382.
AIG/PIP, used in chunk 1293.
ALFA/180, used in chunks 302, 1295, 1299, 1486, and 1493.
ALFA/PIP, used in chunk 1299.
AMG, used in chunks 977, 1227, 1293, 1481, 1489, 1491, and 2382.
AMG/PIP, used in chunks 1227 and 1293.
AOG, used in chunks 229, 357, 364, 370, 372, 374, 376, 870, 977, 1200, 1227, 1256, 1293, 1297, 1299, 1300a, 1481, 1483, 1485, 1487, 1489, 1492, 1498, 1516, 2382, and 2430.
AOG/PIP, used in chunks 1227, 1293, and 1481.
BETA/180, used in chunks 302, 1227, 1295, 1299, 1487, 1493, 1495, 1500, and 1502.
BETA/PIP, used in chunks 1227 and 1299.
BETADOT, used in chunks 1493, 1498, 1500, and 1502.
CMDAPMOD, used in chunks 216, 302, 1200, 1256, 1485, 1495, 1496, 1498, 1500, 1506, 1518, and 1519.
JETAG, used in chunks 1483, 1485, 1496, 1500, 1504, 1506, 1510, 1513, and 1518.
OLDELP, used in chunks 1483 and 1491.
OLDELQ, used in chunks 1483 and 1489.
OLDELR, used in chunks 1483 and 1491.
PAXERR1, used in chunks 302, 1485, 1502, 1506, and 1519.
PHIDOT, used in chunks 1493, 1495, and 1519.
PREL, used in chunks 302, 1491, 1493, 1495, 1498, 1504, and 1521.
QREL, used in chunks 302, 1489, 1492, 1493, 1495, 1498, and 1500.
ROLL/180, used in chunks 1227, 1295, 1297, 1299, 1486, 1491, 1495, 1502, 1504, and 1518.
ROLL/PIP, used in chunks 1227 and 1297.
ROLLC, used in chunks 42, 216, 229, 302, 474, 1200, 1248, 1254, 1256, 1486, 1498, 1504, 1506, 1518, and 1519.
ROLLTM, used in chunks 302, 1495, and 1518.
RREL, used in chunks 302, 1491–93, 1495, 1498, 1500, and 1521.
TUSED, used in chunks 1504, 1513, 1514, and 1516.

Uses BCDU 219, P 188, Q 80, ROLLHOLD 216, and TM 219.

216 ⟨*Page CM0112* 216⟩≡ (75 2684)

```
ROLLHOLD        EQUALS  ROLLC   +2      # 1P FOR ATTITUDE HOLD IN CMDAPMOD = +1

# ENTRY DAP QUANTITIES THAT SHARE WITH RCS DAP.
ALFACOM         EQUALS  DCDU            # 1P KEEP ADJACENT TO BETACOM. <<
BETACOM         EQUALS  ALFACOM +1      # 1P

# JET LIST.  DT, JETBITS IN THIS ORDER.
TOFF            EQUALS  BETACOM +1      # 1P DP PAIR
TBITS           EQUALS  TOFF    +1      # 1P
TON2            EQUALS  TBITS   +1      # 1P DP PAIR
T2BITS          EQUALS  TON2    +1      # 1P

# MISCELLANEOUS PERMANENT ERASABLE.
OUTTAG          EQUALS  T2BITS  +1      # 1P
NUJET           EQUALS  OUTTAG  +1      # 1P

# MORE ENTRY DAP QUANTITIES THAT DO NOT SHARE WITH RCS DAP.
JETEM           EQUALS  ROLLHOLD +1     # 2P THIS DP USED IN RATEAVG
GAMA            EQUALS  JETEM   +2      # 1P
GAMDOT          EQUALS  GAMA    +1      # 1P
POSEXIT         EQUALS  GAMDOT  +1      # 1P
CM/GYMDT        EQUALS  POSEXIT +1      # 1P
HEADSUP         EQUALS  CM/GYMDT +1     # 1P DSP NOUN 61 FOR P62,63,64,67.
P63FLAG         EQUALS  HEADSUP +1      # 1P INTERLOCK FOR WAKEP62

                                        #>> SHARE BELOW WITH RCS RUPT TEMPS (< 15D) <
CALFA           EQUALS  SPNDX           # 1P
SALFA           EQUALS  CALFA   +1      # 1P

SINM            EQUALS  SALFA   +1      # 1P
COSM            EQUALS  SINM    +1      # 1P
SINO            EQUALS  COSM    +1      # 1P
COSO            EQUALS  SINO    +1      # 1P
SINOCOSM        EQUALS  COSO    +1      # 1P
COSOCOSM        EQUALS  SINOCOSM +1     # 1P
                                        #>> SHARE ABOVE WITH RCS RUPT TEMPS <<<

# THE FOLLOWING FEW REGISTERS USED ONCE EACH 2 SEC
-VT/180         EQUALS  NUJET   +1      # 1P
LCX/360         EQUALS  -VT/180 +1      # 1P
XD/360          EQUALS  LCX/360 +1      # 1P
VSQ/4API        EQUALS  XD/360  +1      # 1P
JNDX            EQUALS  VSQ/4API +1     # 1P
JNDX1           EQUALS  JNDX    +1      # 1P
```

Defines:

-VT/180, used in chunks 1504, 1506, 1508, 1510, and 1512.
ALFACOM, used in chunks 1200, 1486, 1495, and 1498.
BETACOM, used in chunks 1200, 1495, 1498, 1500, and 1502.
CALFA, used in chunks 1493, 1498, 1500, 1506, and 1519.
CM/GYMDT, used in chunks 377, 1227, 1481, and 1487.
COSM, used in chunks 1489 and 1491.
COSO, used in chunks 1489 and 1491.
COSOCOSM, used in chunk 1489.
GAMA, used in chunks 1296 and 1297.
GAMDOT, used in chunks 119, 1297, 1483, 1491, and 1492.
HEADSUP, used in chunks 42, 472, 1200, 1248, 1256, 1485, and 1486.
JETEM, used in chunks 1483, 1484, 1487, 1489, 1491, 1492, 1495, 1497, and 1500.
JNDX, used in chunks 1504, 1508, 1510, 1512, and 1514.
JNDX1, used in chunks 218, 1508, 1510, 1512, 1514, and 1516.
LCX/360, used in chunks 1504, 1506, 1508, 1510, and 1512.
NUJET, used in chunk 1516.
OUTTAG, used in chunks 1516 and 1518.
P63FLAG, used in chunks 1200, 1485, 1498, and 1500.
POSEXIT, used in chunks 1200, 1256, and 1299.
ROLLHOLD, used in chunks 214, 1256, 1486, 1502, and 1518.
SALFA, used in chunks 1493 and 1502.
SINM, used in chunks 1491 and 1504.
SINO, used in chunks 1489 and 1491.
SINOCOSM, used in chunks 1489 and 1491.
T2BITS, used in chunks 1514 and 1516.
TBITS, used in chunks 1514 and 1516.
TOFF, used in chunks 1513, 1514, and 1516.
TON2, used in chunks 1510, 1512–14, and 1516.
VSQ/4API, used in chunks 1508 and 1510.
XD/360, used in chunks 1510 and 1512.

Uses CMDAPMOD 214, DCDU 211, ROLLC 214, and SPNDX 209.

218 ⟨*Page CM0113* 218⟩≡ (75 2684)

```
TON1            EQUALS  JNDX1   +1      # 1P DP PAIR
T1BITS          EQUALS  TON1    +1      # 1P

# MISCELLANEOUS REGISTERS USED EACH UPDATE.
CM/SAVE         EQUALS  T1BITS  +1      # 1P
JETEM2          EQUALS  CM/SAVE +1      # 1P TEMPORARY STORAGE

# DAP QUANTITIES SHARED WITH RCS DAP FOR TM & FLIGHT RECORDER.
VDT/180         =       ERRORX          # 1P (EDIT)
-VT/180E        =       ERRORY          # 1P (EDIT)

PAXERR          EQUALS  AK              # 1P ROLL ERROR FOR NEEDLES
QAXERR          =       THETADX         # 1P SINCE AK1 IS ZEROED IN ATM DAP.
RAXERR          =       QAXERR  +1      # 1P SINCE AK2 IS ZEROED IN TM DAP.

# *** COLMANU (R60,R62) ****
VECQTEMP        EQUALS  COFSKEW
```

Defines:
-VT/180E, used in chunk 1508.
CM/SAVE, used in chunks 1493 and 1521.
JETEM2, used in chunk 1497.
PAXERR, used in chunk 1519.
QAXERR, used in chunks 1495 and 1500.
RAXERR, used in chunks 1495, 1500, and 1502.
T1BITS, used in chunk 1514.
TON1, used in chunks 1510, 1512–14, and 1516.
VDT/180, used in chunks 1510, 1512, 1513, and 1518.
VECQTEMP, used in chunks 651, 653, and 657.

Uses AK 200, AK1 200, AK2 200, COFSKEW 219, ERRORX 211, ERRORY 211, JNDX1 216, SAVE 191, THETADX 211, and TM 219.

219 ⟨*Page CM0114* 219⟩≡ (75 2684)

```
# ******** KALCMANU VARIABLES. (71D) ******************************
BCDU            EQUALS  YMANNDX +1      # B(3)TMP
KSPNDX          EQUALS  BCDU    +3      # B(1)TMP
KDPNDX          EQUALS  KSPNDX  +1      # B(1)TMP

TMIS            EQUALS  KDPNDX  +1      # I(18) MUST BE IN THE SAME BANK AS RCS DAP
COFSKEW         EQUALS  TMIS    +18D    # I(6) MUST BE IN THE SAME BANK AS RCS DAP
CAM             EQUALS  COFSKEW +6      # I(2) MUST BE IN THE SAME BANK AS RCS DAP

MIS             EQUALS  CAM     +2      # I(18) (THE REST MAY GO ANYWHERE)
COF             EQUALS  MIS     +18D    # I(6)TMP
SCAXIS          EQUALS  COF     +6      # I(6)TMP
POINTVSM        EQUALS  SCAXIS  +6      # I(6)TMP
AM              EQUALS  POINTVSM +6     # I(2)TMP
RAD             EQUALS  AM      +2      # I(2)TMP

# FIRST-ORDER OVERLAYS IN KALCMANU
KV1             EQUALS  TMIS            # I(6)TMP
MFISYM          EQUALS  TMIS            # I   TMP
TMFI            EQUALS  TMIS            # I   TMP
NCDU            EQUALS  TMIS            # B   TMP
NEXTIME         EQUALS  TMIS    +3      # B   TMP
TTEMP           EQUALS  TMIS    +4      # B   TMP
KV2             EQUALS  TMIS    +6      # I(6)TMP
BIASTEMP        EQUALS  TMIS    +6      # B   TMP
KV3             EQUALS  TMIS    +12D    # I(6)TMP
CGF             EQUALS  TMIS    +12D    # I   TMP

BRATE           EQUALS  COFSKEW         # B   TMP
TM              EQUALS  CAM             # B   TMP

# SECOND-ORDER OVERLAYS IN KALCMANU
P21             EQUALS  KV1             # I(2)TMP
D21             EQUALS  KV1     +2      # I(2)TMP
G21             EQUALS  KV1     +4      # I(2)TMP

# SATURN BOOST STORAGE.  SAVE TILL RCS DAP OPERATION.   (17D)
POLYNUM         EQUALS  BCDU            # B(15) PAD LOADED
POLYLOC         =       POLYNUM +10D
SATRLRT         EQUALS  POLYNUM +15D    # B(2)  PAD LOADED

# MORE P11 STORAGE --PAD LOADED--       (2D)
```

Defines:

AM, used in chunks 662, 682, 2152, 2154, 2169, and 2171.

BCDU, used in chunks 214, 653, 660, 681a, 682, 684, 686, 688, 689, 1938, 2167, 2175, 2177,

and 2188a.
BIASTEMP, used in chunks 682 and 688.
BRATE, used in chunks 682 and 688.
CAM, used in chunks 662, 664, 2169, and 2171.
CGF, never used.
COF, used in chunks 651, 653, 655, 657, 662, 664, 666, 667, 674, 676, 678, 682, 2152, 2154, 2164, 2169, 2171, 2173, 2174, 2181, 2183, 2185, and 2311.
COFSKEW, used in chunks 218, 662, 666, 667, 2169, 2173, and 2174.
D21, used in chunks 1373, 2365, and 2367.
G21, never used.
KDPNDX, used in chunks 684 and 686.
KSPNDX, used in chunks 684 and 686.
KV1, never used.
KV2, never used.
KV3, never used.
MFISYM, used in chunks 662, 664, 666, 667, 2154, 2169, 2171, 2173, and 2174.
MIS, used in chunks 651, 653, 655, 657, 660, 684, 2154, and 2167.
NCDU, used in chunks 684 and 686.
NEXTIME, used in chunks 688 and 689.
P21, used in chunks 22, 52, 56a, 103, 179, 221, 244, 359, 745, and 747.
POINTVSM, used in chunks 651, 653, 973, 1013, 1021, 1094, 2148, 2165, and 2299.
POLYLOC, used in chunk 886.
POLYNUM, used in chunks 860, 862, and 876.
RAD, used in chunks 127, 221, 876, 878, 961, 975, 1094, 1200, 1252, 1254, 1675, 1684, 1780, 1852, 2049, 2057, 2087, 2450, 2452, 2512, 2513, 2519, 2542, 2561, 2574, 2601, 2605, 2606, 2611, and 2624.
SATRLRT, used in chunks 221, 868, 874, 878, and 886.
SCAXIS, used in chunks 651, 653, 655, 657, 973, 975, 1013, 1021, 1094, 2125, 2126, 2128, 2129, 2148, 2165, and 2299.
TM, used in chunks 145, 159, 214, 218, 223, 226, 229, 277, 330, 682, 686, 688, 1200, 1227, 1256, 1487, 1495, 1500, 1506, 1513, 1519, and 1521.
TMFI, used in chunks 660, 662, 664, 2169, and 2171.
TMIS, used in chunks 660 and 2167.
TTEMP, used in chunk 686.
Uses I 206, SAVE 191, and YMANNDX 213.

221 ⟨*Page CM0115* 221⟩≡ (75 2684)

```
# (NOTE:  THIS PAD LOAD WILL NOT BE PRESERVED THROUGHOUT THE MISSION AS IT SHARES STORAGE WITH
# ENTRY DAP AND TVC DAP)
RPSTART         EQUALS  SATRLRT +2      # B(1) PITCH ROLL START TIME
POLYSTOP        EQUALS  RPSTART +1      # B(1) POLYCUT OFF MINUS RPSTART SEC

# STORAGE FOR VHHDOT AND ATTDSP
BODY3           EQUALS  POLYSTOP +1     # B(1)OUT
BODY2           EQUALS  BODY3   +1      # B(1)OUT
BODY1           EQUALS  BODY2   +1      # B(1)OUT
SPOLYARG        EQUALS  BODY1   +1      # B(1)TMP ARGUMENT FOR POLLY

OLDBODY1        =       EDRIVEX         # 1 PULSE = 0.0432 DEGREES
OLDBODY2        =       EDRIVEY
OLDBODY3        =       EDRIVEZ

# STORAGE FOR S11.1
VDISP           EQUALS  SPOLYARG +1     # I(2)OUT       2(7) M/CS
HDISP           EQUALS  VDISP   +2      # I(2)OUT       2(29) M
HDOTDISP        EQUALS  HDISP   +2      # I(2)OUT       2(7) M/CS
BOOSTEMP        EQUALS  HDOTDISP +2     # B(3)TEMP

# P11 SATURN I/F                        (9D)
SATRATE         EQUALS  BOOSTEMP +3     # B(4)PL MANEUVER RATES FOR SATURN STICK
SATSW           EQUALS  SATRATE +4      # B(1)TEM STATUS SW FOR BOOST TAKEOVER
BIASAK          EQUALS  SATSW   +1      # B(3)TEM STOR AKBIAS FOR BOOST TAKEOVER
SATSCALE        EQUALS  BIASAK  +3      # B(1) SCALE FACTOR FOR SATURN STEERING

# P21 STORAGE.                          (1D)
GENRET          EQUALS  RAD     +2      # B(1)TMP

# R61CSM STORAGE.                       (1D)
SAVBNK          EQUALS  GENRET  +1      # B(1) S-S SAVE EBANK FOR R61 SUBROUTINE

# CRS61.1 STORAGE FOR AUTOPILOT BANK.   (3D)
SAVEDCDU        EQUALS  SAVBNK  +1      # B(3)TMP

# R61 STORAGE.                          (1D)
```

Defines:
BIASAK, used in chunks 882 and 884.
BODY1, used in chunk 862.
BODY2, used in chunk 862.
BODY3, used in chunks 372, 862, 864, 872, 890, and 891.
BOOSTEMP, used in chunks 880, 884, and 886.
GENRET, used in chunks 223, 934, and 936.
HDISP, never used.
HDOTDISP, used in chunks 2311 and 2382.

OLDBODY1, never used.
OLDBODY2, never used.
OLDBODY3, never used.
POLYSTOP, used in chunks 858, 860, 874, and 876.
RPSTART, used in chunks 858, 860, 874, and 876.
SATRATE, used in chunk 891.
SATSCALE, used in chunk 886.
SATSW, used in chunks 872, 876, 882, 884, and 2749.
SAVBNK, used in chunks 934 and 936.
SAVEDCDU, used in chunks 223, 963, 965, 967, 969, 971, and 973.
SPOLYARG, used in chunks 862, 876, and 878.
VDISP, never used.

Uses EBANK 80, EDRIVEX 200, EDRIVEY 200, EDRIVEZ 202, F 238, FACTOR 226, I 206, IT 185, P21 219, RAD 219, SATRLRT 219, SAVE 191, and TEMP 191.

223 ⟨*Page CM0116* 223⟩≡ (75 2684)

```
R61CNTR         EQUALS  SAVEDCDU +3     #  (1)TMP

# ENTRY RESTART PROTECTION STORAGE.  --KEEP TEMPS IN ORDER--    (12D)
TEMPROLL        EQUALS  GENRET          # B(1)TMP COPY CYCLE REGISTER
TEMPALFA        EQUALS  TEMPROLL +1     # B(1)TMP COPY CYCLE REGISTER
TEMPBETA        EQUALS  TEMPALFA +1     # B(1)TMP COPY CYCLE REGISTER
60GENRET        EQUALS  TEMPBETA +1     # B(1)TMP QSAVE FOR S61.1 AND ENTRY.
S61DT           EQUALS  60GENRET +1     # B(1)TMP VARIABLE DT FOR S61.1 RESTART.

# ENTRY TM SHARING FOR ACCELERATION PROFILE.
XPIPBUF         EQUALS  ADOT            # B(1) PIPA BUFFER FOR TM DURING ENTRY.
YPIPBUF         EQUALS  XPIPBUF +1      # B(1) PIPS FILED HERE EACH .5 SEC APPEAR
ZPIPBUF         EQUALS  YPIPBUF +1      # B(1) ON DOWNLIST ONCE PER SECOND DURING
XOLDBUF         EQUALS  ZPIPBUF +1      # B(1) ENTRY AFTER RCS DAP HAS BEEN DIS-
YOLDBUF         EQUALS  XOLDBUF +1      # B(1) ABLED.  NEWEST PIP VALUE REPLACES
ZOLDBUF         EQUALS  YOLDBUF +1      # B(1) PIPBUF, WHICH IS MOVED INTO OLDBUF.

# REENTRY VARIABLES SHARED WITH RCS DAP FOR TM & FLIGHT RECORDER.
Q7              =       THETADZ         # I(2) HI-WORD ONLY ON DNLIST.
ASPS(TM)        =       WBODY           # I(6)DWN
                                        #       ASKEP, ASP1, ASPUP, ASPDN, ASP3, ASP3+1

# P37 PAD LOADS                         (1)
P37RANGE        EQUALS  R61CNTR +1      # I(1)PL        *****

END-E6          =       P37RANGE +1     # FIRST UNUSED ERASABLE LOCATION IN E6
```

Defines:
60GENRET, used in chunks 1200 and 1256.
ASPS(TM), used in chunk 1256.
END-E6, never used.
P37RANGE, used in chunk 1301.
Q7, used in chunks 42, 474, 1200, 1248, 1252, and 1256.
R61CNTR, used in chunks 915, 918, 934, 936, 955, and 969.
S61DT, used in chunks 370 and 1200.
TEMPALFA, used in chunk 1299.
TEMPBETA, used in chunk 1299.
TEMPROLL, used in chunk 1299.
XOLDBUF, used in chunk 1227.
XPIPBUF, used in chunks 1227 and 1250.
YOLDBUF, used in chunk 1227.
YPIPBUF, used in chunks 1227 and 1250.
ZOLDBUF, used in chunk 1227.
ZPIPBUF, used in chunks 1227 and 1250.

Uses ADOT 209, ASKEP 229, ASP1 229, ASP3 229, ASPS 229, ASPUP 229, GENRET 221, I 206, REENTRY 65, RESTART 57, SAVEDCDU 221, THETADZ 211, TM 219, and WBODY 209.

224 ⟨*Page CM0117* 224⟩≡ (75 2684)

```
# EBANK-7 ASSIGNMENTS

                SETLOC  3400

# *-*-*-*- OVERLAY NUMBER 0 IN EBANK 7 -*-*-*-*

# EXTERNAL DELTA-V UPDATE.              (21D)
# (MUST BE IN ORDER FOR UPDATE PROGRAM.  ALSO ENTRY PROGRAM PICK UP 'LAT(SPL' WITH A

LAT(SPL)        ERASE   +20D            # I(2)DSP NOUN 61 FOR P62,63,64,67
LNG(SPL)        EQUALS  LAT(SPL) +2     # I(2)DSP NOUN 61 FOR P62,63,64,67

DELVSLV         EQUALS  LNG(SPL) +2     # I(6)TMP DELTA VEL VECT, LOC VER COORDS
TIG             EQUALS  DELVSLV +6      # B(2)DSP NOUN 33 FOR X-V84(R32),P30,40.
RTARG           EQUALS  TIG     +2      # I(6)IN DESIRED VEHICLE RADIUS VECTOR
DELLT4          EQUALS  RTARG   +6      # I(2)IN TIME DIFFERENCE FOR INITVEL
ECSTEER         EQUALS  DELLT4  +2      # I(1)PL FOR P40'S
DELVLVC         =       DELVSLV
END-DELV        ERASE                   # *NEXT AVAIL LOC AFTER UNSHARED E7*

# SERVICER STORAGE.                     (13D)
DVTOTAL         EQUALS  END-DELV        # B(2)DSP NOUN 40,99 FOR P30,34,35,40
TGO             EQUALS  DVTOTAL +2      # B(2)
DVCNTR          EQUALS  TGO     +2      # B(1)TMP
DELVREF         EQUALS  DVCNTR  +1      # I(6)TMP

NOMTIG          EQUALS  END-KALC        # I(2) (CANNOT SHARE WITH KALCMANU
                                        #       OR DELVREF)
END-SVCR        EQUALS  NOMTIG  +2      # ***NEXT AVAILABLE AFTER SERVICER

# ALIGNMENT STORAGE.                    (25D)
XSCD            EQUALS  END-SVCR        # I(6)TMP
YSCD            EQUALS  XSCD    +6      # I(6)TMP
ZSCD            EQUALS  YSCD    +6      # I(6)TMP
VEL/C           EQUALS  ZSCD    +6      # I(6)TMP
R53EXIT         EQUALS  VEL/C   +6      # I(1)TMP

# ALIGNMENT MARKDATA (DOWNLINK) ******* (7D)
MARK2DWN        EQUALS  R53EXIT +1      #  (7) USED BY ALIGNMENT P50'S
```

Defines:
DELLT4, used in chunks 295, 300, 771, 784, 788, 792, 901, 1052, 1053, 1094, 2254, and 2256.
DELVLVC, used in chunks 44, 476, 754, 761, 772, 773, 777, 794, 795, 852, 1052, 1053, 1063, 1094, 1301, 2223, 2258, and 2764.
DELVREF, used in chunks 1094, 1227, 1256, and 2382.
DELVSLV, used in chunks 300, 1049, 1051, and 2219.

DVCNTR, used in chunks 73, 374, 376, 864, 1200, 1227, 2273, 2275, 2277, 2279, 2281, 2294, 2299, 2311, 2343, 2353, 2359, and 2382.
DVTOTAL, used in chunks 40, 44, 470, 476, 1094, 1227, 2263, and 2382.
ECSTEER, used in chunks 300, 1062a, 1094, and 1301.
END-DELV, used in chunk 232.
END-SVCR, used in chunk 226.
LAT(SPL), used in chunks 42, 300, 302, 472, 722, 1054, 1200, 1256, and 1301.
LNG(SPL), used in chunks 42, 300, 302, 472, 1200, and 1301.
MARK2DWN, used in chunks 298 and 1147.
NOMTIG, used in chunk 1094.
R53EXIT, used in chunks 1147 and 2766.
RTARG, used in chunks 234, 295, 300, 754, 761, 771, 773, 784, 786, 788, 793, 901, 1045, 1052, 1094, 1301, and 2254.
TGO, used in chunks 295, 366, 1094, 2273, 2291, 2343, 2353, 2363, 2365, 2367, 2375, and 2377.
TIG, used in chunks 30, 32, 38, 54, 123, 241, 243, 295, 298, 300, 357, 368, 370, 372, 374, 376, 377, 454, 456, 752, 754, 756, 759, 761, 762, 773, 820, 822, 842, 844, 846, 848, 852, 854, 1043, 1045, 1049, 1052, 1053, 1063, 1094, 1227, 1301, 1810, 2091, 2219, 2223, 2254, 2256, 2260, 2263, 2265, 2267, 2269, 2271, 2273, 2275, 2283, 2285, 2287, 2289, 2299, 2343, and 2353.
VEL/C, used in chunk 1147.
XSCD, never used.
YSCD, never used.
ZSCD, never used.

Uses A 80, DELV 159, EBANK 80, END-KALC 232, I 206, LAT 157, LOC 145, MARKDATA 161, V 229, and VEL 226.

226 ⟨*Page CM0118* 226⟩≡ (75 2684)

```
# *-*-*-*- OVERLAY NUMBER 1 IN EBANK 7 -*-*-*-*

# REENTRY ERASABLES.                    (206D)
RTINIT          EQUALS  END-SVCR        # 6P
RTEAST          EQUALS  RTINIT  +6      # 6P
RTNORM          EQUALS  RTEAST  +6      # 6P
RT              EQUALS  RTNORM  +6      # 6P
UNI             EQUALS  RT      +6      # 6P
UNITV           EQUALS  UNI     +6      # 6P
VEL             EQUALS  UNITV   +6      # 6P

TIME/RTO        EQUALS  VEL     +6      # 2P TIME OF INITIAL TARGET, RTO.
-VREL           EQUALS  TIME/RTO +2     # 6P
OLDUYA          EQUALS  -VREL   +6      # 6P USED BY CM/POSE    (ENTRY DAP)
UXA/2           EQUALS  OLDUYA  +6      # 6P USED BY CM/POSE    (ENTRY DAP) -UVA
URH             =       UXA/2           #       P67 DISPLAY NOUN
UYA/2           EQUALS  UXA/2   +6      # 6P USED BY CM/POSE    (ENTRY DAP) UYA
UZA/2           EQUALS  UYA/2   +6      # 6P USED BY CM/POSE    (ENTRY DAP) UNA
UBX/2           EQUALS  UZA/2   +6      # 6P USED BY CM/POSE    (ENTRY DAP)
UBY/2           EQUALS  UBX/2   +6      # 6P USED BY CM/POSE    (ENTRY DAP)
UBZ/2           EQUALS  UBY/2   +6      # 6P USED BY CM/POSE    (ENTRY DAP)

DTEAROT         EQUALS  UBZ/2   +6      # 2P
DIFF            EQUALS  DTEAROT +2      # 2P
DIFFOLD         EQUALS  DIFF    +2      # 2P
FACTOR          EQUALS  DIFFOLD +2      # 2P
FACT1           EQUALS  FACTOR  +2      # 2P
FACT2           EQUALS  FACT1   +2      # 2P
#Q7             =       THETAD2         # 2P SHARED FOR TM.  P64-P66
VSQUARE         EQUALS  FACT2   +2      # 2P
LAD             EQUALS  VSQUARE +2      # 2P
LOD             EQUALS  LAD     +2      # 2P
L/DCMINR        EQUALS  LOD     +2      # 2P
KLAT            EQUALS  L/DCMINR +2     # 2P
L/D             EQUALS  KLAT    +2      # 2P
L/D1            EQUALS  L/D     +2      # 2P
LEWD            =       VIO             # 2P SHARED FOR TM.  P64-P65
D               EQUALS  L/D1    +2      # 2P DSP NOUN 64,66,68 FOR P63,64,67
#V1             =       ENDBUF  +1      # 2P SHARED FOR TM. P64-P65
DLEWD           EQUALS  D       +2      # 2P
K2ROLL          EQUALS  DLEWD   +2      # 2P
GOTOADDR        EQUALS  K2ROLL  +2      # 1P
TEM1B           EQUALS  GOTOADDR +1     # 2P
MM              EQUALS  TEM1B   +2      # 2P
GRAD            EQUALS  MM      +1      # 2P
```

```
FX              EQUALS  GRAD    +1      # 1P OVERWRITES NEXT 5 LOCS IN P67
LEQ             EQUALS  FX      +1      # 2P
DHOOK           EQUALS  LEQ     +2      # 2P
AHOOKDV         EQUALS  DHOOK   +2      # 2P
```

Defines:

-VREL, used in chunks 1250, 1255a, 1256, and 1291.
AHOOKDV, used in chunks 229, 1245, and 1256.
D, used in chunks 20, 38, 40, 42, 44–46, 198, 229, 331, 335, 474, 670, 752, 790, 820, 839, 842, 925, 965, 973, 979, 981, 983, 985, 989, 1054, 1063, 1094, 1200, 1227, 1245, 1247, 1248, 1250, 1252, 1254, 1256, 1362, 1412, 1456, 1457, 1463, 1465, 1491, 1492, 1497, 1502, 1519, 1526, 1536, 1605, 1684, 1780, 1852, 1872, 1894, 2001, 2044, 2057b, 2059, 2164, 2177, 2223, 2311, 2343, 2365, 2367, 2369, 2382, 2463, 2472, 2478, 2514, 2519, 2542, 2561, 2574, 2596, 2603, 2605, 2606, and 2633.
DHOOK, used in chunks 1245 and 1256.
DIFF, used in chunks 967, 1147, 1245, 1256, 1396, 1944a, and 2574.
DIFFOLD, used in chunks 1245 and 1256.
DLEWD, used in chunks 1245 and 1256.
DTEAROT, used in chunks 489, 491, 1200, 1250, and 1256.
FACT1, used in chunks 1247 and 1256.
FACT2, used in chunks 1247 and 1256.
FACTOR, used in chunks 140, 167, 221, 514, 545, 557, 797, 961, 963, 1245, 1247, 1250, 1252, 1256, 1301, 1362, 1578a, 1713–26, 1814, 2027, 2035, 2059, 2118, 2299, 2382, 2420, 2455, 2542, and 2574.
FX, used in chunks 1245, 1247, 1248, 1250, and 1256.
GOTOADDR, used in chunks 1200, 1250, and 1256.
GRAD, used in chunks 1250 and 1256.
K2ROLL, used in chunks 1248 and 1256.
KLAT, used in chunks 1248, 1252, and 1256.
L/D, used in chunks 198, 229, 1054, 1200, 1247, 1248, 1250, 1252, 1256, 1491, 1492, and 1502.
L/D1, used in chunks 302, 1248, and 1256.
L/DCMINR, used in chunks 1248 and 1256.
LAD, used in chunks 1248 and 1256.
LEQ, used in chunks 1200, 1248, 1256, 1297, and 1852.
LEWD, used in chunks 1245, 1248, 1252, and 1256.
LOD, used in chunks 198, 1248, and 1256.
MM, used in chunks 42, 50, 335, 337, 339, 345, 355, 357, 384, 398, 407, 419, 420, 446, 535, 607, 609, 629, 694, 698, 712, 731, 733, 737, 864, 1147, 1200, 1227, 1250, 1256, 1844, 1949, 1993, 1997, and 2189.
OLDUYA, used in chunks 1255a and 1291.
RT, used in chunks 182, 489, 491, 987, 1054, 1200, 1245, 1250, 1256, 1301, and 1852.
RTEAST, used in chunks 489, 491, 1245, and 1256.
RTINIT, used in chunks 372, 489, 491, 1200, 1245, 1250, 1256, and 1291.
RTNORM, used in chunks 489, 491, 1245, and 1256.
TEM1B, used in chunks 1250 and 1256.
TIME/RTO, used in chunks 1250 and 1256.
UBX/2, used in chunks 1255a, 1293, and 1295.
UBY/2, used in chunks 1255a, 1293, and 1295.
UBZ/2, used in chunks 1255a and 1295.
UNI, used in chunks 1200, 1245, and 1256.
UNITV, used in chunks 1063, 1250, 1256, and 2223.
URH, used in chunk 1200.
UXA/2, used in chunks 1200, 1255a, 1256, 1291, and 1295.
UYA/2, used in chunks 1200, 1255a, 1291, and 1295.
UZA/2, used in chunks 1200, 1255a, 1291, 1295, and 1296.
VEL, used in chunks 35, 169, 172, 177, 197, 224, 234, 236, 241, 244, 458, 464, 474, 485, 749,

770b, 771, 814, 858, 949, 965, 1147, 1245, 1248, 1252, 1256, 2047, 2064b, 2103, 2143, 2212, 2353, 2382, and 2438.

`VSQUARE`, used in chunks 1248 and 1256.

Uses `EBANK` 80, `END-SVCR` 224, `ENDBUF` 145, `L` 80, `REENTRY` 65, `TM` 219, and `VIO` 229.

229 ⟨*Page CM0119* 229⟩≡ (75 2684)

```
DVL             EQUALS  AHOOKDV +2      # 2P
#A0             =       ENDBUF  +3      # 2P SHARED FOR TM. (HI-WD) P84-P85
A1              EQUALS  DVL     +2      # 2P
VBARS           EQUALS  A1      +2      # 2P
COSG/2          EQUALS  VBARS   +2      # 2P
#GAMMAL         =       GAMMAEI         # 2P SHARED FOR TM.  P64
GAMMAL1         =       22D             # 2P
VS1             EQUALS  COSG/2  +2      # 2P
VL              =       VPRED           # 2P SHARED FOR TM.  P64-P65
V               EQUALS  VS1     +2      # 2P
#VREF           =       THETAD  +2      # 2P SHARED FOR TM.  P65
LATANG          EQUALS  V       +2      # 2P ADJACENT FOR TM.
RDOT            EQUALS  LATANG  +2      # 2P ADJACENT FOR TM.
THETAH          EQUALS  RDOT    +2      # 2P DSP NOUN 64,67 FOR P63,64,67
#RDOTREF        =       THETAD          # 2P SHARED FOR TM.  P65
ALP             EQUALS  THETAH  +2      # 2P

ASKEP           =       ASPS            # 2P)                THESE ARE STORED IN
ASP1            =       ASPS    +1      # 2P)                SEQUENCE, OVERLAPPING
ASPUP           =       ASPS    +2      # 2P)>HI-WD OF EACH< HI-WORD ONLY APPEARING
ASPDWN          =       ASPS    +3      # 2P)                ON DOWNLIST, EXCEPT
ASP3            =       ASPS    +4      # 2P)                ASP3 IS COMPLETE.

C/D0            EQUALS  ALP     +2      # 2P    -1/D0
D0              EQUALS  C/D0    +2      # I(2)  CONSTANT DRAG
Q2              EQUALS  D0      +2      # 2P

# ROLLC IS LOCATED IN EBANK= AOG TO AID ENTRY DAP.
RTGO            EQUALS  Q2      +2      # 2P DSP NOUN 66 FOR P64,P67
DNRNGERR        EQUALS  RTGO    +2      # 2P DSP NOUN 66 FOR P64,67
XRNGERR         =       LATANG          #       FOR DISKY DISPLAY
KAT             EQUALS  DNRNGERR +2     # 2P
GMAX            EQUALS  KAT     +2      # 1P DSP NOUN 60 FOR P61,62,63
                                        # GMAX IS LOADED IN DOUBLE PRECISION.
L/DCALC         =       TTE             # 2P CALCULATED L/D FOR TM: P64-P67.
GAMMAL          =       GAMMAEI         # 2P SHARED FOR TM.  P64.
PREDANG         =       GAMMAEI         #       FOR TM IN P67.
JJ              =       PREDANG +1      #       FOR TM IN P67.
VMAGI           EQUALS  GMAX    +1      # 2P DSP NOUN 62,64,66 FOR P11,63,64.
VIO             EQUALS  VMAGI   +2      # 2P DSP NOUN 63 FOR P61.
TTE             EQUALS  VIO     +2      # 2P DSP NOUN 63 FOR P61.
ASPS            EQUALS  TTE     +2      # I(2) HI-WORD ONLY ON DNLIST FOR TEMP
TTE1            EQUALS  ASPS    +2      # I(2)TMP HOLDS UNDECREMENTED TTE VALUE

# **** P60'S ****
```

```
RTGON64          EQUALS  RTGO            # RANGE ERRORS NEGATIVE IF FALLS SHORT
```

Defines:
A1, used in chunks 1147, 1245, 1256, 1506, 1508, 1512, and 1522.
ALP, used in chunks 1245, 1252, and 1256.
ASKEP, used in chunks 223, 1245, and 1256.
ASP1, used in chunks 223, 1245, and 1256.
ASP3, used in chunks 223, 1245, and 1256.
ASPDWN, used in chunks 1245 and 1256.
ASPS, used in chunks 223 and 1256.
ASPUP, used in chunks 223, 1245, and 1256.
C/DO, used in chunks 1245 and 1256.
COSG/2, used in chunks 1245 and 1256.
DO, used in chunks 1245, 1252, 1256, and 2363.
DNRNGERR, used in chunks 42, 474, 1200, 1254, and 1256.
DVL, used in chunks 1245 and 1256.
GAMMAL, used in chunks 1245, 1247, 1252, and 1256.
GAMMAL1, used in chunks 1247, 1252, and 1256.
GMAX, used in chunks 33, 42, 458, 472, 1200, 1252, and 1256.
JJ, used in chunks 40, 44, 50, 1250, and 1256.
KAT, used in chunks 1248 and 1256.
L/DCALC, used in chunk 1256.
LATANG, used in chunks 302, 1248, 1254, and 1256.
PREDANG, used in chunks 1248, 1254, and 1256.
Q2, used in chunks 1248, 1252, 1256, and 1852.
RDOT, used in chunks 35, 42, 302, 458, 474, 814, 816, 818, 1200, 1245, 1248, 1250, 1252, 1256, 1504, 1776, 2046, 2353, 2363, 2365, and 2375.
RTGO, used in chunks 35, 42, 231, 458, 474, and 1200.
RTGON64, used in chunks 42 and 474.
THETAH, used in chunks 302, 1200, 1248, 1254, and 1256.
TTE, used in chunks 42, 303, 458, 474, 1200, and 1254.
TTE1, used in chunks 231 and 1200.
V, used in chunks 28, 33, 37, 52, 121, 154, 161, 172, 179, 224, 236, 241, 297, 331, 390, 405, 418, 420, 438, 442, 456, 458, 460, 485, 486, 508, 510, 512, 527, 635, 637, 638, 640, 642, 678, 710, 749, 752–54, 760–62, 773, 777, 795, 802, 804, 806, 820, 822, 827, 829, 833, 842, 844, 850, 854, 858, 868, 882, 909, 919, 930, 941, 963, 965, 969, 971, 983, 991, 993, 1011, 1013, 1045, 1049, 1054, 1056, 1058, 1060, 1063, 1094, 1147, 1200, 1245, 1248, 1250, 1252, 1256, 1291, 1301, 1344, 1486, 1504, 1508, 1510, 1512, 1552, 1554, 1578b, 1580, 1586, 1606–8, 1727, 1814, 1852, 1872, 1874, 1961, 2086, 2087, 2132, 2141, 2143, 2148, 2160, 2162, 2185, 2213, 2219, 2223, 2265, 2299, 2311, 2343, 2353, 2361, 2377, 2382, 2426, 2428, 2478, 2480, 2500, 2519, 2542, 2561, 2588, 2594, 2605, 2609, 2615, 2617, 2619, and 2623–25.
VBARS, used in chunks 1248 and 1256.
VIO, used in chunks 35, 42, 226, 303, 458, 474, 1200, and 1254.
VL, used in chunks 35, 42, 458, 474, 961, 969, 1200, 1245, 1247, 1248, 1252, 1254, and 1256.
VMAGI, used in chunks 42, 474, 872, 884, 1254, and 1299.
VS1, used in chunks 1245, 1248, and 1256.
XRNGERR, used in chunks 42, 474, 1200, 1254, and 1256.

Uses AHOOKDV 226, AOG 214, D 226, EBANK 80, ENDBUF 145, GAMMAEI 231, I 206, L 80, L/D 226, RANGE 179, ROLLC 214, TEMP 191, THETAD 157, TM 219, and VPRED 231.

231 ⟨*Page CM0120* 231⟩≡ (75 2684)

```
RTGON67         EQUALS  RTGO            # DSP NOUN 67

# REENTRY, RETURN TO EARTH COMMON DISPLAY       (4D)
VPRED           EQUALS  BETA12  +2      # DSP NOUN 60 FOR P61,62,63
GAMMAEI         EQUALS  VPRED   +2      # DSP NOUN 60 FOR P61,62,63

# DISPLAY REGISTER FOR VG               (2D)
VGDISP          EQUALS  GAMMAEI +2      # B(2)DSP N.40,42,99 FOR P30,34,35,37,40,
                                        #           41 VG DISPLAY

# SOME P11 DISPLAY REGISTERS            (6D)
ALTI            EQUALS  TTE1    +2      # 2P DSP NOUN 62 FOR P11.
HDOT            EQUALS  ALTI    +2      # 2P DSP NOUN 62 FOR P11.
```

Defines:
ALTI, used in chunks 42, 474, 862, 872, and 884.
GAMMAEI, used in chunks 42, 229, 300, 302, 472, 1200, 1254, and 1301.
HDOT, used in chunks 35, 42, 458, 474, 858, 862, 872, 884, 1094, 1254, and 2382.
RTGON67, used in chunks 42, 474, and 1256.
VGDISP, used in chunks 40, 44, 470, 476, 1045, 1049, 1051–53, 1094, 1301, 2256, 2258, and 2684.
VPRED, used in chunks 35, 42, 229, 300, 303, 458, 472, 1200, 1254, and 1301.
Uses BETA12 241, N 206, REENTRY 65, RTGO 229, TTE1 229, and VG 234.

232 ⟨*Page CM0121* 232⟩≡ (75 2684)

```
# *-*-*-*- OVERLAY NUMBER 2 IN EBANK 7 -*-*-*-*

# KALCMANU STORAGE.                              (18D)
MFS             EQUALS  END-DELV        # I(18)
MFI             EQUALS  MFS             # I    TMP
DEL             EQUALS  MFS             # I    TMP
END-KALC        EQUALS  MFS     +18D    # **NEXT AVAIL LOC AFTER KALCMANU**

# MEASUREMENT INCORPORATION STORAGE (R22) STORAGE.      (56D)

TX789           EQUALS  END-KALC        # I(6)TMP
GAMMA           EQUALS  TX789   +6      # I(3)TMP
OMEGA           EQUALS  GAMMA   +2      # I(18)TMP
BVECTOR         EQUALS  OMEGA   +18D    # I(18)TMP
DELTAQ          EQUALS  BVECTOR +18D    # I(2)TMP
VARIANCE        EQUALS  DELTAQ  +2      # I(3)TMP
RCLP            EQUALS  VARIANCE +3     # I(6)TMP
GRP2SVQ         EQUALS  RCLP    +6      # I(1)TMP QSAVE FOR RESTARTS

# P20, P22, P23 DSP NOUN                (5D)
N49DISP         EQUALS  BVECTOR         # B(5)TMP

# S22.1 STORAGE.                        (36D)
SVMRKDAT        EQUALS  GRP2SVQ +1      # I(36)TMP 5 SETS OF MARK DATA +PAD OF ONE

# **** CISLUNAR NAV.  ERAS.  (P20'S) ****       (45D)
TRUNX           EQUALS  SVMRKDAT +36D
DATATEST        EQUALS  TRUNX           #  (1)
UBAR0           EQUALS  TRUNX   +1
UBAR1           EQUALS  UBAR0   +6
UBAR2           EQUALS  UBAR1   +6
RZC             EQUALS  UBAR2   +6
VZC             EQUALS  RZC     +6
UCLSTAR         EQUALS  VZC     +6
USSTAR          EQUALS  UCLSTAR +6
SRRETURN        EQUALS  USSTAR  +6
```

Defines:
BVECTOR, used in chunks 937, 945, 949, 951, 977, 991, 1009, 1025, 1693, and 1695.
DATATEST, used in chunk 249.
DEL, used in chunks 651, 653, 655, 674, 676, 678, 682, 684, 773, 1256, 1297, 1396, 1852, 2154, 2162, 2164, 2181, 2183, and 2574.
DELTAQ, used in chunks 937, 949, 991, 1027, 1693, 1697, and 1698.
END-KALC, used in chunks 224 and 234.
GAMMA, used in chunks 35, 458, 1054, 1063, 1200, 1245, 1252, 1254, 1256, 1675, 1677, 1679, 1681, 1693, 1697, 1699, 1743, and 2223.

GRP2SVQ, used in chunks 234 and 1813a.
MFI, used in chunks 653, 660, 662, 664, 2154, 2167, 2169, and 2171.
MFS, used in chunks 653, 655, 660, 2154, and 2167.
N49DISP, used in chunks 40, 472, 947, 949, 953, 993, and 1027.
OMEGA, used in chunks 905, 963, 969, 971, 1693, 1697–99, 2452, 2519, and 2574.
RCLP, used in chunks 937, 945, 949, 977, 991, and 993.
RZC, used in chunks 1024, 1029, and 1035.
SRRETURN, used in chunks 1029 and 1033.
SVMRKDAT, used in chunks 304, 977, and 979.
TRUNX, used in chunk 244.
TX789, used in chunks 1705 and 1707.
UBAR0, used in chunks 1029 and 1033.
UBAR1, used in chunk 1029.
UBAR2, used in chunk 1029.
UCLSTAR, used in chunk 1025.
USSTAR, used in chunk 1025.
VARIANCE, used in chunks 166, 182, 945, 947, 951, 953, 977, 991, 1027, 1663, 1693, and 1695.
VZC, used in chunks 1025 and 1035.

Uses DELV 159, EBANK 80, END-DELV 224, I 206, and LOC 145.

234 ⟨*Page CM0122* 234⟩≡ (75 2684)

```
# *-*-*-*- OVERLAY NUMBER 3 IN EBANK 7 -*-*-*-*

# RENDEZVOUS GUIDANCE STORAGE. -- P32 ... P35 --        (8D)
DELTEEO         EQUALS  END-KALC        # I(2) S-S BACK VALUES OF DELTA TIME
DELEL           EQUALS  DELTEEO +2      # I(2) S-S
SECMAX          EQUALS  DELEL   +2      # I(2) S-S MAX STOP SIZE FOR ROUTINE
XXXALT          EQUALS  SECMAX  +2      # I(2)

# S40.9 STORAGE                         (16D)
VG              EQUALS  XXXALT  +2      # I(6)TMP
VRPREV          EQUALS  VG      +6      # I(6)
TNIT            EQUALS  VRPREV  +6      # I(2)
TNITPREV        EQUALS  TNIT    +2      # I(2)

# S40.2,3 STORAGE.                      (1D)
AXISCODE        EQUALS  TNITPREV +2     # I(1)IN

# P30'S-P17 COMMON STORAGE.             (24D)
RACT3           EQUALS  GRP2SVQ +1      # I(6)TMP POSITION OF ACTIVE AT TPI TIME.
VACT3           EQUALS  RACT3   +6      # I(6)TMP VELOCITY OF ACTIVE AT TPI TIME.
RPASS3          EQUALS  VACT3   +6      # I(6)TMP POSITION OF PASSIVE AT TPI TIME.
VPASS3          EQUALS  RPASS3  +6      # I(6)TMP VELOCITY OF PASSIVE AT TPI TIME.

# P76, N84 DISPLAY                      (6D)
DELVOV          EQUALS  RACT3           # I(6)DSP NOUN 84 FOR X-V84, P34-35

# INITVEL/MIDGIM STORAGE.               (34D)
#       (CALLED BY S34.1,2, S35.1,2, AND S40.9)
#       (CALLS LAMBERT, CONIC SUBROUTINES)
RINIT           EQUALS  VPASS3  +6      # I(6)IN ACTIVE VEHICLE RADIUS VECTOR
VINIT           EQUALS  RINIT   +6      # I(6)IN ACTIVE VEHICLE VELOCITY VECTOR
RTARG1          EQUALS  VINIT   +6      # I(6)TMP SHIFTED RTARG
VIPRIME         EQUALS  RTARG1  +6      # I(6)OUT NEW VEL REQ AT INITIAL RADIUS
VTPRIME         EQUALS  VIPRIME +6      # I(6)OUT TOTAL VELOCITY AT DESIRED RADIUS
+MGA            EQUALS  VTPRIME +6      # I(2)DSP NOUN 45 FOR P30,34,35.  +MID GIM.
COZY4           EQUALS  +MGA    +2      # I(2)TMP COSINE OF ANGLE WHEN ROT STARTS

# THE FOLLOWING OVERLAYS MEASUREMENT INCORP AND CANNOT SHARE WITH TPI
```

Defines:
`+MGA`, used in chunks 40, 357, 472, 754, 761, 779, 794, 795, 842, 850, 852, 919, 1043, 1045, 1048, 1063, 1301, 2219, 2223, and 2258.
`AXISCODE`, used in chunk 236.
`COZY4`, used in chunks 236, 786, 788, and 792.
`DELEL`, used in chunks 763, 767, and 769.
`DELTEEO`, used in chunk 769.
`DELVOV`, used in chunks 44, 476, and 822.

RACT3, used in chunks 759, 763, 765, 769–73, 775, 800a, 850, 893, 895, 897, 901, 903, 905, 1051, 1063, and 2223.
RINIT, used in chunks 236, 772, 784, 786, 788, 790, 794, 795, 901, 1094, 2219, 2254, and 2256.
RPASS3, used in chunks 758, 763, 765, 769–71, 800a, 854, 895, 897, 1063, and 2223.
RTARG1, used in chunks 786, 788, 792, and 793.
SECMAX, used in chunks 763 and 767.
TNIT, used in chunk 1094.
TNITPREV, used in chunk 1094.
VACT3, used in chunks 244, 763, 765, 769, 770b, 772, 773, 800a, 901, 1063, and 2223.
VG, used in chunks 33, 37, 54, 103, 231, 238, 244, 456, 460, 754, 761, 1063, 1094, 2079, 2223, 2256, 2311, and 2363.
VINIT, used in chunks 236, 772, 784, 786, 788, 792, 794, 795, 901, 1094, 2219, and 2256.
VIPRIME, used in chunks 236, 759, 786, 790, 792, 793, 850, 901, 907, 1052, 1094, and 2258.
VPASS3, used in chunks 758, 763, 765, 769, 771, 800a, 854, 895, 897, 1063, and 2223.
VRPREV, used in chunk 1094.
VTPRIME, used in chunks 236, 759, 786, 792, 793, 850, 901, and 905.
XXXALT, used in chunks 797 and 798.

Uses EBANK 80, END-KALC 232, GRP2SVQ 232, I 206, RTARG 224, and VEL 226.

236 ⟨*Page CM0123* 236⟩≡ (75 2684)

```
INTIME          EQUALS  AXISCODE +3
ITCTR           EQUALS  INTIME  +2      # I(1)TMP ITERATION COUNTER
END-IN/M        EQUALS  COZY4   +2      # ** NEXT AVAIL LOC AFTER INITVEL/MIDGIM **

# P34 AND P33 STORAGE.  (OVERLAYS INITVEL/MIDGIM)       (24D)
VAPREC          EQUALS  RINIT           # I(6) S-S PREC VEC FOR NOM TPI TIME (ACT V)
RAPREC          EQUALS  VINIT           # I(6) S-S PREC VEC FOR NOM TPI TIME (ACT V)
VPPREC          EQUALS  VIPRIME         # I(6) S-S PREC VEC FOR NOM TPI TIME (PASS)
RPPREC          EQUALS  VTPRIME         # I(6) S-S PREC VEC FOR NOM TPI TIME (PASS)

# P30, P40 INTERFACE.                   (20D)
RTIG            EQUALS  END-IN/M        # I(6)TMP
VTIG            EQUALS  RTIG    +6      # I(6)TMP
DELVSIN         EQUALS  VTIG    +6      # I(6)TMP
DELVEET3        EQUALS  DELVSIN         #     TMP DELTA VEL VECT INERTIAL COORDS.
VGTEMP          EQUALS  DELVEET3
DELVSAB         EQUALS  DELVSIN +6      # I(2)TMP

# P35-P40 INTERFACE STORAGE.  (OVERLAYS P30-P40 I/F STORAGE)    (12D)
RPASS4          EQUALS  RTIG            # I(6)TMP POSITION OF PASSIVE AT INTERCEPT
VPASS4          EQUALS  RPASS4  +6      # I(6)TMP VELOCITY OF PASSIVE AT INTERCEPT

# TPI SEARCH (P17)                      (6D)
E2              EQUALS  VPASS4  +6      # I(6)TMP

# P30-P40 COMMON STORAGE.               (3D)
TPASS4          EQUALS  DELVSAB +2      # I(2)TMP
TINT            =       TPASS4          # I(2)
QTEMP           EQUALS  TPASS4  +2      # I(1)TMP

# P30-P40 STORAGE.                      (4D)
TTOGO           EQUALS  QTEMP   +1      # B(2)DSP NOUN 35,40,45,59,99
                                        #         FOR P30,34,35,40,41,47, R30.
TTPI            EQUALS  TTOGO   +2      # B(2)DSP NOUN 37 FOR P34 TPI TIME, CSECS.
```

Defines:

DELVEET3, used in chunks 300, 754, 759, 761, 772, 773, 777, 786, 792, 793, 850, 901, 1053, 1094, and 2258.
DELVSAB, used in chunks 1063, 1094, 2219, and 2223.
DELVSIN, used in chunks 777, 779, 850, 1045, 1048, 1049, 1051, 1063, 1094, 1301, 2219, 2223, and 2258.
E2, used in chunks 895, 897, 987, 1200, 1256, 1800, 1882, 2118, and 2488.
END-IN/M, used in chunk 241.
INTIME, used in chunks 759, 762, 771, 784, 792, 848, and 901.
ITCTR, used in chunks 786, 788, and 792.
QTEMP, used in chunks 897, 907, 1049, 1051–53, 1094, 1200, and 2219.
RAPREC, used in chunks 763 and 769.
RPASS4, used in chunks 901, 905, and 907.

RPPREC, used in chunks 763 and 769.
RTIG, used in chunks 1045, 1049, 1051, 1052, 1063, 1094, 2219, 2223, 2256, and 2258.
TINT, used in chunks 185, 842, 846, and 848.
TPASS4, used in chunks 244, 300, 754, 759, 761, 771, 773, 852, 1045, 1052, 1053, 1094, 1301, and 2256.
TTOGO, used in chunks 38, 40, 44, 376, 456, 470, 472, 476, 754, 761, 779, 842, 850, 852, 1043, 1063, 1094, 1301, 2219, 2223, 2258, 2265, 2267, 2271, 2285, 2287, 2289, 2363, and 2375.
TTPI, used in chunks 238, 300, 456, 754, 756, 758, 759, 769, 895, 899, 901, 909, 911, 1063, and 2223.
VAPREC, used in chunks 763 and 769.
VGTEMP, used in chunk 1094.
VPASS4, used in chunks 759, 771, 850, 901, and 907.
VPPREC, used in chunks 763 and 769.
VTIG, used in chunks 1045, 1049, 1051, 1063, 1094, 2219, 2223, and 2256.

Uses AXISCODE 234, COZY4 234, F 238, I 206, LOC 145, RINIT 234, V 229, VEL 226, VINIT 234, VIPRIME 234, and VTPRIME 234.

238 ⟨*Page CM0124* 238⟩≡ (75 2684)

```
END-P30S        EQUALS  TTPI    +2      # ** NEXT AVAIL LOC AFTER P30-40 STORAGE. **

# P40 STORAGE.                          (8D)
VGBODY          EQUALS  END-P30S        # B(6)DSP NOUN 85 FOR P40,41,42 VG-SC COOR
DELVCTL         =       VGBODY
P40TMP          EQUALS  VGBODY  +6      # B(2)TMP

# P47 STORAGE.
DV47TEMP        EQUALS  VG
DELVIMU         EQUALS  P40TMP  +2      # I(6)DSP NOUN 83 FOR P47 DELTAV(IMU).

# S40.1 STORAGE.                        (23D)
CSTEER          EQUALS  DELVIMU +6      # I(2)IN
BDT             EQUALS  CSTEER  +2      # I(6)IN
UT              EQUALS  BDT     +6      # I(6)OUT THRUST DIRECTION
VGTIG           EQUALS  UT      +6      # I(6)OUT
VGPREV          =       VGTIG
F               EQUALS  VGTIG   +6      # I(2)OUT S40.3 NEEDS THIS

QTEMP1          EQUALS  F       +2      # I(1)TMP HOLDS RETURN

# R41                                   (2D)
T-TO-ADD        EQUALS  QTEMP1  +1      # I(1D) FOR MIDTOAVE
```

Defines:
BDT, used in chunk 1094.
CSTEER, used in chunks 295 and 1094.
DELVCTL, used in chunk 1094.
DELVIMU, used in chunks 44, 368, 476, and 1094.
DV47TEMP, used in chunk 1094.
END-P30S, used in chunk 239.
F, used in chunks 46, 221, 236, 544, 545, 596, 621, 637, 989, 1063, 1094, 1200, 1227, 1248, 1549, 1663, 1684, 1814, 1911, 1913, 2223, 2459, 2519, 2590, 2592, 2600, 2603, and 2606.
P40TMP, used in chunks 73, 357, 370, 372, and 1094.
QTEMP1, used in chunk 1094.
T-TO-ADD, used in chunks 1806, 1808, and 1810.
UT, used in chunk 1094.
VGBODY, used in chunks 44, 294, 476, 1094, 2343, and 2363.
VGPREV, used in chunk 1094.
VGTIG, used in chunks 295, 298, and 1094.
Uses I 206, LOC 145, P30S 69, THRUST 85, TTPI 236, and VG 234.

239 ⟨*Page CM0125* 239⟩≡ (75 2684)

```
# *-*-*-*- OVERLAY NUMBER 4 IN EBANK 7 -*-*-*-*

# S35.1 STORAGE.                          (2D)
TSTRT           EQUALS  END-P30S        # I(2)IN MIDCOURSE START TIME

# S34.1 STORAGE.  (OVERLAYS S35.1 STORAGE)      (1)
TITER           EQUALS  TSTRT           # I(1)TMP ITERATION COUNTER

# (P30-31 Q-SAVES)                        (1)
P30/31RT        EQUALS  TITER           # B(1) RETURN POINT

# P22 STORAGE.                            (6D)
S22WUNL         EQUALS  TSTRT   +2      # 1     WUNL W8 UNKNOWN INIT VALUE.
S22TOFF         EQUALS  S22WUNL +1      # 2     T SUB OFF
S22TPRIM        EQUALS  S22TOFF +2      # 2     SAVE TF
S22EORM         EQUALS  S22TPRIM +2     # 0 = EARTH -- NON-ZERO = MOON

# DOWNLINK ERASABLES FOR P22, P20 MARK DATA.    (8D)
MARKDOWN        EQUALS  S22EORM +1      # B(1)
RM              EQUALS  S22RTNEX        # DOWNLINK OF VHF RANGE

# S22.1                                   (1D)
S22RTNEX        EQUALS  MARKDOWN +7     # B(1)

# P22 STORAGE                             (6D)
STARSAV3        EQUALS  S22RTNEX +1     # I(6)TMP

# CRS61.1 STORAGE.  --A SUBSET OF P20-- (14D)
Q611            EQUALS  RM      +1      # I(1)TMP QSAVE
Q6111           EQUALS  Q611    +1      # I(1)TMP QSAVE
SAVEPOS         EQUALS  Q6111   +1      # I(6)TMP LEM POSITION VECTOR
```

Defines:
MARKDOWN, used in chunks 73, 298, 300, 392, 939, 1023, and 1147.
P30/31RT, used in chunks 1047 and 1048.
Q611, used in chunks 965, 967, and 973.
Q6111, used in chunks 965, 969, 971, 973, and 975.
RM, used in chunks 300, 957, 959, 1147, 1682, and 2098.
S22EORM, used in chunks 977, 979, 989, 991, 993, and 999.
S22RTNEX, used in chunks 977 and 997.
S22TOFF, used in chunks 923, 925, 977, 989, 995, and 997.
S22TPRIM, used in chunks 977 and 989.
S22WUNL, used in chunk 244.
SAVEPOS, used in chunks 240, 965, 969, and 973.
STARSAV3, used in chunks 476, 1037, and 1147.
TITER, used in chunks 244, 763, 765, and 767.
TSTRT, used in chunk 762.
Uses A 80, EBANK 80, END-P30S 238, I 206, P30S 69, Q 80, RANGE 179, and SAVE 191.

240 ⟨*Page CM0126* 240⟩≡ (75 2684)

```
SAVEVEL         EQUALS  SAVEPOS +6      # I(6)TMP LEM VELOCITY VECTOR

# ATTITUDE MANEUVER -- CALLED BY P20,R61,R63,CRS61.1    (3D)
PRAXIS          EQUALS  SAVEVEL +6      # B(3) S-S DISP RES FOR PREF AXIS N95.

# MARK ROUTINE (R21) STORAGE.  -- IS SUBSET OF R22 --   (14D)
MRKBUF1         EQUALS  PRAXIS  +3      # B(7)TMP R21 MARK BUFFER.
MRKBUF2         EQUALS  MRKBUF1 +7      # B(7)TMP R21 MARK BUFFER.

# MORE CONICS STORAGE.                  (4)
COGA            EQUALS  3774            # I(2) COTAN OF INITIAL FLIGHT PATH ANGLE
INDEP           EQUALS  COGA            # I(1) USED BY SUBROUTINE 'ITERATOR'
EPSILONL        EQUALS  COGA    +2      # I(2)TMP

# RENDEZVOUS GUIDANCE STORAGE.  -- P32...P35 -- (10D)
ELEV            EQUALS  MRKBUF2 +7      # I(2)TMP
RTX1            EQUALS  ELEV    +2      #  (1)
RTX2            EQUALS  RTX1    +1      #  (1)
RTMU            EQUALS  RTX2    +1      #  (2)
RTSR1/MU        EQUALS  RTMU    +2      #  (2)
CENTANG         EQUALS  RTSR1/MU +2     # I(2) S-S CENTRAL ANGLE COVERED (TPI-TFF)

# TPI SEARCH (S17.1, S17.2) P17 STORAGE.(10D)
DELTEE          EQUALS  MRKBUF2 +7      # I(2)
XRS             EQUALS  DELTEE  +2      # I(2)
THETL           EQUALS  XRS     +2      # I(2)
TF              EQUALS  THETL   +2      # I(2)
DELHITE         EQUALS  TF      +2      #  (2)
```

Uses CONICS 61, I 206, SAVEPOS 239, and TFF 179.

def SAVEVEL PRAXIS MRKBUF1 MRKBUF2 COGA INDEP EPSILONL ELEV def RTX1 RTX2 RTMU RTSR1/MU CENTANG DELTEE XRS THETL TF DELHITE

241 ⟨*Page CM0127* 241⟩≡ (75 2684)

```
# *-*-*-*- OVERLAY NUMBER 5 IN EBANK 7 -*-*-*-*

# P17,P34                                (2D)
NN1             =       NN              # I(2)DSP NOUN 55,R1

# ********* THE FOLLOWING ARE FOR FLIGHT 504 ONLY *************

# RETURN-TO-EARTH STORAGE.               (93D)
RTEDVD          EQUALS  END-IN/M        # I(2)IN DELTA VELOCITY DESIRED         M/CS B7
RTEGAM2D        EQUALS  RTEDVD  +2      # I(2)IN REENTRY ANGLE DESIRED          REVS B0
RCON            EQUALS  RTEGAM2D +2     # I(2)TMP CONIC R2 RADIUS               M B29
R(T1)/          EQUALS  RCON    +2      # I(6)TMP POSITION VECTOR AT TIG        M B29/B27
R(T1)           EQUALS  R(T1)/  +6      # I(2)TMP MAGNITUDE OF R(T1)/           M B29/B27
DT21PR          EQUALS  R(T1)   +2      # I(2)TMP PREVIOUS DT21                 CS B30
MAMAX1          EQUALS  DT21PR  +2      # I(2)TMP MAJ AXIS LOW BOUND LMT        M B30
MAMAX2          EQUALS  MAMAX1  +2      # I(2)TMP MAJ AXIS UP BOUND LMT         M B30
R(T2)/          EQUALS  MAMAX2  +2      # I(6)TMP FINAL POSITION VECTOR         M B29/B27
RD              EQUALS  R(T2)/  +6      # I(2)TMP FINAL R DESIRED               M B29/B27
DRCON           EQUALS  RD      +2      # I(2)TMP RCON SLOPE ITERATOR           M B29/B27
RPRE'           EQUALS  DRCON   +2      # I(2)TMP PREVIOUS RPRE                 M B29/B27
V(T1)/          EQUALS  RPRE'   +2      # I(6)TMP VEL VECTOR AT TIG             M/CS B7/B5
V2(T1)/         EQUALS  V(T1)/  +6      # I(6)TMP POST IMP VEL AT TIG           M/CS B7/B5
DV              EQUALS  V2(T1)/ +6      # I(2)TMP DELTA VELOCITY AT TIG         M/CS B7/B5
V(T2)/          EQUALS  DV      +2      # I(6)TMP FINAL VELOCITY VECTOR         M/CS B7/B5
T1              EQUALS  V(T2)/  +6      # I(2)TMP INITIAL VECTOR TIME           CS B28
PCON            EQUALS  T1      +2      # I(2)TMP SEMI-LATUS RECTUM             M B29
X(T1)           EQUALS  PCON    +2      # I(2)TMP COTANGENT GAMMA1              B5
T12             EQUALS  X(T1)   +2      # I(2)TMP INIT TO FINAL POSIT TIME      CS B28
DELTAT          EQUALS  T12     +2      # I(2)TMP DELTA T IN SAVE PERILUNE      CS B28
NN1A            EQUALS  DELTAT  +2      # I(2)TMP ITERATION COUNTER 1
NN2             EQUALS  NN1A    +2      # I(2)TMP ITERATION COUNTER 2
RTENCKEX        EQUALS  NN2     +2      # I(1)TMP RTENCK RETURN ADDRESS
CONICX1         EQUALS  RTENCKEX +1     # I(1)TMP CONICS MU TABLE INDEX
T2              EQUALS  CONICX1 +1      # I(2)TMP FINAL TIME                    CS B28
UR1/            EQUALS  T2      +2      # I(6)TMP UNIT R(T1)/                   B1
UV1/            EQUALS  UR1/    +6      # I(6)TMP UNIT V(T1)/                   B1
BETA1           EQUALS  UV1/    +6      # I(2)TMP 1+X(T2)**2                    B1
P(T1)           EQUALS  BETA1   +2      # I(1)TMP PRIMARY BODY STATE TIME 1     B14
CFPA            EQUALS  P(T1)   +1      # I(2)TMP COSINE FLIGHT PATH ANGLE      B1
PHI2            EQUALS  CFPA    +2      # I(2)TMP PERI OR APO INDICATOR         B2
SPRTEX          EQUALS  PHI2    +2      # I(1)TMP ROUTINE RETURN ADDRESS
```

```
VNSTORE         EQUALS  SPRTEX  +1      # I(1)TMP VERBNOUN STORAGE
BETA12          EQUALS  VNSTORE +1      # I(2)TMP SIGN FOR TIMERAD

# OVERLAYS WITHIN RETURN-TO-EARTH STORAGE.
```

Defines:
BETA1, used in chunk 1301.
BETA12, used in chunks 231 and 1301.
CFPA, used in chunk 1301.
CONICX1, used in chunk 1301.
DELTAT, used in chunks 243, 362, 493, 495, 496, 498, 501, 503, 1094, and 1663.
DRCON, used in chunk 1301.
DT21PR, used in chunk 1301.
DV, used in chunks 52, 103, 961, 969, 981, 1063, 1094, 1227, 1256, 1301, 1396, 1443, 1506, 1512, 1513, 1586, 1603, 1604b, 1623, 2001, 2043, 2044, 2092, 2223, 2281, 2285, 2306, 2311, 2343, 2353, 2382, 2422, 2426, 2428, 2448, 2452, 2455, 2456, 2458, 2519, 2561, 2574, 2594, 2601, 2605, 2609, and 2621.
MAMAX1, used in chunk 1301.
MAMAX2, used in chunk 1301.
NN1, used in chunks 40, 472, and 907.
NN1A, used in chunk 1301.
NN2, used in chunk 1301.
P(T1), used in chunk 1301.
PCON, used in chunk 1301.
PHI2, used in chunk 1301.
R(T1), used in chunk 1301.
R(T1)/, used in chunk 1301.
R(T2)/, used in chunk 1301.
RCON, used in chunk 1301.
RD, used in chunks 1301 and 2452.
RPRE', used in chunk 1301.
RTEDVD, used in chunks 40, 472, and 1301.
RTEGAM2D, used in chunks 40, 472, and 1301.
RTENCKEX, used in chunk 1301.
SPRTEX, used in chunk 1301.
T1, used in chunks 418, 870, 1033, 1094, 1301, 1475, 1663, 1941, 1943, and 1944a.
T12, used in chunks 243 and 1301.
T2, used in chunks 243, 870, 1301, 1475, 1663, 1941, 1943, 1944a, and 2363.
UR1/, used in chunk 1301.
UV1/, used in chunks 243 and 1301.
V(T1)/, used in chunk 1301.
V(T2)/, used in chunk 1301.
V2(T1)/, used in chunk 1301.
VNSTORE, used in chunk 1301.
X(T1), used in chunk 1301.

Uses CONICS 61, EBANK 80, END-IN/M 236, I 206, NN 244, P 188, R2 188, REENTRY 65, REVS 206, RPRE 243, SAVE 191, SLOPE 213, STATE 138, TIG 224, UR1 188, V 229, VEL 226, VERBNOUN 181, and X(T2) 243.

243 ⟨*Page CM0128* 243⟩≡ (75 2684)

```
RPRE          EQUALS  24D          # I(2)TMP COMPUTED PREC RADIUS        M B29/B27
P/RPRE        EQUALS  26D          # I(2)TMP P/R                          B4
R/APRE        EQUALS  28D          # I(2)TMP R/A                          B6
X(T2)PRE      EQUALS  T12          # I(2)TMP PREC COTAN GAMMA2            B0
X(T2)         EQUALS  DELTAT       # I(2)TMP COTAN GAMMA2                 B0
UH/           EQUALS  UV1/         # I(2)TMP UNIT HORIZONTAL VECTOR.      B1
SPRTETIG      EQUALS  TIG          # I(2)IN TIME OF IGNITION              CS B28
```

Defines:
`P/RPRE`, used in chunk 1301.
`R/APRE`, used in chunk 1301.
`RPRE`, used in chunks 241 and 1301.
`SPRTETIG`, used in chunk 1301.
`UH/`, used in chunk 1301.
`X(T2)`, used in chunks 241 and 1301.
`X(T2)PRE`, used in chunk 1301.
Uses `A` 80, `DELTAT` 241, `I` 206, `P` 188, `T12` 241, `T2` 241, `TIG` 224, and `UV1/` 241.

244 ⟨*Page CM0129* 244⟩≡ (75 2684)

```
# *-*-*-*- OVERLAY 6 IN EBANK 7 -*-*-*-*
# P32,P33

# THE FOLLOWING OVERLAY MEAS. INCORP. ARE AND IN USE ONLY WHEN (32D)
POSTCSI         EQUALS  VG              # I(2)
DELVCSI         EQUALS  POSTCSI +2      # I(2)
DELDV           EQUALS  DELVCSI +2      # I(2)
GAMPREV         EQUALS  DELDV   +2      # I(2)
DVPREV          EQUALS  GAMPREV +2      # I(2)
POSTCDH         EQUALS  DVPREV  +2      # I(2)
HAFPA1          EQUALS  POSTCDH
VACT4           EQUALS  POSTCDH +2      # I(6)
RDOTV           EQUALS  VACT4   +6      # I(2)
VACT1           EQUALS  RDOTV   +2      # I(6)
VPASS1          EQUALS  VACT1   +6      # I(6) VEL. PASSIVE VEH. AT CSI TIME

UNVEC           EQUALS  VACT3

T2TOT3          EQUALS  TPASS4          # I(2) TPI - TCDH

CSIALRM         EQUALS  TITER           # I(2) ALARM INDEX

DELVEET2        EQUALS  S22WUNL         # I(6) VACT3 - VACT2 = DVCDH REF. COORD.

# ADDITIONAL CSI - CDH STORAGE.         (10D)
RPASS1          EQUALS  CENTANG +2      # I(6) POS. PASSIVE VEH. AT CSI TIME.
LOOPCT          EQUALS  RPASS1  +6      # I(2) ITERATION COUNTER
NN              EQUALS  LOOPCT  +2      # I(2)

# P21 STORAGE                           (19D)
P21ORIG         EQUALS  TRUNX           # I(1)
P21BASER        EQUALS  P21ORIG +1      # I(6)
P21BASEV        EQUALS  P21BASER +6     # I(6)
P21ALT          EQUALS  P21BASEV +6     # I(2) NOUN 73 R1 ALTITUDE
P21VEL          EQUALS  P21ALT  +2      # I(2) NOUN 73 R2 VELOCITY
P21GAM          EQUALS  P21VEL  +2      # I(2) NOUN 73 R3 FLIGHT PATH ANGLE

# The following two statements had been just "WHOCARES = 3777".---RSB 2009
                SETLOC  3777
WHOCARES        EQUALS                  # A DUMMY FOR E-BANK INSENSITIVE 2CADRS.
END-E7          EQUALS  WHOCARES        # ***** LAST LOCATION IN E7
```

Defines:
`CSIALRM`, used in chunks 1063 and 2223.
`DELDV`, used in chunks 1063 and 2223.

DELVCSI, used in chunks 1063 and 2223.
DELVEET2, used in chunks 295, 1063, and 2223.
DVPREV, used in chunks 1063, 2223, and 2684.
END-E7, used in chunks 372 and 1195.
GAMPREV, used in chunks 1063 and 2223.
HAFPA1, used in chunks 1063 and 2223.
LOOPCT, used in chunks 1063 and 2223.
NN, used in chunks 241, 454, 456, 460, 462, 470, 478, 756, 771, 846, 1063, and 2223.
P21ALT, used in chunks 42, 474, and 749.
P21BASER, used in chunks 747 and 749.
P21BASEV, used in chunk 749.
P21GAM, used in chunks 42, 474, and 749.
P21ORIG, used in chunk 749.
P21VEL, used in chunks 42, 474, and 749.
POSTCDH, used in chunks 1063, 2223, and 2684.
POSTCSI, used in chunks 1063 and 2223.
RDOTV, used in chunks 1063 and 2223.
RPASS1, used in chunks 1063 and 2223.
T2TOT3, used in chunks 42, 474, 1063, and 2223.
UNVEC, used in chunks 1063 and 2223.
VACT1, used in chunks 1063 and 2223.
VACT4, used in chunks 1063 and 2223.
VPASS1, used in chunks 1063 and 2223.
WHOCARES, used in chunks 357, 368, 1039, 1094, 1977, and 2213.
Uses A 80, EBANK 80, I 206, P21 219, R2 188, S22WUNL 239, TCDH 197, TITER 239, TPASS4 236, TRUNX 232, VACT2 197, VACT3 234, VEL 226, and VG 234.

245a ⟨*Page CM0130* 245a⟩≡ (75 2684)

3.3 comaid routines

245b ⟨*comaid routines* 245b⟩≡ (19a)
⟨*interrupt lead ins* 246⟩
⟨*t4rupt program* 250⟩
⟨*downlink lists* 293b⟩
⟨*fresh start and restart* 306⟩
⟨*restart tables* 361⟩
⟨*sxtmark code* 381⟩
⟨*extended verbs* 404⟩
⟨*pinball noun tables* 449⟩
⟨*csm geometry* 480⟩
⟨*imu compensation package* 492c⟩
⟨*pinball game buttons and lights* 504⟩
⟨*r60-62 code* 646⟩
⟨*anglfind code* 659⟩
⟨*gimbal lock avoidance* 681b⟩
⟨*kalcmanu steering* 683b⟩
⟨*system test standard lead ins* 691b⟩
⟨*imu calibration and alignment* 695⟩

3.3.1 interrupt lead ins

246 ⟨*interrupt lead ins* 246⟩≡ (245b)
⟨*Page CM0131* 247⟩
⟨*Page CM0132* 249⟩

247 ⟨*Page CM0131* 247⟩≡ (246 2728)

```
SETLOC  4000

COUNT   02/RUPTS

INHINT                  # GO
CAF     GOBB
XCH     BBANK
TCF     GOPROG

DXCH    ARUPT           # T6RUPT
EXTEND
DCA     T6LOC
DTCB

DXCH    ARUPT           # T5RUPT
CS      TIME5
AD      .5SEC
TCF     T5RUPT

DXCH    ARUPT           # T3RUPT
CAF     T3RPTBB
XCH     BBANK
TCF     T3RUPT

DXCH    ARUPT           # T4RUPT
CAF     T4RPTBB
XCH     BBANK
TCF     T4RUPT

DXCH    ARUPT           # KEYRUPT1
CAF     KEYRPTBB
XCH     BBANK
TCF     KEYRUPT1

DXCH    ARUPT           # KEYRUPT2
CAF     MKRUPTBB
XCH     BBANK
TCF     MARKRUPT

DXCH    ARUPT           # UPRUPT
CAF     UPRPTBB
XCH     BBANK
TCF     UPRUPT

DXCH    ARUPT           # DOWNRUPT
```

```
                    CAF     DWNRPTBB
                    XCH     BBANK
                    TCF     DODOWNTM

                    DXCH    ARUPT           # RADAR RUPT
```

Uses ARUPT 80, BBANK 80, COUNT 142, T6LOC 163, and TIME5 80.

249 ⟨*Page CM0132* 249⟩≡ (246 2728)

```
                CAF     RDRPTBB
                XCH     BBANK
                TCF     VHFREAD

                DXCH    ARUPT           # HAND CONTROL RUPT
                CAF     HCRUPTBB
                XCH     BBANK
                TCF     RESUME +3       # NOT USED

                EBANK=  LST1            # RESTART USES E0,E3
GOBB            BBCON   GOPROG

                EBANK=  LST1
T3RPTBB         BBCON   T3RUPT

                EBANK=  KEYTEMP1
KEYRPTBB        BBCON   KEYRUPT1

                EBANK=  MRKBUF1
MKRUPTBB        BBCON   MARKRUPT

UPRPTBB         =       KEYRPTBB

                EBANK=  DNTMBUFF
DWNRPTBB        BBCON   DODOWNTM

                EBANK=  DATATEST
RDRPTBB         BBCON   VHFREAD

                EBANK=  TIME1
HCRUPTBB        BBCON   RESUME          # NOT USED

                EBANK=  DSRUPTSW
T4RPTBB         BBCON   T4RUPT

                EBANK=  TIME1
T5RPTBB         BBCON   T5RUPT

T5RUPT          EXTEND
                BZMF    NOQBRSM
                EXTEND
                DCA     T5LOC
                DTCB
```

Uses ARUPT 80, BBANK 80, DATATEST 232, DNTMBUFF 148, DSRUPTSW 161, EBANK 80, KEYTEMP1 138, LST1 167, RESTART 57, T5LOC 163, and TIME1 80.

3.3.2 t4rupt program

250 ⟨*t4rupt program* 250⟩≡ (245b)

⟨*Page CM0133* 251⟩
⟨*Page CM0134* 252⟩
⟨*Page CM0135* 253⟩
⟨*Page CM0136* 254⟩
⟨*Page CM0137* 255⟩
⟨*Page CM0138* 256⟩
⟨*Page CM0139* 257⟩
⟨*Page CM0140* 258⟩
⟨*Page CM0141* 259⟩
⟨*Page CM0142* 261⟩
⟨*Page CM0143* 263⟩
⟨*Page CM0144* 264⟩
⟨*Page CM0145* 265⟩
⟨*Page CM0146* 266⟩
⟨*Page CM0147* 267⟩
⟨*Page CM0148* 268⟩
⟨*Page CM0149* 269⟩
⟨*Page CM0150* 270⟩
⟨*Page CM0151* 271⟩
⟨*Page CM0152* 272⟩
⟨*Page CM0153* 273⟩
⟨*Page CM0154* 274⟩
⟨*Page CM0155* 276⟩
⟨*Page CM0156* 277⟩
⟨*Page CM0157* 278⟩
⟨*Page CM0158* 279⟩
⟨*Page CM0159* 280⟩
⟨*Page CM0160* 281⟩
⟨*Page CM0161* 282⟩
⟨*Page CM0162* 284⟩
⟨*Page CM0163* 285⟩
⟨*Page CM0164* 286⟩
⟨*Page CM0165* 287⟩
⟨*Page CM0166* 288⟩
⟨*Page CM0167* 290⟩
⟨*Page CM0168* 292⟩
⟨*Page CM0169* 293a⟩

251 ⟨*Page CM0133* 251⟩≡ (250 2812)

```
                BANK    12
                SETLOC  T4RUP
                BANK

                COUNT   06/T4RPT

T4RUPT          TS      BANKRUPT
                EXTEND
                QXCH    QRUPT

                CCS     DSRUPTSW        # GOES 7(-1)0 AROUND AND AROUND
                TCF     NORMT4 +1
                TCF     NORMT4

                TCF     QUIKDSP

NORMT4          CAF     SEVEN
                TS      RUPTREG1
                TS      DSRUPTSW

                COUNT   02/T4RPT

74K             =       HIGH4

# RELTAB IS A PACKED TABLE. RELAYWORD CODE IN UPPER 4 BITS, RELAY CODE
# IN LOWER 5 BITS.

                BLOCK   02
                SETLOC  FFTAG12
                BANK

RELTAB          OCT     04025
                OCT     10003
                OCT     14031
                OCT     20033
                OCT     24017
                OCT     30036
                OCT     34034
                OCT     40023
                OCT     44035
                OCT     50037
                OCT     54000
RELTAB11        OCT     60000
```

Uses `A` 80, `BANKRUPT` 80, `CODE` 140, `COUNT` 142, `DSRUPTSW` 161, `FFTAG12` 57, `QRUPT` 80,

RUPTREG1 138, and T4RUP 59.

252 ⟨*Page CM0134* 252⟩≡ (250 2812)

```
# SWITCHED-BANK PORTION

                BANK    12
                SETLOC  T4RUP
                BANK

                COUNT   06/T4RPT

CDRVE           CCS     DSPTAB +11D
                TC      DSPOUT
                TC      DSPOUT

                XCH     DSPTAB +11D
                MASK    LOW11
                TS      DSPTAB +11D
                AD      RELTAB11
                EXTEND
                WRITE   OUT0
                TC      HANG20
```

Uses COUNT 142, DSPTAB 154, OUT0 87, T4RUP 59, and TC 169.

253 ⟨*Page CM0135* 253⟩≡ (250 2812)

```
# DSPOUT PROGRAM, PUTS OUT DISPLAYS

DSPOUTSB        TS      NOUT
                CS      ZERO
                TS      DSRUPTEM        # SET TO -0 FOR 1ST PASS THRU DSPTAB
                XCH     DSPCNT
                AD      NEG0            # TO PREVENT +0
                TS      DSPCNT
DSPSCAN         INDEX   DSPCNT
                CCS     DSPTAB
                CCS     DSPCNT          # IF DSPTAB ENTRY +, SKIP
                TCF     DSPSCAN -2      # IF DSPCNT +, AGAIN
                TCF     DSPLAY          # IF DSPTAB ENTRY -, DISPLAY
TABLNTH         OCT     12              # DEC 10 LENGTH OF DSPTAB
                CCS     DSRUPTEM        # IF DSRUPTEM=+0, 2ND PASS THRU DSPTAB
120MRUPT        DEC     16372           # (DSPCNT = 0).  +0 INTO NOUT.
                TS      NOUT
                TC      Q
                TS      DSRUPTEM        # IF DSRUPTEM=-0, 1ST PASS THRU DSPTAB
                CAF     TABLNTH         # (DSPCNT=0).+0 INTO DSRUPTEM. PASS AGAIN
                TCF     DSPSCAN -1

DSPLAY          AD      ONE
                INDEX   DSPCNT
                TS      DSPTAB          # REPLACE POSITIVELY
                MASK    LOW11           # REMOVE BITS 12 TO 15
                TS      DSRUPTEM
                CAF     HI5
                INDEX   DSPCNT
                MASK    RELTAB          # PICK UP BITS 12 TO 15 OF RELTAB ENTRY
                AD      DSRUPTEM
                EXTEND
                WRITE   OUT0            # WRITE CHANNEL 10
                TCF     Q+1             # *** NORMAL RETURN SKIPS ONE

DSPOUT          CCS     FLAGWRD5        # DON'T DISPLAY UNLESS DSKY FLAG ON
                CAF     ZERO
                TCF     NODSPOUT
                CCS     NOUT
                TC      DSPOUTSB
                TCF     NODSPOUT        # NO DISPLAY REQUESTS

HANG20          CS      11,14,9
                ADS     DSRUPTSW
```

```
                CAF     20MRUPT

SETTIME4        TS      TIME4
```

Uses DISPLAYS 59, DSPCNT 152, DSPTAB 154, DSRUPTEM 138, DSRUPTSW 161, FLAGWRD5 113, NOUT 154, OUTO 87, Q 80, TC 169, and TIME4 80.

254 ⟨*Page CM0136* 254⟩≡ (250 2812)

```
# THE STATUS OF THE PROCEED PUSHBUTTON IS MONITORED EVERY 120 MILLISECONDS VIA THE CH
# THE STATE OF THIS INBIT IS COMPARED WITH ITS STATE DURING THE PREVIOUS T4RUPT AND I
#       IF PREV ON AND NOW ON   -- BYPASS
#       IF PREV ON AND NOW OFF  -- UPDATE IMODES33
#       IF PREV OFF AND NOW ON  -- UPDATE IMODES33 AND PROCESS VIA PINBALL
#       IF PREV OFF AND NOW OFF -- BYPASS
# THE LOGIC EMPLOYED REQUIRES ONLY 9 MCT (APPROX. 108 MICROSECONDS) OF COMPUTER TIME

PROCEEDE        CA      IMODES33        # MONITOR FOR PROCEED BUTTON
                EXTEND
                RXOR    CHAN32          # CHECK IF BIT 14 DIFFERENT
                MASK    BIT14
                EXTEND
                BZF     T4JUMP          # NO CHANGE

                LXCH    IMODES33
                EXTEND
                RXOR    LCHAN
                TS      IMODES33        # UPDATE IMODES33
                MASK    BIT14
                CCS     A
                TCF     T4JUMP          # WAS ON -- NOW OFF

                CAF     CHRPRIO         # WAS OFF -- NOW ON
                TC      NOVAC
                EBANK=  DSPCOUNT
                2CADR   PROCKEY
```

Uses A 80, CHAN32 87, COMPUTER 115, DSPCOUNT 152, EBANK 80, IMODES33 163, LCHAN 87, STATE 138, and TC 169.

255 ⟨*Page CM0137* 255⟩≡ (250 2812)

```
# JUMP TO APPROPRIATE ONCE-PER SECOND (0.96 SEC ACTUALLY) ACTIVITY

T4JUMP          INDEX   RUPTREG1
                TCF     +1

                TCF     OPTTEST
                TCF     OPTMON
                TCF     IMUMON
                TCF     RESUME
                TCF     OPTTEST
                TCF     OPTMON
                TCF     IMUMON
                TCF     RESUME

OPTTEST         TC      IBNKCALL
                CADR    OPTDRIVE

20MRUPT         =       OCT37776        # (DEC 16382)

NODSPOUT        EXTEND                  # TURN OFF RELAYS
                WRITE   OUT0

                CAF     120MRUPT        # SET FOR NEXT CDRVE
                TCF     SETTIME4

QUIKDSP         CAF     BIT14
                MASK    DSRUPTSW
                EXTEND
                BZF     QUIKOFF         # WROTE LAST TIME, NOW TURN OFF RELAYS.

                CCS     NOUT
                TC      DSPOUTSB
                TCF     NODSPY          # NOUT=0 OR BAD RETURN FROM DSPOUTSB
                CS      BIT14           # GOOD RETURN (WE DISPLAYED SOMETHING)
QUIKRUPT        ADS     DSRUPTSW

                CAF     20MRUPT
                TS      TIME4

                CAF     BIT9
                ADS     DSRUPTSW

                TC      RESUME

NODSPY          EXTEND
```

```
                WRITE   OUT0

SYNCT4          CAF     20MRUPT
                ADS     TIME4

                CAF     BIT9
```

Uses DSRUPTSW 161, NOUT 154, OUT0 87, RUPTREG1 138, TC 169, and TIME4 80.

256 ⟨*Page CM0138* 256⟩≡ (250 2812)

```
                ADS     DSRUPTSW
                CCS     DSRUPTSW
                TC      RESUME
OCT37737        OCT     37737
                TC      SYNCT4
                TC      RESUME

QUIKOFF         EXTEND
                WRITE   OUT0
                CAF     BIT14           # RESET DSRUPTSW TO SEND DISPLAY NEXT PASS
                TCF     QUIKRUPT

11,14,9         OCT     22400
```

Uses DSRUPTSW 161, OUT0 87, and TC 169.

257 ⟨*Page CM0139* 257⟩≡ (250 2812)

```
# PROGRAM NAME:  IMUMON
#
# FUNCTIONAL DESCRIPTION:  THIS PROGRAM IS ENTERED EVERY 480 MS.  IT DETECTS CHANGES OF THE IMU
# CHANNEL 30 AND CALLS THE APPROPRIATE SUBROUTINES.  THE BITS PROCESSED AND THEIR RELEVANT SUBR
#
#       FUNCTION                BIT     SUBROUTINE CALLED
#       --------                ---     -----------------
#       TEMP IN LIMITS           15     TLIM
#       ISS TURN-ON REQUEST      14     ITURNON
#       IMU FAIL                 13     IMUFAIL (SETISSW)
#       IMU CDU FAIL             12     ICDUFAIL (SETISSW)
#       IMU CAGE                 11     IMUCAGE
#       IMU OPERATE               9     IMUOP
#
# THE LAST SAMPLED STATE OF THESE BITS IS LEFT IN IMODES30.  ALSO, EACH SUBROUTINE CALLED FINDS
# VALUE OF THE BIT IN A, WITH Q SET TO THE PROPER RETURN LOCATION NXTIFAIL.
#
# CALLING SEQUENCE:  T4RUPT EVERY 480 MILLISECONDS.
#
# JOBS OR TASKS INITIATED:  NONE.
#
# SUBROUTINES CALLED:  TLIM, ITURNON, SETISSW, IMUCAGE, IMUOP.
#
# ERASABLE INITIALIZATION:
#       FRESH START OR RESTART WITH NO GROUPS ACTIVE:  C(IMODES30) = OCT 37411.
#       RESTART WITH ACTIVE GROUPS:     C(IMODES30) = (B(IMODES30)AND(OCT 00035)) PLUS OCT 3740
#                                       THIS LEAVES IMU FAIL BITS INTACT.
#
# ALARMS:  NONE.
#
# EXIT:  TNONTEST.
#
# OUTPUT:  UPDATED IMODES30 WITH CHANGES PROCESSED BY APPROPRIATE SUBROUTINE.

IMUMON          CA      IMODES30        # SEE IF THERE HAS BEEN A CHANGE IN THE
                EXTEND                  # RELEVANT BITS OF CHAN 30.
                RXOR    CHAN30          # CHECK IF BITS 9,11-15 CHANGED
                MASK    30RDMSK
                EXTEND
                BZF     TNONTEST        # NO CHANGE IN STATUS

                TS      RUPTREG1        # SAVE BITS WHICH HAVE CHANGED.
                LXCH    IMODES30        # UPDATE IMODES30.
                EXTEND
                RXOR    LCHAN
```

```
                TS      IMODES30

                CS      ONE
                XCH     RUPTREG1
                EXTEND
```

Uses A 80, CHAN 191, CHAN30 87, IMODES30 163, IT 185, LCHAN 87, Q 80, RESTART 57, RUPTREG1 138, SAVE 191, STATE 138, and TEMP 191.

258 ⟨*Page CM0140* 258⟩≡ (250 2812)

```
                BZMF    TLIM            # CHANGE IN IMU TEMP.
                TCF     NXTIFBIT        # BEGIN BIT SCAN.

        -1      AD      ONE             # (RE-ENTERS HERE FROM NXTIFAIL.)
NXTIFBIT        INCR    RUPTREG1        # ADVANCE BIT POSITION NUMBER.
        +1      DOUBLE
                TS      A               # SKIP IF OVERFLOW.
                TCF     NXTIFBIT        # LOOK FOR BIT.

                XCH     RUPTREG2        # SAVE OVERFLOW-CORRECTED DATA.
                INDEX   RUPTREG1        # SELECT NEW VALUE OF THIS BIT.
                CAF     BIT14
                MASK    IMODES30
                INDEX   RUPTREG1
                TC      IFAILJMP

NXTIFAIL        CCS     RUPTREG2        # PROCESS ANY ADDITIONAL CHANGES.
                TCF     NXTIFBIT -1
```

Uses A 80, IMODES30 163, RUPTREG1 138, RUPTREG2 138, SAVE 191, TC 169, and TEMP 191.

259 ⟨*Page CM0141* 259⟩≡ (250 2812)

```
# PROGRAM NAME:  TNONTEST.
#
# FUNCTIONAL DESCRIPTION:  THIS PROGRAM HONORS REQUESTS FOR ISS INITIALIZATION.  ISS TURN-ON (C
# AND ISS OPERATE (CHANNEL 30 BIT 9) REQUESTS ARE TREATED AS A PAIR AND PROCESSING TAKES PLACE
# AFTER EITHER ONE APPEARS.  THIS INITIALIZATION TAKES ON ONE OF THE FOLLOWING THREE FORMS:
#
#       1) ISS TURN-ON:  IN THIS SITUATION THE COMPUTER IS OPERATING WHEN THE ISS IS TURNED ON.
#       BOTH ISS TURN-ON AND ISS OPERATE APPEAR.  THE PLATFORM IS CAGED FOR 90 SECONDS AND THE
#       SO THAT AT THE END OF THE PROCESS THE GIMBAL LOCK MONITOR WILL FUNCTION PROPERLY.
#
#       2) ICDU INITIALIZATION:  IN THIS CASE THE COMPUTER WAS PROBABLY TURNED ON WITH THE ISS
#       A FRESH START WAS DONE WIT THE ISS IN OPERATE.  IN THIS CASE ONLY ISS OPERATE IS ON.  T
#       ZEROED SO THE GIMBAL LOCK MONITOR WILL FUNCTION.  AN EXCEPTION IS IF THE ISS IS IN GIME
#       A RESTART, THE ICDU'S WILL NOT BE ZEROED.
#
#       3) RESTART WITH RESTARTABLE PROGRAM USING THE IMU:  IN THIS CASE, NO INITIALIZATION TAK
#       IT IS ASSUMED THAT THE USING PROGRAM DID THE INITIALIZATION AND THEREFORE T4RUPT SHOULD
#
# IMODES30 BIT 7 IS SET = 1 BY THE FIRST BIT (CHANNEL 30 BIT 14 OR 9) WHICH ARRIVES.  FOLLOWING
# ENTERED, FINDS BIT 7 = 1 BUT BIT 8 = 0, SO IT SETS BIT 8 = 1 AND EXITS.  THE NEXT TIME IT FIN
# PROCEEDS, SETTING BITS 8 AND 7 = 0.  AT PROCTNON, IF ISS TURN-ON REQUEST IS PRESENT, THE ISS
# COARSE).  IF ISS OPERATE IS NOT PRESENT PROGRAM ALARM 00213 IS ISSUED.  AT THE END OF A 90 SE
# OF IMODES30 IS TESTED.  IF IT IS = 1, ISS TURN-ON WAS NOT PRESENT FOR THE ENTIRE 90 SECONDS.
# THE ISS TURN-ON REQUEST IS PRESENT THE 90 SECOND WAIT IS REPEATED,  OTHERWISE NO ACTION OCCUR
# WAS WAITING FOR THE INITIALIZATION IN WHICH CASE THE PROGRAM IS GIVEN AN IMUSTALL ERROR RETUR
# WENT PROPERLY, THE ISS DELAY OUTBIT IS SENT AND THE ICDU'S ZEROED.  A TASK IS INITIATED TO RE
# INHIBIT BIT IN 10.24 SECONDS.  IF A MISSION PROGRAM WAS WAITING IT IS INFORMED VIA ENDIMU.
#
# AT PROCTNON, IF ONLY ISS OPERATE IS PRESENT (OPONLY), THE CDU'S ARE ZEROED UNLESS THE PLATFOR
# ALIGN (= GIMBAL LOCK HERE) OR A MISSION PROGRAM IS USING THE IMU (INUSEFLG = 1).
#
# CALLING SEQUENCE:  T4RUPT EVERY 480 MILLISECONDS AFTER IMUMON.
#
# JOBS OR TASKS INITIATED:  1) ENDTNON, 90 SECONDS AFTER CAGING STARTED.  2) ISSUP, 4 SECONDS A
#       3) PFAILOK, 10.24 SECONDS AFTER INITIALIZATION COMPLETED.  4) UNZ2, 320 MILLISECONDS AF
#       STARTED.
#
# SUBROUTINES CALLED: CAGESUB, CAGESUB2, ZEROICDU, ENDIMU, IMUBAD, NOATTOFF, SETISSW, VARDELAY.
#
# ERASABLE INITIALIZATION:  SEE IMUMON.
#
# ALARMS:  PROGRAM ALARM 00213 IF ISS TURN-ON REQUESTED WITHOUT ISS OPERATE.
#
# EXIT:  ENDTNON EXITS TO C33TEST.  TASKS HAVING TO DO WITH INITIALIZATION EXIT AS FOLLOWS:  MI
# WAITING AND INITIALIZATION COMPLETE, EXIT TO ENDIMU, MISSION PROGRAM WAITING AND INITIALIZATI
```

```
# IMUBAD, IMU NOT IN USE, EXIT TO TASKOVER.
#
# OUTPUT:  ISS INITIALIZED.

TNONTEST                CS      IMODES30        # AFTER PROCESSING ALL CHANGES, SEE I
```

Uses A 80, COMPUTER 115, IMODES30 163, IT 185, and RESTART 57.

261 ⟨*Page CM0142* 261⟩≡ (250 2812)

```
                        MASK    BIT7            # IS TIME TO ACT ON A TURN-ON SEQUENCE.
                        CCS     A
                        TCF     C33TEST         # NO -- EXAMINE CHANNEL 33.

                        CAF     BIT8            # SEE IF FIRST SAMPLE OR SECOND.
                        MASK    IMODES30
                        CCS     A
                        TCF     PROCTNON        # REACT AFTER A SECOND SAMPLE.

                        CAF     BIT8            # IF FIRST SAMPLE, SET BIT TO REACT NEXT
                        ADS     IMODES30        # TIME.
                        TCF     C33TEST

# PROCESS IMU TURN-ON REQUESTS AFTER WAITING 1 SAMPLE FOR ALL SIGNALS TO ARRIVE.

PROCTNON                CS      BITS7&8
                        MASK    IMODES30
                        TS      IMODES30
                        MASK    BIT14           # SEE IF TURN-ON REQUEST.
                        CCS     A
                        TCF     OPONLY          # OPERATE ON ONLY.

                        CS      IMODES30        # IF TURN-ON REQUEST, WE SHOULD HAVE IMU
                        MASK    BIT9            # OPERATE.
                        CCS     A
                        TCF     +3

                        TC      ALARM           # ALARM IF NOT
                        OCT     213

        +3              TC      CAGESUB

                        CAF     90SECS
                        TC      WAITLIST
                        EBANK=  CDUIND
                        2CADR   ENDTNON

                        TCF     C33TEST

RETNON                  CAF     90SECS
                        TC      VARDELAY

ENDTNON                 CS      BIT2            # RESET TURN-ON REQUEST FAIL BIT.
                        MASK    IMODES30
                        XCH     IMODES30
```

```
MASK    BIT2            # IF IT WAS OFF, SEND ISS DELAY COMPI
EXTEND
BZF     ENDTNON2
```

Uses A 80, CDUIND 169, EBANK 80, IMODES30 163, IT 185, and TC 169.

263 ⟨*Page CM0143* 263⟩≡ (250 2812)

```
                    CAF     BIT14           # IF IT WAS ON AND TURN-ON REQUEST NOW.
                    MASK    IMODES30        # PRESENT, RE-ENTER 90 SEC DELAY IN WL.
                    EXTEND
                    BZF     RETNON

                    CS      STATE           # IF IT IS NOT ON NOW, SEE IF A PROG WAS
                    MASK    IMUSEFLG        # WAITING.
                    CCS     A
                    TCF     TASKOVER
                    TC      POSTJUMP
                    CADR    IMUBAD          # UNSUCCESSFUL TURN-ON.

ENDTNON2            CAF     BIT15           # SEND ISS DELAY COMPLETE.
                    EXTEND
                    WOR     CHAN12          # TURN OFF ISS DELAY COUNTER
                    TC      IBNKCALL        # TURN OFF NO ATT LAMP.
                    CADR    NOATTOFF

UNZ2                TC      ZEROICDU

                    CS      BITS4&5         # REMOVE ZERO AND COARSE.
                    EXTEND
                    WAND    CHAN12

                    CAF     BIT11           # WAIT 10 SECS FOR CTRS TO FIND GIMBALS
                    TC      VARDELAY

ISSUP               CS      OCT54           # REMOVE CAGING, IMU FAIL INHIBIT, AND
                    MASK    IMODES30        # ICDUFAIL INHIBIT FLAGS.
                    TS      IMODES30

                    CS      BIT6            # ENABLE DAP
                    MASK    IMODES33
                    TS      IMODES33

                    TC      SETISSW         # ISS WARNING MIGHT HAVE BEEN INHIBITED.

                    CS      BIT15           # REMOVE IMU DELAY COMPLETE DISCRETE.
                    EXTEND
                    WAND    CHAN12

                    CAF     4SECS           # DONT ENABLE PROG ALARM ON PIP FAIL FOR
                    TC      WAITLIST        # ANOTHER 4 SECS.
                    EBANK=  CDUIND
                    2CADR   PFAILOK
```

```
                        TCF     TASKOVER

  OPONLY                CAF     BIT4
```

Uses A 80, CDUIND 169, CHAN12 87, EBANK 80, IMODES30 163, IMODES33 163, IT 185, STATE 138, and TC 169.

264 ⟨*Page CM0144* 264⟩≡ (250 2812)

```
                        EXTEND                  # IF OPERATE ON ONLY AND WE ARE IN CO
                        RAND    CHAN12          # ALIGN, DON'T ZERO THE CDUS BECAUSE
                        CCS     A               # MIGHT BE IN GIMBAL LOCK. USE V41N20
                        TCF     C33TEST         # RECOVER.

                        CAF     IMUSEFLG        # OTHERWISE, ZERO THE COUNTERS
                        MASK    STATE           # UNLESS SOMEONE IS USING THE IMU.
                        CCS     A
                        TCF     C33TEST

                        TC      CAGESUB2        # SET TURNON FLAGS.

  ISSZERO               TC      IBNKCALL        # TURN OFF NO ATT LAMP.
                        CADR    NOATTOFF        #     IMU CAGE OFF ENTRY.

                        CAF     BIT5            # ISS CDU ZERO
                        EXTEND
                        WOR     CHAN12

                        TC      ZEROICDU
                        CAF     BIT6            # WAIT 300 MS FOR AGS TO RECEIVE SIGN
                        TC      WAITLIST
                        EBANK=  OPTMODES
                        2CADR   UNZ2

                        TCF     C33TEST
```

Uses A 80, CDUS 80, CHAN12 87, EBANK 80, OPTMODES 163, STATE 138, and TC 169.

265 ⟨*Page CM0145* 265⟩≡ (250 2812)

```
# PROGRAM NAME:  C33TEST
#
# FUNCTIONAL DESCRIPTION:  THIS PROGRAM MONITORS THREE FLIP-FLOP INBITS OF CHANNEL 33 AND CALLS
# SUBROUTINE TO PROCESS A CHANGE.  IT IS ANALOGOUS TO IMUMON, WHICH MONITORS CHANNEL 30, EXCEPT
# CHANNEL 33 WITH A WAND INSTRUCTION BECAUSE A 'WRITE' PULSE IS REQUIRED TO RESET THE FLIP-FLOP
# PROCESSED AND THE SUBROUTINES CALLED ARE:
#       BIT     FUNCTION                SUBROUTINE
#       ---     --------                ----------
#        13     PIPA FAIL               PIPFAIL
#        12     DOWNLINK TOO FAST       DNTMFAST
#        11     UPLINK TOO FAST         UPTMFAST
#
# UPON ENTRY TO THE SUBROUTINE, THE NEW BIT STATE IS IN A.
#
# CALLING SEQUENCE:  EVERY 480 MILLISECONDS AFTER TNONTEST.
#
# JOBS OR TASKS INITIATED:  NONE.
#
# SUBROUTINES CALLED:  PIPFAIL, DNTMFAST AND UPTMFAST ON BIT CHANGES.
#
# ERASABLE INITIALIZATION:  C(IMODES33) = OCT 16000 ON A FRESH START OR RESTART, THEREFORE, THE
# REAPPEAR IF THE CONDITIONS PERSIST.
#
# ALARMS:  NONE.
#
# EXIT:  GLOCKMON.
#
# OUTPUT:  UPDATED BITS 13, 12, AND 11 OF IMODES33 WITH CHANGES PROCESSED.

C33TEST         CA      IMODES33                # SEE IF RELEVANT CHAN33 BITS HAVE
                MASK    33RDMSK
                TS      L                       # CHANGED.
                CAF     33RDMSK
                EXTEND
                WAND    CHAN33                  # RESETS FLIP-FLOP INPUTS
                EXTEND
                RXOR    LCHAN
                EXTEND
                BZF     GLOCKMON                # ON NO CHANGE.

                TS      RUPTREG1                # SAVE BITS WHICH HAVE CHANGED
                LXCH    IMODES33
                EXTEND
                RXOR    LCHAN
                TS      IMODES33                # UPDATED IMODES33.
```

```
                CAF     ZERO
                XCH     RUPTREG1
                DOUBLE
```

Uses A 80, CHAN33 87, IMODES33 163, IT 185, L 80, LCHAN 87, RESTART 57, RUPTREG1 138, SAVE 191, and STATE 138.

266 ⟨*Page CM0146* 266⟩≡ (250 2812)

```
                TCF     NXTIBT +1               # SCAN FOR BIT CHANGES.

        -1      AD      ONE
NXTIBT          INCR    RUPTREG1
        +1      DOUBLE
                TS      A                       # (CODING IDENTICAL TO CHAN 30).
                TCF     NXTIBT

                XCH     RUPTREG2
                INDEX   RUPTREG1                # GET NEW VALUE OF BIT WHICH CHANGED.
                CAF     BIT13
                MASK    IMODES33
                INDEX   RUPTREG1
                TC      C33JMP

NXTFL33         CCS     RUPTREG2                # PROCESS POSSIBLE ADDITIONAL CHANGES
                TCF     NXTIBT -1
```

Uses A 80, CHAN 191, IMODES33 163, RUPTREG1 138, RUPTREG2 138, and TC 169.

267 ⟨*Page CM0147* 267⟩≡ (250 2812)

```
# PROGRAM NAME:  GLOCKMON
#
# FUNCTIONAL DESCRIPTION:  THIS PROGRAM MONITORS THE CDUZ COUNTER TO DETERMINE WHETHER THE ISS
# AND TAKES ACTION IF IT IS.  THREE REGIONS OF MIDDLE GIMBAL ANGLE (MGA) ARE USED:
#
#       1) ABS(MGA) LESS THAN OR EQUAL TO 70 DEGREES -- NORMAL MODE.
#       2) ABS(MGA) GREATER THAN 70 DEGREES AND LESS THAN OR EQUAL TO 85 DEGREES -- GIMBAL LOCK
#       3) ABS(MGA) GREATER THAN 85 DEGREES -- ISS PUT IN COARSE ALIGN AND NO ATT LAMP TURNED O
#
# CALLING SEQUENCE:  EVERY 480 MILLISECONDS AFTER C33TEST.
#
# JOBS OR TASKS INITIATED:  NONE.
#
# SUBROUTINES CALLED:   1) SETCOARS WHEN ABS(MGA) GREATER THEN 85 DEGREES AND ISS NOT IN COARSE
#                       2) LAMPTEST BEFORE TURNING OFF GIMBAL LOCK LAMP.
#
# ERASABLE INITIALIZATION:
#               1) FRESH START OR RESTART WITH NO GROUPS ACTIVE:  C(CDUZ) = 0, IMODES30 BIT 6 =
#               2) RESTART WITH GROUPS ACTIVE:  SAME AS FRESH START EXCEPT C(CDUZ) NOT CHANGED
#                                               PROCEEDS AS BEFORE.
#
# ALARMS:       1) MGA REGION (2) CAUSES GIMBAL LOCK LAMP TO BE LIT.
#               2) MGA REGION (3) CAUSES THE ISS TO BE PUT IN COARSE ALIGN AND THE NO ATT LAMP
#                  SO ALREADY.

GLOCKMON        CCS     CDUZ
                TCF     GLOCKCHK                # SEE IF MAGNITUDE OF MGA IS GREATER THAN
                TCF     SETGLOCK                # 70 DEGREES.
                TCF     GLOCKCHK
                TCF     SETGLOCK

GLOCKCHK        AD      -70DEGS
                EXTEND
                BZMF    SETGLOCK -1             # NO LOCK.

                AD      -15DEGS                 # SEE IF ABS(MGA) GREATER THAN 85 DEGREES
                EXTEND
                BZMF    NOGIMRUN

                CAF     BIT4                    # IF SO, SYSTEM SHOULD BE IN COARSE ALIGN
                EXTEND                          # TO PREVENT GIMBAL RUNAWAY.
                RAND    CHAN12
                CCS     A
                TCF     NOGIMRUN
```

```
                TC      IBNKCALL                # GO INTO COARSE ALIGN.
                CADR    SETCOARS

                CAF     SIX                     # ENABLE ISS ERROR COUNTERS IN 60 MS.
                TC      WAITLIST
```

Uses A 80, CDUZ 80, CHAN12 87, IMODES30 163, IMODES33 163, IT 185, MODE 145, RESTART 57, and TC 169.

268 ⟨*Page CM0148* 268⟩≡ (250 2812)

```
                EBANK=  CDUIND
                2CADR   CA+ECE

NOGIMRUN        CAF     BIT6                    # TURN ON GIMBAL LOCK LAMP.
                TCF     SETGLOCK

 -1             CAF     ZERO
SETGLOCK        AD      DSPTAB +11D             # SEE IF PRESENT STATE OF GIMBAL LOCK
                MASK    BIT6                    # AGREES WITH DESIRED STATE BY HALF A
                EXTEND                          # THE TWO.
                BZF     GLOCKOK                 # OK AS IS.

                MASK    DSPTAB +11D             # IF OFF, DON'T TURN ON IF IMU BEING
                CCS     A
                TCF     GLAMPTST                # TURN OFF UNLESS LAMP TEST IN PROGRE

                CAF     BIT6
                MASK    IMODES30
                CCS     A
                TCF     GLOCKOK

GLINVERT        CS      DSPTAB +11D             # INVERT GIMBAL LOCK LAMP.
                MASK    BIT6
                AD      BIT15                   # TO INDICATE CHANGE IN DSPTAB +11D.
                XCH     DSPTAB +11D
                MASK    OCT37737
                ADS     DSPTAB +11D
                TCF     GLOCKOK

GLAMPTST        TC      LAMPTEST                # TURN OFF UNLESS LAMP TEST IN PROGRE
                TCF     GLOCKOK
                TCF     GLINVERT

-70DEGS         DEC     -.38888                 # -70 DEGREES SCALED IN HALF-REVOLUTI
-15DEGS         DEC     -.08333
```

Uses A 80, CDUIND 169, DSPTAB 154, EBANK 80, IMODES30 163, STATE 138, and TC 169.

269 ⟨*Page CM0149* 269⟩≡ (250 2812)

```
# PROGRAM NAME:  TLIM.
#
# FUNCTIONAL DESCRIPTION:  THIS PROGRAM MAINTAINS THE TEMP LAMP (BIT 4 OF CHANNEL 11) ON THE DS
# THE TEMP SIGNAL FROM THE ISS (BIT 15 OF CHANNEL 30).  HOWEVER, THE LIGHT WILL NOT BE TURNED O
# IS IN PROGRESS.
#
# CALLING SEQUENCE:  CALLED BY IMUMON ON A CHANGE OF BIT 15 OF CHANNEL 30.
#
# JOBS OR TASKS INITIATED:  NONE.
#
# SUBROUTINES CALLED:  LAMPTEST.
#
# ERASABLE INITIALIZATION:  FRESH START AND RESTART TURN THE TEMP LAMP OFF.
#
# ALARMS:  TEMP LAMP TURNED ON WHEN THE IMU TEMP GOES OUT OF LIMITS.
#
# EXIT:  NXTIFAIL.
#
# OUTPUT:  SERVICE OF TEMP LAMP.                  IN A, EXCEPT FOR TLIM.

TLIM            MASK    POSMAX                  # REMOVE BIT FROM WORD OF CHANGES AND SET
                TS      RUPTREG2                # DSKY TEMP LAMP ACCORDINGLY.

                CCS     IMODES30
                TCF     TEMPOK
                TCF     TEMPOK

                CAF     BIT4                    # TURN ON LAMP.
                EXTEND
                WOR     DSALMOUT
                TCF     NXTIFAIL

TEMPOK          TC      LAMPTEST                # IF TEMP NOW OK, DON'T TURN OFF LAMP IF
                TCF     NXTIFAIL                # LAMP TEST IN PROGRESS.

                CS      BIT4
                EXTEND
                WAND    DSALMOUT                # TURN OFF LAMP
                TCF     NXTIFAIL
```

Uses A 80, DSALMOUT 87, IMODES30 163, RESTART 57, RUPTREG2 138, TC 169, and TEMP 191.

270 ⟨*Page CM0150* 270⟩≡ (250 2812)

```
# PROGRAM NAME:  ITURNON.
#
# FUNCTIONAL DESCRIPTION:  THIS PROGRAM IS CALLED BY IMUMON WHEN A CHANGE OF BIT 14 (
# REQUEST) IS DETECTED.  UPON ENTRY, ITURNON CHECKS IF A TURN-ON DELAY SEQUENCE HAS B
# IF NOT, IT CHECKS WHETHER THE TURN-ON REQUEST CHANGE IS TO ON OR OFF.  IF ON, IT SE
# THAT TNONTEST WILL INITIATE THE ISS INITIALIZATION SEQUENCE.  IF OFF, THE TURN-ON D
# 15, IS CHECKED AND IF IT IS ON, ITURNON EXITS.  IF THE DELAY SIGNAL IS OFF, PROGRAM
# OF IMODES30 IS SET TO 1 AND THE PROGRAM EXITS.
#
# THE SETTING OF BIT 2 OF IMODES30 (ISS DELAY SEQUENCE FAIL) INHIBITS THIS ROUTINE AN
# PROCESSING ANY CHANGES.  THIS BIT WILL BE RESET BY THE ENDTNON ROUTINE WHEN THE CUR
# ENDS.
#
# CALLING SEQUENCE:  FROM IMUMON WHEN ISS TURN-ON REQUEST CHANGES STATE.
#
# JOBS OR TASKS INITIATED:  NONE.
#
# SUBROUTINES CALLED:  ALARM, IF THE ISS TURN-ON REQUEST IS NOT PRESENT FOR 90 SECOND
#
# ERASABLE INITIALIZATION:  FRESH START AND RESTART SET BIT 15 OF CHANNEL 12 AND BITS
# AND BIT 14 OF IMODES30 TO 1.
#
# ALARMS: PROGRAM ALARM 00207 IS ISSUED IF THE ISS TURN-ON REQUEST SIGNAL IS NOT PRES
#
# EXIT:  NXTIFAIL.
#
# OUTPUT:  BIT 7 OF IMODES30 TO START ISS INITIALIZATION, OR BIT 2 OF IMODES30 AND PR
# A FAILED TURN-ON SEQUENCE.

ITURNON         CAF     BIT2            # IF DELAY REQUEST HAS GONE OFF
                MASK    IMODES30        # PREMATURELY, DO NOT PROCESS ANY CHANGES
                CCS     A               # UNTIL THE CURRENT 90 SEC WAIT EXPIRES.
                TCF     NXTIFAIL

                CAF     BIT14           # SEE IF JUST ON OR OFF.
                MASK    IMODES30
                EXTEND
                BZF     ITURNON2        # IF JUST ON.

                CAF     BIT15
                EXTEND                  # SEE IF DELAY PRESENT DISCRETE HAS BEEN
                RAND    CHAN12          # SENT.  IF SO, ACTION COMPLETE
                EXTEND
                BZF     +2
                TCF     NXTIFAIL
```

```
                CAF     BIT2            # IF NOT, SET BIT TO INDICATE REQUEST NOT
                ADS     IMODES30        # PRESENT FOR FULL DURATION.
                TC      ALARM
                OCT     207
                TCF     NXTIFAIL
```

Uses A 80, CHAN12 87, IMODES30 163, IT 185, RESTART 57, STATE 138, and TC 169.

271 ⟨*Page CM0151* 271⟩≡ (250 2812)

```
  ITURNON2      CS      IMODES30        # SET BIT7 TO INDICATE WAIT OF 1 SAMPLE
                MASK    BIT7
                ADS     IMODES30
                TCF     NXTIFAIL
```

Uses IMODES30 163.

272 ⟨*Page CM0152* 272⟩≡ (250 2812)

```
# PROGRAM NAME:  IMUCAGE.
#
# FUNCTIONAL DESCRIPTION:  THIS PROGRAM PROCESSES CHANGES OF THE IMUCAGE INBIT, CHANN
# CHANGES TO 0 (CAGE BUTTON PRESSED), THE ISS IS CAGED (ICDU ZERO + COARSE ALIGN + NO
# ASTRONAUT SELECTS ANOTHER PROGRAM TO ALIGN THE ISS.  ANY PULSE TRAINS TO THE ICDU'S
# THE ASSOCIATE OUTCOUNTERS ARE ZEROED AND THE GYRO'S ARE DE-SELECTED.  NO ACTION OCC
# RELEASED (INBIT CHANGES TO 1).
#
# CALLING SEQUENCE:  BY IMUMON WHEN IMU CAGE BIT CHANGES.
#
# JOBS OR TASKS INITIATED:  NONE.
#
# SUBROUTINES CALLED:  CAGESUB.
#
# ERASABLE INITIALZATION:  FRESH START AND RESTART SET BIT 11 OF IMODES30 TO 1.
#
# ALARMS: NONE.
#
# EXIT:  NXTIFAIL.
#
# OUTPUT:  ISS CAGED, COUNTERS ZEROED, PULSE TRAINS TERMINATED AND NO ATT LAMP LIT.

IMUCAGE         CCS     A               # NO ACTION IF GOING OFF.
                TCF     ISSZERO
                CS      OCT77000        # TERMINATE ICDU, OPTICS, GYRO PULSE TRAINS
                EXTEND
                WAND    CHAN14

                CS      OCT272          # KNOCK DOWN TVC ENABLE, IMU ERROR COUNTER
                EXTEND                  #   ENABLE, ZERO ICDU, COARSE ALIGN
                WAND    CHAN12          #   ENABLE, OPTICS ERR CNTR ENABLE

                CS      BIT13           # TURN OFF ENGINE
                EXTEND
                WAND    DSALMOUT

                TC      CAGESUB1

                TC      IBNKCALL        # KNOCK DOWN TRACK, REFSMMAT, DRIFT FLAGS
                CADR    RNDREFDR

                CS      ZERO            # ZERO COMMAND OUT-COUNTERS
                TS      CDUXCMD
                TS      CDUYCMD
                TS      CDUZCMD
```

```
TS      GYROCMD

CS      OCT740          # HAVING WAITED AT LEAST 27 MCT FROM
EXTEND                  # GYRO PULSE TRAIN TERMINATION, WE CAN
WAND    CHAN14          # DE-SELECT THE GYROS.
```

Uses A 80, CDUXCMD 80, CDUYCMD 80, CDUZCMD 85, CHAN12 87, CHAN14 87, CNTR 200, COMMAND 169, DSALMOUT 87, GYROCMD 80, IMODES30 163, REFSMMAT 172, RESTART 57, and TC 169.

273 ⟨*Page CM0153* 273⟩≡ (250 2812)

```
TCF     NXTIFAIL
```

274 ⟨*Page CM0154* 274⟩≡ (250 2812)

```
# PROGRAM NAME:  IMUOP.
#
# FUNCTIONAL DESCRIPTION:  THIS PROGRAM PROCESSES CHANGES IN THE ISS OPERATE DISCRETE
# IF THE INBIT CHANGES TO 0, INDICATING ISS ON, IMUOP GENERALLY SETS BIT 7 OF IMODES3
# INITIALIZATION VIA TNONTEST.  AN EXCEPTION IS DURING A FAILED ISS DELAY DURING WHIC
# TO 1 AND NO FURTHER INITIALIZATION IS REQUIRED.  WHEN THE INBIT CHANGES TO 1, INDIC
# TESTED TO SEE IF ANY PROGRAM WAS USING THE ISS.  IF SO, PROGRAM ALARM 00214 IS ISSU
#
# CALLING SEQUENCE:  BY IMUMON WHEN BIT 9 OF CHANNEL 30 CHANGES.
#
# JOBS OR TASKS INITIATED:  NONE.
#
# SUBROUTINES CALLED:  ALARM, IF ISS IS TURNED OFF WHILE IN USE.
#
# ERASABLE INITIALIZATION:  ON FRESH START AND RESTART, BIT 9 OF IMODES30 IS SET TO 1
# LAMP IS ON, IN WHICH CASE IT IS SET TO 0.  THIS PREVENTS ICDU ZERO BY TNONTEST WITH
#
# ALARMS:  PROGRAM ALARM 00214 IF THE ISS IS TURNED OFF WHILE IN USE.
#
# EXIT:  NXTIFAIL.
#
# OUTPUT:  ISS INITIALIZATION REQUEST (IMODES30 BIT 7) OR PROGRAM ALARM 00214.

IMUOP           EXTEND                          # IF OPERATE JUST ON, WAIT 1 SAMPLE.
                BZF     IMUOP2

                CS      IMODES33                # DISABLE DAP
                MASK    BIT6
                ADS     IMODES33

                TC      IBNKCALL                # KNOCK DOWN TRACK, REFSMMAT, DRIFT B
                CADR    RNDREFDR

                CS      BITS7&8                 # KNOCK DOWN RENDEZVOUS, IMUUSE FLAGS
                MASK    STATE
                XCH     STATE                   # IF GOING OFF, ALARM IF PROG USING I
                COM
                MASK    IMUSEFLG
                CCS     A
                TCF     NXTIFAIL

                TC      ALARM
                OCT     214
                TCF     NXTIFAIL
```

```
IMUOP2          CAF     BIT2                    # SEE IF FAILED ISS TURN-ON SEQ IN PROG.
                MASK    IMODES30
                CCS     A
                TCF     NXTIFAIL                # IF SO, DON'T PROCESS UNTIL PRESENT 90
                TCF     ITURNON2                # SECONDS EXPIRES
```

Uses A 80, IMODES30 163, IMODES33 163, IT 185, REFSMMAT 172, RESTART 57, STATE 138, and TC 169.

276 ⟨*Page CM0155* 276⟩≡ (250 2812)

```
# PROGRAM NAME:  PIPFAIL
#
# FUNCTIONAL DESCRIPTION:  THIS PROGRAM PROCESSES CHANGES OF BIT 13 OF CHANNEL 33, PI
# IMODES30 TO AGREE.  IT CALLS SETISSW IN CASE A PIPA FAIL NECESSITATES AN ISS WARNIN
# BIT 1 = 1, AND A PIPA FAIL IS PRESENT AND THE ISS NOT BEING INITIALIZED, PROGRAM AL
#
# CALLING SEQUENCE:  BY C33TEST ON CHANGES OF CHANNEL 33 BIT 13.
#
# JOBS OR TASKS INITIATED:  NONE.
#
# SUBROUTINES CALLED:  1) SETISSW, AND 2) ALARM (SEE FUNCTIONAL DESCRIPTION).
#
# ERASABLE INITIALIZATION:  SEE IMUMON FOR INITIALIZATION OF IMODES30.  THE RELEVANT
#
# ALARMS:  PROGRAM ALARM 00212 IF PIPA FAIL IS PRESENT BUT NEITHER ISS WARNING IS TO
# BEING INITIALIZED.
#
# EXIT:  NXTFL33.
#
# OUTPUT:  PROGRAM ALARM 00212 AND ISS WARNING MAINTENANCE.

PIPFAIL         CCS     A                       # SET BIT10 IN IMODES30 SO ALL ISS WA
                CAF     BIT10                   # INFO IS IN ONE REGISTER.
                XCH     IMODES30
                MASK    -BIT10
                ADS     IMODES30

                TC      SETISSW

                CS      IMODES30                # IF PIP FAIL DOESN'T LIGHT ISS WARNI
                MASK    BIT1                    # A PROGRAM ALARM IF IMU OPERATING BU
                CCS     A                       # CAGED OR BEING TURNED ON.
                TCF     NXTFL33

                CA      IMODES30
                MASK    OCT1720
                CCS     A
                TCF     NXTFL33                 # ABOVE CONDITION NOT MET.

                TC      ALARM
                OCT     212
                TCF     NXTFL33
```

Uses A 80, I 206, IMODES30 163, IT 185, and TC 169.

277 ⟨*Page CM0156* 277⟩≡ (250 2812)

```
# PROGRAM NAMES:  DNTMFAST, UPTMFAST
#
# FUNCTIONAL DESCRIPTION:  THESE PROGRAMS PROCESS CHANGES OF BITS 12 AND 11 OF CHANNEL 33.  IF
# 0, A PROGRAM ALARM IS ISSUED.  THE ALARMS ARE:
#
#       BIT     ALARM   CAUSE
#       ---     -----   -----
#        12     01105   DOWNLINK TOO FAST
#        11     01106   UPLINK TOO FAST
#
# CALLING SEQUENCE:  BY C33TEST ON A BIT CHANGE.
#
# SUBROUTINES CALLED:  ALARM, IF A BIT CHANGES TO A 0.
#
# ERASABLE INITIALIZATION:  FRESH START OR RESTART, BITS 12 AND 11 OF IMODES33 ARE SET TO 1.
#
# ALARMS:  SEE FUNCTIONAL DESCRIPTION.
#
# EXIT:  NXTFL33.
#
# OUTPUT:  PROGRAM ALARM ON A BIT CHANGE TO 0.

DNTMFAST        CCS     A                       # DO PROG ALARM IF TM TOO FAST.
                TCF     NXTFL33

                TC      ALARM
                OCT     1105
                TCF     NXTFL33

UPTMFAST        CCS     A                       # SAME AS DNLINK TOO FAST WITH DIFFERENT
                TCF     NXTFL33                 # ALARM CODE.

                TC      ALARM
                OCT     1106
                TCF     NXTFL33
```

Uses A 80, CODE 140, IMODES33 163, RESTART 57, TC 169, and TM 219.

278 ⟨*Page CM0157* 278⟩≡ (250 2812)

```
# PROGRAM NAME:  SETISSW
#
# FUNCTIONAL DESCRIPTION:  THIS PROGRAM TURNS THE ISS WARNING LAMP ON AND OFF (CHANNE
# 0 FOR OFF) DEPENDING ON THE STATUS OF IMODES30 BITS 13 (IMU FAIL) AND 4 (INHIBIT IN
# 3 (INHIBIT ICDU FAIL), AND 10 (PIPA FAIL) AND 1 (INHIBIT PIPA FAIL).  THE LAMP IS I
# PROGRESS.
#
# CALLING SEQUENCE:  CALLED BY IMUMON ON CHANGES TO IMU FAIL AND ICDU FAIL.  CALLED B
# REMOVAL OF THE FAIL INHIBITS.  CALLED BY PIPFAIL WHEN THE PIPA FAIL DISCRETE CHANGE
# SINCE THE PIPA FAIL PROGRAM ALARM MAY NECESSITATE AN ISS WARNING, AND LIKEWISE BY P
# AND IT IS CALLED BY IMUZERO3 AND ISSUP AFTER THE FAIL INHIBITS HAVE BEEN REMOVED.
#
# JOBS OR TASKS INITIATED:  NONE.
#
# SUBROUTINES CALLED:  NONE.
#
# ERASABLE INITIALIZATION:
#
#       1) IMODES30 -- SEE IMUMON.
#       2) IMODES33 BIT 1 = 0 (LAMP TEST NOT IN PROGRESS).
#
# ALARMS:  ISS WARNING.
#
# EXIT: VIA Q.
#
# OUTPUT: ISS WARNING LAMP SET PROPERLY.

SETISSW         CAF     OCT15                   # SET ISS WARNING USING THE FAIL BITS
                MASK    IMODES30                # BITS 13, 12, AND 10 OF IMODES30 AND
                EXTEND                          # FAILURE INHIBIT BITS IN POSITIONS
                MP      BIT10                   # 4, 3, AND 1.
                CA      IMODES30
                EXTEND
                ROR     LCHAN                   # 0 INDICATES FAILURE
                COM
                MASK    OCT15000
                CCS     A
                TCF     ISSWON                  # FAILURE.

ISSWOFF         CAF     BIT1                    # DON'T TURN OFF ISS WARNING IF LAMP
                MASK    IMODES33                # IN PROGRESS.
                CCS     A
                TC      Q

                CS      BIT1
```

```
                EXTEND
                WAND    DSALMOUT                # TURN OFF ISS WARNING.
                TC      Q

ISSWON          EXTEND
```

Uses A 80, DSALMOUT 87, IMODES30 163, IMODES33 163, IT 185, LCHAN 87, Q 80, and TC 169.

279 ⟨*Page CM0158* 279⟩≡ (250 2812)

```
                QXCH    ITEMP6
                TC      VARALARM                # TELL EVERYONE WHAT CAUSED THE ISS WARNING
                CAF     BIT1
                EXTEND
                WOR     DSALMOUT                # TURN ON ISS WARNING
                TC      ITEMP6

CAGESUB         CS      BIT15+6                 # SET OUTBITS + INTERNAL FLAGS FOR
                EXTEND                          # SYSTEM TURN-ON OR CAGE.  DISABLE THE
                WAND    CHAN12                  # ERROR COUNTER AND REMOVE THE IMU DELAY COMP.
                CAF     BITS4&5                 # SEND ZERO AND COARSE.
                EXTEND
                WOR     CHAN12

CAGESUB1        CS      DSPTAB +11D             # TURN ON NO ATT LAMP
                MASK    OC40010
                ADS     DSPTAB +11D

CAGESUB2        CS      IMODES30                # SET FLAGS TO INDICATE CAGING OR TURN-ON
                MASK    OCT75                   # AND INHIBIT ALL ISS WARNING INFO
                ADS     IMODES30

                CS      IMODES33                # DISABLE DAP AUTO AND HOLD MODES
                MASK    BIT6
                ADS     IMODES33

                TC      Q

IMUFAIL         EQUALS  SETISSW
ICDUFAIL        EQUALS  SETISSW
```

Uses CHAN12 87, DSALMOUT 87, DSPTAB 154, IMODES30 163, IMODES33 163, ITEMP6 138, Q 80, and TC 169.

280 ⟨*Page CM0159* 280⟩≡ (250 2812)

```
# JUMP TABLES AND CONSTANTS.

IFAILJMP        TCF     ITURNON                 # CHANNEL 30 DISPATCH.
                TCF     IMUFAIL
                TCF     ICDUFAIL
                TCF     IMUCAGE
30RDMSK         OCT     76400                   # (BIT 10 NOT SAMPLED HERE).
                TCF     IMUOP

C33JMP          TCF     PIPFAIL                 # CHANNEL 33 DISPATCH.
                TCF     DNTMFAST
                TCF     UPTMFAST

# SUBROUTINE TO SKIP IF LAMP TEST NOT IN PROGRESS.

LAMPTEST        CS      IMODES33                # BIT 1 OF IMODES33 = 1 IF LAMP TEST
                MASK    BIT1                    # PROGRESS.
                TCF     ZOPFIN3

33RDMSK         EQUALS  PRIO16
OC40010         OCT     40010
OCT54           OCT     54
OCT75           OCT     75
OCT272          OCT     00272
BITS7&8         OCT     300
OCT1720         OCT     1720
OCT740          OCT     00740
OCT15000        EQUALS  PRIO15
OCT77000        OCT     77000
-BIT10          OCT     -1000

90SECS          DEC     9000
120MS           =       OCT14                   # (DEC12)
GLOCKOK         EQUALS  RESUME
```

Uses IMODES33 163.

281 ⟨*Page CM0160* 281⟩≡ (250 2812)

```
# OPTICS MONITORING AND ZERO ROUTINES
OPTMON          CA      OPTMODES                # MONITOR OPTICS INBITS IN CHAN 30 AND 33
                EXTEND
                RXOR    CHAN30                  # LOOK FOR OCDU FAIL BIT CHANGE
                MASK    BIT7
                TS      RUPTREG1                # STORE CHANGE BIT
                CCS     A
                TC      OCDUFTST                # PROCESS OCDUFAIL BIT CHANGE

33OPTMON        CCS     OPTIND                  # BYPASS IF TVC TAKEOVER
                TCF     +4
                TCF     +3
                TCF     +2
                TCF     RESUME

                CA      OPTMODES                # LOOK FOR OPTICS MODE SWITCH CHANGE
                EXTEND
                RXOR    CHAN33
                MASK    OCTHIRTY
                ADS     RUPTREG1                # STORE INBIT CHANGES
                LXCH    OPTMODES
                EXTEND
                RXOR    LCHAN
                TS      OPTMODES                # UPDATE OPTMODES TO SHOW BIT CHANGES

                COM                             # SAMPLE CURRENT SWITCH SETTING
                MASK    OCTHIRTY
                EXTEND
                BZF     SETSAMP                 # MANUAL-SET ZERO IN SWSAMPLE

                MASK    BIT5                    # SEE IF CSC
                CCS     A
                TC      +2                      # CSC-SET SWSAMPLE POS
                CAF     NEGONE                  # ZOPTICS-SET SWSAMPLE (-1)
SETSAMP         TS      SWSAMPLE                # CURRENT OPTICS SWITCH SETTING

PROCESSW        CCS     DESOPMOD                # BRANCH ON PREVIOUS SETTING
                TC      CSCDES                  # CSC
                TC      MANUDES                 # MANUAL
                TC      ZOPTDES                 # ZERO OPTICS
```

Uses `A` 80, `CHAN` 191, `CHAN30` 87, `CHAN33` 87, `DESOPMOD` 163, `LCHAN` 87, `MODE` 145, `OPTIND` 161, `OPTMODES` 163, `RUPTREG1` 138, `SWSAMPLE` 163, and `TC` 169.

282 ⟨*Page CM0161* 282⟩≡ (250 2812)

```
ZOPTDES         CCS     SWSAMPLE                # IS SWITCH STILL AT ZOPTICS
                TC      ZTOCSC                  # NOW AT CSC
                TC      ZTOMAN                  # MANUAL
                TC      ZOPFIN1                 # ZOPTICS-SEE IF ZOPT PROCESSING
                TC      SETDESMD                # ZOPT NOT PROCESSING-NO ACTION

                CCS     ZOPTCNT                 # ZOPT PROCESSING-CHECK COUNTER
                TC      SETCNT                  # 32 SAMPLE NOT FINISHED-SET COUNTER
                TC      SETZOEND                # 32 SAMPLE WAIT COMPLETED-SET UP ZOP

ZTOMAN          TC      ZOPFIN1                 # ZOP TO MANUAL-IS ZOPT DONE
                TC      SETDESMD                # YES-NORMAL EXIT

ZOPALARM        TC      ALARM                   # ALARM-SWITCHED ALTERED WHILE ZOPTIC
                OCT     00116
                CAF     OCT13                   # PROCESSING-SET RETURN OPTION
                TS      WTOPTION

                TC      CANZOPT                 # CANCEL ZOPT

                TC      SETDESMD

ZTOCSC          TC      ZOPFIN1                 # SEE IF ZOPT PROCESSING
                TC      MANTOCSC +3             # NO-CHECK RETURN TO COARS OPT
                TC      ALARM                   # ZOPT PROCESSING-ALARM
                OCT     00116
                TC      CANZOPT                 # CANCEL ZOPT
                TC      MANTOCSC                # ZERO CNT-LOOK FOR COARS OPT RETURN

COARSLOK        CAF     BIT9                    # IF COARS OPT SINCE FSTART GO TO L+2
                TCF     ZOPFIN2                 # IF NOT GO TO L+1
ZOPFIN1         CAF     BIT1                    # SEE IF END ZOPT TASK WORKING  // La
                MASK    OPTMODES
                CCS     A
                TC      RESUME                  # ZOPT TASK WORKING-WAIT ONE SAMPLE P

                CAF     BIT3                    # TEST IF ZOPTICS PROCESSING
ZOPFIN2         MASK    OPTMODES                # RETURNS TO L+1 PROCESSING AND
ZOPFIN3         CCS     A
                INCR    Q                       # L+2 IF NOT
                TC      Q

CANZOPT         CS      SIX                     # CANCEL ZERO OPTICS
                MASK    OPTMODES                # ZERO ZOPT PROCESSING BIT-ENABLE OCD
                TS      OPTMODES
```

```
CS      BIT1                    # MAKE SURE ZERO OCDU IS OFF
EXTEND
WAND    CHAN12
TC      Q
```

Uses A 80, CHAN12 87, L 80, OPTMODES 163, Q 80, SWSAMPLE 163, TC 169, WTOPTION 163, and ZOPTCNT 163.

284 ⟨*Page CM0162* 284⟩≡ (250 2812)

```
MANUDES         CCS     SWSAMPLE                # SEE IF SWITCH STILL IN MANUAL MODE
                TC      MANTOCSC                # NOW AT CSC
                TC      MANTOMAN                # STILL MANUAL
                CCS     WTOPTION                # ZOPTICS-LOOK AT ZOPTICS RETURN OPTI
                TC      +2                      # 5 SEC RETURN GOOD-CONTINUE ZOPTICS
                TC      OPTZERO                 # ZOPTICS MUST START ANEW

                TC      INITZOPT                # SHOW ZERO OPTICS PROCESSING
                TC      SETDESMD                # NORMAL EXIT

MANTOMAN        CCS     WTOPTION                # DECREMENT RETURN OPTION TIME
                TS      WTOPTION
                TC      SETDESMD

MANTOCSC        CAF     ZERO                    # CANCEL ZOPT RETURN OPTION IF SET
                TS      WTOPTION
                TS      ZOPTCNT

                TC      COARSLOK                # CHECK FOR COARS OPT RETURN
                TC      SETDESMD                # NO COARS TASK-NO ACTION

                CAF     ONE                     # SET COARS OPT WORKING
                TS      OPTIND
                CAF     BIT2                    # ENABLE OPTICS CDU ERROR CNTS
                EXTEND
                WOR     CHAN12

                TC      SETDESMD

CSCDES          CCS     SWSAMPLE                # SEE IF SWITCH STILL AT CSC
                TC      SETDESMD                # STILL AT CSC
                TC      CSCTOMAN                # MANUAL
CSCTOZOP        CAF     OCT40                   # ZOPTICS-INITIALIZE FOR ZOPT
                TS      ZOPTCNT
                TC      INITZOPT

CSCTOMAN        CCS     OPTIND                  # SEE IF COARS WORKING
                TC      CANCOARS                # COARS WORKING-SWITCH NOT CSC-KILL C
                TC      CANCOARS
                TC      +1                      # NO COARS-NORMAL EXIT
                TC      SETDESMD
```

Uses CHAN12 87, MODE 145, OPTIND 161, SWSAMPLE 163, TC 169, WTOPTION 163, and ZOPTCNT 163.

285 ⟨*Page CM0163* 285⟩≡ (250 2812)

```
CANCOARS        CA      NEGONE
                TS      OPTIND          # SET OPTIND (-1) TO SHOW NOT WORKING
                CS      BIT2            # DISABLE OCDU ERR CNTS
                EXTEND
                WAND    CHAN12
                CS      OPTMODES        # SET RETURN-TO-COARS BIT
                MASK    BIT9
                ADS     OPTMODES

                TC      SETDESMD
OPTZERO         TC      INITZOPT        # INITIALIZE ZERO OPTICS

                CA      OCT40           # SET UP 32 SAMPLE WAIT
SETCNT          TS      ZOPTCNT
SETDESMD        CA      SWSAMPLE        # SET CURRENT SWITCH INDICATION-RESUME
                TS      DESOPMOD
                TC      RESUME

SETZOEND        CAF     BIT1            # SEND ZERO OPTICS CDU
                EXTEND
                WOR     CHAN12
                CA      200MS           # HOLD ZERO CDU FOR 200 MS
                TC      WAITLIST
                EBANK=  OPTMODES
                2CADR   ENDZOPT

                CS      OPTMODES        # SHOW ZOPTICS TASK WORKING
                MASK    BIT1
                ADS     OPTMODES

                TC      SETDESMD

ENDZOPT         TC      ZEROPCDU        # ZERO OCDU COUNTERS
                CS      BIT1            # TURN OFF ZERO OCDU
                EXTEND
                WAND    CHAN12
                CAF     200MS           # DELAY 200MS FOR CDUS TO RESYNCHRONIZE
                TC      VARDELAY

                CS      OPTMODES        # SHOW ZOPTICS SINCE LAST FRESH START
                MASK    BIT10           #       OR RESTART
                ADS     OPTMODES

                CS      SEVEN           # ENABLE OCDUFAIL-SHOW OPTICS COMPLETE
                MASK    OPTMODES
```

```
                TS      OPTMODES

                TC      OCDUFTST                # CHECK OCDU FAIL BIT AFTER ENABLE.
```

Uses CDUS 80, CHAN12 87, DESOPMOD 163, EBANK 80, OPTIND 161, OPTMODES 163, RESTART 57, SWSAMPLE 163, TC 169, and ZOPTCNT 163.

286 ⟨*Page CM0164* 286⟩≡ (250 2812)

```
                TC      TASKOVER

ZEROPCDU        CAF     ZERO
                TS      CDUS                    # ZERO IN CDUS, -20 IN CDUT
                TS      ZONE                    # INITIALIZE SHAFT MONITOR ZONE
                CS      20DEGS
                TS      CDUT
                TC      Q

INITZOPT        CAF     ZERO                    # INITIALIZE ZOPTICS-INHIBIT OCDUFAIL
                TS      WTOPTION                # AND SHOW OPTICS PROCESSING
                CS      OPTMODES                # SET ZERO OPTICS PROCESSING
                MASK    SIX                     #       OPTICS CDU FAIL INHIBITED
                ADS     OPTMODES
                TC      Q
```

Uses CDUS 80, CDUT 80, OPTMODES 163, Q 80, TC 169, WTOPTION 163, and ZONE 163.

287 ⟨*Page CM0165* 287⟩≡ (250 2812)

```
OCDUFTST        CAF     BIT7                    # SEE IF OCDUFAIL ON OR OFF
                EXTEND
                RAND    CHAN30
                CCS     A
                TCF     OPFAILOF                # OCDUFAIL LIGHT OFF

                CAF     BIT2                    # OCDUFAIL LIGHT ON UNLESS INHIBITED
                MASK    OPTMODES
                CCS     A
                TC      Q                       # OCDUFAIL INHIBITED

OPFAILON        CAF     BIT8                    # ON BIT
                AD      DSPTAB  +11D
                MASK    BIT8
SETOFF          EXTEND
                BZF     TCQ                     # NO CHANGE

                TS      L
                CA      DSPTAB  +11D
                EXTEND
                RXOR    LCHAN
                MASK    POSMAX
                AD      BIT15                   # SHOW ACTION WANTED
                TS      DSPTAB  +11D
                TC      Q

OPFAILOF        CAF     BIT1                    # DON'T TURN OFF IF LAMP TEST
                MASK    IMODES33
                CCS     A
                TC      Q                       # LAMP TEST IN PROGRESS

                CAF     BIT8                    # TURN OFF OCDUFAIL LIGHT
                MASK    DSPTAB  +11D
                TCF     SETOFF

OCT13           =       ELEVEN
OCTHIRTY        EQUALS  BITS4&5
20DEGS          DEC     7199
OCT40           EQUALS  BIT6
200MS           EQUALS  OCT24
```

Uses `A` 80, `CHAN30` 87, `DSPTAB` 154, `IMODES33` 163, `L` 80, `LCHAN` 87, `OPTMODES` 163, `Q` 80, and `TC` 169.

288 ⟨*Page CM0166* 288⟩≡ (250 2812)

```
# OPTICS CDU DRIVING PROGRAM

                BANK    10
                SETLOC  OPTDRV
                BANK
                COUNT*  $$/SXT

# SHAFT STOP MONITOR-ZONE UPDATE

OPTDRIVE        CA      CDUS                    # GRAB OPTIC SHAFT CDU
                TS      L
                CCS     A                       # GET ABS(CDUS)
                AD      13,14,15
                TCF     +2                      # ABS(CDUS) - 45 DEG
                TCF     -2
                EXTEND
                BZMF    OZONE                   # LESS THAN 45 DEG-SET ZONE 0
                CA      ZONE                    # IF ZONE ZERO, CHANGE TO + OR - OTHE
                EXTEND                          # DON'T MESS WITH ZONE
                BZF     +2
                TCF     CONTDRVE                # JUST CONTINUE
                XCH     L                       # GREATER THAN 45 DEG-SET ZONE TO SIG
                TCF     OZONE   +1
OZONE           CAF     ZERO                    # ABS(CDUS) LESS THAN 90 DEG-ZONE ZER
                TS      ZONE
                COUNT*  $$/T4RUPT
CONTDRVE        CCS     OPTIND
                TC      +4                      # WORK COARS OPTICS
                TC      +3                      # WORK COARS OPTICS
                TC      RESUME                  # NO OPT
                TC      RESUME                  # NO OPT

                CA      SWSAMPLE                # SEE IF SWITCH AT CMC
                EXTEND
                BZMF    RESUME                  # ZERO (-1)     MANUAL (+0)

                CAF     BIT10                   # SEE IF OCDUS ZEROED SINCE LAST FSTA
                MASK    OPTMODES
                CCS     A
                TC      +3
                TC      ALARM                   # OPTICS NOT ZEROED
                OCT     00120

                CA      BIT2                    # SEE IF ERR CNTS ENABLED
                EXTEND
```

```
RAND    CHAN12
EXTEND
BZF     SETBIT                  # CNTS NOT ENABLED-DO IT AND RESUME

CAF     ONE                     # INITIALIZE OPTIND
```

Uses A 80, CDUS 80, CHAN12 87, COUNT 142, IT 185, L 80, OPTDRV 59, OPTIND 161, OPTMODES 163, SWSAMPLE 163, TC 169, and ZONE 163.

290 ⟨*Page CM0167* 290⟩≡ (250 2812)

```
OPT2            TS      OPTIND
                EXTEND
                BZF     TRUNCMD                 # CHECK TRUNION COMMAND

GETOPCMD        INDEX   OPTIND
                CA      DESOPTT                 # PICK UP DESIRED OPT ANGLE
                EXTEND
                INDEX   OPTIND
                MSU     CDUT                    # GET DIFFERENCE
                EXTEND
                MP      BIT13
                XCH     L
                DOUBLE
                TS      ITEMP1
                TCF     +2                      # NO OVFL

                ADS     L                       # WITH OVFL
STORCMD         INDEX   OPTIND
                LXCH    COMMANDO                # STORE COMMAND
                CCS     OPTIND
                TCF     OPT2                    # GET NEXT COMMAND

                TS      ITEMP1                  # INITIALIZE SEND INDICATOR TO ZERO
                COUNT*  $$/SXT

# SHAFT STOP AVOIDANCE

                CCS     CDUS                    # IF CDUS GREATER THAN + OR - 90 DEG
                AD      NEG1/2                  # FOR POSSIBLE STOP PROBLEM
                TCF     +2
                TCF     -2
                EXTEND
                BZMF    CMDSETUP                # CDU LESS THAN 90 DEG, NO PROBLEMS

                CA      ZONE
                EXTEND
                BZF     CMDSETUP                # ZONE=3, NORMAL COMMAND
                MASK    BIT15                   # GRAB SIGN OF ZONE
                TS      L
                CA      COMMANDO +1
                MASK    BIT15                   # GRAB SIGN OF SHAFT COMMAND
                EXTEND
                RXOR    LCHAN
                CCS     A
                TCF     CMDSETUP                # SIGN ZONE NOT EQUAL TO SIGN COMMAND
```

```
CCS     DESOPTS                 # SEE IF DESOPTS BETWEEN -90 AND +90
AD      NEG1/2
TCF     +2                      # ABS(DESOPTS) - 90 DEG
TCF     -2
EXTEND
```

Uses A 80, CDUS 80, CDUT 80, COMMAND 169, COMMANDO 161, COUNT 142, DESOPTS 159, DESOPTT 159, ITEMP1 138, L 80, LCHAN 87, OPTIND 161, TRUNION 190, and ZONE 163.

292 ⟨*Page CM0168* 292⟩≡ (250 2812)

```
                BZMF    +2                  # DESOPTS IN FIRST OR FOURTH QUAD
                TCF     CMDSETUP
                CS      COMMANDO +1         # REVERSE REGULAR COMMAND
                TS      COMMANDO +1

                COUNT*  $$/T4RPT

CMDSETUP        CAF     ONE                 # SET OPTIND
                TS      OPTIND
                INDEX   A
                CCS     COMMANDO            # GET SIGN OF COMMAND
                TC      POSOPCMD
                TC      NEXTOPT +1          # ZERO COMMAND-SKIP SEND INDICATOR
                TC      NEGOPCMD
                TC      NEXTOPT +1          # ZERO COMMAND

TRUNCMD         CS      CDUT                # IF COMMAND GREATER THAN 45 DEG-COMM
                AD      DESOPTT             # 45 DEG
                TS      Q
                TC      GETOPCMD            # LESS THAN 45 DEG-NORMAL OPERATION

                CCS     A                   # GREATER THAN 45 DEG-USE OPSMAX WITH
                CA      POSMAX              # CORRECT SIGN
                TC      +2
                CS      POSMAX
                TS      L
                TC      STORCMD
POSOPCMD        AD      MAXPLS1
                EXTEND
                BZMF    DELOPCMD            # COMMAND LESS THAN MAX PULSE
                CS      MAXPLS              # GREATER THAN MAX PULSE-USE MAX PULS

NEXTOPT         INCR    ITEMP1              # SET SEND INDICATOR
                AD      NEGO                # MAKE SURE ZERO COMMAND IS -ZERO
                INDEX   OPTIND
                TS      CDUTCMD             # STORE PULSE IN SEND REG

                CCS     OPTIND
                TC      CMDSETUP +1         # GET NEXT OPT

                CCS     ITEMP1              # ARE ANY PULSES TO GO
                TCF     SENDOCMD            # YES-SEND EM
                TC      RESUME              # NO

NEGOPCMD        AD      MAXPLS1
```

```
                EXTEND
                BZMF    DELOPCMD                # LESS THAN MAX PULSE
                CA      MAXPLS                  # MAX PULSES
                TCF     NEXTOPT
```

Uses A 80, CDUT 80, CDUTCMD 85, COMMAND 169, COMMANDO 161, COUNT 142, DESOPTS 159, DESOPTT 159, ITEMP1 138, L 80, OPTIND 161, Q 80, and TC 169.

293a ⟨*Page CM0169* 293a⟩≡ (250 2812)

```
DELOPCMD        INDEX   OPTIND
                XCH     COMMANDO                # SET UP SMALL COMMAND
                TCF     NEXTOPT

SENDOCMD        CAF     11,12                   # SEND OCDU DRIVE COMMANDS
                EXTEND
                WOR     CHAN14
                TC      RESUME

SETBIT          CAF     BIT2                    # ENABLE OCDU ERR CNTS
                EXTEND
                WOR     CHAN12
                TC      RESUME                  # START COARS NEXT TIME AROUND

MAXPLS          DEC     -165                    # WAS -80
MAXPLS1         DEC     -164                    # WAS -79
11,12           EQUALS  PRIO6
```

Uses CHAN12 87, CHAN14 87, COMMAND 169, COMMANDO 161, OPTIND 161, and TC 169.

3.3.3 downlink lists

293b ⟨*downlink lists* 293b⟩≡ (245b)

⟨*Page CM0170* 294⟩
⟨*Page CM0171* 295⟩
⟨*Page CM0172* 297⟩
⟨*Page CM0173* 298⟩
⟨*Page CM0174* 299⟩
⟨*Page CM0175* 300⟩
⟨*Page CM0176* 301⟩
⟨*Page CM0177* 302⟩
⟨*Page CM0178* 303⟩
⟨*Page CM0179* 304⟩
⟨*Page CM0180* 305⟩

294 ⟨*Page CM0170* 294⟩≡ (293b 2676)

```
                BANK    22
                SETLOC  DOWNTELM
                BANK

                EBANK=  DNTMBUFF

# SPECIAL DOWNLINK OP CODES
#       OP CODE         ADDRESS (EXAMPLE)       SENDS...                BIT 15
#       -------         -----------------       --------                ------
#       1DNADR          TIME2                   (2 AGC WDS)             0
#       2DNADR          TEPHEM                  (4 AGC WDS)             0
#       3DNADR          VGBODY                  (6 AGC WDS)             0
#       4DNADR          STATE                   (8 AGC WDS)             0
#       5DNADR          UPBUFF                  (10 AGC WDS)            0
#       6DNADR          DSPTAB                  (12 AGC WDS)            0
#       DNCHAN          30                      CHANNELS                0
#
#       DNPTR           NEXTLIST                POINTS TO NEXT          0
#                                               LIST
#
# DOWNLIST FORMAT DEFINITIONS AND RULES --
# 1. END OF A LIST = -XDNADR (X = 1 TO 6), -DNPTR, OR -DNCHAN.
# 2. SNAPSHOT SUBLIST = LIST WHICH STARTS WITH A -1DNADR.
# 3. SNAPSHOT SUBLIST CAN ONLY CONTAIN 1DNADRS.
# 4. TIME2 1DNADR MUST BE LOCATED IN THE CONTROL LIST OF A DOWNLIST.
# 5. ERASABLE DOWN TELEMETRY WORDS SHOULD BE GROUPED IN SEQUENTIAL
#    LOCATIONS AS MUCH AS POSSIBLE TO SAVE STORAGE USED BY DOWNLINK LISTS.
# 6. THE DOWNLINK LISTS (INCLUDING SUBLISTS) ARE ORGANIZED SUCH THAT THE ITEMS LISTED
#    SENT FIRST.  EXCEPTION--- SNAPSHOT SUBLISTS.  IN THE SNAPSHOT SUBLISTS THE DATA
#    11 1DNADRS IS PRESERVED (IN ORDER) IN DNTMBUFF AND SENT BY THE NEXT 11 DOWNRUPTS
#    LIST IS SENT IMMEDIATELY.

                COUNT   05/DLIST
ERASZERO        EQUALS  7
SPARE           EQUALS  ERASZERO                        # USE SPARE TO INDICATE AVAIL
LOWIDCOD        OCT     77340                           # LOW ID CODE

NOMDNLST        EQUALS  CMCSTADL                        # FRESH START AND POST P27 DO
UPDNLIST        EQUALS  CMENTRDL                        # UPDATE PROGRAM (P27) DOWNLI
```

Uses A 80, CODE 140, COUNT 142, DNTMBUFF 148, DOWNTELM 59, DSPTAB 154, EBANK 80, FBANK 80, SAVE 191, STATE 138, TEPHEM 172, TIME2 80, UPBUFF 145, and VGBODY 238.

295 ⟨*Page CM0171* 295⟩≡ (293b 2676)

```
# CSM POWERED FLIGHT DOWNLIST
#
# -------------------- CONTROL LIST -------------------------

CMPOWEDL        EQUALS
                DNPTR   CMPOWE01                        # COLLECT SNAPSHOT
                6DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMPOWE02                        # COLLECT SECOND SNAPSHOT
                4DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMPOWE03                        # COMMON DATA
                1DNADR  TIG                             # TIG,+1
                1DNADR  DELLT4                          # DELLT4,+1
                3DNADR  RTARG                           # RTARG,+1,+2,...+5
                1DNADR  TGO                             # TGO,+1
                1DNADR  PIPTIME1                        # PIPTIME1,+1
                3DNADR  DELV                            # DELV,+1,...,+4,+5
                1DNADR  PACTOFF                         # PACTOFF,YACTOFF
                1DNADR  PCMD                            # PCMD,YCMD
                1DNADR  CSTEER                          # CSTEER,+1
                3DNADR  DELVEET1                        # CSI DELTA VELOCITY COMPONENTS   (31-3
                6DNADR  REFSMMAT                        # REFSMMAT,+1,...+10,+11
                DNPTR   CMPOWE04                        # COMMON DATA
                1DNADR  TIME2                           # TIME2,TIME1
                DNPTR   CMPOWE05                        # COMMON DATA
                6DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMPOWE02                        # COLLECT SNAPSHOT
                4DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMPOWE03                        #
                DNPTR   CMPOWE06                        # COMMON DATA
                1DNADR  ELEV                            # ELEV,+1
                1DNADR  CENTANG                         # CENTANG,+1
                1DNADR  DELTAR                          # DELTAR,+1
                1DNADR  STATE   +10D                    # FLAGWORDS 10 AND 11
                1DNADR  TEVENT                          # TEVENT,+1
                1DNADR  PCMD                            # PCMD,YCMD
                1DNADR  OPTMODES                        # OPTMODES,HOLDFLAG
                DNPTR   CMPOWE07                        # COMMON DATA
                3DNADR  VGTIG                           # VGTIG,+1,...,+4,+5
                -3DNADR DELVEET2                        # CDH DELTA VELOCITY COMPONENTS   (98-1

# --------------------- SUB LISTS ---------------------------

CMPOWE01        -1DNADR RN      +2                      # RN +2,+3                      SNAPSHO
                1DNADR  RN      +4                      # RN +4,+5
                1DNADR  VN                              # VN, +1
```

```
                1DNADR  VN      +2                      # VN +2,+3
                1DNADR  VN      +4                      # VN +4,+5
                1DNADR  PIPTIME                         # PIPTIME, +1
                -1DNADR RN                              # RN, +1

CMPOWEO2        -1DNADR CDUZ                            # CDUZ,CDUT
```

Uses CDUT 80, CDUZ 80, CSTEER 238, DELLT4 224, DELTAR 183, DELV 159, DELVEET1 197, DELVEET2 244, DNTMBUFF 148, HOLDFLAG 163, OPTMODES 163, PACTOFF 198, PCMD 204, PIPTIME 159, PIPTIME1 159, REFSMMAT 172, RN 159, RTARG 224, STATE 138, TEVENT 163, TGO 224, TIG 224, TIME1 80, TIME2 80, VGTIG 238, VN 159, YACTOFF 198, and YCMD 204.

297 ⟨*Page CM0172* 297⟩≡ (293b 2676)

```
                1DNADR  ADOT                    # ADOT,+1/OGARATE,+1
                1DNADR  ADOT    +2              # ADOT+2,+3/OMEGAB+2,+3
                1DNADR  ADOT    +4              # ADOT+4,+5/OMEGAB+4,+5
                -1DNADR CDUX                    # CDUX,CDUY

CMPOWE03        2DNADR  AK                      # AK,AK1,AK2,RCSFLAGS           COMMON
                -2DNADR THETADX                 # THETADX,THETADY,THETADZ,GARBAGE

CMPOWE04        5DNADR  STATE                   # FLAGWRD0 THRU FLAGWRD9        COMMON
                -6DNADR DSPTAB                  # DISPLAY TABLES

CMPOWE05        -1DNADR R-OTHER +2              # R-OTHER+2,+3                  SNAPSHO
                1DNADR  R-OTHER +4              # R-OTHER+4,+5
                1DNADR  V-OTHER                 # V-OTHER,+1
                1DNADR  V-OTHER +2              # V-OTHER+2,+3
                1DNADR  V-OTHER +4              # V-OTHER+4,+5
                1DNADR  T-OTHER                 # T-OTHER,+1
                -1DNADR R-OTHER                 # R-OTHER,+1

CMPOWE06        1DNADR  RSBBQ                   # RSBBQ,+1                      COMMON
                3DNADR  CADRFLSH                # CADRFLSH,+1,+2,FAILREG,+1,+2
                -2DNADR CDUS                    # CDUS,PIPAX,PIPAY,PIPAZ

CMPOWE07        1DNADR  LEMMASS                 # LEMMASS,CSMMASS               COMMON
                1DNADR  DAPDATR1                # DAPDATR1,DAPDATR2
                2DNADR  ERRORX                  # ERRORX,ERRORY,ERRORZ,GARBAGE
                3DNADR  WBODY                   # WBODY,...+5/OMEGAC,...+5
                2DNADR  REDOCTR                 # REDOCTR,THETAD,+1,+2
                1DNADR  IMODES30                # IMODES30,IMODES33
                DNCHAN  11                      # CHANNELS 11,12
                DNCHAN  13                      # CHANNELS 13,14
                DNCHAN  30                      # CHANNELS 30,31
                -DNCHAN 32                      # CHANNELS 32,33

# ------------------------------------------------------------
```

Uses ADOT 209, AK 200, AK1 200, AK2 200, CADRFLSH 150, CDUS 80, CDUX 80, CDUY 80, CSMMASS 200, DAPDATR1 200, DAPDATR2 200, DSPTAB 154, ERRORX 211, ERRORY 211, ERRORZ 211, FAILREG 150, FLAGWRD0 95, IMODES30 163, IMODES33 163, LEMMASS 200, OGARATE 208, OMEGAB 202, OMEGAC 202, PIPAX 80, PIPAY 80, PIPAZ 80, R-OTHER 172, RCSFLAGS 200, REDOCTR 157, RSBBQ 167, STATE 138, T-OTHER 172, THETAD 157, THETADX 211, THETADY 211, THETADZ 211, V 229, V-OTHER 172, and WBODY 209.

298 ⟨*Page CM0173* 298⟩≡ (293b 2676)

```
# CSM COAST AND ALIGNMENT DOWNLIST

# --------------------- CONTROL LIST ------------------------

CMCSTADL        EQUALS                                  # SEND ID BY SPECIAL CODING
                DNPTR   CMCSTA01                        # COLLECT SNAPSHOT
                6DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMCSTA02                        # COLLECT SECOND SNAPSHOT
                4DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMCSTA03                        # COMMON DATA
                1DNADR  TIG                             # TIG,+1
                1DNADR  BESTI                           # BESTI,BESTJ
                4DNADR  MARKDOWN                        # MARKDOWN,+1,...+5,+6,GARBA
                4DNADR  MARK2DWN                        # MARK2DWN,+1,...+5,+6
                2DNADR  HAPOX                           # APOGEE AND PERIGEE FROM R3
                1DNADR  PACTOFF                         # PACTOFF, YACTOFF
                3DNADR  VGTIG                           # VGTIG,...+5
                6DNADR  REFSMMAT                        # REFSMMAT,+1,...+10,+11
                DNPTR   CMCSTA04                        # COMMON DATA
                1DNADR  TIME2                           # TIME2,TIME1
                DNPTR   CMCSTA05                        # COLLECT SNAPSHOT
                6DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMCSTA02                        # COLLECT SNAPSHOT
                4DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMCSTA03                        # COMMON DATA
                DNPTR   CMCSTA06                        # COMMON DATA
                3DNADR  OGC                             # OGC,+1,IGC,+1,MGC,+1
                1DNADR  STATE   +10D                    # FLAGWRDS 10 AND 11
                1DNADR  TEVENT                          # TEVENT,+1
                1DNADR  LAUNCHAZ                        # LAUNCHAZ,+1
                1DNADR  OPTMODES                        # OPTMODES,HOLDFLAG
                DNPTR   CMCSTA07                        # COMMON DATA
                -6DNADR DSPTAB                          # DISPLAY TABLES

# --------------------- SUB LISTS ---------------------------

CMCSTA01        EQUALS  CMPOWE01                        # COMMON DOWNLIST DATA

CMCSTA02        EQUALS  CMPOWE02                        # COMMON DOWNLIST DATA

CMCSTA03        EQUALS  CMPOWE03                        # COMMON DOWNLIST DATA

CMCSTA04        EQUALS  CMPOWE04                        # COMMON DOWNLIST DATA

CMCSTA05        EQUALS  CMPOWE05                        # COMMON DOWNLIST DATA
```

```
CMCSTA06        EQUALS  CMPOWE06                        # COMMON DOWNLIST DATA

CMCSTA07        EQUALS  CMPOWE07                        # COMMON DOWNLIST DATA
```

Uses BESTI 145, BESTJ 145, DNTMBUFF 148, DSPTAB 154, HAPOX 181, HOLDFLAG 163, IGC 186, LAUNCHAZ 194, MARK2DWN 224, MARKDOWN 239, MGC 186, OGC 186, OPTMODES 163, PACTOFF 198, REFSMMAT 172, STATE 138, TEVENT 163, TIG 224, TIME1 80, TIME2 80, VGTIG 238, and YACTOFF 198.

299 ⟨*Page CM0174* 299⟩≡ (293b 2676)

```
# ------------------------------------------------------------
```

300 ⟨*Page CM0175* 300⟩≡ (293b 2676)

```
# CSM RENDEZVOUS AND PRETHRUST LIST

# --------------------- CONTROL LIST ------------------------

CMRENDDL        EQUALS                                  # SEND ID BY SPECIAL CODING
                DNPTR   CMREND01                        # COLLECT SNAPSHOT
                6DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMREND02                        # COLLECT SECOND SNAPSHOT
                4DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMREND03                        # COMMON DATA
                1DNADR  TIG                             # TIG,+1
                1DNADR  DELLT4                          # DELLT4,+1
                3DNADR  RTARG                           # RTARG,+1,...+4,+5
                1DNADR  VHFTIME                         # VHFTIME,+1
                4DNADR  MARKDOWN                        # MARKTIME(DP),YCDU,SCDU,ZCDU
                1DNADR  VHFCNT                          # VHFCNT,+1
                1DNADR  TTPI                            # TTPI,+1
                1DNADR  ECSTEER                         # ECSTEER,+1
                1DNADR  DELVTPF                         # DELVTPF,+1
                2DNADR TCDH                             # CDH AND CSI TIME
                1DNADR  TPASS4                          # TPASS4,+1
                3DNADR  DELVSLV                         # DELVSLV,+1...+4,+5
                2DNADR  RANGE                           # RANGE,+1,RRATE,+1
                DNPTR   CMREND04                        # COMMON DATA
                1DNADR  TIME2                           # TIME2,TIME1
                DNPTR   CMREND05                        # COLLECT SNAPSHOT
                6DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMREND02                        # COLLECT SNAPSHOT
                4DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMREND03                        # COMMON DATA
                DNPTR   CMREND06                        # COMMON DATA
                1DNADR  DIFFALT                         # CDH DELTA ALTITUDE
                1DNADR  CENTANG                         # CENTANG,+1
                1DNADR  DELTAR                          # DELTAR,+1
                3DNADR  DELVEET3                        # DELVEET3,+1,...,+4,+5
                1DNADR  OPTMODES                        # OPTMODES,HOLDFLAG
                DNPTR   CMREND07                        # COMMON DATA
                1DNADR  RTHETA                          # RTHETA,+1
                2DNADR  LAT(SPL)                        # LAT(SPL),LNG(SPL),+1
                2DNADR  VPRED                           # VPRED,+1,GAMMAEI,+1
                -1DNADR STATE   +10D                    # FLAGWRDS 10 AND 11

# --------------------- SUB LISTS ----------------------------

CMREND01        EQUALS  CMPOWE01                        # COMMON DOWNLIST DATA
```

```
CMREND02        EQUALS  CMPOWE02                        # COMMON DOWNLIST DATA

CMREND03        EQUALS  CMPOWE03                        # COMMON DOWNLIST DATA

CMREND04        EQUALS  CMPOWE04                        # COMMON DOWNLIST DATA
```

Uses DELLT4 224, DELTAR 183, DELVEET3 236, DELVSLV 224, DELVTPF 183, DIFFALT 197, DNTMBUFF 148, ECSTEER 224, GAMMAEI 231, HOLDFLAG 163, LAT 157, LAT(SPL) 224, LNG(SPL) 224, MARKDOWN 239, MARKTIME 161, OPTMODES 163, RANGE 179, RM 239, RRATE 179, RTARG 224, RTHETA 179, STATE 138, TCDH 197, TIG 224, TIME1 80, TIME2 80, TPASS4 236, TTPI 236, VHFCNT 157, VHFTIME 159, and VPRED 231.

301 ⟨*Page CM0176* 301⟩≡ (293b 2676)

```
CMREND05        EQUALS  CMPOWE05                        # COMMON DOWNLIST DATA

CMREND06        EQUALS  CMPOWE06                        # COMMON DOWNLIST DATA

CMREND07        EQUALS  CMPOWE07                        # COMMON DOWNLIST DATA

# ------------------------------------------------------------
```

302 ⟨*Page CM0177* 302⟩≡ (293b 2676)

```
# CSM ENTRY AND UPDATE DOWNLIST
# --------------------- CONTROL LIST -------------------------

CMENTRDL        EQUALS                                  # SEND ID BY SPECIAL CODING
                DNPTR   CMENTR01                        # COLLECT SNAPSHOT
                6DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMENTR02                        # COLLECT SNAPSHOT
                4DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMENTR03                        # COMMON DATA
                2DNADR  CMDAPMOD                        # CMDAPMOD,PREL,QREL,RREL
                1DNADR  L/D1                            # L/D1,+1
                6DNADR  UPBUFF                          # UPBUFF,+1,...+10,+11
                4DNADR  UPBUFF  +12D                    # UPBUFF+12,13,...+18,+19D
                2DNADR  COMPNUMB                        # COMPNUMB,UPOLDMOD,UPVERB,UP
                1DNADR  PAXERR1                         # PAXERR1,ROLLTM
                3DNADR  LATANG                          # LATANG,+1,RDOT,+1,THETAH,+1
                2DNADR  LAT(SPL)                        # LAT(SPL),+1,LNG(SPL),+1
                1DNADR  ALFA/180                        # ALFA/180,BETA/180
                DNPTR   CMENTR04                        # COMMON DATA
                1DNADR  TIME2                           # TIME2,TIME1
                DNPTR   CMENTR05                        # COLLECT SNAPSHOT
                6DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMENTR02                        # COLLECT SNAPSHOT
                4DNADR  DNTMBUFF                        # SENT SNAPSHOT
                2DNADR  AK                              # AK,AK1,AK2,RCSFLAGS
                3DNADR  ERRORX                          # ERRORX/Y/Z,THETADX/Y/Z
                2DNADR  CMDAPMOD                        # CMDAPMOD,PREL,QREL,RREL
                6DNADR  UPBUFF                          # UPBUFF+0,+1,...+10,+11D
                4DNADR  UPBUFF  +12D                    # UPBUFF+12,+13,...+18,+19D
                1DNADR  LEMMASS                         # LEMMASS,CSMMASS
                1DNADR  DAPDATR1                        # DAPDATR1,DAPDATR2
                1DNADR  ROLLTM                          # ROLLTM,ROLLC
                1DNADR  OPTMODES                        # OPTMODES,HOLDFLAG
                3DNADR  WBODY                           # WBODY,...+5/OMEGAC,...+5
                2DNADR  REDOCTR                         # REDOCTR,THETAD+0,+1,+2
                1DNADR  IMODES30                        # IMODES30,IMODES33
                DNCHAN  11                              # CHANNELS 11,12
                DNCHAN  13                              # CHANNELS 13,14
                DNCHAN  30                              # CHANNELS 30,31
                DNCHAN  32                              # CHANNELS 32,33
                1DNADR  RSBBQ                           # RSBBQ,+1
                3DNADR  CADRFLSH                        # CADRFLSH,+1,+2,FAILREG,+1,-
                1DNADR  STATE   +10D                    # FLAGWRDS 10 AND 11
                -1DNADR GAMMAEI                         # GAMMAEI,+1
```

```
# --------------------- SUB LISTS ----------------------------

CMENTR01        EQUALS  CMPOWE01                        # COMMON DOWNLIST DATA
```

Uses AK 200, AK1 200, AK2 200, ALFA/180 214, BETA/180 214, CADRFLSH 150, CMDAPMOD 214, COMPNUMB 145, CSMMASS 200, DAPDATR1 200, DAPDATR2 200, DNTMBUFF 148, ERRORX 211, FAILREG 150, GAMMAEI 231, HOLDFLAG 163, IMODES30 163, IMODES33 163, L 80, L/D1 226, LAT 157, LAT(SPL) 224, LATANG 229, LEMMASS 200, LNG(SPL) 224, OMEGAC 202, OPTMODES 163, PAXERR1 214, PREL 214, QREL 214, RCSFLAGS 200, RDOT 229, REDOCTR 157, ROLLC 214, ROLLTM 214, RREL 214, RSBBQ 167, STATE 138, THETAD 157, THETADX 211, THETAH 229, TIME1 80, TIME2 80, UPBUFF 145, UPCOUNT 145, UPOLDMOD 145, UPVERB 145, WBODY 209, and Z 80.

303 ⟨*Page CM0178* 303⟩≡ (293b 2676)

```
CMENTR02        EQUALS  CMPOWE02                        # COMMON DOWNLIST DATA

CMENTR03        EQUALS  CMPOWE03                        # COMMON DOWNLIST DATA

CMENTR04        EQUALS  CMPOWE04                        # COMMON DOWNLIST DATA

CMENTR05        -1DNADR DELV                            # DELV,+1                       SNAPSHO
                1DNADR  DELV    +2                      # DELV+2,+3
                1DNADR  DELV    +4                      # DELV+4,+5
                1DNADR  TTE                             # TTE,+1
                1DNADR  VIO                             # VIO,+1
                1DNADR  VPRED                           # VPRED,+1
                -1DNADR PIPTIME1                        # PIPTIME1,+1

CMENTR07        EQUALS  CMPOWE07                        # COMMON DOWNLIST DATA

# ------------------------------------------------------------
```

Uses DELV 159, PIPTIME1 159, TTE 229, VIO 229, and VPRED 231.

304 ⟨*Page CM0179* 304⟩≡ (293b 2676)

```
# --------------------- CONTROL LIST --------------------------

CMPG22DL        EQUALS                                  # SEND ID BY SPECIAL CODING
                DNPTR   CMPG2201                        # COLLECT SNAPSHOT
                6DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMPG2202                        # COLLECT SNAPSHOT
                4DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMPG2203                        # COMMON DATA
                6DNADR  SVMRKDAT                        # LANDING SITE MARK DATA
                6DNADR  SVMRKDAT +12D                   # SVMRKDAT+0,...+34
                6DNADR  SVMRKDAT +24D                   # LANDING SITE MARK DATA
                1DNADR  LANDMARK                        # LANDMARK,GARBAGE
                1DNADR  SPARE
                1DNADR  SPARE
                1DNADR  SPARE
                DNPTR   CMPG2204                        # COMMON DATA
                1DNADR  TIME2                           # TIME2,TIME1
                DNPTR   CMPG2205                        # COLLECT SNAPSHOT
                2DNADR  DNTMBUFF                        # SEND SNAPSHOT
                1DNADR  SPARE
                1DNADR  SPARE
                1DNADR  SPARE
                1DNADR  SPARE
                DNPTR   CMPG2202                        # COLLECT SNAPSHOT
                4DNADR  DNTMBUFF                        # SEND SNAPSHOT
                DNPTR   CMPG2203                        # COMMON DATA
                DNPTR   CMPG2206                        # COMMON DATA
                1DNADR  8NN                             # 8NN,GARBAGE
                1DNADR  STATE   +10D                    # FLAGWRDS 10 AND 11
                3DNADR  RLS                             # RLS,+1,...+4,+5
                1DNADR  SPARE
                1DNADR  OPTMODES                        # OPTMODES,HOLDFLAG
                DNPTR   CMPG2207                        # COMMON DATA
                1DNADR  SPARE
                1DNADR  SPARE
                1DNADR  SPARE
                1DNADR  SPARE
                1DNADR  SPARE
                -1DNADR SPARE

# --------------------- SUB LISTS --------------------------

CMPG2201        EQUALS  CMPOWE01                        # COMMON DOWNLIST DATA

CMPG2202        EQUALS  CMPOWE02                        # COMMON DOWNLIST DATA
```

```
CMPG2203        EQUALS  CMPOWE03                        # COMMON DOWNLIST DATA
```

Uses 8NN 190, DNTMBUFF 148, HOLDFLAG 163, LANDMARK 190, OPTMODES 163, RLS 175, STATE 138, SVMRKDAT 232, TIME1 80, and TIME2 80.

305 ⟨*Page CM0180* 305⟩≡ (293b 2676)

```
CMPG2204        EQUALS  CMPOWE04                        # COMMON DOWNLIST DATA

CMPG2205        -1DNADR LONG                            # LONG,+1                       SNAPSHO
                1DNADR  ALT                             # ALT,+1
                -1DNADR LAT                             # LAT,+1

CMPG2206        EQUALS  CMPOWE06                        # COMMON DOWNLIST DATA

CMPG2207        EQUALS  CMPOWE07                        # COMMON DOWNLIST DATA

# ------------------------------------------------------------

DNTABLE         GENADR  CMCSTADL
                GENADR  CMENTRDL
                GENADR  CMRENDDL
                GENADR  CMPOWEDL
                GENADR  CMPG22DL

# ------------------------------------------------------------
```

Uses ALT 157, LAT 157, and LONG 157.

3.3.4 fresh start and restart

306 ⟨*fresh start and restart* 306⟩≡ (245b)

⟨*Page CM0181* 307⟩
⟨*Page CM0182* 309⟩
⟨*Page CM0183* 311⟩
⟨*Page CM0184* 313⟩
⟨*Page CM0185* 315⟩
⟨*Page CM0186* 317⟩
⟨*Page CM0187* 319⟩
⟨*Page CM0188* 321⟩
⟨*Page CM0189* 323⟩
⟨*Page CM0190* 325⟩
⟨*Page CM0191* 327⟩
⟨*Page CM0192* 329⟩
⟨*Page CM0193* 330⟩
⟨*Page CM0194* 331⟩
⟨*Page CM0195* 332⟩
⟨*Page CM0196* 333⟩
⟨*Page CM0197* 335⟩
⟨*Page CM0198* 337⟩
⟨*Page CM0199* 339⟩
⟨*Page CM0200* 341⟩
⟨*Page CM0201* 343⟩
⟨*Page CM0202* 345⟩
⟨*Page CM0203* 347⟩
⟨*Page CM0204* 349⟩
⟨*Page CM0205* 351⟩
⟨*Page CM0206* 353⟩
⟨*Page CM0207* 355⟩
⟨*Page CM0208* 357⟩
⟨*Page CM0209* 359⟩
⟨*Page CM0210* 360⟩

307 ⟨*Page CM0181* 307⟩≡ (306 2700)

```
# PROGRAM DESCRIPTION                                          8 APRIL, 1967
#                                                              SUNDISK REV 120
# FUNCTIONAL DESCRIPTION
#
# SLAP1         MAN INITIATED FRESH START
#       1.      EXECUTE STARTSUB
#       2.      TURN OFF DSKY DISCRETE-LAMPS
#       3.      CLEAR FAIL REGISTERS, SELF-CHECK ERROR COUNTER AND RESTART
#               COUNTER
#       4.      EXECUTE DOFSTART
#
# DOFSTART      MACHINE INITIATED FRESH START
#
#       1.      CLEAR SELF-CHECK REGISTERS, MODE REGISTER AND CDUZ REGISTER
#       2.      CLEAR PHASE TABLE
#       3.      INITIALIZE IMU FLAGS
#       4.      INITIALIZE FLAGWORDS
#       5.      TRANSFER CONTROL TO IDLE LOOP IN DUMMYJOB
#
# GOPROG        HARDWARE RESTART
#
#       0.      EXECUTE STARTSUB
#       1.      TRANSFER CONTROL TO DOFSTART IF ANY OF THE FOLLOWING CONDITIONS
#               EXIST.
#               A.      RESTART OCCURRED DURING EXECUTION OF ERASCHK.
#               B.      BOTH OSCILLATOR FAIL AND AGC WARNING ARE ON.
#               C.      MARK REJECT AND EITHER NAV OR MAIN DSKY ERROR LIGHT RESET
#                       ARE ON.
#       2.      SCHEDULE A T5RUPT PROGRAM FOR THE DAP
#       3.      SET FLAGWRD5 BITS FOR INTWAKE ROUTINE
#       4.      EXTINGUISH ALL DSKY LAMPS, EXCEPT FOR PROGRAM ALARM, GIMBAL LOCK, AND
#               NO ATT
#       5.      INITIALIZE IMU FLAGS
#       6.      IF ENGINE COMMAND IS ON (FLAGWRD5, BIT 7), SET ENGINE ON (CHANNEL
#               11, BIT 13).
#       7.      TRANSFER CONTROL TO GOPROG3
#
# ENEMA         SOFTWARE RESTART -- INITIATED BY MAJOR MODE CHANGE
#
#       1.      EXECUTE STARTSB2
#       2.      KILL PROGRAMS THAT WERE INTEGRATING OR WAITING FOR INTEGRATION
#               ROUTINE
#       3.      TRANSFER CONTROL TO GOPROG3
#
# GOPROG3       SUBROUTINE COMMON TO GOPROG AND ENEMA
```

```
#
#       1.      TEST PHASE TABLES -- IF INCORRECT, DISPLAY ALARM 1107 AND
#               TRANSFER CONTROL TO DOFSTART
#       2.      DISPLAY MAJOR MODE
#       3.      IF ANY GROUPS WERE ACTIVE UPON RESTART, TRANSFER CONTROL TO THE
```

Uses A 80, CDUZ 80, COMMAND 169, FLAGWRD5 113, MODE 145, and RESTART 57.

309 ⟨*Page CM0182* 309⟩≡ (306 2700)

```
#               RESTARTS SUBROUTINE TO RESCHEDULE PENDING TASKS, LONGCALLS, AND
#               JOBS (P20 IS RESTARTED VIA FINDVAC)
#       4.      IF NO GROUPS WERE ACTIVE UPON RESTART, DISPLAY ALARM CODE
#               1110 (RESTART WITH NO ACTIVE GROUPS)
#       5.      TRANSFER CONTROL TO IDLE LOOP IN DUMMYJOB
#
# STARTSUB      SUBROUTINE COMMON TO SLAP1 AND GOPROG
#
#       1.      CLEAR OUTBIT CHANNELS 5 AND 6
#       2.      INITIALIZE TIME5, TIME4, TIME3
#       3.      TRANSFER CONTROL TO STARTSB2
#
# STARTSB2      SUBROUTINE COMMON TO STARTSUB AND ENEMA
#
#       1.      INTIALIZE OUTBIT CHANNELS 11,12,13, AND 14
#       2.      REPLACE ALL TASKS ON WAITLIST WITH ENDTASK
#       3.      MAKE ALL EXECUTIVE REGISTERS AVAILABLE
#       4.      MAKE ALL VAC AREAS AVAILABLE
#       5.      CLEAR DSKY REGISTERS
#       6.      ZERO NUMEROUS SWITCHES
#       7.      INITIALIZE OPTICS FLAGS
#       8.      INITIALIZE PIPA AND TELEMETRY FAIL FLAGS
#       9.      INITIALIZE DOWN TELEMETRY
#
# INPUT/OUTPUT INITIALIZATION
#
#       A.      CALLING SEQUENCE
#
#               SLAP1 --        TC POSTJUMP     OR      VERB 36,ENTER
#                               CADR SLAP1
#
#               ENEMA --        TC POSTJUMP     *** DO NOT CALL ENEMA WITHOUT ***
#                               CADR ENEMA      ***  CONSULTING POOH PEOPLE   ***
#
#       B.      OUTPUT
#
#               ERASABLE MEMORY INITIALIZATION
#
# PROGRAM ANALYSIS
#
#       A.      SUBROUTINES CALLED
#
#               MR.KLEAN,WAITLIST,DSPMM,ALARM,RESTARTS,FINDVAC
#
#       B.      ALARMS
```

```
#
#               1107    PHASE TABLE ERROR
#               1110    RESTART WITH NO ACTIVE GROUPS
```

Uses `A` 80, `CODE` 140, `RESTART` 57, `TC` 169, `TIME3` 80, `TIME4` 80, and `TIME5` 80.

311 ⟨*Page CM0183* 311⟩≡ (306 2700)

```
                BANK    10
                SETLOC  FRANDRES
                BANK

                EBANK=  LST1

                COUNT   05/START

SLAP1           INHINT                  # FRESH START.  COMES HERE FROM PINBALL.
                TC      STARTSUB        # SUBROUTINE DOES MOST OF THE WORK.

STARTSW         TCF     SKIPSIM         # PATCH....TCF STARTSIM...FOR SIMULATION
STARTSIM        CAF     BIT14
                TC      FINDVAC
SIM2CADR        OCT     77777           # PATCH 2CADR (AND EBANK DESIGNATION) OF
                OCT     77777           # SIMULATION START ADDRESS.

SKIPSIM         CA      DSPTAB +11D
                MASK    BITS4&6
                AD      BIT15
                TS      DSPTAB +11D     # REQUESTED FRESH START.

                CA      ZERO            # SAME STORY ON ZEROING FAILREG.
                TS      ERCOUNT
                TS      FAILREG
                TS      FAILREG +1
                TS      FAILREG +2
                TS      REDOCTR

                CS      PRIO12
                TS      DSRUPTSW

DOFSTART        CAF     ZERO            # DO A FRESH START.
                TS      ERESTORE        # ***** MUST NOT BE REMOVED FROM DOFSTART
                TS      SMODE           # ***** MUST NOT BE REMOVED FROM DOFSTART
                TS      UPSVFLAG        # UPDATE STATE VECTOR REQUEST FLAGWORD
                EXTEND
                WRITE   CHAN5           # TURN OFF RCS JETS
                EXTEND
                WRITE   CHAN6           # TURN OFF RCS JETS
                EXTEND
                WRITE   DSALMOUT        # ZERO CHANNEL 11
                EXTEND
                WRITE   CHAN12          # ZERO CHANNEL 12
                EXTEND
```

```
WRITE   CHAN13          # ZERO CHANNEL 13
EXTEND
WRITE   CHAN14          # ZERO CHANNEL 14
TS      WTOPTION
TS      DNLSTCOD
```

Uses A 80, CHAN12 87, CHAN13 87, CHAN14 87, COUNT 142, DNLSTCOD 148, DSALMOUT 87, DSPTAB 154, DSRUPTSW 161, EBANK 80, ERCOUNT 165, ERESTORE 165, FAILREG 150, FRANDRES 59, LST1 167, REDOCTR 157, SMODE 165, STATE 138, TC 169, UPSVFLAG 169, and WTOPTION 163.

313 ⟨*Page CM0184* 313⟩≡ (306 2700)

```
TS      NVSAVE
TS      EBANKTEM
TS      RATEINDX
TS      TRKMKCNT
TS      VHFCNT
TS      EXTVBACT

CS      DSPTAB +11D
MASK    BITS4&6
CCS     A
TC      +4
CA      BITS4&6
EXTEND                  # THE IMU WAS IN COARSE ALIGN IN GIMBAL
WOR     CHAN12          # LOCK, SO PUT IT BACK INTO COARSE ALIGN.
TC      MR.KLEAN

CS      ZERO
TS      MODREG

CAF     PRIO30
TS      RESTREG

CAF     IM30INIF        # FRESH START IMU INITIALIZATION.
TS      IMODES30

CAF     NEGONE
TS      OPTIND          # KILL COARSE OPTICS

CAF     OPTINITF
TS      OPTMODES

CAF     IM33INIT
TS      IMODES33

EXTEND                  # LET T5 IDLE.
DCA     T5IDLER
DXCH    T5LOC

CA      SWINIT
TS      STATE

CA      FLAGWRD1
MASK    NOP01BIT        # LEAVE NODOP01 FLAG UNTOUCHED
AD      SWINIT +1
TS      FLAGWRD1
```

```
CA      SWINIT +2
TS      STATE +2

CA      FLAGWRD3
```

Uses A 80, CHAN12 87, DSPTAB 154, EBANKTEM 156, EXTVBACT 154, FLAGWRD1 97, FLAGWRD3 105, IMODES30 163, IMODES33 163, IT 185, MODREG 154, NODOP01 99, NOP01BIT 99, NVSAVE 150, OPTIND 161, OPTMODES 163, RATEINDX 157, RESTREG 150, STATE 138, T5LOC 163, TC 169, TRKMKCNT 157, and VHFCNT 157.

315 ⟨*Page CM0185* 315⟩≡ (306 2700)

```
                MASK    BIT13           # REFSMMAT FLAG
                AD      SWINIT +3
                TS      FLAGWRD3

                EXTEND
                DCA     SWINIT +4
                DXCH    STATE +4
                EXTEND
                DCA     SWINIT +6
                DXCH    STATE +6
                CA      FLAGWRD8
                MASK    OCT6200         # CMOONFLG, LMOONFLG, AND SUFFLAG
                AD      SWINIT  +8D
                TS      FLAGWRD8

                CA      SWINIT +9D
                TS      STATE +9D

                EXTEND
                DCA     SWINIT +10D
                DXCH    STATE +10D

ENDRSTRT        TC      POSTJUMP
                CADR    DUMMYJOB +2     # PICKS UP AT RELINT.   (IN A SWITCHED BANK.)

MR.KLEAN        INHINT
                EXTEND
                DCA     NEG0
                DXCH    -PHASE2
P00KLEAN        EXTEND
                DCA     NEG0
                DXCH    -PHASE4
                EXTEND
                DCA     NEG0
                DXCH    -PHASE1
V37KLEAN        EXTEND
                DCA     NEG0
                DXCH    -PHASE3
                EXTEND
                DCA     NEG0
                DXCH    -PHASE5
                EXTEND
                DCA     NEG0
                DXCH    -PHASE6
                TC      Q
```

```
OCT6200 OCT     6200
```

Uses -PHASE1 152, -PHASE2 152, -PHASE3 152, -PHASE4 152, -PHASE5 152, -PHASE6 152, A 80, CMOONFLG 125, FLAGWRD3 105, FLAGWRD8 125, LMOONFLG 125, PHASE1 152, PHASE2 152, PHASE3 152, PHASE4 152, PHASE5 152, PHASE6 152, Q 80, REFSMMAT 172, STATE 138, and TC 169.

317 ⟨*Page CM0186* 317⟩≡ (306 2700)

```
# COMES HERE FROM LOCATION 4000, GOJAM, RESTART ANY PROGRAMS WHICH MAY HAVE BEEN RUNNING AT THE

GOPROG          INCR    REDOCTR         # ADVANCE RESTART COUNTER.

                LXCH    Q
                EXTEND
                ROR     SUPERBNK
                DXCH    RSBBQ
                TC      BANKCALL        # STORE ERASABLES FOR DEBUGGING PURPOSES.
                CADR    VAC5STOR
                CA      BIT15           # TEST OSC FAIL BIT TO SEE IF WE HAVE
                EXTEND                  # HAD A POWER TRANSIENT. IF SO, ATTEMPT
                WAND    CHAN33          # A RESTART. IF NOT, CHECK THE PRESENT
                EXTEND                  # STATE OF AGC WARNING BIT.
                BZF     BUTTONS

                CA      BIT14           # IF AGC WARNING ON (BIT = 0), DO A
                EXTEND                  # FRESH START ON THE ASSUMPTION THAT
                RAND    CHAN33          # WE ARE IN A RESTART LOOP.
                EXTEND
                BZF     NONAVKEY +1

BUTTONS         TC      LIGHTSET        # MAKE FRESH START CHECKS BEFORE ERESTORE.

# ERASCHK TEMPORARILY STORES THE CONTENST OF TWO ERASABLE LOCATIONS, X
# AND X+1 INTO SKEEP5 AND SKEEP6.  IT ALSO STORES X INTO SKEEP7 AND
# ERESTORE.  IF ERASCHK IS INTERRUPTED BY A RESTART, C(ERESTORE) SHOULD
# EQUAL C(SKEEP7), AND SHOULD BE A + NUMBER LESS THAN 2000 OCT.  OTHERWISE
# C(ERESTORE) SHOULD EQUAL +0.

                CAF     HI5
                MASK    ERESTORE
                EXTEND
                BZF     +2              # IF ERESTORE NOT = +0 OR +N LESS THAN 2K,
                TCF     NONAVKEY +1     # DOUBT E MEMORY AND DO A FRESH START
                CS      ERESTORE
                EXTEND
                BZF     ELRSKIP -1
                AD      SKEEP7
                EXTEND
                BZF     +2              # = SKEEP7, RESTORE E MEMORY.
                TCF     NONAVKEY +1     # NOT = SKEEP7, DOUBT E MEM, DO FRESH START
                CA      SKEEP4
                TS      EBANK           # EBANK OF E MEMORY THAT WAS UNDER TEST.
                EXTEND                  # (NOT DXCH SINCE THIS MIGHT HAPPEN AGAIN)
```

```
DCA     SKEEP5
INDEX   SKEEP7
DXCH    0000            # E MEMORY RESTORED
CA      ZERO
TS      ERESTORE
```

Uses A 80, CHAN33 87, EBANK 80, ERESTORE 165, IT 185, N 206, Q 80, REDOCTR 157, RESTART 57, RSBBQ 167, SKEEP4 165, SKEEP5 165, SKEEP6 165, SKEEP7 165, STATE 138, SUPERBNK 87, and TC 169.

319 ⟨*Page CM0187* 319⟩≡ (306 2700)

```
                TC      STARTSUB        # DO INITIALIZATION AFTER ERASE RESTORE.
  ELRSKIP       CA      FLAGWRD6        # RESTART AUTOPILOTS
                EXTEND
                MP      BIT3            # BITS 15,14    00      T5IDLOC
                MASK    SIX             #               01      REDORCS
                EXTEND                  #               10      REDOTVC
                INDEX   A               #               11      REDOSAT
                DCA     T5IDLER
                DXCH    T5LOC

                CS      INTFLBIT
                MASK    RASFLAG
                TS      RASFLAG

                CA      OPTMODES
                MASK    OPTINITR
                AD      BIT7
                TS      OPTMODES

                CAF     BIT6
                MASK    IMODES33
                AD      IM33INIT
                TS      IMODES33

                CA      9,6,4           # LEAVE PROG ALARM, GIMBAL LOCK, NO ATT
                MASK    DSPTAB +11D     # LAMPS INTACT ON HARDWARE RESTART
                AD      BIT15
                XCH     DSPTAB +11D
                MASK    BIT4            # IF NO ATT LAMP WAS ON, LEAVE ISS IN
                EXTEND                  # COARSE ALIGN
                BZF     NOCOARSE
                TC      IBNKCALL        # IF NO ATT LAMP ON, RETURN ISS TO
                CADR    SETCOARS        #       COARSE ALIGN.

                CAF     SIX
                TC      WAITLIST
                EBANK=  CDUIND
                2CADR   CA+ECE

  NOCOARSE      CAF     IFAILINH        # LEAVE FAILURE INHIBITS INTACT ON
                MASK    IMODES30        #       HARDWARE RESTART.  RESET ALL
                AD      IM30INIR        #       FAILURE CODES.
                TS      IMODES30

                CS      FLAGWRD5
```

```
MASK    ENGONBIT
CCS     A
TCF     GOPROG3
CAF     BIT13
EXTEND
```

Uses A 80, CDUIND 169, DSPTAB 154, EBANK 80, ENGONBIT 115, FLAGWRD5 113, FLAGWRD6 117, IMODES30 163, IMODES33 163, INTFLBIT 133, OPTMODES 163, RASFLAG 133, RESTART 57, T5LOC 163, and TC 169.

321 ⟨*Page CM0188* 321⟩≡ (306 2700)

```
                WOR     DSALMOUT        # TURN ENGINE ON
                TCF     GOPROG3

ENEMA           INHINT
                TC      LIGHTSET        # EXIT TO DOFSTART IF ERROR RESET AND
                TC      STARTSB2        # MARK REJECT DEPRESSED SIMULTANEOUSLY
                CS      INTMASK         # RESET INTEGRATION BITS
                MASK    RASFLAG
                TS      RASFLAG

                CS      FLAGWRD6        # IS TVC ON
                MASK    OCT60000
                EXTEND
                BZMF    GOPROG3         # NO

                CAF     .5SEC           # YES, CALL TVCEXEC TASK WHICH WAS KILLED
                TC      WAITLIST        #       IN STARTSB2
                EBANK=  BZERO
                2CADR   TVCEXEC

GOPROG3         CAF     NUMGRPS         # VERIFY PHASE TABLE AGREEMENTS
PCLOOP          TS      MPAC +5
                DOUBLE
                EXTEND
                INDEX   A
                DCA     -PHASE1         # COMPLEMENT INTO A, DIRECT INTO L.
                EXTEND
                RXOR    LCHAN           # RESULT MUST BE -0 FOR AGREEMENT.
                CCS     A
                TCF     PTBAD           # RESTART FAILURE.
                TCF     PTBAD
                TCF     PTBAD

                CCS     MPAC +5         # PROCESS ALL RESTART GROUPS.
                TCF     PCLOOP

                TS      MPAC +6         # SET TO +0.
                TC      MMDSPLAY        # DISPLAY MAJOR MODE

                INHINT                  # RELINT DONE IN MMDSPLAY

                CAE     FLAGWRD6        # IS RCS DAP RUNNING (BITS 15 14 OF
                MASK    OCT60000        # FLAGWORD6 = 01)
                EXTEND                  # YES, DO STOPRATE
                BZMF    NXTRST -1       # NO, SKIP TO NXTRST -1
```

```
CAF     EBANK6          # STOPRATE IS DONE IN EBANK 6
TS      EBANK
TC      STOPRATE        # ZERO DELCDUS, WBODYS, AND BIASES THUS
                        # STOPPING AUTOMATIC MANEUVERING

CAF     EBANK3
TS      EBANK
```

Uses -PHASE1 152, A 80, BZERO 208, DSALMOUT 87, EBANK 80, FLAGWRD6 117, L 80, LCHAN 87, MODE 145, MPAC 145, PHASE1 152, RASFLAG 133, RESTART 57, and TC 169.

323 ⟨*Page CM0189* 323⟩≡ (306 2700)

```
                CAF     NUMGRPS         # SEE IF ANY GROUPS RUNNING
NXTRST          TS      MPAC +5
                DOUBLE
                INDEX   A
                CCS     PHASE1
                TCF     PACTIVE         # PNZ -- GROUP ACTIVE.
                TCF     PINACT          # +0 -- GROUP NOT RUNNING.

PACTIVE         TS      MPAC
                INCR    MPAC            # ABS OF PHASE.
                INCR    MPAC +6         # INDICATE GROUP DEMANDS PRESENT.
                CA      RACTCADR
                TC      SWCALL          # MUST RETURN TO SWRETURN.

PINACT          CCS     MPAC +5         # PROCESS ALL RESTART GROUPS.
                TCF     NXTRST

                CCS     MPAC +6         # NO, CHECK PHASE ACTIVITY FLAG
                TCF     ENDRSTRT        # PHASE ACTIVE
                CAF     BIT15           # IS MODE -0
                MASK    MODREG
                EXTEND
                BZF     GOTOP00H        # NO
                TCF     ENDRSTRT        # YES
PTBAD           TC      ALARM           # SET ALARM TO SHOW PHASE TABLE FAILURE.
                OCT     1107

                TCF     DOFSTART        # IN R21.

# ********* ********* **********

# DO NOT USE GOPROG2 OR ENEMA WITHOUT CONSULTING P00H PEOPLE.

GOPROG2         EQUALS  ENEMA
OCT10000        =       BIT13
OCT30000        =       PRIO30
OCT7777         OCT     7777
RACTCADR        CADR    RESTARTS

LIGHTSET        CAF     BIT7            # DOFSTART IF MARK REJECT AND EITHER
                EXTEND                  # ERROR LIGHT RESET BUTTONS ARE DEPRESSED
                RAND    NAVKEYIN
                EXTEND
                BZF     NONAVKEY        # NO MARK REJECT
                CAF     OCT37
```

```
EXTEND
RAND    NAVKEYIN        # NAV DSKY KEYCODES,MARK,MARK REJECT
AD      -ELR
EXTEND
BZF     NONAVKEY +1
EXTEND
```

Uses A 80, MODE 145, MODREG 154, MPAC 145, NAVKEYIN 87, PHASE1 152, RESTART 57, and TC 169.

325 ⟨*Page CM0190* 325⟩≡ (306 2700)

```
                READ    MNKEYIN         # MAIN DSKY KEYCODES
                AD      -ELR
                EXTEND
                BZF     +2

NONAVKEY        TC      Q

                TC      STARTSUB
                TCF     DOFSTART
STARTSUB        CAF     LDNPHAS1        # SET POINTER SO NEXT 20MS DOWNRUPT WILL
                TS      DNTMGOTO        # CAUSE THE CURRENT DOWNLIST TO BE
                                        # INTERRUPTED AND START SENDING FROM THE
                                        # BEGINNING OF THE CURRENT DOWNLIST.
                CAF     POSMAX
                TS      TIME3           # 37777 TO TIME3.
                AD      MINUS2
                TS      TIME4           # 37775 TO TIME4.
                AD      NEGONE
                TS      TIME5           # 37774 TO TIME5.

STARTSB2        CAF     OCT77603        # TURN OFF UPLINK ACTY, TEMP CAUTION, KR,
                EXTEND                  # FLASH, OP. ERROR, LEAVE OTHERS UNCHANGED.
                WAND    DSALMOUT

                CAF     OCT74777        # TURN OFF TEST ALARMS, STANDBY ENABLE.
                EXTEND
                WAND    CHAN13
                CS      PRIO25          # CLEAR R21MARK, P21FLAG, AND SKIPVHF BIT.
                MASK    FLAGWRD2
                AD      SKIPVBIT        # NOW SET SKIPVHF FLAG.
                TS      FLAGWRD2
                EBANK=  LST1
                CAF     STARTEB
                TS      EBANK           # SET FOR E3

                CAF     NEG1/2          # INITIALIZE WAITLIST DELTA-TS.
                TS      LST1 +7
                TS      LST1 +6
                TS      LST1 +5
                TS      LST1 +4
                TS      LST1 +3
                TS      LST1 +2
                TS      LST1 +1
                TS      LST1
```

```
CS      ENDTASK
TS      LST2
TS      LST2 +2
TS      LST2 +4
```

Uses CHAN13 87, DNTMGOTO 148, DSALMOUT 87, EBANK 80, FLAGWRD2 101, LST1 167, LST2 167, MNKEYIN 87, P21FLAG 103, Q 80, R21MARK 103, SKIPVBIT 103, SKIPVHF 103, TC 169, TEMP 191, TIME3 80, TIME4 80, and TIME5 80.

327 ⟨*Page CM0191* 327⟩≡ (306 2700)

```
                TS      LST2 +6
                TS      LST2 +8D
                TS      LST2 +10D
                TS      LST2 +12D
                TS      LST2 +14D
                TS      LST2 +16D
                CS      ENDTASK +1
                TS      LST2 +1
                TS      LST2 +3
                TS      LST2 +5
                TS      LST2 +7
                TS      LST2 +9D
                TS      LST2 +11D
                TS      LST2 +13D
                TS      LST2 +15D
                TS      LST2 +17D

                CS      ZERO            # MAKE ALL EXECUTIVE REGISTER SETS
                TS      PRIORITY        # AVAILABLE.
                TS      PRIORITY +12D
                TS      PRIORITY +24D
                TS      PRIORITY +36D
                TS      PRIORITY +48D
                TS      PRIORITY +60D
                TS      PRIORITY +72D

                TS      DSRUPTSW
                TS      NEWJOB          # SHOWS NO ACTIVE JOBS.

                CAF     VAC1ADRC        # MAKE ALL VAC AREAS AVAILABLE.
                TS      VAC1USE
                AD      LTHVACA
                TS      VAC2USE
                AD      LTHVACA
                TS      VAC3USE
                AD      LTHVACA
                TS      VAC4USE
                AD      LTHVACA
                TS      VAC5USE

                CAF     TEN             # BLANK DSKY REGISTERS (PROGRAM,VERB,NOUN,
                                        # R1,R2,R3)
DSPOFF          TS      MPAC
                CS      BIT12
                INDEX   MPAC
```

```
TS      DSPTAB
CCS     MPAC
TCF     DSPOFF

TS      DELAYLOC
```

Uses DELAYLOC 157, DSPTAB 154, DSRUPTSW 161, LST2 167, MPAC 145, NEWJOB 138, PRIORITY 145, R2 188, VAC1USE 150, VAC2USE 150, VAC3USE 150, VAC4USE 150, and VAC5USE 150.

329 ⟨*Page CM0192* 329⟩≡ (306 2700)

```
                TS      DELAYLOC +1
                TS      DELAYLOC +2
                TS      DELAYLOC +3
                TS      R1SAVE
                TS      INLINK
                TS      DSPCNT
                TS      CADRSTOR
                TS      REQRET
                TS      CLPASS
                TS      DSPLOCK
                TS      MONSAVE         # KILL MONITOR
                TS      MONSAVE1
                TS      VERBREG
                TS      NOUNREG
                TS      DSPLIST
                TS      MARKSTAT
                TS      IMUCADR
                TS      OPTCADR
                TS      RADCADR
                TS      ATTCADR
                TS      LGYRO
                TS      FLAGWRD4        # KILL INTERFACE DISPLAYS
                CAF     NOUTCON
                TS      NOUT

                CAF     BIT14
                MASK    EXTVBACT
                TS      EXTVBACT
                CAF     LESCHK          # SELF CHECK GO-TO REGISTER.
                TS      SELFRET

                CS      VD1
                TS      DSPCOUNT

                TC      Q

T5IDLOC         CA      L               # T5RUPT COMES HERE EVERY 163.84 SECS
                TCF     NOQRSM  +1      # WHEN NOBODY IS USING IT.

                EBANK=  OGANOW
T5IDLER         2CADR   T5IDLOC

                EBANK=  OGANOW
                2CADR   REDORCS
```

```
                EBANK=  OGANOW
                2CADR   REDOTVC

                EBANK=  OGANOW
                2CADR   REDOSAT
```

Uses ATTCADR 163, CADRSTOR 154, CLPASS 154, DELAYLOC 157, DISPLAYS 59, DSPCNT 152, DSPCOUNT 152, DSPLIST 154, DSPLOCK 154, EBANK 80, EXTVBACT 154, FLAGWRD4 109, IMUCADR 163, INLINK 80, IT 185, L 80, LGYRO 161, MARKSTAT 163, MONSAVE 154, MONSAVE1 154, NOUNREG 152, NOUT 154, OGANOW 206, OPTCADR 163, Q 80, R1SAVE 156, RADCADR 163, REQRET 154, SELFRET 165, TC 169, and VERBREG 152.

330 ⟨*Page CM0193* 330⟩≡ (306 2700)

```
IFAILINH        OCT     435
LDNPHAS1        GENADR  DNPHASE1
LESCHK          GENADR  SELFCHK
VAC1ADRC        ADRES   VAC1USE
LTHVACA         DEC     44

INTMASK         OCT     20100
OCT77603        OCT     77603
OCT74777        OCT     74777
STARTEB         ECADR   LST1
NUMGRPS         EQUALS  FIVE
-ELR            OCT     -22             # -ERROR LIGHT RESET KEY CODE.
IM30INIF        OCT     37411           # INHIBITS IMU FAIL FOR 5 SEC AND PIP ISSW
IM30INIR        OCT     37000
IM33INIT        =       PRIO16          # NO PIP OR TM FAIL SIGNALS.
9,6,4           OCT     450
OPTINITF        OCT     130
OPTINITR        OCT     430
SWINIT          OCT     0
                OCT     0
                OCT     0
                OCT     0

                OCT     0
                OCT     00200
                OCT     0
                OCT     0
                OCT     0
                OCT     0
                OCT     0
                OCT     0
```

Uses CODE 140, LST1 167, TM 219, and VAC1USE 150.

331 ⟨*Page CM0194* 331⟩≡ (306 2700)

```
# PROGRAM NAME          GOTOP00H                ASSEMBLY SUNDISK
# LOG SECTION           FRESH START AND RESTART
#
# FUNCTIONAL DESCRIPTION
#
#       1.      DISPLAY MAJOR MODE NUMBER 00 IN DSKY REGISTER R1 AND R3.  FLASH V50N07 ON DSKY.
#       2.      PERMIT A CURRENT PENDING REQUEST (FLASH ON DSKY) TO BE REPLACED (WITHOUT AN ABO
#               CHANGE REQUEST.
#
# INPUT/OUTPUT INFORMATION
#
#       A. CALLING SEQUENCE                     TC GOTOP00H
#       B. ERASABLE INITIALIZATION              NONE
#       C. OUTPUT                               FLASH V 50 NOUN 07 ON DSKY
#       D. DEBRIS                               L
#
# PROGRAM ANALYSIS
#
#       A. SUBROUTINES CALLED                   GOPERF3, LINUS
#       B. NORMAL EXIT                          TCF ENDOFJOB
#       C. ALARM AND ABORT EXITS                NONE

                BLOCK   02
                SETLOC  FFTAG10
                BANK

                COUNT   02/P00

GOTOP00H        TC      PHASCHNG                # RESTART GOTOP00H
                OCT     14

                TC      POSTJUMP
                CADR    GOP00FIX
                BANK    10
                SETLOC  VERB37
                BANK

                COUNT   04/P00

GOP00FIX        TC      INITSUB
                TC      CLEARMRK +2
                CAF     V37N99
                TC      BANKCALL
                CADR    GOFLASH
                TCF     -3
```

Uses A 80, COUNT 142, D 226, FFTAG10 57, L 80, MODE 145, RESTART 57, TC 169, V 229, and VERB37 57.

332 ⟨*Page CM0195* 332⟩≡ (306 2700)

```
                    TCF     -4
                    TCF     -5
V37N99              VN      3799
```

Uses VN 159.

333 ⟨*Page CM0196* 333⟩≡ (306 2700)

```
# PROGRAM NAME          V37                     ASSEMBLY SUNDISK
#
# LOG SECTION           FRESH START AND RESTART
#
# FUNCTIONAL DESCRIPTION
#
#       1. CHECK IF NEW PROGRAM ALLOWED.  IF BIT 1 OF FLAGWRD2 (NODOFLAG) IS SET, AN ALARM 1520
#       2. CHECK FOR VALIDITY OF PROGRAM SELECTED.  IF AN INVALID PROGRAM IS SELECTED, THE OPER
#          SET AND CURRENT ACTIVITY, IF ANY, CONTINUE.
#       3. SERVICER IS TERMINATED IF IT HAS BEEN RUNNING.
#       4. INSTALL IS EXECUTED TO AVOID INTERRUPTING INTEGRATION.
#       5. THE ENGINE IS TURNED OFF AND THE DAP IS INITIALIZED FOR COAST.
#       6. TRACK, UPDATE, AND TARG1 FLAGS ARE SET TO ZERO.
#       7. DISPLAY SYSTEM IS RELEASED.
#       8. THE FOLLOWING ARE PERFORMED FOR EACH OF THE THREE CASES.
#               A. PROGRAM SELECTED IS P00.
#                       1. RENDEZVOUS FLAG IS RESET.  (KILL P20)
#                       2. STATINT1 IS SCHEDULED BY SETTING RESTART GROUP 2.
#                       3. MAJOR MODE 00 IS STORED IN THE MODE REGISTER (MODREG).
#                       4. SUPERBANK 3 IS SELECTED.
#                       5. NODOFLAG IS RESET.
#                       6. ALL RESTART GROUPS EXCEPT GROUP2 ARE CLEARED. CONTROL IS TRANSFERRED
#                          WHICH CAUSES ALL CURRENT ACTIVITY TO BE DISCONTINUED AND A 9 MINUTE
#                          INITIATED.
#               B. PROGRAM SELECTES IS P20.
#                       1. IF THE CURRENT MAJOR MODE IS THE SAME AS THE SELECTED NEWPROGRAM.  T
#                          VIA V37XEQ, ALL RESTART GROUPS, EXCEPT GROUP 4 ARE CLEARED.
#                       2. IF THE CURRENT MAJOR MODE IS NOT EQUAL TO THE NEW REQUEST, A CHECK I
#                          ED MAJOR MODE HAS BEEN RUNNING THE BACKGROUND,
#                          AND IF IT HAS, NO NEW PROGRAM IS SCHEDULED, THE EXISTING
#                          P20 IS RESTARTED TO CONTINUE, AND ITS MAJORE MODE IS SET.
#                       3. CONTROL IS TRANSFERRED TO GOPROG2.
#               C. PROGRAM SELECTED IS NEITHER P00 NOR P20
#                       1. V37XEQ IS SCHEDULED (AS A JOB) BY SETTING RESTART GROUP 4
#                       2. ALL CURRENT ACTIVITY EXCEPT RENDEZVOUS AND TRACKING IS DISCONTINUED
#                          GROUPS. GROUP 2 IS CLEARED. IF THE RENDEZVOUS FLAG IS ON P20 IS REST
#                          TO CONTINUE.
#
# INPUT/OUTPUT INFORMATION
#
#       A. CALLING SEQUENCE
#               CONTROL IS DIRECTED TO V37 BY THE VERBFAN ROUTINE.
#               VERBFAN GOES TO C(VERBTAB+C(VERBREG)). VERB 37 = MMCHANG.
#               MMCHANG EXECUTES A TC POSTJUMP, CADR V37.
#
```

```
#       B. ERASABLE INITIALIZATION              NONE
#
#       C. OUTPUT
#               MAJOR MODE CHANGE
```

Uses A 80, FLAGWRD2 101, IT 185, MODE 145, MODREG 154, NODOFLAG 105, RESTART 57, TC 169, and VERBREG 152.

335 ⟨*Page CM0197* 335⟩≡ (306 2700)

```
#
#       D. DEBRIS
#               MMNUMBER, MPAC +1, MINDEX, BASETEMP +C(MINDEX), FLAGWRD0, FLAGWRD1, FLAGWRD2, M
#               GOLOC, GOLOC +1, GOLOC +2, BASETEMP, -PHASE2, PHASE2, -PHASE4
#
# PROGRAM ANALYSIS
#
#       A. SUBROUTINES CALLED
#               ALARM, RELDSP, PINBRNCH, INTSTALL, ENGINOF2, ALLCOAST, V37KLEAN, GOPROG2, FALTC
#               DSPMM
#
#       B. NORMAL EXIT                          TC ENDOFJOB
#
#       C. ALARMS                               1520 (MAJOR MODE CHANGE NOT PERMITTED)

                BLOCK   02
                SETLOC  FFTAG10
                BANK

                COUNT   02/V37

OCT24           MM      20
OCT31           MM      25
                BANK    27
                SETLOC  VERB37
                BANK

                COUNT   04/V37

V37             TS      MMNUMBER                # SAVE MAJOR MODE
                CAF     PRIO30                  # RESTART AT PINBALL PRIORITY
                TS      RESTREG

                CA      IMODES30                # IS IMU BEING INITIALIZED
                MASK    BIT6
                CCS     A
                TCF     CANTR00

                CAF     BIT13                   # IS ENGINE ON
                EXTEND
                RAND    DSALMOUT
                CCS     A
                TCF     R00TOP00                # YES, SET UP FOR P00

                CS      FLAGWRD6                # NO, IS TVC DAP ON
```

```
                MASK    OCT60000
                EXTEND
                BZMF    ISITP00                 # NO, CONTINUE WITH R00

R00TOP00        INHINT
                CAF     EBANK6
```

Uses -PHASE2 152, -PHASE4 152, A 80, COUNT 142, D 226, DSALMOUT 87, FFTAG10 57, FLAGWRD0 95, FLAGWRD1 97, FLAGWRD2 101, FLAGWRD6 117, IMODES30 163, MINDEX 152, MM 226, MMNUMBER 152, MODE 145, MODREG 154, MPAC 145, PHASE2 152, PHASE4 152, PRIORITY 145, RESTART 57, RESTREG 150, SAVE 191, TC 169, and VERB37 57.

337 ⟨*Page CM0198* 337⟩≡ (306 2700)

```
                TS      EBANK
                EBANK=  DAPDATR1
                CAE     CSMMASS
                TS      MASSTMP
                TC      IBNKCALL
                CADR    SPSOFF
                TC      IBNKCALL
                CADR    MASSPROP
                CAF     3.1SEC
                TC      IBNKCALL
                CADR    RCSDAPON +1

                TC      IBNKCALL
                CADR    TVCZAP                  # DISABLE TVC
                CAF     ZERO
                TS      MMNUMBER
                RELINT
                CAF     FIVE
                TC      BANKCALL
                CADR    DELAYJOB
                CAF     ZERO
                EXTEND
                WRITE   5
                EXTEND
                WRITE   6
ISITP00         CA      MMNUMBER
                EXTEND
                BZF     ISSERVON                # YES, CHECK SERVICER STATUS

                CS      FLAGWRD2                # NO, IS NODO V37 FLAG SET
                MASK    NODOBIT
                CCS     A
                TCF     CHECKTAB                # NO
CANTR00         TC      ALARM
                OCT     1520

V37BAD          TC      RELDSP                  # RELEASES DISPLAY FROM ASTRONAUT

                TC      POSTJUMP                # BRING BACK LAST NORMAL DISPLAY IF THERE
                CADR    PINBRNCH                # WAS ONE.  OY

CHECKTAB        CA      NOV37MM                 # THE NO. OF MM
AGAINMM         TS      MPAC +1
                NDX     MPAC +1
                CA      PREMM1                  # OBTAIN WHICH MM THIS IS FOR
```

```
                    MASK    LOW7
                    COM
                    AD      MMNUMBER
                    CCS     A
                    CCS     MPAC +1                 # IF GR, SEE IF ANY MORE IN LIST
```

Uses A 80, CSMMASS 200, DAPDATR1 200, EBANK 80, FLAGWRD2 101, MASSTMP 206, MM 226, MMNUMBER 152, MPAC 145, NODOBIT 105, and TC 169.

339 ⟨*Page CM0199* 339⟩≡ (306 2700)

```
                TCF     AGAINMM                 # YES, GET NEXT ONE
                TCF     V37NONO                 # LAST TIME OR PASSED MM

                CA      MPAC +1
                TS      MINDEX                  # SAVE INDEX FOR LATER

ISSERVON        CS      FLAGWRD7                # V37 FLAG SET -- I.E., IS SERVICER GOING
                MASK    V37FLBIT
                CCS     A
                TCF     CANV37                  # NO

                INHINT
                CS      AVEGBIT                 # YES TURN OFF AVERAGE G FLAG AND WAIT
                MASK    FLAGWRD1                # FOR SERVICER TO RETURN TO CANV37
                TS      FLAGWRD1

                TCF     ENDOFJOB

CANV37          CAF     R00AD
                TS      TEMPFLSH

                TC      PHASCHNG
                OCT     14

ROC             TC      INTPRET

                CALL                            # WAIT FOR INTEGRATION TO FINISH
                        INTSTALL
DUMMYAD         EXIT

                CS      OCT1400                 # CLEAR CAUTION RESET
                EXTEND                          #   AND TEST CONNECTOR OUTBIT
                WAND    11

                CAF     OCT44571                # CLEAR ENABLE OPTICS ERROR COUNTER, STAR
                EXTEND                          # TRAKERS ON BIT, TVC ENABLE, ZERO OPTICS,
                WAND    12                      # DISENGAGE OPTICS DAP, SIVB IN J SEQUENCE
                                                # START, AND SIVB CUTOFF BIT.

                CS      OCT600                  # CLEAR UNUSED BITS
                EXTEND
                WAND    13

                TC      INITSUB
```

```
TC      CLEARMRK

TC      DOWNFLAG
ADRES   STIKFLAG
```

Uses A 80, AVEGBIT 101, FLAGWRD1 97, FLAGWRD7 121, I 206, MINDEX 152, MM 226, MPAC 145, SAVE 191, STAR 186, STIKFLAG 99, TC 169, TEMPFLSH 150, and V37FLBIT 123.

341 ⟨*Page CM0200* 341⟩≡ (306 2700)

```
                TC      BANKCALL
                CADR    UPACTOFF            # TURN OFF UPLINK ACTIV LIGHT

                TC      DOWNFLAG
                ADRES   VHFRFLAG
                TC      DOWNFLAG
                ADRES   R21MARK

                CCS     MMNUMBER            # IS THIS A P00H REQUEST
                TCF     NOUVEAU             # NO, PICK UP NEW PROGRAM

                COUNT   04/P00

P00H            TC      RELDSP              # RELEASE DISPLAY SYSTEM
                CAF     PRIO5               # SET VARIABLE RESTART REGISTER FOR P00.
                TS      PHSPRDT2

                INHINT

                CS      NODOBIT             # TURN OFF NODOFLAG.
                MASK    FLAGWRD2
                TS      FLAGWRD2

                CA      FIVE                # SET 2.5 RESTART FOR STATEINT1
                TS      L
                COM
                DXCH    -PHASE2

                CS      BIT7-8              # RESET IMUSE + KILL P20 BY TURNING OFF
                MASK    FLAGWRD0
                TS      FLAGWRD0            #                       RENDFLG

                CAF     DNLADP00

                COUNT   04/V37

SEUDOP00        TS      DNLSTCOD            # SET UP APPROPRIATE DOWNLIST CODE
                                            # (OLD ONE WILL BE FINISHED FIRST)

                CS      OCT01120            # TURN OFF TRACK, TARG1, UPDATE FLAGS
                TS      EBANKTEM
                MASK    FLAGWRD1
                TS      FLAGWRD1

GROUPKIL        TC      IBNKCALL            # KILL GROUPS 3,5,6
```

```
                    CADR    V37KLEAN

                    CCS     MMNUMBER                # IS IT POOH
                    TCF     RENDVOO                 # NO
```

Uses -PHASE2 152, A 80, CODE 140, COUNT 142, DNLSTCOD 148, EBANKTEM 156, FLAGWRD0 95, FLAGWRD1 97, FLAGWRD2 101, IMUSE 95, IT 185, L 80, MMNUMBER 152, NODOBIT 105, NODOFLAG 105, PHASE2 152, PHSPRDT2 154, R21MARK 103, RESTART 57, TC 169, and VHFRFLAG 131.

343 ⟨*Page CM0201* 343⟩≡ (306 2700)

```
                TC      IBNKCALL
                CADR    P00KLEAN            # REDUNDANT EXCEPT FOR GROUP 4.

GOMOD           CA      MMNUMBER
                TS      MODREG

GOGOPROG        TC      POSTJUMP
                CADR    GOPROG2

RENDV00         CS      MMNUMBER            # IS NEW PROG = 20
                AD      OCT24               # 20
                EXTEND
                BZF     RENDN00             # YES
                TCF     P00FIZZ
RENDN00         CS      MMNUMBER
                AD      MODREG
                EXTEND
                BZF     KILL20

                CA      FLAGWRD0            # IS RENDEZVOO FLAG SET
                MASK    RNDVZBIT
                CCS     A
                TCF     STATQUO

P00FIZZ         CAF     RNDVZBIT
                MASK    FLAGWRD0
                CCS     A
                TCF     REV37
KILL20          EXTEND                      # NO, KILL GROUPS 1 + 2
                DCA     NEG0
                DXCH    -PHASE1

                EXTEND
                DCA     NEG0
                DXCH    -PHASE2

REV37           CAF     V37QCAD             # SET RESTART POINT
                TS      TEMPFLSH

                TCF     GOGOPROG


STATQUO         CS      FLAGWRD1            # SET TRACKFLAG AND UPDATE FLAG
                MASK    OCT120
                ADS     FLAGWRD1
```

```
EXTEND                          # KILL GROUP 4
DCA     NEG0
DXCH    -PHASE4
```

Uses -PHASE1 152, -PHASE2 152, -PHASE4 152, A 80, FLAGWRD0 95, FLAGWRD1 97, MMNUMBER 152, MODREG 154, PHASE1 152, PHASE2 152, PHASE4 152, RESTART 57, RNDVZBIT 97, TC 169, and TEMPFLSH 150.

345 ⟨*Page CM0202* 345⟩≡ (306 2700)

```
                TCF     GOMOD

NOUVEAU         CAF     RNDVZBIT
                MASK    FLAGWRD0
                CCS     A
                TCF     +3
                TC      DOWNFLAG                # NO, RESET IMUINUSE FLAG
                ADRES   IMUSE                   # BIT 8 FLAG 0
        +3      INDEX   MINDEX
                CAF     DNLADMM1                # OBTAIN NEW DOWNLIST ADDRESS

                INHINT
                TCF     SEUDOP00

V37NONO         TC      FALTON                  # COME HERE IF MM REQUESTED DOESN'T EXIST
                TCF     V37BAD

OCT00010        EQUALS  BIT4
V37XEQ          INHINT
                INDEX   MINDEX
                CAF     PREMM1
                TS      MMTEMP                  # OBTAIN PRIORITY BITS 15-11
                TS      CYR                     # SHIFT RIGHT TO BITS 14-10

                CA      CYR
                MASK    PRIO37
                TS      PHSPRDT4                # PRESET GROUP 4 RESTART PRIORITY
                TS      NEWPRIO                 # STORE PRIO FOR SPVAC

                CA      MMTEMP                  # OBTAIN EBANK -- BITS 8, 9, 10 OF MMTEMP.
                EXTEND
                MP      BIT8
                MASK    LOW3
                TS      L
                INDEX   MINDEX
                CAF     FCADRMM1
                TS      BASETEMP
                MASK    HI5
                ADS     L

                CA      BASETEMP                # OBTAIN GENADR PORTION OF 2CADR.
                MASK    LOW10
                AD      BIT11

                TC      SPVAC
```

```
V37XEQC         CA      MMTEMP                  # UPON RETURN FROM FINDVAC PLACE THE
                MASK    LOW7                    # NEW MM IN MODREG (THE LOW 7 BITS OF
                TC      NEWMODEA                # PHSBRDT1)
```

Uses A 80, CYR 80, EBANK 80, FLAGWRDO 95, IMUSE 95, L 80, MINDEX 152, MM 226, MODREG 154, NEWPRIO 138, PHSPRDT4 154, PRIORITY 145, RESTART 57, RNDVZBIT 97, and TC 169.

347 ⟨*Page CM0203* 347⟩≡ (306 2700)

```
# FOR SUNDISK ONLY
                TC      RELDSP                  # RELEASE DISPLAY
                TC      ENDOFJOB                # AND EXIT

INITSUB         EXTEND
                QXCH    MPAC    +1

                CAF     EBANK6                  # SET E6 FOR DEADBAND CODING
                TS      EBANK                   # WILL BE RESET IN STARTSB2
                INHINT
                TC      STOPRATE

                CA      FLAGWRD9                # RESTORE DEADBAND
                MASK    MAXDBBIT
                CCS     A
                TCF     SETMAXER                # MAX DE SELECTED
                TC      BANKCALL                # MIN DE SELECTED
                CADR    SETMINDB
                TCF     RAKE
SETMAXER        TC      BANKCALL
                CADR    SETMAXDB

RAKE            CAF     ELEVEN                  # THIS PART CLEARS FLAGWORD BITS.
        +1      TS      MPAC                    # LOOP COMES HERE
                INDEX   MPAC
                CS      FLAGTABL
                INDEX   MPAC
                MASK    FLAGWRD0
                INDEX   MPAC                    # PUT REVISED FLAGWORD BACK.
                TS      FLAGWRD0
                CCS     MPAC
                TCF     RAKE    +1              # GET THE NEXT FLAGWORD
                RELINT

                TC      UPFLAG                  # NOW SET IMPULSW
                ADRES   IMPULSW

                CA      NEGONE
                TS      OPTIND
                TC      MPAC    +1              # RETURN FROM INITSUB

FLAGTABL        OCT     0
                OCT     00040                   # IDLEFAIL
                OCT     06000                   # P21FLAG, STEERSW
                OCT     0
```

```
                OCT     0
                OCT     04140                   # V59FLAG, ENGONFLG, 3AXISFLG
                OCT     10000                   # STRULLSW
                OCT     16000
                OCT     0
```

Uses 3AXISFLG 115, A 80, EBANK 80, ENGONFLG 115, FLAGWRD0 95, IDLEFAIL 101, IMPULSW 103, MPAC 145, OPTIND 161, P21FLAG 103, STEERSW 103, STRULLSW 117, TC 169, and V59FLAG 113.

349 ⟨*Page CM0204* 349⟩≡ (306 2700)

```
                OCT     42000                   # SWTOVER, V94FLAG
                OCT     0
                OCT     0

                SETLOC  VAC5LOC
                BANK
VAC5STOR        CA      ZERO                    # INITIALIZE INDEX REGISTERS
                TS      ITEMP1
                TS      ITEMP2

V5LOOP1         EXTEND                          # LOOP TO STORE LOCS, BANKSETS, AND PRIOS.
                INDEX   ITEMP1
                DCA     LOC
                INDEX   ITEMP2
                DXCH    VAC5

                INDEX   ITEMP1
                CA      PRIORITY
                INDEX   ITEMP2
                TS      VAC5 +2

                CS      ITEMP2                  # HAVE WE STORED THEM ALL?
                AD      EIGHTEEN
                EXTEND
                BZF     V5OUT1                  # YES, GET PHASE INFORMATION.

                CA      TWELVE                  # NO, INCREMENT INDEXES AND LOOP.
                ADS     ITEMP1
                CA      THREE
                ADS     ITEMP2
                TCF     V5LOOP1

                EBANK=  PHSNAME1
V5OUT1          CA      EBANK3                  # PHSNAME REGISTERS ARE IN EBANK3.
                TS      EBANK

                CA      ELEVEN                  # GET PHASE 2CADRS.
                TC      GENTRAN
                ADRES   PHSNAME1
                ADRES   VAC5 +21D

                CA      ZERO                    # NOW INITIALIZE INDEXES AGAIN.
                TS      ITEMP1
                TS      ITEMP2
```

```
V5LOOP2         INDEX   ITEMP1                  # LOOP TO GET PHASE TABLES.
                CA      PHASE1
                INDEX   ITEMP2
                TS      VAC5 +33D
```

Uses EBANK 80, ITEMP1 138, ITEMP2 138, LOC 145, PHASE1 152, PHSNAME1 167, PRIORITY 145, TC 169, VAC5 150, and VAC5LOC 63.

351 ⟨*Page CM0205* 351⟩≡ (306 2700)

```
                CS      ITEMP2          # DO WE HAVE THEM ALL?
                AD      FIVE
                EXTEND
                BZF     V5OUT2          # YES, GO FINISH UP.

                CA      TWO             # NO, INCREMENT INDEXES AND LOOP.
                ADS     ITEMP1
                INCR    ITEMP2
                TCF     V5LOOP2

V5OUT2          CA      MPAC +3
                TS      VAC5 +39D

                EXTEND
                DCA     NEWLOC
                DXCH    VAC5 +40D

                CA      NEWJOB
                TS      VAC5 +22D

                CA      NEWPRIO
                TS      VAC5 +26D

                TC      SWRETURN

EIGHTEEN        OCT     22
                SETLOC  VERB37
                BANK

NEG7            EQUALS  OCT77770

OCT44571        OCT     44571           # CONSTANTS TO CLEAR CHANNEL BITS IN V37
OCT600          OCT     600
                EBANK=  PACTOFF
P00DAPAD        2CADR   T5IDLOC

MMTEMP          EQUALS  PHSPRDT3
BASETEMP        EQUALS  TBASE4
BIT7-8          OCT     300
OCT01120        OCT     01120

V37QCAD         CADR    V37XEQ +3
R00AD           CADR    DUMMYAD
                EBANK=  DAPDATR1
RCSADDR4        2CADR   RCSATT
```

```
3.1SEC          OCT     37312                   # 2.5 + 0.6 SEC

# FOR VERB 37 TWO TABLES ARE MAINTAINED.  EACH TABLE HAS AN ENTRY FOR EACH
# MAJOR MODE THAT CAN BE STARTED FROM THE KEYBOARD.  THE ENTRIES ARE PUT
# INTO THE TABLE WITH THE ENTRY FOR THE HIGHEST MAJOR MODE COMING FIRST,
```

Uses DAPDATR1 200, EBANK 80, ITEMP1 138, ITEMP2 138, MODE 145, MPAC 145, NEWJOB 138, NEWLOC 138, NEWPRIO 138, PACTOFF 198, PHSPRDT3 154, TBASE4 154, TC 169, VAC5 150, and VERB37 57.

353 ⟨*Page CM0206* 353⟩≡ (306 2700)

```
# TO THE LOWEST MAJOR MODE WHICH IS THE LAST ENTRY IN EACH TABLE.
#
# THE FCADRMM TABLE CONTAINS THE FCADR OF THE STARTING JOB OF
# THE MAJOR MODE.  FOR EXAMPLE,
#
#       FCADRMM1        FCADR   P79             # START OF P 79
#                       FCADR   PROG18          # START OF P 18
#                       FCADR   P01             # START OF P 01

FCADRMM1        EQUALS
                FCADR   P79
                FCADR   P78
                FCADR   P77
                FCADR   P76
                FCADR   P75
                FCADR   P74
                FCADR   P73
                FCADR   P72
                FCADR   P62
                FCADR   P61
                FCADR   P54
                FCADR   P53
                FCADR   PROG52
                FCADR   P51
                FCADR   P47CSM
                FCADR   P41CSM
                FCADR   P40CSM
                FCADR   P39
                FCADR   P38
                FCADR   P37
                FCADR   P35
                FCADR   P34
                FCADR   P33
                FCADR   P32
                FCADR   P31
                FCADR   P30
                FCADR   P23
                FCADR   PROG22
                FCADR   PROG21
                FCADR   PROG20
                FCADR   P17
                FCADR   P06
                FCADR   GTSCPSS1                        # GYROCOMPASS STANDARD LEAD IN.

# THE PREMM TABLE CONTAINS THE E-BANK, MAJOR MODE, AND PRIORITY
```

```
# INFORMATION, IT IS IN THE FOLLOWING FORM,
#
#       PPP PPE EEM MMM MMM
#
```

Uses IT 185, MODE 145, P 188, and PRIORITY 145.

355 ⟨*Page CM0207* 355⟩≡ (306 2700)

```
#       WHERE THE       7 M BITS CONTAIN THE MAJOR MODE NUMBER
#                       3 E BITS CONTAIN THE E-BANK NUMBER
#                       5 P BITS CONTAIN THE PRIORITY AT WHICH THE JOB IS
#                           TO BE STARTED
#
#       FOR EXAMPLE,
#
#               PREMM1          OCT     67213           # PRIORITY      33
#                                                       # E-BANK        5
#                                                       # MAJOR MODE    11
#                               OCT     25437           # PRIORITY      12
#                                                       # E-BANK        6
#                                                       # MAJOR MODE    31

PREMM1          EQUALS
                OCT     27117           # MM 79         EBANK 4         PRIO 13
                OCT     27116           # MM 78         EBANK 4         PRIO 13 (original says
                OCT     27115           # MM 77         EBANK 4         PRIO 13
                OCT     27714           # MM 76         EBANK 4         PRIO 13
                OCT     27113           # MM 75         EBANK 4         PRIO 13
                OCT     27112           # MM 74         EBANK 4         PRIO 13
                OCT     27111           # MM 73         EBANK 4         PRIO 13
                OCT     27110           # MM 72         EBANK 4         PRIO 13
                OCT     27476           # MM 62         EBANK 6         PRIO 13
                OCT     27475           # MM 61         EBANK 6         PRIO 13
                OCT     27266           # MM 54         EBANK 5         PRIO 13
                OCT     27265           # MM 53         EBANK 5         PRIO 13
                OCT     27264           # MM 52         EBANK 5         PRIO 13
                OCT     27263           # MM 51         EBANK 5         PRIO 13
                OCT     27657           # MM 47         EBANK 7         PRIO 13
                OCT     27451           # MM 41         EBANK 6         PRIO 13
                OCT     27450           # MM 40         EBANK 6         PRIO 13
                OCT     27047           # MM 39         EBANK 4         PRIO 13
                OCT     27046           # MM 38         EBANK 4         PRIO 13
                OCT     27645           # MM 37         EBANK 7         PRIO 13
                OCT     27043           # MM 35         EBANK 4         PRIO 13
                OCT     27042           # MM 34         EBANK 4         PRIO 13
                OCT     27041           # MM 33         EBANK 4         PRIO 13
                OCT     27040           # MM 32         EBANK 4         PRIO 13
                OCT     27637           # MM 31         EBANK 7         PRIO 13
                OCT     27636           # MM 30         EBANK 7         PRIO 13
                OCT     27227           # MM 23         EBANK 5         PRIO 13
                OCT     27226           # MM 22         EBANK 5         PRIO 13
                OCT     27025           # MM 21         EBANK 4         PRIO 13
                OCT     27424           # MM 20         EBANK 6         PRIO 13
```

```
OCT     27021          # MM 17        EBANK 6        PRIO 13
OCT     27006          # MM 06        EBANK 4        PRIO 13
OCT     41201          # MM 01        EBANK 5        PRIO 20
```

Uses EBANK 80, MM 226, MODE 145, P 188, and PRIORITY 145.

357 ⟨*Page CM0208* 357⟩≡ (306 2700)

```
# THE FOLLOWING LIST IS FOR THE PURPOSE OF VERIFYING THAT THE EBA

                EBANK=  TIG             # EBANK SETTING REQUIRED BY MM 76
                EBANK=  KT              # EBANK SETTING REQUIRED BY MM 75
                EBANK=  SUBEXIT         # EBANK SETTING REQUIRED BY MM 74
                EBANK=  SUBEXIT         # EBANK SETTING REQUIRED BY MM 73
                EBANK=  SUBEXIT         # EBANK SETTING REQUIRED BY MM 72
                EBANK=  AOG             # EBANK SETTING REQUIRED BY MM 62
                EBANK=  AOG             # EBANK SETTING REQUIRED BY MM 61
                EBANK=  BESTI           # EBANK SETTING REQUIRED BY MM 54
                EBANK=  STARIND         # EBANK SETTING REQUIRED BY MM 53
                EBANK=  BESTI           # EBANK SETTING REQUIRED BY MM 52
                EBANK=  STARIND         # EBANK SETTING REQUIRED BY MM 51
                EBANK=  P40TMP          # EBANK SETTING REQUIRED BY MM 47
                EBANK=  DAPDATR1        # EBANK SETTING REQUIRED BY MM 41
                EBANK=  KMPAC           # EBANK SETTING REQUIRED BY MM 40
                EBANK=  KT              # EBANK SETTING REQUIRED BY MM 35
                EBANK=  SUBEXIT         # EBANK SETTING REQUIRED BY MM 34
                EBANK=  SUBEXIT         # EBANK SETTING REQUIRED BY MM 33
                EBANK=  SUBEXIT         # EBANK SETTING REQUIRED BY MM 32
                EBANK=  +MGA            # EBANK SETTING REQUIRED BY MM 30
                EBANK=  LANDMARK        # EBANK SETTING REQUIRED BY MM 23
                EBANK=  MARKINDX        # EBANK SETTING REQUIRED BY MM 22
                EBANK=  WHOCARES        # EBANK SETTING REQUIRED BY MM 21
                EBANK=  ESTROKER        # EBANK SETTING REQUIRED BY MM 20
                EBANK=  TIME2SAV        # EBANK SETTING REQUIRED BY MM 06
                EBANK=  QPLACE          # EBANK SETTING REQUIRED BY MM 01

# NOTE:         THE FOLLOWING CONSTANT IS THE NUMBER OF ENTRIES IN EACH OF
# -----         THE ABOVE LISTS-1 (I.E., THE NUMBER OF MAJOR MODES (EXCEPT P00)
#               THAT CAN BE CALLED FROM THE KEYBOARD MINUS ONE)

EPREMM1         EQUALS                  # END OF PREMM1 TABLE
                SETLOC  PREMM1          # THIS CODING WILL AUTOMATICALLY CHANGE
NO.MMS          =MINUS  EPREMM1         # THE "NOV37MM" CONSTANT AS ENTRIES ARE
                SETLOC  VERB37          # INSERTED(IN) OR DELETED(FROM) THE
                BANK                    # "PREMM1" TABLE.

NOV37MM         ADRES   NO.MMS  -1      # ITEMS IN "PREMM1" TABLE - 1.  *DON'T MOVE*

DNLADMM1        EQUALS
                ADRES   RENDEZVU        # P79
                ADRES   RENDEZVU        # P78
                ADRES   RENDEZVU        # P77
                ADRES   RENDEZVU        # P76
```

```
ADRES   RENDEZVU        # P75
ADRES   RENDEZVU        # P74
ADRES   RENDEZVU        # P73
```

Uses +MGA 234, AOG 214, BESTI 145, DAPDATR1 200, EBANK 80, ESTROKER 198, I 206, KMPAC 209, KT 181, LANDMARK 190, MARKINDX 145, MM 226, P40TMP 238, QPLACE 191, STARIND 145, SUBEXIT 181, TIG 224, TIME2SAV 157, VERB37 57, and WHOCARES 244.

359 ⟨*Page CM0209* 359⟩≡ (306 2700)

```
                ADRES   RENDEZVU        # P72
                ADRES   ENTRYUPD        # P62
                ADRES   POWERED         # P61
                ADRES   COSTALIN
                ADRES   COSTALIN
                ADRES   COSTALIN        # P52
                ADRES   COSTALIN        # P51
                ADRES   POWERED         # P47
                ADRES   POWERED         # P41
                ADRES   POWERED         # P40
                ADRES   RENDEZVU        # P39
                ADRES   RENDEZVU        # P38
                ADRES   RENDEZVU        # P37
                ADRES   RENDEZVU        # P35
                ADRES   RENDEZVU        # P34
                ADRES   RENDEZVU        # P33
                ADRES   RENDEZVU        # P32
                ADRES   RENDEZVU
                ADRES   RENDEZVU        # P30
                ADRES   RENDEZVU        # P23
                ADRES   P22DNLST        # P22
                ADRES   RENDEZVU        # P21
                ADRES   RENDEZVU        # P20
                ADRES   RENDEZVU        # P17
                ADRES   COSTALIN        # P06
                ADRES   COSTALIN        # P01

DNLADP00        =       ZERO
COSTALIN        =       0
ENTRYUPD        =       1
RENDEZVU        =       2
POWERED         =       3

P22DNLST        =       4

# ORBITAL INTEGRATION CONSTANTS

# THESE CONSTANTS ARE USED IN COMPUTING THE SETTING OF MIDFLAG.

RMM             2DEC    2538.09 E3 B-27 # 800 KM ABOVE LUNAR SURFACE

RME             2DEC    7178165 B-29    # 800 KM ABOVE EQ. RADIUS

                BANK    13
                SETLOC  INTINIT
```

```
                BANK

                COUNT*  $$/INTIN

                EBANK=  RRECTCSM

STATEUP         SET     BOF             # EXTRAPOLATE CM STATE VECTOR
                        VINTFLAG
```

Uses COUNT 142, EBANK 80, INTINIT 61, MIDFLAG 95, ORBITAL 59, P21 219, RRECTCSM 172, STATE 138, and VINTFLAG 109.

360 ⟨*Page CM0210* 360⟩≡ (306 2700)

```
                        ORBWFLAG        # ALSO 6X6 W-MATRIX IF VALID
                        +3              #       FOR ORBITAL NAVIGATION
                SET
                        DIMOFLAG
                CLEAR   CALL
                        PRECIFLG
                        INTEGRV
                BON     DLOAD
                        SURFFLAG
                        STATEND
                        TETCSM
                STCALL  TDEC1
                        INTSTALL
                CLEAR   CALL            # EXTRAPOLATE LM STATE VECTOR
                        VINTFLAG
                        SETIFLGS        #       AND 6X6 W-MATRIX IF VALID
                BOF     SET
                        RENDWFLG        #       FOR RENDEZVOUS NAVIGATION
                        +2
                        DIMOFLAG
                SET     CALL
                        PRECIFLG
                        INTEGRV
STATEND         CLRGO
                        NODOFLAG
                        ENDINT

# THIS VINT IS CALLED BY MIDTOAV1 AND 2

THISVINT        SET     RVQ
                        VINTFLAG
```

Uses DIMOFLAG 109, NODOFLAG 105, ORBITAL 59, ORBWFLAG 107, PRECIFLG 107, RENDWFLG 117, STATE 138, SURFFLAG 127, TETCSM 172, VINTFLAG 109, and W 183.

3.3.5 restart tables

361 ⟨*restart tables* 361⟩≡ (245b)
⟨*Page CM0211* 362⟩
⟨*Page CM0212* 364⟩
⟨*Page CM0213* 366⟩
⟨*Page CM0214* 368⟩
⟨*Page CM0215* 370⟩
⟨*Page CM0216* 372⟩
⟨*Page CM0218* 376⟩
⟨*Page CM0219* 377⟩
⟨*Page CM0220* 378⟩
⟨*Page CM0221* 380⟩

362 ⟨*Page CM0211* 362⟩≡ (361 2796)

```
# RESTART TABLES
# --------------
#
# THERE ARE TWO FORMS OF RESTART TABLES FOR EACH GROUP.  THEY ARE KNOWN AS THE EVEN R
# RESTART TABLES.  THE ODD TABLES HAVE ONLY ONE ENTRY OF THREE LOCATIONS WHILE THE EV
# EACH USING THREE LOCATIONS.  THE INFORMATION AS TO WHETHER IT IS A JOB, WAITLIST, O
# WAY THINGS ARE PUT IN TO THE TABLES.
#
# A JOB HAS ITS PRIORITY STORED IN A PRDTTAB OF THE CORRECT PHASE SPOT -- A POSITIVE
# FINDVAC JOB, A NEGATIVE PRIORITY A NOVAC.  THE 2CADR OF THE JOB IS STORED IN THE CA
# FOR EXAMPLE,
#
#               5.7SPOT         OCT     23000
#                               2CADR   SOMEJOB
#
# A RESTART OF GROUP 5 WITH PHASE SEVEN WOULD THEN CAUSE SOMEJOB TO BE RESTARTED AS A
#
#               5.5SPOT         OCT     -23000
#                               2CADR   ANYJOB
#
# HERE A RESTART OF GROUP 5 WITH PHASE 7 WOULD CAUSE ANYJOB TO BE RESTARTED AS A NOVA
# A LONGCALL HAS ITS GENADR OF ITS 2CADR STORED NEGATIVELY AND ITS BBCON STORED POSIT
# PLACED THE LOCATION OF A DP REGISTER THAT CONTAINS THE DELTA TIME THAT LONGCALL HAD
# WITH.  EXAMPLE,
#
#               3.6SPOT         GENADR  DELTAT
#                               -GENADR LONGTASK
#                               BBCON   LONGTASK

#                               OCT     31000
#                               2CADR   JOBAGAIN
#
# THIS WOULD START UP LONGTASK AT THE APPROPRIATE TIME, OR IMMEDIATELY IF THE TIME HA
# BE NOTED THAT IF DELTAT IS IN A SWITCHED E BANK, THIS INFORMATION SHOULD BE IN THE
# TASK.  FROM ABOVE, WE SEE THAT THE SECOND PART OF THIS PHASE WOULD BE STARTED AS A
#
# WAITLIST CALLS ARE IDENTIFIED BY THE FACT THAT THEIR 2CADR IS STORED NEGATIVELY.  I
# IS POSITIVE, THEN IT CONTAINS THE DELTA TIME, IF PRDTTAB IS NEGATIVE THEN IT IS THE
# LOCATION CONTAINING THE DELTA TIME, THAT IS, THE TIME IS STORED INDIRECTLY. IT SHOU
# IF THE TIME IS STORED INDIRECTLY, THE BBCON MUST CONTAIN THE NECESSARY E BANK INFOR
# WAITLIST WE HAVE ONE FURTHER OPTION, IF -0 IS STORED IN PRDTTAB, IT WILL CAUSE AN I
# TASK.  EXAMPLES,
#
#                               OCT     77777           # THIS WILL CAUSE AN IMMEDIAT
#                               -2CADR  ATASK           # OF THE TASK "ATASK"
```

```
#
#                                DEC     200             # IF THE TIME OF THE 2 SECONDS SINCE DU
#                                -2CADR  DUMMY           # WAS PUT ON THE WAITLIST IS UP, IT WIL
#                                                        # IN 10 MS, OTHERWISE IT WILL BEGIN WHE
#                                                        # IT NORMALLY WOULD HAVE BEGUN.
```

Uses A 80, DELTAT 241, IT 185, PRIORITY 145, and RESTART 57.

364 ⟨*Page CM0212* 364⟩≡ (361 2796)

```
#                               -GENADR DTIME          # WHERE DTIME CONTAINS THE DE
#                               -2CADR  TASKTASK       # OTHERWISE THIS IS AS ABOVE
#
# ***** NOW THE TABLES THEMSELVES *****

                BANK    01
                SETLOC  RESTART
                BANK

                COUNT   01/RSTAB

PRDTTAB         EQUALS  12000                   # USED TO FIND THE PRIORITY OR DELTAT
CADRTAB         EQUALS  12001                   # THIS AND THE NEXT RELATIVE LOC CONT
                                                # RESTART 2CADR

SIZETAB         TC      1.2SPOT -12006
                TC      1.3SPOT -12004
                TC      2.2SPOT -12006
                TC      2.3SPOT -12004
                TC      3.2SPOT -12006
                TC      3.3SPOT -12004
                TC      4.2SPOT -12006
                TC      4.3SPOT -12004
                TC      5.2SPOT -12006
                TC      5.3SPOT -12004
                TC      6.2SPOT -12006
                TC      6.3SPOT -12004
1.2SPOT         EQUALS  3.2SPOT

# ANY MORE GROUP 1.EVEN RESTART VALUES SHOULD GO HERE.

1.3SPOT         DEC     120                     # THIS NUMBER MUST BE EQUAL C(JTAGTIN
                EBANK=  AOG
                -2CADR  SETJTAG

1.5SPOT         OCT     10000
                EBANK=  DAPDATR1
                2CADR   REDO40.9

1.7SPOT         OCT     10000
                EBANK=  ESTROKER
                2CADR   RELINUS

1.11SPOT        OCT     10000
                EBANK=  ESTROKER
```

```
                2CADR   PIKUP20

  # ANY MORE GROUP 1.ODD RESTART VALUES SHOULD GO HERE.

  2.2SPOT         EQUALS  1.2SPOT

  # ANY MORE GROUP 2.EVEN RESTART VALUES SHOULD GO HERE
```

Uses AOG 214, COUNT 142, DAPDATR1 200, EBANK 80, ESTROKER 198, LOC 145, PRIORITY 145, RESTART 57, and TC 169.

366 ⟨*Page CM0213* 366⟩≡ (361 2796)

```
2.3SPOT         GENADR  600SECS
                -GENADR STATEINT
                EBANK=  RRECTCSM
                BBCON   STATEINT

2.5SPOT         OCT     05000
                EBANK=  RRECTCSM
                2CADR   STATINT1

2.7SPOT         OCT     10000
                EBANK=  MRKBUF2
                2CADR   R22

2.11SPOT        OCT     14000
                EBANK=  LANDMARK
                2CADR   V94ENTER

2.13SPOT        OCT     10000
                EBANK=  MRKBUF2
                2CADR   REDOR22

# ANY MORE GROUP 2.ODD RESTART VALUES SHOULD GO HERE.

3.2SPOT         EQUALS  4.2SPOT

# ANY MORE GROUP 3.EVEN RESTART VALUES SHOULD GO HERE

3.3SPOT         OCT     20000
                EBANK=  TGO
                2CADR   S40.13

3.5SPOT         DEC     0
                DEC     0
                DEC     0

3.7SPOT         OCT     22000
                EBANK=  TEPHEM
                2CADR   MATRXJOB

3.11SPOT        OCT     22000
                EBANK=  TEPHEM
                2CADR   REP11

3.13SPOT        OCT     22000
```

```
                EBANK=  TEPHEM
                2CADR   REP11A

  3.15SPOT      -GENADR TGO     +1
                EBANK=  TGO
                -2CADR  ENGINOFF
```

Uses EBANK 80, LANDMARK 190, RESTART 57, RRECTCSM 172, TEPHEM 172, and TGO 224.

368 ⟨*Page CM0214* 368⟩≡ (361 2796)

```
# ANY MORE GROUP 3.ODD RESTART VALUES SHOULD GO HERE

4.2SPOT         OCT     77777
                EBANK=  TIG
                -2CADR  PRECHECK

                OCT     30000
                EBANK=  DELVIMU
                2CADR   P47BODY

4.4SPOT         OCT     77777
                EBANK=  TIG
                -2CADR  PRECHECK

                DEC     2996
                EBANK=  DAPDATR1
                -2CADR  TTG/0

4.6SPOT         OCT     77777
                EBANK=  TIG
                -2CADR  PRECHECK

                DEC     2496
                EBANK=  TIG
                -2CADR  TIG-5

# ANY MORE GROUP 4.EVEN RESTART VALUES SHOULD GO HERE

4.3SPOT         DEC     40
                EBANK=  PACTOFF
                -2CADR  DOTVCON

4.5SPOT         DEC     160
                EBANK=  PACTOFF
                -2CADR  DOSTRULL

4.7SPOT         DEC     500
                EBANK=  PACTOFF
                -2CADR  TIG-0

4.11SPOT        DEC     250
                EBANK=  DAPDATR1
                -2CADR  V97E40.6

4.13SPOT        DEC     200
```

```
                EBANK=  WHOCARES
                -2CADR  R40ENABL

4.15SPOT        OCT     16000                   # PRELAUNCH OPTICAL VERIFICATION
                EBANK=  OGC
```

Uses DAPDATR1 200, DELVIMU 238, EBANK 80, OGC 186, PACTOFF 198, RESTART 57, TIG 224, and WHOCARES 244.

370 ⟨*Page CM0215* 370⟩≡ (361 2796)

```
                 2CADR   COMPVER                 # CALLS FOR OPTICS DATA AGAIN (STD LE

4.17SPOT         OCT     16000
                 EBANK=  XSM
                 2CADR   AZMTHCG1

4.21SPOT         GENADR  P40TMP                  # DELTA TIME USED IN SETTING UP
                 -GENADR TIGBLNK                 # LONG CALL OF TIGBLNK BY P40,P41
                 EBANK=  P40TMP
                 BBCON   TIGBLNK

4.23SPOT         OCT     12000                   # PROTECT P40S/SV BY P40 P41
                 EBANK=  TIG
                 2CADR   P40S/SV

4.25SPOT         OCT     24000
                 EBANK=  BESTI
                 2CADR   PROG52

4.27SPOT         DEC     250
                 EBANK=  PACTOFF
                 -2CADR  DOTVCRCS

4.31SPOT         OCT     13000
                 EBANK=  STAR
                 2CADR   R51     +1

4.33SPOT         DEC     2100                    # PROTECT CONTINUING JOB TO START P63
                 EBANK=  AOG
                 -2CADR  WAKEP62

4.35SPOT         OCT     12000
                 EBANK=  DAPDATR1
                 2CADR   POSTBURN

4.37SPOT         DEC     500
                 EBANK=  TIG
                 -2CADR  TIGAVEG

4.41SPOT         OCT     17000                   # PROTECT DISPLAY JOB IN P67
                 EBANK=  AOG
                 2CADR   P67.1

4.43SPOT         -GENADR S61DT                   # PROTECT TASK TO START PREREAD,ENTRY
                 EBANK=  S61DT                   # S61.1C WILL CHANGE EBANK=EB7 FOR PR
```

```
                -2CADR  S61.1C

4.45SPOT        OCT     13000                   # PROTECT CONTINUING JOB S61.1
                EBANK=  AOG                     # (ENTRY IMU ALIGNMENT)
```

Uses AOG 214, BESTI 145, DAPDATR1 200, EBANK 80, LONG 157, P40S 65, P40TMP 238, PACTOFF 198, S61DT 223, STAR 186, TIG 224, and XSM 186.

372 ⟨*Page CM0216* 372⟩≡ (361 2796)

```
                    2CADR   S61.1A  -1

4.47SPOT            OCT     17000                   # PROTECT HUNTEST ITERATION
                    EBANK=  AOG
                    2CADR   PRE-HUNT

4.51SPOT            OCT     77777                   # PROTECT FDAI ATTITUDE
                    EBANK=  BODY3                   # ERROR DISPLAY IN P11
                    -2CADR  ATERTASK

4.53SPOT            DEC     -0
                    EBANK=  END-E7                  # EBANK7 FOR TIG
                    -2CADR  V97ETASK

4.55SPOT            OCT     13000                   # PROTECT P65 RESPONSIVE DISPLAY.
                    EBANK=  RTINIT
                    2CADR   P65.1

4.57SPOT            -GENADR P40TMP
                    EBANK=  P40TMP
                    -2CADR  TIGON

4.61SPOT            OCT     77777
                    EBANK=  PACTOFF
                    -2CADR  IGNITION

4.63SPOT            OCT     77777
                    EBANK=  PACTOFF
                    -2CADR  DOSPSOFF

4.65SPOT            DEC     10
                    EBANK=  TIG
                    -2CADR  TIG-5

4.67SPOT            DEC     -0
                    EBANK=  CSMMASS
                    -2CADR  V97TTASK

4.71SPOT            DEC     250
                    EBANK=  DAPDATR1                # (FOR RCSDAPON)
                    -2CADR  V97TRCS

4.73SPOT            DEC     -0
                    EBANK=  V97VCNTR
                    -2CADR  V97PTASK
```

```
4.75SPOT        DEC     -0
                EBANK=  DAPDATR1
                -2CADR  SPSOFF97
```

Uses AOG 214, BODY3 221, CSMMASS 200, DAPDATR1 200, EBANK 80, END-E7 244, P40TMP 238, PACTOFF 198, RTINIT 226, TIG 224, and V97VCNTR 200.

374 ⟨*Page CM0217* 374⟩≡ (2796)

```
4.77SPOT        DEC     -0
                EBANK=  PACTOFF
                -2CADR  TIG-0

# ANY MORE GROUP 4.ODD RESTART VALUES SHOULD GO HERE

5.2SPOT         OCT     32000
                EBANK=  DVCNTR
                2CADR   NORMLIZE

                DEC     200
                EBANK=  AOG
                -2CADR  REREADAC

5.4SPOT         OCT     20000
                EBANK=  DVCNTR
                2CADR   SERVICER

                DEC     200
                EBANK=  AOG
                -2CADR  REREADAC

# ANY MORE GROUP 5.EVEN RESTART VALUES SHOULD GO HERE

5.3SPOT         DEC     200
                EBANK=  AOG
                -2CADR  REREADAC

5.5SPOT         OCT     77777
                EBANK=  AOG
                -2CADR  REDO5.5

5.7SPOT         OCT     20000                   # USED BY PRELAUNCH
                EBANK=  XSM
                2CADR   RSTGTS1

5.11SPOT        OCT     77777
                EBANK=  XSM
                -2CADR  ALLOOP1

5.13SPOT        OCT     20000
                EBANK=  XSM
                2CADR   WTLISTNT

5.15SPOT        OCT     20000
```

```
                EBANK=  XSM
                2CADR   RESTEST1

5.17SPOT        OCT     20000
                EBANK=  XSM
```

Uses AOG 214, DVCNTR 224, EBANK 80, PACTOFF 198, RESTART 57, TIG 224, and XSM 186.

376 ⟨*Page CM0218* 376⟩≡ (361 2796)

```
                  2CADR   GEOSTRT4

5.21SPOT          OCT     22000
                  EBANK=  XSM
                  2CADR   ALFLT1

5.23SPOT          OCT     77777
                  EBANK=  XSM
                  -2CADR  SPECSTS

5.25SPOT          OCT     20000
                  EBANK=  XSM
                  2CADR   RESTEST3

5.27SPOT          OCT     20000
                  EBANK=  XSM
                  2CADR   RESTAIER

5.31SPOT          DEC     0
                  DEC     0
                  DEC     0

5.33SPOT          OCT     20000
                  EBANK=  XSM
                  2CADR   RESCHNG

5.35SPOT          DEC     0
                  2DEC    0

5.37SPOT          OCT     77777
                  EBANK=  AOG
                  -2CADR  CHEKAVEG

5.41SPOT          OCT     77777                   # TO PROTECT PREREAD AT TIG-30A
                  EBANK=  DVCNTR                  #       TIG-15 T+60
                  -2CADR  PREREAD

# ANY MORE GROUP 5.ODD RESTART VALUES SHOULD GO HERE

6.2SPOT           OCT     77777                   # USED BY P40 AFTER GIMB DR TST TO RE
                  EBANK=  AK                      # ENGINE UNTIL TVCDAPON
                  -2CADR  PRE40.6

                  DEC     100
                  EBANK=  TTOGO
```

```
                -2CADR  CLOKTASK

  # ANY MORE 6.ODD RESTART VALUES SHOULD GO HERE
```

Uses AK 200, AOG 214, DVCNTR 224, EBANK 80, RESTART 57, TIG 224, TTOGO 236, and XSM 186.

377 ⟨*Page CM0219* 377⟩≡ (361 2796)

```
  6.3SPOT         DEC     100
                  EBANK=  TIG
                  -2CADR  CLOKTASK

  6.5SPOT         OCT     30000                   # PROTECT INCREMENTING OF TIME2,TIME1 BY
                  EBANK=  TEPHEM                  # P27(UPDATE PROGRAM)
                  2CADR   TIMEDIDR

  6.7SPOT         OCT     0
                  OCT     0
                  OCT     0

  6.11SPOT        -GENADR CM/GYMDT                # PROTECT TASK TO READ CDUS.
                  EBANK=  CM/GYMDT                # FOR ENTRY DAP
                  -2CADR  READGYMB

  6.13SPOT        DEC     0
                  DEC     0
                  DEC     0
```

Uses CDUS 80, CM/GYMDT 216, EBANK 80, TEPHEM 172, TIG 224, TIME1 80, and TIME2 80.

378 ⟨*Page CM0220* 378⟩≡ (361 2796)

```
# PROGRAM DESCRIPTION: NEWPHASE                                          DATE:  11 NOV
# MOD: 1                                                                 ASSEMBLY:  SU
# MOD BY: COPPS                                                          LOG SECTION:
#
# FUNCTIONAL DESCRIPTION:
#
#       NEWPHASE IS THE QUICK WAY TO MAKE A NON VARIABLE PHASE CHANGE.  IT INCLUDES T
#       TBASE OF THE GROUP.  IF TBASE IS TO BE SET, -C(TIME1) IS STORED IN THE TBASE
#
#               (L-1)   TBASE0
#               (L)     TBASE1  (IF GROUP=1)
#               (L+1)
#               (L+2)   TBASE2  (IF GROUP=2)
#               -----
#               (L+6)   TBASE4  (IF GROUP=4)
#               (L+7)
#               (L+8)   TBASE5  (IF GROUP=5)
#
#       IN ANY CASE, THE NEGATIVE OF THE PHASE, FOLLOWED (IN THE NEXT REGISTER) BY TH
#       PHASE TABLE AS FOLLOWS:
#
#               (L)     -PHASE1 (IF GROUP=1)
#               (L+1)   PHASE1
#               (L+2)   -PHASE2 (IF GROUP=2)
#               (L+3)   PHASE2
#               -----
#               (L+7)   PHASE4
#               (L+8)   -PHASE5 (IF GROUP=5)
#               (L+9)   PHASE5
#
# CALLING SEQUENCE:
#
#       EXAMPLE IS FOR PLACING A PHASE OF FIVE INTO GROUP THREE:
#
#       1)      IF TBASE IS NOT TO BE SET:
#                       L-1     CA      FIVE
#                       L       TC      NEWPHASE
#                       L+1     OCT     00003
#
#       2)      IF TBASE IS TO BE SET:
#                       L-1     CS      FIVE
#                       L       TC      NEWPHASE
#                       L+1     OCT     00003
#
# SUBROUTINES CALLED:  NONE
```

```
#
# NORMAL EXIT MODE:  AT L+2 OF CALLING SEQUENCE
#
# ALARM OR ABORT EXITS:  NONE
#
# OUTPUT:  PHASE TABLE AND TBASE TABLE UPDATED
#
# ERASABLE INITIALIZATION REQ'D:  NONE
```

Uses -PHASE1 152, -PHASE2 152, -PHASE5 152, A 80, IT 185, L 80, MODE 145, PHASE1 152, PHASE2 152, PHASE4 152, PHASE5 152, TBASE1 154, TBASE2 154, TBASE4 154, TBASE5 154, TC 169, and TIME1 80.

380 ⟨*Page CM0221* 380⟩≡ (361 2796)

```
# DEBRIS:  A,L,TEMPG

# *** WARNING *** THIS PROGRAM IS TO BE PLACED IN FIXED-FIXED AND UNSWITCHED ERASABLE

                BLOCK   02
                SETLOC  FFTAG1
                BANK

                COUNT*  $$/PHASE

NEWPHASE        INHINT

                TS      L                       # SAVE FOR FURTHER USE

                NDX     Q                       # OBTAIN THE GROUP NUMBER
                CA      0
                INCR    Q                       # OBTAIN THE RETURN ADDRESS
                DOUBLE                          # SAVE THE GROUP IN A FORM USED FOR
                TS      TEMPG                   # INDEXING

                CCS     L                       # SEE IF WE ARE TO SET TBASE
                TCF     +7                      # NO, THE DELTA T WAS POSITIVE
                TCF     +6

NUFAZ+10        INCR    A                       # SET TBASE AND STORE PHASE CORRECTLY
                TS      L

                CS      TIME1                   # SET TBASE
                NDX     TEMPG
                TS      TBASE1 -2

                CS      L                       # NOW PUT THE PHASE IN THE RIGHT TABL
                NDX     TEMPG
                DXCH    -PHASE1 -2

                RELINT
                TC      Q                       # NOW RETURN TO CALLER
```

Uses -PHASE1 152, A 80, COUNT 142, FFTAG1 57, L 80, LOC 145, PHASE1 152, Q 80, SAVE 191, TBASE1 154, TC 169, and TIME1 80.

3.3.6 sctmark code

381 ⟨*sxtmark code* 381⟩≡ (245b)

⟨*Page CM0222* 382⟩
⟨*Page CM0223* 384⟩
⟨*Page CM0224* 386⟩
⟨*Page CM0225* 388⟩
⟨*Page CM0226* 389⟩
⟨*Page CM0227* 390⟩
⟨*Page CM0228* 392⟩
⟨*Page CM0229* 394⟩
⟨*Page CM0230* 396⟩
⟨*Page CM0231* 397⟩
⟨*Page CM0232* 398⟩
⟨*Page CM0233* 400⟩
⟨*Page CM0234* 402⟩
⟨*Page CM0235* 403⟩

382 ⟨*Page CM0222* 382⟩≡ (381 2809)

```
# PROGRAM NAME:  SXTMARK                                        DATE:  5 APRIL 1967
# PROGRAM MODIFIED BY 258/278 PROGRAMMERS                       LOG SECTION SXTMARK
# MOD BY: R. MELANSON TO ADD DOCUMENTATION                      ASSEMBLY SUNDISK REV
#
# FUNCTIONAL DESCRIPTION:
#
#       SXTMARK IS CALLED FROM INTERNAL ROUTINES WHICH MAY REQUIRE STAR OR LANDMARK M
#       THE MARK SYSTEM IS NOT IN USE, SXTMARK RESERVES A VAC AREA FOR MARKING AND RE
#       ROUTINE VIA THE EXECUTIVE JOB PRIORITY LIST.  R21 USES THIS ROUTINE TO DETERM
#       USED.  IF YES, SXTMARK RETURNS TO R21 TO PERFORM ITS OWN MARK REQUESTS VIA TH
#
# CALLING SEQUENCE:
#
#       CAF     (NO. MARK REQUESTS IN BITS 1-3 OF A)
#       TC      BANKCALL
#       CADR    SXTMARK
#
# NORMAL EXIT MODE:
#
#       SWRETURN
#
# ALARM OR ABORT EXIT MODE:
#
#       ABORT
#
# OUTPUT:
#
#       1)      MARKSTAT CONTAINS MARK VALUE (BITS 14-12) AND VAC AREA ADDRESS
#       2)      QPRET = VAC AREA POINTER VALUE
#       3)      1ST WORD OF RESERVED VAC AREA SET TO +0
#       4)      PRIO32 PLACED IN A REGISTER
#
# ERASABLE INITIALIZATION:
#
#       1)      BITS 1-3 OF A = NO. MARKS REQUESTED
#       2)      BITS 2,3 OF EXTVBACT = 0
#       3)      A VAC AREA MUST BE AVAILABLE (WORD 1 = ADDRESS OF VAC AREA)
#
# DEBRIS:
#
#       A,Q,L,RUPTREG1,MARKSTAT,QPRET,BIT2 OF EXTVBACT

                BANK    13
                SETLOC  SXTMARKE
                BANK
```

```
                EBANK=  MRKBUF1
                COUNT   07/SXTMK

SXTMARK         INHINT
                TS      RUPTREG1                # NUMBER OF MARKS WANTED

                CAF     SIX                     # BIT2 = MARKING SYSTEM IN USE
                MASK    EXTVBACT                # BIT3 = EXTENDED VERB IN PROGRESS
                CCS     A
                TC      MKABORT
```

Uses A 80, COUNT 142, EBANK 80, EXTVBACT 154, L 80, LANDMARK 190, MARKSTAT 163, MODE 145, PRIORITY 145, Q 80, QPRET 85, RUPTREG1 138, STAR 186, SXTMARKE 59, and TC 169.

384 ⟨*Page CM0223* 384⟩≡ (381 2809)

```
                CAF     BIT2                    # NOT SET
                ADS     EXTVBACT                # SET IT, RESET IN ENDMARK
                TC      MARKOK                  # YES, FIND VAC AREA

MKABORT         TC      BAILOUT
                OCT     01211
MARKOK          CCS     VAC1USE                 # FIND VAC AREA
                TC      MKVACFND
                CCS     VAC2USE
                TC      MKVACFND
                CCS     VAC3USE
                TC      MKVACFND
                CCS     VAC4USE
                TC      MKVACFND
                CCS     VAC5USE
                TC      MKVACFND
                TC      BAILOUT
                OCT     01207

MKVACFND        AD      TWO                     # ADDRESS OF VAC AREA
                TS      MARKSTAT
                INDEX   A
                TS      QPRET                   # STORE NEXT AVAILABLE MARK SLOT

                CAF     ZERO                    # STORE VAC AREA OCCUPIED
                INDEX   MARKSTAT
                TS      0       -1

                TC      CHECKMM                 # BACKUP MARK ROUTINE USES SXTMARK
                MM      53
                TCF     +2
                TCF     SWRETURN
                TC      CHECKMM
                MM      54
                TCF     +2
                TCF     SWRETURN
                CAF     BIT12                   # DESIRED NUMBER OF MARKS IN 12-14
                EXTEND
                MP      RUPTREG1
                XCH     L
                ADS     MARKSTAT

                CAF     PRIO32                  # ENTER MARK JOB
                TC      NOVAC
                EBANK=  MARKSTAT
```

```
2CADR   MKVB51

RELINT
TCF     SWRETURN                # SAME AS MODEEXIT
```

Uses A 80, EBANK 80, EXTVBACT 154, IT 185, L 80, MARKSTAT 163, MM 226, QPRET 85, RUPTREG1 138, TC 169, VAC1USE 150, VAC2USE 150, VAC3USE 150, VAC4USE 150, and VAC5USE 150.

386 ⟨*Page CM0224* 386⟩≡ (381 2809)

```
# PROGRAM NAME:  MKRELEAS                                    DATE:  5 APRIL 1967
# PROGRAM MODIFIED BY 248/278 PROGRAMMERS                    LOG SECTION SXTMARK
# MOD BY:  R. MELANSON TO ADD DOCUMENTATION                  ASSEMBLY SUNDISK REV.
#
# FUNCTIONAL DESCRIPTION:
#
#       MKRELEAS IS EXECUTED BY INTERNAL ROUTINES TO RELEASE THE MARK SYSTEM TO MAKE
#       SYSTEM ROUTINES.  IT ALSO CLEARS THE COARSE OPTICS FLAG BIT AND DISABLES THE
#
# CALLING SEQUENCE:
#
#       TC      BANKCALL
#       CADR    MKRELEAS
#
# NORMAL EXIT MODE:
#
#       SWRETURN
#
# ALARM OR EXIT MODE:  NONE
#
# OUTPUT:
#
#       1)      BIT9 OPTMODES SET TO 0
#       2)      OPTIND SET TO -1
#       3)      1ST WORD OF VAC AREA SET TO VAC ADDRESS TO SIGNIFY AVAILABILITY
#       4)      MARKSTAT CLEARED
#       5)      BIT2 CHANNEL 12 SET TO 0
#
# ERASABLE INITIALIZATION:  NONE
#
# DEBRIS:
#
#       A,MARKSTAT,BIT9,OPTMODES OPTIND,BIT2 CHANNEL 12

MKRELEAS        CAF     ZERO                    # SHOW MARK SYSTEM NOW AVAILABLE
                XCH     MARKSTAT
                MASK    LOW9
                CCS     A
                INDEX   A
                TS      0
MKRLEES         INHINT
                CS      BIT9                    # COARSE OPTICS RETURN FLAG.
                MASK    OPTMODES
                TS      OPTMODES
```

```
CA      NEGONE
TS      OPTIND                  # KILL COARSE OPTICS

CS      BIT2                    # DISABLE OPTICS ERROR COUNTER
EXTEND
WAND    CHAN12

RELINT
TC      SWRETURN
```

Uses A 80, CHAN12 87, IT 185, MARKSTAT 163, MODE 145, OPTIND 161, OPTMODES 163, and TC 169.

388 ⟨*Page CM0225* 388⟩≡ (381 2809)

```
# PROGRAM NAME:  MARKRUPT                                    DATE:  5 APRIL 1967
# PROGRAM MODIFIED BY 258/278 PROGRAMMERS                    LOG SECTION SXTMARK
# MOD BY:  R. MELANSON TO ADD DOCUMENTATION                  ASSEMBLY SUNDISK REV
#
# FUNCTIONAL DESCRIPTION:
#
#       MARKRUPT STORES CDUS,OPTICS AND TIME AND TRANSFERS CONTROL TO THE MARKIT,MARK
#       BITS IN CHANNEL 16 ARE SET AS REQUIRED.
#
# CALLING SEQUENCE:
#
#       ROUTINE ENTERED VIA KEYRUPT2 WHEN MARK,MARK REJECT OR DSKY KEYS DEPRESSED BY
#
# NORMAL EXIT MODE:
#
#       MARKIT, MKREJECT, OR POSTJUMP ROUTINES (MARK, MARK REJECT, OR DSKY CODE)
#
# ALARM OR ABORT EXIT MODE:
#
#       ALARM AND RESUME
#
# OUTPUT:
#
#       RUPTSTOR+5 = CDUT, RUPTSTOR+3 = CDUS, RUPTSTOR+2 = CDUY,
#       RUPTREG3 = CDUZ, RUPTSTOR+6 = CDUX, RUPTSTOR+1 AND SAMPTIME+1 = TIME1,
#       RUPTSTOR AND SAMPTIME = TIME2
#
# ERASABLE INITIALIZATION:
#
#       CDUT,CDUS,CDUY,CDUZ,CDUX,TIME2,TIME1,CHANNEL 16 BITS 6,7 OR 1-5.
#
# DEBRIS:
#
#       A,QRUPT,RUPTREG3,SAMPTIME,SAMPTIME+1,RUPTSTOR TO RUPTSTOR+6 EXCEPT RUPTSTOR+4

MARKRUPT        TS      BANKRUPT                # STORE CDUS AND OPTICS NOW
                CA      CDUT
                TS      MKCDUT
                CA      CDUS
                TS      MKCDUS
                CA      CDUY
                TS      MKCDUY
                CA      CDUZ
                TS      MKCDUZ
                CA      CDUX
```

```
                TS      MKCDUX
                EXTEND
                DCA     TIME2                   # GET TIME
                DXCH    MKT2T1
                EXTEND
                DCA     MKT2T1
                DXCH    SAMPTIME                # RUPT TIME FOR NOUN 65.

                XCH     Q
                TS      QRUPT

                CAF     BIT6                    # SEE IF MARK OR MKREJECT
```

Uses A 80, BANKRUPT 80, CDUS 80, CDUT 80, CDUX 80, CDUY 80, CDUZ 80, CODE 140, MKCDUS 148, MKCDUT 148, MKCDUX 148, MKCDUY 148, MKCDUZ 148, MKT2T1 148, MODE 145, Q 80, QRUPT 80, RUPTREG3 138, RUPTSTOR 138, SAMPTIME 80, TIME1 80, and TIME2 80.

389 ⟨*Page CM0226* 389⟩≡ (381 2809)

```
                EXTEND
                RAND    NAVKEYIN
                CCS     A
                TC      MARKIT                  # IT'S A MARK

                CAF     BIT7                    # NOT A MARK, SEE IF MKREJECT
                EXTEND
                RAND    NAVKEYIN
                CCS     A
                TC      MKREJECT                # IT'S A MARK REJECT

  KEYCALL       CAF     OCT37                   # NOT MARK OR MKREJECT, SEE IF KEYCODE
                EXTEND
                RAND    NAVKEYIN
                EXTEND
                BZF     +3                      # IF NO INBITS
                TC      POSTJUMP
                CADR    KEYCOM                  # IT'S A KEY CODE, NOT A MARK.

          +3    TC      ALARM                   # ALARM IF NO INBITS
                OCT     113
                TC      RESUME
```

Uses A 80, CODE 140, NAVKEYIN 87, and TC 169.

390 ⟨*Page CM0227* 390⟩≡ (381 2809)

```
# PROGRAM NAME:  MARKCONT                                DATE:  19 SEPT 1967
# PROGRAM MODIFIED BY 258/278 PROGRAMMERS                LOG SECTION SXTMARK
# MOD BY:  R. MELANSON TO ADD DOCUMENTATION              ASSEMBLY SUNDISK REV. 116
#
# FUNCTIONAL DESCRIPTION:
#
#       MARKCONT IS USED TO PERFORM A SPECIAL MARK FUNCTION FOR R21, TO EXECUTE A SPE
#       TO PERFORM A MARK OF THE STAR OR LAND SIGHTING BASED UPON FLASHING V-N.
#
# CALLING SEQUENCE:
#
#       FROM MARKDIF
#
# NORMAL EXIT MODE:
#
#       TASKOVER
#
# ALARM OR ABORT EXIT MODE:
#
#       ALARM AND TASKOVER
#
# OUTPUT:
#
#       1)      FOR R21:
#               EBANK=EBANK7
#               MRKBUF1 TO MRKBUF1+6 = TIME2,TIME1,CDUY,OPTICX,CDUZ,OPTICSY,CDUX OF C
#               MRKBUF2 TO MRKBUF2+6 CONTAINS PREVIOUS R21 MARK VALUES.
#       2)      FOR SPECIAL DISPLAY JOB:
#               RUPTREG1 AND MRKBUF1 = CDUS,RUPTREG2, AND MRKBUF1+1 = CDUT.
#               RUPTREG3 AND MRKBUF1+2 = TIME2,RUPTREG4, AND MRKBUF1+3 = TIME1.
#       3)      FOR NORMAL MARKING:
#               DECREMENT BITS14-12 OF MARKSTAT BY 1,
#               BIT10 MARKSTAT SET TO 1, INCREMENT QPRET BY 7,
#               STORE TIME2,TIME1,CDUY,CDUS,CDUZ,CDUT, AND CDUX IN VAC+1 TO VAC+7.
#
# ERASABLE INITIALIZATION:
#
#       1)      FOR R21:
#               BIT14 OF STATE+2 =1, MRKBUF1 TO MRKBUF1+6, ITEMP1, RUPTREG3,
#               RUPTSTOR TO RUPTSTOR+6 EXCEPT RUPTSTOR+4.
#       2)      FOR SPECIAL DISPLAY JOB:
#               BIT14 OF STATE+2 =0, MARKSTAT =+0, RUPTREG1,RUPTREG2,RUPTREG3
#               RUPTREG4,RUPTSTOR,RUPTSTOR+1,RUPTSTOR+3,RUPTSTOR+5,
#               BIT12 OF STATE+5 (V59 FLAG), MRKBUF1 THRU MRKBUF1+3
#       3)      FOR NORMAL MARKING:
```

```
#               BIT14 OF STATE+2 =0, MARKSTATE =VAC ADDRESS, A REG, ITEMP1, RUPTREG3,
#               RUPTSTOR TO RUPTSTOR+6 EXCEPT RUPTSTOR+4.
#
# DEBRIS:
#
#       1)      FOR R21:
#               A, ITEMP1, MRKBUF1, MRKBUF2
#       2)      FOR SPECIAL DISPLAY JOB:
#               A,RUPTREG1,RUPTREG2,RUPTREG3,RUPTREG4,MPAC TO MPAC+3.
#       3)      FOR NORMAL MARKING:
#               A,MARKSTAT,ITEMP1,QPRET,VAC+1 TO VAC+7 OF VAC AREA IN USE.
```

Uses A 80, CDUS 80, CDUT 80, CDUX 80, CDUY 80, CDUZ 80, EBANK 80, ITEMP1 138, MARKSTAT 163, MODE 145, MPAC 145, N 206, QPRET 85, RUPTREG1 138, RUPTREG2 138, RUPTREG3 138, RUPTREG4 138, RUPTSTOR 138, STAR 186, STATE 138, TIME1 80, TIME2 80, and V 229.

392 ⟨*Page CM0228* 392⟩≡ (381 2809)

```
MARKCONT        CAF     BIT14
                MASK    STATE   +2              # R21 MARK (SPECIAL MARKING FOR R21)
                EXTEND
                BZF     MARKET                  # NOT SET THEREFORE REGULAR MARKING
MARKIT1         CAF     SIX                     # SPECIAL FOR R21
                TC      GENTRAN                 # TRANSFER MRKBUF1 TO MRKBUF2
                ADRES   MRKBUF1
                ADRES   MRKBUF2

                CAF     SIX                     # TRANSFER CURRENT MARK DATE TO MARKE
                TC      GENTRAN
                ADRES   MKT2T1
                ADRES   MRKBUF1

                TCF     TASKOVER

MARKET          CCS     MARKSTAT                # SEE IF MARKS CALLED FOR
                TC      MARK2                   # COLLECT MARKS

                CAF     TWO                     # IS MARKING SYSTEM IN USE (BIT2)
                MASK    EXTVBACT
                EXTEND
                BZF     MARKET3                 # MARKING NOT CALLED FOR
                CAF     BIT12
                MASK    STATE   +5              # V59FLAG
                EXTEND
                BZF     MARKET3                 # IF V59FLAG NOT SET-MARK UNCALLED FO
                CAF     PRIO5                   # CALIBRATION MARK (SET) FOR P23
                TC      NOVAC                   # SPECIAL DISPLAY JOB
                EBANK=  MRKBUF1
                2CADR   MARKDISP

                CAF     SIX
                TC      GENTRAN                 # TRANSFER MARK DATE TO MARKDOWN
                ADRES   MKT2T1
                ADRES   MARKDOWN
                CAF     SIX
                TC      GENTRAN                 # TRANSFER MARK DATA TO MRKBUF1 FOR
                ADRES   MKT2T1                  # SPECIAL DISPLAY OF SHAFT AND TRUNNI
                ADRES   MRKBUF1                 # IF V59 ACTING
                TCF     TASKOVER
MARKET3         TC      ALARM
                OCT     122                     # MARKING NOT CALLED FOR
                TCF     TASKOVER
114ALM          TC      ALARM                   # MARK NOT WANTED
```

```
OCT     114
TCF     TASKOVER
```

Uses EBANK 80, EXTVBACT 154, MARKDOWN 239, MARKSTAT 163, MKT2T1 148, STATE 138, TC 169, and V59FLAG 113.

394 ⟨*Page CM0229* 394⟩≡ (381 2809)

```
# STORE MARK DATA IN MKVAC AND INCREMENT POINTER

MARK2           AD      74K                     # SEE IF MARKS WANTED-REDUCE MARKS WA
                EXTEND
                BZMF    114ALM                  # MARK NOT WANTED-ALARM
                TS      MARKSTAT
                COM
                MASK    BIT10                   # SET BIT10 TO ENABLE REJECT
                ADS     MARKSTAT

                MASK    LOW9
                TS      ITEMP1
                INDEX   A
                XCH     QPRET                   # PICK UP MARK SLOT-POINTER
                TS      ITEMP2                  # SAVE CURRENT POINTER
                AD      SEVEN                   # INCREMENT POINTER
                INDEX   ITEMP1
                TS      QPRET                   # STORE ADVANCED POINTER

VACSTOR         EXTEND
                DCA     MKT2T1
                INDEX   ITEMP2
                DXCH    0
                CA      MKCDUY
                INDEX   ITEMP2
                TS      2
                CA      MKCDUS
                INDEX   ITEMP2
                TS      3
                CA      MKCDUZ
                INDEX   ITEMP2
                TS      4
                CA      MKCDUT
                INDEX   ITEMP2
                TS      5
                CA      MKCDUX
                INDEX   ITEMP2
                TS      6

                CAF     PRIO34                  # IF ALL MARKS MADE FLASH VB50
                MASK    MARKSTAT
                EXTEND
                BZF     +2
                TCF     TASKOVER
                CAF     PRIO32
```

```
TC      NOVAC
EBANK=  MARKSTAT
2CADR   MKVB50

TCF     TASKOVER
```

Uses A 80, EBANK 80, ITEMP1 138, ITEMP2 138, MARKSTAT 163, MKCDUS 148, MKCDUT 148, MKCDUX 148, MKCDUY 148, MKCDUZ 148, MKT2T1 148, QPRET 85, SAVE 191, and TC 169.

396 ⟨*Page CM0230* 396⟩≡ (381 2809)

```
# PROGRAM NAME:  MKREJECT                                    DATE:  5 APRIL 1967
# PROGRAM MODIFIED BY 258/276 PROGRAMMERS                    LOG SECTION SXTMARK
# MOD BY:  R. MELANSON TO ADD DOCUMENTATION                  ASSEMBLY SUNDISK REV
#
# FUNCTIONAL DESCRIPTION:
#
#       ROUTINE ALLOWS OPEATOR TO REJECT MARK MADE PRIOR TO ACCEPTANCE AND ALLOWS A N
#
# CALLING SEQUENCE:
#
#       FROM MARKRUPT IF BIT7 OF CHANNEL 16 IS 1.
#
# NORMAL EXIT MODE:
#
#       RESUME
#
# ALARM OR ABORT EXIT MODE:
#
#       ALARM AND RESUME
#
# OUTPUT:
#
#       1)      FOR R21:
#               MRKRUP1 SET TO -1
#       2)      FOR NORMAL MARKING:
#               BIT10 MARKSTAT =0, INCREMENT NO. MARKS BY 1, DECREMENT QPRET BY 7
#
# ERASABLE INITIALIZATION:
#
#       1)      FOR R21:
#               BIT14 OF STATE+2 SET TO 1
#       2)      FOR NORMAL MARKING:
#               BIT14 OF STATE+2 SET TO 0, MARKSTAT,QPRET
#
# DEBRIS:
#
#       1)      FOR R21:
#               A,MARKSTAT,EBANK
#       2)      FOR NORMAL MARKING:
#               A,MARKSTAT,ITEMP1,QPRET

MKREJECT        CAF     BIT14
                MASK    STATE   +2              # R21 MARK (SPECIAL MARKING FOR R21)
                EXTEND
                BZF     MRKREJCT                # NOT SET THEREFORE REGULAR REJECT
```

```
                CA      NEGONE              # -1 (FOR R22)
                TS      MRKBUF1             # -0 IN TIME IS FLAG TO R22 SIGNIFYING A
                TC      RESUME              # REJECTED MARK
MRKREJCT        CCS     MARKSTAT            # SEE IF MARKS BEING ACCEPTED
                TC      REJECT2
                TC      ALARM               # MARKS NOT BEING ACCEPTED
                OCT     112
                TC      RESUME

REJECT2         CS      BIT10               # SEE IF MARK HAD BEEN MADE SINCE LAST
                MASK    MARKSTAT            # REJECT, AND SET BIT10 TO ZERO TO
                XCH     MARKSTAT            # SHOW MARK REJECT
```

Uses A 80, EBANK 80, ITEMP1 138, MARKSTAT 163, MODE 145, QPRET 85, STATE 138, and TC 169.

397 ⟨*Page CM0231* 397⟩≡ (381 2809)

```
                MASK    BIT10
                CCS     A
                TC      REJECT3

                TC      ALARM               # DON'T ACCEPT TWO REJECTS TOGETHER
                OCT     110
                TC      RESUME

REJECT3         CAF     LOW9                # DECREMENT POINTER TO REJECT MARK
                MASK    MARKSTAT
                TS      ITEMP1
                CS      SEVEN
                INDEX   ITEMP1
                ADS     QPRET               # NEW POINTER

                CAF     BIT12               # INCREMENT MARKS WANTED AND IF FIELD
                AD      MARKSTAT            # IS NOW NON-ZERO, CHANGE TO VB51 TO
                XCH     MARKSTAT            # INDICATE MORE MARKS WANTED
                MASK    PRIO34              # INDICATE MORE MARKS WANTED
                CCS     A
                TC      RESUME
                CAF     PRIO32
                TC      NOVAC
                EBANK=  MARKSTAT
                2CADR   MKVB51

                TC      RESUME
```

Uses A 80, EBANK 80, ITEMP1 138, MARKSTAT 163, QPRET 85, and TC 169.

398 ⟨*Page CM0232* 398⟩≡ (381 2809)

```
# PROGRAM DESCRIPTION MKVB51 AND MKVB50
#
# AUTHOR:       BARNERT         DATE: 2-15-67           MOD: 0
# PURPOSE:      FLASH V51N70,V51N43, OR V51 TO REQUEST MARKING,
#               AND V50N25 R1=16 TO REQUEST TERMINATE MARKING.
#
# CALLING SEQUENCE:     AS JOB WITHIN SXTMARK
#
# EXIT TO ENDMARK UPON RECEIPT OF V33, V34 CAUSES GOTOP00H, ENTER
#       RECYCLES THE DISPLAY
#
# NOTE: SXTMARK AUTOMATICALLY CHANGES FROM CALLING MKVB51 TO MKVB50 WHEN
#       SUFFICIENT MARKS HAVE BEEN MADE, AND THE REVERSE WHEN A MARK
#       REJECT REDUCES THE NUMBER MADE BELOW THAT REQUIRED
#
# SUBROUTINES CALLED:  BANKCALL, GOMARK2, GOODEND, ENDMARK, WAITLIST
#
# ALARM OR ABORT MODES:  NONE
#
# ERASABLE USED:  VERBREG, MARKSTAT, QPRET, DSPTEM1
#
# OUTPUT MARKSTAT = VAC ADDRESS

# QPRET = NO. MARKS

MKVB51          TC      BANKCALL                # CLEAR DISPLAY FOR MARK VERB
                CADR    KLEENEX
                CAF     VB51                    # DISPLAY MARK VB51
                TC      BANKCALL
                CADR    GOMARK4
                TCF     TERMSXT                 # VB34-TERMINATE
                TCF     ENTANSWR                # V33-PROCEED-MARKING DONE
                TCF     MKVB5X                  # ENTER-RECYCLE TO INITIAL MARK DISPI

TERMSXT         TC      CLEARMRK                # CLEAR MARK ACTIVITY.

                TC      CHECKMM
                MM      03
                TCF     +2
                TC      TERMP03
                TC      POSTJUMP
                CADR    TERM52

TERMP03         TC      UPFLAG
                ADRES   TRM03FLG
```

```
ENTANSWR        CAF     LOW9                    # PUT VAC ADR IN MARKSTAT AND NO. OF
                MASK    MARKSTAT                # MARKS MADE IN QPRET BEFORE LEAVING
                TS      MARKSTAT                # SXTMARK
                COM
                INDEX   MARKSTAT
                AD      QPRET
```

Uses A 80, DSPTEM1 154, MARKSTAT 163, MM 226, QPRET 85, TC 169, TRM03FLG 101, and VERBREG 152.

400 ⟨*Page CM0233* 400⟩≡ (381 2809)

```
                EXTEND
                BZMF    JAMIT                   # NO MARKS MADE, SHOW IT IN QPRET, R5
                EXTEND                          #       WILL PICK IT UP AND RECYCLE
                MP      BIT12                   # THIS PUTS NUMBER MARKS-1 IN A
                AD      ONE
JAMIT           INDEX   MARKSTAT                # STORE NO OF MARKS MADE
                TS      QPRET
                INHINT                          # SERVICE OPTSTALL INTERFACE WITH
                CAF     FIVE
                TC      WAITLIST
                EBANK=  MARKSTAT
                2CADR   ENDMARKS

                TC      ENDMARK                 # KNOCKS DOWN MARKING FLAG + DOES END

ENDMARKS        CAF     ONE
                TC      IBNKCALL
                CADR    GOODEND
MKVB5X          CAF     PRIO34
                MASK    MARKSTAT                # RE-DISPLAY VB51 IF MORE MARKS WANTE
                CCS     A                       # AND VB50 IF ALL IN
                TCF     MKVB51
MKVB50          CAF     R1D1                    # OCT 16
                TS      DSPTEM1
                CAF     V50N25
                TCF     MKVB51  +3

V50N25          VN      5025
VB51            VN      5100
OCT37           =       LOW5

# PROGRAM NAME:  MARKIT                         DATE: 19 SEPT 1967
#
# CALLING SEQUENCE:
#
#       FROM MARKRUPT IF CHAN 16 BIT 6 = 1
#
# EXIT
#
#       RESUME
#
# INPUT
#
#       CDUCHKWD.  ALSO ALL INITIALIZATION FOR MARKCONT
#
```

```
# OUTPUT
#
#       MKT2T1,MKCDUX,MKCDUY,MKCDUZ,MKCDUS,MKCDUT
#
# ALARM EXIT
#
#       NONE

MARKIT          CCS     CDUCHKWD
                TCF     +3                      # DELAY OF CDUCHKWD CS IF PNZ
```

Uses A 80, CDUCHKWD 165, CHAN 191, DSPTEM1 154, EBANK 80, IT 185, MARKSTAT 163, MKCDUS 148, MKCDUT 148, MKCDUX 148, MKCDUY 148, MKCDUZ 148, MKT2T1 148, QPRET 85, TC 169, and VN 159.

402 ⟨*Page CM0234* 402⟩≡ (381 2809)

```
                TCF     +2
                CAF     ZERO
                AD      ONE                     # 10 MS IF NO CHECK
                TC      WAITLIST
                EBANK=  MRKBUF1
                2CADR   MARKDIF

                TCF     RESUME

                SETLOC  SXTMARK1
                BANK

                COUNT   20/SXTMK

# PROGRAM NAME:  MARKDIF
#
# CALLING SEQUENCE
#
#       WAITLIST FROM MARKIT
#
# EXIT
#
#       TASKOVER TO IBNKCALL TO MARKCONT
#
# INPUT
#
#       OUTPUT FROM MARKIT, INPUT TO MARKCONT, CDUCHKWD
#
# OUTPUT
#
#       RUPTSTOR - RUPTSTOR+3, RUPTREG3, RUPTSTOR+5 - RUPTSTOR+6
#
# ALARM EXIT
#
#       ALARM AND TASKOVER

MARKDIF         CA      CDUCHKWD                # IF DELAY CHECK IS ZERO OR NEG, ACP
                EXTEND
                BZMF    MKACPT
                CS      BIT1
                TS      MKNDX                   # SET INDEX -1
                CA      MKCDUX
                TC      DIFCHK                  # SEE IF VEHICLE RATE TO MUCH AT MARK
                CA      MKCDUY
                TC      DIFCHK
```

```
                CA      MKCDUZ
                TC      DIFCHK

MKACPT          TC      IBNKCALL
                CADR    MARKCONT                # MARK DATA OK, WHAT DO WE DO WITH IT

DIFCHK          INCR    MKNDX                   # INCREMENT INDEX

                EXTEND
                INDEX   MKNDX
```

Uses CDUCHKWD 165, COUNT 142, EBANK 80, IT 185, MKCDUX 148, MKCDUY 148, MKCDUZ 148, MKNDX 148, RUPTREG3 138, RUPTSTOR 138, SXTMARK1 59, and TC 169.

403 ⟨*Page CM0235* 403⟩≡ (381 2809)

```
                MSU     CDUX                    # GET MARK(ICDU) - CURRENT(ICDU)
                CCS     A
                TCF     +4
                TC      Q
                TCF     +2
                TC      Q
                AD      NEG2                    # SEE IF DIFFERENCE GREATER THAN 3 BITS
                EXTEND
                BZMF    -3                      # NOT GREATER

                TC      ALARM                   # COUPLED WITH PROGRAM ALARM
                OCT     00121

                TCF     TASKOVER                # DO NOT ACCEPT
```

Uses A 80, CDUX 80, Q 80, and TC 169.

3.3.7 extended verbs

404 ⟨*extended verbs* 404⟩≡ (245b)

⟨*Page CM0236* 405⟩
⟨*Page CM0237* 407⟩
⟨*Page CM0238* 408⟩
⟨*Page CM0239* 409⟩
⟨*Page CM0240* 410⟩
⟨*Page CM0241* 411⟩
⟨*Page CM0242* 412⟩
⟨*Page CM0243* 414⟩
⟨*Page CM0244* 416⟩
⟨*Page CM0245* 417⟩
⟨*Page CM0246* 418⟩
⟨*Page CM0247* 419⟩
⟨*Page CM0248* 420⟩
⟨*Page CM0249* 421⟩
⟨*Page CM0250* 423⟩
⟨*Page CM0251* 424⟩
⟨*Page CM0252* 425⟩
⟨*Page CM0253* 426⟩
⟨*Page CM0254* 428⟩
⟨*Page CM0255* 430⟩
⟨*Page CM0256* 431⟩
⟨*Page CM0257* 432⟩
⟨*Page CM0258* 433⟩
⟨*Page CM0259* 434⟩
⟨*Page CM0260* 436⟩
⟨*Page CM0261* 437⟩
⟨*Page CM0262* 438⟩
⟨*Page CM0263* 440⟩
⟨*Page CM0264* 442⟩
⟨*Page CM0265* 444⟩
⟨*Page CM0266* 446⟩
⟨*Page CM0267* 448⟩

405 ⟨*Page CM0236* 405⟩≡ (404 2692)

```
                BANK    7
                SETLOC  EXTVERBS
                BANK

                EBANK=  OGC

                COUNT*  $$/EXTVB

# FAN-OUT

GOEXTVB         INDEX   MPAC            # VERB-40 IS IN MPAC
                TC      LST2FAN         # FAN AS BEFROE.

LST2FAN         TC      VBZERO          # VB40 ZERO (USED WITH NOUN 20 ONLY)
                TC      VBCOARK         # VB41 COARSE ALIGN (USED WITH NOUN 20 OR
                                        #                               91 ONLY)
                TC      IMUFINEK        # VB42 FINE ALIGN IMU
                TC      IMUATTCK        # VB43 LOAD IMU ATTITUDE ERROR METERS.
                TC      SETSURF         # VB44 SET SURFACE FLAG
                TC      RESTSRF         # VB45 RESET SURFACE FLAG
                TC      STABLISH        # VB46 ESTABLISH G+C CONTROL
                TC      LMTOCMSV        # VB47 MOVE LM STATE VECTOR INTO CM
                TC      DAPDISP         # VB48 LOAD A/P DATA
                TCF     CREWMANU        # VB49 START AUTOMATIC ATTITUDE MANEUVER
                TC      GOLOADLV        # VB50 PLEASE PERFORM
                TC      GOLOADLV        # VB51 PLEASE MARK
                TC      V52             # VB52 SET OFFSET NO. FOR P22
                TC      GOLOADLV        # VB53 PLEASE PERFORM COAS MARK
                TC      GOTOR23         # VB54 PLEASE MARK (R-21 BACKUP)
                TC      ALINTIME        # VB55 ALIGN TIME
                TC      TRACKTRM        # VB56 TERMINATE TRACKING (P20 + P25)
                TC      GOTOR21         # VB57 START R21 REND TRACK SIGHT MARK ROUT
                TC      ENATMA          # VB58 ENABLE AUTOMATIC ATTITUDE MANEUVER
                TC      GOLOADLV        # VB59 PLEASE CALIBRATE
                TC      V60             # VB60 SET CPHIX (N17) EQUAL TO CDU
                TC      V61             # VB61 SELECT MODE I
                TC      V62             # VB62 SELECT MODE II, ERROR WRT N22
                TC      V63             # VB63 SELECT MODE III, ERROR WRT N17
                TC      VB64            # VB64 CALCULATE, DISPLAY S-BAND ANT ANGLES
                TC      CKOPTVB         # V 65 E OPTICAL VERIFICATION FOR PRELAUNC
                TC      ATTACHED        # VB66 ATTACHED. MOVE THIS TO OTHER STATE
                TC      V67             # VB67 W MATRIX MONITOR
                TC      STROKON         # VB68 CSM STROKE TEST ON.
VERB69          TC      VERB69          # VB69 CAUSE RESTART
                TC      V70UPDAT        # VB70 UPDATE LIFTOFF TIME.
```

```
TC      V71UPDAT        # VB71 UNIVERSAL UPDATE -- BLOCK ADDRESS
TC      V72UPDAT        # VB72 UNIVERSAL UPDATE -- SINGLE ADDRESS
TC      V73UPDAT        # VB73 UPDATE AGC TIME (OCTAL)
TC      DNEDUMP         # VB74 INITIALIZE DOWN-TELEMETRY PROGRAM
                        #       FOR ERASABLE DUMP.
TC      LFTFLGON        # VB75 SET LIFTOFF FLAG.
```

Uses A 80, COUNT 142, CPHIX 163, EBANK 80, EXTVERBS 71, I 206, MODE 145, MPAC 145, OGC 186, P 188, RESTART 57, STATE 138, TC 169, V 229, and W 183.

407 ⟨*Page CM0237* 407⟩≡ (404 2692)

```
                TC      SETPRFLG        # VB76 SET PREFERRED ATTITUDE FLAG
                TC      RESETPRF        # VB77 RESET PREFERRED ATT. FLAG
                TC      CHAZFOGC        # CHANGE GYROCOMPASS LAUNCH AZIMUTH V78
                TC      ALM/END         # V79 SPARE
                TC      LEMVEC          # VB80 UPDATE LEM STATE VECTOR
                TC      CSMVEC          # VB81 UPDATE CSM STATE VECTOR
                TC      V82PERF         # VB82 REQUEST ORBIT PARAM DISPLAY (R30)
                TC      V83PERF         # VB83 RANGE, RANGE RATE, +X AXIS  (R31)
                TC      ALM/END         # V84  SPARE
                TC      V85PERF         # VB85 RANGE, RANGE RATE, SLOS     (R32)
                TC      V86PERF         # VB86 BACKUP MARK REJECT
                TC      SETVHFLG        # VB87 SET VHF RANGE FLAG
                TC      RESETVHF        # VB88 RESET VHF RANGE FLAG
                TC      V89PERF         # V89-ALIGN X OR PRF CSM AXIS TO LOS (R63)
                TC      V90PERF         # VB90-OUT OF PLAN PARAMETERS      (R36)
                TC      GOSHOSUM        # VB91 TEMP FOR HYBRID AND STG.
                TC      SYSTEST         # VB92 OPERATE IMU PERFORMANCE TEST
                TC      WMATRXNG        # VB93 CLEAR RENDWFLG
                TC      VERB94          # VB94 DO R64
                TC      ALM/END         # VB95 SPARE
                TCF     VERB96          # VB96 SET QUITFLAG TO STOP INTEGRATION
                TC      GOLOADLV        # VB97 PLEASE PERFORM ENGINE-FAIL (R41)
                TC      ALM/END         # VB98 SPARE
                TC      GOLOADLV        # VB99 PLEASE ENABLE ENGINE

# END OF EXTENDED VERB FAN

TESTXACT        CCS     EXTVBACT
                TC      ALM/END         # YES, TURN ON OPERATOR ERROR LIGHT
                CA      FLAGWRD4        # ARE PRIOS USING DSKY
                MASK    OC24100
                CCS     A
                TC      ALM/END

                CAF     OCT24           # SET BITS 3 AND 5
SETXTACT        TS      EXTVBACT        # NO. SET FLAG TO SHOW EXT VERB DISPLAY
                                        # SYSTEM BUSY

                CA      Q
                TS      MPAC +1

                CS      TWO             # BLANK EVERYTHING EXCEPT MM AND VERB
                TC      NVSUB
                TC      +1
                TC      MPAC +1
```

```
XACTALM         TC      FALTON          # TURN ON OPERATOR ERROR LIGHT.
                TC      ENDEXT          # RELEASE MARK AND EXT. VERB DISPLAY SYS.
```

Uses A 80, AZIMUTH 191, EXTVBACT 154, FLAGWRD4 109, MM 226, MPAC 145, Q 80, QUITFLAG 131, R31 67, RANGE 179, RENDWFLG 117, STATE 138, TC 169, and TEMP 191.

408 ⟨*Page CM0238* 408⟩≡ (404 2692)

```
TERMEXTV        EQUALS  ENDEXT
ENDEXTVB        EQUALS  ENDEXT

XACT0           CAF     ZERO            # RELEASE MARK AND EXT. VERB DISPLAY SYS.
                TC      SETXTACT

ALM/END         TC      FALTON          # TURN ON OPERATOR ERROR LIGHT
GOPIN           TC      POSTJUMP
                CADR    PINBRNCH

OC24100         OCT     24100
```

Uses TC 169.

409 ⟨*Page CM0239* 409⟩≡ (404 2692)

```
# VBZERO        VERB 40         DESCRIPTION
#
#       1.      REQUIRE NOUN 20 (ICDU ANGLES)
#       2.      REQUIRE AVAILABILITY OF EXT VERB DISPLAY SYSTEM
#       3.      IF EITHER OF ABOVE CONDITIONS NOT PRESENT, TURN ON OPERATOR ERROR LIGHT AND GO
#       4.      SET EXT VERB DISPLAY ACTIVE FLAG.
#       5.      EXECUTE IMUZERO (ZERO IMU CDU ANGLES).
#       6.      EXECUTE IMUSTALL (ALLOW TIME FOR DATA TRANSFER).
#       7.      RELEASE EXT. VERB DISPLAY SYSTEM.

VBZERO          TC      OP/INERT
                TC      IMUZEROK        # RETURN HERE IF NOUN = ICDU(20)
                TC      ALM/END         # RETURN HERE IF NOUN = OCDU(91)
                                        #       (NOT IN USE YET)

IMUZEROK        TC      CKMODCAD        # KEYBOARD REQUEST FOR ISS CDUZERO
                TC      BANKCALL
                CADR    IMUZERO

                TC      BANKCALL        # STALL
                CADR    IMUSTALL
                TC      +1

                TC      GOPIN

OP/INERT        CS      OCT24
                AD      NOUNREG
                EXTEND
                BZF     XACTOQ          # IF = 20.

                INCR    Q
                AD      OPIMDIFF        # -71
                EXTEND
                BZF     XACTOQ

                TC      ALM/END         # ILLEGAL.

OPIMDIFF        DEC     -71
```

Uses NOUNREG 152, Q 80, and TC 169.

410 ⟨*Page CM0240* 410⟩≡ (404 2692)

```
# VBCOARK       VERB 41         DESCRIPTION
#       COARSE ALIGN IMU OR RADAR
#
#       1.      REQUIRE NOUN 20 OR NOUN 91 OR TURN ON OPERATOR ERROR.
#       2.      REQUIRE EXT VERB DISPLAY SYS AVAILABLE OR TURN ON OPERATOR ERROR LIGH
#
#       CASE 1  NOUN 20 (ICDU ANGLES)
#       3.      SET EXT VERB DISPLAY ACTIVE FLAG.
#       4.      DISPLAY FLASHING V25,N22 (LOAD NEW ICDU ANGLES).
#               RESPONSES
#               A.      TERMINATE
#                       1.      RELEASE EXT VERB DISPLAY SYSTEM.
#               B.      PROCEED
#                       1.      DISPLAY FLASHING V25,N23 (LOAD DELTA ICDU ANGLES).
#                               RESPONSES:
#                               A.      TERMINATE
#                                       1.      RELEASE EXT VERB DISPLAY SYSTEM.
#                               B.      PROCEED
#                                       1.      EXECUTE ICORK2.
#                               C.      ENTER
#                                       1.      INCREMENT CDU ANGLES
#                                       2.      EXECUTE ICORK2
#               C.      ENTER
#                       1.      EXECUTE ICORK2
# ICORK2
#       1.      RE-DISPLAY VERB 41.
#       2.      EXECUTE IMUCCARS (IMU COARSE ALIGN).
#       3.      EXECUTE IMUSTALL (ALLOW TIME FOR DATA TRANSFER).
#       4.      RELEASE EXT VERB DISPLAY SYSTEM.
#
#       CASE 2  NOUN 91 (OCDU ANGLES)
#       5.      (REQUIRE OPTICS SWITCH TO BE AT COMUTER OR TURN ON OPERATOR ERROR AND
#               OPTICS AVAILABLE AND DISPLAY FLASHING V24,N92....LOAD NEW OPTICS ANGL
#               AND RELEASE EXT VERB DISPLAY SYSTEM).
#       6.      RESPONSES TO V29,N92
#               A.      TERMINATE
#                       RELEASE EXT VERB DISPLAY SYS.
#               B.      PROCEED OR ENTER
#                       RE-DISPLAY VERB 41,     SET SWITCH TO INDICATE COURSE ALIGN (
#                       RELEASE EXT VERB DISPLAY SYSTEM.

VBCOARK         TC      OP/INERT
                TC      IMUCOARK                # RETURN HERE IF NOUN = ICDU (20)
                TC      OPTCOARK                # RETURN HERE IF NOUN = OCDU (91)
```

```
# RETURNS TO L+1 IF NOUN 20 -- TO L+2 IF NOUN 91.

IMUCOARK        TC      CKMODCAD                # COARSE ALIGN FROM KEYBOARD
                TC      TESTXACT
                CAF     VNLODCDU                # CALL FOR THETAD LOAD
                TC      BANKCALL
                CADR    GOXDSPF
                TC      TERMEXTV
                TCF     +1
```

Uses A 80, L 80, TC 169, and THETAD 157.

411 ⟨*Page CM0241* 411⟩≡ (404 2692)

```
ICORK2          CAF     IMUCOARV                # RE-DISPLAY COARSE ALIGN VERB.
                TC      BANKCALL
                CADR    EXDSPRET

                TC      BANKCALL                # CALL MODE SWITCHING PROG
                CADR    IMUCOARS

                TC      BANKCALL                # STALL
                CADR    IMUSTALL
                TC      ENDEXTVB
                TC      ENDEXTVB

VNLODCDU        VN      2522
IMUCOARV        VN      4100
```

Uses MODE 145, TC 169, and VN 159.

412 ⟨*Page CM0242* 412⟩≡ (404 2692)

```
# TEMPORARY ROUTINE TO RUN THE OPTICS CDUS FROM THE KEYBOARD

OPTCOARK        CA      OPTCADR
                TC      CKMODCAD +1
                TC      TESTXACT
                CAF     EBANK5
                TS      EBANK

                CCS     SWSAMPLE                # SEE IF SWITCH AT COMPUTER
                TC      +5                      # SWITCH AT COMPUTER
                TC      +1                      # NOT ON COMPUTER
                TC      FALTON                  # TURN ON OPERATOR ERR
                TC      ALARM                   # AND ALARM
                OCT     00115

                CCS     OPTIND                  # SEE IF OPTICS AVAILABLE
                TC      OPTC1                   # IN USE
                TC      OPTC1                   # IN USE
                TC      OPTC1                   # IN USE

                TC      ALARM                   # OPTICS RESERVED (OPTIND=-0)
                OCT     00117
                TC      ENDEXT

OPTC1           CAF     VNLD0CDU                # VERB-NOUN TO LOAD OPTICS CDUS
                TC      BANKCALL
                CADR    GOXDSPF
                TC      TERMEXTV
                TC      +1                      # PROCEED

                CA      SAC
                TS      DESOPTS
                CA      PAC
                TS      DESOPTT
                CAF     OPTCOARV                # RE-DISPLAY OUR OWN VERB
                TC      BANKCALL
                CADR    EXDSPRET

                CAF     ONE
                TS      OPTIND                  # SET COARS WORKING

                TC      ENDEXTVB
                TC      ENDEXTVB

VNLD0CDU        VN      2492
```

```
OPTCOARV        EQUALS  IMUCOARV                # DIFFERENT NOUNS.
```

Uses CDUS 80, COMPUTER 115, DESOPTS 159, DESOPTT 159, EBANK 80, OPTCADR 163, OPTIND 161, PAC 186, RUN 191, SAC 186, SWSAMPLE 163, TC 169, and VN 159.

414 ⟨*Page CM0243* 414⟩≡ (404 2692)

```
# IMUFINEK      VERB 42         DESCRIPTION
#       FINE ALIGN IMU
#
#       1.      REQUIRE EXT VERB DISPLAY AVAILABLE AND SET BUSY FLAG OR TURN ON OPER
#       2.      DISPLAY FLASHING V25,N93....LOAD DELTA GYRO ANGLES....
#               RESPONSES
#               A.      TERMINATE
#                       1.      RELEASE EXT VERB DISPLAY SYSTEM.
#               B.      PROCEED OR ENTER
#                       1.      RE-DISPLAY VERB 42
#                       2.      EXECUTE IMUFINE (IMU FIVE ALIGN MODE SWITCHING).
#                       3.      EXECUTE IMUSTALL (ALLOW FOR DATA TRANSFER)
#                               A.      FAILED
#                                       1.      RELEASE EXT VERB DISPLAY SYSTEM.
#                               B.      GOOD
#                                       1.      EXECUTE IMUPULSE (TORQUE IRIGS).
#                                       2.      EXECUTE IMUSTALL AND RELEASE EXT VERB

IMUFINEK        TC      CKMODCAD                # FINE ALIGN WITH GYRO TORQUING.
                TC      TESTXACT
                CAF     VNLODGYR                # CALL FOR LOAD OF GYRO COMMANDS
                TC      BANKCALL
                CADR    GOXDSPF
                TC      TERMEXTV
                TC      +1                      # PROCEED WITHOUT A LOAD

                CAF     IMUFINEV                # RE-DISPLAY OUR OWN VERB
                TC      BANKCALL
                CADR    EXDSPRET

                TC      BANKCALL                # CALL MODE SWITCH PROG
                CADR    IMUFINE

                TC      BANKCALL                # HIBERNATION
                CADR    IMUSTALL
                TC      ENDEXTVB

FINEK2          CAF     LGYROBIN                # PINBALL LEFT COMMANDS IN OGC REGIST
                TC      BANKCALL
                CADR    IMUPULSE

                TC      BANKCALL                # WAIT FOR PULSES TO GET OUT.
                CADR    IMUSTALL
                TC      ENDEXTVB
                TC      ENDEXTVB
```

```
LGYROBIN        ECADR   OGC
VNLODGYR        VN      2593
IMUFINEV        VN      4200                    # FINE ALIGN VERB

CKMODCAD        CA      MODECADR
```

Uses A 80, MODE 145, MODECADR 163, OGC 186, TC 169, and VN 159.

416 ⟨*Page CM0244* 416⟩≡ (404 2692)

```
                EXTEND
                BZF     TCQ
                TC      ALM/END                 # SOMEBODY IS USING MODECADR SO EXIT

# GOLOADLV      VERB 50         DESCRIPTION
#       AND OTHER PLEASE
#       DO SOMETHING VERBS
#
# PLEASE PERFORM, MARK, CALIBRATE, ETC.
#
#       1.      PRESSING ENTER ON DSKY INDICATES REQUESTED ACTION HAS BEEN PERFORMED,
#               SAME RECALL AS A COMPLETED LOAD.
#       2.      THE EXECUTION OF A VERB 33 (PROCEED WITHOUT DATA) INDICATES THE REQUE

GOLOADLV        TC      FLASHOFF
                CAF     PINSUPBT
                EXTEND
                WRITE   SUPERBNK        # TURN ON FE7
                TC      POSTJUMP
                SBANK=  PINSUPER
                CADR    LOADLV1

# V60   VERB 60
V60             EXTEND                  # SET ASTRONAUT TOTAL ATTITUDE (N17) EQUAL
                DCA     CDUX            # TO PRESENT ATTITUDE
                DXCH    CPHIX
                CA      CDUZ
                TS      CPHIX   +2
                TC      GOPIN

# V61   VERB 61
V61             TC      DOWNFLAG        # SET NEEDLFLG TO 0 (FLAGWRD0,BIT9), PHASE
                ADRES   NEEDLFLG        # PLANE A/P FOLLOWING ERROR DISPLAYED
                TC      GOPIN

# V62   VERB 62
V62             TC      UPFLAG          # SET NEEDLFLG TO 1 (FLAGWRD0,BIT9),
                ADRES   NEEDLFLG        # TOTAL ATTITUDE ERROR DISPLAYED

                TC      UPFLAG          # SET N22ORN17 TO 1 (FLAGWRD9,BIT6),
                ADRES   N22ORN17        # COMPUTE TOTAL ATTITUDE ERROR WRT N22
                TC      GOPIN

# V63   VERB 63
V63             TC      UPFLAG          # SET NEEDLFLG TO 1 (FLAGWRD0,BIT9),
```

```
ADRES   NEEDLFLG        # TOTAL ATTITUDE ERROR DISPLAYED

TC      DOWNFLAG        # SET N22ORN17 TO 0 (FLAGWRD9,BIT6),
```

Uses A 80, CDUX 80, CDUZ 80, CPHIX 163, FLAGWRD0 95, MODECADR 163, N22ORN17 131, NEEDLFLG 95, P 188, PINSUPER 69, SUPERBNK 87, and TC 169.

417 ⟨*Page CM0245* 417⟩≡ (404 2692)

```
ADRES   N22ORN17        # COMPUTE TOAL ASTRONAUT ATTITUDE ERROR
TC      GOPIN
```

Uses N22ORN17 131 and TC 169.

418 ⟨*Page CM0246* 418⟩≡ (404 2692)

```
# ALINTIME      VERB 55         DESCRIPTION
#
#       1.      SET EXT VERB DISPLAY BUSY FLAG.
#       2.      DISPLAY FLASHING V25,N24 (LOAD DELTA TIME FOR AGC CLOCK.
#       3.      REQUIRE EXECUTION OF VERB 23.
#       4.      ADD DELTA TIME, RECEIVED FROM INPUT REGISTER, TO THE COMPUTER TIME.
#       5.      RELEASE EXT VERB DISPLAY SYSTEM.

                COUNT   04/R33

ALINTIME        TC      TESTXACT

                CAF     VNLODDT
                TC      BANKCALL
                CADR    GOMARKF
                TC      ENDEXT          # TERMINATE
                TC      ENDEXT          # PROCEED
                CS      DEC23           # DATA IN OR RESEQUENCE (UNLIKELY)
                AD      MPAC            # RECALL LEFT VERB IN MPAC
                EXTEND
                BZF     UPDATIME        # GO AHEAD WITH UPDATE ONLY IF RECALL
                TC      ENDEXT          #       WITH V23 (DATA IN).

UPDATIME        INHINT                  # DELTA TIME IS IN DSPTEM1, +1.
                CAF     ZERO
                TS      MPAC +2         # NEEDED FOR TP AGREE
                TS      L               # ZERO T1 + 2 WHILE ALIGNING.
                DXCH    TIME2
                DXCH    MPAC
                DXCH    DSPTEM2 +1      # INCREMENT
                DAS     MPAC

                TC      TPAGREE         # FORCE SIGN AGREEMENT.
                DXCH    MPAC            # NEW CLOCK.
                DAS     TIME2
                RELINT
UPDTMEND        TC      ENDEXT
DEC23           DEC     23              # V 23

VNLODDT         VN      2524            # V25N24 FOR LOAD DELTA TIME
```

Uses COMPUTER 115, COUNT 142, DSPTEM1 154, DSPTEM2 154, L 80, MPAC 145, T1 241, TC 169, TIME2 80, V 229, and VN 159.

419 ⟨*Page CM0247* 419⟩≡ (404 2692)

```
# SYSTEST       VERB 92         DESCRIPTION
#       OPERATE SELECTED SYSTEM TEST.
#
#       1.      REQUIRE P00 OR P00- OR TURN ON OPERATOR ERROR.
#       2.      TURN OFF DAP IF IT IS ON.
#       3.      DISPLAY FLASHING V21,N01 (LOAD TEST NUMBER 1 THRU 17).
#       4.      UPON ENTRY OF TEST NUMBER, SCHEDULE TSELECT WITH PRIORITY 20.
#
#       TSELECT
#       1.      IF LOADED TEST NUMBER IS VALID, GO TO THAT TEST ROUTINE, OTHERWISE TURN ON OPER
#               REPEAT LOAD REQUEST DISPLAY.  (NO. 3 ABOVE)

                EBANK=  QPLACE

                COUNT   04/EXTVB

SYSTEST         TC      CHKP00H
                CA      FLAGWRD1        # IS NODOP01 FLAGBIT ON? (SET BY P11)
                MASK    NOP01BIT
                EXTEND
                BZF     V92CONT         # IF IT'S NOT YET SET, CONTINUE
                TC      P00D00          # IT'S ON. SEND NODO ALARM FOR P07
                OCT     1521
V92CONT         TC      EXDAPOFF        # TURN DAP OFF IF IT'S ON
                CAF     PRIO20
                TC      FINDVAC
                EBANK=  QPLACE
                SBANK=  IMUSUPER
                2CADR   REDO

                TC      GOPIN

# REDO AND TSELECT ARE NOW IN SYSTEM TEST.

                COUNT*  $$/EXTVB
# CKOPTVB       VERB 65         DESCRIPTION
#       OPTICAL VERIFICATION FOR PRELAUNCH.
#       1.      SCHEDULE GCOMPVER, OPTICAL VERIFICATION SUBPROGRAM, WITH PRIORITY 17.

CKOPTVB         TC      CHECKMM
                MM      02              # I WONDER IF PRELAUNCH IS RUNNING
                TC      ALM/END         # NOT RUNNING OPERATOR ERROR
                INHINT
                CAF     PRIO16          # PRELAUNCH OPTICAL VERIFICATION
                TC      FINDVAC
```

```
                EBANK=  QPLACE
                2CADR   COMPVER         # STANDARD LEADIN TO GCOMPVER.

                TC      GOPIN
```

Uses COUNT 142, EBANK 80, FLAGWRD1 97, I 206, IMUSUPER 67, IT 185, MM 226, NODOP01 99, NOP01BIT 99, PRIORITY 145, QPLACE 191, and TC 169.

420 ⟨*Page CM0248* 420⟩≡ (404 2692)

```
  # V 78 ....     TO CHANGE GYROCOMPASS AZIMUTH

  CHAZFOGC      TC      CHECKMM         # IS IT PRELAUNCH
                MM      02
                TC      ALM/END         # NO -- OPERATOR ERROR

                CAF     PRIO16          # PRELAUNCH AZIMUTH CHANGE
                TC      FINDVAC
                EBANK=  XSM
                2CADR   AZMTHCG1

                TC      PHASCHNG
                OCT     00174
                TC      GOPIN
```

Uses AZIMUTH 191, EBANK 80, IT 185, MM 226, TC 169, V 229, and XSM 186.

421 ⟨*Page CM0249* 421⟩≡ (404 2692)

```
# IMUATTCK      VERB 43         DESCRIPTION
#       LOAD IMU ATTITUDE ERROR METERS
#
#       1.      REQUIRE PROGRAM 00 ACTIVE, COARSE ALIGN ENABLE BIT OFF AND ZERO ICDU BIT OFF.
#       2.      IF GUID REF RELEASE OR LIFTOFF HAS OCCURRED REQUIRE EXT VERB DISPLAY AVAILABLE
#               FLAG, OTHERWISE ALLOW CURRENT EXT VERB DISPLAY TO BE OVER-RIDDEN.
#       3.      REMOVE COARSE ALIGN ENABLE AND IMU ERROR COUNTER ENABLE.
#       4.      DISPLAY FLASHING V25,N22 (LOAD NEW ICDU ANGLES).
#       5.      UPON PROCEED OR ENTER RESPONSE, INITIALIZE CURRENT DAC AND COMMAND VALUES, ENAB
#               TRANSFER LOADED VALUES TO REGISTERS, AND SEND COMMANDS.
#       6.      IF BUSY FLAG SET, RESET IT TO RELEASE EXT VERB DISPLAY.

IMUATTCK        TC      CHKP00H

                CAF     OCTAL30         # SEE IF IMU ZERO AND IMU COARSE ARE ON
                EXTEND
                RAND    CHAN12
                CCS     A
                TCF     ALM/END         # NOT ALLOWED IF IMU COARSE OR IMU ZERO ON

                TC      CKLFTBTS        # IS IT BEFORE OR AFTER LIFTOFF
                TC      TESTXACT        # AFTER
                CS      OCT50           # REMOVE COARSE AND ECTR ENABLE
                EXTEND
                WAND    CHAN12

                CAF     VNLODCDU
                TC      BANKCALL
                CADR    GOXDSPF
                TCF     TRMATTCK
                TC      +1
                CAF     EBANK6
                TS      EBANK           # SET E6 FOR NEEDLES.

                EBANK=  AK

                TC      BANKCALL        # INITIALIZE CURRENT DAC AND
                CADR    NEEDLE11        # COMMAND VALUES.

                TC      BANKCALL        # ENABLE ERROR COUNTERS.
                CADR    NEEDLER2

                CAF     TWO             # 4 MS MIN.
                TC      WAITLIST
                EBANK=  AK
```

```
                2CADR   ATTCK1

  TRMATTCK      TC      CKLFTBTS        # IS IT BEFORE OR AFTER LIFTOFF
                TCF     ENDEXT          # AFTER
                TC      GOPIN
```

Uses A 80, AK 200, CHAN12 87, COMMAND 169, EBANK 80, IT 185, and TC 169.

423 ⟨*Page CM0250* 423⟩≡ (404 2692)

```
ATTCK1          EXTEND                  # TRANSFER LOADED VALUES TO DESIRED REQS.
                DCA     THETAD
                DXCH    AK
                CAE     THETAD  +2
                TS      AK      +2

                TC      IBNKCALL        # SENDS COMMANDS LIMITED TO +,- 384 PULSES
                CADR    NEEDLES         # AND LEAVES ERROR COUNTERS ENABLED.

                TC      TASKOVER

CKLFTBTS        CAF     GRRBKBIT        # HAS LIFTOFF OCCURRED
                MASK    FLAGWRD5
                CCS     A
                TC      Q               # YES
                CAF     BIT5
                EXTEND
                RAND    CHAN30
                CCS     A
                TCF     Q+1
XACTOQ          TC      Q               # YES

OCTAL30         OCT     30
VB64            TC      CHKP00H         # DEMAND PROGRAM 00.
                TC      TESTXACT        # IF DISPLAY SYS. NOT BUSY, MAKE IT BUSY.
                INHINT
                CAF     PRIO4
                TC      FINDVAC
                EBANK=  RHOSB
                2CADR   SBANDANT        # CALC.,DISPLAY S-BAND ANTENNA ANGLES.

                TC      ENDOFJOB

# ENATMA        VERB 58         DESCRIPTION
#       ENABLE AUTOMATIC ATTITUDE MANEUVER
#
# VERB58 RESETS STIKFLAG TO ENABLE R61 TO PERFORM AUTOMATIC TRACKING MANEUVERS, AFTER INTERRUPT
# ACTIVITY.

ENATMA          TC      DOWNFLAG        # RESET STIKFLAG.
                ADRES   STIKFLAG        # BIT 14 FLAG 1
                TC      GOPIN
```

Uses A 80, AK 200, CHAN30 87, EBANK 80, FLAGWRD5 113, GRRBKBIT 115, IT 185, Q 80, RHOSB 179, STIKFLAG 99, TC 169, and THETAD 157.

424 ⟨*Page CM0251* 424⟩≡ (404 2692)

```
# STROKON       VERB 68         DESCRIPTION
#       STROKE TEST SETUP/ENABLE
#       1.      SET EXT VERB DISPLAY BUSY FLAG
#       2.      SCHEDULE STRKTST1 WITH PRIORITY 30.
#       3.      RELEASE EXT VERB DISPLAY.

                EBANK=  T5TVCDT
STROKON         CS      FLAGWRD6        # V68   PERMITTED ONLY DURING TVC
                MASK    OCT60000
                EXTEND
                BZMF    ALM/END         # NOT TVC....FLASH OP ERROR LIGHT
                CAF     PRIO30          # JOB REQUEST, TO SET UP STROKE TEST,
                TC      NOVAC           #       INCLUDING INITIALIZATIONS
                SBANK=  PINSUPER        # Added RSB 2009.
                EBANK=  STROKER
                2CADR   STRKTSTI

                TC      GOPIN

# STABLISH      VERB 46         DESCRIPTION
#       ESTABLISH G AND N AUTOPILOT CONTROL
#       1.      SETS UP EITHER RCS, ENTRY, OR SATURN
#       2.      IF TVC IS ON, SETS UP CSM/LM SWITCH-OVER
#                       FROM HIGH BW TO LOW BW


STABLISH        CAF     EBANK6          # V46 - SET EBANK TO E6
                TS      EBANK

                CS      FLAGWRD6        # TEST FOR TVC
                MASK    OCT60000
                EXTEND
                BZMF    +8

                CAE     DAPDATR1        # TET FOR CSM/LM
                MASK    BIT14
                EXTEND
                BZMF    +3

                TC      POSTJUMP        # CSM/LM, SO PERFORM HB TO LB SWITCH-OVER
                CADR    PRESWTCH

+3              TC      ALM/END

+8              TC      POSTJUMP        # SET UP RCS, ENTRY, OR SATURN-STICK DAP
```

```
                CADR    DAPFIG
```

Uses DAPDATR1 200, EBANK 80, FLAGWRD6 117, N 206, PINSUPER 69, PRIORITY 145, STROKER 204, T5TVCDT 204, TC 169, and TET 169.

425 ⟨*Page CM0252* 425⟩≡ (404 2692)

```
# CREMANU       VERB 49         DESCRIPTION
#       START AUTOMATIC ATTITUDE MANEUVER
#
#       1.      REQUIRE PROGRAM 00 ACTIVE.
#       2.      SET EXT VERB DISPLAY BUSY FLAG.
#       3.      SCHEDULE R62DISP WITH PRIORITY 10.
#       4.      RELEASE EXT VERB DISPLAY.
#
#       R62DISP
#       1.      DISPLAY FLASHING V06,N22 (DECIMAL DISPLAY NEW ICDU ANGLES).  UPON IMMEDIATE RET
#               4 FOR RESTART OF DISPLAY SEQUENCE.
#               RESPONSES
#               A.      TERMINATE
#                       1.      GOTOP00H
#               B.      PROCEED
#                       1.      SET 3AXISFLG TO INDICATE MANEUVER IS SPECIFIED BY 3 AXIS.
#                       2.      EXECUTE R60CSM (ATTITUDE MANEUVER).
#                       3.      ZERO GROUP 4 (END R62).
#               C.      ENTER
#                       1.      REPEAT FLASHING V06,N22.

CREWMANU        TC      CHKP00H         # DEMAND P00

                TC      TESTXACT

                CAF     PRIO10
                TC      FINDVAC
                EBANK=  CPHI
                2CADR   R62DISP

                TC      ENDOFJOB
```

Uses 3AXISFLG 115, A 80, CPHI 157, EBANK 80, PRIORITY 145, RESTART 57, and TC 169.

426 ⟨*Page CM0253* 426⟩≡ (404 2692)

```
# DAPDISP       VERB 48         DESCRIPTION
#       LOAD AUTOPILOT DATA (ROUTINE R03)
#
#       0.      CHECKFAIL AND RETURN IF TVC.
#       1.      REQUIRE EXT VERB DISPLAY AVAILABLE AND SET BUSY FLAG.
#       2.      LOWER PRIORITY TO 10.
#       3.      DISPLAY FLASHING V04,N46 (DISPLAY AUTOPILOT CONFIGURATION).
#       4.      UPON PROCEED RESPONSE, EXECUTE S41.2.
#       5.      DISPLAY FLASHING V06,N47 (DISPLAY CSM WGT., LEM WGT.)
#       6.      UPON PROCEED RESPONSE EXECUTE S40.14.
#       7.      DISPLAY FLASHING V06,N48 (DISPLAY PITCH TRIM, YAW TRIM)
#       8.      UPON PROCEED RESPONSE, RELEASE EXTENDED VERB DISPLAY SYSTEM.

                COUNT*  $$/EXTVB

DAPDISP         CS      FLAGWRD6
                MASK    OCT60000
                EXTEND
                BZMF    +2              # TVC = 10, CS YIELDS 01, BZMF TO CONTINUE
                TC      ALM/END         # RETURN IF TVC

                TC      TESTXACT
                TC      BANKCALL
                CADR    DAPDISP1
                BANK    42
                SETLOC  EXTVBS
                BANK
                COUNT   24/R03

DAPDISP1        CAF     EBANK6
                TS      EBANK

                CAF     PRIO10
                TC      PRIOCHNG

DONOUN46        CAF     V04N46          #       R1              R2
                TC      BANKCALL        #       DAPDATR1        DAPDATR2
                CADR    GOXDSPF         # GOXDSP ROUTINES USED FOR EXTENDED VERBS.

                TC      ENDEXT          # EXT. VBS GO TO ENDEXT, NOT ENDOFJOB.
                TC      +2
                TC      DONOUN46

                CA      DAPDATR1
                MASK    BIT4
```

```
                CCS     A
                TCF     MAXIN
                TC      DOWNFLAG
                ADRES   MAXDBFLG
MAXOUT          TC      BANKCALL
                CADR    S41.2

DONOUN47        CAF     V06N47          #       R1              R2              R3
```

Uses `A` 80, `COUNT` 142, `DAPDATR1` 200, `DAPDATR2` 200, `EBANK` 80, `EXTVBS` 71, `FLAGWRD6` 117, `PRIORITY` 145, `R2` 188, and `TC` 169.

428 ⟨*Page CM0254* 428⟩≡ (404 2692)

```
                TC      BANKCALL        #       CSM WGT.        LEM WGT.        BLANK
                CADR    GOXDSPF

                TC      ENDEXT
                TC      +2
                TC      DONOUN47
                CAE     DAPDATR1        # DO MASS PROPERTIES CALCULATION ONLY IF
                MASK    PRIO30          # CONFIG = 1(CSM), 2 (CSM/LM), 6(CSM/LMA)
                EXTEND
                BZF     DONOUN48        # SKIP IF 0,4
                COM
                MASK    PRIO30
                EXTEND
                BZF     DONOUN48        # SKIP IF 3,7
                INHINT
                TC      IBNKCALL
                CADR    MASSPROP        # UPDATE IXX, IAVG, IAVG/TLX

                RELINT
                TC      BANKCALL
                CADR    S40.14          # COMPUTE RCS DAP STUFF

DONOUN48        CAF     V0648           #       R1              R2              R3
                TC      BANKCALL        #       PTRIM           YTRIM           BLANK
                CADR    GOXDSPF

                TC      ENDEXT
                TC      ENDEXT
                TC      DONOUN48

MAXIN           TC      UPFLAG
                ADRES   MAXDBFLG
                TC      MAXOUT

V0648           VN      0648
V06N47          VN      0647
V04N46          VN      0446
                BANK    43
                SETLOC  EXTVERBS
                BANK

                COUNT*  $$/EXTVB

# V82PERF       VERB82          DESCRIPTION
#       REQUEST ORBIT PARAMETERS DISPLAY (R30)
```

```
#
#       1.      IF AVERAGE G IS OFF:
#                       FLASH DISPLAY V04N06.  R2 INDICATES WHICH SHIP'S STATE VECTOR IS
#                        TO BE UPDATED.  INITIAL CHOICE IS THIS SHIP (R2=1).  ASTRONAUT
#                        CAN CHANGE TO OTHER SHIP BY V22EXE, WHERE X NOT EQ I.
#                       SELECTED STATE VECTOR UPDATED BY THISPREC (OTHPREC).
#                       CALLS SR30.1 (WHICH CALLS TFFCONMU + TFFRP/RA) TO CALCULATE
```

Uses COUNT 142, DAPDATR1 200, EXTVERBS 71, I 206, IAVG 200, IAVG/TLX 200, IXX 200, MASS 200, OTHPREC 71, R2 188, STATE 138, TC 169, THISPREC 73, and VN 159.

430 ⟨*Page CM0255* 430⟩≡ (404 2692)

```
#                        RPER (PERIGEE RADIUS), RAPO (APOGEE RADIUS), HPER (PERIGEE
#                        HEIGHT ABOVE LAUNCH PAD OR LUNAR LANDING SITE), HAPO (APOGEE
#                        HEIGHT AS ABOVE), TPER (TIME TO PERIGEE), TFF (TIME TO
#                        INTERSECT 300 KFT ABOVE PAD OR 35KFT ABOVE LANDING SITE).
#                       FLASH MONITOR V16N44 (HAPO, HPER, TFF).  TFF IS -59M59S IF IT
#                        NOT COMPUTABLE, OTHERWISE IT INCREMENTS ONCE PER SECOND.
#                        ASTRONAUT HAS OPTION TO MONITOR TPER BY KEYING IN N 32 E.
#                        DISPLAY IS IN HMS, IS NEGATIVE (AS WAS TFF), AND INCREMENTS
#                        ONCE PER SECOND ONLY IF TFF DISPLAY WAS -59M59S.
#
#       2.      IF AVERAGE G IS ON:
#                       CALLS SR30.1 APPROX EVERY TWO SECS.  STATE VECTOR IS ALWAYS
#                        FOR THIS VEHICLE.  V82 DOES NOT DISTURB STATE VECTOR.  RESULT
#                        OF SR30.1 ARE RAPO, RPER, HAPO, HPER, TPER, TFF.
#                       FLASH MONITOR V16N44 (HAPO, HPER, TFF).
#                        IF MODE IS P11, THEN CALL DELRSPL SO ASTRONAUT CAN MONITOR
#                        RESULTS BY N50E.  SPLASH COMPUTATION DONE ONCE PER TWO SECS.
#
# ADDENDUM:     HAPO AND HPER SHOULD BE CHANGED TO READ HAPOX AND HPERX IN THE
#               ABOVE REMARKS.

V82PERF         TC      TESTXACT

                CAF     PRIO7
                TC      PRIOCHNG
                TC      POSTJUMP
                CADR    V82CALL         # ***** V82CALL MUST NOT BE A FINDVAC JOB.

# VB83PERF      VERB 83         DESCRIPTION
#       REQUEST RENDEZVOUS PARAMETER DISPLAY (R31)
#
#       1.      SET EXT VERB DISPLAY BUSY FLAG.
#       2.      SCHEDULE V83CALL WITH PRIORITY 10.
#               A.      DISPLAY
#                       R1      RANGE
#                       R2      RANGE RATE
#                       R3      THETA

V83PERF         TC      TESTXACT
                INHINT
                CS      FLAGWRD9        # SET R31 FLAG-BIT 4 FLAGWRD9
                MASK    R31FLBIT
                ADS     FLAGWRD9
                CAF     PRIO5
                TC      NOVAC
```

```
                SBANK=  LOWSUPER        # Added by RSB 2009
                EBANK=  SUBEXIT
                2CADR   R31CALL

                TC      ENDOFJOB
```

Uses A 80, EBANK 80, HAPO 181, HAPOX 181, HPER 181, HPERX 181, IT 185, LOWSUPER 67, MODE 145, N 206, PRIORITY 145, R2 188, R31 67, R31FLBIT 131, RANGE 179, STATE 138, SUBEXIT 181, TC 169, TFF 179, and THETA 148.

431 ⟨*Page CM0256* 431⟩≡ (404 2692)

```
V85PERF         TC      TESTXACT
                INHINT
                CS      R31FLBIT        # RESET R31 FLAG TO INDICATE R34
                MASK    FLAGWRD9
                TS      FLAGWRD9
                TC      V83PERF +5
```

Uses R31 67, R31FLBIT 131, R34 67, and TC 169.

432 ⟨*Page CM0257* 432⟩≡ (404 2692)

```
#       GOTOR21         VERB 57
#       GOTOR23-        VERB 54         DESCRIPTION
# SET UP MARKING FOR R22 (REND TRACK DATA PROC)
# 1.    SET EXT VERB DISPLAY BUSY FLAG
# 2.    IF REND (P20 RUNNING) + TRACK (TRACKING ALLOWED) FLAGS ARE SET,
#       SCHEDULE R21 OR R23 WITH PRIORITY 16, OTHERWISE TURN ON ALARM 406
# 3.    RELEASE EXT VERB DISPLAY SYSTEM

GOTOR21         TC      DOWNFLAG        # CLEAR R23FLG
                ADRES   R23FLG          # BIT 9 FLAG 1
                TC      +3
GOTOR23         TC      UPFLAG          # SET R23FLG
                ADRES   R23FLG          # BIT 9 FLAG 1
                TC      TESTXACT
                CA      FLAGWRD0        # VB 57 UNACCEPTABLE UNLESS BOTH
                MASK    RNDVZBIT        #       RENDEZVOUS AND TRACK FLAGS ON
                EXTEND
                BZF     R22ALARM

                CA      FLAGWRD1
                MASK    TRACKBIT
                EXTEND
                BZF     R22ALARM

                CA      FLAGWRD1        # TEST R23FLG
                MASK    R23BIT
                EXTEND
                BZF     REGR21          # R21
                CAF     PRIO16
                TC      NOVAC
                EBANK=  MRKBUF1
                2CADR   R23CSM

                TC      ENDOFJOB
REGR21          CAF     PRIO16
                TC      NOVAC
                EBANK=  MRKBUF1
                2CADR   R21CSM

                TC      ENDOFJOB
R22ALARM        TC      ALARM           # VERB 57 WAS SELECTED AND NEITHER REND
                OCT     00406           #       NOR TRACK FLAG WERE ON.
                TC      ENDEXT
```

Uses EBANK 80, FLAGWRD0 95, FLAGWRD1 97, PRIORITY 145, R23BIT 99, R23FLG 99, RNDVZBIT 97,

TC 169, and TRACKBIT 101.

433 ⟨*Page CM0258* 433⟩≡ (404 2692)

```
# VERB 86       DESCRIPTION
#       V86 IS TO R23 AS MARK REJECT IS TO R21
#       V86 IS THE MARK REJECT FOR R23 (THE BACKUP MARKING ROUTINE)

                EBANK=  MRKBUF1
V86PERF         CAF     EBANK7          # BACKUP MARK REJECT (R23)
                XCH     EBANK
                CA      NEGONE
                TS      MRKBUF1
                TC      GOPIN
```

Uses EBANK 80 and TC 169.

434 ⟨*Page CM0259* 434⟩≡ (404 2692)

```
# TRACKTRM      VERB 56         DESCRIPTION
#       TERMINATE TRACKING (P20)
#       1.      KNOCK DOWN RENDEZVOUS, TRACK, AND UPDATE FLAGS.
#       2.      REQUIRE P20 NOT RUNNING ALONE OR GO TO GOTOPOOH (REQUEST PROGRAM 00)
#       3.      REQUIRE R22 RUNNING OR GO TO PINBRNCH.
#       4.      IF INTEGRATION RUNNING, STALL UNTIL IT IS COMPLETED, THEN ZERO GROUPS
#       3.      KNOCK DOWN RENDEZFOUS, R22, R21, TRACK, UPDATE, AND TARG1 FLAGS.
#       4.      GO TO ENEMA (SOFTWARE RESTART).
#       REFERENCE
#               P20     RENDEZVOUS      NAVIGATION
#               R21     RENDEZVOUS      TRACKING SIGHTING MARK.
#               R22     RENDEZVOUS      TRACKING DATA PROCESSING.

TRACKTRM        CA      RNDVZBIT        # IS REND FLAG ON
                MASK    FLAGWRD0
                EXTEND
                BZF     GOPIN           # NO

                TC      DOWNFLAG
                ADRES   RNDVZFLG

                CA      TRACKBIT        # IS TRACK FLAG ON
                MASK    FLAGWRD1
                EXTEND
                BZF     GOPIN           # NO

                TC      DOWNFLAG
                ADRES   TRACKFLG

                TC      DOWNFLAG
                ADRES   UPDATFLG

                TC      DOWNFLAG
                ADRES   IMUSE

                CAF     EBANK6
                TS      EBANK

                INHINT
                TC      STOPRATE

                CAF     NEGONE
                TS      OPTIND

                TC      INTPRET
```

```
CALL
        INTSTALL        # DON'T INTERRUPT INTEGRATION
EXIT

TC      2PHSCHNG
```

Uses EBANK 80, FLAGWRD0 95, FLAGWRD1 97, IMUSE 95, IT 185, OPTIND 161, RESTART 57, RNDVZBIT 97, RNDVZFLG 97, TC 169, TRACKBIT 101, TRACKFLG 101, and UPDATFLG 99.

436 ⟨*Page CM0260* 436⟩≡ (404 2692)

```
                OCT     2               # KILL GROUP 2 TO HALT P20 ACTIVITY
                OCT     1               # ALSO KILL GROUP 1

CLEANOUT        INHINT
                TC      POSTJUMP
                CADR    ENEMA           # CAUSE RESTART

# LEMVEC        VERB 80         DESCRIPTION
#       UPDATE LEM STATE VECTOR
#               RESET VEHUPFLG TO 0

LEMVEC          TC      DOWNFLAG
                ADRES   VEHUPFLG        # VEHUPFLG DOWN INDICATES LEM

                TCF     GOPIN

# CSMVEC        VERB 81         DESCRIPTION
#       UPDATE CSM STATE VECTOR
#               SET VEHUPFLG TO 1

CSMVEC          TC      UPFLAG
                ADRES   VEHUPFLG        # VEHUPFLG UP INDICATES CM

                TCF     GOPIN

# DNEDUMP       VERB 74         DESCRIPTION
#       INITIALZE DOWN-TELEMETRY PROGRAM FOR ERASABLE MEMORY DUMP.
#
#       1.      SET EXT VERB DISPLAY BUSY FLAG.
#       2.      REPLACE CURRENT DOWNLIST WITH ERASABLE MEMORY.
#       3.      RELEASE EXT VERB DISPLAY.

                EBANK=  10
DNEDUMP         CAF     LDNDUMPI
                TS      DNTMGOTO
                TC      GOPIN

V74             EQUALS  DNEDUMP
LDNDUMPI        REMADR  DNDUMPI

# LFTFLGON      VERB 75         DESCRIPTION
#       SET LIFT-OFF FLAG
#       1.      SETUP GRRBKFLG, GUIDANCE REFERENCE RELEASE BACK-UP FLAG.
#       2.      RETURN VIA PINBRNCH
```

```
LFTFLGON        TC      UPFLAG          # VB 75 -- SET LIFTOFF FLAG BIT
                ADRES   GRRBKFLG        # BIT 5 FLAG 5
                TC      GOPIN
```

Uses DNTMGOTO 148, EBANK 80, GRRBKFLG 115, RESTART 57, STATE 138, TC 169, and VEHUPFLG 99.

437 ⟨*Page CM0261* 437⟩≡ (404 2692)

```
CHKP00H         CA      MODREG
                EXTEND
                BZF     TCQ
                TCF     ALM/END

EXDAPOFF        EXTEND
                DCA     IDLECADR        # SET T5 TO IDLE.
                DXCH    T5LOC
                CS      OCT60000
                MASK    FLAGWRD6        # RESET DAPBITS 1 AND 2.
                TS      FLAGWRD6
                TC      Q

                SBANK=  PINSUPER        # Added RSB 2009
                EBANK=  PACTOFF
IDLECADR        2CADR   T5IDLOC
```

Uses EBANK 80, FLAGWRD6 117, MODREG 154, PACTOFF 198, PINSUPER 69, Q 80, T5LOC 163, and TC 169.

438 ⟨*Page CM0262* 438⟩≡ (404 2692)

```
# VERB 89       DESCRIPTION     RENDEZVOUS FINAL ATTITUDE ROUTINE (R63)
#
# CALLED BY VERB 89 ENTER DURING P00.  PRIO 10 IS USED.  CALCULATES AND
# DISPLAYS FINAL GIMBAL ANGLES TO POINT CSM +X AXIS OR PREFERRED AXIS
# (UNIT(Z)COS55 DEG + UNIT(X)SIN55 DEG) AT LM.
#
# 1. KEY IN V 89 E ONLY IF IN PROG 00.  IF NOT IN P00, OPERATOR ERROR AND
# EXIT R63, OTHERWISE CONTINUE.
#
# 2. IF IN P00, DO IMU STATUS CHECK ROUTINE (R02BOTH).  IF IMU ON AND ITS
# ORIENTATION KNOWN TO CGC, CONTINUE.
#
# 3. FLASH DISPLAY V 04 N 06.  R2 INDICATES WHICH SPACECRAFT AXIS IS TO
# BE POINTED AT LM.  INITIAL CHOICE IS PREFERRED AXIS (R2=1).
# ASTRONAUT CAN CHANGE TO (+X) AXIS (R2 NOT = 1) BY V 22 E 2 E.  CONTINUE
# AFTER KEYING IN PROCEED.
#
# 4. SET PREFERRED ATTITUDE FLAG ACCORDING TO OPTION DESIRED.  SET FLAG
# FOR PREFERRED AXIS.  RESET FLAG FOR X AXIS.
#
# 5. CURRENT TIME IS STORED AND R63COMP IS CALLED
#
#       R63COMP JOB:
#
#               UPDATES CSM AND LM STATE VECTORS USING CONIC EQUATIONS.
#
#               CALCULATES BOTH PREFERRED AND X AXIS TRACKING ATT FROM CSM TO LM.
#
#               DESIRED GIMBAL ANGLES AS INDICATED BY PREFERRED ATTITUDE FLAG
#               ARE STORED FOR LATER R60CSM CALL.
#
# 6.  FLASH DISPLAY V 06 N18 AND AWAIT RESPONSE.
#
# 7.  RECYCLE:  RETURN TO STEP 5.
#     TERMINATE:  EXIT R63 ROUTINE
#     PROCEED:  RESET 3AXISFLG AND CALL R60CSM FOR ATTITUDE MANEUVER.

V89PERF         TC      CHKP00H         # DEMAND P00
                TC      TESTXACT
                INHINT
                CAF     PRIO10
                TC      FINDVAC
                SBANK=  LOWSUPER        # Added by RSB 2009.
                EBANK=  P21TIME
                2CADR   V89CALL
```

```
                TCF     ENDOFJOB

WMATRXNG        TC      DOWNFLAG        # RESET RENDWFLAG
                ADRES   RENDWFLG
```

Uses 3AXISFLG 115, DISPLAYS 59, EBANK 80, LOWSUPER 67, N 206, P21TIME 179, R2 188, RENDWFLG 117, STATE 138, TC 169, V 229, and Z 80.

440 ⟨*Page CM0263* 440⟩≡ (404 2692)

```
                TC      DOWNFLAG        # RESET ORBWFLAG
                ADRES   ORBWFLAG
                TC      GOPIN

GOSHOSUM        EQUALS  SHOWSUM

SHOWSUM         TC      CHKP00H
                TC      TESTXACT        # *
                CAF     S+1             # *
                TS      SKEEP6          # * SHOWSUM OPTION
                CAF     S+ZERO          # *
                TS      SMODE           # * TURN OFF SELF-CHECK
                CA      SELFADRS        # *
                TS      SELFRET         # *
                TC      STSHOSUM        # * ENTER ROPECHK

SDISPLAY        LXCH    SKEEP2          # * BNK NO FOR DSP
                LXCH    SKEEP3          # * BUGGER WORD FOR DSP
NOKILL          CA      ADRS1           # *
                TS      MPAC    +2      # *
                CA      VNCON           # * 0501
                TC      BANKCALL        # *
                CADR    GOXDSPF         # *
                TC      +3              # *
                TC      NXTBNK          # *
                TC      NOKILL          # *
                CA      SELFADRS
                TS      SKEEP1

                TC      ENDEXT          # *

VNCON           VN      501             # *

ENDSUMS         CA      SKEEP6          # *
                EXTEND                  # *
                BZF     SELFCHK         # * ROPECHK, START SELFCHK AGAIN.
                TC      STSHOSUM        # * START SHOWSUM AGAIN.


# VB 76 --- SET PREFERRED ATTITUDE FLAG --- DRIVE TO PREFERRED.

SETPRFLG        TC      UPFLAG
                ADRES   PRFTRKAT        # BIT 10 FLAG 5
                TC      GOPIN
```

```
# VB 77 --- RESET PREFERRED ATTITUDE FLAG --- DRIVE TO +X-AXIS ATT.

RESETPRF        TC      DOWNFLAG
                ADRES   PRFTRKAT        # BIT 10 FLAG 5
                TC      GOPIN
```

Uses MPAC 145, ORBWFLAG 107, PRFTRKAT 115, SELFRET 165, SKEEP1 165, SKEEP2 165, SKEEP3 165, SKEEP6 165, SMODE 165, TC 169, and VN 159.

442 ⟨*Page CM0264* 442⟩≡ (404 2692)

```
# VB 87 --- SET VHF RANGE FLAG --- ALLOWS R22 TO ACCEPT RANGE DATA.

SETVHFLG        TC      INTPRET
                SET     EXIT
                        VHFRFLAG
                TC      GOPIN

# VB 88 --- RESET VHF RANGE FLAG --- STOPS ACCEPTANCE OF RANGE DATA.

RESETVHF        TC      INTPRET
                CLEAR   EXIT
                        VHFRFLAG
                TC      TRFAILOF        # TRACKER FAIL LIGHT

                TC      GOPIN

# VERB 66.      VEHICLES ARE ATTACHED. --- MOVE THIS VEHICLE STATE VECTOR TO
#               OTHER VEHICLE STATE VECTOR.

# USE SUBROUTINE GENTRAN.

                EBANK=  RRECTHIS
ATTACHED        CAF     PRIO10
                TC      FINDVAC
                EBANK=  RRECTHIS
                2CADR   ATTACHIT

                TC      ENDOFJOB

ATTACHIT        TC      INTPRET
                CALL
                        INTSTALL
                SET     BON
                        MOONOTH
                        MOONTHIS
                        +3
                CLEAR
                        MOONOTH
                EXIT
                CAF     OCT51
                TC      GENTRAN
                ADRES   RRECTHIS        # OUR STATE VECTOR INTO OTHER VIA GENTRAN
                ADRES   RRECTOTH

TACHEXIT        RELINT
```

```
TC      INTPRET
CALL                    # UPDATE RN, VN, R-OTHER, V-OTHER
        PTOACSM
```

Uses EBANK 80, MOONOTH 73, MOONTHIS 71, R-OTHER 172, RANGE 179, RN 159, RRECTHIS 172, RRECTOTH 172, STATE 138, TC 169, V 229, V-OTHER 172, VHFRFLAG 131, and VN 159.

444 ⟨*Page CM0265* 444⟩≡ (404 2692)

```
                LXA,2   CALL
                        PBODY
                        SVDWN1
                CALL
                        SVDWN2
                EXIT

                CAF     TCPINAD
                INDEX   FIXLOC
                TS      QPRET
                TC      POSTJUMP
                CADR    INTWAKE

TCPIN           RTB
                        PINBRNCH

OCT51           OCT     51
TCPINAD         CADR    TCPIN

# VERB 47.  MOVE LM STATE VECTOR INTO CSM STATE VECTOR

LMTOCMSV        CAF     PRIO10
                TC      FINDVAC
                EBANK=  RRECTHIS
                2CADR   LMTOCM

                TC      ENDOFJOB

LMTOCM          TC      INTPRET
                CALL
                        INTSTALL
                SET     BON
                        MOONTHIS
                        MOONOTH
                        +3
                CLEAR
                        MOONTHIS
                EXIT

                CAF     OCT51
                TC      GENTRAN
                ADRES   RRECTOTH        # LM STATE VECTOR INTO CM VIA GENTRAN
                ADRES   RRECTHIS

                TCF     TACHEXIT
```

```
# VERB 94 --- DO R64 VIA ENEMA TO PICK UP IN P23.

VERB94          CAF     V94FLBIT
                MASK    FLAGWRD9        # IS V94FLAG SET
```

Uses EBANK 80, FIXLOC 140, MOONOTH 73, MOONTHIS 71, PBODY 177, QPRET 85, RRECTHIS 172, RRECTOTH 172, STATE 138, and TC 169.

446 ⟨*Page CM0266* 446⟩≡ (404 2692)

```
                EXTEND
                BZF     ALM/END         # NO --- OPERATOR ERROR

                TC      DOWNFLAG
                ADRES   V94FLAG

                TC      CHECKMM         # IS IT P23
                MM      23
                TC      ALM/END         # NO -- OPERATOR ERROR
                TC      PHASCHNG
                OCT     112             # SET GROUP 2 TO DO R64

                TC      CLEANOUT        # CAUSE RESTART

# V90PERF       VERB 90         DESCRIPTION
#       REQUEST RENDEZVOUS OUT-OF-PLANE DISPLAY (R36)
#
#       1.      SET EXT VERB DISPLAY BUSY FLAG.
#       2.      SCHEDULE R36 CALL WITH PRIORITY 10
#               A.      DISPLAY
#                       TIME OF EVENT -- HOURS, MINUTES, SECONDS
#                       Y       OUT-OF-PLANE POSITION -- NAUTICAL MILES
#                       YDOT    OUT-OF-PLANE VELOCITY -- FEET/SECOND
#                       PSI     ANGLE BTW LINE OF SIGHT AND FORWARD
#                               DIRECTION VECTOR IN HORIZONTAL PLANE -- DEGREES

V90PERF         TC      TESTXACT
                CAF     PRIO7           # R36,V90
                TC      FINDVAC
                SBANK=  PINSUPER        # Added RSB 2009
                EBANK=  RPASS36
                2CADR   R36

                TCF     ENDOFJOB

# VERB 96  SET QUITFLAG TO STOP INTEGRATION

VERB96          TC      UPFLAG          # QUITFLAG WILL CAUSE INTEGRATION TO EXIT
                ADRES   QUITFLAG        #       AT NEXT TIMESTEP

                TC      UPFLAG
                ADRES   V96ONFLG
                CAF     ZERO
                TC      POSTJUMP
                CADR    V37             # GO TO P00
```

```
                EBANK=  LANDMARK
V52             TC      CHECKMM         # IS P22 OPERATING
                MM      22
                TC      ALM/END         # NO
                CAF     LANDBANK
                TS      EBANK
```

Uses A 80, EBANK 80, IT 185, LANDMARK 190, MM 226, PINSUPER 69, PRIORITY 145, QUITFLAG 131, RESTART 57, RPASS36 179, and TC 169.

448 ⟨*Page CM0267* 448⟩≡ (404 2692)

```
                CS      PRIO7           # YES   SET BITS 12,11,10 OF LANDMARK =
                MASK    LANDMARK        #       BITS 14,13,12 OF MARKSTAT AFTER
                TS      LANDMARK        #       SUBT. THEM FROM 5 TO GET OFFSET
                CA      MARKSTAT        #       MARK NO.
                TS      SR
                CA      SR
                CA      SR
                MASK    PRIO7
                CS      A
                AD      PRIO5
                ADS     LANDMARK
                TC      GOPIN
LANDBANK        ECADR   LANDMARK

# VERB 67  ASTRONAUT DISPLAY OF W MATRIX

V67             TC      TESTXACT
                CAF     PRIO5
                TC      FINDVAC
                EBANK=  W
                2CADR   V67CALL

                TC      ENDOFJOB

# VB 44. SET SURFACE FLAG.

SETSURF         TC      UPFLAG
                ADRES   SURFFLAG
                TCF     GOPIN

# VB 45. RESET SURFACE FLAG

RESTSRF         TC      DOWNFLAG
                ADRES   SURFFLAG
                TCF     GOPIN
```

Uses A 80, EBANK 80, LANDMARK 190, MARKSTAT 163, SR 80, SURFFLAG 127, TC 169, and W 183.

3.3.8 pinball noun tables

449 ⟨*pinball noun tables* 449⟩≡ (245b)

⟨*Page CM0268* 450⟩
⟨*Page CM0269* 451⟩
⟨*Page CM0270* 452⟩
⟨*Page CM0271* 454⟩
⟨*Page CM0272* 456⟩
⟨*Page CM0273* 458⟩
⟨*Page CM0274* 460⟩
⟨*Page CM0275* 462⟩
⟨*Page CM0276* 464⟩
⟨*Page CM0277* 466⟩
⟨*Page CM0278* 468⟩
⟨*Page CM0279* 470⟩
⟨*Page CM0280* 472⟩
⟨*Page CM0281* 474⟩
⟨*Page CM0282* 476⟩
⟨*Page CM0283* 478⟩
⟨*Page CM0284* 479⟩

450 ⟨*Page CM0268* 450⟩≡ (449 2778)

```
# THE FOLLOWING REFERS TO THE NOUN TABLES
#
#       COMPONENT CODE NUMBER   INTERPRETATION
#
#       00000                   1 COMPONENT
#       00001                   2 COMPONENT
#       00010                   3 COMPONENT
#       X1XXX                   BIT 4 = 1.  DECIMAL ONLY
#       1XXXX                   BIT 5 = 1.  NO LOAD
#
#       END OF COMPONENT CODE NUMBERS
#
#       SF ROUTINE CODE NUMBER  INTERPRETATION
#
#       00000                   OCTAL ONLY
#       00001                   STRAIGHT FRACTIONAL
#       00010                   CDU DEGREES (XXX.XX)
#       00011                   ARITHMETIC SF
#       00100                   ARITH DP1       OUT (MULT BY 2EXP14 AT END)     IN (S
#       00101                   ARITH DP2       OUT (STRAIGHT)                  IN (S
#       00110                   Y OPTICS DEGREES (XX.XXX MAX 89.999)
#       00111                   ARITH DP3       OUT (SL 7 AT END)               IN (S
#       01000                   WHOLE HOURS IN R1, WHOLE MINUES (MOD 60) IN R2,
#                                       SECONDS (MOD 60) 0XX.XX IN R3.  *** ALARMS IF
#       01001                   MINUTES (MOD 60) IN D1D2, D3 BLANK, SECONDS (MOD 60)
#                                       LIMITS TO 59B59 IF MAG EXCEEDS THIS VALUE.
#                                       ALARMS IF USED WITH OCTAL ******** IN (ALARM)
#       01010                   ARITH DP4       OUT (STRAIGHT)                  IN (S
#       01011                   ARITH1 SF       OUT (MULT BY 2EXP14 AT END)     IN (S
#       01100                   2 INTEGERS IN D1D2, D4D5, D3 BLANK.
#                                       ALARMS IF USED WITH OCTAL ******** IN (ALARM)
#       01101                   DP STRAIGHT FRACTIONAL
#
#       END OF SF ROUTINE CODE NUMBERS

#       SF CONSTANT CODE NUMBER INTERPRETATION
#
#       00000                   WHOLE                           USE ARITH
#       00000                   DP TIME SEC (XXX.XX SEC)        USE ARITHDP1
#       00001                   SPARE
#       00010                   CDU DEGREES                     USE CDU DEGREES
#       00010                   Y OPTICS DEGREES                USE Y OPTICS DEGREES
#       00011                   DP DEGREES (90) XX.XXX DEG      USE ARITHDP3
#       00100                   DP DEGREES (360) XXX.XX DEG     USE ARITHDP4
#       00101                   DEGREES (180) XXX.XX DEG        USE ARITH
```

```
#       00110                   WEIGHT2 (XXXXX. LBS)            USE ARITH1
#       00111                   POSITION5 (XXX.XX NAUTICAL MILES)
#                                                               USE ARITHDP3
#       01000                   POSITION4 (XXXX.X NAUTICAL MILES)
```

Uses CODE 140 and R2 188.

451 ⟨*Page CM0269* 451⟩≡ (449 2778)

```
#                                                               USE ARITHDP3
#       01001                   VELOCITY2 (XXXXX. FT/SEC)       USE ARITHDP4
#       01010                   VELOCITY3 (XXXX.X FT/SEC)       USE ARITHDP3
#       01011                   ELEVATION DEGREES (89.999 MAX)  USE ARITH
#       01100                   TRIM DEGREES (XXX.XX DEG)       USE ARITH
#       01101                   INERTIA (XXXXXBB. SLUG FT FT)   USE ARITH
#       01101                   THRUST MOMENT (XXXXXBB. FT LBS) USE ARITH
#       01110                   VELOCITY/2VS (XXXXX. FT/SEC)    USE ARITHDP4
#       01111                   POSITION6 (XXXX.X NAUT MI)      USE ARITHDP3
#       10000                   DRAG ACCELERATION (XXX.XX)      USE ARITHDP2
#       10001                   POSITION8 (XXXX.X NAUT MI)      USE ARITHDP?
#       10010                   POSITION9 (XXX.XX NAUT MI)      USE ARITHDP4
#       10011                   VELOCITY4 (XXXX.X FT/SEC)       USE ARITHDP2
#
#       END OF SF CONSTANT CODE NUMBERS

# FOR GREATER THAN SINGLE PRECISION SCALES, PUT ADDRESS IN MAJOR PART INTO
# NOUN TABLES.

# OCTAL LOADS PLACE +0 INTO MAJOR PART, DATA INTO MINOR PART.

# OCTAL DISPLAYS SHOW MINOR PART ONLY.

# TO GET AT BOTH MAJOR AND MINOR PARTS (IN OCTAL), USE NOUN 01.

# A NOUN MAY BE DECLARED "DECIMAL ONLY" BY MAKING BIT4=1 OF ITS COMPONENT
# CODE NUMBER.  IF THIS NOUN IS USED WITH ANY OCTAL DISPLAY VERB, OR IF
# DATA IS LOADED IN OCTAL, IT ALARMS.

# IN LOADING AN "HOURS, MINUTES, SECONDS" NOUN, ALL 3 WORDS MUST BE
# LOADED, OR ALARM.

# ALARM IF AN ATTEMPT IS MADE TO LOAD "SPLIT MINUTES/SECONDS" (MMBSS).
# THIS IS USED FOR DISPLAY ONLY.
```

Uses A 80, CODE 140, DISPLAYS 59, IT 185, and THRUST 85.

452 ⟨*Page CM0270* 452⟩≡ (449 2778)

```
# THE FOLLOWING ROUTINES ARE FOR READING THE NOUN TABLES AND THE SF TABLES
# (WHICH ARE IN A SEPARATE BANK FROM THE REST OF PINBALL).  THESE READING
# ROUTINES ARE IN THE SAME BANK AS THE TABLES.  THEY ARE CALLED BY DXCH Z.

# LODNNTAB LOADS NNADTEM WITH THE NNADTAB ENTRY, NNTYPTEM WITH THE
# NNTYPTAB ENTRY.  IF THE NOUN IS MIXED, IDADITEM IS LOADED WITH THE FIRST
# IDADDTAB ENTRY, IDAD2TEM THE SECOND IDADDTAB ENTRY, IDAD3TEM THE THIRD
# IDADDTAB ENTRY, RUTMXTEM WITH THE RUTMXTAB ENTRY.  MIXBR IS SET FOR
# MIXED OR NORMAL NOUN.

                BANK    06
                SETLOC  PINBALL3
                BANK

                COUNT   42/NOUNS

LODNNTAB        DXCH    IDAD2TEM                # SAVE RETURN INFO IN IDAD2TEM, IDAD3
                INDEX   NOUNREG
                CAF     NNADTAB
                TS      NNADTEM
                INDEX   NOUNREG
                CAF     NNTYPTAB
                TS      NNTYPTEM
                CS      NOUNREG
                AD      MIXCON
                EXTEND
                BZMF    LODMIXNN                # NOUN NUMBER G/E FIRST MIXED NOUN
                CAF     ONE                     # NOUN NUMBER L/ FIRST MIXED NOUN
                TS      MIXBR                   # NORMAL.  +1 INTO MIXBR
                TC      LODNLV
LODMIXNN        CAF     TWO                     # MIXED.  +2 INTO MIXBR.
                TS      MIXBR
                INDEX   NOUNREG
                CAF     RUTMXTAB -40D           # FIRST MIXED NOUN = 40.
                TS      RUTMXTEM
                CAF     LOW10
                MASK    NNADTEM
                TS      Q                       # TEMP
                INDEX   A
                CAF     IDADDTAB
                TS      IDAD1TEM                # LOAD IDAD1TEM WITH FIRST IDADDTAB E
                EXTEND
                INDEX   Q                       # LOAD IDAD2TEM WITH 2ND IDADDTAB ENT
                DCA     IDADDTAB +1             # LOAD IDAD3TEM WITH 3RD IDADDTAB ENT
LODNLV          DXCH    IDAD2TEM                # PUT RETURN INFO INTO A, L.
```

```
                DXCH    Z

MIXCON          =       OCT50                   # FIRST MIXED NOUN =40.  (DEC 40)

# GTSFOUT LOADS SFTEMP1, SFTEMP2 WITH THE DP SFOUTAB ENTRIES.
```

Uses A 80, COUNT 142, IDAD1TEM 144, IDAD2TEM 144, IDAD3TEM 144, L 80, MIXBR 142, NNADTEM 144, NNTYPTEM 144, NOUNREG 152, PINBALL3 71, Q 80, RUTMXTEM 144, SAVE 191, SFTEMP1 140, SFTEMP2 140, TC 169, TEMP 191, and Z 80.

454 ⟨*Page CM0271* 454⟩≡ (449 2778)

```
GTSFOUT         DXCH    SFTEMP1                 # 2X (SFCONUM) ARRIVES IN SFTEMP1.
                EXTEND
                INDEX   A
                DCA     SFOUTAB
SFCOM           DXCH    SFTEMP1
                DXCH    Z

# GTSFIN LOADS SFTEMP1, SFTEMP2 WITH THE DP SFINTAB INTRIES.

GTSFIN          DXCH    SFTEMP1                 # 2X (SFCONUM) ARIVES IN SFTEMP1.
                EXTEND
                INDEX   A
                DCA     SFINTAB
                TCF     SFCOM

                                                # NN    NORMAL NOUNS

NNADTAB         OCT     00000                   # 00    NOT IN USE
                OCT     40000                   # 01    SPECIFY MACHINE ADDRESS (FRAC
                OCT     40000                   # 02    SPECIFY MACHINE ADDRESS (WHOI
                OCT     40000                   # 03    SPECIFY MACHINE ADDRESS (DEGI
                OCT     0                       # 04    SPARE
                ECADR   DSPTEM1                 # 05    ANGULAR ERROR/DIFFERENCE
                ECADR   OPTION1                 # 06    OPTION CODE
                ECADR   XREG                    # 07    ECADR OF WORD TO BE MODIFIED
                                                #       ONES FOR BITS TO BE MODIFIED
                                                #       1 TO SET OR 0 TO RESET SELECT
                ECADR   ALMCADR                 # 08    ALARM DATA
                ECADR   FAILREG                 # 09    ALARM CODES
                OCT     77776                   # 10    CHANNEL TO BE SPECIFIED
                ECADR   TCSI                    # 11    TIG OF CSI (HRS,MIN,SEC)
                ECADR   OPTIONX                 # 12    OPTION CODE
                                                #       (USED BY EXTENDED VERBS ONLY)
                ECADR   TCDH                    # 13    TIG OF CDH (HRS,MIN,SEC)
                OCT     0                       # 14    SPARE
                OCT     77777                   # 15    INCREMENT MACHINE ADDRESS
                ECADR   DSPTEMX                 # 16    TIME OF EVENT (HRS,MIN,SEC)
                ECADR   CPHIX                   # 17    ASTRONAUT TOTAL ATTITUDE
                ECADR   THETAD                  # 18    AUTO MANEUVER BALL ANGLES
                ECADR   THETAD                  # 19    BYPASS ATTITUDE TRIM MANEUVER
                ECADR   CDUX                    # 20    ICDU ANGLES
                ECADR   PIPAX                   # 21    PIPAS
                ECADR   THETAD                  # 22    NEW ICDU ANGLES
                OCT     00000                   # 23    SPARE
```

```
ECADR   DSPTEM2 +1              # 24    DELTA TIME FOR AGC CLOCK (HRS,MIN,SEC)
ECADR   DSPTEM1                 # 25    CHECKLIST
                                #       (USED WITH PLEASE PERFORM ONLY)
ECADR   DSPTEM1                 # 26    PRIO/DELAY, ADRES, BBCON
ECADR   SMODE                   # 27    SELF TEST ON/OFF SWITCH
```

Uses A 80, ALMCADR 165, CDUX 80, CODE 140, CPHIX 163, DSPTEM1 154, DSPTEM2 154, DSPTEMX 154, FAILREG 150, NN 244, OPTION1 157, OPTIONX 154, PIPAX 80, SFTEMP1 140, SFTEMP2 140, SMODE 165, TCDH 197, TCSI 197, THETAD 157, TIG 224, XREG 152, and Z 80.

456 ⟨*Page CM0272* 456⟩≡ (449 2778)

```
                    OCT     0                   # 28    SPARE
                    ECADR   DSPTEM1             # 29    XSM LAUNCH AZIMUTH
                    ECADR   DSPTEM1             # 30    TARGET CODES
                    ECADR   DSPTEM1             # 31    TIME OF LANDING SITE (HRS,MI
                    ECADR   -TPER               # 32    TIME TO PERIGEE (HRS,MIN,SEC
                    ECADR   TIG                 # 33    TIME OF IGNITION (HRS,MIN,SE
                    ECADR   DSPTEM1             # 34    TIME OF EVENT (HRS,MIN,SEC)
                    ECADR   TTOGO               # 35    TIME TO GO TO EVENT (HRS,MIN
                    ECADR   TIME2               # 36    TIME OF AGC CLOCK (HRS,MIN,S
                    ECADR   TTPI                # 37    TIG OF TPI (HRS,MIN,SEC)
                    ECADR   TET                 # 38    TIME OF STATE VECTOR
                    ECADR   T3TOT4              # 39    DELTA TIME TO TRANSFER (HRS,

  # END OF NNADTAB FOR NORMAL NOUNS

                                                # NN    MIXED NOUNS

                    OCT     64000               # 40    TIME TO IGNITION/CUTOFF
                                                #       VG
                                                #       DELTA V (ACCUMULATED)
                    OCT     02003               # 41    TARGET  AZIMUTH
                                                #               ELEVATION
                    OCT     24006               # 42    APOGEE
                                                #       PERIGEE
                                                #       DELTA V (REQUIRED)
                    OCT     24011               # 43    LATITUDE
                                                #       LONGITUDE
                                                #       ALTITUDE
                    OCT     64014               # 44    APOGEE
                                                #       PERIGEE
                                                #       TFF
                    OCT     64017               # 45    MARKS (VHF -  OPTIC)
                                                #       TTI OF NEXT BURN
                                                #       MGA
                    OCT     02022               # 46    AUTOPILOT CONFIGURATION
                    OCT     22025               # 47    THIS VEHICLE WEIGHT
                                                #       OTHER VEHICLE WEIGHT
                    OCT     22030               # 48    PITCH TRIM
                                                #       YAW TRIM
                    OCT     24033               # 49    DELTA R
                                                #       DELTA V
                                                #       VHF OR OPTICS CODE
                    OCT     64036               # 50    SPLASH ERROR
                                                #       PERIGEE
                                                #       TFF
```

```
OCT     22041                   # 51    S-BAND ANTENNA  PITCH
                                #                       YAW
OCT     00044                   # 52    CENTRAL ANGLE OF ACTIVE VEHICLE
OCT     24047                   # 53    RANGE
                                #       RANGE RATE
                                #       PHI
```

Uses -TPER 179, AZIMUTH 191, CODE 140, DSPTEM1 154, LATITUDE 191, NN 244, RANGE 179, STATE 138, T3TOT4 185, TET 169, TFF 179, TIG 224, TIME2 80, TTOGO 236, TTPI 236, V 229, VG 234, and XSM 186.

458 ⟨*Page CM0273* 458⟩≡ (449 2778)

```
OCT     24052                   # 54    RANGE
                                #       RANGE RATE
                                #       THETA
OCT     24055                   # 55    PERIGEE CODE
                                #       ELEVATION ANGLE
                                #       CENTRAL ANGLE
OCT     22060                   # 56    REENTRY ANGLE,
                                #       DELTA V
OCT     20063                   # 57    DELTA R
OCT     24066                   # 58    PERIGEE ALT
                                #       DELTA V TPI
                                #       DELTA V TPF
OCT     24071                   # 59    DELTA VELOCITY LOS
OCT     24074                   # 60    GMAX
                                #       VPRED
                                #       GAMMA EI
OCT     24077                   # 61    IMPACT LATITUDE
                                #       IMPACT LONGITUDE
                                #       HEADS UP/DOWN
OCT     24102                   # 62    INERTIAL VEL MAG (V1)
                                #       ALT RATE CHANGE (HDOT)
                                #       ALT ABOVE PAD RADIUS (H)
OCT     64105                   # 63    RANGE 297,431 TO SPLASH (RTG0
                                #       PREDICTED INERT VEL (VIO)
                                #       TIME TO GO TO 297,431 (TTE)
OCT     24110                   # 64    DRAG ACCELERATION
                                #       INERTIAL VELOCITY (VI)
                                #       RANGE TO SPLASH
OCT     24113                   # 65    SAMPLED AGC TIME (HRS,MIN,SEC
                                #       (FETCHED IN INTERRUPT)
OCT     24116                   # 66    COMMAND BANK ANGLE (BETA)
                                #       CROSS RANGE ERROR
                                #       DOWN RANGE ERROR
OCT     24121                   # 67    RANGE TO TARGET
                                #       PRESENT LATITUDE
                                #       PRESENT LONGITUDE
OCT     24124                   # 68    COMMAND BANK ANGLE (BETA)
                                #       INERTIAL VELOCITY (VI)
                                #       ALT RATE CHANGE (RDOT)
OCT     24127                   # 69    BETA
                                #       DL
                                #       VL
OCT     04132                   # 70    STAR CODE
                                #       LANDMARK DATA
                                #       HORIZON DATA
```

```
OCT     04135                   # 71    STAR CODE
                                #       LANDMARK DATA
                                #       HORIZON DATA
OCT     24140                   # 72    DELT ANG
                                #       DELT ALT
```

Uses ALT 157, CODE 140, COMMAND 169, DELT 188, GAMMA 232, GMAX 229, H 177, HDOT 231, HORIZON 190, LANDMARK 190, LATITUDE 191, RANGE 179, RDOT 229, REENTRY 65, RTGO 229, STAR 186, THETA 148, TTE 229, V 229, V1 145, VEL 226, VIO 229, VL 229, and VPRED 231.

460 ⟨*Page CM0274* 460⟩≡ (449 2778)

```
                                        #       SEARCH OPTION
                OCT     04143           # 73    ALTITUDE
                                        #       VELOCITY
                                        #       FLIGHT PATH ANGLE
                OCT     04146           # 74    COMMAND BANK ANGLE (BETA)
                                        #       INERTIAL VELOCITY (VI)
                                        #       DRAG ACCELERATION
                OCT     64151           # 75    DELTA ALTITUDE CDH
                                        #       DELTA TIME (CDH-CSI OR TPI-CD
                                        #       DELTA TIME (TPI-CDH OR TPI-NC
                OCT     0               # 76    SPARE
                OCT     0               # 77    SPARE
                OCT     0               # 78    SPARE
                OCT     0               # 79    SPARE
                OCT     64170           # 80    TIME TO IGNITION/CUTOFF
                                        #       VG
                                        #       DELTA V (ACCUMULATED)
                OCT     24173           # 81    DELTA V (LV)
                OCT     24176           # 82    DELTA V (LV)
                OCT     24201           # 83    DELTA V (BODY)
                OCT     24204           # 84    DELTA V (OTHER VEHICLE)
                OCT     24207           # 85    VG (BODY)
                OCT     24212           # 86    DELTA V (LV)
                OCT     02215           # 87    MARK DATA       SHAFT
                                        #                       TRUNION
                OCT     24220           # 88    HALF UNIT SUN OR PLANET VECTO
                OCT     24223           # 89    LANDMARK        LATITUDE
                                        #                       LONGITUDE/2
                                        #                       ALTITUDE
                OCT     24226           # 90    Y
                                        #       Y DOT
                                        #       PSI
                OCT     02231           # 91    OCDU ANGLES     SHAFT
                                        #                       TRUNION
                OCT     02234           # 92    NEW OPTICS ANGLES SHAFT
                                        #                         TRUNION
                OCT     04237           # 93    DELTA GYRO ANGLES
                OCT     02242           # 94    NEW OPTICS ANGLES SHAFT
                                        #                         TRUNNION
                OCT     04245           # 95    PREFERRED ATTITUDE ICDU ANGLE
                OCT     04250           # 96    +X-AXIS ATTITUDE ICDU ANGLES
                OCT     04253           # 97    SYSTEM TEST INPUTS
                OCT     04256           # 98    SYSTEM TEST RESULTS
                OCT     24261           # 99    RMS IN POSITION
                                        #       RMS IN VELOCITY
```

```
                                                    #       RMS OPTION

  # END OF NNADTAB FOR MIXED NOUNS

                                                    # NN    NORMAL NOUNS
```

Uses COMMAND 169, LANDMARK 190, LATITUDE 191, LV 85, NN 244, NOMTPI 181, TRUNION 190, V 229, and VG 234.

462 ⟨*Page CM0275* 462⟩≡ (449 2778)

```
NNTYPTAB        OCT     00000                   # 00    NOT IN USE
                OCT     04040                   # 01    3COMP FRACTIONAL
                OCT     04140                   # 02    3COMP WHOLE
                OCT     04102                   # 03    3COMP CDU DEGREES
                OCT     0                       # 04    SPARE
                OCT     00504                   # 05    1COMP DPDEG(360)
                OCT     02000                   # 06    2COMP OCTAL ONLY
                OCT     04000                   # 07    3COMP OCTAL ONLY
                OCT     04000                   # 08    3COMP OCTAL ONLY
                OCT     04000                   # 09    3COMP OCTAL ONLY
                OCT     00000                   # 10    1COMP OCTAL ONLY
                OCT     24400                   # 11    3COMP HMS (DEC ONLY)
                OCT     02000                   # 12    2COMP OCTAL ONLY
                OCT     24400                   # 13    3COMP HMS (DEC ONLY)
                OCT     0                       # 14    SPARE
                OCT     00000                   # 15    1COMP OCTAL ONLY
                OCT     24400                   # 16    3COMP HMS (DEC ONLY)
                OCT     04102                   # 17    3COMP CDU DEG
                OCT     04102                   # 18    3COMP CDU DEG
                OCT     04102                   # 19    3COMP CDU DEG
                OCT     04102                   # 20    3COMP CDU DEGREES
                OCT     04140                   # 21    3COMP WHOLE
                OCT     04102                   # 22    3COMP CDU DEGREES
                OCT     00000                   # 23    SPARE
                OCT     24400                   # 24    3COMP HMS (DEC ONLY)
                OCT     04140                   # 25    3COMP WHOLE
                OCT     04000                   # 26    3COMP OCTAL ONLY
                OCT     00140                   # 27    1COMP WHILE
                OCT     00000                   # 28    SPARE
                OCT     20102                   # 29    1COMP CDU DEG (DEC ONLY)
                OCT     04140                   # 30    3COMP WHOLE
                OCT     24400                   # 31    3COMP HMS (DEC ONLY)
                OCT     24400                   # 32    3COMP HMS (DEC ONLY)
                OCT     24400                   # 33    3COMP HMS (DEC ONLY)
                OCT     24400                   # 34    3COMP HMS (DEC ONLY)
                OCT     24400                   # 35    3COMP HMS (DEC ONLY)
                OCT     24400                   # 36    3COMP HMS (DEC ONLY)
                OCT     24400                   # 37    3COMP HMS (DEC ONLY)
                OCT     24400                   # 38    3COMP HMS (DEC ONLY)
                OCT     24400                   # 39    3COMP HMS (DEC ONLY)

# END OF NNTYPTAB FOR NORMAL NOUNS

                                                # NN    MIXED NOUNS
```

```
OCT     24500                   # 40    3COMP   MIN/SEC, VEL3, VEL3
                                #               (NO LOAD, DEC ONLY)
OCT     00542                   # 41    2COMP   CDU DEG, ELEV DEG
OCT     24410                   # 42    3COMP   POS4, POS4, VEL3
                                #               (DEC ONLY)
OCT     20204                   # 43    3COMP   DPDEG(360), DPDEG(360) POS4
```

Uses NN 244.

464 ⟨*Page CM0276* 464⟩≡ (449 2778)

```
                                        #              (DEC ONLY)
OCT     00410                           # 44    3COMP  POS4, POS4, MIN/SEC
                                        #              (NO LOAD, DEC ONLY)
OCT     10000                           # 45    3COMP  2INT, MIN/SEC, DPDEG
                                        #              (NO LOAD, DEC ONLY)
OCT     00000                           # 46    2COMP  OCTAL ONLY FOR EACH
OCT     00306                           # 47    2COMP  WEIGHT2 FOR EACH
                                        #              (DEC ONLY)
OCT     00614                           # 48    2COMP  TRIM DEG, TRIM DEG
                                        #              (DEC ONLY)
OCT     00510                           # 49    3COMP  POS4, VEL3, WHOLE
                                        #              (DEC ONLY)
OCT     00417                           # 50    3COMP  POS6, POS4, MIN/SEC
                                        #              (NO LOAD, DEC ONLY)
OCT     00204                           # 51    2COMP  DPDEG(360), DPDEG(360
                                        #              (DEC ONLY)
OCT     00004                           # 52    1COMP  DPDEG(360)
OCT     10507                           # 53    3COMP  POS5, VEL3, DPDEG(360
                                        #              (DEC ONLY)
OCT     10507                           # 54    3COMP  POS5, VEL3, DPDEG(360
                                        #              (DEC ONLY)
OCT     10200                           # 55    3COMP  WHOLE, DPDEG(360), DP
                                        #              (DEC ONLY)
OCT     00444                           # 56    2COMP  DPDEG(360), VEL2
                                        #              (DEC ONLY)
OCT     00010                           # 57    1COMP  POS4
                                        #              (DEC ONLY)
OCT     24510                           # 58    3COMP  POS4, VEL3, VEL3
                                        #              (DEC ONLY)
OCT     24512                           # 59    3COMP  VEL3 FOR EACH
                                        #              (DEC ONLY)
OCT     10440                           # 60    3COMP  WHOLE, VEL2, DPDEG(36
                                        #              (DEC ONLY)
OCT     00204                           # 61    3COMP  DPDEG(360), DPDEG(360
                                        #              (DEC ONLY)
OCT     20451                           # 62    3COMP  VEL2, VEL2, POS4
                                        #              (DEC ONLY)
OCT     00457                           # 63    3COMP  POS6, VEL2, MIN/SEC
                                        #              (NO LOAD, DEC ONLY)
OCT     36460                           # 64    3COMP  DRAG ACCEL, VEL2, POS
                                        #              (DEC ONLY)
OCT     00000                           # 65    3COMP  HMS (DEC ONLY)
OCT     37044                           # 66    3COMP  DPDEG(360), POS8, POS
                                        #              (DEC ONLY)
OCT     10217                           # 67    3COMP  POS6, DPDEG(360), DPD
```

```
                                        #               (DEC ONLY)
                OCT     34444           # 68    3COMP   DPDEG(360), VEL2, VEL/2VS
                                        #               (DEC ONLY)
                OCT     35004           # 69    3COMP   DPDEG(360), DRAG ACCEL, VEL/2VS
                                        #               (DEC ONLY)
```

Uses VEL 226.

466 ⟨*Page CM0277* 466⟩≡ (449 2778)

```
                    OCT     00000                   # 70    3COMP   OCTAL ONLY FOR EACH
                    OCT     0                       # 71    3COMP   OCTAL ONLY FOR EACH
                    OCT     00404                   # 72    3COMP   DPDEG(360), POS4, WHO
                                                    #               (DEC ONLY)
                    OCT     10450                   # 73    3COMP   POS4, VEL2, DPDEG(360
                    OCT     40444                   # 74    3COMP   DPDEG(360), VEL2, DRA
                    OCT     00010                   # 75    3COMP   POS4, MIN/SEC, MIN/SE
  #                                                 #                       (NO LOAD, DEC
                    OCT     0                       # 76    SPARE
                    OCT     0                       # 77    SPARE
                    OCT     0                       # 78    SPARE
                    OCT     0                       # 79    SPARE
                    OCT     22440                   # 80    3COMP   MIN/SEC, VEL2, VEL2
                                                    #               (NO LOAD, DEC ONLY)
                    OCT     24512                   # 81    3COMP   VEL3 FOR EACH
                                                    #               (NO LOAD, DEC ONLY)
                    OCT     24512                   # 82    3COMP   VEL3 FOR EACH
                                                    #               (NO LOAD, DEC ONLY)
                    OCT     24512                   # 83    3COMP   VEL3 FOR EACH
                                                    #               (DEC ONLY)
                    OCT     24512                   # 84    3COMP   VEL3 FOR EACH
                                                    #               (DEC ONLY)
                    OCT     24512                   # 85    3COMP   VEL3 FOR EACH
                                                    #               (DEC ONLY)
                    OCT     22451                   # 86    3COMP   VEL2 FOR EACH
                                                    #               (DEC ONLY)
                                                    #               (DEC ONLY)
                    OCT     00102                   # 87    2COMP   CDU DEG, Y OPTICS DEG
                    OCT     0                       # 88    3COMP   FRAC FOR EACH
                                                    #               (DEC ONLY)
                    OCT     16143                   # 89    3COMP   DPDEG(90), DPDEG(90)
                                                    #               (DEC ONLY)
                    OCT     10507                   # 90    3COMP   POS5, VEL3, DEPDEG(36
                                                    #               (DEC ONLY)
                    OCT     00102                   # 91    2COMP   CDUDEG, YOPTICS DEG
                    OCT     00102                   # 92    2COMP   CDUDEG, YOPTICS DEG
                    OCT     06143                   # 93    3COMP   DPDEG(90) FOR EACH
                    OCT     00102                   # 94    2COMP   CDUDEG, YOPTICS DEG
                    OCT     04102                   # 95    3COMP   CDU DEG FOR EACH
                    OCT     04102                   # 96    3COMP   CDU DEG FOR EACH
                    OCT     00000                   # 97    3COMP   WHOLE FOR EACH
                    OCT     00000                   # 98    3COMP   WHOLE, FRAC, WHOLE
                    OCT     01162                   # 99    3COMP   POS9, VEL4, WHOLE
                                                    #               (DEC ONLY)
```

```
# END OF NNTYPTAB FOR MIXED NOUNS

SFINTAB         OCT     00006                   # WHOLE, DP TIME (SEC)
                OCT     03240
                OCT     00000                   # SPARE
                OCT     00000
```

468 ⟨*Page CM0278* 468⟩≡ (449 2778)

```
                    OCT     00000                   # CDU DEGREES, Y OPTICS DEGREES
                    OCT     00000                   #       (SFCONS IN DEGINSF, OPTDEGIN)
                    OCT     10707                   # DP DEGREES (90)
                    OCT     03435                   #       UPPED BY 1
                    OCT     13070                   # DP DEGREES (360) (POINT BETWN BITS
                    OCT     34345                   #       UPPED BY 1
                    OCT     00005                   # DEGREES (180)
                    OCT     21616
                    OCT     26113                   # WEIGHT2
                    OCT     31713
                    OCT     00070                   # POSITION5
                    OCT     20460
                    OCT     01065                   # POSITION4
                    OCT     05740
                    OCT     11414                   # VELOCITY2     (POINT BETWN BITS 11-
                    OCT     31463
                    OCT     07475                   # VELOCITY3
                    OCT     16051
                    OCT     00001                   # ELEVATION DEGREES
                    OCT     03434
                    OCT     00002                   # TRIM DEGREES
                    OCT     22245
                    OCT     00014                   # INERTIA, THRUST MOMENT
                    OCT     35607
                    OCT     07606                   # VELOCITY/2VS
                    OCT     06300
                    OCT     16631                   # POSITION 6
                    OCT     11307
                    OCT     12000                   # DRAG ACCELERATION (POINT BETWN BITS
                    OCT     00000
                    OCT     27176                   # POSITION 8
                    OCT     14235
                    2DEC    30480 B-19              # POSITION 9

                    2DEC    30.48 B-7               # VELOCITY4

  # END OF SFINTAB

  SFOUTAB           OCT     05174                   # WHOLE, DP TIME (SEC)
                    OCT     13261
                    OCT     00000                   # SPARE
                    OCT     00000
                    OCT     00000                   # CDU DEGREES, Y OPTICS DEGREES
                    OCT     00000                   #       (SFCONS IN DEGOUTSF, OPTDEGOU
                    OCT     00714                   # DP DEGREES (90) (POINT BETWN BITS 7
```

```
OCT     31463
OCT     13412                   # DP DEGREES (360)
OCT     07534
OCT     05605                   # DEGREES (180)
```

Uses THRUST 85.

470 ⟨*Page CM0279* 470⟩≡ (449 2778)

```
                OCT     03656
                OCT     00001                   # WEIGHT2
                OCT     16170
                OCT     00441                   # POSITION5
                OCT     34306
                OCT     07176                   # POSITION4
                OCT     21603
                OCT     15340                   # VELOCITY2
                OCT     15340
                OCT     01031                   # VELOCITY3     (POINT BETWN BITS 7-8
                OCT     21032
                OCT     34631                   # ELEVATION DEGREES
                OCT     23146
                OCT     14340                   # TRIM DEGREES
                OCT     24145
                OCT     02363                   # INERTIA, THRUST MOMENT
                OCT     03721
                OCT     20373                   # VELOCITY/ZVS
                OCT     02122
                OCT     00424                   # POSITION 6    (POINT BETWN BITS 7-8
                OCT     30446
                OCT     00631                   # DRAG ACCELERATION
                OCT     23146
                OCT     00260                   # POSITION 8
                OCT     06213
                2DEC    17.2010499 B-7          # POSITION 9

                2DEC    .032808399              # VELOCITY4

# END OF SFOUTAB

                                                # NN    SF CONSTANT             SF RO

IDADDTAB        ECADR   TTOGO                   # 40    MIN/SEC                 M/S
                ECADR   VGDISP                  # 40    VEL3                    DP3
                ECADR   DVTOTAL                 # 40    VEL3                    DP3
                ECADR   DSPTEM1                 # 41    CDU DEG                 CDU
                ECADR   DSPTEM1 +1              # 41    ELEV DEG                ARTH
                OCT     0                       # 41    SPARE COMPONENT
                ECADR   HAPO                    # 42    POS4                    DP3
                ECADR   HPER                    # 42    POS4                    DP3
                ECADR   VGDISP                  # 42    VEL3                    DP3
                ECADR   LAT                     # 43    DPDEG(360)              DP4
                ECADR   LONG                    # 43    DPDEG(360               DP4
                ECADR   ALT                     # 43    POS4                    DP3
```

```
ECADR   HAPOX                   # 44    POS4                    DP3
ECADR   HPERX                   # 44    POS4                    DP3
ECADR   TFF                     # 44    MIN/SEC                 M/S
ECADR   VHFCNT                  # 45    2INT                    2INT
```

Uses ALT 157, DSPTEM1 154, DVTOTAL 224, HAPO 181, HAPOX 181, HPER 181, HPERX 181, LAT 157, LONG 157, NN 244, TFF 179, THRUST 85, TTOGO 236, VGDISP 231, and VHFCNT 157.

472 ⟨*Page CM0280* 472⟩≡ (449 2778)

```
ECADR   TTOGO          # 45   MIN/SEC          M/S
ECADR   +MGA           # 45   DPDEG(360)       DP4
ECADR   DAPDATR1       # 46   OCTAL ONLY       OCT
ECADR   DAPDATR2       # 46   OCATAL ONLY      OCT
OCT     0              # 46   SPARE COMPONENT
ECADR   CSMMASS        # 47   WEIGHT2          ARTH1
ECADR   LEMMASS        # 47   WEIGHT2          ARTH1
OCT     00000          # 47   SPARE COMPONENT
ECADR   PACTOFF        # 48   TRIM DEG2        ARTH
ECADR   YACTOFF        # 48   TRIM DEG2        ARTH
OCT     00000          # 48   SPARE COMPONENT
ECADR   N49DISP        # 49   POS4             DP3
ECADR   N49DISP +2     # 49   VEL3             DP3
ECADR   N49DISP +4     # 49   WHOLE            ARTH
ECADR   RSP-RREC       # 50   POS6             DP3
ECADR   HPERX          # 50   POS4             DP3
ECADR   TFF            # 50   MIN/SEC          M/S
ECADR   RHOSB          # 51   DPDEG(360)
ECADR   GAMMASB        # 51   DPDEG(360)       DP4
OCT     0              # 51   SPARE COMPONENT
ECADR   ACTCENT        # 52   DPDEG(360)       DP4
OCT     00000          # 52   SPARE COMPONENT
OCT     00000          # 52   SPARE COMPONENT
ECADR   RANGE          # 53   POS5             DP1
ECADR   RRATE          # 53   VEL3             DP3
ECADR   RTHETA         # 53   DPDEG(360)       DP4
ECADR   RANGE          # 54   POS5             DP1
ECADR   RRATE          # 54   VEL3             DP3
ECADR   RTHETA         # 54   DPDEG(360)       DP4
ECADR   NN1            # 55   WHOLE            ARTH
ECADR   ELEV           # 55   DPDEG(360)       DP4
ECADR   CENTANG        # 55   DPDEG(360)       DP4
ECADR   RTEGAM2D       # 56   DPDEG(360)       DP4
ECADR   RTEDVD         # 56   VEL2             DP4
OCT     0              # 56   SPARE COMPONENT
ECADR   DELTAR         # 57   POS4             DP3
OCT     0              # 57   SPARE COMPONENT
OCT     0              # 57   SPARE COMPONENT
ECADR   POSTTPI        # 58   POS4             DP3
ECADR   DELVTPI        # 58   VEL3             DP3
ECADR   DELVTPF        # 58   VEL3             DP3
ECADR   DVLOS          # 59   VEL3             DP3
ECADR   DVLOS +2       # 59   VEL3             DP3
ECADR   DVLOS +4       # 59   VEL3             DP3
ECADR   GMAX           # 60   WHOLE            ARTH
```

```
ECADR   VPRED                   # 60    VEL2                    DP4
ECADR   GAMMAEI                 # 60    DPDEG(360)              DP4
ECADR   LAT(SPL)                # 61    DPDEG(360)              DP4
ECADR   LNG(SPL)                # 61    DPDEG(360)              DP4
ECADR   HEADSUP                 # 61    WHOLE                   ARTH
```

Uses +MGA 234, ACTCENT 183, CSMMASS 200, DAPDATR1 200, DAPDATR2 200, DELTAR 183, DELVTPF 183, DELVTPI 183, DVLOS 183, GAMMAEI 231, GAMMASB 179, GMAX 229, HEADSUP 216, HPERX 181, LAT 157, LAT(SPL) 224, LEMMASS 200, LNG(SPL) 224, N49DISP 232, NN1 241, PACTOFF 198, POSTTPI 183, RANGE 179, RHOSB 179, RRATE 179, RSP-RREC 181, RTEDVD 241, RTEGAM2D 241, RTHETA 179, TFF 179, TTOGO 236, VPRED 231, and YACTOFF 198.

474 ⟨*Page CM0281* 474⟩≡ (449 2778)

```
ECADR   VMAGI       # 62   VEL2                  DP4
ECADR   HDOT        # 62   VEL2                  DP4
ECADR   ALTI        # 62   POS4                  DP3
ECADR   RTGO        # 63   POS6                  DP3
ECADR   VIO         # 63   VEL2                  DP4
ECADR   TTE         # 63   MIN/SEC               M/S
ECADR   D           # 64   DRAG ACCEL            DP2
ECADR   VMAGI       # 64   VEL2                  DP4
ECADR   RTGON64     # 64   POS6                  DP3
ECADR   SAMPTIME    # 65   HMS (MIXED ONLY TO KEEP CODE
ECADR   SAMPTIME    # 65   HMS                   HMS
ECADR   SAMPTIME    # 65   HMS                   HMS
ECADR   ROLLC       # 66   DPDEG(360)            DP4
ECADR   XRNGERR     # 66   POS8                  DP3
ECADR   DNRNGERR    # 66   POS6                  DP3
ECADR   RTGON67     # 67   POS6                  DP3
ECADR   LAT         # 67   DPDEG(360)            DP4
ECADR   LONG        # 67   DPDEG(360)            DP4
ECADR   ROLLC       # 68   DPDEG(360)            DP4
ECADR   VMAGI       # 68   VEL2                  DP4
ECADR   RDOT        # 68   VEL/2VS               DP4
ECADR   ROLLC       # 69   DPDEG(360)            DP4
ECADR   Q7          # 69   DRAG ACCEL            DP2
ECADR   VL          # 69   VEL/2VS               DP4
ECADR   STARCODE    # 70   OCTAL ONLY            OCT
ECADR   LANDMARK    # 70   OCTAL ONLY            OCT
ECADR   HORIZON     # 70   OCTAL ONLY            OCT
ECADR   STARCODE    # 71   OCTAL ONLY            OCT
ECADR   LANDMARK    # 71   OCTAL ONLY            OCT
ECADR   HORIZON     # 71   OCTAL ONLY            OCT
ECADR   THETZERO    # 72   DPDEG(360)            DP4
ECADR   DELHITE     # 72   POS4                  DP3
ECADR   OPTION2     # 72   WHOLE                 ARTH
ECADR   P21ALT      # 73   POS4                  DP3
ECADR   P21VEL      # 73   VEL2                  DP4
ECADR   P21GAM      # 73   DPDEG(360)            DP4
ECADR   ROLLC       # 74   DPDEG(360)            DP4
ECADR   VMAGI       # 74   VEL 2                 DP4
ECADR   D           # 74   DRAG ACCEL            DP2
ECADR   DIFFALT     # 75   POS4                  DP3
ECADR   T1TOT2      # 75   MIN/SEC               M/S
ECADR   T2TOT3      # 75   MIN/SEC               M/S
OCT     0           # 76   SPARE
OCT     0           # 76   SPARE
OCT     0           # 76   SPARE
```

```
OCT     0                       # 77    SPARE
OCT     0                       # 77    SPARE
OCT     0                       # 77    SPARE
OCT     0                       # 78    SPARE
OCT     0                       # 78    SPARE
```

Uses ALTI 231, CODE 140, D 226, DIFFALT 197, DNRNGERR 229, HDOT 231, HORIZON 190, LANDMARK 190, LAT 157, LONG 157, OPTION2 157, P21ALT 244, P21GAM 244, P21VEL 244, Q7 223, RDOT 229, ROLLC 214, RTGO 229, RTGON64 229, RTGON67 231, SAMPTIME 80, STARCODE 150, T1TOT2 197, T2TOT3 244, THETZERO 185, TTE 229, VEL 226, VIO 229, VL 229, VMAGI 229, and XRNGERR 229.

476 ⟨*Page CM0282* 476⟩≡ (449 2778)

```
OCT     0                   # 78    SPARE
OCT     0                   # 79    SPARE
OCT     0                   # 79    SPARE
OCT     0                   # 79    SPARE
ECADR   TTOGO               # 80    MIN/SEC                 M/S
ECADR   VGDISP              # 80    VEL2                    DP4
ECADR   DVTOTAL             # 80    VEL2                    DP4
ECADR   DELVLVC             # 81    VEL3                    DP3
ECADR   DELVLVC +2          # 81    VEL3                    DP3
ECADR   DELVLVC +4          # 81    VEL3                    DP3
ECADR   DELVLVC             # 82    VEL3                    DP3
ECADR   DELVLVC +2          # 82    VEL3                    DP3
ECADR   DELVLVC +4          # 82    VEL3                    DP3
ECADR   DELVIMU             # 83    VEL3                    DP3
ECADR   DELVIMU +2          # 83    VEL3                    DP3
ECADR   DELVIMU +4          # 83    VEL3                    DP3
ECADR   DELVOV              # 84    VEL3                    DP3
ECADR   DELVOV +2           # 84    VEL3                    DP3
ECADR   DELVOV +4           # 84    VEL3                    DP3
ECADR   VGBODY              # 85    VEL3                    DP3
ECADR   VGBODY +2           # 85    VEL3                    DP3
ECADR   VGBODY +4           # 85    VEL3                    DP3
ECADR   DELVLVC             # 86    VEL3                    DP3
ECADR   DELVLVC +2          # 86    VEL3                    DP3
ECADR   DELVLVC +4          # 86    VEL3                    DP3
ECADR   MRKBUF1 +3          # 87    CDU DEG                 CDU
ECADR   MRKBUF1 +5          # 87    Y OPTICS DEG            YOPT
OCT     0                   # 87    SPARE COMPONENT
ECADR   STARSAV3            # 88    DPFRAC                  DPFRA
ECADR   STARSAV3 +2         # 88    DPFRAC                  DPFRA
ECADR   STARSAV3 +4         # 88    DPFRAC                  DPFRA
ECADR   LANDLAT             # 89    DPDEG(90)               DP3
ECADR   LANDLONG            # 89    DPDEG(90)               DP3
ECADR   LANDALT             # 89    POS5                    DP1
ECADR   RANGE               # 90    POS5                    DP1
ECADR   RRATE               # 90    VEL3                    DP3
ECADR   RTHETA              # 90    DPDEG(360)              DP4
ECADR   CDUS                # 91    CDU DEG                 CDU
ECADR   CDUT                # 91    Y OPTICS DEG            YOPT
OCT     0                   # 91    SPARE COMPONENT
ECADR   SAC                 # 92    CDU DEG                 CDU
ECADR   PAC                 # 92    Y OPTICS DEG            YOPT
OCT     0                   # 92    SPARE COMPONENT
ECADR   OGC                 # 93    DPDEG(90)               DP3
ECADR   OGC +2              # 93    DPDEG(90)               DP3
```

```
ECADR   OGC +4          # 93   DPDEG(90)        DP3
ECADR   MRKBUF1 +3      # 94   CDU DEG          CDU
ECADR   MRKBUF1 +5      # 94   Y OPTICS DEG     YOPT
OCT     00000           # 94   SPARE
ECADR   PRAXIS          # 95   CDU DEG          CDU
```

Uses CDUS 80, CDUT 80, DELVIMU 238, DELVLVC 224, DELVOV 234, DVTOTAL 224, LANDALT 181, LANDLAT 157, LANDLONG 181, OGC 186, PAC 186, RANGE 179, RRATE 179, RTHETA 179, SAC 186, STARSAV3 239, TTOGO 236, VGBODY 238, and VGDISP 231.

478 ⟨*Page CM0283* 478⟩≡ (449 2778)

```
                ECADR   PRAXIS +1           # 95    CDU DEG                 CDU
                ECADR   PRAXIS +2           # 95    CDU DEG                 CDU
                ECADR   CPHIX               # 96    CDU DEG                 CDU
                ECADR   CPHIX +1            # 96    CDU DEG                 CDU
                ECADR   CPHIX +2            # 96    CDU DEG                 CDU
                ECADR   DSPTEM1             # 97    WHOLE                   ARTH
                ECADR   DSPTEM1 +1          # 97    WHOLE                   ARTH
                ECADR   DSPTEM1 +2          # 97    WHOLE                   ARTH
                ECADR   DSPTEM2             # 98    WHOLE                   ARTH
                ECADR   DSPTEM2 +1          # 98    FRAC                    FRAC
                ECADR   DSPTEM2 +2          # 98    WHOLE                   ARTH
                ECADR   WWPOS               # 99    POS9                    DP3
                ECADR   WWVEL               # 99    VEL4                    DP2
                ECADR   WWOPT               # 99    WHOLE                   ARTH

# END OF IDADDTAB

                                            # NN    SF ROUTINES

RUTMXTAB        OCT     16351               # 40    M/S, DP3, DP3
                OCT     00142               # 41    CDU, ARTH
                OCT     16347               # 42    DP3, DP3, DP3
                OCT     16512               # 43    DP4, DP4, DP3
                OCT     22347               # 44    DP3, DP3, M/S
                OCT     24454               # 45    2INT, M/S, DP4
                OCT     00000               # 46    OCT, OCT
                OCT     00553               # 47    ARITH1, ARITH1
                OCT     00143               # 48    ARTH, ARTH
                OCT     06347               # 49    DP3, DP3, ARTH
                OCT     22347               # 50    DP3, DP3, M/S
                OCT     00512               # 51    DP4, DP4
                OCT     00012               # 52    DP4
                OCT     24344               # 53    DP1, DP3, DP4
                OCT     24344               # 54    DP1, DP3, DP4
                OCT     24503               # 55    ARTH, DP4, DP4
                OCT     00512               # 56    DP4, DP4
                OCT     00007               # 57    DP3
                OCT     16347               # 58    DP3, DP3, DP3
                OCT     16347               # 59    DP3, DP3, DP3
                OCT     24503               # 60    ARTH, DP4, DP4
                OCT     06512               # 61    DP4, DP4, ARTH
                OCT     16512               # 62    DP4, DP4, DP3
                OCT     22507               # 63    DP3, DP4, M/S
                OCT     16505               # 64    DP2, DP4, DP3
                OCT     20410               # 65    HMS, HMS, HMS
```

```
        OCT     16352           # 66    DP4, DP3, DP3
        OCT     24507           # 67    DP3, DP4, DP4
        OCT     24512           # 68    DP4, DP4, DP4
        OCT     24252           # 69    DP4, DP2, DP4
        OCT     00000           # 70    OCT, OCT, OCT
```

Uses CPHIX 163, DSPTEM1 154, DSPTEM2 154, and NN 244.

479 ⟨*Page CM0284* 479⟩≡ (449 2778)

```
        OCT     0               # 71    OCT, OCT,OCT
        OCT     06352           # 72    DP4, DP3, ARTH
        OCT     24507           # 73    DPR, DP4, DP4
        OCT     12512           # 74    DP4, DP4, DP2
        OCT     22447           # 75    DP3, M/S, M/S
        OCT     0               # 76    SPARE
        OCT     0               # 77    SPARE
        OCT     0               # 78    SPARE
        OCT     0               # 79    SPARE
        OCT     24511           # 80    M/S, DP4, DP4
        OCT     16347           # 81    DP3, DP3, DP3
        OCT     16347           # 82    DP3, DP3, DP3
        OCT     16347           # 83    DP3, DP3, DP3
        OCT     16347           # 84    DP3, DP3, DP3
        OCT     16347           # 85    DP3, DP3, DP3
        OCT     24512           # 86    DP4, DP4, DP4
        OCT     00302           # 87    CDU, YOPT
        OCT     32655           # 88    DPFRAC FOR EACH
        OCT     10347           # 89    DP3, DP3, DP1
        OCT     24344           # 90    DP1, DP3, DP4
        OCT     00302           # 91    CDU, YOPT
        OCT     00302           # 92    CDU, YOPT
        OCT     16347           # 93    DP3, DP3, DP3
        OCT     00302           # 94    CDU, YOPT
        OCT     04102           # 95    CDU, CDU, CDU
        OCT     04102           # 96    CDU, CDU, CDU
        OCT     06143           # 97    ARTH, ARTH, ARTH
        OCT     06043           # 98    ARTH, FRAC, ARTH
        OCT     06247           # 99    DP3, DP2, ARTH

  # END OF RUTMXTAB

        SBANK=  LOWSUPER
```

Uses LOWSUPER 67.

3.3.9 csm geometry

480 ⟨*csm geometry* 480⟩≡ (245b)

⟨*Page CM0285* 481⟩
⟨*Page CM0286* 482⟩
⟨*Page CM0287* 483⟩
⟨*Page CM0288* 484⟩
⟨*Page CM0289* 485⟩
⟨*Page CM0290* 486⟩
⟨*Page CM0291* 487⟩
⟨*Page CM0292* 488⟩
⟨*Page CM0293* 489⟩
⟨*Page CM0294* 491⟩
⟨*Page CM0295* 492a⟩
⟨*Page CM0296* 492b⟩

481 ⟨*Page CM0285* 481⟩≡ (480 2668)

```
                BANK    22
                SETLOC  COMGEOM1
                BANK

# THIS ROUTINE TAKES THE SHAFT AND TRUNNION ANGLES AS READ BY THE CM OPTICAL SYSTEM AND CONVERT
# VECTOR REFERENCED TO THE NAVIGATION BASE COORDINATE SYSTEM AND COINCIDENT WITH THE SEXTANT LI
#
# THE INPUTS ARE:  1) THE SEXTANT SHAFT AND TRUNNION ANGLES ARE STORED SP IN LOCATIONS 3 AND 5
# MARK VAC AREA.  2) THE COMPLEMENT OF THE BASE ADDRESS OF THE MARK VAC AREA IS STORED SP AT LO
# JOB VAC AREA.
#
# THE OUTPUT IS A HALF-UNIT VECTOR IN NAVIGATION BASE COORDINATES AND STORED AT LOCATION 32D OF
# OUTPUT IS ALSO AVAILABLE AT MPAC.

                COUNT   23/GEOM

SXTNB           SLOAD*  RTB             # PUSHDOWN 00,02,04,(17D-19D),32D-36D
                        5,1             # TRUNNION = TA
                        CDULOGIC
                RTB     PUSH
                        SXTLOGIC
                SIN     SL1
                PUSH    SLOAD*          # PD2 = SIN(TA)
                        3,1             # SHAFT = SA
                RTB     PUSH            # PD4 = SA
                        CDULOGIC

                COS     DMP
                        2
                STODL   STARM           # COS(SA)SIN(TA)

                SIN     DMP
                STADR
                STODL   STARM   +2      # SIN(SA)SIN(TA)

                COS
                STOVL   STARM   +4
                        STARM           # STARM = 32D
                MXV     VSL1
                        NB1NB2
                STORE   32D
                RVQ

SXTLOGIC        CAF     10DEGS-         # CORRECT FOR 19.775 DEGREE OFFSET
                ADS     MPAC
```

```
                CAF     QUARTER
                TC      SHORTMP
                TC      DANZIG
```

Uses A 80, COMGEOM1 65, COUNT 142, MPAC 145, STARM 148, TC 169, and X1 85.

482 ⟨*Page CM0286* 482⟩≡ (480 2668)

```
# CALCSXA COMPUTES THE SEXTANT SHAFT AND TRUNNION ANGLES REQUIRED TO POSITION THE OPT
# OF-SIGHT LIES ALONG THE STAR VECTOR.  THE ROUTINE TAKES THE GIVEN STAR VECTOR AND R
# ERENECED TO THE OPTICS COORDINATE SYSTEM.  IN ADDITION IT SETS UP THREE UNIT VECTOR
# REFERENCED TO THE OPTICS COORDINATE SYSTEM.
#
# THE INPUTS ARE:  1) THE STAR VECTOR REFERRED TO THE PRESENT STABLE MEMBER COORDINAT
# INPUT AS *SMNB*, I.E., SINES AND COSINES OF THE CDU ANGLES, IN THE ORDER Y Z X, AT
# TO CDUTRIG WILL PROVIDE THIS INPUT.
#
# THE OUTPUT ARE THE SEXTANT SHAFT AND TRUNNION ANGLES STORED DP AT SAC AND PAC RESPE
# EQUAL TO ZERO).

CALCSXA         ITA     VLOAD           # PUSHDOWN 00-26D, 28D, 30D, 32D-36D
                        28D
                        STAR
                CALL
                        *SMNB*
                MXV     VSL1
                        NB2NB1
                STOVL   STAR
                        HIUNITX
                STOVL   XNB1
                        HIUNITY
                STOVL   YNB1
                        HIUNITZ
                STCALL  ZNB1
                        SXTANG1
```

Uses A 80, COSCDU 150, HIUNITX 71, HIUNITY 71, HIUNITZ 71, I 206, IT 185, PAC 186, SAC 186, SINCDU 150, STAR 186, XNB1 183, YNB1 183, Z 80, and ZNB1 183.

483 ⟨*Page CM0287* 483⟩≡ (480 2668)

```
# SXTANG COMPUTES THE SEXTANT SHAFT AND TRUNNION ANGLES REQUIRED TO POSITION THE OPTICS SUCH TH
# SIGHT LIES ALONG THE STAR VECTOR.
#
# THE INPUTS ARE:  1) THE STAR VECTOR REFERRED TO ANY COORDINATE SYSTEM STORED AT STAR.  2) THE
# COORDINATES REFERRED TO THE SAME COORDINATE SYSTEM.  THESE THREE HALF-UNIT VECTORS ARE STORED
# ZNB.
#
# THE OUTPUTS ARE THE SEXTANT SHAFT AND TRUNNION ANGLES STORED DP AT SAC AND PAC RESPECTIVELY.
# EQUAL TO ZERO).

SXTANG          ITA     RTB             # PUSHDOWN 16D,18D,22D-26D,28D
                        28D
                        TRANSP1         # EREF WRT NB2
                VLOAD   MXV
                        XNB
                        NB2NB1
                VSL1
                STOVL   XNB1
                        YNB
                MXV     VSL1
                        NB2NB1
                STOVL   YNB1
                        ZNB
                MXV     VSL1
                        NB2NB1
                STORE   ZNB1

                RTB     RTB
                        TRANSP1
                        TRANSP2

SXTANG1         VLOAD   VXV
                        ZNB1
                        STAR
                BOV
                        +1
                UNIT    BOV
                        ZNB=S1
                STORE   PDA             # PDA = UNIT(ZNB X S)

                DOT     DCOMP
                        XNB1
                STOVL   SINTH           # SIN(SA) = PDA . -XNB
                        PDA
```

```
                DOT
                        YNB1
                STCALL  COSTH           # COS(SA) = PDA . YNB
                        ARCTRIG
```

Uses A 80, COSTH 148, PAC 186, PDA 148, S1 85, SAC 186, SINTH 148, STAR 186, XNB 186, XNB1 183, YNB 186, YNB1 183, ZNB 186, and ZNB1 183.

484 ⟨*Page CM0288* 484⟩≡ (480 2668)

```
                RTB
                        1STO2S
                STOVL   SAC
                        STAR
                BOV
                        +1
                DOT     SL1
                        ZNB1
                ACOS
                BMN     SL2
                        SXTALARM        # TRUNNION ANGLE NEGATIVE
                BOV     DSU
                        SXTALARM        # TRUNNION ANGLE GREATER THAN 90 DEGREES
                        20DEG-
                RTB
                        1STO2S
                STORE   PAC             # FOR FLIGHT USE, CULTFLAG IS ON IF
                CLRGO                   # TRUNION IS GREATER THAN 90 DEG
                        CULTFLAG
                        28D
  SXTALARM      SETGO                   # ALARM HAS BEEN REMOVED FROM THIS
                        CULTFLAG
                        28D             # SUBROUTINE, ALARM WILL BE SET BY MPI
  ZNB=S1        DLOAD
                        270DEG
                STODL   SAC
                        20DEGS-
                STORE   PAC
                CLRGO
                        CULTFLAG
                        28D
```

Uses CULTFLAG 107, PAC 186, S1 85, SAC 186, STAR 186, TRUNION 190, ZNB 186, and ZNB1 183.

485 ⟨*Page CM0289* 485⟩≡ (480 2668)

```
# THESE TWO ROUTINES COMPUTE THE ACTUAL STATE VECTOR FOR LM, CSM BY ADDING
# THE CONIC R,V AND THE DEVIATIONS R,V.  THE STATE VECTORS ARE CONVERTED TO
# METERS B-29 AND METERS/CSEC B-7 AND STORED APPROPRIATELY IN RN,VN OR
# R-OTHER, V-OTHER FOR DOWNLINK.  THE ROUTINES NAMES ARE SWITCHED IN THE
# OTHER VEHICLES COMPUTER.
#
# INPUT
#       STATE VECTOR IN TEMPORARY STORAGE AREA
#       IF STATE VECTOR IS SCALED POS B27 AND VEL B5
#               SET X2 TO +2
#       IF STATE VECTOR IS SCALED POS B29 AND VEL B7
#               SET X2 TO 0
#
# OUTPUT
#       R(T) IN RN, V(T) IN VN, T IN PIPTIME
#               OR
#       R(T) IN R-OTHER, V(T) IN V-OTHER        (T IS DEFINED BY T-OTHER)

                BANK    23
                SETLOC  COMGEOM2
                BANK
                COUNT   10/GEOM
SVDWN1          BOF     RVQ                     # SW=1=AVETOMID DOING W-MATRIX INTEG
                        AVEMIDSW
                        +1
                VLOAD   VSL*
                        TDELTAV
                        0       -7,2
                VAD     VSL*
                        RCV
                        0,2
                STOVL   RN
                        TNUV
                VSL*    VAD
                        0       -4,2
                        VCV
                VSL*
                        0,2
                STODL   VN
                        TET
                STORE   PIPTIME
                RVQ

SVDWN2          VLOAD   VSL*
                        TDELTAV
```

```
        0       -7,2
VAD     VSL*
        RCV
```

Uses AVEMIDSW 133, COMGEOM2 59, COMPUTER 115, COUNT 142, PIPTIME 159, R-OTHER 172, RCV 169, RN 159, STATE 138, T-OTHER 172, TDELTAV 169, TET 169, TNUV 169, V 229, V-OTHER 172, VCV 169, VEL 226, VN 159, W 183, and X2 85.

486 ⟨*Page CM0290* 486⟩≡ (480 2668)

```
        0,2
STOVL   R-OTHER
        TNUV
VSL*    VAD
        0       -4,2
        VCV
VSL*
        0,2
STORE   V-OTHER
RVQ
```

Uses R-OTHER 172, TNUV 169, V 229, V-OTHER 172, and VCV 169.

487 ⟨*Page CM0291* 487⟩≡ (480 2668)

```
# SUBROUTINE TO COMPUTE THE NATURAL LOG OF C(MPAC, MPAC +1).
#
#       ENTRY:  CALL
#                       LOG
#
# SUBROUTINE RETURNS WITH -LOG IN DP MPAC.
#
# EBANK IS ARBITRARY.

                BANK    14
                SETLOC  POWFLIT2
                BANK
                COUNT   23/GEOM

LOG             NORM    BDSU            # GENERATES LOG BY SHIFTING ARG
                        MPAC    +3      # UNTIL IT LIES BETWEEN .5 AND 1.
                        NEARLY1         # THE LOG OF THIS PART IS FOUND AND THE
                EXIT                    # LOG OF THE SHIFTED PART IS COMPUTED
                TC      POLY            # AND ADDED IN.  SHIFT COUNT STORED
                DEC     2               # (N-1, SUPPLIED BY SMERZH)
                2DEC    0               # IN MPAC +3.
                2DEC    .031335467
                2DEC    .0130145859
                2DEC    .0215738898

                CAF     ZERO
                TS      MPAC    +2
                EXTEND
                DCA     CLOG2/32
                DXCH    MPAC
                DXCH    MPAC    +3
                COM                     # LOAD POSITIVE SHIFT COUNT IN A.
                TC      SHORTMP         # MULTIPLY BY SHIFT COUNT.

                DXCH    MPAC    +1
                DXCH    MPAC
                DXCH    MPAC    +3
                DAS     MPAC
                TC      INTPRET         # RESULT IN MPAC, MPAC +1

                RVQ

NEARLY1         2DEC    .999999999
```

Uses A 80, COUNT 142, EBANK 80, IT 185, MPAC 145, N 206, POWFLIT2 65, and TC 169.

488 ⟨*Page CM0292* 488⟩≡ (480 2668)

```
CLOG2/32        2DEC    .0216608494
```

489 ⟨*Page CM0293* 489⟩≡ (480 2668)

```
# SUBROUTINE NAME:  EARTH ROTATOR       (EARROT1 OR EARROT2)            DATE:  15 FEB 67
# MOD NO:  N +1                                                         LOG SECTION:  POWERED F
# MOD BY:  ENTRY GROUP (BAIRNSFATHER)
#
# FUNCTIONAL DESCRIPTION:  THIS ROUTINE PROJECTS THE INITIAL EARTH TARGET VECTOR RTINIT AHEAD T
#       THE ESTIMATED TIME OF FLIGHT.  INITIAL CALL RESOLVES THE INITIAL TARGET VECTOR RTINIT I
#       AND NORMAL COMPONENTS RTEAST AND RTNORM.  INITIAL AND SUBSEQUENT CALLS ROTATE THIS VECT
#       ABOUT THE (FULL) UNIT POLAR AXIS UNITW THROUGH THE ANGLE  WIE DTEAROT  TO OBTAIN THE RO
#       TARGET VECTOR RT.  ALL VECTORS EXCEPT UNITW ARE HALF UNIT.
#       THE EQUATIONS ARE:
#               _    _        _                        _
#               RT = RTINIT + RTNORM (COS(WT) - 1) + RTEAST SIN(WT)
#
#       WHERE   WT = WIE DTEAROT
#
#               RTINIT = INITIAL TARGET VECTOR
#               _        _       _
#               RTEAST = UNITW * RTINIT
#               _        _        _
#               RTNORM = RTEAST * UNITW
#
#       FOR CONTINUOUS UPDATING, ONLY ONE ENTRY TO EARROT1 IS REQUIRED, WITH SUBSEQUENT ENTRIES
#
# CALLING SEQUENCE:     FIRST CALL                      SUBSEQUENT CALL
#                       STCALL  DTEAROT                 STCALL  DTEAROT
#                               EARROT1                         EARROT2
#                       C(MPAC) UNSPECIFIED             C(MPAC) = DTEAROT
#       PUSHLOC = PDL+0, ARBITRARY.  6 LOCATIONS USED.
#
# SUBROUTINES USED:  NONE
#
# NORMAL EXIT MODES:  RVQ
#
# ALARMS:  NONE
#
# OUTPUT:       RTEAST  (-1)            .5 UNIT VECTOR EAST, COMPNT OF RTINIT   LEFT BY FIRST C
#               RTNORM  (-1)            .5 UNIT VECTOR NORML, COMPNT OF RTINIT  LEFT BY FIRST C
#               RT      (-1)            .5 UNIT TARGET VECTOR, ROTATED          LEFT BY ALL CAL
#               DTEAROT (-28) CS        MAY BE CHANGED BY EARROT2, IF OVER 1 DAY
#
# ERASABLE INITIALIZATION REQUIRED:
#               UNITW   (0)             UNIT POLAR VECTOR                       PAD LOADED
#               RTINIT  (-1)            .5 UNIT INITIAL TARGET VECTOR           LEFT BY ENTRY
#               DTEAROT (-28) CS        TIME OF FLIGHT                          LEFT BY CALLER
#
```

```
# DEBRIS:  QPRET, PDL+0 ... PDL+5
```

Uses DTEAROT 226, MPAC 145, N 206, PUSHLOC 145, QPRET 85, RT 226, RTEAST 226, RTINIT 226, RTNORM 226, and UNITW 172.

491 ⟨*Page CM0294* 491⟩≡ (480 2668)

```
                EBANK=  RTINIT

EARROT1         VLOAD   VXV
                        UNITW           # FULL UNIT VECTOR
                        RTINIT          # .5 UNIT
                STORE   RTEAST          # .5 UNIT

                VXV
                        UNITW           # FULL UNIT
                STODL   RTNORM          # .5 UNIT
                        DTEAROT         # (-28) CS

EARROT2         BOVB    DDV
                        TCDANZIG        # RESET OVFIND, IF ON
                        1/WIE
                BOV     PUSH
                        OVERADAY
                COS     DSU
                        HIDPHALF
                VXSC    PDDL            # XCH W PUSH LIST
                        RTNORM          # .5 UNIT
                SIN     VXSC
                        RTEAST          # .5 UNIT
                VAD     VSL1
                VAD     UNIT            # INSURE THAT RT IS "UNIT".
                        RTINIT          # .5 UNIT
                STORE   RT              # .5 UNIT TARGET VECTOR

                RVQ

OVERADAY        DLOAD   SIGN
                        1/WIE
                        DTEAROT
                BDSU
                        DTEAROT
                STORE   DTEAROT

                GOTO
                        EARROT2

#WIE            2DEC    .1901487997
1/WIE           2DEC    8616410
NB2NB1          2DEC    +.8431756920 B-1
                2DEC    0
                2DEC    -.5376381241 B-1
```

Uses DTEAROT 226, EBANK 80, HIDPHALF 71, OVFIND 140, RT 226, RTEAST 226, RTINIT 226, RTNORM 226, UNITW 172, and W 183.

492a ⟨*Page CM0295* 492a⟩≡ (480 2668)

```
ZERINFLT        2DEC    0
HALFNFLT        2DEC    .5
                2DEC    0
                2DEC    +.5376381241 B-1
                2DEC    0
                2DEC    +.8431756920 B-1
NB1NB2          2DEC    +.8431756920 B-1
                2DEC    0
                2DEC    +.5376381241 B-1
                2DEC    0
                2DEC    .5
                2DEC    0
                2DEC    -.5376381241 B-1
                2DEC    0
                2DEC    +.8431756920 B-1
```

492b ⟨*Page CM0296* 492b⟩≡ (480 2668)

```
10DEGS-         DEC     3600
270DEG          OCT     60000           # SHAFT 270 DEGREES     25 COMP.
                OCT     00000
20DEGS-         DEC     -07199
                DEC     -00000
20DEG-          DEC     03600
                DEC     00000
```

3.3.10 imu compensation package

492c ⟨*imu compensation package* 492c⟩≡ (245b)

⟨*Page CM0297* 493⟩
⟨*Page CM0298* 494⟩
⟨*Page CM0299* 495⟩
⟨*Page CM0300* 496⟩
⟨*Page CM0301* 497⟩
⟨*Page CM0302* 498⟩
⟨*Page CM0303* 499⟩
⟨*Page CM0304* 501⟩
⟨*Page CM0305* 502⟩
⟨*Page CM0306* 503⟩

493 ⟨*Page CM0297* 493⟩≡ (492c 2707)

```
                BANK    7
                SETLOC  IMUCOMP
                BANK
                EBANK=  NBDX

                COUNT   06/ICOMP

1/PIPA          CAF     LGCOMP          # SAVE EBANK OF CALLING PROGRAM
                XCH     EBANK
                TS      MODE

                CCS     GCOMPSW         # BYPASS IF GCOMPSW NEGATIVE
                TCF     +3
                TCF     +2
                TCF     IRIG1           # RETURN

                INHINT                  # ASSURE COMPLETE COMPENSATION OF DELV'S
                                        # FOR DOWNLINK.

1/PIPA1         CAF     FOUR            # PIPAZ, PIPAY, PIPAX
                TS      BUF +2

                INDEX   BUF +2
                CA      PIPASCF         # (P.P.M.) X 2(-9)
                EXTEND
                INDEX   BUF +2
                MP      DELVX           # (PP) X 2(+14) NOW (PIPA PULSES) X 2(+5)
                TS      Q               # SAVE MAJOR PART

                CA      L               # MINOR PART
                EXTEND
                MP      BIT6            # SCALE 2(+9)   SHIFT RIGHT 9
                INDEX   BUF +2
                TS      DELVX +1        # FRACTIONAL PIPA PULSES SCALED 2(+14)

                CA      Q               # MAJOR PART
                EXTEND
                MP      BIT6            # SCALE 2(+9)   SHIFT RIGHT 9
                INDEX   BUF +2
                DAS     DELVX           # (PIPAI) + (PIPAI)(SF)

                INDEX   BUF +2
                CS      PIPABIAS        # (PIPA PULSES)/(CS) X 2(-8)                    *
                EXTEND
                MP      1/PIPADT        # (CS) X 2(+8) NOW (PIPA PULSES) X 2(+0)        *
```

```
EXTEND
MP      BIT1            # SCALE 2(+14) SHIFT RIGHT 14
INDEX   BUF +2
DAS     DELVX           # (PIPAI) + (PIPAI)(SFE) - (BIAS)(DELTAT)

CCS     BUF +2          # PIPAZ, PIPAY, PIPAX
```

Uses 1/PIPADT 156, BIAS 211, BUF 142, COUNT 142, DELTAT 241, DELVX 159, EBANK 80, GCOMPSW 169, IMUCOMP 59, L 80, MODE 145, NBDX 167, P 188, PIPABIAS 167, PIPASCF 167, PIPAX 80, PIPAY 80, PIPAZ 80, Q 80, and SAVE 191.

494 ⟨*Page CM0298* 494⟩≡ (492c 2707)

```
AD      NEG1
TCF     1/PIPA1 +1
NOOP                    # LESS THAN ZERO IMPOSSIBLE
RELINT
```

495 ⟨*Page CM0299* 495⟩≡ (492c 2707)

```
IRIGCOMP        TS      GCOMPSW         # INDICATE COMMANDS 2 PULSES OR LESS.
                TS      BUF             # INDEX COUNTER.  IRIGX, IRIGY, IRIGZ.

IRIGX           EXTEND
                DCS     DELVX           # (PIPA PULSES) X 2(+14)
                DXCH    MPAC
                CA      ADIAX           # (GYRO PULSES)/(PIPA PULSE) X 2(-3)            *
                TC      GCOMPSUB        # -(ADIAX)(PIPAX)       (GYRO PULSES) X 2(+14)

                EXTEND                  #
                DCS     DELVY           #       (PIPA PULSES) X 2(+14)
                DXCH    MPAC            #
                CS      ADSRAX          #       (GYRO PULSES)/(PIPA PULSE) X 2(-3)      *
                TC      GCOMPSUB        #       -(ADSRAX)(PIPAY)        (GYRO PULSES) X 2(+14)

#               EXTEND                  # ***
#               DCS     DELVY           # ***   (PIPA PULSES) X 2(+14)
#               DXCH    MPAC            # ***
#               CA      ADOAX           # ***   (GYRO PULSES)/(PIPA PULSE) X 2(-3)      *
#               TC      GCOMPSUB        # ***   -(ADOAX)(PIPAZ)         (GYRO PULSES) X 2(+14)

                CS      NBDX            #       (GYRO PULSES)/(CS) X 2(-3)
                TC      DRIFTSUB        #       -(NBDX)(DELTAT) (GYRO PULSES) X 2(+14)

IRIGY           EXTEND
                DCS     DELVY           # (PIPA PULSES) X 2(+14)
                DXCH    MPAC
                CA      ADIAY           # (GYRO PULSES)/(PIPA PULSE) X 2(-3)            *
                TC      GCOMPSUB        # -(ADIAY)(PIPAY)       (GYRO PULSES) X 2(+14)

                EXTEND
                DCS     DELVZ           # (PIPA PULSES) X 2(+14)
                DXCH    MPAC
                CS      ADSRAY          # (GYRO PULSES)/(PIPA PULSE) X 2(-3)            *
                TC      GCOMPSUB        # +(ADSRAY)(PIPAZ)      (GYRO PULSES) X 2(+14)

#               EXTEND                  # ***
#               DCS     DELVX           # ***   (PIPA PULSES) X 2(+14)
#               DXCH    MPAC            # ***
#               CA      ADOAY           # ***   (GYRO PULSES)/(PIPA PULS) X 2(-3)       *
#               TC      GCOMPSUB        # ***   -(ADOAY)(/PIPAX)        (GYRO PULSES) X 2(+14)

                CS      NBDY            #       (GYRO PULSES)/(CS) X 2(-5)
                TC      DRIFTSUB        #       -(NBDY)(DELTAT) (GYRO PULSES) X 2(+14)
```

```
IRIGZ           EXTEND
                DCS     DELVY           # (PIPA PULSES) X 2(-14)
                DXCH    MPAC
                CA      ADSRAZ          # (GYRO PULSES)/(PIPA PULSE) X 2(-3)
```

Uses ADIAX 169, ADIAY 169, ADSRAX 169, ADSRAY 169, ADSRAZ 169, BUF 142, DELTAT 241, DELVX 159, DELVY 159, DELVZ 159, GCOMPSW 169, MPAC 145, NBDX 167, NBDY 167, PIPAX 80, PIPAY 80, PIPAZ 80, and TC 169.

496 ⟨*Page CM0300* 496⟩≡ (492c 2707)

```
                TC      GCOMPSUB        # -(ADSRAZ)(PIPAY)      (GYRO PULSES) X 2(+14

                EXTEND
                DCS     DELVZ           # (PIPA PULSES) X 2(+14)
                DXCH    MPAC
                CA      ADIAZ           # (GYRO PULSES)/(PIPA PULSE) X 2(-3)
                TC      GCOMPSUB        # -(ADIAZ)(PIPAZ)       (GYRO PULSES) X 2(+14

#               EXTEND                  # ***
#               DCS     DELVX           # ***   (PIPA PULSE) X 2(+14)
#               DXCH    MPAC            # ***
#               CS      ADOAZ           # ***   (GYRO PULSES)/(PIPA PULSE) X 2(-3)
#               TC      GCOMPSUB        # ***   +(ADOAZ)(PIPAX) (GYRO PULSES) X 2(+14

                CA      NBDZ            #       (GYRO PULSES)/(CS) X 2(-5)
                TC      DRIFTSUB        #       +(NBDZ)(DELTAT) (GYRO PULSES) X 2(+14
```

Uses ADIAZ 169, ADSRAZ 169, DELTAT 241, DELVX 159, DELVZ 159, MPAC 145, NBDZ 169, PIPAX 80, PIPAY 80, PIPAZ 80, and TC 169.

497 ⟨*Page CM0301* 497⟩≡ (492c 2707)

```
                CCS     GCOMPSW         # ARE GYRO COMMANDS GREATER THAN 2 PULSES
                TCF     +2              # YES
                TCF     IRIG1           # NO

                CA      PRIO21          # HIGHER THAN SERVICER -- LESS THAN PRELAUNCH
                TC      NOVAC
                EBANK=  NBDX
                2CADR   1/GYRO

                RELINT
IRIG1           CA      MODE            # SET EBANK FOR RETURN
                TS      EBANK
                TCF     SWRETURN

GCOMPSUB        XCH     MPAC            # ADIA OR ADSRA COEFFICIENT ARRIVES IN A
                EXTEND                  # C(MPAC) = (PIPA PULSES) X 2(+14)
                MP      MPAC            # (GYRO PULSES)/(PIPA PULSE) X 2(-3)          *
                DXCH    VBUF            # NOW = (GYRO PULSES) X 2(+11)                *

                CA      MPAC +1         # MINOR PART OF PIPA PULSES
                EXTEND
                MP      MPAC            # ADIA OR ADSRA
                TS      L
                CAF     ZERO
                DAS     VBUF            # NOW = (GYRO PULSES) X 2(+11)                *

                CA      VBUF            # PARTIAL RESULT -- MAJOR
                EXTEND
                MP      BIT12           # SCALE 2(+3)   SHIFT RIGHT 3                 *
                INDEX   BUF             # RESULT = (GYRO PULSES) X 2(+14)
                DAS     GCOMP           # HI(ADIA)(PIPAI) OR HI(ADSRA)(PIPAI)

                CA      VBUF +1         # PARTIAL RESULT -- MINOR
                EXTEND
                MP      BIT12           # SCALE 2(+3)   SHIFT RIGHT 3                 *
                TS      L
                CAF     ZERO
                INDEX   BUF             # RESULT = (GYRO PULSES) X 2(+14)
                DAS     GCOMP           # (ADIA)(PIPAI) OR (ADSRA)(PIPAI)

                TC      Q
```

Uses `A` 80, `BUF` 142, `EBANK` 80, `GCOMP` 169, `GCOMPSW` 169, `L` 80, `MODE` 145, `MPAC` 145, `NBDX` 167, `Q` 80, `TC` 169, and `VBUF` 140.

498 ⟨*Page CM0302* 498⟩≡ (492c 2707)

```
DRIFTSUB        EXTEND
                QXCH    BUF +1

                EXTEND                  # C(A) = NBD    (GYRO PULSES)/(CS) X 2(-5)
                MP      1/PIPADT        # (CS) X 2(+8)  NO (GYRO PULSES) X 2(+3)
                LXCH    MPAC +1         # SAVE FOR FRACTIONAL COMPENSATION
                EXTEND
                MP      BIT4            # SCALE 2(+11)  SHIFT RIGHT 11
                INDEX   BUF
                DAS     GCOMP           # HI(NBD)(DELTAT)       (GYRO PULSES) X 2(+14

                CA      MPAC +1         # NOW MINOR PART
                EXTEND
                MP      BIT4            # SCALE 2(+11)          SHIFT RIGHT 11
                TS      L
                CAF     ZERO
                INDEX   BUF             # ADD IN FRACTIONAL COMPENSATION
                DAS     GCOMP           # (NBD)(DELTAT)         (GYRO PULSES) X 2(+14

DRFTSUB2        CAF     TWO             # PIPAX, PIPAY, PIPAZ
                AD      BUF
                XCH     BUF
                INDEX   A
                CCS     GCOMP           # ARE GYRO COMMANDS 1 PULSE OR GREATER
                TCF     +2              # YES
                TC      BUF +1          # NO

                MASK    NEGONE
                CCS     A               # ARE GYRO COMMANDS GREATER THAN 2 PULSES
                TS      GCOMPSW         # YES -- SET GCOMPSW POSITIVE
                TC      BUF +1          # NO
```

Uses 1/PIPADT 156, A 80, BUF 142, DELTAT 241, GCOMP 169, GCOMPSW 169, L 80, MPAC 145, PIPAX 80, PIPAY 80, PIPAZ 80, SAVE 191, and TC 169.

499 ⟨*Page CM0303* 499⟩≡ (492c 2707)

```
1/GYRO          CAF     FOUR            # PIPAZ, PIPAY, PIPAX
                TS      BUF

                INDEX   BUF             # SCALE GYRO COMMANDS FOR IMUPULSE
                CA      GCOMP +1        # FRACTIONAL PULSES
                EXTEND
                MP      BIT8            # SHIFT RIGHT 7
                INDEX   BUF
                TS      GCOMP +1        # FRACTIONAL PULSES SCALED

                CAF     ZERO            # SET GCOMP = 0 FOR DAS INSTRUCTION
                INDEX   BUF
                XCH     GCOMP           # GYRO PULSES
                EXTEND
                MP      BIT8            # SHIFT RIGHT 7
                INDEX   BUF
                DAS     GCOMP           # ADD THESE TO FRACTIONAL PULSES ABOVE

                CCS     BUF             # PIPAZ, PIPAY, PIPAX
                AD      NEG1
                TCF     1/GYRO +1
LGCOMP          ECADR   GCOMP           # LESS THAN ZERO IMPOSSIBLE

                CAF     LGCOMP
                TC      BANKCALL
                CADR    IMUPULSE        # CALL GYRO TORQUING ROUTINE
                TC      BANKCALL
                CADR    IMUSTALL        # WAIT FOR PULSES TO GET OUT
                TCF     ENDOFJOB        # TEMPORARY

GCOMP1          CAF     FOUR            # PIPAZ, PIPAY, PIPAX
                TS      BUF

                INDEX   BUF             # RESCALE
                CA      GCOMP +1
                EXTEND
                MP      BIT8            # SHIFT MINOR PART LEFT 7 -- MAJOR PART = 0
                INDEX   BUF
                LXCH    GCOMP +1        # BITS 8-14 OF MINOR PART WERE = 0

                CCS     BUF             # PIPAZ, PIPAY, PIPAX
                AD      NEG1
                TCF     GCOMP1 +1

V06N30S         VN      0630
```

```
TCF     ENDOFJOB
```

Uses BUF 142, GCOMP 169, PIPAX 80, PIPAY 80, PIPAZ 80, TC 169, and VN 159.

501 ⟨*Page CM0304* 501⟩≡ (492c 2707)

```
NBDONLY         CCS     GCOMPSW         # BYPASS IF GCOMPSW NEGATIVE
                TCF     +3
                TCF     +2
                TCF     ENDOFJOB

                INHINT
                CCS     FLAGWRD2        # PREREAD T3RUPT MAY COINCIDE
                TCF     ENDOFJOB
                TCF     ENDOFJOB
                TCF     +1

                CA      TIME1           # (CS) X 2(+14)
                XCH     1/PIPADT        # PREVIOUS TIME
                RELINT
                COM
                AD      1/PIPADT
NBD2            CCS     A               # CALCULATE ELAPSED TIME.
                AD      ONE             # NO TIME1 OVERFLOW
                TCF     NBD3            # RESTORE TIME DIFFERENCE AND JUMP
                TCF     +2              # TIME1 OVERFLOW
                TCF     ENDOFJOB        # IF ELAPSED TIME = 0 (DIFFERENCE = -0)

                COM                     # CALCULATE ABSOLUTE DIFFERENCE
                AD      POSMAX

NBD3            EXTEND                  # C(A) = DELTAT         (CS) X 2(+14)
                MP      BIT10           # SHIFT RIGHT 5
                DXCH    VBUF
                EXTEND
                DCA     VBUF
                DXCH    MPAC            # DELTAT NOW SCALED (CS) X 2(+19)

                CAF     ZERO
                TS      GCOMPSW         # INDICATE COMMANDS 2 PULSES OR LESS.
                TS      BUF             # INDEX X, Y, Z.

                CS      NBDX            # (GYRO PULSES)/(CS) X 2(-5)
                TC      FBIASSUB        # -(NBOX)(DELTAT)       (GYRO PULSES) X 2(+14)

                EXTEND
                DCS     VBUF
                DXCH    MPAC            # DELTAT SCALED (CS) X 2(+19)
                CA      NBDY            # (GYRO PULSES)/(CS) X 2(-5)
                TC      FBIASSUB        # -(NBDY)(DELTAT)       (GYRO PULSES) X 2(+14)
```

```
EXTEND
DCS     VBUF
DXCH    MPAC            # DELTAT SCALED (CS) X 2(+19)
CS      NBDZ            # (GYRO PULSES)/(CS) X 2(-5)
TC      FBIASSUB        # +(NBDZ)(DELTAT)       (GYRO PULSES) X 2(+14
```

Uses 1/PIPADT 156, A 80, BUF 142, DELTAT 241, FLAGWRD2 101, GCOMPSW 169, MPAC 145, NBDX 167, NBDY 167, NBDZ 169, TC 169, TIME1 80, VBUF 140, and Z 80.

502 ⟨*Page CM0305* 502⟩≡ (492c 2707)

```
CCS     GCOMPSW         # ARE GYRO COMMANDS GREATER THAN 2 PULSES
TCF     1/GYRO          # YES
TCF     ENDOFJOB        # NO
```

Uses GCOMPSW 169.

503 ⟨*Page CM0306* 503⟩≡ (492c 2707)

```
FBIASSUB        XCH     Q
                TS      BUF +1

                CA      Q               # NBD SCALED (GYRO PULSES)/(CS) X 2(-5)
                EXTEND
                MP      MPAC            # DELTAT SCALED (CS) X 2(+19)
                INDEX   BUF
                DAS     GCOMP           # HI(NBD)(DELTAT)       (GYRO PULSES) X 2(+14)

                CA      Q               # NO FRACTIONAL PART
                EXTEND
                MP      MPAC +1
                TS      L
                CAF     ZERO
                INDEX   BUF
                DAS     GCOMP           # (NBD)(DELTAT)         (GYRO PULSES) X 2(+14)

                TCF     DRFTSUB2        # CHECK MAGNITUDE OF COMPENSATION

LASTBIAS        TC      BANKCALL
                CADR    PIPUSE

                CCS     GCOMPSW         # BYPASS IF GCOMPSW NEGATIVE
                TCF     +3
                TCF     +2
                TCF     ENDOFJOB

                CAF     PRIO31          # 2 SECONDS SCALED (CS) X 2(+8)
                XCH     1/PIPADT
                COM
                AD      PIPTIME1 +1     # TIME AT PIPA1 =0
                TCF     NBD2
```

Uses `1/PIPADT` 156, `BUF` 142, `DELTAT` 241, `GCOMP` 169, `GCOMPSW` 169, `L` 80, `MPAC` 145, `PIPTIME1` 159, `Q` 80, and `TC` 169.

3.3.11 pinball game buttons and lights

504 ⟨*pinball game buttons and lights* 504⟩≡ (245b)

⟨*Page CM0307* 506⟩
⟨*Page CM0308* 508⟩
⟨*Page CM0309* 510⟩
⟨*Page CM0310* 512⟩
⟨*Page CM0311* 514⟩
⟨*Page CM0312* 515⟩
⟨*Page CM0313* 517⟩
⟨*Page CM0314* 518⟩
⟨*Page CM0315* 519⟩
⟨*Page CM0316* 521⟩
⟨*Page CM0317* 523⟩
⟨*Page CM0318* 525⟩
⟨*Page CM0319* 527⟩
⟨*Page CM0320* 529⟩
⟨*Page CM0321* 531⟩
⟨*Page CM0322* 533⟩
⟨*Page CM0323* 535⟩
⟨*Page CM0324* 537⟩
⟨*Page CM0325* 539⟩
⟨*Page CM0326* 540⟩
⟨*Page CM0327* 541⟩
⟨*Page CM0328* 543⟩
⟨*Page CM0329* 544⟩
⟨*Page CM0330* 545⟩
⟨*Page CM0331* 547⟩
⟨*Page CM0332* 549⟩
⟨*Page CM0333* 551⟩
⟨*Page CM0334* 553⟩
⟨*Page CM0335* 555⟩
⟨*Page CM0336* 557⟩
⟨*Page CM0337* 559⟩
⟨*Page CM0338* 561⟩
⟨*Page CM0339* 563⟩
⟨*Page CM0340* 565⟩
⟨*Page CM0341* 567⟩
⟨*Page CM0342* 568⟩
⟨*Page CM0343* 569⟩
⟨*Page CM0344* 571⟩
⟨*Page CM0345* 573⟩
⟨*Page CM0346* 575⟩
⟨*Page CM0347* 577⟩
⟨*Page CM0348* 579⟩
⟨*Page CM0349* 581⟩

⟨*Page CM0350* 583⟩
⟨*Page CM0351* 585⟩
⟨*Page CM0352* 587⟩
⟨*Page CM0353* 589⟩
⟨*Page CM0354* 590⟩
⟨*Page CM0355* 591⟩
⟨*Page CM0356* 593⟩
⟨*Page CM0357* 595⟩
⟨*Page CM0358* 596⟩
⟨*Page CM0359* 597⟩
⟨*Page CM0360* 599⟩
⟨*Page CM0361* 601⟩
⟨*Page CM0362* 603⟩
⟨*Page CM0363* 605⟩
⟨*Page CM0364* 607⟩
⟨*Page CM0365* 609⟩
⟨*Page CM0366* 611⟩
⟨*Page CM0367* 612⟩
⟨*Page CM0368* 613⟩
⟨*Page CM0369* 615⟩
⟨*Page CM0370* 617⟩
⟨*Page CM0371* 619⟩
⟨*Page CM0372* 621⟩
⟨*Page CM0373* 623⟩
⟨*Page CM0374* 625⟩
⟨*Page CM0375* 627⟩
⟨*Page CM0376* 629⟩
⟨*Page CM0377* 630⟩
⟨*Page CM0378* 631⟩
⟨*Page CM0379* 633⟩
⟨*Page CM0380* 635⟩
⟨*Page CM0381* 637⟩
⟨*Page CM0382* 638⟩
⟨*Page CM0383* 639a⟩
⟨*Page CM0384* 639b⟩
⟨*Page CM0385* 640⟩
⟨*Page CM0386* 642⟩
⟨*Page CM0387* 643⟩
⟨*Page CM0388* 644⟩
⟨*Page CM0389* 645⟩

506 ⟨*Page CM0307* 506⟩≡ (504 2773)

```
# PROGRAM NAME -- KEYBOARD AND DISPLAY PROGRAM
# MOD NO -- 4           DATE -- 27 APRIL 1967           ASSEMBLY -- PINDISK REV 17
# MOD BY -- FILENE
# LOG SECTION -- PINBALL GAME BUTTONS AND LIGHTS
#
# FUNCTIONAL DESCRIPTION
#
# THE KEYBOARD AND DISPLAY SYSTEM PROGRAM OPERATES UNDER EXECUTIVE
# CONTROL AND PROCESSES INFORMATION EXCHANGED BETWEEN THE AGC AND THE
# COMPUTER OPERATOR.  THE INPUTS TO THE PROGRAM ARE FROM THE KEYBOARD,
# FROM INTERNAL PROGRAM, AND FROM THE UPLINK.
#
# THE LANGUAGE OF COMMUNICATION WITH THE PROGRAM IS A PAIR OF WORDS
# KNOWN AS VERB AND NOUN.  EACH OF THESE IS REPRESENTED BY A 2 CHARACTER
# DECIMAL NUMBER.  THE VERB CODE INDICATES WHAT ACTION IS TO BE TAKEN, THE
# NOUN CODE INDICATES TO WHAT THIS ACTION IS APPLIED.  NOUNS USUALLY
# REFER TO A GROUP OF ERASABLE REGISTERS.
#
# VERBS ARE GROUPED INTO DISPLAYS, LOADS, MONITORS (DISPLAYS THAT ARE
# UPDATED ONCE PER SECOND), SPECIAL FUNCTIONS, AND EXTENDED VERBS (THESE
# ARE OUTSIDE OF THE DOMAIN OF PINBALL AND CAN BE FOUND UNDER LOG SECTION
# 'EXTENDED VERBS').
#
# A LIST OF VERBS AND NOUNS IS GIVEN IN LOG SECTION 'ASSEMBLY AND
# OPERATION INFORMATION'.
#
# CALLING SEQUENCES --
#
# KEYBOARD:
# EACH DEPRESSION OF A MAIN (NAVIGATION) KEYBOARD BUTTON ACTIVATES
# INTERRUPT KEYRUPT1 (KEYRUPT2) AND PLACES THE 5 BIT KEY CODE INTO
# CHANNEL 15 (CHANNEL 16).  KEYRUPT1 (KEYRUPT2) PLACES THE KEY
# CODE INTO MPAC, ENTERS AN EXECUTIVE REQUEST FOR THE KEYBOARD AND DISPLAY
# PROGRAM (AT 'CHARIN'), AND EXECUTES A RESUME.
#
# UPLINK:
# EACH WORD RECEIVED BY THE UPLINK ACTIVATES INTERRUPT UPRUPT, WHICH
# PLACES THE 5 BIT KEY CODE INTO MPAC, ENTERS AN EXECUTIVE REQUEST FOR THE
# KEYBOARD AND DISPLAY PROGRAM (AT 'CHARIN') AND EXECUTES A RESUME.
#
# INTERNAL PROGRAMS:
# INTERNAL PROGRAMS CALL PINBALL AT 'NVSUB' WITH THE DESIRED VERB/NOUN
# CODE IN A (LOW 7 BITS FOR NOUN, NEXT 7 BITS FOR VERB).  DETAILS
# DESCRIBED ON REMARKS CARDS JUST BEFORE 'NVSUB' AND 'NVSBWAIT' (SEE
# SYMBOL TABLE FOR PAGE NUMBERS).
```

```
#
# NORMAL EXIT MODES --
#
#       IF PINBALL WAS CALLED BY EXTERNAL ACTION, THERE ARE FOUR EXITS:
#               1)      ALL BUT (2), (3), AND (4) EXIT DIRECTLY TO ENDOFJOB.
```

Uses A 80, CODE 140, COMPUTER 115, DISPLAYS 59, and MPAC 145.

508 ⟨*Page CM0308* 508⟩≡ (504 2773)

```
#               2)      EXTENDED VERBS TO TO THE EXTENDED VERB FAN AS PART OF THE
#                       PINBALL EXECUTIVE JOB WITH PRIORITY 30000.  IT IS THE
#                       RESPONSIBILITY OF THE EXTENDED VERB CALLED TO EVENTUALLY
#                       CHANGE PRIORITY (IF NECESSARY) AD DO AN ENDOFJOB.
#                       ALSO PINBALL IS A NOVAC JOB.  EBANK SET FOR COMMON.
#               3)      VERB 37.  CHANGE OF PROGRAM (MAJOR MODE) CALLS ‘V37’ IN THE
#                       SERVICE ROUTINES AS PART OF THE PINBALL EXEC JOB WITH PRIO
#                       30000.  THE NEW PROGRAM CODE (MAJOR MODE) IS LEFT IN A.
#               4)      KEY RELEASE BUTTON CALLS ‘PINBRNCH’ IN THE DISPLAY INTERFACE
#                       ROUTINES AS PART OF THE PINBALL EXEC JOB WITH PRIO 30000 IF
#                       THE KEY RELEASE LIGHT IS OFF AND ‘CADRSTOR’ IS NOT 40.
#
# IF PINBALL WAS CALLED BY INTERNAL PROGRAMS, EXIT FROM PINBALL IS BACK
# TO CALLING ROUTINE.  DETAILS DESCRIBED IN REMARKS CARDS JUST BEFORE
# ‘NVSUB’ AND ‘NVSBWAIT’ (SEE SYMBOL TABLE FOR PAGE NUMBERS).
#
# ALARM OR ABORT EXIT MODES --
#
#       EXTERNAL INITIATION:
#               IF SOME IMPROPER SEQUENCE OF KEY CODES IS DETECTED, THE OPERATOR
#               ERROR LIGHT IS TURNED ON AND EXIT IS TO ‘ENDOFJOB’.
#
#       INTERNAL PROGRAM INITIATION:
#               IF AN ILLEGAL V/N COMBINATION IS ATTEMPTED, AN ABORT IS CAUSED
#               (WITH OCTAL 01501).
#               IF A SECOND ATTEMPT IS MADE TO GO TO SLEEP IN PINBALL, AN ABORT IS
#               CAUSED (WITH OCTAL 01206).  THERE ARE TWO WAYS TO GO TO SLEEP IN PINB
#               1)      ENDIDLE OR DATAWAIT.
#               2)      NVSBWAIT, PRENVBSY, OR NVSUBUSY.
#
# CONDITIONS LEADING TO THE ABOVE ARE DESCRIBED IN FORTHCOMING MIT/IL
# E-REPORT DESCRIBING KEYBOARD AND DISPLAY OPERATION FOR 278.
#
# OUTPUT --
#
# INFORMATION TO BE SENT TO THE DISPLAY PANEL IS LEFT IN THE ‘DSPTAB’
# BUFFERS REGISTERS (UNDER EXEC CONTROL).  ‘DSPOUT’ (A PART OF T4RUPT)
# HANDLES THE PLACING OF THE ‘DSPTAB’ INFORMATION INTO OUTPUT CHANNEL 10
# IN INTERRUPT.
#
# ERASABLE INITIALIZATION --
#
# FRESH START AND RESTART INITIALIZE THE NECESSARY E REGISTERS FOR
# PINBALL IN ‘STARTSUB’.  REGISTERS ARE:  DSPTAB BUFFER, CADRSTOR,
# REQRET, CLPASS, DSPLOCK, MONSAVE, MONSAVE1, VERBREG, NOUNREG, DSPLIST,
```

```
# DSPCOUNT, NOUT.
#
```

Uses A 80, CADRSTOR 154, CLPASS 154, CODE 140, DSPCOUNT 152, DSPLIST 154, DSPLOCK 154, DSPTAB 154, EBANK 80, IT 185, MODE 145, MONSAVE 154, MONSAVE1 154, N 206, NOUNREG 152, NOUT 154, PRIORITY 145, REQRET 154, RESTART 57, V 229, and VERBREG 152.

510 ⟨*Page CM0309* 510⟩≡ (504 2773)

```
# A COMPLETE LIST OF ALL THE ERASABLES (BOTH RESERVED AND TEMPORARIES) FOR
# PINBALL IS GIVEN BELOW.
#
# THE FOLLOWING ARE OF GENERAL INTEREST --
#
# REMARKS CARDS PRECEDE THE REFERENCED SYMBOL DEFINITION.  SEE SYMBOL
# TABLE TO FIND APPROPRIATE PAGE NUMBERS.
#
#       NVSUB           CALLING POINT FOR INTERNAL USE OF PINBALL.
#                       OF RELATED INTEREST     NVSBWAIT
#                                               NVSUBUSY
#                                               PRENVBSY
#
#       ENDIDLE         ROUTINE FOR INTERNAL PROGRAMS WISHING TO TO SLEEP WHILE
#                       AWAITING OPERATOR'S RESPONSE.
#
#       DSPMM           ROUTINE BY WHICH AN INTERNAL PROGRAM MAY DISPLAY A DECIMAL
#                       PROGRAM CODE (MAJOR MODE) IN THE PROGRAM (MAJOR MODE) LIGHT
#                       (DSPMM DOES NOT DISPLAY DIRECTLY BUT ENTERS EXEC REQUEST
#                       FOR DSPMMJB WITH PRIO 30000 AND RETURNS TO CALLER.)
#
#       BLANKSUB        ROUTINE BY WHICH AN INTERNAL PROGRAM MAY BLANK ANY
#                       COMBINATION OF THE DISPLAY REGISTERS R1, R2, R3.
#
#       JAMTERM         ROUTINE BY WHICH AN INTERNAL PROGRAM MAY PERFORM THE
#       JAMPROC         TERMINATE (V 34) OR PROCEED (V33) FUNCTION.
#
#       MONITOR         VERBS FOR PERIODIC (1 PER SEC) DISPLAY.
#
#       PLEASE PERFORM, PLEASE MARK SITUATIONS
#               REMARKS DESCRIBING HOW AN INTERNAL ROUTINE SHOULD HANDLE
#               THESE SITUATIONS CAN BE FOUND JUST BEFORE 'NVSUB' (SEE
#               SYMBOL TABLE FOR PAGE NUMBER).
#
#       THE NOUN TABLE FORMAT IS DESCRIBED ON A PAGE OF REMARKS CARDS JUST
#       BEFORE 'DSPABC' (SEE SYMBOL TABLE FOR PAGE NUMBER).
#
#       THE NOUN TABLES THEMSELVES ARE FOUND IN LOG SECTION 'PINBALL NOUN
#       TABLES'.
#
# FOR FURTHER DETAILS ABOUT OPERATION OF THE KEYBOARD AND DISPLAY SYSTEM
# PROGRAM, SEE THE MISSION PLAN AND/OR MIT/IL E-2129
# DESCRIBING KEYBOARD AND DISPLAY OPERATION FOR 278.
# (Note that this doc by Green and Filene is/was available online at
# http://hrst.mit.edu/hrs/apollo/public/archive/1706.pdf --- RSB 6/2004.)
```

```
  #
  # THE FOLLOWING QUOTATION IS PROVIDED THROUGH THE COURTESY OF THE AUTHORS.
  #
  #       "IT WILL BE PROVED TO THY FACE THAT THOU HAST MEN ABOUT THEE THAT
```

Uses `A` 80, `CODE` 140, `IT` 185, `MODE` 145, `R2` 188, and `V` 229.

512 ⟨*Page CM0310* 512⟩≡ (504 2773)

```
#       USUALLY TALK OF A NOUN AND A VERB, AND SUCH ABOMINABLE WORDS AS NO
#       CHRISTIAN EAR CAN ENDURE TO HEAR."
#                                       HENRY 6, ACT 2, SCENE 4

# THE FOLLOWING ASSIGNMENTS FOR PINBALL ARE MADE ELSEWHERE

# RESERVED FOR PINBALL EXECUTIVE ACTION
#
#DSPCOUNT       ERASE                   # DISPLAY POSITION INDICATOR
#DECBRNCH       ERASE                   # +DEC, -DEC, OCT INDICATOR
#VERBREG        ERASE                   # VERB CODE
#NOUNREG        ERASE                   # NOUN CODE
#XREG           ERASE                   # R1 INPUT BUFFER
#YREG           ERASE                   # R2 INPUT BUFFER
#ZREG           ERASE                   # R3 INPUT BUFFER
#XREGLP         ERASE                   # LO PART OF XREG (FOR DEC CONV ONLY)
#YREGLP         ERASE                   # LO PART OF YREG (FOR DEC CONV ONLY)
#HITEMOUT       =       YREGLP          # TEMP FOR DISPLAY OF HRS,MIN,SEC
#                                       # MUST = LOTEMOUT-1.
#ZREGLP         ERASE                   # LO PART OF ZREG (FOR DEC CONV ONLY)
#LOTEMOUT       =       ZREGLP          # TEMP FOR DISPLAY OF HRS,MIN,SEC
#                                       # MUST = HITEMOUT+1
#MODREG         ERASE                   # MODE CODE
#DSPLOCK        ERASE                   # KEYBOARD/SUBROUTINE CALL INTERLOCK
#REQRET         ERASE                   # RETURN REGISTER FOR LOAD
#LOADSTAT       ERASE                   # STATUS INDICATOR FOR LOADTST
#CLPASS         ERASE                   # PASS INDICATOR FOR CLEAR
#NOUT           ERASE                   # ACTIVITY COUNTER FOR DSPTAB
#NOUNCADR       ERASE                   # MACHINE CADR FOR NOUN
#MONSAVE        ERASE                   # N/V CODE FOR MONITOR. (= MONSAVE1-1)
#MONSAVE1       ERASE                   # NOUNCADR FOR MONITOR (MATBS1) = MONSAVE+1
#MONSAVE2       ERASE                   # NVMONOPT OPTIONS
#DSPTAB         ERASE   +13D            # 0-10, DISPLAY PANEL BUFFER 11-13, C RELAYS
#CADRSTOR       ERASE                   # ENDIDLE STORAGE
#NVQTEM         ERASE                   # NVSUB STORAGE FOR CALLING ADDRESS
#                                       # MUST = NVBNKTEM-1.
#NVBNKTEM       ERASE                   # NVSUB STORAGE FOR CALLING BANK
#                                       # MUST = NVQTEM+1
#VERBSAVE       ERASE                   # NEEDED FOR RECYCLE
#DSPLIST        ERASE                   # WAITING REG FOR DSP SYST INTERNAL USE
#EXTVBACT       ERASE                   # EXTENDED VERB ACTIVITY INTERLOCK
#DSPTEM1        ERASE   +2              # BUFFER STORAGE AREA 1 (MOSTLY FOR TIME)
#DSPTEM2        ERASE   +2              # BUFFER STORAGE AREA 2 (MOSTLY FOR DEG)
#
# END OF ERASABLES RESERVED FOR PINBALL EXECUTIVE ACTION.
```

```
#
# TEMPORARIES FOR PINBALL EXECUTIVE ACTION
```

Uses A 80, CODE 140, DSPTAB 154, HITEMOUT 152, LOTEMOUT 152, MODE 145, MONSAVE 154, MONSAVE1 154, N 206, NOUNCADR 154, NVBNKTEM 154, NVQTEM 154, R2 188, TEMP 191, V 229, XREG 152, YREG 152, YREGLP 152, ZREG 152, and ZREGLP 152.

514 ⟨*Page CM0311* 514⟩≡ (504 2773)

```
#DSEXIT         =       INTB15+         # RETURN FOR DSPIN
#EXITEM         =       INTB15+         # RETURN FOR SCALE FACTOR ROUTINE SELECT
#BLANKRET       =       INTB15+         # RETURN FOR 2BLANK
#WRDRET         =       INTBIT15        # RETURN FOR 5BLANK.
#WDRET          =       INTBIT15        # RETURN FOR DSPWD
#DECRET         =       INTBIT15        # RETURN FOR PUTCOM(DEC LOAD)
#21/22REG       =       INTBIT15        # TEMP FOR CHARIN
#UPDATRET       =       POLISH          # RETURN FOR UPDATNN, UPDATVB
#CHAR           =       POLISH          # TEMP FOR CHARIN
#ERCNT          =       POLISH          # COUNTER FOR ERROR LIGHT RESET
#DECOUNT        =       POLISH          # COUNTER FOR SCALING AND DISPLAY (DEC)
#SGNON          =       VBUF            # TEMP FOR +,- ON
#NOUNTEM        =       VBUF            # COUNTER FOR MIXNOUN FETCH
#DISTEM         =       VBUF            # COUNTER FOR OCTAL DISPLAY VERB
#DECTEM         =       VBUF            # COUNTER FOR FETCH (DEC DISPLAY VERBS)
#SGNOFF         =       VBUF +1         # TEMP FOR +,- ON
#NVTEMP         =       VBUF +1         # TEMP FOR NVSUB
#SFTEMP1        =       VBUF +1         # STORAGE FOR SF CONST HI PART (=SFTEMP2-1)
#HITEMIN        =       VBUF +1         # TEMP FOR LOAD OF HRS,MIN,SEC
#                                       #       MUST = LOTEMIN-1.
#CODE           =       VBUF +2         # FOR DSPIN
#SFTEMP2        =       VBUF +2         # STORAGE FOR SF CONST LO PART (=SFTEMP1+1)
#LOTEMIN        =       VBUF +2         # TEMP FOR LOAD OF HRS,MIN,SEC
#                                       #       MUST = HITEMIN+1
#MIXTEMP        =       VBUF +3         # FOR MIXNOUN DATA
#SIGNRET        =       VBUF +3         # RETURN FOR +,- ON
# ALSO MIXTEMP+1 = VBUF+4, MIXTEMP+2 = VBUF+5
#ENTRET         =       DOTINC          # EXIT FROM ENTER
#WDONT          =       DOTRET          # CHAR COUNTER FOR DSPWD
#INREL          =       DOTRET          # INPUT BUFFER SELECTOR (X,Y,Z, REG )
#DSPMMTEM       =       MATINC          # DSPCOUNT SAVE FOR DSPMM
#MIXBR          =       MATINC          # INDICATOR FOR MIXED OR NORMAL NOUN
#TEM1           ERASE                   # EXEC TEMP
#DSREL          =       TEM1            # REL ADDRESS FOR DSPIN
#TEM2           ERASE                   # EXEC TEMP
#DSMAG          =       TEM2            # MAGNITUDE STORE FOR DSPIN
#IDADDTEM       =       TEM2            # MIXNOUN INDIRECT ADDRESS STORAGE
#TEM3           ERASE                   # EXEC TEMP
#COUNT          =       TEM3            # FOR DSPIN
```

Uses CHAR 140, DOTINC 142, DOTRET 142, DSPCOUNT 152, FACTOR 226, HITEMIN 140, INTB15+ 140, INTBIT15 140, LOTEMIN 140, MATINC 142, MIXTEMP 142, POLISH 140, SAVE 191, SFTEMP1 140, SFTEMP2 140, TEM1 142, TEM2 142, TEM3 142, TEMP 191, VBUF 140, and Z 80.

515 ⟨*Page CM0312* 515⟩≡ (504 2773)

```
#TEM4           ERASE                   # EXEC TEMP
#LSTPTR         =       TEM4            # LIST POINTER FOR GRABUSY
#RELRET         =       TEM4            # RETURN FOR RELDSP
#FREERET        =       TEM4            # RETURN FOR FREEDSP
#DSPWDRET       =       TEM4            # RETURN FOR DSPSIGN
#SEPSCRET       =       TEM4            # RETURN FOR SEPSEC
#SEPMNRET       =       TEM4            # RETURN FOR SEPMIN
#TEM5           ERASE                   # EXEC TEMP
#NOUNADD        =       TEM5            # TEMP STORAGE FOR NOUN ADDRESS
#NNADTEM        ERASE                   # TEMP FOR NOUN ADDRESS TABLE ENTRY
#NNTYPTEM       ERASE                   # TEMP FOR NOUN TYPE TABLE ENTRY
#IDAD1TEM       ERASE                   # TEMP FOR INDIR ADDRESS TABLE ENTRY (MIXNN)
#                                       # MUST = IDAD2TEM-1, = IDAD3TEM-2
#IDAD2TEM       ERASE                   # TEMP FOR INDIR ADDRESS TABLE ENTRY (MIXNN)
#                                       # MUST = IDAD1TEM+1, IDAD3TEM-1.
#IDAD3TEM       ERASE                   # TEMP FOR INDIR ADDRESS TABLE ENTRY (MIXNN)
#                                       # MUST = IDAD1TEM+2, IDAD2TEM+1.
#RUTMXTEM       ERASE                   # TEMP FOR SF ROUT TABLE ENTRY (MIXNN ONLY)
#
# END OF TEMPORARIES FOR PINBALL EXECUTIVE ACTION.
#
# ADDITIONAL TEMPORARIES FOR PINBALL EXECUTIVE ACTION
#
#       MPAC, THRU MPAC +6
#       BUF, +1, +2
#       BUF2, +1, +2
#       MPTEMP
#       ADDRWD
#
# END OF ADDITIONAL TEMPS FOR PINBALL EXEC ACTION
#
# RESERVED FOR PINBALL INTERRUPT ACTION
#
#DSPCNT         ERASE                   # COUNTER FOR DSPOUT
#UPLOCK         ERASE                   # BIT1 = UPLINK INTERLOCK (ACTIVATED BY
#                                       # RECEPTION OF A BAD MESSAGE IN UPLINK)
#
# END OF ERASABLES RESERVED FOR PINBALL INTERRUPT ACTION
#
# TEMPORARIES FOR PINBALL INTERRUPT ACTION
#
#KEYTEMP1       =       WAITEXIT        # TEMP FOR KEYRUPT, UPRUPT
#DSRUPTEM       =       WAITEXIT        # TEMP FOR DSPOUT
#KEYTEMP2       =       RUPTAGN         # TEMP FOR KEYRUPT, UPRUPT
#
```

```
# END OF TEMPORARIES FOR PINBALL INTERRUPT ACTION
```

Uses A 80, ADDRWD 140, BUF 142, BUF2 142, IDAD1TEM 144, IDAD2TEM 144, IDAD3TEM 144, KEYRUPT 59, MPAC 145, MPTEMP 142, RUPTAGN 150, TEM4 142, TEM5 142, TEMP 191, and WAITEXIT 138.

517 ⟨*Page CM0313* 517⟩≡ (504 2773)

```
# THE INPUT CODES ASSUMED FOR THE KEYBOARD ARE,
#       0               10000
#       1               00001
#       9               01001
#       VERB            10001
#       ERROR RES       10010
#       KEY RLSE        11001
#       +               11010
#       -               11011
#       ENTER           11100
#       CLEAR           11110
#       NOUN            11111
#
# OUTPUT FORMAT FOR DISPLAY PANEL.  SET OUT0 TO AAAABCCCCCDDDDD.
# A'S   SELECTS A RELAYWORD.  THIS DETERMINES WHICH PAIR OF CHARACTERS ARE
#       ENERGIZED.
# B     FOR SPECIAL RELAYS SUCH AS SIGNS ETC.
# C'S   5 BIT RELAY CODE FOR LEFT CHAR OF PAIR SELECTED BY RELAYWORD.
# D'S   5 BIT RELAY CODE FOR RIGHT CHAR OF PAIR SELECTED BY RELAYWORD.
#
# THE PANEL APPEARS AS FOLLOWS,
#       MD1             MD2 (MAJOR MODE)
#       VD1             VD2 (VERB)                      ND1             ND2 (NOUN)
#       R1D1            R1D2            R1D3            R1D4            R1D5 (R1)
#       R2D1            R2D2            R2D3            R2D4            R2D5 (R2)
#       R3D1            R3D2            R3D3            R3D4            R3D5 (R3)
#
# EACH OF THESE IS GIVEN A DSPCOUNT NUMBER FOR USE WITHIN COMPUTATION ONLY
#
#       MD1     25              R2D1    11              ALL ARE OCTAL
#       MD2     24              R2D2    10
#       VD1     23              R2D3    7
#       VD2     22              R2D4    6
#       ND1     21              R2D5    5
#       ND2     20              R3D1    4
#       R1D1    16              R3D2    3
#       R1D2    15              R3D3    2
#       R1D3    14              R3D4    1
#       R1D4    13              R3D5    0
#       R1D5    12
#
# THERE IS AN 11-REGISTER TABLE (DSPTAB) FOR THE DISPLAY PANEL.
#
#       DSPTAB          RELAYWD         BIT11           BITS 10-6       BITS 5-1
#       RELADD
```

```
#       10              1011                            MD1 (25)        MD2  (24)
#       9               1010                            VD1 (23)        VD2  (22)
#       8               1001                            ND1 (21)        ND2  (20)
#       7               1000                                            R1D1 (16)
```

Uses A 80, CHAR 140, CODE 140, DSPCOUNT 152, DSPTAB 154, MODE 145, OUTO 87, and R2 188.

518 ⟨*Page CM0314* 518⟩≡ (504 2773)

```
#       6               0111            +R1             R1D2 (15)       R1D3 (14)
#       5               0110            -R1             R1D4 (13)       R1D5 (12)
#       4               0101            +R2             R2D1 (11)       R2D2 (10)
#       3               0100            -R2             R2D3 (7)        R2D4 (6)
#       2               0011                            R2D5 (5)        R3D1 (4)
#       1               0010            +R3             R3D2 (3)        R3D3 (2)
#       0               0001            -R3             R3D4 (1)        R3D5 (0)
#                       0000        NO RELAYWORD
#
# THE 5-BIT OUTOUT RELAY CODES ARE:
#
#       BLANK   00000
#       0       10101
#       1       00011
#       2       11001
#       3       11011
#       4       01111
#       5       11110
#       6       11100
#       7       10011
#       8       11101
#       9       11111
#
# OUTPUT BITS USED BY PINBALL:
#
#       KEY RELEASE LIGHT       --      BIT 5 OF CHANNEL 11
#       VERB/NOUN FLASH         --      BIT 6 OF CHANNEL 11
#       OPERATOR ERROR LIGHT    --      BIT 7 OF CHANNEL 11
```

Uses R2 188.

519 ⟨*Page CM0315* 519⟩≡ (504 2773)

```
# START OF EXECUTIVE SECTION OF PINBALL

                BANK    40
                SETLOC  PINBALL1
                BANK

                COUNT   40/PIN

CHARIN          CAF     ONE             # BLOCK DISPLAY SYST
                XCH     DSPLOCK         # MAKE DSP SYST BUSY, BUT SAVE OLD
                TS      21/22REG        # C(DSPLOCK) FOR ERROR LIGHT RESET.
                CCS     CADRSTOR        # ALL KEYS EXCEPT ER TURN ON KR LITE IF
                TC      +2              # CADRSTOR IS FULL.  THIS REMINDS OPERATOR
                TC      CHARIN2         # TO RE-ESTABLISH A FLASHING DISPLAY
                CS      ELRCODE1        # WHICH HE HAS OBSCURED WITH DISPLAYS OF
                AD      MPAC            # HIS OWN (SEE REMARKS PRECEDING ROUTINE
                EXTEND                  # VBRELDSP).
                BZF     CHARIN2
                TC      RELDSPON
CHARIN2         XCH     MPAC
                TS      CHAR
                INDEX   A
                TC      +1              #   INPUT CODE      FUNCTION
                TC      CHARALRM        #       0
                TC      NUM             #       1
                TC      NUM             #       2
                TC      NUM             #       3
                TC      NUM             #       4
                TC      NUM             #       5
                TC      NUM             #       6
                TC      NUM             #       7
                TC      89TEST          #       10              8
                TC      89TEST          #       11              9
                TC      CHARALRM        #       12
                TC      CHARALRM        #       13
                TC      CHARALRM        #       14
                TC      CHARALRM        #       15
                TC      CHARALRM        #       16
                TC      CHARALRM        #       17
                TC      NUM     -2      #       20              0
                TC      VERB            #       21              VERB
                TC      ERROR           #       22              ERROR LIGHT RESET
                TC      CHARALRM        #       23
                TC      CHARALRM        #       24
                TC      CHARALRM        #       25
```

```
                TC      CHARALRM        #       26
                TC      CHARALRM        #       27
                TC      CHARALRM        #       30
                TC      VBRELDSP        #       31              KEY RELEASE
```

Uses 21/22REG 140, A 80, CADRSTOR 154, CHAR 140, CODE 140, COUNT 142, DISPLAYS 59, DSPLOCK 154, MPAC 145, PINBALL1 71, SAVE 191, and TC 169.

521 ⟨*Page CM0316* 521⟩≡ (504 2773)

```
                TC      POSGN           #       32              +
                TC      NEGSGN          #       33              -
                TC      ENTERJMP        #       34              ENTER
                TC      CHARALRM        #       35
                TC      CLEAR           #       36              CLEAR
                TC      NOUN            #       37              NOUN

ELRCODE1        OCT     22
ENTERJMP        TC      POSTJUMP
                CADR    ENTER

89TEST          CCS     DSPCOUNT
                TC      +4              # +
                TC      +3              # +0
                TC      ENDOFJOB        # - BLOCK DATA IN IF DSPCOUNT IS - OR -0
                TC      ENDOFJOB        # -0
                CAF     THREE
                MASK    DECBRNCH
                CCS     A
                TC      NUM             # IF DECBRNCH IS +, 8 OR 9 OK
                TC      CHARALRM        # IF DECBRNCH IS +0, REJECT 8 OR 9

# NUM ASSEMBLES OCTAL 3 BITS AT A TIME.  FOR DECIMAL IT CONVERTS INCOMING
# WORD AS A FRACTION, KEEPING RESULTS TO DP.
# OCTAL RESULTS ARE LEFT IN XREG, YREG, OR ZREG.  HI PART OF DEC IN XREG,
# YREG, ZREG.  THE LOW PARTS IN XREGLP, YREGLP, OR ZREGLP.
# DECBRNCH IS LEFT AT +0 FOR OCT, +1 FOR + DEC, +2 FOR - DEC.
# IF DSPCOUNT WAS LEFT -, NO MORE DATA IS ACCEPTED.

                CAF     ZERO
                TS      CHAR
NUM             CCS     DSPCOUNT
                TC      +4              # +
                TC      +3              # +0
                TC      +1              # -BLOCK DATA IN IF DSPCOUNT IS -
                TC      ENDOFJOB        # -0
                TC      GETINREL
                CCS     CLPASS          # IF CLPASS IS + OR +0, MAKE IT +0.
                CAF     ZERO
                TS      CLPASS
                TC      +1
                INDEX   CHAR
                CAF     RELTAB
                MASK    LOW5
                TS      CODE
```

```
CA      DSPCOUNT
TS      COUNT
TC      DSPIN
```

Uses A 80, CHAR 140, CLPASS 154, CODE 140, COUNT 142, DECBRNCH 152, DSPCOUNT 152, IT 185, TC 169, XREG 152, XREGLP 152, YREG 152, YREGLP 152, ZREG 152, and ZREGLP 152.

523 ⟨*Page CM0317* 523⟩≡ (504 2773)

```
                CAF     THREE
                MASK    DECBRNCH
                CCS     A               # +0, OCTAL.  +1, + DEC.  +2, - DEC.
                TC      DECTOBIN        # +
                INDEX   INREL           # +0 OCTAL
                XCH     VERBREG
                TS      CYL
                CS      CYL
                CS      CYL
                XCH     CYL
                AD      CHAR
                TC      ENDNMTST
DECTOBIN        INDEX   INREL
                XCH     VERBREG
                TS      MPAC            # SUM X 2EXP-14 IN MPAC
                CAF     ZERO
                TS      MPAC +1
                CAF     TEN             # 10 X 2EXP-14
                TC      SHORTMP         # 10SUM X 2EXP-28 IN MPAC, MPAC+1
                XCH     MPAC +1
                AD      CHAR
                TS      MPAC +1
                TC      ENDNMTST        # NO OF
                ADS     MPAC            # OF MUST BE 5TH CHAR
                TC      DECEND
ENDNMTST        INDEX   INREL
                TS      VERBREG
                CS      DSPCOUNT
                INDEX   INREL
                AD      CRITCON
                EXTEND
                BZF     ENDNUM          # -0, DSPCOUNT = CRITCON
                TC      MORNUM          # -, DSPCOUNT G/ CRITCON
ENDNUM          CAF     THREE
                MASK    DECBRNCH
                CCS     A
                TC      DECEND
ENDALL          CS      DSPCOUNT        # BLOCK NUMIN BY PLACING DSPCOUNT
                TC      MORNUM +1       # NEGATIVELY
DECEND          CS      ONE
                AD      INREL
                EXTEND
                BZMF    ENDALL          # IF INREL=0,1 (VBREG,NNREG) LEAVE WHOLE
                TC      DMP             # IF INREL=2,3,4 (R1,R2,R3), CONVERT TO FRAC
                                        # MULT SUM X 2EXP-28 IN MPAC, MPAC+1 BY
```

```
ADRES   DECON           # 2EXP14/10EXP5, GIVES (SUM/10EXP5)X2EXP-14
CAF     THREE           # IN MPAC, +1, +2.
MASK    DECBRNCH
INDEX   A
TC      +0
```

Uses A 80, CHAR 140, CYL 80, DECBRNCH 152, DSPCOUNT 152, INREL 142, MPAC 145, R2 188, TC 169, and VERBREG 152.

525 ⟨*Page CM0318* 525⟩≡ (504 2773)

```
                TC      +DECSGN
                EXTEND                  # - CASE
                DCS     MPAC +1
                DXCH    MPAC +1
+DECSGN         XCH     MPAC +2
                INDEX   INREL
                TS      XREGLP -2
                XCH     MPAC +1
                INDEX   INREL
                TS      VERBREG
                TC      ENDALL
MORNUM          CCS     DSPCOUNT        # DECREMENT DSPCOUNT
                TS      DSPCOUNT
                TC      ENDOFJOB

CRITCON         OCT     22              # (DEC 18)
                OCT     20              # (DEC 16)
                OCT     12              # (DEC 10)
                OCT     5
                OCT     0

DECON           2DEC    1 E-5 B14       # 2EXP14/10EXP5 = .16384 DEC

# GETINREL GETS PROPER DATA REG REL ADDRESS FOR CURRENT C(DSPCOUNT) AND
# PUTS IN INTO INREL.  +0 VERBREG, 1 NOUNREG, 2 XREG, 3 YREG, 4 ZREG.

GETINREL        INDEX   DSPCOUNT
                CAF     INRELTAB
                TS      INREL           # (A TEMP. REG)
                TC      Q

INRELTAB        OCT     4               # R3D5 (DSPCOUNT = 0)
                OCT     4               # R3D4           =(1)
                OCT     4               # R3D3           =(2)
                OCT     4               # R3D2           =(3)
                OCT     4               # R3D1           =(4)
                OCT     3               # R2D5           =(5)
                OCT     3               # R2D4           =(6)
                OCT     3               # R2D3           =(7)
                OCT     3               # R2D2           =(8D)
                OCT     3               # R2D1           =(9D)
                OCT     2               # R1D5           =(10D)
                OCT     2               # R1D4           =(11D)
                OCT     2               # R1D3           =(12D)
                OCT     2               # R1D2           =(13D)
```

```
OCT     2               # R1D1           =(14D)
TC      CCSHOLE         # NO DISCOUNT NUMBER = 15D
OCT     1               # ND2            =(16D)
```

Uses A 80, DSPCOUNT 152, INREL 142, MPAC 145, NOUNREG 152, Q 80, TC 169, TEMP 191, VERBREG 152, XREG 152, XREGLP 152, YREG 152, and ZREG 152.

527 ⟨*Page CM0319* 527⟩≡ (504 2773)

```
                OCT     1               # ND1           =(17D)
                OCT     0               # VD2           =(18D)
                OCT     0               # VD1           =(19D)

VERB            CAF     ZERO
                TS      VERBREG
                CAF     VD1
NVCOM           TS      DSPCOUNT
                TC      2BLANK
                CAF     ONE
                TS      DECBRNCH        # SET FOR DEC V/N CODE
                CAF     ZERO
                TS      REQRET          # SET FOR ENTPASO
                CAF     ENDINST         # IF DSPALARM OCCURS BEFORE FIRST ENTPASO
                TS      ENTRET          # OR NVSUB, ENTRET MUST ALREADY BE SET
                                        # TO TC ENDOFJOB
                TC      ENDOFJOB
NOUN            CAF     ZERO
                TS      NOUNREG
                CAF     ND1             # ND1, OCT 21 (DEC 17)
                TC      NVCOM

NEGSGN          TC      SIGNTEST
                TC      -ON
                CAF     TWO
BOTHSGN         INDEX   INREL           # SET DEC COMP BIT TO 1 (IN DECBRNCH)
                AD      BIT7            # BIT 5 FOR R1.  BIT 4 FOR R2.
                ADS     DECBRNCH        # BIT 3 FOR R3.
FIXCLPAS        CCS     CLPASS          # IF CLPASS IS + OR +0.  MAKE IT +0.
                CAF     ZERO
                TS      CLPASS
                TC      +1
                TC      ENDOFJOB

POSGN           TC      SIGNTEST
                TC      +ON
                CAF     ONE
                TC      BOTHSGN

+ON             LXCH    Q
                TC      GETINREL
                INDEX   INREL
                CAF     SGNTAB -2
                TS      SGNOFF
                AD      ONE
```

```
                TS      SGNON
SGNCOM          CAF     ZERO
                TS      CODE
```

Uses CLPASS 154, CODE 140, DECBRNCH 152, DSPCOUNT 152, ENTRET 142, INREL 142, IT 185, N 206, NOUNREG 152, Q 80, R2 188, REQRET 154, SGNOFF 140, SGNON 140, TC 169, V 229, and VERBREG 152.

529 ⟨*Page CM0320* 529⟩≡ (504 2773)

```
                XCH     SGNOFF
                TC      11DSPIN
                CAF     BIT11
                TS      CODE
                XCH     SGNON
                TC      11DSPIN
                TC      L
-ON             LXCH    Q
                TC      GETINREL
                INDEX   INREL
                CAF     SGNTAB -2
                TS      SGNON
                AD      ONE
                TS      SGNOFF
                TC      SGNCOM

SGNTAB          OCT     5               # -R1
                OCT     3               # -R2
                OCT     0               # -R3

SIGNTEST        LXCH    Q               # ALLOWS +,- ONLY WHEN DSPCOUNT=R1D1,
                CAF     THREE           # R2D1, OR R3D1.  ALLOWS ONLY FIRST OF
                MASK    DECBRNCH        # CONSECUTIVE +/- CHARACTERS.
                CCS     A               # IF LOW2 BITS OF DECBRNCH NOT 0.  SIGN
                TC      ENDOFJOB        # FOR THIS WORD ALREADY IN.  REJECT.
                CS      R1D1
                TC      SGNTST1
                CS      R2D1
                TC      SGNTST1
                CS      R3D1
                TC      SGNTST1
                TC      ENDOFJOB        # NO MATCH FOUND.  SIGN ILLEGAL
SGNTST1         AD      DSPCOUNT
                EXTEND
                BZF     +2              # MATCH FOUND
                TC      Q
                TC      L               # SIGN LEGAL

# CLEAR BLANKS WHICH R1, R2, R3 IS CURRENT OR LAST TO BE DISPLAYED (PERTINENT
# XREG, YREG, ZREG IS CLEARED).  SUCCESSIVE CLEARS TAKE CARE OF EACH RX
# L/ RC UNTIL R1 IS DONE.  THEN NO FURTHER ACTION.
#
# THE SINGLE COMPONENT LOAD VERBS ALLOW ONLY THE SINGLE RC THAT IS
# APPROPRIATE TO BE CLEARED.
#
```

```
# CLPASS        +0 PASS0, CAN BE BACKED UP
#               +NZ HIPASS, CAN BE BACKED UP
#               -NZ PASS0, CANNOT BE BACKED UP
```

Uses A 80, CLPASS 154, CODE 140, DECBRNCH 152, DSPCOUNT 152, INREL 142, L 80, Q 80, R2 188, SGNOFF 140, SGNON 140, TC 169, XREG 152, YREG 152, and ZREG 152.

531 ⟨*Page CM0321* 531⟩≡ (504 2773)

```
CLEAR           CCS     DSPCOUNT
                AD      ONE
                TC      +2
                AD      ONE
                INDEX   A               # DO NOT CHANGE DSPCOUNT BECAUSE MAY LATER
                CAF     INRELTAB        # FAIL LEGALTST.
                TS      INREL           # MUST SET INREL, EVEN FOR HIPASS.
                CCS     CLPASS
                TC      CLPASHI         # +
                TC      +2              # +0    IF CLPASS IS +0 OR -, IT IS PASS0
                TC      +1              # -
                CA      INREL
                TC      LEGALTST
                TC      CLEAR1
CLPASHI         CCS     INREL
                TS      INREL
                TC      LEGALTST
                CAF     DOUBLK +2       # +3 TO - NUMBER, BACKS DATA REQUESTS.
                ADS     REQRET
                CA      INREL
                TS      MIXTEMP         # TEMP STORAGE FOR INREL
                EXTEND
                DIM     VERBREG         # DECREMENT VERB AND RE-DISPLAY
                TC      BANKCALL
                CADR    UPDATVB
                CA      MIXTEMP
                TS      INREL           # RESTORE INREL
CLEAR1          TC      CLR5
                INCR    CLPASS          # ONLY IF CLPASS IS + OR +0
                TC      ENDOFJOB        # SET FOR HIGHER PASS.
CLR5            LXCH    Q               # USED 5BLANK BUT AVOIDS ITS TC GETINREL
                TC      5BLANK +2
LEGALTST        AD      NEG2
                CCS     A
                TC      Q               # LEGAL         INREL G/2
                TC      CCSHOLE
                TC      ENDOFJOB        # ILLEGAL       INREL=0,1
                TC      Q               # LEGAL         INREL=2

# 5BLANK BLANKS 5 CHAR DISPLAY WORD IN R1, R2, OR R3.  IT ALSO ZEROES XREG,
# YREG, OR ZREG.  PLACE ANY + DSPCOUNT NUMBER FOR PERTINENT RC INTO DSPCOUNT.
# DSPCOUNT IS LEFT SET TO LEFT MOST DSP NUMB FOR RC JUST BLANKED.

                TS      DSPCOUNT        # NEEDED FOR BLANKSUB
5BLANK          LXCH    Q
```

```
TC      GETINREL
CAF     ZERO
INDEX   INREL
TS      VERBREG         # ZERO X, Y, Z, REG.
```

Uses A 80, CHAR 140, CLPASS 154, DSPCOUNT 152, INREL 142, IT 185, MIXTEMP 142, Q 80, R2 188, REQRET 154, TC 169, TEMP 191, VERBREG 152, XREG 152, YREG 152, Z 80, and ZREG 152.

533 ⟨*Page CM0322* 533⟩≡ (504 2773)

```
                INDEX   INREL
                TS      XREGLP  -2
                TS      CODE
                INDEX   INREL           # ZERO PERTINENT DEC COMP BIT.
                CS      BIT7            # PROTECT OTHERS
                MASK    DECBRNCH
                MASK    BRNCHCON        # ZERO LOW 2 BITS.
                TS      DECBRNCH
                INDEX   INREL
                CAF     SINBLANK -2     # BLANK ISOLATED CHAR SEPARATELY
                TS      COUNT
                TC      DSPIN
5BLANK1         INDEX   INREL
                CAF     DOUBLK   -2
                TS      DSPCOUNT
                TC      2BLANK
                CS      TWO
                ADS     DSPCOUNT
                TC      2BLANK
                INDEX   INREL
                CAF     R1D1    -2
                TS      DSPCOUNT        # SET DSPCOUNT TO LEFT MOST DSP NUMBER
                TC      L               # OF REG. JUST BLANKED

SINBLANK        OCT     16              # DEC 14
                OCT     5
                OCT     4
DOUBLK          OCT     15              # DEC 13
                OCT     11              # DEC 9
                OCT     3

BRNCHCON        OCT     77774

# 2BLANK BLANKS TWO CHAR. PLACE DSP NUMBER OF LEFT CHAR OF THE PAIR INTO
# DSPCOUNT.  THIS NUMBER IS LEFT IN DSPCOUNT

2BLANK          CA      DSPCOUNT
                TS      SR
                CS      BLANKCON
                INHINT
                INDEX   SR
                XCH     DSPTAB
                EXTEND
                BZMF    +2              # IF OLD CONTENTS -, NOUT OK
                INCR    NOUT            # IF OLD CONTENTS +, +1 TO NOUT
```

```
                RELINT                  # IF -, NOUT OK
                TC      Q
BLANKCON        OCT     4000
```

Uses CHAR 140, CODE 140, COUNT 142, DECBRNCH 152, DSPCOUNT 152, DSPTAB 154, INREL 142, L 80, NOUT 154, Q 80, SR 80, TC 169, and XREGLP 152.

535 ⟨*Page CM0323* 535⟩≡ (504 2773)

```
# ENTER PASS 0 IS THE EXECUTE FUNCTION.  HIGHER ORDER ENTERS ARE TO LOAD
# DATA.  THE SIGN OF REQRET DETERMINES THE PASS, + FOR PASS 0, - FOR HIGHER
# PASSES
#
# MACHINE CADR TO BE SPECIFIED (MCTBS) NOUNS DESIRE AN ECADR TO BE LOADED
# WHEN USED WITH LOAD VERBS, MONITOR VERBS, OR DISPLAY VERBS (EXCEPT
# VERB = FIXED MEMORY DISPLAY, WHICH REQUIRES AN FCADR).

                BANK    41
                SETLOC  PINBALL2
                BANK

                COUNT   41/PIN

NVSUBB          TC      NVSUB1          # STANDARD LEAD INS.  DON'T MOVE.
LOADLV1         TC      LOADLV

# END OF STANDARD LEAD INS.

ENTER           CAF     ZERO
                TS      CLPASS
                CAF     ENDINST
                TS      ENTRET
                CCS     REQRET
                TC      ENTPAS0         # IF +, PASS 0
                TC      ENTPAS0         # IF +, PASS 0
                TC      +1              # IF -, NOT PASS 0
ENTPASHI        CAF     MMADREF
                AD      REQRET          # IF L/ 2 CHAR IN FOR MM CODE, ALARM
                EXTEND                  # AND RECYCLE (DECIDE AT MCHANG+1).
                BZF     ACCEPTWD
                CAF     THREE           # IF DEC, ALARM IF L/ 5 CHAR IN FOR DATA,
                MASK    DECBRNCH        # BUT LEAVE REQRET - AND FLASH ON, SO
                CCS     A               # OPERATOR CAN SUPPLY MISSING NUMERICAL
                TC      +2              # CHARACTERS AND CONTINUE.
                TC      ACCEPTWD        # OCTAL.  ANY NUMBER OF CHAR OK.
                CCS     DSPCOUNT
                TC      GODSPALM        # LESS THAN 5 CHAR DEC(DSPCOUNT IS +)
                TC      GODSPALM        # LESS THAN 5 CHAR DEC(DSPCOUNT IS +)
                TC      +1              # 5 CHAR IN (DSPCOUNT IS -)
ACCEPTWD        CS      REQRET          # 5 CHAR IN (DSPCOUNT IS -)
                TS      REQRET          # SET REQRET +.
                TC      FLASHOFF
                TC      REQRET
```

```
ENTEXIT         =       ENTRET

MMADREF         ADRES   MMCHANG +1      # ASSUMES TC REQMM AT MMCHANG.
```

Uses A 80, CHAR 140, CLPASS 154, CODE 140, COUNT 142, DECBRNCH 152, DSPCOUNT 152, ENTRET 142, L 80, MM 226, PINBALL2 71, REQRET 154, and TC 169.

537 ⟨*Page CM0324* 537⟩≡ (504 2773)

```
LOWVERB         DEC     28              # LOWER VERB THAT AVOIDS NOUN TEST.

ENTPAS0         CAF     ZERO            # NOUN VERB SUB ENTERS HERE
                TS      DECBRNCH
                CS      VD1             # BLOCK FURTHER NUM CHAR, SO THAT STRAY
                TS      DSPCOUNT        # CHAR DO NOT GET INTO VERB OR NOUN LTS.
TESTVB          CS      VERBREG         # IF VERB IS G/E LOWVB, SKIP NOUN TEST.
                TS      VERBSAVE        # SAVE VERB FOR POSSIBLE RECYCLE.
                AD      LOWVERB         # LOWVERB - VB
                EXTEND
                BZMF    VERBFAN         # VERB G/ E LOWVERB
TESTNN          EXTEND                  # VERB L/ LOWVERB
                DCA     LODNNLOC        # SWITCH BANKS TO NOUN TABLE READING
                DXCH    Z               # ROUTINE.
                INDEX   MIXBR
                TC      +0
                TC      +2              # NORMAL
                TC      MIXNOUN         # MIXED
                CCS     NNADTEM         # NORMAL
                TC      VERBFAN -2      #       NORMAL  IF +
                TC      GODSPALM        # NOT IN USE    IF +0
                TC      REQADD          # SPECIFY MACHINE CADR IF -
                INCR    NOUNCADR        # AUGMENT MACHINE CADR IF -0
                TC      SETNADD         # ECADR FROM NOUNCADR, SETS ED, NOUNADD.
                TC      INTMCTBS +2
REQADD          CAF     BIT15           # SET CLPASS FOR PASS 0 ONLY
                TS      CLPASS
                CS      ENDINST         # TEST IF REACHED HERE FROM INTERNAL OR
                AD      ENTEXIT         #       FROM EXTERNAL
                EXTEND
                BZF     +2              # EXTERNAL MACH CADR TO BE SPECIFIED
                TC      INTMCTBS
                TC      REQDATZ         # EXTERNAL MACH CADR TO BE SPECIFIED
                CCS     DECBRNCH        # ALARM AND RECYCLE IF DECIMAL USED
                TC      ALMCYCLE        # FOR MCTBS.
                CS      VD1             # OCTAL USED OK
                TS      DSPCOUNT        # BLOCK NUM CHAR IN
                CCS     CADRSTOR
                TC      +3              # EXTERNAL MCTBS DISPLAY WILL LEAVE FLASH
                TC      USEADD          # ON IF ENDIDLE NOT = +0.
                TC      +1
                TC      FLASHON
USEADD          XCH     ZREG
                TC      SETNCADR        # ECADR INTO NOUNCADR.  SET EB, NOUNADD.
                EXTEND
```

```
DCA     LODNNLOC        # SWITCH BANKS TO NOUN TAB E READING
DXCH    Z               # ROUTINE.
TC      VERBFAN

EBANK=  DSPCOUNT
```

Uses CADRSTOR 154, CHAR 140, CLPASS 154, DECBRNCH 152, DSPCOUNT 152, EBANK 80, L 80, MIXBR 142, NNADTEM 144, NOUNADD 144, NOUNCADR 154, SAVE 191, TC 169, VERBREG 152, VERBSAVE 154, Z 80, and ZREG 152.

539 ⟨*Page CM0325* 539⟩≡ (504 2773)

```
LODNNLOC        2CADR   LODNNTAB

NEG5            OCT     77772

INTMCTBS        CA      MPAC    +2      # INTERNAL MACH CADR TO BE SPECIFIED.
                TC      SETNCADR        # ECADR INTO NOUNCADR.  SET EB, NOUNADD.
                CS      FIVE            # NVSUB CALL LEFT CADR IN MPAC+2 FOR MACH
                AD      VERBREG         # CADR TO BE SPECIFIED.
                EXTEND
                BZF     VERBFAN         # DON'T DISPLAY CADR IF VB = 05.
                CAF     R3D1            # VB NOT = 05.  DISPLAY CADR.
                TS      DSPCOUNT
                CA      NOUNCADR
                TC      DSPOCTWO
                TC      VERBFAN

                AD      ONE
                TC      SETNCADR        # ECADR INTO NOUNCADR.  SETS EB, NOUNADD.
VERBFAN         CS      LST2CON
                AD      VERBREG         # VERB -- LST2CON
                CCS     A
                AD      ONE             # VERB G/ LST2CON
                TC      +2
                TC      VBFANDIR        # VERB L/ LST2CON
                TS      MPAC
                TC      RELDSP          # RELEASE DISPLAY SYST
                TC      POSTJUMP        # GO TO GOEXTVB WITH VB=40 IN MPAC.
                CADR    GOEXTVB
LST2CON         DEC     40              # FIRST LIST2 VERB (EXTENDED VERB)

VBFANDIR        INDEX   VERBREG
                CAF     VERBTAB
                TC      BANKJUMP

VERBTAB         CADR    GODSPALM        # VB00 ILLEGAL
                CADR    DSPA            # VB01 DISPLAY OCT COMP 1 (R1)
                CADR    DSPB            # VB02 DISPLAY OCT COMP 2 (R1)
                CADR    DSPC            # VB03 DISPLAY OCT COMP 3 (R1)
                CADR    DSPAB           # VB04 DISPLAY OCT COMP 1,2 (R1,R2)
                CADR    DSPABC          # VB05 DISPLAY OCT COMP 1,2,3 (R1,R2,R3)
                CADR    DECDSP          # VB06 DECIMAL DISPLAY
                CADR    DSPDPDEC        # VB07 DP DECIMAL DISPLAY (R1,R2)
                CADR    GODSPALM        # VB08 SPARE
                CADR    GODSPALM        # VB09 SPARE
                CADR    DSPALARM        # VB10 SPARE
```

```
                CADR    MONITOR         # VB11 MONITOR OCT COMP 1 (R1)
                CADR    MONITOR         # VB12 MONITOR OCT COMP 2 (R1)
                CADR    MONITOR         # VB13 MONITOR OCT COMP 3 (R1)
                CADR    MONITOR         # VB14 MONITOR OCT COMP 1,2 (R1,R2)
```

Uses A 80, DSPCOUNT 152, L 80, MPAC 145, NOUNADD 144, NOUNCADR 154, R2 188, TC 169, and VERBREG 152.

540 ⟨*Page CM0326* 540⟩≡ (504 2773)

```
                CADR    MONITOR         # VB15 MONITOR OCT COMP 1,2,3 (R1,R2,R3)
                CADR    MONITOR         # VB16 MONITOR DECIMAL
                CADR    MONITOR         # VB17 MONITOR DP DEC (R1,R2)
                CADR    GODSPALM        # VB18 SPARE
                CADR    GODSPALM        # VB19 SPARE
                CADR    GODSPALM        # VB20 SPARE
                CADR    ALOAD           # VB21 LOAD COMP 1 (R1)
                CADR    BLOAD           # VB22 LOAD COMP 2 (R2)
                CADR    CLOAD           # VB23 LOAD COMP 3 (R3)
                CADR    ABLOAD          # VB24 LOAD COMP 1,2 (R1,R2)
                CADR    ABCLOAD         # VB25 LOAD COMP 1,2,3 (R1,R2,R3)
                CADR    GODSPALM        # VB26 SPARE
                CADR    DSPFMEM         # VB27 FIXED MEMORY DISPLAY
                                        # THE FOLLOWING VERBS MAKE NO NOUN TEST
                CADR    GODSPALM        # VB28 SPARE
                CADR    GODSPALM        # VB29 SPARE
  REQEXLQC      CADR    VBRQEXEC        # VB30 REQUEST EXECUTIVE
                CADR    VBRQWAIT        # VB31 REQUEST WAITLIST
                CADR    VBRESEQ         # VB32 RESEQUENCE
                CADR    VBPROC          # VB33 PROCEED WITHOUT DATA
                CADR    VBTERM          # VB34 TERMINATE CURRENT TEST OR LOAD REQ
                CADR    VBTSTLTS        # VB35 TEST LIGHTS
                CADR    SLAP1           # VB36 FRESH START
                CADR    MMCHANG         # VB37 CHANGE MAJOR MODE
                CADR    GODSPALM        # VB38 SPARE
                CADR    GODSPALM        # VB39 SPARE

  # THE LIST2 VERBFAN IS LOCATED IN THE EXTENDED VERB BANK.
```

Uses MODE 145 and R2 188.

541 ⟨*Page CM0327* 541⟩≡ (504 2773)

```
# NNADTAB CONTAINS A RELATIVE ADDRESS, IDADDREL (IN LOW 10 BITS), REFERRING
# TO WHERE 3 CONSECUTIVE ADDRESSES ARE STORED (IN IDADDTAB).
# MIXNOUN GETS DATA AND STORES IN MIXTEMP,+1,+2.  IT SETS NOUNADD FOR
# MIXTEMP.

MIXNOUN         CCS     NNADTEM
                TC      +4              # + IN USE
                TC      GODSPALM        # +0 NOT IN USE
                TC      +2              # - IN USE
                TC      +1              # -0 IN USE
                CS      SIX
                AD      VERBREG
                EXTEND
                BZMF    +2              # VERB L/E 6
                TC      VERBFAN         # AVOID MIXNOUN SWAP IF VB NOT = DISPLAY
                CAF     TWO
MIXNN1          TS      DECOUNT
                AD      MIXAD
                TS      NOUNADD         # SET NOUNADD TO MIXTEMP +K
                INDEX   DECOUNT         # GET IDADDTAB ENTRY FOR COMPONENT K
                CA      IDAD1TEM        # OF NOUN.
                TS      NOUNTEM
                                        # TEST FOR DP (FOR OCT DISPLAY).  IF SO, GET
                                        #       MINOR PART ONLY.
                TC      SFRUTMIX        # GET SF ROUT NUMBER IN A
                TC      DPTEST
                TC      MIXNN2          # NO DP
                INCR    NOUNTEM         # DP GET MINOR PART
MIXNN2          CA      NOUNTEM
                MASK    LOW11           # ESUBK (NO DP) OR (ESUBK)+1  FOR DP.
                TC      SETEBANK        # SET EBANK, LEAVE EADRES IN A.
                INDEX   A               # PICK UP C(ESUBK) NOT DP.
                CA      0               # OR C((ESUBK)+1) FOR DP MINOR PART
                INDEX   NOUNADD
                XCH     0               # STORE IN MIXTEM + K
                CCS     DECOUNT
                TC      MIXNN1
                TC      VERBFAN

MIXAD           TC      MIXTEMP

# DPTEST        ENTER WITH SF ROUT NUMBER IN A.
#               RETURNS TO L+1 IF NO DP.
#               RETURNS TO L+2 IF DP.
```

```
DPTEST          INDEX   A
                TCF     +1
                TC      Q               # OCTAL ONLY NO DP
                TC      Q               # FRACT NO DP
```

Uses A 80, DECOUNT 140, EBANK 80, IDAD1TEM 144, IT 185, L 80, MIXTEMP 142, NNADTEM 144, NOUNADD 144, NOUNTEM 140, Q 80, TC 169, and VERBREG 152.

543 ⟨*Page CM0328* 543⟩≡ (504 2773)

```
                TC      Q               # DEG NO DP
                TC      Q               # ARITH NO DP
                TCF     DPTEST1         # DP1OUT
                TCF     DPTEST1         # DP2OUT
                TC      Q               # OPDEG NO DP
                TCF     DPTEST1         # DP3OUT
                TC      Q               # HMS NO DP
                TC      Q               # M/S NO DP
                TCF     DPTEST1         # DP4OUT
                TC      Q               # ARITH1 NO DP
                TC      Q               # 2INTOUT NO DP TO GET HI PART IN MPAC
                TCF     DPTEST1         # DPFRACOT
DPTEST1         INDEX   Q
                TC      1               # RETURN TO L+2

REQDATX         CAF     R1D1
                TCF     REQCOM
REQDATY         CAF     R2D1
                TCF     REQCOM
REQDATZ         CAF     R3D1
REQCOM          TS      DSPCOUNT
                CS      Q
                TS      REQRET
                TC      BANKCALL
                CADR    5BLANK
                TC      FLASHON
ENDRQDAT        TC      ENTEXIT

                TS      NOUNREG
UPDATNN         XCH     Q
                TS      UPDATRET
                EXTEND
                DCA     LODNNLOC        # SWITCH BANKS TO NOUN TABLE READING
                DXCH    Z               # ROUTINE.
                CCS     NNADTEM
                AD      ONE             # NORMAL
                TCF     PUTADD
                TCF     PUTADD +1       # MCTBS         DON'T CHANGE NOUNADD
                TCF     PUTADD +1       # MCTBI         DON'T CHANGE NOUNADD
PUTADD          TC      SETNCADR        # ECADR INTO NOUNCADR.  SETS EB, NOUNADD.
                CAF     ND1
                TS      DSPCOUNT
                CA      NOUNREG
                TCF     UPDAT1
```

```
                TS      VERBREG
UPDATVB         XCH     Q
                TS      UPDATRET
                CAF     VD1
```

Uses DSPCOUNT 152, L 80, MPAC 145, NNADTEM 144, NOUNADD 144, NOUNCADR 154, NOUNREG 152, Q 80, REQRET 154, TC 169, UPDATRET 140, VERBREG 152, and Z 80.

544 ⟨*Page CM0329* 544⟩≡ (504 2773)

```
                TS      DSPCOUNT
                CA      VERBREG
UPDAT1          TC      POSTJUMP        # CAN'T USE SWCALL TO GO TC DSPDECVN, SINCE
                CADR    GOVNUPDT        # UPDATVB CAN ITSELF BE CALLED BY SWCALL.
                TC      UPDATRET

GOALMCYC        TC      ALMCYCLE        # NEEDED BECAUSE BANKJUMP CAN'T HANDLE F/F.

GODSPALM        TC      POSTJUMP
                CADR    DSPALARM
```

Uses DSPCOUNT 152, F 238, TC 169, UPDATRET 140, and VERBREG 152.

545 ⟨*Page CM0330* 545⟩≡ (504 2773)

```
# NOUN TABLES
#
# NOUN CODE L/40, NORMAL NOUN CASE.  NOUN CODE G/E 40, MIXED NOUN CASE.
# FOR NORMAL CASE, NNADTAB CONTAINS ONE ECADR FOR EACH NOUN.
# +0 INDICATES NOUN NOT USED.  - ENTRY INDICATES MACHINE CADR (E OR F) TO
# BE SPECIFIED.  -1 INDICATES CHANNEL TO BE SPECIFIED.  -0 INDICATES AUGMENT
# OF LAST MACHINE CADR SUPPLIED.
#
# FOR MIXED CASE, NNADTAB CONTAINS ONE INDIRECT ADDRESS (IDADDREL) IN LOW
# 10 BITS, AND THE COMPONENT CODE NUMBER IN THE HIGH 5 BITS.
#
# NNTYPTAB IS A PACKED TABLE OF THE FORM MMMMMNNNNNPPPPP.
#
# FOR THE NORMAL CASE,  M'S ARE THE COMPONENT CODE NUMBER.
#                       N'S ARE THE SF ROUTINE CODE NUMBER.
#                       P'S ARE THE SF CONSTANT CODE NUMBER.
#
# MIXED-CASE,           M'S ARE THE SF CONSTANT3 CODE NUMBER    3 COMPONENT CASE
#                       N'S ARE THE SF CONSTANT2 CODE NUMBER
#                       P'S ARE THE SF CONSTANT1 CODE NUMBER
#                       N'S ARE THE SF CONSTANT2 CODE NUMBER    2 COMPONENT CASE
#                       P'S ARE THE SF CONSTANT1 CODE NUMBER
#                       P'S ARE THE SF CONSTANT1 CODE NUMBER    1 COMPONENT CASE
#
# THERE IS ALSO AN INDIRECT ADDRESS TABLE (IDADDTAB) FOR MIXED CASE ONLY
# EACH ENTRY CONTAINS ONE ECADR.  IDADDREL IS THE RELATIVE ADDRESS OF
# THE FIRST OF THESE ENTRIES.
#
# THERE IS ONE ENTRY IN THIS TABEL FOR EACH COMPONENT OF A MIXED NOUN
# THEY ARE LISTED IN ORDER OF ASCENDING K.
#
# THERE IS ALSO A SCALE FACTOR ROUTINE NUMBER TABLE (RUTMXTAB) FOR MIXED
# CASE ONLY.  THERE IS ONE ENTRY PER MIXED NOUN.  THE FORM IS,
#
#       QQQQQRRRRRSSSSS
#
# Q'S ARE THE SF ROUTINE 3 CODE NUMBER          3 COMPONENT CASE
# R'S ARE THE SF ROUTINE 2 CODE NUMBER
# S'S ARE THE SF ROUTINE 1 CODE NUMBER
# R'S ARE THE SF ROUTINE 2 CODE NUMBER          2 COMPONENT CASE
# S'S ARE THE SF ROUTINE 1 CODE NUMBER
#
# IN OCTAL DISPLAY AND LOAD (OCT OR DEC) VERBS, EXCLUDE USE OF VERBS WHOSE
# COMPONENT NUMBER IS GREATER THAN THE NUMBER OF COMPONENTS IN NOUN.
# (ALL MACHINE ADDRESS TO BE SPECIFIED NOUNS ARE 3 COMPONENT.)
```

```
#
# IN MULTI-COMPONENT LOAD VERBS, NO MIXING OF OCTAL AND DECIMAL DATA
# COMPONENT WORDS IS ALLOWED.  ALARM IF VIOLATION.
#
# IN DECIMAL LOADS OF DATA, 5 NUMERICAL CHARACTERS MUST BE KEYED IN
# BEFORE EACH ENTER.  IF NOT, ALARM.
```

Uses `A` 80, `CODE` 140, `F` 238, `FACTOR` 226, and `L` 80.

547 ⟨*Page CM0331* 547⟩≡ (504 2773)

```
# DISPLAY VERBS

DSPABC          CS      TWO
                TC      COMPTEST
                INDEX   NOUNADD
                CS      2
                XCH     BUF     +2
DSPAB           CS      ONE
                TC      COMPTEST
                INDEX   NOUNADD
                CS      1
                XCH     BUF     +1
DSPA            TC      DECTEST
                TC      TSTFORDP
                INDEX   NOUNADD
                CS      0
DSPCOM1         XCH     BUF
                TC      DSPCOM2
DSPB            CS      ONE
                TC      DCOMPTST
                INDEX   NOUNADD
                CS      1
                TC      DSPCOM1
DSPC            CS      TWO
                TC      DCOMPTST
                INDEX   NOUNADD
                CS      2
                TC      DSPCOM1
DSPCOM2         CS      TWO             # A B C AB ABC
                AD      VERBREG         # -1 -0 +1 +2 +3 IN A
                CCS     A               # +0 +0 +0 +1 +2 IN A AFTER CCS
                TC      DSPCOM3
                TC      ENTEXIT
                TC      +1
DSPCOM3         TS      DISTEM          # +0 +1 +2 INTO DISTEM
                INDEX   A
                CAF     R1D1
                TS      DSPCOUNT
                INDEX   DISTEM
                CS      BUF
                TC      DSPOCTWO
                XCH     DISTEM
                TC      DSPCOM2 +2

# COMPTEST ALARMS IF COMPONENT NUMBER OF VERB (LOAD OR OCT DISPLAY) IS
```

```
# GREATER THAN THE HIGHEST COMPONENT NUMBER OF NOUN.

COMPTEST        TS      SFTEMP1         # VERB COMP
                LXCH    Q
COMPTST1        TC      GETCOMP
                TC      LEFT5
                MASK    THREE           # NOUN COMP
```

Uses A 80, BUF 142, DISTEM 140, DSPCOUNT 152, NOUNADD 144, Q 80, SFTEMP1 140, TC 169, and VERBREG 152.

549 ⟨*Page CM0332* 549⟩≡ (504 2773)

```
                AD      SFTEMP1         # NOUN COMP -- VERB COMP
                CCS     A
                TC      L               # NOUN COMP G/ VERB COMP
                TC      CCSHOLE
                TC      GODSPALM        # NOUN COMP L/ VERB COMP
NDCMPTST        TC      L               # NOUN COMP = VERB COMP

# DCOMPTST ALARMS IF DECIMAL ONLY BIT (BIT4 OF COMP CODE NUMBER) = 1.
# IF NOT, IT PERFORMS REGULAR COMPTEST.

DCOMPTST        TS      SFTEMP1         # - VERB COMP
                LXCH    Q
                TC      DECTEST
                TC      COMPTST1

DECTEST         EXTEND                  # ALARMS IF DEC ONLY BIT = 1 (BIT4 OF COMP
                QXCH    MPAC +2         # CODE NUMBER).  RETURNS IF NOT.
                TC      GETCOMP
                MASK    BIT14
                CCS     A
                TC      GODSPALM
                TC      MPAC +2

DCTSTCYC        LXCH    Q               # ALARMS AND RECYCLES IF DEC ONLY BIT = 1
                TC      GETCOMP         # (BIT4 OF COMP CODE NUMBER). RETURNS
                MASK    BIT14           # IF NOT.  USED BY LOAD VERBS.
                CCS     A
                TC      ALMCYCLE
                TC      L

# NOUNTEST ALARMS IF NO-LOAD BIT (BIT5 OF COMP CODE NUMBER) = 1.
# IF NOT, IT RETURNS.

NOUNTEST        LXCH    Q
                TC      GETCOMP
                CCS     A
                TC      L
                TC      L
                TC      GODSPALM

TSTFORDP        LXCH    Q               # TEST FOR DP.  IF SO, GET MINOR PART ONLY.
                CA      NNADTEM
                AD      ONE             # IF NNADTEM = -1, CHANNEL TO BE SPECIFIED
                EXTEND
                BZF     CHANDSP
```

```
INDEX   MIXBR
TC      +0
TC      +2              # NORMAL
```

Uses A 80, CODE 140, IT 185, L 80, MIXBR 142, MPAC 145, NNADTEM 144, Q 80, SFTEMP1 140, and TC 169.

551 ⟨*Page CM0333* 551⟩≡ (504 2773)

```
                TC      L               # MIXED CASE ALREADY HANDLED IN MIXNOUN
                TC      SFRUTNOR
                TC      DPTEST
                TC      L               # NO DP
                INCR    NOUNADD         # DP    E+1 INTO NOUNADD FOR MINOR PART.
                TC      L

CHANDSP         CA      NOUNCADR
                MASK    LOW9
                EXTEND
                INDEX   A
                READ    0
                CS      A
                TCF     DSPCOM1

COMPICK         ADRES   NNTYPTEM
                ADRES   NNADTEM

GETCOMP         INDEX   MIXBR           #       NORMAL                          MIXED
                CAF     COMPICK -1      #       ADRES NNTYPTEM                  ADRES NNADTEM
                INDEX   A
                CA      0               #       C(NNTYPTEM)                     C(NNADTEM)
                MASK    HI5             #       GET HI5 OF NNTYPTAB (NORM)      OF NNADTAB (MIX
                TC      Q

DECDSP          TC      GETCOMP
                TC      LEFT5
                MASK    THREE
                TS      DECOUNT         # COMP NUMBER INTO DECOUNT
DSPDCGET        TS      DECTEM          # PICKS UP DATA
                AD      NOUNADD         # DECTEM 1COMP +0, 2COMP +1, 3COMP +2
                INDEX   A
                CS      0
                INDEX   DECTEM
                XCH     XREG            # CAN'T USE BUF SINCE DMP USES IT.
                CCS     DECTEM
                TC      DSPDCGET        # MORE TO GET
DSPDCPUT        CAF     ZERO            # DISPLAYS DATA
                TS      MPAC +1         # DECOUNT 1COMP +0, 2COMP +1, 3COMP +2
                TS      MPAC +2
                INDEX   DECOUNT
                CAF     R1D1
                TS      DSPCOUNT
                INDEX   DECOUNT
                CS      XREG
```

```
                TS      MPAC
                TC      SFCONUM         # 2X (SF CON NUMB) IN A
```

Uses A 80, BUF 142, DECOUNT 140, DECTEM 140, DISPLAYS 59, DSPCOUNT 152, IT 185, L 80, MIXBR 142, MPAC 145, NNADTEM 144, NNTYPTEM 144, NOUNADD 144, NOUNCADR 154, Q 80, TC 169, and XREG 152.

553 ⟨*Page CM0334* 553⟩≡ (504 2773)

```
                TS      SFTEMP1
                EXTEND                  # SWITCH BANKS TO SF CONSTANT TABLE
                DCA     GTSFOUTL        #       READING ROUTINE.
                DXCH    Z               # LOADS SFTEMP1, SFTEMP2
                INDEX   MIXBR
                TC      +0
                TC      DSPSFNOR
                TC      SFRUTMIX
                TC      DECDSP3

DSPSFNOR        TC      SFRUTNOR
                TC      DECDSP3

                EBANK=  DSPCOUNT
GTSFOUTL        2CADR   GTSFOUT

DSPDCEND        TC      BANKCALL        # ALL SFOUT ROUTINES END HERE
                CADR    DSPDECWD
                CCS     DECOUNT
                TC      +2
                TC      ENTEXIT
                TS      DECOUNT
                TC      DSPDCPUT        # MORE TO DISPLAY

DECDSP3         INDEX   A
                CAF     SFOUTABR
                TC      BANKJUMP

SFOUTABR        CADR    PREDSPAL        # ALARM IF DEC DISP WITH OCTAL ONLY NOUN
                CADR    DSPDCEND
                CADR    DEGOUTSF
                CADR    ARTOUTSF
                CADR    DP1OUTSF
                CADR    DP2OUTSF
                CADR    OPDEGOUT
                CADR    DP3OUTSF
                CADR    HMSOUT
                CADR    M/SOUT
                CADR    DP2OUTSF
                CADR    AROUT1SF
                CADR    2INTOUT
                CADR    DPFRACOT
ENDRTOUT        EQUALS

# THE FOLLOWING IS ATYPICAL SF ROUTINE.  IT USES MPAC.  LEAVES RESULTS
```

```
# IN MPAC, MPAC+1.  ENDS WITH TC DSPDCEND
```

Uses A 80, DECOUNT 140, DSPCOUNT 152, EBANK 80, IT 185, MIXBR 142, MPAC 145, SFTEMP1 140, SFTEMP2 140, TC 169, and Z 80.

555 ⟨*Page CM0335* 555⟩≡ (504 2773)

```
                SETLOC  BLANKCON +1

                COUNT   40/PIN
# DEGOUTSF SCALES BY .18 THE LOW 14 BITS OF ANGLE, ADDING .18 FOR
# NUMBERS IN THE NEGATIVE (AGC) RANGE.

DEGOUTSF        CAF     ZERO
                TS      MPAC +2         # SET INDEX FOR FULL SCALE.
                TC      FIXRANGE
                TC      +2              # NO AUGMENT NEEDED (SFTEMP1 AND 2 ARE 0)
                TC      SETAUG          # SET AUGMENTER ACCORDING TO C(MPAC +2)
                TC      DEGCOM

# OPDEGOUT SCALES BY .45 (THE RANGE IS 90 DEGREES) AND ADDS A 20 DEG BIAS.

OPDEGOUT        CCS     MPAC            # RANGE IS 90 DEG
                XCH     MPAC            # IF POS OR POS 0 THEN ADD BIAS AND
                TC      +3              # CORRECT FOR POSSIBLE OVERFLOW
                TC      NEGOPT          # IF NEG NON ZERO
                AD      NEG1            # IF NEG ZERO SUBTRACT 1
                AD      20BIAS
BIASCOM         TS      MPAC            # TEST FOR OVERFLOW
                TC      +3              # NO OVFLOW
                CAF     BIT15           # IF OVFLOW
                ADS     MPAC
                CAF     TWO             # SET MULTIPLIER TO .45
                TC      DEGOUTSF +1

NEGOPT          XCH     MPAC            # NEGATIVE CASE
                AD      20BIAS
                CCS     A
                TC      BIASCOM         # IF POS THEN SUBTRACT 1 BECASUE OF 2SCOM
                TC      CCSHOLE
                AD      ONE             # IF NEG RESTORE SUM
                COM                     # IF NEG 0 LEAVE NEG 0
                TC      BIASCOM

SETAUG          EXTEND                  # LOADS SFTEMP1 AND SFTEMP2 WITH THE
                INDEX   MPAC    +2      # DP AUGMENTER CONSTANT
                DCA     DEGTAB
                DXCH    SFTEMP1
                TC      Q

FIXRANGE        CCS     MPAC            # IF MPAC IS + RETURN TO L+1
```

```
TC      Q               # IF MPAC IS - RETURN TO L+2 AFTER
TC      Q               # MASKING OUT THE SIGN BIT
TCF     +1
CS      BIT15
MASK    MPAC
```

Uses A 80, BIAS 211, COUNT 142, L 80, MPAC 145, Q 80, RANGE 179, SFTEMP1 140, SFTEMP2 140, and TC 169.

557 ⟨*Page CM0336* 557⟩≡ (504 2773)

```
                TS      MPAC
                INDEX   Q
                TC      1

DEGCOM          EXTEND                  # LOADS MULTIPLIER, DOES SHORTMP, AND
                INDEX   MPAC +2         # ADDS AUTMENTER.
                DCA     DEGTAB
                DXCH    MPAC            # ADJUSTED ANGLE IN A
                TC      SHORTMP
                DXCH    SFTEMP1
                DAS     MPAC
                TC      SCOUTEND

DEGTAB          OCT     05605           # HI PART OF    .18
                OCT     03656           # LOW PART OF   .18
                OCT     16314           # HI PART OF    .45
                OCT     31463           # LO PART OF    .45

20BIAS          OCT     16040           # 20 DEG BIAS FOR OPTICS

ARTOUTSF        DXCH    SFTEMP1         # ASSUMES POINT AT LEFT OF DP SFCON
                DXCH    MPAC
                TC      PRSHRTMP        # IF C(A) = -0, SHORTMP FAILS TO GIVE -0.
SCOUTEND        TC      POSTJUMP
                CADR    DSPDCEND

AROUT1SF        DXCH    SFTEMP1         # ASSUMES POINT BETWEEN HI AND LO PARTS OF
                DXCH    MPAC            # DP SFCON.  SHIFTS RESULTS LEFT 14, BY
                TC      PRSHRTMP        # TAKING RESULTS FROM MPAC+1, MPAC+2.
                TC      L14/OUT

DP1OUTSF        TC      DPOUT           # SCALES MPAC, MPAC +1 BY DP SCALE FACTOR
L14/OUT         XCH     MPAC +2         # IN SFTEMP1, SFTEMP2.  THEN SCALE RESULT
                XCH     MPAC +1         # BY B14
                TS      MPAC
                TC      SCOUTEND

DP2OUTSF        TC      DPOUT           # SCALES MPAC, MPAC +1 BY DP SCALE FACTOR
                TC      SCOUTEND

DP3OUTSF        TC      DPOUT           # ASSUMES POINT BETWEEN BITS 7-8 OF HIGH
                CAF     SIX             # LEFT BY 7, ROUNDS MPAC+2 INTO MPAC+1
                TC      TPLEFTN         # SHIFT LEFT 7.
                TC      SCOUTEND
```

Uses `A` 80, `BIAS` 211, `FACTOR` 226, `MPAC` 145, `Q` 80, `SFTEMP1` 140, `SFTEMP2` 140, and `TC` 169.

559 ⟨*Page CM0337* 559⟩≡ (504 2773)

```
MPAC+6          =       MPAC +6         # USE MPAC +6 INSTEAD OF OVFIND

DPOUT           XCH     Q
                TS      MPAC+6
                TC      READLO          # GET FRESH DATA FOR BOTH HI AND LO.
                TC      TPAGREE         # MAKE DP DATA AGREE
                TC      DMP
                ADRES   SFTEMP1
                TC      MPAC+6

# THE FOLLOWING ROUTINE DISPLAYS TWO CONTIGUOUS SP POSITIVE INTEGERS
# AS TWO POSITIVE DECIMAL INTEGERS IN RXD1-RXD2 AND RXD4-RXD5 (RXD3 IS
# BLANKED).  THE INTEGER IN THE LOWER NUMBERED ADDRESS IS DISPLAYED IN
# RXD1-RXD2.

2INTOUT         TC      5BLANK          # TO BLANK RXD3
                TC      +ON             # TURN ON + SIGN
                CA      MPAC
                TC      DSPDECVN        # DISPLAY 1ST INTEGER (LIKE VERB AND NOUN)
                CS      THREE
                INDEX   DECOUNT
                AD      R1D1            # RXD4
                TS      DSPCOUNT
                TC      READLO          # GET 2ND INTEGER
                CA      MPAC +1
                TC      DSPDECVN        # DISPLAY 2ND INTEGER (LIKE VERB AND NOUN)
                TC      POSTJUMP
                CADR    DSPDCEND +2

DPFRACOT        TC      READLO          # DP FRACTION TO MPAC,+1
                TC      SCOUTEND

# READLO PICKS UP FRESHDATA FOR BOTH HI AND LO AND LEAVES IT IN
# MPAC, MPAC+1.  THIS IS NEEDED FOR TIME DISPLAY.  IT ZEROES MPAC+2, BUT
# DOES NOT FORCE TPAGREE.

READLO          XCH     Q
                TS      TEM4
                INDEX   MIXBR
                TC      +0
                TC      RDLONOR
                INDEX   DECOUNT
                CA      IDAD1TEM        # GET IDADDTAB ENTRY FOR COMP K OF NOUN.
                MASK    LOW11           # E SUBK
```

```
                TC      SETEBANK        # SET EB, LEAVE EADRES IN A
READLO1         EXTEND                  # MIXED                          NORMAL
                INDEX   A               # C(ESUBK)                       C(E)
                DCA     0               # C(E SUBK)+1)                   C(E+1)
                DXCH    MPAC
```

Uses A 80, DECOUNT 140, DISPLAYS 59, DSPCOUNT 152, IDAD1TEM 144, IT 185, MIXBR 142, MPAC 145, OVFIND 140, Q 80, SFTEMP1 140, TC 169, and TEM4 142.

561 ⟨*Page CM0338* 561⟩≡ (504 2773)

```
                CAF     ZERO
                TS      MPAC    +2
                TC      TEM4

RDLONOR         CA      NOUNADD         # E
ENDRDLO         TC      READLO1

                BANK    42
                SETLOC  PINBALL3
                BANK

                COUNT   42/PIN

HMSOUT          TC      BANKCALL        # READ FRESH DATA FOR HI AND LO INTO MPAC.
                CADR    READLO          # MPAC+1.
                TC      TPAGREE         # MAKE DP DATA AGREE.
                TC      SEPSECNR        # LEAVE FRACT SEC/60 IN MPAC, MPAC+1.  LEAVE
                                        # WHOLE MIN IN BIT13 OF LOTEMOUT AND ABOVE
                TC      DMP             # USE ONLY FRACT SEC/60 MOD 60
                ADRES   SECON2          # MULT BY .06
                CAF     R3D1            # GIVES CENTI-SEC/10EXP5 MOD 60
                TS      DSPCOUNT
                TC      BANKCALL        # DISPLAY SEC MOD 60
                CADR    DSPDECWD
                TC      SEPMIN          # REMOVE REST OF SECONDS
                CAF     MINCON2         # LEAVE FRACT MIN/60 IN MPAC+1.  LEAVE
                XCH     MPAC            # WHOLE HOURS IN MPAC.
                TS      HITEMOUT        # SAVE WHOLE HOURS.
                CAF     MINCON2 +1
                XCH     MPAC    +1      # USE ONLY FRACT MIN/60 MOD 60
                TC      PRSHRTMP        # IF C(A) = -0, SHORTMP FAILS TO GIVE -0.
                                        # MULT BY .0006
                CAF     R2D1            # GIVE MIN/10EXP5 MOD 60
                TS      DSPCOUNT
                TC      BANKCALL        # DISPLAY MIN MOD 60
                CADR    DSPDECWD
                EXTEND                  # MINUTES, SECONDS HAVE BEEN REMOVED
                DCA     HRCON1
                DXCH    MPAC
                CA      HITEMOUT        # USE WHOLE HOURS
                TC      PRSHRTMP        # IF C(A) = -0, SHORTMP FAILS TO GIVE -0.
                                        # MULT BY .16384
                CAF     R1D1            # GIVES HOURS/10EXP5
                TS      DSPCOUNT
                TC      BANKCALL        # USE REGULAR DSPDECWD WITH ROUND OFF.
```

```
                CADR    DSPDECWD
                TC      ENTEXIT

SECON1          2DEC*   1.666666666 E-4 B12*    # 2EXP12/6000
```

Uses A 80, COUNT 142, DSPCOUNT 152, HITEMOUT 152, LOTEMOUT 152, MPAC 145, NOUNADD 144, PINBALL3 71, SAVE 191, TC 169, and TEM4 142.

563 ⟨*Page CM0339* 563⟩≡ (504 2773)

```
SECON2          OCT     01727           # .06 FOR SECONDS DISPLAY
                OCT     01217
MINCON2         OCT     00011           # .0006 FOR MINUTES DISPLAY
                OCT     32445
MINCON1         OCT     02104           # .06..66 UPPED BY 2EXP-2B
                OCT     10422
HRCON1          2DEC    .16384
                OCT     00000
RNDCON          OCT     00062           # .5 SEC

M/SOUT          TC      BANKCALL        # READ FRESH DATA FOR HI AND LO INTO MPAC.
                CADR    READLO          # MPAC+1.
                TC      TPAGREE         # MAKE DP DATA AGREE
                CCS     MPAC            # IF MAG OF (MPAC, MPAC+1) G/ 59 M 59 S.
                TC      +2              # DISPLAY 59B59, WITH PROPER SIGN.
                TC      M/SNORM         # MPAC = +0.  L/ 59M58.5S
                AD      M/SCON1         # - HI PART OF (59M58.5) +1 FOR CCS
                CCS     A               # MAG OF MPAC - HI PART OF (59M58.5S)
                TC      M/SLIMIT        # G/ 59M58.5S
                TC      M/SNORM         # ORIGINAL MPAC = -0.  L/59M58.5S
                TC      M/SNORM         # L/ 59M58.5S
                CCS     MPAC +1         # MAG OF MPAC = HI PART OF 59M58.5S
                TC      +2
                TC      M/SNORM         # MPAC+1 = +0.  L/ 59M58.5S
                AD      M/SCON2         # - LO PART OF (59M58.5S) +1 FOR CCS
                CCS     A               # MAG OF MPAC+1 - LO PART OF (59M58.5S)
                TC      M/SLIMIT        # G/ 59M58.5S
                TC      M/SNORM         # ORIGINAL MPAC+1 = -0.  L/ 49M58.5S
                TC      M/SNORM         # L/ 59M58.5S
M/SLIMIT        CCS     MPAC            # = 59M58.5S    LIMIT
                CAF     M/SCON3         # MPAC CANNOT BE +/- 0 AT THIS POINT.
                TC      +LIMIT          # FORCE MPAC, MPAC+1 TO +/- 59M58.5S
                CS      M/SCON3
                TS      MPAC            # WILL DISPLAY 59M59S IN DSPDECNR
                CS      M/SCON3 +1
LIMITCOM        TS      MPAC +1
                CAF     NORMADR         # SET RETURN TO M/SNORM+1.
                TC      SEPSECNR +1
+LIMIT          TS      MPAC
                CAF     M/SCON3 +1
                TC      LIMITCOM
M/SNORM         TC      SEPSEC          # LEAVE FRACT SEC/60 IN MPAC,MPAC+1.  LEAVE
                                        # WHOLE MIN IN BIT13 OF LOTEMOUT AND ABOVE
                CAF     HISECON         # USE ONLY FRACT SEC/60 MOD 60
                TC      SHORTMP         # MULT BY .6 + 2EXP-14
```

```
                CS      THREE           # GIVES SEC/100 MOD 60
                ADS     DSPCOUNT        # DSPCOUNT ALREADY SET TO RXD1
                TC      BANKCALL        # DISPLAY SEC MOD 60 IN D4D5.
```

Uses A 80, DSPCOUNT 152, L 80, LOTEMOUT 152, MPAC 145, and TC 169.

565 ⟨*Page CM0340* 565⟩≡ (504 2773)

```
                CADR    DSPDC2NR
                CAF     ZERO
                TS      CODE
                CS      TWO
                INDEX   DECOUNT
                AD      R1D1            # RXD3
                TS      COUNT
                TC      BANKCALL        # BLANK MIDDLE CHAR
                CADR    DSPIN
                TC      SEPMIN          # REMOVE REST OF SECONDS
                XCH     MPAC +1         # LEAVE FRACT MIN/60 IN MPAC+1
                EXTEND                  # USE ONLY FRACT MIN/60 MOD 60
                MP      HIMINCON        # MULT BY .6 + 2EXP-7
                DXCH    MPAC            # GIVES MIN/100 MOD 60
                INDEX   DECOUNT
                CAF     R1D1            # RXD1
                TS      DSPCOUNT
                TC      BANKCALL        # DISPLAY MIN MOD 60 IN D1D2.
                CADR    DSPDC2NR
                TC      POSTJUMP
                CADR    DSPDCEND +2

HISECON         OCT     23147           # .6 + 2EXP-14
HIMINCON        OCT     23346           # .6 + 2EXP-7

M/SCON1         OCT     77753           # - HI PART OF (59M58.5S)
M/SCON2         OCT     41126           # - LO PART OF (59M58.5S)
NORMADR         ADRES   M/SNORM +1
M/SCON3         OCT     00025           # 59M 59.5S
                OCT     37016

SEPSEC          CCS     MPAC    +1      # IF +, ROUND BY ADDING .5 SEC
                TCF     POSEC           # IF -, ROUND BY SUBTRACING .5 SEC
                TCF     POSEC           # FINDS TIME IN MPAC, MPAC+1
                TCF     +1              # ROUNDS OFF BY +/- .5 SEC
                EXTEND                  # LEAVES WHOLE MIN IN BIT13 OF
                DCS     RNDCON  -1      # LOTEMOUT AND ABOVE.
SEPSEC1         DAS     MPAC            # LEAVES FRACT SEC/60 IN MPAC, MPAC+1.
                TCF     SEPSECNR
POSEC           EXTEND
                DCA     RNDCON -1
                TCF     SEPSEC1
SEPSECNR        XCH     Q               # THIS ENTRY AVOIDS ROUNDING BY .5 SEC
                TS      SEPSCRET
                TC      DMP             # MULT BY 2EXP12/6000
```

```
ADRES   SECON1          # GIVES FRACT SEC/60 IN BIT12 OF MPAC+1
EXTEND                  # AND BELOW.
DCA     MPAC            # SAVE MINUTES AND HOURS
DXCH    HITEMOUT
```

Uses CHAR 140, CODE 140, COUNT 142, DECOUNT 140, DSPCOUNT 152, HITEMOUT 152, LOTEMOUT 152, MPAC 145, Q 80, SAVE 191, SEPSCRET 142, and TC 169.

567 ⟨*Page CM0341* 567⟩≡ (504 2773)

```
                TC      TPSL1
                TC      TPSL1           # GIVES FRACT SEC/60 IN MPAC+1, MPAC+2.
                CAF     ZERO
                XCH     MPAC +2         # LEAVE FRACT SEC/60 IN MPAC, MPAC+1.
                XCH     MPAC +1
                XCH     MPAC
                TC      SEPSCRET

SEPMIN          XCH     Q               # FIND WHOLE MINUTES IN BIT13
                TS      SEPMNRET        # OF LOTEMOUT AND ABOVE.
                CA      LOTEMOUT        # REMOVES REST OF SECONDS.
                EXTEND                  # LEAVES FRACT MIN/60 IN MPAC+1.
                MP      BIT3            # LEAVES WHOLE HOURS IN MPAC.
                EXTEND                  # SR 12, THROW AWAY LP.
                MP      BIT13           # SR 2, TAKE FROM LP. = SL 12.
                LXCH    MPAC +1         # THIS FORCES BITS 12-1 TO 0 IF +.
                                        # FORCES BITS 12-1 TO 1 IF -.
                CA      HITEMOUT
                TS      MPAC
                TC      DMP             # MULT BY 1/15
                ADRES   MINCON1         # GIVES FRACT MIN/60 IN MPAC+1.
ENDSPMIN        TC      SEPMNRET        # GIVES WHOLE HOURS IN MPAC.

# THIS IS A SPECIAL PURPOSE VERB FOR DISPLAYING A DOUBLE PRECISION AGC
# WORD AS 10 DECIMAL DIGITS ON THE AGC DISPLAY PANEL.  IT CAN BE USED WITH
# ANY NOUN, EXCEPT MIXED NOUNS.  IT DISPLAYS THE CONTENTS
# OF THE REGISTER NOUNADD IS POINTING TO.  IF USED WITH NOUNS WHICH ARE
# INHERENTLY NOT DP SUCH AS THE CDU COUNTERS THE DISPLAY WILL BE GARBAGE.
# DISPLAY IS IN R1 AND R2 ONLY WITH THE SIGN IN R1.

                SETLOC  ENDRDLO +1

                COUNT   40/PIN

DSPDPDEC        INDEX   MIXBR
                TC      +0
                TC      +2              # NORMAL NOUN
                TC      DSPALARM
                EXTEND
                INDEX   NOUNADD
                DCA     0
                DXCH    MPAC
                CAF     R1D1
                TS      DSPCOUNT
                CAF     ZERO
```

```
                TS      MPAC +2
                TC      TPAGREE
```

Uses A 80, COUNT 142, DISPLAYS 59, DSPCOUNT 152, HITEMOUT 152, IT 185, LOTEMOUT 152, MIXBR 142, MPAC 145, NOUNADD 144, Q 80, R2 188, SEPMNRET 142, SEPSCRET 142, SR 80, and TC 169.

568 ⟨*Page CM0342* 568⟩≡ (504 2773)

```
                TC      DSP2DEC
  ENDDPDEC      TC      ENTEXIT
```

Uses TC 169.

569 ⟨*Page CM0343* 569⟩≡ (504 2773)

```
# LOAD VERBS            IF ALARM CONDITION IS DETECTED DURING EXECUTE,
# CHECK FAIL LIGHT IS TURNED ON AND ENDOFJOB.  IF ALARM CONDITION IS
# DETECTED DURING ENTER OF DATA, CHECK FAIL IS TURNED ON AND IT RECYCLES
# TO EXECUTE OF ORIGINAL LOAD VERB.  RECYCLE CAUSED BY          1) DECIMAL MACHINE
# CADR          2) MIXTURE OF OCTAL/DECIMAL DATA        3) OCTAL DATA INTO DECIMAL
# ONLY NOUN     4) DEC DATA INTO OCT ONLY NOUN          5) DATA TOO LARGE FOR SCALE
# 6) FEWER THAN 3 DATA WORDS LOADED FOR HRS, MIN, SEC NOUN.8  (2)-(6) ALARM
# AND RECYCLE OCCUR AT FINAL ENTER OF SET.      (1) ALARM AND RECYCLE OCCUR AT
# ENTER OF CADR.

                SETLOC  ENDRTOUT

                COUNT   41/PIN

ABCLOAD         CS      TWO
                TC      COMPTEST
                TC      NOUNTEST        # TEST IF NOUN CAN BE LOADED.
                CAF     VBSP1LD
                TC      UPDATVB -1
                TC      REQDATX
                CAF     VBSP2LD
                TC      UPDATVB -1
                TC      REQDATY
                CAF     VBSP3LD
                TC      UPDATVB -1
                TC      REQDATZ

PUTXYZ          CS      SIX             # TEST THAT THE 3 DATA WORDS LOADED ARE
                TC      ALLDC/OC        # ALL DEC OR ALL OCT.
                EXTEND
                DCA     LODNNLOC        # SWITCH BANKS TO NOUN TABLE READING
                DXCH    Z               # ROUTINE.
                CAF     ZERO            # X COMP
                TC      PUTCOM
                INDEX   NOUNADD
                TS      0
                CAF     ONE             # Y COMP
                TC      PUTCOM
                INDEX   NOUNADD
                TS      1
                CAF     TWO             # Z COMP
                TC      PUTCOM
                INDEX   NOUNADD
                TS      2
```

```
CS      SEVEN           # IF NOUN 7 HAS JUST BEEN LOADED, SET
AD      NOUNREG         # FLAG BITS AS SPECIFIED.
EXTEND
BZF     +2
```

Uses COUNT 142, IT 185, NOUNADD 144, NOUNREG 152, TC 169, and Z 80.

571 ⟨*Page CM0344* 571⟩≡ (504 2773)

```
                TC      LOADLV
                CA      XREG            # ECADR OF ERASABLE CELL
                TC      SETNCADR +1     # SET EBANK, NOUNADD
                CA      ZREG            # ZERO TO RESET BITS. NON-ZERO TO SET BITS
                INHINT
                EXTEND
                BZF     BITSOFF
                INDEX   NOUNADD
                CS      0
                MASK    YREG            # BITS TO BE PROCESSED
                INDEX   NOUNADD
                ADS     0               # SET BITS.
                TC      BITSOFF1

BITSOFF         CS      YREG            # BITS TO BE PROCESSED
                INDEX   NOUNADD
                MASK    0
                INDEX   NOUNADD
                TS      0               # RESET BITS
BITSOFF1        RELINT
                TC      LOADLV

ABLOAD          CS      ONE
                TC      COMPTEST
                TC      NOUNTEST        # TEST IF NOUN CAN BE LOADED
                CAF     VBSP1LD
                TC      UPDATVB -1
                TC      REQDATX
                CAF     VBSP2LD
                TC      UPDATVB -1
                TC      REQDATY
PUTXY           CS      FIVE            # TEST THAT THE 2 DATA WORDS LOADED ARE
                TC      ALLDC/OC        # ALL DEC OR ALL OCT.
                EXTEND
                DCA     LODNNLOC        # SWITCH BANKS TO NOUN TABLE READING
                DXCH    Z               # ROUTINE.
                CAF     ZERO            # X COMP
                TC      PUTCOM
                INDEX   NOUNADD
                TS      0
                CAF     ONE             # Y COMP
                TC      PUTCOM
                INDEX   NOUNADD
                TS      1
                TC      LOADLV
```

```
ALOAD           TC      REQDATX
                EXTEND
                DCA     LODNNLOC        # SWITCH BANKS TO NOUN TABLE READING
                DXCH    Z               # ROUTINE.
                CAF     ZERO            # X COMP
```

Uses EBANK 80, NOUNADD 144, TC 169, XREG 152, YREG 152, Z 80, and ZREG 152.

573 ⟨*Page CM0345* 573⟩≡ (504 2773)

```
                TC      PUTCOM
                INDEX   NOUNADD
                TS      0
                TC      LOADLV

BLOAD           CS      ONE
                TC      COMPTEST
                CAF     BIT15           # SET CLPASS FOR PASS0 ONLY
                TS      CLPASS
                TC      REQDATY
                EXTEND
                DCA     LODNNLOC        # SWITCH BANKS TO NOUN TABLE READING
                DXCH    Z               # ROUTINE.
                CAF     ONE
                TC      PUTCOM
                INDEX   NOUNADD
                TS      1
                TC      LOADLV

CLOAD           CS      TWO
                TC      COMPTEST
                CAF     BIT15           # SET CLPASS FOR PASS0 ONLY
                TS      CLPASS
                TC      REQDATZ
                EXTEND
                DCA     LODNNLOC        # SWITCH BANKS TO NOUN TABLE READING
                DXCH    Z               # ROUTINE.
                CAF     TWO
                TC      PUTCOM
                INDEX   NOUNADD
                TS      2
                TC      LOADLV

LOADLV          CAF     ZERO
                TS      DECBRNCH
                CS      ZERO
                TS      LOADSTAT
                TC      RELDSP          # RELEASE FOR PRIORITY DISPLAY PROBLEM.
                CS      VD1             # TO BLOCK NUMERICAL CHARACTERS AND
                TS      DSPCOUNT        # CLEARS AFTER A COMPLETED LOAD
                TC      POSTJUMP        # AFTER COMPLETED LOAD, GO TO RECALTST
                CADR    RECALTST        # TO SEE IF THERE IS RECALL FROM ENDIDLE.

VBSP1LD         DEC     21              # VB21 = ALOAD
VBSP2LD         DEC     22              # VB22 = BLOAD
```

```
VBSP3LD         DEC     23              # VB23 = CLOAD

ALLDC/OC        TS      DECOUNT         # TESTS THAT DATA WORDS LOADED ARE EITHER
                CS      DECBRNCH        # ALL DEC OR ALL OCT.  ALARMS IF NOT.
```

Uses A 80, CLPASS 154, DECBRNCH 152, DECOUNT 140, DSPCOUNT 152, LOADSTAT 154, NOUNADD 144, PRIORITY 145, TC 169, and Z 80.

575 ⟨*Page CM0346* 575⟩≡ (504 2773)

```
                TS      SR
                CS      SR
                CS      SR              # SHIFTED RIGHT 2
                CCS     A               # DEC COMP BITS IN LOW 3
                TCF     +2              # SOME ONES IN LOW 3
                TC      Q               # ALL ZEROS.  ALL OCTAL.  OK
                AD      DECOUNT         # DEC COMP = 7 FOR 3COMP, =6 FOR 2COMP
                EXTEND                  # (BUT IT HAS BEEN DECREMENTED BY CCS)
                BZF     +2              # MUST MATCH 6 FOR 3COMP, 5 FOR 2COMP.
                TC      ALMCYCLE        # ALARM AND RECYCLE.
GOQ             TC      Q               # ALL REQUIRED ARE DEC.  OK

SFRUTNOR        XCH     Q               # GETS SF ROUTINE NUMBER FOR NORMAL CASE
                TS      EXITEM          # CAN'T USE L FOR RETURN.  TSTFORDP USES L.
                CAF     MID5
                MASK    NNTYPTEM
                TC      RIGHT5
                TC      EXITEM          # SF ROUTINE NUMBER IN A

SFRUTMIX        XCH     Q               # GETS SF ROUTINE NUMBER FOR MIXED CASE
                TS      EXITEM
                INDEX   DECOUNT
                CAF     DISPLACE        # PUT TC GOQ, TC RIGHT5, OR TC LEFT5 IN L
                TS      L
                INDEX   DECOUNT
                CAF     LOW5            # LOW5, MID5, OR HI5 IN A
                MASK    RUTMXTEM        # GET HI5, MID5, OR LOW5 OF RUTMXTAB ENTRY
                INDEX   L
                TC      0

# DO TC GOQ(DECOUNT=0), DO TC RIGHT5(DECOUNT=1), DO TC LEFT5(DECOUNT=2).

SFRET1          TC      EXITEM          # SF ROUTINE NUMBER IN A

SFCONUM         XCH     Q               # GETS 2X(SF CONSTANT NUMBER)
                TS      EXITEM
                INDEX   MIXBR
                TC      +0
                TC      CONUMNOR        # NORMAL NOUN
                INDEX   DECOUNT         # MIXED NOUN
                CAF     DISPLACE
                TS      L               # PUT TC GOQ, TC RIGHT5, OR TC LEFT5 IN L
                INDEX   DECOUNT
                CAF     LOW5
                MASK    NNTYPTEM
```

```
                INDEX   L
                TC      0

  # DO TC GOQ(DECOUNT=0), DO TC RIGHT5(DECOUNT=1), DO TC LEFT5(DECOUNT=2).

  SFRET         DOUBLE                  # 2X(SF CONSTANT NUMBER) IN A
                TC      EXITEM
```

Uses A 80, DECOUNT 140, EXITEM 140, IT 185, L 80, MIXBR 142, NNTYPTEM 144, Q 80, RUTMXTEM 144, SR 80, and TC 169.

577 ⟨*Page CM0347* 577⟩≡ (504 2773)

```
DISPLACE        TC      GOQ
                TC      RIGHT5
                TC      LEFT5

CONUMNOR        CAF     LOW5            # NORMAL NOUN ALWAYS GETS LOW 5 OF
                MASK    NNTYPTEM        # NNTYPTAB FOR SF CONUM.
                DOUBLE
                TC      EXITEM          # 2X(SF CONSTANT NUMBER) IN A

PUTCOM          TS      DECOUNT
                XCH     Q
                TS      DECRET
                CAF     ZERO
                TS      MPAC+6
                INDEX   DECOUNT
                XCH     XREGLP
                TS      MPAC +1
                INDEX   DECOUNT
                XCH     XREG
                TS      MPAC
                INDEX   MIXBR
                TC      +0
                TC      PUTNORM         # NORMAL NOUN

# IF MIXNOUN, PLACE ADDRESS FOR COMPONENT K INTO NOUNADD, SET EBANK BITS.

                INDEX   DECOUNT         # GET IDADDTAB ENTRY FOR COMPONENT K
                CA      IDAD1TEM        #       OF NOUN.
                MASK    LOW11           # (ECADR)SUBK FOR CURRENT COMP OF NOUN
                TC      SETNCADR        # ECADR INTO NOUNCADR.  SETS EB, NOUNADD.
                EXTEND                  # C(NOUNADD) IN A UPON RETURN
                SU      DECOUNT         # PLACE (ESUBK)-K INTO NOUNADD
                TS      NOUNADD
                CCS     DECBRNCH
                TC      PUTDECSF        # + DEC
                TC      DCTSTCYC        # +0 OCTAL
                TC      SFRUTMIX        # TEST IF DEC ONLY BIT = 1.  IF SO,
                TC      DPTEST          # ALARM AND RECYCLE.  IF NOT, CONTINUE.
                TC      PUTCOM2         # NO DP
                                        # TEST FOR DP SCALE FOR OCT LOAD.  IF SO,
                                        # +0 INTO MAJOR PART.  SET NOUNADD FOR
                                        # LOADING OCTAL WORD INTO MINOR PART.
PUTDPCOM        INCR    NOUNADD         # DP (ESUBK)-K+1 OR E+1
                CA      NOUNADD         # NOUNADD NOW SET FOR MINOR PART
```

```
                ADS     DECOUNT         # (ESUBK)+1 OR E+1 INTO DECOUNT
                CAF     ZERO            # NOUNADD SET FOR MINOR PART
                INDEX   DECOUNT
                TS      0       -1      # ZERO MAJOR PART(ESUBK OR E)
                TC      PUTCOM2

PUTNORM         TC      SETNADD         # ECADR FROM NOUNCADR.  SETS EB, NOUNADD.
```

Uses A 80, DECBRNCH 152, DECOUNT 140, DECRET 140, EBANK 80, EXITEM 140, IDAD1TEM 144, MIXBR 142, MPAC 145, NNTYPTEM 144, NOUNADD 144, NOUNCADR 154, Q 80, TC 169, XREG 152, and XREGLP 152.

579 ⟨*Page CM0348* 579⟩≡ (504 2773)

```
                CCS     DECBRNCH
                TC      PUTDECSF        # + DEC
                TC      DCTSTCYC        # +0 OCTAL
                TC      SFRUTNOR        # TEST IF DEC ONLY BIT (garbled).  IF SO,
                TC      DPTEST          # ALARM AND RECYCLE.  IF NOT, CONTINUE.
                TC      PUTCOM2 -4      # NO DP
                CAF     ZERO            # DP
                TS      DECOUNT
                TC      PUTDPCOM

                CA      NNADTEM
                AD      ONE             # IF NNADTEM = -1, CHANNEL TO BE SPECIFIED
                EXTEND
                BZF     CHANLOAD
PUTCOM2         XCH     MPAC
                TC      DECRET

                EBANK=  DSPCOUNT
GTSFINLC        2CADR   GTSFIN

CHANLOAD        CS      SEVEN           # DON'T LOAD CHAN 7.  (IT'S SUPERBANK).
                AD      NOUNCADR
                EXTEND
                BZF     LOADLV
                CA      NOUNCADR
                MASK    LOW9
                XCH     MPAC
                EXTEND
                INDEX   MPAC
                WRITE   0
                TC      LOADLV

# PUTDECSF FINDS MIXBR AND DECOUNT STILL SET FROM PUTCOM.

PUTDECSF        TC      SFCONUM         # 2X(SF CON NUMB) IN A
                TS      SFTEMP1
                EXTEND                  # SWITCH BANKS TO SF CONSTANT TABLE
                DCA     GTSFINLC        # READING ROUTINE.
                DXCH    Z               # LOADS SFTEMP1, SFTEMP2.
                INDEX   MIXBR
                TC      +0
                TC      PUTSFNOR
                TC      SFRUTMIX
                TC      PUTDCSF2
PUTSFNOR        TC      SFRUTNOR
```

PUTDCSF2 INDEX A

Uses A 80, CHAN 191, DECBRNCH 152, DECOUNT 140, DECRET 140, DSPCOUNT 152, EBANK 80, MIXBR 142, MPAC 145, NNADTEM 144, NOUNCADR 154, SFTEMP1 140, SFTEMP2 140, TC 169, and Z 80.

581 ⟨*Page CM0349* 581⟩≡ (504 2773)

```
                CAF     SFINTABR
                TC      BANKJUMP        # SWITCH BANKS FOR EXPANSION ROOM
SFINTABR        CADR    GOALMCYC        # ALARM AND RECYCLE IF DEC LOAD
                                        # WITH OCTAL ONLY NOUN.
                CADR    BINROUND
                CADR    DEGINSF
                CADR    ARTHINSF
                CADR    DPINSF
                CADR    DPINSF2
                CADR    OPTDEGIN
                CADR    DPINSF          # SAME AS ARITHDP1
                CADR    HMSIN
                CADR    DSPALARM        # MIN/SEC CAN'T BE LOADED.
                CADR    DPINSF4
                CADR    ARTIN1SF
                CADR    DSPALARM        # 2INTOUT CAN'T BE LOADED.
                CADR    DPFRACIN
ENDRUTIN        EQUALS

# SCALE FACTORS FOR THOSE ROUTINES NEEDING THEM ARE AVAILABLE IN SFTEMP1.
# ALL SFIN ROUTINES USE MPAC MPAC+1.  LEAVE RESULT IN A.  END WITH TC DECRET.

                SETLOC  ENDDPDEC +1

                COUNT   40/PIN

# DEGINSF APPLIES 1000/180 * 5.55555(10) = 5.43434(8)

DEGINSF         TC      DMP             # SF ROUTINE FOR DEC DEGREES
                ADRES   DEGCON1         # MULT BY 5.5 5(10)X2EXP-3
                CCS     MPAC +1         # THIS ROUNDS OFF MPAC+1 BEFORE SHIFT
                CAF     BIT11           # LEFT 3, AND CAUSES 360.00 TO OF/UF
                TC      +2              # WHEN SHIFTED LEFT AND ALARM.
                CS      BIT11
                AD      MPAC +1
                TC      2ROUND +2
                TC      TPSL1           # LEFT 1
DEGINSF2        TC      TPSL1           # LEFT 2
                TC      TESTOFUF
                TC      TPSL1           # RETURNS IF NO OF/UF (LEFT3)
                CCS     MPAC
                TC      SIGNFIX         # IF +, GO TO SIGNFIX
                TC      SIGNFIX         # IF +0, GO TO SIGNFIX
                COM                     # IF -, USE -MAGNITUDE +1
                TS      MPAC            # IF -0, USE +0
```

```
SIGNFIX         CCS     MPAC+6
                TC      SGNTO1          # IF OVERFLOW
                TC      ENDSCALE        # NO OVERFLOW/UNDERFLOW
```

Uses A 80, COUNT 142, DECRET 140, MPAC 145, SFTEMP1 140, and TC 169.

583 ⟨*Page CM0350* 583⟩≡ (504 2773)

```
                CCS     MPAC            # IF UF FORCE SIGN TO 0 EXCEPT -180
                TC      CCSHOLE
                TC      NEG180
                TC      +1
                XCH     MPAC
                MASK    POSMAX
                TS      MPAC
ENDSCALE        TC      POSTJUMP
                CADR    PUTCOM2

NEG180          CS      POSMAX
                TC      ENDSCALE -1

SGNTO1          CS      MPAC            # IF OF FORCE SIGN TO 1
                MASK    POSMAX
                CS      A
                TC      ENDSCALE -1

DEGCON1         2DEC    5.555555555 B-3

DEGCON2         2DEC    2.222222222 B-2

NEG.2           OCT     -06250          # = .197753906  I.E., THE BIAS SCALED

ARTHINSF        TC      DMP             # SCALES MPAC, +1 BY SFTEMP1, SFTEMP2.
                ADRES   SFTEMP1         # ASSUMES POINT BETWEEN HI AND LO PARTS
                XCH     MPAC +2         # OF SFCON.  SHIFTS RESULTS LEFT BY 14.
                XCH     MPAC +1         # (BY TAKING RESULTS FROM MPAC+1, MPAC+2)
                XCH     MPAC
                EXTEND
                BZF     BINROUND
                TC      ALMCYCLE        # TOO LARGE A LOAD.  ALARM AND RECYCLE.
BINROUND        TC      2ROUND
                TC      TESTOFUF
                TC      ENDSCALE        # RETURNS IF NO OF/UF

ARTIN1SF        TC      DMP             # SCALES MPAC, +1 BY SFTEMP1, SFTEMP2.
                ADRES   SFTEMP1         # ROUNDS MPAC+1 INTO MPAC.
                TC      BINROUND

OPTDEGIN        CCS     MPAC            # OPTICS SCALING ROUTINE
                TC      +4
                TC      +3
                TC      ALMCYCLE        # REJECT -- INPUT.  ALARM AND RECYCLE.
                TC      ALMCYCLE        # REJECT -- INPUT.  ALARM AND RECYCLE.
```

```
OPDEGIN2        CAF     NEG.2           # RANGE IS 90 DEG
                ADS     MPAC            # SUBTRACT BIAS
```

Uses A 80, BIAS 211, I 206, MPAC 145, RANGE 179, SFTEMP1 140, SFTEMP2 140, and TC 169.

585 ⟨*Page CM0351* 585⟩≡ (504 2773)

```
                TC      DMP             # MULT BY 100 / 45 B-2
                ADRES   DEGCON2
                CAF     BIT12           # ROUND AS IN DEGINSF
                AD      MPAC    +1
                TC      2ROUND  +2
                TC      DEGINSF2

DPINSF          TC      DMP             # SCALES MPAC, MPAC +1 BY SFTEMP1,
                ADRES   SFTEMP1         # SFTEMP.  STORES LOW PART OF RESULT
                XCH     MPAC +2         # IN (E SUBK) +1 OR E+1
                DOUBLE
                TS      MPAC +2
                CAF     ZERO
                AD      MPAC +1
                TC      2ROUND +2
                TC      TESTOFUF
DPFRACIN        INDEX   MIXBR           # RETURNS IF NO OF/UF
                TC      +0
                TC      DPINORM
                CA      DECOUNT         # MIXED NOUN
DPINCOM         AD      NOUNADD         #       MIXED           NORMAL
                TS      Q               #       E SUBK          E
                XCH     MPAC +1
                INDEX   Q
                TS      1               # PLACE LOW PART IN
                TC      ENDSCALE        #       (E SUBK) +1     MIXED

DPINORM         CAF     ZERO            #       E +1            NORMAL
                TC      DPINCOM

DPINSF2         TC      DMP             # ASSUMES POINT BETWEEN BITS 7-8 OF HIGH
                ADRES   SFTEMP1         # PART OF SF CONST.  DPINSF2 SHIFTS RESULTS
                CAF     SIX             # LEFT BY 7, ROUNDS MPAC+2 INTO MPAC+1
                TC      TPLEFTN         # SHIFT LEFT 7.
                TC      DPINSF +2

DPINSF4         TC      DMP             # ASSUMES POINT BETWEEN BITS 11-12 OF HIGH
                ADRES   SFTEMP1         # PART OF SF CONST.  DPINSF2 SHIFTS RESULTS
                CAF     TWO             # LEFT BY 3, ROUNDS MPAC+2 INTO MPAC+1.
                TC      TPLEFTN         # SHIFT LEFT 3.
                TC      DPINSF +2

TPLEFTN         XCH     Q               # SHIFTS MPAC, +1, +2 LEFT N.  SETS OVFIND
                TS      SFTEMP2         # TO +1 FOR OF, -1 FOR UF.
                XCH     Q               # CALL WITH N-1 IN A.
```

```
LEFTNCOM        TS      SFTEMP1         #       LOOP TIME .37 MSEC.
                TC      TPSL1
                CCS     SFTEMP1
```

Uses A 80, DECOUNT 140, MIXBR 142, MPAC 145, N 206, NOUNADD 144, OVFIND 140, Q 80, SFTEMP1 140, SFTEMP2 140, and TC 169.

587 ⟨*Page CM0352* 587⟩≡ (504 2773)

```
                TC      LEFTNCOM
                TC      SFTEMP2

2ROUND          XCH     MPAC     +1
                DOUBLE
                TS      MPAC    +1
                TC      Q               # IF MPAC+1 DOES NOT OF/UF
                AD      MPAC
                TS      MPAC
                TC      Q               # IF MPAC DOES NOT OF/UF
                TS      MPAC+6
2RNDEND         TC      Q

TESTOFUF        CCS     MPAC+6          # RETURNS IF NO OF/UF
                TC      ALMCYCLE        # OF    ALARM AND RECYCLE.
                TC      Q
                TC      ALMCYCLE        # UF    ALARM AND RECYCLE.

                SETLOC  ENDSPMIN +1

                COUNT   42/PIN

HMSIN           TC      ALL3DEC         # IF ALL 3 WORDS WERE NOT LOADED, ALARM.
                TC      DMP             # XREG, XREGLP (=HOURS) WERE ALREADY PUT
                ADRES   WHOLECON        # INTO MPAC, MPAC+1.
                TC      RND/TST         # ROUND OFF TO WHOLE HRS IN MPAC+1.
                CAF     ZERO            # ALARM IF MPAC NON ZERO (G/ 16383).
                TS      MPAC    +2
                CAF     HRCON
                TS      MPAC
                CAF     HRCON   +1
                XCH     MPAC    +1
                TC      SHORTMP
                TC      MPACTST         # ALARM IF MPAC NON ZERO (G/ 745)
                DXCH    MPAC    +1      # STORE HOURS CONTRIBUTION
                DXCH    HITEMIN
                CA      YREG            # PUT YREG, YREGLP INTO MPAC, +1.
                LXCH    YREGLP
                DXCH    MPAC
                TC      DMP
                ADRES   WHOLECON
                TC      RND/TST         # ROUND OFF TO WHOLE MIN IN MPAC+1
                CS      59MIN           # ALARM IF MPAC NON ZERO (G/16383)
                TC      SIZETST         # ALARM IF MPAC+1 G/ 59MIN
                XCH     MPAC    +1
```

```
                EXTEND
                MP      MINCON          # LEAVES MINUTES CONTRIBUTION IN A,L
```

Uses A 80, COUNT 142, HITEMIN 140, L 80, MPAC 145, Q 80, SFTEMP2 140, TC 169, XREG 152, XREGLP 152, YREG 152, and YREGLP 152.

589 ⟨*Page CM0353* 589⟩≡ (504 2773)

```
                DAS     HITEMIN         # ADD IN MINUTES CONTRIBUTION
                EXTEND                  # IF THIS DAS OVERFLOWS, G/ 745 HR,39MIN
                BZF     +2
                TC      ALMCYCLE
                CA      ZREG            # PUT ZREG, ZREGLP INTO MPAC +1.
                LXCH    ZREGLP
                DXCH    MPAC
                TC      DMP
                ADRES   WHOLECON
                TC      RND/TST         # ROUND OFF TO WHOLE CENTI-SEC IN MPAC+1
                CS      59.99SEC        # ALARM IF MPAC NON ZERO (G/163.83 SEC)
                TC      SIZETST         # ALARM IF MPAC+1 G/59.99 SEC
                DXCH    HITEMIN         # ADD IN SECONDS CONTRIBUTION
                DAS     MPAC            # IF THIS DAS OVERFLOWS,
                EXTEND                  # G/ 745 HR, 39 MIN, 14.59 SEC.
                BZF     +2
                TC      ALMCYCLE        # ALARM AND RECYCLE
                CAF     ZERO
                TS      MPAC +2
                TC      TPAGREE
                DXCH    MPAC
                INDEX   NOUNADD
                DXCH    0
                TC      POSTJUMP
                CADR    LOADLV

WHOLECON        OCT     00006           # (10EXP5/2EXP14)2EXP14
                OCT     03240
HRCON           OCT     00025           # 1 HOUR IN CENTI-SEC
                OCT     37100
MINCON          OCT     13560           # 1 MINUTE IN CENTI-SEC
59MIN           OCT     00073           # 59 AS WHOLE
59.99SEC        OCT     13557           # 5999 SENTI-SEC

RND/TST         XCH     MPAC +2         # ROUNDS MPAC+2 INTO MPAC+1.
                DOUBLE                  # ALARMS IF MPAC NOT 0
                TS      MPAC +2
                CAF     ZERO
                AD      MPAC +1
                TS      MPAC +1
                CAF     ZERO
                AD      MPAC            # CAN'T OVFLOW
                XCH     MPAC
MPACTST         CCS     MPAC            # ALARM IF MPAC NON ZERO
                TC      ALMCYCLE        # ALARM AND RECYCLE
```

```
                TC      Q
                TC      ALMCYCLE        # ALARM AND RECYCLE
                TC      Q
```

Uses HITEMIN 140, MPAC 145, NOUNADD 144, Q 80, TC 169, ZREG 152, and ZREGLP 152.

590 ⟨*Page CM0354* 590⟩≡ (504 2773)

```
SIZETST         TS      MPAC +2         # CALLED WITH - CON IN A
                CCS     MPAC +1         # GET MAG OF MPAC+1
                AD      ONE
                TCF     +2
                AD      ONE
                AD      MPAC +2
                EXTEND                  # MAG OF MPAC+1 - CON
                BZMF    +2
                TC      ALMCYCLE        # MAG OF MPAC+1 G/ CON.  ALARM AND RECYCLE.
                TC      Q               # MAG OF MPAC+1 L/= CON

# ALL3DEC TESTS THAT ALL 3 WORDS ARE LOADED IN DEC (FOR HMSIN).
# ALARM IF NOT.  (TEST THAT BITS 3,4,5 OF DECBRNCH ARE ALL = 1).

ALL3DEC         CS      OCT34BAR        # GET BITS 3,4,5 IN A
                MASK    DECBRNCH        # GET BITS 3,4,5 OF DECBRNCH IN A
                AD      OCT34BAR        # BITS 3,4,5 OF DECBRNCH MUST ALL = 1
                CCS     A
                TC      FORCEV25
OCT34BAR        OCT     77743
                TC      FORCEV25
                TC      Q

FORCEV25        CS      OCT31           # FORCE VERB 25 TO BE EXECUTED BY RECYCLE
                TS      VERBSAVE        # IN CASE OPERATOR EXECUTED A LOWER LOAD
                TC      ALMCYCLE        # VERB.  ALARM AND RECYCLE.
ENDHMSS         EQUALS
```

Uses A 80, DECBRNCH 152, L 80, MPAC 145, Q 80, TC 169, and VERBSAVE 154.

591 ⟨*Page CM0355* 591⟩≡ (504 2773)

```
# MONITOR ALLOWS OTHER KEYBOARD ACTIVITY.  IT IS ENDED BY VERB TERMINATE,
# VERB PROCEED WITHOUT DATA, VERB RESEQUENCE,
# ANOTHER MONITOR, OR ANY NVSUB CALL THAT PASSES THE DSPLOCK (PROVIDED
# THAT THE OPERATOR HAS SOMEHOW ALLOWED THE ENDING OF A MONITOR WHICH
# HE HAS INITIATED THROUGH THE KEYBOARD).
#
# MONITOR ACTION IS SUSPENDED, BUT NOT ENDED, BY ANY KEYBOARD ACTION.
# EXCEPT ERROR LIGHT RESET.  IT BEGINS AGAIN WHEN KEY RELEASE IS PERFORMED.
# MONITOR SAVES THE NOUN AND APPROPRIATE DISPLAY VERB IN MONSAVE.  IT SAVES
# NOUNCADR IN MONSAVE1, IF NOUN = MACHINE CADR TO BE SPECIFIED.  BIT 15 OF
# MONSAVE1 IS THE KILL MONITOR SIGNAL (KILLER BIT).  BIT 14 OF MONSAVE1
# INDICATES THE CURRENT MONITOR WAS EXTERNALLY INITIATED (EXTERNAL
# MONITOR BIT).  IT IS TURNED OFF BY RELDSP AND KILMONON.
#
# MONSAVE INDICATES IF MONITOR IS ON (+=ON, +0=OFF)
# IF MONSAVE IS +, MONITOR ENTERS NO REQUEST, BUT TURNS KILLER BIT OFF.
# IF MONSAVE IS +0, MONITOR ENTERS REQUEST AND TURNS KILLER BIT OFF.
#
# NVSUB (IF EXTERNAL MONITOR BIT IS OFF), VB=PROCEED WITHOUT DATA,
# VB=RESEQUENCE, AND VB=TERMINATE TURN KILL MONITOR BIT ON.
#
# IF KILLER BIT IS ON, MONREQ ENTERS NO FURTHER REQUESTS, ZEROS MONSAVE
# AND MONSAVE1 (TURNING OFF KILLER BIT AND EXTERNAL MONITOR BIT).
#
# MONITOR DOESN'T TEST FOR MATBS SINCE NVSUB CAN HANDLE INTERNAL MATBS NOW.

                SETLOC  ENDRUTIN

                COUNT   41/PIN

MONITOR         CS      BIT15/14
                MASK    NOUNCADR
MONIT1          TS      MPAC +1         # TEMP STORAGE
                CS      ENTEXIT
                AD      ENDINST
                CCS     A
                TC      MONIT2
BIT15/14        OCT     60000
                TC      MONIT2
                CAF     BIT14           # EXTERNALLY INITIATED MONITOR.
                ADS     MPAC +1         # SET BIT 14 FOR MONSAVE1.
                CAF     ZERO
                TS      MONSAVE2        # ZERO NVMONOPT OPTIONS
MONIT2          CAF     LOW7
                MASK    VERBREG
```

```
                TC      LEFT5
                TS      CYL
                CS      CYL
                XCH     CYL
                AD      NOUNREG
                TS      MPAC            # TEMP STORAGE
```

Uses A 80, COUNT 142, CYL 80, DSPLOCK 154, IT 185, MONSAVE 154, MONSAVE1 154, MONSAVE2 154, MPAC 145, NOUNCADR 154, NOUNREG 152, TC 169, TEMP 191, and VERBREG 152.

593 ⟨*Page CM0356* 593⟩≡ (504 2773)

```
                CAF     ZERO
                TS      DSPLOCK         # +0 INTO DSPLOCK SO MONITOR CAN RUN.
                CCS     CADRSTOR        # TURN OFF KR LITE IF CADRSTOR AND DSPLIST
                TC      +2              # ARE BOTH EMPTY.  (LITE COMES ON IF NEW
                TC      RELDSP1         # MONITOR IS KEYED IN OVER OLD MONITOR.)
                INHINT
                CCS     MONSAVE
                TC      +5              # IF MONSAVE WAS +, NO REQUEST
                CAF     ONE             # IF MONSAVE WAS 0, REQUEST MONREQ
                TC      WAITLIST
                EBANK=  DSPCOUNT
                2CADR   MONREQ

                DXCH    MPAC            # PLACE MONITOR VERB AND NOUN INTO MONSAVE
                DXCH    MONSAVE         # ZERO THE KILL MONITOR BIT
                RELINT                  # SET UP EXTERNAL MONITOR BIT
                TC      ENTRET

MONREQ          TC      LODSAMPT        # CALLED BY WAITLIST
                CCS     MONSAVE1        # TIME IS SNATCHED N RUPT FOR NOUN 65
                TC      +4              # IF KILLER BIT = 0, ENTER REQUESTS
                TC      +3              # IF KILLER BIT = 0, ENTER REQUESTS
                TC      KILLMON         # IF KILLER BIT = 1, NO REQUESTS.
                TC      KILLMON         # IF KILLER BIT = 1, NO REQUESTS.
                CAF     MONDEL
                TC      WAITLIST        # ENTER WAITLIST REQUEST FOR MONREQ
                EBANK=  DSPCOUNT
                2CADR   MONREQ

                CAF     CHRPRIO
                TC      NOVAC           # ENTER EXEC REQUEST FOR MONDO
                EBANK=  DSPCOUNT
                2CADR   MONDO

                TC      TASKOVER

KILLMON         CAF     ZERO            # ZERO MONSAVE AND TURN KILLER BIT OFF
                TS      MONSAVE
                TS      MONSAVE1        # TURN OFF KILL MONITOR BIT.
                TC      TASKOVER        # TURN OFF EXTERNAL MONITOR BIT.
MONDEL          OCT     144             # FOR 1 SEC MONITOR INTERVALS.

MONDO           CCS     MONSAVE1        # CALLED BY EXEC
                TC      +4              # IF KILLER BIT = 0, CONTINUE
                TC      +3              # IF KILLER BIT = 0, CONTINUE
```

```
TC      ENDOFJOB        # IN CASE TERMINATE CAME SINCE LAST MONREQ
TC      ENDOFJOB        # IN CASE TERMINATE CAME SINCE LAST MONREQ
CCS     DSPLOCK
```

Uses CADRSTOR 154, DSPCOUNT 152, DSPLIST 154, DSPLOCK 154, EBANK 80, ENTRET 142, MONSAVE 154, MONSAVE1 154, MPAC 145, N 206, RUN 191, and TC 169.

595 ⟨*Page CM0357* 595⟩≡ (504 2773)

```
                TC      MONBUSY         # NVSUB IS BUSY
                CAF     LOW7
                MASK    MONSAVE
                TC      UPDATNN -1      # PLACE NOUN INTO NOUNREG AND DISPLAY IT
                CAF     MID7
                MASK    MONSAVE         # CHANGE MONITOR VERB TO DISPLAY VERB
                AD      MONREF          # -DEC10, STARTING IN BIT8
                TS      EDOP            # RIGHT 7
                CA      EDOP
                TS      VERBREG
                CAF     MONBACK         # SET RETURN TO PASTEVB AFTER DATA DISPLAY
                TS      ENTRET
                CS      BIT15/14
                MASK    MONSAVE1        # PUT ECADR INTO MPAC +2.  INTMCTBS WILL
                TS      MPAC +2         # DISPLAY IT AND SET NOUNCADR, NOUNADD,
ENDMONDO        TC      TESTNN          # EBANK.

                BLOCK   2

                SETLOC  FFTAG8
                BANK

                COUNT   02/PIN

PASTEVB         CAF     MID7
                MASK    MONSAVE2        # NVMONOPT PASTE OPTION
                EXTEND
                BZF     +2
                TC      PASTEOPT        # PASTE PLEASE VERB FOR NVMONOPT
                CA      MONSAVE         # PASTE MONITOR VERB -- PASTE OPTION IS 0
PASTEOPT        TS      EDOP            # RIGHT 7
                CA      EDOP            # PLACE MONITOR VERB OR PLEASE VERB INTO
                TC      BANKCALL        #       VERBREG AND DISPLAY IT.
                CADR    UPDATVB -1
                CAF     ZERO            # ZERO REQRET SO THAT PASTED VERBS CAN
                TS      REQRET          #       BE EXECUTED BY OPERATOR.
                CA      MONSAVE2
                TC      BLANKSUB        # PROCESS NVMONOPT BLANK OPTION IF ANY
                TC      +1
ENDPASTE        TC      ENDOFJOB

MID7            OCT     37600

                SETLOC  ENDMONDO +1
                COUNT   41/PIN
```

```
MONREF          OCT     75377           # -DEC10, STARTING IN BIT8
MONBACK         ADRES   PASTEVB
```

Uses COUNT 142, EBANK 80, EDOP 80, ENTRET 142, FFTAG8 57, IT 185, MONSAVE 154, MONSAVE1 154, MONSAVE2 154, MPAC 145, NOUNADD 144, NOUNCADR 154, NOUNREG 152, REQRET 154, TC 169, and VERBREG 152.

596 ⟨*Page CM0358* 596⟩≡ (504 2773)

```
MONBUSY         TC      RELDSPON        # TURN KEY RELEASE LIGHT
                TC      ENDOFJOB

# DSPFMEM IS USED TO DISPLAY (IN OCTAL) ANY FIXED REGISTER.
# IT IS USED WITH NOUN = MACHINE CADR TO BE SPECIFIED.  THE FCADR OF THE
# DESIRED LOCATION IS THEN PUNCHED IN.  IT HANDLES F/F (FCADR 4000-7777)
#
# FOR BANKS L/E 27, THIS IS ENOUGH.
#
# FOR BANKS G/E 30, THE THIRD COMPONENT OF NOUN 26 (PRIO, ADRES, BBCON)
# MUST BE PRELOADED WITH THE DESIRED SUPERBANK BITS (BITS 5,6,7).
#       V23N26 SHOULD BE USED.
#
# SUMMARY
# FOR BANKS L/E 27,                             V27N01E(FCADR)E
# FOR BANKS G/E 30,     V23N26E(SUPERBITS)E     V27N01E(FCADR)E

DSPFMEM         CAF     R1D1            # IF F/F, DATACALL USES BANK 02 OR 03.
                TS      DSPCOUNT
                CA      DSPTEM1 +2      # SUPERBANK BITS WERE PRELOADED INTO
                TS      L               # 3RD COMPONENT OF NOUN 26.
                CA      NOUNCADR        # ORIGINAL FCADR LOADED STILL IN NOUNCADR.
                TC      SUPDACAL        # CALL WITH FCADR IN A, SUPERBITS IN L.
                TC      DSPOCTWO
ENDSPF          TC      ENDOFJOB
```

Uses A 80, DSPCOUNT 152, DSPTEM1 154, F 238, IT 185, L 80, NOUNCADR 154, and TC 169.

597 ⟨*Page CM0359* 597⟩≡ (504 2773)

```
# WORD DISPLAY ROUTINES
                SETLOC  TESTOFUF +4
                COUNT   40/PIN

DSPSIGN         XCH     Q
                TS      DSPWDRET
                CCS     MPAC
                TC      +8D
                TC      +7
                AD      ONE
                TS      MPAC
                TC      -ON
                CS      MPAC +1
                TS      MPAC +1
                TC      DSPWDRET
                TC      +ON
                TC      DSPWDRET

DSPRND          EXTEND                  # ROUND BY 5 EXP-6
                DCA     DECROUND -1
                DAS     MPAC
                EXTEND
                BZF     +4
                EXTEND
                DCA     DPOSMAX
                DXCH    MPAC
                TC      Q

# DSPDECWD CONVERTS C(MPAC,MPAC+1) INTO A SIGN AND 5 CHAR DECIMAL
# STARTING IN LOC SPECIFIED IN DSPCOUNT.  IT ROUNDS BY 5 EXP-6.

DSPDECWD        XCH     Q
                TS      WDRET
                TC      DSPSIGN
                TC      DSPRND
                CAF     FOUR
DSPDCWD1        TS      WDCNT
                CAF     BINCON
                TC      SHORTMP
TRACE1          INDEX   MPAC
                CAF     RELTAB
                MASK    LOW5
                TS      CODE
                CAF     ZERO
                XCH     MPAC +2
```

```
                XCH     MPAC +1
                TS      MPAC
                XCH     DSPCOUNT
TRACE1S         TS      COUNT
```

Uses A 80, CHAR 140, CODE 140, COUNT 142, DSPCOUNT 152, DSPWDRET 142, IT 185, LOC 145, MPAC 145, Q 80, TC 169, WDCNT 142, and WDRET 140.

599 ⟨*Page CM0360* 599⟩≡ (504 2773)

```
                CCS     A               # DECREMENT DSPCOUNT EXCEPT AT +0
                TS      DSPCOUNT
                TC      DSPIN
                CCS     WDCNT
                TC      DSPDCWD1
                CS      VD1
                TS      DSPCOUNT
                TC      WDRET

                OCT     00000
DECROUND        OCT     02476

# DSPDECNR CONVERTS C(MPAC,MPAC+1) INTO A SIGN AND 5 CHAR DECIMAL
# STARTING IN LOC SPECIFIED IN DSPCOUNT.  IT DOES NOT ROUND

DSPDECNR        XCH     Q
                TS      WDRET
                TC      DSPSIGN
                TC      DSPDCWD1 -1

# DSPDC2NR CONVERTS C(MPAC,MPAC+1) INTO A SIGN AND 2 CHAR DECIMAL
# STARTING IN LOC SPECIFIED IN DSPCOUNT.  IT DOES NOT ROUND

DSPDC2NR        XCH     Q
                TS      WDRET
                TC      DSPSIGN
                CAF     ONE
                TC      DSPDCWD1

# DSP2DEC CONVERTS C(MPAC) AND C(MPAC+1) INTO A SIGN AND 10 CHAR DECIMAL
# STARTING IN THE LOC SPECIFIED IN DSPCOUNT.

DSP2DEC         XCH     Q
                TS      WDRET
                CAF     ZERO
                TS      CODE
                CAF     THREE
                TC      11DSPIN         # -R2 OFF
                CAF     FOUR
                TC      11DSPIN         # +R2 OFF
                TC      DSPSIGN
                CAF     R2D1
END2DEC         TC      DSPDCWD1

# DSPDECVN DISPLAYS C(A) UPON ENTRY AS A 2 CHAR DECIMAL BEGINNING IN THE
```

```
# DSP LOC SPECIFIED IN DSPCOUNT.
#
# C(A) SHOULD BE IN FORM N X 2EXP-14.  THIS IS SCALED TO FORM N/100 BEFORE
# DISPLAY CONVERSION.
```

Uses A 80, CHAR 140, CODE 140, DISPLAYS 59, DSPCOUNT 152, IT 185, LOC 145, MPAC 145, N 206, Q 80, R2 188, TC 169, WDCNT 142, and WDRET 140.

601 ⟨*Page CM0361* 601⟩≡ (504 2773)

```
DSPDECVN        EXTEND
                MP      VNDSPCON        # MULT BY .01
                LXCH    MPAC            # TAKE RESULTS FROM L. (MULT BY 2EXP14).
                CAF     ZERO
                TS      MPAC +1
                XCH     Q
                TS      WDRET
                TC      DSPDC2NR +3     # NO SIGN, NO ROUND, 2 CHAR

VNDSPCON        OCT     00244           # .01 ROUNDED UP

GOVNUPDT        TC      DSPDECVN        # THIS IS NOT FOR GENERAL USE.  REALLY PART
                TC      POSTJUMP        # OF UPDATVB.
                CADR    UPDAT1 +2

ENDECVN         EQUALS

                SETLOC  ENDSPF +1
                COUNT   41/PIN

# DSPOCTWD DISPLAYS C(A) UPON ENTRY AS A 5 CHAR OCT STARTING IN THE DSP
# CHAR SPECIFIED IN DSPCOUNT.  IT STOPS AFTER 5 CHAR HAVE BEEN DISPLAYED.

DSPOCTWO        TS      CYL
                XCH     Q
                TS      WDRET           # MUST USE SAME RETURN AS DSP2BIT.
                CAF     BIT14           # TO BLANK SIGNS
                ADS     DSPCOUNT
                CAF     FOUR
WDAGAIN         TS      WDCNT
                CS      CYL
                CS      CYL
                CS      CYL
                CS      A
                MASK    DSPMSK
                INDEX   A
                CAF     RELTAB
                MASK    LOW5
                TS      CODE
                XCH     DSPCOUNT
                TS      COUNT
                CCS     A               # DECREMENT DSPCOUNT EXCEPT AT +0
                TS      DSPCOUNT
                TC      POSTJUMP
```

```
                CADR    DSPOCTIN
OCTBACK         CCS     WDCNT
                TC      WDAGAIN         # +
DSPLV           CS      VD1             # TO BLOCK NUMERICAL CHARACTERS, CLEARS,
```

Uses A 80, CHAR 140, CODE 140, COUNT 142, CYL 80, DISPLAYS 59, DSPCOUNT 152, IT 185, L 80, MPAC 145, Q 80, TC 169, WDCNT 142, and WDRET 140.

603 ⟨*Page CM0362* 603⟩≡ (504 2773)

```
                TS      DSPCOUNT        # AND SIGNS AFTER A COMPLETED DISPLAY.
                TC      WDRET

DSPMSK          =       SEVEN

# DSP2BIT DISPLAYS C(A) UPON ENTRY AS A 2 CHAR OCT BEGINNING IN THE DSP
# LOC SPECIFIED IN DSPCOUNT BY PRE CYCLING RIGHT C(A) AND USING THE LOGIC
# OF THE 5 CHAR OCTAL DISPLAY

DSP2BIT         TS      CYR
                XCH     Q
                TS      WDRET
                CAF     ONE
                TS      WDCNT
                CS      CYR
                CS      CYR
                XCH     CYR
                TS      CYL
                TC      WDAGAIN +5

# FOR DSPIN PLACE 0/25 OCT INTO COUNT, 5 BIT RELAY CODE INTO CODE.  BOTH
# ARE DESTROYED.  IF BIT14 OF COUNT IS 1, SIGN IS BLANKED WITH LEFT CHAR.
# FOR DSPIN1 PLACE 0,1 INTO BIT11 OF CODE, 2 INTO COUNT, REL ADDRESS OF
# DSPTAB ENTRY INTO DSREL.

                SETLOC  ENDECVN

                COUNT   40/PIN

DSPIN           XCH     Q               # CAN'T USE L FOR RETURN, SINCE MANY OF THE
                TS      DSEXIT          # ROUTINES CALLING DSPIN USE L AS RETURN.
                CAF     LOW5
                MASK    COUNT
                TS      SR
                XCH     SR
                TS      DSREL
                CAF     BIT1
                MASK    COUNT
                CCS     A
                TC      +2              # LEFT IF COUNT IS ODD
                TC      DSPIN1 -1       # RIGHT IF COUNT IS EVEN
                XCH     CODE
                TC      SLEFT5          # DOES NOT USE CYL
                TS      CODE
                CAF     BIT14
```

```
                MASK    COUNT
                CCS     A
                CAF     TWO             # BIT14 = 1, BLANK SIGN
```

Uses A 80, CHAR 140, CODE 140, COUNT 142, CYL 80, CYR 80, DISPLAYS 59, DSEXIT 140, DSPCOUNT 152, DSPTAB 154, DSREL 142, L 80, LOC 145, Q 80, SR 80, TC 169, WDCNT 142, and WDRET 140.

605 ⟨*Page CM0363* 605⟩≡ (504 2773)

```
                AD      ONE             # BIT14 = 0, LEAVE SIGN ALONE
                TS      COUNT           # +0 INTO COUNT FOR RIGHT
                                        # +1 INTO COUNT FOR LEFT (SIGN LEFT ALONE)
                                        # +3 INTO COUNT FOR LEFT (TO BLANK SIGN)
DSPIN1          INHINT
                INDEX   DSREL
                CCS     DSPTAB
                TC      +2              # IF +
                TC      CCSHOLE
                AD      ONE             # IF -
                TS      DSMAG
                INDEX   COUNT
                MASK    DSMSK
                EXTEND
                SU      CODE
                EXTEND
                BZF     DSLV            # SAME
DFRNT           INDEX   COUNT
                CS      DSMSK           # MASK WITH 77740, 76037, 76777, OR 74037
                MASK    DSMAG
                AD      CODE
                CS      A
                INDEX   DSREL
                XCH     DSPTAB
                EXTEND
                BZMF    DSLV            # DSPTAB ENTRY WAS -
                INCR    NOUT            # DSPTAB ENTRY WAS +
DSLV            RELINT
                TC      DSEXIT

DSMSK           OCT     37
                OCT     1740
                OCT     2000
                OCT     3740

# FOR 11DSPIN, PUT REL ADDRESS OF DSPTAB ENTRY INTO A, 1 IN BIT11 OR 0 IN
# BIT11 OF CODE.

11DSPIN         TS      DSREL
                CAF     TWO
                TS      COUNT
                XCH     Q               # MUST USE SAME RETURN AS DSPIN
                TS      DSEXIT
                TC      DSPIN1
```

```
DSPOCTIN        TC      DSPIN           # SO DSPOCTWD DOESN'T USE SWCALL
                CAF     +2
                TC      BANKJUMP
```

Uses A 80, CODE 140, COUNT 142, DSEXIT 140, DSMAG 142, DSPTAB 154, DSREL 142, NOUT 154, Q 80, and TC 169.

607 ⟨*Page CM0364* 607⟩≡ (504 2773)

```
ENDSPOCT        CADR    OCTBACK

# DSPALARM FINDS TC NVSUBEND IN ENTRET FOR NVSUB INITIATED ROUTINES
# ABORT WITH 01501.
#
# DSPALARM FINDS TC ENDOFJOB IN ENTRET FOR KEYBOARD INITIATED ROUTINES.
# DC TC ENTRET.

PREDSPAL        CS      VD1
                TS      DSPCOUNT
DSPALARM        CS      NVSBENDL
                AD      ENTEXIT
                EXTEND
                BZF     CHARALRM +2
                CS      MONADR          # IF THIS IS A MONITOR, KILL IT
                AD      ENTEXIT
                EXTEND
                BZF     +2
                TC      CHARALRM
                TC      KILMONON
                TC      FALTON
                TC      PASTEVB         # PUT MONITOR VERB BACK IN VERBREG
CHARALRM        TC      FALTON          # NOT NVSUB INITATED TURN ON OPR ERROR
                TC      ENDOFJOB
                TC      P00DOO
                OCT     01501
MONADR          GENADR  PASTEVB
NVSBENDL        TC      NVSUBEND

# ALMCYCLE TURNS ON CHECK FAIL LIGHT, REDISPLAYS THE ORIGINAL VERB THAT
# WAS EXECUTED, AND RECYCLES TO EXECUTE THE ORIGINAL VERB/NOUN COMBINATION
# THAT WAS LAST EXECUTED.  USED FOR BAD DATA DURING LOAD VERBS AND BY
# MCTBS.  ALSO BY MMCHANG IF 2 NUMERICAL CHARACTERS WERE NOT PUNCHED IN
# FOR MM CODE

                SETLOC  MID7 +1
                COUNT   02/PIN

ALMCYCLE        TC      FALTON          # TURN ON CHECK FAIL LIGHT.
                CS      VERBSAVE        # GET ORIGINAL VERB THAT WAS EXECUTED
                TS      REQRET          # SET FOR ENTPAS0
                TC      BANKCALL        # PUTS ORIGINAL VERB INTO VERBREG AND
                CADR    UPDATVB -1      # DISPLAYS IT IN VERB LIGHTS.
                TC      POSTJUMP
ENDALM          CADR    ENTER
```

```
# MMCHANG USES NOUN DISPLAY UNTIL ENTER.  THEN IT USES MODE DISP.
# IT GOES TO MODROUT WITH THE NEW M M CODE IN A, BUT NOT DISPLAYED IN
```

Uses A 80, CODE 140, COUNT 142, DISPLAYS 59, DSPCOUNT 152, ENTRET 142, IT 185, MM 226, MODE 145, REQRET 154, TC 169, VERBREG 152, and VERBSAVE 154.

609 ⟨*Page CM0365* 609⟩≡ (504 2773)

```
# MM LIGHTS.
#
# IT DEMANDS 2 NUMERICAL CHARACTERS BE PUNCHED IN FOR NEW MM CODE.
# IF NOT, IT RECYCLES.

                SETLOC  DSP2BIT +10D

                COUNT   41/PIN

MMCHANG         TC      REQMM           # ENTPASHI ASSUMES THE TC REQMM AT MMCHANG
                                        # IF THIS MOVES AT ALL, MUST CHANGE
                                        # MMADREF AT ENTPASHI.
                CAF     BIT5            # OCT20 = ND2.
                AD      DSPCOUNT        # DSPCOUNT MUST = -ND2.
                EXTEND                  # DEMAND THAT 2 NUM CHAR WERE PUNCHED IN.
                BZF     +2
                TC      ALMCYCLE        # DSPCOUNT NOT= -ND2.  ALARM AND RECYCLE.
                CAF     ZERO            # DSPCOUNT = -ND2.
                XCH     NOUNREG
                TS      MPAC
                CAF     ND1
                TS      DSPCOUNT
                TC      BANKCALL
                CADR    2BLANK
                CS      VD1             # BLOCK NUM CHAR IN
                TS      DSPCOUNT
                CA      MPAC
                TC      POSTJUMP
                CADR    MODROUTB        # GO THRU STANDARD LOC.

MODROUTB        =       V37
REQMM           CS      Q
                TS      REQRET
                CAF     ND1
                TS      DSPCOUNT
                CAF     ZERO
                TS      NOUNREG
                TC      BANKCALL
                CADR    2BLANK
                TC      FLASHON
                CAF     ONE
                TS      DECBRNCH        # SET FOR DEC
                TC      ENTEXIT

# VBRQEXEC ENTERS REQUEST TO EXEC FOR ANY ADDRESS WITH ANY PRIORITY.
```

```
# IT DOES ENDOFJOB AFTER ENTERING REQUEST.  DISPLAY SYST IS RELEASED.
# IT ASSUMES NOUN 26 HAS BEEN PRELOADED WITH
#       COMPONENT 1     PRIORITY (BITS 10-14) BIT1=0 FOR NOVAC, BIT1=1 FOR FINDVAC.
#       COMPONENT 2     JOB ADRES (12 BIT)
```

Uses CHAR 140, CODE 140, COUNT 142, DECBRNCH 152, DSPCOUNT 152, IT 185, LOC 145, MM 226, MPAC 145, NOUNREG 152, PRIORITY 145, Q 80, REQRET 154, and TC 169.

611 ⟨*Page CM0366* 611⟩≡ (504 2773)

```
#       COMPONENT 3     BBCON

VBRQEXEC        CAF     BIT1
                MASK    DSPTEM1
                CCS     A
                TC      SETVAC          # IF BIT1 = 1, FINDVAC
                CAF     TCNOVAC         # IF BIT1 = 0, NOVAC
REQEX1          TS      MPAC            # TC NOVAC OR TC FINDVAC INTO MPAC
                CS      BIT1
                MASK    DSPTEM1
                TS      MPAC +4         # PRIO INTO MPAC+4 AS A TEMP
REQUESTC        TC      RELDSP
                CA      ENDINST
                TS      MPAC +3         # TC ENDOFJOB INTO MPAC+3
                EXTEND
                DCA     DSPTEM1 +1      # JOB ADRES INTO MPAC+1
                DXCH    MPAC +1         # BBCON INTO MPAC+2
                CA      MPAC +4         # PRIO IN A
                INHINT
                TC      MPAC

SETVAC          CAF     TCFINDVC
                TC      REQEX1

# VBRQWAIT ENTERS REQUEST TO WAITLIST FOR ANY ADDRESS WITH ANY DELAY.
# IT DOES ENDOFJOB AFTER ENTERING REQUEST.  DISPLAY SYST IS RELEASED.
# IT ASSUMES NOUN 26 HAS BEEN PRELOADED WITH
#       COMPONENT 1     DELAY (LOW BITS)
#       COMPONENT 2     TASK ADRES (12 BIT)
#       COMPONENT 3     BBCON

VBRQWAIT        CAF     TCWAIT
                TS      MPAC            # TC WAITLIST INTO MPAC
                CA      DSPTEM1         # TIME DELAY
ENDRQWT         TC      REQUESTC -1

# REQUESTC WILL PUT TASK ADRES INTO MPAC+1, BBCON INTO MPAC+2,
# TC ENDOFJOB INTO MPAC+3.  IT WILL TAKE TIME DELAY OUT OF MPAC+4 AND
# LEAVE IT IN A, INHINT AND TC MPAC.

                SETLOC  NVSBENDL +1
                COUNT   40/PIN

VBPROC          CAF     ONE             # PROCEED WITHOUT DATA
                TS      LOADSTAT
```

```
                TC      KILMONON        # TURN ON KILL MONITOR BIT
                TC      RELDSP
                TC      FLASHOFF
                TC      RECALTST        # SEE IF THERE IS ANY RECALL FROM ENDIDLE
```

Uses A 80, COUNT 142, DSPTEM1 154, IT 185, LOADSTAT 154, MPAC 145, TC 169, and TEMP 191.

612 ⟨*Page CM0367* 612⟩≡ (504 2773)

```
VBTERM          CS      ONE
                TC      VBPROC +1       # TERM VERB SETS LOADSTAT NEG

# PROCKEY PERFORMS THE SAME FUNCTION AS VBPROC.  IT MUST BE CALLED UNDER
# EXECUTIVE CONTROL, WITH CHRPRIO.

PROCKEY         CAF     ZERO            # SET REQRET FOR ENTER PASS 0.
                TS      REQRET
                CS      VD1             # BLOCK NUMERICAL CHARACTERS, SIGNS, CLEAR
                TS      DSPCOUNT
                TC      VBPROC

# VBRESEQ WAKES ENDIDLE AT SAME LINE AS FINAL ENTER OF LOAD (L+3).
# (MAIN USE IS INTENDED AS RESPONSE TO INTERNALLY INITIATED FLASHING
# DISPLAYS IN ENDIDLE.  SHOULD NOT BE USED WITH LOAD VERBS, PLEASE PERFORM,
# OR PLEASE MARK VERBS BECAUSE THEY ALREADY USE L+3 IN ANOTHER CONTEXT.)

VBRESEQ         CS      ZERO            # MAKE IT LOOK LIKE DATA IN.
                TC      VBPROC +1

# FLASH IS TURNED OFF BY PROCEED WITHOUT DATA, TERMINATE, RESEQUENCE,
# END OF LOAD.
```

Uses DISPLAYS 59, DSPCOUNT 152, IT 185, L 80, LOADSTAT 154, REQRET 154, and TC 169.

613 ⟨*Page CM0368* 613⟩≡ (504 2773)

```
# KEY RELEASE ROUTINE
#
# THIS ROUTINE ALWAYS TURNS OFF THE UPACT LIGHT AND ALWAYS CLEARS DSPLOCK.
#
# THE HIGHEST PRIORITY FUNCTION OF THE KEY RELEASE BUTTON IS THE
# UNSUSPENDING OF A SUSPENDED MONITOR WHICH WAS EXTERNALLY INITIATED.
# THIS FUNCTION IS ACCOMPLISHED BY CLEARING DSPLOCK AND TURNING OFF
# THE KEY RELEASE LIGHT IF BOTH DSPLIST AND CADRSTOR ARE EMPTY.
#
# IF NO SUCH MONITOR EXISTS, THEN RELDSP IS EXECUTED TO CLEAR DSPLOCK
# AND THE EXTERNAL MONITOR BIT (FREEING THE DISPLAY SYSTEM FOR INTERNAL
# USE), TURN OFF THE KEY RELEASE LIGHT, AND WAKE UP ANY JOB IN DSPLIST.
#
# IN ADDITION IF THERE IS A JOB IN ENDIDLE, THEN CONTROL IS TRANSFERRED
# TO PINBRNCH (IN DISPLAY INTERFACE ROUTINE) TO RE-EXECUTE THE SERIES OF
# NVSUB CALLS ETC. THAT PRECEDED THE ENDIDLE CALL STILL AWAITING RESPONSE.
# THIS FEATURE IS INTENDED FOR USE WHEN THE OPERATOR HAS BEEN REQUESTED TO
# RESPOND TO SOME INTERNAL ACTION THAT USED ENDIDLE, BUT HE HAS WRITTEN
# OVER THE INFORMATION ON THE DISPLAY PANEL BY SOME DISPLAYS OF HIS OWN
# INITIATION WHICH DO NOT SERVE AS RESPONSES.  HITTING KEYRLSE WILL
# RE-ESTABLISH THE DISPLAYS TO THE STATE THEY WERE IN BEOFRE HE OBSCURED
# THEM, SO THAT HE CAN SEE THE WAITING REQUEST.  THIS WORKS ONLY FOR
# INTERNAL PROGRAMS THAT USED ENDIDLE THROUGH MARGARET'S DISPLAY
# SUBROUTINES.

VBRELDSP        CS      BIT3
                EXTEND
                WAND    DSALMOUT        # TURN OF UPACT LITE
                CCS     21/22REG        # OLD DSPLOCK
                CAF     BIT14
                MASK    MONSAVE1        # EXTERNAL MONITOR BIT (EMB)
                CCS     A
                TC      UNSUSPEN        # OLD DSPLOCK AND EMB BOTH 1, UNSUSPEND,
TSTLTS4         TC      RELDSP          # NOT UNSUSPENDING EXTERNAL MONITOR
                CCS     CADRSTOR        #       RELEASE DISPLAY SYSTEM AND
                TC      +2              #       DO RE-ESTABLISH IF CADRSTOR IS FULL.
                TC      ENDOFJOB
                TC      POSTJUMP
                CADR    PINBRNCH
UNSUSPEN        CAF     ZERO            # EXTERNAL MONITOR IS SUSPENDED,
                TS      DSPLOCK         #       JUST UNSUSPEND IT BY CLEARING DSPLOCK.
                CCS     CADRSTOR        #       TURN KEY RELEASE LIGHT OFF IF BOTH
                TC      ENDOFJOB        #       CADRSTOR AND DSPLIST ARE EMPTY.
                TC      RELDSP1
```

```
                TC      ENDOFJOB

ENDRELDS        EQUALS
```

Uses 21/22REG 140, A 80, CADRSTOR 154, DISPLAYS 59, DSALMOUT 87, DSPLIST 154, DSPLOCK 154, IT 185, MONSAVE1 154, PRIORITY 145, STATE 138, and TC 169.

615 ⟨*Page CM0369* 615⟩≡ (504 2773)

```
# NVSUB IS USED FOR SUBROUTINE CALLS FROM WITHIN COMPUTER.  IT CAN BE
# USED TO CALL THE COMBINATION OF ANY DISPLAY, LOAD, OR MONITOR VERB
# TOGETHER WITH ANY NOUN AVAILABLE TO THE KEYBOARD.
# PLACE 0VVVVVVVVNNNNNNN INTO A.
# V'S ARE THE 7-BIT VERB CODE.  N'S ARE THE 7-BIT NOUN CODE.
#
# IF NVSUB IS CALLED WITH THE FOLLOWING NEGATIVE NUMBERS (RATHER THAN THE
# VERB-NOUN CODE) IN A, THEN THE DISPLAY IS BLANKED AS FOLLOWS ---
# -4 FULL BLANK, -3 LEAVE MODE, -2 LEAVE MODE AND VERB, -1 BLANK R'S ONLY.
#
# NVSUB CAN BE USED WITH MACHINE CADR TO BE SPECIFIED BY PLACING THE CADR INTO
# MPAC+2 BEFORE THE STANDARD NVSUB CALL.
#
# NVSUB RETURNS TO 2+ CALLING LOC AFTER PERFORMING TASK, IF DISPLAY
# SYSTEM IS AVAILABLE.  THE NEW NOUN AND VERB CODES ARE DISPLAYED.
# IF V'S =0, THE NEW NOUN CODE IS DISPLAYED ONLY (RETURN WITH NO FURTHER
# ACTION).  IF N'S =0, THE NEW VERB CODE IS DISPLAYED ONLY (RETURN WITH NO
# FURTHER ACTION).
#
# IT RETURNS TO 1+ CALLING LOC WITHOUT PERFORMING TASK, IF DISPLAY
# SYSTEM IS BLOCKED (NOTHING IS DISPLAYED IN THIS CASE).
# IT DOES TC ABORT (WITH OCT 01501) IF IT ENCOUNTERS A DISPLAY PROGRAM
# ALARM CONDITION BEFORE RETURN TO CALLER.
#
# THE DISPLAY SYSTEM IS BLOCKED BY THE DEPRESSION OF ANY
# KEY, EXCEPT ERROR LIGHT RESET.
# IT IS RELEASED BY THE KEY RELEASE BUTTON, ALL EXTENDED VERBS,
# PROCEED WITHOUT DATA, TERMINATE, RESEQUENCE, INITIALIZE EXECUTIVE,
# RECALL PART OF RECALTST IF ENDIDLE WAS USED,
# VB = REQUEST EXECUTIVE, VB = REQUEST WAITLIST,
# MONITOR SET UP.
#
# THE DISPLAY SYSTEM IS ALSO BLOCKED BY THE EXTERNAL MONITOR BIT, WHICH
# INDICATES AND EXTERNALLY INITIATED MONITOR IS RUNNING (SEE MONITOR).
#
# A NVSUB CALL THAT PASSES DSPLOCK AND THE EXTERNAL MONITOR BIT ENDS OLD
# MONITOR.
#
# DSPLOCK IS THE INTERLOCK FOR USE OF KEYBOARD AND DISPLAY SYSTEM WHICH
# LOCKS OUT INTERNAL USE WHENEVER THERE IS EXTERNAL KEYBOARD ACTION.
#
# NVSUB SHOULD BE USED TWICE IN SUCCESSION FOR 'PLEASE PERFORM' SITUATIONS
# (SIMILARLY FOR PLEASE MARK).  FIRST PLACE THE CODED NUMBER FOR WHAT
# ACTION IS DESIRED OF OPERATOR INTO THEREGISTERS REFERRED TO BY THE
# 'CHECKLIST' NOUN.  GO TO NVSUB WITH A DISPLAY VERB AND THE 'CHECKLIST'
```

```
# NOUN.  GO TO NVSUB AGAIN WITH THE ‘PLEASE PERFORM’ VERB AND ZEROS IN THE
# LOW 7 BITS.  THIS ‘PASTES UP’ THE ‘PLEASE PERFORM’ VERB INTO THE VERB
# LIGHTS.
#
# NVMONOPT IS AN ENTRY SIMILAR TO NVSUB, BUT REQUIRING AN ADDITIONAL
```

Uses A 80, CODE 140, COMPUTER 115, DSPLOCK 154, IT 185, LOC 145, MODE 145, MPAC 145, and TC 169.

617 ⟨*Page CM0370* 617⟩≡ (504 2773)

```
# PARAMETER IN L.  IT SHOULD BE USED ONLY WITH A MONITOR VERB-NOUN CODE IN
# A.  AFTER EACH MONITOR DISPLAY A *PLEASE* VERB WILL BE PASTED IN THE VERB
# LIGHTS OR DATA WILL BE BLANKED (OR BOTH) ACCORDING TO THE OPTIONS
# SPECIFIED IN L.  IF BITS 8-14 OF L ARE OTHER THAN ZERO, THEN THEY WILL
# BE INTERPRETED AS A VERB CODE AND PASTED IN THE VERB LIGHTS.  (THIS VERB
# CODE SHOULD DESIGNATE ONE OF THE *PLEASE* VERBS.)  IF BITS 1-3 OF L ARE
# OTHER THAN ZERO, THEN THEY WILL BE USED BO BLANK DATA BY BEING FED TO
# BLANKSUB.  IF NVMONOPT IS USED WITH A VERB OTHER THAN A MONITOR VERB,
# THE PARAMETER IN L HAS NO EFFECT.
#
# NVSUB IN FIXED-FIXED PLACES 2+CALLING LOC INTO NVQTEM, TC NVSUBEND INTO
# ENTRET.  (THIS WILL RESTORE OLD CALLING BANK BITS)

                SETLOC  ENDALM +1

                COUNT   02/PIN

NVSUB           LXCH    7               # ZERO NVMONOPT OPTIONS
NVMONOPT        TS      NVTEMP
                CAF     BIT14
                MASK    MONSAVE1        # EXTERNAL MONITOR BIT
                AD      DSPLOCK
                CCS     A
                TC      Q               # DSP SYST BLOCKED.  RET TO 1.  CALLING LOC
                CAF     ONE             # DSP SYST AVAILABLE.
NVSBCOM         AD      Q
                TS      NVQTEM          # 2+ CALLING LOC INTO NVQTEM
                LXCH    MONSAVE2        # STORE NVMONOPT OPTIONS
                TC      KILMONON        # TURN ON KILL MONITOR BIT
NVSUBCOM        CAF     NVSBBBNK

                XCH     BBANK
                EXTEND                  # SAVE OLD SUPERBITS
                ROR     SUPERBNK
                TS      NVBNKTEM
                CAF     PINSUPBT
                EXTEND
                WRITE   SUPERBNK
                TC      NVSUBB          # GO TO NVSUB1 THRU STANDARD LOC
                EBANK=  DSPCOUNT
NVSBBBNK        BBCON   NVSUB1

PINSUPBT        =       NVSBBBNK        # CONTAINS THE PINBALL SUPERBIT.

NVSUBEND        DXCH    NVQTEM          # NVBNKTEM MUST = NVQTEM+1
```

```
TC      SUPDXCHZ        # DTCB WITH SUPERBIT SWITCHING

SETLOC  ENDRQWT +1

COUNT   41/PIN
```

Uses A 80, BBANK 80, CODE 140, COUNT 142, DSPCOUNT 152, DSPLOCK 154, EBANK 80, ENTRET 142, IT 185, L 80, LOC 145, MONSAVE1 154, MONSAVE2 154, NVBNKTEM 154, NVQTEM 154, NVTEMP 140, Q 80, SAVE 191, SUPERBNK 87, and TC 169.

619 ⟨*Page CM0371* 619⟩≡ (504 2773)

```
# BLANKDSP BLANKS DISPLAY ACCORDING TO OPTION NUMBER IN NVTEMP AS FOLLOWS:
# -4 FULL BLANK, -3 LEAVE MODE, -2 LEAVE MODE AND VERB, -1 BLANK R'S ONLY.

BLANKDSP        AD      SEVEN           # 7,8,9, OR 10 (A HAD 0,1,2,OR 3)
                INHINT
                TS      CODE            # BLANK SPECIFIED DSPTABS
                CS      BIT12
                INDEX   CODE
                XCH     DSPTAB
                CCS     A
                INCR    NOUT
                TC      +1
                CCS     CODE
                TC      BLANKDSP +2
                RELINT
                INDEX   NVTEMP
                TC      +5
                TC      +1              # NVTEMP HAS    -4 (NEVER TOUCH MODREG)
                TS      VERBREG         #               -3
                TS      NOUNREG         #               -2
                TS      CLPASS          #               -1
                CS      VD1
                TS      DSPCOUNT
                TC      FLASHOFF        # PROTECT AGAINST INVISIBLE FLASH
                TC      ENTSET -2       # ZEROS REQRET

NVSUB1          CAF     ENTSET          # IN BANK
                TS      ENTRET          # SET RETURN TO NVSUBEND
                CCS     NVTEMP          # WHAT NOW
                TC      +4              # NORMAL NVSUB CALL (EXECUTE VN OR PASTE)
                TC      GODSPALM
                TC      BLANKDSP        # BLANK DISPLAY AS SPECIFIED
                TC      GODSPALM
                CAF     LOW7
                MASK    NVTEMP
                TS      MPAC +3         # TEMP FOR NOUN (CAN'T USE MPAC.  DSPDECVN
                CA      NVTEMP          #                USES MPAC, +1, +2).
                TS      EDOP            # RIGHT 7
                CA      EDOP
                TS      MPAC +4         # TEMP FOR VERB (CAN'T USE MPAC+1.  DSPDECVN
                                        #                USES MPAC, +1, +2)
                CCS     MPAC +3         # TEST NOUN
                TC      NVSUB2          # IF NOUN NOT +0, GO ON
                CA      MPAC +4
```

```
                TC      UPDATVB -1      # IF NOUN = +0, DISPLAY VERB.  THEN RETURN
                CAF     ZERO            # ZERO REQRET SO THAT PASTED VERBS CAN
                TS      REQRET          # BE EXECUTED BY OPERATOR.
ENTSET          TC      NVSUBEND
NVSUB2          CCS     MPAC +4         # TEST VERB
                TC      +4              # IF VERB NOT +0, GO ON
```

Uses A 80, CLPASS 154, CODE 140, DSPCOUNT 152, DSPTAB 154, EDOP 80, ENTRET 142, MODE 145, MODREG 154, MPAC 145, NOUNREG 152, NOUT 154, NVTEMP 140, REQRET 154, TC 169, TEMP 191, VERBREG 152, and VN 159.

621 ⟨*Page CM0372* 621⟩≡ (504 2773)

```
                CA      MPAC +3
                TC      UPDATNN -1      # IF VERB = +0, DISPLAY NOUN.  THEN RETURN
                TC      NVSUBEND
                CA      MPAC +2         # TEMP FOR MACH CADR TO BE SPEC.  (DSPDECVN
                TS      MPAC +5         #       USES MPAC, +1, +2)
                CA      MPAC +4
                TC      UPDATVB -1      # IF BOTH NOUN AND VERB NOT +0, DISPLAY
                CA      MPAC +3         # BOTH AND GO TO ENTPAS0.
                TC      UPDATNN -1
                CAF     ZERO
                TS      LOADSTAT        # SET FOR WAITING FOR DATA CONDITION
                TS      CLPASS
                TS      REQRET          # SET REQRET FOR PASS 0.
                CA      MPAC +5         # RESTORES MACH CADR TO BE SPEC TO MPAC+2
                TS      MPAC +2         # FOR USE IN INTMCTBS (IN ENTPAS0).
ENDNVSB1        TC      ENTPAS0

# IF INTERNAL MACH CADR TO BE SPECIFIED, MPAC+2 WILL BE PLACED INTO
# NOUNCADR IN ENTPAS0 (INTMCTBS).

                SETLOC  NVSUBEND +2
                COUNT   02/PIN
                                        # FORCE BIT 15 OF MONSAVE1 TO .
KILMONON        CAF     BIT15           #       THIS IS THE KILL MONITOR BIT.
                TS      MONSAVE1        # TURN OFF BIT 14, THE EXTERNAL
                                        #       MONITOR BIT.
                TC      Q

# LOADSTAT      +0      INACTIVE (WAITING FOR DATA).  SET BY NVSUB
#               +1      PROCEED NO DATA.  SET BY SPECIAL VERB
#               -1      TERMINATE.  SET BY SPECIAL VERB.
#               -0      DATA IN.        SET BY END OF LOAD ROUTINE.
#                       OR RESEQUENCE.  SET BY VERB 32
#
# L TO ENDIDLE (FIXED FIXED).
# ROUTINES THAT REQUEST LOADS THROUGH NVSUB SHOULD USE ENDIDLE WHILE
# WAITING FOR THE DATA TO BE LOADED.  ENDIDLE PUTS CURRENT JOB TO SLEEP.
# ENDIDLE CANNOT BE CALLED FROM ERASABLE OR F/F MEMORY,
# SINCE JOB SLEEP AND JOBWAKE CAN HANDLE ONLY FIXED BANKS.
# RECALTST TESTS LOADSTAT AND WAKES JOB UP TO,
#       L+1     FOR TERMINATE
#       L+2     FOR PROCEED WITHOUT DATA
#       L+3     FOR DATA IN, OR RESEQUENCE
# IT DOES NOTHING IF LOADSTAT INDICATES WAITING FOR DTA.
```

Uses CLPASS 154, COUNT 142, F 238, IT 185, L 80, LOADSTAT 154, MONSAVE1 154, MPAC 145,

NOUNCADR 154, Q 80, REQRET 154, TC 169, and TEMP 191.

623 ⟨*Page CM0373* 623⟩≡ (504 2773)

```
#
# ENDIDLE ABORTS (WITH CODE 1206) IF A SECOND JOB ATTEMPTS TO GO TO SLEEP
# IN PINBALL.  IN PARTICULAR, IF AN ATTEMPT IS MADE TO GO TO ENDIDLE WHEN
#       1)      CADRSTOR NOT= +0.  THIS IS THE CASE WHERE THE CAPACITY OF ENDIDLE IS
#               EXCEEDED.  (+-NZ INDICATES A JOB IS ALREADY ASLEEP DUE TO ENDIDDLE.)
#       2)      DSPLIST NOT= +0.  THIS INDICATES A JOB IS ALREADY ASLEEP DUE TO
#               NVSUBUSY.

ENDIDLE         LXCH    Q               # RETURN ADDRESS INTO L.
                TC      ISCADR+0        # ABORT IF CADRSTOR NOT= +0.
                TC      ISLIST+0        # ABORT IF DSPLIST NOT= +0
                CA      L               # DON'T SET DSPLOC TO 1 SO CAN USE
                MASK    LOW10           # ENDIDLE WITH NVSUB INITIATE MONITOR.
                AD      FBANK           # SAME STRATEGY FOR CADR AS MAKECADR.
                TS      CADRSTOR
                TC      JOBSLEEP

ENDINST         TC      ENDOFJOB

ISCADR+0        CCS     CADRSTOR        # ABORTS (CODE 01206) IF CADRSTOR NOT= +0.
                TC      DSPABORT        # RETURNS IF CADRSTOR = +0.
                TC      Q
                TC      DSPABORT

ISLIST+0        CCS     DSPLIST         # ABORTS (CODE 01206) IF DSPLIST NOT= +0.
                TC      DSPABORT        # RETURNS IF DSPLIST = +0.
                TC      Q
DSPABORT        TC      P00DOO
                OCT     01206

# JAMTERM ALLOWS PROGRAMS TO PERFORM THE TERMINATE FUNCTION.
# IT DOES ENDOFJOB.

JAMTERM         CAF     PINSUPBT
                EXTEND
                WRITE   SUPERBNK
                CAF     34DEC
                TS      REQRET          # LEAVE ENTER SET FOR ENTPASS0.
                CS      VD1
                TS      DSPCOUNT
                TC      POSTJUMP
                CADR    VBTERM

34DEC           DEC     34
```

```
# JAMPROC ALLOWS PROGRAMS TO PERFORM THE PROCEED/PROCEED WITHOUT DATA
# FUNCTION.  IT DOES ENDOFJOB.
```

Uses A 80, CADRSTOR 154, CODE 140, DSPCOUNT 152, DSPLIST 154, FBANK 80, IT 185, L 80, Q 80, REQRET 154, SUPERBNK 87, and TC 169.

625 ⟨*Page CM0374* 625⟩≡ (504 2773)

```
JAMPROC         CAF     PINSUPBT
                EXTEND
                WRITE   SUPERBNK
                CAF     33DEC
                TS      REQRET          # LEAVE ENTER SET FOR ENTPASS0.
                CS      VD1
                TS      DSPCOUNT
                TC      POSTJUMP
                CADR    VBPROC

33DEC           DEC     33

# BLANKSUB BLANKS ANY COMBINATION OF R1, R2, R3.
# CALL WITH BLANKING CODE IN A.
# BIT1=1 BLANKS R1, BIT2=1 BLANKS R2, BIT3=1 BLANKS R3.
# ANY COMBINATION OF THESE BITS IS ACCEPTED.
#
# DSPCOUNT IS RESTORED TO STATE IT WAS IN BEFORE BLANKSUB WAS EXECUTED.

BLANKSUB        MASK    SEVEN
                TS      NVTEMP          # STORE BLANKING CODE IN NVTEMP.
                CAF     BIT14
                MASK    MONSAVE1        # EXTERNAL MONITOR BIT
                AD      DSPLOCK
                CCS     A
                TC      Q               # DSP SYST BLOCKED.  RET TO 1+ CALLING LOC
                INCR    Q               # DSP SYST AVAILABLE
                                        # SET RETURN FOR 2+ CALLING LOC
                CCS     NVTEMP
                TCF     +2
                TC      Q               # NOTHING TO BLANK.  RET TO 2+ CALLING LOC
                LXCH    Q               # SET RETURN FOR 2 + CALLING LOC
                CAF     BLNKBBNK
                XCH     BBANK
                EXTEND
                ROR     SUPERBNK        # SAVE OLD SUPERBITS.
                DXCH    BUF
                CAF     PINSUPBT
                EXTEND
                WRITE   SUPERBNK
                TC      BLNKSUB1

                EBANK=  DSPCOUNT
BLNKBBNK        BBCON   BLNKSUB1
```

```
ENDBLFF         EQUALS

                SETLOC  ENDRELDS
                COUNT   40/PIN
```

Uses A 80, BBANK 80, BUF 142, CODE 140, COUNT 142, DSPCOUNT 152, DSPLOCK 154, EBANK 80, IT 185, LOC 145, MONSAVE1 154, NVTEMP 140, Q 80, R2 188, REQRET 154, SAVE 191, STATE 138, SUPERBNK 87, and TC 169.

627 ⟨*Page CM0375* 627⟩≡ (504 2773)

```
BLNKSUB1        CA      DSPCOUNT        # SAVE OLD DSPCOUNT FOR LATER RESTORATION
                TS      BUF     +2
                CAF     BIT1            # TEST BIT1.  SEE IF R1 TO BE BLANKED.
                TC      TESTBIT
                CAF     R1D1
                TC      5BLANK  -1
                CAF     BIT2            # TEST BIT2.  SEE IF R2 TO BE BLANKED.
                TC      TESTBIT
                CAF     R2D1
                TC      5BLANK  -1
                CAF     BIT3            # TEST BIT3.  SEE IF R3 TO BE BLANKED.
                TC      TESTBIT
                CAF     R3D1
                TC      5BLANK  -1
                CA      BUF     +2      # RESTORE DSPCOUNT TO STATE IT HAD
                TS      DSPCOUNT        #       BEFORE BLANKSUB.
                DXCH    BUF             # CALL L+2 DIRECTORY.
                TC      SUPDXCHZ +1     # DTCB WITH SUPERBIT SWITCHING

TESTBIT         MASK    NVTEMP          # NVTEMP CONTAINS BLANKING CODE
                CCS     A
                TC      Q               # IF CURRENT BIT = 1, RETURN TO L+1.
                INDEX   Q               # IF CURRENT BIT = 0, RETURN TO L+3.
                TC      2

ENDBSUB1        EQUALS

# DSPMM DOES NOT DISPLAY MODREG DIRECTLY.  IT PUTS IN EXEC REQUEST WITH
# PRIO 30000 FOR DSPMMJB AND RETURNS TO CALLER.
#
# IF MODREG CONTAINS -0, DSPMMJB BLANKS THE MODE LIGHTS.
#
# DSPMM MUST BE IN BANK 27 OR LOWER, SO IT CAN BE CALLED VIA BANKCALL.

                BANK    7
                SETLOC  PINBALL4
                BANK

                COUNT   07/PIN

DSPMM           XCH     Q
                TS      MPAC
                INHINT
                CAF     CHRPRIO
                TC      NOVAC
```

```
EBANK=  DSPCOUNT
2CADR   DSPMMJB

RELINT
```

Uses A 80, BUF 142, CODE 140, COUNT 142, DSPCOUNT 152, EBANK 80, IT 185, L 80, MODE 145, MODREG 154, MPAC 145, NVTEMP 140, PINBALL4 57, Q 80, R2 188, SAVE 191, STATE 138, and TC 169.

629 ⟨*Page CM0376* 629⟩≡ (504 2773)

```
ENDSPMM         TC      MPAC

# DSPMM PLACE MAJOR MODE CODE INTO MODREG

                SETLOC  ENDBSUB1

                COUNT   40/PIN

DSPMMJB         CAF     MD1             # GETS HERE THRU DSPMM
                XCH     DSPCOUNT
                TS      DSPMMTEM        # SAVE DSPCOUNT
                CCS     MODREG
                AD      ONE
                TC      DSPDECVN        # IF MODREG IS + OR +0, DISPLAY MODREG
                TC      +2              # IF MODREG IS -NZ, DO NOTHING
                TC      2BLANK          # IF MODREG IS -0, BLANK MM
                XCH     DSPMMTEM        # RESTORE DSPCOUNT
                TS      DSPCOUNT
                TC      ENDOFJOB

# RECALTST IS ENTERED DIRECTLY AFTER DATA IS LOADED (OR RESEQUENCE VERB IS
# EXECUTED), TERMINATE VERB IS EXECUTED, OR PROCEED WITHOUT DATA VERB IS
# EXECUTED.  IT WAKES UP JOB THAT DID TC ENDIDLE.
#
# IF CADRSTOR NOT= +0, IT PUTS +0 INTO DSPLOCK, AND TURNS OFF KEY RLSE
# LIGHT IF DSPLIST IS EMPTY (LEAVES KEY RLSE LIGHT ALONE IF NOT EMPTY).

RECALTST        CCS     CADRSTOR
                TC      RECAL1
                TC      ENDOFJOB        # NORMAL EXIT IF KEYBOARD INITIATED
RECAL1          CAF     ZERO
                XCH     CADRSTOR
                INHINT
                TC      JOBWAKE
                CCS     LOADSTAT
                TC      DOPROC          # + PROCEED WITHOUT DATA
                TC      ENDOFJOB        # PATHOLOGICAL CASE EXIT
                TC      DOTERM          # -  TERMINATE
                CAF     TWO             # -0 DATA IN OR RESEQUENCE
RECAL2          INDEX   LOCCTR
                AD      LOC             # LOC IS + FOR BASIC JOBS
                INDEX   LOCCTR
                TS      LOC
                CA      NOUNREG         # SAVE VERB IN MPAC, NOUN IN MPAC+1 AT
                TS      L               # TIME OF RESPONSE TO ENDIDLE FOR
```

```
                CA      VERBREG         # POSSIBLE LATER TESTING BY JOB THAT HAS
                INDEX   LOCCTR          # BEEN WAKED UP.
                DXCH    MPAC
                RELINT
```

Uses CADRSTOR 154, CODE 140, COUNT 142, DSPCOUNT 152, DSPLIST 154, DSPLOCK 154, DSPMMTEM 142, IT 185, L 80, LOADSTAT 154, LOC 145, LOCCTR 138, MM 226, MODE 145, MODREG 154, MPAC 145, NOUNREG 152, SAVE 191, TC 169, and VERBREG 152.

630 ⟨*Page CM0377* 630⟩≡ (504 2773)

```
RECAL3          TC      RELDSP
                TC      ENDOFJOB

DOTERM          CAF     ZERO
                TC      RECAL2

DOPROC          CAF     ONE
                TC      RECAL2

                SBANK=  LOWSUPER
```

Uses LOWSUPER 67 and TC 169.

631 ⟨*Page CM0378* 631⟩≡ (504 2773)

```
# MISCELLANEOUS SERVICE ROUTINES IN FIXED/FIXED

                SETLOC  ENDBLFF

                COUNT   02/PIN

# SETNCADR      E CADR ARRIVES IN A.  IT IS STORED IN NOUNCADR.  EBANK BITS
#               ARE SET.  E ADRES IS DERIVED AND PUT INTO NOUNADD.

SETNCADR        TS      NOUNCADR        # STORE ECADR
                TS      EBANK           # SET EBANK BITS
                MASK    LOW8
                AD      OCT1400
                TS      NOUNADD         # PUT E ADRES INTO NOUNADD
                TC      Q

# SETNADD       GETS E CADR FROM NOUNCADR, SETS EBANK BITS, DERIVES
#               E ADRES AND PUTS IT INTO NOUNADD.

SETNADD         CA      NOUNCADR
                TCF     SETNCADR +1

# SETEBANK      E CADR ARRIVES IN A.  EBANK BITS ARE SET.  E ADRES IS
#               DERIVED AND LEFT IN A.

SETEBANK        TS      EBANK           # SET EBANK BITS
                MASK    LOW8
                AD      OCT1400         # E ADRES LEFT IN A
                TC      Q

R1D1            OCT     16              # THESE 3 CONSTANTS FORM A PACKED TABLE.
R2D1            OCT     11              # DON'T SEPARATE.
R3D1            OCT     4

RIGHT5          TS      CYR
                CS      CYR
                CS      CYR
                CS      CYR
                CS      CYR
                XCH     CYR
                TC      Q

LEFT5           TS      CYL
                CS      CYL
                CS      CYL
```

CS CYL

Uses A 80, COUNT 142, CYL 80, CYR 80, EBANK 80, IT 185, NOUNADD 144, NOUNCADR 154, Q 80, and TC 169.

633 ⟨*Page CM0379* 633⟩≡ (504 2773)

```
                CS      CYL
                XCH     CYL
                TC      Q

SLEFT5          DOUBLE
                DOUBLE
                DOUBLE
                DOUBLE
                DOUBLE
                TC      Q

LOW5            OCT     37              # THESE 3 CONSTANTS FORM A PACKED TABLE.
MID5            OCT     1740            # DON'T SEPARATE.
HI5             OCT     76000           # MUST STAY HERE

TCNOVAC         TC      NOVAC
TCWAIT          TC      WAITLIST
TCTSKOVR        TC      TASKOVER
TCFINDVC        TC      FINDVAC

CHRPRIO         OCT     30000           # EXEC PRIORITY OF CHARIN

LOW11           OCT     3777
B12-1           EQUALS  LOW11
LOW8            OCT     377

VD1             OCT     23              # THESE 3 CONSTANTS FORM A PACKED TABLE.
ND1             OCT     21              # DON'T SEPARATE.
MD1             OCT     25

BINCON          DEC     10

FALTON          CA      BIT7            # TURN ON OPERATOR ERROR LIGHT.
                EXTEND
                WOR     DSALMOUT        # BIT 7 OF CHANNEL 11
                TC      Q

FALTOF          CS      BIT7            # TURN OFF OPERATOR ERROR LIGHT
                EXTEND
                WAND    DSALMOUT        # BIT 7 OF CHANNEL 11
                TC      Q

RELDSPON        CAF     BIT5            # TURN ON KEY RELEASE LIGHT
                EXTEND
                WOR     DSALMOUT        # BIT 5 OF CHANNEL 11
```

```
TC      Q
```

Uses `A` 80, `CYL` 80, `DSALMOUT` 87, `PRIORITY` 145, `Q` 80, and `TC` 169.

635 ⟨*Page CM0380* 635⟩≡ (504 2773)

```
LODSAMPT        EXTEND
                DCA     TIME2
                DXCH    SAMPTIME
                TC      Q

TPSL1           EXTEND                  # SHIFTS MPAC, +1, +2 LEFT 1
                DCA     MPAC    +1      # LEAVES OVFIND SET TO +/- 1 FOR OF/UF
                DAS     MPAC    +1
                AD      MPAC
                ADS     MPAC
                TS      7               # TS A DOES NOT CHANGE A ON OF/UF.
                TC      Q               # NO NET OF/UF
                TS      MPAC+6          # MPAC +6 SET TO +/- 1 FOR OF/UF
                TC      Q

# IF MPAC, +1 ARE EACH +NZ OR +0 AND C(A)=-0, SHORTMP WRONGLY GIVES +0.
# IF MPAC, +1 ARE EACH -NZ OR -0 AND C(A)=+0, SHORTMP WRONGLY GIVES +0.
# PRSHRTMP FIXES FIRST CASE ONLY, BY MERELY TESTING C(A) AND IF IT = -0,
# SETTING RESULT TO -0.
#
# (DO NOT USE PRSHRTMP UNLESS MPAC, +1 ARE EACH +NZ OR +0, AS THEY ARE
# WHEN THEY CONTAIN THE SF CONSTANTS.)

PRSHRTMP        TS      MPTEMP
                CCS     A
                CA      MPTEMP          # C(A) +,  DO REGULAR SHORTMP
                TCF     SHORTMP +1      # C(A) +0, DO REGULAR SHORTMP
                TCF     -2              # C(A) -,  DO REGULAR SHORTMP
                CS      ZERO            # C(A) -0, FORCE RESULT TO -0 AND RETURN.
                TS      MPAC
                TS      MPAC    +1
                TS      MPAC    +2
                TC      Q

FLASHON         CAF     BIT6            # TURN ON V/N FLASH
                EXTEND                  # BIT 6 OF CHANNEL 11
                WOR     DSALMOUT
                TC      Q

FLASHOFF        CS      BIT6            # TURN OFF V/N FLASH
                EXTEND
                WAND    DSALMOUT        # BIT 6 OF CHANNEL 11
                TC      Q
```

Uses A 80, DSALMOUT 87, IT 185, MPAC 145, MPTEMP 142, N 206, OVFIND 140, Q 80, SAMPTIME 80,

TC 169, TIME2 80, and V 229.

637 ⟨*Page CM0381* 637⟩≡ (504 2773)

```
# INTERNAL USE OF KEYBOARD AND DISPLAY PROGRAM.
#
# USER MUST SCHEDULE CALLS TO NVSUB SO THAT THERE IS NO CONFLICT OF USE OR
# CONFUSION TO OPERATOR.  THE OLD CRABLOCK (INTERNAL/INTERNAL INTERLOCK)
# HAS BEEN REMOVED AND THE INTERNAL USER NO LONGER HAS THE PROTECTION THIS
# OFFERED.
#
# THERE ARE TWO WAYS A JOB CAN BE PUT TO SLEEP BY THE KEYBOARD + DISPLAY
# PROGRAM.      1)      BY ENDIDLE
#               2)      BY NVSUBUSY
# THE BASIC CONVENTION IS THAT ONLY ONE JOB WILL BE PERITTED ASLEEP VIA
# THE KEYBOARD + DISPLAY PROGRAM AT A TIME.  IF A JOB ATTEMPTS TO GO TO
# SLEEP BY MEANS OF (1) OR (2) AND THERE IS ALREADY AJOB ASLEEP THAT WAS
# PUT TO SLEEP BY (1) OR (2), THEN AN ABORT IS CAUSED.
#
# THE CALLING SEQUENCE FOR NVSUB IS
#                       CAF             V/N
#       L               TC              NVSUB
#       L+1             RETURN HERE IF OPERATOR HAS INTERVENED
#       L+2             RETURN HERE AFTER EXECUTION
#
# A ROUTINE CALLED NVSUBUSY IS PROVIDED (USE IS OPTIONAL) TO PUT
# YOUR JOB TO SLEEP UNTIL THE OPERATOR RELEASES THE KEYBOARD + DISPLAY
# SYSTEM.  NVSUBUSY ALSO TURNS ON THE KEY RELEASE LIGHT.
# NVSUBUSY CANNOT BE CALLED FROM ERASABLE OR F/F MEMORY,
# SINCE JOBSLEEP AND JOBWAKE CAN HANDLE ONLY FIXED BANKS.
#
# THE CALLING SEQUENCE IS
#       CAF     WAKEFCADR
#       TC      NVSUBUSY
# .
#
# NVSUBUSY IS INTENDED FOR USE WHEN AN INTERNAL PROGRAM FINDS THE OPERATOR
# IS NOT USING THE KEYBOARD + DISPLAY PROGRAM (BY HIS OWN INITIATION).  IT IS
# NOT INTENDED FOR USE WHEN ONE INTERNAL PROGRAM FINDS ANOTHER INTERNAL
# PROGRAM USING THE KEYBOARD + DISPLAY PROGRAM.
#
# NVSUBUSY ABORTS (WITH CODE 01206) IF A SECOND JOB ATTEMPTS TO GO TO
# SLEEP IN PINBALL.  IN PARTICULAR, IF AN ATTEMPT IS MAKE TO GO TO NVSUBUSY
# WHEN
#
#       1)      DSPLIST NOT= +0.  THIS IS THE CASE WHERE THE CAPACITY FO THE DSPLIST
#               IS EXCEEDED.
#       2)      CADRSTOR NOT= +0.  THIS INDICATES THAT A JOB IS ALREADY USING
```

Uses A 80, CADRSTOR 154, CODE 140, DSPLIST 154, F 238, IT 185, L 80, N 206, TC 169, and V 229.

638 ⟨*Page CM0382* 638⟩≡ (504 2773)

```
# ENDIDLE.  (+-NZ INDICATES A JOB IS ALREADY ASLEEP DUE TO ENDIDLE.)

PRENVBSY        CS      2K+3            # SPECIAL ENTRANCE FOR ROUTINES IN FIXED
                AD      Q               # BANKS ONLY DESIRING THE FCADR OF (LOC
                AD      FBANK           # FROM WHICH THE TC PRENVBSY WAS DONE) -2
NVSUBUSY        TC      POSTJUMP        # TO BE ENTERED.
                CADR    NVSUBSY1
2K+3            OCT     2003

# NVSUBSY1 MUST BE IN BANK 27 OR LOWER, SO IT WILL PUT CALLER TO SLEEP
# WITH HIS PROPER SUPERBITS.

                SETLOC  ENDSPMM +1
                COUNT   07/PIN

NVSUBSY1        TS      L
                TC      ISCADR+0        # ABORT IF CADRSTOR NOT= +0.
                TC      ISLIST+0        # ABORT IF DSPLIST NOT= +0.
                TC      RELDSPON
                CA      L
                TS      DSPLIST
ENDNVBSY        TC      JOBSLEEP

# NVSBWAIT IS A SPECIAL ENTRANCE FOR ROUTINES IN FIXED BANKS ONLY. IF
# SYSTEM IS NOT BUSY, IT EXECUTES V/N AND RETURNS TO L+1 (L= LOC FROM
# WHICH THE TC NVSBWAIT WAS DONE).  IF SYSTEM IS BUSY, IT PUTS CALLING JOB
# TO SLEEP WITH L-1 GOING INTO LIST FOR EVENTUAL WAKING UP WHEN SYSTEM
# IS NOT BUSY.

                SETLOC  NVSUBUSY +3
                COUNT   02/PIN

NVSBWAIT        LXCH    7               # ZERO NVMONOPT OPTIONS
                TS      NVTEMP
                CAF     BIT14
                MASK    MONSAVE1        # EXTERNAL MONITOR BIT
                AD      DSPLOCK
                CCS     A
                TCF     NVSBWT1         # BUSY
                TCF     NVSBCOM         # FREE. NVSUB WILL SAVE L+1 FOR RETURN
                                        # AFTER EXECUTION.
NVSBWT1         INCR    Q               # L+2.  PRENVBSY WILL PUT L-1 INTO LIST AND
                TCF     PRENVBSY        # GO TO SLEEP.

# RELDSP IS USED BY VBPROC, VBTERM, VBRQEXEC, VBRQWAIT, VBRELDSP, EXTENDED
```

```
# VERB DISPATCHER, VBRESEQ, RECALTST.
#
# RELDSP1 IS USED BY MONITOR SET UP, VBRELDSP.

RELDSP          XCH     Q               # SET DSPLOCK TO +0, TURN RELDSP LIGHT
```

Uses A 80, CADRSTOR 154, COUNT 142, DSPLIST 154, DSPLOCK 154, FBANK 80, IT 185, L 80, LOC 145, MONSAVE1 154, N 206, NVTEMP 140, Q 80, SAVE 191, TC 169, and V 229.

639a ⟨*Page CM0383* 639a⟩≡ (504 2773)

```
                TS      RELRET          # OFF, SEARCH DSPLIST
                CS      BIT14
                INHINT
                MASK    MONSAVE1
                TS      MONSAVE1        # TURN OFF EXTERNAL MONITOR BIT
                CCS     DSPLIST
                TC      +2
                TC      RELDSP2         # LIST EMPTY
                CAF     ZERO
                XCH     DSPLIST
                TC      JOBWAKE
RELDSP2         RELINT
                CS      BIT5            # TURN OFF KEY RELEASE LIGHT
                EXTEND                  # (BIT 5 OF CHANNEL 11)
                WAND    DSALMOUT
                CAF     ZERO
                TS      DSPLOCK
                TC      RELRET
RELDSP1         XCH     Q               # SET DSPLOCK TO +0.  NO DSPLIST SEARCH.
                TS      RELRET          # TURN KEY RLSE LIGHT OFF IF DSPLIST IS
                                        # EMPTY.  LEAVE KEY RLSE LIGHT ALONE IF
                                        # DSPLIST IS NOT EMPTY.
                CCS     DSPLIST
                TC      +2              # +     NOT EMPTY.  LEAVE KEY RLSE LIGHT ALONE.
                TC      RELDSP2         # +0    EMPTY.  TURN OFF KEY RLSE LIGHT
                CAF     ZERO            # -     NOT EMPTY.  LEAVE KEY RLSE LIGHT ALONE
                TS      DSPLOCK
                TC      RELRET

ENDPINBF        EQUALS
```

Uses DSALMOUT 87, DSPLIST 154, DSPLOCK 154, MONSAVE1 154, Q 80, RELRET 142, and TC 169.

639b ⟨*Page CM0384* 639b⟩≡ (504 2773)

```
# PINTEST IS NEEDED FOR AUTO CHECK OF PINBALL.

PINTEST         EQUALS  LST2FAN
```

640 ⟨*Page CM0385* 640⟩≡ (504 2773)

```
# VBTSTLTS TURNS ON ALL DISPLAY PANEL LIGHTS.  AFTER 5 SEC, IT TURNS
# OFF THE CAUTION AND STATUS LIGHTS.

                SETLOC  ENDNVSB1 +1

                COUNT   41/PIN

VBTSTLTS        TC      BANKCALL
                CADR    CHKP00H

                INHINT
                CS      BIT1            # SET BIT 1 OF IMODES33 SO IMUMON WON'T
                MASK    IMODES33        # TURN OUT ANY LAMPS.
                AD      BIT1
                TS      IMODES33

                CAF     TSTCON1         # TURN ON UPLINK ACTIVITY, TEMP, KEY RLSE,
                EXTEND                  # V/N FLASH, OPERATOR ERROR.
                WOR     DSALMOUT
                CAF     TSTCON2         # TURN ON NO ATT, GIMBAL LOCK, TRACKER,
                TS      DSPTAB  +11D    # PROG ALM.
                CAF     BIT10           # TURN ON TEST ALARM OUTBIT
                EXTEND
                WOR     CHAN13
                CAF     TEN
TSTLTS1         TS      ERCNT
                CS      FULLDSP
                INDEX   ERCNT
                TS      DSPTAB
                CCS     ERCNT
                TC      TSTLTS1
                CS      FULLDSP1
                TS      DSPTAB +1       # TURN ON 3 PLUS SIGNS
                TS      DSPTAB +4
                TS      DSPTAB +6
                CAF     ELEVEN
                TS      NOUT
                CAF     SHOLTS
                TC      WAITLIST
                EBANK=  DSPTAB
                2CADR   TSTLTS2

                TC      ENDOFJOB        # DSPLOCK IS LEFT BUSY (FROM KEYBOARD
                                        # ACTION) UNTIL TSTLTS3 TO INSURE THAT
                                        # LIGHTS TEST WILL BE SEEN.
```

```
FULLDSP         OCT     05675           # DISPLAY ALL 8'S
FULLDSP1        OCT     07675           # DISPLAY ALL 8'S AND +
TSTCON1         OCT     00175
```

Uses CHAN13 87, COUNT 142, DSALMOUT 87, DSPLOCK 154, DSPTAB 154, EBANK 80, ERCNT 140, IMODES33 163, IT 185, N 206, NOUT 154, TC 169, TEMP 191, and V 229.

642 ⟨*Page CM0386* 642⟩≡ (504 2773)

```
                                        # UPLINK ACTIVITY, TEMP, KEY RLSE,
                                        # V/N FLASH, OPERATOR ERROR.
TSTCON2         OCT     40650           # DSPTAB+11D BITS 4,6,8,9,
                                        # NO ATT, GIMBAL LOCK, TRACKER, PROG ALM.
TSTCON3         OCT     00115           # CHAN 11 BITS 1, 3, 4, 7.
                                        # UPLINK ACITIVY, TEMP, OPERATOR ERROR.
SHOLTS          OCT     764             # 5 SEC

TSTLTS2         CAF     CHRPRIO         # CALLED BY WAITLIST
                TC      NOVAC
                EBANK=  DSPTAB
                2CADR   TSTLTS3

                TC      TASKOVER

TSTLTS3         CS      TSTCON3         # CALLED BY EXECUTIVE
                INHINT
                EXTEND                  # TURN OFF UPLINK ACTIVITY, TEMP,
                WAND    DSALMOUT        # OPERATOR ERROR.
                CS      BIT10           # TURN OFF TEST ALARM OUTBIT
                EXTEND
                WAND    CHAN13
                CAF     BIT4            # MAKE NO ATT FOLLOW BIT 4 OF CHANNEL 12
                EXTEND                  #       (NO TT LIGHT ON IF IN COARSE ALIGN)
                RAND    CHAN12
                AD      BIT15           # TURN OFF AUTO, HOLD, FREE, SPARE,
                TS      DSPTAB  +11D    # GIMBAL LOCK, SPARE, TRACKER, PROG ALM
                CS      13-11,1         # SET BITS TO INDICATE ALL LAMPS OUT. TEST
                MASK    IMODES33        # LIGHTS COMPLETE.
                AD      PRIO16
                TS      IMODES33

                CS      OCT55000
                MASK    IMODES30
                AD      PRIO15          # 15000.
                TS      IMODES30

                CS      OPTMODES
                MASK    BIT7
                ADS     OPTMODES
                RELINT

                TC      BANKCALL        # REDISPLAY C(MODREG)
                CADR    DSPMM
                TC      KILMONON        # TURN ON KILL MONITOR BIT.
```

```
                TC      FLASHOFF        # TURN OFF V/N FLASH.
                TC      POSTJUMP        # DOES RELDSP AND GOES TO PINBRNCH IF
                CADR    TSTLTS4         # ENDIDLE IS AWAITING OPERATOR RESPONSE.
```

Uses CHAN 191, CHAN12 87, CHAN13 87, DSALMOUT 87, DSPTAB 154, EBANK 80, IMODES30 163, IMODES33 163, MODREG 154, N 206, OPTMODES 163, TC 169, TEMP 191, and V 229.

643 ⟨*Page CM0387* 643⟩≡ (504 2773)

```
13-11,1         OCT     16001
OCT55000        OCT     55000
ENDPINS2        EQUALS
```

644 ⟨*Page CM0388* 644⟩≡ (504 2773)

```
# ERROR LIGHT RESET (RSET) TURNS OFF:
# UPLINK ACTIVITY, AUTO, HOLD, FREE, OPERATOR ERROR,
# PROG ALM, TRACKER FAIL.
#
# LEAVES GIMBAL LOCK AND NO ATT ALONE.
#
# IT ALSO ZEROS THE 'TEST ALARM' OUT BIT, WHICH TURNS OFF STBY, RESTART.
# IT ALSO SETS 'CAUTION RESET' TO 1.
# IT ALSO FORCES BIT 12 OF ALL DSPTAB ENTRIES TO 1.

                SETLOC  DOPROC +2
                COUNT   40/PIN

ERROR           XCH     21/22REG        # RESTORE ORIGINAL C(DSPLOCK).  THUS ERROR
                TS      DSPLOCK         # LIGHT RESET LEAVES DSPLOCK CHANGED.
                INHINT
                CAF     BIT10           # TURN ON 'CAUTION RESET' OUTBIT
                EXTEND
                WOR     DSALMOUT        # BIT10 CHAN 11
                CAF     GL+NOATT        # LEAVE GIMBAL LOCK AND NO ATT INTACT,
                MASK    DSPTAB +11D     # TURNING OFF AUTO, HOLD, FREE,
                AD      BIT15           # PROG ALARM, AND TRACKER.
                TS      DSPTAB +11D
                CS      PRIO16          # RESET FAIL BITS WHICH GENERATE PROG
                MASK    IMODES33        # ALARM SO THAT IF THE FAILURE STILL
                AD      PRIO16          # EXISTS, THE ALARM WILL COME BACK.
                TS      IMODES33
                CS      BIT10
                MASK    IMODES30
                AD      BIT10
                TS      IMODES30

                CS      OPTMODES
                MASK    BIT7
                ADS     OPTMODES
                CS      BIT10           # TURN OFF 'TEST ALARM' OUTBIT
                EXTEND
                WAND    CHAN13
                CS      ERCON           # TURN OFF UPLINK ACTIVITY,
                EXTEND                  # OPERATOR ERROR.
                WAND    DSALMOUT
TSTAB           CAF     BINCON          # (DEC 10)
                TS      ERCNT           # ERCNT = COUNT
                INHINT
                INDEX   ERCNT
```

```
                CCS     DSPTAB
                AD      ONE
                TC      ERPLUS
                AD      ONE
ERMINUS         CS      A
                MASK    NOTBIT12
                TC      ERCOM
```

Uses 21/22REG 140, A 80, CHAN 191, CHAN13 87, COUNT 142, DSALMOUT 87, DSPLOCK 154, DSPTAB 154, ERCNT 140, IMODES30 163, IMODES33 163, IT 185, OPTMODES 163, RESTART 57, and TC 169.

645 ⟨*Page CM0389* 645⟩≡ (504 2773)

```
ERPLUS          CS      A
                MASK    NOTBIT12
                CS      A               # MIGHT WANT TO RESET CLPASS, DECBRNCH,
ERCOM           INDEX   ERCNT           # ETC.
                TS      DSPTAB
                RELINT
                CCS     ERCNT
                TC      TSTAB   +1
                CAF     ZERO
                TS      FAILREG
                TS      FAILREG +1
                TS      FAILREG +2
                TS      SFAIL
                TC      ENDOFJOB

ERCON           OCT     104             # CHAN 11 BITS 3,7.
                                        # UPLINK ACTIVITY, AND OPERATOR ERROR.
BITS6,8         OCT     240
GL+NOATT        OCT     00050           # NO ATT AND GIMBAL LOCK LAMPS
NOTBIT12        OCT     73777

ENDPINS1        EQUALS

                SBANK=  LOWSUPER
```

Uses A 80, CHAN 191, CLPASS 154, DECBRNCH 152, DSPTAB 154, ERCNT 140, FAILREG 150, LOWSUPER 67, SFAIL 165, and TC 169.

3.3.12 r60-62 code

646 ⟨*r60-62 code* 646⟩≡ (245b)
⟨*Page CM0390* 647⟩
⟨*Page CM0391* 649⟩
⟨*Page CM0392* 650⟩
⟨*Page CM0393* 651⟩
⟨*Page CM0394* 653⟩
⟨*Page CM0395* 655⟩
⟨*Page CM0396* 657⟩
⟨*Page CM0397* 658a⟩
⟨*Page CM0398* 658b⟩

647 ⟨*Page CM0390* 647⟩≡ (646 2787)

```
                BANK    34
                SETLOC  MANUVER
                BANK

                EBANK=  TEMPR60

                COUNT   27/R60

# CONFORMS TO GSOP CHAPTER FOUR REVISION LOGIC 09       JAN 18, 1968

R60CSM          TC      MAKECADR
                TS      TEMPR60

# INSERT PRIODSP CHECK WITH R22 (V06N49) WITH JENNINGS BRODEUR

REDOMANN        CAF     BIT6
                MASK    FLAGWRD5        # IS 3-AXIS FLAG SET
                CCS     A
                TCF     TOBALL          # YES
                TC      INTPRET
                CALL
                        VECPOINT        # TO COMPUTE FINAL ANGLES
                STORE   CPHI            # STORE FINAL ANGLES -- CPHI, CTHETA, CPSI
                EXIT

TOBALL          CAF     V06N18
                TC      BANKCALL
                CADR    GOPERF2R        # DISPLAY PLEASE PERFORM AUTO MANEUVER
                TC      R61TEST
                TC      REDOMANC        # PROCEED
                TCF     ENDMANU1        # ENTER I.E., FINISHED WITH R60

                TC      CHKLINUS        # TO CHECK FOR PRIORITY DISPLAYS
                TC      ENDOFJOB

REDOMANC        CAF     BIT6
                MASK    FLAGWRD5        # IS 3-AXIS FLAG SET
                CCS     A
                TCF     TOBALLC         # YES
                TC      INTPRET
                CALL
                        VECPOINT        # TO COMPUTE FINAL ANGLES
                STORE   CPHI            # STORE ANGLES
                EXIT
```

```
TOBALLC          CAF      PRIO30          # IS MODE AUTO AND CTL GNC
```

Uses A 80, COUNT 142, CPHI 157, CPSI 157, CTHETA 157, DISPLAYS 59, EBANK 80, FLAGWRD5 113, I 206, MANUVER 65, MODE 145, PRIORITY 145, TC 169, and TEMPR60 157.

649 ⟨*Page CM0391* 649⟩≡ (646 2787)

```
                EXTEND
                RXOR    CHAN31
                MASK    13,14,15
                EXTEND
                BZF     +2              # AUTO, NON-FLASH N18
                TCF     TOBALL          # NOT AUTO

                CAF     V06N18          # STATIC UP NON-FLASHING V06 N18
                TC      BANKCALL
                CADR    GODSPR
                TC      CHKLINUS

STARTMNV        TC      BANKCALL
                CADR    GOMANUR
ENDMANUV        TCF     TOBALL          # FINISHED MANEUVER.

ENDMANU1        TC      DOWNFLAG        # RESET 3-AXIS FLAG
                ADRES   3AXISFLG        # BIT 6 FLAG 5
                CAE     TEMPR60
                TC      BANKJUMP

CHKLINUS        CS      FLAGWRD4
                MASK    BIT12           # IS PRIORITY DISPLAY FLAG SET?
                CCS     A
                TC      Q               # NO -- EXIT
                CA      Q
                TS      MPAC +2         # SAVE RETURN
                CS      THREE           # OBTAIN LOCATION FOR RESTART
                AD      BUF2            # HOLD Q OF LAST DISPLAY
                TS      TBASE1

                TC      PHASCHNG
                OCT     71              # 1.7SPOT FOR RELINUS

                CAF     BIT7
                TC      LINUS           # GO SET BITS FOR PRIORITY DISPLAY
                TC      MPAC +2

RELINUS         CAF     BIT5            # IS TRACK FLAG ON
                MASK    FLAGWRD1
                EXTEND
                BZF     GOREDO20        # NO

                TC      UPFLAG
                ADRES   PDSPFLAG        # R60 PRIODSP FLAG
```

```
                TC      UPFLAG
                ADRES   TARG1FLG        # FOR R52

                CAF     ZERO            # RESET TO ZERO, SINCE
```

Uses 3AXISFLG 115, A 80, BUF2 142, CHAN31 87, FLAGWRD1 97, FLAGWRD4 109, MPAC 145, PDSPFLAG 109, PRIORITY 145, Q 80, RESTART 57, SAVE 191, TARG1FLG 99, TBASE1 154, TC 169, and TEMPR60 157.

650 ⟨*Page CM0392* 650⟩≡ (646 2787)

```
                TS      OPTIND          # OPTIND WAS SET TO -1 BY V379

                CAF     PRIO14          # RESTORE ORIGINAL PRIORITY
                TC      PRIOCHNG

                TC      TBASE1

GOREDO20        TC      PHASCHNG
                OCT     111             # 1.11 FOR PIKUP20

                TC      ENDOFJOB

R61TEST         CA      MODREG          # ARE WE IN P00.  IF YES THIS MUST BE
                EXTEND                  #       VERB49 OR VERB89 SO DO ENDEXT.
                BZF     ENDMANU1        # RESET 3-AXIS & RETURN.  USER DOES ENDEXT
                CA      FLAGWRD4        # ARE WE IN R61 (P20)
                MASK    BIT12
                EXTEND
                BZF     GOTOP00H        # NO
                TC      GOTOV56         # YES

BIT14+7         OCT     20100
V06N18          VN      0618
```

Uses FLAGWRD4 109, MODREG 154, OPTIND 161, PRIORITY 145, TBASE1 154, TC 169, and VN 159.

651 ⟨*Page CM0393* 651⟩≡ (646 2787)

```
# PROGRAM DESCRIPTION -- VECPOINT
#
# THIS INTERPRETIVE SUBROUTINE MAY BE USED TO POINT A SPACECRAFT AXIS IN A DESIRED DIRECTION.
# TO BE POINTED MUST APPEAR AS A HALF UNIT DOUBLE PRECISION VECTOR IN SUCCESSIVE LOCATIONS OF E
# BEGINNING WITH THE LOCATION CALLED SCAXIS.  THE COMPONENTS OF THIS VECTOR ARE GIVEN IN SPACEC
# THE DIRECTION IN WHICH THIS AXIS IS TO BE POINTED MUST APPEAR AS A HALF UNIT DOUBLE PRECISION
# SUCCESSIVE LOCATIONS OF ERASABLE MEMORY BEGINNING WITH THE ADDRESS CALLED POINTVSM.  THE COMP
# VECTOR ARE GIVEN IN STABLE MEMBER COORDINATES.  WITH THIS INFORMATION VECPOINT COMPUTES A SET
# ANGLES (2'S COMPLEMENT) CORRESPONDING TO THE CROSS-PRODUCT ROTATION BETWEEN SCAXIS AND POINTV
# IN T(MPAC) BEFORE RETURNING TO THE CALLER.
#
# THIS ROTATION, HOWEVER, MAY BRING THE S/C INTO GIMBAL LOCK.  WHEN POINTING A VECTOR IN THE Y-
# THE TRANSPONDER AXIS, OR THE AOT FOR THE LEM, THE PROGRAM WILL CORRECT THIS PROGLEM BY ROTATI
# PRODUCT ATTITUDE ABOUT POINTVSM BY A FIXED AMOUNT SUFFICIENT TO ROTATE THE DESIRED S/C ATTITU
# LOCK.  IF THE AXIS TO BE POINTED IS MORE THAN 40.6 DEGREES BUT LESS THAN 60.5 DEG FROM THE +X
# THE ADDITIONAL ROTATION TO AVOID GIMBAL LOCK IS 35 DEGREES.  IF THE AXIS IS MORE THAN 60.5 DE
# THE ADDITIONAL ROTATION IS 35 DEGREES.  THE GIMBAL ANGLES CORRESPONDING TO THIS ATTITUDE ARE
# STORED AS 2'S COMPLEMENT ANGLES N T(MPAC) BEFORE RETURNING TO THE CALLER.
#
# WHEN POINTING THE X-AXIS, OR THE THRUST VECTOR, OR ANY VECTOR WITHIN 40.6 DEG OF THE X-AXIS,
# CANNOT CORRECT FOR A CROSS-PRODUCT ROTATION INTO GIMBAL LOCK.  IN THIS CASE A PLATFORM REALIG
# REQUIRED TO POINT THE VECTOR IN THE DESIRED DIRECTION.  AT PRESENT NO INDICATION IS GIVEN FOR
# EXCEPT THAT THE FINAL MIDDLE GIMBAL ANGLE IN MPAC +2 IS GREATER THAN 59 DEGREES.
#
# CALLING SEQUENCE
#
#       1)      LOAD SCAXIS, POINTVSM
#       2)      CALL
#                       VECPOINT
#
# RETURNS WITH
#
#       1)      DESIRED OUTER GIMBAL ANGLE IN MPAC
#       2)      DESIRED INNER GIMBAL ANGLE IN MPAC +1
#       3)      DESIRED MIDDLE GIMBAL ANGLE IN MPAC +2
#
# ERASABLES USED --
#
#       1)      SCAXIS          6
#       2)      POINTVSM        6
#       3)      MIS             18
#       4)      DEL             18
#       5)      COF             6
#       6)      VECQTEMP        1
#       7)      ALL OF VAC AREA 43
```

```
#
#                       TOTAL   99

                SETLOC  VECPT
                BANK
```

Uses A 80, COF 219, DEL 232, MIS 219, MPAC 145, N 206, POINTVSM 219, SCAXIS 219, THRUST 85, VECPT 67, VECQTEMP 218, and Z 80.

653 ⟨*Page CM0394* 653⟩≡ (646 2787)

```
                EBANK=  BCDU

                COUNT   27/VECPT

VECPOINT        STQ     BOV             # SAVE RETURN ADDRESS
                        VECQTEMP
                        VECLEAR         # AND CLEAR OVFIND
VECLEAR         AXC,2   RTB
                        MIS             # READ THE PRESENT CDU ANGLES AND
                        READCDUK        # STORE THEM IN PD25, 26, 27
                STCALL  25D
                        CDUTODCM        # S/C AXES TO STABLE MEMBER AXES (MIS)
                VLOAD   VXM
                        POINTVSM        # RESOLVE THE POINTING DIRECTION VF INTO
                        MIS             # INITIAL S/C AXES (VF = POINTVSM)
                UNIT
                STORE   28D
                                        # PD 28 29 30 31 32 33
                VXV     UNIT            # TAKE THE CROSS PRODUCT VF X VI
                        SCAXIS          # WHERE VI = SCAXIS
                BOV     VCOMP
                        PICKAXIS
                STODL   COF             # CHECK MAGNITUDE
                        36D             # OF CROSS PRODUCT
                DSU     BMN             # VECTOR, IF LESS
                        DPB-14          # THAN B-14 ASSUME
                        PICKAXIS        # UNIT OPERATION
                VLOAD   DOT             # INVALID.
                        SCAXIS
                        28D
                SL1     ARCCOS
COMPMATX        CALL                    # NO COMPUTE THE TRANSFORMATION FROM
                        DELCOMP         # FINAL S/C AXES TO INITIAL S/C AXES MFI
                AXC,1   AXC,2
                        MIS             # COMPUTE THE TRANSFORMATION FROM FINAL
                        DEL             # S/C AXES TO STABLE MEMBER AXES
                CALL                    # MFS = MIS MFI
                        MXM3            # (IN PD LIST)

                DLOAD   ABS
                        6               # MFS6 = SIN(CPSI)                    $2
                DSU     BMN
                        SINGIMLC        # = SIN(59 DEGS)                      $2
                        FINDGIMB        # /CPSI/ LESS THAN 59 DEGS.
                                        # I.E., DESIRED ATTITUDE NOT IN GIMBAL LOCK
```

```
                DLOAD   ABS             # CHECK TO SEE IF WE ARE POINTING
                        SCAXIS          # THE THRUST AXIS
                DSU     BPL
                        SINVEC1         # SIN 49.4 DEGS                          $2
```

Uses BCDU 219, COF 219, COUNT 142, CPSI 157, DEL 232, EBANK 80, I 206, MFI 232, MFS 232, MIS 219, OVFIND 140, POINTVSM 219, SAVE 191, SCAXIS 219, THRUST 85, VECPT 67, and VECQTEMP 218.

655 ⟨*Page CM0395* 655⟩≡ (646 2787)

```
                        FINDGIMB        # IF SO, WE ARE TRYING TO POINT IT INTO
                VLOAD                   # GIMBAL LOCK, ABORT COULD GO HERE
                STADR
                STOVL   MIS +12D
                STADR                   # STORE MFS (IN PD LIST) IN MIS
                STOVL   MIS +6
                STADR
                STOVL   MIS
                        MIS +6          # INNER GIMBAL AXIS IN FINAL S/C AXES
                BPL     VCOMP           # LOCATE THE IG AXIS DIRECTION CLOSEST TO
                        IGSAMEX         # FINAL X S/C AXIS

IGSAMEX         VXV     BMN             # FIND THE SHORTEST WAY OF ROTATING THE
                        SCAXIS          # S/C OUT OF GIMBAL LOCK BY A ROTATION
                        U=SCAXIS        # ABOUT +- SCAXIS, I.E., IF  (IG (SGN MFS3)
                                        # X SCAXIS . XF) LESS THAN Q, U = SCAXIS
                                        # OTHERWISE U = -SCAXIS.

                VLOAD   VCOMP
                        SCAXIS
                STCALL  COF             # ROTATE ABOUT -SCAXIS
                        CHEKAXIS
U=SCAXIS        VLOAD
                        SCAXIS
                STORE   COF             # ROTATE ABOUT + SCAXIS
CHEKAXIS        DLOAD   ABS
                        SCAXIS          # SEE IF WE ARE POINTING THE AOT
                DSU     BPL
                        SINVEC2         # SIN 29.5 DEGS                        $2
                        PICKANG1        # IF SO, ROTATE 50 DEGS ABOUT +- SCAXIS
                DLOAD   GOTO            # IF NOT, MUST BE POINTING THE TRANSPONDER
                        VECANG2         # OR SOME VECTOR IN THE Y, OR Z PLANE
                        COMPMFSN        # IN THIS CASE ROTATE 35 DEGS TO GET OUT
                                        # OF GIMBAL LOCK (VECANG2 $360)
PICKANG1        DLOAD
                        VECANG1         # = 50 DEGS.                         $360
COMPMFSN        CALL
                        DELCOMP         # COMPUTE THE ROTATION ABOUT SCAXIS TO
                AXC,1   AXC,2           # BRING MFS OUT OF GIMBAL LOCK
                        MIS
                        DEL
                CALL                    # COMPUTE THE NEW TRANSFORMATION FROM
                        MXM3            # DESIRED S/C AXES TO STABLE MEMBER AXES
                                        # WHICH WILL ALIGN VI WITH VF AND AVOID
                                        # GIMBAL LOCK
```

```
FINDGIMB        AXC,1   CALL
                        0               # EXTRACT THE COMMANDED CDU ANGLES FROM
                        DCMTOCDU        # THIS MATRIX
                RTB     SETPD
                        V1STO2S         # CONVERT TO 2'S COMPLEMENT
```

Uses A 80, COF 219, DEL 232, I 206, IT 185, MFS 232, MIS 219, Q 80, SCAXIS 219, and Z 80.

657 ⟨*Page CM0396* 657⟩≡ (646 2787)

```
                        0
                GOTO
                        VECQTEMP        # RETURN TO CALLER

PICKAXIS        VLOAD   DOT             # IF VF X VI = 0, FIND VF, VI
                        28D
                        SCAXIS
                BMN     TLOAD
                        ROT180
                        25D
                GOTO                    # IF VF = VI, CDU DESIRED = PRESENT CDU
                        VECQTEMP        # PRESENT CDU ANGLES

ROT180          VLOAD   VXV             # IF VF, VI ANTI-PARALLEL, 180 DEG ROTATION
                        MIS +6          # IS REQUIRED.  Y STABLE MEMBER AXIS IN
                        HIUNITX         # INITIAL S/C AXES.
                UNIT    VXV             # FIND Y(SM) X X(I)
                        SCAXIS          # FIND UNIT(VI X UNIT(Y(SM) X X(I)))
                UNIT    BOV             # I.E., PICK A VECTOR IN THE PLANE OF X(I),
                        PICKX           # Y(SM) PERPENDICULAR TO VI
                STODL   COF
                        36D             # CHECK MAGNITUDE
                DSU     BMN             # OF THIS VECTOR.
                        DPB-14          # IF LESS THAN B-14,
                        PICKX           # PICK X-AXIS.
                VLOAD
                        COF
XROT            STODL   COF
                        HIDPHALF
                GOTO
                        COMPMATX
PICKX           VLOAD   GOTO            # PICK THE XAXIS IN THIS CASE
                        HIUNITX
                        XROT
                BANK    35
                SETLOC  MANUVER1
                BANK

SINGIMLC        2DEC    .4285836003     # = SIN(59)                          $2

SINVEC1         2DEC    .3796356537     # = SIN(49.4)                        $2

SINVEC2         2DEC    .2462117800     # = SIN(29.5)                        $2

VECANG1         2DEC    .1388888889     # = 50 DEGREES                     $360
```

```
VECANG2         2DEC    .09722222222    # = 35 DEGREES                        $360


1BITDP          OCT     0               # KEEP THIS BEFORE DPB(-14)        ********
DPB-14          OCT     00001
```

Uses A 80, COF 219, HIDPHALF 71, HIUNITX 71, I 206, MANUVER1 65, MIS 219, SCAXIS 219, and VECQTEMP 218.

658a ⟨*Page CM0397* 658a⟩≡ (646 2787)

```
                OCT     00000
                BANK    34
                SETLOC  MANUVER
                BANK
```

Uses MANUVER 65.

658b ⟨*Page CM0398* 658b⟩≡ (646 2787)

```
# ROUTINE FOR INITIATING AUTOMATIC MANEUVER VIA KEYBOARD (V49)

                EBANK=  CPHI

                COUNT   27/R62

R62DISP         CAF     V06N22          # DISPLAY COMMAND ICDUS CPHI, CTHETA, CPHI
                TC      BANKCALL
                CADR    GOFLASH
                TCF     ENDEXT
                TCF     GOMOVE          # PROCEED
                TCF     R62DISP         # ENTER

                                        # ASTRONAUT MAY LOAD NEW ICDUS AT THIS
                                        # POINT.
GOMOVE          TC      UPFLAG          # SET FOR 3-AXIS MANEUVER
                ADRES   3AXISFLG

                TC      BANKCALL
                CADR    R60CSM
                TCF     ENDEXT
```

Uses 3AXISFLG 115, COMMAND 169, COUNT 142, CPHI 157, CTHETA 157, EBANK 80, and TC 169.

3.3.13 anglfind code

659 ⟨*anglfind code* 659⟩≡ (245b)

⟨*Page CM0399* 660⟩
⟨*Page CM0400* 662⟩
⟨*Page CM0401* 664⟩
⟨*Page CM0402* 666⟩
⟨*Page CM0403* 667⟩
⟨*Page CM0404* 668⟩
⟨*Page CM0405* 670⟩
⟨*Page CM0406* 672⟩
⟨*Page CM0407* 674⟩
⟨*Page CM0408* 676⟩
⟨*Page CM0409* 678⟩
⟨*Page CM0410* 680⟩
⟨*Page CM0411* 681a⟩

660 ⟨*Page CM0399* 660⟩≡ (659 2641)

```
                BANK    15
                SETLOC  KALCMON1
                BANK

                EBANK=  BCDU

                COUNT   22/KALC

KALCMAN3        TC      INTPRET
                RTB
                        READCDUK        # PICK UP CURRENT CDU ANGLES
                STORE   BCDU            # STORE THE INITIAL S/C ANGLES
                AXC,2   TLOAD           # COMPUTE THE TRANSFORMATION FROM
                        MIS             # INITIAL S/C AXES TO STABLE MEMBER AXES
                        BCDU            # (MIS)
                CALL
                        CDUTODCM
                AXC,2   TLOAD           # COMPUTE THE TRANSFORMATION FROM
                        MFS             # FINAL S/C AXES TO STABLE MEMBER AXES
                        CPHI            # (MFS)
                CALL
                        CDUTODCM
SECAD           AXC,1   CALL            # MIS AND MFS ARRAYS CALCULATED         $2
                        MIS
                        TRANSPOS
                VLOAD
                STADR
                STOVL   TMIS +12D
                STADR
                STOVL   TMIS +6
                STADR
                STORE   TMIS            # TMIS = TRANSPOSE(MIS) SCALED BY 2
                AXC,1   AXC,2
                        TMIS
                        MFS
                CALL
                        MXM3
                VLOAD   STADR
                STOVL   MFI +12D
                STADR
                STOVL   MFI +6
                STADR
                STORE   MFI             # MFI = TMIS MFS (SCALED BY 4)
                SETPD   CALL            # TRANSPOSE MFI IN PD LIST
                        18D
```

```
        TRNSPSPD
VLOAD   STADR
STOVL   TMFI +12D
STADR
STOVL   TMFI +6
```

Uses BCDU 219, COUNT 142, CPHI 157, EBANK 80, KALCMON1 63, MFI 232, MFS 232, MIS 219, TC 169, TMFI 219, and TMIS 219.

662 ⟨*Page CM0400* 662⟩≡ (659 2641)

```
                STADR
                STORE   TMFI            # TMFI = TRANSPOSE (MFI)  SCALED BY 4

  # CALCULATE COFSKEW AND MFISYM

                DLOAD   DSU
                        TMFI +2
                        MFI +2
                PDDL    DSU             # CALCULATE COF SCALED BY 2/SIN(AM)
                        MFI +4
                        TMFI +4
                PDDL    DSU
                        TMFI +10D
                        MFI +10D
                VDEF
                STORE   COFSKEW         # EQUALS MFISKEW

  # CALCULATE AM AND PROCEED ACCORDING TO ITS MAGNITUDE

                DLOAD   DAD
                        MFI
                        MFI +16D
                DSU     DAD
                        DP1/4TH
                        MFI +8D
                STORE   CAM             # CAM = (MFI0+MFI4+MFI8-1)/2 HALF SCALE
                ARCCOS
                STORE   AM              # AM=ARCCOS(CAM)  (AM SCALED BY 2)
                DSU     BPL
                        MINANG
                        CHECKMAX
                EXIT                    # MANEUVER LESS THAN 0.25 DEG
                INHINT                  # GO DIRECTLY INTO ATTITUDE HOLD
                CS      ONE             # ABOUT COMMANDED ANGLES
                TS      HOLDFLAG        # NOGO WILL STOP ANY RATE AND SET UP FOR A
                TC      LOADCDUD        # GOOD RETURN
                TCF     NOGO

  CHECKMAX      DLOAD   DSU
                        AM
                        MAXANG
                BPL     VLOAD
                        ALTCALC         # UNIT
                        COFSKEW         # COFSKEW
                UNIT
```

```
                STORE   COF             # COF IS THE MANEUVER AXIS
                GOTO                    # SEE IF MANEUVER GOES THRU GIMBAL LOCK
                        LOCSKIRT
  ALTCALC       VLOAD   VAD             # IF AM GREATER THAN 170 DEGREES
                        MFI
```

Uses A 80, AM 219, CAM 219, COF 219, COFSKEW 219, HOLDFLAG 163, MFI 232, MFISYM 219, TC 169, and TMFI 219.

664 ⟨*Page CM0401* 664⟩≡ (659 2641)

```
                        TMFI
                VSR1
                STOVL   MFISYM
                        MFI +6
                VAD     VSR1
                        TMFI +6
                STOVL   MFISYM +6
                        MFI +12D
                VAD     VSR1
                        TMFI +12D
                STORE   MFISYM +12D     # MFISYM=(MFI+TMFI)/2   SCALED BY 4

# CALCULATE COF

                DLOAD   SR1
                        CAM
                PDDL    DSU             # PD0 CAM                            $4
                        DPHALF
                        CAM
                BOVB    PDDL            # PD2 1 - CAM                        $2
                        SIGNMPAC
                        MFISYM +16D
                DSU     DDV
                        0
                        2
                SQRT    PDDL            # COFZ = SQRT(MFISYM8-CAM)/(1-CAM)
                        MFISYM +8D      #                                $ ROOT 2
                DSU     DDV
                        0
                        2
                SQRT    PDDL            # COFY = SQRT(MFISYM4-CAM)/(1-CAM) $ROOT2
                        MFISYM
                DSU     DDV
                        0
                        2
                SQRT    VDEF            # COFX = SQRT(MFISYM-CAM)/(1-CAM) $ROOT 2
                UNIT
                STORE   COF

# DETERMINE LARGEST COF AND ADJUST ACCORDINGLY

COFMAXGO        DLOAD   DSU
                        COF
                        COF +2
                BMN     DLOAD           # COFY G COFX
```

```
                COMP12
                COF
        DSU     BMN
                COF +4
```

Uses CAM 219, COF 219, MFI 232, MFISYM 219, and TMFI 219.

666 ⟨*Page CM0402* 666⟩≡ (659 2641)

```
                        METHOD3         # COFZ G COFX OR COFY
                GOTO
                        METHOD1         # COFX G COFY OR COFZ
COMP12          DLOAD   DSU
                        COF +2
                        COF +4
                BMN
                        METHOD3         # COFZ G COFY OR COFX

METHOD2         DLOAD   BPL             # COFY MAX
                        COFSKEW +2      # UY
                        U2POS
                VLOAD   VCOMP
                        COF
                STORE   COF
U2POS           DLOAD   BPL
                        MFISYM +2       # UX UY
                        OKU21
                DLOAD   DCOMP           # SIGN OF UX OPPOSITE TO UY
                        COF
                STORE   COF
OKU21           DLOAD   BPL
                        MFISYM +10D     # UY UZ
                        LOCSKIRT
                DLOAD   DCOMP           # SIGN OF UZ OPPOSITE TO UY
                        COF +4
                STORE   COF +4
                GOTO
                        LOCSKIRT
METHOD1         DLOAD   BPL             # COFX MAX
                        COFSKEW         # UX
                        U1POS
                VLOAD   VCOMP
                        COF
                STORE   COF
U1POS           DLOAD   BPL
                        MFISYM +2       # UX UY
                        OKU12
                DLOAD   DCOMP
                        COF +2          # SIGN OF UY OPPOSITE TO UX
                STORE   COF +2
OKU12           DLOAD   BPL
                        MFISYM +4       # UX UZ
                        LOCSKIRT
                DLOAD   DCOMP           # SIGN OF UZ OPPOSITE TO UY
```

```
                        COF +4
                STORE   COF +4
                GOTO
                        LOCSKIRT
METHOD3         DLOAD   BPL             # COFZ MAX
```

Uses COF 219, COFSKEW 219, and MFISYM 219.

667 ⟨*Page CM0403* 667⟩≡ (659 2641)

```
                        COFSKEW +4      # UZ
                        U3POS
                VLOAD   VCOMP
                        COF
                STORE   COF
U3POS           DLOAD   BPL
                        MFISYM +4       # UX UZ
                        OKU31
                DLOAD   DCOMP
                        COF             # SIGN OF UX OPPOSITE TO UZ
                STORE   COF
OKU31           DLOAD   BPL
                        MFISYM +10D     # UY UZ
                        LOCSKIRT
                DLOAD   DCOMP
                        COF +2  # SIGN OF UY OPPOSITE TO UZ
                STORE   COF +2
                GOTO
                        LOCSKIRT
```

Uses COF 219, COFSKEW 219, and MFISYM 219.

668 ⟨*Page CM0404* 668⟩≡ (659 2641)

```
# MATRIX OPERATIONS

MXM3            SETPD                   # MXM3 MULTIPLIES 2 3X3 MATRICES
                        0               # AND LEAVES RESULT IN PD LIST
                DLOAD*  PDDL*           # ADDRESS OF 1ST MATRIX IN XR1
                        12D,2           # ADDRESS OF 2ND MATRIX IN XR2
                        6,2
                PDDL*   VDEF            # DEFINE VECTOR M2(COL 1)
                        0,2
                MXV*    PDDL*           # M1XM2(COL 1) IN PD
                        0,1
                        14D,2
                PDDL*   PDDL*
                        8D,2
                        2,2
                VDEF    MXV*            # DEFINE VECTOR M2(COL 2)
                        0,1
                PDDL*   PDDL*           # M1XM2(COL2) IN PD
                        16D,2
                        10D,2
                PDDL*   VDEF            # DEFINE VECTOR M2(COL 3)
                        4,2
                MXV*    PUSH            # M1XM2(COL 3) IN PD
                        0,1
                GOTO
                        TRNSPSPD        # REVERSE ROWS AND COLS IN PD AND
# RETURN WITH M1XM2 IN PD LIST

TRANSPOS        SETPD   VLOAD*          # TRANSPOS TRANSPOSES A 3X3 MATRIX
                        0               #  AND LEAVES RESULT IN PD LIST
                        0,1             # MATRIX ADDRESS IN XR1
                PDVL*   PDVL*
                        6,1
                        12D,1
                PUSH                    # MATRIX IN PD
TRNSPSPD        DLOAD   PDDL            # ENTER WITH MATRIX IN PD LIST
                        2
                        6
                STODL   2
                STADR
                STODL   6
                        4
                PDDL
                        12D
                STODL   4
```

```
STADR
STODL   12D
        10D
PDDL
```

Uses A 80.

670 ⟨*Page CM0405* 670⟩≡ (659 2641)

```
                        14D
                STODL   10D
                STADR
                STORE   14D
                RVQ                     # RETURN WITH TRANSPOSED MATRIX IN PD LIST
MINANG          DEC     .00069375
MAXANG          DEC     .472222
# GIMBAL LOCK CONSTANTS

# D = MGA CORRESPONDING TO GIMBAL LOCK = 60 DEGREES
# NGL = BUFFER ANGLE (TO AVOID DIVISIONS BY ZERO) = 2 DEGREES

SD              DEC     .433015         # = SIN(D)                              $2
K3S1            DEC     .86603          # = SIN(D)                              $2
K4              DEC     -.25            # = -COS(D)                             $2
K4SQ            DEC     .125            # = COS(D)COS(D)                        $2
SNGLCD          DEC     .008725         # = SIN(NGL)COS(D)                      $2
CNGL            DEC     .499695         # = COS(NGL)                            $2
READCDUK        INHINT                  # LOAD T(MPAC) WITH THE CURRENT CDU ANGLES
                CA      CDUZ
                TS      MPAC +2
                EXTEND
                DCA     CDUX
                RELINT
                TCF     TLOAD +6
                BANK    16
                SETLOC  KALCMON2
                BANK

                COUNT*  $$/KALC

CDUTODCM        AXT,1   SSP             # SUBROUTINE TO COMPUTE  DIRECTION COSINE
                OCT     3               # MATRIX RELATING S/C AXES TO STABLE
                        S1              # MEMBER AXES FROM 3 CDU ANGLES IN T(MPAC)
                OCT     1               # SET XR1, S1, AND PD FOR LOOP
                STORE   7
                SETPD
                        0
LOOPSIN         SLOAD*  RTB
                        10D,1
                        CDULOGIC
                STORE   10D             # LOAD PD WITH 0 SIN(PHI)
                SIN     PDDL            #              2 COS(PHI)
                        10D             #              4 SIN(THETA)
                COS     PUSH            #              6 COS(THETA)
```

```
TIX,1   DLOAD           #              8 SIN(PSI)
        LOOPSIN         #             10 COS(PSI)
        6
DMP     SL1
        10D
```

Uses CDUX 80, CDUZ 80, COUNT 142, D 226, KALCMON2 63, MPAC 145, S1 85, and THETA 148.

672 ⟨*Page CM0406* 672⟩≡ (659 2641)

```
STORE   0,2
DLOAD
        4
DMP     PDDL
        0               # (PD6 SIN(THETA)SIN(PHI))
        6
DMP     DMP
        8D
        2
SL1     BDSU
        12D
SL1
STORE   2,2
DLOAD
        2
DMP     PDDL            # (PD7 COS(PHI)SIN(THETA)) SCALED 4
        4
        6
DMP     DMP
        8D
        0
SL1
DAD     SL1
        14D
STORE   4,2
DLOAD
        8D
STORE   6,2
DLOAD
        10D
DMP     SL1
        2
STORE   8D,2
DLOAD
        10D
DMP     DCOMP
        0
SL1
STORE   10D,2
DLOAD
        4
DMP     DCOMP
        10D
SL1
STORE   12D,2
```

```
DLOAD
DMP     SL1             # (PUSH UP 7)
        8D
PDDL    DMP             # (PD7 COS(PHI)SIN(THETA)SIN(PSI)) SCALE4
        6
```

Uses THETA 148.

674 ⟨*Page CM0407* 674⟩≡ (659 2641)

```
                        0
                DAD     SL1             #  (PUSH UP 7)
                STADR                   # C7=COS(PHI)SIN(THETA)SIN(PSI)
                STORE   14D,2
                DLOAD
                DMP     SL1             #  (PUSH UP 6)
                        8D
                PDDL    DMP             #  (PD6 SIN(THETA)SIN(PHI)SIN(PSI)) SCALE4
                        6
                        2
                DSU     SL1             #  (PUSH UP 6)
                STADR
                STORE   16D,2           # C8=-SIN(THETA)SIN(PHI)SIN(PSI)
                RVQ                     #  +COS(THETA)COS(PHI)
ENDOCM          EQUALS

                BANK    15
                SETLOC  KALCMON1
                BANK

# CALCULATION OF THE MATRIX DEL.......
#
#       *      *               --T           *
#       DEL = (IDMATRIX)COS(A)+UU (1-COS(A))+UX SIN(A)          SCALED 1
#
#             -
#       WHERE U IS A UNIT VECTOR (DP SCALED 2) ALONG THE AXIS OF ROTATION.
#       A IS THE ANGLE OF ROTATION (DP SCALED 2)
#                                               -
#       UPON ENTRY THE STARTING ADDRESS OF U IS COF, AND A IS IN MPAC

                COUNT   22/KALC

DELCOMP         SETPD   PUSH            # MPAC CONTAINS THE ANGLE A
                        0
                SIN     PDDL            # PD0 = SIN(A)
                COS     PUSH            # PD2 = COS(A)
                SR2     PDDL            # PD2 = COS(A)                        $8
                BDSU    BOVB            # PD4 = 1-COS(A)                      $2
                        DPHALF
                        SIGNMPAC

# COMPUTE THE DIAGONAL COMPONENTS OF DEL

                PDDL
```

```
        COF
DSQ     DMP
        4
DAD     SL3
```

Uses A 80, COF 219, COUNT 142, DEL 232, KALCMON1 63, MPAC 145, and THETA 148.

676 ⟨*Page CM0408* 676⟩≡ (659 2641)

```
                2
        BOVB
                SIGNMPAC
        STODL   DEL             # UX UX(U-COS(A)) +COS(A)              $1
                COF +2
        DSQ     DMP
                4
        DAD     SL3
                2
        BOVB
                SIGNMPAC
        STODL   DEL +8D         # UY UY(1-COS(A)) +COS(A)              $1
                COF +4
        DSQ     DMP
                4
        DAD     SL3
                2
        BOVB
                SIGNMPAC
        STORE   DEL +16D        # UZ UZ(1-COS(A)) +COS(A)              $1

# COMPUTE THE OFF DIAGONAL TERMS OF DEL

        DLOAD   DMP
                COF
                COF +2
        DMP     SL1
                4
        PDDL    DMP             # D6  UX UY (1-COS A)                 $ 4
                COF +4
                0
        PUSH    DAD             # D8  UZ SIN A                        $ 4
                6
        SL2     BOVB
                SIGNMPAC
        STODL   DEL +6
        BDSU    SL2
        BOVB
                SIGNMPAC
        STODL   DEL +2
                COF
        DMP     DMP
                COF +4
                4
        SL1     PDDL            # D6    UX UZ (1-COS A )              $ 4
```

```
        COF +2
DMP     PUSH            # D8    UY SIN(A)
        0
DAD     SL2
        6
```

Uses `A` 80, `COF` 219, and `DEL` 232.

678 ⟨*Page CM0409* 678⟩≡ (659 2641)

```
        BOVB
                SIGNMPAC
        STODL   DEL +4          # UX UZ (1-COS(A))+UY SIN(A)
        BDSU    SL2
        BOVB
                SIGNMPAC
        STODL   DEL +12D        # UX UZ (U-COS(A))-UY SIGN(A)
                COF +2
        DMP     DMP
                COF +4
                4
        SL1     PDDL            # D6    UY UZ (1-COS(A))                $ 4
                COF
        DMP     PUSH            # D6    UX SIN(A)
                0
        DAD     SL2
                6
        BOVB
                SIGNMPAC
        STODL   DEL +14D        # UY UZ(1-COS(A)) +UX SIN(A)
        BDSU    SL2
        BOVB
                SIGNMPAC
        STORE   DEL +10D        # UY UZ(1-COS(A)) -UX SIN(A)
        RVQ

# DIRECTION COSINE MATRIX TO CDU ANGLE ROUTINE
# X1 CONTAINS THE COMPLEMENT OF THE STARTING ADDRESS FOR MATRIX (SCALED 2)
# LEAVES CDU ANGLES SCALED 2PI IN V(MPAC)
# COS(MGA) WILL BE LEFT IN S1 (SCALED 1)
#
# THE DIRECTION COSINE MATRIX RELATING S/C AXES TO STABLE MEMBER AXES CAN BE WRITTEN
#
#       C =COS(THETA)COS(PSI)
#        0
#       C =-COS(THETA)SIN(PSI)COS(PHI)+SIN(THETA)SIN(PHI)
#        1
#       C =COS(THETA)SIN(PSI)SIN(PHI)+SIN(THETA)COS(PHI)
#        2
#       C =SIN(PSI)
#        3
#       C =COS(PSI)COS(PHI)
#        4
#       C =-COS(PSI)SIN(PHI)
#        5
```

```
#       C =-SIN(THETA)COS(PSI)
#        6
#       C =SIN(THETA)SIN(PSI)COS(PHI)+COS(THETA)SIN(PHI)
#        7
```

Uses `A` 80, `COF` 219, `DEL` 232, `MPAC` 145, `S1` 85, `THETA` 148, `V` 229, and `X1` 85.

680 ⟨*Page CM0410* 680⟩≡ (659 2641)

```
#       C =-SIN(THETA)SIN(PSI)SIN(PHI)+COS(THETA)COS(PHI)
#        8
#
#       WHERE   PHI = OGA
#               THETA = IGA
#               PSI = MGA

DCMTOCDU        DLOAD*  ARCSIN
                        6,1
                PUSH    COS             # PD +0         PSI
                SL1     BOVB
                        SIGNMPAC
                STORE   S1
                DLOAD*  DCOMP
                        12D,1
                DDV     ARCSIN
                        S1
                PDDL*   BPL             # PD +2         THETA
                        0,1             # MUST CHECK THE SIGN OF COS(THETA)
                        OKTHETA         # TO DETERMINE THE PROPER QUADRANT
                DLOAD   DCOMP
                BPL     DAD
                        SUHALFA
                        DPHALF
                GOTO
                        CALCPHI
SUHALFA         DSU
                        DPHALF
CALCPHI         PUSH
OKTHETA         DLOAD*  DCOMP
                        10D,1
                DDV     ARCSIN
                        S1
                PDDL*   BPL             # PUSH DOWN PHI
                        8D,1
                        OKPHI
                DLOAD   DCOMP           # PUSH UP PHI
                BPL     DAD
                        SUHALFAP
                        DPHALF
                GOTO
                        VECOFANG
SUHALFAP        DSU     GOTO
                        DPHALF
                        VECOFANG
```

```
OKPHI           DLOAD                   # PUSH UP PHI
VECOFANG        VDEF    RVQ
```

Uses OGA 206, S1 85, and THETA 148.

681a ⟨*Page CM0411* 681a⟩≡ (659 2641)

```
# ROUTINE FOR TERMINATING AUTOMATIC MANEUVERS

NOGOM2          INHINT                  # THIS LOCATION ACCESSED BY A BZMF NOGO -2
                TC      BANKCALL
                CADR    ZEROERROR

NOGO            INHINT
                TC      STOPRATE

                                        # TERMINATE MANEUVER
                CAF     TWO             # NOTE - ALL RETURNS ARE NOW MADE VIA
                TC      WAITLIST        # GOODEND
                EBANK=  BCDU
                2CADR   ENDMANU

                TCF     ENDOFJOB
```

Uses A 80, BCDU 219, EBANK 80, and TC 169.

3.3.14 gimbal lock avoidance

681b ⟨*gimbal lock avoidance* 681b⟩≡ (245b)

⟨*Page CM0412* 682⟩
⟨*Page CM0413* 683a⟩

682 ⟨*Page CM0412* 682⟩≡ (681b 2702)

```
                    BANK     15
                    SETLOC   KALCMON1
                    BANK

                    EBANK=   BCDU

  # DETECTING GIMBAL LOCK
  LOCSKIRT          EQUALS   WCALC
  WCALC             LXC,1    DLOAD*
                             RATEINDX
                             ARATE,1
                    SR4      CALL            # COMPUTE THE INCREMENTAL ROTATION MATRIX
                             DELCOMP         # DEL CORRESPONDING TO A 1 SEC ROTATION
                                             # ABOUT COF
                    DLOAD*   VXSC
                             ARATE,1
                             COF
                    MXV
                             QUADROT
                    STODL    BRATE
                             AM
                    DMP      DDV*
                             ANGLTIME
                             ARATE,1
                    SR
                             5
                    STOVL    TM
                             BRATE
                    VXSC
                             BIASCALE
                    STORE    BIASTEMP        # ATTITUDE ERROR BIAS TO PREVENT OVERSHOOT
                                             # IN SYSTEM
                    SETGO                    # STATE SWITCH CALCMAN2 (43D)
                             CALCMAN2        # 0(OFF) = BYPASS STARTING PROCEDURE
                             NEWANGL +1      # 1(ON) = START MANEUVER


  ARATE             2DEC     .0022222222     # = .05 DEG/SEC

                    2DEC     .0088888889     # = .2 DEG/SEC

                    2DEC     .0222222222     # = .5 DEG/SEC

                    2DEC     .0888888889     # = 2 DEG/SEC                $22.5 DEG/SEC
```

```
ANGLTIME        2DEC    .000190735      # = 100B - 19

                                        # MANEUVER ANGLE TO MANEUVER TIME
QUADROT         2DEC    .1              # ROTATION MATRIX FROM S/C AXES TO CONTROL
```

Uses A 80, AM 219, BCDU 219, BIAS 211, BIASTEMP 219, BRATE 219, CALCMAN2 105, COF 219, DEL 232, EBANK 80, KALCMON1 63, RATEINDX 157, SR 80, STATE 138, and TM 219.

683a ⟨*Page CM0413* 683a⟩≡ (681b 2702)

```
                2DEC    0               # AXES (X ROT = -7.25 DEG)

                2DEC    0

                2DEC    0

                2DEC    .099200         # =(.1)COS7.25

                2DEC    -.012620        # =-(.1)SIN7.25

                2DEC    0

                2DEC    .012620         # (.1)SIN7.25

                2DEC    .099200         # (.1)COS7.25

BIASCALE        2DEC    .0002543132     # = (450/180)(1/0.6)(1/16384)
```

3.3.15 kalcmanu steering

683b ⟨*kalcmanu steering* 683b⟩≡ (245b)

⟨*Page CM0414* 684⟩
⟨*Page CM0415* 686⟩
⟨*Page CM0416* 688⟩
⟨*Page CM0417* 689⟩
⟨*Page CM0418* 690⟩
⟨*Page CM0419* 691a⟩

684 ⟨*Page CM0414* 684⟩≡ (683b 2731)

```
# GENERATION OF STEERING COMMANDS FOR DIGITAL AUTOPILOT FREE FALL MANEUVERS
#
# NEW COMMANDS WILL BE GENERATED EVERY ONE SECOND DURING THE MANEUVER

                BANK    15

                SETLOC  KALCMON1
                BANK

                EBANK=  BCDU

                COUNT   22/KALC

NEWDELHI        CS      HOLDFLAG        # SEE IF MANEUVER HAS BEEN INTERRUPTED
                EXTEND                  # BY ASTRONAUT.
                BZMF    NOGO    -2      # IF SO, TERMINATE KALCMANU
NEWANGL         TC      INTPRET
                AXC,1   AXC,2
                        MIS             # COMPUTE THE NEW MATRIX FROM S/C TO
                        DEL             # STABLE MEMBER AXES
                CALL
                        MXM3
                VLOAD   STADR
                STOVL   MIS +12D        # CALCULATE NEW DESIRED CDU ANGLES
                STADR
                STOVL   MIS +6D
                STADR
                STORE   MIS
                AXC,1   CALL
                        MIS
                        DCMTOCDU        # PICK UP THE NEW CDU ANGLES FROM MATRIX
                RTB
                        V1STO2S
                STORE   NCDU            # NEW CDU ANGLES
                BONCLR  EXIT
                        CALCMAN2
                        MANUSTAT        # TO START MANEUVER
                CAF     TWO             #          +0 OTHERWISE
INCRDCDU        TS      KSPNDX
                DOUBLE
                TS      KDPNDX
                INDEX   KSPNDX
                CA      NCDU            # NEW DESIRED CDU ANGLES
                EXTEND
                INDEX   KSPNDX
```

```
MSU     BCDU            # INITIAL S/C ANGLE OR PREVIOUS DESIRED
EXTEND                  # CDU ANGLES
MP      QUADROT
INDEX   KDPNDX
DXCH    DELCDUX         # ANGEL INCREMENTS TO BE ADDED TO
```

Uses BCDU 219, CALCMAN2 105, COUNT 142, DEL 232, DELCDUX 211, EBANK 80, HOLDFLAG 163, KALCMON1 63, KDPNDX 219, KSPNDX 219, MIS 219, NCDU 219, and TC 169.

686 ⟨*Page CM0415* 686⟩≡ (683b 2731)

```
                INDEX   KSPNDX          # DCDU EVERY TENTH SEC
                CA      NCDU            # BY LEM DAP
                INDEX   KSPNDX
                XCH     BCDU
                INDEX   KDPNDX
                TS      CDUXD
                CCS     KSPNDX
                TCF     INCRDCDU        # LOOP FOR THREE AXES

                RELINT
# COMPARE PRESENT TIME WITH TIME TO TERMINATE MANEUVER

TMANUCHK        TC      TIMECHK
                TC      POSTJUMP
                CADR    CONTMANU

                CAF     ONE
MANUSTAL        TC      WAITLIST
                EBANK=  BCDU
                2CADR   MANUSTOP

                RELINT
                TCF     ENDOFJOB


TIMECHK         EXTEND
                DCS     TIME2
                DXCH    TTEMP
                EXTEND
                DCA     TM
                DAS     TTEMP
                CCS     TTEMP
                TC      Q
                TCF     +2
                TCF     2NDRETRN
                CCS     TTEMP +1
                TC      Q
                TCF     MANUOFF
                COM
MANUOFF         AD      1SEC
                EXTEND
                BZMF    2NDRETRN
                INCR    Q
2NDRETRN        INCR    Q
                INCR    Q
```

```
TC      Q

SETLOC  MANUSTUF
BANK
```

Uses BCDU 219, CDUXD 213, DCDU 211, EBANK 80, KDPNDX 219, KSPNDX 219, MANUSTUF 63, NCDU 219, Q 80, TC 169, TIME2 80, TM 219, and TTEMP 219.

688 ⟨*Page CM0416* 688⟩≡ (683b 2731)

```
MANUSTAT        EXIT                    # INITIALIZATION ROUTINE
                EXTEND                  # FOR AUTOMATIC MANEUVERS
                DCA     TIME2
                DAS     TM              # TM+TO    MANEUVER COMPLETION TIME
                CS      1SEC
                TS      L
                CS      ZERO
                DAS     TM              # (TM+TO)-1
                INHINT
                CS      ONE             # ENABLE AUTOPILOT TO PERFORM
                TS      HOLDFLAG        # AUTOMATIC MANEUVERS
                CS      RATEINDX        # SEE IF MANEUVERING AT HIGH RATE
                AD      SIX
                EXTEND
                BZMF    HIGHGAIN
                TCF     +4
HIGHGAIN        CS      RCSFLAGS        # IF SO, SET HIGH RATE FLAG (BIT 15 OF
                MASK    BIT15           # RCSFLAGS)
                ADS     RCSFLAGS
                DXCH    BRATE           # X-AXIS MANEUVER RATE
                DXCH    WBODY
                DXCH    BRATE +2        # Y-AXIS MANEUVER RATE
                DXCH    WBODY1
                DXCH    BRATE +4        # Z-AXIS MANEUVER RATE
                DXCH    WBODY2
                CA      BIASTEMP +1     # INSERT ATTITUDE ERROR BIASES
                TS      BIAS            # INTO AUTOPILOT
                CA      BIASTEMP +3
                TS      BIAS1
                CA      BIASTEMP +5
                TS      BIAS2
                CA      TIME1
                AD      1SEC
                XCH     NEXTIME
                TC      POSTJUMP
                CADR    INCRDCDU -1

CONTMANU        INHINT                  # CONTINUE WITH UPDATE PROCESS
                CS      TIME1
                AD      NEXTIME
                CCS     A
                AD      ONE
                TCF     MANUCALL
                AD      NEGMAX
                COM
```

```
MANUCALL        TC      WAITLIST
                EBANK=  BCDU
                2CADR   UPDTCALL

                RELINT
```

Uses A 80, BCDU 219, BIAS 211, BIAS1 211, BIAS2 211, BIASTEMP 219, BRATE 219, EBANK 80, HOLDFLAG 163, L 80, NEXTIME 219, RATEINDX 157, RCSFLAGS 200, TC 169, TIME1 80, TIME2 80, TM 219, WBODY 209, WBODY1 209, WBODY2 209, and Z 80.

689 ⟨*Page CM0417* 689⟩≡ (683b 2731)

```
                CAF     1SEC            # INCREMENT TIME FOR NEXT UPDATE
                ADS     NEXTIME
                TCF     ENDOFJOB


UPDTCALL        CAF     PRIO26          # CALL FOR UPDATE
                TC      FINDVAC         # OF STEERING COMMANDS
                EBANK=  BCDU
                2CADR   NEWDELHI

                TC      TASKOVER
```

Uses BCDU 219, EBANK 80, NEXTIME 219, and TC 169.

690 ⟨*Page CM0418* 690⟩≡ (683b 2731)

```
# ROUTINE FOR TERMINATING AUTOMATIC MANEUVERS

                SETLOC  KALCMON3
                BANK

MANUSTOP        TC      STOPYZ
                TC      IBNKCALL
                CADR    LOADYZ

ENDROLL         CA      CPHI
                TS      CDUXD           # SET CDUXD TO THE COMMANDED OUTER GIMBAL
                TC      STOPRATE
ENDMANU         CA      ATTPRIO         # RESTORE USERS PRIO
                TS      NEWPRIO

                CA      ZERO            # ZERO ATTCADR
                DXCH    ATTCADR

                TC      SPVAC           # RETURN TO USER OF GOMANUR

                TC      TASKOVER

                SETLOC  STOPRAT
                BANK
STOPRATE        CAF     ZERO
                TS      DELCDUX
                TS      DELCDUX +1      # ZERO ROLL INCREMENTAL ANGLES
                TS      WBODY           # RATE
                TS      WBODY +1
                TS      BIAS            # BIAS

                CS      BIT15           # MAKE SURE HIGH RATE FLAG (BIT 15 OF
                MASK    RCSFLAGS        # RCSFLAGS) IS RESET.
                TS      RCSFLAGS

STOPYZ          CAF     ZERO
                TS      DELCDUY         # ZERO PITCH, YAW
                TS      DELCDUY +1      # INCREMENTAL ANGLES
                TS      DELCDUZ
                TS      DELCDUZ +1
                TS      WBODY1          # RATES
                TS      WBODY1 +1
                TS      WBODY2
                TS      WBODY2 +1
                TS      BIAS1           # BIASES
```

```
                TS      BIAS2
                TC      Q

                SETLOC MANUSTUF
                BANK
```

Uses ATTCADR 163, ATTPRIO 163, BIAS 211, BIAS1 211, BIAS2 211, CDUXD 213, CPHI 157, DELCDUX 211, DELCDUY 211, DELCDUZ 211, KALCMON3 63, MANUSTUF 63, NEWPRIO 138, Q 80, RCSFLAGS 200, STOPRAT 57, TC 169, WBODY 209, WBODY1 209, and WBODY2 209.

691a ⟨*Page CM0419* 691a⟩≡ (683b 2731)

```
ZEROERROR       CA      CDUX            # PICK UP CDU ANGLES AND STORE IN
                TS      CDUXD           # CDU DESIRED
                CA      CDUY
                TS      CDUYD
                CA      CDUZ
                TS      CDUZD
                TC      Q

                SETLOC  KALCMON1
                BANK

LOADCDUD        CA      CPHI            # STORE TERMINAL ANGLES INTO
                TS      CDUXD           # COMMAND ANGLES
LOADYZ          CA      CTHETA
                TS      CDUYD
                CA      CPSI
                TS      CDUZD
                TC      Q
```

Uses CDUX 80, CDUXD 213, CDUY 80, CDUYD 213, CDUZ 80, CDUZD 213, COMMAND 169, CPHI 157, CPSI 157, CTHETA 157, KALCMON1 63, Q 80, and TC 169.

3.3.16 system test standard lead ins

691b ⟨*system test standard lead ins* 691b⟩≡ (245b)

⟨*Page CM0420* 692⟩
⟨*Page CM0421* 693⟩
⟨*Page CM0422* 694⟩

692 ⟨*Page CM0420* 692⟩≡ (691b 2811)

```
                EBANK=  XSM

                BANK    33
                SETLOC  E/PROG1
                BANK

                COUNT*  $$/P07

# SPECIAL PROGRAMS TO EASE THE PANGS OF ERASABLE MEMORY PROGRAMS.
#
# E/BKCALL      FOR DOING BANKCALLS FROM AND RETURNING TO ERASABLE.
#
# THIS ROUTINE IS CALLABLE FROM ERASABLE OR FIXED.  LIKE BANKCALL, HOWEVER, SWITCHING
# IS NOT POSSIBLE.
#
# THE CALLING SEQUENCE IS:
#
#       TC      BANKCALL
#       CADR    E/BKCALL
#       CADR    ROUTINE         # WHERE TO WANT TO GO IN FIXED.
#       RETURN HERE FROM DISPLAY TERMINATE, BAD STALL OR TC Q.
#       RETURN HERE FROM DISPLAY PROCEED OR GOOD RETURN FROM STALL.
#       RETURN HERE FROM DISPLAY ENTER OR RECYCLE.
#
# THIS ROUTINE REQUIRES TWO ERASABLES (EBUF2, +1) IN UNSWITCHED WHICH ARE UNSHARED BY
# OTHER EMEMORY PROGRAMS.
#
# A + L ARE PRESERVED THROUGH BANKCALL AND E/BKCALL.

E/BKCALL        DXCH    BUF2            # SAVE A,L AND GET DP RETURN.
                DXCH    EBUF2           # SAVE DP RETURN.
                INCR    EBUF2           # RETURN +1 BECAUSE DOUBLE CADR.
                CA      BBANK
                MASK    LOW10           # GET CURRENT EBANK.  (SBANK SOMEDAY)
                ADS     EBUF2   +1      # FORM BBCON.  (WAS FBANK)
                NDX     EBUF2
                CA      0 -1            # GET CADR OF ROUTINE.
                TC      SWCALL          # GO TO ROUTINE, SETTING Q TO SWRETURN
                                        # AND RESTORING A + L.
                TC      +4              # TX Q, V34, OR BADD STALL RETURN.
                TC      +2              # PROCEED OR GOOD STALL RETURN.
                INCR    EBUF2           # ENTER OR RECYCLE RETURN.
                INCR    EBUF2
E/SWITCH        DXCH    EBUF2
                DTCB
```

Uses A 80, BBANK 80, BUF2 142, COUNT 142, E/PROG1 61, EBANK 80, EBUF2 148, FBANK 80, L 80, Q 80, SAVE 191, TC 169, and XSM 186.

693 ⟨*Page CM0421* 693⟩≡ (691b 2811)

```
# E/CALL        FOR CALLING A FIXED MEMORY INTERPRETIVE SUBROUTINE FROM ERASABLE AND RETURNING
#
# THE CALLING SEQUENCE IS...
#
#       RTB
#               E/CALL
#       CADR    ROUTINE                 # THE INTERPRETIVE SUBROUTINE YOU WANT
#                                       # RETURNS HERE IN INTERPRETIVE.

E/CALL          LXCH    LOC             # ADRES -1 OF CADR.
                INDEX   L
                CA      L               # CADR IN A.
                INCR    L
                INCR    L               # RETURN ADRES IN L.
                DXCH    EBUF2           # STORE CADR AND RETURN.
                TC      INTPRET
                CALL
                        EBUF2           # INDIRECTLY EXECUTE ROUTING.  IT MUST
                EXIT                    # LEAVE VIA RVQ OR EQUIVALENT.
                LXCH    EBUF2 +1        # PICK UP RETURN.
                TCF     INTPRET +2      # SET LOC AND RETURN TO CALLER.
```

Uses A 80, EBUF2 148, IT 185, L 80, LOC 145, and TC 169.

694 ⟨*Page CM0422* 694⟩≡ (691b 2811)

```
# E/JOBWAK      FOR WAKING UP ERASABLE MEMORY JOBS.
#
# THIS ROUTINE MUST BE CALLED IN INTERRUPT OR WITH INTERRUPTS INHIBITED.
#
# THE CALLING SEQUENCE IS
#
#       INHINT
#       ...
#       CA      WAKEADR         # ADDRESS OF SLEEPING JOB
#       TC      IBNKCALL
#       CADR    E/JOBWAK
#       ...                     # RETURNS HERE
#       RELINT                  # IF YOU DID AND INHINT

                BANK    33
                SETLOC  E/PROG
                BANK

                COUNT*   $$/P07

E/JOBWAK        TC      JOBWAKE         # ARRIVE IWTH ADRES IN A.
                CS      BIT11
                NDX     LOCCTR
                ADS     LOC             # KNOCK FIXED MEMORY BIT OUT OF ADRES.
                TC      RUPTREG3        # RETURN


# THESE PROGRAMS ARE PROVIDED TO ALLOW OVERLAY OF BANKS 30 THRU 33 OF THE 205 VERSION
# PRELAUNCH ALIGN.  THE INTENT IS TO ALLOW THE STG AND HYBRID LABS TO RUN ALL THE TES


                BANK    33
                SETLOC  TESTLEAD
                BANK

                COUNT   33/COMST

                EBANK=  QPLACE

COMPVER         TC      GCOMPVER        # MUST BE 33,2000.

GTSCPSS1        TC      GTSCPSS         # MUST BE AT 33,2001

REDO            TC      NEWMODEX        # DISPLAY MM 07.
                MM      07              # FALL INTO IMUTEST
```

Uses A 80, COUNT 142, E/PROG 59, EBANK 80, LOC 145, LOCCTR 138, MM 226, QPLACE 191, RUN 191, RUPTREG3 138, TC 169, and TESTLEAD 67.

3.3.17 imu calibration and alignment

695 ⟨*imu calibration and alignment* 695⟩≡ (245b)

⟨*Page CM0423* 696⟩
⟨*Page CM0424* 698⟩
⟨*Page CM0425* 700⟩
⟨*Page CM0426* 702⟩
⟨*Page CM0427* 703⟩
⟨*Page CM0428* 704⟩
⟨*Page CM0429* 705⟩
⟨*Page CM0430* 706⟩
⟨*Page CM0431* 708⟩
⟨*Page CM0432* 710⟩
⟨*Page CM0433* 711⟩
⟨*Page CM0434* 712⟩
⟨*Page CM0435* 713⟩
⟨*Page CM0436* 714⟩
⟨*Page CM0437* 716⟩
⟨*Page CM0438* 717⟩
⟨*Page CM0439* 718⟩
⟨*Page CM0440* 720⟩
⟨*Page CM0441* 722⟩
⟨*Page CM0442* 724⟩
⟨*Page CM0443* 725⟩
⟨*Page CM0444* 727⟩
⟨*Page CM0445* 729⟩
⟨*Page CM0446* 731⟩
⟨*Page CM0447* 732a⟩
⟨*Page CM0448* 732b⟩
⟨*Page CM0449* 733⟩
⟨*Page CM0450* 735⟩
⟨*Page CM0451* 737⟩
⟨*Page CM0452* 739⟩
⟨*Page CM0453* 741⟩
⟨*Page CM0454* 743⟩
⟨*Page CM0455* 744a⟩

696 ⟨*Page CM0423* 696⟩≡ (695 2704)

```
# NAME --       IMU PERFORMANCE TESTS 2
#
# DATE --       MARCH 20, 1967
#
# BY --         SYSTEM TEST GROUP 864-6900 EXT. 1274
#
# MODNO. --     ZERO
#
# FUNCTIONAL DESCRIPTION
#
# POSITIONING ROUTINES FOR THE IMU PERFORMANCE TESTS AS WELL AS SOME OF
# THE TESTS THEMSELVES.  FOR A DESCRIPTION OF THESE SUBROUTINES AND THE
# OPERATING PROCEDURES (TYPICALLY) SEE STG MEMO 685. THEORETICAL REF. E-1973

                BANK    33
                SETLOC  IMUCAL
                BANK

                EBANK=  POSITON
IMUTEST         CA      ZERO
                TS      DRIFTT
                TS      GEOCOMP1
                CAF     TESTTIME
                TS      LENGTHOT
                TC      COAALIGN                # TAKE CARE OF DRIFT FLAG
                CAF     1SECX
                TS      1SECXT1

                CA      OC14400
                TS      1/PIPADT
GUESS           TC      INTPRET                 # CALCULATE -COS LATITUDE AND SIN LAT
                CALL
                        LATAZCHK
                COS     DCOMP
                SL1
                STODL   WANGI
                        LATITUDE
                SIN     SL1
                STORE   WANGO
                EXIT
GEOIMUTT        TC      BANKCALL                # GYROCOMPASS COMES IN HERE
                CADR    IMUZERO
                TC      IMUSTLLG
IMUBACK         CA      ZERO
                TS      NDXCTR
```

```
                TS      TORQNDX
                TS      TORQNDX +1
NBPOSPL         CA      DEC17
                TS      ZERONDX1
                CA      XNBADR
```

Uses 1/PIPADT 156, 1SECXT1 196, A 80, DRIFTT 194, EBANK 80, GEOCOMP1 196, IMUCAL 69, LATITUDE 191, LENGTHOT 191, NDXCTR 191, POSITON 191, TC 169, TORQNDX 194, WANGI 194, WANGO 194, and ZERONDX1 196.

698 ⟨*Page CM0424* 698⟩≡ (695 2704)

```
TC      ZEROING
CA      HALF
TS      XNB
TC      INTPRET
DLOAD   SIN
        AZIMUTH
STORE   YNB     +2
STODL   ZNB     +4
        AZIMUTH
COS
STORE   YNB     +4
DCOMP
STORE   ZNB     +2
EXIT
TC      CHECKMM
MM      03                      # SEE IF IN OPTICAL VERIFICATION
TCF     +2                      # NO
TCF     SETNBPOS +1             # YES
TC      INTPRET
CALL
        CALCGA
EXIT
TC      BANKCALL
CADR    IMUCOARS
CAF     GLOKFBIT                # IF GLOKFAIL SET, GIMBAL LOCK
MASK    FLAGWRD3
EXTEND
BZF     +2
INCR    NDXCTR                  # +1 IF IN GIMBAL LOCK, OTHERWISE 0
TC      DOWNFLAG                # RESET GIMBAL LOCK FLAG
ADRES   GLOKFAIL                # BIT 14 FLAG 3
TC      IMUSTLLG
CCS     NDXCTR                  # IF ONE GO AND DO A PIPA TEST ONLY
TC      PIPACHK                 # ALIGN AND MEARSUE VERTICAL PIPA RAT
TC      BANKCALL
CADR    IMUFINE
TC      IMUSTLLG
EXTEND
DCA     PERFDLAY
TC      LONGCALL
SBANK=  LOWSUPER                # RSB 2004, OH 2009: Ask Ron
EBANK=  POSITON
2CADR   GOESTIMS

CA      ESTICADR
```

```
                TC      JOBSLEEP
GOESTIMS        CA      ESTICADR
                TC      JOBWAKE
                TC      TASKOVER
ESTICADR        CADR    ESTIMS
```

Uses A 80, AZIMUTH 191, EBANK 80, FLAGWRD3 105, GLOKFAIL 105, GLOKFBIT 105, LOWSUPER 67, MM 226, NDXCTR 191, PERFDLAY 196, POSITON 191, TC 169, XNB 186, YNB 186, and ZNB 186.

700 ⟨*Page CM0425* 700⟩≡ (695 2704)

```
TORQUE          CA      ZERO
                TS      DSPTEM2
                CA      DRIFTI
                TS      DSPTEM2 +1
                INDEX   POSITON
                TS      SOUTHDR -1
                TC      SHOW

PIPACHK         INDEX   NDXCTR          # PIPA TEST
                TC      +1
                TC      EARTHR*
                CA      DEC57
                TS      LENGTHOT
                CA      ONE
                TS      RESULTCT
                CA      ZERO
                INDEX   PIPINDEX
                TS      PIPAX
                TS      DATAPL
                TS      DATAPL +4
                TC      CHECKG          # PIP PULSE CATCHING ROUTINE
                INHINT
                CAF     TWO
                TC      TWIDDLE
                EBANK=  XSM
                ADRES   PIPATASK
                TC      ENDOFJOB
PIPATASK        EXTEND
                DIM     LENGTHOT
                CA      LENGTHOT
                EXTEND
                BZMF    STARTPIP
                CAF     BIT10
                TC      TWIDDLE
                EBANK=  XSM
                ADRES   PIPATASK
STARTPIP        CAF     PRIO20
                TC      FINDVAC
                EBANK=  XSM
                2CADR   PIPJOBB

                TC      TASKOVER

PIPJOBB         INDEX   NDXCTR
                TC      +1
```

```
TC      EARTHR*
CA      LENGTHOT
EXTEND
BZMF    +2
TC      ENDOFJOB
CA      FIVE
```

Uses DATAPL 194, DRIFTI 194, DSPTEM2 154, EBANK 80, LENGTHOT 191, NDXCTR 191, PIPAX 80, PIPINDEX 191, POSITON 191, RESULTCT 194, SOUTHDR 191, TC 169, and XSM 186.

702 ⟨*Page CM0426* 702⟩≡ (695 2704)

```
                TS      RESULTCT
                TC      CHECKG
                EXTEND
                DCS     DATAPL
                DAS     DATAPL  +4

                TC      INTPRET
                DLOAD   DSU
                        DATAPL  +6
                        DATAPL  +2
                BPL     CALL
                        AINGOTN
                        OVERFFIX
AINGOTN         PDDL    DDV
                        DATAPL  +4
                SL4     DMPR
                        DEC585          # DEC585 HAS BEEN REDEFINED FOR LEM
                RTB
                        SGNAGREE
                STORE   DSPTEM2
                EXIT
                CCS     NDXCTR
                TC      COAALIGN        # TAKE PLATFORM OUT OF GIMBAL LOCK
                TC      SHOW
VERTDRFT        CA      3990DEC         # ABOUT 1 HOUR VERTICAL DRIFT TEST
                TS      LENGTHOT
                INDEX   POSITON
                CS      SOUTHDR -2
                TS      DRIFTT
                CA      XSM     +4      # 0 IF POSN 4
                EXTEND
                BZF     PON2
PON4            CS      BIT5            # OFFSET PLATFORM
                ADS     ERCOMP1 +2
                CA      BIT5
                ADS     ERCOMP1
                TCF     PONG
PON2            CS      BIT5
                ADS     ERCOMP1 +2
                CA      BIT5
                ADS     ERCOMP1 +4
PONG            TC      EARTHR*
                CA      ZERO            # ALLOW ONLY SOUTH GYRO EARTH RATE COMPENS
                TS      ERVECTOR
                TS      ERVECTOR +1
```

```
GUESS1          CAF     POSMAX
                TS      TORQNDX
                TS      TORQNDX +1
                CA      CDUX
                TS      LOSVEC
```

Uses CDUX 80, DATAPL 194, DRIFTT 194, DSPTEM2 154, ERCOMP1 196, ERVECTOR 191, LENGTHOT 191, LOSVEC 191, NDXCTR 191, POSITON 191, RESULTCT 194, SOUTHDR 191, TC 169, TORQNDX 194, and XSM 186.

703 ⟨*Page CM0427* 703⟩≡ (695 2704)

```
                TC      ESTIMS
VALMIS          CA      DRIFTO
                TS      DSPTEM2 +1
                CA      ZERO
                TS      DSPTEM2
                TC      SHOW

ENDTEST1        TC      DOWNFLAG        # IMU NOT IN USE
                ADRES   IMUSE           # BIT 8 FLAG 0
                CS      ZERO
                TC      NEWMODEX +3
                TC      BANKCALL
                CADR    MKRELEAS
                TC      ENDEXT
```

Uses DRIFTO 194, DSPTEM2 154, IMUSE 95, and TC 169.

704 ⟨*Page CM0428* 704⟩≡ (695 2704)

```
OVERFFIX        DAD     DAD
                        DPPOSMAX
                        ONEDPP
                RVQ

COAALIGN        EXTEND                  # COARSE ALIGN SUBROUTINE
                QXCH    QPLACE
                CA      ZERO
                TS      THETAD
                TS      THETAD +1
                TS      THETAD +2
                TC      BANKCALL
                CADR    IMUCOARS
                TC      BANKCALL
                CADR    IMUSTALL
                TC      SOMERR2
                TC      QPLACE

IMUSTLLG        EXTEND
                QXCH    QPLACE
                TC      COAALIGN +10

CHECKG          EXTEND                  # PIP PULSE CATCHING ROUTINE
                QXCH    QPLACE
                TC      +6
CHECKG1         RELINT
                CA      NEWJOB
                EXTEND
                BZMF    +6
                TC      CHANG1
                INHINT
                INDEX   PIPINDEX
                CS      PIPAX
                TS      ZERONDX
                INHINT
                INDEX   PIPINDEX
                CA      PIPAX
                AD      ZERONDX
                EXTEND
                BZF     CHECKG1
                INDEX   PIPINDEX
                CA      PIPAX
                INDEX   RESULTCT
                TS      DATAPL
```

```
                TC      FINETIME
                INDEX   RESULTCT
                TS      DATAPL +1
```

Uses DATAPL 194, NEWJOB 138, PIPAX 80, PIPINDEX 191, QPLACE 191, RESULTCT 194, TC 169, THETAD 157, and ZERONDX 196.

705 ⟨*Page CM0429* 705⟩≡ (695 2704)

```
                INDEX   RESULTCT
                LXCH    DATAPL +2
                RELINT
  ENDCHKG       TC      QPLACE

  ZEROING       TS      L
                TCF     +2
  ZEROING1      TS      ZERONDX1
                CAF     ZERO
                INDEX   L
                TS      0
                INCR    L
                CCS     ZERONDX1
                TCF     ZEROING1
                TC      Q
```

Uses DATAPL 194, L 80, Q 80, QPLACE 191, RESULTCT 194, TC 169, and ZERONDX1 196.

706 ⟨*Page CM0430* 706⟩≡ (695 2704)

```
                SETLOC  IMUCAL3
                BANK
ERTHRVSE        DLOAD   PDDL
                        SCHZEROS        # PD24 = (SIN  (missing)  -COS (missing) 0)(0
                        LATITUDE
                COS     DCOMP
                PDDL    SIN
                        LATITUDE
                VDEF    VXSC
                        OMEG/MS
                STORE   ERVECTOR
                RTB
                        LOADTIME
                STOVL   TMARK
                        SCHZEROS
                STORE   ERCOMP1
                RVQ
                SETLOC  IMUCAL
                BANK
EARTHR          ITA     RTB             # CALCULATES AND COMPENSATES EARTH RATE
                        S2
                        LOADTIME
                STORE   TEMPTIME
                DSU     BPL
                        TMARK
                        ERTHR
                CALL
                        OVERFFIX
ERTHR           SL      VXSC
                        9D
                        ERVECTOR
                MXV     VAD
                        XSM
                        ERCOMP1
                STODL   ERCOMP1
                        TEMPTIME
                STORE   TMARK
                AXT,1   RTB
                ECADR   ERCOMP1
                        PULSEIMU
                GOTO
                        S2

EARTHR*         EXTEND
                QXCH    QPLACES
```

```
                TC      INTPRET
                CALL
                        EARTHR
PROUT           EXIT
                TC      IMUSTLLG
                TC      QPLACES
```

Uses ERCOMP1 196, ERVECTOR 191, IMUCAL 69, IMUCAL3 67, LATITUDE 191, QPLACES 191, S2 85, TC 169, TEMPTIME 191, TMARK 191, and XSM 186.

708 ⟨*Page CM0431* 708⟩≡ (695 2704)

```
SHOW            EXTEND
                QXCH    QPLACE
SHOW1           CA      POSITON
                TS      DSPTEM2 +2
                CA      VB06N98
                TC      BANKCALL
                CADR    GOFLASH
                TC      ENDTEST1        # V34
                TC      QPLACE          # V33
                TCF     SHOW1

OC14400         OCT     14400
3990DEC         =       OMEG/MS
VB06N98         VN      0698
TESTTIME        OCT     01602
DEC17           =       ND1
OGCPL           ECADR   OGC
1SECX           =       1SEC
DEC57           =       VD1
XNBADR          GENADR  XNB
XSMADR          GENADR  XSM
OMEG/MS         2DEC    .24339048

P11OUT          TC      BANKCALL
                CADR    MATRXJOB        # RETURN TO P11

                COUNT   02/COMST

                BLOCK   2
FINETIME        INHINT                  # RETURNS WITH INTERRUPT INHIBITED
                EXTEND
                READ    LOSCALAR
                TS      L
                EXTEND
                RXOR    LOSCALAR
                EXTEND
                BZF     +4
                EXTEND
                READ    LOSCALAR
                TS      L
        +4      CS      POSMAX
                AD      L
                EXTEND
                BZF     FINETIME +1
```

```
EXTEND
READ    HISCALAR
TC Q
```

Uses COUNT 142, DSPTEM2 154, HISCALAR 87, L 80, LOSCALAR 87, OGC 186, POSITON 191, Q 80, QPLACE 191, TC 169, VN 159, XNB 186, and XSM 186.

710 ⟨*Page CM0432* 710⟩≡ (695 2704)

```
# PROGRAM NAME:  OPTIMUM PRELAUNCH ALIGNMENT CALIBRATION
# DATE:  NOVEMBER 2 1966
# BY:  GEORGE SCHMIDT IL 7-146 EXT. 126
# MOD NO 3
#
# FUNCTIONAL DESCRIPTION
#
# THIS SECTION CONSISTS OF PRELAUNCH ALIGNMENT AND GYRO DRIFT TESTS
# INTEGRATED TOGETHER TO SAVE WORDS.  COMPASS IS COMPLETELY RESTART
# PROOFED EXCEPT FOR THE FIRST 30 SECONDS OR SO.  PERFORMANCE TESTS OF
# THE IRIGS IS RESTART PROOFED ENOUGH TO GIVE 75 PERCENT CONFIDENCE THAT
# IF A RESTART OCCURS THE DATA WILL STILL BE GOOD.  GOOD PRACTICE TO RECYCL
# WHEN A RESTART OCCURS UNLESS IT HAPPENS NEAR THE END OF A TEST -- THEN WAIT
# FOR THE DATA TO FLASH.
#
# A RESTART IN GYROCOMPASS DURING GYRO TORQUING CAUSES PULSES TO BE LOST.
# THE PRELAUNCH ALIGNMENT TECHNIQUE IS BASICALLY THE SAME AS IN BLOCK 1
# EXCEPT THAT IT HAS BEEN SIMPLIFIED IN THE SENSE THAT SMALL ANGLE APPROX.
# HAVE BEEN USED.  THE DRIFT TESTS USE A UNIQUE IMPLEMENTATION OF THE
# OPTIMUM STATISTICAL FILTER.  FOR A DESCRIPTION SEE E-1973.  BOTH OF THESE
# ROUTINES USE STANDARD SYSTEM TEST LEADIN PROCEDURES.  THE INITIALIZATION
# PROCEDURE THE DRIFT TESTS IS IN THE JDC'S.  THE INITIALIZATION METHOD
# FOR GYROCOMPASS IS AN ERAS LOAD THEN A MISSION PHASE CALL.
# THE COMPASS ALIGNS TO Z DOWN, X DOWNRANGE, HAS THE CAPABILITY
# CHANGE AZIMUTH WHILE RUNNING, IS COMPENSATED FOR
# COMPONENT ERRORS, IS CAPABLE OF OPTICAL VERIFICATION (CSM ONLY).
#
# COMPASS ERASABLE LOAD REQUIRED
#
#       1.      LAUNCHAZ-DP AZIMUTH IN REV FROM NORTH OF XSM DESIRED    (NOM=.2)
#       2.      LATITUDE-DP-OF LAUNCH PAD
#       3.      AZIMUTH-DP-OF ZNB OF VEHICLE
#       4.      IMU COMPENSATION PARAMETERS
#       5.      AZ AND ELEVATION OF TARGETS 1,2         ****OPTIONAL****
#
# TO PERFORM AS PART OF COMPASS
#
#       1.      OPTICAL VERIFICATION: V 65 E
#       2.      AZIMUTH CHANGE: V 78 E
#
# SUBROUTINES CALLED
#
# DURING OPTICAL VERIFICATION (CSM ONLY) ESSENTIALLY ALL OF INFLIGHT ALIGN
# IS CALLED IN ONE WAY OR ANOTHER.  SEE THE LISTING.
#
```

```
# NORMAL EXIT
#
# DRIFT TESTS.  LENGTHOT GOES TO ZERO-RETURN TO IMU PERF TEST2 CONTROL
# GYROCOMPASS-MANY, SEE THE LISTING.
#
# ALARMS
#
# 1600  OVERFLOW IN DRIFT TEST
```

Uses A 80, AZIMUTH 191, INFLIGHT 65, IT 185, LATITUDE 191, LAUNCHAZ 194, LENGTHOT 191, RESTART 57, SAVE 191, V 229, XSM 186, Z 80, and ZNB 186.

711 ⟨*Page CM0433* 711⟩≡ (695 2704)

```
# 1601  BAD IMU TORQUE ABORT
# 1602  BAD OPTICS DURING VERIFICATION-RETURN TO COMPASS        CSM ONLY
#
# OUTPUT
#
# DRIFT TESTS:  FLASHING DISPLAYS OF RESULTS-CONTROLLED IN IMU PERF TESTS 2
# COMPASS-PROGRAM MODE LIGHTS TELL YOU WHAT PHAS OF PROGRAM YOU ARE IN
#       01      INITIALIZING THE PLATFORM POSITION AND ERASABLE
#       02      GYROCOMPASSING
#       03      DOING OPTICAL VERIFICATION (CSM)
#
# DEBRIS
#
# ALL CENTRALS, ALL OF EBANK XSM
```

Uses DISPLAYS 59, EBANK 80, MODE 145, and XSM 186.

712 ⟨*Page CM0434* 712⟩≡ (695 2704)

```
# MOST OF THE ROUTINES COMMON TO ALIGNMENT AND CALIBRATION APPEAR
# ON THE NEXT FEW PAGES.

                COUNT   33/P02

                EBANK=  XSM
                BANK    33
                SETLOC  IMUCAL
                BANK

ESTIMS          TC      2PHSCHNG        # COMES HERE FROM IMU2
                OCT     00075
                OCT     00004           # TURN OFF GROUP 4 IF ON
RSTGTS1         INHINT                  # COMES HERE PHASE1 RESTART
                CA      TIME1
                TS      GTSWTLT1
                CAF     ZERO            # ZERO THE PIPAS
                TS      PIPAX
                TS      PIPAY
                TS      PIPAZ
                RELINT
                CA      77DECML         # ZERO ALL NECESSARY LOCATIONS
                TS      ZERONDX1
                CA      ALXXXZ
                TC      ZEROING
                TC      INTPRET
                SLOAD
                        SCHZEROS
                STOVL   GCOMPSW -1
                        INTVAL +2       # LOAD SOME INITIAL DRIFT GAINS
                STOVL   ALX1S
                        SCHZEROS
                STORE   GCOMP
                STORE   DELVX           # GCOMPZER SUBROUTINE NO LONGER NEEDED
                EXIT

                CCS     GEOCOMP1        # NON ZERO IF COMPASS.
                TC      +2
                TC      SLEEPIE +1
                TC      INTPRET
                CALL
                        ERTHRVSE
                EXIT
                CA      LENGTHOT        # TIMES FIVE IS THE NUM OF SEC ERECTING
                TS      ERECTIME
```

```
TC      NEWMODEX
MM      02
TC      BANKCALL        # SET UP PIPA FAIL TO CAUSE ISS ALARM
```

Uses ALX1S 194, COUNT 142, DELVX 159, EBANK 80, ERECTIME 196, GCOMP 169, GCOMPSW 169, GEOCOMP1 196, GTSWTLT1 196, IMUCAL 69, LENGTHOT 191, MM 226, PHASE1 152, PIPAX 80, PIPAY 80, PIPAZ 80, RESTART 57, TC 169, TIME1 80, XSM 186, and ZERONDX1 196.

713 ⟨*Page CM0435* 713⟩≡ (695 2704)

```
CADR    PIPUSE          # COMPASS NEVER TURNS THIS OFF
TC      ANNNNNN         # END OF FIRST TIME THROUGH
```

Uses TC 169.

714 ⟨*Page CM0436* 714⟩≡ (695 2704)

```
# COMES HERE AT THE END OF EVERY ITERATION THROUGH DRIFT TEST OR COMPASS

# SET UP WAITLIST SECTION
SLEEPIE         TS      LENGTHOT        # TEST NOT OVER-DECREMENT LENGHOT
                TC      PHASCHNG        # CHANGE PHASE
                OCT     00135
                CCS     TORQNDX         # ARE WE DOING VERTDRIFT
                TC      EARTHR*         # TRUE TORQUE SOUTH GYRO
WTLISTNT        TC      CHKCOMED        # SEE IF COMPASS OVER
                TC      SETGWLST
                TC      ENDOFJOB

SETGWLST        EXTEND
                QXCH    MPAC            # CALLED EVERY WAITLIST OR AZIMUTH CHANGE
                INHINT
                CS      TIME1
                AD      GTSWTLT1
                EXTEND
                BZMF    +2
                AD      NEGMAX          # 10 MS ERROR OK
                AD      1SECXT1         # 1 SEC FOR CALIBRATION, .5 SEC IN COMPASS
                EXTEND
                BZMF    RIGHTGTS
WTGTSMPL        TC      TWIDDLE
                EBANK=  ALTIM
                ADRES   ALLOOP
                TC      MPAC
RIGHTGTS        CAF     FOUR            # SET UP NEXT WAITLIST-ALLOW SOME TIME
                TC      WTGTSMPL        # END OF WAITLIST SECTION

# STORE AND LOAD DATA SECTIONS FOR RESTART PROOFING

25DECML         EQUALS  OCT31
STOREDTA        CAF     25DECML
                TS      MPAC
                INDEX   MPAC
                CAE     THETAX1
                INDEX   MPAC
                TS      RESTARPT
                CCS     MPAC
                TCF     STOREDTA +1
                TC      Q

LOADSTDT        CAF     25DECML
                TS      MPAC
```

```
INDEX   MPAC
CA      RESTARPT
INDEX   MPAC
```

Uses 1SECXT1 196, ALTIM 194, AZIMUTH 191, EBANK 80, GTSWTLT1 196, LENGTHOT 191, MPAC 145, Q 80, RESTARPT 194, RESTART 57, TC 169, THETAX1 196, TIME1 80, and TORQNDX 194.

716 ⟨*Page CM0437* 716⟩≡ (695 2704)

```
                TS      THETAX1
                CCS     MPAC
                TCF     LOADSTDT +1
                TC      Q

  # COMES HERE EVERY ITERATION BY A WAITLIST CALL SET IN SLEEPIE

  ALLOOP        CA      TIME1
                TS      GTSWTLT1        # STORE TIME TO SET UP NEXT WAITLIST.
  ALLOOP3       CA      ALTIM
                TS      GEOSAVE1
                TC      PHASCHNG
                OCT     00115
  ALLOOP1       CAE     GEOSAVE1
                TS      ALTIM
                CCS     A
                CA      A               # SHOULD NEVER HIT THIS LOCATION
                TS      ALTIMS
                CS      A
                TS      ALTIM
                CAF     ZERO
                XCH     PIPAX
                TS      DELVX
                CAF     ZERO
                XCH     PIPAY
                TS      DELVY
                CAF     ZERO
                XCH     PIPAZ
                TS      DELVZ
                CAF     19DECML         # 23 OCT
                TC      NEWPHASE
                OCT     00005
  SPECSTS       CAF     PRIO22
                TC      FINDVAC
                EBANK=  GEOSAVE1
                2CADR   ALFLT           # START THE JOB

                TC      TASKOVER
```

Uses A 80, ALTIM 194, ALTIMS 194, DELVX 159, DELVY 159, DELVZ 159, EBANK 80, GEOSAVE1 196, GTSWTLT1 196, MPAC 145, PIPAX 80, PIPAY 80, PIPAZ 80, Q 80, TC 169, THETAX1 196, and TIME1 80.

717 ⟨*Page CM0438* 717⟩≡ (695 2704)

```
# THIS IS PART OF THE JOB DONE EVERY ITERATION

ALFLT           TC      STOREDTA        # STORE DATA IN CASE OF RESTART IN JOB
                TC      PHASCHNG        # THIS IS THE JOB DONE EVERY ITERATION
                OCT     00215
                TCF     +2
ALFLT1          TC      LOADSTDT        # COMES HERE ON RESTART

                CCS     GEOCOMP1
                TC      +2
                TC      NORMLOP
                TC      CHKCOMED        # SEE IF PRELAUNCH OVER
                TC      BANKCALL        # COMPENSATION IF IN COMPASS
                CADR    1/PIPA
NORMLOP         TC      INTPRET
                DLOAD
                        INTVAL
                STOVL   S1
                        DELVX
                VXM     VSL1
                        XSM
                DLOAD   DCOMP
                        MPAC +3
                STODL   DPIPAY
                        MPAC +5
                STORE   DPIPAZ

                SETPD   AXT,1
                        0
                        8D
                SLOAD   DCOMP
                        GEOCOMP1
                BMN
                        ALWAYSG         # DO A QUICK COMPASS
```

Uses A 80, DELVX 159, DPIPAY 194, DPIPAZ 194, GEOCOMP1 196, MPAC 145, RESTART 57, S1 85, TC 169, and XSM 186.

718 ⟨*Page CM0439* 718⟩≡ (695 2704)

```
# NOW WE HAVE JUST THE CALIBRATION PARTS OF THE PROGRAM-NEXT PAGES

                COUNT   33/COMST

ALCGKK          SLOAD   BMN
                        ALTIMS
                        ALFLT3          # NO NEW GAINS NEEDED
ALKCG           AXT,2   LXA,1           # LOADS SLOPES AND TIME CONSTANTS AT RQST
                        12D
                        ALX1S
ALKCG2          DLOAD*  INCR,1
                        ALFDK +144D,1
                DEC     -2
                STORE   ALDK +10D,2
                TIX,2   SXA,1
                        ALKCG2
                        ALX1S

ALFLT3          AXT,1                   # MEASUREMENT INCORPORATION ROUTINES
                        8D              # AND GAIN UPDATES
DELMLP          DLOAD*  DMP
                        DPIPAY +8D,1
                        PIPASC
                SLR     BDSU*
                        9D
                        INTY +8D,1
                STORE   INTY +8D,1
                PDDL    DMP*
                        VELSC
                        VLAUN +8D,1
                SL2R
                DSU     STADR
                STORE   DELM +8D,1
                STORE   DELM +10D,1
                TIX,1   AXT,2
                        DELMLP
                        4
ALILP           DLOAD*  DMPR*
                        ALK +4,2
                        ALDK +4,2
                STORE   ALK +4,2
                TIX,2   AXT,2
                        ALILP
                        8D
ALKLP           LXC,1   SXA,1
```

```
                CMPX1
                CMPX1
DLOAD*          DMPR*
                ALK +1,1
                DELM +8D,2
```

Uses ALDK 194, ALFDK 182, ALK 194, ALTIMS 194, ALX1S 194, CMPX1 194, COUNT 142, DELM 194, DPIPAY 194, INTY 194, and VLAUN 194.

720 ⟨*Page CM0440* 720⟩≡ (695 2704)

```
                DAD*
                        INTY +8D,2
                STORE   INTY +8D,2
                DLOAD*  DAD*
                        ALK +12D,2
                        ALDK +12D,2
                STORE   ALK +12D,2
                DMPR*   DAD*
                        DELM +8D,2
                        INTY +16D,2
                STORE   INTY +16D,2
                DLOAD*  DMP*
                        ALSK +1,1
                        DELM +8D,2
                SL1R    DAD*
                        VLAUN +8D,2
                STORE   VLAUN +8D,2
                TIX,2   AXT,1
                        ALKLP
                        8D

LOOSE           DLOAD*  PDDL*           # EXTRAPOLATE SWAY VARIABLES
                        ACCWD +8D,1
                        VLAUN +8D,1
                PDDL*   VDEF
                        POSNV +8D,1
                MXV     VSL1
                        TRANSM1
                DLOAD
                        MPAC
                STORE   POSNV +8D,1
                DLOAD
                        MPAC +3
                STORE   VLAUN +8D,1
                DLOAD
                        MPAC +5
                STORE   ACCWD +8D,1
                TIX,1
                        LOOSE

                AXT,2   AXT,1           # EVALUATE SINES AND COSINES
                        6
                        2
BOOP            DLOAD*  DMPR
                        ANGX +2,1
```

```
                GEORGEJ
        SR2R
        PUSH    SIN
```

Uses ACCWD 194, ALDK 194, ALK 194, ANGX 194, DELM 194, INTY 194, MPAC 145, POSNV 194, TRANSM1 182, and VLAUN 194.

722 ⟨*Page CM0441* 722⟩≡ (695 2704)

```
                SL3R    XAD,1
                        X1
                STORE   16D,2
                DLOAD
                COS
                STORE   22D,2           # COSINES
                TIX,2
                        BOOP

PERFERAS        EXIT
                CA      EBANK7
                EBANK=  LAT(SPL)
                TS      EBANK
                TC      LAT(SPL)        # GOTO ERASABLE ONLY TO RETURN

# CAUTION
#
# THE ERASABLE PROGRAM THAT DOES THE CALCULATIONS MUST BE LOADED
# BEFORE ANY ATTEMPT IS MAKE TO RUN THE IMU PERFORMANCE TEST

                EBANK=  LENGTHOT
ONCEMORE        CCS     LENGTHOT
                TC      SLEEPIE         # TEST NOT OVER SET UP NEXT WAITLIST
                CCS     TORQNDX
                TCF     +2
                TC      SETUPER1
                CA      CDUX
                TS      LOSVEC +1       # FOR TROUBLESHOOTING POSNS 2$4 VD
SETUPER1        TC      INTPRET         # DRIFT TEST OVER
                DLOAD   PDDL            # ANGLES FROM DRIFT TEST ONLY
                        ANGZ
                        ANGY
                PDDL    VDEF
                        ANGX
                VCOMP   VXSC
                        GEORGEJ
                MXV     VSR1
                        XSM
                STORE   OGC
                EXIT

TORQINCH        TC      PHASCHNG
                OCT     00005
                CA      OGCPL
                TC      BANKCALL
```

```
CADR    IMUPULSE
TC      IMUSTLLG
CCS     TORQNDX         # + IF IN VERTICAL DRIFT TEST
TC      VALMIS          # VERT DRIFT TEST OVER
TC      INTPRET
```

Uses ANGX 194, ANGY 194, ANGZ 194, CDUX 80, EBANK 80, LAT 157, LAT(SPL) 224, LENGTHOT 191, LOSVEC 191, OGC 186, RUN 191, TC 169, TORQNDX 194, X1 85, and XSM 186.

724 ⟨*Page CM0442* 724⟩≡ (695 2704)

```
                CALL                    # SET UP ERATE FOR PIP TEST OR COMPASS
                        ERTHRVSE
                EXIT
                TC      TORQUE          # GO TO IMU2 FOR A PIPA TEST AND DISPLAY

SOMEERRR        TC      ALARM
                OCT     1600
                TC      +3
SOMERR2         TC      ALARM
                OCT     1601
                TC      PHASCHNG
                OCT     00005
                TC      ENDTEST1

# THE FAMOUS MAGIC NUMBERS OF SCHMIDT ARE NOW PART OF AN ERASABLE LOAD

DEC585          OCT     02222           # 1170 B+14 ORDER IS NOW IMPORTANT
SCHZEROS        2DEC    .00000000
                2DEC    .00000000
                OCT     00000
ONEDPP          OCT     00000
                OCT     00001           # ABOVE ORDER IS IMPORTANT

INTVAL          OCT     4
                OCT     2
                DEC     144
                DEC     -1
SOUPLY          2DEC    .93505870       # INITIAL GAINS FOR PIP OUTPUTS
                2DEC    .26266423       # INITIAL GAINS/4 FOR ERECTION ANGLES

77DECML         DEC     77
ALXXXZ          GENADR  ALX1S -1

# GYROCOMPASS PORTIONS FINISH THIS LOG SECTION

                COUNT   33/P01

# INITIALIZATION SECTION

GTSCPSS         CA      FLAGWRD1        # CALLED BY V37
                MASK    NOP01BIT
```

Uses A 80, ALX1S 194, COUNT 142, FLAGWRD1 97, NOP01BIT 99, and TC 169.

725 ⟨*Page CM0443* 725⟩≡ (695 2704)

```
                EXTEND
                BZF     GTSCPSSA
                TC      P00DOO
                OCT     1521            # NODO ALARM FOR P01 - P11 ALREADY DONE

GTSCPSSA        CAF     ONE
                TS      GEOCOMP1        # THIS IS THE LEAD IN FOR COMPASS
                CA      1/PIPAGT
                TS      1/PIPADT
NXXTENN         CA      BIT8
                TS      LENGTHOT
                CAF     1/2SECX         # COMPASS IS A .5 SEC LOOP
                TS      1SECXT1
                CAF     ONE
                TS      PREMTRX1
                TS      PERFDLAY +1
                CAF     ZERO
                TS      PERFDLAY
                EXTEND
                DCA     LUNCHAZ1
                DXCH    NEWAZ1
                EXTEND
                DCA     LUNCHAZ1
                DXCH    OLDAZMTH
SETUPGC         CA      DEC17
                TS      ZERONDX1
                CA      XSMADR
                TC      ZEROING
                TC      POSN17C
                TC      GEOIMUTT        # GO TO IMU2 FOR FURTHER INITIALIZATION


POSN17C         EXTEND                  # COMPASS POSITION Z DOWN, X DOWNRANGE
                QXCH    QPLACE          # FROM NORTH IN REVOLUTIONS + CLOCKWISE
                CS      HALF            # ALL THIS TO INITIALIZE MATRIX
                TS      ZSM
                TC      INTPRET
                DLOAD   PUSH
                        NEWAZ1
                SIN
                STORE   XSM     +4
                STODL   YSM     +2
                COS
                STORE   YSM     +4
                DCOMP
```

```
STORE   XSM     +2
EXIT
TC      QPLACE
```

Uses 1/PIPADT 156, 1SECXT1 196, A 80, GEOCOMP1 196, LENGTHOT 191, LUNCHAZ1 196, NEWAZ1 196, OLDAZMTH 194, PERFDLAY 196, PREMTRX1 196, QPLACE 191, TC 169, XSM 186, YSM 186, Z 80, ZERONDX1 196, and ZSM 186.

727 ⟨*Page CM0444* 727⟩≡ (695 2704)

```
# JOB DONE EVERY ITERATION THROUGH COMPASS PROGRAM.  SET BY TASK ALLOOP

                COUNT   33/P02

ALWAYSG         DLOAD*  DSU*            # COMPASS AND ERECT
                        DPIPAY +8D,1
                        FILDELV1 +8D,1
                DMPR    DAD*
                        GEOCONS1
                        FILDELV1 +8D,1
                STORE   FILDELV1 +8D,1
                DAD*
                        INTVEC1 +8D,1
                STORE   INTVEC1 +8D,1
                DMPR    DAD*
                        GEOCONS2
                        FILDELV1 +8D,1
                DMPR    PUSH
                        GEOCONS5
                TIX,1   SLOAD
                        ALWAYSG
                        ERECTIM1
                BZE     DLOAD
                        COMPGS
                        THETAN1 +2
                DSU     STADR
                STODL   THETAN1 +2      # ERECTION ONLY.
                BDSU
                        THETAN1 +4
                STORE   THETAN1 +4
                GOTO
                        ADDINDRF
COMPGS          DLOAD   DAD             # COMPASS
                        THETAN1
                        FILDELV1
                STODL   THETAN1
                        FILDELV1
                DMPR    BDSU
                        GEOCONS3
                        THETAN1 +4
                STODL   THETAN1 +4
                        FILDELV1 +4
                DMPR    BDSU
                        GEOCONS3
                        THETAN1 +2
```

```
PDDL    DMPR
        INTVEC1 +4
        GEOCONS4
BDSU    STADR
STORE   THETAN1 +2
```

Uses COUNT 142, DPIPAY 194, ERECTIM1 196, FILDELV1 196, INTVEC1 196, and THETAN1 196.

729 ⟨*Page CM0445* 729⟩≡ (695 2704)

```
ADDINDRF        EXIT


ENDGTSAL        CCS     LENGTHOT        # IS 5 SEC OVER-THE TIME TO TORQ PLATFORM
                TC      SLEEPIE         # NO-SET UP NEXT WAITLIST CALL FOR .5 SEC
                TC      CHKCOMED
                CCS     LGYRO           # YES BUT ARE GYROS BUSY
                TCF     SLEEPIE +1      # BUSY-GET THEM .5 SECONDS FROM NOW

LASTGTS         TC      INTPRET
                VLOAD
                        ERCOMP1
                STODL   THETAX1
                        TMARK
                STORE   ALK
                EXIT                    # PREVIOUS SECTION WAS FOR RESTARTS

RESTAIER        TC      PHASCHNG
                OCT     00275
                TC      INTPRET         # ADD COMPASS COMMANDS INTO ERATE
                VLOAD   MXV
                        THETAN1
                        XSM
                VSL1    VAD
                        THETAX1
                STODL   ERCOMP1
                        ALK
                STORE   TMARK
                EXIT
                TC      EARTHR*         # TORQUE IT ALL IN
                CAE     ERECTIM1
                TS      GEOSAVE1
                TC      PHASCHNG
                OCT     00155
RESTEST1        TC      INTPRET
                VLOAD
                        SCHZEROS
                STORE   THETAN1
                EXIT
                CCS     PREMTRXC
                TC      NOCHORLD
                TC      PHASCHNG
                OCT     00255
RESTEST3        TC      INTPRET
                DLOAD
```

```
        LAUNCHAZ
DSU     BZE
        OLDAZMTH
        NOAZCHGE
STORE   OD
```

Uses ALK 194, ERCOMP1 196, ERECTIM1 196, GEOSAVE1 196, IT 185, LAUNCHAZ 194, LENGTHOT 191, LGYRO 161, OLDAZMTH 194, PREMTRXC 194, TC 169, THETAN1 196, THETAX1 196, TMARK 191, and XSM 186.

731 ⟨*Page CM0446* 731⟩≡ (695 2704)

```
                SLOAD   DAD
                        ONEDPP +1
                        PREMTRXC        # DOES NOT CHANGE LAUNCHAZ
                STODL   PREMTRXC
                        LAUNCHAZ
                STODL   NEWAZMTH
                        OD
ADERCOMP        STORE   ERCOMP +4
                EXIT
                TC      POSN17C
                TC      PHASCHNG
                OCT     00335
RESCHNG         EXTEND
                DCA     NEWAZMTH
                DXCH    OLDAZMTH
                CA      BIT7            # SPEND 320 SEC ERECTING
                TS      LENGTHOT
                TC      PHASCHNG
                OCT     00075
SPITGYRO        CA      ERCOMPPL
                TC      BANKCALL
                CADR    IMUPULSE
                TC      BANKCALL
                CADR    IMUSTALL
                TC      SOMERR2
                TC      ESTIMS          # RE-INITIALIZE


NOAZCHGE        EXIT
                CA      ONE
                TS      PREMTRXC
NOCHORLD        CCS     GEOSAVE1
                TS      ERECTIM1        # COUNTS DOWN FOR ERECTION.

ANNNNNN         CAF     NINE
                TS      LENGTHOT
                TC      SLEEPIE +1


CHKCOMED        INHINT
                CS      MODREG          # CHECK FOR MM 07 FIRST
                AD      SEVEN
                EXTEND
                BZF     GOBKCALB        # IF MM 07 RETURN TO PERF TEST
                CS      ZERO
```

```
                EXTEND
                RXOR    CHAN30          # READ AND INVERT BITS IN CHANNEL 30
                MASK    BIT5            # LIFTOFF BIT
                CCS     A
                TCF     PRELTERM        # LIFTOFF HAS OCCURRED
```

Uses A 80, CHAN30 87, ERCOMP 196, ERECTIM1 196, GEOSAVE1 196, LAUNCHAZ 194, LENGTHOT 191, MM 226, MODREG 154, NEWAZMTH 194, OLDAZMTH 194, PREMTRXC 194, and TC 169.

732a ⟨*Page CM0447* 732a⟩≡ (695 2704)

```
                CA      GRRBKBIT        # CHECK FOR BACKUP LIFTOFF
                MASK    FLAGWRD5        # BIT5 FLAGWRD5
                CCS     A
                TCF     PRELTERM        # BACKUP RECEIVED

                RELINT
GOBKCALB        TC      Q

PRELTERM        CA      PRIO22          # PRELAUNCH DONE -- SET UP P11
                TC      PRIOCHNG        # INCREASE PRIORITY HIGHER THAN SERVICER
                INHINT
                TC      POSTJUMP
                CADR    P11


ERCOMPPL        ECADR   ERCOMP

GEOCONS5        EQUALS  HIDPHALF
1/PIPAGT        OCT     06200
17DECML         =       ND1             # OCT 21
19DECML         =       VD1             # OCT 23
1/2SECX         =       .5SEC
```

Uses A 80, ERCOMP 196, FLAGWRD5 113, GRRBKBIT 115, HIDPHALF 71, PRIORITY 145, Q 80, and TC 169.

732b ⟨*Page CM0448* 732b⟩≡ (695 2704)

```
GEOSTRT4        EQUALS  ENDOFJOB
```

733 ⟨*Page CM0449* 733⟩≡ (695 2704)

```
# OPTICAL VERIFICATION ROUTINES FOR GYROCOMPASS

                COUNT   33/P03

GCOMPVER        TC      PHASCHNG        # OPTICAL VERIFICATION ROUTINE
                OCT     00154
                TC      NEWMODEX        # ENTERED BY VERB 65 ENTER
                MM      03
SETNBPOS        TC      NBPOSPL
                TC      BANKCALL
                CADR    MKRELEAS
OPTDATA         CAF     BIT1            # CALLS FOR AZIMUTH AND ELEVATION OF TARGET
                ZL                      # 1, THEN TARGET 2
                LXCH    RUN             # AZIMUTH CLOCKWISE FROM NORTH TO TARGET
                TS      DSPTEM1 +2      # ELEVATION MEASURED FROM HORIZONTAL
                EXTEND
                INDEX   RUN
                DCA     TAZEL1
                DXCH    DSPTEM1
                CAF     V05N30E
                TC      BANKCALL
                CADR    GODSPRET
                CAF     VN0641
                TC      BANKCALL
                CADR    GOFLASH
                TC      GCOMP5
                TC      +3
                TC      -8D
VN0641          VN      0641
                DXCH    DSPTEM1         # TAZEL1 TARGET 1 AZIMUTH
                INDEX   RUN
                DXCH    TAZEL1          # TAZEL1 +2 TARGET 2 AZIMUTH
                CCS     RUN
                TCF     +4
                CAF     TWO
                TS      L
                TCF     OPTDATA +2      # MPAC  1ST PASS=0   2ND PASS=2

                TC      CONTIN33

V05N30E         VN      0530

                TC      INTPRET         # UNDYNAMIC ASSEMBLER
TAR/EREF        AXT,1   AXT,2           # TARGET VECTOR
                        2               # SIN(EL)   -COS(AZ)COS(EL)   SIN(AZ)COS(EL)
```

```
        12D
SSP     SETPD
        S2
        6
```

Uses AZIMUTH 191, COUNT 142, DSPTEM1 154, L 80, MM 226, MPAC 145, RUN 191, S2 85, TAZEL1 191, TC 169, and VN 159.

735 ⟨*Page CM0450* 735⟩≡ (695 2704)

```
                        0
TAR1            SLOAD*  SR2             # X1=2 X2=12 S2=6 X1=0 X2=6 S2=6
                        TAZEL1 +3,1
                STORE   0               # PD00 ELEVATION PD00
                SIN
                STORE   18D,2           # PD06 *** SIN(EL) ***PD12
                DLOAD
                        0
                COS     PUSH            # PD00 COS(EL) PD00
                SLOAD*  RTB
                        TAZEL1 +2,1
                        CDULOGIC
                STORE   2               # PD02 AZIMUTH PD02
                SIN     DMP
                        0
                SL1
                STORE   22D,2           # PD10 *** SIN(AZ)COS(EL) ***PD16
                DLOAD   COS
                        2
                DMP     SL1
                DCOMP   AXT,1
                        0
                STORE   20D,2           # PD08 *** -COS(AZ)COS(EL) ***PD14
                TIX,2   RVQ
                        TAR1


                BANK    33
                SETLOC  IMUCAL
                BANK
                COUNT*  $$/P03

CONTIN33        CA      ONE
                TS      STARCODE
                CA      ZERO
                TC      TARGDRVE
                TC      INTPRET
                CALL
                        TAR/EREF
NEXTBNKS        VLOAD   MXV
                        6D
                        XSM
                VSL1
                STOVL   STARAD
                        12D
```

```
MXV     VSL1
        XSM
STCALL  STARAD +6
        LITTLSUB
STORE   LOSVEC
```

Uses AZIMUTH 191, COUNT 142, IMUCAL 69, LOSVEC 191, S2 85, STARAD 186, STARCODE 150, TAZEL1 191, TC 169, X1 85, X2 85, and XSM 186.

737 ⟨*Page CM0451* 737⟩≡ (695 2704)

```
                EXIT
                TC      BANKCALL
                CADR    MKRELEAS


NEXBNKSS        CAF     TWO
                TS      STARCODE
                CAF     SIX
                TC      TARGDRVE
                TC      INTPRET
                CALL
                        LITTLSUB
                STOVL   12D
                        LOSVEC
                STCALL  06D
                        AXISGEN
                CALL
                        CALCGTA
                EXIT
GCOMP4          CAF     V06N93S
                TC      BANKCALL
                CADR    GOFLASH
                TC      GCOMP5
                TCF     +2
                TCF     GCOMP4
                TC      INTPRET
                VLOAD   VAD
                        OGC
                        ERCOMP1
                STORE   ERCOMP1
                EXIT
GCOMP5          TC      BANKCALL
                CADR    MKRELEAS
                TC      DOWNFLAG
                ADRES   TRM03FLG

                TC      NEWMODEX
                MM      02
                TC      PHASCHNG
                OCT     00004
                TC      ENDOFJOB
V06N93S         VN      0693
GTSOPTCS        TC      ALARM
GTSOPTSS        OCT     01602
                TC      GCOMP5
```

```
BANK     34
SETLOC   IMUCAL1
BANK
```

Uses ERCOMP1 196, IMUCAL1 57, LOSVEC 191, MM 226, OGC 186, STARCODE 150, TC 169, TRM03FLG 101, and VN 159.

739 ⟨*Page CM0452* 739⟩≡ (695 2704)

```
                COUNT   34/COMST

LATAZCHK        DLOAD   SL2             # CALLS FOR AZIMUTH AND LATITUDE
                        LATITUDE
                STODL   DSPTEM1 +1
                        AZIMUTH
                RTB     EXIT
                        1STO2S
                XCH     MPAC
                TS      DSPTEM1
                TC      BANKCALL
                CADR    CLEANDSP
                CAF     VNG0641
                TC      BANKCALL
                CADR    GOFLASH
                TC      +2              # NOT ALLOWED
                TC      +2
                TC      -5
                TC      INTPRET
                SLOAD   RTB
                        DSPTEM1
                        CDULOGIC
                STORE   AZIMUTH
                SLOAD   SR2
                        DSPTEM1 +1
                STORE   LATITUDE
                RVQ
VNG0641         VN      0641
                BANK    33
                SETLOC  IMUCAL
                BANK


                COUNT*  $$/P03
TARGDRVE        EXTEND
                QXCH    QPLAC
                TS      TARG1/2
                TC      INTPRET
                CALL
                        TAR/EREF
                LXC,1   VLOAD*
                        TARG1/2
                        6D,1
                STCALL  STAR
```

```
        SXTANG
EXIT
CA      SAC
TS      DESOPTS
```

Uses AZIMUTH 191, COUNT 142, DESOPTS 159, DSPTEM1 154, IMUCAL 69, LATITUDE 191, MPAC 145, QPLAC 191, SAC 186, STAR 186, TARG1/2 191, TC 169, and VN 159.

741 ⟨*Page CM0453* 741⟩≡ (695 2704)

```
                CA      PAC
                TS      DESOPTT
RETARG          CAF     ZERO
                TS      OPTIND
                CAF     ONE
                TC      BANKCALL
                CADR    SXTMARK
                TC      BANKCALL
                CADR    OPTSTALL
                TC      GTSOPTCS
                CAE     FLAGWRD1
                MASK    TRM03BIT
                CCS     A
                TC      GCOMP5

                INDEX   MARKSTAT
                CA      QPRET
                EXTEND
                BZF     RETARG1
                TC      QPLAC


RETARG1         CA      ZERO            # RELEASE PREVIOUSLY GRABBED VAC AREA
                XCH     MARKSTAT
                CCS     A
                INDEX   A
                TS      A
                TCF     RETARG          # GO DO SXTMARK AGAIN
                BANK    33
                SETLOC  IMUCAL
                BANK
                COUNT*  $$/P03
PIPASC          2DEC    .76376833

VELSC           2DEC    -.52223476

ALSK            2DEC    .17329931

                2DEC    -.00835370

GEORGEJ         2DEC    .63661977

GEOCONS1        2DEC    .1

GEOCONS2        2DEC    .005
```

```
GEOCONS3        2DEC    .062

GEOCONS4        2DEC    .0003
```

Uses A 80, COUNT 142, DESOPTT 159, FLAGWRD1 97, IMUCAL 69, MARKSTAT 163, OPTIND 161, PAC 186, QPLAC 191, QPRET 85, TC 169, and TRM03BIT 101.

743 ⟨*Page CM0454* 743⟩≡ (695 2704)

```
                COUNT   33/P02
LITTLSUB        STQ
                        QPLAC
                LXC,1   VLOAD*
                        MARKSTAT
                        2,1
                STCALL  CDUSPOT
                        SXTNB
                CALL
                        TRG*NBSM
                GOTO
                        QPLAC


                EXIT
AZMTHCG1        TC      INTPRET
                DLOAD   RTB
                        NEWAZMTH
                        1STO2S
                EXIT
                XCH     MPAC
                TS      DSPTEM1
                TC      BANKCALL
                CADR    CLEANDSP
                CAF     VN0629
                TC      BANKCALL
                CADR    GOFLASH
                TCF     +2
                TCF     +2
                TCF     -5
                TC      INTPRET
                SLOAD   RTB
                        DSPTEM1
                        CDULOGIC
                STORE   LAUNCHAZ
                EXIT
                CA      ZERO
                TS      PREMTRXC
                TC      PHASCHNG
                OCT     00004
                TC      POSTJUMP
                CADR    PINBRNCH

VN0629          VN      0629
```

Uses CDUSPOT 152, COUNT 142, DSPTEM1 154, LAUNCHAZ 194, MARKSTAT 163, MPAC 145, NEWAZMTH 194, PREMTRXC 194, QPLAC 191, TC 169, and VN 159.

744a ⟨*Page CM0455* 744a⟩≡ (695 2704)

```
# *** END OF COMAID .029 ***
```

3.4 comekiss routines

744b ⟨*comekiss routines* 744b⟩≡ (19a)

⟨*ground tracking determination program* 744c⟩
⟨*p34-35 p74-75 code* 751⟩
⟨*r31 code* 809⟩
⟨*p76 code* 819⟩
⟨*r30 code* 824⟩
⟨*stable orbit* 841⟩

3.4.1 ground tracking determination program

744c ⟨*ground tracking determination program* 744c⟩≡ (744b)

⟨*Page CM0456* 745⟩
⟨*Page CM0457* 747⟩
⟨*Page CM0458* 749⟩
⟨*Page CM0459* 750⟩

745 ⟨*Page CM0456* 745⟩≡ (744c 2703)

```
# GROUND TRACKING DETERMINATION PROGRAM -- P21
#
# PROGRAM DESCRIPTION
#       MOD NO -- 1
#       MOD BY -- N. M. NEVILLE
#
# FUNCTIONAL DESCRIPTION --
#       TO PROVIDE THE ASTRONAUT DETAILS OF THE LM OR CSM GROUND TRACK WITHOUT
#       THE NEED FOR GROUND COMMUNICATION (REQUESTED BY DSKY).
#
# CALLING SEQUENCE --
#       ASTRONAUT REQUEST THROUGH DSKY V37E21E
#
# SUBROUTINES CALLED --
#       GOPERF4
#       GOFLASH
#       THISPREC
#       OTHPREC
#       LAT-LONG
#
# NORMAL EXIT MODES --
#       ASTRONAUT REQUEST THROUGH DSKY TO TERMINATE PROGRAM V34E
#
# ALARM OR ABORT EXIT MODES --
#       NONE
#
# OUTPUT --
#       OCTAL DISPLAY OF OPTION CODE AND VEHICLE WHOSE GROUND TRACK IS TO BE
#       COMPUTED
#               OPTION CODE     00002
#               THIS            00001
#               OTHER           00002
#       DECIMAL DISPLAY OF TIME TO BE INTEGRATED TO HOURS , MINUTES , SECONDS
#       DECIMAL DISPLAY OF LAT,LONG,ALT
#
# ERASABLE INITIALIZATION REQUIRED
#       AX0      2DEC   4.652459653 E-5   RADIANS       "68-69 CONSTANTS"
#       -AY0     2DEC   2.147535898 E-5   RADIANS
#       AZ0      2DEC   .7753206164       REVOLUTIONS
#       FOR LUNAR ORBITS 504LM VECTOR IS NEEDED
#       504LM    2DEC   -2.700340600 E-5  RADIANS
#       504LM _2 2DEC   -7.514128400 E-4  RADIANS
#       504LM _4 2DEC   _2.553198641 E-4  RADIANS
#
#       NONE
```

```
#
# DEBRIS
```

Uses 504LM 175, ALT 157, CODE 140, LAT 157, LONG 157, N 206, OTHPREC 71, P21 219, and THISPREC 73.

747 ⟨*Page CM0457* 747⟩≡ (744c 2703)

```
#       CENTRALS -- A,Q,L
#       OTHER -- THOSE USED BY THE ABOVE LISTED SUBROUTINES
#       SEE LEMPREC, LAT-LONG

                SBANK=  LOWSUPER        # FOR LOW 2CADR'S.

                BANK    33
                SETLOC  P20S
                BANK

                EBANK=  P21TIME
                COUNT   24/P21

PROG21          CAF     ONE
                TS      OPTION2         # ASSUMED VEHICLE IS LM, R2 = 00001
                CAF     BIT2            #  OPTION 2
                TC      BANKCALL
                CADR    GOPERF4
                TC      GOTOP00H        # TERMINATE
                TC      +2              # PROCEED VALUE OF ASSUMED VEHICLE OK
                TC      -5              # R2 LOADED THROUGH DSKY
P21PROG1        CAF     V6N34           # LOAD DESIRED TIME OF LAT-LONG.
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H        # TERM
                TC      +2              # PROCEED VALUES OK
                TC      -5              # TIME LOADED THROUGH DSKY
                TC      INTPRET
                DLOAD
                        DSPTEM1
                STCALL  TDEC1           # INTEG TO TIME SPECIFIED IN TDEC
                        INTSTALL
                BON     SET
                        P21FLAG
                        P21CONT         # ON...RECYCLE USING BASE VECTOR
                        VINTFLAG        # OFF..1ST PASS CALC BASE VECTOR
                SLOAD   SR1
                        OPTION2
                BHIZ    CLEAR
                        +2              # ZERO..THIS VEHICLE (CM)
                        VINTFLAG        # ONE...OTHER VEHICLE(LM)
                CLEAR   CLEAR
                        DIMOFLAG
                        INTYPFLG        # PRECISION
                CALL
```

```
                        INTEGRV         # CALCULATE
                GOTO                    # .AND
                        P21VSAVE        # ..SAVE BASE VECTOR
P21CONT         VLOAD                   # RECYCLE..INTEG FROM BASE VECTOR
                        P21BASER
```

Uses A 80, COUNT 142, DIMOFLAG 109, DSPTEM1 154, EBANK 80, INTYPFLG 107, L 80, LAT 157, LONG 157, LOWSUPER 67, OPTION2 157, P20S 69, P21 219, P21BASER 244, P21FLAG 103, P21TIME 179, Q 80, R2 188, SAVE 191, TC 169, TDEC 157, and VINTFLAG 109.

749 ⟨*Page CM0458* 749⟩≡ (744c 2703)

```
                STOVL   RCV             # ..POS
                        P21BASEV
                STODL   VCV             # ..VEL
                        P21TIME
                STORE   TET             # ..TIME
                CLEAR   CLEAR
                        DIMOFLAG
                        MOONFLAG
                SLOAD   BZE
                        P21ORIG
                        +3              # ZERO = EARTH
                SET                     # ...2 = MOON
                        MOONFLAG
                CALL
                        INTEGRVS
P21VSAVE        DLOAD                   # SAVE CURRENT BASE VECTOR
                        TAT
                STOVL   P21TIME         # ..TIME
                        RATT1
                STOVL   P21BASER        # ..POS B-29 OR B-27
                        VATT1
                STORE   P21BASEV        # ..VEL B-7  OR B-5
                ABVAL   SL*
                        0,2
                STOVL   P21VEL          # /VEL/ FOR N73 DSP
                        RATT
                UNIT    DOT
                        VATT            # U(R).(V)
                DDV     ASIN            # U(R).U(V)
                        P21VEL
                STORE   P21GAM          # SIN-1 U(R).U(V), -90 TO +90
                SXA,2   SET
                        P21ORIG         # 0 = EARTH  2 = MOON
                        P21FLAG
P21DSP          CLEAR   SLOAD           # GENERATE DISPLAY DATA
                        LUNAFLAG
                        X2
                BZE     SET
                        +2              # 0 = EARTH
                        LUNAFLAG
                VLOAD
                        RATT
                STODL   ALPHAV
                        TAT
                CLEAR   CALL
```

```
                ERADFLAG
                LAT-LONG
        DMP                     # MPAC = ALT, METERS B-29
                K.01
        STORE   P21ALT          # ALT/100 FOR N73 DSP
```

Uses ALPHAV 177, ALT 157, DIMOFLAG 109, ERADFLAG 99, LAT 157, LONG 157, LUNAFLAG 107, MOONFLAG 95, MPAC 145, P21ALT 244, P21BASER 244, P21BASEV 244, P21FLAG 103, P21GAM 244, P21ORIG 244, P21TIME 179, P21VEL 244, RCV 169, SAVE 191, TET 169, V 229, VCV 169, VEL 226, and X2 85.

750 ⟨*Page CM0459* 750⟩≡ (744c 2703)

```
        EXIT
        CAF     V06N43          # DISPLAY LAT,LONG,ALT
        TC      BANKCALL        # LAT,LONG = REVS B0 BOTH EARTH/MOON
        CADR    GOFLASH         # ALT = METERS B-29  BOTH EARTH/MOON
        TC      GOTOP00H        # TERM
        TC      GOTOP00H
        TC      INTPRET         # V32E RECYCLE
        DLOAD   DAD
                P21TIME
                600SEC          # 600 SECONDS OR 10 MIN
        STORE   DSPTEM1
        RTB
                P21PROG1

600SEC          2DEC    60000           # 10 MIN

P21ONENN        OCT     00001           # NEEDED TO DETERMINE VEHICLE
                OCT     00000           # TO BE INTEGRATED
V06N43          VN      00643
V6N34           VN      00634
K.01            2DEC    .01
```

Uses ALT 157, DSPTEM1 154, LAT 157, LONG 157, P21TIME 179, REVS 206, TC 169, and VN 159.

3.4.2 p34-35 p74-75 code

751 ⟨*p34-35 p74-75 code* 751⟩≡ (744b)

⟨*Page CM0460* 752⟩
⟨*Page CM0461* 753⟩
⟨*Page CM0462* 754⟩
⟨*Page CM0463* 756⟩
⟨*Page CM0464* 758⟩
⟨*Page CM0465* 759⟩
⟨*Page CM0466* 760⟩
⟨*Page CM0467* 761⟩
⟨*Page CM0468* 762⟩
⟨*Page CM0469* 763⟩
⟨*Page CM0470* 765⟩
⟨*Page CM0471* 767⟩
⟨*Page CM0472* 769⟩
⟨*Page CM0473* 770a⟩
⟨*Page CM0474* 770b⟩
⟨*Page CM0475* 771⟩
⟨*Page CM0476* 772⟩
⟨*Page CM0477* 773⟩
⟨*Page CM0478* 774⟩
⟨*Page CM0479* 775⟩
⟨*Page CM0480* 777⟩
⟨*Page CM0481* 779⟩
⟨*Page CM0482* 780⟩
⟨*Page CM0483* 781⟩
⟨*Page CM0484* 782⟩
⟨*Page CM0485* 783⟩
⟨*Page CM0486* 784⟩
⟨*Page CM0487* 786⟩
⟨*Page CM0488* 788⟩
⟨*Page CM0489* 790⟩
⟨*Page CM0490* 792⟩
⟨*Page CM0491* 793⟩
⟨*Page CM0492* 794⟩
⟨*Page CM0493* 795⟩
⟨*Page CM0494* 796⟩
⟨*Page CM0495* 797⟩
⟨*Page CM0496* 798⟩
⟨*Page CM0497* 799⟩
⟨*Page CM0498* 800a⟩
⟨*Page CM0499* 800b⟩
⟨*Page CM0500* 801⟩
⟨*Page CM0501* 802⟩
⟨*Page CM0502* 804⟩

⟨*Page CM0503* 806⟩
⟨*Page CM0504* 808⟩

752 ⟨*Page CM0460* 752⟩≡ (751 2761)

```
# TRANSFER PHASE INITIATION (TPI) PROGRAMS (P34 AND P74)
# MOD NO -1                    LOG SECTION -- P32-P35, P72-P75
# MOD BY WHITE, P.             DATE: 1 JUNE 67
#
# PURPOSE
#       (1)     TO CALCULATE THE REQUIRED DELTA V AND OTHER INITIAL CONDITIONS
#               REQUIRED BY THE ACTIVE VEHICLE FOR EXECUTION OF THE TRANSFER
#               PHASE INITIATION (TPI) MANEUVER, GIVEN --
#               (A)     TIME OF IGNITION TIG (TPI) OR THE ELEVATION ANGLE (E) OF
#                       THE ACTIVE/PASSIVE VEHICLE LOS AT TIG (TPI).
#               (B)     CENTRAL ANGLE OF TRANSFER (CENTANG) FROM TIG (TPI) TO
#                       INTERCEPT TIME (TIG (TPF)).
#       (2)     TO CALCULATE TIG (TPI) GIVEN E OR E GIVEN TIG (TPI).
#       (3)     TO CALCULATE THESE PARAMETERS BASED UPON MANEUVER DATA
#               APPROVED AND KEYED INTO THE DSKY BY THE ASTRONAUT.
#       (4)     TO DISPLAY TO THE ASTRONAUT AND THE GROUND CERTAIN DEPENDENT
#               VARIABLES ASSOCIATED WITH THE MANEUVER FOR APPROVAL BY THE
#               ASTRONAUT/GROUND.
#       (5)     TO STORE THE TPI TARGET PARAMETERS FOR USE BY THE DESIRED
#               THRUSTING PROGRAM.
#
# ASSUMPTIONS
#       (1)     LM ONLY -- THIS PROGRAM IS BASED UPON PREVIOUS COMPLETION OF
#               THE CONSTANT DELTA ALTITUDE (CDH) PROGRAM (P33/P73).
#               THEREFORE --
#               (A)     AT A SELECTED TPI TIME (NOW IN STORAGE) THE LINE OF SIGHT
#                       BETWEEN THE ACTIVE AND PASSIVE VEHICLES WAS SELECTED TO BE
#                       A PRESCRIBED ANGLE (E) (NOW IN STORAGE) FROM THE
#                       HORIZONTAL PLANE DEFINED BY THE ACTIVE VEHICLE POSITION.
#               (B)     THE TIME BETWEEN CDH IGNITION AND TPI IGNITION WAS
#                       COMPUTED TO BE GREATER THAN 10 MINUTES.
#               (C)     THE VARIATION OF THE ALTITUDE DIFFERENCE BETWEEN THE
#                       ORBITS WAS MINIMIZED.
#               (D)     THE PERICENTER ALTITUDES OF ORBITS FOLLOWING CSI AND
#                       CDH WERE COMPUTED TO BE GREATER THAN 35,000 FT FOR LUNAR
```

Uses A 80, D 226, P 188, TIG 224, and V 229.

753 ⟨*Page CM0461* 753⟩≡ (751 2761)

```
#                       ORBIT OR 85 NM FOR EARTH ORBIT.
#               (E)     THE CSI AND CDH MANEUVERS WERE ASSUMED TO BE PARALLEL TO
#                       THE PLANE OF THE PASSIVE VEHICLE ORBIT.  HOWEVER, CREW
#                       MODIFICATION OF DELTA V (LV) COMPONENTS MAY HAVE RESULTED
#                       IN AN OUT-OF-PLANE MANEUVER.
#       (2)     STATE VECTOR UPDATED BY P27 ARE DISALLOWED DURING AUTOMATIC
#               STATE VECTOR UPDATING INITIATED BY P20 (SEE ASSUMPTION (4)).
#       (3)     THIS PROGRAM MUST BE DONE OVER A TRACKING STATION FOR REAL
#               TIME GROUND PARTICIPATION IN DATA INPUT AND OUTPUT.  COMPUTED
#               VARIABLES MAY BE STORED FOR LATER VERIFICATION BY THE GROUND.
#               THESE STORAGE CAPABILITIES ARE LIMITED ONLY TO THE PARAMETERS
#               FOR ONE THRUSTING MANEUVER AT A TIME EXCEPT FOR CONCENTRIC
#               FLIGHT PLAN MANEUVER SEQUENCES.
#       (4)     THE RENDEZVOUS RADAR MAY OR MAY NOT BE USED TO UPDATE THE LM
#               OR CSM STATE VECTORS FOR THIS PROGRAM.  IF RADAR USE IS
#               DESIRED THE RADAR WAS TURNED ON AND LOCKED ON THE CSM BY
#               PREVIOUS SELECTION OF P20.  RADAR SIGHTING MARKS WILL BE MADE
#               AUTOMATICALLY APPROXIMATELY ONCE A MINUTE WHEN ENABLED BY THE
#               TRACK AND UPDATE FLAGS (SEE P20).  THE RENDEZVOUS TRACKING
#               MARK COUNTER IS ZEROED BY THE SELECTION OF P20 AND AFTER EACH
#               THRUSTING MANEUVER.
#       (5)     THE ISS NEED NOT BE ON TO COMPLETE THIS PROGRAM.
#       (6)     THE OPERATION OF THE PROGRAM UTILIZES THE FOLLOWING FLAGS --
#
#                       ACTIVE VEHICLE FLAG -- DESIGNATES THE VEHICLE WHICH IS
#                       DOING RENDEZVOUS THRUSTING MANEUVERS TO THE PROGRAM WHICH
#                       CALCULATES THE MANEUVER PARAMETERS.  SET AT THE START OF
#                       EACH RENDEZVOUS PRE-THRUSTING PROGRAM.
#
#                       FINAL FLAG -- SELECTS FINAL PROGRAM DISPLAYS AFTER CREW HAS
#                       SELECTED THE FINAL MANEUVER COMPUTATION CYCLE.
#
#                       EXTERNAL DELTA V FLAG -- DESIGNATES THE TYPE OF STEERING
#                       REQUIRED FOR EXECUTION OF THIS MANEUVER BY THE THRUSTING
#                       PROGRAM SELECTED AFTER COMPLETION OF THIS PROGRAM.
#
#       (7)     ONCE THE PARAMETERS REQUIRED FOR COMPUTATION OF THE MANEUVER
#               HAVE BEEN COMPLETELY SPECIFIED, THE VALUE OF THE ACTIVE
#               VEHICLE CENTRAL ANGLE OF TRANSFER IS COMPUTED AND STORED.
#               THIS NUMBER WILL BE AVAILABLE FOR DISPLAY TO THE ASTRONAUT
#               THROUGH THE USE OF V06N52.
#
#               THE ASTRONAUT WILL CALL THIS DISPLAY TO VERIFY THAT THE
#               CENTRAL ANGLE OF TRANSFER OF THE ACTIVE VEHICLE IS NOT WITHIN
```

Uses A 80, DISPLAYS 59, LV 85, STATE 138, and V 229.

754 ⟨*Page CM0462* 754⟩≡ (751 2761)

```
#               170 TO 190 DEGREES.  IF THE ANGLE IS WITHIN THIS ZONE THE
#               ASTRONAUT SHOULD REASSES THE INPUT TARGETING PARAMETERS BASED
#               UPON DELTA V AND EXPECTED MANEUVER TIME.
#       (8)     THIS PROGRAM IS SELECTED BY THE ASTRONAUT BY DSKY ENTRY --
#
#                       P34 IF THIS VEHICLE IS ACTIVE VEHICLE.
#
#                       P74 IF THIS VEHICLE IS PASSIVE VEHICLE.
#
# INPUT
#       (1)     TTPI    TIME OF THE TPI MANEUVER.
#       (2)     ELEV    DESIRED LOS ANGLE AT TPI
#       (3)     CENTANG ORBITAL CENTRAL ANGLE OF THE PASSIVE VEHICLE DURING
#                       TRANSFER FROM TPI TO TIME OF INTERCEPT
#
# OUTPUT
#       (1)     TRKMKCNT        NUMBER OF MARKS
#       (2)     TTOGO           TIME TO GO
#       (3)     +MGA            MIDDLE GIMBAL ANGLE
#       (4)     TTPI            COMPUTED TIME OF TPI MANEUVER
#                OR
#               ELEV            COMPUTED LOS ANGLE AT TPI
#       (5)     POSTTPI         PERIGEE ALTITUDE AFTER THE TPI MANEUVER
#       (6)     DELVTPI         MAGNITUDE OF DELTA V AT TPI
#       (7)     DELVTPF         MAGNITUDE OF DELTA V AT INTERCEPT
#       (8)     DVLOS           DELTA VELOCITY AT TPI -- LINE OF SIGHT
#       (9)     DELVLVC         DELTA VELOCITY AT TPI -- LOCAL VERTICAL COORDINATES
#
# DOWNLINK
#       (1)     TTPI            TIME OF TPI MANEUVER
#       (2)     TIG             TIME OF TPI MANEUVER
#       (3)     ELEV            DESIRED LOS ANGLE AT TPI
#       (4)     CENTANG         ORBITAL CENTRAL ANGLE OF THE PASSIVE VEHICLE DURING
#                               TRANSFER FROM TPI TO TIME OF INTERCEPT
#       (5)     DELVEET3        DELTA VELOCITY AT TPI -- REFERENCE COORDINATES
#       (6)     TPASS4          TIME OF INTERCEPT
#
# COMMUNICATION TO THRUSTING PROGRAMS
#       (1)     TIG             TIME OF THE TPI MANEUVER
#       (2)     RTARG           OFFSET TARGET POSITION
#       (3)     TPASS4          TIME OF INTERCEPT
#       (4)     XDELVFLG        RESET TO INDICATE LAMBERT (AIMPOINT) VG COMPUTATION
#
# SUBROUTINES USED
#       AVFLAGA
```

Uses +MGA 234, DELVEET3 236, DELVLVC 224, DELVTPF 183, DELVTPI 183, DVLOS 183, ORBITAL 59, POSTTPI 183, RTARG 224, TIG 224, TPASS4 236, TRKMKCNT 157, TTOGO 236, TTPI 236, V 229, VG 234, XDELVFLG 103, and ZONE 163.

756 ⟨*Page CM0463* 756⟩≡ (751 2761)

```
#       AVFLAGP
#       VNP00H
#       DISPLAYE
#       SELECTMU
#       PRECSET
#       S33/34.1
#       ALARM
#       BANKCALL
#       GOFLASH
#       GOTOP00H
#       TIMETHET
#       S34/35.2
#       PERIAPO1
#       SHIFTR1
#       S34/35.5
#       VN1645

                SETLOC  CSI/CDH
                BANK
                EBANK=  SUBEXIT
                COUNT   35/P3474

P34             TC      AVFLAGA
                TC      P34/P74A
P74             TC      AVFLAGP
P34/P74A        TC      P20FLGON        # SET UPDATFLG, TRACKFLG
                CAF     V06N37          # TTPI
                TC      VNP00H          # Onno: The scans look like 0 not zero
                TC      INTPRET
                SSP     EXIT
                        NN
                        0
                TC      DISPLAYE        # ELEV AND CENTANG
                TC      INTPRET
                CLEAR   DLOAD
                        ETPIFLAG
                        TTPI
                STODL   TIG
                        ELEV
                BZE     SET
                        P34/P74B
                        ETPIFLAG
P34/P74B        CALL
                        SELECTMU
DELELO          EQUALS  26D
```

```
P34/P74C        DLOAD   SET
                        ZEROVECS
                        ITSWICH
                BON     CLEAR
                        ETPIFLAG
```

Uses COUNT 142, CSI/CDH 69, EBANK 80, ETPIFLAG 103, ITSWICH 121, NN 244, SUBEXIT 181, TC 169, TIG 224, TRACKFLG 101, TTPI 236, and UPDATFLG 99.

758 ⟨*Page CM0464* 758⟩≡ (751 2761)

```
                        SWCHSET
                        ITSWICH
SWCHSET         STORE   NOMTPI
INTLOOP         DLOAD   DAD
                        TTPI
                        NOMTPI
                STCALL  TDEC1
                        PRECSET
                CALL
                        S33/34.1
                BZE     EXIT
                        SWCHCLR
                TC      ALARM
                OCT     611
                CAF     V05N09
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H
                TC      P34/P74A        # PROCEED
                TC      -7              # V32

SWCHCLR         BONCLR  BON
                        ITSWICH
                        INTLOOP
                        ETPIFLAG
                        P34/P74D        # DISPLAY TTPI
                EXIT
                TC      DISPLAYE        # DISPLAY ELEV AND CENTANG
                TC      P34/P74E
P34/P74D        EXIT
                CAF     V06N37          # TTPI
                TC      VNP00H
P34/P74E        TC      INTPRET
                SETPD   DLOAD
                        0D
                        RTX1
                STODL   X1
                        CENTANG
                PUSH    COS
                STODL   CSTH
                SIN
                STOVL   SNTH
                        RPASS3
                VSR*
                        0,2
```

```
STOVL   RVEC
        VPASS3
VSR*    SET
        0,2
        RVSW
```

Uses CSTH 188, ETPIFLAG 103, ITSWICH 121, NOMTPI 181, RPASS3 234, RVEC 188, RVSW 123, SNTH 188, TC 169, TTPI 236, VPASS3 234, and X1 85.

759 ⟨*Page CM0465* 759⟩≡ (751 2761)

```
STCALL  VVEC
        TIMETHET
DLOAD
        TTPI
STORE   INTIME          # FOR INITVEL
DAD
        T               # RENDEZVOUS TIME
STCALL  TPASS4          # FOR INITVEL
        S34/35.2
VLOAD   ABVAL
        DELVEET3
STOVL   DELVTPI
        VPASS4
VSU     ABVAL
        VTPRIME
STOVL   DELVTPF
        RACT3
PDVL    CALL
        VIPRIME
        PERIAPO1
CALL
        SHIFTR1
STODL   POSTTPI
        TTPI
STORE   TIG
EXIT
CAF     V06N58
TC      VNP00H
TC      INTPRET
CALL
        S34/35.5
CALL
        VN1645
GOTO
        P34/P74C
```

Uses DELVEET3 236, DELVTPF 183, DELVTPI 183, INTIME 236, POSTTPI 183, RACT3 234, TC 169, TIG 224, TPASS4 236, TTPI 236, VIPRIME 234, VPASS4 236, VTPRIME 234, and VVEC 188.

760 ⟨*Page CM0466* 760⟩≡ (751 2761)

```
# RENDEZVOUS MID-COURSE MANEUVER PROGRAMS (P35 AND P75)
# MOD NO -1                    LOG SECTION -- P32-P35, P72-P75
# MOD BY WHITE, P.             DATE:  1 JUNE 67
#
# PURPOSE
#       (1)     TO CALCULATE THE REQUIRED DELTA V AND OTHER INITIAL CONDITIONS
#               REQUIRED BY THE ACTIVE VEHICLE FOR EXECUTION OF THE NEXT
#               MID-COURSE CORRECTION OF THE TRANSFER PHASE OF AN ACTIVE
#               VEHICLE RENDEZVOUS.
#       (2)     TO DISPLAY TO THE ASTRONAUT AND THE GROUND CERTAIN DEPENDENT
#               VARIABLES ASSOCIATED WITH THE MANEUVER FOR APPROVAL BY THE
#               ASTRONAUT/GROUND.
#       (3)     TO STORE THE TPM TARGET PARAMETERS FOR USE BY THE DESIRED
#               THRUSTING PROGRAM.
#
# ASSUMPTIONS
#       (1)     THE ISS NEED NOT BE ON TO COMPLETE THIS PROGRAM.
#       (2)     STATE VECTOR UPDATES BY P27 ARE DISALLOWED DURING AUTOMATIC
#               STATE VECTOR UPDATING INITIATED BY P20 (SEE ASSUMPTION (3)).
#       (3)     THE RENDEZVOUS RADAR IS ON AND IS LOCKED ON THE CSM.  THIS WAS
#               DONE DURING PREVIOUS SELECTION OF P20.  RADAR SIGHTING MARKS
#               WILL BE MADE AUTOMATICALLY APPROXIMATELY ONCE A MINUTE WHEN
#               ENABLED BY THE TRACK AND UPDATE FLAGS (SEE P20).  THE
#               RENDEZVOUS TRACKING MARK COUNTER IS ZEROED BY THE SELECTION OF
#               P20 AND AFTER EACH THRUSTING MANEUVER.
#       (4)     THE OPERATION OF THE PROGRAM UTILIZES THE FOLLOWING FLAGS --
#
#                       ACTIVE VEHICLE FLAG -- DESIGNATES THE VEHICLE WHICH IS
#                       DOING RENDEZVOUS THRUSTING MANEUVERS TO THE PROGRAM WHICH
#                       CALCULATES THE MANEUVER PARAMETERS.  SET AT THE START OF
#                       EACH RENDEZVOUS PRE-THRUSTING PROGRAM.
#
#                       FINAL FLAG -- SELECTS FINAL PROGRAM DISPLAYS AFTER CREW HAS
#                       SELECTED THE FINAL MANEUVER COMPUTATION CYCLE.
#
#                       EXTERNAL DELTA V FLAG -- DESIGNATES THE TYPE OF STEERING
#                       REQUIRED FOR EXECUTION OF THIS MANEUVER BY THE THRUSTING
#                       PROGRAM SELECTED AFTER COMPLETION OF THIS PROGRAM.
#
#       (5)     THE TIME OF INTERCEPT (T(INT)) WAS DEFINED BY PREVIOUS
#               COMPLETION OF THE TRANSFER PHASE INITIATION (TPI) PROGRAM
#               (P34/P74) AND IS PRESENTLY AVAILABLE IN STORAGE.
```

Uses A 80, DISPLAYS 59, P 188, STATE 138, and V 229.

761 ⟨*Page CM0467* 761⟩≡ (751 2761)

```
#       (6)     ONCE THE PARAMETERS REQUIRED FOR COMPUTATION OF THE MANEUVER
#               HAVE BEEN COMPLETELY SPECIFIED, THE VALUE OF THE ACTIVE
#               VEHICLE CENTRAL ANGLE OF TRANSFER IS COMPUTED AND STORED.
#               THIS NUMBER WILL BE AVAILABLE FOR DISPLAY TO THE ASTRONAUT
#               THROUGH THE USE OF V06N52
#
#               THE ASTRONAUT WILL CALL THIS DISPLAY TO VERIFY THAT THE
#               CENTRAL ANGLE OF TRANSFER OF THE ACTIVE VEHICLE IS NOT WITHIN
#               170 TO 190 DEGREES.  IF THE ANGLE IS WITHIN THIS ZONE THE
#               ASTRONAUT SHOULD REASSESS THE INPUT TARGETING PARAMETERS BASED
#               UPON DELTA V AND EXPECTED MANEUVER TIME.
#       (7)     THIS PROGRAM IS SELECTED BY THE ASTRONAUT BY DSKY ENTRY --
#
#                       P35 IF THIS VEHICLE IS ACTIVE VEHICLE.
#
#                       P75 IF THIS VEHICLE IS PASSIVE VEHICLE.
#
# INPUT
#       (1)     TPASS4          TIME OF INTERCEPT -- SAVED FROM P34/P74
#
# OUTPUT
#       (1)     TRKMKCNT        NUMBER OF MARKS
#       (2)     TTOGO           TIME TO GO
#       (3)     +MGA            MIDDLE GIMBAL ANGLE
#       (4)     DVLOS           DELTA VELOCITY AT MID -- LINE OF SIGHT
#       (5)     DELVLVC         DELTA VELOCITY AT MID -- LOCAL VERTICAL COORDINATES
#
# DOWNLINK
#       (1)     TIG             TIME OF THE TPM MANEUVER
#       (2)     DELVEET3        DELTA VELOCITY AT TPM -- REFERENCE COORDINATES
#       (3)     TPASS4          TIME OF INTERCEPT
#
# COMMUNICATION TO THRUSTING PROGRAMS
#       (1)     TIG             TIME OF THE TPM MANEUVER
#       (2)     RTARG           OFFSET TARGET POSITION
#       (3)     TPASS4          TIME OF INTERCEPT
#       (4)     XDELVFLG        RESET TO INDICATE LAMBERT (AIMPOINT) VG COMPUTATION.
#
# SUBROUTINES USED
#       AVFLAGA
#       AVFLAGP
#       LOADTIME
#       SELECTMU
#       PRECSET
#       S34/35.1
```

```
#       S34/35.2
```

Uses +MGA 234, DELVEET3 236, DELVLVC 224, DVLOS 183, RTARG 224, TIG 224, TPASS4 236, TRKMKCNT 157, TTOGO 236, V 229, VG 234, XDELVFLG 103, and ZONE 163.

762 ⟨*Page CM0468* 762⟩≡ (751 2761)

```
#       S34/35.5
#       VN1645

                COUNT   35/P3575
                EBANK=  KT

P35             TC      AVFLAGA
                EXTEND
                DCA     ATIGINC
                TC      P35/P75A
P75             TC      AVFLAGP
                EXTEND
                DCA     PTIGINC
P35/P75A        DXCH    KT
                TC      P20FLGON        # SET UPDATFLG, TRACKFLG
                TC      INTPRET
                CALL
                        SELECTMU
P35/P75B        RTB
                        LOADTIME
                STORE   TSTRT
                DAD
                        KT
                STORE   TIG
                STORE   INTIME          # FOR INITVEL
                STCALL  TDEC1
                        PRECSET         # ADVANCE BOTH VEHICLES
                CALL
                        S34/35.1        # GET NORM AND LOS FOR TRANSFORM
                CALL
                        S34/35.2        # GET DELTA V(LV)
                CALL
                        S34/35.5
                CALL
                        VN1645
                GOTO
                        P35/P75B
```

Uses ATIGINC 175, COUNT 142, EBANK 80, INTIME 236, KT 181, LV 85, PTIGINC 175, TC 169, TIG 224, TRACKFLG 101, TSTRT 239, UPDATFLG 99, and V 229.

763 ⟨*Page CM0469* 763⟩≡ (751 2761)

```
# ***** S33/34.1 *****

S33/34.1        STQ     SSP
                        NORMEX
                        TITER
                OCT     40000
                DLOAD   SETPD
                        MAX250
                        OD
                STOVL   SECMAX
                        RACT3
                STOVL   RAPREC
                        VACT3
                STOVL   VAPREC
                        RPASS3
                STOVL   RPPREC
                        VPASS3
                STORE   VPPREC
ELCALC          CALL
                        S34/35.1        # NORMAL AND LOS
                VXV     PDVL
                        RACT3           # (RA*VA)*RA OD
                PDVL    UNIT            # ULOS AT 6D
                        RACT3
                PDVL    VPROJ           # XCHNJ AND UP
                VSL2    BVSU
                        ULOS
                UNIT    PDVL            # UP AT OD
                DOT     PDVL            # UP.UN*RA AT OD
                        OD              # UP IN MPAC
                DOT     SIGN
                        ULOS
                SL1     ACOS
                PDVL    DOT             # EA AT OD
                        ULOS
                        RACT3
                BPL     DLOAD
                        TESTY
                        DPPOSMAX
                DSU     PUSH
TESTY           BOFF    DLOAD
                        ITSWICH
                        ELEX
                        DELEL
                STODL   DELELO
```

```
DSU
        ELEV
STORE   DELEL
ABS     DSU
        ELEPS
```

Uses DELEL 234, ITSWICH 121, MPAC 145, NORMEX 165, RACT3 234, RAPREC 236, RPASS3 234, RPPREC 236, SECMAX 234, TITER 239, ULOS 183, UN 188, VACT3 234, VAPREC 236, VPASS3 234, and VPPREC 236.

765 ⟨*Page CM0470* 765⟩≡ (751 2761)

```
                BMN
                        TIMEX           # COMMERCIALS EVERYWHERE
  FIGTIME       SLOAD   SR1
                        TITER
                BHIZ    LXA,1
                        NORMEX          # TOO MANY ITERATIONS
                        MPAC
                SXA,1   VLOAD
                        TITER
                        RPASS3
                UNIT    PDDL
                        36D
                PDVL    UNIT
                        RACT3
                PDDL
                PDDL    PUSH
                        36D
                BDSU
                        12D
                STODL   30D             # RP-RA MAGNITUDES
                        DPHALF
                DSU     PUSH
                        ELEV
                SIGN    BMN
                        30D
                        NORMEX
                DLOAD   COS
                DMP     DDV
                        14D
                        12D
                DCOMP                   # SINCE COS(180-A)=-COS A
                STORE   28D
                ABS     BDSU
                        DPHALF
                BMN     VLOAD
                        NORMEX
                        UNRM
                VXV     UNIT
                        6D              # UN*RA
                DOT     DMP
                        VACT3
                        12D
                PDVL    VXV
                        0D
                        VPASS3
```

```
VXV     UNIT
        OD              # (RP*VP)*RP
DOT     DMP
        VPASS3
        14D
```

Uses A 80, MPAC 145, NORMEX 165, RACT3 234, RPASS3 234, TITER 239, UN 188, UNRM 183, VACT3 234, and VPASS3 234.

767 ⟨*Page CM0471* 767⟩≡ (751 2761)

```
                BDSU
                NORM    PDVL            # NORMALIZED WA-WP 12D
                        X1
                        6D
                VXV     DOT
                        0D
                        UNRM            # RA*RP.UN 14D
                PDVL    DOT
                        0D
                        6D
                SL1     ACOS
                SIGN
                DSU     DAD             # ALPHA PI
                        DPHALF
                        ELEV
                PDDL    ACOS
                        28D
                BDSU    SIGN
                        DPHALF
                        30D             # CONTAINS RP-RA
                DAD
                DMP     DDV
                        TWOPI
                DMP
                SL*     DMP
                        0 -3,1
                PUSH    ABS
                DSU     BMN
                        SECMAX
                        OKMAX
                DLOAD   SIGN            # REPLACE TIME WITH MAX TIME SIGNED
                        SECMAX
                PUSH
        OKMAX   SLOAD   BPL             # TEST FIRST ITERATION
                        TITER
                        REPETE
                SSP     DLOAD
                        TITER
                OCT     37777
                GOTO
                        STORDELT
        REPETE  DLOAD   DMP
                        DELEL
                        DELELO
                BPL     DLOAD
```

```
                NEXTES
                SECMAX
        DMP
                THIRD
        STODL   SECMAX
```

Uses DELEL 234, SECMAX 234, TITER 239, UN 188, UNRM 183, and X1 85.

769 ⟨*Page CM0472* 769⟩≡ (751 2761)

```
                ABS     SR1             # CROSSED OVER SOLUTION
                DCOMP   GOTO            # DT=(-SIGN(DTO)//DT//)/2
                        RESIGN
NEXTES          DLOAD   ABS
                        DELEL
                PDDL    ABS
                        DELELO
                DSU
                BMN     DLOAD
                        REVERS          # WRONG DIRECTION
                ABS
RESIGN          SIGN    GOTO
                        DELTEEO
                        STORDELT
REVERS          DLOAD   DCOMP
                        DELTEEO
                PUSH    SR1
                STORE   DELTEEO
                DAD
                GOTO
                        ADTIME
STORDELT        STORE   DELTEEO
ADTIME          DAD
                        NOMTPI          # SUM OF DELTA T:S
                STORE   NOMTPI
                VLOAD   PDVL
                        VAPREC
                        RAPREC
                CALL
                        GOINT
                CALL
                        ACTIVE          # STORE NEW RACT3 VACT3
                VLOAD   PDVL
                        VPPREC
                        RPPREC
                CALL
                        GOINT
                CALL
                        PASSIVE         # STORE NEW RPASS3 VPASS3
                GOTO
                        ELCALC
ELEX            DLOAD   DAD
                        TTPI
                        NOMTPI
                STODL   TTPI
```

```
                BON
                        ETPIFLAG
                        TIMEX
                STORE   ELEV
TIMEX           DLOAD   GOTO
```

Uses DELEL 234, DELTEEO 234, ETPIFLAG 103, NOMTPI 181, RACT3 234, RAPREC 236, RPASS3 234, RPPREC 236, TTPI 236, VACT3 234, VAPREC 236, VPASS3 234, and VPPREC 236.

770a ⟨*Page CM0473* 770a⟩≡ (751 2761)

```
                        ZEROVECS
                        NORMEX
```

Uses NORMEX 165.

770b ⟨*Page CM0474* 770b⟩≡ (751 2761)

```
# ***** S34/35.1 *****

# COMPUTE UNIT NORMAL AND LINE OF SIGHT VECTORS GIVEN THE ACTIVE AND
# PASSIVE POS AND VEL AT TIME T3
                SETLOC  S3435LOC
                BANK

S34/35.1        VLOAD   VSU
                        RPASS3
                        RACT3
                UNIT    PUSH
                STOVL   ULOS
                        RACT3
                VXV     UNIT
                        VACT3
                STORE   UNRM
                RVQ
```

Uses RACT3 234, RPASS3 234, S3435LOC 69, ULOS 183, UNRM 183, VACT3 234, and VEL 226.

771 ⟨*Page CM0475* 771⟩≡ (751 2761)

```
# ***** S34/35.2 *****

# ADVANCE PASSIVE VEH TO RENDEZVOUS TIME AND GET REQ VEL FROM LAMBERT
                SETLOC  CSI/CDH
                BANK

S34/35.2        STQ     VLOAD
                        SUBEXIT
                        VPASS3
                PDVL    PDDL
                        RPASS3
                        INTIME
                PDDL    PDDL
                        TPASS4
                        TWOPI           # CONIC
                PDDL    BHIZ
                        NN
                        S3435.23
                DLOAD   PDDL
                        ZEROVECS        # PRECISION
S3435.23        CALL
                        INTINT          # GET TARGET VECTOR
S3435.25        STOVL   RTARG
                        VATT
                STOVL   VPASS4
                        RTARG
# COMPUTE PHI = PI + (ACOS(UNIT RA.UNIT RP) - PI) SIGN(RA*RP.U)
                UNIT    PDVL            # UNIT RP
                        RACT3
                UNIT    PUSH            # UNIT RA
                VXV     DOT
                        OD
                        UNRM            # RA*RP.U
                PDVL
                DOT     SL1             # UNIT RA.UNIT RP
                        OD
                ACOS    SIGN
                BPL     DAD
                        NOPIE
                        DPPOSMAX        # REASONABLE TWO PI
NOPIE           STODL   ACTCENT
                        TPASS4
                DSU
                        INTIME
                STORE   DELLT4
```

```
SLOAD   SETPD
        NN              # NUMBER OF OFFSETS
        OD
PDDL    PDVL
        EPSFOUR
```

Uses ACTCENT 183, CSI/CDH 69, DELLT4 224, INTIME 236, NN 244, RACT3 234, RPASS3 234, RTARG 224, SUBEXIT 181, TPASS4 236, UNRM 183, VEL 226, VPASS3 234, and VPASS4 236.

772 ⟨*Page CM0476* 772⟩≡ (751 2761)

```
        RACT3
STOVL   RINIT
        VACT3
STCALL  VINIT
        INITVEL
CALL
        LOMAT
VLOAD   MXV
        DELVEET3
        OD
VSL1
STCALL  DELVLVC
        SUBEXIT
```

Uses DELVEET3 236, DELVLVC 224, RACT3 234, RINIT 234, SUBEXIT 181, VACT3 234, and VINIT 234.

773 ⟨*Page CM0477* 773⟩≡ (751 2761)

```
# ***** S34/35.3 *****

S34/35.3        STQ     CALL
                        NORMEX
                        LOMAT           # GET MATRIX IN PUSH LIST
                VLOAD   VXM
                        DELVLVC         # NEW DEL V TPI
                        OD
                VSL1
                STORE   DELVEET3        # SAVE FOR TRANSFORM
                VAD     PDVL
                        VACT3           # NEW V REQ
                        RACT3
                PDDL    PDDL
                        TIG
                        TPASS4
                PDDL    PUSH
                        DPPOSMAX
                CALL                    # INTEG. FOR NEW TARGET VEC
                        INTINT
                VLOAD
                        RATT
                STORE   RTARG
NOVRWRT         VLOAD   PUSH
                        ULOS
                VXV     VCOMP
                        UNRM
                UNIT    PUSH
                VXV     VSL1
                        ULOS
                PDVL
                PDVL    MXV
                        DELVEET3
                        OD
                VSL1
                STCALL  DVLOS
                        NORMEX
```

Uses DEL 232, DELVEET3 236, DELVLVC 224, DVLOS 183, NORMEX 165, RACT3 234, RTARG 224, SAVE 191, TIG 224, TPASS4 236, ULOS 183, UNRM 183, V 229, and VACT3 234.

774 ⟨*Page CM0478* 774⟩≡ (751 2761)

```
# ***** S34/35.4 *****

S34/35.4        STQ     SETPD           # NO ASTRONAUT OVERWRITE
                        NORMEX
                        OD
                GOTO
                        NOVRWRT
```

Uses NORMEX 165.

775 ⟨*Page CM0479* 775⟩≡ (751 2761)

```
# ***** LOMAT *****

LOMAT           VLOAD   VCOMP
                        UNRM
                STOVL   6D              # Y
                        RACT3
                UNIT    VCOMP
                STORE   12D
                VXV     VSL1
                        UNRM            # Z*-Y
                STORE   0D
                SETPD   RVQ
                        18D
GOINT           PDDL    PDDL            # DO
                        ZEROVECS        #       NOT
                        NOMTPI          #
                PUSH    PUSH            #               ORDER OR INSERT BEFORE INTINT
INTINT          STQ     CALL
                        RTRN
                        INTSTALL
                CLEAR   DLOAD
                        INTYPFLG
                BZE     SET
                        +2
                        INTYPFLG
                DLOAD   STADR
                STODL   TDEC1
                SET     LXA,2
                        MOONFLAG
                        RTX2
                BON     CLEAR
                        CMOONFLG
                        ALLSET
                        MOONFLAG
ALLSET          STOVL   TET
                VSR*
                        0,2
                STOVL   RCV
                VSR*
                        0,2
                STCALL  VCV
                        INTEGRVS
                VLOAD   GOTO
                        RATT
                        RTRN
```

Uses CMOONFLG 125, INTYPFLG 107, MOONFLAG 95, NOMTPI 181, RACT3 234, RCV 169, RTRN 181, TET 169, UNRM 183, VCV 169, and Z 80.

777 ⟨*Page CM0480* 777⟩≡ (751 2761)

```
# ***** S34/35.5 *****
#
# SUBROUTINES USED
#       BANKCALL
#       GOFLASH
#       GOTOP00H
#       S34/35.3
#       S34.35.4
#       VNP00H

S34/35.5        STQ     BON
                        SUBEXIT
                        FINALFLG
                        FLAGON
                SET     GOTO
                        UPDATFLG
                        FLAGOFF
FLAGON          VLOAD
                        DELVLVC
                STORE   DVLOS           # SAVE DELTA V BEFORE DISPLAY
                EXIT
                CAF     V06N81
                TC      VNP00H
                TC      INTPRET
                VLOAD   VSU             # TEST FOR OVERWRITE OF COMPUTED
                        DELVLVC         #                      DELTA V
                        DVLOS
                ABVAL   BZE
                        NOCHG           # NO OVERWRITE
                CALL
                        S34/35.3
NOCHG           CLEAR   VLOAD
                        XDELVFLG
                        DELVEET3
                STORE   DELVSIN
FLAGOFF         CALL
                        S34/35.4
                EXIT
                CAF     V06N59
                TC      VNP00H
                TC      INTPRET
                GOTO
                        SUBEXIT
```

Uses DELVEET3 236, DELVLVC 224, DELVSIN 236, DVLOS 183, FINALFLG 105, SAVE 191,

SUBEXIT 181, TC 169, UPDATFLG 99, V 229, and XDELVFLG 103.

779 ⟨*Page CM0481* 779⟩≡ (751 2761)

```
# ***** VN1645 *****
#
# SUBROUTINES USED
#       P3XORP7X
#       GET+MGA
#       BANKCALL
#       DELAYJOB
#       COMPTGO
#       GOFLASHR
#       GOTOPOOH
#       FLAGUP

VN1645          STQ     DLOAD
                        SUBEXIT
                        DP-.01
                STORE   +MGA            # MGA = -.01
                BOFF    DLOAD
                        FINALFLG
                        GET45
                        DP-.01
                DAD
                        DP-.01
                STORE   +MGA            # MGA = -.02
                BOFF    EXIT
                        REFSMFLG
                        GET45
                TC      P3XORP7X
                TC      +2              # P3X
                TC      GET45 +1        # P7X
                TC      INTPRET
                VLOAD   PUSH
                        DELVSIN
                CALL                    # COMPUTE MGA
                        GET+MGA
GET45           EXIT
                TC      COMPTGO         # INITIATE TASK TO UPDATE TTOGO
                CA      SUBEXIT
                TS      QSAVED
                CAF     1SEC
                TC      BANKCALL
                CADR    DELAYJOB
                CAF     V16N45          # TRKMKCNT, TTOGO, +MGA
                TC      BANKCALL
                CADR    GOFLASH
                TC      KILCLOCK        # TERMINATE
```

```
                TC      N45PROC         # PROCEED
                TC      CLUPDATE        # RECYCLE -- RETURN FOR INITIAL COMPUTATION
KILCLOCK        CA      Z
                TS      DISPDEX
```

Uses +MGA 234, DELVSIN 236, DISPDEX 165, FINALFLG 105, QSAVED 181, REFSMFLG 107, SUBEXIT 181, TC 169, TRKMKCNT 157, TTOGO 236, and Z 80.

780 ⟨*Page CM0482* 780⟩≡ (751 2761)

```
                TC      GOTOP00H
N45PROC         CS      FLAGWRD2
                MASK    BIT6
                EXTEND
                BZF     KILCLOCK        # FINALFLG IS SET -- FLASH V37 -- AWAIT NEW P
                TC      PHASCHNG
                OCT     04024
                TC      UPFLAG          # SET
                ADRES   FINALFLG        # FINALFLG
CLUPDATE        CA      Z
                TS      DISPDEX
                TC      PHASCHNG
                OCT     04024
                TC      INTPRET
                CLEAR   GOTO
                        UPDATFLG
                        QSAVED
```

Uses DISPDEX 165, FINALFLG 105, FLAGWRD2 101, QSAVED 181, TC 169, UPDATFLG 99, and Z 80.

781 ⟨*Page CM0483* 781⟩≡ (751 2761)

```
# ***** DISPLAYE *****
#
# SUBROUTINES USED
#       BANKCALL
#       GOFLASHR
#       GOTOPOOH
#       BLANKET
#       ENDOFJOB

DISPLAYE        EXTEND
                QXCH    NORMEX
                CAF     V06N55
                TCR     BANKCALL
                CADR    GOFLASH
                TCF     GOTOPOOH
                TC      NORMEX
                TCF     -5
```

Uses NORMEX 165 and TC 169.

782 ⟨*Page CM0484* 782⟩≡ (751 2761)

```
# ***** P3XORP7X *****

P3XORP7X        CAF     HIGH9
                MASK    MODREG
                EXTEND
                BZF     +2
                INCR    Q
                RETURN

# ***** VNP00H *****
#
# SUBROUTINES USED
#       BANKCALL
#       GOFLASH
#       GOTOP00H

                SETLOC P30SUBS
                BANK

VNP00H          EXTEND
                QXCH    RTRN
                TS      VERBNOUN
                CAF     VNBANK          # ***** THIS ROUTINE MUST REMAIN IN
                XCH     FBANK           #       FIXED-FIXED *****
                TS      TBASE5          # * WATCH OUT *

                CA      VERBNOUN
                TCR     BANKCALL
                CADR    GOFLASH
                TCF     GOTOP00H
                TCF     +2
VNBANK          TC      -5

                CA      TBASE5
                TS      FBANK
                TC      RTRN
```

Uses FBANK 80, MODREG 154, P30SUBS 57, Q 80, RTRN 181, TBASE5 154, TC 169, and VERBNOUN 181.

783 ⟨*Page CM0485* 783⟩≡ (751 2761)

```
# ***** CONSTANTS *****

V06N37          VN      0637
V06N55          VN      0655
V06N58          VN      0658
V06N59          VN      0659
V06N81          VN      0681
V16N45          VN      1645
                SETLOC  CSI/CDH
                BANK

TWOPI           2DEC    6.283185307 B-4
MAX250          2DEC    25 E3 B-28      # RSB 2004 added the B-28. OH 2009 leave?
THIRD           2DEC    .333333333
ELEPS           2DEC    .27777777 E-3
DECTWO          OCT     2
DP-.01          OCT     77777           # CONSTANTS
                OCT     61337           # ADJACENT      -.01 FOR MGA DSP
EPSFOUR         2DEC    .0416666666
```

Uses CSI/CDH 69 and VN 159.

784 ⟨*Page CM0486* 784⟩≡ (751 2761)

```
# ***** INITVEL *****
# MOD NO -1                     LOG SECTION -- P34-P35, P74-P75
# MOD BY WHITE, P.              DATE:  21 NOV 67
#
# FUNCTIONAL DESCRIPTION
#       THIS SUBROUTINE COMPUTES THE REQUIRED INITIAL VELOCITY VECTOR FOR
#       A TRAJECTORY OF SPECIFIC TRANSFER TIME BETWEEN SPECIFIED INITIAL
#       AND TARGET POSITIONS.  THE TRAJECTORY MAY BE EITHER CONIC OR
#       PRECISION DEPENDING ON AN INPUT PARAMETER (NAMELY, NUMBER OF
#       OFFSETS).  IN ADDITION, IN THE PRECISION TRAJECTORY CASE, THE
#       SUBROUTINE ALSO COMPUTES AN OFFSET TARGET VECTOR, TO BE USED
#       DURING PURE-CONIC CROSS-PRODUCT STEERING.  THE OFFSET TARGET
#       VECTOR IS THE TERMINAL POSITION VECTOR OF A CONIC TRAJECTORY WHICH
#       HAS THE SAME INITIAL STATE AS A PRECISION TRAJECTORY WHOSE
#       TERMINAL POSITION VECTOR IS THE SPECIFIED TARGET VECTOR.
#
#       IN ORDER TO AVOID THE INHERENT SINGULARITIES IN THE 180 DEGREE
#       TRANSFER CASE WHEN THE (TRUE OR OFFSET) TARGET VECTOR MAY BE
#       SLIGHTLY OUT OF THE ORBITAL PLANE, THIS SUBROUTINE ROTATES THIS
#       VECTOR INTO A PLANE DEFINED BY THE INPUT INITIAL POSITION VECTOR
#       AND ANOTHER INPUT VECTOR (USUALLY THE INITIAL VELOCITY VECTOR),
#       WHENEVER THE INPUT TARGET VECTOR LIES INSIDE A CONE WHOSE VERTEX
#       IS THE ORIGIN OF COORDINATES, WHOSE AXIS IS THE 180 DEGREE
#       TRANSFER DIRECTION, AND WHOSE CONE ANGLE IS SPECIFIED BY THE USER.
#
#       THE LAMBERT SUBROUTINE IS UTILIZED FOR THE CONIC COMPUTATIONS AND
#       THE COASTING INTEGRATION SUBROUTINE IS UTILIZED FOR THE PRECISION
#       TRAJECTORY COMPUTATIONS.
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             INITVEL
#       L+2     (RETURN -- ALWAYS)
#
# INPUT
#       (1)     RINIT           INITIAL POSITION RADIUS VECTOR
#       (2)     VINIT           INITIAL POSITION VELOCITY VECTOR
#       (3)     RTARG           TARGET POSITION RADIUS VECTOR
#       (4)     DELLT4          DESIRED TIME OF FLIGHT FROM RINIT TO RTARG
#       (5)     INTIME          TIME OF RINIT
#       (6)     0D              NUMBER OF ITERATIONS OF LAMBERT/INTEGRVS
#       (7)     2D              ANGLE TO 180 DEGREES WHEN ROTATION STARTS
#       (8)     RTX1            -2 FOR EARTH, -10D FOR LUNAR
#       (9)     RTX2            COORDINATE SYSTEM ORIGIN -- 0 FOR EARTH, 2 FOR LUNAR
#       PUSHLOC SET AT 4D
```

#

Uses A 80, DELLT4 224, INTIME 236, L 80, ORBITAL 59, P 188, PUSHLOC 145, RINIT 234, RTARG 224, STATE 138, and VINIT 234.

786 ⟨*Page CM0487* 786⟩≡ (751 2761)

```
# OUTPUT
#       (1)     RTARG           OFFSET TARGET POSITION VECTOR
#       (2)     VIPRIME         MANEUVER VELOCITY REQUIRED
#       (3)     VTPRIME         VELOCITY AT TARGET AFTER MANEUVER
#       (4)     DELVEET3        DELTA VELOCITY REQUIRED FOR MANEUVER
#
# SUBROUTINES USED
#       LAMBERT
#       INTSTALL
#       INTEGRVS

                SETLOC  INTVEL
                BANK

                COUNT   11/INITV
INITVEL         SET                     # COGA GUESS NOT AVAILABLE
                        GUESSW
HAVEGUES        VLOAD   STQ
                        RTARG
                        NORMEX
                STORE   RTARG1
                SLOAD   BHIZ
                        RTX2
                        INITVEL1
                VLOAD   VSL2
                        RINIT           # B29
                STOVL   RINIT           # B27
                        VINIT           # B7
                VSL2
                STOVL   VINIT           # B5
                        RTARG1
                VSL2
                STORE   RTARG1

# INITIALIZATION

INITVEL1        SSP     DLOAD           # SET ITCTR TO -1,LOAD MPAC WITH E4 (PL 2D)
                        ITCTR
                        0 -1
                COSINE  SR1             # CALCULATE COSINE (E4) (+2)
                STODL   COZY4           # SET COZY4 TO COSINE (E4) (PL 0D)
                LXA,2   SXA,2
                        MPAC
                        VTARGTAG        # SET VTARGTAG TO 0D (SP)
                VLOAD
```

```
                RINIT
        STOVL   R1VEC           # R1VEC EQ RINIT
                RTARG1
```

Uses COUNT 142, COZY4 234, DELVEET3 236, GUESSW 101, INTVEL 61, ITCTR 236, MPAC 145, NORMEX 165, R1VEC 188, RINIT 234, RTARG 224, RTARG1 234, VINIT 234, VIPRIME 234, VTARGTAG 188, and VTPRIME 234.

788 ⟨*Page CM0488* 788⟩≡ (751 2761)

```
                STODL   R2VEC           # R2VEC EQ RTARG
                        DELLT4
                STORE   TDESIRED        # TDESIRED EQ DELLT4
                SETPD   VLOAD
                        0D              # INITIALIZE PL TO 0D
                        RINIT           # MPAC EQ RINIT (+29)
                UNIT    PUSH            # UNIT(RI) (+1)         (PL 6D)
                VXV     UNIT
                        VINIT           # MPAC EQ UNIT(RI) X VI (+8)
                STOVL   UN
                        RTARG1
                UNIT    DOT             # TEMP=URT.URI (+2)     (PL 0D)
                DAD     CLEAR
                        COZY4
                        NORMSW
                STORE   COZY4
INITVEL2        BPL     SET
                        INITVEL3        # UN CALCULATED IN LAMBERT
                        NORMSW

# ROTATE RC INTO YC PLANE -- SET UNIT NORMAL TO YC

                VLOAD   PUSH            #                                 (PL 6D)
                        R2VEC           # RC TO 6D (+29)
                ABVAL   PDVL            # RC TO MPAC, ABVAL(RC) (+29) TO 0D(PL 2D)
                PUSH    VPROJ           #                                 (PL 8D)
                        UN
                VSL2    BVSU
                UNIT    VXSC            #                                 (PL 0D)
                VSL1
                STORE   R2VEC
                TLOAD   SLOAD
                        ZEROVEC
                        ITCTR
                BPL     VLOAD
                        INITVEL3
                        R2VEC
                STORE   RTARG1
INITVEL3        DLOAD   PDVL            #                             (PL 2D)
                        MUEARTH         # POSITIVE VALUE
                        R2VEC
                UNIT    PDVL            # 2D = UNIT(R2VEC)            (PL 8D)
                        R1VEC
                UNIT    PUSH            # 8D = UNIT(R1VEC)            (PL 14D)
                VXV     VCOMP           # -N = UNIT(R2VEC) X UNIT(R1VEC)
```

```
        2D
PUSH                    #                                   (PL 20D)
LXA,1   DLOAD
        RTX1
        18D
BMN     INCR,1
```

Uses COZY4 234, DELLT4 224, ITCTR 236, MPAC 145, N 206, NORMSW 123, R1VEC 188, R2VEC 188, RINIT 234, RTARG 224, RTARG1 234, TDESIRED 188, TEMP 191, UN 188, and VINIT 234.

790 ⟨*Page CM0489* 790⟩≡ (751 2761)

```
                        +2
                DEC     -8
                INCR,1  SLOAD
                        10D
                        X1
                BHIZ    VLOAD           #                       (PL 14D)
                        +2
                VCOMP   PUSH            #                       (PL 20 D)
                VLOAD                   #                       (PL 14D)
                VXV     DOT             #                       (PL 2D)
                BPL     DLOAD           #                       (PL 0D)
                        INITVEL4
                DCOMP   PUSH            #                       (PL 2D)
INITVEL4        LXA,2   SXA,2
                        0D
                        GEOMSGN

# SET INPUTS UP FOR LAMBERT

                LXA,1   CALL
                        RTX1
#  OPERATE THE LAMBERT CONIC ROUTINE (COASTFLT SUBROUTINE)

                        LAMBERT

# ARRIVED AT SOLUTION IS GOOD ENOUGH ACCORDING TO SLIGHTLY WIDER BOUNDS.

                CLEAR   VLOAD
                        GUESSW
                        VVEC

# STORE CALCULATED INITIAL VELOCITY REQUIRED IN VIPRIME

                STODL   VIPRIME         # INITIAL VELOCITY REQUIRED (+7)

# IF NUMIT IS ZERO, CONTINUE AT INITVELB, OTHERWISE
# SET UP INPUTS FOR ENCKE INTEGRATION (INTEGRVS).

                        VTARGTAG
                BHIZ    CALL
                        INITVEL7
                        INTSTALL
                SLOAD   CLEAR
                        RTX2
                        MOONFLAG
```

```
                BHIZ    SET
                        INITVEL5
                        MOONFLAG
INITVEL5        VLOAD
                        RINIT
                STORE   R1VEC
```

Uses D 226, GEOMSGN 188, GUESSW 101, MOONFLAG 95, R1VEC 188, RINIT 234, VIPRIME 234, VTARGTAG 188, VVEC 188, and X1 85.

792 ⟨*Page CM0490* 792⟩≡ (751 2761)

```
                STOVL   RCV
                        VIPRIME
                STODL   VCV
                        INTIME
                STORE   TET
                DAD     CLEAR
                        DELLT4
                        INTYPFLG
                STCALL  TDEC1
                        INTEGRVS
                VLOAD
                        VATT1
                STORE   VTARGET

# IF ITERATION COUNTER (ITCTR) EQ NO. ITERATIONS (NUMIT), CONTINUE AT
# INITVELC, OTHERWISE REITERATE LAMBERT AND ENCKE

                LXA,2   INCR,2
                        ITCTR
                        1D              # INCREMENT ITCTR
                SXA,2   XSU,2
                        ITCTR
                        VTARGTAG
                SLOAD   BHIZ            # IF SP(MPAC) EQ 0, CONTINUE AT INITVELC
                        X2
                        INITVEL6

# OFFSET CONIC TARGET VECTGOR

                VLOAD   VSU
                        RTARG1
                        RATT1
                VAD
                        R2VEC
                STODL   R2VEC
                        COZY4
                GOTO
                        INITVEL2        # CONTINUE ITERATING AT INITVEL2

# COMPUTE THE DELTA VELOCITY

INITVEL6        VLOAD
                        R2VEC
                STORE   RTARG1
INITVEL7        VLOAD   VSU
```

```
                        VIPRIME
                        VINIT
                STOVL   DELVEET3        # DELVEET3 = VIPRIME-VINIT (+7)
                        VTARGET
                STORE   VTPRIME
                SLOAD   BHIZ
                        RTX2
```

Uses COZY4 234, DELLT4 224, DELVEET3 236, INTIME 236, INTYPFLG 107, ITCTR 236, MPAC 145, R2VEC 188, RCV 169, RTARG1 234, TET 169, VCV 169, VINIT 234, VIPRIME 234, VTARGET 188, VTARGTAG 188, VTPRIME 234, and X2 85.

793 ⟨*Page CM0491* 793⟩≡ (751 2761)

```
                        INITVELX
                VLOAD   VSR2
                        VTPRIME
                STOVL   VTPRIME
                        VIPRIME
                VSR2
                STOVL   VIPRIME
                        RTARG1
                VSR2
                STOVL   RTARG1
                        DELVEET3
                VSR2
                STORE   DELVEET3
INITVELX        SETPD   VLOAD
                        0D
                        RTARG1
                STCALL  RTARG
                        NORMEX

# ***** END OF INITVEL ROUTINE *****
```

Uses DELVEET3 236, NORMEX 165, RTARG 224, RTARG1 234, VIPRIME 234, and VTPRIME 234.

794 ⟨*Page CM0492* 794⟩≡ (751 2761)

```
# ***** MIDGIM *****
# MOD NO. 0, BY WILLMAN, SUBROUTINE RENDGUID, LOG P34-P35, P74-P75
# REVISION 03, 17 FEB 67
#
# IF THE ACTIVE VEHICLE IS DOING THE COMPUTATION, MIDGIM COMPUTES
# THE POSITIVE MIDDLE GIMBAL ANGLE OF THE ACTIVE VEHICLE TO THE INPUT
# DELTA VELOCITY VECTOR (OD IN PUSY LIST), OTHERWISE
# MIDGIM CONVERTS THE INPUT DELTA VELOCITY VECTOR FROM INERTIAL COORDIN-
# ATES TO LOCAL VERTICAL COORDINATES OF THE ACTIVE VEHICLE.
#
# ** INPUTS **
#   NAME     MEANING                                          UNITS/SCALING/MODE
#   AVFLAG   INT FLAG -- 0 IS CSM ACTIVE, 1 IS LEM ACTIVE     BIT
#   COMPUTER INT FLAG -- 0 IS LEM COMPUTER, 1 IS CSM COMPUTER BIT
#   RINIT    ACTIVE VEHICLE RADIUS VECTOR                     METERS/CSEC (+7) VT
#   VINIT    ACTIVE VEHICLE VELOCITY VECTOR                   METERS/CSEC (+7) VT
#   OD(PL)   ACTIVE VEHICLE DELTA VELOCITY VECTOR             METERS/CSEC (+7) VT
#
# ** OUTPUTS **
#   NAME     MEANING                                          UNITS/SCALING/MODE
#   +MGA     + MIDDLE GIMBAL ANGLE                            REVOLUTIONS (+0) DP
#   DELVLVC  DELTA VELOCITY VECTOR IN LV COORD.               METERS/CSEC (+7) VT
#   MGLVFLAG INT FLAG: 0 IS +MGA COMUTED, 1 IS DELVLVC COMP.  BIT
#
# ** CALLING SEQUENCE **
#       L       CALL
#       L+1             MIDGIM
#       L+2     (RETURN -- ALWAYS)
#
# ** NO SUBROUTINES CALLED **
#
# ** DEBRIS -- ERASABLE TEMPORARY USAGE **
#       A,Q,L, PUSH LIST, MPAC.
#
# ** ALARMS -- NONE **
```

Uses +MGA 234, A 80, AVFLAG 105, COMPUTER 115, DELVLVC 224, L 80, LV 85, MGLVFLAG 117, MODE 145, MPAC 145, Q 80, RENDGUID 65, RINIT 234, and VINIT 234.

795 ⟨*Page CM0493* 795⟩≡ (751 2761)

```
# MIDDLE GIMBAL ANGLE COMPUTATION
                SETLOC  MIDDGIM
                BANK

                COUNT*  $$/MIDG

HALFREV         2DEC    1 B-1

MIDGIM          BON     BOFF
                        AVFLAG
                        MIDGIM1
                        COMPUTER
                        GET.LVC

# COMPUTE +MGA IF AVFLAG AND COMPUTER HAVE OPPOSITE VALUES.

GET+MGA         VLOAD   UNIT            # (PL 0D) V (+7) TO MPAC UNITIZE UV (+1)
                DOT     SL1             # DOT UV WITH Y(STABLE MEMBER) AND RESCALE
                        REFSMMAT +6     # FROM +2 TO +1 FOR ASIN ROUTINE
                ARCSIN  BPL
                        SETMGA
                DAD     DAD             # CONVERT -MGA TO +MGA BY
                        HALFREV         # ADDING ONE REVOLUTION
                        HALFREV
SETMGA          STORE   +MGA
                CLR     RVQ             # CLEAR MGLVFLAG TO INDICATE +MGA CALC
                        MGLVFLAG        # AND EXIT

MIDGIM1         BOFF
                        COMPUTER
                        GET+MGA

# COMPUTE DELVLVC IF AVFLAG AND COMPUTER HAVE SAME VALUES

GET.LVC         VLOAD   UNIT            # (PL 6D) R (+29) IN MPAC UNITZE UR
                        RINIT
                VCOMP                   # U(-R)
                STORE   18D             # U(-R) TO 18D
                VXV     UNIT            # U(-R)*V EQ V*U(R), U(V*R)
                        VINIT
                STORE   12D             # U(V*R) TO 12D
                VXV     UNIT            # U(V*R)*U(-R), U((V*R)*(-R))
                        18D
                STOVL   6D              # TRANSFORMATION MATRIX IS IN 6D (+1)
                        0D              # DELTA V (+7) IN 0D
```

```
                MXV     VSL1            # CONVERT FROM INER COOR TO LV COOR (+8)
                        6D              # AND SCALE +7 IN MPAC
                STORE   DELVLVC         # STORE IN DELVLVC (+7(
                SET     RVQ             # SET MGLVFLAG TO INDICATE LVC CALC
                        MGLVFLAG        # AND EXIT

  # ***** END OF MIDGIM ROUTINE *****
```

Uses +MGA 234, AVFLAG 105, COMPUTER 115, COUNT 142, DELVLVC 224, LV 85, MGLVFLAG 117, MIDDGIM 59, MPAC 145, REFSMMAT 172, RINIT 234, V 229, and VINIT 234.

796 ⟨*Page CM0494* 796⟩≡ (751 2761)

```
  SELECTMU      AXC,1   AXT,2
                        2D
                        0D
                BOFF
                        CMOONFLG
                        SETMUER
                AXC,1   AXT,2
                        10D
                        2D
  SETMUER       DLOAD*  SXA,1
                        MUTABLE +4,1
                        RTX1
                STODL*  RTSR1/MU
                        MUTABLE -2,1
                BOFF    SR
                        CMOONFLG
                        RTRNMU
                        6D
  RTRNMU        STORE   RTMU
                SXA,2   CLEAR
                        RTX2
                        FINALFLG
                GOTO
                        VN1645
```

Uses CMOONFLG 125, FINALFLG 105, and SR 80.

797 ⟨*Page CM0495* 797⟩≡ (751 2761)

```
# ***** PERIAPO *****
# MOD NO -1                    LOG SECTION -- P34-P35, P74-P75
# MOD BY WHITE, P.             DATE 18 JAN 68
#
# FUNCTIONAL DESCRIPTION
#       THIS SUBROUTINE COMPUTES THE TWO BODY APOCENTER AND PERICENTER
#       ALTITUDES GIVEN THE POSITION AND VELOCITY VECTORS FOR A POINT ON
#       THE TRAJECTORY AND THE PRIMARY BODY.
#
#       SETRAD IS CALLED TO DETERMINE THE RADIUS OF THE PRIMARY BODY.
#
#       APSIDES IS CALLED TO SOVE FOR THE TWO BODY RADII OF APOCENTER AND
#       PERICENTER AND THE ECCENTRICITY OF THE TRAJECTORY.
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             PERIAPO
#       L+2     (RETURN -- ALWAYS)
#
# INPUT
#       (1)     RVEC    POSITION VECTOR IN METERS
#                       SCALE FACTOR -- EARTH +29, MOON +27
#       (2)     VVEC    VELOCITY VECTOR IN METERS/CENTISECOND
#                       SCALE FACTOR -- EARTH +7, MOON +5
#       (3)     X1      PRIMARY BODY INDICATOR
#                       EARTH -2, MOON -10
#
# OUTPUT
#       (1)     2D      APOCENTER RADIUS IN METERS
#                       SCALE FACTOR -- EARTH +29, MOON +27
#       (2)     4D      APOCENTER ALTITUDE IN METERS
#                       SCALE FACTOR -- EARTH +29, MOON +27
#       (3)     6D      PERICENTER RADIUS IN METERS
#                       SCALE FACTOR -- EARTH +29, MOON +27
#       (4)     8D      PERICENTER ALTITUDE IN METERS
#                       SCALE FACTOR -- EARTH +29, MOON +27
#       (5)     ECC     ECCENTRICITY OF CONIC TRAJECTORY
#                       SCALE FACTOR -- +3
#       (6)     XXXALT  RADIUS OF THE PRIMARY BODY IN METERS
#                       SCALE FACTOR -- EARTH +29, MOON +27
#       (7)     PUSHLOC EQUALS 10D
#
# SUBROUTINES USED
#       SETRAD
```

Uses A 80, ECC 188, FACTOR 226, L 80, P 188, PUSHLOC 145, RVEC 188, VVEC 188, X1 85,

and XXXALT 234.

798 ⟨*Page CM0496* 798⟩≡ (751 2761)

```
#       APSIDES

                SETLOC  APOPERI
                BANK

                COUNT*  $$/PERAP

RPAD            2DEC    6373338 B-29    # STANDARD RADIUS OF PAD 37-B.
                                        # = 20 909 901.57 FT

PERIAPO1        LXA,2   VSR*
                        RTX2
                        0,2
                STOVL   VVEC
                LXA,1   VSR*
                        RTX1
                        0,2
                STORE   RVEC
PERIAPO         STQ     CALL
                        NORMEX
                        SETRAD
                STCALL  XXXALT
                        APSIDES
                SETPD   PUSH            # 2D = APOCENTER RADIUS         B29 OR B27
                        2D
                DSU     PDDL            # 4D = APOGEE ALTITUDE          B29 OR B27
                        XXXALT
                        0D
                PUSH    DSU             # 6D = PERICENTER RADIUS        B29 OR B27
                        XXXALT
                PUSH    GOTO            # 8D = PERIGEE ALTITUDE         B29 OR B27
                        NORMEX
```

Uses APOPERI 63, COUNT 142, NORMEX 165, RVEC 188, VVEC 188, and XXXALT 234.

799 ⟨*Page CM0497* 799⟩≡ (751 2761)

```
# SETRAD
SETRAD          DLOAD   PUSH
                        RPAD
                SXA,1   INCR,2
                        X2
                        2D
                SLOAD   BHIZ
                        X2
                        SETRADX
                VLOAD   ABVAL
                        RLS
                PDDL
SETRADX         DLOAD   RVQ
```

Uses RLS 175 and X2 85.

800a ⟨*Page CM0498* 800a⟩≡ (751 2761)

```
# PRECSET
PRECSET         STQ
                        NORMEX
                STCALL  TDEC2
                        LEMPREC
                CALL
                        LEMSTORE
                DLOAD
                        TDEC2
                STCALL  TDEC1
                        CSMPREC
                CALL
                        CSMSTORE
                GOTO
                        NORMEX
LEMSTORE        VLOAD   BOFF
                        RATT
                        AVFLAG
                        PASSIVE
ACTIVE          STOVL   RACT3
                        VATT
                STORE   VACT3
                RVQ
CSMSTORE        VLOAD   BOFF
                        RATT
                        AVFLAG
                        ACTIVE
PASSIVE         STOVL   RPASS3
                        VATT
                STORE   VPASS3
                RVQ
```

Uses AVFLAG 105, NORMEX 165, RACT3 234, RPASS3 234, TDEC2 183, VACT3 234, and VPASS3 234.

800b ⟨*Page CM0499* 800b⟩≡ (751 2761)

```
# VECSHIFT
VECSHIFT        LXA,2   VSR*
                        RTX2
                        0,2
                LXA,1   PDVL
                        RTX1
                VSR*    PDVL
                        0,2
                RVQ
```

801 ⟨*Page CM0500* 801⟩≡ (751 2761)

```
# SHIFTR1
SHIFTR1         LXA,2   SL*
                        RTX2
                        0,2
                RVQ
```

802 ⟨*Page CM0501* 802⟩≡ (751 2761)

```
# PROGRAM DESCRIPTION
#
# SUBROUTINE NAME       R36     OUT-OF-PLANE RENDEZVOUS ROUTINE
# MOD NO. 2             DATE 2 JANUARY 1969
# MOD BY A.W.BANCROFT   LOG SECTION EXTENDED VERBS
#
# FUNCTIONAL DESCRIPTION
#
# TO DISPLAY AT ASTRONAUT REQUEST LGC CALCULATED RENDEZVOUS
# OUT-OF-PLANE PARAMETERS (Y, YDOT, PSI).  (REQUESTED BY DSKY).
#
# CALLING SEQUENCE
#       ASTRONAUT REQUEST THROUGH DSKY V 90 E
#
# SUBROUTINES CALLED
#       EXDSPRET
#       GOMARKF
#       CSMPREC
#       LEMPREC
#       SGNAGREE
#       LOADTIME
#
# NORMAL EXIT MODES
#       ASTRONAUT REQUEST THROUGH DSKY TO TERMINATE PROGRAM V 34 E
#
# ALARM OR ABORT EXIT MODES
#       NONE
#
# OUTPUT
#       DECIMAL DISPLAY OF TIME, Y, YDOT AND PSI
#
#       DISPLAYED VALUES Y, YDOT, AND PSI, ARE STORED IN ERASABLE
#       REGISTERS RANGE, RRATE, AND RTHETA RESPECTIVELY.
#
# ERASABLE INITIALIZATION REQUIRED
#       CSM AND LEM STATE VECTORS
#
# DEBRIS
#       CENTRALS A,Q,L
#       OTHER:  THOSE USED BY THE ABOVE LISTED SUBROUTINES

                BANK    20
                SETLOC  R36CM
                BANK
```

Uses A 80, L 80, Q 80, R36CM 63, RANGE 179, RRATE 179, RTHETA 179, STATE 138, V 229,

and `W` 183.

804 ⟨*Page CM0502* 804⟩≡ (751 2761)

```
                EBANK=  RPASS36

                SBANK=  R36A
                COUNT*  $$/R36

R36             CAF     TWO
                TS      OPTIONX
                CAF     ONE
                TS      OPTIONX +1
                CAF     OPTION36        # V 04 N 12
                TC      BANKCALL
                CADR    GOXDSPF
                TC      ENDEXT          # TERMINATE
                TC      +2              # PROCEED
                TC      -5              # R2 LOADED VIA DSKY
                TC      POSTJUMP
                CADR    R36A

OPTION36        VN      0412

                SETLOC  R36LM
                BANK

R36A            ZL
                CAF     ZERO            # SET TIME OF EVENT TO ZERO FOR FIRST
                DXCH    DSPTEMX         # DISPLAY
                LXCH    OPTIONY         # SAVE VEH. OPTION
R36P3           CAF     V06N16N
                TC      BANKCALL
                CADR    GOMARKF
                TCF     ENDEXT          # TERMINATE
                TCF     +2              # PROCEED
                TCF     -5              # RECYCLE FOR ASTRONAUT INPUT TIME
                DXCH    DSPTEMX
                EXTEND
                BZF     LREGCHK         # A-REG ZERO GOTO CHECK L-REG FOR ZERO
ASTROTIM        DXCH    MPAC            # A-REG NON-ZERO, TIME = ASTRO INPUT TIME
                TC      INTPRET
                RTB     GOTO
                        DPMODE
                        R36INT

                SETLOC  R36LM1
                BANK
```

```
R36INT          STORE   TDEC1
                SLOAD   SR1
                        OPTIONY
                BHIZ    CALL
                        R36PROG2        # FOR CSM DISPLAY
```

Uses A 80, COUNT 142, DSPTEMX 154, EBANK 80, L 80, MPAC 145, N 206, OPTIONX 154, OPTIONY 179, R2 188, R36LM 71, R36LM1 71, RPASS36 179, SAVE 191, TC 169, V 229, and VN 159.

806 ⟨*Page CM0503* 806⟩≡ (751 2761)

```
                        THISPREC        # FOR LEM DISPLAY
                GOTO
                        R36PROG3
R36PROG2        CALL
                        OTHPREC
R36PROG3        VLOAD   PDVL
                        VATT
                        RATT            # _
                STORE   RPASS36         # R
                UNIT    PDVL            #  P
                VXV     UNIT            # -
                STADR
                STODL   UNP36           # U
                        TAT
                STORE   TDEC1
                SLOAD   SR1
                        OPTIONY
                BHIZ    CALL
                        R36PROG4        # FOR CSM DISPLAY
                        OTHPREC         # FOR LEM DISPLAY
                GOTO
                        R36PROG5
R36PROG4        CALL
                        THISPREC
R36PROG5        VLOAD   PDVL            #                       _
                        VATT            # VELOCITY VECTOR       V       00D
                        RATT            #                        A
                PDDL
                        TAT             # SAVE TIME IN LOCATION 30D FOR REDISPLAY
                STOVL   30D             #                       _
                PUSH    PUSH            # POSITION VECTOR       R   IN  06D AND 12D
                BVSU    PDVL            #                       _A  _
                        RPASS36         # LINE OF SIGHT VECTOR  R - R   12D
                DOT     SL1             #                        P   A
                        UNP36           #     _   _
                STOVL   RANGE           # Y = U . R
                        00D             #          A
                DOT     SL1
                        UNP36           # .   _   _
                STOVL   RRATE           # Y = U . V
                        06D             # _        A
                UNIT    PUSH            # U  = UNIT ( R  )              18D
                VXV     VXV             #  RA          A
                        00D             #  _    _     _     _
                        18D             # (U  X V ) X U   = U
```

```
VSL2    UNIT            #   RA   A     RA    A
UNIT    GOTO
        R36B

SETLOC  R36CM1
```

Uses A 80, OPTIONY 179, OTHPREC 71, P 188, R36CM1 71, RANGE 179, RPASS36 179, RRATE 179, SAVE 191, THISPREC 73, UNP36 179, and V 229.

808 ⟨*Page CM0504* 808⟩≡ (751 2761)

```
                BANK

R36B            STOVL   00D             # UNIT HORIZONTAL IN FORWARD DIR. 00D
                        18D
                DOT     VXSC            # _
                        12D             # U
                VSL2                    #  L
                BVSU    UNIT
                UNIT
                PUSH    DOT             # LOS PROJECTED INTO HORIZONTAL  12D
                        00D             # PLANE
                SL1     ARCCOS          #              _   _
                STOVL   RTHETA          # PSI = ARCCOS(U . U )
                VXV     DOT             #               A   L
                        00D
                BPL     DLOAD
                        R36TAG2
                        DPPOSMAX
                DSU
                        RTHETA
                STCALL  RTHETA
                        R36TAG2

                SETLOC  R36LM
                BANK

R36TAG2         DLOAD   RTB
                        30D
                        SGNAGREE
                STORE   DSPTEMX
                EXIT
                CAF     V06N90N         # DISPLAY Y, YDOT, AND PSI.
                TC      BANKCALL
                CADR    GOMARKF
                TCF     ENDEXT          # TERMINATE
                TCF     ENDEXT          # PROCEED, END OF PROGRAM
                TCF     R36P3           # REDISPLAY OUTPUT
LREGCHK         XCH     L
                EXTEND
                BZF     ENTTIM2         # L-REG ZERO, SET TIME = PRESENT TIME
                XCH     L               # L-REG NON ZERO, TIME = ASTRO INPUT TIME
                TCF     ASTROTIM
ENTTIM2         TC      INTPRET
                RTB     GOTO
                        LOADTIME
```

```
                        R36INT
V06N16N         VN      00616
V06N90N         VN      00690
                SBANK=  LOWSUPER
```

Uses A 80, DSPTEMX 154, L 80, LOWSUPER 67, R36LM 71, RTHETA 179, TC 169, and VN 159.

3.4.3 r31 code

809 ⟨*r31 code* 809⟩≡ (744b)

⟨*Page CM0505* 810⟩
⟨*Page CM0506* 812⟩
⟨*Page CM0507* 813⟩
⟨*Page CM0508* 814⟩
⟨*Page CM0509* 816⟩
⟨*Page CM0510* 818⟩

810 ⟨*Page CM0505* 810⟩≡ (809 2785)

```
                BANK    34
                SETLOC  R31
                BANK

                COUNT*  $$/R31

R31CALL         CAF     PRIO3
                TC      FINDVAC
                EBANK=  SUBEXIT
                2CADR   V83CALL

DSPDELAY        CAF     1SEC
                TC      BANKCALL
                CADR    DELAYJOB
                CA      EXTVBACT
                MASK    BIT12
                EXTEND
                BZF     DSPDELAY

DISPN5X         CA      FLAGWRD9        # TEST R31FLAG (IN SUNDANCE R31FLAG WILL
                MASK    BIT4            #       ALWAYS BE SET AS R34 DOES NOT EXIST.
                EXTEND
                BZF     +3
                CAF     V16N54          # R31   USE NOUN 54
                TC      +2
                CAF     V16N53          # R34   USE NOUN 53
                TC      BANKCALL
                CADR    GOMARKF
                TC      B5OFF
                TC      B5OFF
                TCF     DISPN5X

V83             TC      INTPRET
                GOTO
                        HAVEBASE        # INTEG STATE VECTORS
V83CALL         TC      INTPRET
                GOTO
                        STATEXTP        # EXTRAPOLATE STATE VECTORS
COMPDISP        VLOAD   VSU
                        RATT
                        RONE
                PUSH    ABVAL           # RATT-RONE TO OD       PD= 6
                STORE   RANGE           # METERS B-29
                NORM    VLOAD
                        X1              # RATT-RONE             PD= 0
```

```
VSR1
VSL*    UNIT
        0,1
PDVL    VSU             # UNIT(LOS) TO OD       PD= 6
```

Uses COUNT 142, EBANK 80, EXTVBACT 154, R31 67, R31FLAG 131, R34 67, RANGE 179, RONE 179, STATE 138, SUBEXIT 181, TC 169, and X1 85.

812 ⟨*Page CM0506* 812⟩≡ (809 2785)

```
                        VATT
                        VONE
                DOT                     # (VATT-VONE).UNIT(LOS) PD= 0
                SL1
                STCALL  RRATE           # RANGE RATE M/CS B-7
                        CDUTRIG         # TO INITIALIZE FOR *NBSM*
                CALL
                        R34LOS          # NOTE.  PDL MUST = 0.
R34ANG          VLOAD   UNIT
                        RONE
                PDVL                    # UR TO 0D              PD= 6
                        THISAXIS        # UNITX FOR CM, UNITZ FOR LM
                BON     VLOAD           # CHK R31FLAG.  ON=R31 THETA, OFF=R34 PHI
                        R31FLAG
                        +2              # R31-THETA
                        12D
                CALL
                        *NBSM*
                VXM     PUSH            # UXORZ TO 6D           PD=12D
                        REFSMMAT
                VPROJ   VSL2
                        0D
                BVSU    UNIT
                        6D
                PDVL    VXV             # UP/2 TO 12D           PD=18D
                        RONE
                        VONE
                UNIT    VXV
                        RONE
                DOT     PDVL            # SIGN TO 12D, UP/2 TO MPAC     PD=18D
                        12D
                VSL1    DOT             # UP.UXORZ
                        6D
                SIGN    SL1
                        12D
                ACOS
                STOVL   RTHETA
                        RONE
                DOT     BPL
                        6D
                        +5
                DLOAD   BDSU            # IF UXORZ.R NEG, RTHETA = 1 - RTHETA
                        RTHETA
                        DPPOSMAX
                STORE   RTHETA          # RTHETA BETWEEN 0 AND 1 REV.
```

```
                EXIT
                CAF     BIT5            # HAVE WE BEEN ANSWERED
                MASK    EXTVBACT
                EXTEND
                BZF     ENDEXT          # YES, DIE
```

Uses EXTVBACT 154, MPAC 145, R31 67, R31FLAG 131, R34 67, RANGE 179, REFSMMAT 172, RONE 179, RRATE 179, RTHETA 179, THETA 148, THISAXIS 73, and VONE 179.

813 ⟨*Page CM0507* 813⟩≡ (809 2785)

```
                CS      EXTVBACT
                MASK    BIT12
                ADS     EXTVBACT

                TCF     V83
V16N54          VN      1654
V16N53          VN      1653
```

Uses EXTVBACT 154 and VN 159.

814 ⟨*Page CM0508* 814⟩≡ (809 2785)

```
# STATEXTP DOES AN INITIAL PRECISION EXTRAPOLATION OF THE
# LEM STATE VECTOR TO PRESENT TIME OR TO PIPTIME IF AV G.
# IS ON AND SAVES AS BASE VECTOR. IF AV G IS ON RN + VN
# ARE USED AS THE CM STATE VECTOR AND THE INITIAL R RDOT
# RTHETA ARE COMPUTED WITH NO FURTHER INTEGRATION. IF AV
# G IS OFF A PRECISION EXTRAPOLATION IS MADE OF THE CM
# STATE VECTOR TO PRESENT TIME AND.....
#
#   THE CM + LM STATE VECTORS ARE INTEGRATED TO PRES TIME
#   USING PRECISION OR CONIC AS SURFFLAG IS SET OR CLEAR.
#
#   IF AV G IS ON THEN
#     SUBSEQUENT PASSES WILL PROVIDE
#     USE OF RN + VN AS CM STATE VECTOR AND THE LM STATE
#     VECTOR WILL BE PRECISION INTEGRATED USING LEMPREC
#
#   IF SURFFLAG IS SET.
#     CM STATE VECTOR RONE VONE + LM STATE VECTOR RATT
#     VATT ARE USED IN COMPUTING R RDOT RTHETA.
#

STATEXTP        RTB     BOF             # INITIAL INTEGRATION
                        LOADTIME
                        V37FLAG
                        +3              # AV G OFF, USE PRES TIME
                CALL
                        GETRVN          #      ON,  USE RN VN PIPTIME
                STORE   BASETIME        # PRES TIME OR PIPTIME
                STCALL  TDEC1
                        LEMPREC
                VLOAD                   # BASE VECTOR, LM
                        RATT1
                STOVL   BASEOTP         #   POS.
                        VATT1
                STORE   BASEOTV         #   VEL.
                BON     DLOAD
                        V37FLAG
                        COMPDISP        # COMPUTE R RDOT RTHETA FROM
                                        # RONE(RN) VONE(VN) RATT+VATT(LEMPREC)
                        TAT
                STCALL  TDEC1
                        CSMPREC
                VLOAD                   # BASE VECTOR, CM
                        RATT1
                STOVL   BASETHP         #  POS.
```

```
                        VATT1
                STORE   BASETHV         #  VEL.
HAVEBASE        BON     RTB             # SUBSEQUENT INTEGRATIONS
                        V37FLAG
                        GETRVN5
                        LOADTIME
                STCALL  TDEC1           # AV G OFF, SET INTEG, OF CM
                        INTSTALL
                VLOAD   CLEAR
                        BASETHP
```

Uses A 80, BASEOTP 177, BASEOTV 177, BASETHP 177, BASETHV 177, BASETIME 179, PIPTIME 159, RDOT 229, RN 159, RONE 179, RTHETA 179, STATE 138, SURFFLAG 127, V37FLAG 123, VEL 226, VN 159, and VONE 179.

816 ⟨*Page CM0509* 816⟩≡ (809 2785)

```
                        MOONFLAG
                STOVL   RCV
                        BASETHV
                STODL   VCV
                        BASETIME
                BOF     SET             # GET APPROPRIATE MOONFLAG SETTING
                        MOONTHIS
                        +2
                        MOONFLAG
                CLEAR
                        INTYPFLG
                BON     SET
                        SURFFLAG
                        +2              # PREC. IF LM DOWN
                        INTYPFLG        # CONIC IF LM NOT DOWN
                STCALL  TET
                        INTEGRVS        # INTEGRATION --- AT LAST ---
                VLOAD
                        RATT
                STOVL   RONE
                        VATT
                STODL   VONE            # GET SET FOR CONIC EXTRAP., OTHER.
                        TAT
                BON     CALL
                        SURFFLAG
                        GETRVN6         # LEMPREC IF LM DOWN
                        INTSTALL        # ..CONIC IF NOT DOWN
                SET
                        INTYPFLG
        OTHINT  STORE   TDEC1           # ENTERED IF AV G ON TO INTEG LM
                VLOAD   CLEAR
                        BASEOTP
                        MOONFLAG
                STOVL   RCV
                        BASEOTV
                STODL   VCV
                        BASETIME
                BOF     SET
                        MOONTHIS
                        +2
                        MOONFLAG
                STCALL  TET
                        INTEGRVS
                GOTO
                        COMPDISP        # COMPUTE R RDOT RTHETA
```

```
GETRVN5         CALL                    # AV G ON
                        GETRVN
                BON     CALL
                        SURFFLAG
                        GETRVN6         # LM DOWN, LMPREC
```

Uses BASEOTP 177, BASEOTV 177, BASETHV 177, BASETIME 179, INTYPFLG 107, MOONFLAG 95, MOONTHIS 71, RCV 169, RDOT 229, RONE 179, RTHETA 179, SURFFLAG 127, TET 169, VCV 169, and VONE 179.

818 ⟨*Page CM0510* 818⟩≡ (809 2785)

```
                        INTSTALL
                CLEAR   GOTO
                        INTYPFLG
                        OTHINT
GETRVN6         STCALL  TDEC1
                        LEMPREC
                GOTO
                        COMPDISP        # COMPUTE R RDOT RTHETA
GETRVN          STQ
                        OD
                VLOAD   GOTO            # AV G ON, RONE = RN VONE = VN
                        RN              #  AND USE PIPTIME
                        +1
                STCALL  RONE
                        +1
                VLOAD   GOTO
                        VN
                        +1
                STODL   VONE
                        PIPTIME
                GOTO
                        OD
                SETLOC  R34
                BANK
R34LOS          EXIT
                CA      CDUS
                INDEX   FIXLOC
                TS      9D
                CA      CDUT
                INDEX   FIXLOC
                TS      11D
                CA      FIXLOC
                AD      SIX
                COM
                INDEX   FIXLOC
                TS      X1
                TC      INTPRET
                CALL
                        SXTNB
                STCALL  12D
                        R34ANG
```

Uses CDUS 80, CDUT 80, FIXLOC 140, INTYPFLG 107, PIPTIME 159, R34 67, RDOT 229, RN 159, RONE 179, RTHETA 179, TC 169, VN 159, VONE 179, and X1 85.

3.4.4 p76 code

819 ⟨*p76 code* 819⟩≡ (744b)
⟨*Page CM0511* 820⟩
⟨*Page CM0512* 822⟩
⟨*Page CM0513* 823⟩

820 ⟨*Page CM0511* 820⟩≡ (819 2769)

```
# 1)    PROGRAM NAME -- TARGET DELTA V PROGRAM (P76).
# 2)    FUNCTIONAL DESCRIPTION -- UPON ENTRY BY ASTRONAUT ACTION, P76 FLASHES DSKY RE
#       TO PROVIDE VIA DSKY (1) THE DELTA V TO BE APPLIED TO THE OTHER VEHICLE STATE
#       TIME (TIG) AT WHICH THE OTHER VEHICLE VELOCITY WAS CHANGED BY EXECUTION OF A
#       OTHER VEHICLE STATE VECTOR IS INTEGRATED TO TIG AND UPDATED BY THE ADDITION O
#       BEEN TRANSFORMED FROM LV TO REF COSYS).  USING INTEGRVS, THE PROGRAM THEN INT
#       VEHICLE STATE VECTOR TO THE STATE VECTOR OF THIS VEHICLE, THUS INSURING THAT
#       STATES CORRESPOND TO THE SAME TIME.
# 3)    ERASABLE INITIALIZATION REQUIRED -- NONE.
# 4)    CALLING SEQUENCES AND EXIT MODES -- CALLED BY ASTRONAUT REQUEST THRU DSKY V 3
#       EXITS BY TCF ENDOFJOB.
# 5)    OUTPUT -- OTHER VEHICLE STATE VECTOR INTEGRATED TO TIG AND INCREMENTED BY DEL
#       THE PUSHLIST CONTAINS THE MATRIX BY WHICH THE INPUT DELTA V MUST BE POST-MULT
#       TO REF COSYS.
# 6)    DEBRIS -- OTHER VEHICLE STATE VECTOR.
# 7)    SUBROUTINES CALLED -- BANKCALL, GOXDSPF, CSMPREC (OR LEMPREC), ATOPCSM (OR AT
#       INTPRET, INTEGRVS, AND MINIRECT.
# 8)    FLAG USE -- MOONFLAG, CMOONFLG, INTYPFLG, RASFLAG, AND MARKCTR.

                BANK    30
                SETLOC  P76LOC
                BANK

                COUNT*  $$/P76

                EBANK=  TIG

P76             TC      UPFLAG
                ADRES   TRACKFLG

                CAF     V06N84          # FLASH LAST DELTA V.
                TC      BANKCALL        # AND WAIT FOR KEYBOARD ACTION.
                CADR    GOFLASH
                TCF     ENDP76
                TC      +2              # PROCEED
                TC      -5              # STORE DATA AND REPEAT FLASHING
                CAF     V06N84 +1       # FLASH VERB 06 NOUN 33, DISPLAY LAST TIG,
                TC      BANKCALL        # AND WAIT FOR KEYBOARD ACTION.
                CADR    GOFLASH
                TCF     ENDP76
                TC      +2
                TC      -5
                TC      INTPRET         # RETURN TO INTERPRETIVE CODE
                DLOAD                   # SET D(MPAC)=TIG IN CSEC B28
                        TIG
```

```
                STCALL  TDEC1           # SET TDEC1=TIG FOR ORBITAL INTEGRATION
                        OTHPREC
COMPMAT         VLOAD   UNIT
                        RATT
```

Uses A 80, CMOONFLG 125, CODE 140, COUNT 142, D 226, EBANK 80, INTYPFLG 107, LV 85, MARKCTR 157, MOONFLAG 95, MPAC 145, ORBITAL 59, OTHPREC 71, P76LOC 61, RASFLAG 133, STATE 138, TC 169, TIG 224, TRACKFLG 101, V 229, and W 183.

822 ⟨*Page CM0512* 822⟩≡ (819 2769)

```
                VCOMP                   # U(-R)
                STORE   24D             # U(-R) TO 24D
                VXV     UNIT            # U(-R) X V = U(V X R)
                        VATT
                STORE   18D
                VXV     UNIT            # U(V X R) X U(-R) = U((R X V) X R)
                        24D
                STOVL   12D
                        DELVOV
                VXM     VSL1            # V(MPAC)=DELTA V IN REFCOSYS
                        12D
                VAD
                        VATT
                STORE   6               # V(PD6)=VATT + DELTA V
                CALL                    # PREVENT WOULD-BE USER OF ORBITAL
                        INTSTALL        # INTEG FROM INTERFERING WITH UPDATING
                CALL
                        P76SUB1
                VLOAD   VSR*
                        6
                        0,2
                STOVL   VCV
                        RATT
                VSR*
                        0,2
                STODL   RCV
                        TIG
                STORE   TET
                CLEAR   DLOAD
                        INTYPFLG
                        TETTHIS
INTOTHIS        STCALL  TDEC1
                        INTEGRVS
                CALL
                        INTSTALL
                CALL
                        P76SUB1         # SET/CLEAR MOONFLAG
                VLOAD
                        RATT1
                STORE   RRECT
                STODL   RCV
                        TAT
                STOVL   TET
                        VATT1
                CALL
```

```
                        MINIRECT
                EXIT
                TC      PHASCHNG
                OCT     04024
```

Uses DELVOV 234, INTYPFLG 107, MOONFLAG 95, MPAC 145, ORBITAL 59, RCV 169, RRECT 169, TC 169, TET 169, TETTHIS 172, TIG 224, V 229, and VCV 169.

823 ⟨*Page CM0513* 823⟩≡ (819 2769)

```
                TC      UPFLAG
                ADRES   REINTFLG

                TC      INTPRET
                CALL
                        ATOPOTH
                SSP     EXIT
                        QPRET
                        OUT
                TC      BANKCALL        # PERMIT USE OF ORBITAL INTEGRATION
                CADR    INTWAKE1
OUT             EXIT
ENDP76          CAF     ZERO
                TS      MARKCTR         # CLEAR RR TRACKING MARK COUNTER
                TS      VHFCNT

                CAF     NEGONE
                TS      MRKBUF2         # INVALIDATE MARK BUFFER

                TCF     GOTOPOOH

V06N84          NV      0684
                NV      0633
P76SUB1         CLEAR   SLOAD
                        MOONFLAG
                        X2
                BHIZ    SET             # X2=0...CLEAR MOONFLAG
                        +2              #   =2.....SET MOONFLAG
                        MOONFLAG
                RVQ
```

Uses ATOPOTH 71, MARKCTR 157, MOONFLAG 95, ORBITAL 59, QPRET 85, REINTFLG 135, TC 169, VHFCNT 157, and X2 85.

3.4.5 r30 code

824 ⟨*r30 code* 824⟩≡ (744b)
⟨*Page CM0514* 825⟩
⟨*Page CM0515* 827⟩
⟨*Page CM0516* 829⟩
⟨*Page CM0517* 831⟩
⟨*Page CM0518* 833⟩
⟨*Page CM0519* 835⟩
⟨*Page CM0520* 836⟩
⟨*Page CM0521* 837⟩
⟨*Page CM0522* 839⟩
⟨*Page CM0523* 840a⟩
⟨*Page CM0524* 840b⟩

825 ⟨*Page CM0514* 825⟩≡ (824 2783)

```
# SUBROUTINE NAME:  V82CALL
# MOD NO: 0                                   DATE: 16 FEB 67
# MOD BY: R. R. BAIRNSFATHER                  LOG SECTION:  R30
# MOD NO: 1     MOD BY:  R. R. BAIRNSFATHER   DATE: 11 APR 67         SR30.1 CHANGED TO ALLOW
# MOD NO: 2     MOD BY:  ALONSO               DATE: 11 DEC 67         VB82 PROGRAM REWRITTEN
# MOD NO: 3     MOD BY:  ALONSO               DATE: 26 MAR 68         PROG MOD TO HANDLE DIF
#
# NEW FUNCTIONAL DESCRIPTION:   CALLED BY VERB 82 ENTER.  PRIORITY 10.
# USED THROUGHOUT.              CALCULATE AND DISPLAY ORBITAL PARAMETERS
#
# 1.    IF AVERAGE G IS OFF:
#               FLASH DISPLAY V04N06.  R2 INDICATES WHICH SHIP'S STATE VECTOR IS
#                       TO BE UPDATED.  INITIAL CHOICE IS THIS SHIP (R2=1).  ASTRONAUT
#                       CAN CHANGE TO OTHER SHIP BY V22EXE. WHERE X IS NOT EQ 1.
#               SELECTED STATE VECTOR UPDATED BY THISPREC (OTHPREC).
#               CALLS SR30.1 (WHICH CALLS TFFCONMU + TFFRP/RA) TO CALCULATE
#                       RPER (PERIGEE RADIUS), RAPO (APOGEE RADIUS), HPER (PERIGEE
#                       HEIGHT ABOVE LAUNCH PAD OR LAUNAR LANDING SITE), HARD (APOGEE
#                       HEIGHT AS ABOVE), TPER (TIME TO PERIGEE), TFF (TIME TO
#                       INTERSECT 300 KFT ABOVE PAD OR 35KFT ABOVE LANDING SITE).
#               FLASH MONITOR V16N44 (HAPO, HPER, TFF).  TFF IS -59MS59S IF IT WAS
#                       NOT COMPUTABLE, OTHERWISE IT INCREMENTS ONCE PER SECOND.
#                       ASTRONAUT HAS OPTION TO MONITOR TPER BY KEYING IN N 32 E.
#                       DISPLAY IS IN HMS, IS NEGATIVE (AS WAS TFF), AND INCREMENTS
#                       ONCE PER SECOND ONLY IF TFF DISPLAY WAS -59M59S.
#       2.      IF AVERAGE G IS ON:
#                       CALLS SR30.1 APPROX EVERY TWO SECS.  STATE VECTOR IS ALWAYS
#                               FOR THIS VEHICLE.  V82 DOES NOT DISTURB STATE VECTOR.  RESULTS
#                               OF SR30.1 ARE RAPO, RPER, HAPO, HPER, TPER, TFF.
#                       FLASH MONITOR V16N44 (HAPO, HPER, TFF).
#                       IF MODE IS P11, THEN CALL DELRSPL SO ASTRONAUT CAN MONITOR
#                               RESULTS BY N50E.  SPLASH COMPUTATION DONE ONCE PER TWO SECS.
#       ADDENDUM:  HAPO AND HPER SHOULD BE CHANGED TO READ HAPOX AND HPERX IN THE
#               ABOVE REMARKS.
#
# CALLING SEQUENCE: VERB 82 ENTER.
#
# SUBROUTINES CALLED:   SR30.1, GOXDSPF
#                       MAYBE -- THISPREC, OTHPREC, LOADTIME, DELRSPL
#
# NORMAL EXIT MODES:  TC ENDEXT
#
# ALARMS:  NONE
#
# OUTPUT:       HAPOX   (-29) M
```

```
#                HPERX   (-29) M
#                RAPO    (-29) M EARTH
#                        (-27) M MOON
```

Uses HAPO 181, HAPOX 181, HPER 181, HPERX 181, IT 185, MODE 145, N 206, ORBITAL 59, OTHPREC 71, PRIORITY 145, R2 188, STATE 138, TC 169, TFF 179, and THISPREC 73.

827 ⟨*Page CM0515* 827⟩≡ (824 2783)

```
#               RPER    (-29) M EARTH
#                       (-27) M MOON
#               TFF     (-28) CS        CONTAINS NEGATIVE QUANTITY
#               -TPER   (-28) CS        CONTAINS NEGATIVE QUANTITY
#               RSP-RREC(-29) M         IF DELRSPL CALLED
#
# ERASABLE INITIALIZATION REQUIRED:  STATE VECTOR.
#
# DEBRIS:       QPRET, RONE, VONE, TFF/RTMU, HPERMIN, RPADTEM, V82EMFLG.
#               MAYBE:  TSTART82, V82FLAGS, TDEC1.

                EBANK=  HAPOX
                BANK    31
                SETLOC  R30LOC
                BANK
                COUNT*  $$/R30

V82CALL         TC      INTPRET
                BON     GOTO
                        AVEGFLAG
                        V82GON          # IF AVERAGE G ON
                        V82GOFF         # IF AVERAGE G OFF

V82GOFF         EXIT                    # ALLOW ASTRONAUT TO SELECT VEHICLE
                CAF     TWO             # DESIRED FOR ORBITAL PARAMETERS
                TS      OPTIONX
                CAF     ONE
                TS      OPTIONX +1
                CAF     OPTIONVN        # V 04 N 06
                TC      BANKCALL
                CADR    GOXDSPF
                TC      ENDEXT          # TERMINATE
                TC      +2              # PROCEED
                TC      -5              # DATA IN.  OPTIONX +1 = 1 FOR THIS VEHIC.
                                        #                UNEQ 1 FOR OTHER VEHICLE.
                CAF     BIT4            # 80 MS
                TC      WAITLIST
                EBANK=  TFF
                2CADR   TICKTEST

                RELINT
V82GOFLP        CAF     TFFBANK         # MAJOR RECYCLE LOOP ENTRY
                TS      EBANK
                CAF     ZERO
                TS      V82FLAGS        # ZERO FLAGS FOR TICKTEST, INHIBITS
```

```
                                        # DECREMENTING OF TFF AND -TPER.
                CAF     PRIO7
                TC      FINDVAC         # V82GOFF1 WILL EXECUTE STATE VECTOR
```

Uses -TPER 179, AVEGFLAG 101, COUNT 142, EBANK 80, HAPOX 181, HPERMIN 179, N 206, OPTIONX 154, ORBITAL 59, QPRET 85, R30LOC 65, RONE 179, RPADTEM 179, RSP-RREC 181, STATE 138, TC 169, TFF 179, TSTART82 179, V 229, V82FLAGS 179, and VONE 179.

829 ⟨*Page CM0516* 829⟩≡ (824 2783)

```
                EBANK=  TFF             # UPDATE AND ORBIT CALCULATIONS FOR
                2CADR   V82GOFF1        # SELECTED VEHICLE ABOUT PROPER BODY.

                RELINT
V82STALL        CAF     THREE           # STALL IN THIS LOOP AND WITHOLD V 16 N 44
                MASK    V82FLAGS        # UNTIL STATE VECTOR UPDATE SETS ONE OF
                CCS     A               # OUR FLAG BITS.
                TC      FLAGGON         # EXIT FROM STALL LOOP.
                CAF     1SEC
                TC      BANKCALL
                CADR    DELAYJOB
                TC      V82STALL

FLAGGON         CAF     V16N44          # MONITOR HAPO,HPER,TFF.
                TC      BANKCALL
                CADR    GOXDSPF
                TC      B5OFF           # TERM THIS TELLS TICKTEST TO KILL ITSELF
                TC      B5OFF           # PROCEED  DITTO
                TC      V82GOFLP        # RECYCLE  RECOMPUTE STATE VECT + DISPLAY

OPTIONVN        VN      0412
V16N44          VN      1644
TFFBANK         ECADR   TFF

V82GOFF1        TC      INTPRET
                RTB
                        LOADTIME
                STORE   TDEC1           # TIME FOR STATE VECTOR UPDATE.
                STORE   TSTART82        # TIME FOR INTERNAL USE.
                EXIT
                CS      OPTIONX +1      # 1 FOR THIS VEHICLE, NOT 1 FOR OTHER
                AD      ONE
                EXTEND
                BZF     THISSHIP
OTHSHIP         TC      INTPRET
                CALL                    # CALL STATE VECTOR UPDATE FOR OTHER SHIP.
                        OTHPREC
BOTHSHIP        VLOAD                   # MOVE RESULTS INTO TFFCONIC STORAGE AREAS
                        RATT            # TO BE CALLED BY SR30.1.
                STOVL   RONE            # RATT AT (-29)M FOR EARTH OR MOON
                        VATT
                STORE   VONE            # VATT AT (-7)M/CS FOR EARTH OR MOON
                DLOAD*
                        1/RTMUE,2       # X2 IS 0 FOR EARTH CENTERED STATE VEC
                                        # HG remark: In Comanche055 scan this line (5324) looks
```

```
                                # as it is in start source
STORE   TFF/RTMU                # X2 IS 2 FOR MOON
DLOAD*                          # AS LEFT BY THISPREC OR OTHPREC.
        MINPERE,2
STORE   HPERMIN                 # TFFRTMU, HPERMIN, AND RPADTEM ARE ALL
SLOAD   BHIZ                    # EARTH/MOON PARAMETERS AS SET HERE.
```

Uses A 80, EBANK 80, HAPO 181, HPER 181, HPERMIN 179, N 206, OPTIONX 154, OTHPREC 71, RONE 179, RPADTEM 179, STATE 138, TC 169, TFF 179, THISPREC 73, TSTART82 179, V 229, V82FLAGS 179, VN 159, VONE 179, and X2 85.

831 ⟨*Page CM0517* 831⟩≡ (824 2783)

```
                        X2
                        EARTHPAD
                GOTO
                        MOONPAD
THISSHIP        TC      INTPRET
                CALL                    # CALL STATE VECTOR UPDATE FOR THIS SHIP.
                        THISPREC
                GOTO
                        BOTHSHIP

# THE FOLLOWING CONSTANTS ARE PAIRWISE INDEXED.  DO NOT SEPARATE PAIRS.

1/RTMUM         2DEC*   .45162595 E-4 B14*
1/RTMUE         2DEC*   .50087529 E-5 B17*

MINPERM         2DEC    10668 B-27      # 35 KFT MIN PERIGEE HEIGHT FOR MOON(-27)M
MINPERE         2DEC    91440 B-29      # 300 KFT (-29)M FOR EARTH

EARTHPAD        DLOAD   CLRGO           # PAD 37-B RADIUS.  SCALED AT (-29)M
                        RPAD
                        V82EMFLG        # INDICATE EARTH SCALING FOR SR30.1
                        BOTHPAD

MOONPAD         VLOAD   ABVAL           # COMPUTE MOON PAD RADIUS FROM RLS VECTOR.
                        RLS             # SCALED AT (-27)M.
                SET
                        V82EMFLG        # INDICATE MOON SCALING FOR SR30.1
BOTHPAD         STCALL  RPADTEM
                        SR30.1          # CALCULATE ORBITAL PARAMETERS
                EXIT
                CA      MODREG          # ARE WE IN P00
                EXTEND
                BZF     CANDEL          # YES, DO DELRSPL
SPLRET1         TC      INTPRET
                RTB     DSU
                        LOADTIME
                        TSTART82        # PRESENT TIME -- TIME V82GOFF1 BEGAN
                STORE   TSTART82        #                 SAVE IT
                DLOAD   BZE             # SR30.1 SETS -TPER=0 IF HPER L/
                        -TPER           # HPERMIN (300 OR 35) KFT.
                        TICKTFF         # (-TPER = 0)
TICKTPER        DLOAD   DAD             # (-TPER NON ZERO) TFF WAS NOT COMPUTED.
                        -TPER           # BUT WAS SET TO 59M59S.  DON'T DICK TFF, DO
                        TSTART82        # TICK -TPER.  DISPLAY BOTH.
                STORE   -TPER           # -TPER CORRECTED FOR TIME SINCE V82GOFF1
```

```
EXIT                    # BEGAN.
```

Uses -TPER 179, HPER 181, HPERMIN 179, IT 185, L 80, MODREG 154, ORBITAL 59, RLS 175, RPADTEM 179, SAVE 191, STATE 138, TC 169, TFF 179, THISPREC 73, TSTART82 179, and X2 85.

833 ⟨*Page CM0518* 833⟩≡ (824 2783)

```
                CAF     BIT1
                TS      V82FLAGS        # INFORMS TICKTEST TO INCREMENT ONLY -TPER
                TC      ENDOFJOB

TICKTFF         DLOAD   DAD             # (-TPER=0) TFF WAS COMPUTED.  TICK TFF.
                        TFF             # DO NOT TICK -TPER.  DISPLAY TFF, BUT NOT
                        TSTART82        # -TPER
                STORE   TFF             # TFF CORRECTED FOR TIME SINCE V82GOFF1
                EXIT                    # BEGAN.
                CAF     BIT2
                TS      V82FLAGS        # INFORMS TICKTEST TO INCREMENT ONLY TFF.
                TC      ENDOFJOB

TICKTEST        CAF     BIT5            # THIS WAITLIST PROGRAM PERPETUATES ITSELF
                MASK    EXTVBACT        # ONCE A SEC UNTIL BIT 5 OF EXTVBACT =0.
                CCS     A
                TC      DOTICK
                CAF     PRIO25
                TC      NOVAC           # TERMINATE V 82.  CAN'T CALL ENDEXT IN RUPT.
                EBANK=  EXTVBACT
                2CADR   ENDEXT

                TC      TASKOVER
DOTICK          CAF     1SEC            # RE-REQUEST TICKTEST.
                TC      WAITLIST
                EBANK=  TFF
                2CADR   TICKTEST

                CAF     THREE
                MASK    V82FLAGS
                INDEX   A
                TC      +1
                TC      TASKOVER        # IF NO FLAGBITS SET DONT CHANGE TFF OR
                                        # -TPER, BUT CONTINUE LOOP.
                TC      TPERTICK        # ONLY BIT 1 SET.  INCR -TPER BY 1 SEC.
TFFTICK         CAF     1SEC            # ONLY BIT 2 SET.  INCR TFF BY 1 SEC.
                TS      L
                CAF     ZERO
                DAS     TFF
                TC      TASKOVER
TPERTICK        CAF     1SEC
                TS      L
                CAF     ZERO
                DAS     -TPER
                TC      TASKOVER
```

Uses -TPER 179, A 80, EBANK 80, EXTVBACT 154, L 80, TC 169, TFF 179, TSTART82 179, V 229, and V82FLAGS 179.

835 ⟨*Page CM0519* 835⟩≡ (824 2783)

```
V82GON          EXIT                    # AVERAGE G ON.  USE CURRENT STATE VECTOR
                                        # FOR ORBITAL PARAMETER CALCULATIONS.
                CAF     PRIO7           # LESS THAN LAMBERT
                TC      FINDVAC         # V82GON1 WILL PERFORM ORBIT CALCULATIONS
                EBANK=  TFF             # ABOUT PROPER BODY APPROX ONCE PER SEC.
                2CADR   V82GON1

                RELINT
                CCS     NEWJOB          # WITHOLD V16 N44 UNTIL FIRST ORBIT CALC
                TC      CHANG1          # IS DONE.  NOTE:  V82GON1 (PRIO7, FINDVAC
                                        # JOB) IS COMPLETED BEFORE V82GON (PRIO7,
                                        # NOVAC JOB).
V82REDSP        CAF     V16N44          # MONITOR HAPO, HPER, TFF
                TC      BANKCALL
                CADR    GOXDSPF
                TC      B5OFF           # TERM THIS TELLS V82GON1 TO KILL ITSELF.
                TC      B5OFF           # PROC DITTO.
                TC      V82REDSP        # RECYCLE

V82GON1         TC      INTPRET         # THIS EXEC PROGRAM PERPETUATES ITSELF
                                        # ONCE A SEC UNTIL BIT 5 OF EXTVBACT =0.
                VLOAD   GOTO            # HOLDS OFF CCS NEWJOB BETWEEN RN AND
                        RN              # VN FETCH SO RN, VN ARE FROM SAME
                        NEXTLINE        # STATE VECTOR UPDATE.
NEXTLINE        STOVL   RONE            # RN AT (-29)M FOR EARTH OR MOON
                        VN
                STORE   VONE            # VN AT (-7)M/CS FOR EARTH OR MOON
                BON     GOTO
                        AMOONFLG        # FLAG INDICATES BODY ABOUT WHICH ORBITAL
                        MOONGON         # CALCULATIONS ARE TO BE PERFORMED.
                        EARTHGON        # IF SET - MOON, IF RESET - EARTH.

MOONGON         SET     DLOAD
                        V82EMFLG        # INDICATE MOON SCALING FOR SR30.1
                        1/RTMUM         # LUNAR PARAMETERS LOADED HERE FOR SR30.1
                STODL   TFF/RTMU
                        MINPERM
                STOVL   HPERMIN
                        RLS             # SCALED AT (-27)M
                ABVAL   GOTO
                        V82GON2
EARTHGON        CLEAR   DLOAD
                        V82EMFLG        # INDICATE EARTH SCALING FOR SR30.1
                        1/RTMUE         # EARTH PARAMETERS LOADED HERE FOR SR30.1
                STODL   TFF/RTMU
```

```
                        MINPERE
                STODL   HPERMIN
                        RPAD
V82GON2         STCALL  RPADTEM         # COMMON CODE FOR EARTH & MOON.
                        SR30.1
```

Uses A 80, AMOONFLG 97, CODE 140, EBANK 80, EXTVBACT 154, HAPO 181, HPER 181, HPERMIN 179, NEWJOB 138, ORBITAL 59, RLS 175, RN 159, RONE 179, RPADTEM 179, STATE 138, TC 169, TFF 179, VN 159, and VONE 179.

836 ⟨*Page CM0520* 836⟩≡ (824 2783)

```
                EXIT
                TC      CHECKMM
                DEC     11
                TC      V82GON3         # NOT IN MODE 11.
CANDEL          TC      INTPRET         # IN MODE 11 OR 00
                CALL
                        INTSTALL        # DELRSPL DOES INTWAKE
                DLOAD   CALL
                        TFF
                        DELRSPL         # RETURN IS TO NEXT LINE (SPLRET).
SPLRET          EXIT

                CA      MODREG
                EXTEND
                BZF     SPLRET1
V82GON3         CAF     BIT5
                MASK    EXTVBACT        # SEE IF ASTRONAUT HAS SIGNALLED TERMINATE
                EXTEND
                BZF     ENDEXT          # YES, TERMINATE VB 82 LOOP
                CAF     1SEC
                TC      BANKCALL        # WAIT ONE SECOND BEFORE REPEATING
                CADR    DELAYJOB        # ORBITAL PARAMETER COMPUTATION.
                TC      V82GON1
```

Uses EXTVBACT 154, MODE 145, MODREG 154, ORBITAL 59, TC 169, and TFF 179.

837 ⟨*Page CM0521* 837⟩≡ (824 2783)

```
# SUBROUTINE NAME: SR30.1
# MOD NO: 0                                                          DATE: 16 FEB 67
# MOD BY: R. R. BAIRNSFATHER                                         LOG SECTION: R32
# MOD NO: 1     MOD BY: R. R. BAIRNSFATHER      DATE: 11 APR 67      SR30.1 CHANGED TO ALLOW
# MOD NO: 2     MOD BY: R. R. BAIRNSFATHER      DATE: 14 APR 67      ADD OVFL CK FOR RAPO
# MOD NO: 3     MOD BY ALONSO                   DATE: 11 DEC 67      SUBROUTINE REWRITTEN
# MOD NO: 4     MOD BY ALONSO                   DATE: 26 MAR 68      PROG MOD TO HANDLE DIF
# MOD NO: 5     MOD BY: R. R. BAIRNSFATHER      DATE: 6 AUG 68       OVFL CK FOR HAPO & HPER
#
# NEW FUNCTIONAL DESCRIPTION:  ORBITAL PARAMETERS DISPLAY FOR NOUNS 32 AND 44.
# SR30.1 CALLS TFFCONMU AND TFFRP/RA TO CALCULATE RPER (PERIGEE RADIUS),
# RAPO (APOGEE RADIUS), HPER (PERIGEE HEIGHT ABOVE LAUNCH PAD OR LUNAR
# LANDING SITE), HAPO (APOGEE HEIGHT AS ABOVE), TPER (TIME TO PERIGEE),
# TFF (TIME TO INTERSECT 300 KFT ABOVE PAD OR 35KFT ABOVE LANDING SITE).
# IF HPER IS GREATER THAN OR EQUAL TO HPERMIN, CALCULATES TPER AND STORES
# NEGATIVE.  IN -TPER.  OTHERWISE STORES +0 IN -TPER.  WHENEVER TPER IS
# CALCULATED, TFF IS NOT COMPUTABLE AND DEFAULTS TO -59MIN 59SEC.  IF HAPO
# WOULD EXCEED 9999.9 NM, IT IS LIMITED TO THAT VALUE FOR DISPLAY.
#
# ADDENDUM:     HAPO AND HPER SHOULD BE CHANGED TO READ HAPOX AND HPERX IN THE
#               ABOVE REMARKS.
#
# CALLING SEQUENCE:     CALL
#                               SR30.1
#
# SUBROUTINES CALLED:   TFFCONMU, TFFRP/RA, CALCTPER, CALCTFF
#
# NORMAL EXIT MODE:     CALLING LINE +1 (STILL IN INTERPRETIVE MODE)
#
# ALARMS:       NONE
#
# OUTPUT:       RAPO    (-29) M EARTH   APOGEE RADIUS   EARTH CENTERED COORD.
#                       (-27) M MOON                    MOON CENTERED COORD.
#               RPER    (-29) M EARTH   PERIGEE RADIUS  EARTH CENTERED COORD.
#                       (-27) M MOON                    MOON CENTERED COORD.
#               HAPOX   (-29) M         APOGEE ALTITUDE ABOVE PAD OR LAND. SITE MAX VALUE LIMIT
#               HPERX   (-29) M         PERIGEE ALT. ABOVE PAD OR LAND. SITE    MAX VALUE LIMIT
#               TFF     (-28) CS        TIME TO 300KFT OR 35KFT ALTITUDE
#               -TPER   (-28) CS        TIME TO PERIGEE
#
# ERASABLE INITIALIZATION REQUIRED -
#       TFF/RTMU        (+17) EARTH     RECIPROCAL OF PROPER GRAV CONSTANT FOR
#                       (+14) MOON      EARTH OR MOON = 1/SQRT(MU).
#       RONE            (-29) M         STATE VECTOR
#       VONE            (-7)  M/CS      STATE VECTOR
```

```
#       RPADTEM         (-29) M EARTH   RADIUS OF LAUNCH PAD OR LUNAR LANDING
#                       (-27) M MOON    SITE.
#       HPERMIN         (-29) M EARTH   (300 OR 35) KFT MINIMUM PERIGEE ALTITUDE
#                       (-27) M MOON    ABOVE LAUNCH PAD OR LUNAR LANDING SITE.
#       V82EMFLG        (INT SW BIT)    RESET FOR EARTH, SET FOR MOON.
#
# DEBRIS:       QPRET, PDL, S2
```

Uses -TPER 179, ALT 157, HAPO 181, HAPOX 181, HPER 181, HPERMIN 179, HPERX 181, IT 185, MODE 145, ORBITAL 59, QPRET 85, RONE 179, RPADTEM 179, S2 85, STATE 138, TFF 179, and VONE 179.

839 ⟨*Page CM0522* 839⟩≡ (824 2783)

```
                COUNT*  $$/SR30S

SR30.1          SETPD   STQ             # INITIALIZE PUSHDOWN LIST.
                        0
                        S2
                                        # SR30.1 INPUT: RONE AT (-29)M EARTH/MOON
                                        #               VONE AT (-7)M/CS
                                        # TFFCONMU, TFFRP/RA, CALCTPER, AND CALCTFF
                                        # CALLS REQUIRE:
                                        # EARTH CENTERED (NO RESCALING REQUIRED)
                                        #       RONE SCALED TO B-29 M
                                        #       VONE SCALED TO B-7 M/CS
                                        # MOON CENTERED (RESCALING REQUIRED)
                                        #       RONE SCALED TO B-27 M
                                        #       VONE SCALED TO B-5 M/CS
                BOFF    VLOAD
                        V82EMFLG        # OFF FOR EARTH, ON FOR MOON.
                        TFFCALLS
                        RONE
                VSL2
                STOVL   RONE
                        VONE
                VSL2
                STORE   VONE
TFFCALLS        CALL
                        TFFCONMU
                CALL                    # TFFRP/RA COMPUTES RAPO,RPER.
                        TFFRP/RA
                                        # RETURNS WITH RAPO IN D(MPAC).
                DSU
                        RPADTEM
                BOFF    SR2R            # NEED HAPO AT (-29)M FOR DISPLAY.
                                        # IF MOON CENTERED, RESCALE FROM (-27)M.
                                        # IF EARTH CENTERED ALREADY AT (-29)M.
                        V82EMFLG        # OFF FOR EARTH, ON FOR MOON.
                        +1
                CALL                    # IF HAPO > MAXNM, SET HAPO =9999.9 NM.
                        MAXCHK          # OTHERWISE STORE (RAPO-RPADTEM) IN HAPO.
STORHAPO        STODL   HAPOX
                        RPER
                DSU
                        RPADTEM         # GIVES HPER AT (-29)M EARTH, (-27)M MOON.
                STORE   MPAC +4         # SAVE THIS FOR COMPARISON TO HPERMIN.
                BOFF    SR2R            # NEED HPER AT (-29)M FOR DISPLAY.
                                        # IF MOON CENTERED, RESCALE FROM (-27)M.
```

```
                                        # IF EARTH CENTERED ALREADY AT (-29)M.
                        V82EMFLG        # OFF FOR EARTH, ON FOR MOON.
                        +1
                CALL                    # IF HPER > MAXNM, SET HPER = 9999.9 NM.
                        MAXCHK
```

Uses COUNT 142, D 226, HAPO 181, HAPOX 181, HPER 181, HPERMIN 179, MPAC 145, RONE 179, RPADTEM 179, S2 85, SAVE 191, and VONE 179.

840a ⟨*Page CM0523* 840a⟩≡ (824 2783)

```
STORHPER        STODL   HPERX           # STORE (RPER - RPADTEM) INTO HPERX.
                        MPAC +4
                DSU     BPL             # HPERMIN AT (-29)M FOR EARTH, (-27)M MOON
                        HPERMIN         # IF HPER L/ HPERMIN (300 OR 35) KFT,
                        DOTPER          # THEN ZERO INTO -TPER.
                DLOAD   GOTO            # OTHERWISE CALCULATE TPER.
                        HI6ZEROS
                        SKIPTPER
DOTPER          DLOAD   CALL
                        RPER
                        CALCTPER
                DCOMP                   # TPER IS PUT NEG INTO -TPER.
SKIPTPER        STODL   -TPER
                        HPERMIN         # HPERMIN AT (-29)M FOR EARTH, (-27)M MOON
                DAD     CALL
                        RPADTEM         # RPADTEM AT (-29)M FOR EARTH, (-27)M MOON
                        CALCTFF         # GIVES 59M59S FOR TFF IF RPER G/
                DCOMP                   # HPERMIN + RPADTEM.  (TPER WAS NON ZERO)
                STCALL  TFF             # OTHERWISE COMPUTES TFF.       (GOTO)
                        S2

MAXCHK          DSU     BPL             # IF C(MPAC) > 9999.9 NM. MPAC = 9999.9 NM.
                        MAXNM
                        +3              # OTHERWISE C(MPAC) = B(MPAC).
                DAD     RVQ
                        MAXNM
 +3             DLOAD   RVQ             # (USED BY P30 - P37 ALSO)
                        MAXNM

MAXNM           2OCT    0106505603
```

Uses -TPER 179, HI6ZEROS 71, HPER 181, HPERMIN 179, HPERX 181, L 80, MPAC 145, RPADTEM 179, S2 85, and TFF 179.

840b ⟨*Page CM0524* 840b⟩≡ (824 2783)

```
# There is no source code on this page --- HG 2009
```

3.4.6 stable orbit

841 ⟨*stable orbit* 841⟩≡ (744b)
⟨*Page CM0525* 842⟩
⟨*Page CM0526* 844⟩
⟨*Page CM0527* 846⟩
⟨*Page CM0528* 848⟩
⟨*Page CM0529* 850⟩
⟨*Page CM0530* 852⟩
⟨*Page CM0531* 854⟩
⟨*Page CM0532* 856⟩

842 ⟨*Page CM0525* 842⟩≡ (841 2807)

```
# STABLE ORBIT RENDEZVOUS PROGRAMS (P38 AND P78)
#
# MOD NO -1             LOG SECTION - STABLE ORBIT - P38-P39
# MOD BY RUDNICKI.S     DATE 25JAN68
#
# FUNCTIONAL DESCRIPTION
#
#       P38 AND P78 CALCULATE THE REQUIRED DELTA V AND OTHER INITIAL
#       CONDITIONS REQUIRED BY THE AGC TO (1) PUT THE ACTIVE VEHICLE
#       ON A TRANSFER TRAJECTORY THAT INTERCEPTS THE PASSIVE VEHICLE
#       ORBIT A GIVEN DISTANCE, DELTA R, EITHER AHEAD OF OR BEHIND THE
#       PASSIVE VEHICLE AND (2) ACTUALLY PLACE THE ACTIVE VEHICLE IN THE
#       PASSIVE VEHICLE ORBIT WITH A DELTA R SEPARATION BETWEEN THE TWO
#       VEHICLES
#
# CALLING SEQUENCE
#
#       ASTRONAUT REQUEST THRU DSKY
#
#       V37E38E         IF THIS VEHICLE IS ACTIVE VEHICLE
#       V37E78E         IF OTHER VEHICLE IS ACTIVE VEHICLE
#
# INPUT
#
#       (1)     SOI MANEUVER
#
#               (A)  TIG        TIME OF SOI MANEUVER
#               (B)  CENTANG    ORBITAL CENTRAL ANGLE OF THE PASSIVE VEHICLE
#                               DURING THE TRANSFER FROM TIG TO TIME OF INTERCEPT
#               (C)  DELTAR     THE DESIRED SEPARATION OF THE TWO VEHICLES
#                               SPECIFIED AS A DISTANCE ALONG THE PASSIVE VEHICLE
#                               ORBIT
#               (D)  OPTION     EQUALS 1 FOR SOI
#
#       (2)     SOR MANEUVER
#
#               (A)  TIG        TIME OF SOR MANEUVER
#               (B)  CENTANG    AN OPTIONAL RESPECIFICATION OF 1 (B) ABOVE
#               (C)  OPTION     EQUALS 2 FOR SOR
#               (D)  DELTTIME   THE TIME REQUIRED TO TRAVERSE DELTA R WHEN
#                               TRAVELING AT A VELOCITY EQUAL TO THE HORIZONTAL
#                               VELOCITY OF THE PASSIVE VEHICLE - SAVED FROM
#                               SOI PHASE
#               (E)  TINT       TIME OF INTERCEPT (SOI) - SAVED FROM SOI PHASE
#
```

```
# OUTPUT
#
#       (1)  TRKMKCNT   NUMBER OF MARKS
#       (2)  TTOGO      TIME TO GO
#       (3)  +MGA       MIDDLE GIMBAL ANGLE
```

Uses +MGA 234, A 80, D 226, DELTAR 183, DELTTIME 183, ORBITAL 59, TIG 224, TINT 236, TRKMKCNT 157, TTOGO 236, and V 229.

844 ⟨*Page CM0526* 844⟩≡ (841 2807)

```
#       (4)  DSPTEM1    TIME OF INTERCEPT OF PASSIVE VEHICLE ORBIT
#                       (FOR SOI ONLY)
#       (5)  POSTTPI    PERIGEE ALTITUDE OF ACTIVE VEHICLE ORBIT AFTER
#                       THE SOI (SOR) MANEUVER
#       (6)  DELVTPI    MAGNITUDE OF DELTA V AT SOI (SOR) TIME
#       (7)  DELVTPF    MAGNITUDE OF DELTA V AT INTERCEPT TIME
#       (8)  DELTA      VELOCITY AT SOI (AND SOR) - LOCAL VERTICAL
#                       COORDINATES
#
# SUBROUTINES USED
#
#       AVFLAGA
#       AVFLAGP
#       VNDSPLY
#       BANKCALL
#       GOFLASHR
#       GOTOP00H
#       BLANKET
#       ENDOFJOB
#       PREC/TT
#       SELECTMU
#       INTRPVP
#       MAINRTNE

                BANK    04
                SETLOC  STBLEORB
                BANK

                EBANK=  SUBEXIT
                COUNT*  $$/P3879

P38             TC      AVFLAGA         # THIS VEHICLE ACTIVE
                TC      +2
P78             TC      AVFLAGP         # OTHER VEHICLE ACTIVE
                TC      P20FLGON        # SET UPDATFLG, TRACKFLG
                CAF     V06N33SR        # DISPLAY TIG
                TC      VNDSPLY
                CAF     V06N55SR        # DISPLAY CENTANG
                TCR     BANKCALL
                CADR    GOFLASHR
                TCF     GOTOP00H        # TERMINATE
                TCF     +5              # PROCEED
                TCF     -5              # RECYCLE
                CAF     THREE           # IMMEDIATE RETURN -- BLANK R1, R2
                TCR     BLANKET
```

```
TCF     ENDOFJOB
CAF     FIVE
TS      OPTION1
CAF     ONE
TS      OPTION2         # OPTION CODE IS SET TO 1
```

Uses CODE 140, COUNT 142, DELVTPF 183, DELVTPI 183, DSPTEM1 154, EBANK 80, OPTION1 157, OPTION2 157, POSTTPI 183, R2 188, STBLEORB 59, SUBEXIT 181, TC 169, TIG 224, TRACKFLG 101, UPDATFLG 99, and V 229.

846 ⟨*Page CM0527* 846⟩≡ (841 2807)

```
                    CAF     V04N06SR        # DISPLAY OPTION CODE -1 = SOI, 2 = SOR
                    TCR     BANKCALL
                    CADR    GOFLASHR
                    TCF     GOTOP00H        # TERMINATE
                    TCF     +5              # PROCEED
                    TCF     -5              # RECYCLE
                    CAF     BIT3            # IMMEDIATE RETURN -- BLANK R3
                    TCR     BLANKET
                    TCF     ENDOFJOB
                    TC      INTPRET
                    SSP
                            NN
                            2
                    SLOAD   SR1
                            OPTION2
                    BHIZ    DLOAD
                            OPTN1
                            TINT
                    STORE   TINTSOI         # STORE FOR SOR PHASE
                    CLRGO
                            OPTNSW          # OPTNSW: ON = SOI. OFF = SOR
                            JUNCTN1
OPTN1               SET     CLEAR           # SOI
                            OPTNSW
                            UPDATFLG
                    CALL
                            PREC/TT
                    SET     DAD
                            UPDATFLG
                            TIG
                    STORE   TINT            # TI = TIG + TF
                    STORE   DSPTEM1         # FOR DISPLAY
                    EXIT
                    CAF     V06N57SR        # DISPLAY DELTA R
                    TCR     BANKCALL
                    CADR    GOFLASHR
                    TCF     GOTOP00H        # TERMINATE
                    TCF     +5              # PROCEED
                    TCF     -5              # RECYCLE
                    CAF     SIX             # IMMEDIATE RETURN - BLANK R2, R3
                    TCR     BLANKET
                    TCF     ENDOFJOB
                    CAF     V06N34SR        # DISPLAY TIME OF INTERCEPT
                    TC      VNDSPLY
                    TC      INTPRET
```

```
JUNCTN1         CLEAR   CALL
                        P39/79SW
                        SELECTMU        # SELECT MU, CLEAR FINALFLG, GO TO VN1645
RECYCLE         CALL
                        PREC/TT
```

Uses CODE 140, DSPTEM1 154, FINALFLG 105, NN 244, OPTION2 157, OPTNSW 105, P39/79SW 127, R2 188, TC 169, TIG 224, TINT 236, TINTSOI 183, and UPDATFLG 99.

848 ⟨*Page CM0528* 848⟩≡ (841 2807)

```
                BOFF    DLOAD
                        OPTNSW
                        OPTN2
                        TINT
                STCALL  TDEC1           # PRECISION UPDATE PASSIVE VEHICLE TO
                        INTRPVP         # INTERCEPT TIME
                VLOAD   UNIT
                        RATT            # RP/(RP)
                PDVL    VXV
                        VATT
                ABVAL   NORM            # (VP X RP/(RP))
                        X1
                PDDL    DDV
                        DELTAR
                SL*                     # DELTA R / (VP X RP/RP)
                        0 -7,1
                STCALL  DELTTIME        # DELTA T = (RP) DELTA R / (VP X RP)
                        JUNCTN2
OPTN2           DLOAD   DAD
                        TINTSOI
                        T
                STORE   TINT            # TI = TI + TF
JUNCTN2         DLOAD   DSU
                        TINT
                        DELTTIME
                STORE   TARGTIME        # TT = TI - DELTA T

# .... MAINRTNE ....
#
# SUBROUTINES USED
#
#       S3435.25
#       PERIAPO1
#       SHIFTR1
#       VNDSPLY
#       BANKCALL
#       GOFLASH
#       GOTOPOOH
#       VN1645

MAINRTNE        STCALL  TDEC1           # PRECISION UPDATE PASSIVE VEHICLE TO
                        INTRPVP         #       TARGET TIME
                DLOAD
                        TIG
                STORE   INTIME
```

```
                SSP     VLOAD
                        SUBEXIT
                        TEST3979
                        RATT
                CALL
                        S3435.25
TEST3979        BOFF    BON
```

Uses DELTAR 183, DELTTIME 183, INTIME 236, OPTNSW 105, SUBEXIT 181, TARGTIME 183, TIG 224, TINT 236, TINTSOI 183, and X1 85.

850 ⟨*Page CM0529* 850⟩≡ (841 2807)

```
                        P39/79SW
                        MAINRTN1
                        FINALFLG
                        P39P79
                SET
                        UPDATFLG
P39P79          EXIT
                TC      DSPLY81         # FOR P39 AND P79
MAINRTN1        VLOAD   ABVAL
                        DELVEET3
                STOVL   DELVTPI         # DELTA V
                        VPASS4
                VSU     ABVAL
                        VTPRIME
                STOVL   DELVTPF         # DELTA V (FINAL) = V-T - VT
                        RACT3
                PDVL    CALL
                        VIPRIME
                        PERIAPO1        # GET PERIGEE ALTITUDE
                CALL
                        SHIFTR1
                STORE   POSTTPI
                BON     SET
                        FINALFLG
                        DSPLY58
                        UPDATFLG
DSPLY58         EXIT
                CAF     V06N58SR        # DISPLAY HP, DELTA V, DELTA V (FINAL)
                TC      VNDSPLY
DSPLY81         CAF     V06N81SR        # DISPLAY DELTA V (LV)
                TC      VNDSPLY
                TC      INTPRET
                CLEAR   VLOAD
                        XDELVFLG
                        DELVEET3
                STCALL  DELVSIN
                        VN1645          # DISPLAY TRKMKCNT, TTOGO, +MGA
                BON     GOTO
                        P39/79SW
                        P39/P79B
                        RECYCLE

# STABLE ORBIT MIDCOURSE PROGRAM (P39 AND P79)
#
# MOD NO -1             LOG SECTION - STABLE ORBIT - P38-P39
```

```
# MOD BY RUDNICKI, S    DATE 25JAN68
#
# FUNCTIONAL DESCRIPTION
#
#       P39 AND P79 CALCULATE THE REQUIRED DELTA V AND OTHER INITIAL
#       CONDITIONS REQUIRED BY THE AGC TO MAKE A MIDCOURSE CORRECTION
```

Uses +MGA 234, A 80, DELVEET3 236, DELVSIN 236, DELVTPF 183, DELVTPI 183, FINALFLG 105, HP 185, LV 85, P39/79SW 127, POSTTPI 183, RACT3 234, TC 169, TRKMKCNT 157, TTOGO 236, UPDATFLG 99, V 229, VIPRIME 234, VPASS4 236, VTPRIME 234, and XDELVFLG 103.

852 ⟨*Page CM0530* 852⟩≡ (841 2807)

```
#       MANEUVER AFTER COMPLETING THE SOI MANEUVER BUT BEFORE MAKING
#       THE SOR MANEUVER.
#
# CALLING SEQUENCE
#
#       ASTRONAUT REQUEST THRU DSKY
#
#       V37E39E         IF THIS VEHICLE IS ACTIVE VEHICLE
#       V37E79E         IF OTHER VEHICLE IS ACTIVE VEHICLE
#
# INPUT
#
#       (1)  TPASS4     TIME OF INTERCEPT -- SAVED FROM P38/P78
#       (2)  TARGTIME   TIME THAT PASSIVE VEHICLE IS AT INTERCEPT POINT --
#                       SAVED FROM P38/P78
#
# OUTPUT
#
#       (1)  TRKMKCNT   NUMBER OF MARKS
#       (2)  TTOGO      TIME TO GO
#       (3)  +MGA       MIDDLE GIMBAL ANGLE
#       (4)  DELVLVC    DELTA VELOCITY AT MID -- LOCAL VERTICAL COORDINATES
#
# SUBROUTINES USED
#
#       AVFLAGA
#       AVFLAGP
#       LOADTIME
#       SELECTMU
#       PRECSET
#       S34/35.1
#       MAINRTNE

P39             TC      AVFLAGA         # THIS VEHICLE ACTIVE
                EXTEND
                DCA     ATIGINC
                TC      P39/P79A
P79             TC      AVFLAGP         # OTHER VEHICLE ACTIVE
                EXTEND
                DCA     PTIGINC
P39/P79A        DXCH    KT              # TIME TO PREPARE FOR BURN
                TC      P20FLGON        # SET UPDATFLG, TRACKFLG
                TC      INTPRET
                SET     CALL
                        P39/79SW
```

```
                        SELECTMU        # SELECT MU, CLEAR FINALFLG, GO TO VN1645
P39/P79B        RTB     DAD
                        LOADTIME
                        KT
                STORE   TIG             # TIG = T (PRESENT) + PREPARATION TIME
```

Uses +MGA 234, ATIGINC 175, DELVLVC 224, FINALFLG 105, KT 181, P39/79SW 127, PTIGINC 175, TARGTIME 183, TC 169, TIG 224, TPASS4 236, TRACKFLG 101, TRKMKCNT 157, TTOGO 236, and UPDATFLG 99.

854 ⟨*Page CM0531* 854⟩≡ (841 2807)

```
                STCALL  TDEC1           # PRECISION UPDATE ACTIVE AND PASSIVE
                        PRECSET         #       VEHICLES TO TIG
                CALL
                        S34/35.1        # GET UNIT NORMAL
                DLOAD   GOTO
                        TARGTIME
                        MAINRTNE        # CALCULATE DELTA V AND DELTA V (LV)

# .... PREC/TT ....
#
# SUBROUTINES USED
#
#       PRECSET
#       TIMETHET
#       S34/35.1

PREC/TT         STQ     DLOAD
                        RTRN
                        TIG
                STCALL  TDEC1           # PRECISION UPDATE ACTIVE AND PASSIVE
                        PRECSET         #       VEHICLES TO TIG
                VLOAD   VSR*
                        RPASS3
                        0,2
                STODL   RVEC
                        CENTANG
                PUSH    COS
                STODL   CSTH
                SIN     SET
                        RVSW
                STOVL   SNTH
                        VPASS3
                VSR*
                        0,2
                STCALL  VVEC            # GET TRANSFER TIME BASED ON CENTANG OF
                        TIMETHET        #       PASSIVE VEHICLE
                CALL
                        S34/35.1        # GET UNIT NORMAL
                DLOAD   GOTO
                        T
                        RTRN

# .... INTRPVP ....
#
# SUBROUTINES USED
```

```
#
#       CSMPREC
#       LEMPREC

INTRPVP         STQ     BOFF            # PRECISION UPDATE PASSIVE VEHICLE TO
                        RTRN            #       TDEC1
                        AVFLAG
                        OTHERV
                CALL
```

Uses AVFLAG 105, CSTH 188, LV 85, RPASS3 234, RTRN 181, RVEC 188, RVSW 123, SNTH 188, TARGTIME 183, TIG 224, V 229, VPASS3 234, and VVEC 188.

856 ⟨*Page CM0532* 856⟩≡ (841 2807)

```
                        CSMPREC
                GOTO
                        RTRN
OTHERV          CALL
                        LEMPREC
                GOTO
                        RTRN

# .... VNDSPLY ....
#
# SUBROUTINES USED
#
#       BANKCALL
#       GOFLASH
#       GOTOPOOH

VNDSPLY         EXTEND                  # FLASH DISPLAY
                QXCH    RTRN
                TS      VERBNOUN
                CA      VERBNOUN
                TCR     BANKCALL
                CADR    GOFLASH
                TCF     GOTOPOOH        # TERMINATE
                TC      RTRN            # PROCEED
                TCF     -5              # RECYCLE
V06N33SR        VN      0633
V06N55SR        VN      0655
V04N06SR        VN      0406
V06N57SR        VN      0657
V06N34SR        VN      0634
V06N58SR        VN      0658
V06N81SR        VN      0681

# *** END OF COMEKISS.020 ***
```

Uses RTRN 181, TC 169, VERBNOUN 181, and VN 159.

3.5 trouble routines

857a ⟨*trouble routines* 857a⟩≡ (19a)
⟨*p11 code* 857b⟩
⟨*tpi search* 892⟩
⟨*p20 p25 code* 913⟩
⟨*p30 p37 code* 1042b⟩
⟨*p32-p33 p72-p73 code* 1062b⟩
⟨*p40-p47 code* 1093⟩
⟨*p51-p53 code* 1146⟩
⟨*lunar and solar ephemerides subroutines* 1194⟩
⟨*p61-p67 code* 1199⟩
⟨*servicer207 code* 1226⟩
⟨*entry lexicon* 1244⟩
⟨*reentry control* 1255b⟩
⟨*cm body attitude* 1290⟩
⟨*p37 p70 code* 1300b⟩
⟨*s-band antenna for cm* 1343⟩
⟨*lunar landmark selection for cm* 1346a⟩

3.5.1 p11 code

857b ⟨*p11 code* 857b⟩≡ (857a)
⟨*Page CM0533* 858⟩
⟨*Page CM0534* 860⟩
⟨*Page CM0535* 862⟩
⟨*Page CM0536* 864⟩
⟨*Page CM0537* 866⟩
⟨*Page CM0538* 868⟩
⟨*Page CM0539* 870⟩
⟨*Page CM0540* 872⟩
⟨*Page CM0541* 874⟩
⟨*Page CM0542* 876⟩
⟨*Page CM0543* 878⟩
⟨*Page CM0544* 880⟩
⟨*Page CM0545* 882⟩
⟨*Page CM0546* 884⟩
⟨*Page CM0547* 886⟩
⟨*Page CM0548* 888⟩
⟨*Page CM0549* 890⟩
⟨*Page CM0550* 891⟩

858 ⟨*Page CM0533* 858⟩≡ (857b 2749)

```
# EARTH ORBIT INSERTION MONITOR PROGRAM
# ************************************
#
# PROGRAM DESCRIPTION -P11-
#
#       MOD NO. 1
#       MOD BY ELIASSEN
#
# FUNCTIONAL DESCRIPTION
#
#       P11 IS INITIATED BY
#
#               A) GYROCOMPASS PRG P02 WHEN LIFTOFF DISCRETE IS RECEIVED OR
#               B) BACKUP THRU VERB 75 ENTER
#
#       PROGRAM WILL
#               1. ZERO CMC CLOCK AT LIFTOFF (OR UPON RECEIPT OF BACKUP)
#               2. UPDATE TEPHEM TO TIME CMC CLOCK WAS ZEROED
#               3. INITIATE SERVICER AT PREREAD1
#               4. CHANGE MAJOR MODE TO 11
#               5. CLEAR DSKY IN CASE OF V 75
#               6. STORE LIFTOFF IMU-CDU ANGLES FOR ATT. ERROR DISPLAY
#               7. TERMINATE GYROCOMPASSING     __  __
#               8. COMPUTE INITIAL VECTORS      RN, VN            _  _  _
#               9. COMPUTE REFSMMAT FOR PRELAUNCH ALIGNMENT WHERE U ,U ,U  ARE
#                       _         _                                X  Y  Z
#                       U =(UNIT(-R)    LOCAL VERTICAL AT TIME OF LIFTOFF
#                       _Z      _       _
#                       U =UNIT(A),     A=HOR VECTOR AT LAUNCH AZIMUTH
#                       _X _   _
#                       U =U * U
#                        U  Z   X
#               10. SET REFSMMAT KNOWN FLAG
#               11. SET AVGEXIT IN SERVICER TO VHHDOT TO
#                   COMPUTE AND DISPLAY NOUN 62 EVERY 2 SECONDS
#
#                       R1      V1   -- INERTIAL VELOCITY MAGNITUDE IN FPS
#                       R2      HDOT -- RATE OF CHANGE OF VEHICLE VEL IN FPS
#                       R3      H    -- VEHICLE ALTITUDE ABOVE PAD IN NM
#
#               12. DISPLAY BODY AXES ATT. ERRORS ON FDAI NEEDLES
#
#                       A) FROM L.O. TO RPSTART (APPROX. 0 TO +10SECS AFTER L.O.)
#                          DESIRED ATTITUDE IS AS STORED AT L.O.
#                       B) FROM RPSTART TO POLYSTOP (APPROX. +10 TO +133SECS AFTER LO
```

```
#                           DESIRED ATTITUDE IS SPECIFIED BY CMC PITCH AND ROLL
#                           POLYNOMIALS DURING SATURN ROLLOUT AND PITCHOVER
```

Uses A 80, AVGEXIT 159, AZIMUTH 191, H 177, HDOT 231, L 80, MODE 145, POLYSTOP 221, R2 188, REFSMMAT 172, RN 159, RPSTART 221, TEPHEM 172, V 229, V1 145, VEL 226, VN 159, and Z 80.

860 ⟨*Page CM0534* 860⟩≡ (857b 2749)

```
#                          THE DISPLAY IS RUN AS LOW PRIORITY JOB APPROX.
#                          EVERY 1/2 SEC OR LESS AND IS DISABLED UPON OVFLO OF TIME1
#
# SUBROUTINES CALLED
#
#       2PHSCHNG        BANKCALL        CALCGRA         CDUTRIG         CLEANDSP
#       DELAYJOB        EARTHR          ENDOFJOB        FINDVAC         IBNKCALL
#       INTPRET         LALOTORV        NEEDLER         NEWMODEX        PHASCHNG
#       POSTJUMP        POWRSERS        PREREAD1        REGODSPR        S11.1
#       SERVEXIT        TASKOVER        TCDANZIG        V1STO2S         WAITLIST
#
# ASTRONAUT REQUESTS (IF ALTITUDE ABOVE 300,000 FT)
#
#       DSKY --
#               MONITOR DISPLAY OF TIME TO PERIGEE R1 HOURS
#                                                  R2 MINUTES
#
#       DSKY --
#               MONITOR DISPLAY OF R1 APOGEE ALTITUDE IN NAUTICAL MILES
#                                  R2 PERIGEE ALTITUDE IN NAUTICAL MILES
#                                  R3 TFF IN MINUTES/SECS
#
#       IF ASTRONAUT HAS REQUESTED ANY OF THESE DISPLAYS HE MUST
# HIT PROCEED TO RETURN TO NORMAL NOUN 62 DISPLAY.
# NORMAL EXIT MODE
#
#       ASTRONAUT       VERB 37 ENTER 00 ENTER
#
# ALARM MODES -- NONE
#
# ABORT EXIT MODES --
#
# OUTPUT
#
#       TLIFTOFF (DP)   TEPHEM (TP)
#       REFSMMAT
#       DSKY DISPLAY
#       FDAI DISPLAY
#
# ERASABLE INITIALIZATION
#
#       AZO, AXO, -AYO
#       LATITUDE
#       PADLONG
#       TEPHEM
```

```
#       PGNCSALT
#       POLYNUM THRU POLYNUM +14D
#       RPSTART
#       POLYSTOP
# FLAGS SET OR RESET
```

Uses -AYO 172, AXO 172, AZO 172, DISPLAYS 59, LATITUDE 191, MODE 145, PADLONG 161, PGNCSALT 161, POLYNUM 219, POLYSTOP 221, PRIORITY 145, R2 188, REFSMMAT 172, RPSTART 221, RUN 191, TEPHEM 172, TFF 179, TIME1 80, and TLIFTOFF 163.

862 ⟨*Page CM0535* 862⟩≡ (857b 2749)

```
#       SET REFSMFLG
#       SET DVMON IDLE FLAG
#       CLEAR ERADFLAG
#
# DEBRIS
#
#       LIFTTEMP
#       POLYNUM THRU POLYNUM +7
#       SPOLYARG
#       BODY1, BODY2, BODY3
#       VMAG2, ALTI, HDOT
#       CENTRALS, CORE SET, AND VAC AREAS

                COUNT   34/P11

BITS5-6         =       SUPER011
                BANK    42
                SETLOC  P11ONE
                BANK

                EBANK=  TEPHEM
P11             CA      EBANK3
                TS      EBANK

                EXTEND
                DCA     REP11S          # DIRECT RESTARTS TO REP11
                DXCH    -PHASE3
                CS      ZERO
                ZL
                TS      LIFTTEMP
                DXCH    -PHASE5         # INACTIVE GROUP 5, PRELAUNCH PROTECTION
P11+7           EXTEND
                DCA     REP11SA
                DXCH    TLIFTOFF

                EXTEND
                DCA     TIME2
                DXCH    LIFTTEMP        # FORE RESTARTS

                CA      ZERO
                ZL
                DXCH    TIME2
REP11A-2        DXCH    TLIFTOFF
REP11A-1        DXCH    -PHASE3         # RESET PHASE
```

```
REP11A          INHINT
                EXTEND
                DCA     TEPHEM  +1
                DXCH    TEPHEM1 +1
                CA      TEPHEM
```

Uses -PHASE3 152, -PHASE5 152, ALTI 231, BODY1 221, BODY2 221, BODY3 221, COUNT 142, EBANK 80, ERADFLAG 99, HDOT 231, LIFTTEMP 161, P11ONE 69, PHASE3 152, PHASE5 152, POLYNUM 219, REFSMFLG 107, SPOLYARG 221, TEPHEM 172, TEPHEM1 161, TIME2 80, and TLIFTOFF 163.

864 ⟨*Page CM0536* 864⟩≡ (857b 2749)

```
XCH     TEPHEM1

EXTEND
DCA     TLIFTOFF
DAS     TEPHEM1 +1
ADS     TEPHEM1         # CORRECT FOR OVERFLOW

TC      PHASCHNG
OCT     05023
OCT     22000

INHINT
EXTEND
DCA     TEPHEM1
DXCH    TEPHEM
CA      TEPHEM1 +2
XCH     TEPHEM  +2

CAF     EBDVCNT
TS      EBANK
EBANK=  DVCNTR
TC      IBNKCALL
CADR    PREREAD1        # ZERO PIPS AND INITIALIZE AVERAGEG

TC      PHASCHNG
OCT     05023           # CONTINUE HERE ON RESTART
OCT     22000

CAF     .5SEC           # START ATT ERROR DISPLAY
TC      WAITLIST        # IN .5 SEC
EBANK=  BODY3
2CADR   ATERTASK

TC      NEWMODEX        # DISPLAY MM 11
MM      11

TC      UPFLAG
ADRES   NODOP01

CA      POWDNCOD        # SWITCH TO POWERED FLIGHT DOWNLIST
TS      DNLSTCOD

TC      BANKCALL
CADR    CLEANDSP        # CLEAR DSKY IN CASE OF V75
```

```
TC      2PHSCHNG
OCT     40514           # PROTECT ATERTASK
OCT     00073
CAF     EBQPLACE
```

Uses BODY3 221, DNLSTCOD 148, DVCNTR 224, EBANK 80, EBDVCNT 73, EBQPLACE 73, MM 226, NODOP01 99, RESTART 57, TC 169, TEPHEM 172, TEPHEM1 161, and TLIFTOFF 163.

866 ⟨*Page CM0537* 866⟩≡ (857b 2749)

```
                    TS      EBANK

                    EBANK=  QPLACES
                    CA      P11XIT          # SET EXIT FROM PROUT IN EARTHR
                    TS      QPLACES
                    TC      INTPRET
                    VLOAD   MXV
                            THETAN
                            XSM
                    VSL1    VAD
                            ERCOMP
                    STODL   ERCOMP
                            TLIFTOFF
                    SSP     GOTO
                            S2
                    CADR    PROUT           # RETURN FROM EARTHR
                            EARTHR  +3
          MATRXJOB  ZL                      # STORE DP GIMBAL ANGLES FOR ATTITUDE
                    CA      CDUX            #       ERROR DISPLAY AFTER LIFTOFF
                    DXCH    OGC
                    ZL
                    CA      CDUY
                    DXCH    IGC
                    ZL
                    CA      CDUZ
                    DXCH    MGC
                    TC      INTPRET                 _
                    VLOAD   VSR1            # SCALE OGC B-1
                            OGC
                    STORE   OGC
                    SSP                     # ZERO RTX2
                            RTX2            # FOR
                            0               # EARTH
                    DLOAD   PDDL
                            PGNCSALT        # ALTITUDE OF PGNCS
                            PADLONG         # LONGITUDE
                    PDDL    VDEF
                            LATITUDE        # GEODETIC LATITUDE
                    STODL   LAT             # LAT,LONG,ALT ARE CONSECUTIVE
                            HI6ZEROS        # TIME = 0
                    CLEAR   CALL
                            ERADFLAG
                            LALOTORV        # CONVERT TO POSITION VECTOR IN REF. COORDS.

                    STCALL  RN1             #              _
```

```
        GETDOWN         # RETURN WITH VECTOR FOR DOWN DIRECTION
VCOMP   UNIT
STOVL   REFSMMAT +12D   # UNITZ = UNIT(GRAV)
        RN1
VXV     VXSC
```

Uses ALT 157, CDUX 80, CDUY 80, CDUZ 80, EBANK 80, ERADFLAG 99, ERCOMP 196, HI6ZEROS 71, IGC 186, LAT 157, LATITUDE 191, LONG 157, MGC 186, OGC 186, PADLONG 161, PGNCSALT 161, QPLACES 191, REFSMMAT 172, RN1 159, S2 85, TC 169, THETAN 194, TLIFTOFF 163, and XSM 186.

868 ⟨*Page CM0538* 868⟩≡ (857b 2749)

```
        UNITW           # SCALED AT 1
        -ERTHRAT        # V = EARTHRATE X R
VSL4                    # SCALE TO 2(7) M/CS
STOVL   VN1
        REFSMMAT +12D
VXV     UNIT
        UNITW           # (REF3 X UNITW) = EAST
PUSH    VXV
        REFSMMAT +12D   # (EAST X REF3) = -SOUTH
UNIT    PDDL
        LAUNCHAZ        # COS(AZ)*SOUTH
COS     VXSC
STADR
STODL   REFSMMAT        # TEMPORARY STORAGE
        LAUNCHAZ
SIN     VXSC            # SIN(AZ)*EAST
VAD     UNIT            # SIN(AZ)*EAST - COS(AZ)*SOUTH = REF1
        REFSMMAT
STORE   REFSMMAT

VXV     UNIT            # (REF1 X REF3) = -REF3
        REFSMMAT +12D
VCOMP
STORE   REFSMMAT +6
DLOAD   DSU
        DPHALF          # 1/2 REV
        LAUNCHAZ
DAD     PDDL
        AZIMUTH
        SATRLRT         # SET SATRLRT = -SATRLRT IF
SIGN    STADR           # (1/2REV -LAVNCHAZ +AZIMUTH) IS NEGATIVE
STORE   SATRLRT         # FOR ROLL CALC IN FDAI ATT. ERROR DISPLAY
SET     EXIT
        REFSMFLG        # SET REFSMMAT KNOWN FLAG

TC      PHASCHNG
OCT     04023

EXTEND
DCA     P11SCADR
DXCH    AVGEXIT         # SET AVGEXIT

CA      PRIO31          # 2 SECONDS AT 2(+8)
TS      1/PIPADT
```

```
EBANK=  RCSFLAGS
CA      EBANK6
TS      EBANK

INHINT
```

Uses 1/PIPADT 156, AVGEXIT 159, AZIMUTH 191, EBANK 80, LAUNCHAZ 194, RCSFLAGS 200, REFSMFLG 107, REFSMMAT 172, SATRLRT 219, TC 169, UNITW 172, V 229, and VN1 159.

870 ⟨*Page CM0539* 870⟩≡ (857b 2749)

```
                    CS      ZERO
                    TS      TBASE5          # RESTART READACCS 2 SECONDS AFTER LIFTOFF

                    CS      TIME1
                    AD      2SECS           # DO READACCS 2 SECONDS AFTER LIFTOFF

                    CCS     A               # CHECK TO INSURE DT IS POSITIVE
                    TCF     +3              # TIME POSITIVE
                    TCF     +2              # CANNOT GET HERE
                    CA      ZERO            # TIME NEGATIVE -- SET TO 1
                    AD      ONE             # RESTORE TIME  --  OR MAKE POSITIVE

                    TC      WAITLIST
                    EBANK=  AOG
                    2CADR   READACCS

                    TC      2PHSCHNG
                    OCT     00003           # TURN OFF GROUP 3
                    OCT     00025           # PROTECT NORMLIZE AND READACCS

                    TC      POSTJUMP
                    CADR    NORMLIZE        # DO NORMLIZE AND ENDOFJOB


                    EBANK=  TEPHEM
          REP11     INHINT
                    CCS     PHASE5
                    TC      ENDOFJOB

                    CCS     LIFTTEMP
                    TCF     +4
                    TCF     +3
                    TCF     +2
                    TCF     P11+7

                    CS      TLIFTOFF
                    EXTEND
                    BZMF    ENDREP11

                    CCS     TIME2           # ** TIME2 MUST BE NON-ZERO AT LIFTOFF **
                    TCF     REP11A  -5      # T2,T1 NOT YET ZEROED, GO AND DO IT

                    EXTEND                  # T2,T1 ZEROED, SET TLIFTOFF
                    DCA     LIFTTEMP
                    TCF     REP11A-2
```

```
ENDREP11        EXTEND
                DCA     REP11SA
                TCF     REP11A-1
```

Uses A 80, AOG 214, EBANK 80, IT 185, LIFTTEMP 161, PHASE5 152, RESTART 57, T1 241, T2 241, TBASE5 154, TC 169, TEPHEM 172, TIME1 80, TIME2 80, and TLIFTOFF 163.

872 ⟨*Page CM0540* 872⟩≡ (857b 2749)

```
REP11S          2OCT    7776600011

REP11SA         2OCT    7776400013

P11XIT          GENADR  P11OUT
-ERTHRAT        2DEC*   -7.292115138 E-7 B18*   # - EARTH RATE AT 2(18)

                EBANK=  BODY3
P11SCADR        2CADR   VHHDOT

POWDNCOD        EQUALS  THREE

                EBANK=  BODY3
# VHHDOT IS EXECUTED EVERY 2 SECONDS TO DISPLAY ON DSKY
#       VI      INERTIAL VELOCITY MAGNITUDE
#       HDOT    RATE OF CHANGE OF ALT ABOVE L PAD RADIUS
#       H       ALTITUDE ABOVE L PAD RADIUS

VHHDOT          TC      INTPRET
                CALL                    # LOAD VMAGI, ALTI,
                        S11.1           # HDOT FOR DISPLAY
                EXIT
                TC      PHASCHNG
                OCT     00035

                CAF     V06N62          # DISPLAY IN R1 R2   R3
                TC      BANKCALL        #            VI HDOT H
                CADR    REGODSP

ATERTASK        CAF     PRIO1           # ESTABLISH JOB TO DISPLAY ATT ERRORS
                TC      FINDVAC         # COMES HERE AT L.O. + .33 SEC
                EBANK=  BODY3
                2CADR   ATERJOB

                CS      RCSFLAGS        # SET BIT3 FOR
                MASK    BIT3            # NEEDLER
                ADS     RCSFLAGS        # INITIALIZATION PASS
                TC      IBNKCALL        # AND GO
                CADR    NEEDLER         # DO IT
                CA      BIT1            # SET SW
                TS      SATSW           # FOR DISPLAY
                TC      TASKOVER
GETDOWN         STQ     SETPD
                        INCORPEX
                        OD
```

DLOAD

HI6ZEROS

Uses ALT 157, ALTI 231, BODY3 221, EBANK 80, H 177, HDOT 231, HI6ZEROS 71, INCORPEX 177, IT 185, L 80, R2 188, RCSFLAGS 200, SATSW 221, TC 169, and VMAGI 229.

874 ⟨*Page CM0541* 874⟩≡ (857b 2749)

```
                STODL   6D
                        DPHALF
                STCALL  8D
                        LALOTORV +5
# THIS SECTION PROVIDES ATTITUDE ERROR DISPLAYS TO THE FDAI DURING SONE BOOST
#
#       COMPUTE DESIRED PITCH W.R.T. PAD LOCAL VERTICAL AT LIFTOFF
#                         2    3    4    5    6
#       PITCH = A0+A1T+A2T +A3T +A4T +A5T +A6T
#               SCALED TO 32 REVS.                                    -14
#       IF TL = TIME IN SECS FROM L.O., THEN    T = 100(TL-RPSTART0)2
#       WHERE   TL GE RPSTART
#               TL LE (-POLYSTOP + RPSTART)
#       COMPUTE DESIRED ROLL WEHRE ROLL EQUALS ANGLE FROM
#       LAUNCHAZ TO -Z(S/C) AS SEEN FROM X(S/C).
#       ROLL = LAUNCHAZ-AZIMUTH-.5+SATRLRT*T    IN REV
#       SATRLRT = RATE OF ROLL IN REV/CENTI-SEC
#       T, IN CENTI-SEC, IS DEFINED AS ABOVE, INCLUSIVE OF TIME RESTRICTIONS
#
#       FOR SIMPLICITY, LET     P = 2*PI*PITCH
#                               R = 2*PI*ROLL
#
#       CONSTRUCT THE TRANSFORMATION MATRIX, TSMV, GIVING DESIRED S/C AXES IN
#       TERMS OF SM COORDINATES.  LET THE RESULTING ROWS EQUAL THE VECTORS XDC,
#       YDC, AND ZDC.
#
#        *     (    SIN(P)                 0               -COS(P)    )   (XDC)
#       TSMV = (-SIN(R)*COS(P)          -COS(R)         -SIN(R)*SIN(P)) = (YDC)
#              (-COS(R)*COS(P)           SIN(R)         -COS(R)*SIN(P))   (ZDC)
#
#       XDC,YDC,ZDC ARE USED AS INPUT TO CALCGTA FOR THE EXTRACTION OF THE
#       EULER SET OF ANGLES WHICH WILL BRING THE SM INTO THE DESIRED
#       ORIENTATION.  THIS EULER SET, OGC, IGC, AND MGC, MAY BE IDENTIFIED
#       AS THE DESIRED CDU ANGLES.
#
#       (XDC)                   (OGC)
#       (YDC) ---) CALCGTA ---) (IGC)
#       (ZDC)                   (MGC)
#                         _
#       DEFINE THE VECTOR DELTACDU.
#
#        _         (OGC)   (CDUX)
#       DELTACDU = (IGC) - (CDUY)
#                  (MGC)   (CDUZ)
#                                _             _    *    _
```

```
#       COMPUTE ATTITUDE ERRORS, A, WHERE       A = TGSC*DELTACDU
#
#        *     (1             SIN(CDUZ)             0    )   THE GIMBAL ANGLES
```

Uses A 80, AO 145, AZIMUTH 191, CDUX 80, CDUY 80, CDUZ 80, DISPLAYS 59, IGC 186, L 80, LAUNCHAZ 194, MGC 186, OGC 186, P 188, POLYSTOP 221, REVS 206, RPSTART 221, SATRLRT 219, W 183, XDC 186, YDC 186, Z 80, and ZDC 186.

876 ⟨*Page CM0542* 876⟩≡ (857b 2749)

```
#       TGSC = (0       COS(CDUX)*COS(CDUZ)     SIN(CDUX)) = TO SPACECRAFT AXES
#              (0      -SIN(CDUX)*COS(CDUZ)     COS(CDUX))   CONVERSION MATRIX
#
#       THE ATTITUDE ERRORS, Ā, ARE STORED ONE HALF SINGLE PRECISION IN
#       THE REGISTERS AK, AK1, AK2 AS INPUT TO NEEDLER, THE FDAI ATTITUDE
#       ERROR DISPLAY ROUTINE.

ATERJOB         CAE     FLAGWRD6        # CHECK FLAGWRD6
                MASK    OCT60000        # BITS 14, 15
                EXTEND
                BZF     +2              # OK -- CONTINUE
                TC      ENDOFJOB        # STAURN STICK ON -- KILL JOB
                CAF     BIT10           # CHECK IF S/C CONTROL
                EXTEND                  # OF SATURN PANEL
                RAND    CHAN30          # SWITCH IS ON
                EXTEND
                BZF     STRSAT          # IT IS -- GO STEER
                CCS     SATSW           # IT IS NOT -- WAS IT ON LAST CYCLE
                TC      ATTDISP         # NO -- CONTINUE
                TC      ATRESET         # YES -- REINITIALIZE NEEDLER
                TC      ATRESET         # YES -- REINITIALIZE NEEDLER
ATTDISP         CS      RPSTART         # PITCH/ROLL START TIME
                AD      TIME1
                EXTEND
                BZMF    NOPOLY          # IF MINUS THEN ATTITUDE HOLD
                TS      MPAC            # MPAC = TIME1 - RPSTART
                TS      SPOLYARG        # SAVE FOR USE IN ROLL CALCULATION
                AD      POLYSTOP        # NEG PITCHOVER TIME IN CSECS
                EXTEND
                BZMF    +2
                TC      NOPOLY          # GO TO ATTITUDE HOLD
                CA      TIME2
                EXTEND
                BZMF    +2
                TC      NOPOLY          # GO TO ATTITUDE HOLD
                CAE     POLYNUM
                TS      L
                CAF     COEFPOLY        # EVALUATE PITCH POLYNOMIAL
                TC      POWRSERS        # SCALED TO 32 REVOLUTIONS
                CA      ZERO            # RETURN WITH PITCH(32REV)
                TS      MODE            # STORED MPAC, MPAC +1
                TC      INTPRET
                SETPD   SL              # 32(PITCH(32REV)) = PITCH(REV)
                        0
                        5
```

```
                PUSH                    # LET P(RAD) = 2*PI*PITCH(REV)
                GOTO
                        ATTDISP1        # AROUND SETLOC
```

Uses A 80, AK 200, AK1 200, AK2 200, CDUX 80, CDUZ 80, CHAN30 87, FLAGWRD6 117, IT 185, L 80, MODE 145, MPAC 145, P 188, POLYNUM 219, POLYSTOP 221, RAD 219, RPSTART 221, SATSW 221, SAVE 191, SPOLYARG 221, TC 169, TIME1 80, and TIME2 80.

878 ⟨*Page CM0543* 878⟩≡ (857b 2749)

```
#                                   *
#       CONSTRUCT SM TO S/C MATRIX, TSMV

                SETLOC  P11TWO
                BANK                    # 36 IN COL., 34 IN DISK

                COUNT   36/P11

ATTDISP1        COS     DCOMP
                STODL   14D             # -.5*COS(P)
                SIN
                STODL   10D             # .5*SIN(P)
                        ZEROVECS
                STORE   12D             # 0

#       EVALUATE ROLL = LAUNCHAZ-AZIMUTH-.5+SATRLRT*T
                SLOAD   DMP
                        SPOLYARG        # TIME1 - RSPSTART, CSECS B-14.
                        SATRLRT
                SL      DSU
                        14D
                        DPHALF
                DAD     DSU             # ASSUMING X(SM) ALONG LAUNCH AZIMUTH,
                        LAUNCHAZ        # LAUNCHAZ = ANGLE FROM NORTH TO X(SM).
                        AZIMUTH         # AZIMUTH = -ANGLE FROM NORTH TO Z(S/C)
                RTB                     # DETERMINE IF ROLLOUT
                        RLTST           # IS COMPLETED
ATTDISPR        PUSH    COS             # CONTINUE COMPUTING TSMV
                PUSH                    # LET R(RAD) = 2*PI*ROLL(REV)
                DMP     SL1
                        14D
                STODL   22D             # -.5*COS(R)*COS(P)
                DCOMP
                STORE   18D             # -.5*COS(R)
                DMP     SL1
                        10D
                STODL   26D             # -.5*COS(R)*SIN(P)
                SIN     PUSH
                STORE   24D             # .5*SIN(R)
                DMP     SL1
                        14D
                STODL   16D             # -.5*SIN(R)*COS(P)
                DCOMP
                DMP     SL1
                        10D
```

```
                STOVL   20D             # -.5*SIN(R)*SIN(P)
                        10D

#       FROM TSMV FIND THE HALF UNIT VECTORS XDC,YDC,ZDC = INPUT TO CALCGTA
```

Uses AZIMUTH 191, COUNT 142, LAUNCHAZ 194, P 188, P11TWO 69, RAD 219, SATRLRT 219, SPOLYARG 221, TIME1 80, XDC 186, YDC 186, Z 80, and ZDC 186.

880 ⟨*Page CM0544* 880⟩≡ (857b 2749)

```
                UNIT
                STOVL   XDC             # XDC = .5*UNIT(SIN(P),0,-COS(P))
                        16D
                UNIT
                STOVL   YDC             # YDC = .5*UNIT(-SIN(R)*COS(P),-COS(R),
                        22D             #                       -SIN(R)*SIN(P))
                UNIT
                STCALL  ZDC             # ZDC = .5*UNIT(-COS(R)*COS(P),SIN(R),
                        CALCGTA         #                       -COS(R)*SIN(P))

#       CALL CALCGTA TO COMPUTE DESIRED SM ORIENTATION  OGC,IGC, AND MGC
#                                 _          _   _
#       FIND DIFFERENCE VECTOR  DELTACDU = OGC-CDUX
#
#       ENTER HERE IF ATTITUDE HOLD

NOPOLYM         VLOAD   PUSH            #        OGC      IGC
                        OGC             # CHANGE IGC  TO  MGC FOR COMPATIBILITY
                PUSH    CALL            #        MGC      OGC
                        CDUTRIG         # WITH Y,Z,X ORDER OF CDUSPOT
                VLOAD   RTB             #  _         DPHI     OGC-CDUX , PD4
                        2               # DELTACDU = DTHETA = IGC-CDUY , 0
                        V1STO2S         #            DPSI     MGC-CDUZ , 2
                STOVL   BOOSTEMP
                        ZEROVECS
                STOVL   0
                        CDUSPOT
                RTB     RTB
                        V1STO2S
                        DELSTOR
                STODL   10D
                        SINCDUZ
                DMP     SL1
                        0
                DAD     SR2             # CHANGE SCALE OF AK TO 2REVS
                        4
                GOTO
                        ATTDISP2

                SETLOC  P11ONE
                BANK
                COUNT   34/P11

ATTDISP2        STODL   16D             # 16D, .5(DPHI + DTHETA*SIN(CDUZ))
                        COSCDUZ
```

```
DMP     PUSH
        0
DMP     SL1
        COSCDUX
PDDL    DMP
```

Uses AK 200, BOOSTEMP 221, CDUSPOT 152, CDUX 80, CDUY 80, CDUZ 80, COSCDUX 150, COSCDUZ 150, COUNT 142, IGC 186, MGC 186, OGC 186, P 188, P11ONE 69, SINCDUZ 150, XDC 186, YDC 186, Z 80, and ZDC 186.

882 ⟨*Page CM0545* 882⟩≡ (857b 2749)

```
                        SINCDUX
                        2
                DAD     SL1
                STADR
                STODL   17D             # 17D,  .5(DTHETA*COS(CDUX)*COS(CDUZ)
                DMP     SL1             #                       +DPSI*SIN(CDUX))
                        SINCDUX
                PDDL    DMP
                        COSCDUX
                        2
                DSU     SL1
                STADR
                STORE   18D             # 18D,  .5(-DTHETA*SIN(CDUX)*COS(CDUZ)
                TLOAD                   #                       +DPSI*COS(CDUX))
                        16D
                STORE   AK              # STORE ATTITUDE ERRORS IN AK,AK1,AK2
                EXIT

                CA      SATSW
                CCS     A               # CHK TAKEOVER STATUS
                TC      SATOUT          # POS -- DISPLAY ONLY
                TC      AKLOAD          # 0      STORE BIAS
STEERSAT        TC      INTPRET         # NEG    STEER L/V
                TLOAD   TAD
                        BIASAK
                        AK
                STORE   AK              # AKS = AKS - STORED BIAS
                EXIT
                CA      AK
                TC      RESCALES
                TS      AK
                CA      AK1
                TC      RESCALES
                TS      AK1
                CA      AK2
                TC      RESCALES
                TS      AK2
#       DISPLAY ATTITUDE ERRORS ON FDAI VIA NEEDLER

SATOUT          TC      BANKCALL
                CADR    NEEDLER
ATERSET         CAF     OCT31           # DELAY .25 SEC
                TC      BANKCALL        # EXECUTION + DELAY = .56SEC APPROX
                CADR    DELAYJOB
                TC      ATERJOB         # END OF ATT ERROR DISPLAY CYCLE
```

```
AKLOAD          CS      AK              # STORE AKS
                TS      BIASAK          # INTO BIAS
                CS      AK1             # COMPLEMENTED
                TS      BIASAK +1
```

Uses A 80, AK 200, AK1 200, AK2 200, BIAS 211, BIASAK 221, CDUX 80, CDUZ 80, COSCDUX 150, L 80, SATSW 221, SINCDUX 150, TC 169, and V 229.

884 ⟨*Page CM0546* 884⟩≡ (857b 2749)

```
                CS      AK2
                TS      BIASAK +2
                CS      BIT1            # SET SW
                TS      SATSW           # TO STEER
                TC      STEERSAT        # GO STEER
STRSAT          CA      SATSW           # CHECK IF NEDLER
                EXTEND                  # HAS BEEN INITIALIZED
                BZMF    ATTDISP         # YES -- CONTINUE
ATRESET         CS      RCSFLAGS        # NO -- SET
                MASK    BIT3            # INITIALIZATION SW
                ADS     RCSFLAGS        # FOR NEDLER
                TC      BANKCALL        # AND GO
                CADR    NEEDLER         # DO IT
                CAF     REVCNT          # OCT 6
                TC      BANKCALL        # DELAY JOB
                CADR    DELAYJOB        # 60 MS --WAIT TILL IMUERRCNTR ZEROED
                CCS     SATSW           # CHECK SW STATUS
                TC      TAKEON          # POS   STEER INIT.
                TC      +1              # 0     RETURN TO DISPLAY
                CA      BIT1            # NEG   RETURN TO DISPLAY
                TS      SATSW           # SW = DISPLAY ON
                CS      BIT9            # DISABLE
                EXTEND                  # SIVB
                WAND    CHAN12          # TAKEOVER
                TC      SATOUT          # DISPLAY
TAKEON          CAF     BIT9            # ENABLE
                EXTEND                  # SIVB
                WOR     CHAN12          # TAKEOVER
                CA      ZERO            # INDICATE NEEDLER
                TS      SATSW           # WAS INITIALIZED
                TC      SATOUT
S11.1           VLOAD   ABVAL
                        VN
                STOVL   VMAGI           # VI    SCALED 2(7) IN METERS/CSEC
                        RN
                UNIT    DOT
                        VN
                SL1
                STODL   HDOT
                        RPAD
                BOF     VLOAD
                        AMOONFLG
                        EARTHALT
                        RLS
                ABVAL   SR2
```

```
EARTHALT          BDSU
                          36D
                  STORE   ALTI
                  RVQ
DELSTOR           CA      BOOSTEMP
```

Uses AK2 200, ALTI 231, AMOONFLG 97, BIASAK 221, BOOSTEMP 221, CHAN12 87, HDOT 231, IT 185, RCSFLAGS 200, RLS 175, RN 159, SATSW 221, TC 169, VMAGI 229, and VN 159.

886 ⟨*Page CM0547* 886⟩≡ (857b 2749)

```
                EXTEND                  # STORE DELTACDU INTO PDL 0,2,4
                MSU     MPAC
                INDEX   FIXLOC
                TS      0
                CA      BOOSTEMP +1
                EXTEND
                MSU     MPAC +1
                INDEX   FIXLOC
                TS      2
                CA      BOOSTEMP +2
                EXTEND
                MSU     MPAC +2
                INDEX   FIXLOC
                TS      4
                TCF     DANZIG
RLTST           CA      MPAC            # DETERMINE IF ROLLOUT
                EXTEND                  # IS COMPLETED
                MP      SATRLRT +1
                EXTEND
                BZMF    DANZIG          # UNLIKE SIGNS STILL ROLLING
                EXTEND                  # ROLLOUT COMPLETED
                DCA     MBDYTCTL +2     # ZERO OUT ROLL CONTRIBUTION
                DXCH    MPAC
                TC      DANZIG
NOPOLY          TC      INTPRET         # COMES HERE IF
                SETPD   GOTO            # ATTITUDE HOLD
                        0
                        NOPOLYM
COEFPOLY        ADRES   POLYLOC
V06N62          VN      0662
RESCALES        EXTEND                  # RESCALE AK S FOR
                MP      SATSCALE        # NEW HARDWARE
                DDOUBL                  # SCALING FOR
                DDOUBL                  # STEERING
                TC      Q               # SATURN

# SATURN TAKEOVER FUNCTION
# ************************
#
# PROGRAM DESCRIPTION
#
#       MOD NUMBER 1
#       MOD BY ELIASSEN
#
# FUNCTIONAL DESCRIPTION
```

```
#
#       DURING THE COASTING PHASE OF SIVB ATTACHED, THE
#       ASTRONAUT MAY REQUEST SATURN TAKEOVER THROUGH
#       EXTENDED VERB 46 (BITS 13,14 OF DAPDATR1 SET ).
#       THE CMC REGARDS RHC COMMANDS AS BODY-AXES RATE
#       COMMANDS AND IT TRANSMITS THESE TO SATURN AS DC
```

Uses AK 200, BOOSTEMP 221, DAPDATR1 200, FIXLOC 140, IT 185, MPAC 145, POLYLOC 219, Q 80, SATRLRT 219, SATSCALE 221, TC 169, and VN 159.

888 ⟨*Page CM0548* 888⟩≡ (857b 2749)

```
#       VOLTAGES.  THE VALUE OF THE CONSTANT RATE COMMAND
#       IS 0.5 DEG/SEC.  AN ABSENCE OF RHC ACTIVITY RE-
#       SULTS IN A ZERO RATE COMMAND.
#
#       THE FDAI ERROR NEEDLES WILL INDICATE THE VALUE
#       OF THE RATE COMMAND.
#
# CALLING SEQUENCE
#
#       DAPFIG +9D      TC      POSTJUMP
#                       CADR    SATSTKON
#
# SUBROUTINES CALLED
#
#       ENDEXT
#       IBNKCALL
#       STICKCHK
#       NEEDLER
#       T5RUPT
#       RESUME
#
# ASTRONAUT REQUESTS
#
#       ENTRY --  VERB 46 ENTER
#                 (CONDITION -- BITS 13, 14 OF DAPDATR1 SET)
#
#       EXIT --   VERB 48 ENTER (FLASH V06N46)
#                 VERB 21 ENTER AXXXX ENTER WHERE A=0 OR 1
#                 VERB 34 ENTER
#                 VERB 46 ENTER
#
# NORMAL EXIT MODE
#
#       VERB 46 ENTER   (SEE ASTRONAUT ABOVE)
#
# ALARM OR ABORT EXIT MODES
#
#       NONE
#
# OUTPUT
#
#       SATURN RATES IN CDUXCMD, CDUYCMD, CDUZCMD
#
# ERASABLE INITIALIZATION
#
```

```
#       DAPDATR1        (BITS 13, 14 MUST BE SET)
#
# DEBRIS
#
#       CENTRALS
```

Uses A 80, CDUXCMD 80, CDUYCMD 80, CDUZCMD 85, COMMAND 169, DAPDATR1 200, MODE 145, and TC 169.

890 ⟨*Page CM0549* 890⟩≡ (857b 2749)

```
#       CDUXCMD, CDUYCMD, CDUZCMD

                BANK    43
                SETLOC  EXTVERBS
                BANK

                COUNT   23/STTKE
SATSTKON        EXTEND
                DCA     2REDOSAT
                INHINT
                DXCH    T5LOC
                CAF     POSMAX
                TS      TIME5
                CS      FLAGWRD6        # TURN ON BITS 15,14 OF
                MASK    RELTAB11        # FLAGWRD6
                ADS     FLAGWRD6        #       SATSTICK CONTROL OF T5
                TC      IBNKCALL        # ZERO JET CHANNELS IN 14 MS AND THEN
                CADR    ZEROJET         # LEAVE THE T6 CLOCK DISABLED
                RELINT
                TC      GOPIN           # EXIT THUS BECAUSE WE CAME VIA V46

                SBANK=  PINSUPER        # Added RSB 2009
                EBANK=  BODY3
2REDOSAT        2CADR   REDOSAT


                SBANK=  LOWSUPER
                BANK    32
                SETLOC  P11FOUR
                BANK

REDOSAT         LXCH    BANKRUPT        # ALSO COMES HERE FOR RESTARTS
                EXTEND
                QXCH    QRUPT
                CS      RCSFLAGS        # TURN ON BIT3 OF RCSFLAGX
                MASK    BIT3            # FOR
                ADS     RCSFLAGS        # NEEDLER INITIALIZATION
                TC      IBNKCALL
                CADR    NEEDLER         # DISABLE IMU ERR COUNTERS ETC.
                CAF     BIT9            # SIVB
                EXTEND                  # TAKEOVER
                WOR     CHAN12          # ENABLE
                EXTEND                  # SET UP T5 CYCLE
                DCA     2SATSTCK
                DXCH    T5LOC
```

```
                CAF     100MST5         # IN 100 MSECS
                TS      TIME5
                TCF     RESUME          # END OF SATURN STICK INITIALIZATION

#       THIS SECTION IS EXECUTED EVERY 100 MSECS.
```

Uses BANKRUPT 80, BODY3 221, CDUXCMD 80, CDUYCMD 80, CDUZCMD 85, CHAN12 87, COUNT 142, EBANK 80, EXTVERBS 71, FLAGWRD6 117, LOWSUPER 67, P11FOUR 65, PINSUPER 69, QRUPT 80, RCSFLAGS 200, T5LOC 163, TC 169, and TIME5 80.

891 ⟨*Page CM0550* 891⟩≡ (857b 2749)

```
SATSTICK        LXCH    BANKRUPT
                EXTEND
                QXCH    QRUPT

                CAF     2SATSTCK        # SET UP RUPT
                TS      T5LOC           # LO ORDER LOC SET
                CAF     100MST5         # 100 MSECS
                TS      TIME5
                CAF     STIKBITS
                EXTEND
                RXOR    CHAN31          # CHECK IF MAN ROT BITS SAME
                MASK    STIKBITS
                TC      IBNKCALL        # SET RATE INDICES
                CADR    STICKCHK        # FOR PITCH YAW AND ROLL

                INDEX   RMANNDX         # SET SATURN RATES
                CA      SATRATE
                TS      AK              #       ROLL
                INDEX   PMANNDX
                CA      SATRATE
                TS      AK1             #       PITCH
                INDEX   YMANNDX
                CA      SATRATE
                TS      AK2             #       YAW

                TC      IBNKCALL        # FOR SATURN INTERFACE AND FDAI DISPLAY
                CADR    NEEDLER
                TCF     RESUME          # END OF SATURN STICK CONTROL

STIKBITS        OCT     00077
100MST5         DEC     16374
                EBANK=  BODY3
2SATSTCK        2CADR   SATSTICK
```

Uses AK 200, AK1 200, AK2 200, BANKRUPT 80, BODY3 221, CHAN31 87, EBANK 80, LOC 145, PMANNDX 213, QRUPT 80, RMANNDX 213, SATRATE 221, T5LOC 163, TC 169, TIME5 80, and YMANNDX 213.

3.5.2 tpi search

892 ⟨*tpi search* 892⟩≡ (857a)

⟨*Page CM0551* 893⟩
⟨*Page CM0552* 895⟩
⟨*Page CM0553* 897⟩
⟨*Page CM0554* 899⟩
⟨*Page CM0555* 901⟩
⟨*Page CM0556* 903⟩
⟨*Page CM0557* 905⟩
⟨*Page CM0558* 907⟩
⟨*Page CM0559* 909⟩
⟨*Page CM0560* 911⟩
⟨*Page CM0561* 912⟩

893 ⟨*Page CM0551* 893⟩≡ (892 2822)

```
# TPI SEARCH
#
# PROGRAM DESCRIPTION S17.1 AND S17.2
#
# FUNCTIONAL DESCRIPTION
#
# THE TPI SEARCH ROUTINE DETERMINES THE MINIMUM TOTAL VELOCITY TRANSFER TRAJECTORY FROM A GIVEN
# MANEUVER TIME WITHIN THE CONSTRAINT OF A SAFE PERICENTER.  THIS VELOCITY IS THE SUM OF THE IM
# FOR THE TPI AND TPF MANEUVERS.
#
# THE S17.1 ROUTINE EXTRAPOLATES THE STATE VECTORS OF BOTH VEHICLES TO THE TPI TIME AND COMPUTE
# RELATIVE PHASE ANGLE BETWEEN THE VEHICLES, THE ALTITUDE DIFFERENCE (I.E., THE MAGNITUDE DIFFE
# POSITION VECTORS) AND SELECTS A SEARCH SECTOR BASED ON THE SIGN OF THE ALTITUDE DIFFERENCE.
#
# THE S17.2 ROUTINE FURTHER DEFINES THE SEARCH SECTOR BY COMPUTING ANGULAR LIMITS AND USES THE
# SUBROUTINE TO COMPUTE THE SEARCH START AND END TIMES.  THE SEARCH IS THEN MADE IN AN ITERATIV
# LAMBERT SUBROUTINE TO COMPUTE THE VELOCITIES REQUIRED AT TPI TIME AND AT TPF TIME.  EXIT FROM
# IS MADE WHEN SOLUTION CRITERIA ARE MET (NORMAL EXIT) OR AS SOON AS IT IS EVIDENT THAT NO SOLU
# THE SECTOR SEARCHED.
#
# CALLING SEQUENCE
#
#       BOTH ROUTINES ARE CALLED IN INTERPRETIVE CODE AND RETURN VIA QPRET.  S17.1 HAS ONLY A N
#       S17.2 RETURNS VIA QPRET FOR NORMAL EXIT AND TO ALARUMS FOR ERROR EXIT.
#
# SUBROUTINES CALLED
#
#       CSMCONIC
#       LEMCONIC
#       TIMETHET
#       INITVEL

                BANK    36
                SETLOC  P17S1
                BANK

                COUNT   36/TPI

                EBANK=  RACT3

# **** TEMPORARY ****

HPE             2DEC    157420.0 B-29           # EARTH'S MIN. PERICENTER ALTITUDE 85 N.M.

HPL             2DEC    10668.0213 B-29         # MOON'S MIN. PERICENTER ALTITUDE 35000 FT.
```

```
CDSEC           2DEC    40000

CLSEC           2DEC    15000

PIINVERS        2DEC    .3183098862

SEC1THET        2DEC    .1944444444
```

Uses A 80, CODE 140, COUNT 142, EBANK 80, I 206, IT 185, N 206, P17S1 69, QPRET 85, RACT3 234, STATE 138, and THETA 148.

895 ⟨*Page CM0552* 895⟩≡ (892 2822)

```
SEC2THET        2DEC    .9166666667

MANYFEET        2DEC    -1.0 B-2

LIMVEL          2DEC    .6096 E-2 B-7           # 2FPS

DFTMOON         2DEC    .1524 E3 B-29           # 500 FEET

DP-.002         2DEC    0.002

                SETLOC  P17S
                BANK
S17.1           STQ     DLOAD
                        NORMEX
                        TTPI
                STCALL  TDEC1                   # ADVANCE PASSIVE VEHICLE TO TPI
                        LEMCONIC
                CALL
                        LEMSTORE
                DLOAD
                        TTPI
                STCALL  TDEC1                   # ADVANCE ACTIVE VEHICLE TO TPI
                        CSMCONIC
                CALL
                        CSMSTORE
                VLOAD
                        RACT3
                ABVAL   PDVL                    # /RA/ 0D                       PL 2D
                        RPASS3
                UNIT    PDDL                    # UNIT RP 0D                    PL 6D
                BDSU    SET
                        36D                     # /RP/ -/RA/
                        KFLAG                   # OFF = +
                BMN     CLEAR
                        +2
                        KFLAG                   # ON = -
                STOVL   DELHITE
                        0D
                VXV     UNIT
                        VPASS3
                STOVL   E2                      # ALMOST IT SAVE FOR 17.2
                        RACT3
                PUSH    VPROJ
                        E2
                VSL2    BVSU                    # RPA
```

```
UNIT    DOT
        OD
SL1     ACOS
PDVL
VXV     DOT
```

Uses E2 236, IT 185, KFLAG 97, NORMEX 165, P17S 69, RACT3 234, RPASS3 234, SAVE 191, TTPI 236, and VPASS3 234.

897 ⟨*Page CM0553* 897⟩≡ (892 2822)

```
                        RACT3
                        E2
                PDDL    SIGN
                STADR
                STODL   THETZERO                # CENTRAL ANGLE
                        X1
                STCALL  XRS                     # SAVE INDICES FOR FURTHER USE
                        NORMEX                  #   += ACTIVE AHEAD  -= ACTIVE BEHIND
S17.2           STQ     VLOAD                   # COMPUTE SEARCH SECTOR LIMITS
                        QTEMP
                        RACT3
                UNIT    DOT
                        E2
                ABS     SQRT
                SL1     DAD
                        DP-.002                 # ADD .002 RADIANS TO IT
                BON     DCOMP                   # GIVES CORRECT SINE, COSINE MUST BE
                        KFLAG                   # COMP. ADD .5 FOR ANGLE
                        +1
# PHI(0)=180-(-(THETAZERO +K5IT)), PHI(I)=180-(-THETAZERO+K2IT))
# SIN(180-ALPHA)=SIN(ALPHA) ETC
                DMP     SETPD
                        PIINVERS                # REVOLUTIONARY HERES TWO IT
                        OD
                PUSH    DSU
                        THETZERO
                STORE   IT                      # PHI(I) , -(THETZERO + K2IT)
                PDDL    PUSH
                SR1     DAD
                DAD     PUSH                    # PHI(0) , -(THETZERO + K5IT)
                SIN     SET
                        RVSW
                STODL   SNTH
                COS     BMN
                        +2
                DCOMP
                STODL   CSTH
                        XRS
                STOVL   X1
                        RPASS3
                VSR*
                        0,2
                STOVL   RVEC
                        VPASS3
                VSR*
```

```
        0,2
STCALL  VVEC
        TIMETHET
DLOAD                           # SAVE START TIME AND GET END TIME
        T
```

Uses CSTH 188, E2 236, I 206, IT 185, KFLAG 97, NORMEX 165, QTEMP 236, RACT3 234, RPASS3 234, RVEC 188, RVSW 123, SAVE 191, SNTH 188, THETZERO 185, VPASS3 234, VVEC 188, and X1 85.

899 ⟨*Page CM0554* 899⟩≡ (892 2822)

```
                STORE   TF
                STODL   TFO
                        IT
                PUSH    SIN
                STODL   SNTH
                COS     BMN
                        +2
                DCOMP
                STORE   CSTH
                LXA,1   CALL
                        XRS
                        TIMETHET
# INITIALIZE LOOP
                DLOAD   CLEAR
                        T
                        ITSWICH
                STODL   TFI                 # SAVE TIME FOR LOOP TEST
                        DPPOSMAX
                STODL   DELVEE
                        MANYFEET
                STODL   HP
                        SEC1THET            # 70 DEGREES
                BON     DLOAD
                        KFLAG
                        +2
                        SEC2THET            # 330 DEGREES
                STCALL  THETL
                        CONCAUL
BIS             DLOAD   SR1
                        CSTH
                STODL   COSTH
                        SNTH
                SR1
                STCALL  SINTH               # GET 4 QUADRANT THETA
                        ARCTRIG
                BPL     DAD
                        +2
                        DPPOSMAX            # PUT THETA BETWEEN 0,1
                BDSU    PDDL
                        THETL
                        TF
                DSU     SIGN                # FAST TIMES
                        TFI
                BMN
                        RNGETEST            # TIME MUST HAVE A STOP
```

```
# ADVANCE PASSIVE FOR TARGET VECTOR
CONCAUL         DLOAD
                        TTPI
                DAD     BON
                        TF
```

Uses A 80, COSTH 148, CSTH 188, DELVEE 185, HP 185, IT 185, ITSWICH 121, KFLAG 97, SAVE 191, SINTH 148, SNTH 188, TFI 185, TFO 185, THETA 148, and TTPI 236.

901 ⟨*Page CM0555* 901⟩≡ (892 2822)

```
                        AVFLAG
                        ADVCSM
                STCALL  TDEC1
                        LEMCONIC
                GOTO
                        JUNCT3
ADVCSM          STCALL  TDEC1
                        CSMCONIC
# SAVE BACK VALUES OF HP AND DELVEE
JUNCT3          VLOAD
                        VATT
                STOVL   VPASS4
                        RATT
                STORE   RPASS4
                STODL   RTARG
                        TF
                STODL   DELLT4
                        HP
                STODL   HPO
                        DELVEE
                STODL   DELVEO
# PREPARE FOR LAMBERT
                        TTPI
                STODL   INTIME
                        XRS
                STODL   RTX1
                        HI6ZEROS
                SETPD   PDDL
                        OD
                        EPSFOUR
                PDVL
                        RACT3
                STOVL   RINIT
                        VACT3
                STCALL  VINIT
                        INITVEL
# COMPUTE H ET CETERA
                VLOAD   VSU
                        VTPRIME
                        VPASS4
                ABVAL   PUSH
                STOVL   RELDELV                 # /V2-VP(TPI+TF)/
                        DELVEET3                # V1-VA
                ABVAL                           # /V1-VA/
                STORE   MAGVTPI
```

```
DAD     STADR
STODL   DELVEE
        XRS
STOVL   X1
        VIPRIME
```

Uses AVFLAG 105, DELLT4 224, DELVEE 185, DELVEET3 236, DELVEO 185, H 177, HI6ZEROS 71, HP 185, HPO 185, INTIME 236, MAGVTPI 185, RACT3 234, RELDELV 185, RINIT 234, RPASS4 236, RTARG 224, SAVE 191, TTPI 236, V1 145, VACT3 234, VINIT 234, VIPRIME 234, VPASS4 236, VTPRIME 234, and X1 85.

903 ⟨*Page CM0556* 903⟩≡ (892 2822)

```
                VSR*
                        0,2
                STOVL   VVEC
                        RACT3
                VSR*
                        0,2
                STCALL  RVEC
                        PERIAPO
                LXA,2   DLOAD
                        XRS     +1
                SL*
                        0,2
                STORE   HP
# ITSWICH DENOTES INTERPOLATION -- SOLUTION ACCEPTANCE IS FORCED
                BON     DLOAD
                        ITSWICH
                        ENDEN
                        HPERMIN
                DSU     BMN
                        HP
                        HALFSAFE
                PDDL    DSU                     # WAS PERICENTER ALT SAFE
                        HPERMIN
                        HPO
                BMN     DSU                     # (HPLIM-HPO)-(HPLIM-HP)=HP-HPO
                        INTERP                  # SOLUTION AT HAND
                BMN     DLOAD
                        ALARUMS                 # IT'S GETTING WORSE -- SOUND THE ALARM
                        CDSEC
JUNCT1          BOFF    DCOMP                   # OFF IS PLUS, ON IS MINUS
                        KFLAG
                        +1
                STORE   DELTEE
JUNCT2          DLOAD   DAD
                        DELTEE
                        TF
                STCALL  TF
                        BIS                     # RECYCLE
INTERP          SET     DSU                     # HP-HPO
                        ITSWICH
                NORM    PDDL
                        X1
                        DFTMOON
                DAD     DSU
                        HPERMIN
```

```
        HP
NORM    SR1
        X2
XSU,2   DDV
        X1
```

Uses ALT 157, HP 185, HPERMIN 179, HPO 185, ITSWICH 121, KFLAG 97, RACT3 234, RVEC 188, VVEC 188, X1 85, and X2 85.

905 ⟨*Page CM0557* 905⟩≡ (892 2822)

```
                DMP     SR*
                        DELTEE
                        0       -1,2
                STCALL  DELTEE
                        JUNCT2
HALFSAFE        PDDL    DSU                     # SAVE HP-HPLIM FOR POSSIBLE
                        DELVEE
                        DELVEO                  # SAVE THIS TOO
                PUSH    ABS
                DSU     BMN
                        LIMVEL                  # 2 FT PS
                        ENDEN
                DLOAD   DSU
                        HPERMIN
                        HPO
                PDDL
                BMN     DLOAD
                        LRGRDVO
                BPL     DLOAD
                        INTERP
                        DELTEE
                SR1     DCOMP
                STCALL  DELTEE
                        JUNCT2
LRGRDVO         DLOAD
                BMN     DLOAD
                        JUNCT2
                        CLSEC
                GOTO
                        JUNCT1
# TIME RAN OUT ASSUME SOLUTION IF SAVE PERICENTER
RNGETEST        DLOAD   DSU
                        HP
                        HPERMIN
                BMN     DLOAD
                        ALARUMS
                        TF
                DSU
                        DELTEE
                STORE   TF                      # TIME OF SOLUTION
ENDEN           VLOAD
                        VTPRIME
                DOT     PDDL                    # SG2 WITH MAGNITUDE
                        RPASS4
                        RELDELV
```

```
SIGN    STADR                   # NOW SIGN(RELDELV)=SIGN(SG2)
STCALL  RELDELV
        TRANSANG                # COMPUTE OMEGA T, CENTRAL ANGLE
VLOAD   DOT
        RACT3
```

Uses DELVEE 185, DELVEO 185, HP 185, HPERMIN 179, HPO 185, OMEGA 232, RACT3 234, RELDELV 185, RPASS4 236, SAVE 191, SR 80, and VTPRIME 234.

907 ⟨*Page CM0558* 907⟩≡ (892 2822)

```
                        VIPRIME                 # SG1
                SIGN    BPL                     # IF POSITIVE THEN SG1 = SG2 OTHERWISE
                        RELDELV
                        USEKAY                  # SIGN(SG2-SG1)=SIGN(SG2)=SIGN(RELDELV)
                SLOAD   DCOMP
                        DECTWO
                SIGN    BPL
                        RELDELV
                        NEXUS
                DCOMP   GOTO
                        USEKAY  +4
USEKAY          SLOAD   BON
                        DECTWO
                        KFLAG
                        NEXUS
                DSU
                        P21ONENN
NEXUS           STODL   NN1
                        HP
                STCALL  POSTTPI
                        QTEMP
                BANK    07
                SETLOC  XANG
                BANK
                COUNT   07/XANG

# CENTRAL ANGLE SUBROUTINE
#
# THIS SUBROUTINE COMPUTES THE CENTRAL ANGLE OF TRAVEL OF THE
# PASSIVE VEHICLE DURING THE TRANSFER.

TRANSANG        STQ     SETPD
                        SUBEXIT
                        0
                LXA,1   LXA,2
                        XRS
                        XRS     +1
                VLOAD   VSR*
                        VPASS4
                        0,2
                STODL*  VVEC
                        MUTABLE +2,1
                PDVL    VSR*                    # SQRT MU (+18 OR +15)                 00D
                        RPASS4
                        0,2
```

```
ABVAL   PDDL*                   # MAGNITUDE OF R        (+29 OR +27)
        MUTABLE,1
PDVL    VSQ                     # 1/MU                   (+34 OR +28)
        VVEC
NORM    DMPR                    # PUSH LIST AT O2D
        X1
```

Uses COUNT 142, HP 185, KFLAG 97, NN1 241, POSTTPI 183, QTEMP 236, RELDELV 185, RPASS4 236, SUBEXIT 181, VIPRIME 234, VPASS4 236, VVEC 188, X1 85, and XANG 59.

909 ⟨*Page CM0559* 909⟩≡ (892 2822)

```
                DMP     SRR*
                        02D
                        0       -3,1
                BDSU                            # R V**/MU             (+6)
                        D1/32
                NORM    PDDL
                        X1                      # (2 - R V**/MU)        (+6-N)
                SR1R    DDV                     # MAGNITUDE OF R        (+30 OR +28)
                SL*     PUSH                    # R/(2 - R V**/MU)      (+29 OR +27)    02D
                        0       -5,1
                SR1     SQRT
                DMP
                NORM    PDDL                    # ASUBP***                              00D
                        X1
                SR1     DDV
                DMP     SL*
                        TF
                        0,1
                PDDL    NORM
                        2PISC
                        X1
                PDDL    DDV
                SL*
                        0       -3,1            # CENTANG = (SQRT(MU/ASUP***)TF)
                STCALL  CENTANG                 # IN REVOLUTIONS B-0
                        SUBEXIT
                BANK    35
                SETLOC  P17S1
                BANK
                COUNT   35/P17

# TPI SEARCH DISPLAY ROUTNE

P17             TC      AVFLAGA                 # AVFLAG = CSM, SET TRACK + UPDATE FLAGS
                TC      P17.1
P77             TC      AVFLAGP                 # AVFLAG = LEM, SET TRACK + UPDATE FLAGS
P17.1           TC      P20FLGON                #       SET UPDATE FLAG
                CAF     V06N37                  #       DISPLAY TTPI TIME
                TC      VNP00H
                TC      INTPRET
                CLEAR   CALL
                        UPDATFLG
                        S17.1                   # UPDATE STATE VECTORS TO TTPI
                SET     AXT,1
                        UPDATFLG
```

```
                DEC     2                       # DELTA H = 2 K POSITIVE, KFLAG OFF
                BOFF    AXT,1
                        KFLAG
                        +2
                DEC     1                       # DELTA H = 1 K NEGATIVE, KFLAG ON
```

Uses AVFLAG 105, COUNT 142, H 177, KFLAG 97, N 206, P17S1 69, STATE 138, SUBEXIT 181, TC 169, TTPI 236, UPDATFLG 99, V 229, and X1 85.

911 ⟨*Page CM0560* 911⟩≡ (892 2822)

```
                SXA,1   EXIT
                        OPTION2
                CAF     V06N72              # DISPLAY PHI, DELTA H, SEARCH OPTION K
                TC      VNCOMP17
                TC      INTPRET
                CLEAR   SET
                        UPDATFLG
                        KFLAG
                SLOAD   DSU
                        OPTION2             # RESET KFLAG ON FOR OPTION =1
                        P21ONENN            #            OFF FOR OPTION =2
                BHIZ    CLEAR
                        +2
                        KFLAG
                SLOAD   BHIZ
                        XRS     +1
                        +4
                DLOAD   GOTO
                        HPL
                        P17.2
                DLOAD
                        HPE
P17.2           STCALL  HPERMIN
                        S17.2
                SET     EXIT
                        UPDATFLG
P17.3           CAF     V06N58              # DISPLAY DELTA VTPI, DELTA VTPF, AND H
                TC      VNCOMP17
                CAF     V06N55              # DISPLAY PERICENTER CODE AND CENTRAL ANG,
                TC      BANKCALL
                CADR    GOFLASHR
                TC      GOTOP00H            # TERMINATE PROGRAM
                TC      GOTOP00H            # END PROGRAM
                TC      P17.1               # RECYCLE WITH NEW TTPI OR SEARCH OPTION
                CAF     TWO                 # BLANK R2
                TC      BLANKET
                TCF     ENDOFJOB
                EBANK=  RTRN

VNCOMP17        EXTEND
                QXCH    QSAVED
                TS      VERBNOUN
                CA      VERBNOUN
                TCR     BANKCALL
                CADR    GOFLASH
```

```
                TC      -3                      # TERMINATE ILLEGAL REDISPLAY
                TC      QSAVED                  # PROCEED
                CS      MPAC                    # RECYCLE WITH NEW TPI TIME
                AD      BIT6                    # OR PROCEED WITH NEW SEARCH OPTION
                EXTEND
```

Uses CODE 140, EBANK 80, H 177, HPERMIN 179, KFLAG 97, MPAC 145, OPTION2 157, QSAVED 181, R2 188, RTRN 181, TC 169, TTPI 236, UPDATFLG 99, and VERBNOUN 181.

912 ⟨*Page CM0561* 912⟩≡ (892 2822)

```
                BZF     P17.1
                TC      VNCOMP17 +3
  ALARUMS       SET     EXIT
                        UPDATFLG
                TC      ALARM
                OCT     00124                   # NO SAFE PERICENTER IN THIS SECTOR
                CAF     V05N09
                TC      VNCOMP17
                TC      GOTOP00H                # PROCEED ILLEGAL TERMINATE PROGRAM
  V06N72        VN      0672
```

Uses TC 169, UPDATFLG 99, and VN 159.

3.5.3 p20 p25 code

913 ⟨*p20 p25 code* 913⟩≡ (857a)

⟨*Page CM0562* 915⟩
⟨*Page CM0563* 917⟩
⟨*Page CM0564* 918⟩
⟨*Page CM0565* 919⟩
⟨*Page CM0566* 921⟩
⟨*Page CM0567* 923⟩
⟨*Page CM0568* 925⟩
⟨*Page CM0569* 926⟩
⟨*Page CM0570* 927⟩
⟨*Page CM0571* 929⟩
⟨*Page CM0572* 930⟩
⟨*Page CM0573* 932⟩
⟨*Page CM0574* 934⟩
⟨*Page CM0575* 936⟩
⟨*Page CM0576* 937⟩
⟨*Page CM0577* 938⟩
⟨*Page CM0578* 939⟩
⟨*Page CM0579* 941⟩
⟨*Page CM0580* 943⟩
⟨*Page CM0581* 945⟩
⟨*Page CM0582* 947⟩
⟨*Page CM0583* 949⟩
⟨*Page CM0584* 951⟩
⟨*Page CM0585* 953⟩
⟨*Page CM0586* 955⟩
⟨*Page CM0587* 957⟩
⟨*Page CM0588* 959⟩
⟨*Page CM0589* 960⟩
⟨*Page CM0590* 961⟩
⟨*Page CM0591* 963⟩
⟨*Page CM0592* 965⟩
⟨*Page CM0593* 967⟩
⟨*Page CM0594* 969⟩
⟨*Page CM0595* 971⟩
⟨*Page CM0596* 973⟩
⟨*Page CM0597* 975⟩
⟨*Page CM0598* 977⟩
⟨*Page CM0599* 979⟩
⟨*Page CM0600* 981⟩
⟨*Page CM0601* 983⟩
⟨*Page CM0602* 985⟩
⟨*Page CM0603* 987⟩
⟨*Page CM0604* 989⟩

⟨*Page CM0605* 991⟩
⟨*Page CM0606* 993⟩
⟨*Page CM0607* 995⟩
⟨*Page CM0608* 997⟩
⟨*Page CM0609* 999⟩
⟨*Page CM0610* 1001⟩
⟨*Page CM0611* 1003⟩
⟨*Page CM0612* 1005⟩
⟨*Page CM0613* 1007⟩
⟨*Page CM0614* 1009⟩
⟨*Page CM0615* 1010⟩
⟨*Page CM0616* 1011⟩
⟨*Page CM0617* 1013⟩
⟨*Page CM0618* 1014⟩
⟨*Page CM0619* 1015⟩
⟨*Page CM0620* 1017⟩
⟨*Page CM0621* 1019⟩
⟨*Page CM0622* 1021⟩
⟨*Page CM0623* 1023⟩
⟨*Page CM0624* 1024⟩
⟨*Page CM0625* 1025⟩
⟨*Page CM0626* 1027⟩
⟨*Page CM0627* 1029⟩
⟨*Page CM0628* 1031⟩
⟨*Page CM0629* 1033⟩
⟨*Page CM0630* 1035⟩
⟨*Page CM0631* 1037⟩
⟨*Page CM0632* 1039⟩
⟨*Page CM0633* 1041⟩
⟨*Page CM0634* 1042a⟩

915 ⟨*Page CM0562* 915⟩≡ (913 2752)

```
# RENDEZVOUS NAVIGATION PROGRAM 20
#
# PROGRAM DESCRIPTION
#
#       MOD NO -- 1
#       MOD BY -- N. BRODEUR
#
# FUNCTIONAL DESCRIPTION
#
#       TO CONTROL THE CSM ATTITUDE AND OPTICS TO ACQUIRE THE LEM IN THE S+T
#       FIELD AND TO POINT THE CSM TRANSPONDER AT THE LEM.  TO UPDATE EITHER THE
#       LEM OR CSM STATE VECTOR (AS SPECIFIED BY THE ASTRONAUT BY THE DSKY
#       ENTRY) ON THE BASIS OF OPTICAL TRACKING DATA (REQUESTED BY DSKY)
#
# CALLING SEQUENCE --
#
#       ASTRONAUT REQUEST THROUGH DSKY V37E20E
#
# SUBROUTINES CALLED
#
#       R02BOTH (IMU STATUS CHECK)                              BANKCALL
#       FLAGUP                          2PHCHNG                 LOADTIME
#       R61CSM (PREFERRED TRACKING ATTITUDE)                    FLAGDOWN
#       R52 (AUTO OPTICS POSITIONING ROUT)                      SETINTG
#       R22 (REND TRACK DATA PROC ROUT)                         PRIOCHNG
#       ENDOFJOB                        INTEGRV                 GRP2PC
#       INTPRET                         MKRLEES                 FINDVAC
#
# NORMAL EXIT MODES --
#
#       P20 MAY BE TERMINATED IN TWO WAYS -- ASTRONAUT SELECTION OF IDLING
#       PROGRAM (P00) BY KEYING V37E00E OR BY KEYING IN V56E
#
# ALARM OR ABORT EXIT MODES --
#
#       NONE DIRECTLY FROM P20
#
# OUTPUT
#
#       TRKMKCNT = NO OF RENDEZVOUS TRACKING MARKS TAKEN (COUNTER)
#       VHFCNT = NO OF VHF RANGING MARKS INCORPORATED (COUNTER)
#
# FLAGS SET + RESET
#
#       RNDVZFLG,VEHUPFLG,UPDATFLG,TRACKFLG,TARG1FLG
```

```
#       HOLDFLAG,WBODY,WBODY1,WBODY2,DELCDUX,DELCDUY,DELCDUZ
#       STIKFLAG,PRFTRKAT,VINTFLAG,DIMOFLAG,R60FLAG,R61CNTR

                BANK    33
                SETLOC  P20S
                BANK

                EBANK=  ESTROKER
                COUNT*  $$/P20

PROG20          TC      BANKCALL
                CADR    R02BOTH         # IMU STATUS CHECK
                                        # BLOCKING OF UPLINK IS DONE BY UPLINK PRG
                CAF     ZERO
                TS      TRKMKCNT        # ZERO REND TRACKING MARK COUNTER
                TS      VHFCNT          # ZERO REND VHF RNG MRK COUNTER
                TC      UPFLAG          # SET PREF TRACK ATT FLAG
                ADRES   PRFTRKAT        # BIT 10 FLAG 5
                TC      DOWNFLAG        # LEM TO BE UPDATED.  VEHUPFLG RESET.
                ADRES   VEHUPFLG        # BIT 8 FLAG 1
```

Uses COUNT 142, DELCDUX 211, DELCDUY 211, DELCDUZ 211, DIMOFLAG 109, EBANK 80, ESTROKER 198, HOLDFLAG 163, N 206, P20S 69, PRFTRKAT 115, R60FLAG 115, R61CNTR 223, RNDVZFLG 97, STATE 138, STIKFLAG 99, TARG1FLG 99, TC 169, TRACKFLG 101, TRKMKCNT 157, UPDATFLG 99, VEHUPFLG 99, VHFCNT 157, VINTFLAG 109, WBODY 209, WBODY1 209, and WBODY2 209.

917 ⟨*Page CM0563* 917⟩≡ (913 2752)

```
                TC      UPFLAG          # SET TRACKFLAG
                ADRES   TRACKFLG        # BIT 5 FLAG 1
                TC      UPFLAG          # SET UPDATFLG
                ADRES   UPDATFLG        # BIT 7 FLAG 1
                TC      UPFLAG          # SET RNDVZFLG
                ADRES   RNDVZFLG        # BIT 7 FLAG 0
                TC      2PHSCHNG
                OCT     4
                OCT     05022
                OCT     26000
                TC      INTPRET
                RTB
                        LOADTIME
                STCALL  MARKTIME
                        SETINTG         # SET INTEGRATION FLAGS
                BOFF    SET
                        RENDWFLG
                        P20.1
                        DIMOFLAG        # SET TO INTEGRATE THE W MATRIX
P20.1           BON     CLEAR
                        VEHUPFLG
                        P20.2
                        VINTFLAG        # SET FOR LM INTEGRATION
P20.2           CALL
                        INTEGRV
                CALL
                        GRP2PC          # GROUP 2 PHASE CHANGE
                CALL
                        SETINTG         # SET INTEGRATION FLAGS
                BOFF    CLEAR
                        VEHUPFLG
                        P20.3
                        VINTFLAG        # SET FOR LM INTEGRATION
P20.3           CALL
                        INTEGRV
                EXIT
                CAF     PRIO26
                TC      FINDVAC
                EBANK=  MRKBUF2
                2CADR   R22

                TC      2PHSCHNG
                OCT     00072
                OCT     00111
PIKUP20         CAF     PRIO14          # ALLOW HIGHER PRIO THAN LAMBERT
```

```
                TC      PRIOCHNG
                CAF     BIT5            # IS TRACK FLAG SET
                MASK    STATE   +1
                EXTEND
                BZF     ENDOFJOB        # NO
```

Uses DIMOFLAG 109, EBANK 80, MARKTIME 161, RENDWFLG 117, RNDVZFLG 97, STATE 138, TC 169, TRACKFLG 101, UPDATFLG 99, VEHUPFLG 99, VINTFLAG 109, and W 183.

918 ⟨*Page CM0564* 918⟩≡ (913 2752)

```
                CAF     BIT13
                MASK    STATE   +3      # IS REFSMFLG SET
                EXTEND
                BZF     ENDOFJOB
                CAF     ZERO
                TS      R61CNTR         # INITIALIZE R61 COUNTER
                TC      BANKCALL
                CADR    R61CSM
                EBANK=  QMIN
                CAF     EBANK5
                TS      EBANK
                TC      UPFLAG          # SET TARGET FLAG TO LEM
                ADRES   TARG1FLG        # BIT 10 FLAG 1
P20R52JB        TC      INTPRET
                CALL
                        R52             # SET UP AUTO OPTICS JOB
                EXIT
                TC      BANKCALL
                CADR    MKRLEES
                CAF     ONE             # HOLD PRESENT ATTITUDE
                TS      HOLDFLAG
                TC      ENDOFJOB
OCT203          OCT     00203
FIRST3          EQUALS  FURST3
```

Uses EBANK 80, HOLDFLAG 163, QMIN 186, R61CNTR 223, REFSMFLG 107, STATE 138, TARG1FLG 99, and TC 169.

919 ⟨*Page CM0565* 919⟩≡ (913 2752)

```
# ORBITAL NAVIGATION PROGRAM 22

                BANK    31
                SETLOC  P20S1
                BANK

                EBANK=  LANDMARK
                COUNT*  $$/P22

PROG22          TC      DOWNFLAG        # RESET RNDVZFLG BIT 7 FLAG 0
                ADRES   RNDVZFLG
                TC      BANKCALL
                CADR    R02BOTH         # IMU STATUS CHECK
                TC      INTPRET         # COMPUTE ANGLE BETWEEN Y AND VXR SM
                RTB
                        LOADTIME
                STCALL  TDEC1
                        CSMCONIC        # INTEGRATE TO PRESENT TIME
                VLOAD   VXV             # CROSS PRODUCT BETWEEN V AND R
                        VATT
                        RATT
                UNIT    DOT
                        REFSMMAT +6
                ABS
                SL1     ARCCOS
                STORE   +MGA
                CLEAR   EXIT
                        RENDWFLG
                CAF     V06N45B
                TC      BANKCALL
                CADR    GOFLASHR
                TC      GOTOP00H        # TERM P22
                TC      PROG22A         # PROC
                TC      -5              # ENTER
                CAF     THREE
                TC      BLANKET         # BLANK OUT R1 + R2
                TC      ENDOFJOB
PROG22A         CS      PRIO7           # RESULT=70777  SET OFFSET NO.=0
                MASK    LANDMARK
                TS      LANDMARK
                TC      INTPRET
                CLEAR
                        P22MKFLG
                SET     BOFF
                        ERADFLAG
```

```
        CMOONFLG
        PROG22B         # EARTH
SET                     # MOON
        LUNAFLAG
DLOAD   CALL            # MPAC=V05N70,MPAC+1=NONZERO FOR N70
        V05N7022
```

Uses +MGA 234, CMOONFLG 125, COUNT 142, EBANK 80, ERADFLAG 99, LANDMARK 190, LUNAFLAG 107, MPAC 145, ORBITAL 59, P20S1 67, P22MKFLG 107, R2 188, REFSMMAT 172, RENDWFLG 117, RNDVZFLG 97, TC 169, and V 229.

921 ⟨*Page CM0566* 921⟩≡ (913 2752)

```
                        S22N7071
                GOTO
                        CALLR52
PROG22B         CLEAR   SET             # EARTH ORBIT
                        LUNAFLAG
                        KNOWNFLG
                CALL                    # GET LAT/LONG/ALT FROM ASTRO
                        P22SUBRB
CALLR52         EXIT
                TC      2PHSCHNG
                OCT     00004
                OCT     05022
                OCT     13000
                CAF     FIVE
                TS      MARKINDX        # SET MARK INDEX=5 FOR R52
                TC      UPFLAG
                ADRES   TARG2FLG        # SET FOR SIGHTING LMK
                TC      DOWNFLAG
                ADRES   TARG1FLG        # CLEAR FOR NON-LEM
                TC      INTPRET
                CALL
                        R52
DOV5N71         SLOAD   CALL            # MPAC=V05N71,MPAC+1=0 FOR N71
                        V05N7122
                        S22N7071
PROG22C         LXC,2   SLOAD*
                        MARKSTAT
                        QPRET,2
                STCALL  8NN
                        S22.1           # ESTABLISH LANDMARK -- COMPUTE ORBITAL
P22OVER         EXIT
                TC      PHASCHNG
                OCT     04022
                TC      PROG22A         # POINT A ON GSOP
V06N45B         VN      0645
V05N7022        VN      00570
V05N7122        VN      00571
                SETLOC  P20S
                BANK

                SETLOC  P20S1
                BANK

S22LSITE        RTB                     # CONVERT RLS FROM MOON-FIXED TO BASIC REF
                        LOADTIME
```

```
STOVL   6D              # 6-7D= TIME
        RLS
STODL   0D              # 0-5D= LANDING SITE VECTOR
        HIDPHALF        # MPAC= ANY NON-ZERO FOR MOON
CALL
```

Uses 8NN 190, A 80, ALT 157, HIDPHALF 71, KNOWNFLG 119, LANDMARK 190, LAT 157, LONG 157, LUNAFLAG 107, MARKINDX 145, MARKSTAT 163, MPAC 145, ORBITAL 59, P20S 69, P20S1 67, QPRET 85, RLS 175, TARG1FLG 99, TARG2FLG 99, TC 169, and VN 159.

923 ⟨*Page CM0567* 923⟩≡ (913 2752)

```
                        RP-TO-R         # RLS IN BASIC REF B-27 IN MPAC
                VSR2                    # LUNAFLAG AND ERADFLAG SET ABOVE
                STORE   ALPHAV          # SCALE RLS B-29 FOR LAT-LONG
                RTB
                        LOADTIME        # SET PRESENT TIME IN MPAC FOR LAT-LONG
                CALL
                        LAT-LONG
                GOTO
                        S22TOFF         # EXIT
OBTAINLL        CALL                    # GET LAT/LONG/ALT FROM ASTRO
                        P22SUBRB
                GOTO
                        S22TOFF         # EXIT
P22SUBRB        STQ     EXIT            # GET LAT/LONG/ALT FROM ASTRO
                        S22TOFF +1
                CAF     V06N89B
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H        # TERMINATE
                TC      +2              # PROCEED
                TC      -5              # ENTER OR RECYCLE
                TC      INTPRET
                DLOAD   ABS             # TEST LAT/LONG GREATER THAN 90
                        LANDLAT
                BDSU    BMN             # 1/4 REV - LAT
                        DP1/4TH
                        N89ERRX
                DLOAD   ABS
                        LANDLONG
                BDSU    BPL
                        DP1/4TH
                        +4

N89ERRX         EXIT
                TC      FALTON
                TC      P22SUBRB +2     # LONG GR. THAN 90  REDISPLAY
                CALL
                        LLASRDA
                GOTO
                        S22TOFF +1      # EXIT
S22N7071        STORE   8KK             # 8KK=V05N71,V05N70 8KK+1=0 N71, NOT 0 N70
                STQ     EXIT
                        S22TOFF
S22DSPPA        CA      8KK             # V05N70 OR V05N71
                TC      BANKCALL
```

```
CADR    GOFLASHR
TC      GOTOP00H        # V34E TERMINATE
TC      +5              # V33E PROCEED
TC      -5              # V32E RECYCLE
CAF     FIVE            # IMMEDIATE RETURN BLANK OUT R1,R3
TC      BLANKET
```

Uses 8KK 190, ALPHAV 177, ALT 157, ERADFLAG 99, LANDLAT 157, LANDLONG 181, LAT 157, LONG 157, LUNAFLAG 107, MPAC 145, RLS 175, S22TOFF 239, and TC 169.

925 ⟨*Page CM0568* 925⟩≡ (913 2752)

```
                TC      ENDOFJOB
                CA      LANDMARK
                MASK    PRIO7           # 07000
                TS      CXOFF           # 08000 = OFFSET INDICATOR
                CS      PRIO5           # 5 8-5
                AD      CXOFF
                EXTEND
                BZMF    +2              # OFF=0 THRU 5 OK
                TC      S22DSPP         # OFF=6.7 ILLEGAL REDISPLAY
                TC      DOWNFLAG
                ADRES   KNOWNFLG        # CLEAR KNOWNFLG
                CA      LANDMARK        # MASK A FROM ABCDE
                MASK    13,14,15
                EXTEND
                BZMF    S22DSPP         # A=0,4,5,6,7  ILLEGAL REDISPLAY
                TS      22SUBSCL        # TEMP
                CS      BIT14
                AD      22SUBSCL
                CCS     A
S22DSPP         TC      FALTON          # + A=3 ILLEGAL REDISPLAY
                TC      S22DSPPA        # COMMON ERROR EXIT BACK TO DISPLAY
                TC      +2              # - A=1 KNOWN LMK  CHECK DE
                TC      S22ABDE         # -0 A=2 UNKNOWN LMK, DE MEANINGLESS
                TC      UPFLAG
                ADRES   KNOWNFLG        # SET KNOWNFLG
                CS      HIGH9           # RESULT= 00077
                MASK    LANDMARK
                TS      22SUBSCL        # 000DE
                CS      BIT1
                AD      22SUBSCL
                EXTEND
                BZMF    S22ABDE         # DE=0,1 OK FOR BOTH N70,N71
                CA      8KK     +1      # =0 FOR N71, NOT =0 FOR N70
                EXTEND
                BZF     S22DSPP         # N71 REDISPLAY  DE MUST= 0 OR 1
                CA      BIT5            # N70 TEST DE= 50-57 OCTAL FOR ADV. ORBIT
                AD      OCT50           # SUM=00070
                MASK    22SUBSCL        # 00D0
                CS      A
                AD      OCT50
                EXTEND
                BZF     DE-GR-50        # D=5 OR DE=50-57, OK FOR N70
                TC      S22DSPP         # DE NOT 50-57  ILLEGAL, REDISPLAY
S22ABDE         TC      INTPRET
                BOFF    SLOAD
```

```
                        KNOWNFLG        # UNKNOWN LMK, DE MEANINGLESS
                        S22TOFF
                        22SUBSCL        # =0 GET LLA FROM ASTRO, NOT=0 USE RLS
                BHIZ    GOTO
                        OBTAINLL        # GET LAT/LONG/ALT FROM ASTRO  N89
```

Uses 22SUBSCL 190, 8KK 190, A 80, ALT 157, CXOFF 190, D 226, KNOWNFLG 119, LANDMARK 190, LAT 157, LONG 157, RLS 175, S22TOFF 239, TC 169, and TEMP 191.

926 ⟨*Page CM0569* 926⟩≡ (913 2752)

```
                        S22LSITE        # GET LAT/LONG/ALT FROM RLS
DE-GR-50        TC      2PHSCHNG
                OCT     00004
                OCT     05022
                OCT     13000
                CA      FIVE
                TS      MARKINDX
                TC      UPFLAG
                ADRES   TARG2FLG
                TC      DOWNFLAG
                ADRES   TARG1FLG
                TC      INTPRET
                CALL
                        ADVORB
                GOTO
                        DOV5N71
```

Uses ALT 157, LAT 157, LONG 157, MARKINDX 145, RLS 175, TARG1FLG 99, TARG2FLG 99, and TC 169.

927 ⟨*Page CM0570* 927⟩≡ (913 2752)

```
# PROGRAM NAME:  OPTICS CALIBRATION ROUTINE
# MOD NO:  1
# MOD BY:  TOM KNATT
#
# FUNCTIONAL DESCRIPTION:  TO MEASURE THE EFFECT OF SOLAR RADIATION ON
#       THE SXT TRUNNON ANGLE AND STORE THE MEASURED TRUNNION BIAS FOR P23
#
# CALLING SEQUENCE:     CALL
#                               R57
#
# SUBROUTINES CALLED:  DISPLAY ROUTINES
#
# NORMAL EXIT MODES:  VIA EGRESS
#
# ALARMS:  NONE
#
# ABORT MODES:  P23 ABORT IF MARKING SYSTEM OR EXTENDED VERB ACTIVE
#
# INPUT:  NONE REQUIRED, NORMALLY CALLED BY P23
#
# OUTPUT:  TRUNNION BIAS ANGLE: ANGLE DETERMINED WHEN SHAFT LINE OF SIGHT
#       (SLOS) AND LANDMARK LINE OF SIGHT (LLOS) ARE SUPERIMPOSED.  THIS ANGLE
#       MAY NOT BE EXACTLY ZERO BECAUSE OF UNEVEN HEATING OF THE OPTICS, FOR
#       EXAMPLE.
#
# ERASABLE INITIALIZATION REQUIRED:  MRKBUF1, EXTVBACT
#
# DEBRIS:  RUPTREGS USED BY MARKRUPT AND ERASABLES USED BY DISPLAYS.

                BANK    33
                SETLOC  P20S
                BANK
                COUNT*  $$/R57
                EBANK=  MRKBUF1
R57             STQ     EXIT
                        EGRESS
                CAF     EBANK7
                TS      EBANK
                CAF     SIX             # BIT2 = MARKING SYSTEM IN USE
                MASK    EXTVBACT        # BIT3 = EXTENDED VERB IN PROGRESS
                CCS     A
                TC      P23ABRT         # SET, THEREFORE ABORT
                CAF     BIT2            # NOT SET
                ADS     EXTVBACT        # SET IT
R57A            TC      UPFLAG          # SET V59FLAG (BIT 12 FLAG 5 TO INDICATE
```

```
ADRES   V59FLAG         # CALIBRATION MARK
CAF     V59NB
TC      BANKCALL
CADR    GOMARKFR
TC      GOTOP00H        # TERMINATE
TC      ENDR57
TC      ENDR57
CAF     SEVEN
```

Uses A 80, BIAS 211, COUNT 142, DISPLAYS 59, EBANK 80, EGRESS 179, EXTVBACT 154, IT 185, LANDMARK 190, P20S 69, TC 169, and V59FLAG 113.

929 ⟨*Page CM0571* 929⟩≡ (913 2752)

```
                TC      BLANKET         # BLANK OUT R1,R2,R3
                TC      ENDOFJOB
# STORE TRUNNION ANGLE (OCDU)
MARKDISP        CAF     V06N87NB
                TC      BANKCALL
                CADR    GOMARKFR
                TC      GOTOP00H        # TERMINATE
                TC      R57B            # PROCEED
                TC      R57A            # ENTER (RECYCLE)
                CAF     FIVE
                TC      BLANKET         # BLANK OUT R1,R3
                TC      ENDOFJOB
R57B            CA      19.77DEG        # PUT FIXED INTO ERASABLE FOR MSU
                TS      L               # INSTRUCTION COMING UP
                CA      MRKBUF1 +5      # CONTAINS TRUNNION
                EXTEND
                MSU     L               # CONNECTS TRUNBIAS FROM 2'S TO 1'S
                TS      TRUNBIAS
ENDR57          TC      DOWNFLAG        # RESET V59FLAG
                ADRES   V59FLAG         # BIT 12 FLAG 5
                CAF     EBANK5
                TS      EBANK
                CAF     PRIO14
                TC      NOVAC           # THIS JOB CLEARS BIT IN
                EBANK=  MARKSTAT
                2CADR   ENDMARK         # MARKING IN R57 SO R53 CAN TAKE OVER

                TC      INTPRET
                GOTO
                        EGRESS
P23ABRT         TC      BAILOUT
                OCT     01211
V06N87NB        VN      0687
V59NB           VN      5900
V51NB           VN      5100
19.77DEG        OCT     61740
```

Uses EBANK 80, EGRESS 179, L 80, MARKSTAT 163, R2 188, TC 169, TRUNBIAS 165, V59FLAG 113, and VN 159.

930 ⟨*Page CM0572* 930⟩≡ (913 2752)

```
# PROGRAM DESCRIPTION
# MOD NO:  1
# MOD BY:  N. BRODEUR
#
# FUNCTIONAL DESCRIPTION
#
# TO PERFORM SIGHTING MARKS IN CONJUNCTION WITH THE RENDEZVOUS NAVIG-
# ATION PROGRAM.  CALLED BY ASTRONAUT VIA EXTENDED VERB.
#
# CALLING SEQUENCE:
#
#       R21 VIA V57
#       R23 VIA V 54
#
# SUBROUTINES CALLED:
#
#       FLAGUP          FLAGDOWN        BANKCALL
#       ENDOFJOB        GOMARK2         GOMARKF
#       INTPRET         GENTRAN         KLEENEX
#       ENDMARK
#
# NORMAL EXIT MODES:
#
# MARKRUPT USED BY SXTMARK HAS BEEN MODIFIED TO STORE MARK IN MRKBUF2
# FOR USE BY R22.  WHEN ASTRONAUT IS FINISHED TAKING MARKS, HE HITS AN
# PROCEED, R21 IS TERMINATED THUS CAUSING THE FINAL MARK TO BE TRANSFRD
# TO MRKBUF2 FOR PROCESSING BY R22
#
# ALARM OR ABORT EXIT MODES:
#
#       NONE
#
# OUTPUT:
#
#       7 REGISTER MRKBUF2 CONTAINING TIME2,TIME1,CDUY,OPTICS X,CDUZ, OPTICS Y,
#       CDUX.
#
# ERASABLE INITIALIZATION REQUIRED
#
# FLAGS SET AND RESET
#       R21MARK         (COMMUNICATION TO MARKRUPT TO STORE MARKS IN MRKBUF1 +2)
#       R23FLG          INDICATES COAS MARKING
#
# DEBRIS
```

```
                EBANK=  MRKBUF1
                SETLOC  RENDEZ
                BANK

                COUNT*  $$/R21

R21CSM          TC      UPFLAG          # SET R21MARK
                ADRES   R21MARK         # BIT 14 FLAG 2
R23CSM          CA      NEGONE
                TS      MRKBUF1
                TS      MRKBUF2
                CA      FLAGWRD1
                MASK    R23BIT          # TEST R23FLG
                EXTEND
                BZF     R21C1           # NOT SET REGULAR R21 MARKING
                CAF     V0694           # R23 BACKUP MARKING
                TC      BANKCALL        # DISPLAY SHAFT + TRUNNION
                CADR    GOMARKF
                TC      R21END          # TERM
                TC      +2              # PROC
```

Uses CDUX 80, CDUY 80, CDUZ 80, COUNT 142, EBANK 80, FLAGWRD1 97, N 206, R21MARK 103, R23BIT 99, R23FLG 99, RENDEZ 69, TC 169, TIME1 80, TIME2 80, and V 229.

932 ⟨*Page CM0573* 932⟩≡ (913 2752)

```
                TC      -5              # ENTER
R23CSM1         CAF     V53             # PERFORM ALT LOST SIGHT MARK
                TC      BANKCALL
                CADR    GOMARK2
                TC      R21END          # V34: TERMINATE R23
                TCF     R21CSMA         # PROCEED: END BACK UP MARKING (R23)
                CAF     SIX             # TRANSFER MRKBUF1 TO MRKBUF2
                TC      GENTRAN
                ADRES   MRKBUF1
                ADRES   MRKBUF2
                EXTEND
                DCA     TIME2
                DXCH    MRKBUF1         # READ TIME
                CA      CDUY            # READ CDU ANGLES
                TS      MRKBUF1 +2
                CA      CDUZ
                TS      MRKBUF1 +4
                CA      CDUX
                TS      MRKBUF1 +6
                RELINT
                TC      R23CSM1
R21C1           CAF     V51NB
                TC      BANKCALL
                CADR    GOMARK2
                TC      R21END          # V34: TERMINATE R21
                TCF     R21CSMA         # PROCEED: END R21
                TCF     R21C1           # RECYCLE

R21CSMA         CA      MRKBUF1         # IF -1 NO MARK
                AD      ONE
                EXTEND
                BZF     R21END          # ZERO = NO MARK
                CAF     SIX             # MARK THEREFORE TRANSFER IT TO MRKBUF2
R21CSM1         TC      GENTRAN         # TRANSFER MRKBUF1 TO MRKBUF2
                ADRES   MRKBUF1
                ADRES   MRKBUF2
                RELINT
R21END          TC      BANKCALL
                CADR    KLEENEX
                TC      DOWNFLAG        # RESET R21MARK
                ADRES   R21MARK         # BIT 14 FLAG 2
                TC      ENDMARK         # END MARKING AND ENDJOB
V53             VN      5300
V0694           VN      0694
```

Uses `ALT` 157, `CDUX` 80, `CDUY` 80, `CDUZ` 80, `IT` 185, `R21MARK` 103, `TC` 169, `TIME2` 80, and `VN` 159.

934 ⟨*Page CM0574* 934⟩≡ (913 2752)

```
# PREFERRED TRACKING ATTITUDE ROUTINE R61CSM
#
# PROGRAM DESCRIPTION
#       MOD NO:  2
#       MOD BY:  N. BRODEUR
#
# FUNCTIONAL DESCRIPTION:
#
#       TO COMPUTE THE PREFERRED TRACKING ATTITUDE OF THE CSM TO ENABLE OPTICS
#       TRACKING OF THE LM AND TO PERFORM THE MANEUVER TO THE PREFERRED
#       OR X-AXIS TRACKING ATTITUDE.
#
# CALLING SEQUENCE:
#
#       TC      BANKCALL
#       CADR    R61CSM
#
# SUBROUTINE CALLED
#
#       MAKECADR        BANKCALL
#       INTPRET         FLAGUP          FLAGDOWN
#       BANKJUMP        CRS61.1         R60CSM
#       PHASCHNG
#
# NORMAL EXIT MODES:
#
#       NORMAL RETURN TO CALLER + 1
#
# OUTPUT:
#
#       SEE OUTPUT FOR CRS61.1 & ATTITUDE MANEUVER ROUTINE (R60CSM)
#
# ERASABLE INITIALIZATION REQUIRED
#
#       GENRET USED TO SAVE Q FOR RETURN
#       R61CNTR MUST BE PRESET TO ZERO
#
# FLAGS SET + RESET
#
#       3-AXIS FLAG
#
# DEBRIS
#
#       SEE SUBROUTINES
```

```
                EBANK=  GENRET
                COUNT*  $$/R61          # ROUTINES -- NAVIGATION -- PREF. TR. 9TT=

R61CSM          CAF     EBANK6          # SWITCH TO EBANK 6
                XCH     EBANK
                TS      SAVBNK          # SAVE EBANK
                TC      MAKECADR
                TS      GENRET
                CCS     R61CNTR         # TEST R61DNTR
                TC      DECRM61         # NOT READY TO DO R61
                TC      +2              # DO R61
                TC      DECRM61 +1
                TC      INTPRET
                CALL
                        CRS61.1         # LOS DETERMINATION + VEH ATTITUDE
                EXIT
                INDEX   MPAC
                TC      +1
                TC      R61END          # SUBROUTINE DRIVING DAP        (EXIT R61)
                                        # OR AUTO MODE NOT SET          (EXIT R61)
                                        # OR SKIKFLAG SET               (EXIT R61)
R61C1           TC      DOWNFLAG        # RESET 3-AXIS FLAG
                ADRES   3AXISFLG        # BIT 6 FLAG 5
```

Uses 3AXISFLG 115, COUNT 142, EBANK 80, GENRET 221, MODE 145, MPAC 145, N 206, Q 80, R61CNTR 223, SAVBNK 221, SAVE 191, and TC 169.

936 ⟨*Page CM0575* 936⟩≡ (913 2752)

```
                CS      ONE             # SET R61CNTR NEG. TO INDICATE KALCMANU
                TS      R61CNTR

                TC      UPFLAG          # SET FLAG FOR PRIORITY DISPLAYS FOR R60
                ADRES   PDSPFLAG        # BIT 12 FLAG 4
                TC      BANKCALL
                CADR    R60CSM
                TC      DOWNFLAG        # RESET FLAG FOR PRIORITY DISPLAYS IN R60
                ADRES   PDSPFLAG        # BIT 12 FLAG 4
                TC      PHASCHNG
                OCT     00111
                CAF     ZERO
                TC      DECRM61
R61END          CAF     THREE

DECRM61         TS      R61CNTR

                CAE     GENRET
                LXCH    A               # RETURN IS IN L
                CA      SAVBNK          # RESTORE EBANK
                XCH     EBANK
                LXCH    A               # RETURN IS NOW BACK IN A
                TC      BANKJUMP        # EXIT R61
                BANK    13
                SETLOC  P20S2
                BANK

                EBANK=  MRKBUF1
```

Uses A 80, DISPLAYS 59, EBANK 80, GENRET 221, L 80, P20S2 65, PDSPFLAG 109, PRIORITY 145, R61CNTR 223, SAVBNK 221, and TC 169.

937 ⟨*Page CM0576* 937⟩≡ (913 2752)

```
# BVECTOR PERFORMS COMPUTATIONS FOR
#
#       DELTAQ, THE MEASURED DEVIATION BASED ON THE DIFFERENCE BETWEEN THE CSM-LEM
#       STATE VECTOR ESTIMATES AND THE ACTUAL TRACKING MEASUREMENT.
#
#       US, THE MODIFIED FICTITIOUS STAR DIRECTION VECTOR
#       GEOMETRY VECTORY B ASSOCIATED WITH EACH TRACKING MEASUREMENT.
#
# INPUT
#
#       UM,1/2 UNIT VECTOR ALONG THE CSM-LM LINE-OF-SIGHT (BASIC REF. SYSTEM)
#
#       USTAR,FICTITIOUS STAR DIRECTION (1/2 UNIT VECTOR)
#
#       RCLP,RELATIVE CSM TO LM POSITION VECTOR
#
# OUTPUT
#
#       USTAR,MODIFIED FICTITIOUS STAR DIRECTION (1/2 UNIT VECTOR)
#
#       BVECTOR = 9 DIMENSIONAL BVECTOR (1/2 UNIT VEC.)
#
#       DELTAQ = MEASURED DEVIATION
#
# CALLING SEQUENCE
#
#       L       CALL BVECTORS
#
# NORMAL EXIT
#
#       L+1 OF CALLING SEQUENCE

                COUNT   23/20SUB

BVECTORS        STQ
                        EGRESS
                VLOAD   UNIT
                        RCLP            # RELATIVE POSITION VECTOR
                STODL   26D             # RCLP UNIT VEC
                        36D             # RCLP ABS VALUE
                STOVL   TEMPOR1         # MOVE TO SAFE LOCATION
                        USTAR
                VXV     UNIT
                        26D             # USTAR = UNIT(US X UCL)
                STCALL  BVECTOR
```

```
        GRP2PC          # PHASE CHANGE
VLOAD
        BVECTOR
STORE   USTAR
DOT     SL1
        UM              # USTAR DOT UM
ACOS    DSU
        DP1/4TH
NORM    DMP
        X1
        PI/4.0
DMP     SRR*
        TEMPOR1         # RCLP ABS VALUE
        0 -3,1          # ADJUST SCALING
STOVL   DELTAQ
        ZEROVECS
STORE   BVECTOR +6
STORE   BVECTOR +12D
GOTO
```

Uses BVECTOR 232, COUNT 142, DELTAQ 232, EGRESS 179, L 80, RCLP 232, STAR 186, STATE 138, TEMPOR1 161, UCL 161, UM 161, US 185, USTAR 161, and X1 85.

938 ⟨*Page CM0577* 938⟩≡ (913 2752)

```
        EGRESS
PI/4.0  2DEC    .785398164
```

Uses EGRESS 179.

939 ⟨*Page CM0578* 939⟩≡ (913 2752)

```
# GETUM:  DETERMINES THE LINE OF SIGHT UNIT VECTOR UM IN THE BASIC REFERENCE
# COORDINATE SYSTEM FROM THE OPTICS SHAFT AND TRUNNION ANGLES AND THE IMU
# GIMBAL ANGLES.
#
# INPUT
#
#       MARKDATA, BASE ADDRESS OF MARK DATA
#       REFSMMAT, ROTATION MATRIX FROM STABLE MEMBER TO BASIC REF. COORD. SYSTEM
#
# SUBROUTINES CALLED-
#
#       SXTNB -- SEXT. ANGULAR READINGS TO NAV. BASE COOR.
#       NBSM -- TRANSFORM FROM NAV. BASE TO STABLE MEMBER
#
# OUTPUT
#
#       MPAC = LINE OF SIGHT 1/2 UNIT VECTOR IN BASIC REFERENCE SYSTEM
#
# CALLING SEQUENCE
#
#       L       CALL GETUM
#
# NORMAL EXIT
#
#       L+1 OF CALLING SEQUENCE

GETUM           STQ     SETPD
                        EGRESS
                        0
                LXC,1   VLOAD*
                        MARKDATA        # CONTAINS ADDRESS OF MARK DATA
                        1,1
                STODL*  MARKDOWN +1     # TRANSFER DATA FROM WORKING STORAGE
                        0,1             # TO MARKDOWN ARRAY FOR DOWNLINK
                STORE   MARKDOWN
                AXT,2
                        2
                XSU,2   SXA,2
                        X1              # X1 = MARKDATA
                        S1              # S1 = MARKDATA(ADR) +2
                CALL
                        SXTNB           # SEXT. ANGULAR READINGS TO NAV. BASE COOR.
                CALL
                        NBSM            # TRANSFORM FROM NAV. BASE TO STABLE MEM.
                VXM     VSL1
```

```
        REFSMMAT
GOTO                    # MPAC = (UM) LINE OF SIGHT VECTOR
        EGRESS          # EXIT
```

Uses EGRESS 179, L 80, MARKDATA 161, MARKDOWN 239, MPAC 145, REFSMMAT 172, S1 85, UM 161, and X1 85.

941 ⟨*Page CM0579* 941⟩≡ (913 2752)

```
# RENDEZVOUS TRACKING DATA PROCESSING ROUTINE (R22)
#
# PURPOSE       (1) TO PROCESS RENDEZVOUS SIGHTING MARK DATA TO UPDATE THE STATE VECTOR OF EITH
#               DEFINED BY THE RENDEZVOUS NAVIGATION PROGRAM (P20).
#
# ASSUMPTIONS   (1) THIS ROUTINE IS MANUALLY SELECTED BY THE ASTRONAUT BY V55E WHENEVER RENDEZV
#               ARE DESIRED.  ITS SELECTION, HOWEVER, IS LIMITED TO PERIODS WHEN THE CMC IS HOL
#               DATA DISPLAY.  THIS ROUTINE RETURNS TO THE ORIGINAL PROGRAM AT THE INTERRUPTED

                BANK    34
                SETLOC  P20S3
                BANK

                COUNT   34/R22

R22             CAF     PRIO26
                TS      PHSPRDT2
                TC      PRIOCHNG
                CA      NEG3
                TS      MRKBUF2
                TC      INTPRET
                RTB
                        LOADTIME
                STORE   VHFTIME         # PRESENT TIME
REND1           CALL
                        GRP2PC
                CALL
                        WAITONE
REND1A          EXIT
                CA      MRKBUF2
                EXTEND
                BZF     REND2
                EXTEND
                BZMF    REND3A
REND2           CAF     SIX
                TC      GENTRAN
                ADRES   MRKBUF2
                ADRES   MARKTIME        # MARKTIME MUST BE CONTIGUOUS WITH VTEMP
                CAF     NEG3            # NEG VALUE TO INDICATE VALUES USED
                TS      MRKBUF2
                RELINT
                TC      INTPRET
                CLEAR   CALL
                        SOURCFLG        # 0 = OPTICS DATA
                        GRP2PC
```

```
                SSP     GOTO
                        MARKDATA
                ECADR   VTEMP -2
                        REND4
REND3A          TC      INTPRET
REND3           CALL
```

Uses A 80, COUNT 142, MARKDATA 161, MARKTIME 161, N 206, P20S3 69, PHSPRDT2 154, SOURCFLG 131, STATE 138, TC 169, V 229, VHFTIME 159, and VTEMP 161.

943 ⟨*Page CM0580* 943⟩≡ (913 2752)

```
                GRP2PC
        CALL
                WAITONE
        BOFF
                VHFRFLAG
                REND1A
        RTB
                LOADTIME        # PRESENT TIME
        DSU     DSU
                60SECDP         # 1 MIN
                VHFTIME         # LAST READING OF RADAR
        BMN     CALL
                REND1A
                RANGERD         # READ RADAR RANGE
        DLOAD
                MARKTIME
        STORE   VHFTIME         # FOR DOWNLINK
REND4   CALL
                SETINTG         # SET INTEGRV FLAGS
        BON     CALL
                VEHUPFLG
                CSMUPP          # BRANCH IF CSM UPDATE
                INTEGRV
        CALL
                GRP2PC          # PHASE CHANGE
        CALL
                SETINTG         # SET INTEGRV FLAGS
        CLEAR
                VINTFLAG        # SET INTEGRATION VEHICLE TO LM
REND5   BOFF    SET
                RENDWFLG
                REND5A          # DO NOT INTEGRATE W IF FLAG = 0
                DIM0FLAG
REND5A  CALL
                INTEGRV
        CALL
                SHIFTNDX        # SET EARTH MOON SCALING INDEX
        CALL
                CMPOS           # SET CSM POSITION
        SET     CALL
                INCORFLG        # SET FOR 1ST PASS
                LMPOS           # SET LM POSITION
        CLEAR   BON
                ORBWFLAG        # CLEAR FOR ORBITAL AND CISLUNAR
                RENDWFLG
```

```
                REND6
        DLOAD
                WRENDPOS
        STCALL  0               # 0 = WRENDPOS  1 = WRENDVEL
                INITIALW        # INTIIALIZE W MATRIX
```

Uses DIMOFLAG 109, INCORFLG 115, MARKTIME 161, ORBITAL 59, ORBWFLAG 107, RANGE 179, RENDWFLG 117, VEHUPFLG 99, VHFRFLAG 131, VHFTIME 159, VINTFLAG 109, W 183, WRENDPOS 175, and WRENDVEL 175.

945 ⟨*Page CM0581* 945⟩≡ (913 2752)

```
                DLOAD
                        ZEROVECS
                STORE   VHFCNT          # ZERO OUT VHFCNT AND TRKMKCNT
REND6           SET
                        RENDWFLG
                VLOAD   VSU
                        LEMPOS
                        CSMPOS
                STORE   RCLP            # LM - CSM
REND7           UNIT    BON
                        SOURCFLG
                        REND14          # BRANCH IF DATA IS RADAR
                STORE   UCL
                BOFF    CALL
                        INCORFLG
                        REND9
                        GETUM           # CALCULATE UM LINE OF SIGHT
                STOVL   UM
                        UCL
                VXV     BOV
                        UM              # UCL X UM
                        REND8
REND8           UNIT    BOV
                        REND3           # BRANCH IF OVERFLOW IGNORE MARK
                STORE   USTAR
REND9           CALL
                        BVECTORS
                BON     VLOAD
                        VEHUPFLG
                        REND9A
                        BVECTOR
                VCOMP
                STORE   BVECTOR
REND9A          CALL
                        GRP2PC
                BON
                        R23FLG
                        REND15          # BRANCH IF BACKUP OPTICS (R23 WORKING)
                DLOAD   DAD
                        SXTVAR
                        IMUVAR
REND10          STOVL   VARIANCE        # TEMP STORAGE FOR VARIANCE CALC.
                        RCLP
                ABVAL   NORM
                        X1
```

```
DSQ     DMP
        VARIANCE
XAD,1   CALL
        X1
        SHIFTNDX        # GET EARTH MOON SCALING INDEX
```

Uses BVECTOR 232, CSMPOS 161, INCORFLG 115, LEMPOS 161, R23FLG 99, RCLP 232, RENDWFLG 117, SOURCFLG 131, TEMP 191, TRKMKCNT 157, UCL 161, UM 161, USTAR 161, VARIANCE 232, VEHUPFLG 99, VHFCNT 157, and X1 85.

947 ⟨*Page CM0582* 947⟩≡ (913 2752)

```
                XAD,1   XAD,1
                        X2
                        X2
                SR*     TLOAD
                        0 -2,1          # ADJUST SCALING TO B-40
                        MPAC
                STORE   VARIANCE
                SLOAD   SR
                        INTVAR          # INTEGRATION VARIANCE SCALED B-15
                        25D             # SCALE IT B-40
                TAD     RTB
                        VARIANCE
                        TPMODE
                STORE   VARIANCE
                BOFF    TAD
                        SOURCFLG        # BRANCH IF NOT VHF RADAR
                        REND10A
                        RVARMIN         # VHF RADAR MIN. VARIANCE
                BPL     TLOAD
                        REND10A
                        RVARMIN
                ABS                     # MIN. VALUE WAS STORED AS NEG.
                STORE   VARIANCE        # STORE MIN. VALUE
REND10A         CLEAR   CALL
                        DMENFLG         # CLEAR FOR 6 X 6 W MATRIX
                        INCORP1         # CALCULATE UPDATE
                CALL
                        GRP2PC
                BOFF    CALL
                        INCORFLG
                        REND12
                        SHIFTNDX        # GET EARTH MOON SCALING INDEX
                VLOAD   ABVAL
                        DELTAX +6
                SR*
                        0,2
                STOVL   N49DISP +2
                        DELTAX
                ABVAL   SR*
                        0,2
                STORE   N49DISP
                SLOAD
                        RMAX
                SR      DSU
                        10D
```

```
                N49DISP
        BMN     SLOAD
                RENDISP         # BRANCH IF POS UP. GREATER THAN MAX.
                VMAX
        DSU     BMN
```

Uses DELTAX 161, DMENFLG 115, INCORFLG 115, INTVAR 182, IT 185, MPAC 145, N49DISP 232, RMAX 175, RVARMIN 198, SOURCFLG 131, SR 80, VARIANCE 232, VMAX 175, W 183, and X2 85.

949 ⟨*Page CM0583* 949⟩≡ (913 2752)

```
                        N49DISP +2
                        RENDISP         # BRANCH IF VEL. UPDATE GREATER THAN MAX.
REND12          CALL
                        INCORP2         # INCORPORATE UPDATE VALUES INTO STATE VEC
                BON     BOFF
                        SOURCFLG
                        REND16          # BRANCH IF DATA IS RADAR
                        INCORFLG
                        REND17
                CALL
                        SHIFTNDX        # GET EARTH MOON SCALING INDEX
                BON     CALL
                        VEHUPFLG
                        REND18          # BRANCH IF CSM UPDATE
                        LMPOS           # GET LM POSITION
REND13          CALL
                        GRP2PC          # PHASE CHANGE
                VLOAD   VSU
                        LEMPOS
                        CSMPOS
                STORE   RCLP            # LM - CSM
                CLRGO
                        INCORFLG
                        REND7           # BRANCH FOR 2ND PASS THIS OPTICS MARK
CSMUPP          CLEAR   CALL
                        VINTFLAG        # SET INTEGRATION VEHICLE EQ LM
                        INTEGRV
                CALL
                        GRP2PC          # PHASE CHANGE
                CALL
                        SETINTG         # SET FLAGS FOR INTEGRATION
                GOTO
                        REND5
REND14          STOVL   BVECTOR         # VHF RADAR BVECTOR
                        ZEROVECS
                STORE   BVECTOR +6
                STOVL   BVECTOR +12D
                        RCLP
                UNIT    DLOAD
                        VHFRANGE        # VHFRANGE SCALED B-27
                BON     SR2
                        MOONTHIS
                        +1
                DSU     SET
                        36D             # ABVAL (RCLP)
```

```
        INCORFLG
STORE   DELTAQ
BOFF    VLOAD
        VEHUPFLG
        REND14A
```

Uses BVECTOR 232, CSMPOS 161, DELTAQ 232, INCORFLG 115, LEMPOS 161, MOONTHIS 71, N49DISP 232, RCLP 232, SOURCFLG 131, STATE 138, VEHUPFLG 99, VEL 226, VHFRANGE 161, and VINTFLAG 109.

951 ⟨*Page CM0584* 951⟩≡ (913 2752)

```
                        BVECTOR
                VCOMP
                STORE   BVECTOR
REND14A         CALL
                        GRP2PC
                DLOAD   GOTO
                        RVAR
                        REND10
REND15          SLOAD   DAD             # GET ALT LOS VARIANCE
                        ALTVAR          # BACKUP OPTICS
                        IMUVAR          # IMU VARIANCE
                GOTO
                        REND10
REND16          LXA,1   INCR,1
                        VHFCNT          # VHF RADAR UPDATE COUNT
                DEC     1
                SXA,1   GOTO
                        VHFCNT          # UPDATE COUNT
                        REND1
REND17          LXA,1   INCR,1
                        TRKMKCNT        # OPTICS MARK COUNT
                DEC     1
                SXA,1   GOTO
                        TRKMKCNT        # UPDATE COUNT
                        REND3
REND18          CALL
                        CMPOS           # GET CSM POSITION
                GOTO
                        REND13
CMPOS           VLOAD   VSR*
                        DELTACSM
                        7,2
                VAD
                        RCVCSM
                STORE   CSMPOS          # CSM POSITION SCALED B-27 OR B-29
                RVQ
LMPOS           VLOAD   VSR*
                        DELTALEM
                        7,2
                VAD
                        RCVLEM
                STORE   LEMPOS          # LM POSITION SCALED B-27 OR B-29
                RVQ
RENDISP         EXIT
                CA      FLAGWRD9
```

```
MASK    SOURCBIT
EXTEND
BZF     +3
CA      BIT2
TC      +2
```

Uses ALT 157, ALTVAR 166, BVECTOR 232, COUNT 142, CSMPOS 161, DELTACSM 172, DELTALEM 172, LEMPOS 161, RCVCSM 172, RCVLEM 172, RVAR 198, SOURCBIT 131, TC 169, TRKMKCNT 157, VARIANCE 232, and VHFCNT 157.

953 ⟨*Page CM0585* 953⟩≡ (913 2752)

```
                CA      BIT1
                TS      N49DISP +4
                CAF     ZERO            # SET TEMPOR1 > ZERO TO INDICATE
                TS      TEMPOR1         # V06 N49 DISPLAY HASN'T BEEN ANSWERED
                TC      PHASCHNG
                OCT     04022
                CAF     PRIO27          # SET UP DISPLAY JOB WITH HIGHER PRIORITY
                TC      NOVAC
                EBANK=  MRKBUF1         # THAN PRESENT JOB
                2CADR   RENDISP2

RENDISP7        TC      INTPRET
                STORE   MPAC
                SLOAD   BZE
                        TEMPOR1
                        RENDISP7 +1     # DISPLAY HAS NOT BEEN ANSWERED YET
                BMN     GOTO
                        REND12          # NEG INDICATES PROCEED
                        RENDISP3        # POS INDICATES RECYCLE
RENDISP2        CAF     V06N49
                TC      BANKCALL
                CADR    PRIODSP
                TC      GOTOV56         # TERM EXIT P20 VIA V56
                CS      ONE             # NEG INDICATES PROCEED RENDISP7 JOB
                TS      TEMPOR1         # POS INDICATES RECYCLE RENDISP7 JOB
                TC      ENDOFJOB        # GO COMPLETE ABOVE JOB
RENDISP3        BON
                        SOURCFLG
                        REND1           # DATA WAS RADAR GO LOOK FOR OPTICS NEXT
                EXIT
                EBANK=  MRKBUF1
                INHINT
                CAF     BUFBANK
                TS      BBANK
                CA      NEGONE
                TS      MRKBUF1         # ERASE MARK ONE BUFFER
                TS      MRKBUF2         # ERASE MARK TWO BUFFER
                RELINT
RENDISP4        TC      INTPRET
                GOTO
                        REND3
SXTVAR          2DEC    0.04 E-6 B+16   # SXT ERROR VARIANCE = .04 (MR)SQ

IMUVAR          2DEC    0.04 E-6 B+16   # IMU ERROR VARIANCE = .04 (MR)SQ
```

```
V06N49          VN      0649
                EBANK=  MRKBUF1
BUFBANK         BBCON   RENDISP3
                BANK    31
                SETLOC  R22S1
```

Uses BBANK 80, EBANK 80, MPAC 145, N49DISP 232, PRIORITY 145, R22S1 67, SOURCFLG 131, SQ 156, TC 169, TEMPOR1 161, VARIANCE 232, and VN 159.

955 ⟨*Page CM0586* 955⟩≡ (913 2752)

```
                BANK
SETINTG         STQ     CALL
                        EGRESS
                        INTSTALL        # RESERVE INTEGRATION
                DLOAD   SET
                        MARKTIME
                        STATEFLG
                STORE   TDEC1           # MARKTIME
                CLEAR   CLEAR
                        INTYPFLG        # PRECISION INTEGRATION
                        DIMOFLAG
                SET     CLRGO
                        VINTFLAG        # SET VEHICLE EQ. CSM
                        D6OR9FLG        # SET W MATRIX DIM. EQ 6
                        EGRESS          # EXIT
CNTCHK          STQ
                        POINTEX
CONTCHK         BOFF
                        REFSMFLG        # BRANCH TO END OF JOB IF REFSMMAT NO GOOD
                        ENDPLAC
                SLOAD   BMN
                        R61CNTR
                        WAITONE1
                BON     BOFF            # IS TRACK FLAG SET
                        UPDATFLG
                        POINTEX
                        TRACKFLG
                        ENDPLAC
                EXIT
REDOR22         TC      PHASCHNG
                OCT     00132
                CAF     PRIO26
                TC      PRIOCHNG
                TC      WAITONE +3
WAITONE         STQ
                        POINTEX
WAITONE1        EXIT
                CAF     4SECS           # WAIT 4 SECS.
                TC      BANKCALL
                CADR    DELAYJOB
                TC      INTPRET
                GOTO
                        CONTCHK         # CHECK AGAIN NOW
RANGERD         EXIT
                INHINT
```

```
                CS      OCT17
                EXTEND
                WAND    CHAN13          # ZERO OUT BITS 1-4 OF CHANNEL 13
                CAF     OCT11
                EXTEND
```

Uses CHAN13 87, D6OR9FLG 109, DIMOFLAG 109, EGRESS 179, INTYPFLG 107, MARKTIME 161, POINTEX 159, R61CNTR 223, REFSMFLG 107, REFSMMAT 172, STATEFLG 107, TC 169, TRACKFLG 101, UPDATFLG 99, VINTFLAG 109, and W 183.

957 ⟨*Page CM0587* 957⟩≡ (913 2752)

```
                WOR     CHAN13          # GENERAGE SHIFT PULSES TO RADR, SET R. BIT
                RELINT
                EXTEND
                DCA     TIME2
                DXCH    MARKTIME        # READ PRESENT TIME
                TC      DOWNFLAG
                ADRES   SKIPVHF
                TC      BANKCALL
                CADR    RADSTALL        # WAIT FOR RANGE COMPLETE
                TC      LIGHTON         # BAD DATA GOOD BIT
                TC      TRFAILOF        # TURN TRACKER LIGHT OFF
RANGERD1        CCS     RM              # 15 BIT UNSIGNED RANGE
                TC      RANGERD4        # GR + 0
                TC      LIGHTON +4      # = + 0
                TC      RANGERD3        # L - 0
                TC      RANGERD3        # = - 0
RANGERD4        TC      INTPRET
                SLOAD   DMP
                        RM
                        CONVRNGE        # CONVERT RANGE TO METERS B-27
RANGERD2        STORE   VHFRANGE
                SET     RVQ
                        SOURCFLG        # SOURCE OF DATA TO VHF RADAR
RANGERD3        CA      RM
                MASK    POSMAX
                TS      MPAC            # MASK OUT NEG. SIGN BIT
                TC      INTPRET
                DMP
                        CONVRNGE        # CONVERT FROM NM TO METERS AND SCALE B-27
                DAD     GOTO
                        RANGEB14        # VALUE IN METERS OF SIGN BIT SCALED B-27
                        RANGERD2
LIGHTON         CA      VHFRANGE
                EXTEND
                BZF     +2
                TC      TRFAILON
                TC      INTPRET
                DLOAD
                        MARKTIME
                STORE   VHFTIME
                GOTO
                        REND1
RANGEB14        2DEC    303431.7 B-27   # 16384 X 18.52 SCALED B-27

OCT17           OCT     00017
```

```
OC40200         OCT     40200
CONVRNGE        2DEC    18.52 B-13      # VHF INPUT RANGE CONV. FROM .01 NM TO M

VHFREAD         EXTEND
                ROR     SUPERBNK        # MUST SAVE SBANK BECAUSE OF RUPT
```

Uses CHAN13 87, L 80, MARKTIME 161, MPAC 145, RANGE 179, RM 239, SAVE 191, SKIPVHF 103, SOURCFLG 131, SUPERBNK 87, TC 169, TIME2 80, VHFRANGE 161, and VHFTIME 159.

959 ⟨*Page CM0588* 959⟩≡ (913 2752)

```
                TS      BANKRUPT        # EXITS VIA TASKOVER BADEND OR GOODEND
                CS      ZERO
                TS      RUPTAGN
                EXTEND
                QXCH    QRUPT
                CS      STATE   +2
                MASK    SKIPVBIT        # SKIPVHF FLAG
                EXTEND
                BZF     TASKOVER        # BRANCH IF VHF RESTART BIT SET
                CAF     UPDATBIT
                MASK    STATE +1        # UPDATEFLG
                EXTEND
                BZF     BYPASS1
                CS      STATE   +4
                MASK    PDSPFBIT        # PDSPFLAG
                EXTEND
                BZF     BYPASS1
                CA      RNRAD
                TS      RM              # SAVE RANGE
                CAF     BIT2
                EXTEND
                RAND    CHAN33          # READ DATA GOOD BIT
                EXTEND
                BZF     VHFGOOD         # BRANCH IF DATA GOOD BIT EQUALS GOOD
BYPASS          TS      VHFRANGE        # STORE NON ZERO VALUE
                CAF     TWO
                TC      POSTJUMP
                CADR    BADEND
BYPASS1         CAF     ZERO
                TC      BYPASS
VHFGOOD         CAF     TWO
                TC      POSTJUMP
                CADR    GOODEND
SHIFTNDX        AXT,2   BON
                        0
                        VEHUPFLG
                        SHIFTA          # VEHICLE IS CSM
                BON     RVQ
                        LMOONFLG
                        +1
                INCR,2  RVQ
                DEC     -2
SHIFTA          BON     RVQ
                        CMOONFLG
                        +1              # MOON ORB.
```

```
                INCR,2  RVQ
                DEC     -2
INITIALW        AXT,1   SSP
                        36D
                        S1
```

Uses BANKRUPT 80, CHAN33 87, CMOONFLG 125, LMOONFLG 125, PDSPFBIT 109, PDSPFLAG 109, QRUPT 80, RANGE 179, RESTART 57, RM 239, RNRAD 80, RUPTAGN 150, S1 85, SAVE 191, SKIPVBIT 103, SKIPVHF 103, STATE 138, TC 169, UPDATBIT 101, VEHUPFLG 99, and VHFRANGE 161.

960 ⟨*Page CM0589* 960⟩≡ (913 2752)

```
                        6
                VLOAD
                        ZEROVECS
INITA           STORE   W +36D,1        # CLEAR 0 - 35
                TIX,1   AXT,1
                        INITA
                        36D
INITB           STORE   W +90D,1        # CLEAR 54 - 89
                TIX,1   SLOAD
                        INITB
                        0               # POSITION VALUE
                STORE   W               # INITIALIZE DIAGONAL W POSITION
                STORE   W +8D
                STORE   W +16D
                SLOAD
                        1               # VELOCITY VALUE
                STORE   W +72D          # INITIALIZE DIAGONAL W VELOCITY
                STORE   W +80D
                STORE   W +88D
                RVQ
```

Uses W 183.

961 ⟨*Page CM0590* 961⟩≡ (913 2752)

```
# CRS61.1       R/10/68
#
# TO COMPUTE THE PREFERRED TRACKING ATTITUDE OF THE CSM WHICH ENABLES
# OPTICS TRACKING OF THE LEM AND LM TRACKING OF THE CSM RADAR TRANSPONDER
# AND TO COMPUTE THE X-AXIS TRACKING ATTITUDE OF THE CSM WHICH ENABLES
# COAS TRACKING OF THE LM.
#
# TO PERFORM THE MANEUVER TO THE SELECTED TRACKING ATTITUDE IF THE
# MANEUVER IS LESS THAN 10 DEGREES BUT TO CALL R60 IF THE MANEUVER IS
# GREATER THAN 10 DEGREES BUT TO CALL R60 IF THE MANEUVER IS
# GREATER THAN 10 DEGREES OR IF THE R60 FLAG IS SET.
#
#       (1)     EXTRAPOLATE LM AND CSM STATE VECTORS TO PRESENT TIME USING
#               CONIC EQUATIONS.
#
#       (2)     CALCULATE LOS FROM CSM TO LM = RL - RC.
#
#       (3)     THE PRERFERRED TRACKING ATTITUDE IS DEFINED AS FOLLOWS:
#               THE TRACK AXIS (I) IS ALIGNED ALONG THE LOS TO THE LM.  THE
#               TRACK AXIS (I) IS DEFINED AS:
#
#               UNIT(I)=UNIT(Z  )COS55  &  UNIT(X  )SIN55
#                    -       -SC                -SC
#
#       (4)     COMPUTE DESIRED CDU ANGLES, USING VECPOINT.
#
# (Sorry, I don't know where (5) and (6) are. --- RSB 2009.)
#       (7)     FORM DIFFERENCE BETWEEN DESIRED AND ACTUAL CDUS.
#               IF ANY OF THE THREE ANGLE DIFFERENCES EXCEEDS 10 DEGREES,
#               GROSS MANEUVER IS REQUIRED.  SIGNAL R61 (SET MPAC=1) TO
#               OPERATE KALCMANU AND EXIT CRS61.1.
#               IF ALL DIFFERENCES ARE LESS THAN 10 DEGREES, CONTINUE.
#
#       (8)     CALCULATE ORTHOGONAL LOS RATE IN REF COORDS AS
#
#               OMEGATH = (UNITLOS(B1) X UNITDV(B1))(ABSDV(B7)/ABSLOS(B29))
#
#               CONVERSION FACTOR OF 100/2PI (B4) REV CSEC PER RAD SEC IS
#               APPLIED TO YIELD UNITS OF REVS/SEC.  SCALE IS CARRIED AS
#               B+1+1+7-29+4+1 PLUS RESULTS OF NORMALIZING ABSDV, ABSLOS.
#               THE EXTRA B+1 RESULTS FROM RESCALING ABSDV B8 AFTER NORM
#               TO AVOID OVFLOW ON DIVIDE.
#
#               UNITLOS = UNIT( RL - RC ) B1.
#               UNITDY  = UNIT( VL - VC ) B1.
```

```
#               ABSLOS  = LENGTH OF LOS, METERS B29.
#               ABSDV   = LENGTH OF DV, METERS/CSEC B7.
#
#       (9)     OBTAIN RATE IN SM COORDS.
#
#               OMETATHSM = (REFSMMAT)(OMEGATH).
#
#       (10)    OBTAIN GIMBAL ANGLE INCREMENTS FOR 0.1 SECOND.
#
#               DTHETASM = (0.1)(OMEGATHSM)
#
#       (11)    OBTAIN DELCDUX,Y,Z USING SUBR SMCDURES.
```

Uses CDUS 80, DELCDUX 211, DTHETASM 211, DV 241, FACTOR 226, I 206, MPAC 145, RAD 219, REFSMMAT 172, REVS 206, STATE 138, VL 229, and Z 80.

963 ⟨*Page CM0591* 963⟩≡ (913 2752)

```
#               INPUT CONSISTS OF
#
#               (A)     VECTOR OF ANGULAR INCREMENTS, DTHETASM, STORED
#                       IN V(DTHETASM).
#               (B)     SIN,COS CDUX,Y,Z FROM SUBR CDUTRIG.
#
#               TRANSFER OUTPUT OF SMCDURES FROM V(DCDU) TO VAC14D.
#
#       (12)    CALCULATE ANG LOS RATE IN BODY(NB) COORDS USING SUBR SMNB.
#
#               OMEGANB = (SMNB)(OMETATHSM)
#
#               SUBR SMNB REQUIRES OMEGATHSM IN V(VAC32D) AND ACTUAL CDUS
#               (Y,X,Z ORDER) IN V(VAC20D) WITH S1 OF VAC = BASE ADDRESS
#               OF CDUS (FIXLOC + 20D).
#
#       (13)    CALCULATE ANG LOS RATE IN CONTROL COORDS AS FOLLOWS
#
#               WBODY = (MBDYTCTL)(OMEGANB)     UNITS=REVS/SEC(B0) (?).
#
#                               ( 0.5       0              0      )   BODY TO
#               MBDYTCTL(B1) = (  0   COS(7.25)B1   -SIN(7.25)B1 ) = CONTROL
#                               (  0   SIN(7.25)B1    COS(7.25)B1 )   AXES
#                                                                     CONVERSION
#                                                                     MATRIX
#
#       (14)    RESCALE WBODY TO UNITS OF 460 DEG/SEC BY APPLYING FACTOR
#               OF 0.8 TO REVS/SEC.
#
#       (15)    ADDRESS LIVE AUTOPILOT REGISTERS IN BASIC (UNDER INHINT).
#
#               TRANSFER DESIRED CDUS, SCALED 180 DEGREES, FROM T(SAVEDCDU)
#               TO V(CDUXD).
#
#               TRANSFER DELCDUS, SCALED 180 DEG, FROM V(VAC14D)
#               TO V(DELCDUX).
#
#               TRANSFER OMEGA CONTROL, SCALED 450 DEG/SEC, FROM V(MPAC)
#               TO V(WBODY).
#
#               RELINT, SET MPAC=0, EXIT CRS61.1.
#
# CALL:         L       CALL    CRS61.1
#
# RETURNS:      ALL TO L+1.
```

```
#
#               (1)     S(MPAC)=0.  NORMAL EXIT.  3 SETS OF INPUTS FED TO DAP.
#               (2)     S(MPAC)=1.  CALCULATED DESIRED CDUS,SP, SET IN T(CPHI)
#                       FOR KALCMANU.  ABS(ACDU - DCDU) EXCEEDS 10 DEGREES.
#               (3)     S(MPAC)=2.  GNCS AUTO MODE NOT SELECTED (BIT10=1).
#               (4)     S(MPAC)=3.  DAP HOLD FLAG (HOLDFLAG) NOT EQUAL -1.
```

Uses A 80, CDUS 80, CDUX 80, CDUXD 213, CPHI 157, DCDU 211, DELCDUX 211, DTHETASM 211, FACTOR 226, FIXLOC 140, HOLDFLAG 163, L 80, MODE 145, MPAC 145, OMEGA 232, REVS 206, S1 85, SAVEDCDU 221, V 229, WBODY 209, and Z 80.

965 ⟨*Page CM0592* 965⟩≡ (913 2752)

```
#
# INPUT:        (1)     TIME2,TIME1.  COMPUTER CLOCK TIME,DP, CENTISEC B28.
#               (2)     CDUX,Y,Z.  PRESENT CDU ANGLES,SP,2S COMPL HALF-REVS B0.
#               (3)     M(REFSMMAT), STABLE MEMBER COORDS B1.
#
# OUTPUT:       NORMAL.  EXIT WITH S(MPAC) = 0.
#
#               (1)     CDUXD,CDUYD,CDUZD, DESIRED OUTER, INNER, MIDDLE CDU ANGLES,
#                       DP, IS COMPL, SCALED 180 DEGREES (HALF-REVS B0).
#               (2)     DELCDUX,DELCDUY,DELCDUZ.  0.1 SEC DCU ANGULAR INCREMENTS,
#                       DP, IS COMPL, SCALED 180 DEG.
#               (3)     WBODY,WBODY1,WBODY2.  LOS ANGULAR RATE IN CONTROL COORDS,
#                       DP, IS COMPL, SCALED 450 DEG/SEC.
#
#               SPECIAL.  EXIT WITH S(MPAC) = 1.
#
#               (1)     CPHI,CTHETA,CPSI.  DESIRED OUTER, INNER, MIDDLE CDU ANGLES,
#                       SP, 2'S COMPL, SCALED 180 DEGREES.
#
# EXTERNAL SUBROUTINES USED     (B)=BASIC
#
#       (1) CALCGA              (5) LOADTIME(B)         (9) SMNB
#       (2) CDUTRIG             (6) MATMOVE
#       (3) CSMCONIC            (7) RCDUS(B)
#       (4) LEMCONIC            (8) SMCDURES
#
# ERASABLE
#
#       (1) S(Q611),EBANK7      CRS61.1 EXIT.
#       (2) S(Q6111),EBANK7     CALCDCDU EXIT.
#       (3) T(SAVEDCDU),E6      SP VECTOR OF CDUDS.
#       (4) V(SAVEPOS),E7       CSM POS VEC AND D(SAVEPOS)= LENGTH OF LOS.
#       (5) V(SAVEVEL),E7       CSM VEL VEC.
#
# FLAGWDS:      HOLDFLAG.  USED, NOT SET.
#
# MISC: (1) ERASABLE ITEMP1 USED TO TEMP STORE EBANK UNDER INHINT.
#       (2) ERASABLE P21TIME USED AS TEMP STORE DURING CRS61.1
#       (3) ERAS DTHETASM USED AS TEMP STORE DURING EARLY CRS61.1
#
# DEBRIS -- CURRENT VAC AREA, CRS61.1 ERASABLES, ITEMP1, P21TIME

                BANK    24
                SETLOC  P20S4
                BANK
```

```
                EBANK=  CDUXD
                COUNT*  $/CRS61

CRS61.1         STQ     SETPD
                        Q611
                        0
                RTB
```

Uses CDUX 80, CDUXD 213, CDUYD 213, CDUZD 213, COMPUTER 115, COUNT 142, CPHI 157, CPSI 157, CTHETA 157, D 226, DELCDUX 211, DELCDUY 211, DELCDUZ 211, DTHETASM 211, EBANK 80, HOLDFLAG 163, ITEMP1 138, MPAC 145, P20S4 69, P21TIME 179, Q611 239, Q6111 239, REFSMMAT 172, REVS 206, SAVEDCDU 221, SAVEPOS 239, TEMP 191, TIME1 80, TIME2 80, V 229, VEL 226, WBODY 209, WBODY1 209, WBODY2 209, and Z 80.

967 ⟨*Page CM0593* 967⟩≡ (913 2752)

```
                        LOADTIME        # LOAD CLOCK TIME2,1 INTO MPAC.

STORT           STCALL  P21TIME         # STORE CLOCK TIME FOR SUBR R63
                        R63             # SUBR TO CALC DCDU (T=PRESENT,PASS1)
                TLOAD
                        THETAD          # SAVE DCDU(T) FROM CALCDCDU FOR STEP4.
                STORE   SAVEDCDU

                EXIT
                TC      STEP2CK
AUTOCK          CAF     PRIO30
                EXTEND
                RXOR    CHAN31
                MASK    FURST3
                EXTEND                  # AUTO MODE SELECTED (BITS 15-13=011)
                BZF     DAPCK           #       YES -- CONTINUE.
                TC      ASET

DAPCK           CS      FLAGWRD1        # IS STIKFLAG SET (I.E., IS SOMEONE ON RHC)
                MASK    STIKBIT
                CCS     A
                TC      STEP3CK
ASET            CAF     ZERO
                TS      MPAC
                TC      INTPRET         # EXIT CRS61.1
                GOTO
                        Q611

STEP2CK         TC      BANKCALL
                CADR    UPACTOFF

                CAF     TWO             # SET TEMPORARY INDEX DTHETASM = 2
CDULOOP         TS      DTHETASM
                INDEX   DTHETASM
                CA      CDUX            # SET A = ACTUAL CDU (ACDU).
                EXTEND
                INDEX   DTHETASM        # SET INDEX TO ACCESS DESIRED CDU (DCDU).
                MSU     THETAD          # A = DIFF = ACDU - DCDU.
                TS      MPAC            # RETURN TO INTERPRETER FOR 10 DEGREE CK.
                TC      INTPRET         # (DP APPROX SP OK FOR ROUGH CHECK)
                ABS     DSU
                        DEGREE10        # IS (ACDU - DCDU) MORE THAN 10 DEGREES.
                BPL     EXIT            # NO -- OK, CONTINUE CHECKING OTHER ANGLES.
                        STKTEST         # TEST STICK FLAG
                CCS     DTHETASM        # HAVE ALL 3 ANGLE DIFFS BEEN CHECKED.
```

```
                TC      CDULOOP         # NO -- DIM COUNT, CHECK NEXT ANGLE DIFF.
                TC      AUTOCK
STKTEST         EXIT
                CS      FLAGWRD1
                MASK    STIKBIT
```

Uses A 80, CDUX 80, CHAN31 87, COUNT 142, DCDU 211, DIFF 226, DTHETASM 211, FLAGWRD1 97, I 206, MODE 145, MPAC 145, P21TIME 179, Q611 239, SAVE 191, SAVEDCDU 221, STIKBIT 99, STIKFLAG 99, TC 169, THETAD 157, and TIME2 80.

969 ⟨*Page CM0594* 969⟩≡ (913 2752)

```
                CCS     A
                TC      MANUEXIS        # STIKFLAG IS NOT SET (DO R63)
                CAF     BIT3
                EXTEND                  # STIKFLG IS SET
                WOR     DSALMOUT        # TURN ON UPACTY LIGHT

                TC      ASET            # EXIT AND SET R61CNTR
STEP3CK         TC      INTPRET
                SETPD
                        0               # *
                                        # NOW HAVE DCDUS STORED IN T(SAVEDCDU).
                                        # GO CALC OTHER DAP INPUTS (DELCDU,WBODY)
CRS61.2         VLOAD   VSU
                        DCDU
                        SAVEVEL         # DV = VL - VC
                UNIT    VCOMP           # V(MPAC)=-UNITDV. VAC36D=ABSDV.
                VXV     VXSC            # (-UNITDV)CROSS(UNITLOS).
                        SAVEPOS
                        RVCS/RDS        # (UNITLOS B1)(UNITDV B1)(CONST B4)=CROSS.
                PUSH                    # HOLD CROSS IN PUSHLIST0.  SCALED B6.
                DLOAD   NORM            # OBTAIN ABS VALUE OF LOS.
                        P21TIME         # P21TIME IS TEMP STORE FOR ABSLOS.
                        X1
                PUSH                    # NORM ABSLOS(DENOM) AND HOLD IN PUSH1.

                DLOAD   NORM
                        36D             # NORM ABS VALUE OF DV(NUM).
                        S1

                XSU,1   SR1             # X1 = X1(N DENOM)-S1(N NUM).
                        S1              # SR1 TO AVOID OFLOW ON DOV.
                DDV     VXSC            # ABSDV(MPAC)/ABSLOS(PUSH1) = QUOT.
                SXA,1                   # QUOT(MPAC) X CROSS(PUSH0)
                        Q6111           # SAVE SCALE OF RESULT (R-15,1X).
                                        # X1= NORM OF QUOT. QTUOT SCALE B7-B29=B-22
                                        # CROSS IS SCALED B6.  NEED SL1 TO RECOVER
                                        # SR1 SO THAT -22+6+1=-15.  MPAC NOW HOLDS
                                        # ORTHO LOS RATE (OMEGA TH, B-15,X1).
                MXV     VSL1            # OBTAIN RATE IN SM COORDS (OMEGTHSM) AND
                        REFSMMAT        # ADJUST FOR REFSMMAT SCALE OF B1.
                STORE   20D             # OMEGTHSM = VAC20D
                                        # DELTA THETA SM = OMEGTHSM * .1B-3.
                VXSC
                        TENTH
                STORE   DTHETASM        # STORE SM INCREM ANGLES FOR SMCDURES.
```

```
                CALL
                        CDUTRIG         # OBTAIN SIN,COSCDUS FOR SMCDURES.
                SETPD   CALL            # SMCDURES USES PUSH
                        0
                        SMCDURES        # OBTAIN DELCDU IN V(DCDU).
```

Uses A 80, DCDU 211, DSALMOUT 87, DTHETASM 211, DV 241, MPAC 145, N 206, OMEGA 232, P21TIME 179, Q6111 239, R61CNTR 223, REFSMMAT 172, S1 85, SAVE 191, SAVEDCDU 221, SAVEPOS 239, STIKFLAG 99, TC 169, TEMP 191, THETA 148, V 229, VL 229, WBODY 209, and X1 85.

971 ⟨*Page CM0595* 971⟩≡ (913 2752)

```
        LXA,1                   # RELOAD X1
                Q6111
        VLOAD   VSL*            # RECOVER SCALE.
                DCDU            # (B-15,X1) + TENTH(B-3) + HALFREVS(B1)
                0 -17D,1        # EQUALS B-17D,1 TO OBTAIN HALFREVS B0.
        STORE   14D             # HOLD DELS IN V(VAC14D) FOR AUTOPILOT.

        CALL                    # COMPUTES SINES AND COSINES FOR *SMNB*
                CDUTRIG
        VLOAD   CALL            # LOAD VECTOR AND CALL TRANSFORMATION
                20D             # VECTOR FOR TRG*SMNB INTO MPAC
                *SMNB*          # OBTAIN ANG. RATE REFERRED TO NB (BODY)
        MXV
                MBDYTCTL        # CONVERT RATE(OMEGA) TO CONTROL COORDS.
        VXSC                    # MULT. BY 0.8 TO RESCALE REVS TO 450 DEG.
                POINT8          # RECOVER SCALE.
        LXA,1   VSL*            # RELOAD X1 TO RECOVER NORMALIZ.
                Q6111           # (B-15,X1) + MBDYTCTL(B1) = B-14D,1 TO
                0 -14D,1        # OBTAIN REVS SCALED AT 450 DEGREES.

CRS61.2A        EXIT
        INHINT
        CAF     ZERO            # TRANSFER DESIRED GIMBAL ANGLES
        TS      CDUXD   +1      # FROM T(SAVEDCDU) TO V(CDUXD).
        TS      CDUYD   +1
        TS      CDUZD   +1
        CA      SAVEDCDU
        TS      CDUXD
        CA      SAVEDCDU +1
        TS      CDUYD
        CA      SAVEDCDU +2
        TS      CDUZD

        EXTEND                  # TRANSFER OMEGA CONTROL (ANG. LOS RATE)
        DCA     MPAC            # FROM V(MPAC) TO V(WBODY)
        DXCH    WBODY
        EXTEND
        DCA     MPAC    +3
        DXCH    WBODY1
        EXTEND
        DCA     MPAC    +5
        DXCH    WBODY2

        EXTEND                  # TRANSFER CDU INCREMENTS
        INDEX   FIXLOC          # FROM V(VAC14D) TO V(DELCDUX)
```

```
DCA      14D
DXCH     DELCDUX
EXTEND
INDEX    FIXLOC
DCA      16D
```

Uses CDUXD 213, CDUYD 213, CDUZD 213, DCDU 211, DELCDUX 211, FIXLOC 140, MPAC 145, OMEGA 232, Q6111 239, REVS 206, SAVEDCDU 221, V 229, WBODY 209, WBODY1 209, WBODY2 209, and X1 85.

973 ⟨*Page CM0596* 973⟩≡ (913 2752)

```
                DXCH    DELCDUY
                EXTEND
                INDEX   FIXLOC
                DCA     18D
                DXCH    DELCDUZ
                CS      ONE             # NOW DAP VARIABLES LOADED.  SET HOLDFLAG.
                TS      HOLDFLAG        # TO -1.
                RELINT
                TC      ASET
MANUEXIS        TC      INTPRET
MANUEXIT        TLOAD                   # ENTER FROM STEP2.  ACDU-DCDU EXCEEDS
                        SAVEDCDU        # 10 DEG. STORE DCDU(T) IN CPHI,CTHETA,
                STORE   CPHI            # CPSI FOR KALCMANU.
                SLOAD   GOTO            # SPECIAL RETURN (MPAC+0 = 1)
                        LOONE           # OCTAL 00001
                        Q611

R63             STQ     DLOAD           # SUBR TO CALC DCDUS(T)
                        Q6111
                        P21TIME
                STCALL  TDEC1
                        CSMCONIC
HOLDATT         VLOAD                   # HOLD EXTRAPOLATED CSM POSITION AND
                        RATT            # VELOCITY
                STOVL   SAVEPOS
                        VATT
                STORE   SAVEVEL
CALCLEM         DLOAD                   # EXTRAPOLATE LEM STATE VECTOR TO SAVE
                        P21TIME         # TIME AS CSM USING LEMCONIC
                STCALL  TDEC1
                        LEMCONIC
                VLOAD
                        VATT
                STOVL   DCDU            # STORE VATT IN DCDU TEMPORARILY
                        RATT            # LOS = RL RC
                VSU     UNIT
                        SAVEPOS
                STORE   SAVEPOS         # SAVE UNITLOS FOR CRS61.2 RATE CALC.
                MXV     VSL1
                        REFSMMAT        # CONVERT TO STABLE MEMBER
                STODL   POINTVSM
                        36D             # HOLD ABS VAL OF LOS (VAC 36D)
                STORE   P21TIME         # IN D(P21TIME) FOR CRS61.2 RATE CALC.
                VLOAD
                        UNITX
```

```
STCALL  SCAXIS          # TRACK AXIS UNIT VECTOR
        VECPOINT        # FOR +X-AXIS TRACKING ATTITUDE
STORE   CPHIX           # STORE ANGLES FOR N96 DISPLAY
VLOAD
        PRFUNIT
```

Uses CPHI 157, CPHIX 163, CPSI 157, CTHETA 157, D 226, DCDU 211, DELCDUY 211, DELCDUZ 211, FIXLOC 140, HOLDFLAG 163, MPAC 145, P21TIME 179, POINTVSM 219, Q611 239, Q6111 239, REFSMMAT 172, SAVE 191, SAVEDCDU 221, SAVEPOS 239, SCAXIS 219, STATE 138, and TC 169.

975 ⟨*Page CM0597* 975⟩≡ (913 2752)

```
                STCALL  SCAXIS
                        VECPOINT
                STORE   PRAXIS          # STORE ANGLES FOR N95 DISPLAY
                BOFF
                        PRFTRKAT
                        CRSTOR1
CRSTOR          STORE   THETAD          # STORE ANGLES FOR N18 DISPLAY
                GOTO
                        Q6111
CRSTOR1         VLOAD
                        UNITX
                STORE   SCAXIS
                TLOAD   GOTO
                        CPHIX
                        CRSTOR
PRFUNIT         2DEC    .40957602       # 55 DEG TRACK AXIS UNIT VECTOR

                2DEC    0.0             # FOR USE WITH VECPOINT

                2DEC    .28678822

DEGREE10        DEC     .05556          # 10 DEG IN REVS                STEP2
RVCS/RDS        2DEC    15.915494 B-4   # 100/2PI REV-CSEC/RAD-SEC.

TENTH           2DEC    .1 B+3          # .1 B-3 (TO SCALE ANG. RATE TO .1 INREMS)

MAT1B1          2DEC    1.0 B-1

MBDYTCTL        2DEC    .5              #               7.25 DEG NEGATIVE

                2DEC    0               #               X-AXIS ROTATION MATRIX

                2DEC    0               #               CONVERTS BODY TO CTL

                2DEC    0               #               AXES.  CAME AS QUADROT

                2DEC    .99200495 B-1   # COS7.25 B1    BUT SCALED B

                2DEC    -.12619897 B-1  # -SIN7.25 B1

                2DEC    0

                2DEC    .12619897 B-1   # SIN7.25 B1

                2DEC    .99200495 B-1   # COS7.25 B1
```

```
LOONE           OCT     00001           # TO SET MPAC = 00001 FOR SPECIAL EXIT.
FURST3          EQUALS  13,14,15        # CONSTANT FOR AUTOCK (OCT 70000).
```

Uses CPHIX 163, MPAC 145, PRFTRKAT 115, Q6111 239, RAD 219, REVS 206, SCAXIS 219, and THETAD 157.

977 ⟨*Page CM0598* 977⟩≡ (913 2752)

```
# ..... S22.1 ORBITAL NAVIGATION ROUTINE
# MOD 1
#
# FUNCTIONAL DESCRIPTION
#       1.  UPDATE CSM STATE VECTOR
#       2.  UPDATE LANDMARK POSITION
#       3.  CONVERT W MATRIX FROM 9 TO 6 DIMENSIONS
#
# SUBROUTINES CALLED
#       INTSTALL,INTEGRV,GETNUM,SETRE,R-TO-TP,RP-TO-R,BVECTORS,INCORP1,INCORP2
#       LALOTORV,S22F2410,LAT-LONG,ROWDOT
#
# ERASABLE INITIALIZATION
#       W=9X9 MATRIX
#       ORBWFLAG=0 FOR INVALID W MATRIX, =1 FOR VALID W MATRIX
#       ASTRONAUT ENTRY OF KNOWN,L,OFF
#       8NN= NUMBER OF MARKS, DECIMAL INTEGER B-14
#       REFSMMAT= TRANSFORMATION MATRIX
#       MARKSTAT= ADDRESS OF START OF MARK DATA (MARK DATA OF EACH MARK IS
#                 STORED AS FOLLOWS: TIME,AIG,SA,AMG,PA,AOG) TIME IS IN DOUBLE
#                 PRECISION, ALL OTHERS ARE IN SINGLE PRECISION
#       CSM STATE VECTOR
#
# OUTPUT
#       UPDATED CSM STATE VECTOR
#       UPDATED LANDMARK POSITION
#       NEW 6 DIMENSIONAL W MATRIX
#
# DEBRIS
#       PUSH LIST,CSMPOS,ALPHAV,ERADM,UM,RCLP,USTAR,VARIANCE,X789,BVECTOR,8KK,
#       S22LOC,SVMRKDAT TABLE,22SUBSCL,LANDMARK,CXOFF,S22C,LAT,LOG,ALT,
#       TEMPOR1,S22TOFF,S221OFF,DSPTEM1,S22EORM,S22TPRIM

                BANK    13

                SETLOC  P20S6
                BANK

                EBANK=  LANDMARK
                COUNT   35/LUORB

S22.1           STQ     SSP
                        S22RTNEX
                        S1
                DEC     6
```

```
SSP     SSP             # SET I=1       ITEM 8KK IS I
        8KK
DEC     1
        S22LOC
ECADR   SVMRKDAT        # SET MARK DATA ADDRESS INTO S22LOC
```

Uses 22SUBSCL 190, 8KK 190, 8NN 190, AIG 214, ALPHAV 177, ALT 157, AMG 214, AOG 214, BVECTOR 232, COUNT 142, CSMPOS 161, CXOFF 190, DSPTEM1 154, EBANK 80, ERADM 177, I 206, L 80, LANDMARK 190, LAT 157, LONG 157, MARKSTAT 163, ORBITAL 59, ORBWFLAG 107, P20S6 67, RCLP 232, REFSMMAT 172, S1 85, S22EORM 239, S22LOC 190, S22RTNEX 239, S22TOFF 239, S22TPRIM 239, STATE 138, SVMRKDAT 232, TEMPOR1 161, UM 161, USTAR 161, VARIANCE 232, W 183, and X789 172.

979 ⟨*Page CM0599* 979⟩≡ (913 2752)

```
                LXC,2   AXT,1
                        MARKSTAT
                DEC     36
S22.111         VLOAD*                  # MOVE MARK DATA (5 SETS FROM ADDR. IN
                        0,2             # MARKSTAT TO SVMRKDAT TABLE TO AVOID LOSS
                STORE   SVMRKDAT +36D,1 # IF RESTART OCCURS
                INCR,2  TIX,1
                DEC     -6
                        S22.111
                SET     EXIT
                        P22MKFLG        # DOWNLINKED SVMRKDAT HOLDS PRESENT MARKS
                TC      BANKCALL        # RELEASE VAC AREA WHERE MARK DATA WAS
                CADR    MKRELEAS
                TC      2PHSCHNG
                OCT     00004
                OCT     05022
                OCT     13000
                TC      INTPRET
                AXT,1   BOFF
                        0D
                        CMOONFLG        # =0 EARTH, =1 MOON
                        S22SHIFT
                INCR,1
                DEC     -2
S22SHIFT        SXA,1   SETPD
                        S22EORM         # SET =0 EARTH, =-2 MOON FOR SHIFTING
                        0D
FIG2EXIT        CALL
                        INTSTALL
                CALL
                        S22FLGS
#       FLOWCHART D=0   THEN DIM0FLAG=0, D6O9FLG NOT TESTED
#       FLOWCHART D=6   THEN DIM0FLAG=1, D6OR9FLG=0
#       FLOWCHART D=9   THEN DIM0FLAG=1, D6OR9FLG=1

                BOFF    CLRGO
                        ORBWFLAG
                        SETWW5D         # BRANCH TO SET W0-W5,ORBWFLAG,D
                        D6OR9FLG        # FLOWCHART D=6 PATH
                        SETVANDI
SETWW5D         CLEAR
                        DIM0FLAG        # FLOWCHART D=0 PATH
                AXT,1   SSP
                DEC     108
                        S1
```

```
                DEC     6
                CLEAR   VLOAD
                        RENDWFLG        # GSOP CHANGE 8/18/67
                        ZEROVECS
CLEARWW5        STORE   W +108D,1
```

Uses CMOONFLG 125, D 226, D6OR9FLG 109, DIMOFLAG 109, MARKSTAT 163, ORBWFLAG 107, P22MKFLG 107, RENDWFLG 117, RESTART 57, S1 85, S22EORM 239, SVMRKDAT 232, TC 169, and W 183.

981 ⟨*Page CM0600* 981⟩≡ (913 2752)

```
                TIX,1   SLOAD
                        CLEARWW5
                        WORBPOS
                STORE   W               # SET DIAGONALS OF W0
                STORE   W +8D
                STORE   W +16D
                SLOAD
                        WORBVEL
                STORE   W +72D          # SET DIAGONALS OF W4
                STORE   W +80D
                STORE   W +88D
SETVANDI        CLEAR
                        DMENFLG         # 0=6X6W, 1=9X9W
S22NXTIN        CALL
                        GETTF
                STCALL  TDEC1
                        INTEGRV
                CALL
                        S22CALRC        # CALC. RC B-29 OR B-27 (CSMPOS)
                LXA,1   SXA,1
                        S22LOC          # SETUP ADDR. OF MARK DATA FOR GETUM SUBR.
                        MARKDATA
                CALL                    # COMPUTE UM
S2GETUM                 GETUM
                STORE   UM
DMPINTEG        SLOAD   PUSH            # TEST OFF=I
                        8KK
                SLOAD   SR3             # CXOFF SCALED B-5, MUST MOVE TO B-14
                        CXOFF           # BEFORE SUBT.
                SR3     SR3
                DSU
                BHIZ    BON
                        S22OFF=I        # BRANCH HERE IF OFF=I
                        DMENFLG         # 0=6X6W, 1=9X9W
                        S22D=9
                CALL
                        GRP2PC
                SET
                        ORBWFLAG
                SET     SET
                        DMENFLG         # =0 ON FIRST PASS THRU HERE FOR D=0, OR 6
                        22DSPFLG        # =1 TO DISPLAY DR,DV ON FIRST PASS
                SET     BON
                        ERADFLAG        # =1 TO COMPUTE FISCHER RADIUS
                        KNOWNFLG
```

```
        S22BOX22
VLOAD   UNIT            # UNIT ALSO PUTS ABVAL(RC) IN 36D
        CSMPOS
STORE   ALPHAV          # ALPHAV +4=SINL FOR SETRE
CLEAR   BOFF
```

Uses 22DSPFLG 103, 8KK 190, ALPHAV 177, CSMPOS 161, CXOFF 190, D 226, DMENFLG 115, DV 241, ERADFLAG 99, I 206, KNOWNFLG 119, MARKDATA 161, ORBWFLAG 107, S22LOC 190, UM 161, W 183, WORBPOS 175, and WORBVEL 175.

983 ⟨*Page CM0601* 983⟩≡ (913 2752)

```
                        LUNAFLAG
                        CMOONFLG
                        S22C=I
                SET
                        LUNAFLAG
S22C=I          CALL                    # ERADM= R0 METERS B-29 BOTH EARTH/MOON
                        SETRE
                CALL                    # COMPUTE RL FROM EQUATION 2.4.10
                        S22F2410        # STORED IN X789,MPAC B-27,B-29
                BOFF    VSR2            # SCALE RL B-29 FOR BOTH EARTH/MOON
                        CMOONFLG
                        +1
                STORE   S22RL
                DOT     SL1
                        UM
                STOVL   S22D            # D=UM RL B-29
                        ZEROVECS
                SETPD   PUSH
                        0D
                PUSH    PDDL            # SET 0-18D = I BACKWARDS
                        HIDPHALF        # PD 18
                SR2                     # B-3
                STORE   4D
                STORE   8D
                STOVL   12D
                        UM              # B-1
                STOVL   S223X1
                        S22RL           # B-29
                CALL                    # (UM)(RL T) B-30 STORED IN S22UMRL THRU
                        S2231X13        # S22UMRL +17D
                AXT,1   SSP
                DEC     18
                        S1
                DEC     6
S22NXTU         VLOAD*  VSR2            # (UM)(RL T) B-32
                        S22UMRL +18D,1
                V/SC
                        S22D            # D B-29
                BVSU    STADR           # SUBTRACT FROM I B-3
                STORE   S22UMRL +18D,1  # U MATRIX B-3
                TIX,1   AXT,1           # PD 0 AFTER TIX
                        S22NXTU
                DEC     36              # S1 STILL 6 FROM ABOVE
S22NXTWI        VLOAD*  MXV
                        W +36D,1        # B-19
```

```
        S22UMRL         # B-3
VSL3
STORE   W +144D,1       # W(I+18)= UW(I) B-19
TIX,1   DLOAD
        S22NXTWI
```

Uses CMOONFLG 125, D 226, ERADM 177, HIDPHALF 71, I 206, LUNAFLAG 107, MPAC 145, S1 85, UM 161, V 229, W 183, and X789 172.

985 ⟨*Page CM0602* 985⟩≡ (913 2752)

```
                        S22RHO          # B-28,B-30
                BOFF    SR2             # MAKE RHO B-30
                        CMOONFLG
                        +1
                NORM    XAD,2
                        X2
                        X2
                DSQ     DMP
                        SCTVAR          # B+16
                SR1                     # ACCOUNTS FOR 1/2 IN NEXT FORMULA
                STORE   S22RHO          # 1/2(RHO SQ)(VARSCT)
                AXT,1
                DEC     18              # S1 STILL 6 FROM ABOVE
S22NXXA         VLOAD*  MXV
                        S22UMRL +18D,1  # B-3
                        S22UMRL         # B-3
                VXSC    VSR*
                        S22RHO
                        0 -12D,2        # WITH VARRP SCALED B-28
                STORE   S22UUT +18D,1   # 1/2(RHO SQ)(VARSCT)(U)(U T)
                TIX,1   VLOAD
                        S22NXXA
                        UM
                STCALL  S223X1          # UM ALSO IN MPAC FOR S2231X13 SUBR.
                        S2231X13        # (UM)(UM T) B-2 IN S22UMRL,P17D
                DLOAD   SR3
                        ERADM           # B0 B-29
                DDV     DSQ
                        S22D            # B-29
                DMP
                        RPVAR           # ***** METERS SQ
                STORE   S22RHO          # TEMP (VARRP)(R0/D)
                AXT,1
                DEC     18              # S1 STILL 6 FROM ABOVE
S22NXXB         VLOAD*  VXSC
                        S22UMRL +18D,1  # (UM)(UM T) B-2
                        S22RHO
                VAD*
                        S22UUT +18D,1
                STORE   S22UUT +18D,1   # SMALL E MATRIX
                VLOAD
                        ZEROVECS
                STORE   W +162D,1       # CLEAR W8
                TIX,1   BOV
                        S22NXXB
```

```
        +1
DLOAD   BMN
        S22UUT +16D     # E5
        S22W76X
SQRT    BZE
```

Uses CMOONFLG 125, D 226, ERADM 177, MPAC 145, RHO 211, RPVAR 175, S1 85, SQ 156, TEMP 191, UM 161, W 183, and X2 85.

987 ⟨*Page CM0603* 987⟩≡ (913 2752)

```
                        S22W76X
                STODL   W +148D         # W74= SQ ROOT E5
                        S22UUT +14D     # E4
                DDV     BOV
                        W +148D
                        S22W72X
                STORE   W +146D         # W73= E4/W74
S22W72X         DLOAD   DDV
                        S22UUT +12D     # E3
                        W +148D
                BOV
                        S22W76X
                STORE   W +144D         # W72= E4/W74
S22W76X         DLOAD   DSQ
                        W +146D         # W73
                BDSU    BMN
                        S22UUT +8D      # E2
                        S22W78X
                SQRT    BZE
                        S22W78X
                STODL   W +152D         # W76= SQ ROOT (E2-W73 SQ)
                        W +144D         # W72
                DMP     BDSU
                        W +146D         # W73
                        S22UUT +6D      # E1
                DDV     BOV
                        W +152D         # W76
                        S22W78X
                STORE   W +150D         # W75= (E1-W72W73)/W76
S22W78X         DLOAD   DSQ
                        W +150D
                PDDL    DSQ
                        W +144D         # W72
                DAD
                BDSU    BMN
                        S22UUT          # E0
                        S22SCLW
                SQRT
                STORE   W +156D         # W78= SQ RT(E0-W72 SQ-W75 SQ)
S22SCLW         VLOAD   VSR1            # SCALE W6 METERS B-19
                        W +144D
                STOVL   W +144D
                        W +150D
                VSR1
                STOVL   W +150D
```

```
                        W +156D
                VSR1
                STORE   W +156D
S22SAVET        CALL
                        GETTF
```

Uses E2 236, RT 226, SQ 156, and W 183.

989 ⟨*Page CM0604* 989⟩≡ (913 2752)

```
                STORE   S22TPRIM        # SAVE PRESENT TIME FOR PIOS
S22I=N          EXIT                    # TEST I=N
                TC      PHASCHNG
                OCT     04022
                CS      8KK
                AD      8NN
                EXTEND
                BZMF    S22F244X        # EXIT TO FIGURE 2.4-4
                CA      8KK             # I=I+1
                AD      ONE
                TS      TEMPOR1
                CA      S22LOC          # ADD 7 TO LOC TO GET ADDR. OF NEXT MARK
                AD      SEVEN
                TS      TEMPOR1 +1
                TC      PHASCHNG
                OCT     04022
                CA      TEMPOR1
                TS      8KK
                CA      TEMPOR1 +1
                TS      S22LOC
                TC      INTPRET
                CALL                    # FOR ALL INTEGRATIONS OTHER THAN FIRST
S2INTS1                 INTSTALL
                CALL
                        S22FLGS
                BON     CLEAR
                        DMENFLG
                        S22NXTIN        # RETURN ALWAYS EXCEPT OFFSET POINT MARK 1
                        DIMOFLAG
                BOFF    SET
                        ORBWFLAG
                        S22NXTIN        # OFFSET POINT MARK 1, NO W INTEGRATION
                        DIMOFLAG
                CLRGO
                        D6OR9FLG
                        S22NXTIN        # OFFSET POINT MARK 1, INTEGRATE W 6X6
S22OFF=I        CALL
                        GETTF
                STOVL   S22TOFF         # TIME SUB OFF
                        UM
                STCALL  S22UOFF         # U SUB OFF
                        S22I=N          # TEST I=N
S22D=9          VLOAD                   # D=9 PATH
                        X789
                STODL   OD              # CALL PIOS TWICE TO TRANSFORM RL TO TIME
```

```
                        S22TPRIM        # T(SUB F) FROM TIME T PRIME
                STORE   6D
                SLOAD   CALL
                        S22EORM         # 0=EARTH, NON-ZERO=MOON
S2RTRP                  R-TO-RP
```

Uses 8KK 190, 8NN 190, D 226, D6OR9FLG 109, DIMOFLAG 109, DMENFLG 115, F 238, I 206, LOC 145, N 206, ORBWFLAG 107, S22EORM 239, S22LOC 190, S22TOFF 239, S22TPRIM 239, SAVE 191, TC 169, TEMPOR1 161, UM 161, W 183, and X789 172.

991 ⟨*Page CM0605* 991⟩≡ (913 2752)

```
                PUSH    CALL            # R-TO-RP LEAVES PUSHLOC AT 0
                        GETTF
                STORE   6D
                SLOAD   CALL
                        S22EORM
S2RPTR                  RP-TO-R
S22BOX32        STORE   X789
                SET     BOV
                        INCORFLG        # FLAG=1
                        +1              # CLEAR OVERFLOW
                VSU
                        CSMPOS
                STORE   RCLP            # RCL=RL-RC
                UNIT    VXV             # USTAR=UNIT(UNIT(RCL)XUM)
                        UM
                UNIT    BOV
                        S22SAVET        # COMPUTATION OVERFLOW, SAVE TF
                STORE   USTAR
S22BOX12        SET     SET
                        DMENFLG         # =1 FOR 9X9 W
                        VEHUPFLG        # =1 FOR CSM
                DLOAD   DAD
                        SCTVAR          # B+18
                        IMUVARR         # B+18
                STOVL   VARIANCE
                        RCLP            # B-29 OR B-27
                ABVAL   NORM
                        X1
                DSQ     DMP
                        VARIANCE
                XAD,1   XAD,1
                        X1              # DOUBLE NORM SHIFT SINCE RCLP WAS SQUARED
                        S22EORM         # DOUBLE EARTH OR MOON SHIFT, SAME REASON
                XAD,1   SR*
                        S22EORM
                        0,1             # SCALE VARIANCE B-40 FOR BOTH EARTH, MOON
                TLOAD                   # CHANGE MODE TO TRIPLE
                        MPAC
                STCALL  VARIANCE        # CALC B0,B1,DELTAQ, NEW USTAR
S2BVTRS                 BVECTORS
                VLOAD   VCOMP
                        BVECTOR
                STCALL  BVECTOR +12D    # B2=-B0
S2INCP1                 INCORP1
                CALL
```

```
                GRP2PC
        BOFF    CLEAR
                22DSPFLG        # =1 DISPLAY DELTA R,V    =0 DO NOT
                S22BOX42
                22DSPFLG
```

Uses 22DSPFLG 103, BVECTOR 232, CSMPOS 161, DELTAQ 232, DMENFLG 115, INCORFLG 115, MODE 145, MPAC 145, PUSHLOC 145, RCL 161, RCLP 232, S22EORM 239, SAVE 191, SR 80, UM 161, USTAR 161, V 229, VARIANCE 232, VEHUPFLG 99, W 183, X1 85, and X789 172.

993 ⟨*Page CM0606* 993⟩≡ (913 2752)

```
                CALL
                        GRP2PC
                VLOAD   ABVAL
                        DELTAX          # DELTA R
                LXA,1   SR*
                        S22EORM         # SCALE DELTA R ALWAYS METERS B-29
                        0,1
                STOVL   N49DISP
                        DELTAX +6       # DELTA V
                ABVAL   SR*             # DELTA V=METERS/CSEC B-7 ALWAYS
                        0,1
                STORE   N49DISP +2
                EXIT
                CAF     V06N49EE
                TC      BANKCALL
                CADR    GOFLASHR
                TC      GOTOP00H        # V34E TERMINATE
                TC      +5              # INCORPORATE CHANGES
                TC      S22EXEX         # V32E RECYCLE
                CAF     BIT3
                TC      BLANKET
                TC      ENDOFJOB
                TC      INTPRET
S22BOX42        CALL
                        INCORP2
                CALL                    # CSMPOS=RC B-29 OR B-27
                        S22CALRC
DMPINCP2        BOFF    CALL
                        INCORFLG
                        S22SAVET        # SAVE TF AND TEST I=N
                        GRP2PC
                CLEAR   VLOAD
                        INCORFLG        # FLAG=0
                        X789
                VSU
                        CSMPOS
                STCALL  RCLP            # RCL=RL-RC
                        S22BOX12
S22BOX22        AXT,1   SSP             # CLEAR W6,W7,W8.  (27 ELEMENTS 54 REGS)
                DEC     54
                        S1
                DEC     6
                VLOAD
                        ZEROVECS
CLRW678         STORE   W +162D,1
```

```
TIX,1   SLOAD
        CLRW678
        S22WSUBL
STORE   W +144D
STORE   W +152D
```

Uses CSMPOS 161, DELTAX 161, I 206, INCORFLG 115, N 206, N49DISP 232, RCL 161, RCLP 232, S1 85, S22EORM 239, S22WSUBL 175, SAVE 191, SR 80, TC 169, V 229, W 183, and X789 172.

995 ⟨*Page CM0607* 995⟩≡ (913 2752)

```
                STORE   W +160D
                CLEAR   BOFF            # SET LUNAFLAG, TIME FOR LALOTORV
                        LUNAFLAG        # ERADFLAG,LAT,LONG,ALT SET PREVIOUSLY
                        CMOONFLG        # CHECK SCALING OF ITEMS,ALT INPUT AND
                        S22BX22A        # RL OUTPUT IN ALPHAV BOTH B-29
                SET
                        LUNAFLAG
S22BX22A        CALL
                        GETTF
                CALL                    # COMPUTE RL
                        LALOTORV
                VLOAD   BOFF
                        ALPHAV          # RL B-29
                        CMOONFLG
                        S22BX22B
                VSL2                    # SCALE RL B-27 FOR MOON
S22BX22B        GOTO
                        S22BOX32
S22F244X        TC      INTPRET
S22F244         SLOAD   BHIZ            # FIG 2.4-4     TEST OFF=0
                        CXOFF
                        S22BOX44
                SR                      # SCALE OFFSET B-14 THEN GET GR. 8NN
                        9D
                STORE   ALPHAV          # TEMP
                SLOAD   DSU
                        8NN
                        ALPHAV
                BMN     CALL            # OFFSET GR. NO. MARKS.  FORGET IT
                        S22BOX44
                        GRP2PC          # GROUP 2 PHASE CHANGE
                DLOAD
                        S22TOFF
                STCALL  TDEC1           # CALC RC AT OFFSET TIME
                        CSMPREC
                VLOAD
                        RATT1           # RC METERS B-29 OR B-27
                STOVL   CSMPOS
                        S22UOFF
                STOVL   UM              # U=UOFF
                        X789
                ABVAL   BOFF
                        CMOONFLG
                        +2
                SR2                     # SCALE MOON R0 B-29 FOR S22F2410 SUBR
```

```
                STCALL  ERADM
                        S22F2410
                GOTO
                        S22BX44A
S22BOX44        CALL
```

Uses 8NN 190, ALPHAV 177, ALT 157, CMOONFLG 125, CSMPOS 161, CXOFF 190, ERADFLAG 99, ERADM 177, IT 185, LAT 157, LONG 157, LUNAFLAG 107, S22TOFF 239, SR 80, TC 169, TEMP 191, UM 161, W 183, and X789 172.

997 ⟨*Page CM0608* 997⟩≡ (913 2752)

```
                        GETTF
                STORE   S22TOFF         # PRESENT TIME FOR LAT-LONG SETUP
S22BX44A        CLEAR   VLOAD
                        LUNAFLAG
                        X789
                BOFF    SET
                        CMOONFLG
                        S22BX44B
                        LUNAFLAG        # SET = 1 FOR LAT-LONG
                VSR2                    # SCALE RL MOON B-29 FOR LAT-LONG
S22BX44B        STODL   ALPHAV          # RL SCALED B-29 FOR LAT-LONG
                        S22TOFF         # EITHER PRESENT OR OFFSET TIME
                CALL
                        LAT-LONG        # **** ALT OUTPUT ALWAYS B-29
                CALL                    # DISPLAY LAT/LONG/ALT
                        LLASRD
                EXIT
                CAF     V06N89B
                TC      BANKCALL
                CADR    GOFLASH
                TC      S22GTP          # V34E TERMINATE
                TC      +2              # PROCEED       SAVE LANDING SITE COORD
                TC      S22.981X        # RECYCLE       POINT A IN GSOP
                TC      INTPRET
                DLOAD
                        S22TOFF         # EITHER PRESENT OR OFFSET TIME
                STOVL   6D              # 6-7D= LANDING SITE TIME FOR R-TO-RP
                        X789
                STORE   0D              # 0-5D= LANDING SITE VEC FOR R-TO-RP
                SLOAD   CALL
                        HIDPHALF        # ANY NON-ZERO FOR MOON
                        R-TO-RP         # CONVERT RLS TO MOON-FIXED COORD
                STORE   RLS             # LANDING SITE VECTOR
                EXIT
S22.981X        TC      INTPRET
                CALL
                        9DWTO6DW
                EXIT                    # GO TO POINT A IN CHAPTER 5
S22EXEX         TC      INTPRET         # WITHOUT CONVERTING W
                GOTO
                        S22RTNEX

S22GTP          TC      INTPRET         # CONVERT W BEFORE TC GOTOP00H
                CALL
                        9DWTO6DW
```

```
                EXIT
                TC      GOTOPOOH
S22F2410        SETPD   VLOAD           # COMPUTE FORMULA 2.4.10
                        OD
                        CSMPOS          # RC B-29 EARTH, B-27 MOON
```

Uses A 80, ALPHAV 177, ALT 157, CMOONFLG 125, CSMPOS 161, HIDPHALF 71, LAT 157, LONG 157, LUNAFLAG 107, RLS 175, S22RTNEX 239, S22TOFF 239, SAVE 191, TC 169, W 183, and X789 172.

999 ⟨*Page CM0609* 999⟩≡ (913 2752)

```
                UNIT    DOT             # UNIT ALSO SETS 36D=ABVAL(RC) USED BELOW
                        UM
                SL1     DCOMP           # GSOP CHANGE 8/18/67
                PUSH                    # PD 2D 8D=COSA=-(UM.RC)/ABVAL(RC)      B-1
                DSQ     BDSU
                        DEC1B2
                PDDL    BOFF            # PD 4D 2D=1-COSA SQ=SINA SQ            B-2
                        ERADM           # R0 ALWAYS B-29 FROM SETRE
                        CMOONFLG
                        +2
                SL2                     # SCALE R0 B-27 FOR MOON
                SR1R    DDV             # (R0/RC)       B-1
                        36D
                DSQ     DSU             # PD 2D (RP/RC) SQ - SINA SQ            B-2
                SQRT    BDSU            # PD 0D COSA-SQRT((R0/RC)SQ-SINA SQ)    B-1
                DMP                     # DMP RESULT B-28 MOON, B-30 EARTH
                        36D             # VXSC RESULT B-29 MOON, B-31 EARTH
                STORE   S22RHO          # RHO FOR W INIT. OF UNKNOWN LMK B-28,B-30
                VXSC
                        UM
                VSL2    VAD             # SCALE B-27 MOON, B-29 EARTH AND ADD RC
                        CSMPOS
                STORE   X789
                RVQ                     # B-27 FOR EARTH OR B-29 FOR MOON
S22CALRC        LXA,1   VLOAD           # COMPUTE RC B-29 OR B-27
                        S22EORM         # =0 FOR EARTH, -2 FOR MOON
                        DELTACSM
                VSR*    VAD
                        7,1
                        RCVCSM
                STORE   CSMPOS
                RVQ
                SETLOC  P22S
                BANK

S2231X13        STORE   S221X3          # MULT 3X1 BY 1X3, STORE RESULTING 3X3 IN
                SSP     AXT,2           # S22UMRL - S22UMRL+17D
                        S2
                DEC     2
                DEC     6
                AXT,1
                DEC     18
S2231NXT        VLOAD   VXSC*
                        S221X3
                        S223X1  +6,2
```

```
STORE   S22UMRL +18D,1
INCR,1  TIX,2
DEC     -6
        S2231NXT
RVQ
```

Uses CMOONFLG 125, CSMPOS 161, DELTACSM 172, ERADM 177, P22S 67, RCVCSM 172, RHO 211, S2 85, S22EORM 239, SQ 156, UM 161, W 183, and X789 172.

1001 ⟨*Page CM0610* 1001⟩≡ (913 2752)

```
GETTF           LXC,1   DLOAD*          # SET MPAC= TF
                        S22LOC
                        0,1
                RVQ
S22FLGS         SET     SET             # INTEGRATION FLAGS
                        DIMOFLAG
                        D6OR9FLG
                SET     SET
                        VINTFLAG
                        STATEFLG
                CLEAR   RVQ
                        INTYPFLG

# SUBROUTINE TO MODIFY ALT AND STORE LAT TO LAT+5 IN LANDLAT TO LANDLAT+5
# PRIOR TO DISPLAY.

LLASRD          DLOAD                   # ALT, LANDALT METERS B-29
                        ALT
                STODL   LANDALT
                        LONG
                SR1
                STORE   LANDLONG
                RVQ

# SUBROUTINE TO MODIFY LANDALT AND STORE LANDALT TO LANDALT+5 IN LAT TO
# LAT+5 AFTER LMK DATA LOADED BY ASTRONAUT.

LLASRDA         DLOAD                   # ALT, LANDALT METERS B-29
                        LANDALT
                STODL   ALT
                        LANDLONG
                SL1
                STORE   LONG
                RVQ
                SETLOC  P20S6
                BANK

9DWTO6DW        STQ     SETPD
                        9DWXX
                        OD
                VLOAD   PUSH            # CLEAR WORKING AREA OF PUSHLIST
                        HI6ZEROS        # INCLUDING P
                PUSH    PUSH            # PD 18D
                SSP
                        9DWJ            # J=29  USE 2*29 FOR DP WORDS
```

```
                DEC     58
9DWI=J          LXA,1   SXA,1           # SET I=J
                        9DWJ
                        9DWI
9DWEPCAL        CALL
```

Uses ALT 157, D6OR9FLG 109, DIMOFLAG 109, HI6ZEROS 71, I 206, INTYPFLG 107, LANDALT 181, LANDLAT 157, LANDLONG 181, LAT 157, LONG 157, MPAC 145, P 188, P20S6 67, S22LOC 190, STATEFLG 107, and VINTFLAG 109.

1003 ⟨*Page CM0611* 1003⟩≡ (913 2752)

```
                        ROWDOT
                LXA,1                   # P VARIES 0-20 INSTEAD OF 20-0
                        9DWP
                STORE   EMATRIX +40D,1
                INCR,1  SXA,1
                DEC     2
                        9DWP
                SLOAD   BHIZ            # TEST I=0
                        9DWI
                        9DWTESTJ
                DSU                     # I=I-1
                        9DWID
                STORE   9DWI
                DSU     BHIZ            # TEST I=26
                        9DW26D
                        9DWSETI2
                GOTO                    # NEXT E SUB P
                        9DWEPCAL
9DWSETI2        SSP     GOTO            # I=2
                        9DWI
                DEC     4
                        9DWEPCAL
9DWTESTJ        SLOAD   BHIZ            # TEST J=0
                        9DWJ
                        9DWFIG6
                DSU
                        9DWID
                STORE   9DWJ            # J=J-1
                DSU     BHIZ            # TEST J=26
                        9DW26D
                        9DWSETJ2
                GOTO
                        9DWI=J
9DWSETJ2        SSP     GOTO            # SET J=2
                        9DWJ
                DEC     4
                        9DWI=J
9DWFIG6         CALL
                        GRP2PC
                SSP     VLOAD           # START OF FIGURE 2.4-6
                        9DWJ            # J=29
                DEC     58
                        HI6ZEROS
                STORE   9DWP            # P,N,I=0
                AXT,1   SSP
```

```
                DEC     108             # CLEAR W0 TO W54
                        S1
                        6
  CLEARW54      STORE   W +108D,1
                TIX,1
```

Uses EMATRIX 183, HI6ZEROS 71, I 206, N 206, P 188, S1 85, and W 183.

1005 ⟨*Page CM0612* 1005⟩≡ (913 2752)

```
                        CLEARW54
9DWI=JA         LXA,1   SXA,1           # I=J
                        9DWJ
                        9DWI
                CALL
                        ROWDOT
                LXA,1   BDSU*
                        9DWP
                        EMATRIX +40D,1
                INCR,1  SXA,1           # -(P+1)
                        2
                        9DWP
                LXC,1   XSU,1           # -(I+N)
                        9DWI
                        9DWN
                BPL     DLOAD           # TEST WSQ LTE 0
                        9DWAAA
                        HI6ZEROS        # W=0
                GOTO
                        9DWAAB
9DWAAA          SQRT                    # W= SQRT(WSQ)
9DWAAB          STORE   W,1
                STODL   WORKW
                        9DWJ            # TEST J=0
                BHIZ
                        9DWEXITX        # EXIT
TST2I=0         SLOAD   BHIZ            # TEST I=0
                        9DWI
                        9DWN=N+3
                DSU
                        9DWID
                STORE   9DWI            # I=I-1
                DSU     BHIZ            # TEST I=26
                        9DW26D
                        9DWAAC
                GOTO
                        9DWNEXEP
9DWAAC          SSP                     # I=2
                        9DWI
                        4
9DWNEXEP        CALL
                        ROWDOT
                LXA,1   BDSU*           # (EP-ROWI*ROWJ)/W
                        9DWP
                        EMATRIX +40D,1
```

```
DDV     INCR,1          # P=P+1
        WORKW
        2
SXA,1   LXC,1
        9DWP
```

Uses EMATRIX 183, HI6ZEROS 71, I 206, N 206, P 188, and W 183.

1007 ⟨*Page CM0613* 1007⟩≡ (913 2752)

```
                        9DWI
                XSU,1   BOV             # -(I+N)
                        9DWN
                        SETWIN=0
                GOTO
                        9DWSETWX
SETWIN=0        DLOAD                   # W(I+N)=0
                        HI6ZEROS
9DWSETWX        STORE   W,1
                GOTO
                        TST2I=0
9DWN=N+3        LXA,1   INCR,1          # N=N+3
                        9DWN
                        6
                SXA,1   SLOAD           # J=J-1
                        9DWN
                        9DWJ
                DSU
                        9DWID
                STORE   9DWJ
                DSU     BHIZ            # TEST J=26
                        9DW26D
                        SETJ=2A
                GOTO
                        9DWI=JA
SETJ=2A         SSP     GOTO            # J=2
                        9DWJ
                        4
                        9DWI=JA
9DWEXITX        CALL
                        GRP2PC
                AXT,1   SSP             # CLEAR W6,W7,W8 USED TEMP FOR EMATRIX
                DEC     54
                        S1
                        6
                VLOAD
                        HI6ZEROS
9DWEXXXA        STORE   W +162D,1
                TIX,1   GOTO
                        9DWEXXXA
                        9DWXX
ROWDOT          SSP     BOV
                        XTMP1
                OCT     377
                        +1
```

```
LXC,1   LXC,2
        9DWI
        9DWJ
DLOAD   PUSH
        HI6ZEROS
```

Uses EMATRIX 183, HI6ZEROS 71, I 206, N 206, S1 85, TEMP 191, and W 183.

1009 ⟨*Page CM0614* 1009⟩≡ (913 2752)

```
ROWDOT1         DLOAD*  DMPR*
                        W,1
                        W,2
                DAD     PUSH
                BOV     INCR,1
                        ROWDOT3
                DEC     -6
                INCR,2  SLOAD
                DEC     -6
                        XTMP1
                BHIZ    SR1
                        ROWDOT2
                STORE   XTMP1
                GOTO
                        ROWDOT1
ROWDOT2         DLOAD
                RVQ
ROWDOT3         CLRGO
                        ORBWFLAG
                        ROWDOT2
WORKW           =       0D
XTMP1           =       6D
9DWP            =       8D              # P
9DWI            =       10D             # I
9DWN            =       12D             # N
9DWJ            =       14D             # J
9DWXX           =       S22UOFF
S22UMRL         =       BVECTOR         # 18
S22UUT          =       DELTAX          # 18
S223X1          =       18D             # 6
S221X3          =       24D             # 6
S22D            =       30D             # 2
S22RHO          =       32D             # 2
S22RL           =       W +156D         # 6
9DW26D          2DEC    52 B-14

9DWID           2DEC    2 B-14

SCTVAR          2DEC    1.0 E-6 B+18

IMUVARR         2DEC    0.04 E-6 B+18

DEC1B2          2DEC    1 B-2

V06N49EE        VN      00649
```

```
V06N89B         VN      00689
S22UOFF         =       LEMPOS          # 6     U SUB OFF
                SETLOC  P20S2
                BANK
```

Uses BVECTOR 232, DELTAX 161, I 206, LEMPOS 161, N 206, ORBWFLAG 107, P 188, P20S2 65, VN 159, and W 183.

1010 ⟨*Page CM0615* 1010⟩≡ (913 2752)

```
# Nothing on this page. --- RSB 2009.
```

1011 ⟨*Page CM0616* 1011⟩≡ (913 2752)

```
# SUBROUTINE NAME:  V89CALL
# MOD NO:  0                                    DATE: 8 FEB 1968
# MOD BY:  DIGITAL DEVEL GROUP                  LOG SECTION:  P20-P25
#
# FUNCTIONAL DESCRIPTION:
#
# CALLED BY VERB 89 ENTER DURING P00.  PRIO 10 USED.  CALCULATES AND
# DISPLAYS FINAL GIMBAL ANGLES TO POINT CSM +X AXIS OR PREFERRED AXIS
# (UNIT(Z)COS55 DEG + UNIT(X)SIN55 DEG) AT LM.
#
# 1. KEY IN V89 E ONLY IF IN PROG 00. IF NOT IN P00, OPERATOR ERROR AND
# EXIT R63, OTHERWISE CONTINUE.
#
# 2. IF IN P00, DO IMU STATUS CHECK (R02BOTH).  IF IMU ON AND ITS
# ORIENTATION KNOWN TO CGC, CONTINUE.
#
# 3. FLASH DISPLAY V 04 N 06.  R2 INDICATES WHICH SPACECRAFT AXIS IS TO
# BE POINTED AT LM.  INITIAL CHOICE IS PREFERRED AXIS.  (R2=1).
# ASTRONAUT CAN CHANGE TO (+X) AXIS (R2 NOT= 1) BY V22 E 2 E.  CONTINUE
# AFTER KEYING IN PROCEED.
#
# 4. SET PREFERRED ATTITUDE FLAG ACCORDING TO OPTION DESIRED.  SET FLAG
# FOR PREFERRED AXIS.  RESET FLAG FOR X AXIS.
#
# 5. CURRENT TIME IS STORED AND R63COMP IS CALLED
#
#       R63COMP JOB:
#
#               UPDATE CSM AND LM STATE VECTORS USING CONIC EQUATIONS
#
#               CALCULATES BOTH PREFERRED AND X AXIS TRACKING ATT FROM CSM TO LM.
#
#               DESIRED GIMBAL ANGLES AS INDICATED BY PREFERRED ATTITUDE FLAG
#               ARE STORED FOR LATER R60CSM CALL.
#
# 6. FLASH DISPLAY V 06 N18 AND AWAIT RESPONSE.
#
# 7. RECYCLE: RETURN TO STEP 5.
#    TERMINATE: EXIT R63 ROUTINE
#    PROCEED:  RESET 3AXISFLG AND CALL R60CSM FOR ATTITUDE MANEUVER.
#
# CALLING SEQUENCE:     V 89 E
#
# SUBROUTINES CALLED:  CHKP00H, R02BOTH, GOXDSPF, R63COMP, R60CSM
#
```

```
# ALARMS        1.  OPERATOR ERROR IF NOT IN P00
#               2.  PROGRAM ALARM IF IMU IS OFF
#               3.  PROGRAM ALARM IF IMU ORIENTATION IS UNKNOWN
```

Uses 3AXISFLG 115, DISPLAYS 59, N 206, R2 188, STATE 138, V 229, and Z 80.

1013 ⟨*Page CM0617* 1013⟩≡ (913 2752)

```
#
# ERASABLE INITIALIZATION REQUIRED:  NONE
#
# DEBRIS:  OPTION1, OPTION1+1, PRFTEXAT(PREF ATT FLAG), P21TIME, 3AXISFLG

DP1MIN          2DEC    6000

                EBANK=  P21TIME
                BANK    34
                SETLOC  P20S4
                BANK
                COUNT*  $$/R63

V89CALL         TC      BANKCALL        # IMU STATUS CHECK. RETURNS IF ORIENTATION
                CADR    R02BOTH         # KNOWN.  ALARMS IF NOT.
                CAF     THREE           # ALLOW ASTRONAUT TO SELECT DESIRED
                TS      OPTION1         # TRACKING ATTITUDE AXIS.
                CAF     ONE
                TS      OPTION1 +1
                CAF     VB04N06         # V 04 N 06
                TC      BANKCALL
                CADR    GOFLASH
                TC      ENDEXT          # TERMINATE
                TC      +2              # PROCEED
                TC      -5              # DATA IN.  OPTION1 +1 = 1 FOR PREF AXIS
                                        #                      = 2 FOR X AXIS
                CS      OPTION1 +1      # 1 FOR PREF AXIS.  2 FOR X AXIS.
                AD      ONE
                EXTEND
                BZF     SETPAF
RSTPAF          TC      DOWNFLAG        # RESET PREF ATT FLAG FOR R63COMP
                ADRES   RNGSCFLG        # TO DO X AXIS.  RESET BIT 10 FLAG 5
V89RECL         TC      INTPRET
                RTB     DAD
                        LOADTIME        # READ PRESENT TIME
                        DP1MIN          # INTEGRATE TO 1 MIN FROM NOW
                STCALL  P21TIME         # STORE TIME FOR CALL TO R63COMP.  R63COMP
                        R63COMP         # LEAVES DESIRED GIM ANGS IN THETAD, LOS IN
                EXIT                    # POINTVSM, AND SELECTED AXIS IN SCAXIS.
                CAF     VB06N18         # V 06 N 18
                TC      BANKCALL        # NOUN 18 REFERS TO THE DESIRED GIMBAL
                CADR    GOFLASH
                TC      ENDEXT          # TERMINATE
                TC      +2              # PROCEED
                TC      V89RECL         # RECYCLE
```

```
                TC      DOWNFLAG        # RESET 3 AXIS FLAG
                ADRES   3AXISFLG        # RESET BIT 6 FLAG 5
```

Uses 3AXISFLG 115, COUNT 142, EBANK 80, N 206, OPTION1 157, P20S4 69, P21TIME 179, POINTVSM 219, RNGSCFLG 115, SCAXIS 219, TC 169, THETAD 157, and V 229.

1014 ⟨*Page CM0618* 1014⟩≡ (913 2752)

```
                TC      BANKCALL        # PERFORMS CSM MANEUVER TO ALIGN SELECTED
                CADR    R60CSM          # SPACECRAFT AXIS TO LOS.
                TCF     ENDEXT

  SETPAF        TC      UPFLAG          # SET PREFERRED ATT FLAG FOR R63COMP
                ADRES   RNGSCFLG        # TO DO PREF AXIS.  SET BIT 10 FLAG 5.
                TC      V89RECL

  VB04N06       VN      0406
  VB06N18       VN      0618

  R63COMP       EQUALS  R63
```

Uses RNGSCFLG 115, TC 169, and VN 159.

1015 ⟨*Page CM0619* 1015⟩≡ (913 2752)

```
# PROGRAM NAME:  P23 CISLUNAR MIDCOURSE NAVIGATION
# MOD NO:
# MOD BY:  TOM KNATT
#
# FUNCTIONAL DESCRIPTION:  DO MIDCOURSE NAVIGATION BY INCORPORATION OF
# STAR/EARTH AND STAR/MOON OPTICAL MEASUREMENTS.
#
# CALLING SEQUENCE:  ASTRONAUT OPERATED
#
# SUBROUTINES CALLED:  R52,R53,R57,R60,ORBITAL INTEGRATION (INTEGRV)
# INCORP1,INCORP2,LALOTORV,LUNLMKLD, AND DISPLAY INTERFACE ROuTINES.
#
# NORMAL EXIT MODES:  VIA R00
#
# ALARMS:  NONE
#
# ABORT MODES:  NONE
#
# ERASABLE INITIALIZATION REQUIRED:  PAD-LOADED ERASABLES, ORBWFLAG RESET,
# REFSMFLG=0 IF IMU OFF AND REFSMFLG=1 IF IMU ONE
#
# INPUTS BY USER REQUIRED:  STAR NUMBER, LANDMARK LAT, LONG/2, ALT OR ID NUMB.
# IF LANDMARK IS USED, NEAR OR FAR HORIzON IF HORIZON IS USED, AND
# BODY TO BE MARKED ON (EARTH OR MOON).  SEE GSOP CHAPT 4.
#
# OUTPUT:  UPDATED CMC STATE VECTOR.  VECTOR FROM S/C TO HORIZON OR LANDMARK
# IN POINTAXS.  POINTAXS CAN BE USED TO GENERATE THIS VECTOR APART FROM
# P23 IF DESIRED.
#
# DEBRIS:  NO USABLE DEBRIS IS GENERATED.  RENDWFLG IS RESET FOR P20 UPON
# COMPLETION OF P23.  RUPTREGS AND ERASABLES USED BY DISPLAYS ARE DEBRIS.

                BANK    31
                SETLOC  RT23
                BANK
                COUNT   31/S23
                EBANK=  W
P23             TC      DOWNFLAG
                ADRES   RNDVZFLG

                TC      2PHSCHNG
                OCT     00004           # LEAVE GROUP 4
                OCT     00012           # ENTER GROUP 2
                CAF     PRIO13
                TS      PHSPRDT2
```

```
                TC      INTPRET
                SSP     CLEAR
                        MARKINDX
                        1
                        TARG2FLG        # TARGET FLAG USED R52 AND R53
                CLEAR   SSP
                        TARG1FLG
                        STARIND
                        0
                SSP     CLEAR
                        BESTI
                        0
                        R57FLAG         # SET = DO NOT REPERFORM R57
                CLEAR   EXIT
                        V94FLAG         # SET = ALLOW V94
P23.00          TC      INTPRET
```

Uses ALT 157, BESTI 145, COUNT 142, DISPLAYS 59, EBANK 80, HORIZON 190, LANDMARK 190, LAT 157, LONG 157, MARKINDX 145, ORBITAL 59, ORBWFLAG 107, PHSPRDT2 154, R57FLAG 119, REFSMFLG 107, RENDWFLG 117, RNDVZFLG 97, RT23 67, STAR 186, STARIND 145, STATE 138, TARG1FLG 99, TARG2FLG 99, TC 169, and W 183.

1017 ⟨*Page CM0620* 1017⟩≡ (913 2752)

```
                BON     CALL
                        REFSMFLG        # SET NOW AS INPUT, NORMALLY EXTERNAL CONT
                        P23.05          # WHEN ALIGNED, PERFORM MEASUREMENT
                        R57             # DO OPTICS CALIBRATION IF IMU NOT ALIGNED.
                CALL
                        R53
                GOTO
                        P23.60
P23.05          CLEAR   EXIT
                        SAVECFLG        # USED TO SAVE SPACE IN P23.65
P23.06          CAF     V05N70
                TC      BANKCALL        # IDENTIFICATION:  STAR, HOR  IDENT.
                CADR    GOFLASH
                TC      GOTOP00H        # TERMINATE
                TC      P23.15
                TC      -5              # REDISPLAY
P23.15          CA      LANDMARK        # IF C=2, LUNAFLAG=1.  IF C=1, LUNAFLAG=0
                EXTEND
                BZF     P23.151
                CA      HORIZON
                EXTEND
                BZF     +2
                TC      R23.10          # OPERATOR DSKY ERROR
                CA      LANDMARK
                TC      P23.152
P23.151         CA      HORIZON
                EXTEND
                BZF     R23.10
P23.152         MASK    BITS7-9         # IS C EQUAL TO 1 OR 2
                AD      NEG100
                EXTEND
                BZF     P23.16
                AD      NEG100
                EXTEND
                BZF     +2
                TC      R23.10
                TC      UPFLAG
                ADRES   LUNAFLAG
                TCF     +3
P23.16          TC      DOWNFLAG
                ADRES   LUNAFLAG
                CA      STARCODE        # IS STARCODE GREATER THAN OR
                EXTEND                  # EQUAL TO 0 AND LESS THAN 37
                BZF     P23.176
                EXTEND
```

```
BZMF    R23.10
AD      NEG37
EXTEND
BZMF    +2
TC      R23.10
```

Uses HORIZON 190, LANDMARK 190, LUNAFLAG 107, REFSMFLG 107, SAVE 191, STAR 186, STARCODE 150, and TC 169.

1019 ⟨*Page CM0621* 1019⟩≡ (913 2752)

```
                TC      INTPRET
P23.17          SLOAD   BZE
                        STARCODE
                        P23.175
                PUSH
                SLOAD   DMP
                        SPSIX
                LXA,1   SXA,1
                        MPAC +1
                        BESTI           # BESTI = 6 X STAR NUMBER
                CALL
                        LOWMEMRY        # NEEDED TO RETRIEVE STAR VECTOR FROM LOW
                STORE   STARSAV2        # STORE FOR R53,P23.  US(IN P23)=STARSAV2
P23.175         EXIT
P23.176         CA      HORIZON
                EXTEND
                BZF     P23.20
                MASK    BITS4-6
                AD      -OCT10
                EXTEND
                BZF     P23.18
                AD      -OCT10
                EXTEND
                BZF     +2
                TC      R23.10
                TC      UPFLAG
                ADRES   NORFHOR
                TC      P23.30
P23.18          TC      DOWNFLAG
                ADRES   NORFHOR
                TC      P23.30
P23.20          TC      INTPRET
                CALL
                        P22SUBRB
                EXIT
P23.30          TC      INTPRET
                SLOAD   BZE
                        STARCODE
                        LDPLANET
P23.31          BON     EXIT
                        SAVECFLG
                        P23.85
                CAF     V50N25P
                TC      BANKCALL
```

```
                CADR    GOPERF1         # GOPERF1 BLANKS OUT R2 AND R3
                TC      GOTOP00H
                TC      V94ENTER        # PROCEED.  AUTOCONTROL CMC
P23.55          TC      INTPRET
                GOTO
                        P23.56
```

Uses BESTI 145, HORIZON 190, MPAC 145, NORFHOR 95, R2 188, STAR 186, STARCODE 150, STARSAV2 185, TC 169, and US 185.

1021 ⟨*Page CM0622* 1021⟩≡ (913 2752)

```
# VERB 94 BEGINS HERE
V94ENTER        TC      INTPRET
                RTB
                        LOADTIME        # READ CLOCK
                STCALL  MARKTIME
                        POINTAXS        # RETURN LOS IN RCLL AND MPAC
                MXV     UNIT
                        REFSMMAT
                STOVL   POINTVSM
                        JCAXIS
                STORE   SCAXIS
                EXIT
                TC      DOWNFLAG        # CLEAR AND GO TO VECPOINT IN R60
                ADRES   3AXISFLG        # BIT 6 FLAG 5
                CAF     R60ADRS
                TS      TEMPFLSH
                TC      PHASCHNG
                OCT     00012
R60CALL         TC      BANKCALL
                CADR    R60CSM
                TC      PHASCHNG
                OCT     04022
                TC      INTPRET
                BON
                        R57FLAG
                        P23.57          # DO NOT REPERFORM R57
P23.56          CALL
                        R57
P23.57          SET     SET
                        V94FLAG
                        R57FLAG
                CALL
                        R52
                CLEAR   CLEAR
                        V94FLAG
                        R57FLAG
P23.60          EXIT
                INHINT
                CA      MARKSTAT
                MASK    LOW10
                TS      MARKDATA
                EXTEND
                INDEX   MARKDATA
                DCA     0
```

```
DXCH    MARKTIME
INDEX   MARKDATA
CA      5
XCH     TRUNION
RELINT
TC      INTPRET
```

Uses 3AXISFLG 115, MARKDATA 161, MARKSTAT 163, MARKTIME 161, MPAC 145, POINTVSM 219, R57FLAG 119, REFSMMAT 172, SCAXIS 219, TC 169, TEMPFLSH 150, and TRUNION 190.

1023 ⟨*Page CM0623* 1023⟩≡ (913 2752)

```
                LXC,1   VLOAD*
                        MARKDATA
                        1,1
                STODL*  MARKDOWN +1
                        0,1
                STORE   MARKDOWN
                EXIT
                CAF     V05N71
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H        # TERMINATE
                TC      P23.65          # STORE DATA
                TC      -5              # REDISPLAY
P23.65          TC      INTPRET
                SET     EXIT
                        SAVECFLG
                TC      P23.15
P23.85          CLEAR   CALL
                        RENDWFLG
                        POINTAXS
                GOTO
                        R23.55

# WE BEGIN CALCULATIONS HERE
# POINTAXIS SUBROUTINE

POINTAXS        STQ
                        POINTEX
R23.05          BON     DLOAD
                        ORBWFLAG
                        R23.1
                        WMIDPOS
                STCALL  0
                        INITIALW        # INITIALIZE W-MATRIX FIRST PASS IN P23
R23.1           CALL
                        SETINTG         # SETUP FOR CSM INTEGRATION
                BOF     SET
                        ORBWFLAG
                        R23.2
                        DIM0FLAG
R23.2           SET     CALL
                        ORBWFLAG
                        INTEGRV         # INTEGRATE CSM STATE VEC. TO MARKTIME
                EXIT
                TC      PHASCHNG
```

```
                OCT     04022
                TC      INTPRET
                CALL
                        RECT.1          # PICKUP CSM STATE VECTOR FROM PERM
                BOFF
                        ZMEASURE        # IN SPHERE OF INFLUENCE OF PRIMARY BODY
                        R23.3
```

Uses DIMOFLAG 109, MARKDATA 161, MARKDOWN 239, MARKTIME 161, ORBWFLAG 107, POINTEX 159, RENDWFLG 117, STATE 138, TC 169, W 183, WMIDPOS 198, and ZMEASURE 95.

1024 ⟨*Page CM0624* 1024⟩≡ (913 2752)

```
                DLOAD   CALL
                        MARKTIME
                        LUNPOS
                BON     VCOMP
                        CMOONFLG
                        +1
                VAD
                        RZC
                STORE   RZC
R23.3           SLOAD   BHIZ
                        LANDMARK        # IF LANDMARK = 0, USE HORIZ SUBR
                        R23.4
                SET
                        ERADFLAG
                DLOAD   CALL
                        MARKTIME
                        LALOTORV
                GOTO
                        R23.5
R23.4           CALL
                        HORIZ
R23.5           VSU     SETPD
                        RZC
                        0
                GOTO
                        POINTEX
```

Uses CMOONFLG 125, ERADFLAG 99, LANDMARK 190, MARKTIME 161, POINTEX 159, and RZC 232.

1025 ⟨*Page CM0625* 1025⟩≡ (913 2752)

```
R23.55          UNIT    PUSH            # RCLL IS IN MPAC
                VLOAD
                        34D             # RCLL * RCLL
                STOVL   30D             # PUSH 30-31 =RCLL*RCLL 32-33=ABVAL RCLL
                        VZC
                VXSC    VSR
                        ONE/C
                        15D
                VAD                     # PUSH UP RCLL(UNIT)
                UNIT
                STOVL   UCLSTAR
                        VZC
                VSR2    VSU
                        VESO
                VXSC    VSR
                        ONE/C
                        13D
                VAD     UNIT
                        US
                STORE   USSTAR
                DOT     SL1
                        UCLSTAR
                PUSH    VLOAD           # PD 0,1 = USSTAR(DOT)UCLSTAR
                        UCLSTAR
                VXSC    VCOMP
                VSL1    VAD
                        USSTAR
                UNIT
                STOVL   BVECTOR         # USSTAR - COSQ(UCLSTAR)
                        ZEROVECS
                STORE   BVECTOR +6
                STODL   BVECTOR +12D
                        0
                ACOS    DCOMP
                PUSH    DLOAD
                        ZEROVECS
                EXIT
                CA      VARSUBL         # PUT FIXED INTO ERASABLE FOR MSU
                TS      L               # INSTRUCTION COMING UP
                CA      TRUNION         # REQUIRED TO CHANGE 2'S COMPLEMENT
                EXTEND                  # TRUNION TO 1'S COMPLEMENT
                MSU     L               # TRUNION (2'S)-00000 CONVERTS TRUNION TO
                TS      MPAC            # 1'S.  VARSUBL=00000.
                TC      INTPRET
                PUSH    SLOAD           # PUSH IS DP.  WHEN BDSU IS EXECUTED, 2ND
```

```
                TRUNBIAS        # HALF OF PUSHLIST IS GUARANTEED ZERO FROM
        BDSU                    # DLOAD ZEROVECS ABOVE
        SR3     DAD
        DAD     DMP
```

Uses BVECTOR 232, L 80, MPAC 145, TC 169, TRUNBIAS 165, TRUNION 190, UCLSTAR 232, US 185, USSTAR 232, VESO 177, and VZC 232.

1027 ⟨*Page CM0626* 1027⟩≡ (913 2752)

```
                        TRUN19
                        32D
                DMP     SL3
                        PI/4.0
                BOFF    SL2
                        CMOONFLG
                        R23.51
R23.51          STODL   DELTAQ
                        30D             # RCLL * RCLL
                DMP     RTB
                        TRUNVAR
                        TPMODE
                TAD
                        VARSUBL
                STORE   VARIANCE
                CLEAR   CALL
                        DMENFLG
                        INCORP1
                CALL
                        GRP2PC
                VLOAD   ABVAL
                        DELTAX +6
                BOF     SR2             # DISPLAY IS 2-27 IF IN LUNAR SPHERE.
                        CMOONFLG
                        R23.52
R23.52          STOVL   N49DISP +2
                        DELTAX
                ABVAL
                BOF     SR2
                        CMOONFLG
                        R23.53
R23.53          STORE   N49DISP
                EXIT
R23.6           CAF     V6N49
                TC      BANKCALL
                CADR    GOFLASHR
                TC      GOTOP00H
                TC      R23.7           # INCORPORATE DATA
                TC      GOTOP00H
                CAF     BIT3            # BLAN OUT R3
                TC      BLANKET
                TC      PHASCHNG
                OCT     00012
                TC      ENDOFJOB
R23.7           TC      INTPRET
```

```
R23.8           SET     CALL
                        VEHUPFLG
                        INCORP2
                EXIT
R23.END         TC      GOTOP00H
```

Uses CMOONFLG 125, DELTAQ 232, DELTAX 161, DMENFLG 115, N49DISP 232, TC 169, VARIANCE 232, and VEHUPFLG 99.

1029 ⟨*Page CM0627* 1029⟩≡ (913 2752)

```
R23.10          TC      FALTON
                TC      P23.06
HORIZ           STQ     SETPD
                        SRRETURN
                        0
                DLOAD   PDDL            # PUSH 0-1 = -AYO SCALED B0
                        -AYO
                        AXO
                PDDL    PDVL            # PUSH 2-3 = +AX SCALED B0
                        DPPOSMAX
                        US
                VXV     UNIT
                        RZC
                STOVL   UBAR2
                VXV     UNIT            # PUSH UP
                        UBAR2
                STOVL   UBAR0
                        UBAR2
                VXV     UNIT
                        UBAR0
                STORE   UBAR1
                BON     DOT
                        LUNAFLAG
                        HORIZ.6
                        0               # UBAR1 DOT UZ
                STCALL  ALPHAV +4
                        GETERAD
                DAD     PDDL            # MPAC HAS RADIUS OF FISCHER ELLIPSOID
                        HORIZALT        # PUSH 0-1 = BH SCALED B29
                        AEARTH
                DAD     PUSH            # PUSH 2-3 = AH B29
                        HORIZALT
HORIZ.1         VLOAD   MXV
                        RZC             # B29
                        UBAR0           # B1
                VSL1    PDVL            # PUSH 4-9 = RH(XH,YH,ZH) B29
                        US
                MXV     VSL1
                        UBAR0
                PDDL                    # PUSH 10-15 = USH B1
                        2               # AH
                STODL   34D
                        4               # XH
                CALL
                        DIVIDE
```

```
SR*     DMP
        8D,1            # NOW SCALED B9
        MPAC
STODL   30D
        0
```

Uses -AYO 172, ALPHAV 177, AXO 172, HORIZALT 166, LUNAFLAG 107, MPAC 145, RZC 232, SR 80, SRRETURN 232, TC 169, UBAR0 232, UBAR1 232, UBAR2 232, and US 185.

1031 ⟨*Page CM0628* 1031⟩≡ (913 2752)

```
STODL   34D
        6               # YH
CALL
        DIVIDE
SR*     DMP
        8D,1            # B9
        MPAC            # B18
DAD     PUSH            # PUSH 16-17 =A SCALED B18
        30D
DSU     SQRT
        1.0B18
PDDL                    # PUSH 18-19 SQRT(A-1) B9
        16D
STODL   34D
        4               # XH
CALL
        DIVIDE
SR*     PDDL
        17D,1           # PUSH 20-21 = XH/A B29
        6               # YH
CALL
        DIVIDE
SR*     PDDL
        17D,1           # PUSH 22-23 = YH/A B29
        16D             # A
STODL   34D
        18D             # SQRT(A-1)
CALL
        DIVIDE
SR*
        8D,1
STODL   28D
        0               # BH
STODL   34D
        2               # AH
CALL
        DIVIDE
SR*     DMP             # AH/BH SCALED B1
        0,1
        28D             # SQRT(A-1)/A
DMP     SL1
        6               # YH
PDDL
        2               # AH
STODL   34D
```

```
                        0
                CALL
                        DIVIDE
                SR*     DMP             # BH/AH SCALED B1
                        0,1
```

Uses `A` 80, `MPAC` 145, and `SR` 80.

1033 ⟨*Page CM0629* 1033⟩≡ (913 2752)

```
                        28D             # SQRT (A-1)/A
                DMP     SL1
                        4               # XH
                PDDL    DAD
                        20D             # XH/A
                        24D             # ALPHA
                PDDL    DSU
                        22D             # YH/A
                        26D             # BETA
                PUSH    SETPD
                        16D
                DLOAD   DSU
                        20D             # XH/A
                        24D             # ALPHA
                PDDL    DAD
                        22D             # YH/A
                        26D             # BETA
                PDDL    PUSH
                        ZEROVECS
                STOVL   32D             # ZERO THIRD COMP. OF T-0 VECTOR
                        28D
                VSU     UNIT
                        4               # RH VECTOR
                DOT     PDVL            # PUSH 22-23 A-SUB-ZERO
                        10D             # USH VECTOR
                        16D             # T1 VECTOR
                VSU     UNIT
                        4               # RH VECTOR
                DOT     PUSH            # PUSH 24-25 A-SUB-ONE
                        10D
                BDSU    BMN
                        22D             # A-SUB-ZERO
                        HORIZ.3
                BON
                        NORFHOR
                        HORIZ.4
HORIZ.2         VLOAD   GOTO
                        28D             # T-0 VECTOR
                        HORIZ.5
HORIZ.3         BON     GOTO
                        NORFHOR
                        HORIZ.2
                        HORIZ.4
HORIZ.4         VLOAD
                        16D             # T1 VECTOR
```

```
HORIZ.5         VXM     VSL1
                        UBARO
                GOTO
                        SRRETURN
HORIZ.6         DLOAD   PUSH
```

Uses A 80, NORFHOR 95, SRRETURN 232, T1 241, and UBARO 232.

1035 ⟨*Page CM0630* 1035⟩≡ (913 2752)

```
                        RADMOON
                PUSH    GOTO
                        HORIZ.1
DIVIDE          NORM    SR1
                        X1
                STODL   36D
                        34D
                NORM    BDDV
                        S1
                        36D
                XSU,1   RVQ
                        S1
RECT.1          BOFF    AXT,2           # SR TO SET ZMEASURE = 0 IF MEASUREMENT
                        CMOONFLG        #   PLANET AND PRIMARY PLANET ARE THE SAME.
                        RECT.3          #     OTHERWISE = 1
                DEC     -2
                BOFF                    #       VEC. AND SCALE B29 AND B7
                        LUNAFLAG
                        RECT.4
RECT.2          CLEAR   GOTO
                        ZMEASURE
                        RECT.5
RECT.3          AXT,2   BOFF
                        0
                        LUNAFLAG
                        RECT.2
RECT.4          SET
                        ZMEASURE
RECT.5          VLOAD   VSR7
                        DELTACSM        # SCALED B22 OR B18
                VSR*    VAD
                        0,2
                        RCVCSM          # SCALED B29 OR B27
                VSR*
                        0,2
                STOVL   RZC             # NOW SCALED B29
                        NUVCSM          # SCALED B3 OR B-1
                VSR4    VSR*
                        0,2
                VAD     VSR*
                        VCVCSM          # SCALED B7 OR B5
                        0,2
                STORE   VZC             # NOW SCALED B7
                RVQ
ONE/C           2DEC*   .333564049 E-6 B+21*
```

```
AEARTH          2DEC    6378166 B-29    # A AXIS OF EARTH (METERS B-29)

RADMOON         2DEC    1738090 B-29    # RADIUS MOON IN METERS
```

Uses A 80, CMOONFLG 125, DELTACSM 172, LUNAFLAG 107, NUVCSM 172, RCVCSM 172, RZC 232, S1 85, SR 80, VCVCSM 172, VZC 232, X1 85, and ZMEASURE 95.

1037 ⟨*Page CM0631* 1037⟩≡ (913 2752)

```
TRUN19          OCT     01604
TRUN19A         OCT     00000
1.0B18          2DEC    1.0 B-18

VARSUBL         DEC     0
VARSUBL3        2DEC*   3.4299040 E+6 B-26*

TRUNVAR         2DEC    2.5 E-9 B+18

V6N49           VN      0649
V05N70          VN      0570
V05N71          VN      0571
OCT00077        OCT     00077
V50N25P         OCT     00202
SPSIX           OCT     00006
JCAXIS          2DEC    .2688190620     # 1/2(SIN 32.523 DEG)  TRACK AXIS

                2DEC    0

                2DEC    .4215878460     # 1/2(COS 32.523 DEG)

R60ADRS         CADR    R60CALL +3
NEG37           DEC     -37
BITS7-9         OCT     700
BITS4-6         OCT     70
                SETLOC  RT53
                BANK
LOWMEMRY        VLOAD*  RVQ
                        CATLOG,1
                BANK    37
                SETLOC  P23S1
                BANK
LDPLANET        EXIT                    # KEEP THIS OPEN SUBROUTINE IN EBANK=5
                CAF     VNPLAN23        # BECAUSE STAR IS EBANK=5
                TC      BANKCALL        # LDPLANET ALLOWS VECTOR TO PLANET TO BE
                CADR    GOFLASH         # STORED IN STARSAV2 IF STORED STARS ARE
                TC      GOTOP00H        # NOT VISIBLE
                TC      +2
                TC      -5
                TC      INTPRET
                VLOAD
                        STARSAV3
                VXSC    UNIT
                        1/SQR3
```

```
                STORE   STARSAV2
                GOTO
                        P23.31
  VNPLAN23      VN      0688
                BLOCK   02
  GOTOV56       EXTEND                  # P20 TERMINATES BY GOTOV56 INSTEAD OF
```

Uses EBANK 80, P23S1 63, RT53 61, STAR 186, STARSAV2 185, STARSAV3 239, TC 169, and VN 159.

1039 ⟨*Page CM0632* 1039⟩≡ (913 2752)

```
                DCA     VB56CADR        #       GOTOP00H
                TCF     SUPDXCHZ
                EBANK=  WHOCARES
VB56CADR        2CADR   TRACKTRM

                SETLOC  FFTAG2
                BANK
                COUNT*  $$/P20
                BANK    40
                SETLOC  ENDPINS1
                BANK
                COUNT*  $$/EXTVB
V67CALL         TC      INTPRET
                CALL
                        V67WW
                EXIT
V06N99DS        CAF     V06N99A
                TC      BANKCALL
                CADR    GOXDSPF
                TCF     ENDEXT
                TC      V06N9933
                TC      V06N99DS
V06N9933        TC      INTPRET
                SLOAD   BHIZ            # IF R3 OF V67 = 0 EXIT
                        WWOPT
                        +3
                GOTO
                        V6N99INP
                EXIT
                TCF     ENDEXT
V6N99INP        LXA,1   LXA,2
                        WWPOS
                        WWVEL
                SLOAD   DSU
                        WWOPT
                        V67DEC2
                BHIZ    BPL
                        V67WORB
                        V67WMID
                SXA,1   SXA,2
                        WRENDPOS
                        WRENDVEL
                GOTO
                        V67EXITX
V67WORB         SXA,1   SXA,2
```

```
                        WORBPOS
                        WORBVEL
                GOTO
                        V67EXITX
V67WMID         SXA,1   SXA,2
```

Uses COUNT 142, EBANK 80, FFTAG2 57, TC 169, WHOCARES 244, WORBPOS 175, WORBVEL 175, WRENDPOS 175, and WRENDVEL 175.

1041 ⟨*Page CM0633* 1041⟩≡ (913 2752)

```
                        WMIDPOS
                        WMIDVEL
V67EXITX        CLEAR   CLEAR
                        ORBWFLAG
                        RENDWFLG
                EXIT
                TCF     ENDEXT
V67WW           STQ     BOV
                        S2
                        +1
                CALL
                        INTSTALL
                SSP     DLOAD
                        S1
                DEC     6
                        ZEROVECS
                STORE   WWPOS
                STORE   WWVEL
                STORE   WWOPT
                AXT,1
                DEC     36
NXPOSVEL        VLOAD*  VSQ
                        W +36D,1
                DAD
                        WWPOS
                STORE   WWPOS
                VLOAD*  VSQ
                        W +90D,1
                DAD
                        WWVEL
                STORE   WWVEL
                TIX,1   SQRT
                        NXPOSVEL
                STODL   WWVEL
                        WWPOS
                SQRT
                STORE   WWPOS
                BOV     GOTO
                        +2
                        V67XXX
                DLOAD
                        DPPOSMAX
                STORE   WWPOS
                STORE   WWVEL
V67XXX          DLOAD   DSU
```

```
                        WWPOS
                        FT99999
                BMN     DLOAD
                        +3
                        FT99999
```

Uses ORBWFLAG 107, RENDWFLG 117, S1 85, S2 85, W 183, WMIDPOS 198, and WMIDVEL 198.

1042a ⟨*Page CM0634* 1042a⟩≡ (913 2752)

```
                STORE   WWPOS
                LXA,1   SXA,1
                        S2
                        QPRET
                EXIT
                TC      POSTJUMP
                CADR    INTWAKE
WWPOS           =       RANGE
WWVEL           =       RRATE
WWOPT           =       RTHETA
V06N99A         VN      0699
FT99999         2DEC    30479 B-19

V67DEC2         2DEC    2 B-14

                SBANK=  LOWSUPER
```

Uses LOWSUPER 67, QPRET 85, RANGE 179, RRATE 179, RTHETA 179, S2 85, TC 169, and VN 159.

3.5.4 p30 p37 code

1042b ⟨*p30 p37 code* 1042b⟩≡ (857a)

⟨*Page CM0635* 1043⟩
⟨*Page CM0636* 1045⟩
⟨*Page CM0637* 1047⟩
⟨*Page CM0638* 1048⟩
⟨*Page CM0639* 1049⟩
⟨*Page CM0640* 1051⟩
⟨*Page CM0641* 1052⟩
⟨*Page CM0642* 1053⟩
⟨*Page CM0643* 1054⟩
⟨*Page CM0644* 1056⟩
⟨*Page CM0645* 1058⟩
⟨*Page CM0646* 1059⟩
⟨*Page CM0646a* 1060⟩
⟨*Page CM0647* 1061⟩
⟨*Page CM0648* 1062a⟩

1043 ⟨*Page CM0635* 1043⟩≡ (1042b 2757)

```
                BANK    32

                SETLOC  P30S1
                BANK

                EBANK=  +MGA

                COUNT   35/P34

DISPMGA         STQ     EXIT            # USED IN P30

                        RGEXIT
                TC      COMPTGO

DISP45          CAF     V16N45
                TC      BANKCALL
                CADR    GOFLASHR
                TC      GOTOP00H
                TC      END45
                TC      DISP45
P30PHSI         TC      PHASCHNG
                OCT     14
                TCR     ENDOFJOB
END45           TC      INTPRET
                CLEAR   GOTO
                        TIMRFLAG
                        RGEXIT

COMPTGO         EXTEND                  # USED TO COMPUTE TTOGO
                QXCH    PHSPRDT6        # ** GROUP 6 TEMPORARY USED, BEWARE **

                TC      UPFLAG          # SET TIMRFLAG
                ADRES   TIMRFLAG        # BIT 11 FLAG 7
                CAF     ZERO
                TS      NVWORD1

                CAF     ONE
                TC      WAITLIST
                EBANK=  TIG
                2CADR   CLOKTASK

                TC      2PHSCHNG
                OCT     40036           # 6.3SPOT FOR CLOKTASK
                OCT     05024           # GROUP 4 CONTINUES HERE
                OCT     13000
```

TC PHSPRDT6

Uses +MGA 234, COUNT 142, EBANK 80, NVWORD1 157, P30S1 69, PHSPRDT6 154, RGEXIT 181, TC 169, TIG 224, TIMRFLAG 123, and TTOGO 236.

1045 ⟨*Page CM0636* 1045⟩≡ (1042b 2757)

```
# PROGRAM DESCRIPTION P30       DATE 3-6-67
# MOD. I BY S. ZELDIN:  TO ADD P31 AND ADAPT P30 FOR P31 USE.   22DEC67
#
# FUNCTIONAL DESCRIPTION
#       P30     (EXTERNAL DELTA-V TARGETING PROGRAM)
#               ACCEPTS ASTRONAUT INPUTS OF TIG,DELV(LV) AND COMPUTES, FOR DISPLAY,
#               APOGEE, PERIGEE, DELV(MAG), MGA ASSOCIATED WITH DESIRED MANEUVER.
#       P31     (GENERAL LAMBERT AIMPOINT GUIDANCE)
#               A GROUND RULE FOR P31 IS THE ANGLE BETWEEN THE TARGET VECTOR AND
#               POSITION VECTOR AT TIG IS NOT 165-195 DEGREES APART
#               BASED ON STORED INPUT OF OFFSET TARGET(B+29) AND DELTA T TRANS, AND
#               ASTRONAUT ENTRY OF TIG, P31 COMPUTES REQUIRED VELOCITY FOR MANEUVER
#               AND, FOR DISPLAY, APOGEE, PERIGEE, DELV(7AG), +MGA ASSOCIATED WITH
#               DESIRED MANEUVER.
#
# THE FOLLOWING SUBROUTINES ARE USED IN P30 AND P31
#       S30.1 (P30 ONLY)
#       S31.1 (P31 ONLY)
#       P30/P31 -- DISPLAYS TIG
#       CNTUP30 -- DISPLAYS DELV(LV)
#       PARAM30 -- DISPLAYS APOGEE, PERIGEE, DELV(MAG), MGA, TIME FROM TIG,
#                  MARKS SINCE LAST THRUSTING MANEUVER
#
# CALLING SEQUENCE VIA JOB FROM V37
#
# EXIT VIA V37 OR GOTOP00H
#
# OUTPUT FOR POWERED FLIGHT
#       VTIG    X
#       RTIG    X       SEE S30.1
#       DELVSIN X
#       VGDISP
#       RTARG   X
#       TPASS4  X       SEE S31.1
#               X

                COUNT   35/P30

P30             TC      P30/P31
                TC      CNTNUP30
                TC      DOWNFLAG        # RESET UPDATFLG
                ADRES   UPDATFLG        # BIT 7 FLAG 1
                TC      INTPRET
                CALL
                        S30.1
```

```
EXIT
TC      PARAM30
TC      UPFLAG
```

Uses +MGA 234, A 80, COUNT 142, DELV 159, DELVSIN 236, DISPLAYS 59, I 206, LV 85, RTARG 224, RTIG 236, TC 169, TIG 224, TPASS4 236, UPDATFLG 99, V 229, VGDISP 231, and VTIG 236.

1047 ⟨*Page CM0637* 1047⟩≡ (1042b 2757)

```
                ADRES   XDELVFLG        # SET XDELVFLG BIT 8 FLAG 2
                TCF     GOTOP00H

P31             TC      P30/P31
                TC      DOWNFLAG
                ADRES   UPDATFLG        # RESET UPDATFLG BIT 7 FLAG 1
                TC      DOWNFLAG
                ADRES   NORMSW          # RESET NORMSW BIT 10 FLAG 7
                TC      INTPRET
                CALL
                        S31.1
                EXIT
                TC      CNTNUP30
                TC      PARAM30
                TC      DOWNFLAG
                ADRES   XDELVFLG        # BIT 8 FLAG 2.
                TCF     GOTOP00H

P30/P31         XCH     Q
                TS      P30/31RT
                TC      UPFLAG
                ADRES   UPDATFLG        # SET UPDATFLG BIT 7 FLAG 1
                TC      UPFLAG
                ADRES   TRACKFLG        # SET TRACKFLG BIT 5 FLAG 1
                CAF     V06N33          # T OF IGN
                TC      BANKCALL
                CADR    GOFLASHR
                TCF     GOTOP00H
                TC      P30/31RT
                TCF     P30/P31 +4
                TC      PHASCHNG
                OCT     00014
                TC      ENDOFJOB

CNTNUP30        XCH     Q
                TS      P30/RET
                CAF     V06N81
                TC      BANKCALL
                CADR    GOFLASH
                TCF     GOTOP00H
                TC      P30/RET
                TCF     CNTNUP30 +2
PARAM30         XCH     Q
                TS      P30/31RT
                CAF     V06N42
```

```
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H        # ON TERMINATION GOTOP00H
                TCF     REFTEST         # ON PROCEED GO DO REFTEST
```

Uses NORMSW 123, P30/31RT 239, P30/RET 157, Q 80, TC 169, TRACKFLG 101, UPDATFLG 99, and XDELVFLG 103.

1048 ⟨*Page CM0638* 1048⟩≡ (1042b 2757)

```
                TCF     PARAM30 +2
REFTEST         CAF     BIT13
                MASK    STATE +3        # REFSMFLAG
                EXTEND
                BZF     NOTSET          # REFSMFLAG =0, THEN BRANCH TO NOTSET
                TC      INTPRET
                VLOAD   PUSH
                        DELVSIN
                CALL
                        GET+MGA
                GOTO
                        FLASHMGA
NOTSET          EXTEND
                DCS     MARSDP
                DXCH    +MGA            # +MGA, +MGA+1 CONTAINS (-00001)
                TC      INTPRET
FLASHMGA        CALL
                        DISPMGA
                EXIT
                TC      P30/31RT
MARSDP          OCT     00000           # (00000) (16440) = (+00001)
                OCT     35100
                                        # ( .01 ) DEGREES IN THE LOW ORDER REGISTER

V06N33          VN      0633
V06N42          VN      0642
V16N35          VN      1635
V06N45          VN      0645
```

Uses +MGA 234, DELVSIN 236, P30/31RT 239, STATE 138, TC 169, and VN 159.

1049 ⟨*Page CM0639* 1049⟩≡ (1042b 2757)

```
# PROGRAM DESCRIPTION S30.1     DATE 9NOV66
# MOD NO 1                      LOG SECTION P30,P37
# MOD BY RAMA AIYAWAR **
# MOD.2 BY S.ZELDIN -- TO CORRECT MOD.1 FOR COLOSSUS            29DEC67
#
# FUNCTIONAL DESCRIPTION
#       BASED ON STORED TARGET PARAMETERS (R OF IGNITION (RTIG), V OF
#       IGNITION (VTIG), TIME OF IGNITION (TIG)), DELV(LV), COMPUTE PERIGEE ALTITUDE
#       APOGEE ALTITUDE AND DELTA-V REQUIRED IN REF. COORDS. (DELVSIN).
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             S30.1
#
# NORMAL EXIT MODE
#       AT L+2 OR CALLING SEQUENCE (GOTO L+2)
#
# SUBROUTINES CALLED
#       THISPREC
#       PERIAPO
#
# ALARM OR ABORT EXIT MODES
#       NONE
#
# ERASABLE INITIALIZATION REQUIRED
#       TIG             TIME OF IGNITION        DP B28CS
#       DELVSLV         SPECIFIED DELTA-V IN LOCAL VERT.
#                       COORDS. OF ACTIVE VEHICLE AT
#                       TIME OF IGNITION        VCT. B+7 M/CS
#
# OUTPUT
#       RTIG            POSITION AT TIG         VCT.    B+29 M
#       VTIG            VELOCITY AT TIG         VCT.    B+7 M
#       HAPO            APOGEE ALT.             DP      B+29 M
#       HPER            PERIGEE ALT.            DP      B+29 M
#       DELVSIN         DELVSLV IN REF COORDS   VCT.    B+7 M/CS
#       VGDISP          MAG. OF DELVSIN         DP      B+7 M/CS
#
# DEBRIS        QTEMP   TEMP.ERASABLE
#               QPRET, MPAC
#               PUSHLIST

                SETLOC  P30S1A
                BANK
```

```
                COUNT   35/S30S

S30.1           STQ     DLOAD
                        QTEMP
                        TIG             # TIME IGNITION SCALED AT 2(+28)CS
                STCALL  TDEC1
                        THISPREC        # ENCKE ROUTINE FOR

                VLOAD   SXA,2
                        VATT
                        RTX2
                STOVL   VTIG
```

Uses ALT 157, COUNT 142, DELV 159, DELVSIN 236, DELVSLV 224, HAPO 181, HPER 181, L 80, LV 85, MODE 145, MPAC 145, P30S1A 67, QPRET 85, QTEMP 236, RTIG 236, TEMP 191, THISPREC 73, TIG 224, V 229, VGDISP 231, and VTIG 236.

1051 ⟨*Page CM0640* 1051⟩≡ (1042b 2757)

```
        RATT
STORE   RTIG
STORE   RACT3
VXV     UNIT
        VTIG
STCALL  UNRM
        LOMAT
VLOAD   VXM
        DELVSLV
        0
VSL1    SXA,1
        RTX1
STORE   DELVSIN
ABVAL
STOVL   VGDISP          # MAG DELV
        RTIG
PDVL    VAD
        DELVSIN
        VTIG
CALL
        PERIAPO1
CALL
        SHIFTR1
CALL
        MAXCHK
STODL   HPER            # PERIGEE ALT B+29
        4D
CALL
        SHIFTR1
CALL
        MAXCHK
STCALL  HAPO            # APOGEE ALT B+29
        QTEMP
```

Uses ALT 157, DELV 159, DELVSIN 236, DELVSLV 224, HAPO 181, HPER 181, QTEMP 236, RACT3 234, RTIG 236, UNRM 183, VGDISP 231, and VTIG 236.

1052 ⟨*Page CM0641* 1052⟩≡ (1042b 2757)

```
# S31.1 PROGRAM DESCRIPTION             28DEC67
# MOD.1 BY S.ZELDIN
#
# S31.1 COMPUTES DELV IN REF AND LV COORDS,MAG OF DELV,INTERCEPT TIME,
# APOGEE AND PERIGEE ALT FOR REQUIRED MANEUVER
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             S31.1
#
# NORMAL EXIT MODE
#       AT L +2 OF CALLING SEQUENCE (GOTO L+2)
#
# SUBROUTINES CALLED
#       AGAIN
#       PERIAPO1
#       SHIFTR1
#       MIDGIM
#
# NO ALARM OR ABORT MODES
#
# INPUT
#       DELLT4          DP      +28
#       TIG             DP      +28
#       RTARG           VCT     +29
#
# OUTPUT
#       DELVLVC         VCT     +7
#       VGDISP          DP      +7
#       HAPO            DP      +29
#       HPER            DP      +29
#       TPASS4          DP      +28
#
# DEBRIS -- QTEMP

S31.1           STQ     DLOAD
                        QTEMP
                        TIG
                STCALL  TDEC1
                        AGAIN           # RETURNS RTX2,RTX1,RATT,VATT,VIPRIME
                VLOAD   PDVL            # DELUEET3
                        RTIG
                        VIPRIME
                CALL
                        PERIAPO1
```

```
        CALL
                SHIFTR1
        CALL
                MAXCHK
        STODL   HPER            # B29
                4D
        CALL
                SHIFTR1
        CALL
                MAXCHK
        STOVL   HAPO            # B29
```

Uses ALT 157, DELLT4 224, DELV 159, DELVLVC 224, HAPO 181, HPER 181, L 80, LV 85, MODE 145, QTEMP 236, RTARG 224, RTIG 236, TIG 224, TPASS4 236, VGDISP 231, and VIPRIME 234.

1053 ⟨*Page CM0642* 1053⟩≡ (1042b 2757)

```
                DELVEET3
        STORE   0
        SET     CALL
                AVFLAG
                MIDGIM          # GET DELVLVC B7 FOR DISPLAY
        ABVAL
        STODL   VGDISP          # B+7 FOR DISPLAY
                DELLT4
        DAD
                TIG
        STCALL  TPASS4          # FOR S40.1
                QTEMP
```

Uses AVFLAG 105, DELLT4 224, DELVEET3 236, DELVLVC 224, QTEMP 236, TIG 224, TPASS4 236, and VGDISP 231.

1054 ⟨*Page CM0643* 1054⟩≡ (1042b 2757)

```
# SUBROUTINE NAME:      DELRSPL         (CONTINUATION OF V 82 IN CSM IF P11 ACTIVE)
# TRANSFERRED COMPLETELY FROM SUNDISK, P30S REV 33.  9 SEPT 67.
# MOD NO: 0     MOD BY: ZELDIN          DATE:
# MOD NO: 1     MOD BY: RR BAIRNSFATHER DATE: 11 APR 67
# MOD NO: 2     MOD BY: RR BAIRNSFATHER DATE: 12 MAY 67         ADD UR.RT CALC WHEN P
# MOD NO: 2.1   MOD BY: RR BAIRNSFATHER DATE: 5 JULY 67         FIX ERROR ON MOD. 2
# MOD NO: 3     MOD BY: RR BAIRNSFATHER DATE: 12 JUL 67         CHANGE SIGN OF DISPLA
# MOD 4         MOD BY  S.ZELDIN        DATE: 3 APRIL 68        CHANGE EQUATIONS FOR
#
# FUNCTION:     CALCULATE (FOR DISPLAY ON CALL) AN APPROXIMATE MEASURE OF IN-PLANE SP
#               ERROR.  IF THE FREE-FALL TRANSFER ANGLE TO 300K FT ABOVE PAD RADIUS I
#               SPLASH ERROR= -RANGE TO TARGET + FREE-FALL TRANSFER ANGLE + ESTIMATED
#               THE TARGET LOCATION AT ESTIMATED TIME OF IMPACT IS USED.  IF THE FREE
#               ANGLE IS NEGATIVE:  SPASH ERROR= -RANGE TO TARGET.
#               THE PRESENT TARGET LOCATION IS USED.
#
# CALLING SEQUENCE: CALLED AFTER SR30.1 IF IN CSM AND IF P11 OPERATING (UNDER CONTROL
#
# SUBROUTINES CALLED:  VGAMCALC, TFF/TRIG, LALOTORV.
#
# EXIT:         RETURN DIRECTLY TO V 82 PROG. AT SPLRET
#
# ERASABLE INITIALIZATION:  LEFT BY SR30.1 AND V82GON1
#
# OUTPUT:       RSP-RREC RANGE IN REVOLUTIONS.                  DSKY DISPLAY IN N. MI
#
# DEBRIS:       QPRET, PDL0 ... PDL7, PDL10.

# THETA(1)

                BANK    32
                SETLOC  DELRSPL1
                BANK
                COUNT*  $$/P30          # PROGRAMS: P30 EXTERNAL DELTA V

DELRSPL         STORE   8D
                BPL     DSU
                        CANTDO          # GONE PAST 300K FT ALT
                        1BITDP
                BOV     CALL
                        CANTDO          # POSMAX INDICATES NO 300K FT SOLUTION.
                        VGAMCALC        # +GAMMA(REV) IN PMAC,V300 MAG(B-7)=PDL 0
                PUSH    CALL
                        TFF/TRIG
                CALL
```

```
                        AUGEKUGL
                PDDL    ACOS            # T ENTRY PDL 6
                        CDELF/2
                DAD
                        4
GETARG          STOVL   THETA(1)
                        LAT(SPL)
                STODL   LAT
                        HI6ZEROS
                STODL   ALT             # ALT=0 = LAT +4
                        PIPTIME
```

Uses ALT 157, COUNT 142, D 226, DELRSPL1 67, GAMMA 232, HI6ZEROS 71, L 80, L/D 226, LAT 157, LAT(SPL) 224, N 206, P3OS 69, PIPTIME 159, QPRET 85, RANGE 179, RSP-RREC 181, RT 226, TFF 179, THETA 148, THETA(1) 179, and V 229.

1056 ⟨*Page CM0644* 1056⟩≡ (1042b 2757)

```
                    BON     DLOAD
                            V37FLAG
                            +2
                            TSTART82
                    DSU     DAD
                            8D
                    CLEAR   CALL
                            ERADFLAG
                            LALOTORV        # R RECOV. IN ALPHAV AND MPAC

                    UNIT    PDVL
                            RONE
                    UNIT    DOT
                    SL1     ARCCOS
                    BDSU                    # ERROR = THETA EST - THETA TARG
                                            # NEGATIVE NUMBER SIGNIFIES THAT WILL FALL SH
                                            # POSITIVE NUMBER SIGNIFIES THAT WILL OVERSHO
                            THETA(1)
DELRDONE            STCALL  RSP-RREC        # DOWNRANGE RECOVERY RANGE ERROR        /360
                            INTWAKEO
                    CALL
                            SPLRET
CANTDO              DLOAD   PDDL            # INITIALIZE ERASE TO DOT TARGET AND UR
                                            # FOR RANGE ANGLE.
                            HIDPHALF        # TO PDL 0 FOR DEN INDDV.
                            HI6ZEROS
                    PUSH                    # ZERO TO PDL 2 FOR PHI ENTRY
                    STCALL  8D
                            GETARG          # GO SET RSP-RREC =0

AUGEKUGL            VLOAD
                            X1CON -2
                    STODL   X1 -2
                            0
                    DSU     BMN
                            V(21K)
                            LOOPSET
                    XSU,1   XCHX,2
                            S1
                            X1
                    XCHX,2  DSU
                            S1
                            V(3K)
                    BMN     XCHX,2
                            LOOPSET
```

```
        S1
DSU     BMN
        V(4K)
        LOOPSET
XCHX,2  XCHX,2
```

Uses ALPHAV 177, ERADFLAG 99, HI6ZEROS 71, HIDPHALF 71, MPAC 145, RANGE 179, RONE 179, RSP-RREC 181, S1 85, THETA 148, THETA(1) 179, TSTART82 179, V 229, V37FLAG 123, and X1 85.

1058 ⟨*Page CM0645* 1058⟩≡ (1042b 2757)

```
                        S1
                        X1
                DSU     BMN
                        V(400)
                        LOOPSET
                SXA,1
                        S1
LOOPSET         INCR,1  GOTO
                DEC     1
                        K1K2LOOP
K2CALC          SXA,1
                        S1
K1K2LOOP        DLOAD   DSU*
                        0
                        V(32K) +1,1
                DMP*    DAD*
                        YK1K2 +1,1
                        CK1K2 +1,1
                PDDL    TIX,1
                        2
                        K2CALC
                DSU     BDDV
                PUSH    BOV
                        MAXPHI
                BMN     DSU
                        MAXPHI
                        MAXPHIC
                BPL
                        MAXPHI
PHICALC         DLOAD   DSU             # PHI ENTRY PDL 4D
                        0
                        V(26K)
                BPL     DLOAD
                        TGR26
                        TLESS26
                DDV
                        0
TENT            DMP     RVQ
                        4D
TGR26           DLOAD   GOTO
                        TGR26CON
                        TENT

MAXPHI          DLOAD   PDDL
                        MAXPHIC
```

```
                GOTO
                        PHICALC
  MAXPHIC       2DEC    .09259298       # 2000 NM FOR MAXIMUM PHI ENTRY
```

Uses S1 85, V 229, and X1 85.

1059 ⟨*Page CM0646* 1059⟩≡ (1042b 2757)

```
                COUNT*  $$/P30

                                        #               BELOW
                                        # **** TABLE IS INDEXED. KEEP IN ORDER ***
```

Uses COUNT 142.

1060 ⟨*Page CM0646a* 1060⟩≡ (1042b 2757)

```
                    2DEC    7.07304526 E-4          # 5500
                    2DEC    3.08641975 E-4          # 2400
                    2DEC    3.08641975 E-4          # 2400
                    2DEC    -8.8888888 E-3          # -3.2
                    2DEC    2.7777777 E-3           # 1
CK1K2               2DEC    6.6666666 E-3           # 2.4
                    2DEC    0                       # 0
                    2DEC*   -1.86909989 E-5 B7*     # -.443
                    2DEC    0
                    2DEC*   1.11639691 E-3 B7*      # .001225
                    2DEC*   9.56911636 E-4 B7*      # .00105
YK1K2               2DEC*   2.59733157 E-4 B7*      # .000285
V(400)              2DEC    1.2192 B-7
V(28K)              2DEC    85.344 B-7
V(3K)               2DEC    9.144 B-7
V(24K)              2DEC    73.152 B-7
                    2DEC    85.344 B-7
V(32K)              2DEC    97.536 B-7
V(4K)               2DEC    12.192 B-7
V(21K)              2DEC    64.000 B-7
TLESS26             2DEC*   5.70146688 E7 B-35*     # 8660PHI/V
TGR26CON            2DEC    7.2 E5 B-28             # PHI/3
V(26K)              2DEC    79.248 B-7              # 26000
```

Uses V 229.

1061 ⟨*Page CM0647* 1061⟩≡ (1042b 2757)

```
X1CON           DEC     10

                DEC     8

                DEC     6
                                        # **** TABLE IS INDEXED.  KEEP IN ORDER ***
                                        #               ABOVE
```

1062a ⟨*Page CM0648* 1062a⟩≡ (1042b 2757)

```
# ***** AVFLAG/P *****
#
# SUBROUTINES USED
#
#       UPFLAG
#       DOWNFLAG

                SETLOC  P30SUBS
                BANK
                EBANK=  SUBEXIT
AVFLAGA         EXTEND                  # AVFLAG = CSM
                QXCH    SUBEXIT
                TC      DOWNFLAG
                ADRES   AVFLAG          # BIT 5 FLAG 2
                CAF     EBANK7
                TS      EBANK
                EBANK=  ECSTEER
                CAF     BIT13
                TS      ECSTEER         # SET ECSTEER = 1
                CAF     EBANK4
                TS      EBANK
                EBANK=  SUBEXIT
                TC      SUBEXIT
AVFLAGP         EXTEND                  # AVFLAG = LEM
                QXCH    SUBEXIT
                TC      UPFLAG
                ADRES   AVFLAG          # BIT 5 FLAG 2
                TC      SUBEXIT
P20FLGON        EXTEND
                QXCH    SUBEXIT
                TC      UPFLAG
                ADRES   TRACKFLG
                TC      UPFLAG
                ADRES   UPDATFLG
                TC      SUBEXIT         # DP B4
```

Uses AVFLAG 105, EBANK 80, ECSTEER 224, P 188, P30SUBS 57, SUBEXIT 181, TC 169, TRACKFLG 101, and UPDATFLG 99.

3.5.5 p32-p33 p72-p73 code

1062b ⟨*p32-p33 p72-p73 code* 1062b⟩≡ (857a 2759)

⟨*Page CM0649* 1063⟩

1063 ⟨*Page CM0649* 1063⟩≡ (1062b)

```
# Page 649
# COELLIPTIC SEQUENCE INITIATION (CSI) PROGRAMS (P32 AND P72)
#
# MOD NO -1             LOG SECTION -- P32-P35, P72-P75
# MOD BY WHITE.P        DATE 1JUNE67
#
# PURPOSE
#       (1)     TO CALCULATE PARAMETERS ASSOCIATED WITH THE FOLLOWING
#               CONCENTRIC FLIGHT PLAN MANEUVERS -- THE CO-ELLIPTIC SEQUENCE
#               INITIATION (CSI) MANEUVER AND THE CONSTANT DELTA ALTITUDE
#               (CDH) MANEUVER.
#       (2)     TO CALCULATE THESE PARAMETERS BASED UPON MANEUVER DATA
#               APPROVED AND KEYED INTO THE DSKY BY THE ASTRONAUT.
#       (3)     TO DISPLAY TO THE ASTRONAUT AND THE GROUND DEPENDENT VARIABLES
#               ASSOCIATED WITH THE CONCENTRIC FLIGHT PLAN MANEUVERS FOR
#               APPROVAL BY THE ASTRONAUT/GROUND.
#       (4)     TO STORE THE CSI TARGET PARAMETERS FOR USE BY THE DESIRED
#               THRUSTING PROGRAM.
#
# ASSUMPTIONS
#       (1)     AT A SELECTED TPI TIME THE LINE OF SIGHT BETWEEN THE ACTIVE
#               AND PASSIVE VEHICLES IS SELECTED TO BE A PRESCRIBED ANGLE (E)
#               FROM THE HORIZONTAL PLANE DEFINED BY THE ACTIVE VEHICLE
#               POSITION.
#       (2)     THE TIME BETWEEN CSI IGNITION AND CDH IGNITION MUST BE
#               COMPUTED TO BE GREATER THAN 10 MINUTES FOR SUCCESSFUL
#               COMPLETION OF THE PROGRAM.
#       (3)     THE TIME BETWEEN CDH IGNITION AND TPI IGNITION MUST BE
#               COMPUTED TO BE GREATER THAN 10 MINUTES FOR SUCCESSFUL
#               COMPLETION OF THE PROGRAM.
#       (4)     CDH DELTA V IS SELECTED TO MINIMIZE THE VARIATION OF THE
#               ALTITUDE DIFFERENCE BETWEEN THE ORBITS.
#       (5)     CSI BURN IS DEFINED SUCH THAT THE IMPULSIVE DELTA V IS IN THE
#               HORIZONTAL PLANE DEFINED BY THE ACTIVE VEHICLE POSITION AT CSI
#               IGNITION.
#       (6)     THE PERICENTER ALTITUDE OF THE ORBIT FOLLOWING CSI AND CDH
#               MUST BE GREATER THAN 35,000 FT (LUNAR ORBIT) OR 85 NM (EARTH
#               ORBIT) FOR SUCCESSFUL COMPLETION OF THIS PROGRAM.
#       (7)     THE CSI AND CDH MANEUVERS ARE ORIGINALLY ASSUMED TO BE
#               PARALLEL TO THE PLANE OF THE CSM ORBIT.  HOWEVER, CREW
# Page 650
#               MODIFICATION OF DELTA V (LV) COMPONENTS MAY RESULT IN AN
#               OUT-OF-PLANE CSI MANEUVER
#       (8)     STATE VECTOR UPDATES BY P27 ARE DISALLOWED DURING AUTOMATIC
#               STATE VECTOR UPDATING INITIATED BY P20 (SEE ASSUMPTION 10).
```

```
#       (9)     COMPUTED VARIABLES MAY BE STORED FOR LATER VERIFICATION BY
#               THE GROUND.  THESE STORAGE CAPABILITIES ARE NORMALLY LIMITED
#               ONLY TO THE PARAMETERS FOR ONE THRUSTING MANEUVER AT A TIME
#               EXCEPT FOR CONCENTRIC FLIGHT PLAN MANEUVER SEQUENCES.
#       (10)    THE RENDEZVOUS RADAR MAY OR MAY NOT BE USED TO UPDATE THE LM
#               OR CSM STATE VECTORS FOR THIS PROGRAM.  IF RADAR USE IS
#               DESIRED THE RADAR WAS TURNED ON AND LOCKED BY THE CSM BY
#               PREVIOUS SELECTION OF P20.  RADAR SIGHTING MARKS WILL BE MADE
#               AUTOMATICALLY APPROXIMATELY ONCE A MINUTE WHEN ENABLED BY THE
#               TRACK AND UPDATE FLAGS (SEE P20).  THE RENDEZVOUS TRACKING
#               MARK COUNTER IS ZEROED BY THE SELECTION OF P20 AND AFTER EACH
#               THRUSTING MANEUVER.
#       (11)    THE ISS NEED NOT BE ON TO COMPLETE THIS PROGRAM.
#       (12)    THE OPERATION OF THE PROGRAM UTILIZES THE FOLLOWING FLAGS --
#
#                       ACTIVE VEHICLE FLAG -- DESIGNATES THE VEHICLE WHICH IS
#                       DOING RENDEZVOUS THRUSTING MANEUVERS TO THE PROGRAM WHICH
#                       CALCULATES THE MANEUVER PARAMETERS.  SET AT THE START OF
#                       EACH RENDEZVOUS PRE-THRUSTING PROGRAM.
#
#                       FINAL FLAG -- SELECTS FINAL PROGRAM DISPLAYS AFTER CREW HAS
#                       COMPLETED THE FINAL MANEUVER COMPUTATION AND DISPLAY
#                       CYCLE.
#
#                       EXTERNAL DELTA V STEERING FLAG -- DESIGNATES THE TYPE OF
#                       STEERING REQUIRED FOR EXECUTION OF THIS MANEUVER BY THE
#                       THRUSTING PROGRAM SELECTED AFTER COMPLETION OF THIS
#                       PROGRAM.
#
#       (13)    IT IS NORMALLY REQUIRED THAT THE ISS BE ON FOR 1 HOUR PRIOR TO
#               A THRUSTING MANEUVER.
#
#       (14)    THIS PROGRAM IS SELECTED BY THE ASTRONAUT BY DSKY ENTRY
#
#                       P32 IF THIS VEHICLE IS ACTIVE VEHICLE.
#
#                       P72 IF THIS VEHICLE IS THE PASSIVE VEHICLE.
#
# INPUT
#       (1)     TCSI            TIME OF THE CSI MANEUVER
# Page 651
#       (2)     NN              NUMBER OF APSIDAL CROSSINGS THRU WHICH THE ACTIVE
#                               VEHICLE ORBIT CAN BE ADVANCED TO OBTAIN THE CDH
#                               MANEUVER POINT.
#       (3)     ELEV            DESIRED LOS ANGLE AT TPI
#       (4)     TTPI            TIME OF THE TPI MANEUVER
```

```
#
# OUTPUT
#       (1)     TRKMKCNT        NUMBER OF MARKS
#       (2)     TTOGO           TIME TO GO
#       (3)     +MGA            MIDDLE GIMBAL ANGLE
#       (4)     DIFFALT         DELTA ALTITUDE AT CDH
#       (5)     T1TOT2          DELTA TIME FROM CSI TO CDH
#       (6)     T2TOT3          DELTA TIME FROM CDH TO TPI
#       (7)     DELVLVC         DELTA VELOCITY AT CSI -- LOCAL VERTICAL COORDINATES
#       (8)     DELVLVC         DELTA VELOCITY AT CDH -- LOCAL VERTICAL COORDINATES
#
# DOWNLINK
#       (1)     TCSI            TIME OF THE CSI MANEUVER
#       (2)     TCDH            TIME OF THE CDH MANEUVER
#       (3)     TTPI            TIME OF THE TPI MANEUVER
#       (4)     TIG             TIME OF THE CSI MANEUVER
#       (5)     DELVEET1        DELTA VELOCITY AT CSI -- REFERENCE COORDINATES
#       (6)     DELVEET2        DELTA VELOCITY AT CDH -- REFERENCE COORDINATES
#       (7)     DIFFALT         DELTA ALTITUDE AT CDH
#       (8)     NN              NUMBER OF APSIDAL CROSSINGS THRU WHICH THE ACTIVE
#                               VEHICLE ORBIT CAN BE ADVANCED TO OBTAIN THE CDH
#                               MANEUVER POINT
#       (9)     ELEV            DESIRED LOS ANGLE AT TPI
#
# COMMUNICATION TO THRUSTING PROGRAMS
#       (1)     TIG             TIME OF THE CSI MANEUVER
#       (2)     RTIG            POSITION OF ACTIVE VEHICLE AT CSI -- BEFORE ROTATION
#                               INTO PLANE OF PASSIVE VEHICLE
#       (3)     VTIG            VELOCITY OF ACTIVE VEHICLE AT CSE -- BEFORE ROTATION
#                               INTO PLANE OF PASSIVE VEHICLE
#       (4)     DELVSIN         DELTA VELOCITY AT CSI -- REFERENCE COORDINATES
#       (5)     DELVSAB         MAGNITUDE OF DELTA VELOCITY AT CSI
#       (6)     XDELVFLG        SET TO INDICATE EXTERNAL DELTA V VG COMPUTATION
#
# SUBROUTINES USED
#       AVFLAGA
#       AVFLAGP
#       P20FLGON
#       VARALARM
#       BANKCALL
#       GOFLASH
#       GOTOPOOH
# Page 652
#       VNPOOH
#       GOFLASHR
#       BLANKET
```

```
#       ENDOFJOB
#       SELECTMU
#       ADVANCE
#       INTINT
#       PASSIVE
#       CSI/A
#       S32/33.1
#       DISDVLVC
#       VN1645

                BANK    35
                SETLOC  CSI/CDH1
                BANK
                EBANK=  SUBEXIT
                COUNT   35/P3272
P32             TC      AVFLAGA
                TC      P32STRT
P72             TC      AVFLAGP
P32STRT         TC      INTPRET
                DLOAD
                        ZEROVEC
                STORE   CENTANG
                EXIT
                TC      P32/P72A
ALMXITA         SXA,2
                        CSIALRM
ALMXIT          LXC,1
                        CSIALRM
                SLOAD*  EXIT
                        ALARM/TB -1,1
                CA      MPAC
                TC      VARALARM
                CAF     V05N09
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H
                TC      -4
P32/P72A        TC      P20FLGON
                TC      INTPRET
                DLOAD
                        ZEROVEC
                STORE   NN
                EXIT
                CAF     V06N11          # TCSI
                TC      VNP00H
                CAF     V06N55
```

```
# Page 653
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H
                TC      +2
                TC      -5
                CAF     V06N37          # TTPI
                TC      VNP00H
                TC      INTPRET
                DLOAD
                        TCSI
                STCALL  TIG
                        SELECTMU
P32/P72B        CALL
                        ADVANCE
                SETPD   VLOAD
                        0D
                        VPASS1
                PDVL    PDDL
                        RPASS1
                        TCSI
                PDDL    PDDL
                        TTPI
                        2PISC
                SL2     PUSH
                CALL
                        INTINT
                CALL
                        PASSIVE
                CALL
                        CSI/A
P32/P72C        BON     SET
                        FINALFLG
                        P32/P72D
                        UPDATFLG
P32/P72D        DLOAD   GOTO
                        T1TOT2
                        P32/P72E
                SETLOC  CSI/CDH3
                BANK
P32/P72E        STORE   T1TOT2
                DSU     BPL
                        60MIN
                        P32/P72E
                DLOAD   GOTO
                        T2TOT3
```

```
                        P32/P72F
                SETLOC  CSI/CDH1
                BANK
P32/P72F        STORE   T2TOT3
                DSU     BPL
# Page 654
                        60MIN
                        P32/P72F
                EXIT
                CAF     V06N75
                TC      VNP00H
                TC      INTPRET
                VLOAD   CALL
                        DELVEET1
                        S32/33.1
                STOVL   DELVEET1
                        RACT2
                STOVL   RACT1
                        DELVEET2
                AXT,1   CALL
                VN      0682
                        DISDVLVC
                DLOAD
                        TTPI
                STCALL  TTPIO
                        VN1645
                GOTO
                        P32/P72B

# Page 655
# CONSTANT DELTA HEIGHT (CDH) PROGRAMS (P33 AND P73)
# MOD NO -1                     LOC SECTION -- P32-P35, P72-P75
# MOD BY WHITE, P.              DATE: 1 JUNE 67
#
# PURPOSE
#
#       (1)     TO CALCULATE PARAMETERS ASSOCIATED WITH THE CONSTANT DELTA
#               ALTITUDE MANEUVER (CDH).
#
#       (2)     TO CALCULATE THESE PARAMETERS BASED UPON MANEUVER DATA
#               APPROVED AND KEYED INTO THE DSKY BY THE ASTRONAUT.
#
#       (3)     TO DISPLAY TO THE ASTRONAUT AND THE GROUND DEPENDENT VARIABLES
#               ASSOCIATED WITH THE CDH MANEUVER FOR APPROVAL BY THE
#               ASTRONAUT/GROUND.
#
```

```
#       (4)     TO STORE THE CDH TARGET PARAMETERS FOR USE BY THE DESIRED
#               THRUSTING PROGRAM.
#
# ASSUMPTIONS
#
#       (1)     THIS PROGRAM IS BASED UPON PREVIOUS COMPLETION OF THE
#               CO-ELLIPTIC SEQUENCE INITIATION (CSI) PROGRAM (P32/P72).
#               THEREFORE --
#
#               (A)     AT A SELECTED TPI TIME (NOW IN STORAGE) THE LINE OF SIGHT
#                       BETWEEN THE ACTIVE AND PASSIVE VEHICLES WAS SELECTED TO BE
#                       A PRESCRIBED ANGLE (E) (NOW IN STORAGE) FROM THE
#                       HORIZONTAL PLANE DEFINED BY THE ACTIVE VEHICLE POSITION.
#
#               (B)     THE TIME BETWEEN CSI IGNITION AND CDH IGNITION WAS
#                       COMPUTED TO BE GREATER THAN 10 MINUTES.
#
#               (C)     THE TIME BETWEEN CDH IGNITION AND TPI IGNITION WAS
#                       COMPUTED TO BE GREATER THAN 10 MINUTES.
#
#               (D)     THE VARIATION OF THE ALTITUDE DIFFERENCE BETWEEN THE
#                       ORBITS WAS MINIMIZED.
#
#               (E)     CSI BURN WAS DEFINED SUCH THAT THE IMPULSIVE DELTA V WAS
#                       IN THE HORIZONTAL PLANE DEFINED BY ACTIVE VEHICLE
#                       POSITION AT CSI IGNITION.
#
#               (F)     THE PERICENTER ALTITUDES OF THE ORBITS FOLLOWING CSI AND
#                       CDH WERE COMPUTED TO BE GREATER THAN 35,000 FT FOR LUNAR
#                       ORBIT OR 85 NM FOR EARTH ORBIT.
#
#               (G)     THE CSI AND CDH MANEUVERS WERE ASSUMED TO BE PARALLEL TO
#                       THE PLANE OF THE PASSIVE VEHICLE ORBIT.  HOWEVER, CREW
# Page 656
#                       MODIFICATION OF DELTA V (LV) COMPONENTS MAY HAVE RESULTED
#                       IN AN OUT-OF-PLANE MANEUVER.
#
#       (2)     STATE VECTOR UPDATES BY P27 ARE DISALLOWED DURING AUTOMATIC
#               STATE VECTOR UPDATING INITIATED BY P20 (SEE ASSUMPTION 4).
#
#       (3)     COMPUTED VARIABLES MAY BE STORED FOR LATER VERIFICATION BY
#               THE GROUND.  THESE STORAGE CAPABILITIES ARE NORMALLY LIMITED
#               ONLY TO THE PARAMETERS FOR ONE THRUSTING MANEUVER AT A TIME
#               EXCEPT FOR CONCENTRIC FLIGHT PLAN MANEUVER SEQUENCES.
#
#       (4)     THE RENDEZVOUS RADAR MAY OR MAY NOT BE USED TO UPDATE THE LM.
```

```
#               OR CSM STATE VECTORS FOR THIS PROGRAM.  IF RADAR USE IS
#               DESIRED THE RADAR WAS TURNED ON AND LOCKED ON THE CSM BY
#               PREVIOUS SELECTION OF P20.  RADAR SIGHTING MARKS WILL BE MADE
#               AUTOMATICALLY APPROXIMATELY ONCE A MINUTE WHEN ENABLED BY THE
#               TRACK AND UPDATE FLAGS (SEE P20).  THE RENDEZVOUS TRACKING
#               MARK COUNTER IS ZEROED BY THE SELECTION OF P20 AND AFTER EACH
#               THRUSTING MANEUVER.
#
#       (5)     THE ISS NEED NOT BE ON TO COMPLETE THIS PROGRAM.
#
#       (6)     THE OPERATION OF THE PROGRAM UTILIZES THE FOLLOWING FLAGS --
#
#                       ACTIVE VEHICLE FLAG -- DESIGNATES THE VEHICLE WHICH IS
#                       DOING RENDEZVOUS THRUSTING MANEUVERS TO THE PROGRAM WHICH
#                       CALCULATES THE MANEUVER PARAMETERS.  SET AT THE START OF
#                       EACH RENDEZVOUS PRE-THRUSTING PROGRAM.
#
#                       FINAL FLAG -- SELECTS FINAL PROGRAM DISPLAYS AFTER CREW HAS
#                       COMPLETED THE FINAL MANEUVER COMPUTATION AND DISPLAY
#                       CYCLE.
#
#                       EXTERNAL DELTA V STEERING FLAG -- DESIGNATES THE TYPE OF
#                       STEERING REQUIRED FOR EXECUTION OF THIS MANEUVER BY THE
#                       THRUSTING PROGRAM SELECTED AFTER COMPLETION OF THIS
#                       PROGRAM.
#
#       (7)     IT IS NORMALLY REQUIRED THAT THE ISS BE ON FOR 1 HOUR PRIOR TO
#               A THRUSTING MANEUVER.
#
#       (8)     THIS PROGRAM IS SELECTED BY THE ASTRONAUT BY DSKY ENTRY.
#
#                       P33 IF THIS VEHICLE IS ACTIVE VEHICLE.
#
#                       P73 IF THIS VEHICLE IS PASSIVE VEHICLE.
#
# INPUT
#
#       (1)     TTPIO   TIME OF THE TPI MANEUVER -- SAVED FROM P32/P72
# Page 657
#       (2)     ELEV    DESIRED LOS ANGLE AT TPI -- SAVED FROM P32/P72
#       (3)     TCDH    TIME OF THE CDH MANEUVER
#
# OUTPUT
#
#       (1)     TRKMKCNT        NUMBER OF MARKS
#       (2)     TTOGO           TIME TO GO
```

```
#       (3)     +MGA            MIDDLE GIMBAL ANGLE
#       (4)     DIFFALT         DELTA ALTITUDE AT CDH
#       (5)     T2TOT3          DELTA TIME FROM CDH TO COMPUTED TPI
#       (6)     NOMTPI          DELTA TIME FROM NOMINAL TPI TO COMPUTED TPI
#       (7)     DELVLVC         DELTA VELOCITY AT CDH -- LOCAL VERTICAL COORDINATES
#
# DOWNLINK
#
#       (1)     TCDH            TIME OF THE CDH MANEUVER
#       (2)     TTPI            TIME OF THE TPI MANEUVER
#       (3)     TIG             TIME OF THE CDH MANEUVER
#       (4)     DELLVEET2       DELTA VELOCITY AT CDH -- REFERENCE COORDINATES
#       (5)     DIFFALT         DELTA ALTITUDE AT CDH
#       (6)     ELEV            DESIRED LOS ANGLE AT TPI
#
# COMMUNICATION TO THRUSTING PROGRAMS
#
#       (1)     TIG             TIME OF THE CDH MANEUVER
#       (2)     RTIG            POSITION OF ACTIVE VEHICLE AT CDH -- BEFORE ROTATION
#                               INTO PLANE OF PASSIVE VEHICLE.
#       (3)     VTIG            VELOCITY OF ACTIVE VEHICLE AT CDH -- BEFORE ROTATION
#                               INTO PLANE OF PASSIVE VEHICLE.
#       (4)     DELVSIN         DELTA VELOCITY AT CDH -- REFERENCE COORDINATES.
#       (5)     DELVSAB         MAGNITUDE OF DELTA VELOCITY AT CDH.
#       (6)     XDELVFLG        SET TO INDICATE EXTERNAL DELTA V VG COMPUTATION.
#
# SUBROUTINES USED
#
#       AVFLAGA
#       AVFLAGP
#       P20FLGON
#       VNP00H
#       SELECTMU
#       ADVANCE
#       CDHMVR
#       INTINT3P
#       ACTIVE
#       PASSIVE
#       S33/S34.1
#       ALARM
#       BANKCALL
#       GOFLASH
#       GOTOP00H
#       S32/33.1
# Page 658
#       VN1645
```

```
                COUNT   35/P3373

P33             TC      AVFLAGA
                TC      P33/P73A
P73             TC      AVFLAGP
P33/P73A        TC      P20FLGON
                CAF     V06N13          # TCDH
                TC      VNP00H
                TC      INTPRET
                DLOAD
                        TTPIO
                STODL   TTPI
                        TCDH
                STCALL  TIG
                        SELECTMU
P33/P73B        CALL
                        ADVANCE
                CALL
                        CDHMVR
                SETPD   VLOAD
                        0D
                        VACT3
                PDVL    CALL
                        RACT2
                        INTINT3P
                CALL
                        ACTIVE
                SETPD   VLOAD
                        0D
                        VPASS2
                PDVL    CALL
                        RPASS2
                        INTINT3P
                CALL
                        PASSIVE
                DLOAD   SET
                        ZEROVEC
                        ITSWICH
                STCALL  NOMTPI
                        S33/34.1
                BZE     EXIT
                        P33/P73C
                TC      ALARM
                OCT     611
                CAF     V05N09
```

```
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H
# Page 659
                TC      +2
                TC      P33/P73A
                TC      INTPRET
                DLOAD
                        ZEROVEC
                STCALL  NOMTPI
                        P33/P73C
                SETLOC  CSI/CDH2
                BANK

P33/P73C        BON     SET
                        FINALFLG
                        P33/P73D
                        UPDATFLG
P33/P73D        DLOAD   DAD
                        NOMTPI
                        TTPI
                STORE   TTPI
                DSU     GOTO
                        TCDH
                        P33/P73E
                SETLOC  CSI/CDH1
                BANK

P33/P73E        DSU     BPL
                        60MIN
                        P33/P73E
                DAD
                        60MIN
                STODL   T1TOT2
                        TTPI
                DSU     PUSH
                        TTPIO
P33/P73F        ABS     DSU
                        60MIN
                BPL     DAD
                        P33/P73F
                        60MIN
                SIGN    STADR
                STORE   T2TOT3
                EXIT
                CAF     V06N75
```

```
                TC      VNP00H
                TC      INTPRET
                VLOAD   CALL
                        DELVEET2
                        S32/33.1
                STCALL  DELVEET2
                        VN1645
                GOTO
# Page 660
                        P33/P73B

# Page 661
# ***** AVFLAGA/P *****

# Page 662
# ***** DISDVLVC *****
#
# SUBROUTINES USED
#
#       S32/33.X
#       VNP00H

                SETLOC  CDHTAG3
                BANK

DISDVLVC        STORE   DELVLVC
                STQ     CALL
                        NORMEX
                        S32/33.X
                VLOAD   MXV
                        DELVLVC
                        OD
                VSL1    SXA,1
                        VERBNOUN
                STORE   DELVLVC
                EXIT
                CA      VERBNOUN
                TC      VNP00H
                TC      INTPRET
                GOTO
                        NORMEX
                SETLOC  FFTAG12
                BANK

V06N11          VN      0611
V06N13          VN      0613
```

```
V06N75          VN      0675

V06N50          VN      0650

# Page 663

# ***** CSI/A *****
#
# SUBROUTINES USED
#
#       VECSHIFT
#       TIMETHET
#       PERIAPO
#       SHIFTR1
#       INTINT2C
#       CDHMVR
#       PERIAPO1
#       INTINT
#       ACTIVE

                BANK    34
                SETLOC  CSIPROG
                BANK
                EBANK=  SUBEXIT
                COUNT   34/CSI

60MIN           2DEC    360000

ALARM/TB        OCT     00600           # NO 1
                OCT     00601           #    2
                OCT     00602           #    3
                OCT     00603           #    4
                OCT     00604           #    5
                OCT     00605           #    6
                OCT     00606           #    7
LOOPMX          2DEC    16

INITST          2DEC    .03048 B-7      # INITIAL DELDV = 10 FPS

DVMAX1          2DEC    3.0480 B-7      # MAXIMUM DV1 = 1000 FPS

DVMAX2          2DEC    3.014472 B-7    #                989 FPS

1DPB2           2DEC    1.0 B-2

1DPB28          2DEC    1
```

```
EPSILN1         2DEC    .0003048 B-7    # .1 FPS


FIFPSDP         2DEC    -.152400 B-7    # 5 FPS

DELMAX1         2DEC    .6096000 B-7    # 200 FPS

                SETLOC  CSI/CDH
                BANK
PMINE           2DEC    157420 B-29     # 84 NM -- MUST BE 8 WORDS BEFORE PMINM

# Page 664

NICKELDP        2DEC    .021336 B-7     # 7 FPS

INITST1         2DEC    .03048 B-7      # INITIAL DELDV = 10 FPS

ONETHTH         2DEC    .0001 B-3

PMINM           2DEC    10668 B-29      # 35000 FT -- MUST BE 8 WORDS AFTER PMINE

                SETLOC  CSIPROG
                BANK

CSI/A           CLEAR   SET             # INITIALIZE INDICATORS
                        S32.1F1         # DVT1 HAS EXCEEDED MAX INDICATOR
                        S32.1F2         # FIRST PASS FOR NEWTON ITERATION INDICATOR
                CLEAR   SET
                        S32.1F3A        # 00=1ST 2 PASSES 2ND CYCLE, 01=FIRST CYCLE
                        S32.1F3B        # 10=2ND CYCLE, 11=50 FPS STAGE 2ND CYCLE
                DLOAD
                        ZEROVEC
                STORE   LOOPCT
                STORE   CSIALRM
CSI/B           SETPD   VLOAD
                        OD
                        RACT1
                ABVAL   PUSH            # RA1                                   B29 PI
                NORM    SR1
                        X2              #                               B29-N2+ B1 PI
                PDVL    ABVAL
                        RPASS3
                NORM    BDDV            # RA1/RP3                                B1 PI
                        X1
                XSU,2   SR*             #                                      B2
```

```
                X1
                1,2
        DAD     DMP             # (1+(RA1/RP3))RA1              B29+B2=B31 PL00D
                1DPB2
        NORM    PDDL            #                                         PL02D
                X1
                RTMU
        SR1     DDV             #                             B38-B31= B7 PL00D
        SL*     SQRT            #                                      B7
                0 -7,1
        PDVL    UNIT            #                                         PL02D
                RACT1
        PDVL    VXV
                UP1
        UNIT                    # UNIT(URP1 X UVP1 X URA1) = UH1
        DOT     SL1             # VA1 . UH1                            B7
                VACT1
        BDSU    STADR           #                                         PL00D
# Page 665
        STODL   DELVCSI
                INITST          # 10 FPS
        STORE   DELDV
CSI/B1  DLOAD   DAD             # IF LOOPCT = 16
                LOOPCT
                1DPB28
        STORE   LOOPCT
        DSU     AXT,2
                LOOPMX
                6
        BPL     GOTO
                SCNDSOL
                CSI/B2

        SETLOC  CSIPROG2
        BANK

CSI/B2  SETPD
                0D
        DLOAD   ABS
                DELVCSI
        DSU     BMN
                DVMAX1
                CSI/B23
        AXT,2   BON
                7
                S32.1F1
```

```
                        SCNDSOL
                BOFF    BON
                        S32.1F3A
                        CSI/B22         # FLAG 3 NEQ 3
                        S32.1F3B
                        SCNDSOL
CSI/B22         SET     DLOAD
                        S32.1F1
                        DVMAX2
                SIGN
                        DELVCSI
                STCALL  DELVCSI
                        CSI/B23

                SETLOC  CSIPROG3
                BANK

CSI/B23         VLOAD   PUSH
                        RACT1
                UNIT    PDVL
                        UP1
                VXV     UNIT            # UNIT (URP1 X UVP1 X URA1) = UH1
                VXSC    VSL1
# Page 666
                        DELVCSI
                STORE   DELVEET1
                VAD     BOV
                        VACT1
                        CSI/B23D
CSI/B23D        STCALL  VACT4
                        VECSHIFT
                STOVL   VVEC
                SET
                        RVSW
                STOVL   RVEC
                        SN359+
                STCALL  SNTH            # ALSO CSTH
                        TIMETHET
                SR1     LXA,1
                        RTX1
                STCALL  HAFPA1
                        PERIAPO
                CALL
                        SHIFTR1
                STODL   POSTCSI
                        CENTANG
```

```
                BZE     GOTO
                        +2
                        CIRCL
                DLOAD
                        ECC
                DSU     BMN
                        ONETHTH
                        CIRCL
                DLOAD   CALL
                        R1
                        SHIFTR1
                SETPD   NORM
                        2D
                        X1
                PDVL    DOT             #                               PL04D
                        RACT1
                        VACT4
                ABS     DDV
                        02D             # (/RDOTV/)/R1          B36-B29= B7
                SL*     DSU
                        0,1
                        NICKELDP
                BMN     DLOAD
                        CIRCL
                        P
                SL2     DSU
                        1RTEB2          # 1.B.2
                STODL   14D
# Page 667
                        RTSR1/MU
                SR1     DDV             # (1/ROOTMU)/R1         B-16-B29 = B-45 PL02D
                PDDL    DMP
                        P
                        R1
                CALL
                        SHIFTR1
                SL4     SL1
                SQRT    DMP             # ((P/MU)**.5)/R1       B14+B-14 = B-31 BL02D
                BOFF    SL3
                        CMOONFLG
                        CSI/B3
CSI/B3          PDVL    DOT
                        RACT1
                        VACT4
                STORE   RDOTV
                ABS
```

```
                NORM    DMP             # ((P/MU)**.5)RDOTV/R1                  PL02D
                        X2
                XSU,1   SL*             #                       B-31+B36-B3 = B2
                        X2
                        3,1
                STODL   12D
                        ZEROVECS
                STORE   16D
                VLOAD   UNIT
                        12D
                STOVL   SNTH            # ALSO STORES CSTH AND 0
                        RACT1
                PDVL    SIGN
                        VACT4
                        RDOTV
                VCOMP   CALL
                        VECSHIFT
                STOVL   VVEC
                SETGO
                        RVSW
                        CSINEXT

SN359+          2DEC    -.000086601

CS359+          2DEC    +.499999992

                SETLOC  CSIPROG4
                BANK

CSINEXT         STCALL  RVEC
                        TIMETHET
                PDDL    BPL
                        RDOTV
# Page 668
                        NTP/2
                DLOAD   DSU
                        HAFPA1
                PUSH    GOTO
                        NTP/2
CIRCL           SETPD   DLOAD
                        00D
                        ZEROVECS
                PUSH
NTP/2           DLOAD   DMP
                        NN
                        HAFPA1
```

```
                SL      DSU
                        14D
                DAD
                        TCSI
                STORE   TCDH
                BDSU    AXT,2
                        TTPI
                        5D
                BMN     SETPD
                        SCNDSOL
                        0D
                VLOAD   PDVL
                        VACT4
                        RACT1
                CALL
                        INTINT2C
                STOVL   RACT2
                        VATT
                STOVL   VACT2
                        VPASS1
                SETPD   PDVL
                        0D
                        RPASS1
                GOTO
                        CSINEXT1

                SETLOC  CSIPROG5
                BANK

CSINEXT1        CALL
                        INTINT2C
                STOVL   RPASS2
                        VATT
                STCALL  VPASS2
                        CDHMVR
                VLOAD   SETPD
                        RACT2
                        0D
# Page 669
                PDVL    CALL
                        VACT3
                        PERIAPO1
                CALL
                        SHIFTR1
                STOVL   POSTCDH
                        VACT3
```

```
                SETPD   PDVL
                        0D
                        RACT2
                PDDL    PDDL
                        TCDH
                        TTPI
                PDDL    SL2
                        2PISC
                PUSH    CALL
                        INTINT
                CALL
                        ACTIVE
                DLOAD
                        ELEV
                SETPD   SINE
                        6D
                PDVL    UNIT
                        RACT3
                STORE   00D             # URA3 AT 00D
                PDVL    VXV             # PL14D, PL08D
                        UP1
                UNIT
                PDDL    COSINE          # UNIT(URA3 X UVA3 X URA3) = UH3        B1 PI
                        ELEV
                VXSC    STADR           # (COSLOS)(UH3)                         B2 PI
                STCALL  18D             #               PLUS
                        CSINEXT2

                SETLOC  CSIPROG6
                BANK

CSINEXT2        DLOAD   VXSC            # (SINLOS)(URA3) = U                    B2 PI
                VAD     VSL1
                        18D             #                                       B1
                PUSH    DOT             #                                          PI
                        RACT3           # (U . RA3) = TEMP1         B1 + B29 = B30
                SL1     PUSH            #                                     B29 PI
                DSQ     TLOAD           # TEMP1**2                            B58
                        MPAC
                PDVL    DOT             #                                          PI
                        RACT3
                        RACT3
                TLOAD   DCOMP           # RA3 . RA3
# Page 670
                        MPAC
                PDVL    DOT             # RP3 . RP3                        B58 PL14D
```

```
                RPASS3
                RPASS3          #                                       PL11D
        TAD     TAD             # TEMP1**2 + RA3.RA3 + RP3.RP3 = TEMP2  PL08D
        BPL     DLOAD
                K10RK2
                LOOPCT
        DSU     AXT,2
                1DPB28
                1D
        BZE
                ALMXITA
        DLOAD   SR1
                DELDV
        STORE   DELDV
        BDSU
                DVPREV
        STCALL  DELVCSI
                CSI/B1
K10RK2  SQRT    PUSH            # TEMP3 = TEMP2**.5                 B29 PL10D
        DCOMP   DSU
                06D             # -TEMP1-TEMP3 = K2 AT 10D
        STODL   10D             #                                       PL08D
        DSU     STADR           #                                       PL06D
        STORE   12D             # -TEMP1+TEMP3 = K1 AT 12D
        ABS
        STODL   14D
                10D
        ABS     DSU
                14D
        BMN     DLOAD
                K2.
                12D
        STCALL  10D             # K EQUALS K1
                K2.

        SETLOC  CSIPROG7
        BANK

K2.     DLOAD
                10D
        VXSC    VSL1
        VAD     UNIT            # V = RA3 + KU UNIT                 B1
                RACT3
        PDVL    UNIT
                RPASS3          #                                       PL06D
        PDVL    UNIT
```

```
                        VPASS3          #                                       PL12D
                VXV     PDVL            # UVP3 X URP3                           PL18D
# Page 671
                        06D
                        06D
                VXV     DOT
                        00D
                STADR                   #                                       PL12D
                STOVL   12D             # (URP3 X V).(UVP3 X URP3)=TEMP         PL06D
                DOT     SL1             #                                       PL00D
                ARCCOS  SIGN
                        12D             #                                   B0
                SR1     PUSH            # GAMMA = SIGN(TEMP)ARCOS(UNITV.URP3)   PL02D
                BON     DLOAD
                        S32.1F2
                        FRSTPAS
                        00D             # NOT THE FIRST PASS OF A CYCLE
                DSU     PDDL            # GAMMA-GAMPREV                     B1 PL04D
                        GAMPREV
                        DELVCSI
                DSU     NORM            #                                   B7
                        DVPREV
                        X1
                BDDV    PDDL            # (GAM-GAMPREV)/(DV-DVPREV)      B-6+N1 PL06D
                        02D             #       = SLOPE
                        DELVCSI
                STORE   DVPREV
                BOFF    BOFF
                        S32.1F3A
                        THRDCHK
                        S32.1F3B
                        THRDCHK
                DLOAD   DMP
                        02D
                        GAMPREV
                BPL     DLOAD
                        FIFTYFPS
                        INITST1
                SIGN
                        DELDV
                STORE   DELDV
                SET     CLEAR
                        S32.1F3A
                        S32.1F3B
FRSTPAS         DLOAD
                        00D
```

```
                STODL   GAMPREV
                        DELVCSI
                STCALL  DVPREV
                        CSINEXT3

                SETLOC  CSIPROG8
                BANK
# Page 672

CSINEXT3        DSU     CLEAR
                        DELDV
                        S32.1F2
                STCALL  DELVCSI
                        CSI/B1
THRDCHK         BON     BON
                        S32.1F3A
                        NEWTN
                        S32.1F3B
                        NEWTN
FIFTYFPS        DLOAD   SIGN
                        FIFPSDP
                        04D
                SIGN
                        GAMPREV
                STORE   DELDV
                DCOMP   DAD
                        DELVCSI
                STODL   DELVCSI
                        00D
                SET     SET
                        S32.1F3B
                        S32.1F3A
                STCALL  GAMPREV
                        CSI/B2
NEWTN           DLOAD   NORM
                        04D
                        X2
                BDDV    XSU,1
                        00D
                        X2
                SR*
                        0,1
                STODL   DELDV
                        00D
                STORE   GAMPREV
                DLOAD   ABS
```

```
                        DELDV
                PUSH    DSU             #                                       PL08D
                        EPSILN1
                BMN     DLOAD
                        CSI/SOL
                DSU     BMN
                        DELMAX1
                        CSISTEP
                DLOAD   SIGN
                        DELMAX1
                        DELDV
                STORE   DELDV
CSISTEP         DLOAD   DSU
# Page 673
                        DELVCSI
                        DELDV
                STCALL  DELVCSI
                        CSI/B1
CSI/SOL         DLOAD   AXT,2
                        POSTCSI
                        2
                LXA,1   GOTO
                        RTX1
                        CSINEXT4

                SETLOC  CSIPROG9
                BANK

CSINEXT4        DSU*    BMN
                        PMINE -2,1
                        SCNDSOL
                AXT,2   DLOAD
                        3
                        POSTCDH
                DSU*    BMN
                        PMINE -2,1
                        SCNDSOL
                DLOAD   DSU
                        TCDH
                        TCSI
                STORE   T1TOT2
                AXT,2   DSU
                        4
                        600SEC
                BMN     AXT,2
                        SCNDSOL
```

```
                        5
                DLOAD   DSU
                        TTPI
                        TCDH
                STORE   T2TOT3
                DSU     BPL
                        600SEC
                        P32/P72C
SCNDSOL         BON     BOFF
                        S32.1F3A
                        ALMXIT
                        S32.1F3B
                        ALMXIT
                SXA,2   DLOAD
                        CSIALRM
                        ZEROVECS
                CLEAR   SET
                        S32.1F1
# Page 674
                        S32.1F2
                CLEAR   CLEAR
                        S32.1F3A
                        S32.1F3B
                STCALL  LOOPCT
                        CSI/B

# Page 675
# ***** ADVANCE *****
#
# SUBROUTINES USED
#       PRECSET
#       ROTATE

                SETLOC  CDHTAG3
                BANK

ADVANCE         STQ     DLOAD
                        SUBEXIT
                        TIG
                STCALL  TDEC1
                        PRECSET
                SET     VLOAD
                        XDELVFLG
                        VPASS3
                STORE   VPASS2
                STOVL   VPASS1
```

```
                        RPASS3
                STORE   RPASS2
                STORE   RPASS1
                UNIT    VXV
                        VPASS1
                UNIT
                STOVL   UP1
                        RACT3
                STCALL  RTIG
                        ROTATE
                STORE   RACT2
                STOVL   RACT1
                        VACT3
                STCALL  VTIG
                        ROTATE
                STORE   VACT2
                STCALL  VACT1
                        SUBEXIT

# Page 676
# ***** ROTATE *****

                SETLOC  CDHTAG
                BANK

ROTATE          PUSH    PUSH
                DOT     VXSC
                        UP1
                        UP1
                VSL2    BVSU
                UNIT    PDVL
                ABVAL   VXSC
                VSL1    RVQ

# Page 677
# ***** INTINTNA *****

                SETLOC  CDHTAG2
                BANK

INTINT2C        PDDL    PDDL
                        TCSI
                        TCDH
                PDDL    PUSH
                        TWOPI
                GOTO
```

```
                        INTINT
INTINT3P        PDDL    PDDL
                        TCDH
                        TTPI
                PDDL    PUSH
                        ZEROVECS
                GOTO
                        INTINT

# Page 678
# ***** S32/33.1 *****
#
# SUBROUTINES USED
#       S32/33.X

                SETLOC  CSI/CDH
                BANK

S32/33.1        STQ     AXT,1
                        SUBEXIT
                VN      0681
                CALL
                        DISDVLVC
                CALL
                        S32/33.X
                VLOAD   VXM
                        DELVLVC
                        0D
                VSL1
                STORE   DELVSIN
                PUSH    ABVAL
                STOVL   DELVSAB
                GOTO
                        SUBEXIT

# Page 679
# ***** S32/33.X *****

                SETLOC  CDHTAGS
                BANK

S32/33.X        SETPD   VLOAD
                        6D
                        UP1
                VCOMP   PDVL
                        RACT1
```

```
                UNIT    VCOMP
                PUSH    VXV
                        UP1
                VSL1
                STORE   OD
                RVQ

# Page 680
# ***** CDHMVR *****
#
# SUBROUTINES USED
#       VECSHIFT
#       TIMETHET
#       SHIFTR1

                SETLOC  CDHTAG
                BANK

CDHMVR          STQ     VLOAD
                        SUBEXIT
                        RACT2
                PUSH    UNIT
                STOVL   UNVEC           # UR SUB A
                        RPASS2
                UNIT    DOT
                        UNVEC
                PUSH    SL1
                STODL   CSTH
                DSQ     PDDL
                        DP1/4
                SR2     DSU
                SQRT    SL1
                PDVL    VCOMP
                VXV
                        RPASS2
                DOT     PDDL
                        UP1
                SIGN    STADR
                STOVL   SNTH
                        RPASS2
                PDVL    CALL
                        VPASS2
                        VECSHIFT
                STOVL   VVEC
                CLEAR
                        RVSW
```

```
                STCALL  RVEC
                        TIMETHET
                LXA,2   VSL*
                        RTX2
                        0,2
                STORE   18D
                DOT     SL1R
                        UNVEC
                PDVL    ABVAL           # 0D = V SUB PV
                SL*     PDVL
                        0,2
# Page 681
                        RACT2
                ABVAL   PDDL            # 2D = LENGTH OF R SUB A
                DSU
                        02D
                STODL   DIFFALT         # DELTA H IN METERS             B+29
                        R1A
                NORM    PDDL            # 2 - R V**/MU                          04D
                        X1
                        R1
                CALL
                        SHIFTR1
                SR1R    DDV
                SL*     PUSH
                        0 -5,1
                DSU     PDDL            # A SUB A                       B+29    04D
                        DIFFALT
                SR2     DDV             # A SUB P                       B+31
                        04D             #                               B+2
                PUSH    SQRT            # A SUB P/A SUB A                       06D
                DMPR    DMP
                        06D
                        00D
                SL3R    PDDL            # V SUB A V METERS/CS           B+7     08D
                        02D             # R SUB A MAGNITUDE             B+29
                NORM    PDDL
                        X1
                        RTMU
                SR1     DDV             # 2MU                           B+38
                SL*     PDDL            # 2 MU/R SUBAA                  B+14    10D
                        0 -5,1
                        04D             # ASUBA                         B+29
                NORM    PDDL
                        X2
                        RTMU
```

```
                SR1     DDV
                SL*     BDSU
                        0 -6,2          # 2U/R - U/A             B+14 (METERS/CS)SQ
                PDDL    DSQ             #                                     10D
                        08D
                BDSU    SQRT
                PDVL    VXV             # SQRT(MU(2/R SUB A-1/A SUB A)-VSUBA2)  10D
                        UP1
                        UNVEC
                UNIT    VXSC
                        10D
                PDVL    VXSC
                        UNVEC
                        08D
                VAD     VSL1
                STADR
# Page 682
                STORE   VACT3
                VSU
                        VACT2
                STCALL  DELVEET2        # DELTA VCDH -- REFERENCE COORDINATES
                        SUBEXIT

# Page 683
# ***** COMPTGO *****
#
# SUBROUTINES USED
#       CLOKTASK
#       2PHSCHNG

                BANK    35
                SETLOC  CSI/CDH
                BANK

                EBANK=  RTRN

                COUNT*  $$/P3575
```

Uses +MGA 234, A 80, CDHTAG 59, CDHTAG2 67, CDHTAG3 69, CDHTAGS 61, CMOONFLG 125, COUNT 142, CSI/CDH 69, CSI/CDH1 57, CSI/CDH2 61, CSI/CDH3 61, CSIALRM 244, CSIPROG 59, CSIPROG2 61, CSIPROG3 63, CSIPROG4 65, CSIPROG5 61, CSIPROG6 59, CSIPROG7 65, CSIPROG8 59, CSIPROG9 67, CSTH 188, D 226, DELDV 244, DELVCSI 244, DELVEET1 197, DELVEET2 244, DELVLVC 224, DELVSAB 236, DELVSIN 236, DIFFALT 197, DISPLAYS 59, DV 241, DVPREV 244, EBANK 80, ECC 188, F 238, FFTAG12 57, FINALFLG 105, GAMMA 232, GAMPREV 244, H 177, HAFPA1 244, IT 185, ITSWICH 121, LOC 145, LOOPCT 244, LV 85, MPAC 145, NN 244, NOMTPI 181, NORMEX 165, P 188, POSTCDH 244, POSTCSI 244, R1A 188, RACT1 197, RACT2 197, RACT3 234, RDOTV 244, RPASS1 244, RPASS2 197, RPASS3 234, RTIG 236, RTRN 181, RVEC 188,

RVSW 123, S32.1F1 135, S32.1F2 135, S32.1F3A 135, S32.1F3B 135, SLOPE 213, SNTH 188, SQ 156, SR 80, STATE 138, SUBEXIT 181, T1TOT2 197, T2TOT3 244, TC 169, TCDH 197, TCSI 197, TEMP 191, TIG 224, TRKMKCNT 157, TTOGO 236, TTPI 236, TTPIO 197, UNITV 226, UNVEC 244, UP1 197, UPDATFLG 99, V 229, VACT1 244, VACT2 197, VACT3 234, VACT4 244, VERBNOUN 181, VG 234, VN 159, VPASS1 244, VPASS2 197, VPASS3 234, VTIG 236, VVEC 188, X1 85, X2 85, and XDELVFLG 103.

3.5.6 p40-p47 code

1093 ⟨*p40-p47 code* 1093⟩≡ (857a 2765)
⟨*Page CM0684* 1094⟩

1094 ⟨*Page CM0684* 1094⟩≡ (1093)

```
# Page 684
# PROGRAM DESCRIPTION ** P40CSM **

                EBANK=  DAPDATR1
                BANK    31
                SETLOC  P40S
                BANK

                COUNT   24/P40

P40CSM          TC      DOWNFLAG
                ADRES   ENG2FLAG

                TC      INTPRET
                SLOAD   BOFF
                        ECSTEER         # IS THIS AN EXTERNAL DELTA V BURN
                        XDELVFLG
                        P40S/C          # NO    CSTEER = ECSTEER
                DLOAD                   # YES   CSTEER = ZERO
                        HI6ZEROS
P40S/C          STODL   CSTEER
                        FENG            # SET UP THRUST FOR P40 20,000 LBS
P40S/F          STODL   F               # P41 ENTERS HERE
                        TIG             # ORIGINAL TIG MAY BE SLIPPED BY P40S/SV
                STORE   NOMTIG          # SET ORIGINAL TIME OF IGNITION FOR S40.9

                EXIT
                TC      BANKCALL
                CADR    R02BOTH         # IMU STATUS CHECK

P40PVA          TC      INTPRET
                CALL
                        S40.1           # COMPUTE VGTIG,UT
                CALL
                        S40.2,3         # COMPUTE PREFERRED ATTITUDE
                SET     EXIT
                        PFRATFLG
P40SXTY         TCR     SETMINDB -1     # NARROW DEADBAND FOR MANEUVER (EBANK6)
                RELINT
                TC      BANKCALL
                CADR    R60CSM          # ATTITUDE MANEUVER
                CS      ONE             # FOR UPDATEVG
                TS      NBRCYCLS
                TC      UPFLAG
                ADRES   TIMRFLAG        # ALLOW CLOCKTASK
```

```
                TC      P41/P40
                TC      P41/DSP         # P41

P40TTOG         CAF     V06N40          # INITIALIZE FOR CLOCKTASK WHICH IS CALLED
# Page 685
                TS      NVWORD1         # BELOW

                TC      INTPRET
                VLOAD   ABVAL           # FOR R2
                        VGTIG
                STODL   VGDISP
                        HI6ZEROS
                STORE   DVTOTAL
                EXIT

                EXTEND
                DCA     STEERADS        # SET FOR UPDATEVG AND TEST FOR STEERING
                DXCH    AVEGEXIT        # AFTER AVERAGE G

P40GMB          CAF     P40CKLS2        # (4.1 PROTECTION)
                TC      BANKCALL
                CADR    GOPERF1
                TCF     POST41          # V34
                TCF     TST,TRIM        # V33
TRIMONLY        CS      BIT1            # SET MRKRTEMP FOR GIMBAL TRIM (-1)
        +1      TS      MRKRTMP         # ENTRY FROM TST,TRIM

                CAF     ZERO            # SET CNTR      +0 FOR RESTART LOGIC IN S40.6
                TS      CNTR            #       +0 SAYS NORMAL ENTRY
                                        #       +1 (PRE40.6) SAYS RESTART ENTRY

                CAF     ONE
                TC      WAITLIST
                EBANK=  DAPDATR1
                2CADR   S40.6

                CCS     MRKRTMP         # TEST TO FIND TIME TO WAIT FOR GIMBAL TEST
                CAF     18SEC           # PLUS, DELAY FOR 18 SECONDS
                TCF     +2              # HOLE
                CAF     5SEC            # DELAY FOR TRIM ONLY TASK
                TC      BANKCALL
                CADR    DELAYJOB
                TC      2PHSCHNG
                OCT     40026           # 6.2 = PRE40.6(-0CS), CLOKTASK(100CS)
                OCT     00234           # 4.23 = P40S/SV (PRIO12)
```

```
P40S/RS         CAF     ONE
                TC      WAITLIST        # P41/SDP
                EBANK=  TIG
                2CADR   CLOKTASK

                RELINT

P40S/SV         TCR     E7SETTER        # JOB, 4.23 PRETECTS, PREO12
                EBANK=  TIG
# Page 686
                TC      INTPRET
                DLOAD   DSU
                        TIG
                        SEC29.96
                STORE   TDEC1

                CALRB                   # RETURN IN BASIC
                        MIDTOAV1
                TCF     +2
                TC      P40SNEWM        # INTEGRATION TIME GREATER THAN ALLOWED
P40SET          EXTEND
                DCA     MPAC            # DELTA TIME TO PREREAD (INT.INIT.)
                DXCH    P40TMP
                EXTEND
                DCS     5SECDP          # FOR TIGBLNK
                DAS     P40TMP
                EXTEND
                DCA     P40TMP
                TC      LONGCALL
                EBANK=  TIG
                2CADR   TIGBLNK

                TC      PHASCHNG
                OCT     20214           # 4.21 = TIGBLNK (P40TMP CS)

                TCF     ENDOFJOB
P40BLNKR        TC      BANKCALL
                CADR    CLEANDSP        # REMOVE RESIDUE
                TCF     ENDOFJOB
                EBANK=  TIG
P40SNEWM        EXTEND
                DCA     PIPTIME1
                DXCH    TIG             # SET NEW TIG FOR 06 40
                EXTEND
                DCA     SEC29.96
                DAS     TIG
```

```
                TCF     P40SET          # FOR LONGCALL OF TIG-30 (OR -35)

                EBANK=  DAPDATR1
POSTBURN        CAF     V16N40
                TC      BANKCALL
                CADR    REFLASH
                TCF     POST41          # V34 GO FINISH
                TCF     P40RCS          # PROCEED
                TCF     POSTBURN        # RECYCLE
P40RCS          EXTEND                  # V99N40 ENTERS HERE ON A P40 BYPASS SPS
                DCA     ACADN85
                DXCH    AVEGEXIT
                CAF     2SECS           # WAIT FOR CALCN85 VIA AVEGEXIT
                TC      BANKCALL
# Page 687
                CADR    DELAYJOB

P40MINDB        TCR     SETMINDB -1
                RELINT
TIGNOW          TC      PHASCHNG
                OCT     05024           # TYPE C GROUP 4 BELOW FOR NOUN 85
                OCT     20000           # PRIO 20
                CAF     V16N85B
                TC      BANKCALL
                CADR    REFLASH
                TCF     POST41          # FINISH P40/P41
                TCF     POST41          # V03 PROCEED WITH REST OF THE CLEAN-UP
                TCF     TIGNOW          # V32 NOT GSOP RESPONSE BUT REDISPLAY N85

POST41          EXTEND
                DCA     SERVCADR
                DXCH    AVEGEXIT
                TCF     GOTOP00H

MINDB           DEC     46
MAXDB           DEC     455
                EBANK=  DAPDATR1
        -1      INHINT
SETMINDB        CA      CDUX            # ROUTINE FOR SETTING
                TS      THETADX         # THE MINIMUM DEADBAND
                EXTEND                  # IN AUTOPILOT
                DCA     CDUY
                DXCH    THETADY
                CA      MINDB           # SHOULD BE CALLED UNDER
                TS      ADB             # INTERRUPT INHIBITED
                CS      BIT4            # EBANK = E6
```

```
                MASK    DAPDATR1
                TS      DAPDATR1
                TC      Q

                EBANK=  DAPDATR1
        -1      INHINT
SETMAXDB        CA      MAXDB           # ROUTINE FOR SETTING
                TS      ADB             # THE MAXIMUM DEADBAND IN AUTOPILOT
                CS      DAPDATR1
                MASK    BIT4            # SHOULD BE CALLED UNDER
                ADS     DAPDATR1        # INTERRUPT INHIBITED
                TC      Q               # EBANK = E6

# Page 688
# PROGRAM DESCRIPTION ** P41CSM **

                SETLOC  P40S2
                BANK

                EBANK=  DAPDATR1
                COUNT   24/P41

P41CSM          TC      UPFLAG
                ADRES   ENG2FLAG        # SET FOR RCS

                TC      INTPRET
                DLOAD
                        HI6ZEROS        # FOR P41 CSTEER =0
                STORE   CSTEER

                DLOAD   BON
                        FRCS2           # 2JET THRUST FOR S40.1
                        NJETSFLG
                        P40S/F          # NJETS = 1 2-JET
                DAD     GOTO            # NJETS = 0 4-JET
                        FRCS2
                        P40S/F

                SETLOC  P40S
                BANK

P41/P40         CS      MODREG
                MASK    ONE             # P41EXITS AT CALL LOC +1
                EXTEND
                BZF     +2              # P41
                INCR    Q               # P40 EXITS AT CALL LOC +2
```

```
                TC      Q

TTG/0           CAF     PRIO20          # TASK (4.4 PROTECTS IN P41)
                TC      NOVAC
                EBANK=  DAPDATR1
                2CADR   TIGNOW

P40CLK          TC      DOWNFLAG
                ADRES   TIMRFLAG

                TCF     TASKOVER

P41/DSP         CAF     V06N85B         # SET UP FOR NONFLASH V 06 N85 BY CLOCKJOB
                TS      NVWORD1

                TC      INTPRET
# Page 689
                CALL                    # COMPUTE
                        P40CNV85        #       VGTIG IN CTRL COORDS
                EXIT
                EXTEND                  # DO CONTROL COORD CALCULATION AFTER AVEG
                DCA     ACADN85
                DXCH    AVEGEXIT
                TC      2PHSCHNG
                OCT     40036           # 6.3=CLOKTASK(100CS)
                OCT     234             # 4.23=P40S/SV(PRIO12)

                TCF     P40S/RS
P41REDSP        CAF     V16N85B         # ENTER FROM P41 SIDE OF TIGAVEG
                TS      NVWORD1         # REDISPLAY NONFLASHING
                CAF     SEC29.96 +1
                TC      WAITLIST
                EBANK=  DAPDATR1
                2CADR   TTG/0

                CS      BIT3
                TCF     TTGPHS
P40CNV85        STQ     SETPD
                        QTEMP1
                        0
                VLOAD   PUSH
                        VGPREV          # EQUALS VGTIG (TARGETTING INPUT)
                CALL
                        S41.1
                STCALL  VGBODY
                        QTEMP1
```

```
                EBANK=  DAPDATR1
CALCN85         TC      INTPRET
                CALL
                        UPDATEVG        # NEW VG, S40.8 (+MAYBE S40.9)
                CALL
                        P40CNV85        # COMPUTE VGBODY
                EXIT
                TC      SERVXT
FENG            2DEC    9.1188544 B-7   # SPS THRUST (20500LBS), SC.AT B+7 NEWT/E4

FRCS2           2DEC    .087437837 B-7  # RCS ULLAGE (199.6COS10 LBS), SC.AT

                                        #       B+7 NEWTONS/E+4
SEC24.96        DEC     2496
SEC29.96        2DEC    2996

18SEC           DEC     1800
P40CKLS2        OCT     204
40CST5          OCT     37730           # 40 CS FOR THE T5 CLOCK
OCT12           =       TEN
# Page 690
V1683           VN      1683
V06N85B         VN      0685
V16N85B         VN      1685
V06N40          VN      0640
V16N40          VN      1640
OCT27/24        OCT     27
OCT53           OCT     53
OCT35           OCT     35
                EBANK=  DAPDATR1
T5IDL24         2CADR   T5IDLOC

3MDOT           DEC     86.6175796 B-16 # 3SEC MASS LOSS (63.8 LBS/SEC), SC.AT
                                        # B+16 KB/SEC (NOT, EMDOT IS PAD-LOADED,
                                        # BUT 3MDOT IS NOT A CRITICAL QUANTITY, SO
                                        # IT CAN REMAIN IN FIXED MEMORY)
TST,TRIM        CAF     BIT1            # SET UP FOR GIMB DRIVE TEST AND TRIM (+1)
                TCF     TRIMONLY +1
TIGBLNK         CAF     5SEC            # CALL TIGAVEG IN FIVE SEC AT TIG-30
                TC      WAITLIST
                EBANK=  TIG
                2CADR   TIGAVEG

                CAF     ZERO            # DISABLE HERE, NOT IN P40BLNKR
                TS      NVWORD1
```

```
                CAF     PRIO14
                TC      NOVAC
                EBANK=  TIG
                2CADR   P40BLNKR        # DON'T PROTECT -- RESTARTS BLANK DSKY

                CS      OCT37           # 4.37 = TIGAVEG (500CS)
P40TSK          TC      NEWPHASE
                OCT     4
                TC      TASKOVER

                EBANK=  TIG
ACADN83         2CADR   CALCN83

                EBANK=  TIG
SERVCADR        2CADR   SERVEXIT

                EBANK=  DAPDATR1
ACADN85         2CADR   CALCN85

# Page 691
# PROGRAM DESCRIPTION ** P47CSM **

                COUNT   24/P47

                EBANK=  TIG
P47CSM          TC      BANKCALL        # IMU STATUS CHECK
                CADR    R02BOTH
                TC      INTPRET
                CALRB
                        MIDTOAV2
                CA      MPAC +1         # DELTA TIME TO RPEREAD (LESS THAN 100
                TS      P40TMP          #       CS, WITH A TPAGREE, INT.INIT.)
                TC      WAITLIST
                EBANK=  TIG
                2CADR   TIGON           # TIGON IS REQUIRED TO MATHCHTAT AND AVEG

                TC      PHASCHNG
                OCT     40574           # A, 4.57 = TIGON (P40TMP CS)
                TCF     ENDOFJOB

                EBANK=  P40TMP
TIGON           EXTEND
                DCA     ACADN83
                DXCH    AVEGEXIT
                CAF     PRIO30          # FORCE ZEROING OF N83 BEFORE SERVICER
```

```
                TC      NOVAC
                EBANK=  TIG
                2CADR   P47BODY

                CS      BIT2            # 4.2 = PRECHECK (-0CS), P47BODY (PRIO30)
                TCF     TTGPHS

                EBANK=  TIG
CALCN83         TC      INTPRET
                SETPD                   # SET UP PUSHLIST FOR S41.1
                        0
                VLOAD   VAD
                        DELVCTL
                        DELVREF
                STORE   DV47TEMP        # FOR COPYCYCLE BELOW
                PUSH    CALL
                        S41.1
                STCALL  DELVIMU
                        S11.1           # CALC. VI, H, HDOT FOR NOUN 62
                EXIT
                TC      PHASCHNG
                OCT     10035
# Page 692
                CAF     FIVE
                TC      GENTRAN
                ADRES   DV47TEMP
                ADRES   DELVCTL

                TC      SERVXT
P47BODY         TC      INTPRET
                VLOAD
                        HI6ZEROS
                STORE   DELVIMU         # CLEAR DISPLAY AND ACCUMULATOR STORAGE
                STORE   DELVCTL         # UPON INITIATION OR ENTER RESPONSE
                EXIT
P47BOD          CAF     PRIO15          # LOWER PRIO THAN CALCN83 (20)
                TC      PRIOCHNG        #       TO PREVENT INTERRUPTION OF CALCN83
                TC      PHASCHNG
                OCT     05024           # TYPE C GROUP 4 BELOW FOR NOUN 83
                OCT     15000           # PRIO 15
P47/DSP         CAF     V1683
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H
                TC      GOTOP00H
                TCF     P47BODY         # RECYCLE -- CLEAR ACCUMULATED VELOCITY
```

```
# Page 693
# ROUTINE ** TIG-30 ** DESCRIPTION

                EBANK=  TIG
                COUNT   24/P40

TIGAVEG         TC      P41/P40         # TASK (4.37 PROTECTS)
                TCF     P41REDSP

                CAF     V06N40          # UNBLANK DISPLAY
                TS      NVWORD1

                CAF     SEC24.96
                TC      WAITLIST
                EBANK=  TIG
                2CADR   TIG-5

                CS      SIX             # 4.6 = TIG-5 (2496CS), PRECHECK (-0CS)
TTGPHS          TC      NEWPHASE        # ENTRY FROM P41REDSP (P41) WITH A=-4, OR
                OCT     4               #       FROM TIGON    (P47) WITH A=-1

PRECHECK        CCS     PHASE5          # HAS SERVICER BEEN RESTARTED
                TCF     TASKOVER        # YES, DON'T START ANOTHER ONE
                TC      POSTJUMP
                CADR    PREREAD

# Page 694
# ROUTINE ** TIG-5 ** DESCRIPTION

                EBANK=  TIG
TIG-5           CAF     5SEC
                TC      WAITLIST
                EBANK=  DAPDATR1
                2CADR   TIG-0

                CS      BIT9            # WILL CAUSE V99 FLASH
                TS      NVWORD1

                TC      2PHSCHNG
                OCT     40074           # A, 4.7 = TIG-0 (500CS)
                OCT     00033           # A, 3.3 = S40.13 (PRIO20)

                CAF     PRIO20
                TC      FINDVAC
                EBANK=  TGO
```

```
                2CADR   S40.13

                TCF     TASKOVER

# Page 695
# ROUTINES ** TIG-0 ** AND ** IGNITION ** DESCRIPTION

                EBANK=  DAPDATR1        # TASK, 4.7 PHASE, OR 4.77 (-0CS) IN R40
TIG-0           CS      FLAGWRD7        # SET IGN FLAG
                MASK    BIT13
                ADS     FLAGWRD7

                CAE     FLAGWRD7        # CHECK ASTN FLAG FOR V99 RESPONSE
                MASK    BIT12
                EXTEND
                BZF     TASKOVER        # WAIT FOR V99P

                CAF     V06N40          # CLEAR THE V99 (IN CASE OF A RESTART
                TS      NVWORD1         #       DURING THE V99 SEQUENCE)

                TC      PHASCHNG        # V99P HAS COME ALREADY, DO IGNITION NOW
                OCT     00614           # A, 4.61 = IGNITION (-0CS) TBASE OLD

IGNITION        CAE     CDUX            # SAVE FOR ROLL DAP REFERENCE OGAD
                TS      OGAD            #       V99PJOB (CLOCKJOB) SETS UP IGNITION
                EXTEND                  #       TASK (4.61 PROTECTION)
                DCA     TIME2           #       FOR RESTARTS
                DXCH    TEVENT
                CS      FLAGWRD5        # SET ENGONFLG
                MASK    BIT7
                ADS     FLAGWRD5
SPSON           CAF     BIT13           # TURN ON SPS ENGINE
                EXTEND
                WOR     DSALMOUT

IMPULCHK        CAF     BIT9            # CHECK FOR IMPULSIVE BURN
                MASK    FLAGWRD2
                CCS     A
                TCF     IMPLBURN        # IMPULSIVE
                CS      FLAGWRD6        # NON-IMPULSIVE, SET STRULLSW FOR STEERULL
                MASK    BIT13
                ADS     FLAGWRD6

PREPTVC         CS      OCT60000        # RESET T5 BITS
                MASK    FLAGWRD6
                TS      FLAGWRD6
```

```
                EXTEND                  # KILL RCS
                DCA     T5IDL24
                DXCH    T5LOC

                CS      THREE           # 4.3 = DOTVCON (40CS)
                TC      NEWPHASE
                OCT     4

# Page 696
                TC      FIXDELAY
                DEC     40              # 0.4 SECOND DELAY FOR THRUST BUILDUP

DOTVCON         CS      BIT1            # SET TVCPHASE = TVCDAPON CALL (FRESHDAP)
                TS      TVCPHASE
                CAF     ZERO            # SET TVCEXECUTIVE PHASE
                TS      TVCEXPHS
                CS      OCT60000        # SET T5 BITS TO INDICATE TVC TAKEOVER ....
                MASK    FLAGWRD6        #       BITS 15,14 = 10
                AD      BIT15
                TS      FLAGWRD6

                CAF     THREE           # 6.3 = CLOKTASK (100CS), DROPPING PRE40.6
                TS      L               #       WHICH IS HANDLED NOW BY REDOTVC
                COM
                DXCH    -PHASE6

                EXTEND                  # STORE RCS ATTITUDE ERRORS FOR USE IN
                DCS     ERRORY          # INITIALIZING TVC ATTITUDE ERRORS
                DXCH    ERRBTMP

                CS      FIVE            # 4.5 = DOSTRULL (160 CS)
                TC      NEWPHASE
                OCT     4

                CAF     POSMAX          # SET TIME5 FOR STARTING RIGHT AWAY
                TS      TIME5
                EXTEND
                DCA     TVCON2C         # (TVCDAPON)
                DXCH    T5LOC           # (KILLS RCS DAP)

                TC      FIXDELAY        # 0.4 + 1.6 = 2.0 SEC FOR ULLAGE-OFF AND
                DEC     160             #       STEERING (IF NON-IMPULSIVE)

DOSTRULL        CAF     BIT13           # CHECK STRULLSW FOR IMPULSIVE BURN
                MASK    FLAGWRD6
```

```
                CCS     A
                TCR     STEERULL        # NON-IMPULSIVE, STEERING AND ULLAGE OFF
                TCR     ULAGEOFF        # ULLAGE OFF (ONLY, OR AGAIN)

                EXTEND
                DCA     NEG0            # KILL GROUP 4 (DP NEG0 = -0,+0)
                DXCH    -PHASE4

ENDIGN          TCF     TASKOVER

STEERULL        CS      FLAGWRD2        # SET STEERSW
                MASK    BIT11
                ADS     FLAGWRD2

# Page 697

ULAGEOFF        CAF     ZERO
                EXTEND
                WRITE   CHAN5           # ZERO CHANNEL 5
                TC      Q

IMPLBURN        CS      BIT13           # RESET STRULLSW (COULD BE AN IMPULSIVE
                MASK    FLAGWRD6        #       ENGINE FAIL)
                TS      FLAGWRD6

                TCR     E7SETTER

                EBANK=  TIG
                EXTEND                  # PREPARE FOR R1 OF V06N40 (CLOCKTASK)
                DCA     TGO
                DXCH    TIG
                EXTEND
                DCA     TIME2
                DAS     TIG

                TC      2PHSCHNG
                OCT     40153           # A, 3.15 = ENGINOFF (TGO+1) .... NOT GROUP
                OCT     07014           # C, DELTAT NEXT, TASK BELOW, IN
                DEC     -0              # -0 CS
                EBANK=  DAPDATR1
                2CADR   IMPLCONT

                CAE     TGO +1          # (TPAGREE IN S40.13, LESS THAN 600CS)
                TC      WAITLIST
                EBANK=  TGO
                2CADR   ENGINOFF
```

```
IMPLCONT        CS      BIT9            # RESET IMPULSW, ENGINOFF IS NOW SET UP
                MASK    FLAGWRD2
                TS      FLAGWRD2

                TCR     E6SETTER
                EBANK=  DAPDATR1

                CAF     ZERO            # SET UP V97VCNTR IN CASE ENGINOFF (MASS-=
                TS      V97VCNTR        #       BACK) ARRIVES BEFORE TVCDAPON

                TCF     PREPTVC

                EBANK=  TGO             # E7 FORCED BY 3.15SPOT VARIABLE DELTA-T
ENGINOFF        TCR     E6SETTER        # TASK, 3.15 PHASE (TGO+1 CS)   GET E6
                EBANK=  DAPDATR1
                CAE     CSMMASS
                TS      MASSTMP         # COPYCYCLE FOR MASSBACK
# Page 698
                TC      2PHSCHNG
                OCT     00003           # KILL GROUP 3 PROTECTION OF ENGINOFF, DO
                OCT     40634           # A, 4.63 = DOSPSOFF (-0CS)
DOSPSOFF        TCR     SPSOFF          # SHUTDOWN SPS, MASS UPDATES, ETC.
                CS      OCT27/24        # (OCTAL 27)
                TC      NEWPHASE
                OCT     4               # 4.27 = DOTVCRCS (250 CS)

                TC      FIXDELAY        # 2.5 SECOND DELAY FOR SPS TAILOFF
                DEC     250

DOTVCRCS        TCR     SETMAXDB        # WIDE DEADBAND FOR CUTOFF TRANSIENT

                TC      IBNKCALL        # SET UP RCS DAP (KILLS TVCDAPS, SETS T5
                CADR    RCSDAPON        #       BITS, WAITS 0.6SEC FOR TVCEXEC DIE)

                TC      IBNKCALL        # UPDATE WEIGHT/G AND MASS-PROPERTIES FOR
                CADR    MASSPROP        #       RCS DAP STARTUP IN 0.6 SECONDS

                TCR     TVCZAP          # WIPE OUT TVC, TURN OFF CLOKTASK

                TC      PHASCHNG
                OCT     00354           # A, 4.35 = POSTBURN (NOVAC, PRIO12)
                CAF     PRIO12          # SET UP POSTBURN V16N40 JOB
                TC      NOVAC
                EBANK=  DAPDATR1        # (SET MAXDB IN POST41)
                2CADR   POSTBURN
```

```
                TCF     TASKOVER

                EBANK=  DAPDATR1
SPSOFF          EXTEND                  # ESTABLISH SPSOFF TEVENT
                DCA     TIME2
                DXCH    TEVENT
                CS      BIT7            # RESET ENGONFLG
                MASK    FLAGWRD5
                TS      FLAGWRD5        # (RESTARTS WILL SHUT DOWN SPS NOW)
                CS      BIT13           # SHUT DOWN SPS ENGINE
                EXTEND
                WAND    DSALMOUT

                CAF     BIT14           # ISSUE SIV CUTOFF COMMAND
                EXTEND                  # FOR POSSIBLE BACK-UP USE
                WOR     CHAN12
MASSBACK        CAE     V97VCNTR        # RESTORE PART OF PRE-DECREMENTED MASS
                                        #       V97CNTR = VCNTR UNLESS V97 IS
                                        #       ACTIVE.  ONLY V97CNTR IS THEN RIGHT.
                EXTEND                  # VCNTR COUNTS 1/2-SECONDS IN TVC EXEC
                MP      EMDOT           #       MDOT, SC.AT B+3 KG/CS
                LXCH    A
# Page 699
                EXTEND
                MP      1SEC            # DEC 100
                AD      MASSTMP         # CORRECTION IS ACCURATE TO 5 CS OF FLOW
                TS      CSMMASS         #       (1.44 KG OR 0.4 BITS)

                CA      TVCPHASE        # CHECK IF OK FOR TRIM UPDATE
                AD      ONE             #       THESE CHECKS ARE ONLY NEEDED
                EXTEND                  #       FOR A LESS THAN 0.4 SEC BURN
                BZF     BTRIMR          # NO.  INITIALIZATION NOT COMPLETE
                CS      FLAGWRD6        # YES, CHECK IF TVC
                MASK    OCT60000
                EXTEND
                BZMF    BTRIMR          # NO, NOT TVC YET
BESTTRIM        CAE     DELPBAR         # UPDATE TRIMS WITH DELFILTER VALUES
                TS      PACTOFF
                CAE     DELYBAR
                TS      YACTOFF
BTRIMR          TC      Q
                EBANK=  DAPDATR1
STEERADS        2CADR   STEERING

.6SECT5         OCT     37703
```

```
5SECDP          DEC     0               # MAKE DP 5SEC
5SEC            DEC     500
OCT02202        OCT     02202           # BITS 2, 8, 11 FOR CHANNEL 12 TVC/OPTICS
                EBANK=  DAPDATR1
TVCON2C         2CADR   TVCDAPON

        -1      INHINT
TVCZAP          CS      OCT02202        # DISABLE TVC AND OPT ERR CNTRLS, REENGAGE
                EXTEND                  #       OPTICS DAC
                WAND    CHAN12
                CS      BIT1            # ENABLE T4RUPT OPTICS MONITOR .... PERMIT
                TS      OPTIND          #       OPTICS-ZERO BUT NOT OPTICS-DRIVE
                CAF     ZERO            # CLEAR NVWORD1 IN CASE CLOCKJOB WAITING
                TS      NVWORD1
                CS      BIT11           # CLEAR TIMRFLAG TO STOP CLOKTASK
                MASK    FLAGWRD7
                TS      FLAGWRD7
                TC      Q
                EBANK=  DAPDATR1
UPDATEVG        STQ     BON
                        QTEMP1
                        XDELVFLG
                        CALL40.8

                SLOAD   BMN
                        NBRCYCLS
                        SETUP.9
# Page 700

                VLOAD   VAD
                        DELVSUM
                        DELVREF
                STORE   DELVSUMP
                EXIT
                CA      ONE
                AD      NBRCYCLS
                TS      NBRCYCLP

                TC      PHASCHNG        # TYPE B RESTART RESTART BELOW AND 5.3 REREADACCS
                OCT     10035

                CA      NBRCYCLP
                TS      NBRCYCLS
                TC      INTPRET
                VLOAD
                        DELVSUMP
```

```
                STORE   DELVSUM

CALL40.8        CALL
                        S40.8
                GOTO
                        QTEMP1

SETUP.9         BON     SLOAD
                        FIRSTFLG
                        SURELY.9
                        NBRCYCLP
                NORM    VXSC            # (NORM HANDLES ZERO PROPERLY)
                        X1
                        BDT
                VSR*    VAD
                        0 -14D,1
                        VGTEMP
                VSU
                        DELVSUM
                STORE   VGPREV
SURELY.9        EXIT
                CAF     PRIO10
                TC      FINDVAC
                EBANK=  DAPDATR1
                2CADR   S40.9

                TC      2PHSCHNG
                OCT     00051           # A, 1.5 = REDO40.9, PRIO 10
                OCT     10035
                TC      INTPRET
                VLOAD
                        RN              # ACTIVE VEHICLE RADIUS VECTOR AT T1
                STOVL   RINIT
# Page 701
                        VN              # ACTIVE VEHICLE VELOCITY VECTOR AT T1
                STODL   VINIT
                        PIPTIME
                STORE   TNIT
                BDSU
                        TPASS4
                STOVL   DELLT4
                        HI6ZEROS
                STODL   DELVSUM
                        HI6ZEROS
                STORE   NBRCYCLS
                GOTO
```

```
                        CALL40.8
                EBANK=  DAPDATR1
STEERING        TC      INTPRET
                CALL
                        UPDATEVG
                EXIT
                CAF     BIT9            # CHECK IMPULSW
                MASK    FLAGWRD2
                CCS     A
                TCF     +3              # PRE-IGNITE, REQUEST ENG-OFF, OR POST-OFF
SERVXT          TC      POSTJUMP
                CADR    SERVEXIT
                CAF     BIT13           # CHECK ENGINE-ON/-OFF
                EXTEND
                RAND    DSALMOUT
                EXTEND
                BZF     SERVXT          # ENGINE-OFF, SO PRE-IGNITE OR POST-OFF
                TCR     E7SETTER
                EBANK=  TIG
                INHINT
                EXTEND
                DCA     TIG
                DXCH    MPAC
                EXTEND
                DCS     TIME2
                DAS     MPAC
                TCR     DPAGREE
                CAE     MPAC +1         # (LESS THAN 6 (OR 4) SECONDS TO GO)
                CCS     A               # PROTECT AGAINST NEG/ZRO W.L. CALL
                TCF     +3
                TCF     +2
                CAF     ZERO
                AD      ONE
                XCH     L
                CA      ZERO
                DXCH    TGO
                CA      TGO +1
                TC      WAITLIST
# Page 702
                EBANK=  TGO
                2CADR   ENGINOFF

                TC      2PHSCHNG
                OCT     40153           # A, 3.15 = ENGINOFF (TGO+1) .... NOTE GROUP
                OCT     10035           # B, 5.3 = REREADAC, AND START BELOW
                TC      DOWNFLAG        # CLEAR IMPULSW, ENGINOFF IS NOW SET UP
```

```
                ADRES   IMPULSW         # RESTARTS OK
                TCF     SERVXT

# Page 703
# ROUTINE ** CLOKTASK ** DESCRIPTION

                EBANK=  TIG
CLOKTASK        CAF     BIT11           # IS TIMRFLAG SET
                MASK    FLAGWRD7
                CCS     A
                TCF     CLOCKON
                TC      PHASCHNG
                OCT     00006           # KILL RESTART
                TC      TASKOVER

CLOCKON         EXTEND
                DCA     TIME2
                DXCH    TTOGO
                EXTEND
                DCS     TIG
                DAS     TTOGO

SETCLOCK        CAF     1SEC
                TC      WAITLIST
                EBANK=  TIG
                2CADR   CLOKTASK

                CCS     NVWORD1
                TCF     +3
                TCF     SETTB6

                TCF     +1
                CS      V06N85B         # CHECK FOR V06N85B (P41)
                AD      NVWORD1
                EXTEND
                BZF     SETUPDYN        # V06N85, SO UPDATE N85 FOR DYNAMIC DISP

                CAF     PRIO27
                TC      NOVAC
                EBANK=  DAPDATR1
                2CADR   CLOCKJOB

SETTB6          CS      TIME1           # SET GROUP6 TIMEBASE
                TS      TBASE6
                TCF     TASKOVER
```

```
SETUPDYN        CAF     PRIO27          # SET UP A JOB TO UPDATE N85 (FOR P41=V06)
                TC      FINDVAC
                EBANK=  DAPDATR1
                2CADR   DYNDISP

                TCF     SETTB6          # CLOSE OUT CLOCKTASK
# Page 704
DYNDISP         TC      INTPRET         # UPDATE N85 FOR A DYNAMIC V06N85 IN P41.
                CALL                    #       PRIOR TO BLANKING AND AVEG (V16N85)
                        P40CNV85
                EXIT
                TCF     CKNVWRD1

# Page 705
# ROUTINE ** CLOCKJOB ** DESCRIPTION

                EBANK=  DAPDATR1
CLOCKJOB        CA      CDUX
                TS      CDUSPOTX
                CA      CDUY
                TS      CDUSPOTY
                CA      CDUZ
                TS      CDUSPOTZ
                TC      BANKCALL
                CADR    QUICTRIG
CKNVWRD1        INHINT
                CCS     NVWORD1         # DETERMINE FUNCTION, INDICATED BY NVWORD1
                TCF     NOFLASH
                TCF     ENDOFJOB
                TCF     ENGREQST        # SPS ENGINE-ON-ENABLE V99 FLASH
FAILDSP         CAF     V06N40          # SPS ENGINE-FAILED V97 FLASH
                TC      BANKCALL
                CADR    CLOCPLAY
                TCF     V97T            # TERMINATE
                TCF     V97P            # PROCEED
                TCF     V97E            # ENTER

ENGREQST        CAF     V06N40
                TC      BANKCALL
                CADR    CLOCPLAY        # LINUS MAKES IT A REDO, INHINT OK
                TCF     V99T            # TERMINATE
                TCF     V99P            # PROCEED
                TCF     V99E            # ENTER

NOFLASH         CAE     NVWORD1         # DISPLAY NVWORD1 NORMALLY
                TC      BANKCALL
```

```
                CADR    REGODSP

E7SETTER        CAF     EBANK7
                TS      EBANK
                EBANK=  TIG
                TC      Q

E6SETTER        CAF     EBANK6          # SET UP EBANK6
                TS      EBANK
                EBANK=  DAPDATR1
                TC      Q

                EBANK=  DAPDATR1
V99E            TC      2PHSCHNG
                OCT     00006           # KILL PRE40.6/CLOKTASK PROTECTION
                OCT     05024           # C, PRIORITY NEXT, JOB BELOW
# Page 706
                OCT     27000
V99EJOB         TCR     TVCZAP -1       # WIPE OUT TVC, CLOKTASK
                TCF     P40RCS          # V16N85 POST-BURN OPERATIONS

                EBANK=  DAPDATR1
V99T            TC      2PHSCHNG        # (ENTRY FROM V97T FLOW TOO)
                OCT     00006           # KILL PRE40.6/CLOKTASK PROTECTION
                OCT     05024           # C, PRIORITY NEXT, JOB BELOW
                OCT     27000
V99TJOB         TCR     TVCZAP -1       # WIPE OUT TVC, CLOKTASK
                TCF     POST41          # AVEGEXIT, SETMAXDB, GOTOP00H

V99P            INHINT
                CAE     FLAGWRD7        # CHECK ASTN FLAG FOR PRIOR V99P
                MASK    BIT12
                CCS     A
                TCF     V99P/TIG        # YES, THIS MUST BE A RESTART ENTRY

ASTNV99P        CAF     BIT12           # SET ASTN FLAG
                ADS     FLAGWRD7
                CAE     FLAGWRD7        # CHECK IGN FLAG FOR TIG-0 ARRIVAL
                MASK    BIT13
                EXTEND
                BZF     V99P/TIG        # NO, CLEAR THE V99 AND WAIT FOR TIG-0

ENDV99PI        CAF     BIT1            # TIG-0 HAS COME ALREADY
                TC      WAITLIST        # SET UP IGNITION HERE
                EBANK=  DAPDATR1
                2CADR   IGNITION
```

```
V99P/TIG        CAF     V06N40          # CLEAR THE V99 FLASH AND WAIT FOR TIG-0
                TS      NVWORD1
ENDV99P         TCF     ENDOFJOB

                EBANK=  CSMMASS
V97T            TC      2PHSCHNG
                OCT     00006           # KILL GROUP 6 (CLOKTASK)
                OCT     40674           # A, 4.67 = V97TTASK (-0 CS), TBASE NOW
                CAF     BIT1
                TC      TWIDDLE
                ADRES   V97TTASK        # KEEP EBANK6 FOR MASSES, SPSOFF, ETC.
                TCF     ENDOFJOB

                EBANK=  CSMMASS
V97TTASK        CAF     ZERO            # DISABLE CLOCKJOB
                TS      NVWORD1
                CAF     3MDOT           # 3 SECONDS OF MDOT (2-4 SEC ENGFAIL
                AD      CSMMASS         #       DETECTION) NOT LOST BECAUSE THRUST
                TS      MASSTMP         #       FAILED.  COPYCYCLE FOR MASSBACK
# Page 707
                TC      PHASCHNG
                OCT     05014           # C, DELTAT NEXT, TASK BELOW, IN
                DEC     -0              # -0 CS

                TCR     SPSOFF          # SHUTDOWN SPS ENGINE, MASS UPDATE, ETC.
                TC      PHASCHNG
                OCT     00714           # A, 4.71 = V97TRCS (250 CS), TBASE OLD
                TC      FIXDELAY        # DELAY 2.5 SECONDS FOR (POSSIBLE) TAIL-
                DEC     250             #       OFF (FALSE THRUST-LOSS)

                EBANK=  DAPDATR1
V97TRCS         TC      IBNKCALL        # RCS DAP IN 0.6SEC, SETTING T5 BITS TO
                CADR    RCSDAPON        #       KILL TVCEXEC/TVCROLLDAP STARTS
                CAF     PRIO27          # SET UP V99T FOR TVCZAP AND POST41 (SET-
                TC      NOVAC           #       MAXDB AND GOTOP00H)
                EBANK=  DAPDATR1        # EBANK6 FOR SETMAXDB IN POST41
                2CADR   V99T

ENDV97T         TCF     TASKOVER

                EBANK=  V97VCNTR
V97P            TC      PHASCHNG
                OCT     40734           # A, 4.73 = V97PTASK (-0 CS), TBASE NOW
                CAF     BIT1
                TC      TWIDDLE
```

```
                ADRES   V97PTASK
                TCF     ENDOFJOB

                EBANK=  V97VCNTR
V97PTASK        CAE     V97VCNTR        # GET MASS UPDATES (TVCEXEC) GOING AGAIN
                TS      VCNTR           #       (ERRORS IF FLASE THRUST-LOSS AND/OR
                                        #       POOR SYNC OF MANUAL ENGINE-ON AND
                                        #       THE VERB 97 PROCEED)
                CAF     V06N40          # REDISPLAY V06N40
                TS      NVWORD1
                TC      UPFLAG          # SET IDLEFAIL TO ALLOW R41-BYPASS, IN
                ADRES   IDLEFAIL        #       CASE OF UNFAVORABLE S40.8 SYNCH
                TC      UPFLAG          # SET STEERSW TO RE-ENABLE STEERING
                ADRES   STEERSW
                TC      PHASCHNG
                OCT     00134           # A, 4.13 = R40ENABL (200 CS), TBASE OLD
                TC      FIXDELAY        # WAIT 2 SECONDS, THEN
                DEC     200

                EBANK=  WHOCARES
R40ENABL        TC      DOWNFLAG        # RE-ENABLE R40 BY CLEARING IDLEFAIL
                ADRES   IDLEFAIL
                TC      PHASCHNG
                OCT     00004           # KILL GROUP 4
# Page 708
ENDV97P         TCF     TASKOVER

                EBANK=  WHOCARES
V97E            TC      PHASCHNG
                OCT     40534           # A, 4.53 = V97ETASK (-0 CS), TBASE NOW
                CAF     BIT1
                TC      WAITLIST
                EBANK=  TIG
                2CADR   V97ETASK

                TCF     ENDOFJOB

                EBANK=  TIG
V97ETASK        CS      OCT24           # FORCE R1 OF V06N40 TO READ  59X59
                TS      TIG
                CAF     V06N40          # REDISPLAY V06N40
                TS      NVWORD1
                TCR     E6SETTER        # RETURN TO EBANK6 FOR REST OF V97ETASK
                EBANK=  CSMMASS
                CAF     3MDOT           # 3 SECONDS OF MDOT (2-4 SEC ENGFAIL
                AD      CSMMASS         #       DETECTION) NOT LOST BECAUSE THRUST
```

```
                TS      MASSTMP         #       FAILED....COPYCYCLE FOR MASSBACK
                TC      PHASCHNG
                OCT     00754           # A, 4.75 = SPSOFF97 (-0 CS), TBASE OLD
SPSOFF97        TCR     SPSOFF
                TC      PHASCHNG
                OCT     00114           # A, 4.11 = V97E40.6 (250 CS), TBASE OLD
                TC      FIXDELAY        # DELAY 2.5 SECONDS FOR (POSSIBLE) TAIL-
                DEC     250             #       OFF (FALSE THRUST-LOSS)

                EBANK=  DAPDATR1
V97E40.6        CAF     BIT1
                TC      WAITLIST
                EBANK=  CNTR
                2CADR   PRE40.6         # USE S40.6 RESTART ENTRY TO TRIM ENGINE

                TC      IBNKCALL        # RCS DAP IN 0.6SEC, SETTING T5 BITS TO
                CADR    RCSDAPON        #       KILL TVCEXEC/TVCROLLDAP STARTS.
                                        #       LEAVE NARROW DEADBAND FOR REIGNITE.

                TC      2PHSCHNG
                OCT     00026           # A, 6.2 = PRE40.6 (-0 CS), CLOKTASK (1 SEC)
                OCT     05014           # C, DELTAT NEXT, TASK BELOW, IN
                DEC     -0              # -0 CS.

QUICKIGN        CS      PRIO14          # CLEAR ASTNFLAG AND SET IGNFLAG FOR
                MASK    FLAGWRD7        #       IMMEDIATE V99 RESPONSE.
                AD      BIT13
                TS      FLAGWRD7
                TC      FIXDELAY        # DELAY TO ALLOW TIME FOR PRE40.6
# Page 709
                DEC     30

V99FLASH        CS      BIT9            # CAUSE V99 TO FLASH
                TS      NVWORD1
                TC      2PHSCHNG
                OCT     40774           # A, 4.77 = TIG-0 (-0 CS) TBASE FOR PREPTVC
                OCT     00033           # A, 3.3 = S40.13 (PRIO 20)
                CAF     PRIO20          # SET UP TIMEBURN
                TC      FINDVAC
                EBANK=  TGO
                2CADR   S40.13

ENDV97E         TCF     TASKOVER        # WAIT FOR CLOCKJOB (IMMEDIATE) REACTION
                                        #       TO FLASHING V99 RESPONSE.

# MOD NO2                               LOG SECTION P40-P47
```

```
# MOD BY ZELDIN
#
# FUNCTIONAL DESCRIPTION
#       COMPUTE INITIAL THRUST DIRECTION(UT) AND INITIAL VALUE OF VG
#       VECTOR(VGTIG).
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             S40.1
#
# NORMAL EXIT MODE
#       AT L+2 OF CALLING SEQUENCE (GOTO L+2) NORMAL RETURN OR
#       ERROR RETURN IF NOSOFLAG =1
#
# SUBROUTINES CALLED
#       CSMPREC
#       INITVEL
#       CALCGRAV
#       MIDGIM
#
# ALARM OR ABORT EXIT MODES
#       L+2 OF CALLING SEQUENCE, UNSOLVABLE CONIC IF NOSOFLAG=1
#
# ERASABLE INITIALIZATION REQUIRED
#       WEIGHT/G        ANTICIPATED VEHICLE MASS        SP B16 KGM
#       XDELVFLG        1=DELTA-V MANEUVER, 0=AIMPT STEER
#   IF DELTA-V MANEUVER:
#       DELVSIN         SPECIFIED DELTA-V REQUIRED IN
#                       INERTIAL COORDS. OF ACTIVE VEHICLE
#                       AT TIME OF IGNITION             VECTOR B7 M/CS
#       DELVSAB         MAG. OF DELVSIN                 DP B7 M/CS
#       RTIG            POSITION AT TIME OF IGNITION    VECTOR B29 M
#       VTIG            VELOCITY AT TIME OF IGNITION    VECTOR B7 M/CS.
#       CSTEER = 0                                      DP
#   IF AIMPOINT STEERING:
#   IF AIMPT STEER
#       TIG             TIME OF IGNITION                DP B28 CS
#       RTARG           POSITION TARGET TIME            VECTOR B29 M
#       CSTEER = ECSTEER (GR 0)                         DP B1
# Page 710
#       TPASS4 -- TIME OF ARRIVAL AT AIMPOINT
#
# OUTPUT
#       UT              1/2 UNIT VECTOR ALIGNED WITH THRUST DIRETION IN REF COOR
#       VGTIG           INITIAL VALUE OF VELOCITY
#                       TO BE GAINED (INERT. COORD.)            VECTOR B7 M/CS
```

```
#       DELVLVC         VGTIG IN LOC. VERT. COORDS.             B7 M/CS
#       F               NOMINAL THRUST FOR ENG USED FOR S40.13  DP B7 M-NEWT
#       BDT             V REQUIRED AT TIG -V REQUIRED AT (TIG-2SEC)
#       -GDT            FOR S40.13                              VECT B7 M/CS
#       RTIG            CALC IN S40.1B (AIMPT) FOR S40.2,3      VECTOR B29M
#                       POSITION AT TIME OF IGNITION
#
# DEBRIS        QTEMP1
#               MPAC, QPRET
#               PUSHLIST
#               RTX2,RTX1

                BANK    14
                SETLOC  P40S1
                BANK

                COUNT   16/S40.1

S40.1           SET     VLOAD
                        FIRSTFLG
                        LO6ZEROS
                STORE   BDT
                STQ     BOF
                        QTEMP
                        XDELVFLG
                        S40.1B          # LAMBERT
                VLOAD   ABVAL           # EXTERNAL DELTA-V
                        DELVSIN
                STORE   DELVSAB         # COMPUTE FOR P30/P40 INTERFACE
                                        #       THUS PERMITTING MODULE-ONLY CHANGE
                SETPD   VLOAD
                        0
                        VTIG
                STORE   VINIT
                VXV     UNIT
                        RTIG
                STOVL   UT              # UP IN UT
                        RTIG
                STORE   RINIT
                VSQ     PDDL
                        36D
                DMPR    DDV
                        THETACON
                DMP     DMP
                        DELVSAB
                        WEIGHT/G
```

```
                DDV
# Page 711
                        F
                STOVL   14D
                        DELVSIN

                DOT     VXSC
                        UT
                        UT
                VSL2    PUSH            # (DELTAV.UP)UP SCALED AT 2(+7) P.D.L. 0
                BVSU    PDDL            # DELTA VP SCALED AT 2(+7) P.D.L. 6
                        DELVSIN
                        14D
                SIN     PDVL
                        6D
                VXV     UNIT
                        UT
                VXSC    STADR
                STOVL   VGTIG           # UNIT(VP X UP)SIN(THETAT/2) IN VGTIG.
                UNIT    PDDL            # UNIT(DELTA VP) IN P.D.L. 6
                        14D
                COS     VXSC
                VAD     VXSC
                        VGTIG
                        36D
                VSL2    VAD
                STADR
                STORE   VGTIG           # VG IGNITION SCALED AT 2(+7) M/CS

                UNIT
                STOVL   UT              # THRUST DIRECTION SCALED AT 2(+1)
                        VGTIG
                PUSH    SET
                        AVFLAG
                CALL
                        MIDGIM          # VGTIG IN LV COOR AT 2(+7)M/CS IN DELVLVC
                GOTO
                        QTEMP
S40.1B          DLOAD   DSU             # LAMBERT
                        TIG
                        TWODT
                STODL   TDEC1
                        TPASS4
                DSU
                        TDEC1
                STCALL  DELLT4
```

```
                        AGAIN
                VLOAD
                        VIPRIME
                STODL   UT
                        TIG
                STORE   TDEC1
# Page 712
                BDSU
                        TPASS4
                STCALL  DELLT4
                        AGAIN
                VLOAD   PUSH
                        DELVEET3
                STORE   VGTIG
                SET     CALL
                        AVFLAG
                        MIDGIM
                SETPD   GOTO
                        0
                        CALCUT

THETACON        2DEC    .31830989 B-8

                SETLOC  P40S3
                BANK

                COUNT   24/S40.1

EP4(45)H        2DEC    .125

EP4(10)H        2DEC    .027777777

AGAIN           STQ     CALL
                        QTEMP1
                        THISPREC
                SXA,2   SXA,1
                        RTX2
                        RTX1
                VLOAD
                        RATT
                STORE   RTIG
                STOVL   RINIT
                        VATT
                STORE   VTIG
                STORE   VINIT
                SETPD   SLOAD
```

```
                        0
                        HI6ZEROS
                PDDL    BON
                        EP4(45)H
                        NORMSW
                        +3
                DLOAD
                        EP4(10)H
                PUSH    CALL
                        INITVEL
                SETPD   GOTO
# Page 713
                        0
                        QTEMP1
CALCUT          VLOAD   CALL
                        RTIG
                        CALCGRAV        # GDELTAT IN MPAC AT 2(+7) M/CS
                VSL1    V/SC
                        200CS           # G AT 2(-5) M/CS. CS
                PDVL    VSU
                        VIPRIME
                        UT
                V/SC    VSU
                        200CS
                VXSC    VSL2
                        CSTEER
                STOVL   12D             # B.C SCALED AT 2(-15) PDL 12D
                        VGTIG
                UNIT    PUSH            # UG PDL 0 SCALED AT 2(+1)

                DOT     VXSC
                        12D
                        0
                VSL2    BVSU
                        12D
                STODL   12D             # Q PDL SCALED AT 2(-5)
                        F
                SRR     DDV
                        4
                        WEIGHT/G
                DSQ     PDVL            # F/MASS SQUARED PDL 6 AT 2(-10M/(CS.CS)
                        12D
                VSQ
                BDSU    SQRT
                VXSC    VSL1
                VAD     UNIT
```

```
                        12D
                STCALL  UT
                        QTEMP
200CS           2DEC    200 B-12

# Page 714
# PROGRAM DESCRIPTION S40.2,3           DATE 15 NOV 66
# MOD NO 2                              LOG SECTIONS P40-P47
# MOD BY ZELDIN
#
# FUNCTIONAL DESCRIPTION
#
#       COMPUTE GIMBAL ANGLES IF THRUSTING OCCURRED WITH PRESENT IMU
#       ORIENTATION, WINGS LEVEL SPACECRAFT, HEADS UP
#       COMPUTE X AXIS OF ENGINE BELL
#       COMPUTE PREFERRED IMU ORIENTATION (XSCREF)
#       FOR THIS CALCULATION, ASSUME X AXIS OF SC ALONG UT INITIALLY,
#       YSC=UNIT(XXR), ZSC=UNIT(XX(XXR)) AND ROTATE ENGINE BELL ALONG UT.
#       NEW SC AXES WILL BE APPROX. WINGS LEVEL AND NEW SC AXES IN REF.
#       COORDS. WILL BE PREFERRED IMU ORIENTATION.
#       COMPUTE DESIRED THRUST DIRECTION IN SM COORDS.
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             S40.2,3
#
# NORMAL EXIT MODE
#       AT L+2 OF CALLING SEQUENCE (GOTO L+2)
#
# SUBROUTINES CALLED
#       CALCGA
#
# ALARM OR ABORT MODES
#       NONE
#
# ERASABLE INITIALIZATION REQUIRED
#       PACTOFF         TOTAL PITCH TRIM ANGLE          SP AT 1.0795111 REV.
#       YACTOFF         TOTAL YAW   TRIM ANGLE          SP AT 1.0795111 REV.
#       UT              DESIRED THRUST DIRECTION        VECT. B2 M/(CS.CS)
#       RTIG            POSITION AT TIME OF IGNITION    VECT. B29 M
#       ENG2FLAG        ON=RCS  OFF=SPS
#
# OUTPUT
#       SCAXIS          UNIT VECT. ALIGNED WITH ENG BELL IN SC COOR.    B1
#       XSCREF          UNIT VECTORS ALIGNED WTH PREFERRED IMU          B1
#       YSCREF
```

```
#       ZSCREF
#       GIMBAL ANGLES IN THETAD
#       POINTVSM        UNIT VECT ALONG DESIRED THRUST DIRECTION IN SM  B1
#
# DEBRIS
#       PUSHLIST, QPRET, MPAC
#       QTEMP   TEMP. ERASABLE

                BANK    24
                SETLOC  P40S
                BANK
                COUNT*  $$/S40.2
S40.2,3         VLOAD   MXV
                        UT
                        REFSMMAT
                VSL1    STQ
                        QTEMP
                STORE   POINTVSM        # THRUST IN SM AT 2
                SETPD   BON
                        0
# Page 715
                        ENG2FLAG
                        S40.2,3B
                DLOAD
                        HI6ZEROS
                PUSH    SLOAD           # ZERO PDL 0
                        YACTOFF
                DMP     SL1
                        TRIMSCAL
                DAD     PUSH
                        YBIAS
                COS     PDDL            # COS(Y +Y0) PDL 2
                SIN     PUSH            # SIN(Y +Y0) PDL 4
                SLOAD
                        PACTOFF
                DMP     SL1
                        TRIMSCAL
                DAD     PUSH
                        PBIAS
                COS     PDDL            # COS(P +P0) PDL 6
                SIN     PUSH            # SIN(P +P0) PDL 8D
                STODL   ZSCREF          # SIN(P +P0)
                        6
                DMP     SL1
                        4
                DCOMP   PDDL            # -SIN(Y+Y0)COS(P+P0) PDL 10
```

```
                6
        DMP     SL1
                2
        VDEF

        STODL   XSCREF          # PD POINTER AT 6 NEW SC X AXIS SCALED AT
                ZSCREF
        DMP     SL1
                4
        PDDL    DMP
                ZSCREF
                2
        SL1     DCOMP
        VDEF

        STODL   ZSCREF          # PD POINTER AT 4 NEW SC Z AXIS SCALED AT 2
        VDEF

        STODL   YSCREF          # PD POINTER AT 0 NEW SC Y AXIS SCALED AT 2
                ZSCREF
        PDDL    PDDL
                YSCREF
                XSCREF
        VDEF
# Page 716
        STOVL   SCAXIS          # ENGINE BELL SCALED AT 2
                UT
        PDVL    UNIT
                RTIG
        VXV     VCOMP
                0
        UNIT    PUSH
        CALL
                TSTRXUT
        VXV     VCOMP
                0
        VSL1    PDVL            # 2 RF/SC IN PDL 12D
                XSCREF
        VXM     VSL1
                0
        STOVL   XSCREF          # X OF PREF. IMU,X OF SC IN REF COOR. AT 2
                YSCREF
        VXM     VSL1
                0
        STOVL   YSCREF          # Y OF PREF. IMU,Y OF SC IN REF COOR. AT 2
                ZSCREF
```

```
                VXM     VSL1
                        0
                STORE   ZSCREF          # Z OF PREF. IMU,Z OF SC IN REF COOR. AT 2
                SETPD   GOTO
                        0
                        QTEMP
S40.2,3B        VLOAD
                        UNITX
                STOVL   SCAXIS
                        UT
                STORE   XSCREF
                VXV     UNIT
                        RTIG
                STCALL  6D
                        TSTRXUT
                STORE   YSCREF
                VXV     VCOMP
                        XSCREF
                VSL1
                STCALL  ZSCREF          # ZNB AXIS IN REF COOR
                        QTEMP
TSTRXUT         DLOAD   BHIZ
                        36D
                        BADVCTOR
                VLOAD   RVQ
                        6D
BADVCTOR        VLOAD   UNIT
                        RTIG
                PDVL    UNIT
# Page 717
                        VTIG
                VSR3    VAD
                VXV     UNIT
                        UT
                VCOMP
                STORE   6D
                RVQ
TRIMSCAL        2DEC    1.07975111 B-1

YBIAS           2DEC    +.00263888889   # YAW   MECH BIAS (+0.95 DEG, THRUST ON)

PBIAS           2DEC    -.00597222222   # PITCH MECH BIAS (-2.15 DEG, THRUST ON)

                                        # REFERENCE, TRW 68.6520.3.3-40 27 FEB, 1968

# PROGRAM DESCRIPTION S41.1             DATE 8 DEC 66
```

```
# MOD NO 1                              LOG SECTION P40-P47
# MOD BY ZELDIN
#
# FUNCTIONAL DESCRIPTION
#
#       COMPUTE VELOCITY TO BE GAINED INITIALLY IN REF COORDS.
#       TO CONTROL COORDS.
#
# CALLING SEQUENCE
#
#       L       CALL
#       L+1             S41.1
#
# NORMAL EXIT MODE
#
#       AT L +2 OF CALLING SEQUENCE
#
# SUBROUTINES CALLED:
#
#       CALCSMSC
#       CDUTRIG
#
# ALARM OR ABORT MODES
#
#       NONE
#
# ERASABLE INITIALIZATION REQUIRED
#
#       VG IN REF. COORD. PDL L POINTER AT L+5.  S41.1 WILL RETURN WITH
#       POINTER AT L (L MUST BE LESS THAN OR = TO 14D)
#
# OUTPUT
#
#       MPAC CONTAINS VG IN CONTROL COORDS              VECT. B7 M/CS
#
# DEBRIS:
#
#       QTEMP           TEMP ERASABLE
#       QPRET

                COUNT   22/S41.1

                SETLOC  P40S5
                BANK

S41.1           STQ     CALL
```

```
                        QTEMP
                        CDUTRIG
                VLOAD
                MXV     CALL
                        REFSMMAT
                        *SMNB*
# Page 718
                MXV     VXSC
                        QUADROT
                        TENBNK14        # VG IN CONTROL COORD IN MPAC SCALED AT
                VSL5    GOTO            # VG IN CONTROL COORDS. IN MPAC AT 2(+7)
                        QTEMP
TENBNK14        2DEC    10. B-4

# Page 719
# NAME          S40.8 -- CROSS PRODUCT STEERING
# FUNCTION      (1) UPDATES THE VELOCITY-TO-BE-GAINED VECTOR.
#               (2) GENERATES ANGULAR RATE STEERING COMMANDS FOR AUTOPILOT.
#               (3) ESTABLISHES ENGINE CUT-OFF SIGNALS AT APPROPRIATE TIMES.
#               (4) INITIATES THRUST-FAIL ROUTINE, R40
# CALLING SEQ   CALL S40.6
# INPUT         VGPREV          LAST VALUE OF THE VELOCITY-TO-BE-GAINED VECTOR
#                               PRIOR TO UPDATING IN METERS/CS AT +7.
#               DELVREF         CHANGE IN VEHICLE VELOCITY SINCE LAST MEASUREMENT
#                               IN METERS/CS AT +7.
#               BDT             EFFECT OF RATE OF CHANGE OF REQUIRED VELOCITY AND
#                               GRAVITY DURING DT UPON VELOCITY-TO-BE-GAINED IN
#                               METERS/CS AT +7.
#               CSTEER          A SCALAR OF THE STEERING LAW, SC.AT B+1, USED FOR
#                               SPS AIMPOINT STEERING MANEUVERS.
#               IDLEFAIL        A FLAG TO INHIBIT (IDLE) THE THRUST-FAIL ROUTINE.
#               STEERSW         A SWITCH TO PRECLUDE NEEDLESS CONDUCT OF STEERING.
#               REFSMMAT, DAPDATR1, PIPTIME
#               EREPFRAC, ETDECAY, KPRIMEDT FOR TVC.
# OUTPUT        TTOGO           TIME REMAINING FOR ENGINE BURN IN CS AT +28.
#               OMEGAC          DP VECTOR RATE COMMAND, SC.AT 1/(2TVCDT) REVS/SEC.
#               VG, VGPREV, VGDISP, TGO, TIG, SCALED AS NOTED IN CODING
#               STEERSW, IMPULSW, NVWORD1
#               REPFRAC, CNTR, VCNTR, VCNTRTMP FOR TVC (R40 INTERFACING)
# DEBRIS        OMEGAXC, +1
# SUBROUTINES USED:  *SMNB*, ALARM

                SETLOC  P40S1
                BANK
                EBANK=  DAPDATR1
                COUNT   16/S40.8
```

```
S40.8           SETPD   STQ
SPBIT1                  OOD
                        QTEMP
                VLOAD   BVSU            # CONSTRUCT DELVG, SC.AT B+7 M/CS
                        DELVREF
                        BDT
                VAD
                        VGPREV
                STORE   VG              # VELOCITY-TO-BE-GAINED, SC.AT B+7 M/CS

                ABVAL
                STORE   VGDISP          # FOR DISPLAY PURPOSES
                EXIT
                TC      PHASCHNG
                OCT     10035           # TYPE B RESTART RESTART BELOW AND 5.3 REREADAC

                TC      INTPRET
                VLOAD
# Page 720
                        VG
                STORE   VGPREV
                BOFF    VLOAD
                        STEERSW         # SKIP TGO AND CROSS-PRODUCT
                        QTEMP
                        DELVREF
                ABVAL   PUSH            # CHECK FOR LOTHRUST
                SLOAD   DMP
                        DVTHRESH        # SC.AT B-2 M/CS
                        DPB-9
                BDSU
                BMN     EXIT
                        LOTHRUST
                CAE     DAPDATR1        # ENABLE TVCDAP CG TRACKING
                MASK    BIT14
                CCS     A
                CAF     BIT1
                INDEX   A               # LM-OFF, LM-ON VALUE
                CAE     EREPFRAC
                TS      REPFRAC

                TC      INTPRET
TGOCALC         VLOAD   BVSU            # GET DELVG
                        DELVREF
                        BDT
                UNIT
```

```
                DOT     PUSH            # (OOD)
                        VG
                BPL     DDV             # ANGLE SHOULD BE GREATER THAN PI/2
                        INCRSVG         #       DISPLAY ALARM IF NOT
                        2VEXHUST
                DAD     DMP             # (DOT PRODUCT UP FROM OOD)
                        LODPHALF
                NORM    SR1
                        X1
                PDDL    NORM
                        36D             # (MAG DELVG)
                        X2
                BDDV
                XSU,2   SL*
                        X1
                        0 -9D,2
                DMP     PUSH            # (OOD)
                        -FOURDT
                SLOAD   SR
                        ETDECAY         # ETDECAY SC.AT B+14 CS
                        14D
                BDSU    STADR
                STORE   TGO             # TIME TO GO IN CS. AT +28
                DAD
# Page 721
                        PIPTIME
                STODL   TIG
                        TGO
                DSU     BMN
                        FOURSEC
                        S40.81

XPRODUCT        VLOAD   VXSC
                        BDT
                        CSTEER
                VSL2    VSU
                        DELVREF
                UNIT    PDVL
                        VG
                UNIT    VXV
                MXV     CALL
                        REFSMMAT        # (REFSMMAT/2)
                        *SMNB*
                VXSC
                        KPRIMEDT        # (KPRIMEDT SCIAT PI/8 RAD)
OMEGACLC        STORE   OMEGAC
```

```
                GOTO
                        QTEMP

                SETLOC  DAPS7
                BANK
                COUNT   17/S40.8

TWODT           2DEC    200.0 B-28      # 2 SEC

-FOURDT         2DEC    -800 B-18       # -4(200CS), SC.AT B+18CS (-4 FOR SCALING)

2VEXHUST        2DEC    63.020792 B-7   # 2(10338.0564 FPS), SC.AT B+7 M/CS

FOURSEC         2DEC    400.0 B-28      # 4 SEC

DPB-9           2DEC    1 B-9

                SETLOC  DAPS6
                BANK

                COUNT   20/S40.8

S40.81          SET     VLOAD           # TGO LESS THAN 4 SECONDS
                        IMPULSW         # FOR ENGINE-OFF CALL
                        HI6ZEROS
RATEZRO         STORE   OMEGAC          # TVC TO ATTITUDE HOLD
                EXIT
                CAF     POSMAX          # INHIBIT SWITCHOVER/TVC EG TRACKING
                TS      CNTR
# Page 722
                TC      INTPRET
                CLEAR   GOTO
                        STEERSW         # RESTARTS OK
                        QTEMP
INCRSVG         EXIT                    # ALARM INDICATING THAT THRUST IS POINTING
                TC      ALARM           # IN WRONG DIRECTION.
                OCT     01407
                TC      INTPRET
                GOTO
                        QTEMP

LOTHRUST        BON     VLOAD           # THRUST FAILURE (LO-OR-NO) INDICATED
                        IDLEFAIL        # SET BY V97P.  ALLOWS 1 BYPASS IN CASE OF
                        QTEMP           #       UNFAVORABLE S40.8 SYNCH.
                        HI6ZEROS        # START OF ENGINE-FAIL (R40) OPERATIONS
                STORE   OMEGAC          # PUT TVC IN ATTITUDE HOLD
```

```
                EXIT

                CS      ZERO
                TS      VCNTR           # KILL CSMMASS UPDATING
                TS      VCNTRTMP        # (TVCEXEC LOGIC REQUIRES THIS TOO)
                TS      REPFRAC         # KILL TVCDAP CG TRIM TRACKING
                TS      NVWORD1         # SET UP ENGINE-FAIL V97FLASH (CLOCKJOB)

                TC      INTPRET
                CLEAR   GOTO            # INHIBIT STEERING AND TGO CALC (MANUAL
                        STEERSW         #       SHUTDOWN IF NOT SET UP AGAIN)
                        QTEMP           # RESTARTS OK

# Page 723
# NAME          S40.9 -- VTOGAIN (AIMPOINT MANEUVERS ONLY)
# FUNCTION      (1) GENERATES REQUIRED VELOCITY AND VELOCITY-TO-BE-GAINED
#               VECTORS FOR USE DURING AIMPOINT MANEUVERS.
#               (2) UPDATES THE B VECTOR WHICH IS USED IN THE FINAL
#               CALCULATION OF EXTRAPOLATING THE VELOCITY-TO-BE-GAINED.
# CALLING SEQ   VIA FINDVEC AS NEW JOB.
# INPUT         RNIT    ACTIVE VEHICLE RADIUS VECTOR IN METERS AT +29.
#               VNIT    ACTIVE VEHICLE VELOCITY VECTOR IN METERS/CS AT +7.
#               VRPREV  LAST COMPUTED VELOCITY REQUIRED VECTOR IN
#                       METERS/CS AT +7.
#               NONTIG  TIME OF IGN.  USED IN TARGETTING ROUTINES B+28
#               DELLT4  TRANSFER TIME FROM PIPTIME TO TARGET B+28
#               TNIT    TIME OF RNIT AND VNIT IN CS AT +28
#               GDT/2   HALF OF VELOCITY GAINED IN DELTA T TIME DUE TO
#                       ACCELERATION OF GRAVITY IN METERS/CS AT +7.
#               DELVREF CHANGE IN VELOCITY DURING LAST 2 SEC IN
#                       METERS/CS AT +7.
#               NORMSW  SET=CENTRAL ANGLE BETWEEN RTARG AND RTIG IS BETWEEN
#                       165 TO 195 DEGREES.
#                       RESET=CENTRAL ANGLE OUTSIDE CONE DESCRIBED ABOVE.
# OUTPUT        VGTEMP  VELOCITY TO BE GAINED VECTOR IN METERS/CS AT +7.
#               COGA    INPUT OF INITIAL GUESS FOR LAMBERT FROM S40.1
#                       OR PREVIOUS PASS THRU S40.9.
#               GOBL/2  OBLATENESS TERM IN AVG GRAV CALC: GOBL*RSQ/MU
#               VRPREV/ VELOCITY REQUIRED VECTOR IN METERS/CS AT +7.
#               BDT     B VECTOR IN METERS/CS AT +7.
# SUBROUTINES USED -- INITVEL

                SETLOC  P40S1
                BANK

                EBANK=  NBRCYCLS
```

```
                COUNT   16/S40.9

S40.9           TC      INTPRET
                SETPD   DLOAD
                        00D
                        LO6ZEROS
                PDDL
                        EP4(45)L
                BON     DLOAD
                        NORMSW
                        +2
                        EP4(10)L
                PUSH
                CLEAR   CALL
                        GUESSW
                        HAVEGUES
                EXIT
                TC      PHASCHNG        # SAVE TIME BY NOT REDOING LAMBERT CALCS
                OCT     05021           # C, PRIORITY NEXT, JOB BELOW
# Page 724
                OCT     10000
                TC      INTPRET
ENDLAMB         BON
                        FIRSTFLG
                        FIRSTTME
                VLOAD   VSU
                        VIPRIME
                        VRPREV
                PDDL    DSU
                        TNIT
                        TNITPREV
                SL      BDDV
                        17D
                        200CSHI
                VXSC
                VSU     VSL1
                        GDT/2
                STORE   BDT
FIRSTTME        SLOAD   DCOMP
                        RTX2
                BMN
                        MOONCASE
                VLOAD   UNIT
                        RN
                DLOAD   DSU
                        PIPTIME
```

```
                        NOMTIG
                DMP     DDV
                        EARTHMU
                        34D
                VXSC    VAD
                        GOBL/2
                        VGTEMP          # NOTE: NO TEST IS MADE TO SUBTRACT GOBL
                STORE   VGTEMP          # INSIDE 165-195 DEGREE CONE AREA.
MOONCASE        EXIT
                TC      PHASCHNG
                OCT     04021           # C, JOB BELOW

COPY40.9        TC      INTPRET
                DLOAD
                        TNIT
                STOVL   TNITPREV
                        VIPRIME
                STORE   VRPREV
                CLEAR   EXIT
                        FIRSTFLG
        -2      CS      ONE             # REDO40.9 (RESTART) ENTRY TO END S40.9
                TS      NBRCYCLS
ENDS40.9        TC      PHASCHNG
                OCT     00001
# Page 725
                TCF     ENDOFJOB

REDO40.9        TC      INTPRET         # S40.9 RESTARTS COME HERE TO GRACEFULLY
                VLOAD                   #       TERMINATE S40.9 SO THAT IT CAN BE
                        LO6ZEROS        #       SET UP WITH LATEST R,V,T NEXT PASS
                STODL   DELVSUM         #       (TYPE C PHASE POINTS '04021' WILL
                        LO6ZEROS        #       FORCE NORMAL S40.9 TERMINATIONS,
                STOVL   NBRCYCLS        #       RATHER THAN LOSE TIME OF BRAND NEW
                        VGPREV          #       PASS -- QUICK OLD DATA BETTER THAN
                STORE   VGTEMP          #       NONE) NOW CAN GO THRU SETUP.9
                EXIT                    #       WITHOUT DISTURBING VGPREV.
                TCF     ENDS40.9 -2     # STORE 0,0 COVERED NBRCYCLS,P -- FIX UP S

200CSHI         2DEC    200 B-12

EARTHMU         2DEC*   -3.986032 E10 B-36*

EP4(45)L        2DEC    .125

EP4(10)L        2DEC    .027777777
```

```
# Page 726
# NAME:                 S40.13 -- TIMEBURN
#
# FUNCTION              (1) DETERMINE WHETHER A GIVEN COMBINATION OF VELOCITY-TO-
#                       BE-GAINED AND ENGINE CHOICE RESULT IN A BURN TIME SUFFICIENT
#                       TO ALLOW STEERING AT THE VEHICLE DURING THE BURN, AND
#                       (2) THE MAGNITUDE OF THE RESULTING BURN TIME -- IF IT IS SHORT --
#                       AND THE ASSOCIATED TIME OF THE ENGINE OFF SIGNAL.
#
# CALLING SEQUENCE      VIA FINDVAC AS A NEW JOB
#
# INPUT                 VGTIG -- VELOCITY TO BE GAINED VECTOR (METERS/CS) AT +7
#                       WEIGHT/G -- MASS OF VEHICLE IN KGM AT TIG
#                       F -- ENGINE THRUST IN M.NEWTONS AT +7
#                       MDOT -- RATE OF DECREASE OF VEHICLE MASS DURING ENGINE BURN
#                               IN KILOGRAMS/CENTISECOND AT +3.  THIS SCALING MAY
#                               REQUIRE MODIFICATION FOR SATURN BURNS.
#
# OUTPUT                IMPULSW         ZERO FOR STEERING
#                                       ONE FOR ATTITUDE HOLD
#                       TGO             TIME TO BURN IN CENTISECONDS AT +14
#                       THE QUANTITY M.NEWTON SHALL BE USED TO EXPRESS WEIGHT IN TERMS OF
#                       (KILOGRAM*METER)/(CENTISECOND*CENTISECOND)
#                       (1) M.NEWTON = (10000) NEWTONS.

                EBANK=  TGO
                COUNT   16/40.13

S40.13          TC      INTPRET
                SETPD   SET
                        00D
                        IMPULSW         # ASSUME NO STEERING UNTIL FOUND OTHERWISE
                VLOAD   ABVAL
                        VGTIG           # VELOCITY TO BE GAINED AT +7
                EXIT
                CAF     BIT7            # TEST +X TRANSLATION
                EXTEND
                RXOR    CHAN31
                MASK    BIT7
                EXTEND
                BZF     NOTADDUL
                TC      INTPRET
                PDDL    DDV             # 00D = MAG OF VGTIG AT +7
                        S40.135         # COMPENSATION FOR 2 JET ULLAGE AT +24
                        WEIGHT/G        # MASS IN KGMS AT +16
                BON     SL1             # DOUBLE CORRECTION IF FOUR JETS
```

```
                        NJETSFLG
                        S40.130
S40.130         BDSU
                PDDL    DDV             # 00D = MAG OF VGTIG CORRECTED FOR ULLAGE
                        K1VAL           # M.NEWTON-CS AT +24
                        WEIGHT/G
                BDSU    BMN
                        00D
                        S40.131         # TGO LESS THAN 100 CS
                PDDL    DMP             # 02D = TEMP1 AT +7
# Page 727
                        EMDOT           # SPS FLOW RATE SC.AT B+3 KG/CS (SP, NOTE)
                        3.5SEC          # 350 CS AT +14
                BDSU    PDDL
                        WEIGHT/G
                        FANG
                DMP     SR2
                        5SECOND         # 500 CS AT +14
                DDV     PUSH            # 04D = TEMP2
                BDSU    BPL
                        02D
                        S40.133         # TGO GREATER THAN 600 CS
                DLOAD   BDDV
                DMP     DAD
                        5SECOND         # 500 CS AT +14
                        1SEC2D          # 100 CS AT +14
                GOTO
                        S40.132
S40.131         DLOAD   DMP             # TGO LESS THAN 100 CS
                        WEIGHT/G
                DAD     DDV
                        K2VAL           # M.NEWTON CS AT +24
                        K3VAL           # M.NEWTON AT +10
S40.132         EXIT
                EBANK=  TGO
                TC      TPAGREE
                CA      MPAC
                XCH     L
                CA      ZERO
                DXCH    TGO             # TGO IN CS AT +28
                TC      S40.134
S40.133         CLEAR   EXIT            # WILL STEER VEHICLE
                        IMPULSW
S40.134         TC      PHASCHNG        # KILL GROUP 3
                OCT     3
```

```
                TCF     ENDOFJOB

NOTADDUL        TC      INTPRET
                GOTO
                        S40.130 +1      # DO NOT COMPENSATE FOR 7 SEC OF ULLAGE
                SETLOC  DAPS7
                BANK

                COUNT   17/40.13

K1VAL           =       EK1VAL          # DP PAD LOAD B+23 NEWTON-SEC/E+2
K2VAL           =       EK2VAL          # DP PAD LOAD B+23 NEWTON-SEC/E+2
K3VAL           =       EK3VAL          # DP PAD LOAD B+09 NEWTONS/E+4
1SEC2D          2DEC    100.0 B-14      # 100.0 CS AT +14
# Page 728
3.5SEC          2DEC    350.0 B-13      # 350 CS AT +13

5SECOND         2DEC    500.0 B-14      # 500.0 CS AT +14

S40.135         2DEC    69.6005183 B-23 # IMPULSE FROM 7.96 SECS OF 2-JET FIRING
                                        #       7.96 (199.6)COS(10) LB-SEC, SC.AT
                                        #       B+23 NEWTON-SEC/E+2 (7 SEC ULLAGE
                                        #       TO GO, PLUS 0.96 SEC FROM PIPTIME)

# Page 729
# NAME          S40.6 GIMBAL DRIVE TEST AND/OR GIMBAL TRIM
# MOD NO 5                              DATE 9 MARCH, 1967
# MOD BY ENGEL                          LOG SECTION P40-P47
#
# FUNCTIONAL DESCRIPTION
#       GIMBAL DRIVE TEST....0,+2,-2,0 DEGREE ENGINE COMMANDS, AT 2 SECOND
#               INTERVALS, FIRST IN PITCH, THEN IN YAW.  ASTRONAUT VERIFICATION
#               OF GIMBAL MOTION ON GPI
#       GIMBAL TRIM....AFTER A 4 SECOND DELAY, ENGINE COMMANDED TO
#               PRE-COMPUTED TRIM POSITION.  ASTRONAUT VERIFICATION ON GPI.
#       PRE40.6....RESTART ENTRY TO RE-DO S40.6, ONLY IF RCS IS ON --- IF TVC
#               IS NOT ON --- PRIMARILY TO GET ACTUATORS TRIMMED FOR IGNITION.
#               BYPASS 4 SEC DELAY.  SPEED IS CRITICAL NEAR IGNITION.
#               IF TVC IS ON (TVCDAPON OR LATER) THEN REDOTVC WILL TAKE CARE
#               OF RESTARTING ACTUATORS.
#
# CALLING SEQUENCE....
#       WAITLIST, WITH 2CADR FOR S40.6 (OR PRE40.6), WITH EBANK= CNTR
#
# NORMAL EXIT MODE -- FIXDELAY, TASKOVER
#
```

```
# SUBROUTINES CALLED....
#       OUTPUT (INTERNAL)
#       FIXDELAY
#
# ALARM OR ABORT EXIT MODES --- NONE
#
# ERASABLE INITIALIZATION REQUIRED
#       CNTR = +0, NORMALLY SET BY THE P40 CALL AT TST,TRIM.
#       MRKRTMP....POSITIVE FOR GIMBAL DRIVE TEST AND GIMBAL TRIM (BOTH)
#                  NEGATIVE FOR GIMBAL TRIM ONLY
#       PACTOFF, YACTOFF SC.AT 85.41 ARCSEC/BIT (V48N48 P, YTRIM)
#       "SC CONT" SWITCH AT "CMC" (A/P CONTROL SWITCH AT "GNC")
#       ACTIVE SPS GIMBAL MOTOR POWER(S), PITCH, YAW
#
# OUTPUT
#       TVCYAW, TVCPITCH (BITS RELEASED)
#       TVC ENABLE AND OPTICS ERROR COUNTER ENABLE
#
# DEBRIS
#       TBMPR60, CNTR

                BANK    17
                SETLOC  DAPS6
                BANK

                EBANK=  CNTR
                COUNT   20/S40.6

PRE40.6         CS      FLAGWRD6        # RESTART ENTRY TO S40.6 (DO NOT PERMIT
                MASK    OCT60000        #       IF TVC, BITS 15,14 = 1,0)
                EXTEND
                BZMF    +2
                TCF     TASKOVER        # TVC, REDOTVC WILL REESTABLISH INTERFACE

                CS      BIT1            # RCS, SO DO S40.6, GIMTRIM ONLY
# Page 730
                TS      MRKRTMP

                CAF     BIT1            # FOR REVISED S40.6 TIMING FOR RESTARTS...
                TS      CNTR            # TO INDICATE A RESTART ENTRY (CNTR 1S
                                        #       NORMALLY +0, BY S40.6)

                EBANK=  CNTR
S40.6           CS      ZERO            # INHIBIT OPTICS ACTIVITY
                TS      OPTIND
```

```
                CS      BIT2            # DISENABLE OPTICS ERROR COUNTERS (ZERO,
                EXTEND                  #       AND INHIBIT PULSE TRANSMISSION --
                WAND    CHAN12          #       NORMAL STATE)

                CAF     OCT02200        # TVC ENABLE (SPS SERVO AMPS SEE DAC
                EXTEND                  #       VOLTAGES) AND DISENGAGE OPTICS/DAC
                WOR     CHAN12

                TC      FIXDELAY        # 60MS PROCEDURAL DELAY (40MS MINIMUM) FOR
                DEC     6               #       RELAY LATCHING

                CAF     BIT2            # ENABLE OPTICS ERROR COUNTERS
                EXTEND
                WOR     CHAN12

                TC      FIXDELAY        # 20MS PROCEDURAL DELAY (4MS MINIMUM) FOR
                DEC     2               #       RELAY LATCHING

RSTRTST         CCS     CNTR            # CHECK FOR RESTART ENTRY (PRE40.6)
                TCF     GIMTRIM +2      # RESTART ENTRY....BYPASS 4 SECOND DELAY
                                        #       TST,TRIM SETS +0 ON NORMAL ENTRY

                CAE     MRKRTMP         # CHECK FOR TEST/TRIM OR TRIM ONLY
                TS      CNTR            #       MRKRTMP SAVES CNTR FOR RESTARTS
                EXTEND
                BZMF    GIMTRIM         # (TRIM ONLY)

GDTSETUP        CS      ZERO            # GIMBAL DRIVE TEST SETUP, FOR PITCH
                TS      CNTR

GIMDTEST        CAF     +2ACTDEG        # GIMBAL DRIVE TEST, 1ST INCREMENT
                TC      OUTPUT          #       (LEAVES GIMBAL AT +2 DEG)
                CAF     -4ACTDEG        # 2ND INCREMENT (LEAVES GIMBAL AT -2)
                TC      OUTPUT
                CAF     +2ACTDEG        # 3RD INCREMENT (LEAVES GIMBAL AT -0)
                TC      OUTPUT

                CS      CNTR            # CHECK FOR COMPLETION OF YAW TEST.
# Page 731
                CCS     A
                TCF     GIMTRIM         # COMPLETED, GO TO GIMBAL TRIM ROUTINE
                CS      BIT1            # SET UP YAW TEST
                TS      CNTR
                TCF     GIMDTEST        # FOR YAW TEST

OUTPUT          EXTEND                  # OUTPUT THE INCREMENT....SAVE Q
```

```
                QXCH    TEMPR60

                INDEX   CNTR
                TS      TVCPITCH

                INDEX   CNTR
                CAF     BIT11
                EXTEND
                WOR     CHAN14

                TC      FIXDELAY        # WAIT 2SEC, WHILE ASTRONAUT VERIFIES
                DEC     200             #       GIMBAL MOTION ON GPI
                TC      TEMPR60

GIMTRIM         TC      FIXDELAY        # WAIT 4 SECONDS BEFORE GIMBAL TRIM
                DEC     400

        +2      CS      ZERO            # PICK UP TRIM VALUES AND OUTPUT THEM
                AD      PACTOFF         #       (AVOID +0) ENTRY POINT FROM RSTRTST
                TS      TVCPITCH        #       ON A RESTART, TO AVOID 4SEC DELAY
                CS      ZERO
                AD      YACTOFF
                TS      TVCYAW

                CAF     PRIO6           # RELEASE THE COUNTERS, BITS 11,12
                EXTEND
                WOR     CHAN14

ENDS40.6        TCF     TASKOVER

OCT02200        OCT     02200           # BITS 8,11 FOR CHANNEL 12 TVC/OPTICS
-4ACTDEG        DEC     -168            # -2(+2ACTDEG), WHOLE BITS, NO ROUNDUP
+2ACTDEG        DEC     +84             # +2 DEG, SC.AT 85.41 ARCSEC/BIT (+84D)

# CALLED BY "DONOUN46" (VERB 48), OR DIRECTLY BY "FRESHDAP" (RCS DAP) VIA IBNKCALL

                COUNT   20/S41.2

S41.2           CA      DAPDATR1
# Page 732
                MASK    THREE
                AD      A
                TS      RATEINDX

                INHINT
                CAE     DAPDATR1        # IS LEM ATTACHED (BITS 14,13 OF DAPDATR1
```

```
                MASK    PRIO30          #       =10)
                AD      -BIT14          # (OCT57777)
                EXTEND
                BZF     TOGETHER        # YES

                CS      BIT2            # NO, UNSET FLAG
                MASK    FLAGWRD7
                TS      FLAGWRD7

                TCF     +4

TOGETHER        CS      FLAGWRD7        # ATTACHED, SET FLAG FOR INTEGRATION
                MASK    BIT2
                ADS     FLAGWRD7

                RELINT

                CA      DAPDATR1
                MASK    BIT4
                EXTEND
                BZMF    +2              # DEC 46 MEANS NARROW DB
                CA      DEC409
                AD      DEC46           # DEC 455 MEANS WIDE DB
                TS      ADB

                CA      DAPDATR1
                MASK    BIT7            # QUAD BD
                EXTEND
                BZMF    +2
                CA      ONE
                TS      XTRANS
                CA      DAPDATR1
                MASK    BIT10           # QUAD AC
                EXTEND
                BZMF    +2
                CS      ONE
                ADS     XTRANS

                INHINT
                EXTEND
                BZF     +5              # CLEAR NJETSFLG (4 JETS, OR NO JETS)
                CS      FLAGWRD1        # SET NJETSFLG (2 JETS, AC OR BD QUADS)
                MASK    BIT15           # NJETSFLG = 1 FOR 2 JET ULLAGE (AC OR BD)
                ADS     FLAGWRD1
# Page 733
                TCF     +4
```

```
                CS      BIT15           # KJETSFLG = 0 FOR 4 JET (OR 0 JET) ULLAGE
                MASK    FLAGWRD1
                TS      FLAGWRD1
                RELINT
                CA      DAPDATR2
                MASK    BIT13
                EXTEND
                BZMF    +2
                TCF     +2
                CS      ONE
                COM
                TS      ACORBD          # MINUS FOR A-C, PLUS FOR B-D

                CA      DAPDATR2
                MASK    BIT10
                CCS     A
                TCF     +4
                CA      ONE
                TS      RACFAIL
                TCF     BDFAIL
                CA      ZERO
                TS      RACFAIL
                CA      DAPDATR2
                MASK    BIT4
                CCS     A
                TCF     BDFAIL
                CS      ONE
                TS      RACFAIL
BDFAIL          CA      DAPDATR2
                MASK    BIT7
                CCS     A
                TCF     +4
                CA      ONE
                TS      RBDFAIL
                TC      Q
                CA      ZERO
                TS      RBDFAIL
                CA      DAPDATR2
                MASK    BIT1
                CCS     A
                TC      Q
                CS      ONE
                TS      RBDFAIL
                TC      Q

# DAPFIG ENTRY VIA TC POSTJUMP AS JOB FROM "STABLISH" (VERB 46)
```

```
                BANK    42
                SETLOC  EXTVBS
# Page 734
                BANK

DAPFIG          CS      BIT9            # TURN OFF SIVB TAKEOVER
                EXTEND
                WAND    CHAN12
                CAE     DAPDATR1        # DETERMINE VEHICLE CONFIGURATION
                EXTEND
                MP      BIT3            #       RIGHT SHIFT 4 OCTAL DIGITS
                MASK    THREE           #       (IN CASE BIT 15 IS USED)
                INDEX   A
                TCF     +1              #       BRANCH BASED ON CONFIG....

                TCF     NODAPUP         # CM.......ACTIVATE NODAP
                TCF     RCSDAPUP        #       CSM......ACTIVATE RCSDAP
                TCF     RCSDAPUP        #       CSM/LEM..ACTIVATE RCSDAP
                TC      POSTJUMP
                CADR    SATSTKON
RCSDAPUP        INHINT                  # CALL TO ACTIVATE RCSDAP, AND RETURN
                TCR     IBNKCALL
                CADR    RCSDAPON
                RELINT
                TCF     ENDFIG          # CAME IN VIA V46, GO OUT VIA GOPIN
NODAPUP         EXTEND                  # T5 IDLE FOR NODAP (DON'T WORRY ABOUT T)
                DCA     T5IDLDAP
                DXCH    T5LOC
                TC      DOWNFLAG        # RESET T5-USAGE FLAGS FOR NODAP
                ADRES   DAPBIT1         # BIT 15 FLAG 6 = 0
                TC      DOWNFLAG
                ADRES   DAPBIT2         # BIT 14 FLAG 6 = 0
                INHINT
                TC      IBNKCALL        # ZERO JET CHANNELS IN 14 MS AND THEN
                CADR    ZEROJET         # LEAVE THE T6 CLOCK DISABLED.
                RELINT
                CAF     BIT1            # KILL KALCMANU JOB
                TS      HOLDFLAG
ENDFIG          TC      POSTJUMP        # CAME IN VIA V46, GO OUT VIA GOPIN
                CADR    GOPIN
                SBANK=  PINSUPER        # Added by RSB 2009
                EBANK=  PACTOFF
T5IDLDAP        2CADR   T5IDLOC

                SBANK=  LOWSUPER
```

```
                BANK    17
                SETLOC  DAPS6
                BANK

DEC409          DEC     409
DEC46           DEC     46

# Page 735

# CALLED BY "DONOUN47" (VERB 48), OR DIRECTLY BY "FRESHDAP" (RCS DAP)
S40.14          CAE     IXX             # RCS ENTRY
                EXTEND
                MP      CONTONE
                TS      J/M

                CA      IAVG
                EXTEND
                MP      CONTONE
                TS      J/M1

                TS      J/M2

                EXTEND
                DCA     CONTTWO
                EXTEND
                DV      IXX
                TS      KMJ

                EXTEND
                DCA     CONTTWO
                EXTEND
                DV      IAVG
                TS      KMJ1

                TS      KMJ2

                TC      Q

CONTONE         DEC     .662034         # 2PI/M
CONTTWO         2DEC    .00118

                COUNT   24/TVNG

                BANK    31
                SETLOC  P40S
                BANK
```

```
POS-2.5         OCT     37405
                EBANK=  DAPDATR1
RCSCADR         2CADR   RCSUP

6SECT5          OCT     37704
                COUNT   21/RCSUP

                BANK    20

                SETLOC  DAPS3
                BANK

# Page 736

RCSUP           LXCH    BANKRUPT
                EXTEND
                QXCH    QRUPT

                TCR     RCSDAPON        # ACTIVATE RCS DAP

                TCF     RESUME

                EBANK=  DAPDATR1
RCSADDR         2CADR   RCSATT

0.6SECT5        OCT     37704

                                        # RCSDAPON ENTRY MUST BE UNDER INT-INHIBIT
RCSDAPON        CAF     0.6SECT5        # 0.6 SEC ALLOWS TVCEXEC/ROLLDAP TO DIE
        +1      TS      TIME5           # ENTRY FROM R00TOP00
                TS      T5PHASE         # WILL CAUSE FRESHDAP (+1)

                CS      RCSFLAGS        # SET BIT3 TO REINITIALIZE FDAI ERROR
                MASK    BIT3            #       DISPLAY, IN CASE SC CONT SWITCH
                ADS     RCSFLAGS        #       IN SCS NOT GNC (GUIDEMODE PRIMARY)

                EXTEND
                DCA     RCSADDR         # (RCSATT)
                DXCH    T5LOC

                CS      OCT60000        # SEE BITS 15,14 TO 01 TO INDICATE
                MASK    FLAGWRD6        #       T5 TAKEOVER BY RCSDAP
                AD      BIT14
                TS      FLAGWRD6        # KILLS TVCEXEC AND ROLLDAP STARTS
```

```
TC      Q                # RETURN TO CALLER (TVCDAPOF OR RCSDAPUP)
```

Uses -PHASE4 152, -PHASE6 152, A 80, ACORBD 211, ADB 213, ASTNFLAG 123, AVEGEXIT 159, AVFLAG 105, BANKRUPT 80, BDT 238, BIAS 211, CDUSPOTX 152, CDUSPOTY 152, CDUSPOTZ 152, CDUX 80, CDUY 80, CDUZ 80, CHAN12 87, CHAN14 87, CHAN31 87, CNTR 200, COMMAND 169, COUNT 142, CSMMASS 200, CSTEER 238, D 226, DAPBIT1 117, DAPBIT2 117, DAPDATR1 200, DAPDATR2 200, DAPS3 63, DAPS6 63, DAPS7 63, DELLT4 224, DELPBAR 204, DELTAT 241, DELVCTL 238, DELVEET3 236, DELVIMU 238, DELVLVC 224, DELVREF 224, DELVSAB 236, DELVSIN 236, DELVSUM 208, DELVSUMP 208, DELYBAR 204, DSALMOUT 87, DV 241, DV47TEMP 238, DVTHRESH 166, DVTOTAL 224, EBANK 80, ECSTEER 224, EK1VAL 174, EK2VAL 174, EK3VAL 174, EMDOT 138, ENG2FLAG 99, ENGONFLG 115, EREPFRAC 198, ERRBTMP 206, ERRORY 211, ETDECAY 198, EXTVBS 71, F 238, FANG 174, FIRSTFLG 103, FLAGWRD1 97, FLAGWRD2 101, FLAGWRD5 113, FLAGWRD6 117, FLAGWRD7 121, GDT/2 159, GOBL/2 159, GUESSW 101, H 177, HDOT 231, HI6ZEROS 71, HOLDFLAG 163, IAVG 200, IDLEFAIL 101, IGNFLAG 123, IMPULSW 103, IT 185, IXX 200, J/M 211, J/M1 211, J/M2 211, KMJ 211, KMJ1 211, KMJ2 211, KPRIMEDT 204, L 80, LO6ZEROS 71, LOC 145, LODPHALF 71, LOWSUPER 67, LV 85, MASS 200, MASSTMP 206, MODE 145, MODREG 154, MPAC 145, MRKRTMP 200, NBRCYCLP 208, NBRCYCLS 208, NJETSFLG 97, NOMTIG 224, NORMSW 123, NVWORD1 157, OGAD 200, OMEGAC 202, OMEGAXC 202, OPTIND 161, P 188, P40S 65, P40S1 61, P40S2 67, P40S3 67, P40S5 63, P40TMP 238, PACTOFF 198, PFRATFLG 105, PHASE4 152, PHASE5 152, PHASE6 152, PINSUPER 69, PIPTIME 159, PIPTIME1 159, POINTVSM 219, PRIORITY 145, Q 80, QPRET 85, QRUPT 80, QTEMP 236, QTEMP1 238, R2 188, RACFAIL 211, RAD 219, RATEINDX 157, RBDFAIL 211, RCSFLAGS 200, REFSMMAT 172, REPFRAC 204, RESTART 57, REVS 206, RINIT 234, RN 159, RTARG 224, RTIG 236, SAVE 191, SCAXIS 219, SR 80, STATE 138, STEERSW 103, STRULLSW 117, T1 241, T5LOC 163, T5PHASE 200, TBASE6 154, TC 169, TEMP 191, TEMPR60 157, TEVENT 163, TGO 224, THETAD 157, THETADX 211, THETADY 211, THISPREC 73, THRUST 85, TIG 224, TIME1 80, TIME2 80, TIME5 80, TIMRFLAG 123, TNIT 234, TNITPREV 234, TPASS4 236, TTOGO 236, TVCEXPHS 206, TVCPHASE 204, TVCPITCH 85, TVCYAW 85, UT 238, V 229, V97VCNTR 200, VCNTR 204, VCNTRTMP 206, VG 234, VGBODY 238, VGDISP 231, VGPREV 238, VGTEMP 236, VGTIG 238, VINIT 234, VIPRIME 234, VN 159, VRPREV 234, VTIG 236, W 183, WEIGHT/G 200, WHOCARES 244, X1 85, X2 85, XDELVFLG 103, XSCREF 148, XTRANS 211, YACTOFF 198, YSCREF 148, Z 80, ZNB 186, and ZSCREF 148.

3.5.7 p51-p53 code

1146 ⟨*p51-p53 code* 1146⟩≡ (857a 2766)
⟨*Page CM0737* 1147⟩

1147 ⟨*Page CM0737* 1147⟩≡ (1146)

```
# Page 737
# PROGRAM NAME -- PROG52                        DATE -- NOV 30, 1966
# MOD NO -- 2                                   LOG SECTION -- P51-P53
# MODIFICATION BY -- LONSKE                     ASSEMBLY -- SUNDISK REV 30
#
# FUNCTIONAL DESCRIPTION --
#
#       ALIGNS THE IMU TO ONE OF THREE ORIENTATIONS SELECTED BY THE ASTRONAUT.  THE PRESENT IMU
#       AND IS STORED IN REFSMMAT.  THE THREE POSSIBLE ORIENTATIONS MAY BE:
#
#       (A)     PREFERRED ORIENTATION
#
#               AN OPTIMUM ORIENTATION FOR A PREVIOUSLY CALCULATED MANEUVER.  THIS ORIENTATION
#               STORED BY A PREVIOUSLY SELECTED PROGRAM.
#
#       (B)     NOMINAL ORIENTATION
#
#               X   = UNIT ( Y   x Z   )
#               -SM          -SM   -SM
#
#               Y   = UNIT (V X R)
#               -SM         -   -
#
#               Z   = UNIT ( -R )
#               -SM           -
#
#               WHERE:
#
#               R = THE GEOMETRIC RADIUS VECTOR AT TIME T(ALIGN) SELECTED BY THE ASTRONAUT
#               -
#
#               V = THE INERTIAL VELOCITY VECTOR AT TIME T(ALIGN) SELECTED BY THE ASTRONAUT
#               -
#
#       (C)     RERSMMAT ORIENTATION
#
#               THIS SELECTION CORRECTS THE PRESENT IMU ORIENTATION.  THE PRESENT ORIENTATION D
#               WAS LAST ALIGNED ONLY DUE TO GYRO DRIVE (I.E., NEITHER GIMBAL LOCK NOR IMU POWE
#               SINCE THE LAST ALIGNMENT).
#
#       AFTER A IMU ORIENTATION HAS BEEN SELECTED ROUTINE S52.2 IS OPERATED TO COMPUTE THE GIME
#       NEW ORIENTATION AND THE PRESENT VEHICLE ATTITUDE.  CAL52A THEN USES THESE ANGLES, STORE
#       COARSE ALIGN THE IMU.  THE STARS SELECTION ROUTINE, R56, IS THEN OPERATED.  IF 2 STARS
#       IS FLASHED TO NOTIFY THE ASTRONAUT.  AT THIS POINT THE ASTRONAUT WILL MANEUVER THE VEHI
#       EITHER MANUALLY OR AUTOMATICALLY.  AFTER 2 STARS HAVE BEEN SELECTED THE IMU IS FINE ALI
```

```
#       THE RENDEZVOUS NAVIGATION PROCESS IS OPERATING (INDICATED BY RNDVZFLG) P20 IS
#       REQUESTED.
#
# CALLING SEQUENCE --
#
#       THE PROGRAM IS CALLED BY THE ASTRONAUT BY DSKY ENTRY.
# Page 738
#
# SUBROUTINES CALLED --
#
#       1. FLAGDOWN              7. S52.2               13. NEWMODEX
#       2. R02BOTH               8. CAL53A              14. PRIOLARM
#       3. GOPERF4               9. FLAGUP
#       4. MATMOVE              10. R56
#       5. GOFLASH              11. R51
#       6. S52.3                12. GOPERF3
#
# NORMAL EXIT MODES --
#
#       EXITS TO ENDOFJOB
#
# ALARM OR ABORT EXIT MODES --
#
#       NONE
#
# OUTPUT --
#
#       THE FOLLOWING MAY BE FLASHED ON THE DSKY
#               1. IMU ORIENTATION CODE
#               2. ALARM CODE 215 -- PREFERRED IMU ORIENTATION NOT SPECIFIED
#               3. TIME OF NEXT IGNITION
#               4. GIMBAL ANGLES
#               5. ALARM CODE 405 -- TWO STARS NOT AVAILABLE
#               6. PLEASE PERFORM P00
#       THE MODE DISPLAY MAY BE CHANGED TO 20
#
# ERASABLE INITIALIZATION REQUIRED --
#
#       PFRATFLG SHOULD BE SET IF A PREFERRED ORIENTATION HAS BEEN COMPUTED.  IF IT I
#       XSMD, YSMD, ZSMD.
#
#       RNDVZFLG INDICATES WHETHER THE RENDEZVOUS NAVIGATION PROCESS IS OPERATING.
#
# DEBRIS --
#
#       WORK AREA
```

```
P54             =       PROG52
                BANK    33
                SETLOC  P50S
                BANK

                SBANK=  LOWSUPER
                EBANK=  SAC
                COUNT   15/P52

PROG52          TC      PHASCHNG
                OCT     00254
                TC      DOWNFLAG
                ADRES   UPDATFLG        # BIT 7 FLAG 1
# Page 739
                TC      DOWNFLAG
                ADRES   TRACKFLG        # BIT 5 FLAG 1
                TC      BANKCALL
                CADR    R02BOTH         # IMU STATUS CHECK
                CAF     BIT4
                MASK    STATE +2        # IS PFRATFLG SET?
                CCS     A
                TC      P52A            # YES
                CAF     BIT2            # NO
                TC      P52A +1
P52A            CAF     BIT1
                TS      OPTION2
P52B            CAF     BIT1
                TC      BANKCALL        # FLASH OPTION CODE AND ORIENTATION CODE
                CADR    GOPERF4R
                TC      GOTOP00H
                TC      +5
                TC      P52B            # NEW CODE -- NEW ORIENTATION CODE INPUT
                TC      PHASCHNG
                OCT     00014
                TC      ENDOFJOB
                CA      OPTION2
                MASK    THREE
                INDEX   A
                TC      +1
                TC      P52T            # L.S.
                TC      P52J            # PREF
                TC      P52T            # NORM
                TCF     P52C            # REF
P52T            EXTEND
                DCA     NEG0
```

```
                DXCH    DSPTEM1
                CAF     V06N34
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H
                TC      +2
                TC      -5
                EXTEND
                DCA     DSPTEM1
                EXTEND
                BZF     +2
                TCF     +4

                EXTEND
                DCA     TIME2
                DXCH    DSPTEM1
                CA      OPTION2
                MASK    BIT2
                CCS     A
# Page 740
                TCF     +6              # NOM
                TC      INTPRET         # LS
                CALL
                        P52LS
                GOTO
                        P52D
                TC      INTPRET
                DLOAD
                        DSPTEM1
                CALL                    # COMPUTE NOMINAL IMU
                        S52.3           #       ORIENTATION
P52D            CALL                    # READ VEHICLE ATTITUDE AND
                        S52.2           #       COMPUTE GIMBAL ANGLES
                EXIT
                CAF     VB06N22
                TC      BANKCALL        # DISPLAY GIMBAL ANGLES
                CADR    GOFLASH
                TC      GOTOP00H
                TC      COARSTYP
P52J            TC      INTPRET         # RECYCLE: VEHICLE HAS BEEN MANEUVERED
                GOTO
                        P52D
                TC      INTPRET
                CALL                    # DO COARSE ALIGN
                        CAL53A          #       ROUTINE
CAL53RET        SET     EXIT
```

```
                        REFSMFLG
P52C            TC      PHASCHNG
                OCT     04024
                CAF     ALRM15
                TC      BANKCALL
                CADR    GOPERF1
                TC      GOTOP00H
                TC      +2              # V33
                TC      P52F            # E
                TC      INTPRET
                RTB     DAD
                        LOADTIME
                        TSIGHT1
                CALL
                        LOCSAM
                EXIT
P52E            TC      BANKCALL        # DO STAR SELECTION
                CADR    PICAPAR
                TC      P52I            # 2 STARS NOT AVAILABLE
P52F            TC      INTPRET         # 2 STARS AVAILABLE
                CALL
                        R51
ENDP50S         EXIT
                TC      GOTOP00H
# Page 741
P52I            TC      ALARM
                OCT 405
                CAF     V05N09
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H
                TC      P52F            # PROCEED:  DO FINE ALIGN-R51
                TC      P52C            # RECYCLE:  VEHICLE HAS BEEN MANEUVERED
V06N34          VN      0634
VB06N22         VN      00622
COARSTYP        CAF     OCT13
                TC      BANKCALL
                CADR    GOPERF1
                TCF     GOTOP00H        # V34
                TCF     P52J    +3      #       NORMAL
                TC      INTPRET         # GYRO COARSE
GYCRS           VLOAD   MXV
                        XSMD
                        REFSMMAT
                UNIT
                STOVL   XDC
```

```
                        YSMD
                MXV     UNIT
                        REFSMMAT
                STOVL   YDC
                        ZSMD
                MXV     UNIT
                        REFSMMAT
                STCALL  ZDC
                        CALCGTA
                CLEAR   CLEAR
                        DRIFTFLG
                        REFSMFLG
                EXIT
                CAF     V16N20
                TC      BANKCALL
                CADR    GODSPR
                CA      R55CDR
                TC      BANKCALL
                CADR    IMUPULSE
                TC      BANKCALL
                CADR    IMUSTALL
                TC      CURTAINS
                TC      PHASCHNG
                OCT     04024
                TC      INTPRET
                AXC,1   AXC,2
                        XSMD
                        REFSMMAT
                CALL
# Page 742
                        MATMOVE
                CLEAR   SET
                        PFRATFLG
                        REFSMFLG
                RTB     VLOAD
                        SET1/PDT
                        ZEROVEC
                STORE   GCOMP
                SET     GOTO
                        DRIFTFLG
                        R51K
V16N20          VN      1620
ALRM15          EQUALS  OCT15
                SETLOC  P50S2
                BANK
V06N89*         VN      0689
```

```
# NAME -- P52LS
#
# FUNCTION -- TO DISPLAY THE LANDING SITE LATITUDE,
# LONGITUDE AND ALTITUDE.  TO ACCEPT NEW DATA VIA
# THE KEYBOARD.  TO COMPUTE THE LANDING SITE
# ORIENTATION FOR P52 OR P54
#
# LET:
#       RLS  = LANDING SITE VECTOR IN REF COORDINATES
#       R    = CSM POSITION VECTOR IN REF COORDINATES
#       V    = CSM VELOCITY VECTOR IN REF COORDINATES
# THEN THE LANDING SITE ORIENTATION IS:
#       XSMD = UNIT(RLS)
#       YSMD = UNIT(ZSMD*XSMD)
#       ZSMD = UNIT((R*V)*RLS)
#
# CALL:         CALL
#                       P52LS
#
# INPUTS:       DSPTEM1 = TIME OF ALIGNMENT
#               RLS = LANDING SITE VECTOR IN MOON FIXED COORDINATES
#
# OUTPUTS:      XSMD, YSMD, ZSMD
#
# SUBROUTINES:  RP-TO-R, LAT-LONG, LLASRD, LLASRDA, CSMPREC
#
# DEBRIS:       VAC, SEE SUBROUTINES

P52LS           STQ     SET
                        QMAJ
                        LUNAFLAG
                DLOAD
                        DSPTEM1
                STORE   TSIGHT
                VLOAD   SET
                        RLS
                        ERADFLAG
                STODL   0D
                        TSIGHT
                STCALL  6D
# Page 743
                        RP-TO-R
                VSR2
                STODL   ALPHAV
                        TSIGHT
```

```
                CALL
                        LAT-LONG
                CALL
                        LLASRD
                EXIT
LSDISP          CAF     V06N89*
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H
                TC      +2
                TC      LSDISP
                TC      INTPRET
                CALL
                        LLASRDA
                DLOAD   CALL
                        TSIGHT
                        LALOTORV
                VLOAD   UNIT
                        ALPHAV
                STODL   XSMD
                        TSIGHT
                STCALL  TDEC1
                        CSMPREC
                VLOAD   VXV
                        RATT
                        VATT
                VXV     UNIT
                        XSMD
                STORE   ZSMD
                VXV     UNIT
                        XSMD
                STCALL  YSMD
                        QMAJ
                SETLOC  P50S1
                BANK

# NAME:         AUTOMATIC OPTICS POSITIONING ROUTINE
#
# FUNCTION:     (1) TO POINT THE STAR LOS OF THE OPTICS AT A STAR OR LANDMARK DEFINED
#               (2) TO POINT THE STAR LOS OF THE OPTICS AT THE LEM DURING RENDEZVOUS
#
# CALLING:      CALL R52
#
# INPUT:        1.  TARG1FLG AND TARG2FLG:  PRESET BY CALLER
#               2.  RNDVZFLG AND TRACKFLG:  PRESET BY CALLER
#               3.  STAR CODE:  PRESET BY CALLER.  ALSO INPUT THROUGH DSKY
```

```
#               4.  LAT, LONG, AND ALT OF LANDMARK:  INPUT THROUGH DSKY
# Page 744
#               5.  NO. OF MARKS (MARKINDX):  PRESET BY CALLER
#
# OUTPUT:       DRIVE SHAFT AND TRUNNION CDUS.
#
# SUBROUTINES:  1.  FIXDELAY            7.  CLEANDSP
#               2.  GOPERF1             8.  GODSPR
#               3.  GOFLASH             9.  REFLASHR
#               4.  R53                 10. R52.2
#               5.  ALARM               11. R52.3
#               6.  SR52.1

                COUNT   15/R52

R52             STQ     CLEAR
                        SAVQR52
                        ADVTRK
R52VRB          EXIT
                EXTEND
                DCA     CDUT
                DXCH    DESOPTT
                TC      INTPRET
                SSP     CLEAR
                        OPTIND
                        0
                        R53FLAG
                EXIT
R52A            TC      INTPRET
                SET     BON
                        TRUNFLAG
                        TARG1FLG
                        R52H
                CLEAR   EXIT
                        TERMIFLG
R52C            CA      SWSAMPLE        # IS OPTICS MODE IN AGC
                EXTEND
                BZMF    R52M            # MANUAL
R52D            TC      BANKCALL        # AGC
                CADR    SR52.1
                TCF     R52L            # GR 90 DEGREES
                TCF     R52J            # GR 50 DEGREES
                TC      UPFLAG          # LS 50 DEGREES
                ADRES   TRUNFLAG        # SET TRUNFLAG BIT 4 FLAG 0
R52JA           CAF     BIT10           # IS THIS A LEM
                MASK    STATE +1
```

```
                CCS     A
                TC      R52E            # YES
                CAF     BIT6            # NO, IS R53FLAG SET
                MASK    STATE
                CCS     A
                TCF     R52E            # YES
# Page 745
                CAF     V06N92          # NO
                TC      BANKCALL
                CADR    GODSPR
R52E            CA      SWSAMPLE        # IS OSS IN CMC MODE
                EXTEND
                BZMF    R52F            # NO
                CS      STATE           # YES: IS TRUNFLAG SET
                MASK    BIT4
                CCS     A
                TC      +3              # NO
                CA      PAC             # YES
                TS      DESOPTT
                CA      SAC
                TS      DESOPTS
R52F            CAF     .5SEC           # WAIT 1/2 SEC
                TC      BANKCALL
                CADR    DELAYJOB
                CAF     BIT10
                MASK    STATE +1
                CCS     A
                TCF     R52HA           # YES, LEM
                CAF     BIT15           # NO
                MASK    STATE +7        # IS TERMIFLG SET
                EXTEND
                BZF     R52C            # NO
R52Q            TC      INTPRET         # YES
                GOTO
                        SAVQR52
R52H            EXIT                    # LEM
R52HA           TC      BANKCALL
                CADR    R61CSM
                CA      STATE +1
                MASK    BIT5
                EXTEND                  # TRACKFLG
                BZF     R52Q

                CS      STATE +1
                MASK    BIT7            # UPDATFLG
                CCS     A
```

```
                TCF     R52SYNC

R52I            CA      STATE +5
                MASK    BIT10
                CCS     A
                TC      R52D            # PRFTRKAT = 1
R52SYNC         CAF     1.8SEC          # MAKE UP FOR LOST TIME
                TCF     R52F +1

R52J            TC      DOWNFLAG        # CLEAR TRUNFLAG
                ADRES   TRUNFLAG        # BIT 4 FLAG 0
# Page 746
                TC      ALARM           # SET 407 ALARM
                OCT     407
                TC      R52JA
R52M            CAF     BIT6            # IS R53FLAG SET
                MASK    STATE
                CCS     A
                TC      R52F            # YES
                INHINT                  # NO
                CAF     PRIO24
                TC      FINDVAC
                EBANK=  SAC
                2CADR   R53JOB

                RELINT
                TCF     R52F
R53JOB          TC      INTPRET
                CALL
                        R53
ENDPLAC         EXIT                    # INTERPRETER RETURN TO ENDOFJOB (R22 USES)
                TC      ENDOFJOB
V06N92          VN      00692
V06N89A         VN      0689
SHAXIS          2DEC    .5376381241 B-1

                2DEC    0

                2DEC    .8431766920 B-1

R52L            CAF     BIT10           # IS THIS A LEM
                MASK    STATE +1
                CCS     A
                TC      R52J            # YES
                CAF     OCT404
                TC      BANKCALL
```

```
                CADR    PRIOLARM
                TCF     TERM52          # TERMINATE
                TCF     R52F            # PROCEED
                TCF     R52F            # NO PROVISION FOR NEW DATA
                TCF     ENDOFJOB

OCT404          OCT     404
1.8SEC          DEC     180

TERM52          TC      CLEARMRK

                TC      BANKCALL        # KILL MARK SYSTEM
                CADR    MKRELEAS

# Page 747

                CAF     ZERO
                TS      OPTCADR

                TC      BANKCALL        # CLEAR OUT EXTENDED VERBS
                CADR    KLEENEX

                TC      GOTOP00H        # NO GO TO P00

ADVORB          STQ     SET             # SETS UP ADVANCED ORBIT TRACKING
                        SAVQR52
                        ADVTRK
                SET     SET
                        LUNAFLAG
                        ERADFLAG
                GOTO
                        R52VRB

# Page 748
# NAME -- S50 ALIAS LOCSAM
# NAME: LOCSAM
#
# FUNCTION -- TO COMPUTE QUATITIGS LISTED BELOW, USED IN THE
#             IMU ALIGNMENT PROGRAMS.
#
#       DEFINE:
#
#       RATT = POSITION VECTOR OF CM WRT PRIMARY BODY
#
#       VATT = VELOCITY VECTOR OF CM WRT PRIMARY BODY
#
```

```
#       RE = RADIUS OF EARTH
#
#       RM = RADIUS OF MOON
#
#       ECLIPOL = POLE OF ECLIPTIC SCALED BY TANGENTIAL VELOCITY OF EARTH
#                 WRT TO SUN OVER THE VELOCITY OF LIGHT
#
#       REM = POSITION OF MOON WRT EARTH
#
#       RES = POSITION OF SUN WRT EARTH
#
#       C = VELOCITY OF LIGHT
#
#               EARTH IS PRIMARY                        MOON IS PRIMARY
#                       _                                       _
#               VEARTH=-1(RATT)                         VEARTH=-1(REM+RATT)
#                       _                                       _
#               VMOON = 1(REM-RATT)                     VMOON =-1(RATT)
#                       _                                       _
#               VSUN  = 1(RES)                          VSUN  = 1(RES-REM)
#                             -1
#               CEARTH=COS(SIN  (RE/RATT)+5)            CEARTH=COS 5
#                                                                    -1
#               CMOON =COS 5                            CMOON =COS(SIN  CRM/RATT)+5)
#
#               CSUN  =COS 15                           CSUN  =COS 15
#
#                           VEL/C = VSUN x ECLIPOL + VATT/C
#
# CALL:         DLOAD   CALL
#                       DESIRED TIME
#                       LOCSAM
#
# INPUTS:       MPAC = TIME
#
# OUTPUTS:      VEARTH, VMOON, VSUN, CEARTH, CMOON, CSUN, VEL/C
#
# SUBROUTINES:  LSPOS, CSMCONIC
#
# DEBRIS:       VAC AREA, SEE SUBROUTINES.

# Page 749
                SETLOC  P50S1
                BANK

                COUNT*  $$/S50
```

```
LOCSAM          =       S50
S50             STQ
                        QMAJ
                STCALL  TSIGHT
                        LSPOS
                STOVL   VMOON
                        2D
                STODL   VSUN
                        TSIGHT
                STCALL  TDEC1
                        CSMCONIC
                SSP     TIX,2
                        S2
                        0
                        MOONCNTR
EARTCNTR        VLOAD   VSU
                        VMOON
                        RATT
                UNIT
                STOVL   VMOON
                        RATT
                UNIT    VCOMP
                STODL   VEARTH
                        RSUBE
                CALL
                        OCCOS
                STODL   CEARTH
                        CSS5
                STOVL   CMOON
                        VSUN
                UNIT
                STCALL  VSUN
                        ENDSAM
MOONCNTR        VLOAD   VSR8
                        VMOON
                VSR1    BVSU
                        VSUN
                UNIT
                STOVL   VSUN
                        VMOON
                VAD     UNIT
                        RATT
                VCOMP
                STOVL   VEARTH
# Page 750
```

```
                        RATT
                UNIT    VCOMP
                STODL   VMOON
                        RSUBM
                CALL
                        OCCOS
                STODL   CMOON
                        CSS5
                STOVL   CEARTH
                        VSUN
ENDSAM          VXV
                        ECLIPOL
                STOVL   VEL/C
                        VATT
                VXSC    VAD
                        1/C
                        VEL/C
                STODL   VEL/C
                        CSSUN
                STCALL  CSUN
                        QMAJ
OCCOS           DDV     SR1
                        36D
                ASIN    DAD
                        5DEGREES
                COS     SR1
                RVQ
                SETLOC  P50S
                BANK
RSUBM           2DEC    1738090 B-29    # MOON RADIUS IN METERS

RSUBE           2DEC    6378166 B-29

5DEGREES        2DEC    .013888889      # SCALED IN REVS

1/C             2DEC    .000042699 B-1  # *

ECLIPOL         2DEC    0               # *

                2DEC    -.00007896 B-1  # *

                2DEC    .00018209 B-1   # *             * FOR USE BY CSM ONLY

TSIGHT1         2DEC    24000
```

```
CEARTH          =       14D
CSUN            =       16D
CMOON           =       18D
CSS5            2DEC    .2490475        # (COS 5)/4
# Page 751
CSSUN           2DEC    .24148          # (COS 15)/4

# Page 752
# PROGRAM NAME -- PICAPAR       DATE: DEC 20 66
# MOD 1                         LOG SECTION: P51-P53
#                               ASSEMBLY:  SUNDISK REV40
# BY KEN VINCENT
#
# FUNCTION
#       THIS PROGRAM READS THE IMU-CDUS AND COMPUTES THE VEHICLE ORIENTATION
#       WITH RESPECT TO INERTIAL SPACE.  IT THEN COMPUTES THE SHAFT AXIS (SAX)
#       WITH RESPECT TO REFERENCE INERTIAL.  EACH STAR IN THE CATALOG IS TESTED
#       TO DETERMINE IF IT IS OCCULTED BY EITHER EARTH, SUN OR MOON.  IF A
#       STAR IS NOT OCCULTED THEN IT IS PAIRED WITH ALL STARS OF LOWER INDEX.
#       THE PAIRED STAR IS TESTED FOR OCCULTATION.  PAIRS OF STARS THAT PASS
#       THE OCCULTATION TESTS ARE TESTED FOR GOOD SEPARATION.  A PAIR OF STARS
#       HAVE GOOD SEPARATION IF THE ANGLE BETWEEN THEM IS LESS THAN 66 DEGREES
#       AND MORE THAN 40 DEGREES.  THOSE PAIRS WITH GOOD SEPARATION
#       ARE THEN TESTED TO SEE IF THEY LIE IN CURRENT FIELD OF VIEW.  (WITHIN
#       33 DEGREES OF SAX).  THE PAIR WITH MAX SEPARATION IS CHOSEN FROM
#       THOSE WITH GOOD SEPARATION, AND IN FIELD OF VIEW.
#
# CALLING SEQUENCE
#       L       TC      BANKCALL
#       L+1     CADR    PICAPAR
#       L+2     ERROR RETURN -- NO STARS IN FIELD OF VIEW
#       L+3     NORMAL RETURN
#
# OUTPUT
#       BESTI, BESTJ -- SINGLE PREC, INTEGERS, STAR NUMBERS TIMES 6
#       VFLAG -- FLAG BIT SET IMPLIES NO STARS IN FIELD OF VIEW
#
# INITIALIZATION
#       1)      A CALL TO LOCSAM MUST BE MADE
#       2)      VEARTH = -UNIT(R) WHERE R HAS BEEN UPDATED TO APPROXIMATE TIME OF
#               SIGHTINGS.
#
# DEBRIS
#       WORK AREA
#       X,Y,ZNB
#       SINCDU, COSCDU
```

```
#       STARAD -- STAR +5

                COUNT   14/PICAP

                SETLOC  P50S1
                BANK
PICAPAR         TC      MAKECADR
                TS      QMIN
                TC      INTPRET
                CALL
                        CDUTRIG
                CALL
                        CALCSMSC
# Page 753
                SETPD
                        0
                SET     DLOAD           # VFLAG = 1
                        VFLAG
                        DPZERO
                STOVL   BESTI
                        XNB
                VXSC    PDVL
                        SIN33
                        ZNB
                AXT,1   VXSC
                        228D            # X1 = 37 X 6 + 6
                        COS33
                VAD
                VXM     UNIT
                        REFSMMAT
                STORE   SAX             # SAX = SHAFT AXIS
                SSP     SSP             # S1 = S2 = 6
                        S1
                        6
                        S2
                        6
PIC1            TIX,1   GOTO            # MAJOR STAR
                        PIC2
                        PICEND
PIC2            VLOAD*  CALL
                        CATLOG,1
                        OCCULT
                BON     LXA,2
                        CULTFLAG
                        PIC1
                        X1
```

```
PIC3            TIX,2   GOTO
                        PIC4
                        PIC1
PIC4            VLOAD*  CALL
                        CATLOG,2
                        OCCULT
                BON     VLOAD*
                        CULTFLAG
                        PIC3
                        CATLOG,1
                DOT*    DSU
                        CATLOG,2
                        CSS66           # SEPARATION LESS THAN 66 DEG.
                BMN     DAD
                        PIC3
                        CSS6640         # SEPARATION MORE THAN 40 DEG.
                BPL
                        PIC3
# Page 754
                VLOAD*  DOT
                        CATLOG,1
                        SAX
                DSU     BMN             # MAJOR STAR IN CONE
                        CSS33
                        PIC1
                VLOAD*  DOT
                        CATLOG,2
                        SAX
                DSU     BPL
                        CSS33
                        STRATGY
                GOTO
                        PIC3
STRATGY         BONCLR
                        VFLAG
                        NEWPAR
                XCHX,1  XCHX,2
                        BESTI
                        BESTJ
STRAT           VLOAD*  DOT*
                        CATLOG,1
                        CATLOG,2
                PUSH    BOFINV
                        VFLAG
                        STRAT -3
                DLOAD   DSU
```

```
                BPL
                        PIC3
NEWPAR          SXA,1   SXA,2
                        BESTI
                        BESTJ
                GOTO
                        PIC3
OCCULT          MXV     BVSU
                        CULTRIX
                        CSS
                BZE
                        CULTED
                BMN     SIGN
                        CULTED
                        MPAC +3
                BMN     SIGN
                        CULTED
                        MPAC +5
                BMN     CLRGO
                        CULTED
                        CULTFLAG
                        QPRET
CULTED          SETGO
# Page 755
                        CULTFLAG
                        QPRET
CSS             =       CEARTH
SIN33           2DEC    .5376381241

COS33           2DEC    .8431756920

CSS66           2DEC    .060480472      # (COS76)/4

CSS6640         2DEC    -.15602587      # (COS76 - COS30)/4

CSS33           2DEC    .197002688      # (COS(1/2(76))/4

PICEND          BOFF    EXIT
                        VFLAG
                        PICGXT
                TC      PICBXT
PICGXT          EXIT
                INCR    QMIN
PICBXT          CA      QMIN
                TC      SWCALL
#V1             =       12D
```

```
# Page 756
# NAME -- R51   FINE ALIGN
# FUNCTION -- TO ALIGN THE STABLE MEMBER TO REFSSMAT
# CALLING SEQ -- CALL R51
# INPUT -- BESTI, BESTJ (PAIR OF STAR NO)
# OUTPUT -- GYRO TORQUE PULSES
# SUBROUTINES -- R52, R54, R55 (SXTNB, NBSM, AXISGEN)

                COUNT   14/R51

R51             EXIT
                CAF     BIT1
                TS      STARIND
                TS      MARKINDX
R51.2           TC      INTPRET
R51.3           CLEAR   CLEAR
                        TARG2FLG
                        TARG1FLG
                EXIT
                TC      PHASCHNG
                OCT     05024           # RESTART GR 4 FOR R52-R53
                OCT     13000
                INDEX   STARIND
                CA      BESTI
                EXTEND
                MP      1/6TH
                TS      STARCODE
R51DSP          CAF     V01N70
                TC      BANKCALL
                CADR    GOFLASHR
                TC      GOTOP00H
                TC      +5
                TC      -5
                CAF     SIX
                TC      BLANKET
                TCF     ENDOFJOB
                TC      CHKSCODE
                TC      FALTON
                TC      R51DSP
                TC      INTPRET
                RTB     CALL
                        LOADTIME
                        PLANET
                SSP     LXA,1
                        S1
```

```
                        0
                        STARIND
                TIX,1
                        R51ST
                STCALL  STARSAV2        # 2ND STAR
                        R51ST +1
R51ST           STORE   STARSAV1        # 1ST STAR
# Page 757
                EXIT
                CS      MODREG          # IS THIS P54
                AD      OCT66
                EXTEND
                BZF     R51B            # YES
                TC      INTPRET
                CALL
                        R52             # AOP WILL MAKE CALLS TO SIGHTING
R51A            CALL                    # COMPUTE LOS IN SM FROM MARK DATA
                        SXTSM
                STORE   STARSAV2
                EXIT
                TC      BANKCALL
                CADR    MKRELEAS
                TC      INTPRET
                DLOAD   CALL
                        TSIGHT
                        PLANET
                EXIT
                CCS     STARIND
                TC      R51.4
                TC      INTPRET
                MXV     UNIT
                        REFSMMAT
                STORE   STARAD
                VLOAD
                        STARSAV2
                STOVL   6D
                        STARSAV1
                STOVL   12D
                        PLANVEC
                STCALL  STARAD +6
                        R54             # STAR DATA TEST
                BOFF    CALL
                        FREEFLAG
                        R51K
                        AXISGEN
                CALL
```

```
                        R55             # GYRO TORQUE
                CLEAR
                        PFRATFLG
R51K            EXIT
                CAF     OCT14
                TC      BANKCALL
                CADR    GOPERF1
                TC      GOTOP00H
                TC      +2              # V33
                TC      +3
                TC      BANKCALL
                CADR    P52C
# Page 758
                TC      INTPRET
                GOTO
                        ENDP50S
R51.4           TC      INTPRET
                MXV     UNIT
                        REFSMMAT
                STOVL   PLANVEC
                        STARSAV2
                STORE   STARSAV1
                SSP
                        STARIND
                        0
                GOTO
                        R51.3
R51B            TC      INTPRET
                CALL
                        R56
                GOTO
                        R51A
OCT66           OCT     00066
V01N70          VN      0170
1/6TH           DEC     .1666667

# Page 759
# NAME:         R55     GYRO TORQUE
# FUNCTION -- COMPUTE AND SEND GYRO PULSES
# CALLING SEQ -- CALL R55
# INPUT -- X,Y,ZDC -- REFSMMAT WRT PRESENT STABLE MEMBER
# OUTPUT -- GYRO PULSES
# SUBROUTINES -- CALCGTA, GOFLASH, GODSPR, IMUFINE, IMUPULSE, GOPERF1

                SETLOC  P50S
                BANK
```

```
                COUNT*  $$/R55
R55             STQ
                        QMIN
                CALL
                        CALCGTA
PULSEM          EXIT
R55.1           CAF     V06N93
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H
                TC      R55.2
                TC      R55RET
R55.2           TC      PHASCHNG
                OCT     00314
                CA      R55CDR
                TC      BANKCALL
                CADR    IMUPULSE
                TC      BANKCALL
                CADR    IMUSTALL
                TC      CURTAINS
                TC      PHASCHNG
                OCT     05024
                OCT     13000
R55RET          TC      INTPRET
                GOTO
                        QMIN
V06N93          VN      0693
R55CDR          ECADR   OGC
R54             =       CHKSDATA

# ROUTINE NAME -- CHKSDATA              DATE -- JAN 9, 1967
# MOD NO -- 0                           LOG SECTION -- P51-P53
# MODIFICATION BY -- LONSKE             ASSEMBLY --
#
# FUNCTIONAL DESCRIPTION -- CHECKS THE VALIDITY OF A PAIR OF STAR SIGHTINGS.  WHEN A PAIR OF ST
# BY THE ASTRONAUT THIS ROUTINE OPERATES AND CHECKS THE OBSERVED SIGHTINGS AGAINST STORED STAR
# COMPUTER TO INSURE A PROPER SIGHTING WAS MADE.  THE FOLLOWING COMPUTATIONS ARE PERFORMED --
#       OS1     =       OBSERVED STAR 1 VECTOR
#       OS2     =       OBSERVED STAR 2 VECTOR
#       SS1     =       STORED STAR 1 VECTOR
#       SS2     =       STORED STAR 2 VECTOR
#        A1     =       ARCCOS(OS1 - OS2)
# Page 760
#        A2     =       ARCCOS(SS1 - SS2)
#         A     =       ABS(2(A1 - A2))
```

```
# THE ANGULAR DIFFERENCE IS DISPLAYED FOR ASTRONAUT ACCEPTANCE.
#
# EXIT MODE --  1. FREEFLAG SET IMPLIES ASTRONAUT WANTS TO PROCEED
#               2. FREEFLAG RESET IMPLIES ASTRONAUT WANTS TO RECYCLE
#
# OUTPUT --     1. VERB 6,NOUN 3 -- DISPLAYS ANGULAR DIFFERENCE BETWEEN 2 SETS OF STA
#               2. STAR VECTORS FROM STAR CATALOG ARE LEFT IN 6D AND 12D.
#
# ERASABLE INITIALIZATION REQUIRED --
#               1. MARK VECTORS ARE STORED IN STARAD AND STARAD +6.
#               2. CATALOG VECTORS ARE STORED IN 6D AND 12D.
#
# DEBRIS --

                SETLOC  P50S1
                BANK
                COUNT*  $$/R50
CHKSDATA        STQ     SET
                        QMIN
                        FREEFLAG
CHKSAB          AXC,1                   # SET X1 TO STORE EPHEMERIS DATA
                        STARAD

CHKSB           VLOAD*  DOT*            # CAL. ANGLE THETA
                        0,1
                        6,1
                SL1     ACOS
                STORE   THETA
                BOFF    INVERT          # BRANCH TO CHKSD IF THIS IS 2ND PASS
                        FREEFLAG
                        CHKSD
                        FREEFLAG        # CLEAR FREEFLAG
                AXC,1   DLOAD           # SET X1 TO MARK ANGLES
                        6D
                        THETA
                STORE   18D
                GOTO
                        CHKSB           # RETURN TO CAL. 2ND ANGLE
CHKSD           DLOAD   DSU
                        THETA           # COMPUTE POS DIFF
                        18D
                ABS     RTB
                        SGNAGREE
                STORE   NORMTEM1
                SET     EXIT
                        FREEFLAG
```

```
                CAF     ZERO
                TC      BANKCALL
                CADR    CLEANDSP

                CAF     VB6N5
# Page 761
                TC      BANKCALL
                CADR    GOFLASH
                TCF     GOTOP00H
                TC      CHKSDA          # PROCEED
                TC      INTPRET
                CLEAR   GOTO
                        FREEFLAG
                        QMIN
CHKSDA          TC      INTPRET
                GOTO
                        QMIN
VB6N5           VN      605

# NAME -- CAL53A
# FUNCTION -- COARSE ALIGN THE IMU, IF NECESSARY
# CALLING SEQUENCE -- CALL CAL53A
# INPUT -- PRESENT GIMBAL ANGLES -- CDUX, CDUY, CDUZ
#          DESIRED GIMBAL ANGLES -- THETAD,+1,+2
# OUTPUT -- THE IMU COORDINATES AT STORED IN REFSMMAT
# SUBROUTINES -- 1.IMUCOARS, 2.IMUSTALL, 3CURTAINS

                COUNT   14/R50

CAL53A          CALL
                        S52.2           # MAKE FINAL COMP OF GIMBAL ANGLES
                RTB     SSP
                        RDCDUS          # READ CDUS
                        S1
                        1
                AXT,1   SETPD
                        3
                        4
CALOOP          DLOAD*  SR1
                        THETAD +3D,1
                PDDL*   SR1
                        4,1
                DSU     ABS
                PUSH    DSU
                        DEGREE1
                BMN     DLOAD
```

```
                        CALOOP1
                DSU     BPL
                        DEG359
                        CALOOP1
COARFINE        EXIT
                TC      PHASCHNG
                OCT     04024
                TC      BANKCALL
                CADR    IMUCOARS        # PERFORM COARSE ALIGNMENT
                TC      BANKCALL
                CADR    IMUSTALL        # REQUEST MODE SWITCH
# Page 762
                TC      CURTAINS
                TC      BANKCALL
                CADR    IMUFIN20
                TC      BANKCALL
                CADR    IMUSTALL
                TC      CURTAINS        # TEST FOR MALFUNCTION
                TC      INTPRET
                RTB     VLOAD
                        SET1/PDT
                        ZEROVEC
                STORE   GCOMP
                SET     GOTO
                        DRIFTFLG
                        FINEONLY
CALOOP1         TIX,1
                        CALOOP
FINEONLY        AXC,1   AXC,2
                        XSM
                        REFSMMAT
                CALL
                        MATMOVE
                GOTO
                        CAL53RET
MATMOVE         VLOAD*                  # TRANSFER MATRIX
                        0,1
                STORE   0,2
                VLOAD*
                        6D,1
                STORE   6D,2
                VLOAD*
                        12D,1
                STORE   12D,2
                RVQ
DEGREE1         DEC     46
```

```
DEG359          DEC     16338
                SETLOC  P50S
                BANK
RDCDUS          INHINT                  # READ CDUS
                CA      CDUX
                INDEX   FIXLOC
                TS      1
                CA      CDUY
                INDEX   FIXLOC
                TS      2
                CA      CDUZ
                INDEX   FIXLOC
                TS      3
                RELINT
                TC      DANZIG

# Page 763
# NAME:         GIMB
#
# FUNCTION:     DETERMINE AND COMPUTE THE DESIRED GIMBAL ANGLES TO BE USED FOR COARSE ALIGNMENT
#
# CALLING SEQUENCE:  CALL GIMB
#
# INPUT:        DESIRED IMU INERTIAL ORIENTATION VECTORS:  XSMD, YSMD, ZSMD
#
# OUTPUT:       GIMBAL ANGLES LEFT IN THETAD, +1, +2
#
# SUBROUTINES USED:  1.CDUTRIG 2.CALCSMSC 3.CALCGA

                SETLOC  P50S2
                BANK
                COUNT   14/INFLT

CALCSMSC        DLOAD   DMP
                        SINCDUY
                        COSCDUZ
                DCOMP
                PDDL    SR1
                        SINCDUZ
                PDDL    DMP
                        COSCDUY
                        COSCDUZ
                VDEF    VSL1
                STORE   XNB
                DLOAD   DMP
                        SINCDUX
```

```
                        SINCDUZ
                SL1
                STORE   26D
                DMP
                        SINCDUY
                PDDL    DMP
                        COSCDUX
                        COSCDUY
                DSU
                PDDL    DMP
                        SINCDUX
                        COSCDUZ
                DCOMP
                PDDL    DMP
                        COSCDUX
                        SINCDUY
                PDDL    DMP
                        COSCDUY
                        26D
                DAD     VDEF
                VSL1
                STORE   ZNB
                VXV     VSL1
                        XNB
                STORE   YNB
                RVQ

# NAME -- P51 -- IMU ORIENTATION DETERMINATION
# MOD. NO. 2    21 DEC 66                              LOG SECTION -- P51-P53
# Page 764
# MOD BY STURLAUGSON                                   ASSEMBLY SUNDISK REV15
#
# FUNCTIONAL DESCRIPTION
#       DETERMINES THE INERTIAL ORIENTATION OF THE IMU.  THE PROGRAM IS SELECTED BY I
#       ROUTINE IS CALLED TO COLLECT THE CDU COUNTERS AND SHAFT AND TRUNNION ANGLES F
#       THEN PROCESSED AS FOLLOWS.
#
#       1.  SEXTANT ANGLES ARE COMPUTED IN TERMS OF NAVIGATIONAL BASE COORDINATES.  I
#       TRUNNION ANGLES, RESPECTIVELY.  THEN,
#       _
#       V  = (SIN(TA)*COS(SA), SIN(TA)*SIN(SA), COS(TA))        (A COLUMN VECTOR)
#        NB
#       THE OUTPUT IS A HALF-UNIT VECTOR STORED IN STARM.
#
#       2.  THIS VECTOR IN NAV. BASE COORDS. IS THEN TRANSFORMED TO ONE IN STABLE MEM
#       _    T  T  T _
```

```
#       V = Q *Q *Q *V  ,       WHERE
#            1  2  3  NB
#
#            ( COS(IG)   0    -SIN(IG) )
#            (                         )                                        THE GIMBAL ANGL
#       Q  = (   0       1       0     ), IG= INNER GIMBAL ANGLE                THE CDU COUNTER
#        1   (                         )                                        ROT AND CDULOGI
#            ( SIN(IG)   0     COS(IG) )
#
#            ( COS(MG) SIN(MG)   0     )
#            (                         )
#       Q  = (-SIN(MG) COS(MG)   0     ), MG= MIDDLE GIMBAL ANGLE
#        2   (                         )
#            (   0       0       1     )
#
#            (   1       0       0     )
#            (                         )
#       Q  = (   0     COS(OG) SIN(OG) ), OG= OUTER GIMBAL ANGLE
#        3   (                         )
#            (   0    -SIN(OG) COS(OG) )
#
#       3.  THE STAR NUMBER IS SAVED AND THE SECOND STAR IS THEN SIMILARLY PROCESSED.
#
#       4.  THE ANGLE BETWEEN THE TWO STARS IS THEN CHECKED AT CKSDATA.
#
#       5.  REFSMMAT IS THEN COMPUTED AT AXISGEN AS FOLLOWS.
#                  _      _
#               LET S  AND S  BE TWO STAR VECTORS EXPRESSED IN TWO COORDINATE SYSTEMS, A AND B
#                    1      2
# Page 765
#               DEFINE,
#               _    _
#               U  = S
#                A    A1
#               _         _    _
#               V  = UNIT(S  x S  )
#                A         A1   A2
#               _    _   _
#               W  = U x V
#                A    A   A
#
#               AND,
#               _    _
#               U  = S
#                B    B1
#               _         _    _
```

```
#               V  = UNIT(S  x S  )
#                B         B1   B2
#               _    _   _
#               W  = U x V
#                B    B   B
#
#               THEN
#               _        _        _        _
#               X  = U  *U + V  *V + W  *W
#                     B1  A   B1  A   B1  A
#               _        _        _        _
#               Y  = U  *U + V  *V + W  *W              (REFSMMAT)
#                     B2  A   B2  A   B2  A
#               _        _        _        _
#               Z  = U  *U + V  *V + W  *W
#                     B3  A   B3  A   B3  A
#
# THE INPUTS CONSIST OF THE FOUR HALF-UNIT VECTORS STORED AS FOLLOWS
#               _
#               S   IN 6-11 OF THE VAC AREA
#                A1
#               _
#               S   IN 12-17 OF THE VAC AREA
#                A2
#               _
#               S   IN STARAD
#                B1
# Page 766      _
#               S   IN STARAD +6
#                B2
#
# CALLING SEQUENCE:
#
#       THE PROGRAM IS CALLED BY THE ASTRONAUT BY DSKY ENTRY.
#
# SUBROUTINES CALLED:
#
#       GOPERF3
#       GOPERF1R
#       GODSPR
#       IMUCOARS
#       IMUFIN20
#       R53
#       SXTNB
#       NBSM
#       MKRELEAS
```

```
#       CHKSDATA
#       MATMOVE
#
# ALARMS
#
#       NONE
#
# ERASABLE INITIALIZATION:
#
#       IMU ZERO FLAG SHOULD BE SET.
#
# OUTPUT
#
#       REFSMMAT
#       REFSMFLG
#
# DEBRIS
#
#       WORK AREA
#       STARAD
#       STARIND
#       BESTI
#       BESTJ

                SETLOC  P50S1
                BANK
                COUNT   14/P5153

P53             EQUALS  P51
P51             CS      IMODES30
                MASK    BIT9
                CCS     A
# Page 767
                TC      P51A
                TC      ALARM
                OCT     210
                TC      GOTOP00H
P51A            TC      BANKCALL
                CADR    R02ZERO

P51AA           CAF     PRFMSTAQ
                TC      BANKCALL
                CADR    GOPERF1
                TC      GOTOP00H        # TERM.
                TC      P51B            # V33
                TC      PHASCHNG
```

```
                OCT     05024
                OCT     13000
                CAF     P51ZERO
                TS      THETAD          # ZERO THE GIMBALS
                TS      THETAD +1
                TS      THETAD +2
                CAF     V6N22
                TC      BANKCALL
                CADR    GODSPRET
                CAF     V41K            # NOW DISPLAY COARSE ALIGN VERB 41
                TC      BANKCALL
                CADR    GODSPRET
                TC      BANKCALL
                CADR    IMUCOARS
                TC      BANKCALL
                CADR    IMUSTALL
                TC      CURTAINS        # CAGING OR BAD END
                TC      BANKCALL        # SCHEDULE IFAILOK AND IMUFINED TASKS, IN 5
                CADR    IMUFIN20        # AND 20 SECS. DIRECT RETURN AND NO STALL,
                TC      BANKCALL        # IF CAGING, BUT T4 WILL ZERO C/A ENABLE.
                CADR    IMUSTALL        # IF PUT TO SLEEP, IMUFINED WILL WAKE US
                TC      CURTAINS        # UP.
                TC      PHASCHNG
                OCT     05024
                OCT     13000
                TCF     P51AA           # COARSE ALIGN DONE:  RECYCLE FOR FINE

# Page 768
# DO STAR SIGHTING AND COMPUTE NEW REFSMMAT
P51B            TC      PHASCHNG
                OCT     00014
                TC      INTPRET
                SSP     SETPD
                        STARIND         # INDEX -- STAR 1 OR 2
                        0
                        0
                RTB     VLOAD
                        SET1/PDT
                        ZEROVEC
                STORE   GCOMP
                SET     CLEAR
                        DRIFTFLG        # ENABLE T4 COMPENSATION
                        TARG2FLG        # SHOW MARK IS STAR --- NOT LANDMARK
                EXIT
                CAF     BIT1
                TS      MARKINDX        # INITIALIZE FOR ONE MARK
```

```
P51C            TC      PHASCHNG
                OCT     05024
                OCT     13000
                TC      CHECKMM
                MM      53              # BACKUP PROGRAM
                TCF     P51C.1          # NOT P53
                TC      INTPRET
                CALL
                        R56
                GOTO
                        P51C.2
P51C.1          TC      INTPRET
                CALL
                        R53             # SIGHTING ROUTINE
P51C.2          CALL                    # COMPUTE LOS IN SM FROM MARK DATA
                        SXTSM
                PUSH
                SLOAD   BZE
                        STARIND
                        P51D
                VLOAD   STADR
                STORE   STARSAV2        # DOWNLINK
                GOTO
                        P51E
P51D            VLOAD   STADR
                STODL   STARSAV1
                        TSIGHT
                CALL
                        PLANET
                STORE   PLANVEC
# Page 769
P51E            EXIT
                TC      PHASCHNG
                OCT     05024
                OCT     13000
                TC      BANKCALL
                CADR    MKRELEAS        # ZERO MARKSTAT
                CCS     STARIND
                TCF     P51F            # STAR 2
                TC      PHASCHNG
                OCT     05024
                OCT     13000
                CAF     BIT1
                TS      STARIND
                TCF     P51C            # GO DO SECOND STAR
```

```
P51F            TC      PHASCHNG
                OCT     05024
                OCT     13000
                TC      INTPRET
                DLOAD   CALL
                        TSIGHT
                        PLANET
                STOVL   12D
                        PLANVEC
                STOVL   6D
                        STARSAV1
                STOVL   STARAD
                        STARSAV2
                STCALL  STARAD +6
                        CHKSDATA        # CHECK STAR ANGLES IN STARAD AND
                BON     EXIT
                        FREEFLAG
                        P51G
                TC      P51AA
P51G            CALL
                        AXISGEN         # COME BACK WITH REFSMMAT IN XDC
                AXC,1   AXC,2
                        XDC
                        REFSMMAT
                CLEAR   CALL
                        REFSMFLG
                        MATMOVE
                SET     GOTO
                        REFSMFLG
                        ENDP50S
PRFMSTAQ        =       OCT15
P51ZERO         =       ZERO
P51FIVE         =       FIVE
V6N22           VN      0622
V41K            VN      4100
SET1/PDT        CA      TIME1
# Page 770
                TS      1/PIPADT
                TCF     DANZIG

# Page 771
# SXTSM COMPUTES AN LOS VECTOR IN SM COORD FROM OCDU AND ICDU MARK DATA

                SETLOC  P50S3
                BANK
SXTSM           STQ
```

```
                        QMAJ
                LXC,1   DLOAD*
                        MARKSTAT
                        OD,1
                STORE   TSIGHT
                LXC,2   SLOAD*
                        STARIND
                        MKDNCDR,2
                LXC,2   VLOAD*
                        MPAC
                        0,1
                STORE   0,2
                DLOAD*
                        5,1
                STORE   5,2
                CALL
                        SXTNB           # COMPUTE LOS VECTOR FROM OCDU IN MKVAC
                LXA,1   INCR,1
                        MARKSTAT
                        2               # INCREMENT TO BASE ADR OF ICDU
                SXA,1   CALL
                        S1
                        NBSM            # TRANSFORM LOS TO SM
                GOTO
                        QMAJ
MKDNCDR         ECADR   MARKDOWN
                ECADR   MARK2DWN

# Page 772
# PROGRAM DESCRIPTION:  R53 -- SIGHTING MARK ROUTINE
# MOD. NO. 2                                          21 DEC 66
# MOD. BY STURLAUGSON
#
# FUNCTIONAL DESCRIPTION:
#
#       TO PERFORM A SATISFACTORY NUMBER OF SIGHTING MARKS FOR THE REQUESTING PROGRAM (OR ROUTI
#       CAN BE MADE ON A STAR OR LANDMARK.  WHEN THE CMC ACCEPTS A MARK IT RECORDS AND STORES 5
#       OCDUS) AND THE TIME OF THE MARK.
#
# CALLING SEQUENCE:
#
#       R53 IS CALLED AND RETURNS IN INTERPRETIVE CODE.  RETURN IS VIA QPRET.
#       THERE IS NO ERROR EXIT IN THIS ROUTINE ITSELF.
#
# SUBROUTINES CALLED
#
```

```
#       SXTMARK
#       OPTSTALL
#       GOFLASH
#
# ERASABLE INITIALIZATION:
#
#       TARGET FLAG -- STAR OR LANDMARK
#       MARKINDX -- NUMBER OF MARKS WANTED
#       STARIND -- INDEX TO BESTI OR BESTJ (STAR NUMBER)
#
# OUTPUT
#
#       MARKSTAT CONTAINS INDEX TO VACANT AREA WEHRE MARK DATA IS STORED
#       BESTI (INDEXED BY STARIND) CONTAINS STAR NUMBER SIGHTED.
#
# DEBRIS
#
#       MARKINDX CONTAINS NUMBER OF MARKS DESIRED

                SETLOC  RT53
                BANK

                COUNT   14/R53

R53             STQ     SET             # SET SIGHTING MARK FLAG
                        R53EXIT
                        R53FLAG
                EXIT
R53A            CA      MARKINDX        # NUMBER OF MARKS
                MASK    LOW3
                TC      BANKCALL
                CADR    SXTMARK
                TC      BANKCALL
                CADR    OPTSTALL
                TC      CURTAINS
                INDEX   MARKSTAT
                CCS     QPRET           # NUMBER OF MARKS ACTUALLY DONE
                TCF     R53B
                TCF     +2              # ZERO
                TCF     +1              # CCS HOLE
                CAF     ZERO            # HOUSEKEEP VAC AREA SAVE
                XCH     MARKSTAT        #       AND MARKSTAT
# Page 773
                CCS     A
                INDEX   A
                TS      0
```

```
                TCF     R53A
R53B            TC      CHECKMM
                MM      22
                TCF     +2
                TCF     R53D
                TC      CHECKMM
                MM      23
                TCF     R53C1
                TCF     R53D
R53C1           CAF     ZERO
                TC      BANKCALL
                CADR    CLEANDSP
R53C            CAF     V01N71
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H        # TERM.
                TCF     R53Z
                TC      R53C            # RECYCLE
R53Z            TC      CHKSCODE
                TC      FALTON
                TC      R53C
                CS      HIGH9
                MASK    STARCODE
                EXTEND
                MP      SIGHTSIX
                XCH     L
                INDEX   STARIND
                TS      BESTI
R53D            TC      INTPRET
R53OUT          SETGO
                        TERMIFLG        # SET TERMINATE FOR R52
                        R53EXIT
SIGHTSIX        =       SIX
V01N71          VN      0171

# ****** KEEP IN SAME BANK AS R51 AND R53 ********
CHKSCODE        CCS     STARCODE
                AD      NEG47
                CCS     A
                TC      Q               # SC < 0 OR SC > 50
                TCF     +2              # SC = + OR - 0
                TCF     +1              # 0 <= SC< 50
                INDEX   Q               # SC = 50
                TC      00002
NEG47           OCT     77730
```

```
# Page 774
# NAME -- S52.2
# FUNCTION -- COMPUTE GIMBAL ANGLES FOR DESIRED SM AND PRESENT VEHICLE
# CALL -- CALL S52.2
# INPUT -- X,Y,ZSMD
# OUTPUT -- OGC,IGC,MGC,THETAD,+1,+2
# SUBROUTINES -- CDUTRIG, CALCSMSC, MATMOVE, CALCGA

                SETLOC  S52/2
                BANK

                COUNT   13/S52.2
S52.2           STQ
                        QMAJ
                CALL
                        CDUTRIG
                CALL
                        CALCSMSC
                AXT,1   SSP
                        18D
                        S1
                        6D
S52.2A          VLOAD*  VXM
                        XNB     +18D,1
                        REFSMMAT
                UNIT
                STORE   XNB     +18D,1
                TIX,1
                        S52.2A
S52.2.1         AXC,1   AXC,2
                        XSMD
                        XSM
                CALL
                        MATMOVE
                CALL
                        CALCGA
                GOTO
                        QMAJ

# Page 775
# PROGRAM NAME:  SR52.1                          DATE:  DEC 20 1968
# MOD 1                                          LOG SEC:  P51-P53
# BY KEN VINCENT                                 ASSEMBLY:  SUNDISK REV 40
#
# FUNCTION
#
```

```
# TARG1 AND TARG2 FLAGS ARE LOOKED AT TO DETERMINE IF THE TARGET IS THE
# LEM, STAR, OR LANDMARK.  IN CASE OF LEM OR LMK, THE PRESENT TIME PLUS
# 2 SECONDS IS SAVED IN AOPTIME (ALIAS STARAD, +1).  IF THE LEM IS
# THE TARGET THEN CONIC UPDATES OF THE CSM AND LEM ARE MADE TO
# THE TIME IN AOPTIME.  THE UNIT OF THE DIFFERENCE OF LEM AND CSM
# POSITION VECTORS BECOMES THE REFERENCE SIGHTING VECTOR USED IN THE
# COMMON PART OF THE THIS PROGRAM.
#
# IN THE CASE OF LANDMARK, THE CSM IS UPDATED CONICALLY.  THE RADIUS
# VECTOR FOR THE LANDMARK IS OBTAINED FROM LALOTORV.  BOTH OF THESE ARE
# FOUND FOR THE TIME IN AOPTIME.  THE UNIT OF THE DIFFERENCE BETWEEN
# THE LANDMARK AND CSM RADIUS VECTORS BECOMES THE REFERENCE SIGHTING
# VECTOR FOR THE COMMON PART OF THIS ROUTINE.
#
# IF A STAR IS THE TARGET, THE PROPER STAR IS OBTAINED FROM THE CATALOG
# AND THIS VECTOR BECOMES THE REFERENCE SIGHTING VECTOR.
#
# THE COMMON PART OF THIS PROGRAM TRANSFORMS THE REFERENCE SIGHTING
# VECTOR INTO STABLE MEMBER COORDINATES.  IT READS THE IMU-CDUS AND USES
# THIS DATA IN A CALL TO CALCSXA.  ON RETURN FROM CALCSXA A TEST IS
# MADE TO SEE IF THE TRUNNION ANGLE IS GREATER THAN  90DEG OR 38DEG.
# MADE TO SEE IF THE TRUNNION ANGLE IS GREATER THAN 90DEG. OR 50DEG.
#
# CALLING SEQUENCE
#
#       L+4     RETURN WHEN SHAFT OR TRUNION NOT WITHIN 5 DEG OF DESIRED
#       L       TC      BANKCALL
#       L+1     CADR    SR52.1
#       L+2     ERROR RETURN    TRUNNION GREATER THAN 90 DEG.
#       L+3     ERROR RETURN    TRUNNION GREATER THAN 50 DEG
#       L+4     NORMAL RETURN
#
# OUTPUT
#
#       SAC:    SINGLE PREC, 2'S COMP, SCALED AT HALF REVS -- SHAFT ANGLE DESIRED.
#       PAC:    SINGLE PREC, 2'S COMP, SCALED AT EIGHTH REVS -- TRUNNION ANGLE DESIRED.
#
# INITIALIZATION
#
#       IF TARG1FLG =1 THEN TARGET IS LEM -- NO OTHER INPUT REQUIRED.
#
#       IF TARG1FLG =0 AND TARG2FLG =0 THE TARGET IS STAR, STARIND SHOULD
#       0 OR 1 DENOTING BESTI OR BESTJ RESPECTIVELY AS STAR CODE.  STAR CODES
#       ARE 6 TIMES STAR NUMBER.
#
#       IF TARG1FLG =0 AND TARG2FLG =1 THEN TARGET IS LANDMARK.  SETT ROUTINE
```

```
#       LALOTORV FOR INPUT REQUIREMENTS.  HERE FIXERAD=1 FOR CONSTANT EARTH
#       RADIUS
#
# DEBRIS
#
#       WORK AREA
#       STARAD -- STAR+5 (STAR IS DESIRED LOS IN STABLE MEMBER COORDINATES)

                COUNT*  $$/SR521
# Page 776
                SETLOC  SR52/1
                BANK

SR52.1          TC      MAKECADR
                TS      QMIN
                TC      INTPRET
                RTB     DAD
                        LOADTIME
                        1.3SECDP
                STORE   AOPTIME
                BON     BON
                        TARG1FLG
                        LEM52
                        TARG2FLG
                        LMK52
                GOTO
                        STAR52
LEM52           DLOAD
                        AOPTIME
                STCALL  TDEC1
                        LEMCONIC
                VLOAD
                        RATT
                GOTO
                        LMKLMCOM
LMK52           BON     DLOAD
                        ADVTRK
                        ADVTRACK
                        AOPTIME
                CALL
                        LALOTORV
                VLOAD
                        ALPHAV
LMKLMCOM        STODL   STAR
                        AOPTIME
                STCALL  TDEC1
```

```
                        CSMCONIC
                VLOAD   VSU
                        STAR
                        RATT
                UNIT    GOTO
                        COM52
STAR52          SSP     LXA,1
                        S1
                        0
                        STARIND
                TIX,1
                        ST52ST
                VLOAD   GOTO
                        STARSAV2
# Page 777
                        COM52
ST52ST          VLOAD
                        STARSAV1
COM52           MXV     UNIT
                        REFSMMAT
                STORE   STAR
                SETPD   CALL
                        0
                        CDUTRIG         # COMPUTES SINES AND COSINES FOR CALCSXA
                CALL                    #       NOW EXPECT TO SEE THE CDU ANGLES.
                        CALCSXA
                BOFF    EXIT
                        CULTFLAG
                        TRUN38
                TC      SR52E1
TRUN38          DLOAD   DSU
                        PAC
                        38TRDEG
                BPL     DLOAD
                        SR52E22
                        PAC
                DSU     BPL
                        20DEGSMN
                        SR52E3
SR52E22         EXIT
                TC      SR52E2
SR52E3          EXIT
                INCR    QMIN
SR52E2          INCR    QMIN
SR52E1          CA      QMIN
                TC      SWCALL
```

```
38TRDEG         2DEC    .66666667       # CORRESPONDS TO 50 DEGS IN TRUNION

1.3SECDP        2DEC    130

20DEGSMN        DEC     -07199
                DEC     -0

# Page 778
# THE ADVTRACK ROUTINE IS USED TO COMPUTE AN OPTICS LOS VECTOR TO
# A POINT ON THE GROUND TRACK 60 DEGREES FORWARD OF THE LOCAL VERTICAL
# OF AN ADVANCED ORBIT A SPECIFIED NUMBER OF REVOLUTIONS FROM NOW.

                SETLOC  26P50S
                BANK
ADVTRACK        SETPD
                        0
                VLOAD   PUSH            # INITIALIZE FOR RP-TO-R
                        UNITZ           # UZ VEC IN PD 0-5
                RTB     PUSH            # TIME IN PD 6-7
                        LOADTIME
                STCALL  AOPTIME         # TIME ALSO IN AOPTIME FOR CSMCONIC
                        RP-TO-R         # GET MOON ROTATION VEC IN REF
                STODL   STAR
                        AOPTIME         # PICK UP TIME
                STCALL  TDEC1           # UPDATE STATE TO TIME
                        CSMCONIC
                VLOAD   VXV
                        VATT
                        RATT
                UNIT
                STOVL   24D             # SAVE -UNIT(VxR) FOR 2ND ROTATION
                        RATT
                UNIT    VCOMP
                SETPD   PUSH            # PUSH LOS=-UNIT(RVEC) PD 0-5
                        0
                EXIT
                CA      LANDMARK
                MASK    SEVEN           # GET NUMBER OF ADVANCE PERIODS
                EXTEND
                MP      BIT11           # GET N/16
                XCH     L
                INDEX   FIXLOC
                TS      30D             # TEMP STORE N/16
                TC      INTPRET
                SLOAD   DMP
                        30D
```

```
                        MPERIOD
                STCALL  AOPTIME         # ROTATE ANG ABOUT UR
                        ROTA
                VLOAD
                        24D             # PICK UP 2ND ROTATION AXIS
                STODL   STAR
                        DP1/6
                DSU
                        AOPTIME         # 2ND RAT ANGLE = 60 - A
                STCALL  AOPTIME
                        ROTA            # GO ROTATE 2ND TIME
                VLOAD
# Page 779
                        0
                STCALL  STAR            # STORE FINAL LOS IN STAR
                        COM52           # RETURN TO SR52.1

ROTA            DLOAD   SIN
                        AOPTIME
                PDVL    VXV             # PUSH 1/2SIN(A) PD 6-7
                        STAR            #       UR VEC
                        0               #       LOS
                VXSC    VSL2            # 1/2SIN(A)(URXLOS) PD 6-11
                PDVL    DOT
                        STAR
                        0
                VXSC    VSL2
                        STAR
                PDDL    COS             # 1/2(UR . LOS)UR 12-17
                        AOPTIME
                PDVL    BVSU            # PUSH 1/2COS(A) 18-19
                        12D
                        0
                VXSC    VSL1            # UP 18-19
                VAD     VAD             # UP 12-17 UP 6011
                UNIT    SETPD
                        0
                PUSH    RVQ

DP1/6           2DEC    .16666666

MPERIOD         2DEC    .047619         # APPROX LUNAR ROT ANG IN 2HRS x 16

# Page 780
# NAME -- S52.3
# FUNCTION --   XSMD= UNIT(YSMD x ZSMD)
```

```
#               YSMD= UNIT(V X R)
#               ZSMD= UNIT(-R)
# CALL --       DLOAD   CALL
#                       TALIGN
#                       S52.3
# INPUT --      TIME OF ALIGNMENT IN MPAC
# OUTPUT --     X,Y,ZSMD
# SUBROUTINES -- CSMCONIC

                SETLOC  P50S2
                BANK

                COUNT   15/S52.3
S52.3           STQ
                        QMAJ
                STCALL  TDEC1
                        CSMPREC
                SETPD
                        0
                VLOAD   VCOMP
                        RATT
                UNIT
                STOVL   ZSMD
                        VATT
                VXV     UNIT
                        RATT
                STORE   YSMD
                VXV     UNIT
                        ZSMD
                STCALL  XSMD
                        QMAJ

# Page 781
# PROGRAM DESCRIPTION:  R56 -- ALTERNATE LOS SIGHTING MARK ROUTINE
#
# FUNCTIONAL DESCRIPTION
#
#       TO PERFORM SIGHTING MARKS FOR THE BACK-UP ALIGNMENT PROGRAMS (P53,P54).  THE
#       COORDINATES (OPTICS) OF THE ALTERNATE LINE OF SIGHT HE MUST USE FOR THIS ROUT
#       ENTER IN RESPONSE TO THE FLASHING V50 N25 R1-XXXXX THE CMC STORES THE THREE I
#       IN N92.
#
# CALLING SEQUENCE
#
#       CALL
#               R56
```

```
#
# SUBROUTINES CALLED
#
#       A PORTION OF SXTMARK (VAC.AREA SEARCH)
#       GOFLASH
#       GOPERF1
#
# ERASABLE INITIALIZATION
#
#       STARIND:  INDEX TO STAR NUMBER
#
# OUTPUT
#
#       MARKSTAT:  INDEX TO VAC.AREA WHERE OUTPUT IS STORED.
#       BESTI (INDEXED BY STARIND) CONTAINS STAR NUMBER.
#       ICDU AND OCDU ANGLES IN VAC. AREA AS FOLLOWS:
#               VAC +2  CDUY
#               VAC +3  CDUS
#               VAC +4  CDUZ
#               VAC +5  CDUT
#               VAC +6  CDUX

                COUNT*  $$/R56
                SETLOC  P50S3
                BANK
R56             STQ     EXIT
                        R53EXIT
                CAF     V06N94B
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H        # TERM.
                TC      R56A            # PROCEED:  ANGLES OK
                TC      -5              # ENTER:  NEW ANGLES
R56A            TC      BANKCALL
                CADR    SXTMARK +2      # INHIBIR EXT VB ACT AND FIND VAC AREA

                CAF     ZERO
                TC      BANKCALL
                CADR    CLEANDSP

R56A1           CAF     VB53            # DISPLAY V53 REQUESTING ALTERNATE MARK
                TC      BANKCALL
# Page 782
                CADR    GOMARK2
                TCF     GOTOP00H        # V34:  TERMINATE
                TCF     R56A1           # V33:  DONT PROCEED -- JUST ENTER TO MARK
```

```
                TC      INTPRET
                DLOAD
                        MRKBUF1 +3
                STODL   SAC
                        MRKBUF1 +5
                STORE   PAC
                EXIT
                INHINT
                EXTEND
                DCA     TIME2
                INDEX   MARKSTAT
                DXCH    0
                CA      CDUY            # ENTER:  THIS IS A BACKUP SYSTEM MARK
                INDEX   MARKSTAT
                TS      2
                CA      SAC
                INDEX   MARKSTAT
                TS      3
                CA      CDUZ
                INDEX   MARKSTAT
                TS      4
                CA      PAC
                INDEX   MARKSTAT
                TS      5
                CA      CDUX
                INDEX   MARKSTAT
                TS      6
                RELINT
                TC      CLEARMRK        # ENABLE EXTENDED VERBS
                CAF     OCT16
                TC      BANKCALL
                CADR    GOPERF1
                TC      GOTOP00H        # TERM.
                TCF     R56B            # PROCEED:  MARK COMPLETED
                TCF     R56A    +2      # RECYCLE:  DO ANOTHER MARK -- LIKE REJECT.
R56B            TC      BANKCALL
                CADR    R53C1
VB53            VN      05300           # ALTERNATE MARK VERB
V06N94B         VN      00694
                SETLOC  P50S
                BANK

PLANET          STORE   TSIGHT
                STQ     CALL
                        QMIN
                        LOCSAM
```

```
                VLOAD
# Page 783
                        VEARTH
                STOVL   OD
                        VSUN
                STOVL   VEARTH
                        OD
                STORE   VSUN
NOSAM           EXIT
                CS      HIGH9
                MASK    STARCODE
                EXTEND
                MP      SIGHTSIX
                XCH     L
                INDEX   STARIND
                TS      BESTI
                CCS     A
                TCF     NOTPLAN
                CAF     VNPLANV
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H
                TC      +2
                TC      -5
                TC      INTPRET
                VLOAD   VXSC
                        STARSAV3
                        1/SQR3
                UNIT    GOTO
                        CORPLAN
NOTPLAN         CS      A
                AD      DEC227
                EXTEND
                BZMF    CALSAM1
                INDEX   STARIND
                CA      BESTI
                INDEX   FIXLOC
                TS      X1
                TC      INTPRET
                VLOAD*  GOTO
                        CATLOG,1
                        CORPLAN
CALSAM1         TC      INTPRET
                LXC,1   DLOAD*
                        STARIND
                        BESTI,1
```

```
                LXC,1   VLOAD*
                        MPAC
                        STARAD  -228D,1
CORPLAN         VAD     UNIT
                        VEL/C
                GOTO
# Page 784
                        QMIN
DEC227          DEC     227
VNPLANV         VN      0688
1/SQR3          2DEC    .57735021
```

Uses 1/PIPADT 156, 26P50S 65, A 80, A1 229, ADVTRK 127, ALPHAV 177, ALT 157, AOPTIME 181, BESTI 145, BESTJ 145, CDUS 80, CDUT 80, CDUX 80, CDUY 80, CDUZ 80, CODE 140, COMPUTER 115, COSCDU 150, COSCDUX 150, COSCDUY 150, COSCDUZ 150, COUNT 142, CULTFLAG 107, CULTRIX 186, DESOPTS 159, DESOPTT 159, DIFF 226, DISPLAYS 59, DRIFTFLG 101, DSPTEM1 154, EBANK 80, ERADFLAG 99, FIXLOC 140, FREEFLAG 97, GCOMP 169, I 206, IGC 186, IMODES30 163, IT 185, L 80, LANDMARK 190, LAT 157, LATITUDE 191, LONG 157, LOWSUPER 67, LUNAFLAG 107, MARK2DWN 224, MARKDOWN 239, MARKINDX 145, MARKSTAT 163, MGC 186, MM 226, MODE 145, MODREG 154, MPAC 145, N 206, NORMTEM1 154, OGC 186, OPTCADR 163, OPTIND 161, OPTION2 157, P50S 61, P50S1 61, P50S2 63, P50S3 63, PAC 186, PFRATFLG 105, PLANVEC 183, PRFTRKAT 115, Q 80, QMAJ 145, QMIN 186, QPRET 85, R53EXIT 224, R53FLAG 97, REFSMFLG 107, REFSMMAT 172, RESTART 57, REVS 206, RLS 175, RM 239, RNDVZFLG 97, RT53 61, RVEC 188, S1 85, S2 85, S52/2 61, SAC 186, SAVE 191, SAVQR52 183, SAX 186, SINCDU 150, SINCDUX 150, SINCDUY 150, SINCDUZ 150, SR52/1 61, STAR 186, STARAD 186, STARCODE 150, STARIND 145, STARM 148, STARSAV1 185, STARSAV2 185, STARSAV3 239, STATE 138, SWSAMPLE 163, TARG1FLG 99, TARG2FLG 99, TC 169, TEMP 191, TERMIFLG 121, THETA 148, THETAD 157, TIME1 80, TIME2 80, TRACKFLG 101, TRUNFLAG 97, TRUNION 190, TSIGHT 183, UPDATFLG 99, US 185, V 229, VEARTH 186, VEL 226, VEL/C 224, VFLAG 107, VMOON 186, VN 159, VSUN 186, W 183, X1 85, XDC 186, XNB 186, XSM 186, XSMD 148, YDC 186, YNB 186, YSMD 148, Z 80, ZDC 186, ZNB 186, and ZSMD 148.

3.5.8 lunar and solar ephemerides subroutines

1194 ⟨*lunar and solar ephemerides subroutines* 1194⟩≡ (857a 2739)
⟨*Page CM0785* 1195⟩

1195 ⟨*Page CM0785* 1195⟩≡ (1194)

```
# Page 785
# LUNAR AND SOLAR EPHEMERIDES SUBROUTINES
#
# FUNCTIONAL DESCRIPTION
#
#       THESE SUBROUTINES ARE USED TO DETERMINE THE POSITION AND VELOCITY
#       VECTORS OF THE SUN AND THE MOON RELATIVE TO THE EARTH AT THE
#       SPECIFIED GROUND ELAPSED TIME INPUT BY THE USER.
#
#       THE POSITION OF THE MOON IS STORED IN THE COMPUTER IN THE FORM OF
#       A NINTH DEGREE POLYNOMIAL APPROXIMATION WHICH IS VALID OVER A 15
#       DAY INTERVAL BEGINNING SHORTLY BEFORE LAUNCH.  THEREFORE THE TIME
#       INPUT BY THE USER SHOULD FALL WITHIN THIS 15 DAY INTERVAL.
##      The 9th-degree polynomial spoken of here is a pad load, meaning
##      that it is not actually hardcoded into the software.  Additional
##      information about calculating the polynomial can be found on the
##      <a href="http://nassp.sourceforge.net/wiki/Lunar_Ephemeris_Polynomials">
##      <b>Orbiter</b> NASSP wiki</a>, as well as information about calculation
##      of the <a href="http://nassp.sourceforge.net/wiki/Solar_Ephemeris">
##      solar ephemerides</a>.
#
#       LSPOS COMPUTES THE POSITION VECTORS OF THE SUN AND THE MOON.
#
#       LUNPOS COMPUTES THE POSITION VECTOR OF THE MOON.
#
#       LUNVEL COMPUTES THE VELOCITY VECTOR OF THE MOON.
#
#       SOLPOS COMPUTES THE POSITION VECTOR OF THE SUN.
#
# CALLING SEQUENCE
#
#       DLOAD   CALL
#               TIME            GROUND ELAPSED TIME
#               SUBROUTINE      LSPOS OR LUNPOS OR LUNVEL OR SOLPOS
#
# INPUT
#
#       1) SPECIFIED GROUND ELAPSED TIME IN CS x B-28 LOADED IN MPAC.
#
#       2) TIMEMO -- TIME AT THE CENTER OF THE RANGE OVER WHICH THE LUNAR
#       POSITION POLYNOMIAL IS VALID IN CS x B-42.
#
#       3) VECOEM -- VECTOR COEFFICIENTS OF THE LUNAR POSITION POLYNOMIAL
#       LOADED IN DESCENDING SEQUENCE IN METERS/CS**N x B-2
#
```

```
#       4) RESO -- POSITION VECTOR OF THE SUN RELATIVE TO THE EARTH AT
#       TIMEMO IN METERS x B-38
#
#       5) VESO -- VELOCITY VECTOR OF THE SUN RELATIVE TO THE EARTH AT
#       TIMEMO IN METERS/CS x B-9
#
#       6) OMEGAES -- ANGULAR VELOCITY OF THE VECTOR RESO AT TIMEMO IN
#       REV/CS x B+26
#
#       ALL EXCEPT THE FIRST INPUT ARE INCLUDED IN THE PRE-LAUNCH
#       ERASABLE DATA LOAD.
#
# OUTPUT -- LSPOS
# Page 786
#
#       1) 2D OF VAC AREA CONTAINS THE POSITION VECTOR OF THE SUN RELATIVE
#       TO THE EARTH AT TIME INPUT BY THE USER IN METERS x B-38.
#
#       2) MPAC CONTAINS THE POSITION VECTOR OF THE MOON RELATIVE TO THE
#       EARTH AT TIME INPUT BY THE USER IN METERS x B-29
#
# OUTPUT -- LUNPOS
#
#       MPAC CONTAINS THE POSITION VECTOR OF THE MOON RELATIVE TO THE
#       EARTH AT THE TIME INPUT BY USER IN METERS x B-29
#
# OUTPUT -- LUNVEL
#
#       MPAC CONTAINS THE VELOCITY VECTOR OF THE MOON RELATIVE TO THE
#       EARTH AT THE TIME INPUT BY THE USER IN METERS/CS x B-7
#
# OUTPUT -- SOLPOS
#
#       MPAC CONTAINS THE POSITION VECTOR OF THE SUN RELATIVE TO THE EARTH
#       AT TIME INPUT BY THE USER IN METERS x B-38.
#
# SUBROUTINES USED
#
#       NONE
#
# REMARKS
#
#       THE VAC AREA IS USED FOR STORAGE OF INTERMEDIATE AND FINAL RESULTS
#       OF COMPUTATIONS.
#
#       S1, X1, AND X2 ARE USED BY THESE SUBROUTINES.
```

```
#
#       PRELAUNCH ERASABLE DATA LOAD ARE ONLY ERASABLE STORAGE USED BY
#       THESE SUBROUTINES.
#
#       RESTARTS DURING OPERATION OF THESE SUBROUTINES MUST BE HANDLED BY
#       THE USER.

                BANK    36
                SETLOC  EPHEM
                BANK

                COUNT*  $$/EPHEM
                EBANK=  END-E7
LSPOS           AXT,2                   # COMPUTES POSITION VECTORS OF BOTH THE
                        RESA            # SUN AND THE MOON.  THE POSITION VECTOR
                AXT,1   GOTO            # OF THE SUN IS STORED IN 2D OF THE VAC
                        RES             # AREA.  THE POSITION VECTOR OF THE MOON
                        LSTIME          # IS STORED IN MPAC.
LUNPOS          AXT,1   GOTO            # COMPUTES THE POSITION VECTOR OF THE MOON
                        REM             # AND STORES IT IN MPAC.
                        LSTIME
# Page 787
LUNVEL          AXT,1   GOTO            # COMPUTES THE VELOCITY VECTOR OF THE MOON
                        VEM             # AND STORES IT IN MPAC.
                        LSTIME
SOLPOS          STQ     AXT,1           # COMPUTES THE POSITION VECTOR OF THE SUN
                        X2              # AND STORES IT IN MPAC.
                        RES
LSTIME          SETPD   SR
                        0D
                        14D
                TAD     DCOMP
                        TEPHEM
                TAD     DCOMP
                        TIMEMO
                SL      SSP
                        16D
                        S1
                        6D
                GOTO
                        X1
RES             PUSH    DMP             #                                       PD- 2
                        OMEGAES
                PUSH    COS             #                                       PD- 4
                VXSC    PDDL            #                                       PD- 8
                        RESO
```

```
                SIN     PDVL            #                                       PD-1
                        RESO
                PUSH    UNIT            #                                       PD-1
                VXV     UNIT
                        VESO
                VXV     VSL1            #                                       PD-1
                VXSC    VAD             #                                       PD-0
                VSL1    GOTO            # RES IN METERS x B-38 IN MPAC.
                        X2
RESA            STODL   2D              # RES IN METERS x B-38 IN 2D OF VAC.    PD- 
REM             AXT,1   PDVL            #                                       PD- 
                        54D
                        VECOEM
REMA            VXSC    VAD*
                        OD
                        VECOEM +60D,1
                TIX,1   VSL2            # REM IN METERS x B-29 IN MPAC.
                        REMA
                RVQ
VEM             AXT,1   PDDL            #                                       PD- 
                        48D
                        NINEB4
                PUSH    VXSC            #                                       PD- 
                        VECOEM
VEMA            VXSC
                        OD
# Page 788
                STODL   4D              #                                       PD- 
                DSU     PUSH            #                                       PD- 
                        ONEB4
                VXSC*   VAD
                        VECOEM +54D,1
                        4D
                TIX,1   VSL2            # VEM IN METERS/CS x B-7 IN MPAC.
                        VEMA
                RVQ
NINEB4          2DEC    9.0 B-4

ONEB4           2DEC    1.0 B-4
```

Uses A 80, COMPUTER 115, COUNT 142, EBANK 80, END-E7 244, EPHEM 65, IT 185, MPAC 145, N 206, OMEGAES 177, RANGE 179, RESO 175, S1 85, SR 80, TEPHEM 172, TIMEMO 175, VECOEM 175, VESO 177, X1 85, and X2 85.

3.5.9 p61-p67 code

1199 ⟨*p61-p67 code* 1199⟩≡ (857a 2767)
⟨*Page CM0789* 1200⟩

1200 ⟨*Page CM0789* 1200⟩≡ (1199)

```
# Page 789
# PROGRAM:      P61
# MOD NO.:      0       MAR. 13, 1967
# MOD BY:       R. HIRSCHKOP
# MOD NO: 1     MOD BY:  RR BAIRNSFATHER        DATE: 22 JUN 67         RESTARTS
# MOD NO: 2     MOD BY:  RR BAIRNSFATHER        DATE: 17 JAN 68         COLOSSUS GSOP
# MOD NO: 3     MOD BY:  RR BAIRNSFATHER        DATE:  8 MAY 68         DELETE CMSM N
# FUNCTION:     TO CALCULATE AND DISPLAY EMS INITIALIZATION DATA
# CALLING SEQUENCE:  BY V37
# EXIT:         TO P62
# SUBROUTINE CALLS:  S61.1, S61.3, GOFLASH, FLAGUP, R02BOTH
# ERASABLE INITIALIZATION:
#       EMSALT (-29) M          .05G ALTITUDE ABOVE FISCHER ELLIPSOID   PAD LOADED.
#       ALFAPAD /180            HYPERSONIC CM TRIM ANGLE OF ATTACK      PAD LOADED
# OUTPUT:       THE FOLLOWING REGISTERS ARE WRITTEN IN FOR USE BY DISPLAYS
#               GMAX    100 GMAX (-14) G,S      MAXIMUM ACCELERATION
#               VPRED   (-7) M/CS               PREDICTED VELOCITY AT 400K FT
#               GAMMAEI (GAMMA/360              PREDICTED GAMMA    AT 400K FT
#               RTGO    THETAH/360              RANGE ANGLE TO SPLASH FROM EMSALT
#               VIO     (-7) M/CS               INERTIAL VELOCITY AT       EMSALT
#               TTE     (-28) CS                TIME TO                    EMSALT
#               LAT(SPL) /360                   TARGET LOCATION
#               LNG(SPL) /360                   TARGET LOCATION
#               HEADSUP (0)                     +1 = LIFT DOWN, -1 = LIFT UP
# DEBRIS:       SEE SUBROUTINES.

                BANK    26
                SETLOC  P60S
                BANK

                EBANK=  AOG

                COUNT*  $$/P61

P61             CA      BIT14           # EXTENDED VERB SHOULD BE FREE THIS CLOSE
                TS      EXTVBACT        # TO V37
                                        # LOCK OUT EXTENDED VERBS SO CAN USE TFF
                                        # ROUTINES.  EXT VERB ERASE IS USED

                CS      ONE             # REMOVE IF HEADSUP EVER ON UPLINK DATA
                TS      HEADSUP         # PRELOAD

                TC      S61.1           # CHECK STATE VECTOR AND IMU ORIENTATION
                                        # RV 50GENRET. DOES PHASCHNG, GROUP 4.
```

```
                CA      V06N61          # LAT(SPL)      LNG(SPL)        HEADSUP
                                        # XXX.XX DEG    XXX.XX DEG      XXXXX.
                TC      BANKCALL
                CADR    GOFLASHR
                TC      GOTOP00H
# Page 790
                TC      P61.4
                TC      -5

P61.3           TC      PHASCHNG
                OCT     00014

                TC      ENDOFJOB

P61.4           ZL
                CCS     HEADSUP         # C(HEADSUP)= +1/-1
                CA      BIT14           # IF HEADSUP POS,ROLLC =180 DEG.(LIFT DWN)
                NOOP                    # IF HEADSUP NEG,ROLLC =0 (LIFT UP)
                DXCH    ROLLC           # ROLLC IS USED BY S62.3: GIM ANG AT .05G

                TC      INTPRET
NEWRNVN         DLOAD
                        PIPTIME         # SAVE TIME OF RN,VN TO DETERMINE IF AN
                STCALL  MM              # UPDATE HAS OCCURRED.
                        STARTEN1        # INITIALIZE
                VLOAD
                        RN
                STORE   RONE
                UNIT
                STOVL   URONE
                        VN
                STORE   VONE
                VXV     UNIT
                        URONE
                STORE   UNI
DUMPP61         DLOAD   DSU
                        MM              # INITIAL VALUE OF PIPTIME
                        PIPTIME
                BMN     CALRB
                        NEWRNVN         # UPDATED... GO TRY AGAIN
                        S61.2           # GET DISPLAY DATA FOR N60 AND N63
                                        # AND RETURN IN BASIC, BELOW.
P61.1           TC      CLEARMRK
                CA      V06N60          # GMAX           VPRED           GAMMAEI
                                        # XXX.XX G       XXXXX. FPS      XXX.XX DEG
                TC      BANKCALL
```

```
                CADR    GOFLASH

                TC      GOTOP00H
                TC      P61.2           # PROCEED
                TC      -5

P61.2           TC      INTPRET         # CORRECT TTE FOR TIME LAPSE DURING
                                        # ABOVE DISPLAY.
                RTB     DSU
                        LOADTIME        # CURRENT TIME.
# Page 791
                        MM              # PIPTIME FOR RONE & VONE.
                DAD
                        TTE1            # NEGATIVE OF FREE FALL TIME.
                STORE   TTE             # DECREMENTED

                EXIT

                CA      V06N63          # RTGO          VIO             TTE
                                        # XXXX.X NM     XXXXX. FPS      XXBXX M,S
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H
                TC      +2
                TC      P61.2           # REDO

#               .... THEN FALL INTO P62
# Page 792

# PROGRAM:      P62
# MOD NO.:      0       MAR. 13, 1967
# MOD BY:       R. HIRSCHKOP
# MOD NO:  1    MOD BY:  RR BAIRNSFATHER        DATE: 21 MAR 67
# MOD NO:  2    MOD BY:  RR BAIRNSFATHER        DATE: 22 JUN 67         RESTARTS.
# MOD NO:  3    MOD BY:  RR BAIRNSFATHER        DATE: 17 JAN 68         COLOSSUS GSOP
# MOD NO:  4    MOD BY:  RR BAIRNSFATHER        DATE:  8 MAY 68         MOVE START OF
# FUNCTION:     1) TO NOTIFY CREW WHEN GNC SYSTEM IS PREPARED FOR CM/SM SEPARATION.
#               2) TO ORIENT THE CM TO THE CORRECT ATTITUDE FOR ATMOSPHERIC ENTRY.
# CALLING SEQUENCE:  BY V37 OR DIRECTLY FROM P61
# EXIT:         TO P63
# ERASABLE INITIALIZATION:
#       ALFAPAD                                         LEFT BY PAD LOAD
#       LADPAD                                          LEFT BY PAD LOAD
#       LODPAD                                          LEFT BY PAD LOAD
#       LAT(SPL)        (MAY BE CHANGED BELOW)          LEFT BY DSKY, VIA P61
#       LNG(SPL)        (MAY BE CHANGED BELOW)          LEFT BY DSKY, VIA P61
```

```
#       HEADSUP         (MAY BE CHANGED BELOW)          LEFT BY DSKY, VIA P61
# SUBROUTINE CALLS:  NEWMODEX, S61.1, CM/DAPIC, CM/DAPON, R02BOTH, GOPERF1, GOFLASH, GODSPR.

                COUNT*  $$/P62

                TC      NEWMODEX                # MODE CHANGE IF CAME FROM P61.
                MM      62                      # MODE CHANGE AUTOMATIC VIA V 37.
                CA      ONE
                TS      DNLSTCOD

P62             TC      S61.1                   # CHECK STATE VECTOR AND IMU ORIENTATION.

                TC      INTPRET
                SSP     RTB
                        POSEXIT
                        P62.3                   # CALCULATE DESIRED .05G GIMBAL ANGLES.
                                                # WITHOUT DISPLAY.
                        CM/DAPIC                # START CM/POSE AND BODY RATE CALC

                                                # DOES 2PHSCHNG, OCT 40116, OCT 05024, OCT 1300
                                                # CM/DAPIC SETS EBANK = EBAOG
                                                # AND RETURNS IN BASIC TO P62.2.
P62.2           EXTEND
                DCA     POSECADR                # CONTINUE WITH CM/POSE AFTER AV G.
                DXCH    AVEGEXIT

                CAF     OCT41                   # REQUEST SEPARATION
                TC      BANKCALL
                CADR    GOPERF1R
                TC      GOTOP00H
                TC      +3                      # PROCEED
# Page 793
                                                # NOTE:  NODOFLAG WILL BE SET IN CM/DAPON. ***
                TC      -5                      # ENTER
                TC      P61.3                   # FOR PHASCHNG AND ENDOFJOB

        +3      TC      POSTJUMP
                CADR    CM/DAPON                # DISABLE RCS DAP, ENABLE ENTRY DAP AND
                                                # DO ATTITUDE HOLD.

                                                # WILL IDLE UNTIL CM/POSE DOES ONE UPDATE.
                                                # CM/DAPON DOES NO PHASCHNG.

P62.1           CA      V06N61                  # LAT(SPL)      LNG(SPL)        HEADSUP
                                                # XXX.XX DEG    XXX.XX DEG      0000X.
```

```
                                        # TERMINATE ATTITUDE HOLD.  SET UP CO
                                        # ROLLC, ALFACOM, BETACOM.  BEGIN MAN
                                        # ENTRY ATTITUDE.

                TC      BANKCALL
                CADR    GOFLASH
                TC      -3
                TC      +2
                TC      -5

                TC      PHASCHNG
                OCT     04024           # USE ENTRYVN FOR DISPLAY BELOW.
                                        # EBANK WAS SET IN CM/DAPON TO EBAOG

                CCS     HEADSUP         # C(HEADSUP) = +/- 1
                CA      BIT14           # IF HEADSUP POS, ROLLC=180 DEG (LIFT
                NOOP                    # IF HEADSUP NEG, ROLLC=0 DEG (LIFT U
                TS      ROLLC
                CA      ALFAPAD         # NOMINAL ALFATRIM PAD LOADED, NEG. N
                ZL
                DXCH    ALFACOM         # SET ALFACOM = ALFA TRIM, BETACOM=0

                CA      ONE             # PERMITS EXDAP2 TO CHANGE FLAG TO +0
                TS      P63FLAG         # AS INDICATOR.  STARTS UP P63.

                CA      V06N22          # SET UP DISPLAY FOR CDU DESIRED VALU
                TS      ENTRYVN         # FROM ENTRY ATTITUDE CALC, THAT IS
                                        # ALREADY GOING.
                TC      UPFLAG          # TURN ON ENTRY DISPLAY
                ADRES   ENTRYDSP        # ENTRYDSP = 92D BIT 13 FLAG 6
SKIP
# Page 794
                CS      CMDAPMOD        # GO DIRECTLY TO P63 IF BODY ATTITUDE
                MASK    ONE             # IS SUCH THAT THE DELAY TASK: WAKEP6
                EXTEND                  # WILL BE OMITTED.
                BZF     P63.1           # DISABLE GRP 4, GO TO ENDOFJOB.
                                        # (I.E., CONTINUE IF CMDAPMOD = -1, O
                TC      P63

                                        # PUT JOB TO SLEEP UNTIL VEHICLE MANE
                                        # REDUCED ALFA TO +/-45 DEG. CONSIDER
                                        # 65 DEG (25 DEG IF ALFA NEG) TO ALFA
                                        # OCCUR AT 3 DEG/SEC, AND TERMINATE P
                                        # TIME.

                                        # TASK WAKEP62 IS CALLED FROM ENTRY D
```

```
WAKEP62         CA      PRIO13
                TC      NOVAC
                EBANK=  AOG
                2CADR   P63

                TC      TASKOVER

                                        # EACH 2 SEC, CALCULATE GIMBAL ANGLES FOR ENTRY
                                        # DITIONS THAT WILL HOLD IF REORIENTATION WERE
                                        # AT PRESENT RN, VN.  COME HERE FROM CM/POSE AN
                                        # IN KEPLER PHASE OF ENTRY.

P62.3           SSP     GOTO            # SET RETURN ADDRESS SO THAT ROUTINE
                        QPRET           # GOES DIRECTLY TO ENTRY GUIDANCE EXIT
                        ENDEXIT         # THAT DOES ENTRY DISPLAY, GRP 5.
                        S62.3           # PUT DESIRED CDU VALUES IN CPHI'S FOR
                                        # N22 DISPLAY.

# Page 795
#       P63
# PROGRAM:      P63
# MOD NO:       0       MAR. 13, 1967
# MOD BY:       R. HIRSCHKOP
# MOD NO: 1     MOD BY: RR BAIRNSFATHER         DATE: 22 JUN 67         RESTARTS
# MOD NO: 2     MOD BY: RR BAIRNSFATHER         DATE: 14 JUL 67         REVISED RESTARTS
# FUNCTION:     1) TO INITIALIZE THE ENTRY EQUATIONS.
#               2) TO CONTINUE TO HOLD THE CM TO THE CORRECT ATTITUDE WITH RESPECT TO THE ATMOS
#                  THE ONSET OF ENTRY DECELERATION.  ROLL ANGLE IS LIFT UP/DOWN AS SPECIFIED BY
#               3) TO SENSE .05G.
# CALLING SEQUENCE:  DIRECTLY FROM P62
# EXIT:         TO ENDOFJOB
# SUBROUTINE CALLS:  NEWMODEX, GODSPR

                COUNT*  $$/P63

P63             TC      NEWMODEX
                MM      63

                                        # ARRIVE WITH EBANK = AOG.

                CA      ENTCADR         # CONTINUE AT STARTENT AFTER CM/POSE.

                                        # AT END OF STATEMENT, CHANGE ADDRESS IN GOTOAD
                                        # TO CONTINUE AT SCALEPOP THEREAFTER.

                TS      POSEXIT
```

```
                CA      V06N64                  # G             VI              R TO
                                                # XXX.XX G      XXXX. FPS       XXXX
                TS      ENTRYVN                 # FOR DISPLAY CALL IN OVERNOUT

                CS      ONE                     # IN CASE FLAG IS LEFT AT +1 BY DAP.
                TS      P63FLAG                 # -1 ASSURES THAT EXO-ATM DAP WILL NO
                                                # CALL P63 OUT OF SEQUENCE IN P66.

                TC      PHASCHNG                # THIS IS REQUIRED TO PRESERVE CLEAND
                OCT     00004                   # RETURN IN EVENT OF AN EXTENDED VERI

                TC      BANKCALL                # FLUSH 'N22' DISPLAY, IF ON, (OMIT
                CADR    CLEANDSP                # DISPLAY DURING 'STARTENT' PASS.)

P63.1           TC      PHASCHNG
                OCT     00004                   # DISABLE.  DISPLAY RESTARTED VIA ENT

                TC      ENDOFJOB

V06N60          VN      0660
V06N61          VN      0661
V06N63          VN      0663
# Page 796
V06N64          VN      0664
ENTCADR         CADR    STARTENT

                EBANK=  RTINIT                  # TO CARRY OVER INTO ENTRY STEERING.
POSECADR        2CADR   CM/POSE

# Page 797
# PROGRAM:      P64
# MOD NO:       1       SEPT. 19, 1967
# MOD BY:       R. HIRSCHKOP
# MOD NO: 2     MOD BY: RR BAIRNSFATHER         DATE: 8 MAY 68          REVISED COMME
# FUNCTION:     1.  TO START ENTRY GUIDANCE AT .05G SELECTING ROLL ATTITUDE, CONSTANT
#                   DRAG THRESHOLD, KA, WHICH ARE KEYED TO THE .05G POINT.
#               2.  SELECT FINAL PHASE P67 IF V < 27000 FPS WHEN .2G OCCURS.
#               3.  ITERATE FOR UP-CONTROL SOLUTION P65 IF V > 27000 FPS AND IF ALTIT
#                   LEVEL CONDITIONS ARE SATISFIED.  ENTER P65 WHEN CONSTANT DRAG CON
#                   AS PREDICTED TO WITHIN 25 NM OF DESIRED RANGE.
#               4.  SELECT FINAL PHASE  P67  IF NO UP-CONTROL SOLUTION EXISTS WITH VE
# CALLING SEQUENCE:  BY RTB FROM REENTRY CONTROL
# EXIT:         BACK TO REENTRY CONTROL.
# SUBROUTINE CALLS:  NEWMODEX
```

```
                BANK    25
                SETLOC  P60S1
                BANK

# THIS DISPLAY IS CALLED EACH PASS THROUGH STEERING.  RESTART PROTECTION IS VIA STEERING.

                COUNT*  $$/P64

P64             TC      NEWMODEX                # ENTER VIA RTB WHEN .05G IS EXCEEDED.
                MM      64
                CA      V06N74                  # ROLLC         VI              D
                                                # XXX.XX DEG    XXXXX. FPS      XXX.XX G
                TS      ENTRYVN                 # DISPLAY VIA OVERNOUT.

                TC      DANZIG                  # ... AND CONTINUE IN INITROLL ...

V06N74          VN      0674

# Page 798
# PROGRAM:      P65
# MOD NO:  0    MOD BY:  RR BAIRNSFATHER        DATE:  17 JAN 68        COLOSSUS GSOP ADDITION.
# FUNCTION:     TO CONTINUE ENTRY GUIDANCE, USING THE UP-CONTROL PHASE TO STEER TO A CONTROLLED
#               CONDITION.  THIS PHASE TERMINATES  A) IF D < Q7 FPSS, GOTO TO P66.
#                                                  B) IF RDOT NEG, AND IF V < VL +500 FPS, GO T
# CALLING SEQUENCE:  BY RTB FROM REENTRY CONTROL
# EXIT:         BACK TO REENTRY CONTROL, OR TO ENDOFJOB.
# SUBROUTINE CALLS:  NEWMODEX

                COUNT*  $$/P65

P65             TC      NEWMODEX                # ENTER VIA RTB WHEN RANGE < 25 N M OF
                MM      65                      # TARGET.

                CA      PRIO13
                TC      NOVAC
                EBANK=  ENTRYVN
                2CADR   P65.1

                TC      2PHSCHNG                # 2 PHASE CHG REQUIRED TO PREVENT RE-
                OCT     00554                   # STARTING FLASHING DISPLAY TWICE.
                OCT     10035                   # 4.55 SPOT AND SERVICER, HERE.
                TC      INTPRET
                SSP     RTB
                        GOTOADDR                # CHANGE ENTRY MODE TO UPCONTRL.
                        UPCONTRL
                        REFAZE10                # GO HERE TO REESTABLISH ENTRY SEQUENCER.
```

```
                                                # AND CONTINUE AT UPCONTRL...

P65.1           TC      DOWNFLAG
                ADRES   ENTRYDSP                # ENTRYDSP = 92D BIT 13 FLAG 6

                CA      V16N69                  # ROLLC         DL (Q7)         VL
                TC      BANKCALL                # XXX.XX DEG    XXX.XX G        XXXXX
                CADR    GOFLASHR
                TC      -3                      # NODOFLAG IS SET ...
                TC      +3
                TC      -5
                TC      P61.3                   # EST. GRP 4 FOR DISPLAY AND DO ENDOF
                                                # IF PROCEED, CONTINUE
                TC      UPFLAG
                ADRES   ENTRYDSP                # ENTRYDSP = 92D BIT 13 FLAG 6

                TC      P63.1                   # DISABLE GRP 4, START UP ENTRY DISPL
                                                # N06V68 VIA OVERNOUT, AS USED IN P64
V16N69          VN      1669

# Page 799
# PROGRAM:      P66
# MOD NO: 0     MOD BY: RR BAIRNSFATHER         DATE: 17 JAN 68         COLOSSUS GSOP
# FUNCTION:     KEEP CM ATTITUDE IN TRIM TO THE RELATIVE VELOCITY VECTOR.  ENTRY GUID
#               ROLL COMMANDS UNTIL DRAG BUILDS UP TO Q7+0.5 FPSS.
# CALLING SEQUENCE:  VIA RTB FROM REENTRY CONTROL.
# EXIT:         BACK TO REENTRY CONTROL.
# SUBROUTINE CALLS:  NEWMODEX

                COUNT*  $$/P66

P66             TC      NEWMODEX                # ENTER VIA RTB WHEN D < Q7 FPSS
                MM      66

                CA      V06N22                  # OGA           IGA             MGA
                                                # XXX.XX DEG    XXX.XX DEG      XXX.X
                TC      P66END                  # IN CASE CAME FROM P65, GO TO DISABL
                                                # AND SET ENTRYDSP TO DO DISPLAY VIA
                                                # OVERNOUT.

                                                # ... AND CONTINUE AT KEP2

# Page 800
# PROGRAM:      P67
# MOD NO:       0       MAR. 16, 1967
# MOD BY:       R. HIRSCHKOP
```

```
# FUNCTION:     TO TERMINATE STEERING WHEN THE CM VELOCITY WRT EARTH = 1000 FT/SEC
# CALLING SEQUENCE:
# EXIT:         TO P00H
# SUBROUTINE CALLS:  GOFLASH

# THIS DISPLAY IS CALLED EACH PASS THROUGH STEERING.  RESTART PROTECTION IS VIA STEERING.

                COUNT*  $$/P67

P67             TC      NEWMODEX                # ENTER VIA RTB
                MM      67
                CA      V06N66                  # ROLLC         XRNGERR         DNRNGERR
                                                # XXX.XX DEG    XXXX.X NM       XXXX.X NM
P66END          TS      ENTRYVN                 # DISPLAY VIA OVERNOUT.

                TC      UPFLAG                  # (IN CASE CAME FROM P65.  ENTRY DISPLAY
                ADRES   ENTRYDSP                # WILL FLUSH FLASHING DISP.  IF STILL ON)
                                                # BIT 13 FLAG 6
KILLGRP4        TC      PHASCHNG                # DISABLE GRP4, IN CASE CAME FROM HUNTEST.
                OCT     00004                   # (COME TO KILLGRP4 VIA RTB, RET TO CALLER)

                TC      DANZIG                  # ... AND CONTINUE AT PREDICT3 ...

V06N66          VN      0666

                BANK    26
                SETLOC  P60S2
                BANK

P67.1           CA      V16N67                  # RTOGO         LAT             LONG
                                                # XXXX.X NM     XXX.XX DEG      XXX.XX DEG
                TC      BANKCALL
                CADR    GOFLASH
                TC      +3                      # EFFECTIVE GOTOP00H
                TC      +2
                TC      P67.1                   # REDO

                CS      THREE                   # TURN OFF ENTRY DAP
                INHINT
                MASK    CM/FLAGS                # CM/DSTBY, GAMDIFSW
                TS      CM/FLAGS
                RELINT
                EXTEND
                DCA     SERVCAD2

# Page 801
```

```
                DXCH    AVEGEXIT

                TCF     GOTOPOOH

# Page 802
P67.2           VLOAD   CLEAR                   # CALC PRESENT LAT, LONG, ALT.
                        RN
                        ERADFLAG                # USE PAD RAD FOR ALT. (NOT SEEN ANYW
                STODL   ALPHAV
                        PIPTIME                 # USE TIME OF RN
                CLEAR   CALL
                        LUNAFLAG
                        LAT-LONG
P67.3           RTB                             # ENTRY EXIT THAT OMITS DISPLAY.
                        SERVNOUT

V16N67          VN      1667
OCT41           =       33DEC
SERVCAD2        =       SERVCAD1

# Page 803
# SUBROUTINE NAME:      S61.1
# MOD NO:       0                                       DATE:           21 FEB 67
# MOD BY:       RR BAIRNSFATHER                         LOG SECTION:    P61-P67
# MOD NO:       1       MOD BY: RR BAIRNSFATHER         DATE:           22 JUN 67
# FUNCTIONAL DESCRIPTION:       CALLED BY BOTH P61 AND P62
#       FIRST, TEST TO SEE IF  AVERAGEG  IS ON.  IF NOT, UPDATE THE STATE VECTOR TO P
#       AND TURN ON  AVERAGEG  AT THAT TIME, AND CONTINUE.  OTHERWISE CONTINUE:  SEE
#       WITHIN 30 DEG OF VAR.  IF YES, EXIT SUBROUTINE S61.1.  IF SO, SEE IF -Y AXIS
#       30 DEG OF VAR.  IF YES, DISPLAY ALARM:  01427   IMU REVERSED.
#                       IF NO, DISPLAY ALARM:   01426   IMU UNSATISFACTORY.
#       IN EITHER OF THESE LAST 2 CASES, WAIT 10 SEC AND THEN EXIT SUBROUTINE S61.1.
#
# REMARK:       THERE WILL BE A SHORT 10 SEC DELAY IF AN ALARM EXIT IS TAKEN.  THE DE
#               AS SHORT AS CAN BE MADE, BUT IS ARBITRARY SINCE IT DEPENDS ON THE AGE
#
# CALLING SEQUENCE:     CALL
#                               S61.1
#
#                       C(MPAC) UNSPECIFIED
#                       PUSHLOC UNSPECIFIED
#
# SUBROUTINES CALLED:   LOADTIME, CSMPREC, TPAGTREE,
#                       WAITLIST, JOBSLEEP, JOBWAKE, PREREAD, ALARM, GODSPR, BANKCALL
#
# NORMAL EXIT MODES:    RVQ
```

```
#
# ALARMS:       01426   IMU UNSATISFACTORY
#               01427   IMU REVERSED
#
# OUTPUT:       POSSIBLE ALARMS
#               POSSIBLY TDEC1, RATT, VATT, RN, VN
#
# ERASABLE INITIALIZATION REQUIRED:
#       AVEGFLAG                AVERAGEG ON OR OFF                              LEFT BY SERVICE
#       PIPTIME   (-28) CS      TIME OF PIPA UPDATE                             LEFT BY READACC
#       RN        (-29) M       STATE VECTOR                                    LEFT BY AVERAGE
#       VN        (-7) M/CS     STATE VECTOR                                    LEFT BY AVERAGE
#       REFSMMAT  (-1)          .5 REF TO SM MATRIX                             LEFT BY LAST IM
#
# DEBRIS:       QPRET
#               POSSIBLY PIPTIME1, RATT, VATT, TDEC1, RN1, VN1, QTEMP, X1       IF UPDATED
#               PUSH LIST LOCS USED BY CSMPREC

                EBANK=  AOG             # FOR 60GENRET, S61DT
                BANK    26
                SETLOC  P60S3
                BANK

                COUNT*  $$/S61.1

S61.1           EXTEND
                QXCH    60GENRET        # SAVE RET ADDR IN EB 6
                TC      BANKCALL
                CADR    R02BOTH
                TC      INTPRET
# Page 804
                BON     CALRB
                        AVEGFLAG        # IS AVERAGEG ON
                        S61.1A          # YES
                        MIDTOAV2        # GET FUTURE STATE VECTOR SOON AS CAN

                CA      MPAC +1         # RETURN INHINTED ***
                TS      S61DT           # FOR RESTART.
                TC      WAITLIST
                EBANK=  DVCNTR
                2CADR   S61.1C

                TC      PHASCHNG
                OCT     40434
                TC      ENDOFJOB
```

```
S61.1C          CA      PRIO13
                TC      FINDVAC
                EBANK=  AOG
                2CADR   S61.1A  -1

                EXTEND
                DCA     SERVCAD1        # HE WHO START AVERAGEG MUST SERVICE
                DXCH    AVEGEXIT        # THE EXIT.

                TC      2PHSCHNG
                OCT     00454
                OCT     00415

                CA      EBENTRY         # SET EB= 7 FOR PREREAD.
                TS      EBANK

                TC      POSTJUMP
                CADR    PREREAD         # PREREAD DOES TC TASKOVER.

                TC      INTPRET
S61.1A          BOVB    VLOAD
                        TCDANZIG        # TURN OFF OVFIND, IF ON
                        VN              # VN    (-7) M/CS
                VXV     MXV
                        RN              # RN    (-29) M
                        REFSMMAT        # .5 UNIT MATRIX
                UNIT    DLOAD
                        MPAC +3         # GET COS(THETA)/2
                BMN     DAD
                        S61.1B          # DO TEST ON -YSM
                        C(30)LIM        # = 1.0 -.5 COS(30)
                BOVB    RTB
                        RETRN1
                        RETRN3
# Page 805
S61.1B          DCOMP   DAD
                        C(30)LIM        # = 1.0 - .5 COS(30)
                BOVB    EXIT
                        RETRN2

RETRN3          TC      ALARM
                OCT     01426           # IMU UNSATISFACTORY
                TC      RETRN2 +2

RETRN2          TC      ALARM
                OCT     01427           # IMU REVERSED
```

```
        +2      CAF     V05N09
                TC      BANKCALL
                CADR    GODSPR          # DO DISPLAY
                CA      10SECS
                TC      BANKCALL
                CADR    DELAYJOB

RETRN1          TC      60GENRET

                EBANK=  DVCNTR
SERVCAD1        2CADR   SERVEXIT

C(30)LIM        2DEC    .566985         # = 1.0 - .5 COS(30)

10SECS          DEC     1000            # 1000 CS
60SECDP         2DEC    6000 B-28       # 6000 CS

# Page 806
# PROGRAM NAME:         S61.2                   DATE:           14 FEB 67
# MOD NO:       1                               LOG SECTION:    P61-P67
# MOD BY:       NORTH / BAIRNSFATHER
# MOD NO: 2     MOD BY: NORTH/BAIRNSFATHER      DATE: 11 MAY 67         ADD 2ND ITER FOR ERAD A
# MOD NO: 3     MOD BY: RR BAIRNSFATHER         DATE: 21 NOV 67         VARIABLE MU ADDED.
# MOD NO: 4     MOD BY: RR BAIRNSFATHER         DATE: 21 MAR 68         DIFFERENT EARTH/MOON SC
#
# FUNCTIONAL DESCRIPTION:  CALLED IN P61.  PROVIDES DISPLAYS FOR NOUNS  N60  AND  N63 .
#       PROGRAM CALCULATES ENTRY DISPLAY OF MAXIMUM ACCELERATION EXPECTED  (GMAX)  AND ALSO THE
#       INERTIAL VELOCITY (VPRED) AND ENTRY ANGLE  (GAMMAEI)  THAT WILL OBTAIN AT 400K FT ABOVE
#       ELLIPSOID.  PROGRAM ALSO CALCULATES A SECOND DISPLAY RELATIVE TO THE  EMSALT  ABOVE FIS
#       AND CONSISTS OF RANGE TO SPLASH FROM NOW  (RTGO) , PREDICTED INERTIAL VELOCITY  (VIO) ,
#       GO FROM NOW  (TTE) .
#
# CALLING SEQUENCE:     CALL
#                               S61.2
#                       C(MPAC) UNSPECIFIED
#                       PUSHLOC WILL BE SET TO ZERO.
#
# SUBROUTINES CALLED:   TFFCONIC, CALCTFF, TFF/TRIG, FISHCALC, GETERAD, VGAMCALC
#
# NORMAL EXIT MODES:    RTB, P61.1
#
# ALARMS:       NONE
#
# OUTPUT:       THE FOLLOWING REGISTERS ARE WRITTEN IN FOR USE BY DISPLAYS
#               GMAX    100 GMAX (-14) G,S      MAXIMUM ACCELERATION
```

```
#               VPRED   (-7) M/CS               PREDICTED VELOCITY AT 400K FT
#               GAMMAEI GAMMA/360               PREDICTED GAMMA    AT 400K FT
#                                               FOR TM, DP(GAMMAEI) = (GAMMAEI, RTGO)
#               RTGO    THETAH/360              RANGE ANGLE TO SPLASH FROM EMSALT
#               VIO     (-7) M/CS               INTERTIAL VELOCITY AT      EMSALT
#               TTE     (-28) CS                TIME TO                    EMSALT
#               PUSHLOC = 0
#               CONIC PARAMETERS STORED IN VAC AREA (SEE TFF SUBROUTINES)
#
# ERASABLE INITIALIZATION REQUIRED:
#               RONE    (-29) M                 STATE VECTOR
#               VONE    (-7) M/CS               STATE VECTOR
#               URONE   UR/2
#               UNI     (-1)                    UNIT NORMAL V*R
#               THETAH  THETAH/360              RANGE ANGLE
#               UNITW   (0)                     UNIT POLAR VECTOR
#               EMSALT  (-29) M                 EMS INTERFACE ALTITUDE
#                                               ORBITAL REENTRY: 284843 FT., LUNAR RE
#
# DEBRIS:       QPRET,
#               ALL PDL LOCATIONS ABOVE 12D, INCLUDING X1,X2,S1,S2
#               ALSO PDL+0 ... PDL+5, WHERE INITIAL PUSHLOC = PDL

# Page 807
# THE FOLLOWING PUSH LIST LOCATIONS HAVE BEEN RESERVED FOR TFF ROUTINES AND ARE REPEA
# OF COURSE FOR S61.2 USAGE, EARTH ORIGIN SCALING IS USED.
#
#                               BELOW   E:  IS USED FOR EARTH ORIGIN SCALE
#                                       M:  IS USED FOR MOON ORIGIN SCALE
#
#       RTERM   =       18D             TERMINAL RADIUS M       E:  (-29)       M:  (
#       NRTERM  =       16D             TERMINAL RADIUS M       E:  (-29+NR)
#                                                               M:  (-27+NR)
#       RMAG1   =       12D             PRESENT RADIUS M        E:  (-29)       M:  (
#       NRMAG   =       32D             PRESENT RADIUS M        E:  (-29+NR)
#                                                               M:  (-27+NR)
#       SDELF/2                         SIN(THETA) / 2
#       CDELF/2 =       14D             COS(THETA) / 2
#       TFFX    =       34D             X, ARGUMENT OF SERIES T(X)
#       TFFTEM  =       36D             ARG FOR TRANSFER ANGLE CALCULATION
#       TFFNP   =       28D             LC P M                  E:  (-38+2NR)   M:  (
#       TFF/RTMU=       30D             1/SQRT(MU)              E:  (17)        M:  (
#       TFFVSQ  =       20D             -(VN.VN/MU)     1/M     E:  (20)        M:  (

# Page 808
                BANK    34
```

```
                SETLOC  P60S2
                BANK

                COUNT*  $$/S61.2
                                        # PDL LEFT AT ZERO BY TARGETING

S61.2           DLOAD   DSU
                        EMSALT
                        290KFT
                BPL     DLOAD
                        LUNENT
                        1/RTMU          # ESTABLISH MU FOR ORBITAL ENTRIES
CALLCON         CALL
                        TFFCONIC        # FILL VAC AREA WITH CONIC PARAMETERS

                DLOAD   CALL
                        RTRIAL          # 1ST GUESS AT TERMINAL RADIUS  (-29)
                        CALCTFF         # SAVES MPAC IN RTERM           (18D)

                CALL                    # CALC SDELF/2, CDELF/2
                        TFF/TRIG        # RETURN WITH S(THETA) IN MPAC

                CALL                    # GET FISCHER RADIUS            (-29) M
                        FISHCALC        # ANS IN MPAC AND IN ERADM

                DAD     CALL
                        EMSALT
                        CALCTFF         # SAVES MPAC IN RTERM           (18D)

                DCOMP                   # NEGATIVE AS IN COUNTDOWN
                STORE   TTE1            # DECR TTE FROM BASB TTE1.  (RESTART)
                                        # DNLIST AND DSKY WILL USE TTE.
                STCALL  TTE             # LET MISS CONTRL DECR BY ELAPSED TIME
                                        # TTE= TIME FROM NOW TO EMSALT +FISCHER

                        TFF/TRIG        # S(THETA) IN MPAC ON RETURNING
                                        # AND THETA= RANGE FROM NOW TO EMSALT

                CALL
                        FISHCALC
                CALL
                        VRCALC
                CALL
                        DISPTARG
                CALL
                        DISPTARG
```

```
                STCALL  RTGO
# Page 809
                        VGAMCALC

                DMP                     # MPAC = GAMMA
                                        # PDL0 HAS VGAM.
                BDDV    DAD
                        VEMSCON         # -HS D 180/PI (-14)
                        0               # VGAM FROM PDL0
                STODL   VIO             # PREDICTED VELOCITY AT EMSALT.

                                        # GAMMA AND VGAM AT 300K FT ARE REQUIRED BY (
                                        # ALGORITHM.

                        ERADM           # EARTH RADIUS FROM GETERAD (-29) M
                                        # = FISCHER RADIUS (-29)

                DAD
                        300KFT          # M (-29)
                STCALL  RTERM           # TERMINAL RADIUS M (-29)

                        PREVGAM         # VGAMCALC WITH NEW RTERM

                                        # VBAR = (V(FPS) - 36KF/S) / 20 F/S
# GMAX = (4/(1 + 4.8 VBARSQ))(GAM - 6.05 - 2.4 VBARSQ) - 10(L/D - .3) + 10      ASSUM

# GMAXCALC
                PDDL    DSU             # GAM TO PDL2
                        0               # VGAM IS IN PDL0 (-7)
                        36KFT/S         # (-7) M/CS
                DDV     DSQ
                        20KFT/S         # (-6) M/CS
                STORE   0               # VBARSQ (-2) TO PDL0

                DMP     DAD
                        KR1
                                        # GAM, POS DOWN, FROM PDL2
                DAD     DMP
                        -6.05DEG
                        KR2
                PDDL                    # XCH PDL+0 FOR VBARSQ (-2)
                DDV     DAD
                        KR4
                        DP2(-4)
                BDDV
                                        # NUM FROM PDL+0
```

```
                DAD     BPL
                        KR3
                        +3
                DLOAD
                        HI6ZEROS
                STODL   GMAX            # 100 GMAX (-14)
# Page 810
# DISPLAY USES GMAX AS SP, SO LO WORD IS WRITTEN OVER BY VPRED.
                        ERADM           # = FISCHER RADIUS (-29) M
                DAD     CALL            # 2 ND ITERATION FOR FISCHER RADIUS
                        400KFT
                        CALCTFF         # ESTABLISH TRANSFER ANGLE DATA.
                CALL
                        TFF/TRIG        # GET SIN, COS DELF
                CALL
                        FISHCALC        # GET CORRESPONDING FISCHER RADIUS.

                DAD     LXA,2           # SAVE HI-WORD FOR DOWNLIST.
                        400KFT          # M (-29)
                        RTGO            # (RANGE ANGLE FROM EMSALT) / 360
                STCALL  RTERM
                        PREVGAM         # VGAMCALC WITH NEW RTERM

                DCOMP   SXA,2           # HI-WORD OF EACH ON DOWNLIST.
                        MPAC +1
                STODL   GAMMAEI         # CONIC GAMMA/360 AT 400K FT.   (HI-WORD)
                                        # CONIC RTGO/360 FROM EMSALT   (LOW-WORD)
                                        # FOR TM, DP(GAMMAEI) = (GAMMA, RTGO) / 360

                                        # VGAM FROM PDL+0 (-7)
                STADR
                STORE   VPRED           # CONIC VELOCITY AT 400K FT

                RTB
                        P61.1
                                        # PDL BACK TO ZERO.

LUNENT          DLOAD   GOTO
                        1/RTMUE         # ESTABLISH MU FOR LUNAR TYPE ENTRIES
                        CALLCON
290KFT          2DEC    88392.0 B-29

KTETA1          2DEC*   .421844723 E2 B-14* # 110 2PI/16384(163.84)

36KFT/S         2DEC    109.728 B-7     # (-7) M/CS = 36 KFT/S (-7)
```

```
20KFT/S         2DEC    121.92 B-7      # (-6) M/CS = 2 20KFT/S (-7)

KR1             2DEC    -.026666667     # = -2.4 4 / 360

-6.05DEG        2DEC    -.016805556     # = -6.05 / 360

KR2             2DEC    .54931641       # = (360/4) 100 (-14) = 9000 B-14

KR3             2DEC    1000 B-14       # = 100 (10.0) (-14) G,S
# Page 811
                                        # ASSUMES L/D = 0.3, BANK =0.
RTRIAL          2DEC    6460097.18 B-29 # RPAD +264643 FT =21 194 545 FT
                                        # RPAD DEFINED AS 20 909 901.57 FT =6 373 336
400KFT          2DEC    121920 B-29     # METERS

# 300KFT        2DEC    91440 B-29      # (-29) M

# EMSALT        2DEC    86759.2 B-29    # 284643 FT (-29) M     (ORBITAL REENTRY)

# EMSALT        2DEC    90657 B-29      # 297431 FT (-29) M     (LUNAR REENTRY)

KR4             2DEC    .833333333

300KFT          EQUALS  MINPERE
VEMSCON         2DEC    -.0389676 B-14  # = -HS D / 2 PI (-14)  M SQ / CS SQ

                                        # = -16369      .05G    32.2    .3048   .3048

# Page 812
# SUBROUTINE NAME:  FISHCALC    (USED BY S61.2)         DATE:           01.21.67
# MOD NO: 0                                             LOG SECTION:    P61-P67
# MOD BY: MORTH / BAIRNSFATHER
# MOD NO: 1     MOD BY: RR BAIRNSFATHER                 DATE:           11 MAY 67
#
# FUNCTIONAL DESCRIPTION:  GIVEN THE PRESENT POSITION, UNITR, CALCULATE A NEW UNITR T
#       TRANSFER ANGLE, THETA, ALONG THE TRAJECTORY.  THEN CALCULATE SIN(LAT) AND USE
#       SINCE FISHCALC USED UNI (LEFT BY ENTRY) EARTH SCALING IS ASSUMED.  (WILL IMPE
#
# CALLING SEQUENCE:     CALL
#                               FISHCALC
#       ENTER WITH .5 SIN(THETA) IN MPAC.
#       PUSHLOC IS AT PDL+0, AN ARBITRARY BASE VALUE IF LEQ 8D
#
# SUBROUTINES CALLED:  GET ERAD
#
# NORMAL EXIT MODE:  RVQ
```

```
#
# EXIT MODES:   NONE
#
# OUTPUT:       ERADM (-29) M IN MPAC ON RETURNING
#               NEW UNIT VECTOR NOT SAVED.
#               SIN(LAT) NOT SAVED.
#               PUSHLOC AT PDL+0
#
# ERASABLE INITIALIZATION REQUIRED:
#               SDELF/2         =SIN(THETA) / 2, IN MPAC                LEFT BY TFF/TRIG
#               CDELF/2         =COS(THETA) / 2, STORED IN PDL 14D      LEFT BY TFF/TRIG
#               RONE            (-29) M                                 LEFT BY USER
#               VONE            (-7) M/CS                               LEFT BY USER
#               URONE           UR/2                                    LEFT BY USER
#               UNI             .5 UNIT(V*R)                            LEFT BY ENTRY / P61
#               UNITW           UNIT NORTH POLE                         LEFT BY PAD LOAD
#
# DEBRIS:       QPRET, PDL+0 ... PDL+5
                                        # _      _          _
FISHCALC        PDVL    VXV             # URPR = UR CDELF + UHOR SDELF
                        URONE
                        UNI
                VXSC    VSL1
                                        # SIN(THETA) / 2 FROM PDL+0
                PDVL    VXSC            # TO PDL+0, +5
                        URONE
                        CDELF/2         # COS(THETA) / 2
                VAD     STADR
                STORE   URH             # FOR USE IN RTGO FROM EMS DISPLAY
                DOT     SL1
                        UNITW           # PULL UNIT VECTOR      UNIT NORTH
                STORE   ALPHAV +4       # = .5 SIN(LAT)
DUMPFISH        GOTO
                        GETERAD         # SAVES FISCHER RAD (-29) M IN ERADM AND
                                        # IN MPAC.  RETURNS TO CALLER VIO QPRET.

# Page 813
# SUBROUTINE NAME:  VGAMCALC    (USED BY S61.2)                         DATE:           01.21.6
# MOD NO: 0                                                             LOG SECTION:    P61-P67
# MOD BY: MORTH / BAIRNSFATHER
# MOD NO: 1     MOD BY: RR BAIRNSFATHER         DATE: 11 APR 67
# MOD NO: 2     MOD BY: RR BAIRNSFATHER         DATE: 21 NOV 67         VARIABLE MU ADDED.
# MOD NO: 3     MOD BY: RR BAIRNSFATHER         DATE: 21 MAR 68         ACCEPT DIFFERENT EARTH/
#
# FUNCTIONAL DESCRIPTION:  EARTH CENTERED VIS VIVA CALCULATION OF TERMINAL VELOCITY AND GAMMA (
#       HORIZONTAL) GIVEN THE SCALAR QUANTITIES:  PRESENT RADIUS AND VELOCITY AND THE TERMINAL
```

```
#       THE USER MUST APPEND PROPER SIGN TO GAMMA, SINCE IT IS CALCULATED AS A POSITI
#       THE EQUATIONS ARE
#
#               VGAM = SQRT(VN VN/MU + 2(RN-RTERM)/(RN RTERM) ) RTMU
#
#               COSGAM = H / RTERM VGAM = SQRT (LCP) / (RTERM VGAM/RTMU)
#
#       VGAMCALC ASSUMES THAT THE TERMINAL RADIUS IS LESS THAN THE PRESENT RADIUS.  I
#       MAKE THIS ASSUMPTION.
#
# CALLING SEQUENCE:     CALL                    STCALL  RTERM
#                               VGAMCALC                PREVGAM
#       PUSHLOC AT PDL+0, ARBITRARY IF LEQ 12D
#       C(MPAC) UNSPECIFIED                     C(MPAC)=NEW RTERM
#
# SUBROUTINES CALLED:  NONE
#
# NORMAL EXIT MODE:  RVQ
#
# ALARMS:       NONE
#
# OUTPUT:       GAMMA / 360 IN MPAC, POSITIVE NUMBER
#               VGAM    E: (-7)   M: (-5)       M/CS IN PDL+0
#               PUSHLOC AT PDL+2
#
# ERASABLE INITIALIZATION REQD:
#       TFF/RTMU  E: (17)   M: (14)     1/SQRT(MU)                              LEFT
#       RMAG1     E: (-29)  M: (-27)    M  PRESENT RADIUS LENGTH                LEFT
#       NRMAG     E: (-29+NR)           M  NORM LENGTH OF PRESENT POSITION      LEFT
#                 M: (-27+NR)
#       RTERM     E: (-29)  M: (-27)    M  TERMINAL RADIUS LENGTH               LEFT
#       NRTERM    E: (-29+NR)           M  NORM LENGTH OF TERMINAL RADIUS       LEFT
#                 M: (-27+NR)
#       TFFVSQ    E: (20)   M: (18)   1/M  -(V SQ/MU): PRESENT VELOCITY, NORM   LEFT
#       TFFNP     E: (-38+2NR)          M  LCP, SEMI-LATUS RECTUM, WEIGHT NR    LEFT
#                 M: (-36+2NR)
#
# DEBRIS:       QPRET, PDL+0 ... PDL+3
#               RTERM, NRTERM IF PREVGAM ENTERED.
# Page 814

PREVGAM         SL*                     # ENTER WITH NEW RTERM IN MPAC
                                        # E: (-29)  M: (-27)
                        0,1             # X1 = -NR
                STORE   NRTERM          # RTERM M               E: (-29+NR)     M: (-
```

```
VGAMCALC        DLOAD   DMP
                        NRMAG           # RMAG M                E: (-29+NR)     M: (-27+NR)
                        NRTERM          # RTERM M                E: (-29+NR)     M: (-27+NR)
                PDDL    DSU             # RMAG RTERM M           E: (-58+2NR)    M: (-54+2NR)
                        NRMAG           # RMAG M                 E: (-29+NR)     M: (-27+NR)
                        NRTERM          # RTERM M                E: (-29+NR)     M: (-27+NR)
                SL*     DDV             # 2(RN-RTERM)            E: (-30+NR)     M: (-28+NR)
                        0 -8D,1         # (-8+NR)
                                        # PUSH UP PRODUCT.
                DSU
                        TFFVSQ          # -(V SQ/MU)             E: (20)         M: (18)
                SQRT    PUSH            # SAVE VGAM/RT(MU) FOR NOW.     E: (10) M: (9)
                DDV     PDDL            # XCH PDL+0, LEAVING VGAM FOR OUTPUT.
                                        # VGAM TO PDL M/CS       E: (-7)         M: (-2)
                        TFF/RTMU        #                        E: (17)         M: (14)
                DMP     PDDL            # RTERM VGAM/RTMU        E: (-19+NR)     M: (-18+NR)
                        NRTERM          # RTERM M                E: (-29+NR)     M: (-27+NR)
                        TFFNP           # LC P =H.H/MU M         E: (-38+2NR)    M: (-36+2NR)
                SQRT    DDV             #                        E: (-19+NR)     M: (-18+NR)
                                        # PUSH UP DEN            E: (-19+NR)     M: (-18+NR)
                                        # USE DDV OVFL AS LIMITER (|COS| <1.0)
                SR1     ACOS
DUMPVGAM        RVQ
                                        # CALLER MUST SUPPLY OWN SIGN ...
                                        #                        22W     27MS

# Page 815
# SUBROUTINE NAME:      TFF/TRIG        (USED BY S61.2)         DATE:           01.17.67
# MOD NO: 0                                                     LOG SECTION:    P61-P67
# MOD BY: RR BAIRNSFATHER
# MOD NO: 1     MOD BY: RR BAIRNSFATHER         DATE: 14 APR 67
# MOD NO: 2     MOD BY: RR BAIRNSFATHER         DATE: 21 MAR 68         ACCEPT DIFFERENT EARTH/
#
# FUNCTIONAL DESCRIPTION:  USED BY ENTRY DISPLAY TO CALCULATE SIN(THETA), COS(THETA) FROM DATA
#       PDL BY TFF SUBROUTINES.  THE EQNS ARE
#
#               COS(THETA) = 1-2 ABS(ARG) / (RN RTERM (1+X) )
#                                               2
#               SIN(THETA) = SGN(ARG) SQRT(1-COS (THETA) )
#
#       WHERE THETA = TRANSFER ANGLE
#       AND     ARG = P Z ABS(Z)                        IF ALFA ZZ LEQ 1
#               ARG = (P / ALFA) SGN(Q1 + R 1/Z)        IF ALFA Z Z G 1
#       AND  ARG  HAS BEEN AFFIXED WITH THE SIGN OF SIN(THETA)
#
# CALLING SEQUENCE:     CALL
```

```
#                               TFF/TRIG
#               PUSHLOC AT PDL+0, ARBITRARY IF NOT EQ 14D
#               C(MPAC) UNSPECIFIED
#
# SUBROUTINES CALLED:  NONE
#
# NORMAL EXIT MODES:  RVQ
#
# ALARMS:       NONE
#
# OUTPUT:       C(MPAC) = .5 SIN(THETA)
#               CDELF/2 = .5 COS(THETA)         (IN PDL 14D)
#               PUSHLOC AT PDL+0
#
# ERASABLE INITIALIZATION REQUIRED:
#               TFFX                    X                                       LEFT
#               TFFTEM  E: (-59+2NR)    ARG                                     LEFT
#                       M: (-55+2NR)    WHERE ARG = LCF ZZ SGN(DELF) OR ARG = LCP/ALF
#               NRTERM  E: (-29+NR)     M  NORM LENGTH OF TERMINAL RADIUS       LEFT
#                       M: (-27+NR)
#               NRMAG   E: (-29+NR)     M  NORM LENGTH OF PRESENT POSITION      LEFT
#                       M: (-27+NR)
#
# DEBRIS:       QPRET, CDELF/2

                BANK    27
                SETLOC  P60S5
                BANK
TFF/TRIG        DLOAD   SR1
                        TFFX
                DAD     DMP
                        HIDPHALF
                        NRMAG           # RMAG M                E: (-29+NR)     M: (-
                DMP     BDDV
                        NRTERM          # RTERM M               E: (-29+NR)     M: (-
                        TFFTEM          # P ZSQ OR P/ALFA       E: (-59+2NR)    M: (-
                ABS     BDSU            # THE SIGN IS FOR SDELF.
                        HIDPHALF
                STORE   CDELF/2         # .5 COS(THETA)
                DSQ     DCOMP           # KEEP HONEST FOR SQRT.
# Page 816
                DAD     SQRT
                        HIDP1/4
DUMPTRIG        SIGN    RVQ
                        TFFTEM          # AFFIX SIGN(DELE/2)
                                        # RETURN WITH .5 SIN(THETA) IN MPAC
```

```
                                        #                       16W     15MS

DISPTARG        STQ                     # C(MPAC = TRGO ESTIMATE
                        60GENRET
                DMP     DSU
                        KTETA1
                        TTE1
                STCALL  DTEAROT
                        EARROT2
                CALL
                        VRCALC
                GOTO
                        60GENRET
VRCALC          VLOAD   DOT
                        URH
                        RT
                SL2     ACOS
                RVQ

# END OF PROGRAM S61.2

# Page 817
# PROGRAM DESCRIPTION S62.3     DATE 10JAN67
# MOD NO 1:                     LOG SECTION P60-P67
# MOD BY ZELDIN
# MOD NO: 2     MOD BY: RR BAIRNSFATHER         DATE: 15 MAY 67         CHANGED TO REF COORDS.
# MOD NO: 3     MOD BY: RR BAIRNSFATHER         DATE: 17 JAN 68         ALFAPAD CHANGES MADE.
#
# FUNCTIONAL DESCRIPTION
#
#       COMPUTE DESIRED GIMBAL ANGLES FOR ENTRY ATTITUDE
#       THE FOLLOWING TRAJECTORY TRIAD IS AVAILABLE IN MEMORY AND IS COMPUTED EACH 2 SECONDS BY
#       REFERENCE COORDINATES (V = VELOCITY RELATIVE TO EARTH):
#
#               UXA = -UNIT(V)
#               UYA =  UNIT(V*R)
#               UZA =  UXA*UYA
#
#       GENERATE A DESIRED BODY TRIAD FOR TRIMMED FLIGHT WITH RESPECT TO THE RELATIVE VELOCITY
#       ROLL COMMAND AND TRIM ANGLE OF ATTACK:
#
#               UXD = UNIT(UYD*UXA) SIN(ALFATRIM) + UXA COS(ALFATRIM)
#               UYD = UYA COS(ROLLC) + UZA SIN(ROLLC)
#               UZD = UXD * UYD
#
```

```
#       USE THE DESIRED SET (IN REFERENCE COORDS) AND REFSMMAT TO CALL  CALCGA  AND C
#       IN 2S, C IN MPAC, +2 AND THETAD, +2.
#
# CALLING SEQUENCE
#
#       L       CALL
#       L+1             S62.3
#
# NORMAL EXIT MODE
#
#       RETURN VIA QPRET DIRECTLY FROM CALCGA.
#
# SUBROUTINES CALLED
#
#       CALCGA
#
# ALARM OR ABORT MODES
#
#       NONE
#
# ERASABLE INITIALIZATION REQUIRED
#
#       ROLLC   ROLL COMMAND            DP 1'S COMP AT 1REV
#       ALFAPAD SP 1'S C / 180          LEFT BY PAD LOAD        ALFATRIM IS NEGATIVE.
#       UXA/2   REF COORDS              LEFT BY CM/POSE
#       UYA/2   REF COORDS              LEFT BY CM/POSE
#       UZA/2   REF COORDS              LEFT BY CM/POSE
#
# OUTPUT
#
#       CPHI    GIMBAL ANGLES (O,I,M) 2'S COMP TP (O,I,M)/180
#
# DEBRIS
#
#       QTEMP, QPRET, PUSHLIST

                BANK    10
                SETLOC  P60S4
                BANK
# Page 818
                COUNT*  $$/S62.3

S62.3           SETPD   SLOAD
                        0
                        ALFAPAD         # ALFATRIM / 180, ALFA IS NEG.
                SR1     PUSH
```

```
COS     PDDL            # XCH PDL, COS TO PDL0
SIN     PDDL            # SIN TO PDL2
        ROLLC
COS     VXSC
        UYA/2           #                               REF COORDS
PDDL    SIN             # PUSH VECTOR INTO PDL4...9
        ROLLC
VXSC    VAD
        UZA/2           #                               REF COORDS
                        # VECTOR FROM PDL4...9
VSL1
STORE   YNB             # = UYD                         REF COORDS

VXV     VSL1
        UXA/2           #                               REF COORDS
VXSC    PDDL
                        # SIN TRIM FROM PDL2
                        # XCH PDL0 FOR COS TRIM
VXSC    VAD
        UXA/2           #                               REF COORDS
                        # FROM PDL0
VSL1
STORE   XNB             # X SC AXIS (.5 UNIT)           REF COORDS

VXV     VSL1
        YNB
STOVL   ZNB             # Z SC IN REF COOR. SCALED AT 2
        REFSMMAT
STOVL   XSM
        REFSMMAT +6
STOVL   YSM
        REFSMMAT +12D
STORE   ZSM

CLEAR   GOTO
        CPHIFLAG        # CAUSE CALCGA TO STORE ANS IN TP CPHI
        CALCGA
                        # CALCGA WILL RETURN TO ORIGINAL CALLER
                        # VIA QPRET WITH 2'S COMP. ANGLES IN CPHI
```

Uses 60GENRET 223, A 80, ALFACOM 216, ALFAPAD 198, ALPHAV 177, ALT 157, AOG 214, AVEGEXIT 159, AVEGFLAG 101, BETACOM 216, CM/DSTBY 121, CMDAPMOD 214, COMMAND 169, COUNT 142, CPHI 157, CPHIFLAG 95, D 226, DISPLAYS 59, DNLSTCOD 148, DNRNGERR 229, DTEAROT 226, DVCNTR 224, E2 236, EBANK 80, EMSALT 175, ENTRYDSP 117, ENTRYVN 161,

ERADFLAG 99, ERADM 177, EXTVBACT 154, F 238, GAMDIFSW 119, GAMMA 232, GAMMAEI 231, GMAX 229, GOTOADDR 226, H 177, HEADSUP 216, HI6ZEROS 71, HIDP1/4 71, HIDPHALF 71, I 206, IT 185, L 80, L/D 226, LADPAD 198, LAT 157, LAT(SPL) 224, LEQ 226, LNG(SPL) 224, LODPAD 198, LONG 157, LUNAFLAG 107, MM 226, MODE 145, MPAC 145, N 206, NODOFLAG 105, OGA 206, ORBITAL 59, OVFIND 140, P 188, P60S 65, P60S1 65, P60S2 65, P60S3 65, P60S4 59, P60S5 67, P63FLAG 216, PIPTIME 159, PIPTIME1 159, POSEXIT 216, PUSHLOC 145, Q7 223, QPRET 85, QTEMP 236, RAD 219, RANGE 179, RDOT 229, REENTRY 65, REFSMMAT 172, RESTART 57, RMAG 174, RN 159, RN1 159, ROLLC 214, RONE 179, RT 226, RTGO 229, RTINIT 226, S1 85, S2 85, S61DT 223, SAVE 191, SQ 156, STATE 138, TC 169, TFF 179, THETA 148, THETAD 157, THETAH 229, TM 219, TTE 229, TTE1 229, UNI 226, UNITR 174, UNITW 172, URH 226, URONE 181, UXA/2 226, UYA/2 226, UZA/2 226, V 229, VIO 229, VL 229, VN 159, VN1 159, VONE 179, VPRED 231, X1 85, X2 85, XNB 186, XRNGERR 229, XSM 186, YNB 186, YSM 186, Z 80, ZNB 186, and ZSM 186.

3.5.10 servicer207 code

1226 ⟨*servicer207 code* 1226⟩≡ (857a 2802)
⟨*Page CM0819* 1227⟩

1227 ⟨*Page CM0819* 1227⟩≡ (1226)

```
# Page 819
# SERVICER207
#
# PROGRAM NAME: PREREAD, READACCS, SERVICER, AVERAGE G.
# MOD NO. 00 BY M. HAMILTON     DEC. 12, 1966
#
# FUNCTIONAL DESCRIPTION
#
# THE ROUTINES DESCRIBED BELOW ARE USED TO CALCULATE VALUES OF RN, VN, AND GDT/2 DURING ACCELER
# THE SEVERAL ROUTINES COMPRISE A PACKAGE AND ARE NOT MEANT TO BE USED AS SEPARATE SUBROUTINES.
#
# GENERAL REFERENCES TO  SERVICER  OR  AVERAGE G  ARE UNDERSTOOD TO REFER TO THE ENTIRE SET OF
# RRADACCS, SERVICER, AVERAGE G, INTEREAD, SMOOTHER, AND ANY ADDITIONAL ROUTINES ATTACHED AT AV
#
# PROGRAMS INITIATING SERVICER ARE REQUIRED TO MAKE A WAITLIST CALL FOR PREREAD (OR, IF LIFTOFF
# AT 2 SECONDS BEFORE THE FIRST AVERAGE G UPDATE IN ORDER TO INITIALIZE THE SEQUENCE, WHICH WIL
# 2 SECONDS FROM THAT TIME ON AS LONG AS AVEGFLAG REMAINS SET.
#
# THE USE OF ERASABLE AVGEXIT ALLOWS VARIOUS ROUTINES TO BE PERFORMED AS PART OF THE NORMAL CYC
# EXPLANATION OF AVGEXIT BELOW).
#
# DESCRIPTIONS OF INDIVIDUAL ROUTINES FOLLOW.
#
#       PREREAD
#
#               PREVIOUSLY EXTRAPOLATED VALUES COPIED FROM RN1, VN1, AND PIPTIME1 INTO RN, VN,
#               LASTBIAS JOB SCHEDULED.
#               PIPS READ AND CLEARED VIA PIPASR SUBROUTINE.
#               AVERAGE G FLAG SET ON.
#               DRIFT FLAG SET OFF.
#               V37 FLAG SET ON.
#               INITIALIZATION OF       1) THRUST MONITOR (DVMON) -- DVCNTR SET TO ONE.
#                                       2) TOTAL ACCUMULATED DELV VALUE (DVTOTAL) -- SET TO ZER
#                                       3) AXIS VECTOR (AXIS) -- SET TO (.5,0,0).
#               NORMLIZE JOB SCHEDULED.
#               READACCS TASH CALLED IN 2 SECONDS.
#
#       NORMLIZE
#
#               GDT/2 INITIALIZED VIA CALCGRAV ROUTINE.
#
#       READACCS
#
#               IF ONMON FLAG SET QUIKREAD ROUTINE IS PERFORMED BEFORE PIPASR ZEROS THE PIPA RE
#               ONMONITOR LOOP IS INITIATED TO PROVIDE DOWNLINK INFORMATION DURING ENTRY.
```

```
#               PIPS READ AND CLEARED BY PIPASR SUBROUTINE.
#               IF CM/DSTBY IS ON, ENTRY VARIABLES INITIALIZED AND SETJTAG TASK CALLE
# Page 820
#
#       SERVICER207
#
#               IF AVERAGEG FLAG ON     READACCS CALLED TO RECYCLE IN 2 SECONDS.
#               IF AVERAGEG FLAG OFF    AVERAGE G EXIT (AVGEXIT) SET TO 2CADR AVGEND
#               SERVICER JOB SCHEDULED.
#               TEST CONNECTOR OUTBIT TURNED ON.
#
#       ONMNITOR
#
#               A SEQUENCE OF THREE PASSES THROUGH QUICREAD FOLLOWING A CALL TO READA
#               SEC INTERVALS.  INTERVALS ARE COUNTED OUT BY PIPCTR, INITIALIZED AT 3
#
#       QUIKREAD
#
#               READS CURRENT PIPS INTO X,Y,ZPIPBUF.  READS OLD X,Y,ZPIPBUF INTO X,Y,
#               DOWNLIST DURING ENTRY.
#
#       SERVICER
#
#               DELV VALUES CHECKED TO DETECT RUNAWAY PIP:
#                       IF BAD PIP      1) ALARM SENT.
#                                       2) COMPENSATION, DVTOTAL ACCUMULATION, AND DV
#                                          TRANSFERRED TO AVERAGE G.
#               PIPS COMPENSATED VIA 1/PIPA SUBROUTINE.
#               DVTOTAL INCREMENTED BY ABSOLUTE VALUE OF DELV.
#               THRUST MONITOR (DVMON) PERFORMED UNLESS IDLE FLAG IS ON.
#               CONTROL TRANSFERRED TO AVERAGE Q.
#
#       DVMON
#
#               THRESHOLD VALUD (PLACED IN DVTHRUSH BY USER) CHECKED AGAINST ABSOLUTE
#               THRUST LEVEL.
#
#                       IF THRUST       1) ULLAGE OFF ROUTINE PERFORMED.
#                                       2) STEERING FLAG TURNED ON AT FIRST DETECTION
#                                       3) CONTROL TRANSFERRED TO AVERAGE G.
#                       IF NO THRUST    1) ON FIRST PASS THROUGH MONITOR, CONTROL TRA
#                                       2) ON SUBSEQUENT PASSES, CONTROL TRANSFERRED
#                                          HAS FAILED FOR 3 CONSECUTIVE PASSES.
#
#       ENGINE FAIL
#
```

```
#               ENGFAIL1 TASK CALLED IN 2.5 SECONDS.  THIS WILL RETURN CONTROL TO TIG-5 SO THAT
#                       SEQUENCE MAY BE REPEATED.
#               ENGINOF3 PERFORMED.
#               DAP SET UP FOR RCS.
#
#       AVERAGE G
# Page 821
#               RN1, VN1, GDT1/2 CALCULATED VIA CALCRVG ROUTINE BY UPDATING RN, VN WITH DELV AN
#                       OF GDT/2
#               RN1, VN1, GDT1/2, PIPTIME1 COPIED INTO RN, VN, GDT/2, PIPTIME FOR RESTART PROTE
#               CONTROL TRANSFERRED TO ADDRESS SPECIFIED BY USER (OR BY READACCS FOR LAST PASS)
#               LAST PASS (AVGEND)      1) FREE FALL GYRO COMPENSATION SET UP.
#                                       2) DRIFT FLAG TURNED ON.
#                                       3) STATE VECTOR TRANSFERRED VIA AVETOMID ROUTINE.
#                                       4) ONMONITOR FLAG RESET.
#                                       5) V37 FLAG RESET.
#                                       6) TEST CONNECTOR OUTBIT RESET.
#                                       7) CONTROL TRANSFERRED TO CANV37 TO CONTINUE MM CHANGE
#
# CALLING SEQUENCE
#
#       PREREAD ENTERED DIRECTLY FROM TIG-30 VIA POSTJUMP.
#       READACCS CALLED AS WAITLIST TASK.
#
# SUBROUTINES CALLED
#
#       UTILITY ROUTINES:  PHASCHNG FLAGUP FLAGDOWN NOVAC FINDVAC WAITLIST ALARM NEWPHASE 2PHSC
#
#       OTHER:  PIPASR 1/PIPA CALCGRAV CALCRVG AVETOMID
#
# NORMAL EXIT MODES
#
#       ENDOFJOB        TASKOVER        CANV37
#
#       AVGEXIT:        THIS IS A DOUBLE PRECISION ERASABLE LOCATION BY WHICH CONTROL IS TRANSF
#                               OF EACH CYCLE OF AVERAGE G.
#                       THE 2CADR OF A ROUTINE TO BE PERFORMED AT THAT TIME (E.G., STEERING EQU
#                               AT 2 SECOND INTERVALS) MAY BE SET BY THE USER INTO AVGEXIT.
#                       ALL SUCH ROUTINES SHOULD RETURN TO SERVEXIT, WHICH IS THE NORMAL EXIT F
#
#       SERVEXIT:       DOES A PHASE CHANGE FOR RESTART PROTECTION AND GOES TO ENDOFJOB.
#                       THE 2CADR OF SERVEXIT IS SET INTO AVGEXIT BY THE USERI F NO OTHER ROUTI
#
#       AVGEND:         LAST PASS OF AVERAGE G EXITS HERE, BYPASSING SPECIAL ROUTINE (SEE ABOVE
#                       FINAL EXIT IS TO CANV37.                                F AVERAGE G).
#
```

```
# OUTPUT
#
#       DVTOTAL(2)  PIPTIME(2)  XPIPBUF(2)  YPIPBUF(2)  ZPIPBUF(2)
#       RN(6)           REFERENCE COORD.        SCALED AT 2(+29) M/CS
#       VN(6)           REFERENCE COORD.        SCALED AT 2(+7) M/CS
#       GDT/2(6)        REFERENCE COORD.        SCALED AT 2(+7) M/CS
#       DELV(6)         STABLE MEMB. COORD.     SCALED AT 2(+14)*5.85*10(-4) M/CS (KE
# Page 822
#       DELVREF(6)      REFERENCE COORD.        SCALED AT 2(+7) M/CS
#
# INITIALIZATION
#
#       ONMONITOR FLAG SET BY ENTRY TO SHOW PIPBUF VALUES REQUIRED.
#       IDLE FLAG ON IF DVMON TO BE BYPASSED.
#       DVTHRUSH SET TO APPROPRIATE VALUE FOR DVMON.
#       AVGEXIT SET TO 2CADR OF ROUTINE, IF ANY, TO BE PERFORMED AFTER EACH CYCLE OF
#               TO BE DONE, AVGEXIT SET TO SERVEXIT.
#       VALUES NEEDED
#               REFSMMAT
#               UNITW:  FULL UNIT VECTOR, IN REFERENCE COORD., OF EARTH'S ROTATIONAL
#               RN1, VN1, PIPTIME1:  IN REFERENCE COORD., CONSISTENT WITH TIME OF EXE
#
# DEBRIS
#
#       CENTRALS        A, L, Q
#       OTHER           INTERNAL:  DVCNTR(1)  PIPAGE(1)  PIPCTR(1)  AVGEXIT(2)
#                       EXTERNAL:  ITEMP1(1)  ITEMP2(1)  RUPTREG1(1)  TEMX(1)  TEMY(1
#                       USEFUL DEBRIS
#                               RN1(0)  VN1(0)  GDT1/0  PIPTIME1(2?)
#                                       THESE LOCATIONS USED AS BUFFER STORAGE FOR NE
#                                       AND PIPTIME DURING PERFORMANCE OF SERVICER RO
#                               UNITR:  HALF UNIT VECTOR OF RN, REFERENCE COORD.
#                               RMAG SCALED AT 2(+58) IN 36D.
#                               RMAGSQ SCALED AT 2(+58) IN 34D.
#                               (RE/RMAG)SQ IN 32D

                BANK    27
                SETLOC  SERVICES
                BANK

                EBANK=  DVCNTR
# ********************* PREREAD ****************************************

                COUNT   37/SERV

PREREAD         CAF     PRIO21          # CALLER MUST PROTECT PREREAD
```

```
                TC      NOVAC
                EBANK=  NBDX
                2CADR   LASTBIAS        # DO LAST GYRO COMPENSATION IN FREE FALL

                                        # CALL-TO AND LASTBIAS ITSELF ARE NOT
                                        #       PROTECTED. REREADAC SETS 1/PIPADT
                                        #       TO 2.0 SECS IN CASE LASTBIAS LOST.
                                        #       (REDUNDANT IF LASTBIAS IS AOK.)
# Page 823
REDO5.31        TC      PREREAD1

                CAF     PRIO32
                TC      FINDVAC         # SET UP NORMLIZE JOB REQUIRED PRIOR TO
                EBANK=  DVCNTR          # FIRST AVERAGE G PASS
                2CADR   NORMLIZE

                CAF     2SECS
                TC      WAITLIST
                EBANK=  AOG
                2CADR   READACCS

                CS      TWO
                TC      NEWPHASE
                OCT     5

                TCF     TASKOVER

PREREAD1        EXTEND
                QXCH    RUPTREG1

                TC      PIPASR          # CLEAR + READ PIPS LAST TIME IN FREE FALL

                CAF     ONE             # SET UP PIPAGE FOR REREADAC IN CASE A
                TS      PIPAGE          #       RESTART OCCURS BEFORE READACCS

                CS      FLAGWRD1        # SET AVEG FLAG
                MASK    BIT1
                ADS     FLAGWRD1

                CA      POSMAX
                MASK    FLAGWRD2
                TS      FLAGWRD2        # KNOCK DOWN DRIFT FLAG

                CS      FLAGWRD7        # SET V37 FLAG
                MASK    BIT6
                ADS     FLAGWRD7
```

```
                CAF     ZERO
                TS      DVTOTAL         # CLEAR DVTOTAL
                TS      DVTOTAL +1

                TC      RUPTREG1

# Page 824
# ********************* READACCS ****************************************
                EBANK=  AOG
READACCS        TC      PIPASR

PIPSDONE        CAF     FIVE
                TS      L
                COM
                DXCH    -PHASE5

REDO5.5         CAF     ONE             # SHOW PIPS HAVE BEEN READ
                TS      PIPAGE

                CA      TWO             # SET PIPCTR FOR ONMINTOR
                TS      PIPCTR          # AFTER ABOVE PHASCHNG

                CS      CM/FLAGS
                MASK    BIT2            # CM/DSTBY
                CCS     A
                TC      CHEKAVEG

                CS      PIPTIME1 +1
                TS      TBASE6          # FOR RESTARTS
                EXTEND                  # CONTINUE FOR ENTRY DAP
                DCA     AOG
                DXCH    AOG/PIP
                CA      AMG
                XCH     AMG/PIP
                EXTEND
                DCA     ROLL/180
                DXCH    ROLL/PIP
                CA      BETA/180
                XCH     BETA/PIP
                CA      CM/FLAGS
                MASK    BIT12           # CM/DAPARM 93D BIT12
                EXTEND                  # DURING ENTRY, WHEN RCS DAP IS INACTIVE,
                BZF     NOSAVPIP        # SAVE PIPAS EACH 0.5 SEC FOR TM.

                CA      0.5SEC
```

```
                TC      WAITLIST
                EBANK=  XPIPBUF
                2CADR   QUIKREAD

                                        # NO NEED TO RESTART PROTECT THIS.
                CA      DELVX           # SAVE PIPAS AS READ (BUT NOT COMPENSATED)
                XCH     XPIPBUF
                TS      XOLDBUF

                CA      DELVY
                XCH     YPIPBUF
                TS      YOLDBUF
# Page 825
                CA      DELVZ
                XCH     ZPIPBUF
                TS      ZOLDBUF

NOSAVPIP        CA      FIVE
                TS      CM/GYMDT

                CA      JTAGTIME        # ACTIVATE CM/RCS AFTER PIPUP TO GO
                                        # IN JTAGTIME +5 CS.
                TC      WAITLIST
                EBANK=  AOG
                2CADR   SETJTAG

                CS      THREE           # 1.3SPOT FOR SETJTAG
                TC      NEWPHASE
                OCT     1

                CAF     OCT37
                TS      L
                COM
                DXCH    -PHASE5

CHEKAVEG        CS      FLAGWRD1
                MASK    BIT1
                CCS     A               # IF AVEG FLAG DOWN SET FINAL EXIT AVEG
                TC      AVEGOUT

                CAF     2SECS
                TC      WAITLIST
                EBANK=  AOG
                2CADR   READACCS

MAKESERV        CAF     PRIO20          # ESTABLISH SERVICER ROUTINE
```

```
                TC      FINDVAC
                EBANK=  DVCNTR
                2CADR   SERVICER

                CS      FOUR            # RESTART SERVICER AND READACCS
                TC      NEWPHASE
                OCT     5

                CAF     BIT9
                EXTEND
                WOR     DSALMOUT        # TURN TEST CONNECTOR OUTBIT ON

                TCF     TASKOVER        # END PREVIOUS READACCS WAITLIST TASK

# Page 826
AVEGOUT         EXTEND
                DCA     AVOUTCAD
                DXCH    AVGEXIT
                TCF     MAKESERV

                EBANK=  DVCNTR
AVOUTCAD        2CADR   AVGEND

# Page 827
# ROUTINE NAME: ONMNITOR
# MOD 04 BY BAIRNSFATHER 30 APR 1968    REDO ONMNITOR TO SAVE PIPS EACH 0.5 SEC FOR T
# MOD 03 BY FISHER DECEMBER 1967
# MOD 02 BY RYE SEPT 1967
# MOD 01 BY KOSMALA 23 MAR 1967
# MOD 00 BY KOSMALA 27 FEB 1967
#
# FUNCTIONAL DESCRIPTION
#
#       THE PURPOSE OF ONMONITOR IS TO PROVIDE 1/2 SEC. READING OF PIPAS FOR DOWNLIST
#       X,Y,XPIPBUF CONTAIN PRESET VALUES X,Y,ZOLDBUF CONTAIN VALUES FROM PREVIOUS RE
#
# CALLING SEQUENCE
#
#       CALL AS WAITLIST TASK. TERMINATES ITSELF IN TASKOVER
#
# INITIALIZATION
#
#       PIPCTR = 2 (FOR DT = 0.5 SEC)
#       X,Y,ZPIPBUF SET TO PREVIOUS PIPAX,Y,Z
#
# OUTPUT
```

```
#
#       X,Y,ZPIPBUF, X,Y,ZOLDBUF
#
# DEBRIS
#
#       X,Y,ZPIPBUF CONTAIN LAST PIPAX,Y,Z VALUES
#               X,Y,ZOLDBUF CONTAIN LAST-BUT-ONE PIPAX,Y,Z VALUES
#       RUPTREG1
#       PIPCTR

ONMNITOR        TS      PIPCTR

                TC      FIXDELAY        # WAIT
0.5SEC          DEC     50

QUIKREAD        CAF     TWO
                TS      RUPTREG1
                INDEX   A
                CA      PIPAX           # SAVE ACTUAL PIPAS FOR TM.
                INDEX   RUPTREG1
                XCH     XPIPBUF         # UPDATE X,Y,ZPIPBUF
                INDEX   RUPTREG1
                TS      XOLDBUF         # AND X,Y,ZOLDBUF
CHKCTR          CCS     RUPTREG1
                TCF     QUIKREAD +1     # LOOP AGAIN
                CCS     PIPCTR
                TCF     ONMNITOR
                TC      TASKOVER

# Page 828
# ******************** SERVICER ************************************

                EBANK=  DVCNTR

SERVICER        CAF     TWO
                INHINT
PIPCHECK        TS      RUPTREG1

                DOUBLE
                INDEX   A
                CCS     DELVX
                TC      +2
                TC      PIPLOOP

                AD      -MAXDELV        # DO PIPA-SATURATION TEST BEFORE
                EXTEND
```

```
                BZMF    PIPLOOP         # COMPENSATION.

                TC      ALARM
                OCT     00205           # SATURATED-PIPA ALARM   ***CHANGE LATER
                TC      AVERAGEG

PIPLOOP         CCS     RUPTREG1
                TCF     PIPCHECK

                TC      PHASCHNG        # RESTART REREADAC + SERVICER
                OCT     16035
                OCT     20000
                EBANK=  DVCNTR
                2CADR   DVTOTUP

                TC      BANKCALL        # PIPA COMPENSATION CALL
                CADR    1/PIPA

DVTOTUP         TC      INTPRET
                VLOAD   ABVAL           # GET ABS VALUE OF DELV
                        DELV
                DMP     EXIT
                        KPIP1           # SCALE AT 2(+7)

                EXTEND
                DCA     MPAC
                DAS     DVTOTAL         # ACCUMULATE DVTOTAL
AVERAGEG        TC      PHASCHNG
                OCT     10035

                TC      INTPRET
                CALL
# Page 829
                        CALCRVG
                EXIT

                TC      PHASCHNG
                OCT     10035

                CAF     OCT31           # COPY RN1,VN1,GOT102,GOBL1/2,PIPTIME1
                TC      GENTRAN         # INTO RN, VN, GDT/12, GOBL/2,PIPTIME
                ADRES   RN1
                ADRES   RN
                RELINT                  # GENTRAN DOES AN INHINT
                TC      PHASCHNG
                OCT     10035
```

```
                EXTEND
                DCA     AVGEXIT
                DXCH    Z               # AVERAGEG EXIT

AVGEND          CA      PIPTIME +1      # FINAL AVERAGE G EXIT
                TS      OLDBT1          # SET UP FREE FALL GYRO COMPENSATION

                TC      UPFLAG          # SET DRIFTFLG
                ADRES   DRIFTFLG        # BIT 15 FLAG 2
                TC      2PHSCHNG
                OCT     5               # GROUP 5 OFF
                OCT     05022           # GROUP 2 ON FOR AVETOMID
                OCT     20000

                TC      INTPRET
                CALL
                        AVETOMID        # CONVERT STATE VECTOR TO REFERENCE SCALE.
                EXIT

                CAF     ZERO            # ZERO MARK COUNTERS.
                TS      VHFCNT
                TS      TRKMKCNT

                TC      BANKCALL
                CADR    PIPFREE

                CS      BIT9
                TS      MRKBUF2         # INVALIDATE MARK BUFFER
                EXTEND
                WAND    DSALMOUT

                TC      DOWNFLAG
                ADRES   CM/DSTBY

                TC      DOWNFLAG
                ADRES   V37FLAG

# Page 830
                CAF     BIT7            # RESTORE GROUP 1 + 2 IF P20 IS RUNNING.
                MASK    FLAGWRD0
                EXTEND
                BZF     +4

                TC      2PHSCHNG
                OCT     111             # 1.11SPOT
```

```
                OCT     132             # 2.13SPOT

                TC      POSTJUMP
                CADR    CANV37

SERVEXIT        TC      PHASCHNG
                OCT     00035           # A, 5.3 = REREADAC     (ONLY)

                TCF     ENDOFJOB

DVTHRUSH        EQUALS  ELEVEN          # 15 PERCENT OF 2SEC PIPA ACCUMULATION,
                                        #       FOR 503-FULL CSM/LEM....DELV SC.AT
                                        #       5.85 CM/SEC.

-MAXDELV        DEC     -6398           # 3200 PPS FOR 2 SEC CCS TAKES 1

JTAGTIME        DEC     120             # = 1 SEC + T CDU, T CDU = .1 SEC

2.5SEC          DEC     250
MDOTFAIL        DEC     144.0 B-16      # 5 SEC MASS LOSS AT 28.8 KG/SEC
                                        # SHOULD BE 2-4 SECS FOR NO START
                                        #           6-8 SECS FOR FAILURE

# Page 831
# NORMLIZE PERFORMS THE INITIALIZATION REQUIRED PRIOR TO THE FIRST ENTRY TO AVERAGEG
# HAS 1 LEADING BINARY ZERO.  IN MOST MISSIONS, RN WILL BE SCALED AT 2(+29), BUT IN T
# SCALED AT 2(+24) M.

NORMLIZE        CAF     THIRTEEN        # SET UP TO COPY 14 REGS: RN1,VN1,PIPTIME1
                TC      GENTRAN         # INTO RN,VN,PIPTIME
                ADRES   RN1             # FROM HERE
                ADRES   RN              # TO HERE

                RELINT
                TC      INTPRET
                VLOAD   CALL            # LOAD RN FOR CALCGRAV
                        RN
                        CALCGRAV        # INITIALIZE UNITR RMAG GDT1

                STOVL   GDT/2
                        GOBL1/2
                STORE   GOBL/2
                EXIT
                TCF     ENDOFJOB

# Page 832
```

```
# *****  PIPA READER *****
# MOD NO. 00 BY D. LICKLY DEC. 9 1966
#
# FUNCTIONAL DESCRIPTION
#
# SUBROUTINE TO READ PIPA COUNTERS, TRYING TO BE VERY CAREFUL SO THAT IT WILL BE RESTARTABLE.
# PIPA READINGS ARE STORED IN THE VECTOR DELV.  THE HIGH ORDER PART OF EACH COMPONENT CONTAINS
# RESTARTS BEGIN AT REREADAC.
#
# AT THE END OF THE PIPA READER THE CDUS ARE READ AND STORED AS A
# VECTOR IN CDUTEMP.  THE HIGH ORDER PART OF EACH COMPONENT CONTAINS
# THE CDU READING IN 2'S COMP IN THE ORDER CDUX,Y,Z.  THE THRUST
# VECTOR ESTIMATOR IN FINDCDUD REQUIRES THE CDUS BE READ AT PIPTIME.
#
# CALLING SEQUENCE AND EXIT
#
#       CALL VIA TC, ISWCALL, ETC.
#
#       EXIT IS VIA Q.
#
# INPUT
#
#       INPUT IS THROUGH THE COUNTERS PIPAX, PIPAY, PIPAZ, AND TIME2.
#
# OUTPUT
#
#       HIGH ORDER COMPONENTS OF THE VECTOR DELV CONTAIN THE PIPA READINGS.
#
#       PIPTIME CONTAINS TIME OF PIPA READING.
#
# DEBRIS (ERASABLE LOCATIONS DESTROYED BY THE PROGRAM)
#
#       LOW ORDER DELV'S ARE ZEROED FOR TM INDICATION.
#       TEMX    TEMY    TEMZ    PIPAGE

PIPASR          EXTEND
                DCA     TIME2
                DXCH    PIPTIME1        # CURRENT TIME  POSITIVE VALUE
                CS      ZERO            # INITIALIZE THESE AT NEG ZERO.
                TS      TEMX
                TS      TEMY
                TS      TEMZ
# Page 833
                CA      ZERO
                TS      DELVZ           # OTHER DELVS OK INCLUDING LOW ORDER
                TS      DELVY
```

```
                TS      DELVX +1        # LOW ORDER DELV'S ARE ZEROED FOR TM:  THIS
                TS      DELVY +1        # IF DNLNK=D LOW ORDER DELVS ARE NZ, THEY
                TS      DELVZ +1        # CONTAIN PROPER COMPENSATION.  IF=0, THEN
                                        # THE TM VALUES ARE BEFORE COMPENSATION.

                TS      PIPAGE          # SHOW PIPA READING IN PROGRESS

REPIP1          EXTEND
                DCS     PIPAX           # X AND Y PIPS READ
                DXCH    TEMX
                DXCH    PIPAX           # PIPAS SET TO NEG ZERO AS READ.
                TS      DELVX
                LXCH    DELVY

REPIP3          CS      PIPAZ           # REPEAT PROCESS FOR Z PIP
                XCH     TEMZ
                XCH     PIPAZ
DODELVZ         TS      DELVZ

                TC      Q

                EBANK=  AOG

REREADAC        CCS     PHASE5          # LAST PASS CHECK
                TCF     +2
                TCF     TASKOVER

                CAF     PRIO31          # RESTART MAY HAVE WIPED OUT LASTBIAS, AN
                TS      1/PIPADT        #       UNPROTECTED NOVAC FROM PREREAD,
                                        #       WHICH SET(S) UP 1/PIPADT (THUSLY)
                                        #       FOR NON-COASTING COMPENSATION....BE
                                        #       SURE 1/PIPADT IS AOK.  (PRIO31 IS
                                        #       2.0SEC SC.AT B+8(CS)

                CCS     PIPAGE
                TCF     READACCS        # PIP READING NOT STARTED.  GO TO BEGINNING

                CAF     DONEADR         # SET UP RETURN FROM PIPASR
                TS      Q

                CCS     DELVZ
                TC      Q               # Z DONE, GO DO CDUS
                TCF     +3              # Z NOT DONE, CHECK Y.
                TC      Q
                TC      Q
```

```
# Page 834
                ZL
                CCS     DELVY
                TCF     +3
                TCF     CHKTEMX         # Y NOT DONE, CHECK X.
                TCF     +1
                LXCH    PIPAZ           # Y DONE, ZERO Z PIP.

                CCS     TEMZ
                CS      TEMZ            # TEMZ NOT = -0, CONTAINS -PIPAZ VALUE.
                TCF     DODELVZ
                TCF     -2
                LXCH    DELVZ           # TEMZ = -0, L HAS ZPIP VALUE.
                TC      Q

CHKTEMX         CCS     TEMX            # HAS THIS CHANGED
                CS      TEMX            # YES
                TCF     +3              # YES
                TCF     -2              # YES
                TCF     REPIP1          # NO
                TS      DELVX

                CS      TEMY
                TS      DELVY

                CS      ZERO            # ZERO X AND Y PIPS
                DXCH    PIPAX           # L STILL ZERO FROM ABOVE

                TCF     REPIP3

DONEADR         GENADR  PIPSDONE

# Page 835
#*****************************************************************************************
#
# ROUTINE CALCRVG INTEGRATES THE EQUATIONS OF MOTION BY AVERAGING THE THRUST AND GRAVITATIONAL
# ACCELERATIONS OVER A TIME INTERVAL OF 2 SECONDS.
#
# FOR THE EARTH-CENTERED GRAVITATIONAL FIELD, THE PERTURBATION DUE TO OBLATENESS IS COMPUTED TO
# HARMONIC COEFFICIENT J.
#
# ROUTINE CALCRVG REQUIRES...
#       1) THRUST ACCELERATION INCREMENTS IN DELV SCALED SAME AS PIPAX,Y,Z IN STABLE MEMBER COO
#       2) VN SCALED 2(+7) M/CS IN REFERENCE COORDS.
#       3) RN SCALED AT 2(+29) METERS IN REFERENCE COORDS.
#       4) UNITW THE EARTH'S UNIT ROTATIONAL VECTOR (SCALED AS A FULL UNIT VECTOR) IN REFERENCE
```

```
#
# IT LEAVES RN1 UPDATED (SCALED AT 2(+29)M, VN1 (SCALED AT 2(+7)M/CS), AND GDT1/2 (SC
# UNIT VECTOR UNITR, RMAG IN 36D SCALED AT 2(+29)M, R MAG SQ. IN 34D SCALED AT 2(+58)

CALCGRAV        UNIT    PUSH            # ENTER WITH RN IN MPAC
                STORE   UNITR
                LXC,1   SLOAD
                        RTX2
                        X1
                BMN     VLOAD
                        ITISMOON
                DOT     PUSH
                        UNITW
                DSQ     BDSU
                        DP1/20
                PDDL    DDV
                        RESQ
                        34D             # (RN)SQ
                STORE   32D             # TEMP FOR (RE/RN)SQ
                DMP     DMP
                        20J
                VXSC    PDDL
                        UNITR
                DMP     DMP
                        2J
                        32D
                VXSC    VAD
                        UNITW
                STADR
                STORE   GOBL1/2
                VAD     PUSH
                        UNITR
ITISMOON        DLOAD   NORM
                        34D
                        X2
                BDDV*   SLR*
# Page 836
                        -MUDT(E),1
                        0 -21D,2
                VXSC    STADR
                STORE   GDT1/2          # SCALED AT 2(+7) M/CS
                RVQ

CALCRVG         VLOAD   VXSC
                        DELV
                        KPIP1
```

```
                VXM     VSL1
                        REFSMMAT
                STORE   DELVREF         # DELV IN REF COORDS AT 2(+7)
                VSR1    PUSH
                VAD     PUSH            # (DV-OLDGDT)/2 TO PD SCALED AT 2(+7)M/CS
                        GDT/2
                VAD     VXSC
                        VN
                        2SEC(22)
                VAD     STQ
                        RN
                        31D
                STCALL  RN1             # TEMP STORAGE OF RN SCALED 2(+29)M
                        CALCGRAV

                VAD     VAD
                VAD
                        VN
                STCALL  VN1             # TEMP STORAGE OF VN SCALED 2(+7) M/CS.
                        31D

KPIP            2DEC    .1024           # SCALES DELV TO 2(+4)

KPIP1           2DEC    0.074880        # 207 DELV SCALING.  1 PULSE = 5.85 CM/SEC.

-MUDT(E)        2DEC*   -7.9720645 E+12 B-44*

-MUDT(M)        2DEC*   -9.805556 E+10 B-44*

2SEC(22)        2DEC    200 B-22

DP1/20          2DEC    0.05

RESQ            2DEC*   40.6809913 E12 B-59*

20J             2DEC*   3.24692010 E-2 B1*

2J              2DEC*   3.24692010 E-3 B1*
```

Uses -PHASE5 152, 1/PIPADT 156, A 80, AMG 214, AMG/PIP 214, AOG 214, AOG/PIP 214, AVEGFLAG 101, AVGEXIT 159, BETA/180 214, BETA/PIP 214, CDUS 80, CDUX 80, CM/DSTBY 121, CM/GYMDT 216, COUNT 142, D 226, DELV 159, DELVREF 224, DELVX 159, DELVY 159, DELVZ 159, DRIFTFLG 101, DSALMOUT 87, DV 241, DVCNTR 224, DVTOTAL 224, EBANK 80, F 238, FLAGWRD0 95, FLAGWRD1 97, FLAGWRD2 101, FLAGWRD7 121, GDT/2 159, GDT1/2 159, GOBL/2 159, GOBL1/2 159, IT 185, ITEMP1 138, ITEMP2 138, L 80, LONG 157, MASS 200, MM 226, MPAC 145, NBDX 167, OLDBT1 156, PHASE5 152, PIPAGE 159, PIPAX 80, PIPAY 80, PIPAZ 80, PIPCTR 159, PIPTIME 159, PIPTIME1 159, Q 80, REFSMMAT 172, RESTART 57, RMAG 174, RN 159,

RN1 159, ROLL/180 214, ROLL/PIP 214, RUPTREG1 138, SAVE 191, SERVICES 69, SQ 156, STATE 138, TBASE6 154, TC 169, TEMP 191, TEMX 159, TEMY 159, TEMZ 159, THRUST 85, TIG 224, TIME2 80, TM 219, TRKMKCNT 157, UNITR 174, UNITW 172, V37FLAG 123, VHFCNT 157, VN 159, VN1 159, X1 85, X2 85, XOLDBUF 223, XPIPBUF 223, YOLDBUF 223, YPIPBUF 223, Z 80, ZOLDBUF 223, and ZPIPBUF 223.

3.5.11 entry lexicon

1244 ⟨*entry lexicon* 1244⟩≡ (857a)
⟨*Page CM0837* 1245⟩
⟨*Page CM0838* 1247⟩
⟨*Page CM0839* 1248⟩
⟨*Page CM0840* 1250⟩
⟨*Page CM0841* 1252⟩
⟨*Page CM0842* 1254⟩
⟨*Page CM0843* 1255a⟩

1245 ⟨*Page CM0837* 1245⟩≡ (1244 2682)

```
# VARIABLE      DESCRIPTION                          MAXIMUM VALUE *         COMPUTER NAME
# --------      -----------                          ---------------         -------------
# _
# URTO          INITIAL TARGET VECTOR                2 (UNIT VECTOR)         = RTINIT
# _
# UZ            UNIT VECTOR NORTH                    1                       = UNITW
# _
# V             VELOCITY VECTOR                      2 VSAT                  = VEL
# _
# R             POSITION VECTOR                      2 EXP 29 METERS         = RN
# _
# VI            INERTIAL VELOCITY                    128 M/CENTISEC          = VN
# _
# RTE           VECTOR EAST AT INITIAL TARGET        2                       = RTEAST
# _
# UTR           NORMAL TO RTE AND UZ                 2                       = RTNORM
# _
# URT           TARGET VECTOR                        2                       = RT
# _
# UNI           UNIT NORMAL TO TRAJECTORY PLANE      2
# _
# DELV          INTEGRATED ACCEL. FROM PIPAS         5.85 16384 CM/S
# _
# G             GRAVITY VECTOR                       128 M/CENTISEC          = GDT/2
#
# AO            INITIAL DRAG FOR UPCONTRL            805 FPSS                FPSS=FT/SEC/SEC
#
# AHOOKDV       TERM IN GAMMAL CALC. = AHOOK DVL     16
#
# A1            DRAG VALUE IN FACTOR CALCULATION     805 FPSS
#
# ALP           CONST FOR UPCONTRL                   1
#
# ASKEP         KEPLER RANGE                         21600 NM                NM = NAUTICAL M
#
# ASP1          FINAL PHASE RANGE                    21600 NM
#
# ASPUP         UP-RANGE                             21600 NM
#
# ASP3          GAMMA CORRECTION                     21600 NM
#
# ASPDWN        RANGE DOWN TO PULL-UP                21600 NM
#
# ASP           PREDICTED RANGE                      21600 NM                NOT STORED
#
```

```
# COSG          COSINE(GAMMAL)                          2                       = COS
#
# C/DO          RECIPROCAL DRAG, -4/DO B-8              64/FPSS
#
# D             TOTAL ACCELERATION                      805 FPSS
#
# DO            CONTROLLED CONSTANT D                   805 FPSS
#
# DHOOK         TERM IN GAMMAL COMPUTATION              805 FPSS
#
# DIFF          THETNM-ASP (RANGE DIFFERENCE)           21600 NM
#
# DIFFOLD       PREVIOUS VALUE OF DIFF                  21600 NM
#
# DLEWD         CHANGE IN LEWD                          1
#
# DR            REFERENCE DRAG FOR DOWNCONTROL          805 FPSS                NOT S
#
# DREFR         REFERENCE DRAG                          805 FPSS                NOT S
#
# DVL           VS1-VL                                  2 VSAT
#
# E             ECCENTRICITY                            4                       NOT S
#
# F1            DRANGE/D DRAG   (FINAL PHASE)           2700/805                = FX
#
# F2            DRANGE/D RDOT   (FINAL PHASE)           2700/2VS NM/FPS         = FX
```

Uses A0 145, A1 229, AHOOKDV 226, ALP 229, ASKEP 229, ASP1 229, ASP3 229, ASPDWN 229, ASPUP 229, C/DO 229, COMPUTER 115, COSG/2 229, D 226, DO 229, DELV 159, DHOOK 226, DIFF 226, DIFFOLD 226, DLEWD 226, DVL 229, FACTOR 226, FX 226, GAMMA 232, GAMMAL 229, GDT/2 159, LEWD 226, RANGE 179, RDOT 229, RN 159, RT 226, RTE 67, RTEAST 226, RTINIT 226, RTNORM 226, UNI 226, UNITW 172, V 229, VEL 226, VL 229, VN 159, and VS1 229.

1247 ⟨*Page CM0838* 1247⟩≡ (1244 2682)

```
#
# F3            DRANGE/D (L/D)                          2700 NM                  = FX
#
# FACT1         CONST FOR UPCONTRL                      805 FPSS
#
# FACT2         CONST FOR UPCONTRL                      1/805 FPSS
#
# FACTOR        USED IN UPCONTRL                        1                        * MAXIMUM VALUE
#                                                                                  VARIABLE VALU
# GAMMAL        FLIGHT PATH ANGLE AT VL                 1 RADIAN                   VARIABLE HAS
#
# GAMMAL1       SIMPLE FORM OF GAMMAL                   1 RADIAN
```

Uses D 226, FACT1 226, FACT2 226, FACTOR 226, FX 226, GAMMAL 229, GAMMAL1 229, L 80, L/D 226, and VL 229.

1248 ⟨*Page CM0839* 1248⟩≡ (1244 2682)

```
#
# HEADSUP       INDICATOR FOR INITIAL ROLL              1
#
# KA            DRAG TO LIFT UP IF DOWN                 805 FPSS                = KAT
#
# KLAT          LATERAL SWITCH GAIN                     1                       (NOM
#
# K2ROLL        INDICATOR FOR ROLL SWITCH
#
# LAD           MAX L/D (MIN ACTUAL VEHICLE L/D)        1
#
# LADPAD        NOMINAL VEHICLE L/D, SP PAD LOAD        1                       (NOM
#
# LATANG        LATERAL RANGE                           4 RADIANS
#
# LEQ           EXCESS C.F. OVER GRAV=(VSQ-1)GS         128.8 FPSS
#
# LEWD          UPCONTROL REFERENCE L/D                 1
#
# LOD           FINAL PHASE L/D                         1                       (NOM
#
# LODPAD        FINAL PHASE L/D, SP PAD LOAD            1
#
# L/D           DESIRED LIFT TO DRAG RATIO              1
#               (VERTICAL PLANE)
#
# L/D1          TEMP STORAGE FOR L/D IN LATERAL         1
#
# L/DCMINR      LAD COS(15DEG)                          1                       (NOM
#
# PREDANGLE     PREDICTED RANGE (FINAL PHASE)           2700 NM                 = PRE
#
# Q2            FINAL PHASE RANGE -23500 Q3             21600 NM
#               Q2 = FCN(LAD)
#
# Q7            MINIMUM DRAG FOR UPCONTROL              805FPSS
#
# RDOT          ALTITUDE RATE                           2 VSAT
#
# RDOTREF       REFERENCE RDOT FOR UPCONTROL            2 VSAT
#
# RDTR          REFERENCE RDOT FOR DOWNCONT             2 VSAT                  NOT S
#
# ROLLC         ROLL COMMAND                            1 REVOLUTION
#
```

```
# RTOGO         RANGE TO GO (FINAL PHASE)              2700 NM                = FX +2
#
# SL            SINE OF LATITUDE                       1                      NOT SAVED
#
# T             TIME                                   B 28 CENTISEC          = TIME2,TIME1
#
# THETA         DESIRED RANGE (RADIANS)                2 PI RADIANS           = THETAH
#
# THETNM        DESIRED RANGE (NM)                     21600 NM               NON EXISTENT
#
# V             VELOCITY MAGNITUDE                     2 VSAT
#
# V1            INITIAL VELOCITY FOR UPCONTROL         2 VSAT
#
# VL            EXIT VELOCITY FOR UPCONTROL            2 VSAT
#
# VREF          REFERENCE VELOCITY FOR UPCONTROL       2 VSAT
#
# VS1           VSAT OR V1, WHICHEVER IS SMALLER       2 VSAT
#                 2     2
# VBARS         VL /VSAT                               4
#                                             2     2
# VSQ           NORMALIZED VEL. SQUARED = V /VSAT      4                      = VSQUARE
#
# WT            EARTH RATE TIMES TIME                  1 REVOLUTION           NOT SAVED
#
# X             INTERMEDIATE VARIABLE IN G-LIMITER     2 VSAT                 NOT SAVED
#
# Y             LATERAL MISS LIMIT                     4 RADIANS              NOT SAVED
```

Uses COMMAND 169, D 226, F 238, FX 226, HEADSUP 216, K2ROLL 226, KAT 229, KLAT 226, L 80, L/D 226, L/D1 226, L/DCMINR 226, LAD 226, LADPAD 198, LATANG 229, LATITUDE 191, LEQ 226, LEWD 226, LOD 226, LODPAD 198, PREDANG 229, Q2 229, Q7 223, RANGE 179, RDOT 229, RDOTREF 159, ROLLC 214, TEMP 191, THETA 148, THETAH 229, TIME1 80, TIME2 80, V 229, V1 145, VBARS 229, VEL 226, VL 229, VREF 159, VS1 229, and VSQUARE 226.

1250 ⟨*Page CM0840* 1250⟩≡ (1244 2682)

```
# EXTRA COMPUTER ERASABLE LOCATIONS NOT SHOWN ON FLOW CHARTS
# ----------------------------------------------------------
#
# VARIABLE      DESCRIPTION                             MAXIMUM VALUE
# --------      -----------                             -------------
#
# GOTOADDR      ADDRESS SELECTED BY SEQUENCER
#
# XPIPBUF       BUFFER TO STORE X PIPA COUNTS
#
# YPIPBUF       BUFFER TO STORE Y PIPA COUNTS
#
# ZPIPBUF       BUFFER TO STORE Z PIPA COUNTS
#
# PIPCTR        COUNTS PASSES THRU PIPA READ ROUTINE
#
# JJ            INDEX IN FINAL PHASE TABLE LOOK-UP
#
# MM            INDEX IN FINAL PHASE TABLE LOOK-U
#
# GRAD          INTERPOLATION FACTOR IN FINAL PHASE
#
# FX            DRANGE/D L/D = F3                       2700 NM
#
# FX +1         AREF                                    805 FPSS
#
# FX +2         RTOGO                                   2700 NM
#
# FX +3         RDOTREF                                 VSAT/4
#
# FX +4         DRANGE/D RDOT = F2                      21600/2VS NM/FPS
#
# FX +5         DRANGE/D DRAG = F1                      2700/805 NM/FPSS
#
# TEM1B         TEMPORARY LOCATION
#
# TIME/RTO      TIME OF INITIAL TARGET RTINIT           B 28 CENTISEC
#
# DTEAROT       EST TIME BETWEEN RTINIT AND RT          B 28 CENTISEC
# _
# UNITV         UNIT V VECTOR                           2
# _
# UNITR         UNIT R VECTOR                           2
#  _
# -VREL         NEGATIVE VELOCITY REL TO ATMOSP         2 VSAT
```

```
# COMPUTER SWITCHES                                    INITIAL STATE          CM/FLAGS = STAT
# -----------------                                    -------------          ---------------
#
# ENTRYDSP      DO ENTRY DISPLAY, IF SET               NON-BRANCH (1)         92D, BIT 13
# GONEPAST      INDICATES OVERSHOOT OF TARGET          NON-BRANCH (0)         95D, BIT 10
# RELVELSW      RELATIVE VELOCITY SWITCH               NON-BRANCH (0)         96D, BIT 9
# EGSW          FINAL PHASE SWITCH                     NON-BRANCH (0)         97D, BIT 8
# FIRSTPAS      INITIAL PASS THRU HUNTEST              NON-BRANCH (0)         98D, BIT 7
# HIND          INDICATES ITERATION IN HUNTEST         NON-BRANCH (0)         99D, BIT 6
# INRLSW        INDICATES INIT ROLL ATTITUDE SET       NON-BRANCH (0)         100D, BIT 5
# LATSW         INHIBIT DOWNLIFT SWITCH IF NOT SET         BRANCH (1)         101D, BIT 4
# .05GSW        INDICATES DRAG EXCEEDS .05 GS              BRANCH (0)         102D, BIT 3
#
# GONEBY        INDICATES GONE PAST TARGET (SET)       SELF-INITIALIZING      112D, BIT 8
```

Uses -VREL 226, .05GSW 121, COMPUTER 115, D 226, DTEAROT 226, EGSW 119, ENTRYDSP 117, FACTOR 226, FX 226, GONEBY 123, GONEPAST 119, GOTOADDR 226, GRAD 226, HIND 119, INRLSW 121, JJ 229, L 80, L/D 226, LATSW 121, MM 226, PIPCTR 159, RDOT 229, RDOTREF 159, RELVELSW 119, RT 226, RTINIT 226, STATE 138, TEM1B 226, TIME/RTO 226, UNITR 174, UNITV 226, V 229, XPIPBUF 223, YPIPBUF 223, Z 80, and ZPIPBUF 223.

1252 ⟨*Page CM0841* 1252⟩≡ (1244 2682)

```
# CONSTANTS AND GAINS                                                VALUE
# -------------------                                                -----
#
# C1            FACTOR IN ALP COMPUTATION                            1.25
# C16           CONSTD GAIN ON DRAG                                  .01
# C17           CONSTD GAIN ON RDOT                                  .001
# C18           BIAS VEL. FOR FINAL PHASE START                      500     FPS
# C20           MAX DRAG FOR DOWN-LIFT                               175     FPSS
# CHOOK         FACTOR IN AHOOK COMPUTATION                          .25
# CH1           FACTOR IN GAMMAL COMPUTATION                         1.0
# COS15         COS( 15 DEG )                                        .965
# DLEWD0        INITIAL VARIATION IN LEWD                            -.05
# D2            DRAG TO CHANGE LEWD                                  175     FPSS
# DT            COMPUTATION CYCLE TIME INTERVAL                      2       SEC.
# GMAX          MAXIMUM ACCELERATION                                 257.6   FPSS
# KA1           FACTOR IN KA CALC                                    1.3     GS
# KA2           FACTOR IN KA CALC                                    .2      GS
# KA3           FACTOR IN D0 CALC                                    90 FPSS
# KA4           FACTOR IN D0 CALC                                    40 FPSS
# KB1           OPTIMIZED UPCONTROL GAIN                             3.4
# KB2           OPTIMIZED UPCONTROL GAIN                             .0034
# KDMIN         INCREMENT ON Q7 TO DETECT END OF KEPLER PHASE        .5      FPSS
# KTETA         TIME OF FLIGHT CONSTANT                              1000
# KLAT1         FACTOR IN KLAT CALC                                  1/24
# K44           GAIN USED IN INITIAL ROLL SECTION                    19749550 FPS
# LATBIAS       LATERAL SWITCH BIAS TERM                             .41252961 NM
# LEWD1         NOMINAL UPCONTROL L/D                                .15
# POINT1        FACTOR TO REDUCE UPCONTROL GAIN                      .1
# Q2            FINAL PHASE RANGE - 23500 Q3                         -1002   NM
# Q3            FINAL PHASE DRANGE/D V                               .07     NM/FP
# Q5            FINAL PHASE DRANGE/D GAMMA                           7050    NM/RA
# Q6            FINAL PHASE INITIAL FLIGHT PATH ANGLE                .0349   RAD
# Q7F           MIN DRAG FOR UPCONTROL                               6       FPSS
# Q7MIN         IN VALUE FOR Q7 IN FACTOR CALCULATION                40      FPSS
# Q19           FACTOR IN GAMMAL1 CALCULATION                        .5
# Q21           FACTOR IN Q2 CALCULATION                             1000    NM
# Q22           FACTOR IN Q2 CALCULATION                             -1302   NM
# VFINAL1       VELOCITY TO START FINAL PHASE ON INITIAL ENTRY       27000   FPS
# VFINAL        FACTOR IN INITIAL UP-DOWN CALC                       26600   FPS
# VLMIN         MINIMUM VL                                           18000   FPS
# VMIN          VELOCITY TO SWITCH TO RELATIVE VEL                   VSAT/2
# VRCONTRL      RDOT TO START INTO HUNTEST                           700     FPS
#               VRCONT=COMPUTER NAME
# 25NM          TOLERANCE TO STOP RANGE ITERATION                    25      NM
# VQUIT         VELOCITY TO STOP STEERING                            1000    FPS
```

Uses ALP 229, BIAS 211, COMPUTER 115, D 226, DO 229, FACTOR 226, GAMMA 232, GAMMAL 229, GAMMAL1 229, GMAX 229, KLAT 226, L 80, L/D 226, LEWD 226, Q2 229, Q7 223, RAD 219, RANGE 179, RDOT 229, V 229, VEL 226, and VL 229.

1254 ⟨*Page CM0842* 1254⟩≡ (1244 2682)

```
# CONVERSION FACTORS AND SCALING CONSTANTS
# ----------------------------------------
#
# ATK   ANGLE IN RAD TO NM                                          3437.7468
# G5    NOMINAL G VALUE FOR SCALING                                 32.2
# H5    ATMOSPHERE SCALE HEIGHT                                     28500
# J     GRAVITY HARMONIC COEFFICIENT                                .00162346
# KWE   EQUATORIAL EARTH RATE                                       1546.10168
# MUE   EARTH GRAVITATIONAL CONSTANT                                3.986032233 E
# RE    EARTH RADIUS                                                21202900
# REQ   EARTH EQUATORIAL RADIUS                                     20925738.2
# VSAT  SATELLITE VELOCITY AT RE                                    25766.1973
# WIE   EARTH RATE                                                  .00007292115(

#               (END GSOP AS-278, VOL 1, FIG. 5.6-3 CONSTANTS, GAINS, ETC.)

# DISPLAY QUANTITIES
# ------------------
#
# (SEE SECTION 4 OF THE GSOP FOR SIGN CONVENTIONS.)
#
# VARIABLE      DESCRIPTION                             MAXIMUM VALUE
# --------      -----------                             -------------
#
# QMAX          PREDICTED MAXIMUM ENTRY ACCEL           163.84 GS       N 60
# VPRED         PREDICTED VELOCITY AT ALTITUDE          128 M/CENTISEC  N 60
#               400K FT ABOVE FISCHER RADIUS.
# GAMMAEI       PREDICTED GAMMA AT ALTITUDE             1 REVOLUTION    N 60
#               400K FT ABOVE FISCHER RADIUS
# D             DRAG ACCELERATION                       805 FPSS        N 64
# VMAGI         INERTIAL VELOCITY MAGNITUDE             128 M/CENTISEC  N 64, N 68
# THETAH        DESIRED RANGE ANGLE NM                  1 REVOLUTION    N 64, N 67
# LAT           PRESENT LATITUDE                        1 REVOLUTION    N 67
# LONG          PRESENT LONGITUDE                       1 REVOLUTION    N 67
# RTOGO         RANGE ANGLE TO SPLASH FROM              1 REVOLUTION    N 67
#               EMSALT FT ABOVE FISCHER RADIUS (IN NM)
# VIO           PREDICTED VELOCITY AT ALTITUDE          128 M/CENTISEC  N 63
#               EMSALT FT ABOVE FISCHER RADIUS.
# TTE           TIME OF FREE FALL TO ALT                B 28 CENTISEC   N 63
#               EMSALT FT ABOVE FISCHER RADIUS
# ROLLC         ROLL COMMAND                            1 REVOLUTION    N 68, N 68, N
# LATANG        CROSS-RANGE ERROR (XRNGERR)             4 RADIANS       N 66
# DNRNGERR      DOWN RANGE ERROR                        1 REVOLUTION    N 66
#               (PREDANG - THETAH IN NM)
# HDOT          ALTITUDE RATE                           128 M/CENTISEC  N 68
```

```
# QT            MINIMUM DRAG FOR UPCONTROL              805 FPSS        N 69
# VL            EXIT VELOCITY FOR UP-CONTROL            2 VSAT          N 69
```

Uses ALT 157, COMMAND 169, D 226, DNRNGERR 229, EMSALT 175, GAMMA 232, GAMMAEI 231, HDOT 231, LAT 157, LATANG 229, LATITUDE 191, LONG 157, N 206, PREDANG 229, RAD 219, RANGE 179, ROLLC 214, THETAH 229, TTE 229, VIO 229, VL 229, VMAGI 229, VPRED 231, and XRNGERR 229.

1255a ⟨*Page CM0843* 1255a⟩≡ (1244 2682)

```
# BODY ATTITUDE QUANTITIES (CM/POSE)
# ----------------------------------
#
# VARIABLE      DECRIPTION                              MAXIMUM VALUE
# --------      ----------                              -------------
#  _
# -VREL         NEGATIVE VELOCITY REL TO ATMOS.         2 VSAT
# _
# OLDUYA        USED FOR UYA BELOW 1000 FPS             2
# _
# UXA/2         UNIT VECTOR TRIAD                       2
# _
# UYA/2                 BASED ON                        2
# _
# UZA/2                         THE TRAJECTORY          2
# _
# UBX/2         UNIT VECTOR                             2
# _
# UBY/2                 BODY TRIAD                      2
# _
# UBZ/2                         FOR CM.                 2
```

Uses -VREL 226, OLDUYA 226, UBX/2 226, UBY/2 226, UBZ/2 226, UXA/2 226, UYA/2 226, and UZA/2 226.

3.5.12 reentry control

1255b ⟨*reentry control* 1255b⟩≡ (857a 2793)
⟨*Page CM0844* 1256⟩

1256 ⟨*Page CM0844* 1256⟩≡ (1255b)

```
# Page 844
# ENTRY INITIALIZATION ROUTINE
# ----------------------------

                BANK    25
                SETLOC  REENTRY
                BANK

                COUNT*  $$/ENTRY
                EBANK=  RTINIT

EBENTRY         =       EBANK7
EBAOG           EQUALS  EBANK6
NTRYPRIO        EQUALS  PRIO20          # (SERVICER)
CM/FLAGS        EQUALS  STATE +6

STARTENT        EXIT                    # MM = 63

                                        # COME HERE FROM CM/POSE.  RESTARTED IN CM/PO
                CS      ENTMASK         # INITIALIZE ALL SWITCHES TO ZERO
                                        # EXCEPT LATSW, ENTRYDSP, AND GONEPAST.
                                        # GONEBY 112D BIT8 FLAG7, SELF-INITIALIZING.
                INHINT
                MASK    CM/FLAGS
                                        # ENTRYDSP = 92D B13
                                        # GONEPAST=95D B10      RELVELSW=96D B9
                                        # EGSW = 97D B8
                                        # HIND=99D B6           INRLSW=100D B5
                                        # LATSW=101D B4         .05GSW=102D B3

                AD      ENTRYSW
                TS      CM/FLAGS

                RELINT

                TC      INTPRET

                SLOAD
                        LODPAD
                STORE   LOD

                SLOAD
                        LADPAD
                STORE   LAD
```

```
                DMP                     # L/DCMINR = LAD COS(15)
                        COS15
                STODL   L/DCMINR
                        LATSLOPE
                DMP     SR1             # KLAT = LAD/24
                        LAD
# Page 845
                STODL   KLAT
                        Q7F
                STODL   Q7              # Q7 = Q7F
                        NEARONE         # 1.0 -1BIT
                STODL   FACTOR
                        LAD
                SIGN    DCOMP
                        HEADSUP         # MAY BE NOISE FOR DISPLAY P61
                STCALL  L/D             # L/D = - LAD SGN(HEADSUP)

                        STARTEN1        # RETURN VIA GOTOADDR
                VLOAD   VXV
                        VN              # (-7) M/CS
                        UNITR           # .5 UNIT               REF COORDS
                UNIT    DOT
                        RT              # RT/2 TARGET VECTOR    REF COORDS
                STORE   LATANG          # LATANG = UNI.RT /4
                DCOMP   RTB
                        SIGNMPAC
                STODL   K2ROLL          # K2ROLL = -SGN(LATANG)

                        LAD
                DMP     DAD
                        Q21
                        Q22
                STORE   Q2              # Q2 = -1152 + 500 LAD

                SSP     SSP
                        GOTOADDR        # SET SELECTOR FOR INITIAL PASS
                        INITROLL
                        POSEXIT
                        SCALEPOP        # SET CM/POSE TO CONTINUE AT SCALEPOP

                RTB
                        SERVNOUT        # OMIT INITIAL DISPLAY, SINCE 1ST GUESSBAD

# CALCULATE THE INITIAL TARGET VECTOR: RTINIT, ALSO RTEAST, RTNORM, AND RT.  ALL ARE .5 UNIT AN
# REFERENCE COORDINATES.
```

```
STARTEN1        STQ     VLOAD
                        GOTOADDR
                        LAT(SPL)        # TARGET COORDINATES
                CLEAR   CLEAR           # DO CALL USING PAD RADIUS.  WILL UNIT IT.
                        ERADFLAG        # ANYWAY.
                        LUNAFLAG
                STODL   LAT
                        3ZEROS

                STODL   LAT +4          # SET ALT=0.
                        PIPTIME         # ESTABLISH RTINIT AT TIME OF PRESENT
# Page 846
                                        # RN AND VN.
                STCALL  TIME/RTO        # SAVE TIME BASE OF RTINIT.
                        LALOTORV        # C(MPAC) =TIME  (PIPTIME)
                UNIT                    # ANSWER IN ALPHAV ALSO
                STODL   RTINIT          # .5 UNIT TARGET                REF COORDS
                        500SEC          # NOMINAL ENTRY TIME FOR P63
                                        # TIME/RTO = PIPTIME, STILL.
                STCALL  DTEAROT         # INITIALIZE EARROT
                        EARROT1         # GET R5
                DOT     SL1
                        UNITR           # RT/2 IN MPAC
                ACOS
                STCALL  THETAH          # RANGE ANGLE /360
                        GOTOADDR        # RETURN TO CALLER

500SEC          2DEC    50000 B-28      # CS.

ENTMASK         OCT     11774
ENTRYSW         OCT     11010           # ENTRYDSP B13.  GONEPAST B10.  LATSW B4
# Page 847

SCALEPOP        CALL
                        TARGETNG

                EXIT

REFAZE10        TC      PHASCHNG
                OCT     10035           # SERVICER 5.3 RESTART AT REFAZE10

                TC      INTPRET

# JUMP TO PARTICULAR RE-ENTRY PHASE:
#                               SEQUENCE
                GOTO
```

```
                        GOTOADDR

# GOTOADDR CONTAINS THE ADDRESS OF THE ROLL COMMAND EQUATIONS TO THE CURRENT PHASE OF
# RE-ENTRY.  SEQUENCING IS AS FOLLOWS:
#
# INITROLL      ADDRESS IS SET HERE INITIALLY.  HOLDS INITIAL ROLL ATTITUDE UNTIL  KAT  IS EXCE
#               ATTITUDE UNTIL  VRTHRESH  IS EXCEEDED.  THEN BRANCHES TO
#
# HUNTEST       THIS SECTION CHECKS TO SEE IF THE PREDICTED RANGE AT NOMINAL   L/D FROM PRESENT
#               THAN THE DESIRED RANGE.
#                       IF NOT --- A ROLL COMMAND IS GENERATED BY THE CONSTANT DRAG CONTROLLER.
#                       IF SO  --- CONTROL AND GOTOADDR ARE SET TO UPCONTRL.
#               USUALLY NO ITERATION IS INVOLVED EXCEPT IF THE RANGE DESIRED IS TOO LONG ON THE
#               HUNTEST.
#
# UPCONTRL      CONTROLS ROLL DURING THE SUPER-CIRCULAR PHASE.  UPCONTRL IS TERMINATED EITHER
#                       (A) WHEN THE DRAG (AS MEASURED BY THE PIPAS) FALLS BELOW Q7, OR
#                       (B) IF RDOT IS NEGATIVE AND REFERENCE VL EXCEEDS V.
#               IN CASE (A),  GOTOADDR  IS SET TO  KEP2  AND IN CASE (B), TO  PREDICT3  SKIPPIN
#               ENTRY.
#
# KEP2          GOTOADDR IS SET HERE DURING THE KEPLER PHASE TO MONITOR DRAG.  THE SPACECRAFT I
#               TRIMMED IN PITCH AND YAW TO THE COMPUTED RELATIVE VELOCITY.  THE LAST COMPUTED
#               WHEN THE MEASURED DRAG EXCEEDS Q7 +0.5,  GOTOADDR  IS SET TO
#
# PREDICT3      THIS CONTROLS THE FINAL SUB-ORBITAL PHASE. ROLL COMMANDS CEASE
#               WHEN  V  IS LESS THAN  VQUIT .  AN EXIT IS MADE TO
#
# P67.1         THE LAST COMPUTED ROLL ANGLE IS MAINTAINED.  RATE DAMPING IS DONE IN PITCH AND
#               AND LONGITUDE ARE COMPUTED FOR DISPLAY.
#               ENTRY IS TERMINATED WHEN DISKY RESPONSE IS MADE TO THIS FINAL FLASHING DISPLAY.

# Page 848
# PROCESS AVERAGE G OUTPUT...SCALE IT AND GET INPUT DATA

# * START  TARGETING ...

                EBANK=  RTINIT

                                        # TARGETNG IS CALLED BY P61, FROM GROUP 4.
                                        # TARGETNG IS CALLED BY ENTRY, FROM GROUP 5.

                                        # ALL MM COME HERE.
TARGETNG        BOFF    VLOAD           # ENTER WITH PROPER EB FROM CM/POSE(TEST)
                        RELVELSW        # RELVELSW = 96D BIT9
                        GETVEL          # WANT INERTIAL VEL.  GO GET IT.
```

```
                        -VREL           # NEW V IS RELATIVE, CONTINUE

                VCOMP   GOTO            # (VREL) = (V) + KWE UNITR*UNITW
                        GETUNITV -1     # - VREL WAS LEFT BY CM/POSE

GETVEL          VLOAD   VXSC            # INERTIAL V WANTED
                        VN              # KVSCALE = (12800 / .3048) / 2VS
                        KVSCALE         # KVSCALE = .81491944
                STORE   VEL             # V/2 VS

GETUNITV        UNIT    STQ
                        60GENRET
                STODL   UNITV
                        34D
                STORE   VSQUARE         # VSQ/4

                DSU                     # LEQ = VSQUARE - 1
                        FOURTH          # 4 G'S FULL SCALE
                STODL   LEQ             # LEQ/4

                        36D
                STOVL   V               # V/2 VS = VEL/2 VS

                        VEL
                DOT     SL1             # RDOT= V.UNITR
                        UNITR
                STOVL   RDOT            # RDOT /2 VS

                        DELV            # PIPA COUNTS IN PLATFORM COORDS.
                ABVAL   DMP
                        KASCALE
                SL1     BZE
                        SETMIND
DSTORE          STOVL   D               # ACCELERATION USED TO APPROX DRAG
                        VEL
                VXV     UNIT            # UNI = UNIT(V*R)
# Page 849
                UNITR
                STORE   UNI             # .5 UNI                REF COORDS.

                BOFF    DLOAD
                        RELVELSW
                        GETETA
                        3ZEROS
UPDATERT        DSU     DAD             # PIPTIME-TIME/RTO =ELAPSED TIME SINCE
                                        # RTINIT WAS ESTABLISHED.
```

```
                TIME/RTO
                PIPTIME
        STCALL  DTEAROT         # GET PREDICTED TARGET VECTOR RT

                EARROT2
        DOT     SETPD           # SINCE (RT) UNIT VECT, THIS IS 1/4 MAX
                UNI             # LATANG = RT.UNI
                0
        STOVL   LATANG          # LATANG = MAC LATANG / 4

                RT
        CLEAR
                GONEBY          # SHOW HAVE NOT GONE PAST TARGET.
        VXV     DOT             # IF RT*UNITR.UNI NEG, GONEBY=1
                UNITR           # GONEPAST IS CONDITIONAL SW SET IN
                UNI             # FINAL PHASE.
        BPL     SET
                +2
                GONEBY          # SHOW HAVE GONE PAST TARGET.

        VLOAD
                RT
GETANGLE        DOT     DSU             # THETA = ARCCOS(RT.UNITR)
                UNITR
                NEAR1/4         # TO IMPROVE ACCURACY, CALC RANGE BY
        BPL     DAD             # TINYTHET IF HIGH ORDER PART OF
                TINYTHET        # ARCCOS ARGUMENT IS ZERO
                NEAR1/4
        SL1     ACOS
THETDONE        STORE   THETAH          # THETAH/360
                                        # HI WORD, LO BIT =1.32 NM=360 60/16384

        BON     DCOMP
                GONEBY          # =1 IF HAVE GONE PAST TARGET.
                                # (SIGN MAY BECOME ERRATIC VERY NEAR
                                # TARGET DUE TO LOSS OF PRECISION.)
                +1
        STODL   RTGON67         # RANGE ERROR:  NEG IF WILL FALL SHORT.

                D
        DSU     BMN
# Page 850
                .05G
                NO.05G
        SET     VLOAD
                .05GSW
```

```
                        DELVREF
                PUSH    DOT
                        UXA/2
                SL1     DSQ
                PDVL    VSQ             # EXCHANGE WITH PDL.
                DSU     DDV
                        0
                BOV     SQRT
                        NOLDCALC        # OVFL LAST CLEARED IN EARROT2 ABOVE.
                STORE   L/DCALC

NOLDCALC        GOTO
                        60GENRET

NO.05G          CLEAR   GOTO            # THIS WAY FOR DAP. (MAY INTERRUPT)
                        .05GSW          # .05GSW = 102D B3
                        NOLDCALC        # KEEP SINGLE EXIT FOR TARGETING

# Page 851
# SUBROUTINES CALLED BY SCALEPOP (TARGETING):

                BANK    26
                SETLOC  REENTRY1
                BANK

                COUNT*  $$/ENTRY

GETETA          DLOAD   DDV             # D = D +D(-RDOT/HS -2D/V)  DT/2
                                        # DT/2 = 2/2 =1
                        RDOT
                        -HSCALED
                PDDL    DMP
                        D
                        -KSCALE
                DDV     DAD
                        V
                                        # -RDOT/HS FROM PDL.
                DMP     DAD
                        D
                        D
                STORE   D

                BON     DLOAD           # EGSW INDICATES FINAL PHASE
                        EGSW
                        SUBETA
                        THETAH
```

```
                DMP     GOTO
                        KTETA           # = 1000x2PI/(2)E14 163.84
                        UPDATERT

SUBETA          DLOAD   DSU             # SWITCH FROM INERTIAL TO RELATIVE VEL.
                        V
                        VMIN
                BPL     SET
                        SUBETA2
                        RELVELSW

SUBETA2         DLOAD   DMP

                        THETAH
                        KT1             # KT1 = KT
                DDV     GOTO
                        V               # KT = RE(2 PI)/2 VS 16384 163.84/ 2 VSAT
                        UPDATERT

SETMIND         DLOAD   GOTO
                        1BITDP
                        DSTORE

# Page 852
TINYTHET        DSU     ABS             # ENTER WITH X-.249
                        1BITDP +1       # GET 1/4 - MPAC
                SL      SQRT            # SCALE UP BEFORE SQRT
                        13D             # HAS FACTOR FOR UP SCALING
                DMP     GOTO
                        KACOS
                        THETDONE

# Page 853
# * START       INITIAL ROLL ...

                BANK    25
                SETLOC  REENTRY
                BANK

                COUNT*  $$/ENTRY

                                        # MM = 63, 64, ...
INITROLL        BON     BOFF            # IF D- .05G NEG, GO TO LIMITL/D
                        INRLSW
                        INITRL1
                        .05GSW
```

```
                        LIMITL/D

                                        # MM = 64, NOW
                                        #             3
                                        # KA = KA1 LEG  + KA2
                DLOAD   DSQ
                        LEQ
                DMP     DDV
                        LEQ
                        1/KA1           # = 25 /(64  1.8)
                DAD     RTB
                        KA2             # = .2
                        P64             # ROLLC         VI              RDOT
                                        # XXX.XX DEG    XXXXX. FPS      XXXXX. FPS
                STORE   KAT

                DSU     BMN
                        KALIM
                        +4
                DLOAD
                        KALIM
                STORE   KAT
                DLOAD   DSU             # IF V-VFINAL1 NEG, GO TO FINAL PHASE.
                        V
                        VFINAL1
                CLEAR   BPL             # (CAN'T CLEAR INRLSW AFTER HERE: RESTARTS)
                        GONEPAST        # GONEPAST WAS INITIALLY SET=1 TO FORCE
                                        # ROLLC TO REMAIN AS DEFINED BY HEADSUP
                                        # UNTIL START OF P64.  (UNTIL D > .05G)
                        DOEQ
                SSP     GOTO
                        GOTOADDR
                        KEP2            # AND IDLE UNTIL D > 0.2 G.  (NO P66 HERE)
                        INROLOUT        # GO TO LIMITL/D AFTER SETTING INRLSW.

DOEQ            DLOAD   DMP             # D0 = KA3 LEQ + KA4
# Page 854
                        LEQ
                        KA3
                DAD
                        KA4
                STORE   D0              # D0/805
                BDDV    BOV
                        C001            # (-4/25 G) B-8
                        +1              # CLEAR OVFIND, IF ON.
                STODL   C/D0            # (-4/D0) B-8
```

```
                        LAD             # IF V-VFINAL +K(RDOT/V)CUBED POS,L/D=-LAD
                STODL   L/D
                        RDOT
                DDV     PUSH
                        V
                DSQ     DMP
                DDV     DSU
                        1/K44
                        VFINAL
                                        #                   3
                                        # V-VFINAL +(RDOT/V)  / K44     OVFL $

                DAD     BOV
                        V
                        INROLOUT        # GO TO LIMITL/D AFTER SETTING INRLSW.
                BMN     DLOAD
                        INROLOUT        # GO TO LIMITL/D AFTER SETTING INRLSW.
                        LAD
                DCOMP
                STORE   L/D

                                        # SET INRLSW AT END FOR RESTART PROTECTION
INROLOUT        BOFSET                  # END OF PRE .05G PATH OF INITROLL.
                        INRLSW          # SWITCH IS ZERO INITIALLY.
                        LIMITL/D        # (GO TO)

KATEST          DLOAD   DSU             # IF KAT - D POS, GO TO CONSTD
                        KAT
                        D               # IF POS, OUT WITH COMMAND VIA LIMITL/D
                BPL     GOTO
                        LIMITL/D
                        CONSTD

INITRL1         DLOAD   DAD             # IF RDOT + VRCONT POS, GO TO HUNTEST
                        RDOT
                        VRCONT
                BMN     CALL            # IF POSITIVE, FALL INTO HUNTEST.
                        KATEST

                        FOREHUNT        # INITIALIZE HUNTEST.

# Page 855
# * START       HUNT TEST ...
                                        # MM = 64
                SSP                     # INITIALIZE HUNTEST ON FIRST PASS
                        GOTOADDR
```

```
                        HUNTEST         # MUST GO AFTER FOREHUNT FOR RESTARTS.

HUNTEST         DLOAD
                        D
                STODL   A1              # A1/805 = A1/25G

                        LAD
                STODL   TEM1B
                        RDOT
                BMN     DLOAD           # IF RDOT NEG,TEM1B=LAD, OTHERWISE = LEWD
                        AOCALC
                        LEWD
                STODL   TEM1B

                        RDOT
AOCALC          DDV     DAD             # V1 = V + RDOT/TEM1B
                        TEM1B
                        V
                STODL   V1              # V1/2 VS

                        RDOT
                DSQ     DDV             # AO=(V1/V)SQ(D+RDOT SQ/(TEM1B 2 C1 HS)
                        TEM1B
                DDV     DAD
                        2C1HS
                        D
                DMP     DMP
                        V1
                        V1
                DDV
                        VSQUARE
                STODL   AO              # AO/805 = AO/25G

                        RDOT
                BPL     DLOAD
                        V1LEAD
                        AO
                STORE   A1              # A1/25G

V1LEAD          DLOAD   BPL             # IF L/D NEG, V1=V1 - 1000
                        L/D
                        HUNTEST1

                DLOAD   DSU
                        V1
# Page 856
```

```
                VQUIT
        STORE   V1

HUNTEST1        DLOAD   DMP             # ALP = 2 C1 HS A0/LEWD V1 V1
                        A0
                        2C1HS
        DDV     SETPD
                        V1
                        0
        DDV     DDV
                        V1
                        LEWD
        STORE   ALP

        BDSU    BDDV            # FACT1 = V1 / (1 - ALP)
                        BARELY1
                        V1
        STODL   FACT1           # FACT1 / 2VS

                        ALP
        DSU     DMP             # FACT2 = ALP(ALP - 1) / A0
                        BARELY1
                        ALP
        DDV
                        A0
        STORE   FACT2           # FACT2 (25G)

        DMP     DAD
                        Q7              # Q7 / 805 = Q7 / 25G
                        ALP             # VL=FACT1 (1-SQRT(Q7 FACT2 +ALP) )
        SQRT    BDSU
                        BARELY1
        DMP
                        FACT1
        STORE   VL              # VL / 2 VS

        BDSU    DMP             # GAMMAL1 = LEWD (V1-VL)/VL
                        V1
                        LEWD
        DDV
                        VL
        STODL   GAMMAL1         # GAMMAL1 USED IN UPCONTROL.

                                # GAMMAL1 = PDL 22D.
                        VL
        DSU     BMN             # IF VL-VLMIN NEG, GO TO PREFINAL
```

```
                        VLMIN
                        PREFINAL

                DLOAD   DSQ
# Page 857
                        VL
                STODL   VBARS           # VBARS / 4 VS VS

                        HALVE           # IF VSAT-VL NEG, GO TO CONSTD
                DSU     BMN
                        VL
                        BECONSTD        # SET MODE=HUNTEST, CONTINUE IN CONSTD
                STODL   DVL             # DVL / 2VS

                        HALVE
                STORE   VS1             # VS1 = VSAT

                DSU     BMN             # IF V1 GREATER THAN VSAT, GO ON
                        V1
                        GETDHOOK
                BDSU
                        DVL
                STODL   DVL             # DVL = DVL - (VSAT-V1) = V1 - VL
                        V1
                STORE   VS1             # VS1 = V1, IN THIS CASE

GETDHOOK        DLOAD   CALL            # DHOOK=((1-VS1/FACT1) SQ -ALP)/FACT2
                        VS1             # VS1 / 2 VS
                        DHOOKYQ7        # GO CALC DHOOK
                STORE   DHOOK           # DHOOK / 25G

                SR      DDV
                        6               # CHOOK
                        Q7
                DSU
                        CHOOK           # = .25/16 = (-6)
                STORE   AHOOKDV

                DAD     DMP             # GAMMAL= GAMMAL1-CH1 DVL SQ(1+AHOOK DVL)
                        1/16TH
                        CH1
                DMP     DMP
                        DVL
                        DVL
                DDV     DDV
                        DHOOK
```

```
                        VBARS
                BDSU    BMN
                        GAMMAL1
                        NEGAMA
HUNTEST3        STORE   GAMMAL

                DSU                     # GAMMAL1=GAMMAL1 +Q19 (GAMMAL-GAMMAL1)
                        GAMMAL1
                DMP     DAD
# Page 858
                        Q19
                        GAMMAL1
                STODL   GAMMAL1
                        GAMMAL

# Page 859
# *START        RANGE PREDICTION ...
                                        # C(MPAC) = GAMMAL.
RANGER          DSQ     SR2             # COSG = 1-GAMMAL SQ/2, TRUNCATED SERIES
                BDSU
                        HALVE
                STODL   COSG/2
                        VBARS           # E=SQRT(1+VBARS........

                DSU     DMP
                        HALVE
                        VBARS
                DMP     DMP
                        COSG/2
                        COSG/2
                SL2     DAD
                        C1/16           # C1/16 = 1/16
                SQRT    PDDL            # E/4 INTO PDL

                        VBARS
                DMP     DMP             # ASKEP/2 = ARCSIN(VBARS COSG SING/E)
                        COSG/2
                        GAMMAL
                DDV     ASIN
                SL1     PUSH            # ASKEP TO PDL 0.
                STODL   ASKEP           # BALLISTIC RANGE       ASKEP/2PI

                                        # FOR TM, STORE RANGE COMPONENTS OVERLAPPING (SP)
                        VL
                DMP     DAD             # ASP1 = Q2 + Q3 VL
                        Q3
```

```
                Q2
        STORE   ASP1            # FINAL PHASE RANGE     ASP1/2 PI

        PDDL    DSQ             # ASP1 TO PDL 2.
                V1
                                #                   2
                                # ASPUP= -C12 LOG(V1 Q7/VBARS A0)/GAMMAL1
        DMP     DDV
                Q7
                VBARS
        DDV     CALL
                A0
                LOG             # RETURN WITH -LOG IN MPAC

        DMP     DDV
                C12
                GAMMAL1
        STORE   ASPUP           # UP PHASE RANGE        ASPUP / 2 PI
# Page 860
        PDDL    DMP             # ASPUP TO PDL 4.
                KC3             # KC3 = -4 VS VS / 2 PI 805 RE
                                # ASPDWN = KC3 RDOT V / A0
                RDOT
        DMP     DDV
                V
                A0
        DDV     PUSH            # ASPDWN TO PDL 6.
                LAD
        STODL   ASPDWN          # RANGE TO PULL OUT     ASPDWN /2 PI

                Q6
        DSU     DMP             # ASP3 = Q5(Q6-GAMMAL)
                GAMMAL
                Q5
        STOVL   ASP3            # GAMMA CORRECTION      ASP3/2PI

                ASKEP           # GET HI-WD AND
        STODL   ASPS(TM)        # SAVE HI-WORD OF ASP'S FOR TM.

                ASP3
        DAD     DAD
                                # ASPDWN FROM PDL 6.
                                # ASPUP FROM PDL 4.
        DAD     DAD
                                # ASP1 FROM PDL 2.
                                # ASKEP FROM PDL 0.
```

```
                DSU     BOVB            # CLEAR OVFIND.
                        THETAH
                        TCDANZIG
                STORE   DIFF            # DIFF = (ASP-THETAH) / 2 PI
                                        # ASP=ASKEP+ASP1+ASPUP+ASP3+ASPDWN = TOTAL RANGE

                ABS     DSU             # IF ABS(THETAH-ASP) -25NM NEG, GO TO UPSY
                        25NM
                BMN     BON
                        GOTOUPSY
                        HIND
                        GETLEWD

                DLOAD   BPL
                        DIFF
                        DCONSTD         # EVENTUALLY SETS MODE = HUNTEST.
GETLEWD         DLOAD   DMP
                                        # DLEWD = DLEWD (DIFF/(DIFFOLD-DIFF))
                        DLEWD
                        DIFF
                PDDL    DSU
                        DIFFOLD
                        DIFF
# Page 861
                BDDV
LWDSTORE        STADR
                STORE   DLEWD
                DAD     BMN             # IF LEWD+DLEWD NEG, DLEWD=-LEWD/2
                        LEWD
                        LEWDPTR
                BOV
                        LEWDOVFL
                STORE   LEWD

SIDETRAK        EXIT

                CA      EBENTRY
                TS      EBANK

                CA      PRIO16          # DROP GRP 5 RESTART PRIO TO 1 LESS THAN
                TS      PHSPRDT5        # GRP 4.

                TC      PHASCHNG
                OCT     00474           # RESTART GRP 4 AT PRE-HUN.
                                        # FORCE RESTART TO PICK UP IN GRP 4:
                                        # USE PRIO 17 FOR GRP 4 (< SERVICER PRIO)
```

```
                CA      PRIO16          # CONTINUE GRP 5 AT LOWER PRIO THAN EITHER
                                        # GRP 4 OR SERVICER.
                TC      PRIOCHNG

                CAF     ADENDEXT        # SIDETRACK NEXT PASS UNTIL THIS ONE DONE.
                TS      GOTOADDR        # ONLY AFTER RESTART IS LEFT AFTER DETOUR.

                TC      INTPRET

                DLOAD   SET
                        DIFF
                        HIND
                STODL   DIFFOLD         # DIFFOLD / 2 PI

                        Q7F
                STCALL  Q7              # Q7 / 805 FPSS
                        HUNTEST         # (GO TO)

LEWDOVFL        DLOAD
                        NEARONE
                STCALL  LEWD
                        DCONSTD         # (GO TO)  ALSO WILL SET MODE = HUNTEST

LEWDPTR         DLOAD   SR1
                        LEWD
                DCOMP   GOTO
                        LWDSTORE

# Page 862
NEGAMA          DMP     DMP             # ENTER WITH GAMMAL IN MPAC

                        VL
                        1/3RD
                PDDL    DMP             # PUSH GAMMAL VL/3
                        LEWD
                        1/3RD
                PDDL    DAD             # PUSH LEWD/3
                        AHOOKDV
                        1/24TH
                DMP     DMP             # DEL VL = (GAMMAL VL/3)/(LEWD/3-DVL
                        DVL             # (2/3 + AHOOKDV)(CH1 GS/DHOOK VL))
                        CH1
                DDV     DDV
                        DHOOK
                        VL
                BDSU    BDDV
```

```
                                        # LEWD/3
                                        # GAMMAL VL /3
                DAD
                        VL
                STCALL  VL              # VL/2 VS

                        DHOOKYQ7        # GO CALC Q7
                                        # Q7=((1-VL/FACT1)SQ - ALP)/FACT2
                STODL   Q7              # Q7 / 25G

                        VL
                DSQ
                STODL   VBARS           # VBARS / 4 VS VS

                        3ZEROS
                GOTO                    # SET GAMMAL = 0
                        HUNTEST3

DHOOKYQ7        SR1     DDV             # SUBROUTINE TO CALC DHOOK OR Q7
                        FACT1
                BDSU    SL1
                        HALVE
                DSQ     DSU
                        ALP
                DDV     RVQ
                        FACT2

# Page 863
                                        # COME TO PRE-HUNT WHEN RESTART OCCURS AFTER
                                        # HUNTEST IS SIDE-TRACKED AT SIDETRAK.
                                        # PICK UP IN GROUP 4.

PRE-HUNT        TC      INTPRET
                CLEAR   CALL
                        HIND            # HIND  99D BIT 6 FLAG 6
                        FOREHUNT        # RE-INITIALIZE HUNTEST AFTER RE-START.
                GOTO
                        HUNTEST

FOREHUNT        DLOAD                   # INITIALIZE HUNTEST.
                        3ZEROS
                STODL   DIFFOLD
                        DLEWD0
                STODL   DLEWD
                        LEWD1
                STORE   LEWD
```

```
                RVQ

ADENDEXT        CADR    ENDEXIT

# Page 864
# * START       UP CONTROL ...
                                        # MM = 65
GOTOUPSY        RTB                     # END OF HUNTEST
                        P65             # HUNTEST USE OF GRP4 IS DISABLED BY P65
                                        # USE FOR DISPLAY.
                                        # SET MODE = UPCONTRL.
                                        # RETURN FROM P65 DIRECTLY TO UPDONTRL
                                        # VIA THE GOTOADDR AT REFAZE10.

UPCONTRL        DLOAD   DSU             # IF D-140 POS, NOSWITCH =1
                        D               # (SUPPRESS LATERAL SWITCH)
                        C21
                BMN     SET
                        +2
                        NOSWITCH

                DLOAD   DSU             # IF V-V1 POS, GO TO DOWN CONTROL.
                        V
                        V1
                BPL     DLOAD
                        DOWNCNTL
                        D
                DSU     BMN             # IF D- Q7 NEG, GO TO KEP
                        Q7
                        KEP
                DLOAD   BPL             # IF RDOT NEG, DO VLTEST
                        RDOT
                        CONT1

VLTEST          DLOAD   DSU             # IF V-VL-C18 NEG,EGSW=1,MODE=PREDICT3
                        V
                        VL
                DSU     BMN
                        C18
                        PREFINAL

CONT1           DLOAD                   # IF D-A0 POS, L/D = LAD, GO TO LIMITL/D
                        D
                DSU     BMN
                        A0
                        CONT3
```

```
                DLOAD   GOTO
                        LAD
                        STOREL/D

CONT3           DLOAD   DMP             # VREF=FACT1(1-SQRT(FACT2 D + ALP))
                        D
                        FACT2
# Page 865
                DAD     SQRT
                        ALP
                BDSU    DMP
                        BARELY1
                        FACT1
                STORE   VREF            # VREF / 2VS

                BDSU    DMP             # RDOTREF = LEWD(V1-VREF)
                        V1
                        LEWD
                STODL   RDOTREF         # RDOTREF / 2VS

                        VS1
                DSU     BMN             # IF VSAT-VREF NEG, GO TO CONTINU2
                        VREF
                        CONTINU2

                PUSH    PUSH            # VS1-VREF  TO PDL TWICE
                DMP     DDV             # RDHOOK=CHI1(1+DV AHOOKDV/DVL) DV DV
                        AHOOKDV         #       /DHOOK VREF
                        DVL             # WHERE  DV = (VS1-VREF)
                DAD     DMP
                        1/16TH
                        CH1
                DMP     DMP
                                        # VS1-VREF  FROM PDL TWICE.
                DDV
                        DHOOK
                DDV     BDSU
                        VREF
                        RDOTREF         # C(RDOTREF)= LEWD (V1-VREF)
                STORE   RDOTREF         # RDOTREF = RDOTREF - RDHOOK

CONTINU2        DLOAD   DSU
                        D
                        Q7MIN
                BOVB    BMN
                        TCDANZIG        # CLEAR OVFL IND, IF ON.
```

```
                        UPCNTRL3
                DLOAD   DSU
                        A1
                        Q7
                PDDL    DSU
                        D
                        Q7
                DDV     STADR
                STORE   FACTOR          # FACTOR / 25G

# Page 866
# SKIPPER
                                        # DELTA L/D=-((RDOT-RDOTREF)F1 KB1+V-VREF)F1
                                        #       WHERE F1 = FACTOR

UPCNTRL3        DLOAD
                        RDOT
                DSU     DMP             # L/D = LEWD
                        RDOTREF         # -((RDOT-RDOTREF)F1/KB1+V-VREF)F1/KB2
                        FACTOR
                DDV     DAD
                        1/KB1
                        V
                DSU     DMP
                        VREF
                        FACTOR
                DDV     PUSH

                        -1/KB2          # DELTA L/D INTO PDL
                BOV     ABS             # NONLINEAR CIRCUIT FOR REDUCING HIGH GAIN
                        GOMAXL/D
                DSU     BMN
                        PT1/16
                        NEXT1
                DMP     DAD
                        POINT1
                        PT1/16
                SIGN    PUSH            # ATTACH SIGN OF PUSH TO MPAC THEN PUSH

NEXT1           DLOAD   SL4
                                        # DELTA L/D FROM PDL.

                DAD
                        LEWD
NEGTESTS        BOV     PUSH            # L/D TO PDL FOR USE IN NEGTESTS.
                        GOMAXL/D
```

```
                STODL   L/D
                                        # IF D-C20 POS, LATSW =0
                                        # AND IF L/D NEG, L/D = 0.
                        D
                DSU     BMN
                        C20
                        LIMITL/D
                CLEAR   DLOAD
                        LATSW           # =21D.  ROLL OVER TOP, REGARDLESS.
                                        # L/D FROM PDL.
                BPL     DLOAD
                        LIMITL/D
                        3ZEROS
                STCALL  L/D
                        LIMITL/D        # (GO TO)

# Page 867
DCONSTD         DLOAD                   # TWO RANGER ENTRIES TO CONSTD HERE
                        DIFF
                                        # SAVE OLD VALUE OF DIFF FOR NEXT PASS.
                STODL   DIFFOLD         # DIFFOLD / 2 PI

                        Q7F
                STORE   Q7

BECONSTD        SSP     RTB             # A HUNTEST ENTRY INTO CONSTD.
                        GOTOADDR        # RESET MODE TO HUNTEST
                        HUNTEST
                        KILLGRP4        # DEACTIVATE GRP4 FROM HUNTEST.

CONSTD          BOVB
                        TCDANZIG        # CLEAR OVF IND IF ON.

                DLOAD   DMP
                        LEQ
                        C/D0            # C/D0 = -4/D0 B-8
                PDDL    DMP             # LEQ C/D0 INTO PDL
                        2HS             # 2HS / 4 VS VS
                        D0
                DDV     DAD             # RDOTREF = -2 HS D0/V
                        V
                        RDOT
                DMP     DAD
                        K2D             # C/D0 LEQ + K2D(RDOT-RDOTREF) INTO PD
                PDDL
                        D0              # D0 /805
```

```
CONSTD1         BDSU                    # ENTER WITH DREF IN MPAC
                        D
                DMP     DAD
                        K1D             # K2D TERM FROM PUSH
                SL      GOTO
                        8D
                        NEGTESTS        # (GO TO)

DOWNCNTL        BOVB                    # INITIAL PART OF UPCONTROL.
                        TCDANZIG        # CLEAR OVFIND, IF ON.

                DLOAD   SR
                        LAD
                        8D
                PDDL    DSU             # RDTR = LAD(V1-V)
                        V
                        V1
                DMP     DAD
                        LAD
# Page 868
                        RDOT
                DMP     DAD
                        K2D
                                        # PUSH UP LAD.
                PDDL    DSU             # LAD + K2D(RDOT-RDTR) INTO PD
                        V1
                        V
                DSQ     DMP
                        LAD
                DDV     PDDL            # (V1-V)SQ LAD/(2 C1 HS) INTO PD
                        2C1HS
                        V1
                DSQ     DDV
                        VSQUARE
                BDDV    DSU             # DREF = (V/V1)SQ A0 - PD
                        A0
                                        # PUSH UP HERE
                GOTO                    # C(MPAC) = DREF
                        CONSTD1

                                        #              2           2
                                        # DREF = (V/V1)  A0 -(V-V1)  LAD/2 C1 HS
# Page 869
# * START       BALLISTIC PHASE ...
                                        # MM = 66       UPCONTRL ENTRY INTO KEP2
```

```
KEP             RTB     SSP
                        P66             # DISPLAY TRIM GIMBAL ANGLE VALUES.
                        GOTOADDR        # SET GOTOADDR TO KEPLER PHASE.
                        KEP2

                                        # KEP2 CAN ALSO BE STARTED UP DIRECTLY FROM INITROLL
                                        # IN P64.  PROGRAM WILL IDLE IN P64 UNTIL D EXCEEDS
                                        # .2 G BEFORE GOING ON TO P67.

KEP2            DLOAD   DSU             # IF Q7F+KDMIN -D NEG, GO TO FINAL PHASE.
                        Q7FKDMIN        # (Q7F + KDMIN)/805
                        D
                BMN     TLOAD
                        PREFINAL
                                        # SET ROLLHOLD = ROLLC, IN CASE CMDAPMOD
                        ROLLC           # = +1 EVER ENTERED.
                BON     TLOAD           # IF D > .05G, KEEP PRESENT ROLL COMMAND.
                        .05GSW          # IF D < .06G, SET ROLL COMMAND = 0.
                        +2
                        3ZEROS          # SET ROLLC & ROLLHOLD =0.
        +2      STCALL  ROLLC           # (SP ROLLHOLD FOLLOWS DP ROLLC)
                        P62.3           # CALC DESIRED GIMBAL ANGLES AT PRESENT
                                        # RN, VN TO YIELD TRIM ATTITUDE.
                                        # AVAILABLE IN CPHI'S FOR N22.
# Page 870
# START FINAL PHASE ...
                                        # MM = 67
PREFINAL        SSP     RTB
                        GOTOADDR        # RESTART PROTECT: RESET GOTOADDR IF CAME
                        PREFINAL        # FROM HUNTEST.
                        P67             # DISABLES GRP4.  FINE IF FROM HUNTEST, BUT
                                        # MAY ALSO REMOVE RESTART PROTECTION OF
                                        # N69 (P65).
                                        # ROLLC         XRNGERR         DNRNGERR
                                        # XXX.XX DEG    XXXX.X NM       XXXX.XX NM

                SET     SSP
                        EGSW
                        GOTOADDR
                        PREDICT3

PREDICT3        DLOAD   DSU             # IF V-VQUIT NEG, STOP STEERING
                        V
                        VQUIT
                BMN     EXIT
                        STEEROFF
```

```
                CA      EBENTRY         # PRECAUTIONARY.
                TS      EBANK

                CA      TWELVE
BACK            TS      JJ

                CS      V
                INDEX   JJ
                AD      VREFER          # VREF - V, HIGHEST VREF AT END OF TABLE.
                CCS     A               # IF VREF-V POS LOOP BACK
                CCS     JJ              # DECREMENT JJ, JJ CANNOT BE ZERO
                TCF     BACK
                AD      ONE
                TS      TEM1B           # V-VREF IN TEM1B (MUST BE POSITIVE NUM)

                INDEX   JJ
                CS      VREFER
                INDEX   JJ
                AD      VREFER +1       # V(K+1) - V(K)                 (POS NUM)
                XCH     TEM1B
                ZL
                EXTEND
                DV      TEM1B
                TS      GRAD            # GRAD = (V-VREF)/(VK+1 - VK)   (POS NUM)

                CAF     FIVE

# Page 871
BACK2           TS      MM
                CAF     THIRTEEN
                ADS     JJ
                INDEX   A
                CS      VREFER
                INDEX   JJ
                AD      VREFER   +1     # X(K+1) - X(K)
                EXTEND
                MP      GRAD
                INDEX   JJ
                AD      VREFER
                INDEX   MM
                TS      FX              # FX = AK + GRAD (AK+1 - AK)
                CCS     MM
                TCF     BACK2
                XCH     FX      +1      # ZERO FX +1 AND GET DREFR
                AD      D
```

```
                EXTEND
                MP      FX      +5      # F1
                DXCH    MPAC            # MPAC = F1(D-DREF)

                EXTEND
                DCS     RDOT            # FORM RDOTREF - RDOT
                DDOUBL
                DDOUBL
                DDOUBL                  # SCALE UP BY 8 FOR THIS PHASE.
                AD      FX      +3      # RDOTREF
                EXTEND
                MP      FX      +4      # F2
                AD      FX      +2      # RTOGO
                DAS     MPAC            # ADD F2(DADV1-DADVR)
                CA      MPAC
                TS      PREDANG
                                        # L/D = LOD + (THETA- PREDANG)/ Y
                TC      INTPRET

                SR3     DSU
                        THETAH
                BON     BOFF
                        GONEPAST
                        GONEGLAD
                        GONEBY
                        HAVDNRNG
                DLOAD   SET             # SET GONEPAST IF GONEBY SET & LATCH IN-PLACE
                        MAXRNG          # DISPLAY = 9999.9 IF GONEBY
                        GONEPAST
                STCALL  DNRNGERR
                        GONEGLAD

HAVDNRNG        STORE   DNRNGERR        # = (PREDANG - THETA) /360
# Page 872
                DCOMP                   # FALLS SHORT IF NEG, OVERSHOOT IF POS
                BOVB    DDV
                        TCDANZIG        # CLEAR OVFIND IF ON.
                        FX              # FX= DRANGE/D L/D = Y
                SL      BOV
                        5
                        GOMAXL/D
                DAD     BOV
                        LOD
                        GOMAXL/D
                STCALL  L/D
                        GLIMITER        # (GO TO)
```

```
# GONEGLAD AND GOPOSMAX ENTRY POINTS FOR GLIMITER ...

GONEGLAD        DLOAD                   # SET L/D = -LAD
                        GONEGLAD        # (ANY NEGATIVE NUMBER WILL DO)

GOMAXL/D        RTB     DMP             L/D = LAD SIGN(MPAC)
                        SIGNMPAC
                        LAD
                STORE   L/D             # AND FALL INTO GLIMITER SECTION

GLIMITER        DLOAD   DSU             # IF GMAX/2-D POS, GO TO LIMITL/D
                        GMAX/2
                        D
                BPL     DAD             # IF GMAX  -D NEG, GO TO GOPOSLAD
                        LIMITL/D
                        GMAX/2
                BMN     DMP
                        GOPOSLAD
                        2HS
                PDDL    DMP             # 2HS(GMAX-D) INTO PD
                        LEQ
                        1/GMAX
                DAD     DMP
                        LAD
                PDDL    DDV             # 2HS(GMAX-D) (LEQ/GMAX+LAD) INTO PD
                        2HSGMXSQ
                        VSQUARE
                DAD     SQRT            # XLIM = SQRT(PD+(2HSGMAX/V)SQ)
                DAD     BPL             # IF RDOT+XLIM POS, GO TO LIMITL/D
                        RDOT
                        LIMITL/D

GOPOSLAD        DLOAD
                        LAD
STOREL/D        STORE   L/D

# Page 873
LIMITL/D        DLOAD
                        L/D
                STODL   L/D1
                        VSQUARE

                BON                     # NO LATERAL CONTROL IF PAST TARGET
                        GONEPAST
                        L355
```

```
                DMP     DAD             # Y= KLAT VSQUARE + LATBIAS
                        KLAT
                        LATBIAS         # Y INTO PD
L350            PDDL    ABS             # IF ABS(L/D)-L/DCMINR NEG, GO TO L353
                        L/D
                DSU     BMN
                        L/DCMINR
                        L353
                DLOAD   SIGN            # IF K2ROLL LATANG NEG, GO TO L357
                        LATANG
                        K2ROLL
                BMN     DLOAD
                        L357
                SR1     PUSH            # Y = Y/2
L353            DLOAD   SIGN            # IF LATANG SIGN(K2ROLL)-Y POS, SWITCH
                        LATANG
                        K2ROLL
                DSU
                BMN     DLOAD
                        L355
                        K2ROLL
                BONCLR  DCOMP           # IF NOSWITCH =1, K2ROLL= K2ROLL
                        NOSWITCH
                        L355
                STORE   K2ROLL          # K2ROLL = -K2ROLL

L355            DLOAD   DDV             # ROLLC = ACOS( (L/D1) / LAD)
                        L/D1
                        LAD             # MPAC SET TO +-1 IF OVERFLOW***
                SR1     ACOS
                SIGN    CLEAR
                        K2ROLL
                        NOSWITCH
                STORE   ROLLC

ENDEXIT         EXIT

OVERNOUT        CA      BIT13           # ENTRYDSP =92D B13
                MASK    CM/FLAGS
                EXTEND
                BZF     NODISKY         # OMIT DISPLAY.
# Page 874
                CA      ENTRYVN         # ALL ENTRY DISPLAYS ARE DONE HERE.
                TC      BANKCALL
                CADR    REGODSPR        # NO ABORT IF DISKY IN USE
```

```
NODISKY         INHINT
                CCS     NEWJOB          # PROTECT READACCS GRP 5, IF SIDETRACKED.
                TC      CHANG1
SERVNOUT        TC      POSTJUMP        # ( COME HERE FROM P67.3 )
                CADR    SERVEXIT        # AND END AVERAGEG JOB VIA ENDOJOB.

# Page 875
# DISPLAY WHEN V IS LESS THAN VQUIT.

STEEROFF        EXIT
                CA      EBENTRY         # PRECAUTIONARY.
                TS      EBANK

                CA      PRIO16          # 2 LESS THAN NTRYPRIO.
                TC      NOVAC
                EBANK=  AOG             # ANY EB HERE
                2CADR   P67.1           # START UP REMAINDER OF P67

                                        # RTOGO         LAT             LONG
                                        # XXXX.X NM     XXX.XX DEG      XXX.XX DEG

                TC      2PHSCHNG        # INHINT/RELINT DONE.
                OCT     00414           # 4.41 RESTART FOR P67.1 DISPLAY JOB.
                OCT     10035           # SERVICER 5.3 RESTART.

                CA      P67.2CAD        # HEREAFTER, DO LAT, LONG.
                TS      GOTOADDR

                TC      INTPRET
                GOTO
P67.2CAD                P67.2           # CONTINUE FOR LAT, LONG THIS TIME.

L357            DLOAD   SIGN            # L/D = L/DCMINR SIGN(L/D)
                        L/DCMINR
                        L/D
                STCALL  L/D1
                        L355            # (GO TO)

# Page 876
# TABLE USED FOR SUB-ORBITAL REFERENCE TRAJECTORY CONTROL.

VREFER          DEC     .019288         # REFERENCE VELOCITY SCALED V/51532.3946
                DEC     .040809         # 13 POINTS ARE STORED AS THE INDEPENDENT
                DEC     .076107         # VARIABLE AND THEN SIX 13-POINT FUNCTIONS
                DEC     .122156         # OF V ARE STORED CONSECUTIVELY
                DEC     .165546
```

```
DEC     .196012
DEC     .271945
DEC     .309533
DEC     .356222
DEC     .404192
DEC     .448067
DEC     .456023
DEC     .67918          # HIGHVELOCITY FOR SAFETY.

DEC     -.010337        # DRANGE/DA     SCALED DRDA/(2700/805)
DEC     -.016550
DEC     -.026935
DEC     -.042039
DEC     -.058974
DEC     -.070721
DEC     -.098538
DEC     -.107482
DEC     -.147762
DEC     -.193289
DEC     -.602557
DEC     -.99999
DEC     -.99999

DEC     -.0478599 B-3   # -DRANGE/DRDOT
DEC     -.0683663 B-3   # SCALED ((2VS/8 2700) DR/DRDOT)
DEC     -.1343468 B-3
DEC     -.2759846 B-3
DEC     -.4731437 B-3
DEC     -.6472087 B-3
DEC     -1.171693 B-3
DEC     -1.466382 B-3
DEC     -1.905171 B-3
DEC     -2.547990 B-3
DEC     -4.151220 B-3
DEC     -5.813617 B-3
DEC     -5.813617 B-3

# Page 877
DEC     -.0134001  B3   # RDOTREF       SCALED (8 RDT/2VS)
DEC     -.013947   B3
DEC     -.013462   B3
DEC     -.011813   B3
DEC     -.0095631  B3
DEC     -.00806946 B3
DEC     -.006828   B3
DEC     -.00806946 B3
```

```
                DEC     -.0109791  B3
                DEC     -.0151498  B3
                DEC     -.0179817  B3
                DEC     -.0159061  B3
                DEC     -.0159061  B3

                DEC     .0008067        # RANGE TO GO SCALED RTOGO/2700
                DEC     .0032963        #       8.9
                DEC     .0081852        #       22.1
                DEC     .017148
                DEC     .027926
                DEC     .037
                DEC     .063298
                DEC     .077889
                DEC     .098815
                DEC     .127519
                DEC     .186963
                DEC     .238148
                DEC     .294185185

                DEC     -.051099        # -AREF/805
                DEC     -.074534
                DEC     -.101242
                DEC     -.116646
                DEC     -.122360
                DEC     -.127081
                DEC     -.147453
                DEC     -.155528
                DEC     -.149565
                DEC     -.118509
                DEC     -.034907
                DEC     -.007950
                DEC     -.007950

# Page 878
                DEC     .004491         # DRANGE/D L/D SCALED Y/2700
                DEC     .008081
                DEC     .016030
                DEC     .035815
                DEC     .069422
                DEC     .104519
                DEC     .122
                DEC     .172407
                DEC     .252852
                DEC     .363148
                DEC     .512963
```

```
                DEC     .558519
                DEC     .558519         # END OF STORED REFERENCE

# Page 879
# REENTRY CONSTANTS.

# DEFINED BY EQUALS

DEC15           =       LOW4
#GAMMAL1        =       22D

MAXRNG          2OCT    1663106755      # DNRNGERR = 9999.9 IF GONEPAST=1

                BANK    26
                SETLOC  REENTRY1
                BANK

                COUNT*  $$/ENTRY

BARELY1         =       NEARONE         # COMMON TO BOTH DISK,DANCE, DEFND IN TFF
#1BITDP                                 # COMMON TO BOTH DISK AND DANCE. DEFND IN VECPOINT.

1/12TH          DEC     .083333         # DP 1/12 USES HI WORD IN 1/3 BELOW
1/3RD           2DEC    .3333333333     # DP 1/3

1/16TH          =       DP2(-4)

# BELOW:  VS = VSAT = 25766.1973 FT/SEC

#         RE = 21,202,900 FEET

LEWD1           2DEC    .15

POINT1          2DEC    .1

POINT2          2DEC    .2              # .2

DLEWD0          2DEC    -.05            # -.05

GMAX/2          2DEC    .16             # 8 GS / 2

3ZEROS          EQUALS  HI6ZEROS
NEAR1/4         2OCT    0777700000      # 1/4 LESS 1 BIT IN UPPER PART.

C18             2DEC    .0097026346     # 500/2VS
```

```
Q7FKDMIN        2DEC    .0080745342     # 6.5/805  (Q7F +KDMIN) = 6 + .5)

C1/16           =       DP2(-4)

Q3              2DEC    .167003132      # .07 2VS/21600
# Page 880
Q5              2DEC    .326388889      # .3 23500/21600

Q6              2DEC    .0349           # 2 DEG. APPROX 820/23500

Q7F             2DEC    .0074534161     # 6/805  (VALUE OF Q7 IN FIXED MEM.)

Q19             =       HALVE           # Q19 = .5

Q21             2DEC    .0231481481     # 500/21600

Q22             2DEC    -.053333333     # -1152/21600

VLMIN           2DEC    .34929485       # 18000/2 VS

VMIN            =       FOURTH          # (VS/2) / 2VS
C12             2DEC    .00684572901    # 32 28500/(21202900 2 PI)

1/KB1           2DEC    .29411765       # 1 / 3.4

-1/KB2          2DEC    -.0057074322 B4 # - 1/(.0034 2 VS) EXP +4

VQUIT           2DEC    .019405269      # 1000 /2VS

C20             2DEC    .21739130       # (175 FPSS) LIFT UP IF ABOVE C20

C21             2DEC    .17391304       # 140/805

25NM            2DEC    .0011574074     # 25/21600      (25 NAUT MILES)

K1D             2DEC    .0314453125     # =C16 805/256 = .01 805/256

K2D             2DEC    -.201298418     # -C17 2VS/256 = -.001 2VS/256

KVSCALE         2DEC    .81491944       # 12800/(2 VS .3048)

KASCALE         2DEC    .97657358       # 5.85 16384/(4 .3048 100 805)

KTETA           2DEC*   .383495203 E2 B-14* # 1000 2PI/16384(163.84)

KT1             2DEC*   .157788327 E2 B-14* # RE(2PI)/2 VS(16384) 163.84
```

```
.05G            2DEC    .002            # .05/25

LATBIAS         2DEC    .00003          # APPRX .5 NM/ 4(21600/2 PI)

KWE             2DEC    .120056652 B-1

KACOS           2DEC    .004973592      # 1/32(2PI)

CHOOK           2DEC    1 B-6           # .25/16
# Page 881
1/24TH          2DEC    .0833333333 B-1

CH1             2DEC    .32 B1          # 16 CH1/25 = 16 (1) /25

KC3             2DEC    -.0247622232    # -(4 VS VS/ 2 PI 805 RE)

VRCONT          2DEC    .0135836886     # 700/2 VSAT

HALVE           EQUALS  HIDPHALF
FOURTH          EQUALS  HIDP1/4

1/GMAX          EQUALS  HALVE           # 4/GMAX = 4 / 8
2HS             2DEC    .0172786611     # 2 28500 25 32.2/(4 VS VS)

2HSGMXSQ        2DEC    .0000305717     # (2 28500 8 32.2/ 4 VS VS)SQ

C001            2DEC    -.000625        # -(4/25)/256   LEQ/D0 CONST

POINT8          2DEC    .8

2C1HS           2DEC    .0215983264     # 2 1.25 28500 805/(2 VS)SQ

PT1/16          2DEC    .1 B-4

1/K44           2DEC    .00260929464    # 2 VS/19749550

VFINAL          2DEC    .51618016       # 26600/2 VS

VFINAL1         2DEC    .523942273      # = 27000 / 2 VS

1/KA1           2DEC    .30048077       # 25/(1.3 64)

KA2             2DEC    .008            # .2/25

KA3             2DEC    .44720497       # = 90 4/805
```

```
KA4             2DEC    .049689441      # 40/805

KALIM           2DEC    .06             # 1.5/25

Q7MIN           =       KA4             # = 40/805 = .049689441
-HSCALED        2DEC    -.55305018      # -28500/2 VS

-KSCALE         2DEC    -.0312424837    # -805/VS

COS15           2DEC    .965

LATSLOPE        EQUALS  1/12TH
# ... END OF RE-ENTRY CONSTANTS ...
```

Uses -VREL 226, .05GSW 121, 60GENRET 223, A 80, A0 145, A1 229, AHOOKDV 226, AK 200, ALP 229, ALPHAV 177, ALT 157, AOG 214, ASKEP 229, ASP1 229, ASP3 229, ASPDWN 229, ASPS 229, ASPS(TM) 223, ASPUP 229, C/D0 229, CMDAPMOD 214, COMMAND 169, COSG/2 229, COUNT 142, D 226, D0 229, DEL 232, DELV 159, DELVREF 224, DHOOK 226, DIFF 226, DIFFOLD 226, DISPLAYS 59, DLEWD 226, DNRNGERR 229, DT/2 177, DTEAROT 226, DV 241, DVL 229, E2 236, EBANK 80, EGSW 119, ENTRYDSP 117, ENTRYVN 161, ERADFLAG 99, FACT1 226, FACT2 226, FACTOR 226, FX 226, GAMMA 232, GAMMAL 229, GAMMAL1 229, GMAX 229, GONEBY 123, GONEPAST 119, GOTOADDR 226, GRAD 226, HEADSUP 216, HI6ZEROS 71, HIDP1/4 71, HIDPHALF 71, HIND 119, INRLSW 121, IT 185, JJ 229, K2ROLL 226, KAT 229, KLAT 226, KT 181, L 80, L/D 226, L/D1 226, L/DCALC 229, L/DCMINR 226, LAD 226, LADPAD 198, LAT 157, LAT(SPL) 224, LATANG 229, LATITUDE 191, LATSW 121, LEQ 226, LEWD 226, LOD 226, LODPAD 198, LONG 157, LUNAFLAG 107, MM 226, MODE 145, MPAC 145, NEWJOB 138, NOSWITCH 119, ORBITAL 59, OVFIND 140, PHSPRDT5 154, PIPTIME 159, POSEXIT 216, PREDANG 229, Q2 229, Q7 223, RANGE 179, RDOT 229, RDOTREF 159, REENTRY 65, REENTRY1 65, RELVELSW 119, RESTART 57, RN 159, ROLLC 214, ROLLHOLD 216, RT 226, RTEAST 226, RTGON67 231, RTINIT 226, RTNORM 226, SAVE 191, SQ 156, SR 80, STATE 138, TC 169, TEM1B 226, TFF 179, THETA 148, THETAH 229, TIME/RTO 226, TM 219, UNI 226, UNITR 174, UNITV 226, UNITW 172, UXA/2 226, V 229, V1 145, VBARS 229, VEL 226, VL 229, VN 159, VREF 159, VS1 229, VSQUARE 226, and XRNGERR 229.

3.5.13 cm body attitude

1290 ⟨*cm body attitude* 1290⟩≡ (857a)

⟨*Page CM0883* 1291⟩
⟨*Page CM0884* 1293⟩
⟨*Page CM0885* 1295⟩
⟨*Page CM0886* 1296⟩
⟨*Page CM0887* 1297⟩
⟨*Page CM0888* 1299⟩
⟨*Page CM0889* 1300a⟩

1291 ⟨*Page CM0883* 1291⟩≡ (1290 2657)

```
                BANK    35

                SETLOC  BODYATT
                BANK

                COUNT   37/CMBAT

# PDL 12D - 15D SAFE.

# VALUE OF GIMBAL AND BODY ANGLES VALID AT PIP TIME ARE SAVED DURING  READACCS.

                EBANK=  RTINIT          # LET INTERPRETER SET EB

CM/POSE         TC      INTPRET         # COME HERE VIA AVEGEXIT.

                SETPD   VLOAD
                        0
                        VN              # KVSCALE = (12800/ .3048) /2VS
                VXSC    PDVL
                        -KVSCALE        # KVSCALE = .81491944
                        UNITW           # FULL UNIT VECTOR
                VXV     VXSC            # VREL = V - WE*R
                        UNITR
                        KWE
                VAD     STADR
                STORE   -VREL           # SAVE FOR ENTRY GUIDANCE.      REF COORDS

                UNIT    LXA,1
                        36D             # ABVAL( -VREL) TO X1
                STORE   UXA/2           # -UVREL                        REF COORDS

                VXV     VCOMP
                        UNITR           # .5 UNIT                       REF COORDS
                UNIT    SSP             # THE FOLLOWING IS TO PROVIDE A STABLE
                        S1              # UN FOR THE END OF THE TERMINAL PHASE.
SPVQUIT         DEC     .019405         # 1000/ 2 VS
                TIX,1   VLOAD           # IF V-VQUIT POS, BRANCH.
                        CM/POSE2        # SAME UYA IN OLDUYA
                        OLDUYA          # OTHERWISE CONTINUE TO USE OLDUYA
CM/POSE2        STORE   UYA/2           #                               REF COORDS

                STORE   OLDUYA          # RESTORE, OR SAVE AS CASE MAY BE.

                VXV     VCOMP
                        UXA/2           # FINISH OBTAINING TRAJECTORY TRIAD.
```

```
                    VSL1
                    STORE    UZA/2            #                                REF COORDS
```

Uses -VREL 226, A 80, AVEGEXIT 159, BODYATT 69, COUNT 142, EBANK 80, OLDUYA 226, RTINIT 226, S1 85, SAVE 191, TC 169, UN 188, UNITR 174, UNITW 172, UXA/2 226, UYA/2 226, UZA/2 226, V 229, VN 159, and X1 85.

1293 ⟨*Page CM0884* 1293⟩≡ (1290 2657)

```
                TLOAD                   # PICK UP CDUX, CDUY, CDUZ CORRESPONDING
                        AOG/PIP         # TO PIPUP TIME IN 2'S C AND SAVE.
  CM/TRIO       STODL   24D
                        25D             # AIG/PIP

                RTB     PUSH            # TO PDL0
                        CDULOGIC
                COS
                STODL   UBX/2           # CI /2
                                        # AIG/PIP FROM PDL 0
                SIN     DCOMP
                STODL   UBX/2 +4        # -SI /2
                        26D             # AMG/PIP
                RTB     PUSH            # TO PDL 0
                        CDULOGIC
                SIN     PDDL            # XCH PDL 0.  SAVE SM /2
                COS     PDDL            # CM /2 TO PDL 2
                        0               # SM /2
                DCOMP   VXSC
                        UBX/2
                VSL1                    # NOISE WON'T OVFL
                STODL   UBY/2           # =(-SMCI, NOISE, SMSI)/2
                        2               # CM /2 REPLACES NOISE
                STODL   UBY/2 +2        # UBY/2=(-SMCI, CM, SMSI)/2
                        24D             # AOG/PIP
                RTB     PUSH            # TO PDL 4
                        CDULOGIC
                SIN     PDDL            # XCH PDL 4.  SAVE SO /2
                COS     VXSC            # CO /2
                        UBY/2
                STODL   UBY/2           # UBY/2=(-COSMCI, COCM, COSMSI)/4
                        4D              # SO /2
                DMP     DCOMP
                        UBX/2 +4        # -SI /2
                DAD
                        UBY/2           # INCREMENT BY (SOSI /4)
                STODL   UBY/2
                                        # SO /2 FROM PDL 4
                DMP     DAD
                        UBX/2           # CI /2
                        UBY/2 +4
                STOVL   UBY/2 +4        # YB/4                          PLATFORM COORDS

                                        # YB = (-COSMCI + SOSI , COCM , COSMSI + SOCI )
```

```
        UBY/2
VXM     VSL2
        REFSMMAT        # .5 UNIT
STODL   UBY/2           # YB/2 DONE                    REF COORDS
```

Uses AIG 214, AIG/PIP 214, AMG 214, AMG/PIP 214, AOG 214, AOG/PIP 214, CDUX 80, CDUY 80, CDUZ 80, REFSMMAT 172, SAVE 191, UBX/2 226, and UBY/2 226.

1295 ⟨*Page CM0885* 1295⟩≡ (1290 2657)

```
                        # CM /2 FROM PDL 2
VXSC    VSL1
        UBX/2
STODL   UBX/2           # =( CMCI, NOISE, -CMSI)/2
STADR                   # SM /2 FROM PDL 0
STOVL   UBX/2 +2        # SM /2 REPLACES NOISE
        UBX/2           # XB/2                          PLATFORM COORDS

                        # XB = ( CMCI , SM , -CMSI )

VXM     VSL1
        REFSMMAT        # .5 UNIT
STORE   UBX/2           # XB/2 DONE                     REF COORDS

VXV     VSL1
        UBY/2
STOVL   UBZ/2           # ZB/2 DONE                     REF COORDS

                        # EQUIVALENT TO
                        # ZB = ( SOSMCI + COSI , -SOCM , -SOSMSI + COCI )

        UXA/2           # -UVREL/2 = -UVA/2
VXV     UNIT            # GET UNIT(-UVREL*UBY)/2 = UL/2
        UBY/2           # YB/2
PUSH    DOT             # UL/2 TO PDL 0,5
        UZA/2           # UNA/2
STOVL   COSTH           # COS(ROLL)/4
        0               # UL/2

DOT
        UYA/2
STCALL  SINTH           # -SIN(ROLL)/4
        ARCTRIG
STOVL   6D              # -(ROLL/180) /2
        UBY/2
DOT     SL1             # -UVA.UBY = -SIN(BETA)
        UXA/2           # -UVREL/2
ARCSIN
STOVL   7D              # -(BETA/180) /2
        UBX/2           # XB/2
DOT                     # UL.UBX = -SIN(ALFA)
        0               # UL/2
STOVL   SINTH           # -SIN(ALFA)/4
DOT                     # UL/2 FROM PDL 0
        UBZ/2
```

```
STCALL  COSTH           # COS(ALFA)/2
        ARCTRIG
STOVL   8D              # -(ALFA/180) /2
        UNITR           # UR/2                          REF COORDS
DOT     SL1
```

Uses ALFA/180 214, BETA/180 214, COSTH 148, REFSMMAT 172, ROLL/180 214, SINTH 148, UBX/2 226, UBY/2 226, UBZ/2 226, UNITR 174, UXA/2 226, UYA/2 226, and UZA/2 226.

1296 ⟨*Page CM0886* 1296⟩≡ (1290 2657)

```
        UZA/2           # MORE ACCURATE AT LARGE ARG.
ARCCOS
STORE   10D             # (-GAMA/180)/2

TLOAD   EXIT            # ANGLES IN MPAC IN THE ORDER
                        # -( (ROLL, BETA, ALFA) /180)/2
        6D              # THESE VALUES CORRECT AT PIPUP TIME.
```

Uses GAMA 216, MPAC 145, and UZA/2 226.

1297 ⟨*Page CM0887* 1297⟩≡ (1290 2657)

```
# BASIC SUBROUTINE TO UPDATE ATTITUDE ANGLES

                EBANK=  AOG

CM/ATUP         CA      EBAOG
                TS      EBANK
CMTR1           INDEX   FIXLOC
                CS      10D             # (GAMA/180)/2
                XCH     GAMA
                TS      L

                INHINT
                                        # MUST REMAIN INHINTED UNTIL UPDATE OF BODY
                                        # ANGLES, SO THAT GAMDIFSW IS VALID FIRST PASS
                                        # INDICATOR.

                CS      CM/FLAGS
                MASK    BIT11           # GAMDIFSW=94D BIT11    INITLY=0
                EXTEND                  # DON'T CALC GAMA DOT UNTIL HAVE FORMD
                                        # ONE DIFFERENCE.
                BZF     DOGAMDOT        # IS OK, GO ON.
                ADS     CM/FLAGS        # KNOW BIT IS 0
                TC      NOGAMDOT        # SET GAMDOT = 0

DOGAMDOT        CS      L
                AD      GAMA            # DEL GAMA/360= T GAMDOT/360
                EXTEND
                MP      TCDU            # TCDU = .1 SEC, T = 2 SEC.
                TS      GAMDOT          # GAMA DOT TCDU / 180

                EXTEND                  # IGNORE GAMDOT IF LEQ .5 DEG/SEC
                BZMF    +2
                COM
                AD      FIVE
                EXTEND
                BZMF    +3              # SET GAMDOT=+0 AS TAG IF TOO SMALL.

NOGAMDOT        CA      ZERO            # COME HERE INHINTED
                TS      GAMDOT
                                        # FOR NOW LEAVE IN 2'S C
                                        # UPDATE ANGLES BY CORRECTING EULER ANG
                                        # FOR ACCRUED INCREMENT SINCE PIPUP
                                        # R = R EUIL + R(NOW) - R(PIPUP)
                CS      MPAC            # GET (R EUL/180) /2
                DOUBLE                  # POSSIBLE OVERFLOW
```

```
TC      CORANGOV        # CORRECT FOR OVFL IF ANY
EXTEND
SU      ROLL/PIP        # GET INCR SINCE PIPUP
AD      ROLL/180        # ONLY SINGLE OVFL POSSIBLE.
TC      CORANGOV        # CORRECT FOR OVFL IF ANY
```

Uses AOG 214, DEL 232, EBANK 80, FIXLOC 140, GAMA 216, GAMDIFSW 119, GAMDOT 216, L 80, LEQ 226, MPAC 145, ROLL/180 214, ROLL/PIP 214, and TC 169.

1299 ⟨*Page CM0888* 1299⟩≡ (1290 2657)

```
                TS      TEMPROLL

                CS      MPAC +2         # GET (ALFA EUL/180) /2
                DOUBLE                  # SAME AS FOR ROLL.  NEEDED FOR EXT ATM DAP
                TC      CORANGOV        # CORRECT FOR OVFL IF ANY
                EXTEND
                SU      ALFA/PIP
                AD      ALFA/180
                TC      CORANGOV        # CORRECT FOR OVFL IF ANY
                TS      TEMPALFA

                CS      MPAC +1         # GET (BETA EUL/180) /2
CMTR2           DOUBLE
                EXTEND
                SU      BETA/PIP
                AD      BETA/180
                XCH     TEMPBETA        # OVFL NOT EXPECTED.

                CA      EBANK3
                TS      EBANK

                EBANK=  PHSNAME5
                EXTEND
                DCA     REPOSADR        # THIS ASSUMES THAT THE         TC  PHASCHNG
                DXCH    PHSNAME5        # IS NOT CHANGED IN             OCT 10035
                                        # SERVICER.

                CA      EBAOG
                TS      EBANK

                EBANK=  AOG
REDOPOSE        EXTEND                  # RE-STARTS COME HERE
                DCA     TEMPROLL
                DXCH    ROLL/180
                CA      TEMPBETA
                TS      BETA/180

                RELINT

                TC      INTPRET         # CAN'T TC DANZIG AFTER PHASCHNG.
CM/POSE3        VLOAD   ABVAL           # RETURN FROM CM/ATUP.  (RESTART)
                        VN              # 2(-7) M/CS
                STORE   VMAGI           # FOR DISPLAY ON CALL.

                GOTO
```

```
                        POSEXIT         # ENDEXIT, STARTENT, OR SCALEPOP.

CORANGOV        TS      L
                TC      Q
                INDEX   A
```

Uses A 80, ALFA/180 214, ALFA/PIP 214, AOG 214, BETA/180 214, BETA/PIP 214, EBANK 80, L 80, MPAC 145, PHSNAME5 167, POSEXIT 216, Q 80, RESTART 57, ROLL/180 214, TC 169, TEMPALFA 223, TEMPBETA 223, TEMPROLL 223, VMAGI 229, and VN 159.

1300a ⟨*Page CM0889* 1300a⟩≡ (1290 2657)

```
                CA      LIMITS
                ADS     L
                TC      Q               # COSTS 2 MCT TO USE.  SEE ANGOVCOR.

-KVSCALE        2DEC    -.81491944      # -12800/(2 VS .3048)

TCDU            DEC     .1              # TCDU = .1 SEC.

                EBANK=  AOG
REPOSADR        2CADR   REDOPOSE
```

Uses AOG 214, EBANK 80, L 80, Q 80, and TC 169.

3.5.14 p37 p70 code

1300b ⟨*p37 p70 code* 1300b⟩≡ (857a 2764)
⟨*Page CM0890* 1301⟩

1301 ⟨*Page CM0890* 1301⟩≡ (1300b)

```
# Page 890
                BANK    31
                SETLOC  RTE1
                BANK

                EBANK=  RTEDVD
                COUNT   31/P37

# PROGRAM DESCRIPTION:  P37, RETURN TO EARTH
#
# DESCRIPTION
#       A RETURN TO EARTH TRAJECTORY IS COMPUTED PROVIDED THE CSM IS OUTSIDE THE LUNAR SPHERE O
#       TIME OF IGNITION.  INITIALLY A CONIC TRAJECTORY IS DETERMINED AND RESULTING IGNITION AN
#       DISPLAYED TO THE ASTRONAUT.  THEN IF THE ASTRONAUT SO DESIRES, A PRECISION TRAJECTORY I
#       RESULTING IGNITION AND REENTRY PARAMETERS DISPLAYED.  UPON FINAL ACCEPTANCE BY THE ASTR
#       COMPUTES AND STORES THE TARGET PARAMETERS FOR RETURN TO EARTH FOR USE BY SPS PROGRAM (P
#
# CALLING SEQUENCE
#       L       TC      P37
#
# SUBROUTINES CALLED
#       PREC100
#               V2T100
#               RTENCK2
#               RTENCK3
#               TIMERAD
#               PARAM
#       V2T100
#               GAMDV10
#               XT1LIM
#               DVCALC
#       RTENCK1
#               INTSTALL
#               INTEGRVS
#       RTEVN
#               RETDISP
#               TMRAD100
#               AUGEKUGL
#               LAT-LONG
#       TMRAD100
#               TIMERAD
#       INVC100
#               CSMPREC
#       GETERAD
#       TIMETHET
```

```
#       P370ALRM
#       VN1645
#       POLY
#
# ERASABLE INITIALIZATION REQUIRED
#       CSM STATE VECTOR
# Page 891
#       NJETSFLG        NUMBER OF JETS IF THE RCS PROPULSION SYSTEM SELECTED    STATE
#
# ASTRONAUT INPUT
#       SPRTETIG        TIME OF IGNITION (OVERLAYS TIG)                         DP
#       VPRED           DESIRED CHANGE IN VELOCITY AT TIG(PROGRM COMPUTED IF 0) DP
#       GAMMAEI         DESIRED FLIGHT PATH ANGLE AT REENTRY (COMPUTED IF 0)    DP
#       OPTION2         PROPULSION SYSTEM OPTION                                SP
#
# OUTPUT
#    CONIC OR PRECISION TRAJECTORY DISPLAY
#       VPRED           VELOCITY MAGNITUDE AT 400,000 FT. ENTRY ALTITUDE        DP
#       T3TOT4          TRANSIT TIME TO 400,000 FT. ENTRY ALTITUDE              DP
#       GAMMAEI         FLIGHT PATH ANGLE AT 400,00 FT. ENTRY ALTITUDE          DP
#       DELVLVC         INITIAL VELOCITY CHANGE VECTOR IN LOCAL VERTICAL COORD. VECTO
#       LAT(SPL)        LATITUDE OF THE LANDING SITE                            DP
#       LNG(SPL)        LONGITUDE OF THE LANDING SITE                           DP
#    TARGETING COMPUTATION DISPLAY
#       TIG             RECOMPUTED TIG BASED ON THRUST OPTION                   DP
#       TTOGO           TIME FROM TIG                                           DP
#       +MGA            POSITIVE MIDDLE GIMBAL ANGLE                            DP
#    THRUST PROGRAM COMMUNICATION
#       XDELVFLG        EXTERNAL DELTA V FLAG                                   STATE
#       NORMSW          LAMBERT AIMPT ROTATION SWITCH                           STATE
#       ECSTEER         CROSS PRODUCT STEERING CONSTANT                         SP
#       RTARG           CONICALLY INTEGRATED REENTRY POSITION VECTOR            VECTO
#       TPASS4          REENTRY TIME                                            DP

P37             TC      PHASCHNG        # P37 IS NOT RESTARTABLE
                OCT     4

                TC      INTPRET
                AXT,1   SXA,1
                OCT     04000
                        ECSTEER
                DLOAD
                        ZEROVECS
                STORE   VPRED
                STORE   GAMMAEI
                EXIT
```

```
                CAF     V6N33RTE        # INPUT TIG     STORED IN SPRTETIG
                TCR     P370GOF         #               OVERLAYED WITH TIG
                TCF     -2              # DISPLAY NEW DATA
                CAF     V6N60RTE        # INPUT REENTRY ANGLE IN GAMMAEI
                TCR     P37GFRB1        #       AND DESIRED DELTA V IN RETDVD
                TCF     -2              # DISPLAY NEW DATA
RTE299          TC      INTPRET
                SSP     DLOAD
                        OVFIND
                        0
                        VPRED
# Page 892
                STODL   RTEDVD
                        GAMMAEI
                STODL   RTEGAM2D
                        1RTEB13
                STODL   CONICX1
                        C4RTE
                STCALL  MAMAX1
                        INVC100         # GET R(T1)/,V(T1)/,UR1/,UH/
                CLEAR   DLOAD
                        SLOWFLG
                        RTEDVD
                BPL     ABS
                        RTE317
                STORE   RTEDVD
                DLOAD   DSU
                        R(T1)
                        K1RTE
                BMN     SET
                        RTE317
                        SLOWFLG
RTE317          DLOAD   EXIT
                        R(T1)
                TC      POLY
                DEC     2
                2DEC    181000434. B-31
                2DEC    1.50785145 B-2
                2DEC*   -6.49993057 E-9 B27*
                2DEC*   9.76938926 E-18 B56*
                TC      INTPRET
                SL1
                STODL   MAMAX2          # C0+C1*R+C2*R**2+C3*R**3=MAMAX2 B30
                        M9RTEB28
                STODL   NN1A
                        K2RTE
```

```
RTE320          STODL   RCON            # RCON=K2
                        RTEGAM2D
                BZE     BDSU
                        RTE340          # GOTORTE340 IF REENTRY ANGLE NOT INPUT
                        1RTEB2
                PUSH    COS             #                                       PL02D
                PDDL    SIN
                BDDV    STADR           #                                       PL00D
                STCALL  X(T2)           # X(T2)=COT(GAM2D)                      B0
                        RTE360
RTE340          DLOAD   DSU
                        R(T1)
# Page 893
                        K1RTE
                BMN     DLOAD
                        RTE350
                        K4RTE
                STCALL  X(T2)           # X(T2)=K4
                        RTE360
RTE350          DLOAD
                        K3RTE
                STORE   X(T2)           # X(T2)=K3
RTE360          CALL
                        V2T100
                BZE     GOTO
                        RTE367
                        RTEALRM
RTE367          VLOAD
                        R(T1)/
                STODL   RVEC
                        RCON
                STOVL   RDESIRED
                        V2(T1)/
                STCALL  VVEC
                        TMRAD100
                DAD
                        T1
                STODL   T2
                        RTEGAM2D
                BZE     GOTO
                        RTE369
                        RTE372
RTE369          VLOAD   ABVAL
                        V(T2)/
                EXIT
                TC      POLY
```

```
                DEC     2
                2DEC    0
                2DEC    -4.8760771 E-2 B4
                2DEC    4.5419476 E-4 B11
                2DEC    -1.4317675 E-6 B18

                TC      INTPRET
                DAD
                        RTED1
                SL3     GOTO            # X(T2),=D1+D2V2+D3V2**2+D4V2**3
                        RTE373
RTE372          DLOAD                   # X(T2),=X(T2)
                        X(T2)
RTE373          DSU     PUSH            # X(T2)ERR                              B0 PL02D
# Page 894
                        X(T2)
                VLOAD   UNIT
                        R(T2)/          #                                       B58
                STCALL  ALPHAV
                        GETERAD
                DAD
                        E3RTE
                PUSH    DSU             # RCON,=(E1/1+E2BETA11)**.5)+E3         B29 PL04D
                        RCON
                ABS     DSU
                        EPC2RTE
                BMN     GOTO
                        RTE374
                        RTE375
RTE374          DLOAD   ABS
                        00D
                DSU     BMN
                        EPC3RTE
                        P37E
RTE375          DLOAD   DAD
                        NN1A
                        1RTEB28
                BMN     SLOAD
                        RTE380
                        OCT605
                GOTO
                        RTEALRM         # TOO MANY ITERATIONS
RTE380          STORE   NN1A
                DSU     BZE
                        M8RTEB28
                        RTE385
```

```
                DLOAD   DSU
                        OOD
                        DRCON
                NORM    PDDL            # X(T2)ERR-X(T2)ERR,=Z1                PL06D
                        X1
                        RPRE'
                DSU     DDV             # X(T2)PRI-X(T2)=Z2                     PL04D
                        X(T2)
                DMP     SL*             # DX(T2)=X(T2)ERR(Z2/Z1)
                        OOD
                        0,1
                GOTO
                        RTE390
RTE385          DLOAD                   # DX(T2)=X(T2)ERR
                        OOD
RTE390          STODL   16D             # DX(T2)                                PL02D
                STADR
                STODL   RCON            # RCON=RCON,
                BOV
# Page 895
                        RTE360
                STODL   DRCON           # X(T2)ERR,=X(T2)ERR
                        X(T2)
                STODL   RPRE'           # X(T2)PRI=X(T2)
                        16D
                DAD
                        X(T2)
                STCALL  X(T2)           # X(T2)=X(T2)+DX(T2)
                        RTE360          # REITERATE
P37E            CALL                    # DISPLAY CONIC SOLUTION
                        RTEVN
RTE505          DLOAD   DMP
                        PCON
                        BETA1
                BDSU    BZE
                        RCON
                        RTE510
                BMN     DLOAD
                        RTE510
                        1RTEB2
                GOTO                    # ENTRY NEAR APOGEE
                        RTE515
RTE510          DLOAD   DCOMP           # ENTRY NEAR PERIGEE
                        1RTEB2
RTE515          STCALL  PHI2
                        PREC100         # PRECISION TRAJECTORY COMPUTATION
```

```
RTE625          BZE
                        P37G
RTEALRM         CALL
                        P370ALRM
                EXIT
                TCF     P37             # RECYCLE AFTER ALARM DISPLAY

# RETURN TO EARTH DISPLAY SUBROUTINE

RTEVN           STQ     CALL
                        VNSTORE
                        RTEDISP         # DISPLAY PREPARATION
                EXIT
                CAF     V6N61RTE        # LATITUDE,LONGITUDE,BLANK
                TCR     P370GOFR        #   IN LAT(SPL),LNG(SPL),-
                CAF     FOUR
                TCR     37BLANK +1
                TCF     +5
                TCF     P37             # RECYCLE
                CAF     V6N39RTE        # T21 HRS,MIN,SEC IN T3TOT4
                TCR     P370GOF
                TCF     P37             # RECYCLE
                CAF     V6N60RTE        # DISPLAY BLANK,V(T2),FPA2
                TCR     P37GFRB1        #   IN -,VPRED,GAMMAEI
# Page 896
                TCF     P37             # RECYCLE
                CAF     V6N81RTE        # DISPLAY DELTA V (LV) IN DELVLVC
                TCR     P370GOF
                TCF     P37             # RECYCLE
                TCR     INTPRET
                GOTO
                        VNSTORE

# PRECISION DISPLAY, TARGETING COMPUTATION AND RTE END PROCESSING

P37G            CALL
                        RTEVN
                EXIT
P37N            CAF     SEVEN
                TS      OPTION1
                CAF     ONE
                TS      OPTION2
                CAF     V4N06RTE        # DISPLAY RCS OR SPS OPTION  SPS ASSUMED
                TCR     P370GOF
                TCF     -2              # RECYCLE
                TC      INTPRET         # PROCEED
```

```
                SETPD   SLOAD
                        OOD
                        OPTION2
                DSU     BZE
                        1RTEB13
                        P37Q
                SLOAD   NORM            # SPS
                        EMDOT
                        X1
                PDDL    GOTO
                        VCSPS
                        P37T
P37Q            DLOAD   BON             # RCS
                        MDOTRCS
                        NJETSFLG
                        P37R
                SL1
P37R            SL1
                NORM    PDDL
                        X1
                        VCRCS
P37T            PDDL    DDV             # DV/VC                 B7 -B5 = B2     PL02D
                        DV
                EXIT
                TC      POLY
                DEC     1
                2DEC    5.66240507 E-4 B-3
                2DEC    9.79487897 E-1 B-1
# Page 897
                2DEC    -.388281955 B1
                TC      INTPRET
                PUSH    SLOAD           # (1-E)**(-DV/VC)=A             B3      PL04D
                        WEIGHT/G
                DMP     DDV             # DTB=(MO/MDOT)A        B16+B3-B3=B16   PL00D
                SL*     DMP
                        0 -12D,1
                        CSUBT
                BDSU
                        T1
                STORE   TIG             # TIG=T1-CT*DTB                 B28
                EXIT
                CAF     V6N33RTE        # DISPLAY BIASED TIG
                TCR     P370GOF
                TCF     -2
                CAF     ZERO
                TS      VHFCNT
```

```
                TS      TRKMKCNT
                TC      INTPRET
                CALL                    # CONICALLY INTEGRATE FROM R1,V1 OVER T12
                        RTENCK1
                VLOAD   UNIT            #                                       PL00D
                        R(T2)/
                PDVL    VXSC            # UR2                           B1      PL06D
                        UR1/
                        MCOS7.5
                PDVL    VXSC            # -UR1(COS7.5)                  B1      PL12D
                        UH/
                        MSIN7.5
                VAD     DOT             # K/=-UR1(COS7.5)-UH(SIN7.5)    B2      PL00D
                DAD     BMN
                        MCOS22.5
                        P37W
                VLOAD   DOT             # K/ . UR2 GR COS22.5
                        UH/
                        R(T2)/
                BMN     DLOAD
                        P37U
                        THETA165
                PUSH    GOTO
                        P37V
P37U            DLOAD   PUSH
                        THETA210
P37V            SIN
                STODL   SNTH
                COS     CLEAR
                        RVSW
                STOVL   CSTH
                        R(T1)/
# Page 898
                STOVL   RVEC
                        V2(T1)/
                STCALL  VVEC
                        TIMETHET
P37W            CLEAR   CLEAR
                        XDELVFLG
                        NORMSW
                SET     VLOAD
                        FINALFLG
                STADR
                STODL   RTARG
                        T
                DAD
```

```
                        T1
                STOVL   TPASS4
                        V2(T1)/
                VSU
                        V(T1)/
                STCALL  DELVSIN
                        VN1645
                GOTO
                        P37W

# SUBROUTINE TO GO TO GOFLASHR AND BLANK R1

P37GFRB1        EXTEND
                QXCH    SPRTEX
                TCR     P370GOFR
37BLANK         CAF     ONE
                TCR     BLANKET
                TCF     ENDOFJOB
                TC      SPRTEX          # RECYCLE
                TCF     P37PROC         # PROCEED

# SUBROUTINE TO GO TO GOFLASHR

P370GOFR        EXTEND
                QXCH    RTENCKEX
                TCR     BANKCALL
                CADR    GOFLASHR
                TCF     GOTOP00H        # TERMINATE
                TCF     +3
                TCF     +4
                TC      RTENCKEX        # IMMEDIATE RETURN
                INDEX   RTENCKEX        # PROCEED
                TCF     0 +4
                INDEX   RTENCKEX        # RECYCLE
                TCF     0 +3

# SUBROUTINE TO GO TO GOFLASH

# Page 899
P370GOF         EXTEND
                QXCH    SPRTEX
                TCR     BANKCALL
                CADR    GOFLASH
                TCF     GOTOP00H
                TCF     +2
                TC      SPRTEX
```

```
P37PROC         INDEX   SPRTEX
                TCF     0 +1
V6N33RTE        VN      0633
V4N06RTE        VN      0406
V6N61RTE        VN      0661
V6N39RTE        VN      0639
V6N60RTE        VN      0660
V6N81RTE        VN      0681
                BANK    32
                SETLOC  RTE
                BANK
                COUNT   32/RTE

# Page 900
# ALARM DISPLAY SUBROUTINE

P370ALRM        STQ     EXIT
                        SPRTEX
                CA      MPAC
                TC      VARALARM
                CAF     V5N09RTE
                TC      BANKCALL
                CADR    GOFLASH
                TCF     GOTOP00H
                TCF     -4
                TC      INTPRET
                GOTO
                        SPRTEX
V5N09RTE        VN      0509

# Page 901
# TIME RADIUS CALLING SUBROUTINE
#
# INPUT
#       RVEC            INITIAL POSITION VECTOR                                VECTOR  B29
#       VVEC            INITIAL VELOCITY VECTOR                                VECTOR  B7
#       RDESIRED        FINAL RADIUS FOR WHICH TRANSFER TIME IS TO BE COMPUTED DP      B29
#       CONICX1         X1 SETTING FOR CONIC SUBROUTINES  -2=EARTH             SP      B14
#
# OUTPUT
#       R(T2)/          FINAL POSITION VECTOR                                  VECTOR  B29
#       V(T2)/          FINAL VELOCITY VECTOR                                  VECTOR  B7
#       T12             TRANSFER TIME TO FINAL RADIUS                          DP      B28

TMRAD100        STQ     CLEAR
                        RTENCKEX
```

```
                        RVSW
                AXC,2   SXA,2
                OCT     20000
                        SGNRDOT
                LXC,1   CALL
                        CONICX1
                        TIMERAD
                STOVL   V(T2)/                                          PLOOI
                STADR
                STODL   R(T2)/
                        T
                STCALL  T12
                        RTENCKEX

# Page 902
# DISPLAY CALCULATION SUBROUTINE
#
# DESCRIPTION
#       OUTPUT FOR DISPLAY IS CONVERTED TO PROPER UNITS AND PLACED IN OUTPUT STORAGE
#       COMPUTATION FOR DETERMINING LANDING SITE LATITUDE AND LONGITUDE IS INCLUDED I
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             RTEDISP
#
# SUBROUTINES CALLED
#       TMRAD100
#       AUGEKUGL
#       LAT-LONG
#
# ERASABLE INITIALIZATION REQUIRED
#    PUSHLIST
#       NONE
#    MPAC
#       NONE
#    OTHER
#       R(T2)/          FINAL POSITION VECTOR                           VECTO
#       V(T2)/          FINAL VELOCITY VECTOR                           VECTO
#       T2              FINAL TIME                                      DP
#       V2(T1)/         POST IMPULSE INITIAL VELOCITY VECTOR            VECTO
#       V(T1)/          INITIAL VELOCITY VECTOR                         VECTO
#       UR1/            UNIT INITIAL VECTOR                             VECTO
#       UH/             UNIT HORIZONTAL VECTOR                          VECTO
#
# OUTPUT
#       VPRED           VELOCITY MAGNITUDE AT 400,000 FT. ENTRY ALTITUDE        DP
```

```
#       T3TOT4          TRANSIT TIME TO 400,000 FT. ENTRY ALTITUDE              DP      B28
#       GAMMAEI         FLIGHT PATH ANGLE AT 400,000 FT. ENTRY ALTITUDE         DP      B0
#       DELVLVC         INITIAL VELOCITY CHANGE VECTOR IN LOCAL VERTICAL COORD. VECTOR  B7
#       LAT(SPL)        LATITUDE OF THE LANDING SITE                            DP      B0
#       LNG(SPL)        LONGITUDE OF THE LANDING SITE                           DP      B0

RTEDISP         STQ     VLOAD           # DISPLAY
                        SPRTEX
                        V(T2)/
                UNIT    PDDL
                        36D
                STODL   VPRED           # V(T2)
                        T2
                DSU
                        SPRTETIG
                STOVL   T3TOT4          # T21
                        R(T2)/
                UNIT    DOT
                SL1

# Page 903
                ARCCOS  BDSU
                        1RTEB2
                STOVL   GAMMAEI         # FLIGHT PATH ANGLE T2
                        V2(T1)/
                VSU     PUSH
                        V(T1)/
                DOT     DCOMP
                        UR1/
                PDVL    PUSH
                DLOAD   PDVL
                        ZERORTE
                DOT     VDEF
                        UH/
                VSL1
                STODL   DELVLVC
                        DELVLVC
                BOFF    DCOMP
                        RETROFLG
                        RTD18
                STORE   DELVLVC         # NEGATE X COMPONENT, RETROGRADE
RTD18           VLOAD   ABVAL
                        DELVLVC
                STOVL   VGDISP
                        R(T2)/
                STORE   RVEC            # ***** LANDING SITE COMPUTATION *****
```

```
                ABVAL   DSU
                        30480RTE
                STOVL   RDESIRED
                        V(T2)/
                STCALL  VVEC
                        TMRAD100        # R3,V3,T23 FROM TIMERAD
                VLOAD   UNIT
                        R(T2)/
                PDVL    UNIT            # UR3                                   PL06D
                        V(T2)/
                DOT     SL1             # GAMMAE=ARCSIN(UR3 . UV3)              PL00D
                ARCSIN  PDDL            # V(T3)                                 PL02D
                        36D
                PDDL    ABS
                PUSH    CALL            # /GAMMAE/                              PL04D
                        AUGEKUGL        # PHIE                                  PL06D
                DAD     DAD
                        T12             # T23
                        T2
                STORE   02D             # T(LS)=T2&T23&TE
                SLOAD   BZE
                        P37RANGE
                        RTD22
                STORE   04D             # OVERRIDE RANGE (PCR 261)
RTD22           DLOAD   SIN

# Page 904
                        04D
                STODL   LNG(SPL)        # LNG(SPL)=SIN(PHIE)                    PL04D
                COS
                STORE   LAT(SPL)        # LAT(SPL)=COS(PHIE)
                VLOAD   UNIT
                        R(T2)/
                PUSH    PUSH
                PDVL    UNIT            #                                     PL22D
                        V(T2)/
                PDVL    VXV
                VXV     UNIT            # UH3=UNIT(UR3 X UV3 X UR3)             PL10D
                VXSC    PDVL
                        LNG(SPL)
                VXSC    VAD             #                                     PL04D
                        LAT(SPL)
                CLEAR   CLEAR           # T(LS) IN MPAC
                        ERADFLAG
                        LUNAFLAG
                STODL   ALPHAV          # ALPHAV=UR3(COSPHIE)+UH3(SINPHIE)      PL02D
```

```
                CALL
                        LAT-LONG
                DLOAD
                        LAT
                STODL   LAT(SPL)        # LATITUDE LANDING SITE  *****
                        LONG
                STCALL  LNG(SPL)        # LONGITUDE LANDING SITE *****
                        SPRTEX
                COUNT*  $$/RTE

# Page 905
# INITIAL VECTOR SUBROUTINE
#
# DESCRIPTION
#       A PRECISION INTEGRATION OF THE STATE VECTOR TO THE TIME OF IGNITION IS PERFORMED. PRECO
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             INVC100
#
# NORMAL EXIT MODE
#       AT L+2 OF CALLING SEQUENCE WITH MPAC = 0
#
# ALARM EXIT MODE
#       AT L+2 OF CALLING SEQUENCE WITH MPAC = OCTAL 612 FOR STATE VECTOR IN MOONS SPHERE OF IN
#
# SUBROUTINES CALLED
#       CSMPREC
#
# ERASABLE INITIALIZATION REQUIRED
#    PUSHLIST
#       NONE
#    MPAC
#       NONE
#    OTHER
#       SPRTETIG        TIME OF IGNITION                                        DP      B28
#       CSM STATE VECTOR
#
# OUTPUT
#       R(T1)/          INITIAL POSITION VECTOR AT TIG                          VECTOR  B29
#       V(T1)/          INITIAL VELOCITY VECTOR AT TIG                          VECTOR  B7
#       T1              INITIAL VECTOR TIME (TIG)                               DP      B28
#       UR1/            UNIT INITIAL VECTOR                                     VECTOR  B1
#       UH/             UNIT HORIZONTAL VECTOR                                  VECTOR  B1
#       CFPA            COSINE OF INITIAL FLIGHT PATH ANGLE                     DP      B1
```

```
INVC100         STQ     DLOAD
                        SPRTEX
                        SPRTETIG
                STCALL  TDEC1
                        CSMPREC         # PRECISION INTEGRATION  R0,V0 TO R1,V1
                VLOAD   SXA,2
                        RATT
                        P(T1)
                STOVL   R(T1)/
                        VATT
                STODL   V(T1)/
                        TAT
                STORE   T1
                SLOAD   BZE
                        P(T1)
# Page 906
                        INVC109
INVC107         SLOAD   GOTO
                        OCT612
                        RTEALRM         # R1,V1 NOT IN PROPER SPHERE OF INFLUENCE
INVC109         VLOAD   UNIT
                        R(T1)/
                STODL   UR1/            # UR1/                                  B1
                        36D
                STOVL   R(T1)           # R(T1)                                 B29
                        V(T1)/
                UNIT
                STORE   UV1/
                DOT     SL1
                        UR1/
                STORE   CFPA            # CFPA                                  B1
                ABS     DSU
                        EPC1RTE
                BMN     DLOAD
                        INVC115         # NOT NEAR RECTILINEAR
                        1RTEB2
                PDDL    PUSH
                        ZERORTE
                VDEF    PUSH            # N/ = (0,0,1)
                GOTO
                        INVC120
INVC115         VLOAD   VXV
                        UR1/
                        UV1/
                PUSH                    # N/ = UR X UV                          B2
INVC120         CLEAR   DLOAD
```

```
                        RETROFLG
                PUSH    BPL
                        INVC125
                VLOAD   VCOMP           # RETROGRADE ORBIT
                PUSH    SET
                        RETROFLG
INVC125         VLOAD
                VXV     UNIT
                        UR1/
                STORE   UH/             # UH/                                    B1
                GOTO
                        SPRTEX

# Page 907
# PRECISION TRAJECTORY COMPUTATION SUBROUTINE
#
# DESCRIPTION
#       A NUMERICALLY INTEGRATED TRAJECTORY IS GENERATED WHICH FOR THE RETURN TO EARTH PROBLEM
#       CONSTRAINTS (RCON AND X(T2)) ACHIEVED BY THE INITIAL CONIC TRAJECTORY AND MEETS THE DVD
#       AS POSSIBLE.
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             PREC100
#
# NORMAL EXIT MODE
#       AT L+2 OF CALLING SEQUENCE WITH MPAC = 0
#
# ALARM EXIT MODE
#       AT L+2 OF CALLING SEQUENCE WITH MPAC =
#               OCTAL 605       FOR EXCESS ITERATIONS
#               OCTAL 613       FOR REENTRY ANGLE OUT OF LIMITS
#
# SUBROUTINES CALLED
#       INTSTALL
#       RTENCK2
#       RTENCK3
#       TIMERAD
#       PARAM
#       V2T100
#
# ERASABLE INITIALIZATION REQUIRED
#    PUSHLIST
#       NONE
#    MPAC
#       NONE
```

```
#    OTHER
#       R(T1)/          INITIAL POSITION VECTOR                                VECTO
#       V2(T1)/         POST IMPULSE INITIAL VELOCITY VECTOR                   VECTO
#       V(T1)/          INITIAL VELOCITY VECTOR                                VECTO
#       T1              INITIAL VECTOR TIME                                    DP
#       T12             INITIAL TO FINAL POSITION TIME                         DP
#       RCON            CONIC FINAL RADIUS                                     DP
#       R(T1)           MAGNITUDE OF INITIAL POSITION VECTOR                   DP
#       X(T2)           COTANGENT OF FINAL FLIGHT PATH ANGLE                   DP
#       X(T1)           COTANGENT OF INITIAL FLIGHT PATH ANGLE                 DP
#       RTEDVD          DELTA VELOCITY DESIRED                                 DP
#       MAMAX1          MAJOR AXIS LIMIT FOR LOWER BOUND ON GAMDV ITERATOR     DP
#       MAMAX2          MAJOR AXIS LIMIT FOR UPPER BOUND ON GAMDV ITERATOR     DP
#       UR1/            UNIT INITIAL VECTOR                                    VECTO
#       UH/             UNIT HORIZONTAL VECTOR                                 VECTO
#       BETA1           1+X(T2)**2                                             DP
#       PHI2            PERIGEE OR APOGEE INDICATOR                            DP
#
# Page 908
#
# OUTPUT
#       V2(T1)/         POST IMPULSE INITIAL VELOCITY VECTOR                   VECTO
#       R(T2)/          FINAL POSITION VECTOR                                  VECTO
#       V(T2)/          FINAL VELOCITY VECTOR                                  VECTO
#       T2              FINAL TIME                                             DP
#
# DEBRIS
#       RD              FINAL R DESIRED                                        DP
#       R/APRE          R/A                                                    DP
#       P/RPRE          P/R                                                    DP
#       RPRE            MAGNITUDE OF R(T2)/                                    DP
#       X(T2)PRE        COTANGENT OF GAMMA2                                    DP
#       DT12            CORRECTION TO FINAL TIME T2                            DP
#       RCON            FINAL RADIUS                                           DP
#       DRCON           DELTA RCON                                             DP

PREC100         STQ     DLOAD
                        SPRTEX
                        10RTE
                STODL   NN1A
                        RCON
                STORE   RD
PREC120         DLOAD
                        2RTEB1
                STODL   DT21PR          # DT21PR = POSMAX
                        M15RTE
```

```
                STCALL  NN2
                        RTENCK3
PREC125         CALL
                        PARAM
                DLOAD
                        P
                STODL   P/RPRE
                        R1A
                STODL   R/APRE
                        R1
                STODL   RPRE
                        COGA
                SL
                        5
                STORE   X(T2)PRE
                DCOMP   DAD
                        X(T2)
                ABS     DSU
                        EPC4RTE
                BOV     BMN
                        PREC130
                        PREC175

# DESIRED REENTRY ANGLE NOT ACHIEVED

# Page 909
PREC130         DLOAD   BMN
                        NN2
                        PREC140
PREC132         SLOAD   GOTO            # TOO MANY ITERATIONS
                        OCT605          #       EXIT WITH ALARM
                        PRECX

# DETERMINE RADIUS AT WHICH THE DESIRED REENTRY ANGLE WILL BE ACHIEVED

PREC140         DLOAD   BZE
                        NN1A
                        PREC162
PREC150         DLOAD   SL2                                             B2
                        P/RPRE
                DMP     SL1             # BETA2=BETA1*P/R                B2      PL02
                        BETA1
                PUSH    DLOAD
                        R/APRE
                SL4     DMP
                        OOD
```

```
                BDSU    BMN             # BETA3=1-BETA2*R/A
                        1RTEB4
                        PREC160
PREC155         SL2     SQRT
                DMP     BDSU
                        PHI2
                        1RTEB3
                NORM    PDDL
                        X1
                SR1     DDV             # BETA4=BETA2/(1-PHI2*SQRT(BETA3))
                SL*     GOTO                                            B1
                        0       -1,1
                        PREC165
PREC160         DLOAD   NORM
                        R/APRE
                        X1
                BDDV    SL*                                             B1
                        1RTEB1
                        0       -6,1
                GOTO
                        PREC165
PREC162         DLOAD   NORM
                        RPRE
                        X1
                BDDV    SL*             # BETA4=RD/RPRE                  B1
                        RD
                        0 -1,1
PREC165         SETPD   PUSH
                        0
                DSU     DCOMP
# Page 910
                        1RTEB1
                STORE   BETA12
                BMN     DLOAD
                        PREC168
                        X(T2)PRE
                BMN     DLOAD
                        PREC167
                        BETA12
                DCOMP
                STORE   BETA12
PREC167         DLOAD
                        BETA12
PREC168         ABS     DSU
                        EPC6RTE
                BMN     DLOAD
```

```
                        PREC175
                DMP     SL1
                        RPRE
                PUSH                    # RF = NEW RADIUS
PREC170         DLOAD   DAD
                        NN2
                        1RTEB28
                STORE   NN2
                VLOAD   SET
                        R(T2)/
                        RVSW
                STOVL   RVEC
                        V(T2)/
                SIGN
                        BETA12
                STODL   VVEC
                        1RTEB1
                SIGN    DCOMP
                        BETA12
                LXA,2   DLOAD
                        MPAC
                LXC,1   SXA,2
                        CONICX1
                        SGNRDOT
                STCALL  RDESIRED        # COMPUTED DT12 (CORRECTION TO TIME OF
                        TIMERAD         #       NEW RADIUS)
                DLOAD   SIGN
                        T
                        BETA12
                PDDL    NORM            # DT21=(PHI4)DT21                       PL02D
                        DT21PR
                        X1
                BDDV    SL*
                        00D
                        0 -3,1
# Page 911
                PUSH    BMN             # BETA13=(DT21)/(DT21PR)        R3      PL04D
                        PREC172
                DLOAD   PDDL            # BETA14=1                      B0      PL04D
                        2RTEB1
                GOTO
                        PREC173
PREC172         DLOAD   PDDL            # BETA14=.6                     B0      PL04D
                        M.6RTE
PREC173         DDV     DSU
                        02D
```

```
                        1RTEB3
                BMN     DLOAD
                        PREC174
                DMP
                        DT21PR
                STORE   00D             # DT21=(BETA14)DT21PR          B28
PREC174         DLOAD   PUSH
                        00D
                STCALL  DT21PR
                        RTENCK2
                GOTO
                        PREC125
PREC175         DLOAD   DSU
                        RPRE
                        RD
                PUSH    ABS             # RPRE-RD = RERR
                DSU     BMN
                        EPC7RTE
                        PREC220

# DESIRED RADIUS HAS NOT BEEN ACHIEVED

                DLOAD   BZE
                        NN1A
                        PREC132         # TOO MANY ITERATIONS
                DSU     BZE
                        10RTE
                        PREC207
PREC205         DLOAD   DSU             # NOT FIRST PASS OF ITERATION
                        RPRE'
                        RPRE            # RPRE'-RPRE                    B29/B27
                NORM    BDDV
                        X2
                        DRCON
                SL*     PUSH            # DRCON/(RPRE'-RPRE)=S          B2
                        0 -2,2
                DAD     BOV             # S GR +4 OR LS -4
                        1RTEB1
                        PREC205M
                ABS     DSU
# Page 912
                        1RTEB1
                BMN
                        PREC206
PREC205M        DLOAD   DCOMP           # S GR 0 OR LS -4
                        2RTEB1
```

```
                PDDL                    # S=-4                          B2
PREC206         DLOAD   DMP
                SL2
                STORE   DRCON           # DRCON=S(RERR)                 B29
                DAD
                        RCON
                STORE   RCON            # RCON+DRCON=RCON
                GOTO
                        PREC210
PREC207         DLOAD   DSQ             # FIRST PASS OF ITERATION
                        RD
                NORM    SR1
                        X1
                PDDL    NORM
                        RPRE
                        X2
                XSU,1   BDDV
                        X2
                SR*
                        0 -1,1
                STORE   RCON            # RD**2/RPRE=RCON
                DSU
                        RD
                STORE   DRCON           # RCON-RD=DRCON
PREC210         DLOAD                   # PREPARE FOR NEXT ITERATION
                        RPRE
                STODL   RPRE'
                        NN1A
                DSU
                        1RTEB28
                STCALL  NN1A
                        V2T100
                BHIZ    GOTO
                        PREC120
                        PRECX

# DESIRED RADIUS ACHIEVED

                SETLOC  RTE2
                BANK
PREC220         DLOAD   DSU
                        X(T2)
                        X(T2)PRE
                ABS     DSU
                        EPC8RTE
# Page 913
```

```
                BMN     SLOAD
                        PREC225
                        OCT613
                GOTO
                        PRECX           # IF REENTRY ANGLE OUT OF LIMITS

EPC8RTE         2DEC    .002

OCT613          OCT     613

# DESIRED FINAL ANGLE HAS BEEN REACHED.

                SETLOC  RTE
                BANK
PREC225         DLOAD
                        ZERORTE
PRECX           GOTO
                        SPRTEX

# Page 914
# INTEGRATION CALLING SUBROUTINE
#
# DESCRIPTION
#       PERFORMS CONIC AND PRECISION INTEGRATIONS USING SUBROUTINE INTEGRVS.  THERE A
#       RTENCK2, AND RTENCK3) FOR DIFFERENT SOURCES OF INPUT AND DIFFERENT OPTIONS.
#       WHICH INCLUDES SET UP OF INPUT FOR THE PARAM SUBROUTINE.
#
# RTENCK1 (CONIC INTEGRATION)
#
#    CALLING SEQUENCE
#       L       CALL
#       L+1             RTENCK1
#
#    ERASABLE INITIALIZATION REQUIRED
#       SAME AS FOR THE RTENCK3 ENTRANCE
#
# RTENCK2 (PRECISION INTEGRATION)
#
#    CALLING SEQUENCE
#       L       CALL
#       L+1             RTENCK2
#
#    ERASABLE INITIALIZATION REQUIRED
#       PUSHLIST
#           PUSHLOC-2   INTEGRATION TIME DT12 (CORRECTION TO T2)                DP
#       OTHER
```

```
#           R(T2)/      FINAL POSITION VECTOR                                   VECTOR  B29
#           V(T2)/      FINAL VELOCITY VECTOR                                   VECTOR  B7
#           T2          FINAL TIME                                              DP      B28
#
# RTENCK3 (PRECISION INTEGRATION)
#
#    CALLING SEQUENCE
#       L       CALL
#       L+1             RTENCK3
#
#    ERASABLE INITIALIZATION REQUIRED
#       R(T1)/          INITIAL POSITION VECTOR                                 VECTOR  B29
#       V2(T1)/         POST IMPULSE INITIAL VELOCITY VECTOR                    VECTOR  B7
#       T1              INITIAL VECTOR TIME                                     DP      B28
#       T2              FINAL TIME                                              DP      B28
#
# EXIT MODE
#       AT L+2 OF CALLING SEQUENCE
#
# SUBROUTINES CALLED
#       INTSTALL
#       INTEGRVS
#
# OUTPUT
#    PUSHLIST
# Page 915
#       PUSHLOC-6       FINAL POSITION VECTOR R(T2)/                            VECTOR  B29
#       X1              CONICS MUTABLE ENTRY FOR EARTH (-2)                     SP      B14
#    MPAC
#                       FINAL VELOCITY VECTOR V(T2)/                            VECTOR  B7
#    OTHER
#       R(T2)/          AS IN PUSHLIST
#       V(T2)/          AS IN MPAC
#       T2              FINAL TIME                                              DP      B28

                SETLOC  RTE3
                BANK
RTENCK1         STQ     CALL
                        RTENCKEX
                        INTSTALL
                VLOAD   SET
                        R(T1)/
                        INTYPFLG
                GOTO
                        RTENCK3B
```

```
RTENCK2         STQ     CALL
                        RTENCKEX
                        INTSTALL
                CLEAR   VLOAD
                        INTYPFLG
                        R(T2)/
                STOVL   RCV
                        V(T2)/
                STODL   VCV
                        T2
                STORE   TET
                DAD
                GOTO
                        RTENCK3D

RTENCK3         STQ     CALL
                        RTENCKEX
                        INTSTALL
RTENCK3A        VLOAD   CLEAR
                        R(T1)/
                        INTYPFLG
RTENCK3B        STOVL   RCV
                        V2(T1)/
                STODL   VCV
                        T1
                STODL   TET
                        T2
# Page 916
RTENCK3D        STORE   TDEC1
                CLEAR   CALL
                        MOONFLAG
                        INTEGRVS
                VLOAD
                        RATT
                STORE   R(T2)/
                PDDL    LXC,1
                        TAT
                        CONICX1
                STOVL   T2
                        VATT
                STORE   V(T2)/
                GOTO
                        RTENCKEX
                SETLOC  RTE
                BANK
```

```
# Page 917
# V2(T1) COMPUTATION SUBROUTINE
#
# DESCRIPTION
#       A POST IMPULSE VELOCITY VECTOR (V2(T1)) IS COMPUTED WHICH EITHER
#       (1)     MEETS THE INPUT VELOCITY CHANGE DESIRED (RTEDVD) IN A MINIMUM TIME      OR
#       (2)     IF A VELOCITY CHANGE ISN'T SPECIFIED (RTEDVD = 0), A V2(T1) IS COMPUTED WHICH M
#               AND CONSEQUENTLY FUEL.
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             V2T100
#
# NORMAL EXIT MODE
#       AT L+2 OF CALLING SEQUENCE WITH MPAC = 0
#
# ALARM EXIT MODE
#       AT L+2 OF CALLING SEQUENCE WITH MPAC = OCTAL 605 FOR EXCESS ITERATIONS.
#
# SUBROUTINES CALLED
#       GAMDV10
#       XT1LIM
#       DVCALC
#
# ERASABLE INITIALIZATION REQUIRED
#    PUSHLIST
#       NONE
#    MPAC
#       NONE
#    OTHER
#       R(T1)           MAGNITUDE OF INITIAL POSITION VECTOR                    DP      B29/B27
#       RCON            MAGNITUDE OF FINAL POSITION VECTOR                      DP      B29/B27
#       V(T1)/          INITIAL VELOCITY VECTOR                                 VECTOR  B7/B5
#       RTEDVD          DELTA VELOCITY DESIRED                                  DP      B7/B5
#       UR1/            UNIT INITIAL VECTOR                                     VECTOR  B1
#       UH/             UNIT HORIZONTAL VECTOR                                  VECTOR  B1
#       X(T2)           COTANGENT OF FINAL FLIGHT PATH ANGLE                    DP      B0
#       X(T1)           COTANGENT OF INITIAL FLIGHT PATH ANGLE (INPUT FOR PREC) DP      B5
#       CFPA            COSINE OF INITIAL FLIGHT PATH ANGLE                     DP      B1
#       MAMAX1          MAJOR AXIS LIMIT FOR LOWER BOUND ON GAMDV ITERATOR      DP      B30/B28
#       MAMAX2          MAJOR AXIS LIMIT FOR UPPER BOUND ON GAMDV ITERATOR      DP      B30/B28
#       PHI2            REENTRY NEAR PERIGEE OR APOGEE INDICATE (RTE ONLY)      DP      B2
#       N1              CONIC OR PRECISION ITERATION OPERATOR                   DP      B28
#
# OUTPUT
#       V2(T1)/         POST IMPULSE INITIAL VELOCITY VECTOR                    VECTOR  B7/B5
```

```
#       DV              INITIAL VELOCITY CHANGE                                 DP
#       X(T1)           COTANGENT OF INITIAL FLIGHT PATH ANGLE (POST IMPULSE)   DP
#       PCON            SEMI-LATUS RECTUM                                       DP
#       BETA1           1+X(T2)**2                                              DP
#
# Page 918
#
# DEBRIS
#    PUSHLIST
#       00D             X(T1),,=PREVIOUS PRECISION X(T1)                        DP
#       02D             THETA1=BETA5*LAMBDA-1                                   TP
#       05D             THETA2=2*R(T1)*(LAMBDA-1)                               TP
#       08D             THETA3=MU**.5/R(T1)                                     DP
#       10D             X(T1)MIN=LOWER BOUND ON X(T1) IN GAMDV ITERATOR         DP
#       12D             DX(T1)MAX=MAXIMUM DELTA X(T1)                           DP
#       14D             X(T1)MAX=UPPER BOUND ON X(T1) IN GAMDV ITERATOR         DP
#       16D             DX(T1)=ITERATOR INCREMENT                               DP
#       31D             GAMDV10 SUBROUTINE RETURN ADDRESS
#       32D             DVCALC SUBROUTINE RETURN ADDRESS
#       33D             V2T100 SUBROUTINE RETURN ADDRESS

V2T100          STQ     DLOAD
                        33D
                        RCON
                BMN     DSU             # ABORT IF RCON NEGATIVE
                        V2TERROR
                        R(T1)
                BMN
                        V2T101
V2TERROR        EXIT                    #       OR IF LAMBDA LESS THAN ONE
                TC      P00D00          # NO SOLUTION IF LAMBDA LESS THAN 1
                OCT     00610
V2T101          SETPD   CLEAR
                        0               #                                       PL00I
                        F2RTE
                DLOAD   NORM
                        RCON
                        X1
                PDDL    NORM
                        R(T1)
                        S1
                STORE   10D
                SR1     DDV             # R1/RCON = LAMBDA              B1
                XSU,1   PDDL            #                                       PL02I
                        S1
                        X(T2)
```

```
                DSQ
                SR1     DAD
                        1RTEB1
                STORE   BETA1           # 1+X(T2)**2 = BETA1            B1
                DMP
                        00D
                STORE   28D             # BETAI*LAMBDA = BETA5
                DMP     SL*
                        00D
                        0 -7,1
                SL*     DSU
# Page 919
                        0 -7,1
                        1RTEB17
                RTB     PDDL            # BETA5*LAMBDA-1 = THETA1       B17     PL05D
                        TPMODE
                        1RTEB1
                SR*     DCOMP
                        0,1
                DAD     DMP
                        00D
                        R(T1)
                SL*     RTB
                        0 -7D,1
                        TPMODE
                PDDL                    # 2*R(T1)*(LAMBDA-1)=THETA2     B38/B36 PL08D
                        RTMURTE
                NORM    SR1
                        X2
                XSU,2   DDV
                        S1
                        10D
                SR*     PDDL            # MU**.5/R(T1)=THETA3           B-4/B-5 PL10D
                        6,2
                        MAMAX1
                PUSH    PUSH            # MAMAX1=MA
                CALL
                        XT1LIM
                DCOMP   PUSH            # X(T1)MIN                      B5      PL12D
                DCOMP   SR4
                PDDL    PUSH            # DX(T1)MAX                     B5      PL14D
                        MAMAX2
                PUSH    CALL
                        XT1LIM
                PDDL    BMN             # X(T1)MAX                      B5      PL16D
                        NN1A
```

```
                        V2T102
                GOTO
                        V2T110

# PROCEED HERE IF NOT PRECISION COMPUTATION

V2T102          DLOAD
                        RTEDVD
                BZE     GOTO
                        V2T105
                        V2T140
V2T105          DLOAD   BMN
                        CFPA
                        V2T140
                GOTO
                        V2T145
# Page 920
# DURING A PRECISION TRAJECTORY ITERATION CONSTRAIN THE INDEPENDENT
# VARIABLE TO INSURE THAT ALL CONICS PASS THROUGH RCON ON THE SAME PASS
# THROUGH X(T2)

V2T110          DLOAD   RTB
                        1RTEB17
                        TPMODE
                DCOMP   PDDL            # -1                            B17     PL19D
                        2RTEB1
                SR*     DSU
                        0,1
                        00D
                DMP     SL*
                        28D
                        0 -7,1
                SL*     TAD
                        0 -7,1
                RTB     PDDL            # BETA5(2-LAMBDA)-1=BETA6       B17     PL19D
                        TPMODE
                        X(T1)
                STORE   00D             # X(T1),,                       B5
                TLOAD                   #                                     PL16D
                BMN     BZE
                        V2T115
                        V2T115
                SL      GOTO
                        7
                        V2T120
V2T115          DLOAD   BMN
```

```
                        PHI2
                        V2T125
                DCOMP
                STODL   PHI2
                        10RTE
                STORE   NN1A
                GOTO
                        V2T125
V2T120          SQRT    RTB
                        DPMODE
                PDDL    BMN             # BETA6**.5=X(T1)LIM            B5      PL18D
                        PHI2
                        V2T130
                DLOAD   STADR
                STORE   14D             # X(T1)LIM = X(T1)MAX
                DCOMP
                STORE   10D             # -X(T1)LIM = X(T1)MIN
V2T125          DLOAD   BZE
                        X(T1)
                        V2T140
                BMN     GOTO
# Page 921
                        V2T140
                        V2T145
V2T130          DLOAD   BZE
                        X(T1)
                        V2T135
                BMN     DLOAD           #                                       PL16D
                        V2T135
                STADR
                STORE   10D             # X(T1)LIM = X(T1)MIN
                GOTO
                        V2T145
V2T135          DLOAD   DCOMP           #                                       PL16D
                STADR
                STORE   14D             # -X(T1)LIM = X(T1)MAX
V2T140          DLOAD
                        10D
                STODL   X(T1)           # X(T1)MIN = X(T1)
                        12D
                PUSH    GOTO            # DX(T1)MAX = DX(T1)                    PL18D
                        V2T150
V2T145          DLOAD
                        14D
                STODL   X(T1)           # X(T1)MAX = X(T1)
                        12D
```

```
                DCOMP   PUSH            # -DX(T1)MAX = DX(T1)                    PL18D
V2T150          CALL                    # GOTO X(T1)-DV ITERATOR
                        GAMDV10
                DLOAD   BZE             # EXIT IF MINIMUM FUEL MODE
                        RTEDVD
                        V2T1X

# CONTINUE IF TIME CRITICAL MODE

                DSU     BMN
                        DV
                        V2T155
                GOTO
                        V2T175
V2T155          DLOAD   BMN
                        NN1A
                        V2T160
                GOTO
                        V2T185

# CONIC TRAJECTORY COMPUTATION

V2T160          DLOAD   BZE
                        X(T1)
                        V2T165
                BMN     GOTO
# Page 922
                        V2T165
                        V2T300
V2T165          DLOAD   BZE
                        CFPA
                        V2T300
                BMN     DLOAD
                        V2T300
                        14D
                STODL   X(T1)           # X(T1)MAX=X(T1)
                        12D
                DCOMP
                STCALL  16D             # -DX(T1)MAX=DX(T1)
                        GAMDV10
                DLOAD   DSU
                        RTEDVD
                        DV
                BMN
                        V2T300
V2T175          SET     DLOAD
```

```
                        F2RTE
                        X(T1)
                BOFF
                        SLOWFLG
                        V2T177
                STODL   10D             # X(T1)MIN
                        12D             # DX(T1)MAX
                GOTO
                        V2T179
V2T177          STODL   14D
                        12D
                DCOMP
V2T179          STCALL  16D             # DX(T1)
                        GAMDV10
                DLOAD   BMN
                        NN1A
                        V2T300

# PREVENT A LARGE CHANGE IN INDEPENDENT VARIABLE DURING AN ITERATION FOR A
# PRECISION TRAJECTORY

V2T185          DLOAD   DSU
                        X(T1)
                        00D
                ABS     PDDL            # /X(T1)-X(T1),,/ = BETA7
                        12D
                SL1     BDSU
                BMN     DLOAD
                        V2T300
                        00D             # CONTINUE IF BETA7 LARGER THAN 2DX(T1)MAX
                STORE   X(T1)           # X(T1),, = X(T1)
# Page 923
                DSU     BMN
                        14D
                        V2T195
                DLOAD
                        14D
                STORE   X(T1)           # X(T1)MAX = X(T1)
                GOTO
                        V2T205
V2T195          DLOAD   DSU
                        X(T1)
                        10D
                BMN     GOTO
                        V2T200
                        V2T205
```

```
V2T200          DLOAD
                        10D
                STORE   X(T1)           # X(T1)MIN = X(T1)
V2T205          CALL
                        DVCALC
V2T300          DLOAD
                        ZERORTE
V2T1X           GOTO
                        33D

# Page 924
# X(T1)-DV ITERATOR SUBROUTINE
#
# DESCRIPTION
#       COMPUTES A POST IMPULSE VELOCITY VECTOR (V2(T1)) WHICH REQUIRES A MINIMUM DV
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             GAMDV10
#
# NORMAL EXIT MODE
#       AT L+2 OF CALLING SEQUENCE
#
# ALARM EXIT MODE
#       AT V2T1X WITH MPAC = OCTAL 605 FOR EXCESS ITERATIONS
#
# SUBROUTINES CALLED
#       DVCALC
#
# ERASABLE INITIALIZATION REQUIRED
#    PUSHLIST
#       02D             THETA1=BETA5*LAMBDA-1                                   TP
#       05D             THETA2=2*R(T1)*(LAMBDA-1)                               TP
#       08D             THETA3=MU**.5/R(T1)                                     DP
#       10D             X(T1)MIN=LOWER BOUND ON INDEPENDENT VARIABLE X(T1)      DP
#       12D             DX(T1)MAX=MAXIMUM DX(T1)                                DP
#       14D             X(T1)MAX=UPPER BOUND ON INDEPENDENT VARIABLE X(T1)      DP
#       16D             DX(T1)=ITERATOR INCREMENT                               DP
#    MPAC
#       NONE
#    OTHER
#       V(T1)/          INITIAL VELOCITY VECTOR                                 VECTO
#       RTEDVD          DELTA VELOCITY DESIRED                                  DP
#       UR1/            UNIT INITIAL VECTOR                                     VECTO
#       UH/             UNIT HORIZONTAL VECTOR                                  VECTO
#       X(T1)           COTANGENT OF INITIAL FLIGHT PATH ANGLE (FROM VERTICAL)  DP
```

```
#       F2RTE           TIME CRITICAL OR MINIMUM FUEL MODE INDICATOR            STATE AREA
#
# OUTPUT
#       V2(T1)/         POST IMPULSE INITIAL VELOCITY VECTOR                    VECTOR  B7/B5
#       DV              INITIAL VELOCITY CHANGE                                 DP      B7/B5
#       X(T1)           COTANGENT OF INITIAL FPA MEASURED FROM VERTICAL         DP      B5
#       PCON            SEMI-LATUS RECTUM                                       DP      B28/B26
#
# DEBRIS
#    PUSHLIST
#       00D             X(T1),,
#       02D             THETA1
#       05D             THETA2
#       08D             THETA3
#       10D             X(T1)MIN
#       12D             DX(T1)MAX
# Page 925
#       14D             X(T1)MAX
#       16D             DX(T1)
#       22D             DV,=PREVIOUS DV                                         DP      B7/B5
#       24D             BETA9=X(T1)+1.1DX(T1)                                   DP      B5
#       31D             GAMDV10 SUBROUTINE RETURN ADDRESS
#       32D             DVCALC SUBROUTINE RETURN ADDRESS
#       33D             V2T100 SUBROUTINE RETURN ADDRESS

GAMDV10         STQ
                        31D
                SETPD   CALL
                        18D             #                                       PL18D
                        DVCALC
                DLOAD   DSU
                        14D
                        10D
                BOV
                        GAMDV20
                PUSH    DSU             # X(T1)MAX-X(T1)MIN=BETA8       B5      PL20D
                        EPC9RTE
                BMN     DLOAD
                        GAMDVX          # BOUNDS CLOSE TOGETHER
                        18D
                DSU     BMN             # BETA8-DX(T1)MAX
                        12D
                        GAMDV15
                SETPD   GOTO            #                                       PL18D
                        18D
                        GAMDV20
```

```
GAMDV15         DLOAD                   #                                       PL18D
                SIGN    SR1
                        16D
                STORE   16D             # BETA8(SIGNDX(T1))/2=DX(T1)
GAMDV20         DLOAD
                        M144RTE
                STORE   NN2
GAMDV25         DLOAD   DAD
                        NN2
                        1RTEB28
                BMN     SLOAD
                        GAMDV30
                        OCT605
                GOTO
                        V2T1X
GAMDV30         STORE   NN2             # NN2=NN2+1
                DLOAD   PDDL            # X(T1)=X(T1),                  B5      PL20D
                        X(T1)
                        DV
                PDDL    DAD             # DV=DV,                        B7/B5   PL22D
                        X(T1)
                        16D
# Page 926
                STCALL  X(T1)           # X(T1)+DX(T1)=X(T1)            B5
                        DVCALC
                BON     DLOAD
                        F2RTE
                        GAMDV35
                        DV
                DSU     BMN             # CONTINUE IF FUEL CRITICAL MODE
                        20D
                        GAMDV33
GAMDV32         DLOAD   DCOMP
                        16D
                SR1
                STORE   16D
GAMDV33         SETPD   GOTO
                        18D             #                                       PL18D
                        GAMDV50

# TIME CRITICAL MODE

GAMDV35         DLOAD   DSU
                        RTEDVD
                        DV
                PDDL    PUSH            # DVD-DV=DVERR                  B7/B5   PL22D
```

```
GAMDV40         DLOAD   ABS             # DV,                                   PL24D
                        20D
                DSU     BMN
                        EPC10RTE
                        GAMDVX
GAMDV45         BOVB    DLOAD
                        TCDANZIG        # ASSURE OVFIND IS 0
                BDSU    NORM
                        DV
                        X2
                PDDL                    # DV-DV,                        B7/B5-N2 PL22D
                NORM    SR1             # DVERR                          B8/B6-N1
                        X1
                DDV     PDDL            # DVERR/ DV - DV
                BDSU    DMP             #                                         PL18D
                        X(T1)
                XSU,1
                        X2
                STORE   16D             # PRESERVE SIGN IF OVERFLOW
                SR*     BOV
                        0 -1,1
                        GAMDV47
                STORE   16D             # (X(T1)-X(T1),)DVERR/(DV-DV,)=DX(T1)
                ABS     DSU
                        12D
                BMN
                        GAMDV50
# Page 927
GAMDV47         DLOAD   SIGN
                        12D
                        16D
                STORE   16D             # DX(T1)MAX(SIGNDX(T1))=DX(T1)

# CHECK TO KEEP INDEPENDENT VARIABLE IN BOUNDS

GAMDV50         DLOAD   DMP
                        16D
                        1.1RTEB1
                SL1     DAD
                        X(T1)
                STORE   24D             # X(T1)+1.1DX(T1)=BETA9          B5
                DSU     BMN
                        14D
                        GAMDV55
                DLOAD   DSU
                        14D
```

```
                        X(T1)
                SR1
                STCALL  16D             # (X(T1)MAX-X(T1))/2=DX(T1)     B5
                        GAMDV65
GAMDV55         DLOAD   DSU
                        24D
                        10D
                BMN     GOTO
                        GAMDV60
                        GAMDV65
GAMDV60         DLOAD   DSU
                        10D
                        X(T1)
                SR1
                STORE   16D             # (X(T1)MIN-X(T1))/2=DX(T1)     B5
GAMDV65         DLOAD   ABS
                        16D
                DSU     BMN
                        EPC9RTE
                        GAMDVX
                GOTO
                        GAMDV25
GAMDVX          GOTO
                        31D

# Page 928
# DV CALCULATION SUBROUTINE
#
# INPUT
#    PUSHLIST
#       02D             THETA1=BETA5*LAMBDA-1                                   TP
#       05D             THETA2=2*R(T1)*(LAMBDA-1)                               TP
#       08D             THETA3=MU**.5/R(T1)                                     DP
#    OTHER
#       X(T1)           COTANGENT OF POST IMPULSE INITIAL FLIGHT PATH ANGLE     DP
#       V(T1)/          INITIAL VELOCITY VECTOR (PRE IMPULSE)                   VECTO
#       UR1/            UNIT INITIAL VECTOR                                     VECTO
#       UH/             UNIT HORIZONTAL VECTOR                                  VECTO
#
# OUTPUT
#       V2(T1)/         POST IMPULSE INITIAL VELOCITY VECTOR                    VECTO
#       DV              INITIAL VELOCITY CHANGE                                 DP
#       PCON            SEMI-LATUS RECTUM                                       DP
#
# DEBRIS
#       28D             THETA3*PCON**.5                                         DP
```

```
#       C(PUSHLOC)      THETA3(PCON**.5)*X(T1)*UR1/                             VECTOR  B7/B5
#       32D             DVCALC SUBROUTINE RETURN ADDRESS
#       X1              NORMALIZATION FACTOR FOR VALUE IN 28D
#
# PUSHLOC IS RESTORED TO ITS ENTRANCE VALUE UPON EXITING DVCALC

DVCALC          STQ     DLOAD
                        32D
                        X(T1)
                DSQ     SR
                        7
                DCOMP   TAD
                        02D
                NORM    PUSH
                        X1
                TLOAD   NORM
                        05D
                        X2
                RTB     SR1
                        DPMODE
                XSU,2   DDV
                        X1
                SR*
                        6,2
                STORE   PCON            # THETA2/(THETA1-X(T1)**2)=PCON B28/26
                SQRT    DMP
                        08D
                NORM
                        X1
                STODL   28D             # THETA3*PCON**.5               B10/B8 -N1
# Page 929
                        X(T1)
                NORM    VXSC
                        X2
                        UR1/            # X(T1)*UR1/                    B5+B1 -N2
                XAD,2   VXSC
                        X1
                        28D
                VSR*    PDVL            # THETA3(PCON**.5)X(T1)*UR1/    B7/B5
                        0 -9D,2         #               +
                        UH/
                VXSC    VSR*            # THETA3(PCON**.5)UH/           B7/B5
                        28D
                        0 -4,1          #               =
                VAD     STADR
                STORE   V2(T1)/         # V2(T1)/                       B7/B5
```

```
                VSU     ABVAL
                        V(T1)/
                STORE   DV              # ABVAL(V2(T1)/-V1(T)/)=DV      B7/B5
                GOTO
                        32D

# Page 930
# SUBROUTINE TO COMPUTE BOUNDS ON INDEPENDENT VARIABLE X(T1)
#
# INPUT
#    PUSHLIST
#       PUSHLOC -4      MAJOR AXIS (MA)                                     DP
#       PUSHLOC -2      MAJOR AXIS (MA) AGAIN                               DP
#       28D             BETA5=LAMBDA*BETA1                                  DP
#    OTHER
#       RCON                                                                DP
#       R(T1)                                                               DP
#
# OUTPUT
#    MPAC
#       X(T1)LIM        LIMIT ON INDEPENDENT VARIABLE X(T1)                 DP
#
# DEBRIS
#    PUSHLIST
#       C(PUSHLOC)      MA-RCON                                             DP
#       C(PUSHLOC) +2   MA                                                  DP
#       X1              NORMALIZATION FACTOR FOR MA-RCON
#       20D             XT1LIM SUBROUTINE RETURN ADDRESS
#
# PUSHLOC IS RESTORED TO ITS ENTRANCE VALUE UPON EXITING XT1LIM

XT1LIM          STQ     DLOAD
                        20D
                        RCON
                SR1     BDSU
                NORM    PDDL            # MA-RCON                      B30-N1
                        X2
                PDDL    SR1
                        R(T1)
                BDSU    DDV
                SL*     DMP
                        0       -3,2
                        28D
                SL*     DSU             # BETA10=BETA5(MA-RT)/(MA-RC)-1 B11
                        0       -6,1
                        1RTEB25 +1      # 1.0                           B-11
```

```
                SL1     BOV
                        XT1LIM2
                BMN     GOTO
                        XT1LIM5
                        XT1LIM3
XT1LIM2         DLOAD                   # BETA10=POSMAX IF OVERFLOW
                        2RTEB1
XT1LIM3         SQRT    GOTO            # X(T1)=SQRT(BETA10)
                        XT1LIMX
XT1LIM5         DLOAD
                        ZERORTE
XT1LIMX         GOTO
                        20D

# Page 931
# CONSTANTS FOR THE P37 AND P70 PROGRAMS AND SUBROUTINES

                BANK    36
                SETLOC  RTECON1
                BANK

1RTEB1          2DEC    1. B-1
1RTEB2          2DEC    1. B-2
1RTEB3          2DEC    1. B-3
1RTEB4          2DEC    1. B-4
1RTEB10         2DEC    1. B-10
1RTEB12         2DEC    1. B-12
1RTEB13         2DEC    1. B-13
1RTEB17         2DEC    1. B-17
1RTEB25         2DEC    1. B-25
#                                       * * B25 AND B28 MUST BE CONSECUTIVE * *
1RTEB28         2DEC    1. B-28
ZERORTE         2DEC    0
M144RTE         2DEC    -144. B-28
M15RTE          2DEC    -15
10RTE           2DEC    10
M.6RTE          2DEC    -.6
1.1RTEB1        2DEC    1.1 B-1
M6RTEB28        2DEC    -6
2RTEB1          2OCT    3777737777
M9RTEB28        2DEC    -9
M8RTEB28        2DEC    -8
30480RTE        2DEC    30480. B-29
VCSPS           2DEC    31.510396 B-5   # (SEE 2VEXHUST)
# Page 932
VCRCS           2DEC    27.0664 B-5
```

```
MDOTRCS         2DEC    .0016375 B-3
CSUBT           2DEC    .5
OCT605          OCT     00605
OCT612          OCT     00612
MCOS7.5         2DEC    -.99144486
MSIN7.5         2DEC    -.13052619
MCOS22.5        2DEC    -.92387953 B-2
THETA165        2DEC    .4583333333
THETA210        2DEC    .5833333333
EPC1RTE         2DEC    .99966 B-1
EPC2RTE         2DEC    100. B-29
EPC3RTE         2DEC    .001
EPC4RTE         2DEC    .00001
EPC5RTE         2DEC    .01 B-6
EPC6RTE         2DEC    .000007 B-1
EPC7RTE         2DEC    1000. B-29
EPC9RTE         2DEC    1. B-25
EPC10RTE        2DEC    .0001 B-7

                BANK    35
                SETLOC  RTECON1
                BANK

C4RTE           2DEC    -6.986643 E7 B-30
K1RTE           2DEC    7. E6 B-29
K2RTE           2DEC    6495000. B-29
K3RTE           2DEC    -.06105
K4RTE           2DEC    -.10453
RTMURTE         2DEC    199650.501 B-18
# Page 933
E3RTE           2DEC    121920. B-29
```

Uses +MGA 234, A 80, ALPHAV 177, BETA1 241, BETA12 241, CFPA 241, CONICS 61, CONICX1 241, COUNT 142, CSTH 188, DELVLVC 224, DELVSIN 236, DRCON 241, DT21PR 241, DV 241, EBANK 80, ECSTEER 224, EMDOT 138, ERADFLAG 99, F2RTE 97, FACTOR 226, FINALFLG 105, GAMMAEI 231, HORIZON 190, INTYPFLG 107, L 80, LAT 157, LAT(SPL) 224, LATITUDE 191, LNG(SPL) 224, LONG 157, LUNAFLAG 107, LV 85, MAMAX1 241, MAMAX2 241, MODE 145, MOONFLAG 95, MPAC 145, N 206, NJETSFLG 97, NN1A 241, NN2 241, NORMSW 123, OPTION1 157, OPTION2 157, OVFIND 140, P 188, P(T1) 241, P/RPRE 243, P37RANGE 223, PCON 241, PHI2 241, PUSHLOC 145, R(T1) 241, R(T1)/ 241, R(T2)/ 241, R/APRE 243, R1A 188, RANGE 179, RCON 241, RCV 169, RD 241, RDESIRED 188, REENTRY 65, REFSMFLG 107, RETROFLG 113, REVS 206, RPRE 243, RPRE' 241, RT 226, RTARG 224, RTE 67, RTE1 69, RTE2 63, RTE3 67, RTECON1 69, RTED1 166, RTEDVD 241, RTEGAM2D 241, RTENCKEX 241, RVEC 188, RVSW 123, S1 85, SGNRDOT 188, SLOWFLG 113, SNTH 188, SPRTETIG 243, SPRTEX 241, SR 80, STATE 138, T1 241, T12 241, T2 241, T3TOT4 185, TC 169, TET 169, THRUST 85, TIG 224, TPASS4 236, TRKMKCNT 157, TTOGO 236, UH/ 243, UR1 188, UR1/ 241, UV1/ 241, V 229, V(T1)/ 241, V(T2)/ 241, V1 145, V2(T1)/ 241, VCV 169, VGDISP 231, VHFCNT 157, VN 159, VNSTORE 241, VPRED 231, VVEC 188, WEIGHT/G 200, X(T1) 241, X(T2) 243, X(T2)PRE 243, X1 85, X2 85, and XDELVFLG 103.

3.5.15 s-band antenna for cm

1343 ⟨*s-band antenna for cm* 1343⟩≡ (857a 2800)
⟨*Page CM0934* 1344⟩

1344 ⟨*Page CM0934* 1344⟩≡ (1343)

```
# Page 934
# S-BAND ANTENNA FOR CM

                BANK    23
                SETLOC  SBAND
                BANK

                COUNT*  $$/R05
                EBANK=  EMSALT

SBANDANT        TC      BANKCALL        # V 64 E GETS US HERE
                CADR    R02BOTH         # CHECK IF IMU IS ON AND ALIGNED
                TC      INTPRET
                RTB     CALL
                        LOADTIME        # PICKUP CURRENT TIME SCALED B-28
                        CDUTRIG         # COMPUTE SINES AND COSINES OF CDU ANGLES
                STCALL  TDEC1           # ADVANCE INTEGRATION TO TIME IN TDEC1
                        CSMCONIC        # USING CONIC INTEGRATION
                SLOAD   BHIZ            # ORIGIN OF REFERENCE INERTIAL SYSTEM IS
                        X2              # EARTH = 0, MOON = 2
                        EISOI
                VLOAD
                        RATT
                STORE   RCM             # MOVE RATT TO PREVENT WIPEOUT
                DLOAD   CALL            # MOON, PUSH ON
                        TAT             # GET ORIGINAL TIME
                        LUNPOS          # COMPUTE POSITION VECTOR OF MOON
                VAD     VCOMP           # R= -(REM+RCM) = NEG. OF S/C POS. VEC
                        RCM
                GOTO
                        EISOI +2
EISOI           VLOAD   VCOMP           # EARTH, R= -RCM
                        RATT
                SETPD   MXV             # RCS TO STABLE MEMBER: B-1X B-29X B+1
                        2D              # 2D
                        REFSMMAT        # STABLE MEMBER.  B-1X B-29X B+1= B-29
                VSL1    PDDL            # 8D
                        HI6ZEROS
                STOVL   YAWANG          # ZERO OUT YAWANG, SET UP FOR SMNB
                        RCM             # TRANSFORMATION.  SM COORD.  SCALED B-29
                CALL
                        *SMNB*
                STORE   R               # SAVE NAV. BASE COORDINATES
                UNIT    PDVL            # 14D
                        R
```

```
                VPROJ   VSL2            # COMPUTE PROJECTION OF VECTOR INTO CM
                        HIUNITZ         # XY-PLANE, R-(R.UZ)UZ
                BVSU    BOV             # CLEAR OVERFLOW INDICATOR IF SET
                        R
                        COVCNV
COVCNV          UNIT    BOV             # TEST OVERFLOW FOR INDICATION OF NULL
                        NOADJUST        # VECTOR
                PUSH    DOT             # 20D
# Page 935
                        HIUNITX         # COMPUTE YAW ANGLE = ACOS (URP.UX)
                SL1     ACOS            # REVOLUTIONS SCALED B0
                PDVL    DOT             # 22D YAWANG
                        URP
                        HIUNITY         # COMPUTE FOLLOWING: URP.UY
                SL1     BPL             # POSITIVE
                        NOADJUST        # YES, 0-180 DEGREES
                DLOAD   DSU             # NO, 181-360 DEGREES 20D
                        DPPOSMAX        # COMPUTE 2 PI MINUS YAW ANGLE
                PUSH                    # 22D YAWANG
NOADJUST        VLOAD   DOT             # COMPUTE PITCH ANGLE
                        UR              # ACOS (UR.UZ) - PI/2
                        HIUNITZ
                SL1     ACOS            # REVOLUTIONS B0
                DSU
                        HIDP1/4
                STODL   RHOSB
                        YAWANG
                STORE   GAMMASB         # PATCH FOR CHECKOUT
                EXIT
                CA      EXTVBACT        # IS BIT 5 STILL ON
                MASK    BIT5
                EXTEND
                BZF     ENDEXT          # NO, WE HAVE BEEN ANSWERED
                CAF     V06N51          # DISPLAY ANGLES
                TC      BANKCALL
                CADR    GOMARKFR
                TC      B5OFF           # TERMINATE
                TC      B5OFF
                TC      ENDOFJOB        # RECYCLE
                CAF     BIT3            # IMMEDIATE RETURN
                TC      BLANKET         # BLANK R3
                CAF     BIT1            # DELAY MINIMUM TIME TO ALLOW DISPLAY IN
                TC      BANKCALL
                CADR    DELAYJOB
                TCF     SBANDANT +2
V06N51          VN      0651
```

```
RCM             EQUALS  2D
UR              EQUALS  8D
URP             EQUALS  14D
YAWANG          EQUALS  20D
PITCHANG        EQUALS  22D
R               EQUALS  RCM
                SBANK=  LOWSUPER
```

Uses COUNT 142, EBANK 80, EMSALT 175, EXTVBACT 154, GAMMASB 179, HI6ZEROS 71, HIDP1/4 71, HIUNITX 71, HIUNITY 71, HIUNITZ 71, LOWSUPER 67, REFSMMAT 172, RHOSB 179, SAVE 191, SBAND 71, TC 169, US 185, V 229, VN 159, and X2 85.

3.5.16 lunar landmark selection for cm

1346a ⟨*lunar landmark selection for cm* 1346a⟩≡ (857a 2741)
⟨*Page CM0936* 1346b⟩

1346b ⟨*Page CM0936* 1346b⟩≡ (1346a)

```
# Page 936

# *** END OF TROUBLE .043 ***
```

3.6 tvcdaps routines

1346c ⟨*tvcdaps routines* 1346c⟩≡ (19a)
⟨*tvcinitialize code* 1346d⟩
⟨*tvcexecutive code* 1355⟩
⟨*tvcmassprop code* 1361⟩
⟨*tvcrestarts code* 1366⟩
⟨*tvcdaps code* 1372⟩
⟨*tvcstroketest code* 1389⟩
⟨*tvcrolldap code* 1395⟩
⟨*mysubs code* 1409⟩
⟨*rcs-csm digital autopilot* 1411⟩
⟨*automatic maneuvers* 1433⟩
⟨*rcs-csm dap executive programs* 1450b⟩
⟨*jet selection logic* 1452⟩
⟨*cm entry digital autopilot* 1480⟩

3.6.1 tvcinitialize code

1346d ⟨*tvcinitialize code* 1346d⟩≡ (1346c 2826)
⟨*Page CM0937* 1347⟩

1347 ⟨*Page CM0937* 1347⟩≡ (1346d)

```
# Page 937
# NAME          TVCDAPON (TVC DAP INITIALIZATION AND STARTUP CALL)
# LOG SECTION...TVCINITIALIZE                   SUBROUTINE...DAPCSM
# MODIFIED BY SCHLUNDT                          21 OCTOBER 1968
# FUNCTIONAL DESCRIPTION
#       PERFORMS TVCDAP INITIALIZATION (GAINS, TIMING PARAMETERS, FILTER VARIABLES, ETC.)
#       COMPUTES STEERING (S40.8) GAIN KPRIMEDT, AND ZEROES PASTDELV,+1 VARIABLE
#       MAKES INITIALIZATION CALL TO "NEEDLER" FOR TVC DAP NEEDLES-SETUP
#       PERFORMS INITIALIZATION FOR ROLL DAP
#       CALLS TVCEXECUTIVE AT TVCEXEC, VIA WAITLIST
#       CALLS TVCDAP CDU-RATE INITIALIZATION PKG AT DAPINIT  VIA T5
#       PROVIDES FOR LOADING OF LOW-BANDWIDTH COEFFS AND GAINS AT SWICHOVR
# CALLING SEQUENCE - T5LOC=2CADR(TVCDAPON,EBANK=BZERO), T5=.6SECT5
#       IN PARTICULAR, CALLED BY "DOTVCON" IN P40
#       MRCLEAN AND TVCINIT4 ARE POSSIBLE TVC-RESTART ENTRY POINTS
# NORMAL EXIT MODE
#       TCF RESUME
# SUBROUTINES CALLED
#       NEEDLER, MASSPROP
# ALARM OR ABORT EXIT MODES
#       NONE
# ERASABLE INITIALIZATION REQUIRED
#       CSMMASS, LEMMASS, DAPDATR1 (FOR MASSPROP SUBROUTINE)
#       TVC PAD LOADS (SEE EBANK6 IN ERASABLE ASSIGNMENTS)
#       PACTOFF, YACTOFF, CDUX
#       TVCPHASE AND THE T5 BITS OF FLAGWRD6 (SET AT DOTVCON IN P40)
# OUTPUT
#       ALL TVC AND ROLL DAP ERASABLES, FLAGWRD6 (BITS 13,14), T5, WAITLIST
# DEBRIS
#       NONE

                COUNT*  $$/INIT
                BANK    17
                SETLOC  DAPS7
                BANK

                EBANK=  BZERO

TVCDAPON        LXCH    BANKRUPT        # T5 RUPT ARRIVAL (CALL BY DOTVCON - P40)
                EXTEND                  # SAVE Q REQUIRED IN RESTART (MRCLEAN AND
                QXCH    QRUPT           #       TVCINIT4 ARE ENTRIES)
MRCLEAN         CAF     NZERO           # NUMBER TO ZERO, LESS ONE  (MUST BE ODD)
                                        #       TVC RESTARTS ENTER HERE  (NEW BANK)
        +1      CCS     A
                TS      CNTR
```

```
                CAF     ZERO
                TS      L
                INDEX   CNTR
                DXCH    OMEGAYC         # FIRST (LAST) TWO LOCATIONS
                CCS     CNTR
                TCF     MRCLEAN +1
# Page 938
                EXTEND                  # SET UP ANOTHER T5 RUPT TO CONTINUE
                DCA     INITLOC2        #       INITIALIZATION AT TVCINIT1
                DXCH    T5LOC           # THE PHSCHK2 ENTRY (REDOTVC) AT TVCDAPON
                CAF     POSMAX          #       +3 IS IN ANOTHER BANK.  MUST RESET
                TS      TIME5           #       BBCON TOO (FULL 2CADR), FOR THAT
ENDMRC          TCF     RESUME          #       ENTRY.

TVCINIT1        LXCH    BANKRUPT
                EXTEND
                QXCH    QRUPT

                TC      IBNKCALL        # UPDATE IXX, IAVG/TLX FOR DAP GAINS (R03
                CADR    MASSPROP        #       OR NOUNS 46 AND 47 MUST BE CORRECT)

                CAE     EMDOT           # SPS FLOW RATE, SCALED B+3 KG/CS
                EXTEND
                MP      ONETHOU
                TS      TENMDOT         # 10-SEC MASS LOSS B+16 KG
                COM
                AD      CSMMASS
                TS      MASSTMP         # DECREMENT FOR FIRST 10 SEC OF BURN

                CAE     DAPDATR1        # CHECK LEM-ON/OFF
                MASK    BIT14
                CCS     A
                CAF     BIT1            # LEM-ON (BIT1)
                TS      CNTR            # LEM-OFF (ZERO)

                INDEX   CNTR            # LOAD THE FILTER COEFFICIENTS
                CAF     CSMCFADR
                TS      COEFFADR
                TC      LOADCOEF

                INDEX   CNTR            # PICK UP LM-OFF,-ON KTLX/I
                CAE     EKTLX/I         # SCALED AT 1/(8 ASCREV) OF ACTUAL VALUE
                TS      KTLX/I

                TCR     S40.15          # COMPUTE 1/CONACC, VARK
```

```
TVCINIT2        CS      CNTR            # PICK LM-OFF,-ON VALUE FOR FILTER PERIOD
                INDEX   A               # DETERMINATION:
                CAF     BIT2            #       BIT2 FOR CSM ONLY 40MS FILTER
                TS      KPRIMEDT        #       BIT3 FOR CSM/LM 80MS FILTER

                COM                     # PREPARE T5TVCDT
                AD      POSMAX
                AD      BIT1
                TS      T5TVCDT

                CS      BIT15           # RESET SWTOVER FLAG
# Page 939
                MASK    FLAGWRD9
                TS      FLAGWRD9

                INDEX   CNTR            # PICK UP LEM-OFF,-ON KPRIME
                CAE     EKPRIME         #       SCALED (100 PI)/16
                EXTEND
                MP      KPRIMEDT        # (TVCDT/2, SC.AT B+14 CS)
                LXCH    A               #       SC.AT PI/8      (DIMENSIONLESS)
                DXCH    KPRIMEDT

                INDEX   CNTR            # PICK UP LEM-OFF,-ON REPFRAC
                CAE     EREPFRAC
                TS      REPFRAC

                INDEX   CNTR            # PICK UP ONE-SHOT CORRECTION TIME
                CAF     TCORR
                TS      CNTR

                CAF     NEGONE          # PREVENT STROKE TEST UNTIL CALLED
                TS      STRKTIME

                CAF     NINETEEN        # SET VCNTR FOR VARIABLE-GAIN UPDATES IN
                TS      VCNTR           #       10 SECONDS (TVCEXEC 1/2 SEC RATE)
                TS      V97VCNTR        # FOR ENGFAIL (R41) LOGIC

TVCINIT3        CAE     PACTOFF         # TRIM VALUES TO TRIM-TRACKERS, OUTPUT
                TS      PDELOFF         #       TRACKERS, OFFSET-UPDATES, AND
                TS      PCMD            #       OFFSET-TRACKER FILTERS
                TS      DELPBAR         #       NOTE, LO-ORDER DELOFF,DELBAR ZEROED

                CAE     YACTOFF
                TS      YDELOFF
                TS      YCMD
                TS      DELYBAR
```

```
ATTINIT         CAE     DAPDATR1        # ATTITUDE-ERROR INITIALIZATION LOGIC
                MASK    BIT13           #       TEST FOR CSM OR CSM/LM
                EXTEND
                BZF     NEEDLEIN        #       BYPASS INITIALIZATION FOR CSM/LM

                CAF     BIT1            #       SET UP TEMPORARY COUNTER
        +5      TS      TTMP1

                INDEX   TTMP1
                CA      ERRBTMP         # ERRBTMP CONTAINS RCS ATTITUDE ERRORS
                EXTEND                  #       ERRORY & ERRORZ (P40 AT DOTVCON)
                MP      1/ATTLIM        # .007325(ERROR) = 0 IF ERROR < 1.5 DEG
                EXTEND
                BZF     +8D             #       |ERROR| LESS THAN 1.5 DEG
                EXTEND
# Page 940
                BZMF    +3              #       |ERROR| > 1.5 DEG, AND NEG
                CA      ATTLIM          #       |ERROR| > 1.5 DEG, AND POS
                TCF     +2
        +3      CS      ATTLIM
        +2      INDEX   TTMP1
                TS      ERRBTMP
        +8      CCS     TTMP1           #       TEST TEMPORARY COUNTER
                TCF     ATTINIT +5      #       BACK TO REPEAT FOR PITCH ERROR

                CA      ERRBTMP         # ERRORS ESTABLISHED AND LIMITED
                TS      PERRB
                CA      ERRBTMP +1
                TS      YERRB

NEEDLEIN        CS      RCSFLAGS        # SET BIT 3 FOR INITIALIZATION PASS AND GO
                MASK    BIT3            #       TO NEEDLER.  WILL CLEAR FOR TVC DAP
                ADS     RCSFLAGS        #       (RETURNS AFTER CADR)
                TC      IBNKCALL
                CADR    NEEDLER

TVCINIT4        CAF     ZERO            # SET TVCPHASE TO INDICATE TVCDAPON-THRU-
                TS      TVCPHASE        #       NEEDLEIN INITIALIZATION FINISHED.
                                        #       (POSSIBLE TVC-RESTART ENTRY)

                CAE     CDUX            # PREPARE ROLL DAP
                TS      OGANOW

                CAF     BIT13           # IF ENGINE IS ALREADY OFF, ENGINOFF HAS
                EXTEND                  #       ALREADY ESTABLISHED THE POST-BURN
```

```
                RAND    DSALMOUT        #       CSMMASS (MASSBACK DOES IT).  DON'T
                EXTEND                  #       TOUCH CSMMASS.  IF ENGINE IS ON,
                BZF     +3              #       THEN IT'S OK TO DO THE COPYCYCLE
                                        #       EVEN BURNS LESS THAN 0.4 SEC ARE AOK

                CAE     MASSTMP         # COPYCYCLE
                TS      CSMMASS

        +3      CAF     .5SEC           # CALL TVCEXECUTIVE (ROLLDAP CALL, ETC)
                TC      WAITLIST
                EBANK=  BZERO
                2CADR   TVCEXEC

                EXTEND                  # CALL FOR DAPINIT
                DCA     DAPINIT5
                DXCH    T5LOC
                CAE     T5TVCDT         # (ALLOW TIME FOR RESTART COMPUTATIONS)
                TS      TIME5
# Page 941
ENDTVCIN        TCF     RESUME

PRESWTCH        TCR     SWICHOVR        # ENTRY FROM V46

                TC      POSTJUMP        # THIS PROVIDES AN EXIT FROM SWITCH-OVER
                CADR    PINBRNCH        #       (PINBRNCH DOES A RELINT)

SWICHOVR        INHINT
                CA      TVCPHASE        # SAVE TVCPHASE
                TS      PHASETMP
                CS      BIT2            # SET TVCPHASE = -2 (INDICATES SWITCH-OVER
                TS      TVCPHASE        #       TO RESTART LOGIC)

        +5      EXTEND                  # SAVE Q FOR RETURN (RESTART ENTRY POINT,
                QXCH    RTRNLOC         #       TVCPHASE AND PHASETMP ALREADY SET)

                CAF     NZEROJR         # ZEROING LOOP FOR FILTER STORAGE LOCS
        +8      TS      CNTRTMP

MCLEANJR        CA      ZERO
                TS      L
                INDEX   CNTRTMP
                DXCH    PTMP1 -1
                CCS     CNTRTMP
                CCS     A
                TCF     SWICHOVR +8D
```

```
                CS      FLAGWRD9        # SET SWITCHOVER FLAG FOR DOWNLINK
                MASK    BIT15
                ADS     FLAGWRD9

                CAE     EKTLX/I +2      # LOW BANDWIDTH GAINS   - DAP
                TS      KTLX/I
                TCR     S40.15  +7

                CAF     FKPRIMDT        #                       - STEERING
                TS      KPRIMEDT

                CAF     FREPFRAC        #                       - TMC LOOP
                TS      REPFRAC

                EXTEND                  # UPDATE TRIM ESTIMATES
                DCA     DELPBAR
                DXCH    PDELOFF
                EXTEND
                DCA     DELYBAR
                DXCH    YDELOFF

                CA      LBCFADR
# Page 942
                TS      COEFFADR
                TC      LOADCOEF

                CAE     PHASETMP        # RESTORE TVCPHASE
                TS      TVCPHASE

                TC      RTRNLOC         # BACK TO PRESWTCH OR TVCRESTARTS

LOADCOEF        EXTEND                  # LOAD DAP FILTER COEFFICIENTS
                INDEX   COEFFADR        #   FROM: ERASABLE FOR CSM/LM HB
                DCA     0               #         FIXED    FOR CSM/LM LB
                DXCH    N10             #         FIXED    FOR CSM

                EXTEND                  # NOTE: FOR CSM/LM, NORMAL COEFFICIENT
                INDEX   COEFFADR        # LOAD WILL BE HIGH BANDWIDTH PAD LOAD
                DCA     2               # ERASABLES. DURING CSM/LM SWITCHOVER,
                DXCH    N10     +2      # THIS LOGIC IS USED TO LOAD LOW BANDWIDTH
                                        # COEFFICIENTS FROM FIXED MEMORY.

                EXTEND
                INDEX   COEFFADR
                DCA     4
                DXCH    N10     +4
```

```
                EXTEND
                INDEX   COEFFADR
                DCA     6
                DXCH    N10     +6

                EXTEND
                INDEX   COEFFADR
                DCA     8D
                DXCH    N10     +8D

                EXTEND
                INDEX   COEFFADR
                DCA     10D
                DXCH    N10     +10D

                EXTEND
                INDEX   COEFFADR
                DCA     12D
                DXCH    N10     +12D

                INDEX   COEFFADR
                CA      14D
                TS      N10     +14D

                TC      Q
# Page 943
S40.15          CAE     IXX             # GAIN COMPUTATIONS (1/CONACC, VARK)
                EXTEND                  # ENTERED FROM TVCINITIALIZE AND TVCEXEC
                MP      2PI/M           #       2PI/M SCALED 1/(B+8 N M)
                DDOUBL                  #       IXX   SCALED B+20 KG-MSQ
                DDOUBL
                DDOUBL
                TS      1/CONACC        #             SCALED B+9 SEC-SQ/REV

        +7      CAE     KTLX/I          # ENTRY FROM CSM/LM V46 SWITCH-OVER
                EXTEND                  #            SCALED (B+3 ASCREV)  1/SECSQ
                MP      IAVG/TLX        #            SCALED B+2 SECSQ
                DDOUBL
                DDOUBL
                TS      VARK            #            SCALED (B+3 ASCREV)
                TC      Q

CSMN10          DEC     .99999          # N10   CSM ONLY FILTER COEFFICIENTS
                DEC     -.2549          # N11/2
                DEC     .0588           # N12
```

```
                DEC     -.7620          # D11/2
                DEC     .7450           # D12

                DEC     .99999          # N20
                DEC     -.4852          # N21/2
                DEC     0               # N22
                DEC     -.2692          # D22/2
                DEC     0               # D22

LBN10           DEC     +.99999         # N10   LOW BANDWIDTH FILTER COEFFICIENTS
                DEC     -.3285          # N11/2
                DEC     -.3301          #N12
                DEC     -.9101          #D11/2
                DEC     +.8460          #D12

                DEC     +.03125         #N20
                DEC     0               #N21/2
                DEC     0               #N22
                DEC     -.9101          #D21/2
                DEC     +.8460          #D22

                DEC     +.50000         #N30
                DEC     -.47115         #N31/2
                DEC     +.4749          #N32
                DEC     -.9558          #D31/2
                DEC     +.9372          #D32

CSMCFADR        GENADR  CSMN10          # CSM ONLY COEFFICIENTS ADDRESS
HBCFADR         GENADR  HBN10           # HIGH BANDWIDTH COEFFICIENTS ADDRESS
# Page 944
LBCFADR         GENADR  LBN10           # LOW BANDWIDTH COEFFICIENTS ADDRESS

NZERO           DEC     51              # MUST BE ODD FOR MRCLEAN
NZEROJR         DEC     23              # MUST BE ODD FOR MCLEANJR

ATTLIM          DEC     0.00833         # INITIAL ATTITUDE EROR LIMIT (1.5 DEG)
1/ATTLIM        DEC     0.007325        # .007325(ERROR) = 0 IF ERROR < 1.5 DEG

TCORR           OCT     00005           # CSM
        +1      OCT     00000           # CSM/LM (HB,LB)

FKPRIMDT        DEC     .0102           # CSM/LM (LB), (.05 X .08) SCALED AT PI/8
FREPFRAC        DEC     .0375 B-2       # CSM/LM (LB), 0.0375 SCALED AT B+2

NINETEEN        =       VD1
2PI/M           DEC     .00331017 B+8   # 2PI/M, SCALED AT 1/(B+8 N-M)
```

```
ONETHOU         DEC     1000 B-13       # KG/CS B3 TO KG/10SEC B16 CONVERSION

                EBANK=  BZERO
DAPINIT5        2CADR   DAPINIT

                EBANK=  BZERO
INITLOC2        2CADR   TVCINIT1
```

Uses 1/CONACC 204, A 80, BANKRUPT 80, BZERO 208, CDUX 80, CNTR 200, CNTRTMP 206, COEFFADR 206, COUNT 142, CSMMASS 200, DAPDATR1 200, DAPS7 63, DELPBAR 204, DELYBAR 204, DSALMOUT 87, EBANK 80, EKPRIME 198, EKTLX/I 198, EMDOT 138, EREPFRAC 198, ERRBTMP 206, ERRORY 211, ERRORZ 211, FLAGWRD6 117, HBN10 198, I 206, IAVG 200, IAVG/TLX 200, IT 185, IXX 200, KPRIMEDT 204, KTLX/I 204, L 80, LEMMASS 200, MASS 200, MASSTMP 206, MODE 145, N 206, N10 206, OGANOW 206, OMEGAYC 202, PACTOFF 198, PCMD 204, PDELOFF 204, PERRB 204, PHASETMP 208, PTMP1 202, Q 80, QRUPT 80, RCSFLAGS 200, REPFRAC 204, RESTART 57, RTRNLOC 208, SAVE 191, SQ 156, STRKTIME 206, T5LOC 163, T5TVCDT 204, TC 169, TENMDOT 204, TIME5 80, TTMP1 204, TVCPHASE 204, V97VCNTR 200, VARK 204, VCNTR 204, YACTOFF 198, YCMD 204, YDELOFF 204, and YERRB 204.

3.6.2 tvcexecutive code

1355 ⟨*tvcexecutive code* 1355⟩≡ (1346c 2825)
⟨*Page CM0945* 1356⟩

1356 ⟨*Page CM0945* 1356⟩≡ (1355)

```
# Page 945
# PROGRAM NAME....      TVCEXECUTIVE, CONSISTING OF TVCEXEC, NEEDLEUP, VARGAINS
#                       1SHOTCHK, REPCHEK, CG.CORR, COPYCYCLES, ETC.
# LOG SECTION....       TVCEXECUTIVE            SUBROUTINE ....DAPCSM
# MOD BY SCHLUNDT                               21 OCTOBER 1968
#
# FUNCTIONAL DESCRIPTION....
#      *A SELF-PERPETUATING WAITLIST TASK AT 1/2 SECOND INTERVALS WHICH:
#       PREPARES THE ROLL WITH OGA (CDUX)
#       PREPARES THE ROLL FDAI NEEDLE (FLY-TO  OGA ERROR)
#       PREPARES THE ROLL PHASE PLANE  OGAERR  (FLY-FROM  OGA ERROR)
#       PREPARES THE TVC ROLLDAP TASK WAITLIST CALL (3 CS DELAY)
#       UPDATES THE NEEDLES DISPLAY
#       UPDATES THE VEHICLE MASS AND CALLS MASSPROP TO UPDATE INERTIA DATA
#       UPDATES PITCH, YAW, AND ROLL DAP GAINS FROM MASSPROP DATA
#       PERFORMS ONE-SHOT CORRECTION FOR TMC LOOP 0-3 SEC AFTER IGNITION
#       PERFORMS REPETITIVE UPDATES FOR THE TMC LOOP AFTER THE ONE-SHOT CORR.
#
# CALLING SEQUENCE....
#      *TVCEXEC CALLED AS A WAITLIST TASK, IN PARTICULAR BY TVCINIT4 AND BY
#       ITSELF, BOTH AT 1/2 SECOND INTERVALS
#
# NORMAL EXIT MODE.... TASKOVER
#
# ALARM OR ABORT EXIT MODES.... NONE
#
# SUBROUTINES CALLED....NEEDLER, S40.15, MASSPROP, TASKOVER, IBNKCALL
#
# OTHER INTERFACES....
#      *TVCRESTART PACKAGE FOR RESTARTS
#      *PITCHDAP, YAWDAP FOR VARIABLE GAINS AND ENGINE TRIM ANGLES
#
# ERASABLE INITIALIZATION REQUIRED....
#      *SEE TVCDAPON....TVCINIT4
#      *VARK AND 1/CONACC (S40.15 OF R03)
#      *PAD LOAD EREPFRAC
#      *BITS 15,14 OF FLAGWRD6 (T5 BITS)
#      *TVCEXPHS FOR RESTARTS
#      *ENGINE-ON BIT (11.13) FOR RESTARTS
#      *CDUX, OGAD
#
# OUTPUT....
#      *ROLL DAP OGANOW, FDAI NEEDLE= (AK). AND PHASE PLANE OGAERR
#      *VARIABLE GAINS FOR PITCH/YAW AND ROLL TVC DAPS
#      *SINGLE-SHOT AND REPETITIVE CORRECTIONS TO ENGINE TRIM ANGLES
```

```
#       PACTOFF AND YACTOFF
#
# DEBRIS....    MUCH, BUT SHAREABLE WITH RCS/ENTRY, ALL IN EBANK6

# Page 946
                BANK    16
                SETLOC  DAPROLL
                BANK
                EBANK=  BZERO
                COUNT*  $$/TVCX

TVCEXEC         CS      FLAGWRD6        # CHECK FOR TERMINATION (BITS 15,14 READ
                MASK    OCT60000        #       10 FROM TVCDAPON TO RCSDAPON)
                EXTEND
                BZMF    TVCEXFIN        # TERMINATE

                CAF     .5SEC           # W.L. CALL TO PERPETUATE TVCEXEC
                TC      WAITLIST
                EBANK=  BZERO
                2CADR   TVCEXEC

ROLLPREP        CAE     CDUX            # UPDATE ROLL LADDERS (NO NEED TO RESTART-
                XCH     OGANOW          #       PROTECT, SINCE ROLL DAPS RE-START)
                XCH     OGAPAST

                CAE     OGAD            # PREPARE ROLL FDAI NEEDLE WITH FLY-TO
                EXTEND                  #       ERROR (COMMAND - MEASURED)
                MSU     OGANOW
                TS      AK              # FLY-TO OGA ERROR, SC.AT B-1 REVS

                EXTEND                  # PREPARE ROLL DAP PHASE PLANE OGAERR
                MP      -BIT14
                TS      OGAERR          # PHASE-PLANE (FLY-FROM) OGAERROR,
                                        #       SC.AT B+0 REVS

                CAF     THREE           # SET UP ROLL DAP TASK (ALLOW SOME TIME)
                TC      WAITLIST
                EBANK=  BZERO
                2CADR   ROLLDAP

NEEDLEUP        TC      IBNKCALL        # DO A NEEDLES UPDATE (RETURNS AFTER CADR)
                CADR    NEEDLER         #       (NEEDLES RESTARTS ITSELF)

VARGAINS        CAF     BIT13           # CHECK ENGINE-ON BIT TO INHIBIT VARIABLE
                EXTEND                  #       GAINS AND MASS IF ENGINE OFF
                RAND    DSALMOUT        # CHANNEL 11
```

```
                CCS     A
                TCF     +4              #       ON, SO OK TO UPDATE GAINS AND MASS
        +5      CAF     TWO             #       OFF, SO BYPASS MASS/GAIN UPDATES,
                TS      TVCEXPHS        #               ALSO ENTRY FROM CCS BELOW WI
                TCF     1SHOTCHK        #               VCNTR = -0 (V97 R40 ENGFAIL)
                CCS     VCNTR           #       TEST FOR GAIN OF UPDATE TIME
                TCF     +4              #               NOT YET
# Page 947
                TCF     GAINCHNG        #               NOW
                TCF     +0              #               NOT USED
                TCF     VARGAINS +5     #               NO, LOTHRUST (S40.6 R40)

        +4      TS      VCNTRTMP        #       PROTECT VCNTR AND
                CAE     CSMMASS         #       CSMMASS DURING AN IMPULSIVE BURN
                TS      MASSTMP
                TCF     EXECCOPY

GAINCHNG        TC      IBNKCALL        # UPDATE IXX, IAVG, IAVG/TLX
                CADR    FIXCW           # MASSPROP ENTRY (ALREADY INITIALIZED)
                TC      IBNKCALL        # UPDATE 1/CONACC, VARK
                CADR    S40.15          #       (S40.15 IS IN TVCINITIALIZE)
                CS      TENMDOT         # UPDATE MASS FOR NEXT 10 SEC. OF BURN
                AD      CSMMASS
                TS      MASSTMP         # KG B+16

                CAF     NINETEEN        # RESET THE VARIABLE-GAIN UPDATE COUNTER
                TS      VCNTRTMP

EXECCOPY        INCR    TVCEXPHS        # RESTART-PROTECT THE COPYCYCLE         (1)

                CAE     MASSTMP         # CSMMASS KG B+16
                TS      CSMMASS

                CAE     VCNTRTMP        # VCNTR
                TS      VCNTR
                TS      V97VCNTR        # FOR ENGFAIL (R41) MASS UPATES AT SPSOFF

                INCR    TVCEXPHS        # COPYCYCLE OVER                         (2)

1SHOTCHK        CCS     CNTR            # CHECK FOR ONE-SHOT OR REPCORR
                TCF     +4              #       NOT YET
                TCF     1SHOTOK         #       NOW
                TCF     REPCHEK         #       ONE-SHOT OVER, ON TO REPCORR
                TCF     1SHOTOK         #       NOW (ONE-SHOT ONLY, NO REPCORR)

        +4      TS      CNTRTMP         # COUNT DOWN
```

```
                CAF     SIX             # SETUP TVCEXPHS FOR ENTRY AT CNTRCOPY
                TS      TVCEXPHS
                TCF     CNTRCOPY

REPCHEK         CAE     REPFRAC         # CHECK FOR REPETITIVE UPDATES
                EXTEND
                BZMF    TVCEXFIN        #       NO  (NEG OR +-ZERO)
                TS      TEMPDAP +1      #       YES, SET UP CORRECTION FUNCTION
                CAF     FOUR            # SET UP TVCEXPHS FOR ENTRY AT CORSETUP
                TS      TVCEXPHS
                TCF     CORSETUP
# Page 948
1SHOTOK         CAF     BIT13           # CHECK ENGINE-ON BIT, NOT PERMITTING
                EXTEND                  #       SWITCHOVER DURING ENGINE-SHUTDOWN
                RAND    DSALMOUT
                CCS     A
                TCF     +2              #       ONE-SHOT OK
                TCF     TVCEXFIN        #       NO, TERMINATE

                INCR    TVCEXPHS        #                                       (3)

# RSB 2009.  The following instruction was previously "CAE FCORFRAC", but FCORFRAC
# is not in erasable memory as implied by the use of CAE.  I've accordingly changed
# it to CAF instead to indicate fixed memory.
TEMPSET         CAF     FCORFRAC        #       SET UP CORRECTION FRACTION
                TS      TEMPDAP +1

                INCR    TVCEXPHS        # ENTRY FROM REPCHECK AT NEXT LOCATION  (4)

CORSETUP        CAE     DAPDATR1        # CHECK FOR LEM-OFF/ON
                MASK    BIT13           # (NOTE, SHOWS LEM-OFF)
                EXTEND
                BZF     +2              # LEM IS ON,  PICK UP   TEMPDAP+1
                CAE     TEMPDAP +1      # LEM IS OFF, PICK UP 2(TEMPDAP+1)
                AD      TEMPDAP +1
                TS      TEMPDAP         # CG.CORR USES TEMPDAP

                CAF     NEGONE          # SET UP FOR CNTR = -1 (SWTCHOVR DONE)
                TS      CNTRTMP         #       (COPYCYCLE AT "CNTRCOPY")

CG.CORR         EXTEND                  # PITCH TMC LOOP
                DCA     PDELOFF
                DXCH    PACTTMP
                EXTEND
                DCS     PDELOFF
                DDOUBL
```

```
                DDOUBL
                DXCH    TTMP1
                EXTEND
                DCA     DELPBAR
                DDOUBL
                DDOUBL
                DAS     TTMP1
                EXTEND
                DCA     TTMP1
                EXTEND
                MP      TEMPDAP
                DAS     PACTTMP

                EXTEND                  # YAW TMC LOOP
                DCA     YDELOFF
                DXCH    YACTTMP
                EXTEND
                DCS     YDELOFF
                DDOUBL
# Page 949
                DDOUBL
                DXCH    TTMP1
                EXTEND
                DCA     DELYBAR
                DDOUBL
                DDOUBL
                DAS     TTMP1
                EXTEND
                DCA     TTMP1
                EXTEND
                MP      TEMPDAP
                DAS     YACTTMP

CORCOPY         INCR    TVCEXPHS        # RESTART-PROTECT THE COPYCYCLE         (5)

                EXTEND                  # TRIM-ESTIMATES, AND
                DCA     PACTTMP
                TS      PACTOFF         #       TRIMS
                DXCH    PDELOFF

                EXTEND
                DCA     YACTTMP
                TS      YACTOFF
                DXCH    YDELOFF

                INCR    TVCEXPHS        # ENTRY FROM 1SHOTCHK AT NEXT LOCATION  (6)
```

```
CNTRCOPY        CAE     CNTRTMP         # UPDATE CNTR (RESTARTS OK, FOLLOWS CPYCY)
                TS      CNTR

TVCEXFIN        CAF     ZERO            # RESET TVCEXPHS
                TS      TVCEXPHS
                TCF     TASKOVER        # TVCEXECUTIVE FINISHED

FCORFRAC        OCT     10000           # ONE-SHOT CORRECTION FRACTION

# Page 950 (page is empty)
```

Uses 1/CONACC 204, A 80, AK 200, BZERO 208, CDUX 80, CNTR 200, CNTRTMP 206, COMMAND 169, COUNT 142, CSMMASS 200, DAPDATR1 200, DAPROLL 63, DELPBAR 204, DELYBAR 204, DSALMOUT 87, EBANK 80, EREPFRAC 198, FLAGWRD6 117, IAVG 200, IAVG/TLX 200, IXX 200, L 80, MASS 200, MASSTMP 206, MODE 145, OGA 206, OGAD 200, OGAERR 206, OGANOW 206, OGAPAST 206, PACTOFF 198, PACTTMP 206, PDELOFF 204, REPFRAC 204, RESTART 57, REVS 206, TC 169, TEMPDAP 200, TENMDOT 204, TTMP1 204, TVCEXPHS 206, V97VCNTR 200, VARK 204, VCNTR 204, VCNTRTMP 206, W 183, YACTOFF 198, YACTTMP 206, and YDELOFF 204.

3.6.3 tvcmassprop code

1361 ⟨*tvcmassprop code* 1361⟩≡ (1346c 2827)
⟨*Page CM0951* 1362⟩

1362 ⟨*Page CM0951* 1362⟩≡ (1361)

```
# Page 951
# PROGRAM NAME....MASSPROP
# LOG SECTION....TVCMASSPROP            PROGRAMMER...MELANSON (ENGEL, SCHLUNDT)
#
# FUNCTIONAL DESCRIPTION:
#
#       MASSPROP OPERATES IN TWO MODES: (1) IF LEM MASS OR CONFIGURATION ARE UPDATED
#       FOR THIS) THE ENTIRE PROGRAM MUST BE RUN THROUGH, BREAKPOINT VALUES AND DERIV
#       RESPECT TO CSM MASS BEING CALCULATED PRIOR TO CALCULATION OF THE OUTPUTS.  (2
#       CALCULATED USING PREVIOUSLY COMPUTED BREAKPOINT VALUES AND DERIVATIVES.
#
# CALLING SEQUENCES
#
#       IF LEM MASS OR CONFIGURATION HAS BEEN UPDATED, TRANSFER TO MASSPROP, OTHERWIS
#               L       TC      BANKCALL or IBNKCALL
#               L+1     CADR    MASSPROP
#                       OR
#               L+1     CADR    FIXCW
#               L+2     RETURNS VIA Q
#
# CALLED:  IN PARTICULAR BY DONOUN47 (JOB) AND TVCEXECUTIVE (TASK)
#
# JOBS OR TASKS INITIATED:  NONE
#
# SUBROUTINES CALLED:  NONE
#
# ERASABLE INITIALIZATION REQUIRED
#
#       LEMMASS MUST CONTAIN LEM MASS SCALED AT B+16 KILOGRAMS
#       CSMMASS MUST CONTAIN CSM MASS SCALED AT B+16 KILOGRAMS
#       DAPDATR1 MUST BE SET TO INDICATE VEHICLE CONFIGURATION.
#               BITS (15,14,13)  =  ( 0 , 0 , 1 )       LEM OFF
#                                   ( 0 , 1 , 0 )       LEM ON (ASCNT,DSCNT)
#                                   ( 1 , 1 , 0 )       LEM ON (ASCNT ONLY)
#
# ALARMS:  NONE
#
# EXIT:         TC      Q
#
# OUTPUTS:
#
#       (1)     IXX, SINGLE PRECISION SCALED AT B+20 IN KG-M SQ.
#       (2)     IAVG, SINGLE PRECISION SCALED AT B+20 IN KG-M SQ.
#       (3)     IAVG/TLX, SINGLE PRECISION, SCALED AT B+2 SEC-SQD
#
```

```
#       THEY ARE STORED IN CONSECUTIVE REGISTERS IXX0, IXX1, IXX2
#       CONVERSION FACTOR:  (SLUG-FTSQ) = 0.737562 (KG-MSQ)
# Page 952
#
# OUTPUTS ARE CALCULATED AS FOLLOWS:
#
#       (1)     IF LEM DOCKED, LEMMASS IS FIRST ELIMINATED AS A PARAMETER
#
#               VARST0 = INTVALUE0 + LEMMASS(SLOPEVAL0)         IXX             BREAKPOINT VALU
#               VARST1 = INTVALUE1 + LEMMASS(SLOPEVAL1)         IAVG            BREAKPOINT VALU
#               VARST2 = INTVALUE2 + LEMMASS(SLOPEVAL2)         IAVG/TLX        BREAKPOINT VALU
#
#               VARST3 = INTVALUE3 + LEMMASS(SLOPEVAL3)         IAVG/TLX        SLOPE FOR CSMMA
#               VARST4 = INTVALUE4 + LEMMASS(SLOPEVAL4)         IAVG            SLOPE FOR CSMMA
#
#               VARST5 = INTVALUE5 + LEMMASS(SLOPEVAL5)         IXX             SLOPE FOR ALL V
#
#               VARST6 = INTVALUE6 + LEMMASS(SLOPEVAL6)         IAVG            SLOPE FOR CSMMA
#               VARST7 = INTVALUE7 + LEMMASS(SLOPEVAL7)         IAVG/TLX        SLOPE FOR CSMMA
#
#               VARST8 = INTVALUE8 + LEMMASS(SLOPEVAL8)         IAVG            DECREMENT TO BR
#               VARST9 = INTVALUE9 + LEMMASS(SLOPEVAL9)         IAVG/TLX        DECREMENT TO BR
#
#       (2)     IF LEM NOT DOCKED
#
#               VARST0 = NOLEMVAL0      WHERE THE MEANING AND SCALING OF VARST0
#                        .              TO VARST9 ARE THE SAME AS GIVEN ABOVE
#                        .
#                        .              NOTE... FOR THIS CASE, VARST8,9 HAVE NO
#               VARST9 = NOLEMVAL9      MEANING (THEY ARE COMPUTED BUT NOT USED)
#
#       (3)     THE FINAL OUTPUT CALCULATIONS ARE THEN DONE
#
#               IXX0 = VARST0 + (CSMMASS + NEGBPW)VARST5                IXX
#
#               IXX1 = VARST1 + (CSMMASS + NEGBPW)VARST(4 OR 6)         IAVG
#
#               IXX2 = VARST2 + (CSMMASS + NEGBPW)VARST(3 OR 7)         IAVG/TLX
#
#       THE DATA USED CAME FROM THE CSM/LM SPACECRAFT OPERATIONAL DATA BOOK
#               VOL. 3, NASA DOCUMENT SNA-8-D-027 (MARCH 1968)
#
#       PERTINENT MASS DATA:            CSM WEIGHT      (FULL)  64100 LBS.
#                                                       (EMPTY) 23956 LBS.
#                                       LEM WEIGHT      (FULL)  32000 LBS.
#                                                       (EMPTY) 14116 LBS.
```

```
#
#       (WEIGHTS ARE FROM AMMENDMENT #1 (APRIL 24, 1968) TO ABOVE DATA BOOK)
# Page 953

                BANK    25
                SETLOC  DAPMASS
                BANK
                EBANK=  BZERO
                COUNT*  $$/MASP

MASSPROP        CAF     NINE            # MASSPROP USES TVC/RCS INTERRUPT TEMPS
                TS      PHI333          # SET UP TEN PASSES

LEMTEST         CAE     DAPDATR1        # DETERMINE LEM STATUS
                MASK    BIT13
                EXTEND
                BZF     LEMYES

LEMNO           INDEX   PHI333          # LEM NOT ATTACHED
                CAF     NOLEMVAL
                TCF     STOINST

LEMYES          CAE     LEMMASS         # LEM IS ATTACHED
                DOUBLE
                EXTEND
                INDEX   PHI333
                MP      SLOPEVAL
                DDOUBL
                INDEX   PHI333
                AD      INTVALUE

STOINST         INDEX   PHI333          # STORAGE INST BEGIN HERE
                TS      VARST0
                CCS     PHI333          # ARE ALL TEN PASSES COMPLETED
                TCF     MASSPROP +1     # NO: GO DECREMENT PHI333

DXTEST          CCS     DAPDATR1        # IF NEG, BIT15 IS 1, LEM DSCNT STAGE OFF
                TCF     FIXCW
                TCF     FIXCW
                DXCH    VARST0 +8D
                DAS     VARST0 +1
                CA      DXITFIX
                ADS     VARST0 +7

FIXCW           CAF     BIT2            # COMPUTATION PHASE BEGINS HERE. SET UP
                TS      PHI333          # THREE PASSES
```

```
                TS      PSI333

                CAE     CSMMASS         # GET DELTA CSM WEIGHT:  SIGN DETERMINES
                AD      NEGBPW          # SLOPE LOCATIONS.
                DOUBLE
                TS      TEMP333
# Page 954
                EXTEND
                BZMF    PEGGY           # DETERMINE CORRECT SLOPE
                CAF     NEG2
                TS      PHI333

PEGGY           INDEX   PHI333          # ALL IS READY:  CALCULATE OUTPUTS NOW
                CAE     VARST5          # GET SLOPE
                EXTEND
                MP      TEMP333         # MULT BY DELTA CSM WEIGHT
                DOUBLE
                INDEX   PSI333
                AD      VARST0          # ADD BREAKPOINT VALUE
                INDEX   PSI333
                TS      IXX             # ***** OUTPUTS (IXX0, IXX1, IXX2) *****

                CCS     PSI333          # BOOKKEEPING: MASSPROP FINISHED OR NOT
                TCF     BOKKEP2         # NO:  GO TAKE CARE OF INDEXING REGISTERS

                CAE     DAPDATR1        # UPDATE WEIGHT/G
                MASK    BIT14
                CCS     A
                CA      LEMMASS
                AD      CSMMASS
                TS      WEIGHT/G        # SCALED AT B+16 KILOGRAMS
ENDMASSP        TC      Q

BOKKEP2         TS      PSI333          # REDUCE PSI BY ONE
                EXTEND
                DIM     PHI333
                TCF     PEGGY

# Page 955
NOLEMVAL        DEC     25445 B-20
                DEC     87450 B-20
                DEC     .30715 B-2
                DEC     1.22877 E-5 B+12
                DEC     1.6096 B-6
                DEC     1.54 B-6
                DEC     7.77177 B-6
```

```
                DEC     3.46458 E-5 B+12

INTVALUE        DEC     26850 B-20
                DEC     127518 B-20
                DEC     .54059 B-2
                DEC     .153964 E-4 B+12
                DEC     -.742923 B-6
                DEC     1.5398 B-6
                DEC     9.68 B-6
                DEC     .647625 E-4 B+12
                DEC     -27228 B-20
                DEC     -.206476 B-2

SLOPEVAL        DEC     1.96307 B-6
                DEC     27.5774 B-6
                DEC     2.3548 E-5 B+12
                DEC     2.1777 E-9 B+26
                DEC     1.044 E-3 B+8
                DEC     0
                DEC     2.21068 E-3 B+8
                DEC     1.5166 E-9 B+26
                DEC     -1.284 B-6
                DEC     2 E-5 B+12

NEGBPW          DEC     -15402.17 B-16
DXITFIX         DEC*    -1.88275 E-5 B+12*
```

Uses A 80, BZERO 208, COUNT 142, CSMMASS 200, D 226, DAPDATR1 200, DAPMASS 59, EBANK 80, FACTOR 226, IAVG 200, IAVG/TLX 200, IXX 200, L 80, LEMMASS 200, MASS 200, PHI333 202, PSI333 202, Q 80, RUN 191, SLOPE 213, SQ 156, TC 169, TEMP333 202, VARST0 202, VARST5 202, and WEIGHT/G 200.

3.6.4 tvcrestarts code

1366 ⟨*tvcrestarts code* 1366⟩≡ (1346c 2828)
⟨*Page CM0956* 1367⟩

1367 ⟨*Page CM0956* 1367⟩≡ (1366)

```
# Page 956
# NAME....TVCRESTART PACKAGE, CONSISTING OF REDOTVC, ENABL1, 2, CMDSOUT, PHSCHK2, ETC.
# LOG SECTION....TVCRESTARTS                    SUBROUTINE....DAPCSM
# MODIFIED BY SCHLUNDT                          21 OCTOBER 1968
#
# FUNCTIONAL DESCRIPTION....
#
#      *RESTART-PROCESS THE TVC DAPS, INCLUDING PITCHDAP, YAWDAP,
#       TVCEXECUTIVE, ROLLDAP, TVCINIT4, TVCDAPON, AND CSM/.M V46 SWTCHOVR.
#
#      *TVC RESTARTS DESERVE SPECIAL CONSIDERATION IN SEVERAL AREAS.
#       RESTART DOWN-TIME IS IMPORTANT BECAUSE OF THE TRANSIENTS INTRODUCED
#       BY THE THRUST VECTOR RETURN TO THE ACTUATOR MECHANICAL NULLS
#       FOLLOWING TVC- AND OPTICS-ERROR-COUNTER-DISENABLES (CHANNEL 12).
#       TVC USES A MIXTURE OF WAITLIST, T5, T6, AND JOB CALLS.  THERE IS
#       FILTER MEMORY (UP TO 6TH ORDER) TO BE PROTECTED IF WILD TRANSIENTS
#       ARE TO BE AVOIDED.  COUNTERS ARE INVOLVED FOR ONE-SHOT
#       CORRECTIONS AND GAIN UPDATES.  THE GIMBAL TRIM ESTIMATORS AND THE
#       BODY AXIS ATTITUDE ERROR INTEGRATORS INVOLVE DIGITAL SUMMATION.
#       DIGITAL DIFFERENTIATORS ARE INVOLVED IN THE BODY AXIS RATE ESTIMA-
#       TIONS AND IN THE OUTPUTTING OF ACTUATOR COMMANDS.  THERE IS AN
#       OFFSET-TRACKER-FILTER TO PROTECT.  ETC., ETC.
#
#      *THOSE QUANTITIES WHICH MUST BE PROTECTED ARE STORED IN TEMPORARY
#       REGISTERS AS THEY ARE COMPUTED, FOR UPDATING THE REAL REGISTERS
#       DURING COPYCYCLES.
#
#      *THE SEVERAL COPYCYCLES ARE EACH PROTECTED BY PHASE POINTS AT THEIR
#       BEGINNING AND AT THEIR TERMINATION.  THE PHASE POINTS ARE SIMPLY
#       "INCR" INSTRUCTIONS, EITHER "INCR TVCEXPHS" FOR COPYCYCLES
#       IN THE TVCEXECUTIVE, OR "INCR TVCPHASE" FOR THE PITCH AND YAW
#       COPYCYCLES.  INDEXING ON EACH OF THESE POINTERS THEN PERMITS A
#       RETURN TO THE APPROPRIATE RESTART POINTS.
#
#      *IF A RESTART OCCURS DURING EITHER COPYCYCLE, THAT COPYCYCLE IS
#       COMPLETED.  THEN THE NORMAL TVCINIT4....DAPINIT....PITCHDAP STARTUP
#       SEQUENCE IS CALLED UPON TO GET THINGS GOING AGAIN.
#
#      *TVC-ENABLE AND OPTICS-ERROR-COUNTER ENABLE MUST BE SET ASAP
#       (ALLOWING FOR PROCEDURAL DELAYS).  THEN THE ENGINES ARE COMMANDED
#       TO THE P,YACTOFF TRIM VALUES.  THE DAPS ARE THEN READY TO GO ON THE
#       AIR, WITH THE REGULAR STARTUP SEQUENCE, EITHER AT MRCLEAN FOR A
#       COMPLETE INITIALIZATION OR AT TVCINIT4 FOR A PARTIAL INITIALIZATION.
#
#      *FOR RESTARTS PRIOR TO THE SETTING OF THE T5 BITS AT DOTVCON THE
```

```
#       PRE40.6 SECTION OF S40.6 TAKES CARE OF RE-ESTABLISHING TRIMS.
#
#      *IF A RESTART OCCURS DURING THE TVCEXEC....TVCEXFIN SEQUENCE THE
#       COMPUTATIONS WILL BE COMPLETED, STARTING AT THE APPROPRIATE RESTART
#       POINT, AFTER THE DAPS ARE READY TO GO ON THE AIR.
#
#      *IF A RESTART OCCURS PRIOR TO TVCINIT4 (TVCPHAS = -1) E.G. DURING
#       THE EARLY DAP INITIALIZATION PHASE, THE DAP STARTUP SEQUENCE IS
#       ENTERED AT MRCLEAN FOR A FULL INITIALIZATION.
#
#      *FOR RESTARTS DURING CSM/LM V46 SWITCH-VER, TVCPHASE IS SET TO -2.
#       AND THE RESTART LOGIC GOES BACK TO REDO SWITCH-OVER (AFTER THE
#       NORMAL DAP RESTART SEQUENCE IS FOLLOWED.)
#
#      *RESTARTS ARE NOT CRITICAL TO THE ROLL DAP PERFORMANCES HENCE THE
#       ROLL DAP IS MERELY RESTARTED.
#
#      *RESTARTS DURING A STROKE TEST (STROKER IS NON-ZERO) WILL CAUSE THE
# Page 957
#       STROKE TEST TO BE TERMINATED.  A NEW V68 ENTRY WILL BE REQUIRED
#       TO GET IT GOING AGAIN (NO AUTOMATIC RESTART).
#
#      *REDOTVC IS REACHED FOLLOWING ANY RESTART WHICH FINDS THE T5 BITS
#       (BITS 15,14 OF FLAGWRD6) SET FOR TVC.  DOTVCON TVCPHASE = -1
#       AND TVC EXPHS = 0 JUST BEFORE SETTING THESE BITS, JUST BEFORE
#       MAKING THE T5 CALL TO TVCDAPON.  ON A NORMAL SHUTDOWN DOTVCRCS
#       CALLS RCSDAPON, WHICH RESETS THE T5 BIT FOR RCS
#
# CALLING SEQUENCE....T5, IN PARTICULAR BY ELRSKIP OF FRESH START/RESTART
#
# NORMAL EXIT MODES....RESUME, NOQRSM, POSTJUMP (TO TVCINIT4 OR MRCLEAN)
#
# ALARM OR ABORT EXIT MODES....NONE
#
# SUBROUTINES CALLED....
#
#      *PCOPY+1, YCOPY+1 (PITCH AND YAW COPYCYCLES)
#      *ENABLE1,2, CMDSOUT (RE-ESTABLISH ACTUATOR TRIMS)
#      *MRCLEAN OR TVCINIT4 (TVCDAP INITIALIZATIONS)
#      *SWITCHOVR +5 (CSM/LM V46 SWITCH-OVER)
#      *EXRSTRT AND TVCEXECUTIVE PHASE POINTS 1 THRU 6
#      *WAITLIST, IBNKCALL, POSTJUMP, ISWCALL
#
# OTHER INTERFACES....DOTVCON AND RCSDAPON (T5 BITS), ELRSKIP (CALLS IT)
#
# ERASABLE INITIALIZATION REQUIRED....
```

```
#
#      *T5 BITS (1,0), TVCPHASE (-2,-1,0,1,2,3), TVCEXPHS (1 THRU 6)
#      *TVC DAP VARIABLES
#      *OPERATIONS PERFORMED BY REDOTVC ARE BASED ON THE ASSUMPTION THAT
#       THE TVC DAPS ARE RUNNING NORMALLY
#
# OUTPUT....
#
#      *PITCH AND YAW TVC DAP COPYCYCLES COMPLETED IF INTERRUPTED
#      *TVCEXECUTIVE COMPLETED IF INTERRUPTED
#      *STROKE TEST TERMINATED IF INTERRUPTED
#      *CSM/LM V46 SWITCH-OVER REPEATED IF INTERRUPTED
#      *ACTUATOR TRIMS RE-ESTABLISHED (ACTUATORS BACK ON THE AIR)
#      *TVC DAP INITIALIZATION AS REQUIRED
#      *ALL TVC DAP OPERATIONS ON THE AIR
#
# DEBRIS....TVC TEMPORARIES IN EBANK6

#Page 958

                BANK    16
                SETLOC  DAPROLL
                BANK
                EBANK=  TVCPHASE
                COUNT*  $$/RSRT

REDOTVC         LXCH    BANKRUPT        # TVC RESTART PACKAGE
                EXTEND
                QXCH    QRUPT           # ("TCR" IN "FINCOPY")

EXECPHS         CCS     TVCEXPHS        # CHECK TVCEXECUTIVE PHASE
                TCF     +2              #       MUST RESTART TVCEXECUTIVE
                TCF     TVCDAPHS        #       NO NEED TO RESTART TVCEXECUTIVE

                CAF     NINE            # 9CS DELAY TO FORCE EXRSTRT TO OCCUR
                TC      WAITLIST        #       BEFORE PITCHDAP, AFTER CMDSOUT
                EBANK=  TVCEXPHS
                2CADR   EXRSTRT

TVCDAPHS        CS      OCT37776        # CHECK BITS 15 AND 1 OF TVCPHASE TO SEE
                MASK    TVCPHASE        #       DAP RESTART LOCATION (-1,1,2,3)
                CCS     A
                TCF     FINCOPY         #       FINISH THE COPYCYCLE FIRST
                TCF     ENABL1          #       JUST PREPARE THE OUTCOUNTERS AND GO

                CS      TVCPHASE        # TEST FOR TVCPHASE = -2
```

```
                MASK    BIT2            #       (THIS INDICATES RESTART OCCURRED
                EXTEND                  #        DURING CSM/LM V46 SWITCH-OVER)
                BZF     TRIM/CMD        # NO. TVCPHASE = -1. RSTRT WAS IN TVCINIT

ENABL1          CAF     BIT8            # TVC ENABLE, FOLLOWED BY 40 MS (MIN) WAIT
                AD      BIT11           #       SET BIT FOR OPTICS-DAC-ENABLE ALSO
                EXTEND                  #       (ENABL1 ENTERED FROM TVCDAPHS / FINC
                WOR     CHAN12
                CAF     TVCADDR         # WAIT, CALLING ENABL2 (BBCON THERE)
                TS      T5LOC
                CAF     TVCADDR +4      #       60 MS (TVCEXADR)
                TS      TIME5

                TCF     RESUME

ENABL2          LXCH    BANKRUPT        # CONTINUE PREPARATION OF OUTCOUNTERS

                CAF     BIT2            # OPTICS ERROR CNTR ENABLE, 4MS MIN WAIT
                EXTEND
                WOR     CHAN12
# Page 959
                CAF     TVCADDR +2      # WAIT, CALLING CMDSOUT (BBCON THERE)
                TS      T5LOC
                CAF     OCT37776        #       20MS
                TS      TIME5

                TCF     NOQRSM

CMDSOUT         LXCH    BANKRUPT        # CONTINUE PREPARATION OF OUTCOUNTERS
                EXTEND
                QXCH    QRUPT

                CS      ZERO            # MOST RECENT ACTUATOR COMMANDS
                AD      PCMD            #       (AVOID +0)
                TS      TVCPITCH
                CS      ZERO
                AD      YCMD
                TS      TVCYAW

                CAF     PRIO6           # RELEASE THE COUNTERS (BITS 11,12)
                EXTEND
                WOR     CHAN14

PHSCHK2         CCS     TVCPHASE        # CHECK TVCPHASE AGAIN
                TCF     CHKSTRK
                TCF     CHKSTRK
```

```
                CCS     A               # A CONTAINS THE DIMINISHED ABSOLUTE OF
                TC      +3              # TVCPHASE (-2 BECOMES +1. -1 BECOMES +0)

                TC      POSTJUMP        #       REPEAT TVC INITIALIZATION
                CADR    MRCLEAN         #       (DO NOT RETURN)

        +3      TC      IBNKCALL        #       REPEAT CSM/LM V46 SWITCH-OVER
                CADR    SWICHOVR +5     #       (RETURN TO CHECK FOR STROKE TEST)

CHKSTRK         CCS     STROKER         # CHECK FOR STROKE TEST IN PROGRESS
                TCF     TSTINITJ        # YES, KILL IT
                TCF     +2              # NO, PROCEED
                TCF     TSTINITJ        # YES, KILL IT

        +4      TC      POSTJUMP        #       IF POSITIVE OR ZERO, RESTART AT
                CADR    TVCINIT4        #               TVCINIT4 (ZEROS TVCPHASE, AND
                                        #               CALLS TVC DAPS VIA DAPINIT)
FINCOPY         INDEX   TVCPHASE        # PICK UP THE APPROPRIATE COPYCYCLE
                CAF     TVCCADR
                TCR     ISWCALL         # RE-ENTER THE COPYCYCLE, RETURN AT END
                TCF     ENABL1          # NOW PREPARE THE OUTCOUNTERS

TRIM/CMD        EXTEND                  # TVCDAPON INITIALIZATION NOT COMPLETED,
# Page 960
                DCA     PACTOFF         #       EG. P,YCMD MAY NOT BE SET.  SET...
                DXCH    PCMD
                TCF     ENABL1          # NOW PREPARE THE OUTCOUNTERS

TSTINITJ        CAF     ZERO            # DISABLE STROKE TEST (-0 SHOWS PRIOR V68)
                TS      STROKER         # (+0 MEANS NEW V68 REQUIRED FOR STARTUP)

                TCF     CHKSTRK +4

EXRSTRT         INDEX   TVCEXPHS        # TVCEXECUTIVE RESTARTS....GO TO
                CAF     TVCEXADR        #       APPROPRIATE RESTART POINT
                INDEX   A
                TCF     0

# Page 961
# TVC RESTART TABLES.... ORDER IS REQUIRED.  HI-ORDER WORDS ONLY, OF 2CADRS, SINCE BBCON IS ALR

TVCADDR         =       TVCCADR         # TABLE OF CADRS, UNUSED LOCS FOR GENADRS
TVCCADR         GENADR  ENABL2          # (FOR T5 CALL, UNUSED TABLE LOC)
        +1      CADR    PCOPY   +1      # PITCH COPYCYCLE
        +2      GENADR  CMDSOUT         # (FOR T5 CALL, UNUSED TABLE LOC)
        +3      CADR    YCOPY   +1      # YAW COPYCYCLE
```

```
TVCEXADR        OCT     37772           # (UNUSED TABLE LOC, FILL WITH 60MS, T5)
        +1      GENADR  EXECCOPY +1     # TVCEXECUTIVE RESTART POINTS (ORDERED)
        +2      GENADR  1SHOTCHK
        +3      GENADR  TEMPSET
        +4      GENADR  CORSETUP
        +5      GENADR  CORCOPY +1
        +6      GENADR  CNTRCOPY
```

Uses A 80, BANKRUPT 80, CHAN12 87, CHAN14 87, CNTR 200, COUNT 142, DAPROLL 63, EBANK 80, FLAGWRD6 117, IT 185, LOC 145, P 188, PACTOFF 198, PCMD 204, QRUPT 80, RESTART 57, STROKER 204, T5LOC 163, TC 169, THRUST 85, TIME5 80, TVCEXPHS 206, TVCPHASE 204, TVCPITCH 85, TVCYAW 85, YACTOFF 198, and YCMD 204.

3.6.5 tvcdaps code

1372 ⟨*tvcdaps code* 1372⟩≡ (1346c 2824)
⟨*Page CM0961* 1373⟩

1373 ⟨*Page CM0961* 1373⟩≡ (1372)

```
# Page 961
# PROGRAM NAME....TVCDAP, CONSISTING OF PITCHDAP, YAWDAP, ETC.
# LOG SECTION....TVCDAPS                        SUBROUTINE....DAPCSM
# MODIFIED BY SCHLUNDT                          21 OCTOBER 1968
#
# FUNCTIONAL DESCRIPTION
#
#       SELF-PERPETUATING T5 TASKS WHICH GENERATE THE COMMAND SIGNALS
#       FOR THE PITCH AND YAW SPS GIMBAL ACTUATORS DURING TVC (SPS) BURNS,
#       IN RESPONSE TO BODY-AXIS RATE COMMANDS FROM CROSS-PRODUCT STEERING
#       (S40.8).  IF NO STEERING (IMPULSIVE BURNS) MAINTAINS ATTITUDE-HOLD
#       ABOUT THE REFERENCE (INITIAL) DIRECTIONS (ZERO RATE COMMANDS).
#
#       THE PITCH AND YAW LOOPS ARE SEPARATE, BUT STRUCTURED IDENTICALLY.
#       EACH ATTITUDE-RATE LOOP INCLUDES GIMBAL ANGLE RATE DERIVATION,
#       GIMBAL/BODY AXIS TRANSFORMATION, BODY-AXIS ATTITUDE ERROR
#       INTEGRATION WITH ERROR LIMITING, THE GENERALIZED 6TH-ORDER FILTERS
#       FOR CSM OR CSM/LM OPERATION. A FILTER OUTPUT LIMITER.
#       CG-OFFSET TRACKER FILTER, AND THE CG-TRACKER MINOR LOOP.
#
#       THE DAPS ARE CYCLIC, CALLING EACH OTHER AT 1/2 THE DAP SAMPLE
#       TIME, AS DETERMINED BY T5TVCDT.  THE ACTUATOR COMMANDS ARE
#       REGENERATED AS ANALOG VOLTAGES BY THE OPTICS ERROR COUNTERS, WHICH
#       TRANSMIT THE SIGNAL TO THE ACTUATOR SERVOS WHEN THERE IS PROPER CDU
#       MODING.
#
# CALLING SEQUENCE.... (TYPICALLY)
#
#       T5 CALL OF TVCDAPON (TVCINITIALIZE) BY DOTVCON (P40)
#       T5 CALL OF DAPINIT (TVCDAPS) BY TVCINIT4 (TVCINITIALIZE)
#       T5 CALL OF PITCHDAP BY DAPINIT
#       T5 CALL OF YAWDAP BY PITCHDAP
#       T5 CALL OF PITCHDAP BY YAWDAP
#               ETC.
#       (AUTOMATIC SEQUENCING FROM TVCDAPON)
#
# NORMAL EXIT MODE....RESUME
#
# ALARM OR ABORT EXIT MODES....NONE
#
# SUBROUTINES CALLED....
#
#       HACK FOR STROKE TEST (V68) WAVEFORM GENERATION
#       PCOPY, YCOPY FOR COPY-CYCLES (USED ALSO BY TVC RESTART PACKAGE)
#       DAPINIT FOR INITIAL CDUS FOR RATE MEASUREMENTS
```

```
#       ERRORLIM, ACTLIM FOR INPUT (ATTITUDE-ERROR INTEGRATION) AND
#               OUTPUT (ACTUATOR COMMAND) LIMITING, COMMON TO PITCH AND
#               YAW DAPS
#       FWDFLTR (INCLUDING OPTVARK) AND PRECOMP, TO COMPUTE FILTER
#               OUTPUTS AND STORAGE VALUES
#       RESUME
#
# Page 962
# OTHER INTERFACES
#
#       S40.8 CROSS-PRODUCT STEERING FOR BODY AXIS RATE COMMANDS OMEGAY,ZC
#       S40.15 FOR THE INITIAL DAP GAINS VARK AND 1/CONACC
#       TVCEXECUTIVE FOR DAP GAIN UPDATES AND TMC LOOP OPERATIONS
#       TVCRESTART PACKAGE FOR TVC RESTART PROTECTION.
#
# ERASABLE INITIALIZATION REQUIRED....
#
#       PAD-LOAD ERASABLES (SEE ERASABLE ASSIGNMENTS)
#       CONFIGURATION BITS (14, 13) OF DAPDATR1 AS IN R03
#       ENGINE-ON BIT (11.13) FOR RESTARTS
#       TVCPHASE FOR RESTARTS (SEE DOTVCON, AND TVCINIT4)
#       T5 BITS (15,14 OF FLAGWRD6) FOR RESTARTS
#       MISCELLANEOUS VARIABLES SET UP OR COMPUTED BY TVCDAPON....TVCINIT4,
#               INCLUDING THE ZEROING OF TEMPORARIES BY MRCLEAN
#       CDUX,Y,Z AND SINCDUX.... COSCDUX AS PREPARED BY QUICTRIG1 (WITH
#               UPDATES EVERY 1/2 SECOND)
#       ALSO G+N PRIMARY, TVC ENABLE, AND OPTICS ERROR COUNTER ENABLE
#               UNLESS BENCH-TESTING.
#
# OUTPUT....
#
#       TVCPITCH AND TVCYAW WITH COUNTER RELEASE (11.14 AND 11.13 INCREMENTAL
#               COMMANDS TO OPTICS ERROR COUNTERS), FILTER NODES, BODY-
#               AXIS ATTITUDE ERROR INTEGRATOR, TOTAL ACTUATOR COMMANDS,
#               OFFSET-TRACKER-FILTER OUTPUTS, ETC.
#
# DEBRIS....
#
#       MUCH, SHAREABLE WITH RCS/ENTRY, IN EBANK6 ONLY

                BANK    17
                SETLOC  DAPS2
                BANK

                EBANK=  BZERO
```

```
                COUNT*  $$/DAPS

# Page 963
# PITCH TVCDAP STARTS HERE....(INCOPORATES CSM/LEM DAP FILTER, MODOR DESIGN)

PITCHDAP        LXCH    BANKRUPT        # T5 ENTRY, NORMAL OR VIA DAPINIT
                EXTEND
                QXCH    QRUPT

                CAF     YAWT5           # SET UP T5 CALL FOR YAW AUTOPILOT (LOW-
                TS      T5LOC           #       ORDER PART OF 2CADR ALREADY THERE)
                CAE     T5TVCDT
                TS      TIME5

PSTROKER        CCS     STROKER         # (STRKFLG) CHECK FOR STROKE TEST
                TC      HACK            # TEST-START OR TEST-IN-PROGRESS
                TCF     +2              # NO-TEST
                TC      HACK            # TEST-IN-PROGRESS

PCDUDOTS        CAE     CDUY            # COMPUTE CDUYDOT (USED BY PITCH AND YAW)
                XCH     PCDUYPST
                EXTEND
                MSU     PCDUYPST
                TCR     RLIMTEST        #       RATE TEST
                TS      MCDUYDOT        #       (MINUS, SC.AT 1/2TVCDT REVS/SEC)

                CAE     CDUZ            # COMPUTE CDUZDOT (USED BY PITCH AND YAW)
                XCH     PCDUZPST
                EXTEND
                MSU     PCDUZPST
                TCR     RLIMTEST        #       RATE TEST
                TS      MCDUZDOT        #       (MINUS, SC.AT 1/2TVCDT REVS/SEC)
                TCF     PINTEGRL

RLIMTEST        TS      TTMP1           # TEST FOR EXCESSIVE CDU RATES (GREATER
                EXTEND                  #       THAN 2.33 DEG IN ONE SAMPLE PERIOD
                MP      1/RTLIM
                EXTEND
                BZF     +3
                CAF     ZERO
                TS      TTMP1
                CAE     TTMP1
                TC      Q

PINTEGRL        EXTEND                  # COMPUTE INTEGRAL OF BODY-AXIS PITCH-RATE
                DCA     PERRB           #       ERROR, SC.AT B-1 REVS
```

```
                DXCH    ERRBTMP

                EXTEND
                DCA     OMEGAYC
                DAS     ERRBTMP

# Page 964
                CS      COSCDUZ         # PREPARE BODY-AXIS PITCH RATE, OMEGAYB
                EXTEND
                MP      COSCDUX
                DDOUBL
                EXTEND
                MP      MCDUYDOT
                DDOUBL
                DXCH    OMEGAYB

                CS      MCDUZDOT
                EXTEND
                MP      SINCDUX
                DDOUBL
                DAS     OMEGAYB         # (COMPLETED OMEGAYB, SC.AT 1/2TVCDT REVS)

                EXTEND                  # PICK UP -OMEGAYB (SIGN CHNG, INTEGRATE)
                DCS     OMEGAYB
                DAS     ERRBTMP

PERORLIM        TCR     ERRORLIM        # PITCH BODY-AXIS-ERROR INPUT LIMITER

PFORWARD        EXTEND                  #       PREPARE THE FILTER STORAGE LOCATIONS
                DCA     PTMP1           #       FOR THE PITCH CHANNEL
                DXCH    TMP1
                EXTEND
                DCA     PTMP3
                DXCH    TMP3
                EXTEND
                DCA     PTMP5
                DXCH    TMP5

                TCR     FWDFLTR         # GO COMPUTE PRESENT OUTPUT
                                        # (INCLUDES VARIABLE GAIN PACKAGE)

POFFSET         EXTEND
                DCA     PDELOFF
                DAS     CMDTMP          # NO SCALED AT B+0 ASCREV

PACLIM          TCR     ACTLIM          # ROUND OFF & LIMIT PITCH ACTUATOR COMMAND
```

```
POUT            CS      PCMD            # INCREMENTAL PITCH COMMAND
                AD      CMDTMP
                ADS     TVCPITCH        # UPDATE THE ERROR COUNTER (NO RESTART-
                                        #       PROTECT. SINCE ERROR CNTR ZEROED)

                CAF     BIT11           # BIT FOR TVCPITCH COUNT RELEASE
                EXTEND
                WOR     CHAN14

PPRECOMP        EXTEND                  #       PREPARE THE FILTER STORAGE FOR PITCH
# Page 965
                DCA     PTMP2
                DXCH    TMP2
                EXTEND
                DCA     PTMP4
                DXCH    TMP4
                EXTEND
                DCA     PTMP6
                DXCH    TMP6

                TCR     PRECOMP         #       TO THE FILTER FOR PRECOMPUTATION

DELBARP         CAE     DELPBAR +1
                EXTEND
                MP      E(-AT)
                TS      DELBRTMP +1
                CAE     DELPBAR
                EXTEND
                MP      E(-AT)
                DAS     DELBRTMP
                CAE     CMDTMP
                EXTEND
                MP      1-E(-AT)
                DAS     DELBRTMP

PCOPYCYC        TCR     PCOPY           # PITCH COPYCYCLE

PDAPEND         TCF     RESUME          # PITCH DAP COMPLETED
# Page 966
# PITCH TVCDAP COPYCYCLE SUBROUTINE (CALLED VIA PITCH TVCDAP OR TVC RESTART PACKAGE)

PCOPY           INCR    TVCPHASE        # RESTART-PROTECT THE COPYCYCLE.        (1)
                                        #       NOTE POSSIBLE RE-ENTRY FROM RESTART
                                        #       PACKAGE, SHOULD A RESTART OCCUR
                                        #       DURING PITCH COPYCYCLE.
```

```
                EXTEND
                DCA     TMP1
                DXCH    PTMP1
                EXTEND
                DCA     TMP2
                DXCH    PTMP2
                EXTEND
                DCA     TMP3
                DXCH    PTMP3
                EXTEND
                DCA     TMP4
                DXCH    PTMP4
                EXTEND
                DCA     TMP5
                DXCH    PTMP5
                EXTEND
                DCA     TMP6
                DXCH    PTMP6

PMISC           EXTEND                  # MISC....PITCH-RATE-ERROR INTEGRATOR
                DCA     ERRBTMP
                TS      AK1             #       FOR PITCH NEEDLES, SC.AT B-1 REVS
                DXCH    PERRB

                CAE     CMDTMP          #       PITCH ACTUATOR COMMAND
                TS      PCMD

                EXTEND                  #       PITCH OFFSET-TRACKER-FILTER
                DCA     DELBRTMP
                DXCH    DELPBAR

                INCR    TVCPHASE        # PITCH COPYCYCLE COMPLETED            (2)

                TC      Q

# Page 967
# YAW TVCDAP STARTS HERE....(INCORPORATES CSM/LEM DAP FILTER, MODOR DESIGN)

YAWDAP          LXCH    BANKRUPT        # T5 ENTRY, NORMAL
                EXTEND
                QXCH    QRUPT

                CAF     PITCHT5         # SET UP T5 CALL FOR PITCH AUTOPILOT (LOW-
                TS      T5LOC           #       ORDER PART OF 2CADR ALREADY THERE)
                CAE     T5TVCDT
```

```
                TS      TIME5

YSTROKER        CCS     STROKER         # (STRKFLG) CHECK FOR STROKE TEST
                TC      HACK            # TEST-START OR TEST-IN-PROGRESS
                TCF     +2              # NO-TEST
                TC      HACK            # TEST-IN-PROGRESS

                                        # USE BODY RATES FROM PITCHDAP (PCDUDOTS)

YINTEGRL        EXTEND                  # COMPUTE INTEGRAL OF BODY-AXIS YAW-RATE
                DCA     YERRB           #       ERROR, SC.AT B-1 REVS
                DXCH    ERRBTMP

                EXTEND
                DCA     OMEGAZC
                DAS     ERRBTMP

                CAE     COSCDUZ         # PREPARE BODY-AXIS YAW-RATE, OMEGAZB
                EXTEND
                MP      SINCDUX
                DDOUBL
                EXTEND
                MP      MCDUYDOT
                DDOUBL
                DXCH    OMEGAZB

                CS      MCDUZDOT
                EXTEND
                MP      COSCDUX
                DDOUBL
                DAS     OMEGAZB         # (COMPLETED OMEGAZB, SC.AT 1/2TVCDT REVS)

                EXTEND                  # PICK UP -OMEGAZB (SIGN CHNG, INTEGRATE)
                DCS     OMEGAZB
                DAS     ERRBTMP

YERORLIM        TCR     ERRORLIM        # YAW BODY-AXIS-ERROR INPUT LIMITER

YFORWARD        EXTEND                  #       PREPARE THE FILTER STORAGE LOCATIONS
                DCA     YTMP1           #       FOR THE YAW CHANNEL
# Page 968
                DXCH    TMP1
                EXTEND
                DCA     YTMP3
                DXCH    TMP3
                EXTEND
```

```
                DCA     YTMP5
                DXCH    TMP5

                TCR     FWDFLTR         # GO COMPUTE PRESENT OUTPUT
                                        # (INCLUDES VARIABLE GAIN PACKAGE)

YOFFSET         EXTEND
                DCA     YDELOFF
                DAS     CMDTMP          # NOW SCALED AT B+0 ASCREV

YACLIM          TCR     ACTLIM          # YAW ACTUATOR-COMMAND-LIMITER

YOUT            CS      YCMD            # INCREMENTAL YAW COMMAND
                AD      CMDTMP
                ADS     TVCYAW          # UPDATE THE ERROR COUNTER (NO RESTART-
                                        #       PROTECT, SINCE ERROR CNTR ZEROED)

                CAF     BIT12           # BIT FOR TVCYAW COUNT RELEASE
                EXTEND
                WOR     CHAN14

YPRECOMP        EXTEND                  #       PREPARE THE FILTER STORAGE FOR YAW
                DCA     YTMP2
                DXCH    TMP2
                EXTEND
                DCA     YTMP4
                DXCH    TMP4
                EXTEND
                DCA     YTMP6
                DXCH    TMP6

                TCR     PRECOMP         #       TO THE FILTER FOR PRECOMPUTATION

DELBARY         CAE     DELYBAR +1      # UPDATE YAW OFFSET-TRACKER-FILTER
                EXTEND
                MP      E(-AT)
                TS      DELBRTMP +1
                CAE     DELYBAR
                EXTEND
                MP      E(-AT)
                DAS     DELBRTMP
                CAE     CMDTMP
                EXTEND
                MP      1-E(-AT)
                DAS     DELBRTMP
```

```
# Page 969
YCOPYCYC        TCR     YCOPY           # YAW COPYCYCLE

YDAPEND         TCF     RESUME          # YAW DAP COMPLETED

# Page 970
# TVCDAP COPYCYCLE SUBROUTINE (CALLED VIA YAW   TVCDAP OR TVC RESTART PACKAGE)

YCOPY           INCR    TVCPHASE        # RESTART-PROTECT THE COPYCYCLE.        (3)
                                        #       NOTE POSSIBLE RE-ENTRY FROM RESTART
                                        #       PACKAGE, SHOULD A RESTART OCCUR
                                        #       DURING YAW   COPYCYCLE.

                EXTEND
                DCA     TMP1
                DXCH    YTMP1
                EXTEND
                DCA     TMP2
                DXCH    YTMP2
                EXTEND
                DCA     TMP3
                DXCH    YTMP3
                EXTEND
                DCA     TMP4
                DXCH    YTMP4
                EXTEND
                DCA     TMP5
                DXCH    YTMP5
                EXTEND
                DCA     TMP6
                DXCH    YTMP6

YMISC           EXTEND                  # MISC....YAW-RATE-ERROR INTEGRATOR
                DCA     ERRBTMP
                TS      AK2             #       FOR YAW   NEEDLES, SC.AT B-1 REVS
                DXCH    YERRB

                CAE     CMDTMP
                TS      YCMD

                EXTEND
                DCA     DELBRTMP
                DXCH    DELYBAR

                CAF     ZERO            # YAW   COPYCYCLE COMPLETED
                TS      TVCPHASE        #       RESET TVCPHASE
```

```
                TC      Q

# Page 971
# SUBROUTINES COMMON TO BOTH PITCH AND YAW DAPS....

# INITIALIZATION PACKAGE FOR CDURATES....

DAPINIT         LXCH    BANKRUPT        # T5 RUPT ENTRY (CALLED BY TVCINT4)

                CAF     NEGONE          #       SET UP
                AD      T5TVCDT         #       T5 CALL FOR PITCHDAP IN TVCDT SECS
                AD      NEGMAX          #       (T5TVCDT = POSMAX - TVCDT/2 +1)
                AD      T5TVCDT
                TS      TIME5
                CAF     PITCHT5         #       (BBCON ALREADY THERE)
                TS      T5LOC

                CAE     CDUY            # READ AND STORE CDUS FOR DIFFERENTIATOR
                TS      PCDUYPST        #       PAST-VALUES
                CAE     CDUZ
                TS      PCDUZPST

                TCF     NOQRSM

# BODY-AXIS-ERROR   INPUT LIMITER PACKAGE....

ERRORLIM        CAE     ERRBTMP         # CHECK FOR INPUT-ERROR LIMIT
                EXTEND                  #       CHECKS UPPER WORD ONLY
                MP      1/ERRLIM
                EXTEND
                BZF     +6
                CCS     ERRBTMP
                CAF     ERRLIM
                TCF     +2
                CS      ERRLIM
                TS      ERRBTMP         # LIMIT WRITES OVER UPPER WORD ONLY

                TC      Q

# ACTUATOR-COMMAND LIMITER PACKAGE....

ACTLIM          CAE     CMDTMP  +1      # ROUND UP FOR OUTPUT
                DOUBLE
                TS      L
                CAF     ZERO
```

```
                AD      CMDTMP

                EXTEND                  # CHECK FOR ACTUATOR COMMAND LIMIT
                MP      1/ACTSAT
                EXTEND
# Page 972
                BZF     +6
                CCS     CMDTMP          # APPLY LIMITS
                CAF     ACTSAT
                TCF     +2
                CS      ACTSAT
                TS      CMDTMP          # LIMITS WRITE OVER CMDTMP

                TC      Q

# FILTER COMPUTATIONS FOR PRESENT OUTPUT................

FWDFLTR         CAF     ZERO
                TS      DAP1
                TS      DAP2
                TS      DAP3
                TS      CMDTMP

                TS      DELBRTMP

1DAPCAS         CAE     ERRBTMP +1      # FIRST DAP CASCADE
                EXTEND
                MP      N10             #       N10
                TS      DAP1    +1
                CA      ERRBTMP
                EXTEND
                MP      N10             #       N10
                DAS     DAP1
                DXCH    TMP1
                DAS     DAP1

2DAPCAS         CAE     DAP1    +1      # SECOND DAP CASCADE
                EXTEND
                MP      N10     +5      #       N20
                TS      DAP2    +1
                CA      DAP1
                EXTEND
                MP      N10     +5      #       N20
                DAS     DAP2
                DXCH    TMP3
                DAS     DAP2
```

```
                CAE     DAPDATR1        # TEST FOR LEM ON OR OFF
                MASK    BIT14
                CCS     A
                TCF     3DAPCAS         # LEM ON
                EXTEND                  # LEM OFF
                DCA     DAP2
                DXCH    DAP3
                TCF     OPTVARK

# Page 973
3DAPCAS         CAE     DAP2    +1      # THIRD DAP CASCADE
                EXTEND
                MP      N10     +10D    #       N30
                TS      DAP3    +1
                CA      DAP2
                EXTEND
                MP      N10     +10D    #       N30
                DAS     DAP3
                DXCH    TMP5
                DAS     DAP3

OPTVARK         CS      DAP3    +1      # VARIABLE GAIN PACKAGE
                EXTEND                  # (ALSO, SIGN CHANGE IN FORWARD LOOP)
                MP      VARK            # SCALED AT 1/(8 ASCREV) OF ACTUAL VALUE
                TS      CMDTMP  +1
                CS      DAP3
                EXTEND
                MP      VARK
                DAS     CMDTMP

                DXCH    CMDTMP          # FIX UP SCALING -- SCALED B+3 ASCREVS
                DDOUBL
                DDOUBL
                DXCH    CMDTMP          #                -- SCALED B+1 ASCREVS
                                        # NOTE -- THERE IS AN INHERENT GAIN OF
                                        # (B+1 ASCREVS) ON THE OUTPUT DACS.

                TC      Q

# FILTER PRECOMPUTATIONS FOR NEXT PASS................

PRECOMP         CAF     ZERO            # **** FIRST CASCADE FILTER **********
                TS      TTMP1
                TS      TTMP2
```

```
                CA      ERRBTMP +1      # MULTIPLY INPUT BY
                EXTEND
                MP      N10     +1      #       N11/2
                TS      TTMP1   +1
                CA      ERRBTMP
                EXTEND
                MP      N10     +1      #       N11/2
                DAS     TTMP1

                CS      DAP1    +1      # MULTIPLY OUTPUT BY
                EXTEND
                MP      N10     +3      #       D11/2
                TS      TTMP2   +1
                CS      DAP1

# Page 974
                EXTEND
                MP      N10     +3      #       D11/2
                DAS     TTMP2

                DXCH    TTMP2
                DAS     TTMP1
                DXCH    TTMP1
                DDOUBL
                DAS     TMP2

                DXCH    TMP2
                DXCH    TMP1

                CAF     ZERO
                TS      TTMP1
                TS      TMP2

                CA      ERRBTMP +1      # MULTIPLY INPUT BY
                EXTEND                  # SECOND-ORDER NUMERATOR COEFF.
                MP      N10     +2      #       N12
                TS      TTMP1   +1
                CA      ERRBTMP
                EXTEND
                MP      N10     +2      #       N12
                DAS     TTMP1

                CS      DAP1    +1      # MULTIPLY OUTPUT BY
                EXTEND
                MP      N10     +4      #       D12
                TS      TMP2    +1
```

```
                CS      DAP1
                EXTEND
                MP      N10     +4      #       D12
                DAS     TMP2

                DXCH    TTMP1
                DAS     TMP2

2CASFLTR        CAF     ZERO            # **** SECOND CASCADE FILTER **********
                TS      TTMP1
                TS      TTMP2

                CA      DAP1     +1     # MULTIPLY INPUT BY
                EXTEND
                MP      N10     +6      #       N21/2
                TS      TTMP1   +1
                CA      DAP1
                EXTEND
                MP      N10     +6      #       N21/2
# Page 975
                DAS     TTMP1

                CS      DAP2    +1      # MULTIPLY OUTPUT BY
                EXTEND
                MP      N10     +8D     #       D21/2
                TS      TTMP2   +1
                CS      DAP2
                EXTEND
                MP      N10     +8D     #       D21/2
                DAS     TTMP2

                DXCH    TTMP2
                DAS     TTMP1
                DXCH    TTMP1
                DDOUBL
                DAS     TMP4

                DXCH    TMP4
                DXCH    TMP3

                CAF     ZERO
                TS      TTMP1
                TS      TMP4

                CA      DAP1    +1      # MULTIPLY INPUT BY
                EXTEND                  # SECOND-ORDER NUMERATOR COEFF.
```

```
                MP      N10     +7      #       N22
                TS      TTMP1   +1
                CA      DAP1
                EXTEND
                MP      N10     +7      #       N22
                DAS     TTMP1

                CS      DAP2    +1      # MULTIPLY OUTPUT BY
                EXTEND
                MP      N10     +9D     #       D22
                TS      TMP4    +1
                CS      DAP2
                EXTEND
                MP      N10     +9D     #       D22
                DAS     TMP4

                DXCH    TTMP1
                DAS     TMP4

                CAE     DAPDATR1        # TEST FOR LEM ON OR OFF
                MASK    BIT13
                CCS     A
                TC      Q               # EXIT IF LEM OFF

# Page 976
3CASFLTR        CAF     ZERO            # **** THIRD CASCADE FILTER **********
                TS      TTMP1
                TS      TTMP2

                CA      DAP2     +1     # MULTIPLY INPUT BY (1/2)
                EXTEND
                MP      N10     +11D    #       N31/2
                TS      TTMP1   +1
                CA      DAP2
                EXTEND
                MP      N10     +11D    #       N31/2
                DAS     TTMP1

                CS      DAP3    +1
                EXTEND
                MP      N10     +13D    #       D31/2
                TS      TTMP2   +1
                CS      DAP3
                EXTEND
                MP      N10     +13D    #       D31/2
                DAS     TTMP2
```

```
                DXCH    TTMP2
                DAS     TTMP1
                DXCH    TTMP1
                DDOUBL
                DAS     TMP6

                DXCH    TMP6
                DXCH    TMP5

                CAF     ZERO
                TS      TTMP1
                TS      TMP6

                CA      DAP2    +1      # MULTIPLY INPUT BY
                EXTEND
                MP      N10     +12D    #       N32
                TS      TTMP1   +1
                CA      DAP2
                EXTEND
                MP      N10     +12D    #       N32
                DAS     TTMP1

                CS      DAP3    +1
                EXTEND
                MP      N10     +14D    #       D32
                TS      TMP6    +1
                CS      DAP3
                EXTEND
# Page 977
                MP      N10     +14D    #       D32
                DAS     TMP6

                DXCH    TTMP1
                DAS     TMP6

                TC      Q

# Page 978
# CONSTANTS FOR AUTOPILOTS

# NOTE....1 ASCREV (ACTUATOR CMD SCALING) = 85.41 ARCSEC/BIT OR 1.07975111 REVS (85.4
#         1 SPASCREV (SPECIAL ACTUATOR CMD SCALING) = 1.04620942 REVS

ACTSAT          DEC     253             # ACTUATOR LIMIT (6 DEG), SC.AT 1ASCREV
1/ACTSAT        DEC     .0039525692     # RECIPROCAL (1/253)
```

```
ERRLIM          EQUALS  BIT13           # FILTER INPUT LIMIT....B-3 REVS (45DEG),
1/ERRLIM        EQUALS  BIT3            #       SC.AT B-1 REV, AND ITS RECIPROCAL

PITCHT5         GENADR  PITCHDAP        # UPPER WORDS OF T5 2CADRS, LOWER WORDS
DAPT5           GENADR  DAPINIT         #       (BBCON) ALREADY THERE.  ORDER IS
YAWT5           GENADR  YAWDAP          #       REQUIRED.

1/RTLIM         DEC     0.004715        # .004715(CDUDIF) = 0 IF CDUIF < 2.33 DEG
1-E(-AT)        OCT     00243           # AT = .01SEC....EITHER(1/A=4SEC, T=40MS),
E(-AT)          OCT     37535           #                    OR(1/A=8SEC, T=80MS)
```

Uses 1/CONACC 204, A 80, AK1 200, AK2 200, BANKRUPT 80, BZERO 208, CDUS 80, CDUX 80, CDUY 80, CDUZ 80, CHAN14 87, CMDTMP 206, CNTR 200, COMMAND 169, COSCDUX 150, COSCDUZ 150, COUNT 142, D21 219, DAP1 204, DAP2 204, DAP3 204, DAPDATR1 200, DAPS2 63, DELBRTMP 206, DELPBAR 204, DELYBAR 204, EBANK 80, ERRBTMP 206, FLAGWRD6 117, L 80, MCDUYDOT 204, MCDUZDOT 204, MODE 145, N 206, N10 206, OMEGAYB 202, OMEGAYC 202, OMEGAZB 202, OMEGAZC 202, PCDUYPST 204, PCDUZPST 204, PCMD 204, PDELOFF 204, PERRB 204, PTMP1 202, PTMP2 202, PTMP3 202, PTMP4 202, PTMP5 202, PTMP6 204, Q 80, QRUPT 80, RESTART 57, REVS 206, SINCDUX 150, STROKER 204, T5LOC 163, T5TVCDT 204, TC 169, TIME5 80, TMP1 206, TMP2 206, TMP3 206, TMP4 206, TMP5 206, TMP6 206, TTMP1 204, TTMP2 204, TVCPHASE 204, TVCPITCH 85, TVCYAW 85, VARK 204, YCMD 204, YDELOFF 204, YERRB 204, YTMP1 204, YTMP2 204, YTMP3 204, YTMP4 204, YTMP5 204, YTMP6 204, and Z 80.

3.6.6 tvcstroketest code

1389 ⟨*tvcstroketest code* 1389⟩≡ (1346c 2830)
⟨*Page CM0979* 1390⟩

1390 ⟨*Page CM0979* 1390⟩≡ (1389)

```
# Page 979
# NAME          STROKE TEST PACKAGE             (INCLUDING INITIALIZATION PACKAGE)
# LOG SECTION...TVCSTROKETEST                   SUBROUTINE...DAPCSM
# MODIFIED BY SCHLUNDT                          21 OCTOBER 1968
#
# FUNCTIONAL DESCRIPTION....
#       STROKE TEST PACKAGE GENERATES A WAVEFORM DESIGNED TO EXCITE BENDING
#       STRKTSTI (STROKE TEST INITIALIZATION) IS CALLED AS A JOB BY VB68.
#               IT INITIALIZES ALL ERASABLES REQD FOR A STROKE TEST, AND
#               THEN TESTS FOR CSM/LM (BIT 13 OF DAPDATR1). IF CSM/LM,
#               IN EITHER HIGH OR LOW-BANDWIDTH MODE, THE TEST IS STARTED
#               IMMEDIATELY.  IF NOT CSM/LM, PROGRAM EXITS WITH NO ACTION.
#       HACK (STROKE TEST) GENERATES THE WAVEFORM BY DUMPING PULSE BURSTS
#               OF PROPER SIGN AND IN PROPER SEQUENCE DIRECTLY INTO
#               TVCPITCH, WORKING IN CONJUNCTION WITH BOTH PITCH AND YAW
#               TVC DAPS, WITH INTERMEDIATE WAITLIST CALLS.  NOTE, HOWEVER
#               THAT THE STROKE TEST IS PERFORMED ONLY IN THE PITCH AXIS.
#               AN EXAMPLE WAVEFORM IS GIVEN BELOW, TO DEMONSTRATE STROKE-
#               TEST PARAMETER SELECTION.
#       RESTARTS CAUSE TEST TO BE TERMINATED.  ANOTHER V68 REQD IF TEST
#               IS TO BE RE-RUN.
#       PULSE BURST SIZE IS PAD-LOADED (ESTROKER) SO THAT AMPLITUDE OF
#               WAVEFORM CAN BE CHANGED.  THERE ARE TEN PULSE BURSTS IN
#               THE HALF-AMPLITUDE OF THE FIRST FREQUENCY SET IN THE
#               STANDARD WAVEFORM.  AMPLITUDE IS 10(ESTROKER)(1/42.15),
#               NOMINALLY 50/42.15 = 1.185 DEG
#
# CALLING SEQUENCE....
#       EXTENDED VERB 68 SETS UP STRKTSTI JOB
#       PITCH AND YAW TVCDAPS, FINDING STROKER NON-ZERO, DO A "TC HACK"
#       AN INTERNALLY-GENERATED WAITLIST CALL ENTERS AT "HACKWLST"
#
# NORMAL EXIT MODES....
#       TC BUNKER ("Q" IF ENTRY FROM DAP, "TCTSKOVR" IF FROM WAITLIST) LIST
#
# SUBROUTINES CALLED....
#       WAITLIST
#
# ALARM OR ABORT EXIT MODES....
#       NONE
#
# ERASABLE INITIALIZATION REQUIRED....
#       ESTROKER (PAD-LOAD)
#       STROKER, CADDY, REVS, CARD, N
#
```

```
# OUTPUT....
#       STRKTSTI...INITIALIZATION FOR STROKE TEST
#       HACK, HACKWLST...PULSE BURSTS INTO TVCPITCH VIA "ADS"
#                          RESETS STROKER = +0 WHEN TEST COMPLETED
#
# DEBRIS....
#       N = CADDY = +0, CARD = -0, REVS = -1
#       BUNKER
# Page 980
#
# EXAMPLE STROKE TEST WAVE FORM, DEMONSTRATING PARAMETER SELECTION

# NOTE....THIS IS NOT THE OFFICIAL WAVEFORM....
#
#        **              **
#        **              **
#        **              **             EXAMPLE WAVEFORM (EACH * REPRESENTS
#       *  *            *  *              (85.41 ARCSEC OF ACTUATOR CMD)
#       *  *            *  *
#       *  *            *  *
#      *    *          *    *          **      **      **      **      **
#      *    *          *    *          **      **      **      **      **
#      *    *          *    *          **      **      **      **      **
#     *      *        *      *        *  *    *  *    *  *    *  *    *  *    **  **  **  **  *
#     *      *        *      *        *  *    *  *    *  *    *  *    *  *    **  **  **  **  *
#     *      *        *      *        *  *    *  *    *  *    *  *    *  *    **  **  **  **  *
# ---------------------------------------------------------------------------------------------
#            *      *        *      *    *  *    *  *    *  *    *  *    *  *  **  **  **  **
#            *      *        *      *    *  *    *  *    *  *    *  *    *  *  **  **  **  **
#            *      *        *      *    *  *    *  *    *  *    *  *    *  *  **  **  **  **
#             *    *          *    *      **      **      **      **      **
#             *    *          *    *      **      **      **      **      **
#             *    *          *    *      **      **      **      **      **
#              *  *            *  *
#              *  *            *  *
#              *  *            *  *
#               **              **
#               **              **
#               **              **
#
# FOR THIS (UNOFFICIAL, EXAMPLE) WAVEFORM, THE REQUIRED PARAMETERS ARE AS FOLLOWS....
#
#       FCARD    = +3           (NUMBER OF SETS)
#       ESTROKER = +3           (PULSE BURST SIZE, SC.AT 85.41 ARCSEC/BIT)
#
#       SET1:
```

```
#               FREVS   = +3    (NUMBER REVERSALS MINUS 1)
#               FCADDY  = +4    (NUMBER OF PULSE BURSTS IN 1/2 AMPLITUDE)
#       SET2:
#               FCARD1  = +9    (NUMBER REVERSALS MINUS 1)
#               FCARD4  = +2    (NUMBER OF PULSE BURSTS IN 1/2 AMPLITUDE)
#       SET3:
#               FCARD2  = +9    (NUMBER REVERSALS MINUS 1)
#               FCARD5  = +1    (NUMBER OF PULSE BURSTS IN 1/2 AMPLITUDE)
#       SET4:
#               FCARD3  = +0    (NUMBER OF REVERSALS MINUS 1)
#               FCARD6  = +0    (NUMBER OF PULSE BURSTS IN 1/2 AMPLUTUDE)

# Page 981
# STROKE TEST INITIALIZATION PACKAGE (AS A JOB, FROM VERB 68)

                BANK    17
                SETLOC  DAPS2
                BANK

                COUNT*  $$/STRK
                EBANK=  CADDY

STRKTSTI        TCR     TSTINIT         # STROKE TEST INITIALIZATION PKG (CALLED
                                        # AS A JOB BY VERB68)

STRKCHK         INHINT

                CAE     DAPDATR1        # CHECK FOR CSM/LM CONFIGURATION
                MASK    BIT14
                EXTEND
                BZF     +3

                CAE     ESTROKER        # BEGIN ON NEXT DAP PASS (PITCH OR YAW)
                TS      STROKER         # (STROKING DONE IN PITCH ONLY, HOWEVER)

                TCF     ENDOFJOB

TSTINIT         CS      FCADDY          # NORMAL ENTRY FROM STRKTSTI
                TS      CADDY
                TS      N               #       NOTE SGN CHNG FCADDY(+) TO CADDY(-)

                CAF     FREVS
                TS      REVS

                CS      FCARD           #       NOTE SGN CHNG FCARD(+) TO CARD(-)
                TS      CARD
```

```
                TC      Q               # RETURN TO STRKTSTI+1 (OR CHKSTRK+2 OR +4)

# Page 982
# THE OFFICIAL STROKE TEST WAVEFORM (3 JAN, 1967) CONSISTS OF FOUR STROKE SETS, AS FOLLOWS....
#
#       SET 1...10 BURSTS IN 1/2 AMP,   4 REVERSALS
#       SET 2... 6 BURSTS IN 1/2 AMP,   6 REVERSALS
#       SET 3... 5 BURSTS IN 1/2 AMP,  10 REVERSALS
#       SET 4... 4 BURSTS IN 1/2 AMP,  14 REVERSALS
#
# THE PULSE BURST SIZE (ESTROKER) IS PAD-LOADED (5 BITS AS OF 3 JAN, 1967)
# THE REMAINING WAVEFORM-GENERATING PARAMETERS ARE AS FOLLOWS....

FCADDY          DEC     10              # NO. PULSE BURSTS IN 1/2 AMP, SET1..(+10)
FREVS           DEC     3               # NO. REVERSALS MINUS 1, SET1........(  3)

FCARD           DEC     4               # NO. STROKE SETS...................(+ 4)

FCARD1          DEC     5               # NO. REVERSALS MINUS 1, SET2........(  5)

FCARD2          DEC     9               #                           3........(  9)
FCARD3          DEC     13              #                           4........( 13)

FCARD4          DEC     6               # NO. PULSE BURSTS IN 1/2 AMP, SET2..(+ 6)
FCARD5          DEC     5               #                                 3..(+ 5)
FCARD6          DEC     4               #                                 4..(+ 4)

20MS            =       BIT2

# STROKE TEST PACKAGE PROPER....

                EBANK=  BUNKER

HACK            EXTEND                  # ENTRY (IN T5 RUPT) FROM TVCDAPS
                QXCH    BUNKER          # SAVE Q FOR DAP RETURN

                CAF     20MS            # 2DAPSx2(PASSES/DAP)x2(CS/PASS)=8CS=TVCDT
                TC      WAITLIST
                EBANK=  BUNKER
                2CADR   HACKWLST

                TCF     +3

HACKWLST        CAF     TCTSKOVR        # ENTRY FROM WAITLIST
                TS      BUNKER          # BUNKER IS TC TASKOVER
```

```
                CA      STROKER         # STROKE
                ADS     TVCPITCH

                CAF     BIT11           # RELEASE THE ERROR COUNTERS
                EXTEND
                WOR     CHAN14
                INCR    CADDY           # COUNT DOWN THE NO. BURSTS, THIS SLOPE
# Page 982
                CS      CADDY
                EXTEND
                BZMF    +2
                TC      BUNKER          # EXIT, WHILE ON A SLOPE

                CCS     REVS
                TCF     REVUP           # POSITIVE REVS
                TCF     REVUP +4        # FINAL REVERSAL, THE SET

                INCR    CARD            # NEGATIVE REVS SET LAST PASS, READY FOR
                CS      CARD            #       THE NEXT SET.  CHECK IF NO MORE SETS
                EXTEND
                BZF     STROKILL        # ALL SETS COMPLETED

                INDEX   CARD
                CAF     FCARD +4        # PICK UP NO. REVERSALS (-), NEXT SET
                TS      REVS            # REINITIALIZE
                INDEX   CARD
                CS      FCARD +7        # PICK UP NO. BURSTS IN 1/2AMP, NEXT SET
                TS      N               # REINITIALIZE
                TS      CADDY
                TC      BUNKER          # EXIT, AT END OF SET

STROKILL        TS      STROKER         # RESET (TO +0) TO END TEST
                TC      BUNKER          # EXIT, STROKE TEST FINIS

REVUP           TS      REVS            # ALL REVERSALS EXCEPT LAST OF SET
                CA      N
                DOUBLE                  # 2 x 1/2AMP
                TCF     +4

        +4      CS      ONE             # FINAL REVERSAL, THIS SET
                TS      REVS            # PREPARE TO BRANCH TO NEW BURST
                CA      N               # JUST RETURN TO ZERO, FINAL SLOPE OF SET
                TS      CADDY           # CADUP

                CS      STROKER         # CHANGE SIGN OF SLOPE
```

```
TS      STROKER
TC      BUNKER          # EXIT AT A REVERSAL (SLOPE CHANGE)
```

Uses A 80, BUNKER 206, CADDY 206, CARD 206, CHAN14 87, COUNT 142, DAPDATR1 200, DAPS2 63, EBANK 80, ESTROKER 198, IT 185, MODE 145, N 206, Q 80, REVS 206, RUN 191, SAVE 191, SLOPE 213, STROKER 204, TC 169, and TVCPITCH 85.

3.6.7 tvcrolldap code

1395 ⟨*tvcrolldap code* 1395⟩≡ (1346c 2829)
⟨*Page CM0984* 1396⟩

1396 ⟨*Page CM0984* 1396⟩≡ (1395)

```
# Page 984
# PROGRAM NAME....TVC ROLL AUTOPILOT
# LOG SECTION....TVCROLLDAP                        SUBROUTINE....DAPCSM
# MOD BY SCHLUNDT                                  21 OCTOBER 1968
#
# FUNCTIONAL DESCRIPTION....
#
#      *AN ADAPTATION OF THE LEM P-AXIS CONTROLLER
#      *MAINTAIN OGA WITHIN 5 DEG DEADBND OF OGAD, WHERE OGAD = OGA AS SEEN
#       BY IGNOVER (P40)
#      *MAINTAIN OGA RATE LESS THAN 0.1 DEG/SEC LIMIT CYCLE RATE
#      *SWITCHING LOGIC IN PHASE PLANE.... SEE GSOP CHAPTER 3
#      *USES T6 CLOCK TO TIME JET FIRINGS.
#      *MAXIMUM JET FIRING TIME = 2.56 SECONDS, LIMITED TO 2.5 IF GREATER
#      *MINIMUM JET FIRING TIME = 15 MS
#      *JET PAIRS FIRE ALTERNATELY
#      *AT LEAST 1/2 SECOND DELAY BEFORE A NEW JET PAIR IS FIRED
#      *JET FIRINGS MAY NOT BE EXTENDED, ONLY SHORTENED, WHEN RE-EVALUATION
#       OF A JET FIRING TIME IS MADE ON A LATER PASS
#
# CALLING SEQUENCE....
#
#      *ROLLDAP CALL VIA WAITLIST, IN PARTICULAR BY TVCEXEC (EVERY 1/2 SEC)
#       WITH A 3CS DELAY TO ALLOW FREE TIME FOR OTHER RUPTS (DWNRPT, ETC.)
#
# NORMAL EXIT MODES.... ENDOFJOB
#
# ALARM OR ABORT EXIT MODES.... NONE
#
# SUBROUTINES CALLED.....NONE
#
# OTHER INTERFACES....
#
#      *TVCEXEC SETS UP ROLLDAP TASK EVERY 1/2 SECOND AND UPDATES 1/CONACC
#       EVERY 10 SECONDS (VIA MASSPROP AND S40.15)
#      *RESTARTS SUSPEND ROLL DAP COMPUTATIONS UNTIL THE NEXT 1/2 SEC
#       SAMPLE PERIOD.  (THE PART OF TVCEXECUTIVE THAT CALLS ROLL DAP IS
#       NOT RESTARTED.)  THE OGAD FROM IGNITION IS MAINTAINED.
#
# ERASABLE INITIALIZATION REQUIRED
#
#      *1/CONACC                                   (S40.15)
#      *OGAD                                       (CDUX, AT IGNITION)
#      *OGANOW                                     (CDUX AT TVCINIT4 AND TVCEXECUTIVE)
#      *OGAPAST                                    (OGANOW AT TVCEXECUTIVE)
```

```
#      *ROLLFIRE = TEMREG = ROLLWORD = 0        (MRCLEAN LOOP IN TVCDAPON)
#
# OUTPUT....
#
#      *ROLL JET PAIR FIRINGS
#
# Page 985
# DEBRIS.... MISCELLANEOUS, SHAREABLE WITH RCS/ENTRY, IN EBANK6 ONLY

# Page 986
# SOME NOTES ON THE ROLL AUTOPILOT, AND IN PARTICULAR, ON ITS SWITCHING
# LOGIC.  SEE SECTION THREE OF THE GSOP (SUNDISK/COLOSSUS) FOR DETAILS.

# SWITCHING LOGIC IN THE PHASE PLANE....
#
#                              OGARATE
#                                 *
#                                 *
#  * * * * * * * * * * *          *
#                                 *     (REGION 1, SEE TEXT BELOW)
#                            *    *
#                                 *
# * * * * * * *     (COAST)       *     ...PARABOLA (SWITCHING = CONTROL)
#              *                  *    .
#                *                *   *
#                  *              *                (FIRE NEG ROLL JETS)
#                    *            *      *
#     (-DB,+LMCRATE)....*         *
#                      *          *        *
#                      *          *                             OGAERROR
# ***********************************************************************
#                                 *         *                (-AK, OGAERR)
#                       *         *         *      (REGION 6-PRIME)
#                                 *         *      (SEE TEXT BELOW)
#                          *      *           *
#                                 *             *     ...STRAIGHT LINE
#    (FIRE POS ROLL JETS)     *   *               *  .
#                                 *   (COAST)       *
#                                 *                  * * * * * * * * * *
#                                 *                        -MINLIM
#                                 *    *
#                                 *
#                                 *          * * * * * * * * * * * * * *
#                                 *                       -MAXLIM
#                                 *
#                                 *
```

```
#
# SWITCHING PARABOLAS ARE CONTROL PARABOLAS, THUS REQUIRING KNOWLEDGE OF
#       CONTROL ACCELERATION CONACC, OR ITS RECIPROCAL, 1/CONACC, THE TVC
#       ROLL DAP GAIN  (SEE TVCEXECUTIVE VARIABLE GAIN PACKAGE).  JET
#       FIRING TIME IS SIMPLY THAT REQUIRED TO ACHIEVE THE DESIRED OGARATE,
#       SUBJECT TO THE LIMITATIONS DISCUSSED UNDER FUNCTIONAL DESCRIPTION,
#       ABOVE.
#
# THE THREE CONTROL REGIONS  (+, -, AND ZERO TORQUE) ARE COMPRISED OF
#       TWELVE SUBSET REGIONS  ( 1...6, AND THE CORRESPONDING 1-PRIME...
#       5-PRIME )  SEE SECTION 3 OF THE GSOP  (SUNDISK OR COLOSSUS)
# Page 987
#
# GIVEN THE OPERATING POINT NOT IN THE COAST REGION, THE DESIRED OGARATE
#       IS AT THE POINT OF PENETRATION OF THE COAST REGION BY THE CONTROL
#       PARABOLA WHICH PASSES THROUGH THE OPERATING POINT.  FOR REGION 3
#       DESIRED OGARATE IS SIMPLY +-MAXLIM.  FOR REGIONS 1 OR 6 THE SOLUTION
#       TO A QUADRATIC IS REQUIRED (THE PENETRATION IS ALONG THE STRAIGHT
#       LINE OR MINLIM BOUNDRY SWITCH LINES).  AN APPROXIMATION IS MADE
#       INSTEAD.  CONSIDER AN OPERATING POINT IN REGION 6'.  PASS A TANGENT TO
#       THE CONTROL PARABOLA THROUGH THE OPERATING POINT, AND FIND ITS
#       INTERSECTION WITH THE STRAIGHT LINE SECTION OF THE SWITCH CURVE...
#       THE INTERSECTION DEFINES THE DESIRED OGARATE.  IF THE OPERATING POINT IS
#       CLOSE TO THE SWITCH LINE, THE APPROXIMATION IS QUITE GOOD (INDEED
#       THE APPROXIMATE AND QUADRATIC SOLUTIONS CONVERGE IN THE LIMIT AS
#       THE SWITCH LINE IS APPROACHED).  IF THE OPERATING POINT IS NOT CLOSE
#       TO THE SWITCH LINE, THE APPROXIMATE SOLUTION GIVES VALID TREND
#       INFORMATION (DIRECTION OF DESIRED OGARATE) AT LEAST.  THE
#       RE-EVALUATION OF DESIRED OGARATE IN SUBSEQUENT ROLL DAP PASSES (1/2
#       SECOND INTERVALS) WILL BENEFIT FROM THE CONVERGENT NATURE OF THE
#       APPROXIMATION.
#
# FOR LARGE OGAERROR THE TANGENT INTERSECTS +-MINLIM SWITCH BOUNDRY BEFORE
#       INTERSECTING THE STRAIGHT LINE SWITCH.  HOWEVER THE MINLIM IS
#       IGNORED IN COMPUTING THE FIRING TIME, SO THAT THE EXTENSION (INTO
#       THE COAST REGION) OF THE STRAIGHT LINE SWITCH IS WHAT IS FIRED TO.
#       IF THE ROLL DAP FINDS ITSELF IN THE COAST REGION BEFORE REACHING
#       THE DESIRED INTERSECTION (I.E., IN THE REGION BETWEEN THE MINLIM
#       AND THE STRAIGHT LINE SWITCH) IT WILL EXHIBIT NORMAL COAST-REGION
#       BEHAVIOR AND TURN OFF THE JETS.  THE PURPOSE OF THIS FIRING POLICY
#       IS TO MAINTAIN STATIC ROLL STABILITY IN THE EVENT OF A JET
#       FAILED-ON.
#
# WHEN THE OPERATING POINT IS IN REGION 1 THE SAME APPROXIMATION IS
#       MADE, BUT AT AN ARTIFICIALLY-CREATED OR DUMMY OPERATING POINT,
#       DEFINED BY:  OGAERROR = INTERSECTION OF CONTROL PARABOLA AND
```

```
#       OGAERROR AXIS, OGARATE = +-LMCRATE WHERE SIGN IS OPPOSITE THAT OF
#       REAL OPERATING POINT RATE.  WHEN THE OPERATING POINT HAS PASSED
#       FROM REGION 1 TO REGION 6', THE DUMMY POINT IS NO LONGER REQUIRED,
#       AND THE SOLUTION REVERTS TO THAT OF A REGULAR REGION 6' POINT.
#
# EQUATION FOR SWITCHING PARABOLA (SEE FIGURE ABOVE)....
#                                   2
#       SOGAERROR = (DB - (SOGARATE) (1/CONACC)/2) SGN(SOGARATE)
#
# EQUATION FOR SWITCHING STRAIGHT LINE SEGMENT....
#
#       SOGARATE = -(-SLOPE)(SOGAERROR) - SGN(SOGARATE) INTERCEP
#
#               WHERE  INTERCEP = DB(-SLOPE) - LMCRATE
# Page 988
#
# EQUATION FOR INTERSECTION, CONTROL PARABOLA, AND STRAIGHT SWITCH LINE....
#
#       DOGADOT = NUM/DEN, WHERE
#                                     2
#               NUM = (-SLOPE)(OGARATE) (1/CONACC)
#                     +SGN(DELOGA)(-SLOPE)(OGAERROR - SGN(DELOGA)(DB))
#                     +LMCRATE
#
#               DEN = (-SLOPE)(LMCRATE)(1/CONACC) = SGN(DELOGA)
#                                                 2
#               DELOGA = OGAERROR - (DB - (OGADOT) (1/CONACC)/2)SGN(OGARATE)
#
# FOR REGIONS 6 AND 6-PRIME, USE ACTUAL OPERATING POINT  (OGA, OGARATE)
#       FOR OGAERROR AND OGARATE IN THE INTERSECTION EQUATIONS ABOVE.
#       FOR REGIONS 1 AND 1-PRIME USE DUMMY OPERATING POINT FOR OGAERROR
#       AND OGARATE, WHERE THE DUMMY POINT IS GIVEN BY....
#
#               OGAERROR = DELOGA + DB SGN(OGARATE)
#
#               OGARATE = -LMCRATE SGN(OGARATE)
#
# NOTE, OGAERROR = OGA - OGAD  USES DUMMY REGISTER  OGA  IN ROLL DAP CODING
#       ALSO, AT POINT WHERE DOGADOT IS COMPUTED, REGISTER DELOGA IS USED
#       AS A DUMMY REGISTER FOR THE OGAERROR IN THE NUM EQUATION ABOVE.
# Page 989

# ROLLDAP CODING....

                SETLOC  DAPROLL
                BANK
```

```
                EBANK=  OGANOW
                COUNT*  $$/ROLL
ROLLDAP         CAE     OGANOW          # OGA RATE ESTIMATOR...SIMPLE FIRST-ORDER
                EXTEND                  #       DIFFERENCE (SAMPLE TIME = 1/2 SEC)
                MSU     OGAPAST
                EXTEND
                MP      BIT5
                LXCH    A
                TS      OGARATE         # SC.AT B-4 REV/SEC

# COMPUTATIONS WHICH FOLLOW USE OGA FOR OGAERR (SAME REGISTER)
# EXAMINE DURATION OF LAST ROLL FIRING IF JETS ARE NOW ON.

DURATION        CA      ROLLFIRE        # SAME SGN AS PRESENT TORQ,MAGN=POSMAX
                EXTEND
                BZF     +2              # ROLL JETS ARE NOW OFF.
                TCF     ROLLOGIC        # ENTER LOGIC, JETS NOW ON.

                CAE     TEMREG          # EXAMINE LAST FIRING INTERVAL
                EXTEND                  # IF POSITIVE, DON'T FIRE
                BZF     ROLLOGIC        # ENTER LOGIC, JETS NOW OFF.

                CAF     ZERO            # JETS HAVE NOT BEEN OFF FOR 1/2 SEC. WAIT
                TS      TEMREG          # RESET TEMREG
WAIT1/2         TCF     TASKOVER        # EXIT ROLL DAP

# COMPUTE DB-(1/2 CONACC) (OGARATE)SQ  (1/2 IN THE SCALING)

ROLLOGIC        CS      OGARATE         # SCALED AT 2(-4) REV/SEC
                EXTEND
                MP      1/CONACC        # SCALED AT 2(+9) SEC SQ /REV
                EXTEND
                MP      OGARATE
                AD      DB              # SCALED AT 2(+0) REV
                TS      TEMREG          # QUANTITY SCALED AT 2(+0) REV.

# GET SIGN OF OGARATE

                CA      OGARATE
                EXTEND
                BZMF    +3              # LET SGN(0) BE NEGATIVE
                CA      BIT1
                TCF     +2
                CS      BIT1
                TS      SGNRT           # + OR -  2(-14)
```

```
# Page 990
# CALCULATE DISTANCE FROM SWITCH PARABOLA,DELOGA
                EXTEND
                MP      TEMREG          # SGN(OGARATE) TEMREG NOW IN L
                CS      L
                AD      OGA             # SCALED AT 2(+0) REV
DELOGAC         TS      DELOGA          # SC.AT B+0 REV, PLUS TO RIGHT OF C-PARAB

# EXAMINE SGN(DELOGA) AND CREATE CA OR CS INSTR. DEPENDING UPON SIGN.

                EXTEND
                BZMF    +3
                CAF     PRIO30          # = CA (30000)
                TCF     +2
                CAF     BIT15           # = CS (40000)
                TS      I

                INDEX   I               # TSET ON  I SGN(OGARATE)
                0       SGNRT           # CA OR CS
                COM
                EXTEND
REG1TST         BZMF    ROLLON          # IF REGION 1 (DELOGA OGARATE SAME SIGN)

# NO JET FIRE YET.  TEST FOR MAX OGARATE.

                INDEX   I
                0       OGARATE         # CA OR CS...BOTH MUST BE NEG. HERE
                TS      IOGARATE        # I.E., I OGARATE
                AD      MAXLIM          # SCALED AT 2(-4) REV/SEC
                EXTEND
REG3TST         BZMF    RATELIM         # IF REGION 3 (RATES TOO HIGH, FIRE JETS)

# COMPUTATION OF I((-SLOPE)OGA + OGARATE) - INTERCEPT:  NOTE THAT STR. LINE
# SWITCH SLOPE IS (SLOPE) DEG/SEC/DEG, A NEG. QUANTITY

                CA      OGARATE
                EXTEND
                MP      BIT14
                TS      TEMREG
                CA      OGA
                EXTEND
                MP      -SLOPE
                DDOUBL
                DDOUBL
                DDOUBL                  # (OGA ERROR MUST BE LESS THAN +-225 DEG)
                AD      TEMREG
```

```
                INDEX   I
                O       A               # I((-SLOPE)OGA+OGARATE) AT 2(-3)REV/SEC
                COM
# Page 991
                AD      INTERCEP        # SCALED AT 2(-3) REV.
                COM
                EXTEND
REG2TST         BZMF    NOROLL          # IP REGION 2 (COAST SIDE OF STRT LINE)

# CHECK TO SEE IF OGARATE IS ABOVE MINLIM

                CA      IOGARATE        # ALWAYS NEGATIVE
                AD      MINLIM          # SCALED AT 2(-4) REV/SEC.
                EXTEND
REG4TST         BZMF    NOROLL          # IF REGION 4 (COAST SIDE OF MINLIM)

# ALL AREAS CHECKED EXCEPT LAST AREA...NO FIRE IN THIS SMALL SEGMENT

                INDEX   I
                O       OGA
                COM
                AD      DB
                COM
                EXTEND
REG5TST         BZMF    NOROLL          # IF REGION 5 (COAST SIDE OF DB)

# JETS MUST FIRE NOW.  OGARATE IS NEG. (OR VICE VERSA).  USE DIRECT STR. LINE.
# DELOGA AND DELOGART ARE USED AS DUMMY VARIABLES IN THE SOLUTION OF A
# STRAIGHT LINE APPROXIMATION TO A QUADRATIC SOLUTION OF THE INTERSECTION
# OF THE CONTROL PARABOLA AND THE STRAIGHT-LINE SWITCH LINE.  THE STRAIGHT
# LINE IS THE TANGENT TO THE CONTROL PARABOLA AT THE OPERATING POINT.  (FOR
# OPERATING POINTS IN REGIONS 6 AND 6')

REGION6         CAE     OGA             # USE ACTUAL OPERATING POINT FOR TANGENT
                TS      DELOGA          # ACTUAL STATE
                CA      OGARATE
                TS      DELOGART        # ACTUAL STATE, I.E., DEL OGARATE
                TCF     ONROLL

# JETS ALSO FIRE FROM HERE EXCEPT OGARATE IS POS (VICE VERSA), USE INDIRECT
# STRAIGHT LINE ESTABLISHED BY TANGENT TO A CONTROL PARABOLA AT  ((DELOGA
# + DB SGN(DELOGA) ), -LMCRATE SGN(DELOGA) )    (THIS IS THE DUMMY
# OPERATING POINT FOR OPERATING POINTS IN REGIONS 1 AND 1')

ROLLON          INDEX   I
```

```
                0       DB
                ADS     DELOGA          # DELOGA WAS DIST. FROM SWITCH PARABOLA

                CS      LMCRATE         # LIMIT CYCLE RATE AT 2(-4) REV/SEC
                INDEX   I
                0       A
                TS      DELOGART        # EVALUATE STATE FOR INDIRECT LINE.

# Page 992
# SOLVE STRAIGHT LINES SIMULTANEOUSLY TO OBTAIN DESIRED OGARATE.

ONROLL          EXTEND                  # DELOGART IN ACC. ON ARRIVAL
                MP      1/CONACC
                DOUBLE
                EXTEND
                MP      -SLOPE
                TS      TEMREG          # 2(-SLOPE)RATE /CONACC
                EXTEND
                MP      DELOGART
                TS      DELOGART        # 2(-SLOPE)(RATESQ)/CONACC
                CS      BIT11
                INDEX   I
                0       A
RATEDEN         ADS     TEMREG          # DENOMINATOR COMPLETED

                INDEX   I
                0       DELOGA
                COM
                AD      DB
                COM
                EXTEND
                MP      -SLOPE
                ADS     DELOGART
                CA      LMCRATE
                EXTEND
                MP      BIT11
RATENUM         AD      DELOGART        # NUMERATOR COMPLETED

                XCH     L               # PLACE NUMERATOR IN L FOR OVERFL.  CHECK
                CA      ZERO
                EXTEND
                DV      TEMREG          # OVERFLOW, IF ANYTHING, NOW APPEARS IN A
                EXTEND
                BZF     DVOK            # NO OVERFLOW....(0,L)/TEMREG = 0,L

MINLIMAP        CCS     A
```

```
                CAF     POSMAX          #       POSITIVE OVERFLOW
                TCF     ROLLSET
                CS      POSMAX          #       NEGATIVE OVERFLOW
                TCF     ROLLSET

DVOK            LXCH    A               # PUT NUMERATOR BACK INTO A, 0 INTO L
                EXTEND
                DV      TEMREG          # RESULT OF DIVISION IS DESIRED OGARATE
                TCF     ROLLSET         #       (SCALED AT B-4 REV/SEC)

RATELIM         CS      MAXLIM
                INDEX   I
# Page 993
                0       A               # IF I = CA, DESIRED RATE IS  -MAXLIM

# COMPUTE JET FIRE TIME, BASED ON DESIRED RATE MINUS PRESENT RATE

ROLLSET         TS      TEMREG          # STORE DESIRED OGARATE (SCALED B-4)
                EXTEND
                SU      OGARATE         # RATE DIFF. SCALED AT 2(-4) REV/SEC
                TS      TEMREG          #       OVERFLOW PROTECT
                TCF     +3              #           "       "
                INDEX   A               #           "       "
                CS      LIMITS          #           "       "
                EXTEND
                MP      T6SCALE         # T6SCALE = 8/10.24
                EXTEND
                MP      1/CONACC        # SCALED AT B+9 SECSQ/REV (MAX < .60)
                DDOUBL
                DDOUBL
                TS      TEMREG          #       OVERFLOW PROTECT
                TCF     +3              #           "       "
                INDEX   A               #           "       "
                CS      LIMITS          #           "       "
                TS      TEMREG          # JET FIRE TIME AT 625 MICROSEC/BIT
                EXTEND                  # POS MEANS POSITIVE ROLL TORQUE.
                BZF     NOROLL

# JET FIRE TIME IS NZ, TEST FOR JETS NOW ON.

                CAE     TEMREG          # DESIRED CHANGE IN OGARATE
                EXTEND
                MP      ROLLFIRE        # (SGN OF TORQUE: ZERO IF JETS NOW OFF)
                CCS     A
                TCF     MOREROLL        # CONTINUE FIRING WITH PRESENT POLARITY
                TCF     NEWROLL         # START NEW FIRING NOW, PLUS
```

```
                TCF     NOROLL          # TERMINATE OLD FIRING, NEW SIGN REQUESTED
                TCF     NEWROLL         # START NEW FIRING NOW, MINUS

# CONTINUE PRESENT FIRING

MOREROLL        CAF     ZERO
                TS      I               # USE TEMP. AS MOREROLL SWITCH
                TCF     MAXTFIRE

# START NEW FIRING BUT CHECK IF GREATER THAN MIN FIRE TIME.

NEWROLL         CCS     TEMREG          # CALL THIS T6FIRE
                AD      ONE
                TCF     +2
                AD      ONE
                COM                     # -MAG(T6FIRE)
                AD      TMINFIRE        # TMINFIRE-MAG(T6FIRE)
# Page 994
                COM
                EXTEND
MINTST          BZMF    NOROLL          # IF NOT GREATER THAN TMINFIRE (NEW FIRE)

# PROCEED WITH NEW FIRING BUT NOT LONGER THAN TMAXFIRE

MAXTFIRE        CA      TEMREG
                EXTEND
                MP      1/TMXFIR        # I.E., 1/TMAXFIRE
                EXTEND
MAXTST          BZF     NOMXFIRE        # IF LESS THAN TMAXFIRE

                CCS     A
                CAF     TMAXFIRE        # USE MAXIMUM
                TCF     +2
                CS      TMAXFIRE        # USE MAXIMUM
                TS      TEMREG

# SET UP SIGN OF REQUIRED TORQUE

NOMXFIRE        CCS     TEMREG          # FOR TORQUE SIGN
                CA      POSMAX          # POSITIVE TORQUE REQUIRED
                TCF     +2
                CA      NEGMAX          # NEGATIVE TORQUE REQUIRED
                TS      ROLLFIRE        # SET ROLLFIRE FOR + OR - TORQUE

                COM                     # COMPLEMENT... POS. FOR NEG. TORQUE
                EXTEND
```

```
                BZMF    +3              # POSITIVE TORQUE REQUIRED
                CS      TEMREG
                TS      TEMREG

FIRELOOK        CA      I               # IS IT MOREROLL
                EXTEND
                BZF     FIREPLUG        # YES
                TCF     JETROLL         # MAG(T6FIRE) NOW IN TEMREG

FIREPLUG        CAE     TIME6           # CHECK FOR EXTENDED FIRING
                EXTEND
                SU      TEMREG
                EXTEND
EXTENTST        BZMF    TASKOVER        # IF EXTENSION WANTED, DON'T, EXIT ROLL DAP
                TCF     JETROLL

NOROLL          CS      ZERO            # COAST....(NEG ZERO FOR TIME6)
                TS      ROLLFIRE        # NOTE, JETS CAN FIRE NEXT PASS
                TS      TEMREG

JETROLL         EXTEND
                DCA     NOROL1T6
# Page 995
                DXCH    T6LOC
                CA      TEMREG          # ENTER JET FIRING TIME
                TS      TIME6

                CA      I               # I=0 IF MOREROLL, KEEP SAME JETS ON
                EXTEND
SAMEJETS        BZF     TASKOVER        # IF JETS ON KEEP SAME JETS.  EXIT ROLL DAP

                CCS     ROLLFIRE
                TCF     +TORQUE
                TCF     T6ENABL
                TCF     -TORQUE
                TCF     T6ENABL

# PROCEED WITH + TORQUE

+TORQUE         CA      ROLLWORD        # WHAT WAS THE LAST +TORQUE COMBINATION
                MASK    BIT1            # WAS IT NO.9-11
                EXTEND
                BZF     NO.9-11         # NOT 9-11, SO USE IT THIS TIME

NO.13-15        CS      BIT1
                MASK    ROLLWORD
```

```
                TS      ROLLWORD        # CHANGE BIT 1 TO ZERO
                CAF     +ROLL2
                EXTEND
                WRITE   CHAN6
                TCF     T6ENABL

NO.9-11         CAF     BIT1            # 1ST + JETS TO FIRE (MRCLEAN OS ROLLWORD)
                ADS     ROLLWORD        # CHANGE BIT 1 TO ONE
                CAF     +ROLL1
                EXTEND
                WRITE   CHAN6
                TCF     T6ENABL

-TORQUE         CA      ROLLWORD        # WHAT WAS LAST -TORQUE COMBINATION
                MASK    BIT2            # WAS IT NO.12-10
                EXTEND
                BZF     NO.12-10        # NOT 12-10, SO USE IT THIS TIME

NO.16-14        CS      BIT2
                MASK    ROLLWORD
                TS      ROLLWORD        # CHANGE BIT 2 TO ZERO
                CAF     -ROLL2
                EXTEND
                WRITE   CHAN6
                TCF     T6ENABL

NO.12-10        CAF     BIT2            # 1ST -JETS TO FIRE (MRCLEAN OS ROLLWORD)
# Page 996
                ADS     ROLLWORD        # CHANGE BIT 2 TO ONE
                CAF     -ROLL1
                EXTEND
                WRITE   CHAN6

T6ENABL         CAF     BIT15
                EXTEND
                WOR     CHAN13
RDAPEND         TCF     TASKOVER        # EXIT ROLL DAP

# Page 997
# THIS T6 TASK SHUTS OFF ALL ROLL JETS

NOROLL1         LXCH    BANKRUPT        # SHUT OFF ALL (ROLL) JETS, (A T6 TASK
                CAF     ZERO            #       CALLED BY "JETROLL")
                TS      ROLLFIRE        # ZERO INDICATES JETS NOW OFF
                EXTEND
KILLJETS        WRITE   CHAN6
```

```
                TCF     NOQRSM

# Page 998
# CONSTANTS FOR ROLL AUTOPILOT....

                EBANK=  BZERO
NOROL1T6        2CADR   NOROLL1

DB              DEC     .01388889       # DEAD BAND (5 DEG), SC.AT B+0 REV

-SLOPE          DEC     0.2             # -SWITCHLINE SLOPE(0.2 PER SEC) SC.AT B+0
                                        #       PER SEC
LMCRATE         DEC     .00027778 B+4   # LIMIT CYCLE RATE (0.1 DEG/SEC) SC.AT
                                        #       B-4 REV/SEC
INTERCEP        DEC     .0025 B+3       # DB(-SLOPE) - LMCRATE, SC.AT B-3 REV/SC

MINLIM          DEC     .00277778 B+4   # RATELIM,MIN (1DEG/SEC), SC.AT B-4 REV/SC

1/MINLIM        DEC     360 B-18        # RECIPROCAL THEREOF, SHIFTED 14 RIGHT

MAXLIM          DEC     .01388889 B+4   # RATELIM,MAX (5DEG/SEC), SC.AT B-4 REV/SC

# The following two were B+4.---RSB 2009.
TMINFIRE        DEC     1.5 B-10        # 15 MS. (14MIN), SC.AT 16 BITS/CS

TMAXFIRE        DEC     250 B-10        # 2.5 SEC, SC.AT 16 BITS/CS

1/TMXFIR        =       BIT3            # RECIPROCAL THEREOF, SHIFTED 14 RIGHT,
                                        #       ROUNDS TO OCT00004, SO ALLOWS 2.56
                                        #       SEC FIRINGS BEFORE APPLYING LIMIT
T6SCALE         =       PRIO31          # (B+3) (16 BITS/CS)  (100CS/SEC)

+ROLL1          =       FIVE            # ONBITS FOR JETS 9 AND 11
+ROLL2          =       OCT120          # ONBITS FOR JETS 13 AND 15
-ROLL1          =       TEN             # ONBITS FOR JETS 12 AND 10
-ROLL2          OCT     240             # ONBITS FOR JETS 16 AND 14
```

Uses 1/CONACC 204, A 80, AK 200, BANKRUPT 80, BZERO 208, CDUX 80, CHAN13 87, COUNT 142, DAPROLL 63, DEL 232, DELOGA 206, DELOGART 206, DIFF 226, DV 241, EBANK 80, I 206, IOGARATE 206, IT 185, L 80, OGA 206, OGAD 200, OGAERR 206, OGANOW 206, OGAPAST 206, OGARATE 208, P 188, ROLLFIRE 204, ROLLWORD 204, SGNRT 206, SLOPE 213, SQ 156, STATE 138, T6LOC 163, TEMP 191, TEMREG 204, and TIME6 80.

3.6.8 mysubs code

1409 ⟨*mysubs code* 1409⟩≡ (1346c 2747)
⟨*Page CM0999* 1410⟩

1410 ⟨*Page CM0999* 1410⟩≡ (1409)

```
# Page 999
                BANK    20
                SETLOC  MYSUBS
                BANK

                EBANK=  KMPAC
SPCOS1          EQUALS  SPCOS
SPSIN1          EQUALS  SPSIN
SPCOS2          EQUALS  SPCOS
SPSIN2          EQUALS  SPSIN

                COUNT   21/DAPMS

# ONE AND ONE HALF PRECISION MULTIPLICATION ROUTINE

SMALLMP         TS      KMPTEMP         # A(X+Y)
                EXTEND
                MP      KMPAC   +1
                TS      KMPAC   +1      # AY
                CAF     ZERO
                XCH     KMPAC
                EXTEND
                MP      KMPTEMP         # AX
                DAS     KMPAC           # AX+AY
                TC      Q

# SUBROUTINE FOR DOUBLE PRECISION ADDITIONS OF ANGLES
# A AND L CONTAIN A DP(1S) ANGLE SCALED BY 180 DEGS TO BE ADDED TO KMPAC.
# RESULT IS PLACED IN KMPAC.  TIMING = 6 MCT (22 MCT ON OVERFLOW)

DPADD           DAS     KMPAC
                EXTEND
                BZF     TSK     +1      # NO OVERFLOW
                CCS     KMPAC
                TCF     DPADD+          # + OVERFLOW
                TCF     +2
                TCF     DPADD-          # - OVERFLOW
                CCS     KMPAC   +1
                TCF     DPADD2+         # UPPER = 0, LOWER +
                TCF     +2
                COM                     # UPPER = 0, LOWER -
                AD      POSMAX          # LOWER = 0, A = 0
                TS      KMPAC   +1      # CAN NOT OVERFLOW
                CA      POSMAX          # UPPER WAS = 0
TSK             TS      KMPAC
```

```
                TC      Q

DPADD+          AD      NEGMAX          # KMPAC GREATER THAN 0
                TCF     TSK

# Page 1000
DPADD-          COM
                AD      POSMAX          # KMPAC LESS THAN 0
                TCF     TSK

DPADD2+         AD      NEGMAX          # CAN NOT OVERFLOW
                TS      KMPAC   +1
                CA      NEGMAX          # UPPER WAS = 0
                TCF     TSK

# Page 1001 (empty page)
```

Uses `A` 80, `COUNT` 142, `EBANK` 80, `KMPAC` 209, `KMPTEMP` 209, `L` 80, `MYSUBS` 63, `Q` 80, and `TC` 169.

3.6.9 rcs-csm digital autopilot

1411 ⟨*rcs-csm digital autopilot* 1411⟩≡ (1346c 2791)
⟨*Page CM1002* 1412⟩

1412 ⟨*Page CM1002* 1412⟩≡ (1411)

```
# Page 1002
# T5 INTERRUPT PROGRAM FOR THE RCS-CSM AUTOPILOT

# START OF T5 INTERRUPT PROGRAM

                BANK    20
                SETLOC  DAPS3
                BANK

                COUNT   21/DAPRC

                EBANK=  KMPAC
REDORCS         LXCH    BANKRUPT        # RESTART OF AUTOPILOT COMES HERE
                CA      T5PHASE         # ON A T5 RUPT
                EXTEND
                BZMF    +2              # IF T5PHASE +0, -0, OR -, RESET TO -
                TCF     +3              # IF T5PHASE +, LEAVE IT +.  DO A FRESHDAP
                CS      ONE
                TS      T5PHASE
                EXTEND
                DCA     RCSLOC
                DXCH    T5LOC           # HOOK UP T5RUPT TO AUTOPILOT
                TCF     RCSATT +1
                EBANK=  KMPAC
RCSLOC          2CADR   RCSATT

RCSATT          LXCH    BANKRUPT        # SAVE BB
                EXTEND                  # SAVE Q
                QXCH    QRUPT
                CAF     BIT15           # BIT15 CHAN31 = 0 IF IMU POWER IS ON AND
                EXTEND                  # S/C CONT SW IS IN CMC (I.E., IF G/C AUTO
                RAND    CHAN31          # PILOT IS FULLY ENABLED)
                EXTEND
                BZF     SETT5           # IF G/C AUTOPILOT IS FULLY ENABLED,
                                        # GO TO SETT5

                CS      RCSFLAGS        # IF G/C AUTOPILOT IS NOT FULLY ENABLED,
                MASK    BIT14
                ADS     RCSFLAGS        # SET NORATE FLAG,
                CAF     POSMAX
                TS      HOLDFLAG        # SET HOLDFLAG +,
                CAF     ZERO            # ZERO ERRORX, ERRORY, AND ERRORZ,
                TS      ERRORX
                TS      ERRORY
                TS      ERRORZ
```

```
                CAF     BIT14
                EXTEND
                RAND    CHAN31          # AND CHECK FREE FUNCTION (BIT14 CHAN31).
                EXTEND
# Page 1003
                BZF     SETT5           # IF IN FREE MODE, GO TO SETT5.

                TS      T5PHASE         # IF NOT IN FREE MODE,
                CAF     OCT37766        # SCHEDULE REINITIALIZATION (FRESHDAP)
                TS      TIME5           # IN 100 MS VIA T5RUPT

                TCR     ZEROJET         # ZERO JET CHANNELS IN 14 MS VIA ZEROJET

                TCF     KMATRIX
DELTATT         OCT     37770           # 80MS (TIME5)
DELTATT2        OCT     37776           # 20MS (TIME5)
ONESEK          DEC     16284           # 1 SEC(TIME5)
CHAN5           EQUALS  5
CHAN6           EQUALS  6
PRIO34A         =       PRIO34

# CHECK PHASE OF T5 PROGRAM
#
# BECAUSE OF THE LENGTH OF THE T5 PROGRAM,IT HAS BEEN DIVIDED INTO
# THREE PARTS, T5PHASE1, T5PHASE2, AND THE JET SELECTION LOGIC,
# TO ALLOW FOR THE EXECUTION OF OTHER
# INTERRUPTS.  T5PHASE IS ALSO USED IN THE INITIALIZATION OF THE AUTOPILOT
# VARIABLES AT TURN ON.
#
# THE CODING OF T5PHASE IS...
#
#               + = INITIALIZE T5 RCS-CSM AUTOPILOT
#    T5PHASE = +0 = PHASE2 OF THE T5 PROGRAM
#               - = RESTART DAP
#              -0 = PHASE1 OF THE T5 PROGRAM

SETT5           CCS     T5PHASE
                TCF     FRESHDAP        # TURN ON AUTOPILOT
                TCF     T5PHASE2        # BRANCH TO PHASE2 OF PROGRAM
                TCF     REDAP           # RESTART AUTOPILOT

                TS      T5PHASE         # PHASE 1  RESET  FOR PHASE 2
                CA      TIME5
                TS      T5TIME          # USED IN COMPENSATING FOR DELAYS IN T5
                CAF     DELTATT2        # RESET FOR T5RUPT IN 20MS FOR PHASE2
                TS      TIME5           # OF PROGRAM
```

```
# Page 1004
# IMU STATUS CHECK

                CS      IMODES33        # CHECK IMU STATUS
                MASK    BIT6            # BIT6 = 0 IMU OK
                CCS     A               # BIT6 = 1 NO IMU
                TCF     RATEFILT
FREECHK         CS      RCSFLAGS        # BIT14 INDICATES THAT RATES HAVE NOT BEEN
                MASK    BIT14           # INITIALIZED
                ADS     RCSFLAGS
                CAF     BIT14           # NO ATTITUDE REFERENCE
                TS      HOLDFLAG        # STOP ANY AUTOMATIC STEERING AND PREPARE
                                        # TO PICK UP CDU ANGLES UPON RESUMPTION OF
                                        # ATTITUDE HOLD
                EXTEND
                RAND    CHAN31          # CHECK FOR FREE MODE
                EXTEND
                BZF     KRESUME1        # IN FREE MODE PROVIDE FREE CONTROL ONLY
                TCF     REINIT          # .....TILT..............................
BITS4,5         OCT     30

RATEFILT        CA      RCSFLAGS        # SEE IF RATEFILTER HAS BEEN INITIALIZED
                MASK    BIT14
                EXTEND                  # IF SO, PROCEED WITH RATE DERIVATION
                BZF     +2
                TCF     KMATRIX         # IF NOT, SKIP RATE DERIVATION

#       RATE FILTER     TIMING = 7.72 MS
#
# RATE FILTER EQUATIONS
#
#
# DRHO = DELRHO - (.1)ADOT + (1 = GAIN1)DRHO
#                                          -1
#
# ADOT = ADOT   + GAIN2 DRHO + KMJ DFT
#            -1
#        _       *     _     _
# WHERE DELRHO = AMGB (CDU - CDU  )
#                               -1

                CAF     TWO
DRHOLOOP        TS      SPNDX
                DOUBLE
                TS      DPNDX
```

```
                INDEX   DPNDX
                CS      DRHO            # DRHO SCALED 180 DEGS
                EXTEND
                INDEX   ATTKALMN        # PICK UP DESIRED FILTER GAIN
                MP      GAIN1
                INDEX   DPNDX
                DAS     DRHO            # (1 -.064) DRHO
                EXTEND
# Page 1005
                INDEX   DPNDX
                DCS     ADOT
                DXCH    KMPAC           # -(.1)ADOT
                CA      QUARTER
                TC      SMALLMP
                DXCH    KMPAC
                INDEX   DPNDX
                DAS     DRHO
                CCS     SPNDX
                TCF     DRHOLOOP

                CA      CDUX            # MEASURED BODY RATES--
                XCH     RHO
                EXTEND
                MSU     RHO             # _        *     _     _
                COM                     # DELRHO = AMGB (CDU - CDU  )
                                        #                         -1
                ZL
                DXCH    DELTEMPX
                CA      CDUY
                XCH     RHO1
                EXTEND
                MSU     RHO1
                COM
                TS      T5TEMP          # (CDUY - RHO1)    SCALED 90 DEGS
                EXTEND
                MP      AMGB1
                DAS     DELTEMPX        # DELTEMPX = (CDUX-RHO) + AMGB1(CDUY-RHO1)
                                        # MUST BE DOUBLE PRECISION OR WILL LOSE
                                        # PULSES
                CA      AMGB4
                EXTEND
                MP      T5TEMP
                DXCH    DELTEMPY
                CA      AMGB7
                EXTEND
                MP      T5TEMP
```

```
                DXCH    DELTEMPZ
                CA      CDUZ
                XCH     RHO2
                EXTEND
                MSU     RHO2
                COM
                TS      T5TEMP          # (CDUZ - RHO2)    SCALED 90 DEGS
                EXTEND
                MP      AMGB5
                DAS     DELTEMPY        # DELTEMPY = AMGB4(CDUY-RHO1)
                                        #                  + AMGB5(CDUZ-RHO2)
                CA      AMGB8
                EXTEND

# Page 1006
                MP      T5TEMP
                DAS     DELTEMPZ        # DELTEMPZ = AMBG7(CDUY-RHO1)
                                        #                 + AMGB8(CDUZ-RHO2)
                CAF     TWO
ADOTLOOP        TS      SPNDX
                DOUBLE
                TS      DPNDX
                EXTEND
                INDEX   DPNDX
                DCA     DELTEMPX
                INDEX   DPNDX
                DAS     DRHO
                EXTEND
                INDEX   DPNDX
                DCA     DELTEMPX
                INDEX   DPNDX
                DAS     MERRORX
                INDEX   DPNDX
                CA      DRHO
                DOUBLE                  # N.B.
                DOUBLE                  # N.B.
                EXTEND
                INDEX   ATTKALMN        # PICK UP DESIRED FILTER GAINS
                MP      GAIN2
                INDEX   DPNDX           # ADOT   + (.16)(.1)DRHO
                DAS     ADOT            #     -1
                INDEX   SPNDX           # S/C TORQUE TO INERTIA RATIO
                CA      KMJ             # SCALED (450)(1600)/(57.3)(16384)=1/1.3
                EXTEND
                INDEX   SPNDX
                MP      DFT
```

```
                INDEX   DPNDX
                DAS     ADOT            # KMJ(DFT)
                CCS     SPNDX
                TCF     ADOTLOOP        # END CALCULATION OF VEHICLE RATES
KMATRIX         CA      ATTSEC
                MASK    LOW4
                CCS     A
                TCF     TENTHSEK
                CAF     PRIO34          # CALL FOR 1 SEC UPDATE OF TRANSFORMATION
                TC      NOVAC           # MATRIX FROM GIMBAL AXES TO BODY AXES
                EBANK=  KMPAC
                2CADR   AMBGUPDT

                CAF     NINE

TENTHSEK        TS      ATTSEC

# Page 1007
# WHEN AUTOMATIC MANEUVERS ARE BEING PERFORMED, THE FOLLOWING ANGLE ADDITION MUST BE MADE TO PR
# SEQUENCE OF ANGULAR COMMANDS TO THE AUTOPILOT--
#
#       CDUXD = CDUXD + DELCDUX         (DOUBLE PRECISION)
#       CDUYD = CDUYD + DELCDUY         (DOUBLE PRECISION)
#       CDUZD = CDUZD + DELCDUZ         (DOUBLE PRECISION)
#
# THE STEERING PROGRAMS:
#       1) ATTITUDE MANEUVER ROUTINE
#       2) LEM TRACKING
#
# SHOULD GENERATE THE DESIRED ANGLES (CDUXD, CDUYD, CDUZD) AS WELL AS THE INCREMENTAL ANGLES (D
# DELCDUZ) SO THAT THE GIMBAL ANGLE COMMANDS CAN BE INTERPOLATED BETWEEN UPDATES.
#
# HOLDFLAG CODING:
#
#       + = GRAB PRESENT CDU ANGLES AND STORE IN THETADX, THETADY, THETADZ
#           AND PERFORM ATTITUDE HOLD ABOUT THESE ANGLES
#           ALSO IGNORE AUTOMATIC STEERING
#           SET = + BY
#               1) INITIALIZATION PHASE OF AUTOPILOT
#               2) OCCURANCE OF RHC COMMANDS
#               3) FREE MODE
#               4) SWITCH OVER TO ATTITUDE HOLD FROM AUTO
#                  WHILE DOING AUTOMATIC STEERING (IN THIS CASE
#                  HOLDFLAG IS NOT ACTUALLY SET TO +, BUT THE LOGIC
#                  FUNCTIONS AS IF IT WERE.)
#               5) S/C CONTROL SWITCH IS SCS
```

```
#               6) IMU POWER OFF
#      +0 = IN ATTITUDE HOLD ABOUT A PREVIOUSLY ESTABLISHED REFERENCE
#       - = PERFORMING AUTOMATIC MANEUVER
#      -0 = NOT USED AT PRESENT
#
# NOTE THAT THIS FLAG MUST BE SET = - BY THE STEERING PROGRAM IF IT IS TO COMMAND THE
# SINCE ASTRONAUT ACTION MAY CHANGE THE HOLDFLAG SETTING, IT SHOULD BE MONITORED BY T
# DETERMINE IF THE AUTOMATIC SEQUENCE HAS BEEN INTERRUPTED AND IF SO, TAKE THE APPROP

                CS      HOLDFLAG
                EXTEND
                BZMF    DACNDLS         # IF HOLDFLAG +0,-0,+, BYPASS AUTOMATIC
                                        # COMMANDS.
DCDUINCR        CAF     TWO
DELOOP          TS      SPNDX
                DOUBLE
                TS      DPNDX
                EXTEND
                INDEX   A
                DCA     CDUXD
# Page 1008
                DXCH    KMPAC
                EXTEND
                INDEX   DPNDX
                DCA     DELCDUX
                TC      DPADD
                EXTEND
                DCA     KMPAC
                INDEX   SPNDX
                TS      THETADX
                INDEX   DPNDX
                DXCH    CDUXD
                CCS     SPNDX
                TCF     DELOOP

# Page 1009
# RCS-CSM AUTOPILOT ATTITUDE ERROR DISPLAY
#
# THREE TYPES OF ATTITUDE ERRORS MAY BE DISPLAYED ON THE FDAI:
#
#       MODE 1) AUTOPILOT FOLLOWING ERRORS              SELECTED BY V61E
#               GENERATED INTERNALLY BY THE AUTOPILOT
#
#       MODE 2) TOTAL ATTITUDE ERRORS                   SELECTED BY V62E
#               WITH RESPECT TO THE CONTENTS OF N22
#
```

```
#       MODE 3) TOTAL ASTRONAUT ATTITUDE ERRORS         SELECTED BY V63E
#               WITH RESPECT TO THE CONTENTS OF N17
#
# MODE 1 IS PROVIDED AS A MONITOR OF THE RCS DAP AND ITS ABILITY TO TRACK AUTOMATIC STEERING CO
# MODE THE ATTITUDE ERRORS WILL BE ZEROED WHEN THE CMC MODE SWITCH IS IN FREE.
#
# MODE 2 IS PROVIDED TO ASSIST THE CREW IN MANUALLY MANEUVERING THE S/C TO THE ATTITUDE (GIMBAL
# IN N22.  THE ATTITUDE ERRORS WRT THESE ANGLES AND THE CURRENT CDU ANGLES ARE RESOLVED INTO S/
# AS A FLY-TO INDICATOR.
#
# MODE 3 IS PROVIDED TO ASSIST THE CREW IN MANUALLY MANEUVERING THE S/C TO THE ATTITUDE (GIMBAL
# IN N17.  THE ATTITUDE ERRORS WRT THESE ANGLES AND THE CURRENT CDU ANGLES ARE RESOLVED INTO S/
# AS A FLY-TO INDICATOR.
#
# V60 IS PROVIDED TO LOAD N17 WITH A SNAPSHOT OF THE CURRENT CDU ANGLES, THUS SYNCHRONIZING THE
# WITH THE CURRENT S/C ATTITUDE.  THIS VERB MAY BE USED AT ANY TIME.
#
# THESE DISPLAYS WILL BE AVAILABLE IN ANY MODE (AUTO, HOLD, FREE, G+N, OR SCS) ONCE THE RCS DAP
# INITIATED VIA V46E.  MODE 1, HOWEVER, WILL BE MEANINGFUL ONLY IN G+N AUTO OR HOLD.  THE CREW
# V25N17) AN ATTITUDE REFERENCE (DESIRED GIMBAL ANGLES) INTO N17 AT ANY TIME.

DACNDLS         CS      RCSFLAGS        # ALTERNATE BETWEEN FDAIDSP1 AND FDAIDSP2
                MASK    BIT4
                EXTEND
                BZF     FDAIDSP2

FDAIDSP1        ADS     RCSFLAGS
                TC      NEEDLER
KRESUME1        TCF     RESUME          # END PHASE 1

# Page 1010
# FDAI ATTITUDE ERROR DISPLAY SUBROUTINE
#
# PROGRAM DESCRIPTION:  D. KEENE  5/24/67
#
# THIS SUBROUTINE IS USED TO DISPLAY ATTITUDE ERRORS ON THE FDAI VIA THE DIGITAL TO ANALOG CONV
# IN THE CDUS.  CARE IS TAKEN TO METER OUT THE APPROPRIATE NUMBER OF PULSES TO THE IMU ERROR CO
# OVERFLOW, TO CONTROL THE RELAY SEQUENCING, AND TO AVOID INTERFERENCE WITH THE COARSE ALIGN LO
# THE DACS.
#
# CALLING SEQUENCE:
#
# DURING THE INITIALIZATION SECTION OF THE USER'S PROGRAM, BIT3 OF RCSFLAGS SHOULD BE SET TO IN
# TURN-ON SEQUENCE WITHIN THE NEEDLES PROGRAM:
#
#               CS      RCSFLAGS        # IN EBANK6
```

```
#               MASK    BIT3
#               ADS     RCSFLAGS
#
# THEREAFTER, THE ATTITUDE ERRORS GENERATED BY THE USER SHOULD BE TRANSFERED TO THE I
#
#               AK      SCALED 180 DEGREES      NOTE:   THESE LOCATIONS ARE SUBJECT
#               AK1     SCALED 180 DEGREES              TO CHANGE
#               AK2     SCALED 180 DEGREES
#
# FULL SCALED DEFLECTION CORRESPONDS TO 16 7/8 DEGREES OF ATTITUDE ERROR
#               (= 384 BITS IN IMU ERROR COUNTER)
#
# A CALL TO NEEDLER WILL THEN UPDATE THE DISPLAY:
#
#               INHINT
#               TC      IBNKCALL        # NOTE: EBANK SHOULD BE SET TO E6
#               CADR    NEEDLER
#               RELINT
#
# THIS PROCESS SHOULD BE REPEATED EACH TIME THE ERRORS ARE UPDATED.  AT LEAST 3 PASSE
# REQUIRED BEFORE ANYTHING IS ACTUALLY DISPLAYED ON THE ERROR METERS.
# NOTE:  EACH CALL TO NEEDLER MUST BE SEPARATED BY AT LEAST 50MS TO ASSURE PROPER REI
#
# ERASABLE USED:
#               AK              CDUXCMD
#               AK1             CDUYCMD
#               AK2             CDUZCMD
#               EDRIVEX         A,L,Q
#               EDRIVEY         T5TEMP
#               EDRIVEZ         SPNDX
#
# SWITCHES;     RCSFLAGS        BITS 3,2
#
# I/O CHANNELS: CHAN12          BIT 4            (COARSE ALIGN - READ ONLY)
# Page 1011
#               CHAN12          BIT 6           (IMU ERROR COUNTER ENABLE)
#               CHAN14          BIT 13,14,15    (DAC ACTIVITY)
#
# SIGN CONVENTION:      AK = THETAC - THETA
#               WHERE   THETAC = COMMAND ANGLE
#                       THETA = PRESENT ANGLE

NEEDLER         CAF     BIT4            # CHECK FOR COARSE ALIGN ENABLE
                EXTEND                  # IF IN COARSE ALIGN DO NOT USE IMU
                RAND    CHAN12          # ERROR COUNTERS.  DON'T USE NEEDLES
                EXTEND
```

```
                BZF     NEEDLER1
                CS      RCSFLAGS        # SET BIT3 FOR INITIALIZATION PASS
                MASK    BIT3
                ADS     RCSFLAGS
                TC      Q

NEEDLER1        CA      RCSFLAGS
                MASK    SIX
                EXTEND
                BZF     NEEDLES3
                MASK    BIT3
                EXTEND
                BZF     NEEDLER2        # BIT3 = 0, BIT2 = 1

                CS      BIT6            # FIRST PASS BIT3 = 1
                EXTEND                  # DISABLE IMU ERROR COUNTER TO ZERO DACS
                WAND    CHAN12          # MUST WAIT AT LEAST 60 MS. BEFORE
NEEDLE11        CS      ZERO            # ENABLING COUNTERS.
                TS      AK              # ZERO THE INPUTS ON FIRST PASS
                TS      AK1
                TS      AK2
                TS      EDRIVEX         # ZERO THE DISPLAY REGISTERS
                TS      EDRIVEY
                TS      EDRIVEZ
                TS      CDUXCMD         # ZERO THE OUT COUNTERS
                TS      CDUYCMD
                TS      CDUZCMD
                CS      SIX             # RESET RCSFLAGS FOR PASS2
                MASK    RCSFLAGS
                AD      BIT2
                TS      RCSFLAGS
                TC      Q               # END PASS1

NEEDLER2        CAF     BIT6            # ENABLE IMU ERROR COUNTERS
                EXTEND
                WOR     CHAN12
                CS      SIX             # RESET RCSFLAGS TO DISPLAY ATTITUDE
# Page 1012
                MASK    RCSFLAGS        # ERRORS    WAIT AT LEAST 4 MS FOR
                TS      RCSFLAGS        # RELAY CLOSURE
                TC      Q

NEEDLES3        CAF     BIT6            # CHECK TO SEE IF IMU ERROR COUNTER
                EXTEND                  # IS ENABLED
                RAND    CHAN12
                EXTEND                  # IF NOT RECYCLE NEEDLES
```

```
                BZF     NEEDLER +5

NEEDLES         CAF     TWO
DACLOOP         TS      SPNDX
                CS      QUARTER
                EXTEND
                INDEX   SPNDX
                MP      AK
                TS      L
                CCS     A
                CA      DACLIMIT
                TCF     +2
                CS      DACLIMIT
                AD      L
                TS      T5TEMP          # OVFLO CHK
                TCF     +4
                INDEX   A               # ON OVERFLOW LIMIT OUTPUT TO +-384
                CAF     DACLIMIT
                TS      L
                INDEX   SPNDX
                CS      EDRIVEX         # CURRENT VALUE OF DAC
                AD      L
                INDEX   SPNDX
                ADS     CDUXCMD
                INDEX   SPNDX
                LXCH    EDRIVEX
                CCS     SPNDX
                TCF     DACLOOP
                CAF     13,14,15
                EXTEND
                WOR     CHAN14          # SET DAC ACTIVITY BITS
                TC      Q

REINIT          CAF     DELAY200        # ........TILT LOGIC
                TS      TIME5           # REINITIALIZE DAP IN 200MS
                TS      T5PHASE
                TCF     RESUME
DELAY200        DEC     16364           # 200MS

                DEC     -384

# Page 1013
DACLIMIT        DEC     16000
                DEC     384

# Page 1014
```

```
# INITIALIZATION PROGRAM FOR RCS-CSM AUTOPILOT
#
# THE FOLLOWING QUANTITIES WILL BE ZEROED AND SHOULD APPEAR IN CONSECUTIVE LOCATIONS IN MEMORY
#
#       WBODY   (+1)            DFT                     TAU2
#       WBODY1  (+1)            DFT1                    BIAS
#       WBODY2  (+1)            DFT2                    BIAS1
#       ADOT    (+1)            DRHO    (+1)            BIAS2
#       ADOT1   (+1)            DRHO1   (+1)            ERRORX
#       ADOT2   (+1)            DRHO2   (+1)            ERRORY
#       MERRORX (+1)            ATTSEC                  ERRORZ
#       MERRORY (+1)            TAU
#       MERRORZ (+1)            TAU1

FRESHDAP        CAF     ONE             # RESET HOLDFLAG TO STOP AUTOMATIC
                TS      HOLDFLAG        # STEERING AND PREPARE TO PICK UP AN
                                        # ATTITUDE HOLD REFERENCE

REDAP           TC      IBNKCALL        # DECODE DAPDATR1, DAPDATR2 FOR DEADBANDS
                CADR    S41.2           # RATES, QUADFAILS, QUAD MANAGEMENT

                TC      IBNKCALL        # DECODE IXX, IAVG, AND CONVERT
                CADR    S40.14          # TO AUTOPILOT GAINS

                CAF     NO.T5VAR        # NO. LOCATIONS TO BE ZEROED MINUS ONE
ZEROT5          TS      SPNDX           # ZERO ALL NECESSARY ERASABLE REGISTERS
                CAF     ZERO
                INDEX   SPNDX
                TS      WBODY
                CCS     SPNDX
                TCF     ZEROT5
                TCR     ZEROJET

                CS      ZERO
                TS      CHANTEMP        # INITIALIZE MINIMUM IMPULSE CONTROL

                TS      CH31TEMP        # INITIALIZE RHC POSITION MEMORY FOR
                                        # MANUAL RATE MODES

                CAF     =.24
                TS      SLOPE           # INITIALIZE SWITCHING LOGIC SLOPE

                CAF     FOUR
                TS      T5TIME          # PHASE 0 RESETS FOR PHASE 2 INTERRUPT IN
                                        # 60 MS.  PHASE 2 RESETS FOR PHASE 1 RUPT
                                        # IN (80MS - T5TIME(40MS)).  THEREFORE
```

```
                                        # PHASE 1 (RATEFILTER) BEGINS CYCLING 100
                                        # MS FROM NOW AND EVERY 100MS THEREAFTER.

                CAF     ELEVEN
                TS      ATTKALMN        # RESET TO PICK UP KALMAN FILTER TAINS
                                        # TO INITIALIZE THE S/C ANGULAR RATES
# Page 1015
                CA      CDUX
                TS      RHO
                CA      CDUY
                TS      RHO1
                CA      CDUZ
                TS      RHO2
                CAF     ZERO            # RESET AUTOPILOT TO BEGIN EXECUTING
                TS      T5PHASE         # PHASE2 OF PROGRAM

                CS      IMODES33        # CHECK IMU STATUS
                MASK    BIT6            # IF BIT6 = 0 IMU IN FINE ALIGN
                CCS     A               # IF BIT6 = 1 IMU NOT READY
                TCF     IMUAOK
                TS      ATTKALMN        # CANNOT USE IMU
                CAF     RCSINITB        # PROVIDE FREE CONTROL ONLY
                TCF     RCSSWIT         # DON'T START UP RATE FILTER
                                        # SIGNAL NO RATE FILTER

IMUAOK          CAF     PRIO34          # START MATRIX INITIALIZATION
                TC      NOVAC           # BYPASS IF IMU NOT IN FINE ALIGN
                EBANK=  KMPAC
                2CADR   AMBGUPDT

                CAF     RCSINIT         # CLEAR BIT14 --ASSUME WE HAVE A GOOD IMU
RCSSWIT         TS      RCSFLAGS        # CLEAR BIT1  --INITIALIZE T6 PROGRAM
                                        #   SET BIT3  --INITIALIZE NEEDLES
                                        # CLEAR BIT4  --RESET FOR FDAIDSP1
                CAF     T5WAIT60        # NEXT T5RUPT 60 MS FROM NOW TO ALLOW IMU
                                        # ERROR COUNTER TO ZERO.
                                        # (MINIMUM DELAY = 15 MS)
                TS      TIME5           # SINCE ATTKALMN IS +11, PROGRAM WILL THEN
                TC      RESUME          # PICK UP THE KALMAN FILTER GAINS.  RATE
                                        # FILTER WILL BEGIN OPERATING ZOOMS FROM
                                        # NOW

# CONSTANTS USED IN INITIALIZATION PROGRAM

NO.T5VAR        DEC     36
=.24            DEC     .24             # = SLOPE OF 0.6/SEC
```

```
RCSINIT         OCT     00004
RCSINITB        OCT     20004
T5WAIT60        DEC     16378           # = 6 CS
                EBANK=  KMPAC
T6ADDR          2CADR   T6START

ZEROJET         CAF     ELEVEN          # ZERO BLAST2, BLAST1, BLAST, YWORD2,
                TS      SPNDX           # YWORD1, PWORD2, PWORD1, RWORD2,
                CAF     ZERO            # AND RWORD1

# Page 1016
                INDEX   SPNDX
                TS      RWORD1
                CCS     SPNDX
                TCF     ZEROJET +1

                CAF     FOUR
                TS      BLAST1 +1
                CAF     ELEVEN
                TS      BLAST2 +1

                CS      BIT1
                MASK    RCSFLAGS
                TS      RCSFLAGS        # RESET BIT1 OF RCSFLAGS TO 0

                EXTEND
                DCA     T6ADDR
                DXCH    T6LOC
                CAF     =+14MS          # ENABLE T6RUPT TO SHUT OFF JETS IN 14 MS.
                TS      TIME6
                CAF     BIT15
                EXTEND
                WOR     CHAN13

                TC      Q

T5PHASE2        CCS     ATTKALMN        # IF (+) INITIALIZE RATE ESTIMATE
                TCF     KALUPDT

                TCF     +2              # ONLY IF ATTKALMN POSITIVE
                TCF     +1
                CA      DELTATT2        # RESET FOR PHASE3 IN 20 MS
                XCH     TIME5           # (JET SELECTION LOGIC)
                ADS     T5TIME          # TO COMPENSATE FOR DELAYS IN T5RUPT

                CA      RCSFLAGS        # IF A HIGH RATE AUTO MANEUVER IS IN
```

```
                MASK    BIT15           # PROGRESS (BIT 15 OF RCSFLAGS SET), SET
                EXTEND                  # ATTKALMN TO -1
                BZF     NOHIAUTO        # OTHERWISE SET ATTKALMN TO 0.
                CS      ONE
NOHIAUTO        TS      ATTKALMN

# Page 1017
# MANUAL ROTATION COMMANDS

                CS      OCT01760        # RESET FORCED FIRING BITS (BITS 10 TO 5
                MASK    RCSFLAGS        # OF RCSFLAGS) TO ZERO
                TS      RCSFLAGS

                EXTEND
                READ    CHAN31
                TS      L
                CA      CH31TEMP
                EXTEND
                RXOR    LCHAN
                MASK    MANROT          # = OCT00077
                EXTEND
                BZMF    NOCHANGE

                LXCH    A
                TS      CH31TEMP        # SAVE CONTENTS OF CHANNEL 31 IN CH31TEMP

                CA      L
                EXTEND
                MP      BIT5            # PUT BITS 6-1 OF A IN BITS 10-5 OF L
                CA      L
                ADS     RCSFLAGS        # SET FORCED FIRING BITS FOR AXES WITH
                                        # CHANGES IN COMMAND.  BITS 10,9 FOR
                                        # ROLL, BITS 8,7 FOR YAW, BITS 6,5 FOR
                                        # PITCH

                CS      RCSFLAGS        # SET RATE DAMPING FLAGS (BITS 13,12, AND
                MASK    OCT16000        # 11 OF RCSFLAGS)
                ADS     RCSFLAGS

NOCHANGE        CS      CH31TEMP
                MASK    MANROT
                EXTEND
                BZMF    AHFNOROT        # IF NO MANUAL COMMANDS, GO TO AHFNOROT

                TS      HOLDFLAG        # SET HOLDFLAG +
```

```
                TC      STICKCHK        # WHEN THE RHC IS OUT OF DETENT, PMANNDX,
                                        # YMANNDX, AND RMANNDX ARE ALL SET, BY
                                        # MEANS OF STICKCHK, TO 0, 1, OR 2 FOR NO,
                                        # +, OR - ROTATION RESPECTIVELY AS
                                        # COMMANDED BY THE RHC.
                                        #
                                        # HOWEVER, IT IS WELL TO NOTE THAT AFTER
                                        # THE RHC IS RETURNED TO DETENT, THE
                                        # PROGRAM BRANCHES TO AHFNOROT AND AVOIDS
                                        # STICKCHK SO PMANNDX, YMANNDX, AND
                                        # RMANNDX ARE NOT RESET TO ZERO BUT RATHER
                                        # LEFT SET TO THEIR LAST OUT OF DETENT
# Page 1018
                                        # VALUES.

                CS      FLAGWRD1        # SET STIKFLAG TO INFORM STEERING
                MASK    BIT14           # PROGRAMS (P20) THAT ASTRONAUT HAS
                ADS     FLAGWRD1        # ASSUMED ROTATIONAL CONTROL OF SPACECRAFT

                CAF     BIT14
                EXTEND
                RAND    CHAN31
                EXTEND
                BZMF    FREEFUNC

                CA      RCSFLAGS        # EXAMINE RCSFLAGS TO SEE IF RATE FILTER
                MASK    BIT14           # HAS BEEN INITIALIZED
                CCS     A               # IF SO, PROCEED WITH MANUAL RATE COMMANDS
                TCF     REINIT          # .....TILT, RECYCLE TO INITIALIZE FILTER

                CS      FIVE            # IF MANUAL MANEUVER IS AT HIGH RTE, SET
                AD      RATEINDX        # ATTKALMN TO -1.
                EXTEND                  # OTHERWISE, LEAVE ATTKALMN ALONE.
                BZMF    +3
                CS      ONE
                TS      ATTKALMN

                CAF     TWO             # AUTO-HOLD MANUAL ROTATION
SETWBODY        TS      SPNDX
                DOUBLE
                TS      DPNDX
                INDEX   SPNDX           # RMANNDX = 0 NO ROTATION
                CA      RMANNDX         #         = 1  + ROTATION
                EXTEND                  #         = 2  - ROTATION
                BZF     NORATE          # IF NO ROTATION COMMAND ON THIS AXIS,
                                        # GO TO NORATE.
```

```
                AD      RATEINDX        # RATEINDX = 0  0.05 DEG/SEC
                TS      Q               #          = 2  0.2  DEG/SEC
                INDEX   Q               #          = 4  0.5  DEG/SEC
                CA      MANTABLE -1     #          = 6  2.0  DEG/SEC
                EXTEND
                MP      BIT9            # MULTIPLY MANTABLE BY 2 TO THE -6
                INDEX   DPNDX           # TO GET COMMANDED RATE.
                DXCH    WBODY           # SET WBODY TO COMMANDED RATE.

                CA      RCSFLAGS
                MASK    OCT16000        # IS RATE DAMPING COMPLETED (BITS 13,12 AND
                EXTEND                  # 11 OF RCSFLAGS ALL ZERO.)  IF SO, GO TO
                BZF     MERUPDAT        # MERUPDAT TO UPDATE CUMULATIVE ATTITUDE
                                        # ERROR.

# Page 1019
ZEROER          CA      ZERO            # ZEROER ZEROS MERRORS
                ZL
                INDEX   DPNDX
                DXCH    MERRORX
                TCF     SPNDXCHK

NORATE          ZL
                INDEX   DPNDX
                DXCH    WBODY           # ZERO WBODY FOR THIS AXIS
                CA      RCSFLAGS
                MASK    OCT16000
                EXTEND                  # IS RATE DAMPING COMPLETED
                BZF     SPNDXCHK        # YES, KEEP CURRENT MERRORX GO TO SPNDXCHK
                TCF     ZEROER          # NO, GO TO ZEROER

MERUPDAT        INDEX   Q               # MERRORX=MERRORX+MEASURED CHANGE IN ANGLE
                CS      MANTABLE -1     # -COMMANDED CHANGE IN ANGLE
                EXTEND                  # THE ADDITION OF MEASURED CHANGE IN ANGLE
                MP      BIT7            # HAS ALREADY BEEN DONE IN THE RATE FILTER
                INDEX   DPNDX           # COMMANDED CHANGE IN ANGLE = WBODY TIMES
                DAS     MERRORX         # .1SEC = MANTABLE ENTRY TIMES 2 TO THE -8

SPNDXCHK        INDEX   DPNDX
                CA      MERRORX
                INDEX   SPNDX
                TS      ERRORX          # ERRORX = HIGH ORDER WORD OF MERRORX
                CCS     SPNDX
                TCF     SETWBODY
                TCF     JETS
```

```
OCT01760        OCT     01760           # FORCED FIRING BITS MASK

OCT01400        OCT     01400           # ROLL FORCED FIRING MASK       ORDER OF
OCT00060        OCT     00060           # PITCH FORCED FIRING MASK      DEFINITION
OCT00300        OCT     00300           # YAW FORCED FIRING MASK        MUST BE
                                        #                               PRESERVED
                                        #                               FOR INDEXING
MANROT          OCT     77
OCT16000        OCT     16000           # RATE DAMPING FLAGS MASK
MANTABLE        DEC     .0071111
                DEC     -.0071111
                DEC     .028444
                DEC     -0.028444
                DEC     .071111
                DEC     -.071111
                DEC     .284444
                DEC     -.284444
=+14MS          DEC     23
FREEFUNC        INDEX   RMANNDX         # ACCELERATION
# Page 1020
                CA      FREETAU         # COMMANDS
                TS      TAU
                INDEX   PMANNDX
                CA      FREETAU         # FREETAU       0 SEC
                TS      TAU1            # +1            +0.10 SEC
                INDEX   YMANNDX         # +2            -0.10 SEC
                CA      FREETAU         # (+3)          0 SEC
                TS      TAU2
                TCF     T6PROGM

FREETAU         DEC     0
                DEC     480
                DEC     -480
                DEC     0

T6PROGM         CAF     ZERO            # FOR MANUAL ROTATIONS
                TS      ERRORX
                TS      ERRORY
                TS      ERRORZ
                TCF     T6PROG

# Page 1021
                DEC     .2112           # FILTER GAIN FOR TRANSLATION, LEM ON
                DEC     .8400           # FILTER GAIN FOR TRANSLATION 2(ZETA)WN DT
                DEC     .2112           # FILTER GAIN FOR 4 DEGREE/SEC MANEUVERS
```

```
GAIN1           DEC     .0640           # KALMAN FILTER GAINS FOR INITIALIZATION
                DEC     .3180           # OF ATTITUDE RATES
                DEC     .3452
                DEC     .3774
                DEC     .4161
                DEC     .4634
                DEC     .5223
                DEC     .5970
                DEC     .6933
                DEC     .8151
                DEC     .9342

                DEC     .0174           # FILTER GAIN FOR TRANSLATION, LEM ON
                DEC     .3600           # FILTER GAIN FOR TRANSLATION (WN)(WN)DT
                DEC     .0174           # FILTER GAIN FOR 4 DEGREE/SEC MANEUVERS
GAIN2           DEC     .0016           # SCALED 10
                DEC     .0454
                DEC     .0545
                DEC     .0666
                DEC     .0832
                DEC     .1069
                DEC     .1422
                DEC     .1985
                DEC     .2955
                DEC     .4817
                DEC     .8683
STICKCHK        TS      T5TEMP
                MASK    THREE           # INDICES FOR MANUAL ROTATION
                TS      PMANNDX
                CA      T5TEMP
                EXTEND                  # MAN RATE  0   0 RATE (DP)
                MP      QUARTER         #          +1   + RATE (DP)
                TS      T5TEMP          #          +2   - RATE (DP)
                MASK    THREE           #         (+3)  0 RATE (DP)
                TS      YMANNDX
                CA      T5TEMP
                EXTEND
                MP      QUARTER
                TS      RMANNDX
                TC      Q
KALUPDT         TS      ATTKALMN        # INITIALIZATION OF ATTITUDE RATES USING
                                        # KALMAN FILTER TAKES 1.1 SEC

                CA      DELTATT         # =1SEC - 80MS
                AD      T5TIME          # + DELAYS
# Page 1022
```

```
                TS      TIME5
                TCF     +3
                CAF     DELTATT2        # SAFETY PLAY TO ASSURE
                TS      TIME5           # A T5RUPT

KRESUME2        CS      ZERO            # RESET FOR PHASE1
                TS      T5PHASE         # RESUME INTERRUPTED PROGRAM
                TCF     RESUME

FDAIDSP2        CS      BIT4            # RESET FOR FDAIDSP1
                MASK    RCSFLAGS
                TS      RCSFLAGS

                CS      FLAGWRD0        # ON - DISPLAY ONE OF THE TOTAL ATTITUDE
                MASK    BIT9            # ERRORS
                EXTEND
                BZF     FDAITOTL
                EXTEND
                DCS     ERRORX          # OFF - DISPLAY AUTOPILOT FOLLOWING ERROR
                DXCH    AK
                CS      ERRORZ
                TS      AK2
                TCF     RESUME          # END PHASE 1

FDAITOTL        CA      FLAGWRD9
                MASK    BIT6
                EXTEND
                BZF     WRTN17          # IS N22ORN17 (BIT6 OF FLAGWRD9) = 0
                                        # IF SO, GO TO WRTN17
WRTN22          EXTEND                  # OTHERWISE, CONTINUE ON TO WRTN22 AND
                DCA     CTHETA          # GET SET TO COMPUTE TOTAL ATTITUDE
                DXCH    WTEMP           # ERROR WRT N22 BY PICKING UP THE THREE
                CA      CPHI            # COMPONENTS OF N22

GETAKS          EXTEND                  # COMPUTE TOTAL ATTITUDE ERROR FOR
                MSU     CDUX            # DISPLAY ON FDAI ERROR NEEDLES
                TS      AK
                CA      WTEMP
                EXTEND
                MSU     CDUY
                TS      T5TEMP
                EXTEND
                MP      AMGB1
                ADS     AK
                CA      T5TEMP
                EXTEND
```

```
                MP      AMGB4
# Page 1023
                TS      AK1
                CA      T5TEMP
                EXTEND
                MP      AMGB7
                TS      AK2
                CA      WTEMP +1
                EXTEND
                MSU     CDUZ
                TS      T5TEMP
                EXTEND
                MP      AMGB5
                ADS     AK1
                CA      T5TEMP
                EXTEND
                MP      AMGB8
                ADS     AK2
                TCF     RESUME          # END PHASE1 OF RCS DAP

WRTN17          EXTEND                  # GET SET TO COMPUTE TOTAL ASTRONAUT
                DCA     CPHIX +1        # ATTITUDE ERROR WRT N17 BY PICKING UP
                DXCH    WTEMP           # THE THREE COMPONENTS OF N17
                CA      CPHIX
                TCF     GETAKS

# Page 1024 (empty page)
```

Uses A 80, ADOT 209, ADOT1 209, ADOT2 209, AK 200, AK1 200, AK2 200, AMGB1 211, AMGB4 211, AMGB5 213, AMGB7 213, AMGB8 213, ATTKALMN 211, ATTSEC 211, BANKRUPT 80, BIAS 211, BIAS1 211, BIAS2 211, BLAST 200, BLAST1 200, BLAST2 200, CDUS 80, CDUX 80, CDUXCMD 80, CDUXD 213, CDUY 80, CDUYCMD 80, CDUYD 213, CDUZ 80, CDUZCMD 85, CDUZD 213, CH31TEMP 211, CHAN12 87, CHAN13 87, CHAN14 87, CHAN31 87, CHANTEMP 211, COMMAND 169, COUNT 142, CPHI 157, CPHIX 163, CTHETA 157, D 226, DAPDATR1 200, DAPDATR2 200, DAPS3 63, DELCDUX 211, DELCDUY 211, DELCDUZ 211, DELTEMPX 209, DELTEMPY 209, DELTEMPZ 209, DFT 209, DFT1 209, DFT2 209, DISPLAYS 59, DPNDX 209, DRHO 209, DRHO1 209, DRHO2 211, EBANK 80, EDRIVEX 200, EDRIVEY 200, EDRIVEZ 202, ERRORX 211, ERRORY 211, ERRORZ 211, FLAGWRD0 95, FLAGWRD1 97, HOLDFLAG 163, I 206, IAVG 200, IMODES33 163, IT 185, IXX 200, KMJ 211, KMPAC 209, L 80, LCHAN 87, MERRORX 209, MERRORY 209, MERRORZ 209, MODE 145, N 206, N22ORN17 131, PHASE1 152, PHASE2 152, PHASE3 152, PMANNDX 213, PWORD1 200, PWORD2 200, Q 80, QRUPT 80, RATEINDX 157, RCSFLAGS 200, RESTART 57, RHO 211, RHO1 211, RHO2 211, RMANNDX 213, RTE 67, RWORD1 200, RWORD2 200, SAVE 191, SLOPE 213, SPNDX 209, STIKFLAG 99, T5LOC 163, T5PHASE 200, T5TEMP 200, T5TIME 211, T6LOC 163, TAU 211, TAU1 211, TAU2 211, TC 169, THETA 148, THETADX 211, THETADY 211, THETADZ 211, TIME5 80, TIME6 80, WBODY 209, WBODY1 209, WBODY2 209, WTEMP 209, YMANNDX 213, YWORD1 200, and YWORD2 200.

3.6.10 automatic maneuvers

1433 ⟨*automatic maneuvers* 1433⟩≡ (1346c)

⟨*Page CM1025* 1434⟩
⟨*Page CM1026* 1435⟩
⟨*Page CM1027* 1436⟩
⟨*Page CM1028* 1438⟩
⟨*Page CM1029* 1439⟩
⟨*Page CM1030* 1441⟩
⟨*Page CM1031* 1443⟩
⟨*Page CM1032* 1445⟩
⟨*Page CM1033* 1447⟩
⟨*Page CM1034* 1448⟩
⟨*Page CM1035* 1449⟩
⟨*Page CM1036* 1450a⟩

1434 ⟨*Page CM1025* 1434⟩≡ (1433 2653)

```
                BANK    21
                SETLOC  DAPS3
                BANK

                COUNT   21/DAPAM

                EBANK=  KMPAC
AHFNOROT        EXTEND
                READ    CHAN31
                MASK    BIT14
                EXTEND
                BZMF    FREECONT
                CA      RCSFLAGS        # SEE IF RATE FILTER HAS BEEN INITIALIZED
                MASK    BIT14
                CCS     A               # IF SO, PROCEED WITH ATTITUDE CONTROL
                TCF     REINIT          # IF NOT, RECYCLE TO INITIALIZE FILTER
                                        # AUTOMATIC CONTROL YET
                EXTEND
                READ    CHAN31
                MASK    BIT13
                EXTEND
                BZMF    HOLDFUNC

AUTOCONT        CA      HOLDFLAG        # IF HOLDFLAG IS +, GO TO GRABANG.
                EXTEND                  # OTHERWISE, GO TO ATTHOLD.
                BZMF    ATTHOLD
                TCF     GRABANG

# MINIMUM IMPULSE CONTROL

FREECONT        CAF     ONE
                TS      HOLDFLAG        # RESET HOLDFLAG
                                        # INHIBIT AUTOMATIC STEERING
                EXTEND
                READ    CHAN32
                TS      L
                COM
                MASK    MANROT
                MASK    CHANTEMP
                LXCH    CHANTEMP
                TC      STICKCHK
                INDEX   RMANNDX
                CA      MINTAU          # MINTAU        +0
                TS      TAU             #               +1      +14MS MINIMUM IMPULSE
                INDEX   PMANNDX         #               +2      -14MS TIME
```

```
                CA      MINTAU          #               +3      +0
                TS      TAU1
                INDEX   YMANNDX
                CA      MINTAU
```

Uses A 80, CHAN31 87, CHAN32 87, CHANTEMP 211, COUNT 142, DAPS3 63, EBANK 80, HOLDFLAG 163, KMPAC 209, L 80, PMANNDX 213, RCSFLAGS 200, RMANNDX 213, TAU 211, TAU1 211, TC 169, and YMANNDX 213.

1435 ⟨*Page CM1026* 1435⟩≡ (1433 2653)

```
                TS      TAU2
                TCF     T6PROGM

MINTAU          DEC     0
                DEC     23              # = 14MS
                DEC     -23             # = -14MS
                DEC     0
```

Uses TAU2 211.

1436 ⟨*Page CM1027* 1436⟩≡ (1433 2653)

```
# CALCULATION OF ATTITUDE ERRORS:
#       _    *     _      _          _
#       AK = AMGB (CDUX - THETADX) + BIAS
#
# I.E., *AK *   * 1        SIN(PSI)        0    ** CDUX - THETADX *    *BIAS *
#       *   *   *                                **                *    *     *
#       *AK1* = * 0   COS(PSI)COS(PHI)  SIN(PHI)** CDUY - THETADY *  + *BIAS1*
#       *   *   *                                **                *    *     *
#       *AK2*   * 0  -COS(PSI)SIN(PHI)  COS(PHI)** CDUZ - THETADZ *    *BIAS2*
#
# THE BIASES ARE ADDED ONLY WHILE PERFORMING AUTOMATIC MANEUVERS (ESP KALCMANU) TO PR
# AND PREVENT OVERSHOOT WHEN STARTING AN AUTOMATIC MANEUVER.  NORMALLY THE REQUIRED I
# BUT DURING HIGH RATE MANEUVERS IT CAN BE AS MUCH AS 7 DEGREES.  THE BIASES ARE COMP
# FIXED UNTIL THE MANEUVER IS COMPLETED AT WHICH TIME THEY ARE RESET TO ZERO.

ATTHOLD         CA      CDUX
                EXTEND
                MSU     THETADX
                TS      ERRORX
                CA      CDUY
                EXTEND
                MSU     THETADY
                TS      T5TEMP
                EXTEND
                MP      AMGB1
                ADS     ERRORX
                CA      T5TEMP
                EXTEND
                MP      AMGB4
                TS      ERRORY
                CA      T5TEMP
                EXTEND
                MP      AMGB7
                TS      ERRORZ
                CA      CDUZ
                EXTEND
                MSU     THETADZ
                TS      T5TEMP
                EXTEND
                MP      AMGB5
                ADS     ERRORY
                CA      T5TEMP
                EXTEND
                MP      AMGB8
                ADS     ERRORZ
```

```
CS      HOLDFLAG
EXTEND
```

Uses AK 200, AK1 200, AK2 200, AMGB1 211, AMGB4 211, AMGB5 213, AMGB7 213, AMGB8 213, BIAS 211, BIAS1 211, BIAS2 211, CDUX 80, CDUY 80, CDUZ 80, ERRORX 211, ERRORY 211, ERRORZ 211, HOLDFLAG 163, I 206, IT 185, T5TEMP 200, THETADX 211, THETADY 211, and THETADZ 211.

1438 ⟨*Page CM1028* 1438⟩≡ (1433 2653)

```
                BZMF    JETS
                CA      BIAS            # AD BIASES ONLY IF PERFORMING AUTOMATIC
                ADS     ERRORX
                CA      BIAS1
                ADS     ERRORY
                CA      BIAS2
                ADS     ERRORZ
                TCF     JETS

HOLDFUNC        CCS     HOLDFLAG
                TCF     +3
                TCF     ATTHOLD
                TCF     +1
GRABANG         CAF     ZERO            # ZERO WBODYS AND BIASES
                TS      WBODY
                TS      WBODY +1
                TS      WBODY1
                TS      WBODY1 +1
                TS      WBODY2
                TS      WBODY2 +1
                TS      BIAS
                TS      BIAS1
                TS      BIAS2

                CA      RCSFLAGS
                MASK    OCT16000
                EXTEND                  # IS RATE DAMPING COMPLETED
                BZF     ENDDAMP         # IF SO, GO TO ENDDAMP
                CAF     ZERO            # OTHERWISE, ZERO ERRORS
                TS      ERRORX
                TS      ERRORY
                TS      ERRORZ
                TCF     JETS

ENDDAMP         TS      HOLDFLAG        # SET HOLDFLAG +0
                EXTEND
                DCA     CDUX            # PICK UP CDU ANGLES FOR ATTITUDE HOLD
                DXCH    THETADX         # REFERENCES
                CA      CDUZ
                TS      THETADZ
                TCF     ATTHOLD
```

Uses BIAS 211, BIAS1 211, BIAS2 211, CDUX 80, CDUZ 80, ERRORX 211, ERRORY 211, ERRORZ 211, HOLDFLAG 163, RCSFLAGS 200, THETADX 211, THETADZ 211, WBODY 209, WBODY1 209, and WBODY2 209.

1439 ⟨*Page CM1029* 1439⟩≡ (1433 2653)

```
# JET SWITCHING LOGIC AND CALCULATION OF REQUIRED ROTATION COMMANDS
#
# DETERMINE THE LOCATION OF THE RATE ERROR AND THE ATTITUDE ERROR RELATIVE TO THE SWITCHING LOG
# PLANE.
#
# COMPUTE THE CHANGE IN RATE CORRESPONDING TO THE ATTITUDE ERROR NECESSARY TO DRIVE THE S/C INT
# APPROPRIATE DEADZONE.
#
#                                   .
#   R22                        RATE . ERROR
#        WL+H                       .
# ********************************   .                                ***** SWITCH LINES ENCL
#   R23  WL                       *  .
# ---------------------------------* .                                ----- DESIRED RATE LINE
#   R23  WL-H       -               *.
# ***************** -                .                                R20, R21, R22, ETC REGI
#                  * -               .* R18      R20       R21        PLANE FOF COMPUTING DES
#                   *                . *
#                    *-              .  *
#   R22            R24*-    R23      .   *
#                      *             .    *
#                       *            .     *
#                        + -ADB      .      * AF              ATTITUDE
#  .......................+--+---------------+--+.......................
#                          AF *      .     +ADB  +             ERROR
#                              *     .            *
#                               *    .            -*
#                                *   .             -*
#                                 *  .              -*
#                                  * .                *
#                                   *.               - *
#                                    .                - ****************
#                                    .*-
#                                    . * --------------------------------
#                                    .
#                                    .
#                       FIG. 1  PHASE PLANE SWITCHING LOGIC
#
# CONSTANTS FOR JET SWITCHING LOGIC

WLH/SLOP        DEC     .00463          # = WL+H/SLOPE = .83333 DEG     $180
WL-H/SLP        DEC     .00277          # = WL-H/SLOPE = .5 DEG         $180
WLH             2DEC    .0011111111     # = WL+H = 0.5 DEG/SEC          $450

WLMH            2DEC    .0006666666     # = WL-H = 0.3 DEG/SEC          $450
```

```
WL              2DEC    .0008888888     # = WL   = 0.4 DEG/SEC          $450
```

Uses ADB 213, H 177, and SLOPE 213.

1441 ⟨*Page CM1030* 1441⟩≡ (1433 2653)

```
SLOPE2          DEC     .32             # = 0.8 DEG/SEC/DEG             $450/180
JETS            CA      ADB
                AD      FOUR            # AF = FLAT REGION = .044 DEG
                TS      T5TEMP          # ADB+AF
                CAF     TWO
JLOOP           TS      SPNDX
                DOUBLE
                TS      DPNDX
                EXTEND
                INDEX   A
                DCA     ADOT
                DXCH    EDOT
                CA      HOLDFLAG        # HOLDFLAG = +0 MEANS THAT DAP IS IN
                EXTEND                  # ATTITUDE HOLD AND RATE DAMPING IS OVER.
                BZF     INHOLD          # IF THIS IS THE CASE, BYPASS ADDITION
                                        # OF WBODY AND GO TO INHOLD
                EXTEND
                INDEX   DPNDX
                DCS     WBODY
                DAS     EDOT            # = ADOT-WBODY
INHOLD          INDEX   SPNDX
                CA      ERRORX
                TS      AERR            # AERR = BIAS + AK

                CCS     EDOT
                TCF     POSVEL
                TCF     SIGNCK1
                TCF     NEGVEL
SIGNCK1         CCS     EDOT +1
                TCF     POSVEL
                TCF     POSVEL
                TCF     NEGVEL
                TCF     NEGVEL
POSVEL          EXTEND
                DCA     EDOT
                DXCH    EDOTVEL
                CA      T5TEMP
                TS      ADBVEL          # +(ADB+AF)
                CA      AERR
                TS      AERRVEL
                TC      J6.
NEGVEL          EXTEND
                DCS     EDOT
                DXCH    EDOTVEL
                CS      T5TEMP
```

```
                TS      ADBVEL          # -(ADB+AF)
                CS      AERR
                TS      AERRVEL

J6.             EXTEND
```

Uses A 80, ADB 213, ADBVEL 209, ADOT 209, AERR 209, AERRVEL 209, AK 200, BIAS 211, DPNDX 209, EDOT 209, EDOTVEL 209, ERRORX 211, HOLDFLAG 163, SPNDX 209, T5TEMP 200, TC 169, and WBODY 209.

1443 ⟨*Page CM1031* 1443⟩≡ (1433 2653)

```
                SU      ADB
                AD      WLH/SLOP
                EXTEND
                BZMF    J8

                CS      T5TEMP          # (ADB+AF)
                AD      AERRVEL
                EXTEND
                BZMF    +2
                TCF     J7
                EXTEND
                DCS     EDOTVEL
                EXTEND
                DV      SLOPE
                EXTEND
                SU      AERRVEL
                AD      ADB
                EXTEND
                BZMF    J18
                TCF     J23

J7              CS      WL-H/SLP
                EXTEND
                SU      T5TEMP          # (ADB+AF)
                AD      AERRVEL
                EXTEND
                BZMF    J20
                TCF     J21

J8              EXTEND
                DCS     WLH
                DXCH    WTEMP
                EXTEND
                DCA     EDOTVEL
                DAS     WTEMP
                CCS     WTEMP
                TCF     J22
                TCF     SIGNCK2
                TCF     NJ22
SIGNCK2         CCS     WTEMP +1
                TCF     J22
                TCF     J22
                TCF     NJ22

NJ22            EXTEND
```

```
DCA     EDOTVEL
EXTEND
DV      SLOPE
AD      T5TEMP          # (ADB+AF)
AD      AERRVEL
```

Uses ADB 213, AERRVEL 209, DV 241, EDOTVEL 209, H 177, SLOPE 213, T5TEMP 200, and WTEMP 209.

1445 ⟨*Page CM1032* 1445⟩≡ (1433 2653)

```
                CCS     A
                TCF     J23
                TCF     J23
                TCF     +2
                TCF     J23

                EXTEND
                DCS     WLMH            # WL - H
                DXCH    WTEMP
                EXTEND
                DCA     EDOTVEL
                DAS     WTEMP
                CCS     WTEMP
                TCF     J23
                TCF     SIGNCK3
                TCF     NJ23
SIGNCK3         CCS     WTEMP +1
                TCF     J23
                TCF     J23
                TCF     NJ23

NJ23            CA      AERRVEL
                AD      T5TEMP          # (ADB+AF)
                AD      WL-H/SLP
                CCS     A
                TCF     J24
                TCF     J24
                TCF     J22
                TCF     J22

J18             EXTEND
                DCS     EDOT
                DXCH    KMPAC
                TCF     JTIME

J20             CS      AERR
                AD      ADBVEL
                EXTEND
                MP      SLOPE2          # (HYSTERESIS SLOPE)
                DXCH    KMPAC
                EXTEND
                DCS     EDOT
                DAS     KMPAC
                TCF     JTIME
```

```
J21             CCS     EDOT
                TCF     JP
                TCF     SIGNCK4
                TCF     JN
SIGNCK4         CCS     EDOT +1
```

Uses A 80, ADB 213, ADBVEL 209, AERR 209, AERRVEL 209, EDOT 209, EDOTVEL 209, H 177, KMPAC 209, SLOPE 213, T5TEMP 200, and WTEMP 209.

1447 ⟨*Page CM1033* 1447⟩≡ (1433 2653)

```
                TCF     JP
                TCF     JP
                TCF     JN
JN              EXTEND
                DCS     EDOT
                DXCH    KMPAC
                EXTEND
                DCA     WL
                DAS     KMPAC
                TCF     JTIME

JP              EXTEND
                DCS     EDOT
                DXCH    KMPAC
                EXTEND
                DCS     WL
                DAS     KMPAC
                TCF     JTIME

J22             CCS     EDOT
                TCF     JN
                TCF     SIGNCK5
                TCF     JP
SIGNCK5         CCS     EDOT +1
                TCF     JN
                TCF     JN
                TCF     JP
                TCF     JP

J23             INDEX   SPNDX
                CS      BIT13           # RESET RATE DAMPING FLAG
                MASK    RCSFLAGS        # BIT13 FOR ROLL  (SPNDX = 0)
                TS      RCSFLAGS        # BIT12 FOR PITCH (SPNDX = 1)
                                        # BIT11 FOR YAW   (SPNDX = 2)

                INDEX   SPNDX
                CAF     OCT01400        # IS THERE TO BE A FORCED FIRING ON THIS
                MASK    RCSFLAGS        # AXIS
                EXTEND
                BZF     DOJET +2        # NO, GO TO DOJET +2 AND DO NOTHING

                TCF     J18             # YES, GO TO J18 AND FORCE A FIRING

J24             CS      AERR
                EXTEND
```

```
SU      ADBVEL
EXTEND
MP      SLOPE2          # (HYSTERESIS SLOPE)
DXCH    KMPAC
EXTEND
```

Uses A 80, ADBVEL 209, AERR 209, EDOT 209, KMPAC 209, RCSFLAGS 200, SLOPE 213, and SPNDX 209.

1448 ⟨*Page CM1034* 1448⟩≡ (1433 2653)

```
DCS     EDOT
DAS     KMPAC
```

Uses EDOT 209 and KMPAC 209.

1449 ⟨*Page CM1035* 1449⟩≡ (1433 2653)

```
# COMPUTE THE JET ON TIME NECESSARY TO ACCOMPLISH THE DESIRED CHANGE IN RATE, I.E.,
#
#            T  = J/M(DELTA W)
#             J
#
#       DELTA W = DESIRED CHANGE IN S/C ANGULAR RATE AS DETERMINED BY THE
#                 SWITCHING LOGIC, AT THIS POINT STORED IN KMPAC.
#
#           J/M = S/C INERTIA TO TORQUE RATIO SCALED BY
#                       (57.3/450)(B24/1600)(1/.8)
#                 FOR 1 JET OPERATION  (M = 700 FT-LB).
#                 I.E., J/M = J(SLUG-FTFT) x 0.00000085601606
#
#                 THE CORRESPONDING COMPUTER VARIABLES ESTABLISHED BY
#                 KEYBOARD ENTRY ARE
#                       J/M  (ROLL)
#                       J/M1 (PITCH)
#                       J/M2 (YAW)
#
#            T  = JET-ON TIME    SCALED 16384/1600 SEC
#             J
#
#                 THE COMPUTER VARIABLES ARE
#                       TAU  (ROLL)
#                       TAU1 (PITCH)
#                       TAU2 (YAW)

JTIME           INDEX   SPNDX           # PICK UP S/C INERTIA/TORQUE RATIO
                CA      J/M             # SCALED (57.3/450)(B24/1600)
                TC      SMALLMP         # FOR 1-JET OPERATION
                CA      BIT11
                TC      SMALLMP
                CCS     KMPAC
                TCF     +4
                TCF     TAUNORM
                TCF     +4
                TCF     TAUNORM
                CA      POSMAX
                TCF     DOJET
                CA      NEGMAX
                TCF     DOJET

TAUNORM         CA      KMPAC +1
DOJET           INDEX   SPNDX
                TS      TAU
```

```
                CCS     SPNDX
                TCF     JLOOP
                TCF     T6PROG
```

Uses COMPUTER 115, I 206, J/M 211, J/M1 211, J/M2 211, KMPAC 209, SPNDX 209, TAU 211, TAU1 211, TAU2 211, TC 169, and W 183.

1450a ⟨*Page CM1036* 1450a⟩≡ (1433 2653)

```
ZEROCMDS        CAF     ZERO
                TS      TAU
                TS      TAU1
                TS      TAU2
T6PROG          EXTEND                  # WHEN THE ROTATION COMMANDS (TAUS)
                DCA     JETADDR         # HAVE BEEN DETERMINED
                DXCH    T5LOC           # RESET T5LOC FOR PHASE3
                TCF     RESUME

                EBANK=  KMPAC
JETADDR         2CADR   JETSLECT
```

Uses EBANK 80, KMPAC 209, PHASE3 152, T5LOC 163, TAU 211, TAU1 211, and TAU2 211.

3.6.11 rcs-csm dap executive programs

1450b ⟨*rcs-csm dap executive programs* 1450b⟩≡ (1346c 2790)
⟨*Page CM1037* 1451⟩

1451 ⟨*Page CM1037* 1451⟩≡ (1450b)

```
# Page 1037
# CALCULATION OF  AMGB, AMBG  ONCE EVERY SECOND
#
#       AMGB =  1       SIN(PSI)                0
#               0       COS(PSI)COS(PHI)        SIN(PHI)
#               0       -COS(PSI)SIN(PHI)       COS(PHI)
#
#       AMBG =  1       -TAN(PSI)COS(PHI)       TAN(PSI)SIN(PHI)
#               0       COS(PHI)/COS(PSI)       -SIN(PHI)/COS(PSI)
#               0       SIN(PHI)                COS(PHI)
#
# WHERE PHI AND PSI ARE CDU ANGLES

                BANK    20
                SETLOC  DAPS8
                BANK

                COUNT*  $$/DAPEX
                EBANK=  KMPAC
AMBGUPDT        CA      FLAGWRD6        # CHECK FOR RCS AUTOPILOT
                EXTEND
                BZMF    ENDOFJOB        # BIT15 = 0, BIT14 = 1
                MASK    BIT14           # IF NOT RCS, EXIT
                EXTEND
                BZF     ENDOFJOB        # TO PROTECT TVC DAP ON SWITCHOVER

                CA      CDUZ
                TC      SPSIN2
                TS      AMGB1           # CALCULATE AMGB
                CA      CDUZ
                TC      SPCOS2
                TS      CAPSI           # MUST CHECK FOR GIMBAL LOCK
                CAF     QUADANGL        # = 7.25  DEGREES JET QUAD ANGULAR OFFSET
                EXTEND
                MSU     CDUX
                COM                     # CDUX - 7.25 DEG
                TC      SPCOS1
                TS      AMGB8
                EXTEND
                MP      CAPSI
                TS      AMGB4
                CAF     QUADANGL
                EXTEND
                MSU     CDUX
                COM                     # CDUX - 7.25 DEG
```

```
                TC      SPSIN1
                TS      AMGB5
                EXTEND
                MP      CAPSI
                COM
# Page 1038
                TS      AMGB7
                TCF     ENDOFJOB
QUADANGL        DEC     660             # = 7.25 DEGREES
```

Uses AMGB1 211, AMGB4 211, AMGB5 213, AMGB7 213, AMGB8 213, CAPSI 213, CDUX 80, CDUZ 80, COUNT 142, DAPS8 63, EBANK 80, FLAGWRD6 117, KMPAC 209, and TC 169.

3.6.12 jet selection logic

1452 ⟨*jet selection logic* 1452⟩≡ (1346c)

⟨*Page CM1039* 1453⟩
⟨*Page CM1040* 1455⟩
⟨*Page CM1041* 1456⟩
⟨*Page CM1042* 1457⟩
⟨*Page CM1043* 1458⟩
⟨*Page CM1044* 1460⟩
⟨*Page CM1045* 1461⟩
⟨*Page CM1046* 1462⟩
⟨*Page CM1047* 1463⟩
⟨*Page CM1048* 1464⟩
⟨*Page CM1049* 1465⟩
⟨*Page CM1050* 1466⟩
⟨*Page CM1051* 1467⟩
⟨*Page CM1052* 1468⟩
⟨*Page CM1053* 1469⟩
⟨*Page CM1054* 1470a⟩
⟨*Page CM1055* 1470b⟩
⟨*Page CM1056* 1471⟩
⟨*Page CM1057* 1473⟩
⟨*Page CM1058* 1474⟩
⟨*Page CM1059* 1475⟩
⟨*Page CM1060* 1476⟩
⟨*Page CM1061* 1477⟩
⟨*Page CM1062* 1479⟩

1453 ⟨*Page CM1039* 1453⟩≡ (1452 2729)

```
                BANK    21
                SETLOC  DAPS4
                BANK

                COUNT   17/DAPJS

                EBANK=  KMPAC

  # EXAMINE CHANNEL 31 FOR TRANSLATION COMMANDS

  JETSLECT      LXCH    BANKRUPT
                CAF     DELTATT3        # = 60 MS  RESET TO EXECUTIVE PHASE1
                AD      T5TIME
                TS      TIME5
                TCF     +3
                CAF     DELATT20        # = 20 MS  TO ASSURE A T5RUPT
                TS      TIME5
                CAF     =14MS           # RESET T6 TO INITIALIZE THE JET CHANNELS
                TS      TIME6           # IN 14 MS
                CAF     NEGMAX
                EXTEND
                WOR     CHAN13
                EXTEND
                QXCH    QRUPT
                CAF     XLNMASK         # = 7700 OCT
                EXTEND                  # EXAMINE THE TRANSLATION
                RXOR    CHAN31          # HAND CONTROLLER
                MASK    XLNMASK
                EXTEND
                BZF     NOXLNCMD
                TS      T5TEMP
                EXTEND
                MP      BIT9
                MASK    THREE
                TS      XNDX1           # AC QUAD  X-TRANSLATION INDEX
                TS      XNDX2           # BD QUAD  X-TRANSLATION INDEX
                CA      T5TEMP
                EXTEND                  # 1 = + XLN
                MP      BIT7            # 2 = - XLN
                MASK    THREE           # 3 = NO XLN
                TS      YNDX            # Y-TRANSLATION INDEX

                CA      T5TEMP
                EXTEND
                MP      BIT5
```

```
MASK    THREE
TS      ZNDX            # Z-TRANSLATION INDEX

CA      DAPDATR1        # SET ATTKALMN TO PICK UP FILTER GAINS FOR
MASK    BIT14           # TRANSLATIONS.
EXTEND                  # CHECK DAPDATR1 BIT 14 FOR LEM ATTACHED.
```

Uses A 80, ATTKALMN 211, BANKRUPT 80, CHAN13 87, CHAN31 87, COUNT 142, DAPDATR1 200, DAPS4 63, EBANK 80, KMPAC 209, PHASE1 152, QRUPT 80, T5TEMP 200, T5TIME 211, TIME5 80, TIME6 80, XNDX1 209, XNDX2 209, YNDX 209, Z 80, and ZNDX 209.

1455 ⟨*Page CM1040* 1455⟩≡ (1452 2729)

```
                BZF     NOLEM
                CS      THREE           # IF LEM IS ON, SET ATTKALMN = -3
                TCF     +2
NOLEM           CS      TWO             # IF LEM IS OFF, SET ATTKALMN = -2.
                TS      ATTKALMN
                CCS     XTRANS          # (+, -1, 0)
                TS      XNDX1           # USING BD-X  ZERO XNDX1
                TCF     PWORD
                TS      XNDX2           # USING AC-X  ZERO XNDX2
                TCF     PWORD
XLNMASK         OCT     7700

DELTATT3        DEC     16378           # = 60 MS
DELATT20        DEC     16382           # = 20 MS

NOXLNCMD        TS      XNDX1           # ZERO ALL REQUESTS FOR TRANSLATION
                TS      XNDX2
                TS      YNDX
                TS      ZNDX

# PITCH COMMANDS  TIMING(NO X-TRANS, NO QUAD FAILS) 32MCT

PWORD           CCS     TAU1            # CHECK FOR PITCH COMMANDS
                CAF     ONE
                TCF     +2              #  0 = NO PITCH
                CAF     TWO             # +1 =  + PITCH
                TS      PINDEX          # +2 =  - PITCH

                CCS     RACFAIL         # FLAG FOR REAL AC QUAD FAILURES
                TCF     AFAILP
                TCF     TABPCOM         # 0 = NO REAL AC FAILURES
                TCF     CFAILP          # + = A QUAD FAILED
                TCF     TABPCOM         # - = C QUAD FAILED
                                        # IF FAILURES ARE PRESENT IGNORE
                                        # X-TRANSLATIONS ON THIS AXIS

AFAILP          CAF     NINE            # IF FAILURE IS PRESENT 1JET OPERATION
                TCF     TABPCOM +2      # IS ASSUMED.  IGNORE X-TRANSLATION
CFAILP          CAF     TWELVE
                TCF     TABPCOM +2

XLNNDX          DEC     0               # INDICES FOR TRANSLATION COMMANDS
                DEC     3               # FOR USE IN TABLE LOOK UP
                DEC     6
                DEC     0
```

```
TWELVE          =       OCT14

# TABLE LOOK UP FOR PITCH COMMANDS WITH AND WITHOUT X-TRANSLATION AND AC QUAD FAILURE
# BITS 9, 10 CONTAIN THE NUMBER OF PITCH JETS USED TO PERFORM THE PITCH ROTATION
```

Uses A 80, ATTKALMN 211, PINDEX 209, RACFAIL 211, TAU1 211, XNDX1 209, XNDX2 209, XTRANS 211, YNDX 209, and ZNDX 209.

1456 ⟨*Page CM1041* 1456⟩≡ (1452 2729)

```
TABPCOM         INDEX   XNDX1
                CA      XLNNDX
                AD      PINDEX
                INDEX   A
                CA      PYTABLE
                MASK    PJETS           # =1417 OCT
                TS      PWORD1
                EXTEND
                MP      BIT7
                TS      NPJETS          # = NO. OF PITCH JETS

# YAW JET COMMANDS  TIMING(N X-TRANS, NO QUAD FAILURES)  32MCT

YWORD           CCS     TAU2            # CHECK FOR YAW COMMANDS
                CAF     ONE
                TCF     +2
                CAF     TWO
                TS      YINDEX          # YAW ROTATION INDEX

                CCS     RBDFAIL         # FLAG FOR B OR D QUAD FAILURES
                TCF     BFAILY          # 0 = NO BD FAILURE
                TCF     TABYCOM         # + - B QUAD FAILED
                TCF     DFAILY          # - = D QUAD FAILED
                TCF     TABYCOM

BFAILY          CAF     NINE
                TCF     TABYCOM +2
DFAILY          CAF     TWELVE
                TCF     TABYCOM +2
```

Uses A 80, D 226, N 206, NPJETS 209, PINDEX 209, PWORD1 200, RBDFAIL 211, TAU2 211, XNDX1 209, and YINDEX 209.

1457 ⟨*Page CM1042* 1457⟩≡ (1452 2729)

```
# TABLE FOR PITCH(YAW) COMMANDS
# BITS 4,3,2,1 = PITCH, X-TRANSLATION JETS SELECTED
# BITS    10,9 = NO. PITCH JETS USED TO PERFORM ROTATION
# BITS 8,7,6,5 = YAW, X-TRANSLATION JETS SELECTED
# BITS 12,11:  NO. YAW JETS USED TO PERFORM ROTATION

                                        # ROT   TRANS   QUAD    BIAS
PYTABLE         OCT     0               # 0     0               0
                OCT     5125            # +     0               0
                OCT     5252            # -     0               0
                OCT     0231            # 0     +               3
                OCT     2421            # +     +               3
                OCT     2610            # -     +               3
                OCT     0146            # 0     -               6
                OCT     2504            # +     -               6
                OCT     2442            # -     -               6
                OCT     0               # 0             A(B)    9
                OCT     2421            # +             A(B)    9
                OCT     2442            # -             A(B)    9
                OCT     0               # 0             C(D)    12
                OCT     2504            # +             C(D)    12
                OCT     2610            # -             C(D)    12

# MASKS FOR PITCH AND YAW COMMANDS

PJETS           OCT     1417
YJETS           OCT     6360

# TABLE LOOK UP FOR YAW COMMANDS WITH AND WITHOUT X-TRANSLATION AND AC QUAD FAILURES PRESENT
# BITS 11, 12 CONTAIN THE NUMBER OF YAW JETS USED TO PERFORM THE YAW ROTATION

TABYCOM         INDEX   XNDX2
                CA      XLNNDX
                AD      YINDEX
                INDEX   A
                CA      PYTABLE
                MASK    YJETS           # = 6360 OCT
                TS      YWORD1
                EXTEND
                MP      BIT5
                TS      NYJETS          # NO. OF YAW JETS USED TO PERFORM ROTATION
```

Uses `A` 80, `BIAS` 211, `D` 226, `NYJETS` 209, `XNDX2` 209, `YINDEX` 209, and `YWORD1` 200.

1458 ⟨*Page CM1043* 1458⟩≡ (1452 2729)

```
# ROLL COMMANDS  TIMING(NO Y,Z TRANS, NO QUAD FAILS)  45MCT

RWORD           CCS     TAU             # CHECK FOR ROLL COMMANDS
                CAF     ONE
                TCF     +2
                CAF     TWO
                TS      RINDEX

                CCS     ACORBD          # FLAG FOR AC OR BD QUAD SELECTION FOR
                TCF     BDROLL          # ROLL COMMANDS
                TCF     BDROLL          # +, +0 = BD ROLL
                TCF     +1              # -, -0 = AC ROLL

ACROLL          CCS     RACFAIL         # CHECK FOR REAL FAILURES
                TCF     RAFAIL          # ON AC QUADS
                TCF     RXLNS
                TCF     RCFAIL
                TCF     RXLNS

RAFAIL          CAF     NINE            # QUAD FAILURE WILL GET
                TCF     TABRCOM         # 1-JET OPERATION
RCFAIL          CAF     TWELVE
                TCF     TABRCOM

XLN1NDX         DEC     0
                DEC     1               # INDICES FOR TRANSLATION
                DEC     2
                DEC     0

# TABLE LOOK UP FOR AC-ROLL COMMANDS WITH AND WITHOUT Y-TRANSLATION AND ACQUAD FAILUR
# BITS 9,10,11 CONTAIN THE MAGNITUDE AND DIRECTION OF THE ROLL

RXLNS           INDEX   YNDX            # NO AC QUAD FAILURES
                CA      XLNNDX          # INCLUDE +,-,0, Y-TRANSLATION
TABRCOM         AD      RINDEX
                INDEX   A
                CA      RTABLE
                MASK    ACRJETS         # = 3760 OCT
                TS      RWORD1

# CHECK FOR Z-TRANSLATIONS ON BD

BDZCHECK        CA      ZNDX
                EXTEND
                BZMF    NOBDZ           # NO Z-TRANSLATION
```

Uses `A` 80, `ACORBD` 211, `RACFAIL` 211, `RINDEX` 209, `RWORD1` 200, `TAU` 211, `YNDX` 209, `Z` 80, and `ZNDX` 209.

1460 ⟨*Page CM1044* 1460⟩≡ (1452 2729)

```
# TABLE LOOK UP FOR BD Z-TRANSLATION WITH AND WITHOUT REAL BD QUAD FAILURES.  Z-TRANS
# IBLE AS LONG AS ROLL COMMANDS CAN BE SATISFIED WITH THE AC ROLL JETS.  CRITERION:
# COMMANDS = 0 (WITH Z-TRANSLATION) AND IF TAU = 0, THEN INCLUDE THE BD Z-TRANSLATION
# ROLL COMMAND = 0, AND IF TAU NZ, THEN IGNORE THE BD Z-TRANSLATION

                CCS     RBDFAIL
                CAF     THREE
                TCF     +2
                CAF     SIX
                INDEX   ZNDX
                AD      XLN1NDX
                INDEX   A
                CA      YZTABLE
                MASK    BDZJETS         # = 3417 OCT
                AD      RWORD1          # ADD TO ROLL COMMANDS
                TS      T5TEMP          # IF POSSIBLE.  MUST CHECK TAU FIRST

                EXTEND
                MP      BIT7            # DETERMINE THE NET ROLL COMMAND WITH
                AD      =-4             # Z-TRANSLATION ADDED ON
                TS      NRJETS          # NET NO. OF +,- ROLL JETS ON
                EXTEND
                BZF     TAUCHECK

ACRBDZ          CA      T5TEMP          # Z-TRANSLATION ACCEPTED EVEN THO WE MAY
                TS      RWORD1          # HAVE INTRODUCED AN UNDESIREABLE ROLL
                TCF     ROLLTIME        # BRANCH TO JET ON-TIME CALCULATIONS

TAUCHECK        CCS     TAU
                TCF     NOBDZ
                TCF     ACRBDZ
                TCF     NOBDZ
                TCF     ACRBDZ

NOBDZ           CA      RWORD1          # Z-TRANSLATION NOT ACCEPTED
                EXTEND
                MP      BIT7
                AD      =-2
                TS      NRJETS
                TCF     ROLLTIME        # BRANCH TO JET ON-TIME CALCULATION
```

Uses A 80, COMMAND 169, LONG 157, NRJETS 209, RBDFAIL 211, RWORD1 200, T5TEMP 200, TAU 211, Z 80, and ZNDX 209.

1461 ⟨*Page CM1045* 1461⟩≡ (1452 2729)

```
# BD QUAD SELECTION FOR ROLL COMMANDS

BDROLL          CCS     RBDFAIL
                TCF     RBFAIL
                TCF     RZXLNS
                TCF     RDFAIL
                TCF     RZXLNS
RBFAIL          CAF     NINE
                TCF     TABRZCMD
RDFAIL          CAF     TWELVE
                TCF     TABRZCMD

RZXLNS          INDEX   ZNDX            # NO BD FAILURES
                CA      XLNNDX          # +,-,0 Z-TRANSLATION PRESENT
TABRZCMD        AD      RINDEX
                INDEX   A
                CA      RTABLE
                MASK    BDRJETS         # = 34017 OCT
                TS      RWORD1

ACYCHECK        CA      YNDX            # ANY Y-TRANSLATION
                EXTEND
                BZF     NOACY           # NO Y-TRANSLATION
                CCS     RACFAIL
                CAF     THREE
                TCF     +2
                CAF     SIX
                INDEX   YNDX
                AD      XLN1NDX
                INDEX   A
                CA      YZTABLE
                MASK    ACYJETS         # = 34360 OCT
                AD      RWORD1
                TS      T5TEMP
                EXTEND                  # FOR EXPLANATION SEE CODING ON RTABLE
                MP      BIT4
                AD      =-4
                TS      NRJETS          # NO. OF NET ROLL JETS
                EXTEND
                BZF     TAUCHCK         # IF NRJETS = 0

BDRACZ          CA      T5TEMP          # Y-TRANSLATION ACCEPTED
                TS      RWORD1
                TCF     ROLLTIME        # BRANCH TO JET ON-TIME CALCULATIONS
```

```
TAUCHCK         CCS     TAU
                TCF     NOACY
                TCF     BDRACZ
                TCF     NOACY
                TCF     BDRACZ
```

Uses A 80, NRJETS 209, RACFAIL 211, RBDFAIL 211, RINDEX 209, RWORD1 200, T5TEMP 200, TAU 211, YNDX 209, Z 80, and ZNDX 209.

1462 ⟨*Page CM1046* 1462⟩≡ (1452 2729)

```
NOACY           CA      RWORD1          # Y-TRANSLATION NOT ACCEPTED
                EXTEND
                MP      BIT4
                AD      =-2
                TS      NRJETS
                TCF     ROLLTIME
```

Uses NRJETS 209 and RWORD1 200.

1463 ⟨*Page CM1047* 1463⟩≡ (1452 2729)

```
#                                TABLE FOR ROLL, Y AND Z-TRANSLATION COMMANDS
#
# EITHER AC OR BD ROLL MAY BE SELECTED.  IF AC ROLL IS SELECTED, Y-TRANSLATIONS MAY BE SATISFIE
# PROVIDED THAT THERE ARE NO AC QUAD FAILURES.  IF THERE ARE AC FAILURES, Y-TRANSLATION COMMAND
# IN WHICH CASE THE ASTRONAUT SHOULD SWITCH TO BD ROLL.
#
# IF BDROLL IS SELECTED, Z-TRANSLATIONS MAY BE SATISFIED SIMULTANEOUSLY PROVIDED THAT THERE ARE
# FAILURES.  IF THERE ARE BD FAILURES, Z-TRANSLATION COMMANDS WILL BE IGNORED, IN WHICH CASE TH
# SWITCH TO AC ROLL.
#
# NOTE THAT IF ONE QUAD FAILS (E.G. B FAILED), Z-TRANSLATION IS STILL POSSIBLE AND THAT THE UND
# INTRODUCED BY THIS TRANSLATION WILL BE COMPENSATED BY THE TWO AC ROLL JETS ACTUATED BY THE AU
#
#                                          WORD MAKE UP....RTABLE
#
# TWO WORDS, CORRESPONDING TO AC OR BD ROLL SELECTION, HAVE BEEN COMBINED INTO ONE TABLE.  THE
# TO AC ROLL HAS THE FOLLOWING INTERPRETATION:
#
#       BITS 9,10,11 ARE CODED TO GIVE THE NET ROLL TORQUE FOR THE WORD SELECTED.  THE CODING I
#
#               BIT NO. 11  10   9              NO. OF ROLL JETS
#
#                       0   0   0                      -2
#                       0   0   1                      -1
#                       0   1   0                       0
#                       0   1   1                      +1
#                       1   0   0                      +2
#
# THIS WORD MAY THEN BE ADDED TO THE WORD SELECTED FROM THE YZ-TRANSLATION TABLE, WHICH HAS THE
# CODING AS ABOVE, AND THE NET ROLL DETERMINED BY SHIFTING THE RESULTANT WORD RIGHT 8 PLACES AN
#
# THE WORD CORRESPONDING TO THE BD ROLL HAS A SIMILAR INTERPRETATION, EXCEPT THAT BITS 12, 13,
# (AS ABOVE) TO GIVE THE NET ROLL TORQUE.

                                        # ROLL          TRANS           QUADFAIL        BIAS

RTABLE          OCT     11000           #   0                                             0
                OCT     22125           #   +                                             0
                OCT     00252           #   -                                             0
                OCT     11231           #   0           +Y(+Z)                            3
                OCT     15421           #   +           +Y(+Z)                            3
                OCT     04610           #   -           +Y(+Z)                            3
                OCT     11146           #   0           -Y(-Z)                            6
                OCT     15504           #   +           -Y(-Z)                            6
                OCT     04442           #   -           -Y(-Z)                            6
```

```
        OCT     11000           #   0                           A(B)
        OCT     15504           #   +                           A(B)
        OCT     04610           #   -                           A(B)
        OCT     11000           #   0                           C(D)
        OCT     15421           #   +                           C(D)
        OCT     04442           #   -                           C(D)
```

Uses A 80, BIAS 211, D 226, and Z 80.

1464 ⟨*Page CM1048* 1464⟩≡ (1452 2729)

```
# RTABLE MASKS:

ACRJETS         OCT     03760
BDRJETS         OCT     34017
```

1465 ⟨*Page CM1049* 1465⟩≡ (1452 2729)

```
#                                        Y, Z TRANSLATION TABLE
#
# ONCE AC OR BD ROLL IS SELECTED THE QUAD PAIR WHICH IS NOT BEING USED TO SATISFY THE ROLL COMM
# USED TO SATISFY THE REMAINING TRANSLATION COMMANDS.  HOWEVER, WE MUST MAKE SURE THAT ROLL COM
# WHEN THEY OCCUR.  THEREFORE, THE Y-Z TRANSLATIONS FROM THIS TABLE WILL BE IGNORED IF THE NET
# COMBINED WORD IS ZERO AND THE ROLL COMMANDS ARE NON-ZERO.  THIS SITUATION WOULD OCCUR, FOR EX
# COUNTER SIMULTANEOUS +R +Y -Z COMMANDS AND A QUAD D FAILURE WHILE USING AC FOR ROLL.
#
# TO FACILITATE THE LOGIC, THE Y-Z TRANSLATION TABLE HAS BEEN CODED IN A MANNER SIMILAR TO THE
# ABOVE.
#
# BITS 9,10,11 ARE CODED TO GIVE THE NET ROLL TORQUE INCURRED BY Z-TRANSLATIONS.  THE WORD SELE
# ADDED TO THE AC-ROLL WORD AND THE RESULTANT ROLL TORQUE DETERMINED FROM THE COMBINED WORD.  S
# 12,13,14 ARE CODED TO GIVE THE NET ROLL TORQUE INCURRED BY Y-TRANSLATIONS WHEN BD-ROLL IS SEL

                                         # TRANSLATION   QUADFAIL        BIAS
                                         #
YZTABLE         OCT     11000            #       0                       0
                OCT     11231            #    +Z(+Y)                     0
                OCT     11146            #    -Z(-Y)                     0
                OCT     11000            #       0         B(A)          3
                OCT     04610            #    +Z(+Y)       B(A)          3
                OCT     15504            #    -Z(-Y)       B(A)          3
                OCT     11000            #       0         D(C)          6
                OCT     15421            #    +Z(+Y)       D(C)          6
                OCT     04442            #    -Z(-Y)       D(C)          6

# YZ-TABLE MASKS:

BDZJETS         OCT     03417
ACYJETS         OCT     34360

# ADDITIONAL CONSTANTS

=-2             =       NEG2
=-4             =       NEG4
```

Uses A 80, BIAS 211, D 226, and Z 80.

1466 ⟨*Page CM1050* 1466⟩≡ (1452 2729)

```
#                                       CALCULATION OF JET ON-TIMES
#
# THE ROTATION COMMANDS (TAU'S), WHICH WERE DETERMINED FROM THE JET SWITCHING LOGIC (
# OPERATION, MUST NOW BE UPDATED BY THE ACTUAL NUMBER OF JETS TO BE USED IN SATISFYIN
# ALSO BE DECREMENTED ACCORDING TO THE EXPECTED TORQUE GENERATED BY THE NEW COMMANDS
# INTERVAL.
#
# IN ORDER TO MAINTAIN ACCURATE KNOWLEDGE OF VEHICLE ANGULAR RATES, WE MUST ALSO PROV
# (DFT'S, ALSO IN TERMS OF 1-JET OPERATION) FOR THE RATE FILTER.
#
# NOTE THAT TRANSLATIONS CAN PRODUCE ROTATIONS EVEN THOUGH NO ROTATIONS WERE CALLED F
# UPDATE DFT.
#
# WHEN THE ROTATIONS HAVE FINISHED, WE MUST PROVIDE CHANNEL INFORMATION TO THE T6 PRO
# THE TRANSLATIONS.  THIS WILL BE DONE IN THE NEXT SECTION.  HOWEVER, TO INSURE THAT
# THAN A MINIMUM IMPULSE (14MS), ALL JET CHANNEL COMMANDS WILL BE HELD FIXED FROM THE
# AT LEAST 14MS UNTIL THE INITIALIZATION OF NEW COMMANDS.  MOREOVER, A 14MS ON-TIME W
# COMMANDS GENERATED BY THE MANUAL CONTROLS OR THE JET SWITCHING LOGIC, AND ALL TRANS
# ACTIVE FOR AT LEAST ONE CYCLE OF THE T5 PROGRAM (.1SEC)

# PITCH JET ON-TIME CALCULATION

PITCHTIM        CCS     TAU1
                TCF     PTAUPOS
                TCF     +2
                TCF     PTAUNEG
                TS      DFT1            # NO PITCH ROTATION
                TCF     PBYPASS         # COMMANDS

PTAUNEG         CS      NPJETS
                TS      NPJETS
PTAUPOS         CA      TAU1
                EXTEND
                INDEX   NPJETS
                MP      NJET
                TS      BLAST1
                AD      =-.1SEC
                EXTEND
                BZMF    AD14MSP
                INDEX   NPJETS
                CA      DFTMAX          # THE PITCH ON-TIME IS GREATER THAN .1 SEC
                TS      DFT1
                COM
                ADS     TAU1            # UPDATE TAU1
                CAF     =+.1SEC         # LIMIT THE LENGTH OF PITCH ROTATION
```

```
                TS      BLAST1          # COMMANDS TO 0.1 SEC SO THAT ONLY
                TCF     ASMBLWP         # X-TRANSLATIONS WILL CONTINUE ON SWITCH
                                        # OVER TO TVC
  AD14MSP       CS      BLAST1          # SEE IF JET ON TIME IS LESS THAN
                AD      =14MS           # MINIMUM IMPULSE TIME
                EXTEND
                BZMF    PBLASTOK        # IF SO LIMIT MINIMUM ON TIME TO 14 MS
                CAF     =14MS
```

Uses A 80, BLAST1 200, DFT 209, DFT1 209, NPJETS 209, TAU 211, and TAU1 211.

1467 ⟨*Page CM1051* 1467⟩≡ (1452 2729)

```
                TS      BLAST1
  PBLASTOK      CA      BLAST1
                EXTEND                  # THE PITCH COMMANDS WILL BE COMPLETED
                MP      NPJETS          # WITHIN THE TS-CYCLE TIME
                LXCH    DFT1            # FOR USE IN UPDATING RATE FILTER
                TS      TAU1            # ZERO TAU1 (ACC CONTAINS ZERO)
                TCF     ASMBLWP
```

Uses BLAST1 200, DFT1 209, NPJETS 209, and TAU1 211.

1468 ⟨*Page CM1052* 1468⟩≡ (1452 2729)

```
# YAW JET ON-TIME CALCULATION

YAWTIME         CCS     TAU2
                TCF     YTAUPOS
                TCF     +2
                TCF     YTAUNEG
                TS      DFT2            # NO YAW ROTATION COMMANDS
                TCF     YBYPASS

YTAUNEG         CS      NYJETS
                TS      NYJETS
YTAUPOS         CA      TAU2
                EXTEND
                INDEX   NYJETS
                MP      NJET
                TS      BLAST2
                AD      =-.1SEC
                EXTEND
                BZMF    AD14MSY
                INDEX   NYJETS
                CA      DFTMAX          # YAW COMMANDS WILL LAST LONGER THAN .1SEC
                TS      DFT2
                COM
                ADS     TAU2            # DECREMENT TAU2
                CAF     =+.1SEC         # LIMIT THE LENGTH OF YAW ROTATION COMMAND
                TS      BLAST2          # TO 0.1 SEC SO THAT ONLY X-TRANSLATION
                TCF     ASMBLWY         # WILL CONTINUE ON SWITCH OVER TO TVC

AD14MSY         CS      BLAST2          # SEE IF JET ON-TIME LESS THAN
                AD      =14MS           # MINIMUM IMPULSE TIME
                EXTEND
                BZMF    YBLASTOK        # IF SO, LIMIT MINIMUM ON-TIME TO 14 MS
                CAF     =14MS
                TS      BLAST2
YBLASTOK        CA      BLAST2          # YAW COMMANDS WILL BE COMPLETED WITHIN
                EXTEND                  # THE T5CYCLE TIME
                MP      NYJETS
                LXCH    DFT2
                TS      TAU2            # ZERO TAU2
                TCF     ASMBLWY
```

Uses BLAST2 200, COMMAND 169, DFT2 209, NYJETS 209, and TAU2 211.

1469 ⟨*Page CM1053* 1469⟩≡ (1452 2729)

```
# ROLL ON-TIME CALCULATION:

ROLLTIME        CCS     TAU
                TCF     RBLAST
                TCF     +2
                TCF     RBLAST
                INDEX   NRJETS
                CA      DFTMAX          # UPDATE DFT EVEN THO NO ROLL COMMANDS ARE
                TS      DFT             # PRESENT
                TCF     RBYPASS

                DEC     -480            # =-.3SEC
                DEC     -320            # =-.2SEC
=-.1SEC         DEC     -160            # =-.1SEC
DFTMAX          DEC     0               # 0
=+.1SEC         DEC     160             # =+.1SEC
                DEC     320             # =+.2SEC
                DEC     480             # =+.3SEC
=14MS           DEC     23              # =14MS

RBLAST          CA      TAU
                EXTEND
                INDEX   NRJETS
                MP      NJET
                TS      BLAST           # BLAST IS AN INTERMEDIATE VARIABLE
                                        # USED IN DETERMINING THE JET ON-TIMES
                AD      =-.1SEC
                EXTEND
                BZMF    AD14MSR
                INDEX   NRJETS          # THE ROLL ROTATION WILL LAST LONGER
                CA      DFTMAX          # THAN THE T5 CYCLE TIME
                TS      DFT
                COM
                ADS     TAU
                CAF     =+.1SEC         # LIMIT THE LENGTH OF ROLL ROTATION
                TS      BLAST           # COMMANDS TO 0.1 SEC SO THAT ONLY Y-Z
                TCF     ASMBLWR         # TRANSLATION COMMANDS CONTINUE

AD14MSR         CS      BLAST           # SEE IF THE JET ON-TIME LESS THAN
                AD      =14MS           # MINIMUM IMPULSE TIME
                EXTEND
                BZMF    RBLASTOK
                CAF     =14MS           # IF SO, LIMIT MINIMUM ON-TIME TO 14 MS
                TS      BLAST
RBLASTOK        CA      BLAST
```

```
                EXTEND
                MP      NRJETS
                LXCH    DFT
                TS      TAU             # ZERO TAU
                TCF     ASMBLWR
```

Uses BLAST 200, DFT 209, NRJETS 209, TAU 211, and Z 80.

1470a ⟨*Page CM1054* 1470a⟩≡ (1452 2729)

```
                DEC     -.333333        # = -1/3
                DEC     -.500000        # = -1.2
                DEC     -.999999        # = -1 (NEGMAX)
  NJET          DEC     0
                DEC     .999999         # = +1 (POSMAX)
                DEC     .500000         # = +1/2
                DEC     .333333         # = +1/3
```

1470b ⟨*Page CM1055* 1470b⟩≡ (1452 2729)

```
  # WHEN THE ROTATION COMMANDS ARE COMPLETED, IT IS NECESSARY TO REPLACE THESE COMMANDS
  # CONTINUE ON WITH THE TRANSLATIONS IF ANY ARE PRESENT.
  #
  # IN THIS SECTION THESE NEW COMMANDS ARE GENERATED AND STORED FOR REPLACEMENT OF THE
  # CORRESPONDING ROTATIONS ARE COMPLETED.
  #
  # GENERATION OF THE SECOND PITCH(X-TRANS) WORD...PWORD2

  ASMBLWP       CCS     RACFAIL
                TCF     FPX2            # IF FAILURE ON AC IGNORE X-TRANSLATION
                TCF     +2
                TCF     FPX2
                INDEX   XNDX1
                CA      XLNNDX
                INDEX   A
  FPX2          CA      PYTABLE
                MASK    PJETS
                TS      PWORD2
                TCF     YAWTIME

  PBYPASS       CA      PWORD1          # THE T6 PROGRAM WILL LOAD PWORD2
                TS      PWORD2          # UPON ENTRY
                CAF     ZERO
                TS      BLAST1          # THERE IS NO PWORD2
                TCF     YAWTIME
```

Uses A 80, BLAST1 200, IT 185, PWORD1 200, PWORD2 200, RACFAIL 211, and XNDX1 209.

1471 ⟨*Page CM1056* 1471⟩≡ (1452 2729)

```
# GENERATION OF THE SECOND ROLL (Y,Z) WORD (RWORD2)

ASMBLWR         CCS     YNDX            # CHECK FOR Y-TRANS
                TCF     ACBD2Y
NO2Y            CAF     ZERO
                TS      RWORD2
                CCS     ZNDX            # CHECK FOR Z-TRANS
                TCF     ACBD2Z
NO2Z            CAF     ZERO
                ADS     RWORD2
                TCF     PITCHTIM        # RWORD2 ASSEMBLED

ACBD2Y          CCS     ACORBD
                TCF     AC2Y            # CAN DO Y-TRANS
                TCF     AC2Y
                TCF     +1              # USING AC FOR ROLL
                CCS     RACFAIL
                TCF     NO2Y            # USING AC AND AC HAS FAILED
                TCF     +2
                TCF     NO2Y            # DITTO

                INDEX   YNDX            # NO FAILURES, CAN DO Y
                CA      XLNNDX
                INDEX   A
                CA      RTABLE
                MASK    ACRJETS
                TCF     NO2Y    +1

AC2Y            CCS     RACFAIL
                CAF     THREE
                TCF     +2
                CAF     SIX
                INDEX   YNDX
                AD      XLN1NDX
                INDEX   A
                CA      YZTABLE
                MASK    ACYJETS
                TS      RWORD2
                EXTEND
                MP      BIT4
                AD      =-2
                TS      NRJETS
                CS      BLAST
                AD      =+.1SEC
                EXTEND
```

```
MP      NRJETS
CA      L
ADS     DFT
TCF     NO2Y    +2
```

Uses A 80, ACORBD 211, BLAST 200, DFT 209, L 80, NRJETS 209, RACFAIL 211, RWORD2 200, YNDX 209, Z 80, and ZNDX 209.

1473 ⟨*Page CM1057* 1473⟩≡ (1452 2729)

```
ACBD2Z          CCS     ACORBD
                TCF     BDF2Z           # USING BD-ROLL
                TCF     BDF2Z           # MUST CHECK FOR BD FAILURES
                TCF     +1
                CCS     RBDFAIL         # USING AC FOR ROLL, CAN DO Z-TRANS
                CAF     THREE
                TCF     +2
                CAF     SIX
                INDEX   ZNDX
                AD      XLN1NDX
                INDEX   A
                CA      YZTABLE
                MASK    BDZJETS
                ADS     RWORD2
                EXTEND
                MP      BIT7
                AD      =-2
                TS      NRJETS
                CS      BLAST
                AD      =+.1SEC
                EXTEND
                MP      NRJETS
                CA      L
                ADS     DFT
                TCF     PITCHTIM

BDF2Z           CCS     RBDFAIL
                TCF     NO2Z            # USING BD-ROLL AND BD HAS FAILED
                TCF     +2
                TCF     NO2Z            # DITTO
                INDEX   ZNDX
                CA      XLNNDX
                INDEX   A
                CA      RTABLE
                MASK    BDRJETS
                TCF     NO2Z +1

RBYPASS         CA      RWORD1
                TS      RWORD2
                CAF     ZERO
                TS      BLAST
                TCF     PITCHTIM
```

Uses `A` 80, `ACORBD` 211, `BLAST` 200, `DFT` 209, `L` 80, `NRJETS` 209, `RBDFAIL` 211, `RWORD1` 200, `RWORD2` 200, `Z` 80, and `ZNDX` 209.

1474 ⟨*Page CM1058* 1474⟩≡ (1452 2729)

```
# GENERATION OF THE SECOND YAW (X-TRANS) WORD...YWORD2

ASMBLWY         CCS     RBDFAIL
                TCF     FYX2            # IF FAILURE ON BD IGNORE X-TRANSLATION
                TCF     +2
                TCF     FYX2
                INDEX   XNDX2
                CA      XLNNDX
                INDEX   A
FYX2            CA      PYTABLE
                MASK    YJETS
                TS      YWORD2
                TCF     T6SETUP

YBYPASS         CA      YWORD1
                TS      YWORD2
                CAF     ZERO
                TS      BLAST2
```

Uses `A` 80, `BLAST2` 200, `RBDFAIL` 211, `XNDX2` 209, `YWORD1` 200, and `YWORD2` 200.

1475 ⟨*Page CM1059* 1475⟩≡ (1452 2729)

```
#                                       SORT THE JET ON-TIMES
#
# AT THIS POINT ALL THE CHANNEL COMMANDS AND JET ON-TIMES HAVE BEEN DETERMINED.  IN SUMMARY THE
#
#       RWORD1
#       RWORD2          BLAST
#
#       PWORD1
#       PWORD2          BLAST1
#
#       YWORD1
#       YWORD2          BLAST2
#
# IN THIS SECTION THE JET ON-TIMES ARE SORTED AND THE SEQUENCE OF T6 INTERRUPTS IS DETERMINED.
# THE SORTING PROCESS AND THE T6 PROGRAM, THE VARIABLES BLAST, BLAST1, BLAST2, ARE RESERVED AS
# WORDS.  THE LOWER PART OF THESE WORDS CONTAIN A BRANCH INDEX ASSOCIATED WITH THE ROTATION AXI
# ORDER WORD.

T6SETUP         CAF     ZERO            # BRANCH INDEX FOR ROLL
                TS      BLAST +1
                CAF     FOUR            # BRANCH INDEX FOR PITCH
                TS      BLAST1 +1
                CAF     ELEVEN          # BRANCH INDEX FOR YAW
                TS      BLAST2 +1

                CS      BLAST
                AD      BLAST1
                EXTEND
                BZMF    DXCHT12         # T1 OR T2
CHECKT23        CS      BLAST1
                AD      BLAST2
                EXTEND
                BZMF    DXCHT23
CALCDT6         CS      BLAST1
                ADS     BLAST2
                CS      BLAST
                ADS     BLAST1          # END OF SORTING PROCEDURE
                EXTEND                  # RESET T5LOC TO BEGIN PHASE1
                DCA     RCS2CADR
                DXCH    T5LOC
ENDJETS         CS      BIT1            # RESET BIT1 FOR INITIALIZATION OF
                MASK    RCSFLAGS        # T6 PROGRAM
                TS      RCSFLAGS
                CS      ZERO            # RESET T5PHASE FOR PHASE1
                TS      T5PHASE
```

```
                TCF     RESUME          # RESUME INTERRUPTED PROGRAM

                EBANK=  KMPAC
RCS2CADR        2CADR   RCSATT
```

Uses A 80, BLAST 200, BLAST1 200, BLAST2 200, EBANK 80, KMPAC 209, PHASE1 152, PWORD1 200, PWORD2 200, RCSFLAGS 200, RWORD1 200, RWORD2 200, T1 241, T2 241, T5LOC 163, T5PHASE 200, YWORD1 200, and YWORD2 200.

1476 ⟨*Page CM1060* 1476⟩≡ (1452 2729)

```
DXCHT12         DXCH    BLAST
                DXCH    BLAST1
                DXCH    BLAST
                TCF     CHECKT23

DXCHT23         DXCH    BLAST1
                DXCH    BLAST2
                DXCH    BLAST1
                CS      BLAST
                AD      BLAST1
                EXTEND
                BZMF    +2
                TCF     CALCDT6
                DXCH    BLAST
                DXCH    BLAST1
                DXCH    BLAST
                TCF     CALCDT6
```

Uses BLAST 200, BLAST1 200, and BLAST2 200.

1477 ⟨*Page CM1061* 1477⟩≡ (1452 2729)

```
# T6 PROGRAM AND CHANNEL SETUP

                BANK    21
                SETLOC  DAPS5
                BANK

T6START         LXCH    BANKRUPT
                EXTEND
                QXCH    QRUPT
                CCS     TIME6           # CHECK TO SEE IF TIME6 WAS RESET
                TCF     RESUME          # AFTER T6RUPT OCCURRED (IN T5RUPT)
                TCF     +2              # IF SO WAIT FOR NEXT T6RUPT BEFORE
                TCF     RESUME          # TAKING ACTION

                CS      RCSFLAGS
                MASK    BIT1            # IF BIT1 IS 0 RESET TO 1
                EXTEND                  # AND INITIALIZE CHANNEL
                BZF     T6RUPTOR
                ADS     RCSFLAGS
                CA      RWORD1
                EXTEND                  # INITIALIZE CHANNELS 5,6 WITH WORD1
                WRITE   CHAN6
                CA      PWORD1
                AD      YWORD1
                EXTEND
                WRITE   CHAN5

T6RUPTOR        CCS     BLAST
                TCF     ZBLAST          # ZERO BLAST1
                TCF     REPLACE         # REPLACE WORD1
                TCF     +2
                TCF     REPLACE
T6L1            CCS     BLAST1
                TCF     ZBLAST1
                TCF     REPLACE1
                TCF     +2
                TCF     REPLACE1
T6L2            CCS     BLAST2
                TCF     ZBLAST2
                TCF     REPLACE2
                TCF     RESUME
                TCF     REPLACE2

REPLACE         INDEX   BLAST +1
                TC      REPLACER
```

```
                CS      ONE
                TS      BLAST
                TCF     T6L1

REPLACE1        INDEX   BLAST1 +1
```

Uses BANKRUPT 80, BLAST 200, BLAST1 200, BLAST2 200, DAPS5 63, PWORD1 200, QRUPT 80, RCSFLAGS 200, RWORD1 200, TC 169, TIME6 80, and YWORD1 200.

1479 ⟨*Page CM1062* 1479⟩≡ (1452 2729)

```
                TC      REPLACER
                CS      ONE
                TS      BLAST1
                TCF     T6L2

REPLACE2        INDEX   BLAST2 +1
                TC      REPLACER
                CS      ONE
                TS      BLAST2
                TCF     RESUME

REPLACER        CA      RWORD2          # INITIALIZE CHANNELS 5,6 WITH WORD2
                EXTEND
                WRITE   CHAN6
                TC      Q

REPLACEP        CA      YJETS
                EXTEND
                RAND    CHAN5
                AD      PWORD2
                EXTEND
                WRITE   CHAN5
                TC      Q

REPLACEY        CA      PJETS
                EXTEND
                RAND    CHAN5
                AD      YWORD2
                EXTEND
                WRITE   CHAN5
                TC      Q

ZBLAST          CAF     ZERO
                XCH     BLAST
                TCF     ENABT6
ZBLAST1         CAF     ZERO
                XCH     BLAST1
                TCF     ENABT6
ZBLAST2         CAF     ZERO
                XCH     BLAST2
ENABT6          TS      TIME6
                CAF     NEGMAX
                EXTEND
                WOR     CHAN13          # ENABLE T6RUPT
                TCF     RESUME
```

```
# END OF T6 INTERRUPT

ENDSLECT        EQUALS
```

Uses BLAST 200, BLAST1 200, BLAST2 200, CHAN13 87, PWORD2 200, Q 80, RWORD2 200, TC 169, TIME6 80, and YWORD2 200.

3.6.13 cm entry digital autopilot

1480 ⟨*cm entry digital autopilot* 1480⟩≡ (1346c)

⟨*Page CM1063* 1481⟩
⟨*Page CM1064* 1483⟩
⟨*Page CM1065* 1484⟩
⟨*Page CM1066* 1485⟩
⟨*Page CM1067* 1486⟩
⟨*Page CM1068* 1487⟩
⟨*Page CM1069* 1488⟩
⟨*Page CM1070* 1489⟩
⟨*Page CM1071* 1491⟩
⟨*Page CM1072* 1492⟩
⟨*Page CM1073* 1493⟩
⟨*Page CM1074* 1495⟩
⟨*Page CM1075* 1496⟩
⟨*Page CM1076* 1497⟩
⟨*Page CM1077* 1498⟩
⟨*Page CM1078* 1500⟩
⟨*Page CM1079* 1502⟩
⟨*Page CM1080* 1503⟩
⟨*Page CM1081* 1504⟩
⟨*Page CM1082* 1506⟩
⟨*Page CM1083* 1508⟩
⟨*Page CM1084* 1510⟩
⟨*Page CM1085* 1512⟩
⟨*Page CM1086* 1513⟩
⟨*Page CM1087* 1514⟩
⟨*Page CM1088* 1516⟩
⟨*Page CM1089* 1518⟩
⟨*Page CM1090* 1519⟩
⟨*Page CM1091* 1521⟩
⟨*Page CM1092* 1522⟩

1481 ⟨*Page CM1063* 1481⟩≡ (1480 2659)

```
# SUBROUTINE TO READ GIMBAL ANGLES AND FORM DIFFERENCES.  GIMBAL ANGLES ARE SAVED IN 2'S COMPLE
# DIFFERENCES ARE IN 1'S COMP.  ENTER AND READ ANGLES EACH .1 SEC.
#
#       CM/DSTBY = 1 FOR DAP OPERATION
#       CM/DSTBY = 0 TO TERMINATE DAP OPERATION

                BANK    15

                SETLOC  ETRYDAP
                BANK

                COUNT   15/DAPEN

                EBANK=  AOG

READGYMB        CA      TEN             # KEEP RESTART DT GOING RELATIVE TO
                ADS     CM/GYMDT        # PIPTIME.  (GROUP 6)

                                        # IF A RESTART OCCURS, SKIP PRESENT CYCLE.  THE
                                        # PHASCHNG PROTECTION IS IN CM/DAPIC.

                CA      BIT6            # CHECK FOR FINE ALIGN MODE OF CDU.
                MASK    IMODES33        # (PROTECT AOG/PIP ETC AS WELL AS
                EXTEND                  # GIMBAL DIFFERENCES)
                BZF     READGYM1        # OK

                CS      BIT1            # NOT IN FINE ALIGN, SO IDLE
                MASK    CM/FLAGS        # SET GYMDIFSW = 0
                TS      CM/FLAGS
                TC      FLUSHJET        # QUENCH JETS, SINCE MAY BE A WHILE.
                TC      CM/GYMIC +2

READGYM1        CA      CDUX
                XCH     AOG
                EXTEND
                MSU     AOG             # -DELAOG=AOG(N-1) - AOG(N)
                TS      -DELAOG

                CA      CDUY
                XCH     AIG
                EXTEND
                MSU     AIG
                TS      -DELAIG

                CA      CDUZ
```

```
XCH     AMG
EXTEND
MSU     AMG
TS      -DELAMG
```

Uses -DELAIG 214, -DELAMG 214, -DELAOG 214, A 80, AIG 214, AMG 214, AOG 214, AOG/PIP 214, CDUX 80, CDUY 80, CDUZ 80, CM/DSTBY 121, CM/GYMDT 216, COUNT 142, EBANK 80, ETRYDAP 61, GYMDIFSW 121, IMODES33 163, MODE 145, N 206, PIPTIME 159, RESTART 57, and TC 169.

1483 ⟨*Page CM1064* 1483⟩≡ (1480 2659)

```
DOBRATE?        CS      CM/FLAGS        # CM/DSTBY=103D BIT2  GYMDIFSW=104D BIT1
                MASK    THREE
                INDEX   A
                TC      +1
                TC      DOBRATE         # OK, GO ON
                TC      CM/GYMIC        # DON'T CALC BODYRATE ON FIRST PASS.
                NOOP
                TC      FLUSHJET        # TURN OFF ALL JETS

                TC      PHASCHNG
                OCT     00006           # DEACTIVATE DAP GROUP 6.

                TC      TASKOVER

DOBRATE         CA      ONE             # DO BODYRATE
DOBRATE1        TS      JETEM           # SKIP BODYRATE

                CA      TEN             # KEEP CDU READ GOING.
                TC      WAITLIST
                EBANK=  AOG
                2CADR   READGYMB

                                        # DOES NOT PROTECT TEMK, SQ IN SPSIN/COS

                CCS     JETEM
                TC      BODYRATE
                TC      TASKOVER        # SKIP CALC ON INITIAL PASS.  (PASSES)

CM/GYMIC        ADS     CM/FLAGS        # GYMDIFSW:  C(A)=1, KNOW BIT IS 0
                CAF     ZERO
                TS      JETAG
                TS      OLDELP
                TS      OLDELQ
                TS      OLDELR
                TS      GAMDOT          # NO GYM DIF, PROB NO GAM DIF.
                TC      DOBRATE1
```

Uses A 80, AOG 214, CM/DSTBY 121, EBANK 80, GAMDOT 216, GYMDIFSW 121, JETAG 214, JETEM 216, OLDELP 214, OLDELQ 214, OLDELR 214, SQ 156, TC 169, and TEMK 156.

1484 ⟨*Page CM1065* 1484⟩≡ (1480 2659)

```
# COME HERE TO CORRECT FOR OVERFLOW IN ANGULAR CALCULATIONS

ANGOVCOR        TS      L               # THIS COSTS 2 MCT TO USE.
                TC      Q               # NO OVFL
                INDEX   A
                CAF     LIMITS
                ADS     L
                TC      Q

                BLOCK   3

                COUNT   03/DAPEN

FLUSHJET        CA      7               # COME HERE TO TURN OFF ALL JETS.
                EXTEND
                WRITE   ROLLJETS        # ZERO CHANNEL 6
                EXTEND
                WRITE   PYJETS          # ZERO CHANNEL 5
                TC      Q

                BANK    15

                COUNT   15/DAPEN

                SETLOC  ETRYDAP
                BANK

RATEAVG         COM                     # SUBROUTINE TO ESTIMATE RATES IN PRESENCE
                AD      JETEM           # OF CONSTANT ACCELERATION.
                EXTEND
                MP      HALF            # DELV (EST) = DELV +(DELV-OLDELV)/2
                AD      JETEM
                TC      Q
```

Uses `A` 80, `COUNT` 142, `DELV` 159, `ETRYDAP` 61, `JETEM` 216, `L` 80, `PYJETS` 87, `Q` 80, `ROLLJETS` 87, and `TC` 169.

1485 ⟨*Page CM1066* 1485⟩≡ (1480 2659)

```
# THESE ARE CALLED FOR THE VARIOUS INITIALIZATIONS NEEDED.

                BANK    20
                SETLOC  DAPS1
                BANK

                COUNT   20/DAPEN
                EBANK=  AOG

CM/DAPON        CA      EBAOG
                TS      EBANK

                TC      DOWNFLAG        # RESET DAPBIT1.  T5 RESTART IDENTIFIER.
                ADRES   DAPBIT1         # BIT 15 FLAG 6         CMFLAGS.
                TC      DOWNFLAG        # RESET DAPBIT2
                ADRES   DAPBIT2         # BIT 14 FLAG 6
                EXTEND
                DCA     T5IDLER1        # DISABLE RCS CALCULATION
                DXCH    T5LOC
                EXTEND
                DCA     T5IDLER1        # DISABLE RCS JET CALLS
                DXCH    T6LOC

                TC      FLUSHJET        # JETS DEPARTED ON SM. ZERO JET BITS.

                CS      13,14,15
                MASK    DAPDATR1        # SET CONFIG BITS=0 FOR ENTRY
                TS      DAPDATR1
                TC      +4

NOTYET          CA      .5SEC
                TC      BANKCALL
                CADR    DELAYJOB        # (DELAYJOB DOES INHINT)
        +4      CA      BIT11           # GAMDIFSW = 94D BIT11, INITLY=0
                MASK    CM/FLAGS        # IF ZERO, WAIT UNTIL CM/POSE UPDATE.
                EXTEND
                BZF     NOTYET

                CS      ONE             # ACTIVATE CM/DAP
                TS      RCSFLAGS        # USE BIT3 TO INITIALIZE NEEDLER ON
                                        # NEXT PASS.
                TS      P63FLAG         # SO WAKEP62 WILL NOT BE INITIATED UNTIL
                                        # HEADSUP IS SET IN P62.

                                        # FLAG TO PREVENT MULTIPLE CALLS TO WAKEP62
```

```
CA      7
TS      JETAG
TS      PAXERR1         # KEEP NEEDLES ZERO UNTIL DAP UPDATE
                        # IN CASE CMDAPMOD IS NOT +1.
```

Uses AOG 214, CMDAPMOD 214, COUNT 142, DAPBIT1 117, DAPBIT2 117, DAPDATR1 200, DAPS1 63, EBANK 80, GAMDIFSW 119, HEADSUP 216, JETAG 214, P63FLAG 216, PAXERR1 214, RCSFLAGS 200, RESTART 57, T5LOC 163, T6LOC 163, and TC 169.

1486 ⟨*Page CM1067* 1486⟩≡ (1480 2659)

```
INHINT
EXTEND
DCA     ALFA/180        # DO ATTITUDE HOLD UNTIL KEYBOARD
DXCH    ALFACOM         # ESTABLISHES HEADSUP.
CA      ROLL/180
TS      ROLLHOLD        # FOR ATTITUDE HOLD IN MODE +1.
EXTEND
MP      HALF
TS      ROLLC           # NOT INTERESTED IN LO WORD.

CS      CM/FLAGS
MASK    BIT12           # CMDAPARM =93D BIT12  INITLY=0
ADS     CM/FLAGS        # SET BIT TO 1.

CS      FLAGWRD2        # SET  NODOFLAG  TO PREVENT FURTHER
MASK    BIT1            # V 37 ENTRIES.
ADS     FLAGWRD2

RELINT

TC      POSTJUMP
CADR    P62.1
```

Uses ALFA/180 214, ALFACOM 216, CMDAPARM 117, FLAGWRD2 101, HEADSUP 216, MODE 145, NODOFLAG 105, ROLL/180 214, ROLLC 214, ROLLHOLD 216, TC 169, and V 229.

1487 ⟨*Page CM1068* 1487⟩≡ (1480 2659)

```
# INITIALIZE CM/DAP.  WAITLIST CALL FOR READGYMB.  SET SWITCH CM/DSTBY =1
# SO READACCS WILL ENTER A WTLST CALL FOR  SETJTAG .
#  CMDAPARM  = 0, SO ONLY BODY RATE AND ATTITUDE CALCULATIONS ARE DONE.
# SET AVEGEXIT TO CONTINUE AT CM/POSE

CM/DAPIC        CA      EBAOG
                TS      EBANK

                INHINT
CM/DAP2C        CS      PIPTIME +1
                                        # PRIO OF P62 L PRIO AVG.:PIPTM=PIPTM1.
                TS      JETEM

                CA      POS1/2
                AD      POS1/2
                AD      TIME1           # OVFL GUARANTEED
                ADS     JETEM           # C(A) = DELTA TIME SINCE PIPUP

                CS      FIVE
                AD      JETEM
                CCS     A
                AD      -CDUT+1
                TCF     -2
                NOOP
                AD      ONE             # SEND NO ZERO TO WTLST
                TS      CM/GYMDT        # FOR RESTART
                TC      WAITLIST
                EBANK=  AOG
                2CADR   READGYMB

                CS      CM/SWIC1        # GAMDIFSW, GYMDIFSW, CM/DSTBY
                MASK    CM/FLAGS        # DAPARM, .05GSW, LATSW, ENTRYDSP
                AD      CM/SWIC2        # SET CM/DSTBY, LATSW
                                        # DISABLE ENTRY DISPLAY, SINCE DES. GIMB.
                                        # CALC.  (P62.3) GOES TO ENDEXIT
                TS      CM/FLAGS

                CA      7
                TS      BETA/180        # NECESSARY:  NO OVFL CORRECTIO
                CA      ONE             # INITIALIZE THE TM OF BODY RATES VIA
                TS      SW/NDX          # UPBUFF.

                TC      2PHSCHNG        # DOES INHINT/RELINT
                OCT     40116           # SAVE TBASE6
                OCT     05024
```

```
                OCT     13000

                TC      POSTJUMP
```

Uses .05GSW 121, A 80, AOG 214, AVEGEXIT 159, BETA/180 214, CDUT 80, CM/DSTBY 121, CM/GYMDT 216, CMDAPARM 117, EBANK 80, ENTRYDSP 117, GAMDIFSW 119, GYMDIFSW 121, JETEM 216, L 80, LATSW 121, PIPTIME 159, RESTART 57, SAVE 191, SW/NDX 145, TBASE6 154, TC 169, TIME1 80, TM 219, and UPBUFF 145.

1488 ⟨*Page CM1069* 1488⟩≡ (1480 2659)

```
                CADR    P62.2

CM/SWIC1        OCT     16017
CM/SWIC2        =       TEN             # 00012: CM/DSTBY, LATSW
-CDUT+1         OCT     77766
                EBANK=  T5LOC
T5IDLER1        2CADR   T5IDLOC
```

Uses CDUT 80, CM/DSTBY 121, EBANK 80, LATSW 121, and T5LOC 163.

1489 ⟨*Page CM1070* 1489⟩≡ (1480 2659)

```
# THIS SECTION CALCULATES THE ANGULAR BODY RATES EACH .1 SEC.  THE ANGULAR RATES ARE THOSE ALON
# XB, YB, ZB, AND ARE NORMALLY DESIGNATED P, Q, R.      REQUIREMENT:  TEMPORARILY ERASE.  JETEM
#
# SINCE RESTARTS ZERO THE JET OUTPUT CHANNELS, NO ATTEMPT IS MADE TO RESTART THE ENTRY DAPS.  T
# THE 0.1 SEC DAPS WILL MISS A CYCLE, AND WILL PICK UP AT THE NEXT 0.1 SEC UPDATE.  MOST OF THE
# ROLL SYSTEM WILL MISS ONLY 0.1 SEC OF CONTROL.  HOWEVER, IF THE RESTART OCCURS AFTER THE SECT
# STARTED, THEN THE ROLL SYSTEM WILL MISS ONE CYCLE.
# THIS IS NECESSARY UNDER THE GROUND-RULE THAT NO JET COMMANDS SHALL BE LESS THAN 14 MS.

                EBANK=  AOG
                BANK    15
                SETLOC  ETRYDAP
                BANK

                COUNT   15/DAPEN

BODYRATE        CA      AMG             # THESE ARE 2'S COMPL NOS, BUT USE ANYWAY.
                TC      SPCOS
                TS      COSM

                CA      AOG             # C(AOG) = AOG/180
                TC      SPSIN           # SINO
                TS      SINO            # SINO = SIN(AOG)

                EXTEND
                MP      COSM
                TS      SINOCOSM        # SO CM

                CA      AOG
                TC      SPCOS           # COSO
                TS      COSO

                EXTEND
                MP      COSM
                TS      COSOCOSM        # CO CM

# PITCHDOT:  Q TCDU/180 = IDOT TCDU/180 COSO COSM + MDOT TCDU/180 SINO

                CS      -DELAMG
                EXTEND
                MP      SINO
                DXCH    JETEM           # 2 LOCS
                CS      -DELAIG
                EXTEND
                MP      COSOCOSM
```

```
DAS     JETEM
CA      JETEM
XCH     OLDELQ
TC      RATEAVG
TS      QREL            # PITCHDOT = Q TCDU/180
```

Uses -DELAIG 214, -DELAMG 214, A 80, AMG 214, AOG 214, COSM 216, COSO 216, COSOCOSM 216, COUNT 142, EBANK 80, ETRYDAP 61, JETEM 216, OLDELQ 214, P 188, Q 80, QREL 214, RESTART 57, SINO 216, SINOCOSM 216, and TC 169.

1491 ⟨*Page CM1071* 1491⟩≡ (1480 2659)

```
# YAWDOT:  R TCDU/180 = -IDOT TCDU/180 COSM SINO + MDOT TCDU/180 COSO

                CS      -DELAMG
                EXTEND
                MP      COSO
                DXCH    JETEM
                CA      -DELAIG
                EXTEND
                MP      SINOCOSM
                DAS     JETEM
                CA      JETEM
                XCH     OLDELR
                TC      RATEAVG
                TS      RREL            # YAWDOT = R TCDU/180

# ROLLDOT:  P TCDU/180 = ODOT TCDU/180 + IDOT TCDU/180 SINM

                CA      AMG
                TC      SPSIN
                TS      SINM

                EXTEND
                MP      -DELAIG
                TS      JETEM
                CA      ZERO
                DDOUBL                  # ROUND L INTO A
                AD      -DELAOG
                AD      JETEM
                CS      A
                TS      JETEM
                XCH     OLDELP
                TC      RATEAVG
                TS      PREL            # ROLLDOT = P TCDU/180

                                        # IF GAMDOT < 0.5 DEG/SEC, THEN GAMDOT =0

                CCS     GAMDOT
                TC      +2
                TC      NOGAMDUT
                CS      ROLL/180
                TC      SPSIN
                EXTEND
                MP      GAMDOT
                TS      JETEM +1        # -SR GAMDOT
                EXTEND
```

```
                MP      SINTRIM         # SIN(-20)      (FOR NOMINAL L/D = .3)
                ADS     PREL            # PREL TCDU/180=(P-SALF SR GAMDOT)TCDU/180

                CA      ROLL/180
                TC      SPCOS
```

Uses -DELAIG 214, -DELAMG 214, -DELAOG 214, A 80, AMG 214, COSM 216, COSO 216, D 226, GAMDOT 216, JETEM 216, L 80, L/D 226, OLDELP 214, OLDELR 214, P 188, PREL 214, ROLL/180 214, RREL 214, SINM 216, SINO 216, SINOCOSM 216, SR 80, and TC 169.

1492 ⟨*Page CM1072* 1492⟩≡ (1480 2659)

```
                COM
                EXTEND
                MP      GAMDOT
                ADS     QREL            # QREL TCDU/180=(Q-CR GAMDOT) TCDU/180

                CS      JETEM +1        # B( ) = -SR GAMDOT
                EXTEND
                MP      COSTRIM         # COS(-20)      (FOR NOMINAL L/D = .3)
                ADS     RREL            # RREL TCDU/180=(R+CALF SR GAMDOT)TCDU/180

NOGAMDUT        CA      BIT12           # CMDAPARM = 93D BIT 12
                MASK    CM/FLAGS
                EXTEND
STBYDUMP        BZF     TASKOVER        # DAP NOT ARMED.

                CA      POSMAX          # PICK UP AT ATTRATES IN 10 MS OR SO.
                TS      TIME5

                EXTEND
                DCA     ATDOTCAD
                DXCH    T5LOC
                                        # DOES NOT PROTECT TEMK, SQ IN SPSIN/COS

                TC      TASKOVER

                EBANK=  AOG
ATDOTCAD        2CADR   ATTRATES
```

Uses AOG 214, CMDAPARM 117, D 226, EBANK 80, GAMDOT 216, JETEM 216, L 80, L/D 226, Q 80, QREL 214, RREL 214, SQ 156, SR 80, T5LOC 163, TC 169, TEMK 156, and TIME5 80.

1493 ⟨*Page CM1073* 1493⟩≡ (1480 2659)

```
# CALCULATE BODY ATTITUDE RATES AND INTEGRATE TO OBTAIN ATTITUDE ANGLES.
#
#       CB PHIDOT TCDU/180 = (CA PREL + SA RREL) TCDU/180
#       BETADOT TCDU/180 = (-SA PREL + CA RREL) TCDU/180
#       ALFADOT TCDU = (QREL + SB PHIDOT) TCDU/180

ATTRATES        LXCH    BANKRUPT        # CONTINUE HERE VIA T5
                EXTEND                  # TASK MAY BE SKIPPED AT RESTART.
                QXCH    QRUPT
                CA      SR
                DOUBLE
                TS      CM/SAVE
                                        # DOES NOT PROTECT TEMK, SQ IN SPSIN/COS

                CA      QREL
                AD      ALFA/180
                TC      ANGOVCOR
                TS      ALFA/180
                TC      SPCOS
                TS      CALFA           # CALFA
                TS      PHIDOT

                EXTEND
                MP      PREL
                XCH     PHIDOT          # CA PREL
                EXTEND
                MP      RREL            # CA RREL
                TS      BETADOT

                CA      ALFA/180
                TC      SPSIN
                TS      SALFA           # SIN(ALFA)

                EXTEND
                MP      RREL            # SA RREL
                ADS     PHIDOT          # CB PHIDOT, SAVED.

                CS      SALFA
                EXTEND
                MP      PREL
                ADS     BETADOT         # SAVE BETADOT TCDU/180
                ADS     BETA/180        # BETA DONE.

                TC      SPSIN
                EXTEND
```

```
MP      PHIDOT          # NEGLECT CB IN CB PHIDOT
AD      ALFA/180
TC      ANGOVCOR
TS      ALFA/180        # ALFA DONE.
```

Uses ALFA/180 214, BANKRUPT 80, BETA/180 214, BETADOT 214, CALFA 216, CM/SAVE 218, PHIDOT 214, PREL 214, QREL 214, QRUPT 80, RESTART 57, RREL 214, SALFA 216, SAVE 191, SQ 156, SR 80, TC 169, and TEMK 156.

1495 ⟨*Page CM1074* 1495⟩≡ (1480 2659)

```
                COM
                AD      ALFACOM
                TC      ANGOVCOR        # JUST IN CASE ...
                TS      AK1
                TS      QAXERR          # FOR PITCH FDAI AND EDIT.

                CA      PHIDOT          # PHIDOT TCDU/180, NEGLECTING CB
                AD      ROLL/180
                TC      ANGOVCOR
                TS      ROLLTM          # ROLL/180 FOR TM.
                TS      ROLL/180        # ROLL DONE.

# START YAW AUTOPILOT HERE.  RATE DAMPING WITH ENFORCED COORDINATED ROLL MANEUVER.

                CS      BETA/180        # IF IN ATM, SAVE 'RAXERR' FOR TM DNLST.
                AD      BETACOM
                TS      RAXERR          # IF OUTSIDE ATM, USE TM REGISTER 'RAXERR'
                                        # AS A TEMPORARY.  (DAP OPERATION IS IN INTERRUPT, SO
                                        # IS OK.)  FINAL C(RAXERR) AT END OF DAP CYCLE WILL
                                        # BE R-AXIS ERROR.

                CA      BIT3            # .05GSW = 102D BIT3    SW=0, LESS .05G
                MASK    CM/FLAGS        # SWITCH =1, GREATER THAN .05 G
                EXTEND
                BZF     EXDAP           # IF G LESS THAN .05
                CS      ONE             # IF G GEQ  THAN .05
                TS      CMDAPMOD        # SAVE -1 FOR USE IN CM/RCS

                TS      AK1             # TO ZERO PITCH AND YAW FDAI NEEDLES
                TS      AK2             # IN ATM.  (MODE =-1)

                CS      PREL            # YAW ERROR = RREL - PREL TAN(ALFA)
                EXTEND
                MP      SINTRIM         # LET SIN(-20) BE APPROX FOR TAN(-20)
                AD      RREL
                TC      2D/SDZ          # GO TEST DZ.  GET TAG: +0 IF IN DZ
                INDEX   A               # +/- 1 IF NOT
                CAF     YJETCODE

                TS      JETEM

# START PITCH AUTOPILOT HERE.  RATE DAMPING ONLY.

                CA      QREL
                TC      2D/SDZ
```

```
EXDAPIN         INDEX   A               # COME HERE FROM EX ATM DAP
                CAF     P/RJCODE
                ADS     JETEM           # COMBINE ALL NEW BITS.

                EXTEND                  # DOES NOT REQUIRE SAVING OLD CODES.
```

Uses .05GSW 121, A 80, AK1 200, AK2 200, ALFACOM 216, BETA/180 214, BETACOM 216, CMDAPMOD 214, JETEM 216, MODE 145, P 188, PHIDOT 214, PREL 214, QAXERR 218, QREL 214, RAXERR 218, ROLL/180 214, ROLLTM 214, RREL 214, SAVE 191, TC 169, and TM 219.

1496 ⟨*Page CM1075* 1496⟩≡ (1480 2659)

```
                WRITE   PYJETS          # SET PYCHAN TO DESIRED BIT CONFIG.

                CCS     JETAG
                TC      CM/RCS
                TC      CM/FDAI
                TC      CM/FDAIR -1     # (JETAG=-1 EQUIVALENT TO CMDAPMOD=+1)
```

Uses CMDAPMOD 214, JETAG 214, PYJETS 87, and TC 169.

1497 ⟨*Page CM1076* 1497⟩≡ (1480 2659)

```
# DEAD ZONE LOGIC USED BY ENTRY DIGITAL AUTOPILOTS.

3DDZ            CCS     A               # YAWLIM=1.0-3/180=16384-273=16111
                AD      YAWLIM
                TCF     DZCOM
                AD      YAWLIM
                TCF     DZNOCOM

                                        # BIASED DZ FOR EXT ATM DAP.
BIASEDZ         TS      JETEM2          # SAVE RATE/180.  ERROR/180 IS IN L.
                CCS     A               # START ERROR DZ.
                CS      CM/BIAS         # = .6/180
                TCF     +2
                CA      CM/BIAS
                AD      L               # BIAS THE ERROR.
                LXCH    Q               # SAVE CALLER'S RETURN ADDRES.
                TC      3DDZ            # GO GENERATE THE ERROR BIT.
                DXCH    L               # BIT TO L, RESTORE CALLER'S Q.
4D/SDZ          CCS     JETEM2          # CAME HERE IN EXT ATM.  C(L) = ERROR BIT
                AD      4D/SLIM         # IF RATE GEQ 4D/S, SET L=0 AND TAKE
                TCF     +2              # JET BITS ACCORDING TO SGN OF RATE.
                AD      4D/SLIM
                TS      A
                TCF     +2              # RATE OK. CONTINUE
                ZL                      # RATE GEQ 4 D/S.  OVER RIDE ERROR BIT
                XCH     JETEM2          # AND CONTINUE TO GET SIGN.

2D/SDZ          CCS     A               # COME HERE TO TEST IF A WITHIN 2DEG/S DZ
                AD      YDOTLIM         # 1.0 - YDOT DZ         (OR PDOT)
                TCF     +3
                AD      YDOTLIM         # YDOT DZ = 2 DEG/SEC
DZCOM           COM
DZNOCOM         TS      JETEM +1        # GENERATE TAG, SET C(A)= -+1 OUTSIDE DZ
                CA      ZERO            # SET C(A) = +0 INSIDE
                TC      Q
```

Uses A 80, BIAS 211, D 226, JETEM 216, JETEM2 218, L 80, Q 80, SAVE 191, TC 169, and ZONE 163.

1498 ⟨*Page CM1077* 1498⟩≡ (1480 2659)

```
# EXTRA ATMOSPHERIC DIGITAL AUTOPILOT
#
# 1.    IF ABS(CALF) -C(45) POS, USE                    IF CALFA POS, CMDAPMOD= +0
#       BETA:   YAW ERROR = SGN(CALF) (BETACOM -BETA)   IF CALFA NEG, CMDAPMOD= -0
#                    RATE = BETADOT                     IF CMDAPMOD = -0, RATE = RREL
#                 R-AXIS = CONTROL
#
#       ROLL:  ROLL ERROR = SGN(CALF) (ROLLC - ROLL)    IF CMDAPMOD = -0, RATE DAMP O
#                    RATE = PREL
#                 P-AXIS = CONTROL
#
# 2.    IF C(45) GEQ CALFA GEQ -C(45), USE              CMDAPMOD = +1
#       BETA:  ROLL ERROR = SGN(-SALF) (BETACOM -BETA)
#                    RATE = BETADOT
#                 P-AXIS = CONTROL
#
#       ROLL:   YAW ERROR = SGN(SALF) (ROLLC - ROLL)    RATE DAMP ONLY.
#                    RATE = RREL
#                 R-AXIS = CONTROL
#
# 3.    FOR ALL CASES, USE
#       ALFA: PITCH ERROR = (ALFACOM - ALFA)
#                    RATE = QREL
#                 Q-AXIS = CONTROL

EXDAP           TS      CMDAPMOD        # +0 FOR NOW
                CCS     CALFA
                AD      C45LIM          # =1.0-COS(45)
                TCF     +2
                AD      C45LIM
                TS      A
                TCF     EXDAP2          # HERE IF ABS(CALFA) L COS(45)

                CCS     CALFA           # |CALFA| > 0.707
                TCF     +1              # CONTINUE IF POS; GO TO EXDAP4 IF NEG.

                CCS     P63FLAG         # VALID VALUES ARE:  -1, +1, +0.
                TC      EXDAP4
                TC      +2
                TC      EXDAP4
                TC      PHASCHNG        # SINGLE PASS THROUGH HERE.
                OCT     40334
                CS      ONE
                TS      P63FLAG         # SET FLAG TO ASSURE SINGLE PASS.
                CA      NSEC
```

```
TC      WAITLIST
EBANK=  AOG
2CADR   WAKEP62         # CALL TO TERMINATE P62 IN N SEC.
```

Uses A 80, ALFACOM 216, AOG 214, BETACOM 216, BETADOT 214, CALFA 216, CMDAPMOD 214, EBANK 80, L 80, N 206, P 188, P63FLAG 216, PREL 214, Q 80, QREL 214, ROLLC 214, RREL 214, and TC 169.

1500 ⟨*Page CM1078* 1500⟩≡ (1480 2659)

```
                                        # 65 DEG/ 3DEG/SEC = 21 SEC NOMINAL
                                        # TRANSIT TIME FROM ALFA=45 TO ALFA TRIM.

EXDAP4          CCS     JETAG           # ROLLJET INTERFACE TEST BETWEEN .1 SEC
                TCF     EXDAP3          # DAP AND THE 2 SEC CM/RCS DAP
                TCF     EXDAP3
                CA      ZERO
                EXTEND                  # TURN OFF ROLL JETS IF ON AND WAIT
                WRITE   ROLLJETS        # UNTIL START OF 2 SEC CM/RCS CYCLE
                TS      JETAG           # RESTORE PROPER VALUE +0

                                        # ROLL FDAI WILL BE IN ERROR UNTIL NEXT CM/RC
EXDAP3          CCS     CALFA           # HERE IF ABS(CALFA) GEQ COS(45)
                CA      RAXERR          # C()= BETACOM - BETA/180
                TCF     EXDAP1
                CS      ZERO
                TS      CMDAPMOD        # FOR CM/RCS
                CS      RAXERR          # COMPLEMENT OF YAW ERROR.
EXDAP1          TS      RAXERR          # FOR YAW FDAI
                TS      AK2             # WANT RAXERR FOR TM.
                TS      L
                CCS     CMDAPMOD        # COORDINATE BETA CONTROL.
                TC      +3              # C(CMDAPMOD) CAN BE +1, +0, OR -0.
                CA      ONE             # USE BETADOT TO COORD IN MODE +0
                INDEX   A               # OTHERWISE USE RREL.
                CA      RREL
                TC      BIASEDZ         # GO TEST DZ  +0 IF IN DX, +-1 OTHERWISE
                                        # IF GEQ 4D/S, SET ERROR BIT IN L=0
                EXTEND
                ROR     LCHAN           # L HAS BETA BIT
                INDEX   A
                CAF     YJETCODE
                TS      JETEM

                CA      QAXERR          # ALFA ERROR.
                TS      L
                CA      QREL            # FOR ALPHADOT USE QREL
                TC      BIASEDZ
                EXTEND
                ROR     LCHAN
                TCF     EXDAPIN         # CONTINUE ON IN DAP

EXDAP2          INCR    CMDAPMOD        # SET CMDAPMOD TO +1

                CS      ONE             # INDICATE CHANGE FROM .1 SEC UPDATE TO
```

```
TS      JETAG           # TO 2 SEC FOR ROLL JETS.  (IF CMDAPMOD
                        # =0 AND JETAG =-1, QUENCHES JETS IF ON)

CCS     P63FLAG         # IF FLAG WAS +1, SET =0.
TS      P63FLAG
```

Uses A 80, AK2 200, BETA/180 214, BETACOM 216, BETADOT 214, CALFA 216, CMDAPMOD 214, JETAG 214, JETEM 216, L 80, LCHAN 87, MODE 145, P63FLAG 216, QAXERR 218, QREL 214, RAXERR 218, ROLLJETS 87, RREL 214, TC 169, and TM 219.

1502 ⟨*Page CM1079* 1502⟩≡ (1480 2659)

```
                NOOP

                CCS     SALFA           # BETA CONTROL WITH P JETS
                CS      RAXERR          # B()= BETACOM - BETA/180
                TCF     +2
                CA      RAXERR
                TS      PAXERR1         # TEMP SAVE.  ERROR/180
                EXTEND
                MP      HALF            # CM/FDAI EXPECTS ERROR/360.
                XCH     PAXERR1         # ERROR/360 FOR FDAI, GET ERROR/180.
                TS      L
                CCS     SALFA
                CS      BETADOT         # USE BETADOT TO COORD IN MODE +1
                TC      +2
                CA      BETADOT
                TC      BIASEDZ
                EXTEND
                ROR     LCHAN
                INDEX   A
                CAF     P/RJCODE        # GET ROLL CODE
                EXTEND                  # ROLL CONTROL WITH YAW JETS.
                WRITE   ROLLJETS        # WE'LL SKIP REGULAR ROLL SYST

                CA      ROLLHOLD        # ROLL/180 AT CM/DAPON TIME.
                EXTEND
                MSU     ROLL/180        # 1'S COMPL, BUT SO WHAT'S A BIT?
                TS      L               # FORCE A LIMIT CYCLE IN YAW RATE.
                CCS     SALFA
                CA      L               # TO REMOVE ITS BIASING EFFECT ON M DOT.
                TC      EXDAP1
                CS      L
                TC      EXDAP1

NSEC            DEC     2100            # 65 DEG/ 3 DEG/SEC
                                        # IF NSEC IS CHANGED, REMEMBER TO CHANGE 4.33
4D/SLIM         DEC     16348           # 1.0 -4/180 D/S = 4/1800 EXP 14
YDOTLIM         DEC     16366           # =1.0 - YDOT DZ= 16384 -18
                                        # YDOT DZ = YDOT TCDU/180 = 2/1800 EXP 14

CM/BIAS         DEC     55              # =.6/180 B14 = 55
YAWLIM          DEC     16055           # YAWLIM=1.0-3.6/180=16384-329=16055
C45LIM          DEC     .29289          # =1.0-COS(45)

SINTRIM         DEC     -.34202         # SIN(-20)      (FOR NOMINAL L/D = .3)
COSTRIM         DEC     .93969          # COS(-20)      (FOR NOMINAL L/D = .3)
```

```
# TO MAKE DAP INSENSITIVE TO PITCH ERRORS DUE TO ACCUMULATED NAV ERRORS, USE NOMINAL VALUE (-20
# USED DURING ATMOSPHERIC COORDINATION.  OUTSIDE ATMOSPHERE, NAV ERRORS WILL BE SLIGHT, BUT ALR
# FROM TRIM, SO USE ON-BOARD ESTIMATES.
```

Uses A 80, BETA/180 214, BETACOM 216, BETADOT 214, BIAS 211, CODE 140, D 226, L 80, L/D 226, LCHAN 87, MODE 145, P 188, PAXERR1 214, RAXERR 218, ROLL/180 214, ROLLHOLD 216, ROLLJETS 87, SALFA 216, SAVE 191, TC 169, and TEMP 191.

1503 ⟨*Page CM1080* 1503⟩≡ (1480 2659)

```
# JET CODE TABLES FOLLOW

                OCTAL   00120          # POS Y
YJETCODE        OCTAL   00000          # RCS JET BITS
                OCTAL   00240          # NEG Y
                OCTAL   00005          # POS R JET BITS        ALSO POS P JET BITS
P/RJCODE        OCTAL   00000
                OCTAL   00012          # NEG R                 ALSO NEG P
```

Uses CODE 140 and P 188.

1504 ⟨*Page CM1081* 1504⟩≡ (1480 2659)

```
# RCS           THIS SECTION IS ENTERED EACH 2 SEC BY WAITLIST CALL FOLLOWING A DELAY
# THE TASK  SETJTAG  SETS A FLAG IN  JETAG  TO SIGNIFY THAT ROLL UPDATE IS DUE.  IN P
# EXECUTED AND JETAG WILL CAUSE  CM/RCS  TO ACT ON ROLLC IMMEDIATELY THEREAFTER.  THE
# TASK SAVES THE CALL TIME SO THAT CM/RCS CAN DETERMINE HOW MUCH OF THE 2 SEC INTERVA
# NEXT UPDATE.

SETJTAG         CS      TIME1           # SAVE NOMINAL UPDATE TIME FOR SYNCH
                TS      TUSED
                                        # THE 5 CS APPEARS IN TIMETST.
                CA      ONE             # RATHER THAN INCR, FOR SAFETY
                TS      JETAG           # SET JETAG=1 TO CAUSE CM/RCS TO BE
                TC      PHASCHNG
                OCT     00001

                TC      TASKOVER        # EXECUTED AFTER NEXT BODYRATE UPDATE

# PREDICTIVE ROLL SYSTEM        ENTRY STEERING PROVIDES ROLL COMMAND IN LOC ROLLC.  T
# TRAJECTORY TO THE ORIGIN IN PHASE PLANE (X,V).  PROGRAM ENTERS JET ON AND OFF CALLS
# THE DESIRED TRAJECTORY.  ONLY THOSE CALLS WHICH CAN BE EXECUTED WITHIN THE INTERVAL
# WTLST, THE REMAINDER ARE RECONSIDERED AT NEXT UPDATE.

HALFPR          EQUALS  NEG1/2 +1

                                        # CLEAR JETAG BEFORE TIMETST.  SET TO +0 TO S
                                        # ROLL DAP CALLED.  IN EVENT OF RESTART, BODY
                                        # MAY MISS A CYCLE.  CM/RCS WILL MISS A CYCLE
                                        # IF A RESTART OCCURS AFTER TIMETST COMMENCES

CM/RCS          CS      ONE
                TS      JNDX            # SET NDX FOR POS ROLL, AND CHANGE LATER

                CS      2T/TCDU         # ROLLDOT = DELAOG + DELAIG SINM =DELR
                EXTEND
                MP      PREL            # DELR/180 = RDOT TCDU/180 = RDOT/1800
                AD      L               # -2 RDOT T/180 IN L
                TS      -VT/180         # SAVE -2VT/180 HERE

                CS      ROLL/180
                TS      SR              # SAVE (-R/180) /2

                CS      CM/FLAGS
                MASK    BIT4            # LATSW = 101D BIT4
                EXTEND                  # ROLL OVER TOP $
                BZF     GETLCX          # NO, TAKE SHORTEST PATH
                ADS     CM/FLAGS        # YES, ENFORCE ROLL OVER TOP.. (BIT =0)
```

```
CA      ROLLC           # (ROLLC/180) /2
AD      SR              # -(R/180) /2
XCH     LCX/360         # DIFFERENT X REQD HERE.  DISCONT AT 180.
TCF     COMPAT          # POSSIBLE OVFL ABOVE.
```

Uses -VT/180 216, A 80, COMMAND 169, JETAG 214, JNDX 216, L 80, LATSW 121, LCX/360 216, LOC 145, PREL 214, RDOT 229, RESTART 57, ROLL/180 214, ROLLC 214, SAVE 191, SINM 216, SR 80, TC 169, TIME1 80, TUSED 214, and V 229.

1506 ⟨*Page CM1082* 1506⟩≡ (1480 2659)

```
GETLCX          CA      POS1/2          # FORM RCOM/360
                DOUBLE
                AD      ROLLC
                XCH     LCX/360         # IGNORE POSSIBLE OVFL.

                CA      SR              # FORM -R/360
                AD      NEG1/2
                AD      NEG1/2          # IGNORE OVFL
                XCH     LCX/360         # -R/360
                ADS     LCX/360         # LCX/360 = RCOM/360 - R/360  RANGE (-1,1)

# DOES SGN(-VT) (VT/180) (VT/180) (180/(4 A1 TT COSALFA)) + X/360 + SGN(X) / 2    OVF

                CCS     -VT/180         # TAKE SHORTEST ANGULAR PATH
                AD      ONE             # (BASED ON SINGLE JET ACCELERATION)
                TCF     +2
                AD      ONE
                EXTEND
                MP      -VT/180         # C(-VT/180) = -2 VT/180
                EXTEND
                MP      1/16A1          # = 180/(16 A1 TT)
                EXTEND
                DV      CALFA
                TS      L
                CCS     LCX/360
                CAF     POS1/2
                TCF     +2
                CS      POS1/2
                AD      LCX/360         # IS LCX/360 LESS THAN 180 DEGS  $
                AD      L
                TS      L
                TCF     COMPAT          # YES, GO ON.
TRTAGXPI        INDEX   A               # NO, SHIFT X BY - SGN(X) 2 PI
                CS      HALFPR          # +A YIELDS -1/2
                DOUBLE
                ADS     LCX/360

COMPAT          CA      LCX/360         # CORRECT FOR ASSUMED COORD TURN.
                EXTEND
                MP      CALFA           # COS ALFA
                TS      LCX/360         # SCALED LCX OK HERE.

                CCS     CMDAPMOD        # FOUR POSSIBILITIES HERE
                TC      DZCALL1         # EXIT, SETTING JETAG=0. (C(A)=0)
                                        # ALL 3 AXES ALREADY DONE.
```

```
TC      +1              # G LESS THAN .05.  CA POS. CONTINUE
CA      LCX/360         # G GEQ .05.  CONTINUE IN CM/RCS
TS      LCX/360         # CMDAPMOD=-0.  DAMPING ONLY. SET LCX=0
TS      ERRORZ          # INITIAL ROLL ERROR (UNREFLECTED) FOR TM.
TS      PAXERR1         # SAVE LCX FOR FDAI AND EDIT.  (/360)
```

Uses -VT/180 216, A 80, A1 229, CALFA 216, CMDAPMOD 214, DV 241, ERRORZ 211, JETAG 214, L 80, LCX/360 216, PAXERR1 214, RANGE 179, ROLLC 214, SAVE 191, SR 80, TC 169, and TM 219.

1508 ⟨*Page CM1083* 1508⟩≡ (1480 2659)

```
                CA      -VT/180         # GET - 2 VT/180
                TS      SR
                CA      SR              # GET -VT/180, LEAVE -VT/360 IN SR FOR DZ
                TS      -VT/180E        #                       DIAGNOSTIC ****
                XCH     -VT/180         # NOW CONTENTS OF -VT/180 AS LABELED
                EXTEND
                MP      -VT/180         # B(A) = -ZVT/180
                EXTEND
                MP      180/8ATT
                TS      VSQ/4API

# IS SGN(VT) ( (180/4A1 TT) VT/180 VT/180 - .5 BUFLIM/360 ) -X/360 -.5 BUFLIM/360  PO

WHICHALF        DOUBLE                  # FOR SECOND BURN, A1
                COM
                AD      BUFLIM          # =BUFLIM/(2 360)
                TS      L
                CCS     -VT/180
                CS      L
                TCF     +2
                CA      L
                AD      LCX/360
                AD      BUFLIM
                EXTEND
                BZMF    REFLECT         # POINT (X,V) IN LHP.

# IS SGN(VT) ( (180/4A1 TT) VT/180 VT/180 - .5 BUFLIM/360 ) -X/360 + .5 BUFLIM/360  N

                COM
                AD      BUFLIM
                AD      BUFLIM
                EXTEND
                BZMF    DZ1             # POINT (X,V) IN RHP

# IS POINT WITHIN VELOCITY DZ?

                CS      VSQMIN          # IS VSQ/4API - (VSQ/4API) MIN NEG?
                AD      VSQ/4API
                EXTEND
                BZMF    DZCALL          # YES.

# POINT IS IN BUFFER ZONE.  THRUST TO X AXIS.

                CS      JNDX
                TS      JNDX1
```

```
                TC      OVRLINE1

  REFLECT       CS      -VT/180         # RELFECT LHP INTO RHP REL TO TERM CONTR
                TS      -VT/180
                TS      SR              # -VT/360 SAVED FOR DZ.
```

Uses -VT/180 216, -VT/180E 218, A 80, A1 229, JNDX 216, JNDX1 216, L 80, LCX/360 216, SR 80, TC 169, THRUST 85, V 229, VSQ/4API 216, and ZONE 163.

1510 ⟨*Page CM1084* 1510⟩≡ (1480 2659)

```
                CS      LCX/360
                TS      LCX/360
                CS      JNDX
                TS      JNDX

# IS VSQ/4API - (VSQ/4API) MIN NEG?

DZ1             CS      VSQMIN          # IS VSQ/4API - (VSQ/4API) MIN NEG  $
                AD      VSQ/4API
                EXTEND
                BZMF    DZ2             # YES, GO TEST FURTHER.
                TCF     MAXVTEST        # NO

# IS X/360 - XMIN/360 -VT/360 NEG?

DZ2             CS      XMIN/360        # XMIN/360 = 4/360
                AD      LCX/360
                AD      SR              # C(SR) = -VT/360
                EXTEND                  # IS X/360 - XMIN/360 -VT/360 NEG  $
                BZMF    DZCALL          # YES, IN DZ.  EXIT SETTING JETAG=0.

# IS XD/360 - VM/360K - XS/360 POS?

MAXVTEST        CS      JNDX
                TS      JNDX1           # NOW CAN SET JNDX1 FOR TON2 JETS.
                CS      XS/360          # XS/360 = (XMIN -YMIN/K) /360
                AD      VSQ/4API
                AD      LCX/360
                TS      XD/360          # XD/360= X/360 +VSQ/4API   X INTERCEPT
                                        # BUT C(XD/360) = (XD - XS) /360
                AD      -VM/360K        # X INTERCEPT FOR MAX V (VM)
                COM
                EXTEND
                BZMF    MAXVTIM1        # YES, THRUST TO VM
                CA      XD/360
                EXTEND
                MP      KTRCS
                DDOUBL                  # GO SAVE PREDICTED DRIFTING VELOCITY.

                TC      GETON1          # INSURE THAT Q IS POS AS TAG.
MAXVTIM1        EXTEND
                ZQ                      # SET +Q AS TAG
                CS      -VMT/180
GETON1          TS      VDT/180         # VDT/180 OR VMT/180
                AD      -VT/180
```

```
DOUBLE
EXTEND
MP      180/8ATT
TS      TON1            # TON1 / 4T
```

Uses -VT/180 216, JETAG 214, JNDX 216, JNDX1 216, LCX/360 216, Q 80, SAVE 191, SR 80, TC 169, THRUST 85, TON1 218, TON2 216, V 229, VDT/180 218, VSQ/4API 216, and XD/360 216.

1512 ⟨*Page CM1085* 1512⟩≡ (1480 2659)

```
                EXTEND
                BZMF    OVRLINE
                TC      GETON2          # RESET Q POS IF CAME FROM MAXVTIM1

OVRLINE         CCS     Q
                TCF     OVRLINE1
MAXVTIM2        CA      JNDX1           # ABOVE VM, SO THRUST DOWN
                TS      JNDX
                CS      TON1
                TCF     OVRLINE2 +1

OVRLINE1        CS      -VT/180         # DRIFT AT V
                TS      VDT/180
OVRLINE2        CA      ZERO
                TS      TON1
GETON2          CA      VDT/180         # VDT/180, OR VMT/180 OR VT/180
                DOUBLE
                EXTEND
                MP      180/8ATT
                DOUBLE                  # FOR SECOND BURN, A1
                TS      TON2            # = TON2 / 4T

                COM
                EXTEND
                BZMF    GETOFF
                TS      TON2
                CA      JNDX
                TS      JNDX1

GETOFF          CS      TON2            # TON2 / 4T
                EXTEND
                MP      VDT/180         # VDT/180, OR VT/180, OR VMT/180.
                TS      XD/360          # USE AS TEMP
                CS      VDT/180
                EXTEND
                BZF     TOFFOVFL        # OMIT THE DIVIDE IF DEN = 0.
                AD      -VT/180
                EXTEND
                MP      TON1            # TON1 /4T
                AD      XD/360          # TEMP = -VDT/180 / 2 TON2
                AD      LCX/360
                ZL
                XCH     L               # TEST THE DIVIDE
                EXTEND
                DV      VDT/180
```

```
                EXTEND
                BZF     GETOFF2         # DIVIDE OK

TOFFOVFL        CA      2JETT           # OVFL, USE  2T  FOR CONVENIENCE.
                TCF     TIMSCAL
```

Uses -VT/180 216, A1 229, DV 241, JNDX 216, JNDX1 216, L 80, LCX/360 216, Q 80, TC 169, TEMP 191, THRUST 85, TON1 218, TON2 216, V 229, VDT/180 218, and XD/360 216.

1513 ⟨*Page CM1086* 1513⟩≡ (1480 2659)

```
GETOFF2         XCH     L               # GET NUMERATOR.
                EXTEND
                DV      VDT/180         # C(A) = TOFF / 2T
                EXTEND
                MP      2JETT
TIMSCAL         TS      TOFF            # IN CS

                CAF     4JETT
                EXTEND
                MP      TON1            # C(TON1) = TON1 / 4T
                TS      TON1            # IN CS

                CAF     4JETT
                EXTEND
                MP      TON2            # C(TON2) = TON2 / 4T
                TS      TON2            # IN CS

                CA      ZERO            # CANNOT REDO AFTER TIMETST.  TUSED GONE
                TS      JETAG           # SET +0 TO SHOW ROLL DAP CALLED.

                                        # CAUSE THE TM OF BODY RATES VIA UPBUFF TO BE
                                        # INITIALIZED.  ALSO CAUSE NEEDLES TO BE DONE ON EXIT
                                        # AND ON ALTERNATE PASSES THROUGH CM/DUMPR.

                CA      ONE
                TS      SW/NDX
```

Uses A 80, DV 241, JETAG 214, L 80, SW/NDX 145, TM 219, TOFF 216, TON1 218, TON2 216, TUSED 214, UPBUFF 145, and VDT/180 218.

1514 ⟨*Page CM1087* 1514⟩≡ (1480 2659)

```
# TIMETEST SECTION FOR RCS
#
# ENTER WITH THREE TIME INTERVALS AND THE CORRESPONDING JET CODE INDEXES IN ERASABLE
# JNDX1.  SECTION PROCESSES TIME INTERVALS FOR WTLST CALLS AND ASSURES THAT WTLST CAI
# (1) FOR POS INTERVALS GREATER THAN A SPECIFIED MINIMUM (HERE CHOSEN AS 2 CS) AND
# (2) FOR THE INTERVALS THAT WILL BE EXECUTED WITHIN THE TIME REMAINING IN THE SAMPLE
# TIMETST ESTABLISHES 6 LOCS CONTAINING JET CODES AND CORRESPONDING TIME INTERVALS.
# TOFF, TBITS, TON2, T2BITS.  OF THESE THE FIRST 2 LOCS ARE TEMPORARY, FOR IMMEDIATE
# SECTION JETCALL BELOW PROCESSES THIS LIST.

TIMETST         CA      TIME1           # CORRECT FOR POSSIBLE TIME1 OVFL.
                AD      POS1/2
                AD      POS1/2          # OVFL GUARANTEED.
                ADS     TUSED           # B(TUSED) =-TUSED =-OLTIME1

                CA      -T-3            # =-T +2 -5 (SEE SETJTAG)
                                        # THE +2 REQUIRED FOR PROPER BRANCH.
                ADS     TUSED           # TUSED = TIME(K)-TIME(K-1)-T+2

                CS      TWO             # USE 2 SINCE TIME3 UNCERTAIN TO 1
                AD      TON1
                EXTEND
                BZMF    TIMETST1
                INDEX   JNDX
                CAF     P/RJCODE
                TS      T1BITS

                CA      TON1
                ADS     TUSED
                EXTEND
                BZMF    TOFFTEST
                CA      ZERO
                TCF     TIMETST3
TIMETST1        CS      ONE
                TS      TON1
TOFFTEST        CS      TWO
                AD      TOFF
                EXTEND
                BZMF    TIMETST2
                CA      TOFF
                ADS     TUSED
                EXTEND
                BZMF    TON2TEST
                CA      ZERO
                TCF     TIMETST4
```

```
TIMETST2        CS      ONE
                TS      TOFF
TON2TEST        CS      TWO
                AD      TON2
                EXTEND
                BZMF    TIMETST5
```

Uses A 80, CODE 140, JNDX 216, JNDX1 216, P 188, T1BITS 218, T2BITS 216, TBITS 216, TIME1 80, TIME3 80, TOFF 216, TON1 218, TON2 216, and TUSED 214.

1516 ⟨*Page CM1088* 1516⟩≡ (1480 2659)

```
                INDEX   JNDX1
                CAF     P/RJCODE
                TS      T2BITS
                CA      TON2
                ADS     TUSED
                EXTEND
                BZMF    JETCALL1
                CA      ZERO
                TCF     TIMETST5 +1
TIMETST3        TS      TON1
                CS      ONE
TIMETST4        TS      TOFF
TIMETST5        CS      ONE
                TS      TON2

# SECTION  JETCALL  EXAMINES CONTENTS OF JET TIMES IN LIST, ESTABLISHES WTLST ENTRIES
# JET CODES.  A POSITIVE NZ NUMBER IN A TIME REGISTER INDICATES THAT A WTLST CALL IS
# EXECUTED.  A +0 INDICATES THAT THE TIME INTERVAL DOES NOT APPLY, BUT THE CORRESPOND
# EXECUTED.  A NEG NUMBER INDICATES THAT THE TIME INTERVAL HAS BEEN PROCESSED.  IN EV
# SUBSEQUENT TIME REGISTER IS EXAMINED FOR POSSIBLE ACTION.  THUS JET BITS TO BE EXEC
# THAN ONE REGISTER.

JETCALL1        CA      ZERO
                TS      OUTTAG
                TS      NUJET
                TS      TBITS
                DXCH    TON1
                CCS     A
                TCF     JETCALL2        # CALL WTLST
JETCALL3        LXCH    NUJET           # WTLST ENTRIES COME HERE FROM JETCALL
                CS      ONE
                DXCH    TOFF
                CCS     A
                TCF     JETCALL2        # CALL WTLST
                LXCH    NUJET
                CS      ONE
                DXCH    TON2
                CCS     A
                TCF     JETCALL2        # CALL WTLST
                LXCH    NUJET
                TC      JETACTN         # C(A) = +0
JETCALL2        XCH     L               # SAVE JET BITS FOR AFTER WTLST CALL
                ADS     NUJET
                XCH     L
                AD      ONE             # RESTORE FOR CCS
```

```
                TC      WAITLIST
                EBANK=  AOG
                2CADR   JETCALL

JETACTN         CA      NUJET           # COME HERE WHEN DESIRED JET CODE IS KNOWN
```

Uses A 80, AOG 214, CODE 140, EBANK 80, JNDX1 216, L 80, NUJET 216, OUTTAG 216, P 188, SAVE 191, T2BITS 216, TBITS 216, TC 169, TOFF 216, TON1 218, TON2 216, and TUSED 214.

1518 ⟨*Page CM1089* 1518⟩≡ (1480 2659)

```
                EXTEND                  # NO NEED TO SAVE OLD CODES
                WRITE   ROLLJETS        # SET RCHAN TO NEW BIT CONFIG.

                CCS     OUTTAG
                TC      TASKOVER
ROLLDUMP        TC      CM/FDAIR

                                        # EDIT DUMP AT ABOVE LOCATION.

# WAITLIST ENTRIES COME HERE.

JETCALL         CAF     BIT2            # CM/DSTBY =103D BIT2
                TS      OUTTAG          # SIGNIFY WTLST ENTRY
                MASK    CM/FLAGS        # IS SYSTEM DISABLED  $
                EXTEND
                BZF     JETACTN +1      # YES, QUENCH ROLL JETS, IF ON AND EXIT.
                ZL                      # NO, CONTINUE.
                TCF     JETCALL3        # C(A) POS, C(L) = +0

# DEAD ZONE ENTRIES COME HERE.

DZCALL          CS      CMDAPMOD        # POSSIBLE VALUES OF CMDAPMOD: -1, +0, -0.
                MASK    BIT1
                TS      L               # C(L)=0 FOR -0: C(L)=1 FOR -1 OR +0.
                INDEX   A               # ERASABLE ORDER:  ROLLTM, ROLLC, ROLLC +1.
                CA      ROLLTM          # GET ROLL/180 OR ROLLC (/360).
                INDEX   L
                TS      A               # IF C(L)=1, STORE 'ROLLC' IN 'L'.
                AD      L               # (BOTH MUST BE SCALED DEG/180)
                TC      ANGOVCOR        # C(A)=ROLL/180 OR 2 ROLLC.
                TS      ROLLHOLD        # IF CMDAPMOD =-0, SAVE ROLL ANGLE.
                                        #       OTHERWISE, SAVE ROLL COMMAND.

                CA      ZERO            # COME HERE IF IN DZ, AND CANCEL JETS.
                EXTEND                  # INHINT NOT NEEDED HERE.
                WRITE   ROLLJETS        # TURN OFF ALL ROLL JETS.
                TS      VDT/180         # SET =0 TO SHOW IN DEAD ZONE.
DZCALL1         TS      JETAG           # COME HERE WITH C(A)=0.
                TC      ROLLDUMP
```

Uses A 80, CM/DSTBY 121, CMDAPMOD 214, COMMAND 169, JETAG 214, L 80, OUTTAG 216, ROLL/180 214, ROLLC 214, ROLLHOLD 216, ROLLJETS 87, ROLLTM 214, SAVE 191, TC 169, VDT/180 218, and ZONE 163.

1519 ⟨*Page CM1090* 1519⟩≡ (1480 2659)

```
# CM ENTRY FDAI DISPLAY
#
# CALCULATE BY INTEGRATION THE ROLL ERROR BETWEEN THE 2 SEC CM/RCS UPDATES.  DISPLAY ATTITUDE E
#       ATM DAP:        DISPLAY ONLY ROLL ATTITUDE ERROR.
#       EXT ATM DAP:    PRESENT 3 ATTITUDE ERRORS RELATIVE TO THE APPROPRIATE BODY AXES EACH .1
#                               ROLL    ROLLC-ROLL
#                               PITCH   ALFAC-ALFA
#                               YAW     BETAC-BETA
#
# DURING ENTRY, THE FDAI NEEDLES HAVE FULL SCALE OF 67.5 DEG IN ROLL AND 16.875 DEG IN PITCH AN
# THE SUBROUTINE  NEEDLER  EXPECTS (ANGLE/180) AND SCALES TO 16.875 DEG FULL SCALE.

                                        # COME HERE EACH .1 SEC.  (CMDAPMOD=+1 COMES BELOW)
CM/FDAI         CS      PHIDOT          # INTEGRATE ROLL ERROR 'TWEEN 2SEC UPDATES
                EXTEND
                MP      CALFA           # FOR ASSUMED COORDINATION.
                EXTEND
                MP      HALF
                ADS     PAXERR1         # ROLL ERROR/360.  OVFL OK.

                                        # EDIT DUMP AT ABOVE LOCATION.
CM/FDAIR        CA      HALF
                EXTEND
                MP      PAXERR1         # FULL SCALE FOR FDAI (ROLL) IS 67.5 D
                TS      PAXERR          # .25 (ROLL ERROR/180) FOR FDAI NEEDLE.

                                        # PROGRAM TO FILE BODY RATES FOR TM ON ONE PASS AND
                                        # TO UPDATE THE NEEDLE DISPLAY ON THE NEXT.
                                        # SYNCHRONIZATION WITH CM/RCS IS USED SO THAT THE TM
                                        # IS DONE WITH THE ROLL SYSTEM AND NEEDLES START ON
                                        # THE SUBSEQUENT PASS.

CM/DUMPR        CS      SW/NDX          # COMBINED ALTERNATION SWITCH AND FILE
                TS      SW/NDX
                EXTEND                  # INDEX
                BZMF    CMTMFILE        # FILE STARTS WITH SW/NDX +1 AND GOES TO
                                        # ENDBUF.
                                        # INDEX IS POS FOR NEEDLES.

                TC      IBNKCALL
                CADR    NEEDLER

                TC      CM/END

                                        # INDEX IS NEG FOR TM FILE
```

```
CMTMFILE        AD      THREE
                EXTEND
                BZMF    SAVENDX
```

Uses CALFA 216, CMDAPMOD 214, D 226, ENDBUF 145, PAXERR 218, PAXERR1 214, PHIDOT 214, ROLLC 214, SW/NDX 145, TC 169, and TM 219.

1521 ⟨*Page CM1091* 1521⟩≡ (1480 2659)

```
                CA      TIME1           # INITIALIZE THE TM LIST IN UPBUFF.
                TS      CMTMTIME
                CS      THIRTEEN        # INITIALIZE COUNTER
  SAVENDX       TS      SW/NDX          # A NEGATIVE NUMBER.
                EXTEND
                DCA     PREL
                INDEX   SW/NDX
                DXCH    ENDBUF -1
                CA      RREL
                INDEX   SW/NDX
                TS      ENDBUF +1

  CM/END        CA      CM/SAVE
                TS      SR
                                        # DOES NOT PROTECT TEMK, SQ IN SPSIN/COS

                EXTEND
                DCA     T5IDLER2
                DXCH    T5LOC
                TC      RESUME

                EBANK=  T5LOC
  T5IDLER2      2CADR   T5IDLOC

                                        # DEFINE THE FOLLOWING 17D REGISTERS IN UPBUFF TO BE
                                        # USED TO TELEMETER CM VEHICLE BODY RATE INFORMATION.
                                        # THE INFORMATION IS FILED EACH 0.2 SEC, GIVING 15D
                                        # DATA POINTS EACH 1 SEC.  TM LIST IS READ TWICE
                                        # EACH 2 SECONDS.
                                        #
                                        # THE SEQUENCE IS:      SP TIME         INITIAL TIME
                                        #                       SWITCH          ALSO INDEX.
                                        #                       P               ROLL RATE
                                        #                       Q               PITCH RATE
                                        #                       R               YAW RATE
                                        #                       ETC.

  #CMTMTIME     =       UPBUFF
  #SW/NDX       =       UPBUFF +1
  #ENDBUF       =       UPBUFF +16D
```

Uses A 80, CM/SAVE 218, CMTMTIME 145, EBANK 80, ENDBUF 145, P 188, PREL 214, Q 80, RREL 214, SAVE 191, SQ 156, SR 80, SW/NDX 145, T5LOC 163, TC 169, TEMK 156, TIME1 80, TM 219, and UPBUFF 145.

1522 ⟨*Page CM1092* 1522⟩≡ (1480 2659)

```
# SPACER
#
# CONSTANTS USED IN THE ROLL CONTROL SYSTEM:
# CONSTANTS ARE THE FOLLOWING:  A = 9.1 DEG/SECSQ, VM = 20 DEG/SEC, T = 2 SEC, TCDU =
# XMIN = 4 DEG, VMIN = 2 DEG/SEC, K = .25, A1 = 4.55 DEG/SECSQ, VI = 1 DEG/SEC, INTER
# XBUF = 4DEG

-T-3            DEC     -203            # CS
VSQMIN          DEC     .61050061 E-3   # VSQ MIN/4 A PI = 4/(4 (9.1) 180)
2T/TCDU         =       OCT50           # T/TCDU EXP-14    TCDU = .1SEC
180/8ATT        DEC     .61813187       # 180/(8 (9.1) 4)=(180/ATT)     EXP -3
-VMT/180        =       -VM/360K        # = 20 (2) / 180
2JETT           =       4SECS           # CS            2 (2) 100       INTEGER
4JETT           DEC     800             # CS            4 (2) 100       INTEGER
XMIN/360        DEC     182             # XMIN/360 = 4/ 360  EXP 14  = 182 INTEGER
-VM/360K        DEC     -.22222222      # =-20/( 360 (.25))
1/16A1          =       180/8ATT
                                        # 1/16A1   = 180/(16 A1 TT)
                                        #          = 180/(16 4.55 4)
XS/360          DEC     91              # = (XMIN +VI (T-1/K))/360 = 2/360 EXP 14
BUFLIM          =       XS/360          # 4/(2 360)

KTRCS           =       HALF            #    KT = (.25) 2 = .5

# *** END OF TVCDAPS .011 ***
```

Uses `A` 80, `A1` 229, and `KT` 181.

3.7 chieftan routines

1523a ⟨*chieftan routines* 1523a⟩≡ (19a)
⟨*down-telemetry program* 1523b⟩
⟨*inter-bank communication* 1539b⟩
⟨*interpreter code* 1544⟩
⟨*fixed fixed constant pool* 1637b⟩
⟨*interpretive constants* 1645a⟩
⟨*single precision subroutines* 1646b⟩
⟨*executive code* 1648⟩
⟨*waitlist code* 1662⟩
⟨*latitude longitude subroutines* 1674⟩
⟨*planetary inertial orientation* 1683⟩
⟨*measurement incorporation* 1692⟩
⟨*conic subroutines* 1710⟩
⟨*integration initialization* 1771⟩
⟨*orbital integration* 1813b⟩
⟨*inflight alignment routines* 1834⟩
⟨*powered flight subroutines* 1843b⟩
⟨*time of free fall* 1851⟩
⟨*star tables* 1867⟩
⟨*cm agc block two self check* 1871⟩
⟨*phase table maintenance* 1890⟩
⟨*restarts routine* 1904⟩
⟨*imu mode switching routines* 1916⟩
⟨*keyrupt uprupt* 1944b⟩
⟨*display interface routines* 1948⟩
⟨*service routines* 2000b⟩
⟨*alarm and abort* 2006⟩
⟨*update program* 2014⟩
⟨*rt8 op codes* 2027⟩

3.7.1 down-telemetry program

1523b ⟨*down-telemetry program* 1523b⟩≡ (1523a)
⟨*Page CM1093* 1524⟩
⟨*Page CM1094* 1525⟩
⟨*Page CM1095* 1526⟩
⟨*Page CM1096* 1528⟩
⟨*Page CM1097* 1530⟩
⟨*Page CM1098* 1532⟩
⟨*Page CM1099* 1534⟩
⟨*Page CM1100* 1536⟩
⟨*Page CM1101* 1538⟩
⟨*Page CM1102* 1539a⟩

1524 ⟨*Page CM1093* 1524⟩≡ (1523b 2680)

```
# PROGRAM NAME -- DOWN TELEMETRY PROGRAM
# MOD NO. -- 0          TO COMPLETELY REWRITE THE DOWN TELEMETRY PROGRAM AND DOWNLINK
#                       PURPOSE OF SAVING APPROXIMATELY 150 WORDS OF CORE STORAGE.
#                       THIS CHANGE REQUIRES AN ENTIRELY NEW METHOD OF SPECIFYING DOW
#                       LISTS LOG SECTION FOR MORE DETAILS.  HOWEVER THIS CHANGES WI
#                       OF DOWN TELEMETRY DATA.
# MOD BY -- KILROY, SMITH, DEWITT
# DATE -- 02 OCT 67
# AUTHORS -- KILROY, SMITH, DWWITT, DEWOLF, FAGIN
# LOG SECTION -- DOWN-TELEMETRY PROGRAM
#
# FUNCTIONAL DESCRIPTION -- THIS ROUTINE IS INITIATED BY TELEMETRY END
#       PULSE FROM THE DOWNLINK TELEMETRY CONVERTER.  THIS PULSE OCCURS
#       AT 50 TIMES PER SEC (EVERY 20 MS) THEREFORE DODOWNTM IS
#       EXECUTED AT THESE RATES.  THIS ROUTINE SELECTS THE APPROPRIATE
#       AGC DATA TO BE TRANSMITTED DOWNLINK AND LOADS IT INTO OUTPUT
#       CHANNELS 34 AND 35.  THE INFORMATION IS THEN GATED OUT FROM THE
#       LGC IN SERIAL FASHION.
#
#       THIS PROGRAM IS CODED FOR A 2 SECOND DOWNLIST.  SINCE DOWNRUPTS
#       OCCUR EVERY 20 MS AND 2 AGC COMPUTER WORDS CAN BE PLACED IN
#       CHANNELS 34 AND 35 DURING EACH DOWNRUPT THE PROGRAM IS CAPABLE
#       OF SENDING 200 AGC WORDS EVERY 2 SECONDS.
#
# CALLING SEQUENCE -- NONE
#       PROGRAM IS ENTERED VIA TCF DODOWNTM WHICH IS EXECUTED AS A
#       RESULT OF A DOWNRUPT.  CONTROL IS RETURNED VIA TCF RESUME WHICH
#       IN EFFECT IS A RESUME.
#
# SUBROUTINES CALLED -- NONE
#
# NORMAL EXIT MODE -- TCF RESUME
#
# ALARM OR ABORT EXIT MODE -- NONE
#
# RESTART PROTECTION:
#       ON A FRESH START AND RESTART THE 'STARTSUB' SUBROUTINE WILL INITIALIZE THE DO
#       DNTMGOTO) TO THE BEGINNING OF THE CURRENT DOWNLIST (I.E., CURRENT CONTENTS OF
#       EFFECT OF IGNORING THE REMAINDER OF THE DOWNLIST WHICH THE DOWN-TELEMETRY PRO
#       THE RESTART (OR FRESH START) OCCURRED AND RESUME DOWN TELEMETRY FROM THE BEGI
#       DOWNLIST.
#
#       ALSO OF INTEREST IS THE FACT THAT ON A RESTART THE AGC WILL ZERO DOWNLINK CHA
#
# DOWNLINK LIST SELECTION:
```

```
#       THE APPROPRIATE DOWNLINK LISTS ARE SELECTED BY THE FOLLOWING:
#       1.      FRESH START
#       2.      V37EXXE WHERE XX = THE MAJOR MODE BEING SELECTED.
#       3.      UPDATE PROGRAM (P27)
#       4.      NON-V37 SELECTABLE TYPE PROGRAMS (E.G., AGS INITIALIZATION (SUNDANCE, LUMINARY)
#               TRANSITIONS (COLOSSUS) ETC.).
#
# DOWNLINK LIST RULES AND LIMITATIONS:
#       READ SECTION(S) WHICH FOLLOW ‘DEBRIS’ WRITEUP.
#
# OUTPUT -- EVERY 2 SECONDS 100 DOUBLE PRECISION WORDS (I.E., 200 LGC
#       COMPUTER WORDS) ARE TRANSMITTED VIA DOWNLINK.
#
# ERASABLE INITIALIZATION REQUIRED -- NONE
#       ‘DNTMGOTO’ AND ‘DNLSTADR’ ARE INITIALIZED BY THE FRESH START PROGRAM.
#
# DEBRIS (ERASABLE LOCATIONS DESTROYED BY THIS PROGRAM) --
#       LDATALST, DNTMBUFF TO DNTMBUFF +21D, TMINDEX, DNQ.
```

Uses A 80, COMPUTER 115, DNLSTADR 148, DNQ 148, DNTMBUFF 148, DNTMGOTO 148, I 206, IT 185, LDATALST 148, MODE 145, RESTART 57, and TMINDEX 148.

1525 ⟨*Page CM1094* 1525⟩≡ (1523b 2680)

```
# (No source on this page of the original assembly listing.)
```

1526 ⟨*Page CM1095* 1526⟩≡ (1523b 2680)

```
# DODOWNTM IS ENTERED EVERY 20 MS BY AN INTERRUPT TRIGGERED BY THE
# RECEIPT OF AN ENDPULSE FROM THE SPACECRAFT TELEMETRY PROGRAMMER.
#
# NOTES REGARDING DOWNLINK LISTS ASSOCIATED WITH THIS PROGRAM:
# 1.    DOWNLISTS.  DOWNLISTS MUST BE COMPILED IN THE SAME BANK AS THE
#       DOWN-TELEMETRY PROGRAM.  THIS IS DONE FOR EASE OF CODING, FASTER
#       EXECUTION.
# 2.    EACH DOWNLINK LIST CONSISTS OF A CONTROL LIST AND A NUMBER OF
#       SUBLISTS.
# 3.    A SUBLIST REFERS TO A SNAPSHOT OR DATA COMMON TO THE SAME OR OTHER
#       DOWNLINK LISTS.  ANY SUBLIST CONTAINING COMMON DATA NEEDS TO BE
#       CODED ONLY ONCE FOR THE APPLICABLE DOWNLINK LISTS.
# 4.    SNAPSHOT SUBLISTS REFER SPECIFICALLY TO HOMOGENEOUS DATA WHICH MUST BE
#       SAVED IN A BUFFER DURING ONE DOWNRUPT.
# 5.    THE 1DNADR FOR THE 1ST WORD OF SNAPSHOT DATA IS FOUND AT THE END
#       OF EACH SNAPSHOT SUBLIST, SINCE THE PROGRAM CODING SENDS THIS DP WORD
#       IMMEDIATELY AFTER STORING THE OTHERS IN THE SNAPSHOT BUFFER.
# 6.    ALL LISTS ARE COMBINATIONS OF CODED ERASABLE ADDRESS CONSTANTS
#       CREATED FOR THE DOWNLIST PROGRAM.
#       A.      1DNADR                  1-WORD DOWNLIST ADDRESS.
#               SAME AS ECADR, BUT USED WHEN THE WORD ADDRESSED IS THE LEFT
#               HALF OF A DOUBLE-PRECISION WORD FOR DOWN TELEMETRY.
#       B.      2DNADR - 6DNADR         N-WORD DOWNLIST ADDRESS, N = 2 - 6.
#               SAME AS 1DNADR, BUT WITH THE 4 UNUSED BITS OF THE ECADR FORMAT
#               FILLED IN WITH 0001-0101.  USED TO POINT TO A LIST OF N DOUBLE-
#               PRECISION WORDS, STORED CONSECUTIVELY, FOR DOWN TELEMETRY.
#       C.      DNCHAN                  DOWNLIST CHANNEL ADDRESS.
#               SAME AS 1DNADR, BUT WITH PREFIX BITS 0111.  USED TO POINT TO
#               A PAIR OF CHANNELS FOR DOWN TELEMETRY.
#       D.      DNPTR                   DOWN-TELEMETRY SUBLIST POINTER.
#               SAME AS CAF BUT TAGGES AS A CONSTANT.  USED IN CONTROL LIST TO POINT
#               CAUTION --- A DNPTR CANNOT BE USED IN A SUBLIST.
# 7.    THE WORD ORDER CODE IS SET TO ZERO AT THE BEGINNING OF EACH DOWNLIST (I.E., C
#       A '1DNADR TIME2' IS DETECTED IN THE CONTROL LIST (ONLY).
# 8.    IN THE SNAPSHOT SUBLIST ONLY, THE DNADR'S CANNOT POINT TO THE FIRST WORD OF A
#
# DOWNLIST LIST RESTRICTIONS:
# (THE FOLLOWING POINTS MAY BE LISTED ELSEWHERE BUT ARE LISTED HERE SO IT IS CLEAR TH
# DONE)
# 1.    SNAPSHOT DOWNLIST:
#       (A) CANNOT CONTAIN THE FOLLOWING ECADRS (I.E., 1DNADR'S): Q, 400, 1000, 1400,
#       (B) CAN CONTAIN ONLY 1DNADR'S
# 2.    ALL DOWNLINKED DATA (EXCEPT CHANNELS) IS PICKED UP BY A DCA SO DOWNLINK LISTS
#       EQUIVALENT OF THE FOLLOWING ECADRS (I.E., IDNADRS): 377, 777, 1377, 1777, 237
#       (NOTE: TE TERM 'EQUIVALENT' MEANT THAT THE IDNADR TO 6DNADR WILL BE PROCESSED
```

```
# 3.    CONTROL LISTS AND SUBLISTS CANNOT HAVE ENTRIES = OCTAL 00000 OR OCTAL 77777
```

Uses `A` 80, `CODE` 140, `D` 226, `EBANK` 80, `I` 206, `IT` 185, `N` 206, and `Q` 80.

1528 ⟨*Page CM1096* 1528⟩≡ (1523b 2680)

```
# 4.    THE ‘1DNADR TIME2’ WHICH WILL CAUSE THE DOWNLINT PROGRAM TO SET THE WORDER CO
#       CONTROL SECTION OF THE DOWNLIST.
# 5.    ‘DNCHAN 0’ CANNOT BE USED.
# 6.    ‘DNPTR 0’ CANNOT BE USED.
# 7.    DNPTR CANNOT APPEAR IN A SUBLIST.
#
# EBANK SETTINGS
#       IN THE PROCESS OF SETTING THE EBANK (WHEN PICKING UP DOWNLINK DATA) THE DOWN
#       ‘GARBAGE’ INTO BITS15-12 OF EBANK.  HUGH BLAIR-SMITH WARNS US THAT BITS15-12
#       SIGNIFICANT SOMEDAY IN THE FUTURE.  IF/WHEN THAT HAPPENS, THE PROGRAM SHOULD
#       THAT BITS 15-12 OF EBANK ARE ZERO.
#
# INITIALIZATION REQUIRED -- TO INTERRUPT CURRENT LIST AND START A NEW ONE.
#       1. ADRES OF DOWNLINK LIST INTO DNLSTADR
#       2. NEGONE INTO SUBLIST
#       3. NEGONE INTO DNECADR

                BANK    22
                SETLOC  DOWNTELM
                BANK

                EBANK=  DNTMBUFF

                COUNT   05/DPROG

DODOWNTM        TS      BANKRUPT
                EXTEND
                QXCH    QRUPT           # SAVE Q
                CA      BIT7            # SET WORD ORDER CODE TO 1.  EXCEPTION: AT
                EXTEND                  # THE BEGINNING OF EACH LIST THE WORD
                WOR     CHAN13          # CODE WILL BE SET BACK TO 0.
                TC      DNTMGOTO        # GOTO APPROPRIATE PHASE OF PROGRAM

DNPHASE1        CA      NEGONE          # INITIALIZE ALL CONTROL WORDS
                TS      SUBLIST         # WORDS TO MINUS ONE
                TS      DNECADR
                CA      LDNPHAS2        # SET DNTMGOTO = 0 ALL SUSEQUENT DOWRUPTS
                TS      DNTMGOTO        # GO TO DNPHASE2
                TCF     NEWLIST
DNPHASE2        CCS     DNECADR         # SENDING OF DATA IN PROGRESS
DODNADR         TC      FETCH2WD        # YES -- THEN FETCH THE NEXT 2 SP WORDS
MINTIME2        -1DNADR TIME2           # NEGATIVE OF TIME2 1DNADR
                TCF     +1              # (ECADR OF 3776 + 74001 = 77777)

                CCS     SUBLIST         # IS THE SUBLIST IN CONTROL
```

Uses A 80, BANKRUPT 80, CHAN13 87, CODE 140, COUNT 142, DNLSTADR 148, DNTMBUFF 148, DNTMGOTO 148, DOWNTELM 59, EBANK 80, Q 80, QRUPT 80, SAVE 191, TC 169, TIME2 80, and US 185.

1530 ⟨*Page CM1097* 1530⟩≡ (1523b 2680)

```
                TCF     NEXTINSL        # YES
DNADRDCR        OCT     74001           # DNADR COUNT AND ECADR DECREMENTER

CHKLIST         CA      CTLIST
                EXTEND
                BZMF    NEWLIST         # IT WILL BE NEGATIVE AT END OF LIST
                TCF     NEXTINCL
NEWLIST         INDEX   DNLSTCOD
                CA      DNTABLE         # INITIALIZE CTLIST WITH
                TS      CTLIST          #       STARTING ADDRESS OF NEW LIST
                CS      DNLSTCOD
                TCF     SENDID +3
NEXTINCL        INDEX   CTLIST
                CA      0
                CCS     A
                INCR    CTLIST          # SET POINTER TO PICK UP NEXT CTLIST WORD
                TCF     +4              # ON NEXT ENTRY TO PROG.  (A SHOULD NOT =0)
                XCH     CTLIST          # SET CTLIST TO NEGATIVE AND PLACE(CODING)
                COM                     # UNCOMPLEMENTED DNADR INTO A.    (FOR LA)
                XCH     CTLIST          #                                 (ST IN )
        +4      INCR    A               #                                 (CTLIST)
                TS      DNECADR         # SAVE DNADR
                AD      MINTIME2        # TEST FOR TIME2 (NEG. OF ECADR)
                CCS     A
                TCF     SETWO +1        # DON'T SET WORD ORDER CODE
MINB1314        OCT     47777           # MINUS BIT 13 AND 14 (CAN'T GET HERE)
                TCF     SETWO +1        # DON'T SET WORD ORDER CODE
SETWO           TC      WOZERO          # GO SET WORD ORDER CODE TO ZERO.
        +1      CA      DNECADR         # RELOAD A WITH THE DNADR.
        +2      AD      MINB1314        # IS THIS A REGULAR DNADR?
                EXTEND
                BZMF    FETCH2WD        # YES.  (A MUST NEVER BE ZERO)
                AD      MINB12          # NO.  IS IT A POINTER (DNPTR) OR A
                EXTEND                  #       CHANNEL(DNCHAN)
                BZMF    DODNPTR         # IT'S A POINTER.  (A MUST NEVER BE ZERO)

DODNCHAN        TC      6               # (EXECUTED AS EXTEND)  IT'S A CHANNEL
                INDEX   DNECADR
                INDEX   0 -4000         # (EXECUTED AS READ)
                TS      L
                TC      6               # (EXECUTED AS EXTEND)
                INDEX   DNECADR
                INDEX   0 -4001         # (EXECUTED AS READ)
                TS      DNECADR         # SET DNECADR
                CA      NEGONE          #       TO MINUS
```

```
                XCH     DNECADR         #               WHILE PRESERVING A.
                TCF     DNTMEXIT        # GO SEND CHANNELS

  WOZERO        CS      BIT7
                EXTEND
```

Uses A 80, CODE 140, COUNT 142, DNLSTCOD 148, IT 185, L 80, SAVE 191, TC 169, and TIME2 80.

1532 ⟨*Page CM1098* 1532⟩≡ (1523b 2680)

```
                WAND    CHAN13          # SET WORD ORDER CODE TO ZERO
                TC      Q               # RETURN TO CALLER

DODNPTR         INDEX   DNECADR         # DNECADR CONTAINS ADRES OF SUBLIST
                0       0               # CLEAR AND ADD LIST ENTRY INTO A.
                CCS     A               # IS THIS A SNAPSHOT SUBLIST
                CA      DNECADR         # NO, IT IS A REGULAR SUBLIST.
                TCF     DOSUBLST        # A MUST NOT BE ZERO.

                XCH     DNECADR         # YES.  IT IS A SNAPSHOT SUBLIST.
                TS      SUBLIST         # C(DNECADR) INTO SUBLIST
                CAF     ZERO            #       A    INTO     A
                XCH     TMINDEX         # (NOTE:  TMINDEX = DNECADR)

# THE FOLLOWING CODING (FROM SNAPLOOP TO SNAPEND) IS FOR THE PURPOSE OF TAKING A SNAP
# THIS IS DONE BY SAVING 11 DP REGISTERS IN DNTMBUFF AND SENDING THE FIRST DP WORD IN
# THE SNAPSHOT PROCESSING IS THE MOST TIME CONSUMING AND THEREFORE THE CODING AND LIS
# TO MINIMIZE TIME.  THE TIME OPTIMIZATION RESULTS IN RULES UNIQUE TO THE SNAPSHOT PO
# THESE RULES ARE ......
#       1.      ONLY 1DNADR'S CAN APPEAR IN THE SNAPSHOT SUBLIST
#       2.      THE 1DNADR'S CANNOT REFER TO THE FIRST LOCATION IN ANY BANK.

SNAPLOOP        TS      EBANK           # SET EBANK
                MASK    LOW8            # ISOLATE RELATIVE ADDRESS
                EXTEND
                INDEX   A
                EBANK=  1401
                DCA     1401            # PICK UP 2 SNAPSHOT WORDS.
                EBANK=  DNTMBUFF
                INDEX   TMINDEX
                DXCH    DNTMBUFF        # STORE 2 SNAPSHOT WORDS IN BUFFER
                INCR    TMINDEX         # SET BUFFER INDEX FOR NEXT 2 WORDS.
                INCR    TMINDEX
SNAPAGN         INCR    SUBLIST         # SET POINTER TO NEXT 2 WORDS OF SNAPSHOT
                INDEX   SUBLIST
                0       0               # = CA SSSS (SSSS = NEXT ENTRY IN SUBLIST)
                CCS     A               # TEST FOR LAST TWO WORDS OF SNAPSHOT.
                TCF     SNAPLOOP        # NOT LAST TWO.
LDNPHAS2        GENADR  DNPHASE2
                TS      SUBLIST         # YES, LAST.  SAVE A.
                CA      NEGONE          # SET DNECADR AND
                TS      DNECADR         #       SUBLIST POINTERS
                XCH     SUBLIST         #               TO NEGATIVE VALUES
                TS      EBANK
                MASK    LOW8
```

```
EXTEND
INDEX   A
EBANK=  1401
```

Uses A 80, CHAN13 87, CODE 140, DNTMBUFF 148, EBANK 80, IT 185, Q 80, SAVE 191, TC 169, and TMINDEX 148.

1534 ⟨*Page CM1099* 1534⟩≡ (1523b 2680)

```
                DCA     1401            # PICK UP FIRST 2 WORDS OF SNAPSHOT.
                EBANK=  DNTMBUFF
SNAPEND         TCF     DNTMEXIT        # NOW GO SEND THEM.

FETCH2WD        CA      DNECADR
                TS      EBANK           # SET EBANK
                MASK    LOW8            # ISOLATE RELATIVE ADDRESS
                TS      L
                CA      DNADRDCR        # DECREMENT COUNT AND ECADR
                ADS     DNECADR
                EXTEND
                INDEX   L
                EBANK=  1400
                DCA     1400            # PICK UP 2 DATA WORDS
                EBANK=  DNTMBUFF
                TCF     DNTMEXIT        # NOW GO SEND THEM.

DOSUBLST        TS      SUBLIST         # SET SUBLIST POINTER
NEXTINSL        INDEX   SUBLIST
                0       0               # = CA SSSS (SSSS = NEXT ENTRY IN SUBLIST)
                CCS     A               # IS IT THE END OF THE SUBLIST
                INCR    SUBLIST         # NO --
                TCF     +4
                TS      SUBLIST         # SAVE A.
                CA      NEGONE          # SET SUBLIST TO MINUS
                XCH     SUBLIST         # RETRIEVE A.
        +4      INCR    A
                TS      DNECADR         # SAVE DNADR
                TCF     SETWO +2        # GO USE COMMON CODING (PROBLEMS WOULD
                                        # OCCUR IF THE PROGRAM ENCOUNTERED A
                                        # DNPTR NOW)

DNTMEXIT        EXTEND                  # DOWN-TELEMETRY EXIT
                WRITE   DNTM1           # TO SEND A + L TO CHANNELS 34 + 35
                CA      L               # RESPECTIVELY
TMEXITL         EXTEND
                WRITE   DNTM2
TMRESUME        TCF     RESUME          # EXIT TELEMETRY PROGRAM VIA RESUME.

MINB12          EQUALS  -1/8
DNECADR         EQUALS  TMINDEX
CTLIST          EQUALS  LDATALST
SUBLIST         EQUALS  DNQ
```

Uses A 80, COUNT 142, DNQ 148, DNTM1 87, DNTM2 87, DNTMBUFF 148, EBANK 80, IT 185, L 80,

`LDATALST` 148, `SAVE` 191, and `TMINDEX` 148.

1536 ⟨*Page CM1100* 1536⟩≡ (1523b 2680)

```
# SUBROUTINE NAME -- DNDUMP
#
# FUNCTIONAL DESCRIPTION -- TO SEND (DUMP) ALL 8 BANKS OF ERASABLE STORAGE TWICE.  BA
#       EACH BANK IS PRECEDED BY AN ID WORD, SYNCH BITS, ECADR AND TIME1 FOLLOWED BY
#       EBANK.  EBANKS ARE DUMPED IN ORDER (I.E., EBANK 0 FIRST, THEN EBANK1 ETC.)
#
# CALLING SEQUENCE -- THE GROUND OR ASTRONAUT BY KEYING V74E CAN INITIALIZE THE DUMP
#       AFTER KEYING IN V74E THE CURRENT DOWNLIST WILL BE IMMEDIATELY TERMINATED AND
#       WILL BEGIN.
#
#       ONCE INITIATED THE DOWNLINK ERASABLE DUMP CAN BE TERMINATED (AND INTERRUPTED
#       BY THE FOLLOWING:
#
#       1.      A FRESH START
#       2.      COMPLETION OF ALL DOWNLINK DUMPS REQUESTED (ACCORDING TO BITS SET IN
#               CAN BE ALTERED BY A V21N01.
#       3.      AND INVOLUNTARILY BY A RESTART.
#
# NORMAL EXIT MODE -- TCF DNPHASE1
#
# ALARM OR ABORT MODE -- NONE
#
# *SUBROUTINES CALLED -- NONE
#
# ERASABLE INITIALIZATION REQUIRED --
#       DUMPCNT OCT 20000       IF 4 COMPLETE ERASABLE DUMPS ARE DESIRED
#       DUMPCNT OCT 10000       IF 2 COMPLETE ERASABLE DUMPS ARE DESIRED
#       DUMPCNT OCT 04000       IF 1 COMPLETE ERASABLE DUMP  IS  DESIRED
#
# DEBRIS -- DUMPLOC, DUMPSW, DNTMGOTO, EBANK, AND CENTRAL REGISTERS
#
# TIMING --     TIME (IN SECS) = ((NO.DUMPS)*(NO.EBANKS)*(WDSPEREBANK + NO.IDWDS)) /
#               TIME (IN SECS) =  (   4    )*(    8    )*(    256     +     4   )  /
#          THUS TIME (IN SECS TO SEND DUMP OF ERASABLE 4 TIMES VIA DOWNLINK) = 83.2 S
#
# STRUCTURE OF ONE EBANK AS IT IS SENT BY DOWNLINK PROGRAM --
#       (REMINDER -- THIS ONLY DESCRIBES ONE OF THE 8 EBANKS X 4 (DUMPS) = 32 EBANKS
#
#       DOWNLIST                                W
#         WORD  TAKEN FROM CONTENTS OF  EXAMPLE 0       COMMENTS
#           1   ERASID                   0177X  0       DOWNLIST I.D. FOR DOWNLINK EB
#           2   LOWIDCOD                 77340  1       DOWNLINK SYNCH BITS.  (SAME C
#           3   DUMPLOC                  13400  1       (SEE NOTES ON DUMPLOC) 1 = 3E
#           4   TIME1                    14120  1       TIME IN CENTISECONDS
#           5   FIRST WORD OF EBANK X    03400  1       IN THIS EXAMPLE THIS WORD = C
```

```
#           6   2ND   WORD OF EBANK X    00142  1       IN THIS EXAMPLE THIS WORD = CONTENTS OF
#           7.  3RD   WORD OF EBANK X    00142  1       IN THIS EXAMPLE THIS WORD = CONTENTS OF
#           .
#           .
#           .
#        260D   256TH WORD OF EBANK X    03777  1       IN THIS EXAMPLE THIS WORD = CONTENTS OF
#
# NOTE --       DUMPLOC CONTAINS THE COUNTER AND ECADR FOR EACH WORD BEING SENT.
#               THE BIT STRUCTURE OF DUMPLOC IS FOLLOW --
#                                                 X = NOT USED
#               X ABC EEE RRRRRRRR            ABC = ERASABLE DUMP COUNTER (I.E. ABC = 0,1,2, OR
#                                                   COMPLETE ERASABLE DUMP NUMBER 1,2,3, OR 4 R
#                                             EEE = EBANK BITS
#                                        RRRRRRRR = RELATIVE ADDRESS WITHIN AN EBANK
```

Uses A 80, D 226, DNTMGOTO 148, DUMPCNT 148, DUMPLOC 148, EBANK 80, ERASID 73, I 206, IT 185, MODE 145, RESTART 57, TIME1 80, and W 183.

1538 ⟨*Page CM1101* 1538⟩≡ (1523b 2680)

```
DNDUMPI         CA      ZERO            # INITIALIZE DOWNLINK
                TS      DUMPLOC         # ERASABLE DUMP
        +2      TC      SENDID          # GO SEND ID AND SYNCH BITS
                CA      LDNDUMP1        # SET DNTMGOTO
                TS      DNTMGOTO        # TO LOCATION FOR NEXT PASS
                CA      TIME1           # PLACE TIME1
                XCH     L               # INTO L
                CA      DUMPLOC         # AND ECADR OF THIS EBANK INTO A
                TCF     DNTMEXIT        # SEND DUMPLOC AND TIME1

LDNDUMP         ADRES   DNDUMP
LDNDUMP1        ADRES   DNDUMP1

DNDUMP          CA      TWO             # INCREMENT ECADR IN DUMPLOC
                ADS     DUMPLOC         # TO NEXT DP WORD TO BE
                MASK    LOW8            # DUMPED AND SAVE IT.
                CCS     A               # IS THIS THE BEGINNING OF A NEW EBANK
                TCF     DNDUMP2         # NO -- THEN CONTINUE DUMPING
                CA      DUMPLOC         # YES -- IS THIS THE END OF THE
                MASK    DUMPCNT         # N-TH(N = 1 TO 4) COMPLETE ERASABLE
                MASK    PRIO34          # DUMP(BIT14 FOR 4, BIT13 FOR 2 OR BIT12
                CCS     A               # FOR 1 COMPLETE ERASABLE DUMP(S)).
                TCF     DNPHASE1        # YES -- SEND DOWNLIST AGAIN
                                        # AGAIN
                TCF     DNDUMPI +2      # NO -- GO BACK AND INITIALZE NEXT BANK

DNDUMP1         CA      LDNDUMP         # SET DNTMGOTO
                TS      DNTMGOTO        # FOR WORDS 3 TO 256D OF CURRENT EBANK

DNDUMP2         CA      DUMPLOC
                TS      EBANK           # SET EBANK
                MASK    LOW8            # ISOLATE RELATIVE ADDRESS.
                TS      Q               # (NOTE: MASK INSTRUCTION IS USED TO PICK
                CA      NEG0            # UP ERASABLE REGISTERS TO THAT EDITING
                TS      L               # REGISTERS 20-23 WILL NOT BE ALTERED.)
                INDEX   Q
                EBANK=  1400            # PICK UP LOW ORDER REGISTER OF PAIR
                MASK    1401            # OF ERASABLE REGISTERS.
                XCH     L
                INDEX   Q               # PICK UP HIGH ORDER REGISTER OF PAIR
                MASK    1400            # OF ERASABLE REGISTERS.
                EBANK=  DNTMBUFF
                TCF     DNTMEXIT        # GO SEND THEM

SENDID          EXTEND                  # ** ENTRANCE USED BY ERASABLE DUMP PROG. **
```

```
QXCH    DNTMGOTO        # SET DNTMGOTO SO NEXT TIME PROG WILL GO
CAF     ERASID          # TO LOCATION FOLLOWING ‘TC SENDID’

TS      L               # ** ENTRANCE USED BY REGULAR DOWNLINK PG **
```

Uses A 80, DNTMBUFF 148, DNTMGOTO 148, DUMPCNT 148, DUMPLOC 148, EBANK 80, ERASID 73, IT 185, L 80, N 206, Q 80, SAVE 191, TC 169, and TIME1 80.

1539a ⟨*Page CM1102* 1539a⟩≡ (1523b 2680)

```
TC      WOZERO          # GO SET WORD ORDER CODE TO ZERO
CAF     LOWIDCOD        # PLACE SPECIAL ID CODE INTO L
XCH     L               # AND ID BACK INTO A
TCF     DNTMEXIT        # SEND DOWNLIST ID CODE(S).
```

Uses A 80, CODE 140, L 80, and TC 169.

3.7.2 inter-bank communication

1539b ⟨*inter-bank communication* 1539b⟩≡ (1523a)

⟨*Page CM1103* 1540⟩
⟨*Page CM1104* 1541⟩
⟨*Page CM1105* 1542⟩
⟨*Page CM1106* 1543⟩

1540 ⟨*Page CM1103* 1540⟩≡ (1539b 2720)

```
# THE FOLLOWING ROUTINE CAN BE USED TO CALL A SUBROUTINE IN ANOTHER BANK. IN THE BANK
# CADR OF THE SUBROUTINE IMMEDIATELY FOLLOWS THE TC BANKCALL INSTRUCTION, WITH C(A) A

                BLOCK   02
                COUNT   02/BANK

BANKCALL        DXCH    BUF2            # SAVE INCOMING A,L.
                INDEX   Q               # PICK UP CADR.
                CA      0
                INCR    Q               # SO WE RETURN TO THE LOC. AFTER THE CADR.

# SWCALL IS  IDENTICAL TO BANKCALL, EXCEPT THAT THE CADR ARRIVES IN A.

SWCALL          TS      L
                LXCH    FBANK           # SWITCH BANKS, SAVING RETURN.
                MASK    LOW10           # GET SUB-ADDRESS OF CADR.
                XCH     Q               # A,L NOW CONTAINS DP RETURN.
                DXCH    BUF2            # RESTORING INPUTS IF THIS IS A BANKCALL.
                INDEX   Q
                TC      10000           # SETTING Q TO SWRETURN

SWRETURN        XCH     BUF2 +1         # COMES HERE TO RETURN TO CALLER. C(A,L)
                XCH     FBANK           # ARE PRESERVED FOR RETURN.
                XCH     BUF2 +1
                TC      BUF2

# THE FOLLOWING ROUTINE CAN BE USED AS A UNILATERAL JUMP WITH C(A,L) PRESERVED AND TH
# FOLLOWING THE TC POSTJUMP INSTRUCTION.

POSTJUMP        XCH     Q               # SAVE INCOMING C(A).
                INDEX   A               # GET CADR.
                CA      0

# BANKJUMP IS THE SAME AS POSTJUMP, EXCEPT THAT THE CADR ARRIVES IN A.

BANKJUMP        TS      FBANK
                MASK    LOW10
                XCH     Q               # RESTORING INPUT C(A) IF THIS WAS A
Q+10000         INDEX   Q               # POSTJUMP.
PRIO12          TCF     10000           # PRIO12 = TCF  10000 = 12000
```

Uses `A` 80, `BUF2` 142, `COUNT` 142, `FBANK` 80, `L` 80, `LOC` 145, `Q` 80, `SAVE` 191, and `TC` 169.

1541 ⟨*Page CM1104* 1541⟩≡ (1539b 2720)

```
# THE FOLLOWING ROUTINE GETS THE RETURN CADR SAVED BY SWCALL OR BANKCALL AND LEAVES IT IN A.

MAKECADR        CAF     LOW10
                MASK    BUF2
                AD      BUF2 +1
                TC      Q

SUPDACAL        TS      MPTEMP
                XCH     FBANK           # SET FBANK FOR DATA.
                EXTEND
                ROR     SUPERBNK        # SAVE FBANK IN BITS 15-11, AND
                XCH     MPTEMP          # SUPERBANK IN BITS 7-5.
                MASK    LOW10
                XCH     L               # SAVE REL. ADR. IN BANK, FETCH SUPERBITS
                INHINT                  # BECAUSE RUPT DOES NOT SAVE SUPERBANK.
                EXTEND
                WRITE   SUPERBNK        # SET SUPERBANK FOR DATA.
                INDEX   L
                CA      10000           # PINBALL (FIX MEM DISP) PREVENTS DCA HERE
                XCH     MPTEMP          # SAVE 1ST WD, FETCH OLD FBANK AND SBANK.
                EXTEND
                WRITE   SUPERBNK        # RESTORE SUPERBANK.
                RELINT
                TS      FBANK           # RESTORE FBANK.
                CA      MPTEMP          # RECOVER FIRST WORD OF DATA.
                RETURN                  # 24 WDS. DATACALL 516 MU, SUPDACAL 432 MU
```

Uses `A` 80, `BUF2` 142, `FBANK` 80, `IT` 185, `L` 80, `MPTEMP` 142, `Q` 80, `SAVE` 191, `SUPERBNK` 87, and `TC` 169.

1542 ⟨*Page CM1105* 1542⟩≡ (1539b 2720)

```
# THE FOLLOWING ROUTINES ARE IDENTICAL TO BANKCALL AND SWCALL EXCEPT THAT THEY ARE US

IBNKCALL        DXCH    RUPTREG3        # USES RUPTREG3,4 FOR DP RETURN ADDRESS.
                INDEX   Q
                # Was CAF --- RSB 2009
                CA      0
                INCR    Q

ISWCALL         TS      L
                LXCH    FBANK
                MASK    LOW10
                XCH     Q
                DXCH    RUPTREG3
                INDEX   Q
                TC      10000

ISWRETRN        XCH     RUPTREG4
                XCH     FBANK
                XCH     RUPTREG4
                TC      RUPTREG3

# 2. USPRCADR ACCESSES INTERPRETIVE CODING IN OTHER THAN THE USER'S FBANK.  THE CALLI
#       L       TC      USPRCADR
#       L+1     CADR    INTPRETX        # INTPRETX IS THE INTERPRETIVE CODING
#                                       # RETURN IS TO L+2

USPRCADR        TS      LOC             # SAVE A
                CA      BIT8
                TS      EDOP            # EXIT INSTRUCTION TO EDOP
                CA      BBANK
                TS      BANKSET         # USER'S BBANK TO BANKSET
                INDEX   Q
                CA      0
                TS      FBANK           # INTERPRETIVE BANK TO FBANK
                MASK    LOW10           # YIELDS INTERPRETIVE RELATIVE ADDRESS
                XCH     Q               # INTERPRETIVE ADDRESS TO Q, FETCHING L+1
                XCH     LOC             # L+1 TO LOC, RETRIEVING ORIGINAL A
                TCF     Q+10000
```

Uses `A` 80, `BANKSET` 145, `BBANK` 80, `EDOP` 80, `FBANK` 80, `L` 80, `LOC` 145, `Q` 80, `RUPTREG3` 138, `RUPTREG4` 138, `SAVE` 191, and `TC` 169.

1543 ⟨*Page CM1106* 1543⟩≡ (1539b 2720)

```
# THERE ARE FOUR POSSIBLE SETTINGS FOR CHANNEL 07.  (CHANNEL 07 CONTAINS SUPERBANK SETTING.)
#
#                                        PSEUDO-FIXED     OCTAL PSEUDO
# SUPERBANK     SETTING S-REG. VALUE    BANK NUMBERS       ADDRESSES
# ---------     ------- ------------    ------------       ---------
# SUPERBANK 3     OXX    2000 - 3777       30 - 37       70000 - 107777         (WHERE XX CAN B
#                                                                               WILL USUALLY BE
# SUPERBANK 4     100    2000 - 3777       40 - 47      110000 - 127777         (AS FAR AS IT C
#                                                                               ONLY BANKS 40-4
#                                                                               AND ARE PRESENT
# SUPERBANK 5     101    2000 - 3777       50 - 57      130000 - 147777         (PRESENTLY NOT
#                                                                               THE USER)
# SUPERBANK 6     110    2000 - 3777       60 - 67      150000 - 167777         (PRESENTLY NOT
#                                                                               THE USER)
# *** THIS ROUTINE MAY BE CALLED BY ANY PROGRAM LOCATED IN BANKS 00 - 27.  I.E., NO PROGRAM LIV
# SUPERBANK SHOULD USE SUPERSW. ***
#
# SUPERSW MAY BE CALLED IN THIS FASHION:
#       CAF     ABBCON          WHERE -- ABBCON  BBCON  SOMETHING --
#       TCR     SUPERSW         (THE SUPERBNK BITS ARE IN THE BBCON)
#       ...       ...
#        .         .
#        .         .
# OR IN THIS FASHION:
#       CAF     SUPERSET        WHERE SUPERSET IS ONE OF THE FOUR AVAILABLE
#       TCR     SUPERSW         SUPERBANK BIT CONSTANTS:
#       ...       ...                   SUPER011 OCTAL  60
#        .         .                    SUPER100 OCTAL 100
#        .         .                    SUPER101 OCTAL 120
#                                       SUPER110 OCTAL 140

SUPERSW         EXTEND
                WRITE   SUPERBNK        # WRITE BITS 7-6-5 OF THE ACCUMULATOR INTO
                                        # CHANNEL 07
                TC      Q               # TC TO INSTRUCTION FOLLOWING
                                        #       TC SUPERSW
```

Uses I 206, IT 185, Q 80, SUPERBNK 87, and TC 169.

3.7.3 interpreter code

1544 ⟨*interpreter code* 1544⟩≡ (1523a)

⟨*Page CM1107* 1546⟩
⟨*Page CM1108* 1547⟩
⟨*Page CM1109* 1548⟩
⟨*Page CM1110* 1549⟩
⟨*Page CM1111* 1550⟩
⟨*Page CM1112* 1551⟩
⟨*Page CM1113* 1552⟩
⟨*Page CM1114* 1553a⟩
⟨*Page CM1115* 1553b⟩
⟨*Page CM1116* 1554⟩
⟨*Page CM1117* 1555a⟩
⟨*Page CM1118* 1555b⟩
⟨*Page CM1119* 1556⟩
⟨*Page CM1120* 1557⟩
⟨*Page CM1121* 1558⟩
⟨*Page CM1122* 1559⟩
⟨*Page CM1123* 1560⟩
⟨*Page CM1124* 1561⟩
⟨*Page CM1125* 1562⟩
⟨*Page CM1126* 1563⟩
⟨*Page CM1127* 1564⟩
⟨*Page CM1128* 1565⟩
⟨*Page CM1129* 1566⟩
⟨*Page CM1130* 1567⟩
⟨*Page CM1131* 1568⟩
⟨*Page CM1132* 1569⟩
⟨*Page CM1133* 1570⟩
⟨*Page CM1134* 1571a⟩
⟨*Page CM1135* 1571b⟩
⟨*Page CM1136* 1572⟩
⟨*Page CM1137* 1573⟩
⟨*Page CM1138* 1574⟩
⟨*Page CM1139* 1575⟩
⟨*Page CM1140* 1576⟩
⟨*Page CM1141* 1577⟩
⟨*Page CM1142* 1578a⟩
⟨*Page CM1143* 1578b⟩
⟨*Page CM1144* 1579⟩
⟨*Page CM1145* 1580⟩
⟨*Page CM1146* 1581⟩
⟨*Page CM1147* 1582⟩
⟨*Page CM1148* 1584⟩
⟨*Page CM1149* 1585⟩

⟨*Page CM1150* 1586⟩
⟨*Page CM1151* 1587⟩
⟨*Page CM1152* 1588⟩
⟨*Page CM1153* 1589⟩
⟨*Page CM1154* 1590⟩
⟨*Page CM1155* 1591⟩
⟨*Page CM1156* 1592⟩
⟨*Page CM1157* 1593⟩
⟨*Page CM1158* 1594⟩
⟨*Page CM1159* 1595⟩
⟨*Page CM1160* 1596⟩
⟨*Page CM1161* 1597⟩
⟨*Page CM1162* 1598⟩
⟨*Page CM1163* 1599⟩
⟨*Page CM1164* 1600⟩
⟨*Page CM1165* 1601⟩
⟨*Page CM1166* 1602⟩
⟨*Page CM1167* 1603⟩
⟨*Page CM1168* 1604a⟩
⟨*Page CM1169* 1604b⟩
⟨*Page CM1170* 1605⟩
⟨*Page CM1171* 1606⟩
⟨*Page CM1172* 1607⟩
⟨*Page CM1173* 1608⟩
⟨*Page CM1174* 1609⟩
⟨*Page CM1175* 1610⟩
⟨*Page CM1176* 1611⟩
⟨*Page CM1177* 1612⟩
⟨*Page CM1178* 1613⟩
⟨*Page CM1179* 1614⟩
⟨*Page CM1180* 1615⟩
⟨*Page CM1181* 1616⟩
⟨*Page CM1182* 1618⟩
⟨*Page CM1183* 1620⟩
⟨*Page CM1184* 1621⟩
⟨*Page CM1185* 1623⟩
⟨*Page CM1186* 1624⟩
⟨*Page CM1187* 1625⟩
⟨*Page CM1188* 1626⟩
⟨*Page CM1189* 1627⟩
⟨*Page CM1190* 1628⟩
⟨*Page CM1191* 1629⟩
⟨*Page CM1192* 1630⟩
⟨*Page CM1193* 1631⟩
⟨*Page CM1194* 1632⟩
⟨*Page CM1195* 1633⟩

⟨*Page CM1196* 1634⟩
⟨*Page CM1197* 1635⟩
⟨*Page CM1198* 1636⟩
⟨*Page CM1199* 1637a⟩

1546 ⟨*Page CM1107* 1546⟩≡ (1544 2721)

```
# SECTION 1:  DISPATCHER
#
# ENTRY TO THE INTERPRETER.  INTPRET SETS LOC TO THE FIRST INSTRUCTION, BANKSET TO TH
# OBJECT INTERPRETIVE PROGRAM, AND INTBIT15 TO THE BIT15 CONTENTS OF FBANK.  INTERPRE
# VIRTUALLY ALL BANKS PRESENT UNDER ANY SUPER-BANK SETTING, WITH THE RESTRICTION THAT
# (BIT15 OF FBANK = 1) DO NOT REFER TO LOWBANKS, AND VICE-VERSA.  THE INTERPRETER DOE
# E-BANK SWITCHING OCCURS WHENEVER GENERAL ERASABLE (100-3777) IS ADDRESSED.

                BLOCK   03

                COUNT*  $$/INTER
INTPRET         RELINT
                EXTEND                          # SET LOC TO THE WORD FOLLOWING THE T
                QXCH    LOC
        +2      CA      BBANK                   # INTERPRETIVE BRANCHES FINISH HERE.
                TS      BANKSET
                MASK    BIT15                   # GET 15TH BIT FOR INDEXABLE ADDRESSE
                TS      INTBIT15

                TS      EDOP                    # MAKE SURE NO INSTRUCTIONS LEFT OVER

                TCF     NEWOPS                  # PICK UP OP CODE PAIR AND BEGIN.

INTRSM          LXCH    BBANK                   # RESUME SUSPENDED INTERPRETIVE JOB
                TCF     INTPRET +3

# DLOAD LOADS MPAC, MPAC +1, LEAVING ZERO IN MPAC +2.

DLOAD           EXTEND
                INDEX   ADDRWD
                DCA     0                       # LOAD DP C(C(ADDRWD)) INT MPAC,MPAC
SLOAD2          DXCH    MPAC
                CAF     ZERO                    # ZERO MPAC +2
```

Uses ADDRWD 140, BANKSET 145, BBANK 80, CODE 140, COUNT 142, EDOP 80, FBANK 80, INTBIT15 140, LOC 145, MPAC 145, and TC 169.

1547 ⟨*Page CM1108* 1547⟩≡ (1544 2721)

```
# AT THE END OF MOST INSTRUCTIONS, CONTROL IS GIVEN TO DANZIG TO DISPATCH THE NEXT OPERATION.

                TS      MPAC +2                 # AND DECLARE DP MODE

NEWMODE         TS      MODE                    # PROLOGUE FOR MODE-CHANGING INSTRUCTIONS.

DANZIG          CA      BANKSET                 # SET BBANK BEFORE TESTING NEWJOB SO THAT
                TS      BBANK                   # IT MAY BE SAVED DIRECTLY BY CHANJOB.

NOIBNKSW        CCS     EDOP                    # SEE IF AN ORDER CODE IS LEFT OVER FROM
                TCF     OPJUMP                  # THE LAST PAIR RETRIEVED.  IF SO, EXECUTE.
                                                # EDOP IS SET TO ZERO ON ITS RE-EDITING.

                CCS     NEWJOB                  # SEE IF A JOB OF HIGHER PRIORITY IS
                TCF     CHANG2                  # PRESENT, AND IF SO, CHANGE JOBS.

                INCR    LOC                     # ADVANCE THE LOCATION COUNTER.

# ITRACE (1) REFERS TO "NEWOPS"
NEWOPS          INDEX   LOC                     # ENTRY TO BEGIN BY PICKING OP CODE PAIR.
                CA      0                       # MAY BE AN OPCODE PAIR OR A STORE CODE.
                CCS     A                       # TEST SIGN AND GET DABS(A).
                TCF     DOSTORE                 # PROCESS STORE CODE.

LOW7            OCT     177

                TS      EDOP                    # OP CODE PAIR.  LEAVE THE OTHER IN EDOP
                MASK    LOW7                    # WHERE CCS EDOP WILL HONOR IT NEXT.

OPJUMP          TS      CYR                     # LOWWD ENTERS HERE IF A RIGHT-HAND OP
                CCS     CYR                     # CODE IS TO BE PROCESSED.  TEST PREFICES.
                TCF     OPJUMP2                 # TEST SECOND PREFIX BIT.

                TCF     EXIT                    # +0 OP CODE IS EXIT
```

Uses A 80, BANKSET 145, BBANK 80, CODE 140, CYR 80, EDOP 80, IT 185, LOC 145, MODE 145, MPAC 145, NEWJOB 138, and PRIORITY 145.

1548 ⟨*Page CM1109* 1548⟩≡ (1544 2721)

```
# PROCESS ADDRESSES WHICH MAY BE DIRECT, INDEXED, OR REFERENCE THE PUSHDOWN LIST.

ADDRESS         MASK    BIT1                    # SEE IF ADDRESS IS INDEXED.  CYR CON
                CCS     A                       # 400XX, SO BIT 1 IS NOW AS IT WAS IN
                TCF     INDEX                   # FORM INDEXED ADDRESS.

DIRADRES        INDEX   LOC                     # LOOK AHEAD TO NEXT WORD TO SEE IF
OCT40001        CS      1                       # ADDRESS IS GIVEN.
                CCS     A
                TCF     PUSHUP                  # IF NOT.

NEG4            DEC     -4

                INCR    LOC                     # IF SO, TO SHOW WE PICKED UP A WORD.
                TS      ADDRWD
```

Uses `A` 80, `ADDRWD` 140, `CYR` 80, `IT` 185, and `LOC` 145.

1549 ⟨*Page CM1110* 1549⟩≡ (1544 2721)

```
# FINAL DIGESTION OF DIRECT ADDRESSES OF OP CODES WITH 01 PREFIX IS DONE HERE.   IN EACH CASE,
# REQUIRED 12-BIT SUB-ADDRESS IS LEFT IN ADDRWD, WITH ANY REQUIRED E OR F BANK SWITCHING DONE.
# THAN 45D ARE TAKEN TO BE RELATIVE TO THE WORK AREA.  THE OP CODE IS NOW IN BITS 1-5 OF CYR WI

                AD      -ENDVAC                 # SEE IF ADDRESS RELATIVE TO WORK AREA.
                CCS     A
                AD      -ENDERAS                # IF NOT, SEE IF IN GENERAL ERASABLE.
                TCF     IERASTST

NETZERO         CA      FIXLOC                  # IF SO, LEAVE THE MODIFIED ADDRESS IN
                ADS     ADDRWD                  # ADDRWD AND DISPATCH.
ITR15           INDEX   CYR                     # THIS INDEX MAKES THE NEXT INSTRUCTION
                7       INDJUMP -1              # TCF INDJUMP + OP, EDITING CYR.

IERASTST        EXTEND
                BZMF    GEADDR                  # GO PROCESS GENERAL-ERASABLE ADDRESS.

                MASK    LOW10                   # FIXED BANK ADDRESS. RESTORE AND ADD B15.
                AD      LOW10                   # SWITCH BANKS AND LEAVE SUBADDRESS IN
                XCH     ADDRWD                  # ADDRWD FOR OPERAND RETRIEVAL. (THIS
                AD      INTBIT15                # METHOD PRECLUDES USE OF THE LAST
                TS      FBANK                   # LOCATION IN EACH FBANK.)
ITR12           INDEX   CYR
                7       INDJUMP -1

GEADDR          MASK    LOW8
                AD      OCT1400
                XCH     ADDRWD
                TS      EBANK
ITR10           INDEX   CYR
                7       INDJUMP -1
```

Uses `A` 80, `ADDRWD` 140, `CODE` 140, `CYR` 80, `EBANK` 80, `F` 238, `FBANK` 80, `FIXLOC` 140, and `INTBIT15` 140.

1550 ⟨*Page CM1111* 1550⟩≡ (1544 2721)

```
# THE FOLLOWING ROUTINE PROCESSES INTERPRETIVE INDEXED ADDRESSES.  AN INTERPRETER IND
# CONTAIN THE ADDRESS OF ANY ERASABLE REGISTER (0-42 BEING RELATIVE TO THE VAC AREA)
# BANK, OR ANY INTEGER IN THAT RANGE.

DODLOAD*        CAF     DLOAD*                  # STODL* COMES HERE TO PROCESS LOAD A
                TS      CYR                     # (STOVL* ENTERS HERE).

INDEX           CA      FIXLOC                  # SET UP INDEX LOCATION.
                TS      INDEXLOC
                INCR    LOC                     # (ADDRESS ALWAYS GIVEN).
                INDEX   LOC
                CS      0
                CCS     A                       # INDEX 2 IF ADDRESS STORED COMPLEMEN
                INCR    INDEXLOC
                NOOP

                TS      ADDRWD                  # 14 BIT ADDRESS TO ADDRWD.
                MASK    HIGH4                   # IF ADDRESS GREATER THAN 2K, ADD INT
                EXTEND
                BZF     INDEX2
                CA      INTBIT15
                ADS     ADDRWD

INDEX2          INDEX   INDEXLOC
                CS      X1
                ADS     ADDRWD                  # DO AUGMENT, IGNORING AND CORRECTING

                MASK    HIGH9                   # SEE IF ADDRESS IS IN WORK AREA.
                EXTEND
                BZF     INDWORK
                MASK    HIGH4                   # SEE IF IN FIXED BANK.
                EXTEND
                BZF     INDERASE

                CA      ADDRWD                  # IN FIXED -- SWITCH BANKS AND CREATE
                TS      FBANK                   # SUB-ADDRESS
                MASK    LOW10
                AD      2K
                TS      ADDRWD
ITR11           INDEX   CYR
                3       INDJUMP -1

INDWORK         CA      FIXLOC                  # MAKE ADDRWD RELATIVE TO WORK AREA.
                TCF     ITR13 -1
```

```
INDERASE        CA      OCT1400
                XCH     ADDRWD
                TS      EBANK
                MASK    LOW8
        -1      ADS     ADDRWD
```

Uses A 80, ADDRWD 140, CYR 80, EBANK 80, FBANK 80, FIXLOC 140, INDEXLOC 142, INTBIT15 140, LOC 145, RANGE 179, and X1 85.

1551 ⟨*Page CM1112* 1551⟩≡ (1544 2721)

```
ITR13           INDEX   CYR
                3       INDJUMP -1
```

Uses CYR 80.

1552 ⟨*Page CM1113* 1552⟩≡ (1544 2721)

```
# PUSH-UP ROUTINES.  WHEN NO OPERAND ADDRESS IS GIVEN, THE APPROPRIATE OPERAND IS TAK
# LIST.  IN MOST CASES THE MODE OF THE RESULT (VECTOR OR SCALAR) OF THE LAST ARITHMET
# IS THE SAME AS THE TYPE OF OPERAND DESIRED (ALL ADD/SUBTRACT ETC.).  EXCEPTIONS TO
# BELOW (NOTE THAT IN EVERY CASE THE MODE REGISTER IS LEFT INTACT):
#
#       1.      VXSC AND V/SC WANT THE OPPOSITE TYPE OF OPERAND, E.G., IF THE LAST OP
#               RESULT, VXSC WANTS A SCALAR.
#
#       2.      THE LOAD CODES SHOULD LOAD THE ACCUMULATOR INDEPENDENT OF THE RESULT
#               INCLUDES VLOAD, DLOAD, TLOAD, PDDL, AND PDVL (NO PUSHUP WITH SLOAD).
#
#       3.      SOME ARITHMETIC OPERATIONS REQUIRE A STANDARD TYPE OF OPERAND REGARDL
#               THIS INCLUDES SIGN WANTING DP AND TAD REQUIRING TP.

PUSHUP          CAF     OCT23           # IF THE LOW 5 BITS OF CYR ARE LESS THAN
                MASK    CYR             # 20, THIS OP REQUIRES SPECIAL ATTENTION.
                AD      -OCT10          # (NO -0).
                CCS     A
                TCF     REGUP           # FOR ALL CODES GREATER THAN OCT 7.

-OCT10          OCT     -10

                AD      NEG4            # WE NOW HAVE 7 -- OP CODE (MOD4).  SEE IF
                CCS     A               # THE OP CODE (MOD4) IS THREE (REVERSE).
                INDEX   A               # NO -- THE MODE IS DEFINITE.  PICK UP THE
                CS      NO.WDS
                TCF     REGUP +2

                INDEX   MODE            # FOR VXSC AND V/SC WE WANT THE REQUIRED
                CS      REVCNT          # PUSHLOC DECREMENT WITHOUT CHANGING THE
                TCF     REGUP +2        # MODE AT THE IS TIME.

REGUP           INDEX   MODE            # MOST ALL OP CODES PUSHUP HERE.
                CS      NO.WDS
        +2      ADS     PUSHLOC
                TS      ADDRWD
ITR14           INDEX   CYR
                7       INDJUMP -1      # (THE INDEX MAKES THIS A TCF.)

                OCT     2               # REVERSE PUSHUP DECREMENT. VECTOR TAKES 2
REVCNT          OCT     6               # WORDS, SCALAR TAKES 6.
                OCT     6
NO.WDS          OCT     2               # CONVENTIONAL DECREMENT IS 6 WORDS VECTOR
OCTAL3          OCT     3               # 2 IN DP, AND 3 IN TP.
                OCT     6
```

Uses A 80, ADDRWD 140, CODE 140, CYR 80, MODE 145, PUSHLOC 145, and V 229.

1553a ⟨*Page CM1114* 1553a⟩≡ (1544 2721)

```
# TEST THE SECOND PREFIX BIT TO SEE IF THIS IS A MISCELLANEOUS OR A UNARY/SHORT SHIFT OPERATION

OPJUMP2         CCS     CYR             # TEST SECOND PREFIX BIT.
                TCF     OPJUMP3         # TEST THIRD BIT TO SEE IF UNARY OR SHIFT

-ENDVAC         DEC     -45

# THE FOLLOWING ROUTINE PROCESSES ADDRESSES OF SUFFIX CLASS 10.  THEY ARE BASICALLY WORK AREA A
# IN THE RANGE 0-52, ERASABLE ECADR CONSTANTS FROM 100-3777, AND FCADRS ABOVE THAT.  ALL 15 BIT
# IN CONTRAST TO SUFFIX 1, IN WHICH ONLY THE LOW ORDER 14 ARE AVAILABLE.

15BITADR        INCR    LOC             # (ENTRY HERE FROM STCALL).
                INDEX   LOC             # PICK UP ADDRESS WORD.
                CA      0
                TS      POLISH          # WE MAY NEED A SUBADDRESS LATER.

                CAF     LOW7+2K         # THESE INSTRUCTIONS ARE IN BANK 1.
                TS      FBANK
                MASK    CYR
ITR7            INDEX   A
                TCF     MISCJUMP
```

Uses A 80, CYR 80, FBANK 80, LOC 145, POLISH 140, and RANGE 179.

1553b ⟨*Page CM1115* 1553b⟩≡ (1544 2721)

```
# COMPLETE THE DISPATCHING OF UNARY AND SHORT SHIFT OPERATIONS.

OPJUMP3         TS      FBANK           # CALL IN BANK 0 (BIT5S 11-15 OF A ARE 0.)

                CCS     CYR             # TEST THIRD PREFIX BIT.
                INDEX   A               # THE DECREMENTED UNARY CODE IS IN BITS
                TCF     UNAJUMP         # 1-4 OF A (ZERO, EXIT, HAS BEEN DETECTED)

                CCS     MODE            # IT'S A SHORT SHIFT CODE.  SEE IF PRESENT
                TCF     SHORTT          # SCALAR OR VECTOR.
                TCF     SHORTT
                TCF     SHORTV          # CALLS THE APPROPRIATE ROUTINE.

FBANKMSK        EQUALS  BANKMASK
LVBUF           ADRES   VBUF
```

Uses A 80, CODE 140, CYR 80, FBANK 80, MODE 145, and VBUF 140.

1554 ⟨*Page CM1116* 1554⟩≡ (1544 2721)

```
# THE FOLLOWING IS THE JUMP TABLE FOR OP CODES WHICH MAY HAVE INDEXABLE ADDRESSES OR

INDJUMP         TCF     VLOAD           # 00 -- LOAD MPAC WITH A VECTOR.
                TCF     TAD             # 01 -- TRIPLE PRECISION ADD TO MPAC.
                TCF     SIGN            # 02 -- COMPLEMENT MPAC (V OR SC) IF X NEG.
                TCF     VXSC            # 03 -- VECTOR TIMES SCALAR.
                TCF     CGOTO           # 04 -- COMPUTED GO TO.
                TCF     TLOAD           # 05 -- LOAD MPAC WITH TRIPLE PRECISION.
                TCF     DLOAD           # 06 -- LOAD MPAC WITH A DP SCALAR.
                TCF     V/SC            # 07 -- VECTOR DIVIDED BY A SCALAR.

                TCF     SLOAD           # 10 -- LOAD MPAC IN SINGLE PRECISION.
                TCF     SSP             # 11 -- SET SINGLE PRECISION INTO X.
                TCF     PDDL            # 12 -- PUSH DOWN MPAC AND RE-LOAD IN DP.
                TCF     MXV             # 13 -- MATRIX POST-MULTIPLIED BY VECTOR.
                TCF     PDVL            # 14 -- PUSH DOWN AND VECTORLOAD.
                TCF     CCALL           # 15 -- COMPUTED CALL.
                TCF     VXM             # 16 -- MATRIX PRE-MULTIPLIED BY VECTOR.
                TCF     TSLC            # 17 -- NORMALIZE MPAC (SCALAR ONLY).

                TCF     DMPR            # 20 -- DP MULTIPLY AND ROUND.
                TCF     DDV             # 21 -- DP DIVIDE BY.
                TCF     BDDV            # 22 -- DP DIVIDE INTO.
                TCF     GSHIFT          # 23 -- GENERAL SHIFT INSTRUCTION
                TCF     VAD             # 24 -- VECTOR ADD.
                TCF     VSU             # 25 -- VECTOR SUBTRACT.
                TCF     BVSU            # 26 -- VECTOR SUBTRACT FROM.
                TCF     DOT             # 27 -- VECTOR DOT PRODUCT.

                TCF     VXV             # 30 -- VECTOR CROSS PRODUCT.
                TCF     VPROJ           # 31 -- VECTOR PROJECTION.
                TCF     DSU             # 32 -- DP SUBTRACT.
                TCF     BDSU            # 33 -- DP SUBTRACT FROM.
                TCF     DAD             # 34 -- DP ADD.
                TCF     +0              # 35 -- AVAILABLE
                TCF     DMP1            # 36 -- DP MULTIPLY.
                TCF     SETPD           # 37 -- SET PUSH DOWN POINTER (DIRECT ONLY)

# CODES 10 AND 14 MUST NOT PUSH UP. CODE 04 MAY BE USED FOR VECTOR DECLARE BEFORE PUS
```

Uses `A` 80, `CODE` 140, `MPAC` 145, and `V` 229.

1555a ⟨*Page CM1117* 1555a⟩≡ (1544 2721)

```
# THE FOLLOWING JUMP TABLE APPLIES TO INDEX, BRANCH, AND MISCELLANEOUS INSTRUCTIONS.

MISCJUMP        TCF     AXT             # 00 -- ADDRESS TO INDEX TRUE.
                TCF     AXC             # 01 -- ADDRESS TO INDEX COMPLEMENTED.
                TCF     LXA             # 02 -- LOAD INDEX FROM ERASABLE.
                TCF     LXC             # 03 -- LOAD INDEX FROM COMPLEMENT OF ERAS.
                TCF     SXA             # 04 -- STORE INDEX IN ERASABLE.
                TCF     XCHX            # 05 -- EXCHANGE INDEX WITH ERASABLE.
                TCF     INCR            # 06 -- INCREMENT INDEX REGISTER.
                TCF     TIX             # 07 -- TRANSFER ON INDEX.

                TCF     XAD             # 10 -- INDEX REGISTER ADD FROM ERASABLE.
                TCF     XSU             # 11 -- INDEX SUBTRACT FROM ERASABLE.
                TCF     BZE/GOTO        # 12 -- BRANCH ZERO AND GOTO
                TCF     BPL/BMN         # 13 -- BRANCH PLUS AND BRANCH MINUS.
                TCF     RTB/BHIZ        # 14 -- RETURN TO BASIC AND BRANCH HI ZERO.
                TCF     CALL/ITA        # 15 -- CALL AND STORE QPRET.
                TCF     SW/             # 16 -- SWITCH INSTRUCTIONS AND AVAILABLE.
                TCF     BOV(B)          # 17 -- BRANCH ON OVERFLOW TO BASIC OR INT.
```

Uses QPRET 85.

1555b ⟨*Page CM1118* 1555b⟩≡ (1544 2721)

```
# THE FOLLOWING JUMP TABLE APPLIES TO UNARY INSTRUCTIONS
                COUNT*  $$/INTER
                BANK    0               # 00 -- EXIT -- DETECTED EARLIER.
UNAJUMP         TCF     SQRT            # 01 -- SQUARE ROOT.
                TCF     SINE            # 02 -- SIN.
                TCF     COSINE          # 03 -- COS.
                TCF     ARCSIN          # 04 -- ARC SIN.
                TCF     ARCCOS          # 05 -- ARC COS.
                TCF     DSQ             # 06 -- DP SQUARE.
                TCF     ROUND           # 07 -- ROUND TO DP.

                TCF     COMP            # 10 -- COMPLEMENT VECTOR OR SCALAR
                TCF     VDEF            # 11 -- VECTOR DEFINE.
                TCF     UNIT            # 12 -- UNIT VECTOR.
                TCF     ABVALABS        # 13 -- LENGTH OF VECTOR OR MAG OF SCALAR.
                TCF     VSQ             # 14 -- SQUARE OF LENGTH OF VECTOR.
                TCF     STADR           # 15 -- PUSH UP ON STORE CODE.
                TCF     RVQ             # 16 -- RETURN VIA QPRET.
                TCF     PUSH            # 17 -- PUSH MPAC DOWN.
```

Uses CODE 140, COUNT 142, MPAC 145, and QPRET 85.

1556 ⟨*Page CM1119* 1556⟩≡ (1544 2721)

```
# SECTION 2     LOAD AND STORE PACKAGE.
#
# A SET OF EIGHT STORE CODES IS PROVIDED AS THE PRIMARY METHOD OF STORING THE MULTI-P
# ACCUMULATOR (MPAC).  IF IN THE DANZIG SECTION LOC REFERS TO AN ALGEBRAICALLY POSITI
# STORE CODE WITH A CORRESPONDING ERASABLE ADDRESS.  MOST OF THESE CODES ARE TWO ADDR
# FOLLOWING THE STORE CODE IS TO BE USED AS AN ADDRESS FROM WHICH TO RE-LOAD MPAC.  P
#
#       1. STORE        STORE MPAC.  THE E ADDRESS MAY BE INDEXED.
#       2. STODL        STORE MPAC AND RE-LOAD IT IN DP WITH THE NEXT ADDRESS (THE LO
#       3. STOVL        STORE MPAC AND RE-LOAD A VECTOR (AS ABOVE).
#       4. STCALL       STORE AND DO A CALL (BOTH ADDRESSES MUST BE DIRECT HERE).
#
# STODL AND STOVL WILL TAKE FROM THE PUSH-DOWN LIST IF NO LOAD ADDRESS IS GIVEN.

                BLOCK   3

                COUNT   03/INTER

STADR           CA      BANKSET         # THE STADR CODE (PUSHUP UP ON STORE
                TS      FBANK           # ADDRESS) ENTERS HERE.
                INCR    LOC
ITR1            INDEX   LOC             # THE STORECODE WAS STORED COMPLEMENTED TO
                CS      0               # MAKE IT LOOK LIKE AN OPCODE PAIR.
                AD      NEGONE          # (YUL CANT REMOVE 1 BECAUSE OF EARLY CCS)

DOSTORE         TS      ADDRWD
                MASK    LOW11           # ENTRY FROM DISPATCHER.  SAVE THE ERASABLE
                XCH     ADDRWD          # ADDRESS AND JUMP ON THE STORE CODE NO.
                MASK    B12T14
                EXTEND
                MP      BIT5            # EACH TRANSFER VECTOR ENTRY IS TWO WORDS.
ITR0            INDEX   A
                TCF     STORJUMP
```

Uses `A` 80, `ADDRWD` 140, `BANKSET` 145, `CODE` 140, `COUNT` 142, `FBANK` 80, `IT` 185, `LOC` 145, `MPAC` 145, and `SAVE` 191.

1557 ⟨*Page CM1120* 1557⟩≡ (1544 2721)

```
# STORE CODE JUMP TABLE.  CALLS THE APPROPRIATE STORING ROUTINE AND EXITS TO DANZIG OR TO ADDRE
# A SUPPLIED OPERATION CODE.
#
# STORE STORE,1 AND STORE,2 RETURN TO DANZIG, THUS RESETTING THE EBANK TO ITS STATE AT INTPRET.

STORJUMP        TC      STORE           # STORE.
                TCF     DANZIG          # PICK UP NEW OP CODE(S).
                TC      STORE,1
                TCF     DANZIG
                TC      STORE,2
                TCF     DANZIG

                TC      STORE           # STODL.
                TCF     DODLOAD

                TC      STORE           # STODL WITH INDEXED LOAD ADDRESS.
                TCF     DODLOAD*

                TC      STORE           # STOVL.
                TCF     DOVLOAD

                TC      STORE           # STOVL WITH INDEXED LOAD ADDRESS.
                TCF     DOVLOAD*
                TC      STORE           # STOTC.
                CAF     CALLCODE
                TS      CYR
                TCF     15BITADR        # GET A 15 BIT ADDRESS.
```

Uses `A` 80, `CODE` 140, `CYR` 80, `EBANK` 80, `STATE` 138, and `TC` 169.

1558 ⟨*Page CM1121* 1558⟩≡ (1544 2721)

```
# STORE CODE ADDRESS PROCESSOR.

STORE,1         INDEX   FIXLOC
                CS      X1
                TCF     PRESTORE

STORE,2         INDEX   FIXLOC
                CS      X2
PRESTORE        ADS     ADDRWD          # RESULTANT ADDRESS IS IN ERASABLE.

STORE           CS      ADDRWD
                AD      DEC45
                CCS     A               # DOES THE ADDRESS POINT TO THE WORK AREA?
                CA      FIXLOC          # YES.
                TCF     AHEAD5
                CA      OCT1400         # NO.  SET EBANK & MAKE UP SUBADDRESS.
                XCH     ADDRWD
                TS      EBANK
                MASK    LOW8
AHEAD5          ADS     ADDRWD
```

Uses `A` 80, `ADDRWD` 140, `CODE` 140, `EBANK` 80, `FIXLOC` 140, `X1` 85, and `X2` 85.

1559 ⟨*Page CM1122* 1559⟩≡ (1544 2721)

```
# STORING ROUTINES.  STORE DP, TP, OR VECTOR AS INDICATED BY MODE.

STARTSTO        EXTEND                  # MPAC,+1 MUST BE STORED IN ANY EVENT.
# ITRACE (5) REFERS TO "STARTSTO".
                DCA     MPAC
                INDEX   ADDRWD
                DXCH    0

                CCS     MODE
                TCF     TSTORE
                TC      Q

VSTORE          EXTEND
                DCA     MPAC +3
                INDEX   ADDRWD
                DXCH    2

                EXTEND
                DCA     MPAC +5
                INDEX   ADDRWD
                DXCH    4
                TC      Q

TSTORE          CA      MPAC +2
                INDEX   ADDRWD
                TS      2
                TC      Q
```

Uses ADDRWD 140, MODE 145, MPAC 145, Q 80, and TC 169.

1560 ⟨*Page CM1123* 1560⟩≡ (1544 2721)

```
# ROUTINES TO BEGIN PROCESSING OF THE SECOND ADDRESS ASSOCIATED WITH ALL STORE-TYPE C
# ITSELF.

DODLOAD         CAF     DLOADCOD
                TS      CYR
                TCF     DIRADRES        # GO GET A DIRECT ADDRESS.

DOVLOAD         CAF     VLOADCOD
                TS      CYR
                TCF     DIRADRES

DOVLOAD*        CAF     VLOAD*
                TCF     DODLOAD* +1     # PROLOGUE TO INDEX ROUTINE.
```

Uses `A` 80 and `CYR` 80.

1561 ⟨*Page CM1124* 1561⟩≡ (1544 2721)

```
# THE FOLLOWING LOAD INSTRUCTIONS ARE PROVIDED FOR LOADING THE MULTI-PURPOSE ACCUMULATOR MPAC.

TLOAD           INDEX   ADDRWD
                CA      2               # LOAD A TRIPLE PRECISION ARGUMENT INTO
                TS      MPAC +2         # THE FIRST THREE MPAC REGISTERS, WITH THE
                EXTEND                  # CONTENTS OF THE OTHER FOUR IRRELEVANT.
                INDEX   ADDRWD
                DCA     0
                DXCH    MPAC
TMODE           CAF     ONE
                TCF     NEWMODE         # DECLARE TRIPLE PRECISION MODE.

SLOAD           ZL                      # LOAD A SINGLE PRECISION NUMBER INTO
                INDEX   ADDRWD          # MPAC, SETTING MPAC+1,2 TO ZERO.  THE
                CA      0               # CONTENTS OF THE REMAINING MPAC REGISTERS
                TCF     SLOAD2          # ARE IRRELEVANT.

VLOAD           EXTEND                  # LOAD A DOUBLE PRECISION VECTOR INTO
                INDEX   ADDRWD          # MPAC,+1, MPAC+3,4, AND MPAC+5,6.  THE
                DCA     0               # CONTENTS OF MPAC +2 ARE IRRELEVANT.
                DXCH    MPAC

ENDVLOAD        EXTEND                  # PDVL COMES HERE TO FINISH UP FOR DP, TP.
                INDEX   ADDRWD
                DCA     2
                DXCH    MPAC +3

        +4      EXTEND                  # TPDVL FINISHES HERE.
                INDEX   ADDRWD
                DCA     4
                DXCH    MPAC +5

VMODE           CS      ONE             # DECLARE VECTOR MODE.
                TCF     NEWMODE
```

Uses `A` 80, `ADDRWD` 140, `MODE` 145, and `MPAC` 145.

1562 ⟨*Page CM1125* 1562⟩≡ (1544 2721)

```
# THE FOLLOWING INSTRUCTIONS ARE PROVIDED FOR STORING OPERANDS IN THE PUSHDOWN LIST:
#       1.      PUSH            PUSHDOWN AND NO LOAD.
#       2.      PDDL            PUSHDOWN AND DOUBLE PRECISION LOAD.
#       3.      PDVL            PUSHDOWN AND VECTOR LOAD.

PDDL            EXTEND
                INDEX   ADDRWD          # LOAD MPAC,+1, PUSHING THE FORMER
                DCA     0               # CONTENTS DOWN.
                DXCH    MPAC
                INDEX   PUSHLOC
                DXCH    0

                INDEX   MODE            # ADVANCE THE PUSHDOWN POINTER APPRO-
                CAF     NO.WDS          # PRIATELY.
                ADS     PUSHLOC

                CCS     MODE
                TCF     ENDTPUSH
                TCF     ENDDPUSH

                TS      MODE            # NOW DP.
ENDVPUSH        TS      MPAC +2
                DXCH    MPAC +3         # PUSH DOWN THE REST OF THE VECTOR HERE.
                INDEX   PUSHLOC
                DXCH    0 -4

                DXCH    MPAC +5
                INDEX   PUSHLOC
                DXCH    0 -2

                TCF     DANZIG

ENDDPUSH        TS      MPAC +2         # SET MPAC +2 TO ZERO AND EXIT ON DP.
                TCF     DANZIG

ENDTPUSH        TS      MODE
                XCH     MPAC +2         # ON TRIPLE, SET MPAC +2 TO ZERO, PUSHING
        +2      INDEX   PUSHLOC         # DOWN THE OLD CONTENTS
                TS      0 -1
                TCF     DANZIG
```

Uses ADDRWD 140, MODE 145, MPAC 145, and PUSHLOC 145.

1563 ⟨*Page CM1126* 1563⟩≡ (1544 2721)

```
# PDVL -- PUSHDOWN AND VECTOR LOAD

PDVL            EXTEND                  # RELOAD MPAC AND PUSH DOWN ITS CONTENTS.
                INDEX   ADDRWD
                DCA     0
                DXCH    MPAC
                INDEX   PUSHLOC
                DXCH    0

                INDEX   MODE            # ADVANCE THE PUSHDOWN POINTER.
                CAF     NO.WDS
                ADS     PUSHLOC

                CCS     MODE            # TEST PAST MODE.
                TCF     TPDVL
                TCF     ENDVLOAD        # JUST LOAD LAST FOUR REGISTERS ON DP.

VPDVL           EXTEND                  # PUSHDOWN AND RE-LOAD LAST TWO COMPONENTS
                INDEX   ADDRWD
                DCA     2
                DXCH    MPAC +3
                INDEX   PUSHLOC
                DXCH    0 -4

                EXTEND
                INDEX   ADDRWD
                DCA     4
                DXCH    MPAC +5
                INDEX   PUSHLOC
                DXCH    0 -2

                TCF     DANZIG

TPDVL           EXTEND                  # ON TP, WE MUST LOAD THE Y COMPONENT
                INDEX   ADDRWD          # BEFORE STORING MPAC +2 IN CASE THIS IS A
                DCA     2               # PUSHUP.
                DXCH    MPAC +3

                CA      MPAC +2
                INDEX   PUSHLOC         # IN DP.
                TS      0 -1
                TCF     ENDVLOAD +4

# SSP (STORE SINGLE PRECISION) IS EXECUTED HERE.
```

```
SSP             INCR    LOC             # PICK UP THE WORD FOLLOWING THE GIVEN
                INDEX   LOC             # ADDRESS AND STORE IT AT X.
                CA      0
STORE1          INDEX   ADDRWD          # SOME INDEX AND MISCELLANEOUS OPS END
                TS      0               # HERE.
```

Uses A 80, ADDRWD 140, IT 185, LOC 145, MODE 145, MPAC 145, and PUSHLOC 145.

1564 ⟨*Page CM1127* 1564⟩≡ (1544 2721)

```
                TCF     DANZIG
```

1565 ⟨*Page CM1128* 1565⟩≡ (1544 2721)

```
# SEQUENCE CHANGING AND SUBROUTINE CALLING OPTIONS.
#
# THE FOLLOWING OPERATIONS ARE AVAILABLE FOR SEQUENCING CHANGING, BRANCHING, AND CALLING SUBROU
#       1.      GOTO            GO TO.
#       2.      CALL            CALL SUBROUTINE SETTING QPRET.
#       3.      CGOTO           COMPUTED GO TO.
#       4.      CCALL           COMPUTED CALL.
#       7.      BPL             BRANCH IF MPAC POSITIVE OR ZERO.
#       8.      BZE             BRANCH IF MPAC ZERO.
#       9.      BMN             BRANCH IF MPAC NEGATIVE NON-ZERO.

CCALL           INCR    LOC             # MAINTAIN LOC FOR QPRET COMPUTATION
                INDEX   LOC
                # Was CAF --- RSB 2009.
                CA      0               # GET BASE ADDRESS OF CADR LIST.
                INDEX   ADDRWD
                AD      0               # ADD INCREMENT.
                TS      FBANK           # SELECT DESIRED CADR.
                MASK    LOW10
                INDEX   A
                CAF     10000
                TS      POLISH

CALL            CA      BANKSET         # FOR ANY OF THE CALL OPTIONS, MAKE UP THE
                MASK    BANKMASK        # ADDRESS OF THE NEXT OP-CODE PAIR/STORE
                AD      BANKMASK        # CODE AND LEAVE IT IN QPRET.  NOTE THAT
                AD      LOC             # BANKMASK = -(2000 - 1).
                INDEX   FIXLOC
                TS      QPRET

GOTO            CA      POLISH          # BASIC BRANCHING SEQUENCE.
        +1      MASK    HIGH4
                EXTEND
                BZF     GOTOERS         # SEE IF ADDRESS POINTS TO FIXED OR ERAS.
        +4      CA      BANKSET         # SET EBANK PART OF BBANK.  NEXT, SET UP
                TS      BBANK           # FBANK.  THE COMBINATION IS PICKED UP &
                CA      POLISH          # PUT INTO BANKSET AT INTPRET +2.
                TS      FBANK
                MASK    LOW10
                AD      2K
                TS      LOC
                TCF     INTPRET +3

                EBANK=  1400            # SO YUL DOESN'T CUSS THE "CA 1400" BELOW.
```

```
GOTOERS         CA      POLISH          # THE GIVEN ADDRESS IS IN ERASABLE -- SEE
                AD      -ENDVAC         # IF RELATIVE TO THE WORK ARA.
                CCS     A
                CA      POLISH          # GENERAL ERASABLE.
                TCF     GOTOGE
```

Uses A 80, ADDRWD 140, BANKSET 145, BBANK 80, CODE 140, EBANK 80, FBANK 80, FIXLOC 140, IT 185, LOC 145, MPAC 145, POLISH 140, and QPRET 85.

1566 ⟨*Page CM1129* 1566⟩≡ (1544 2721)

```
                CA      FIXLOC          # WORK AREA.
                AD      POLISH
                INDEX   A               # USE THE GIVEN ADDRESS AS THE ADDRESS OF
                CA      0               # THE BRANCH ADDRESS.
                TS      POLISH
                TCF     GOTO +1         # ALLOWS ARBITRARY INDIRECTNESS LEVELS.

GOTOGE          TS      EBANK
                MASK    LOW8
                INDEX   A               # USE THE GIVEN ADDRESS AS THE ADDRESS OF
                CA      1400            # THE BRANCH ADDRESS.
                TS      POLISH
                TCF     GOTO +1

CGOTO           INDEX   LOC             # COMPUTED GO TO.  PICK UP ADDRESS OF CADR
                CA      1               # LIST
                INDEX   ADDRWD          # ADD MODIFIER.
                AD      0
                TS      FBANK           # SELECT GOTO ADDRESS
                MASK    LOW10
                INDEX   A
                CA      10000
                TS      POLISH
                TCF     GOTO +1         # WITH ADDRESS IN A.

SWBRANCH        CA      BANKSET         # SWITCH INSTRUCTIONS WHICH ELECT TO
                TS      FBANK           # BRANCH COME HERE TO DO SO.
                INDEX   LOC
                CA      1
                TS      POLISH
                TCF     GOTO +1
```

Uses A 80, ADDRWD 140, BANKSET 145, EBANK 80, FBANK 80, FIXLOC 140, LOC 145, and POLISH 140.

1567 ⟨*Page CM1130* 1567⟩≡ (1544 2721)

```
# TRIPLE PRECISION BRANCHING ROUTINE.  IF CALLING TC IS AT L, RETURN IS AS FOLLOWS:
#       L+1     IF MPAC IS GREATER THAN ZERO.
#       L+2     IF MPAC IS EQUAL TO +0 OR -0.
#       L+3     IF MPAC IS LESS THAN ZERO.

BRANCH          CCS     MPAC
                TC      Q
                TCF     +2              # ON ZERO.
                TCF     NEG

                CCS     MPAC +1
                TC      Q
                TCF     +2
                TCF     NEG

                CCS     MPAC +2
                TC      Q
                TCF     +2
                TCF     NEG

Q+1             INDEX   Q
                TC      1

NEG             INDEX   Q               # IF FIRST NON-ZERO REGISTER WAS NEGATIVE.
                TC      2

Q+2             =       NEG

# ITRACE (3) REFERS TO "EXIT".

EXIT            CA      BANKSET         # RESTORE USER'S BANK SETTING, AND LEAVE
                TS      BBANK           # INTERPRETIVE MODE.
                INDEX   LOC
                TC      1
```

Uses BANKSET 145, BBANK 80, L 80, LOC 145, MODE 145, MPAC 145, Q 80, and TC 169.

1568 ⟨*Page CM1131* 1568⟩≡ (1544 2721)

```
# SECTION 3 -- ADD/SUBTRACT PACKAGE.
#
# THE FOLLOWING OPERATIONS ARE PROVIDED FOR ADDING TO AND SUBTRACTING FROM THE MULTI-
# MPAC:
#       1.      DAD     DOUBLE PRECISION ADD.
#       2.      DSU     DOUBLE PRECISION SUBTRACT.
#       3.      BDSU    DOUBLE PRECISION SUBTRACT FROM.
#       4.      TAD     TRIPLE PRECISION ADD.
#       5.      VAD     VECTOR ADD.
#       6.      VSU     VECTOR SUBTRACT.
#       7.      BVSU    VECTOR SUBTRACT FROM.
# THE INTERPRETIVE OVERFLOW INDICATOR OVFIND IS SET NON-ZERO IF OVERFLOW OCCURS IN AN

VSU             CAF     BIT15           # CHANGES 0 TO DCS.
                TCF     +2

VAD             CAF     PRIO30          # CHANGES 0 TO DCA.
                ADS     ADDRWD
                EXTEND
                INDEX   ADDRWD
                READ    HISCALAR        # DCA 2 OR DCS 2
                DAS     MPAC +3
                EXTEND                  # CHECK OVERFLOW.
                BZF     +2
                TC      OVERFLWY

                EXTEND
                INDEX   ADDRWD
                READ    CHAN5           # DCA 4 OR DCS 4
                DAS     MPAC +5
                EXTEND
                BZF     +2
                TC      OVERFLWZ

                EXTEND
                INDEX   ADDRWD
                READ    LCHAN           # DCA 0 OR DCS 0
                TCF     ENDVXV

DAD             EXTEND
                INDEX   ADDRWD
                DCA     0
ENDVXV          DAS     MPAC            # VXV FINISHES HERE.
                EXTEND
                BZF     DANZIG
```

Uses ADDRWD 140, HISCALAR 87, LCHAN 87, MPAC 145, OVFIND 140, and TC 169.

1569 ⟨*Page CM1132* 1569⟩≡ (1544 2721)

```
SETOVF          TC      OVERFLOW
                TCF     DANZIG
```

Uses TC 169.

1570 ⟨*Page CM1133* 1570⟩≡ (1544 2721)

```
DSU             EXTEND
                INDEX   ADDRWD
                DCS     0
                TCF     ENDVXV

OVERFLWZ        TS      L               # ENTRY FOR THIRD COMPONENT.
                CAF     FIVE
                TCF     +3

OVERFLWY        TS      L               # ENTRY FOR SECOND COMPONENT.
                CAF     THREE
                XCH     L

OVERFLOW        INDEX   A               # ENTRY FOR 1ST COMP OR DP (L=0).
                CS      LIMITS          # PICK UP POSMAX OR NEGMAX.
                TS      BUF
                EXTEND
                AUG     A
                INDEX   L
                ADS     MPAC +1
                TS      7
                CAF     ZERO
                AD      BUF
                INDEX   L
                ADS     MPAC
                TS      7
                TC      Q               # NO OVERFLOW EXIT.
                TCF     SETOVF2         # SET OVFIND AND EXIT.

BVSU            EXTEND
                INDEX   ADDRWD
                DCA     2
                DXCH    MPAC +3
                EXTEND
                DCOM
                DAS     MPAC +3
                EXTEND
                BZF     +2
                TC      OVERFLWY

                EXTEND
                INDEX   ADDRWD
                DCA     4
                DXCH    MPAC +5
                EXTEND
```

```
                DCOM
                DAS     MPAC +5
                EXTEND
                BZF     +2
                TC      OVERFLWZ
```

Uses A 80, ADDRWD 140, BUF 142, L 80, MPAC 145, OVFIND 140, Q 80, and TC 169.

1571a ⟨*Page CM1134* 1571a⟩≡ (1544 2721)

```
BDSU            EXTEND
                INDEX   ADDRWD
                DCA     0
                DXCH    MPAC
                EXTEND
                DCOM
                TCF     ENDVXV
```

Uses ADDRWD 140 and MPAC 145.

1571b ⟨*Page CM1135* 1571b⟩≡ (1544 2721)

```
# TRIPLE PRECISION ADD ROUTINE.

TAD             EXTEND
                INDEX   ADDRWD
                DCA     1               # ADD MINOR PARTS FIRST.
                DAS     MPAC +1
                INDEX   ADDRWD
                AD      0
                AD      MPAC
                TS      MPAC
                TCF     DANZIG

                TCF     SETOVF          # SET OVFIND IF SUCH OCCURS.
```

Uses ADDRWD 140, MPAC 145, and OVFIND 140.

1572 ⟨*Page CM1136* 1572⟩≡ (1544 2721)

```
# ARITHMETIC SUBROUTINES REQUIRED IN FIXED-FIXED.
#       1.  DMPSUB      DOUBLE PRECISION MULTIPLY, MULTIPLY THE CONTENTS OF MPAC,+1 I
#                       IS IN ADDRWD AND LEAVE A TRIPLE-PRECISION RESULT IN MPAC.
#       2.  ROUNDSUB    ROUND THE TRIPLE PRECISION CONTENTS OF MPAC TO DOUBLE PRECISI
#       3.  DOTSUB      TAKE THE DOT PRODUCT OF THE VECTOR IN MPAC AND THE VECTOR WHO
#                       AND LEAVE THE TRIPLE PRECISION RESULT IN MPAC.
#       4.  POLY        USING THE CONTENTS OF MPAC AS A DP ARGUMENT, EVALUATE THE POI
#                       COEFFICIENTS IMMEDIATELY FOLLOW THE TC POLY INSTRUCTION (SEE

DMP             INDEX   Q               # BASIC SUBROUTINE FOR USE BY PINBALL, ETC
                # Was CAF --- RSB 2009.
                CA      0
                INCR    Q
        -1      TS      ADDRWD          # (PROLOGUE FOR SETTING ADDRWD.)

DMPSUB          INDEX   ADDRWD          # GET MINOR PART OF OPERAND AT C(ADDRWD).
                CA      1
                TS      MPAC +2         # THIS WORKS FOR SQUARING MPAC AS WELL.
                CAF     ZERO            # SET MPAC +1 TO ZERO SO WE CAN ACCUMULATE
                XCH     MPAC +1         # THE PARTIAL PRODUCTS WITH DAS
                TS      MPTEMP          # INSTRUCTIONS.
                EXTEND
                MP      MPAC +2         # MINOR OF MPAC X MINOR OF C(ADDRWD).

                XCH     MPAC +2         # DISCARD MINOR PART OF ABOVE RESULT AND
                EXTEND                  # FORM MAJOR OF MPAC X MINOR OF C(ADDRWD).
                MP      MPAC
                DAS     MPAC +1         # GUARANTEED NO OVERFLOW.

                INDEX   ADDRWD          # GET MAJOR PART OF ARGUMENT AT C(ADDRWD).
                CA      0
                XCH     MPTEMP          # SAVE AND BRING OUT MINOR OF MPAC.
DMPSUB2         EXTEND
                MP      MPTEMP          # MAJOR OF C(ADDRWD) X MINOR OF MPAC.
                DAS     MPAC +1         # ACCUMULATE, SETTING A TO NET OVERFLOW.

                XCH     MPAC            # SETTING MPAC TO 0 OR +-1.
                EXTEND
                MP      MPTEMP          # MAJOR OF MPAC X MAJOR OF C(ADDRWD).
                DAS     MPAC            # GUARANTEED NO OVERFLOW.
                TC      Q               # 49 MCT = .573 MS. INCLUDING RETURN.
```

Uses `A` 80, `ADDRWD` 140, `MPAC` 145, `MPTEMP` 142, `Q` 80, `SAVE` 191, and `TC` 169.

1573 ⟨*Page CM1137* 1573⟩≡ (1544 2721)

```
# ROUND MPAC TO DOUBLE PRECISION, SETTING OVFIND ON THE RARE EVENT OF OVERFLOW.

ROUNDSUB        CAF     ZERO            # SET MPAC +2 = 0 FOR SCALARS AND CHANGE
        +1      TS      MODE            # MODE TO DP.

VROUND          XCH     MPAC +2         # BUT WE NEEDN'T TAKE THE TIME FOR VECTORS.
                DOUBLE
                TS      L
                TC      Q

                AD      MPAC +1         # ADD ROUDING BIT IF MPAC +2 WAS GREATER
                TS      MPAC +1         # THAN .5 IN MAGNITUDE.
                TC      Q

                AD      MPAC            # PROPAGATE INTERFLOW.
                TS      MPAC
                TC      Q

SETOVF2         TS      OVFIND          # (RARE).
                TC      Q
```

Uses `L` 80, `MODE` 145, `MPAC` 145, `OVFIND` 140, `Q` 80, and `TC` 169.

1574 ⟨*Page CM1138* 1574⟩≡ (1544 2721)

```
# THE DOT PRODUCT SUBROUTINE USUALLY FORMS THE DOT PRODUCT OF THE VECTOR IN MPAC WITH
# REGISTER VECTOR WHOSE ADDRESS IS IN ADDRWD.  IN THIS CASE C(DOTINC) ARE SET TO 2. W
# 6 SO THAT DOTSUB DOTS MPAC WITH A COLUMN VECTOR OF THE MATRIX IN QUESTION IN THIS C

PREDOT          CAF     TWO             # PROLOGUE TO SET DOTINC TO 2.
                TS      DOTINC

DOTSUB          EXTEND
                QXCH    DOTRET          # SAVE RETURN
                TC      DMPSUB          # DOT X COMPONENTS.
                DXCH    MPAC +3         # POSITION Y COMPONENT OF MPAC FOR
                DXCH    MPAC            # MULTIPLICATION WHILE SAVING RESULT IN
                DXCH    BUF             # THREE WORD BUFFER, BUF.
                CA      MPAC +2
                TS      BUF +2

                CA      DOTINC          # ADVANCE ADDRWD TO Y COMPONENT OF
                ADS     ADDRWD          # OTHER ARGUMENT.
                TC      DMPSUB
                DXCH    MPAC +1         # ACCUMULATE PARTIAL PRODUCTS.
                DAS     BUF +1
                AD      MPAC
                AD      BUF
                TS      BUF
                TCF     +2
                TS      OVFIND          # IF OVERFLOW OCCURS.

                DXCH    MPAC +5         # MULTIPLY Z COMPONENTS.
                DXCH    MPAC
                CA      DOTINC
                ADS     ADDRWD
                TC      DMPSUB
ENDDOT          DXCH    BUF +1          # LEAVE FINAL ACCUMULATION IN MPAC.
                DAS     MPAC +1
                AD      MPAC
                AD      BUF
                TS      MPAC
                TC      DOTRET

                TC      OVERFLOW        # ON OVERFLOW HERE.
                TC      DOTRET
```

Uses `A` 80, `ADDRWD` 140, `BUF` 142, `DOTINC` 142, `DOTRET` 142, `MPAC` 145, `OVFIND` 140, `SAVE` 191, `TC` 169, and `Z` 80.

1575 ⟨*Page CM1139* 1575⟩≡ (1544 2721)

```
# DOUBLE PRECISION POLYNOMIAL EVALUATOR
#                                N        N-1
#       THIS ROUTINE EVALUATES A X  + A   X    + ... + A  X + A  LEAVING THE DP RESULT IN MPAC
#                              N      N-1              1      0
#
# THE ROUTINE HAS TWO ENTRIES
#
#       1       ENTRY THRU POWRSERS.  THE COEFFICIENTS MAY BE EITHER IN FIXED OR ERASABLE E.  T
#               TC POWRSERS, AND THE RETURN IS TO LOC(TC POWRSERS)+1.  THE ENTERING DATA MUST B
#                       A       SP      LOC-3           ADDRESS FOR REFERENCING COEF TABLE
#                       L       SP      N-1             N IS THE DEGREE OF THE POWER SERIES
#                       MPAC    DP      X               ARGUMENT
#                       LOC-2N  DP      A(0)
#                               ...
#                       LOC     DP      A(N)
#
#       2.      ENTRY THRU POLY.  THE CALL TO POLY AND THE ENTERING DATA MUST BE AS FOLLOWS
#                       MPAC            DP              X               ARGUMENT
#                       LOC             TC              POLY
#                       LOC+1           DP              A(0)
#                                       ...
#                       LOC+2N+2        DP              A(N)            RETURN IS TO LOC+2N+4

POWRSERS        EXTEND
                QXCH    POLYRET         # RETURN ADDRESS
                TS      POLISH          # POWER SERIES ADDRESS
                LXCH    POLYCNT         # N-1 TO COUNTER
                TCF     POLYCOM         # SKIP SET UP BY POLY

POLY            INDEX   Q
                # Was CAF --- RSB 2009.
                CA      0
                TS      POLYCNT         # N-1 TO COUNTER
                DOUBLE
                AD      Q
                TS      POLISH          # L(A(N))-3 TO POLISH
                AD      FIVE
                TS      POLYRET         # STORE RETURN ADDRESS

POLYCOM         CAF     LVBUF           # INCOMING X WILL BE MOVED TO VBUF, SO
                TS      ADDRWD          # SET ADDRWD SO DMPSUB WILL MPY BY VBUF.

                EXTEND
                INDEX   POLISH
                DCA     3
```

Uses A 80, ADDRWD 140, L 80, LOC 145, MPAC 145, N 206, POLISH 140, POLYCNT 142, POLYRET 142, Q 80, TC 169, and VBUF 140.

1576 ⟨*Page CM1140* 1576⟩≡ (1544 2721)

```
                DXCH    MPAC            # LOAD A(N) INTO MPAC
                DXCH    VBUF            # SAVING X IN VBUF
                TCF     POLY2

POLYLOOP        TS      POLYCNT         # SAVE DECREMENTED LOOP COUNTER
                CS      TWO
                ADS     POLISH          # REGRESS COEFFICIENT POINTER

POLY2           TC      DMPSUB          # MULTIPLY BY X
                EXTEND
                INDEX   POLISH
                DCA     1               # ADD IN NEXT COEFFICIENT
                DAS     MPAC            # USER'S RESPONSIBILITY TO ASSURE NO OVFLOW

                CCS     POLYCNT
                TCF     POLYLOOP
                TC      POLYRET         # RETURN CALLER
```

Uses A 80, MPAC 145, N 206, POLISH 140, POLYCNT 142, POLYRET 142, SAVE 191, TC 169, and VBUF 140.

1577 ⟨*Page CM1141* 1577⟩≡ (1544 2721)

```
# MISCELLANEOUS MULTI-PRECISION ROUTINES REQUIRED IN FIXED-FIXED BUT NOT USED BY THE INTERPRETE

DPAGREE         CAF     ZERO            # DOUBLE PRECISION ENTRY --
                TS      MPAC +2         # ZERO LOW-ORDER WORD

TPAGREE         LXCH    Q               # FORCE SIGN AGREEMENT AMONG THE TRIPLE
                TC      BRANCH          # PRECISION CONTENTS OF MPAC.  RETURNING
                TCF     ARG+            # WITH SIGNUM OF THE INPUT IN A.
                TCF     ARGZERO

                CS      POSMAX          # IF NEGATIVE.
                TCF     +2

ARG+            CAF     POSMAX
                TS      Q
                EXTEND
                AUG     A               # FORMS +-1.0.
                AD      MPAC +2
                TS      MPAC +2
                CAF     ZERO
                AD      Q
                AD      MPAC +1
                TS      MPAC +1
                CAF     ZERO
                AD      Q               # Q STILL HAS POSMAX OR NEGMAX IN IT.
                AD      MPAC
ARGZERO2        TS      MPAC            # ALWAYS SKIPPING UNLESS ARGZERO.
                TS      MPAC +1
                TC      L               # RETURN VIA L.

ARGZERO         TS      MPAC +2         # SET ALL THREE MPAC REGISTERS TO ZERO.
                TCF     ARGZERO2

# SHORTMP MULTIPLIES THE TP CONTENTS OF MPAC BY THE SINGLE PRECISION NUMBER ARRIVING IN A.

SHORTMP         TS      MPTEMP
                EXTEND
                MP      MPAC +2
                TS      MPAC +2
SHORTMP2        CAF     ZERO            # SO SUBSEQUENT DAS WILL WORK.
                XCH     MPAC +1
                TCF     DMPSUB2
```

Uses `A` 80, `IT` 185, `L` 80, `MPAC` 145, `MPTEMP` 142, `Q` 80, and `TC` 169.

1578a ⟨*Page CM1142* 1578a⟩≡ (1544 2721)

```
# DMPNSUB MULTIPLIES THE DP FRACTION ARRIVING IN MPAC BY THE SP
# INTEGER ARRIVING IN A.  THE DP PRODUCT DEPARTS BOTH IN MPAC AND IN
# A AND L.  NOTE THAT DMPNSUB NORMALLY INCREASES THE MAGNITUDE OF THE
# CONTENTS OF MPAC.  THE CUSTOMER MUST INSURE THAT B(A) X B(MPAC,MPAC+1)
# AND B(A) X B(MPAC) ARE LESS THAN 1 IN MAGNITUDE, WHERE B, AS IS OBVIOUS,
# INDICATES THE ARRIVING CONTENTS.

DMPNSUB         TS      DMPNTEMP
                EXTEND
                MP      MPAC +1
                DXCH    MPAC            # LOW PRODUCT TO MPAC, HIGH FACTOR TO A
                EXTEND
                MP      DMPNTEMP
                CA      L
                ADS     MPAC            # COMPLETING THE PRODUCT IN MPAC
                EXTEND
                DCA     MPAC            # BRINGING THE PRODUCT INTO A AND L
                TC      Q
```

Uses `A` 80, `DMPNTEMP` 142, `FACTOR` 226, `L` 80, `MPAC` 145, `Q` 80, and `TC` 169.

1578b ⟨*Page CM1143* 1578b⟩≡ (1544 2721)

```
# MISCELLANEOUS VECTOR OPERATIONS.  INCLUDED HERE ARE THE FOLLOWING.
#       1.      DOT     DP VECTOR DOT PRODUCT.
#       2.      VXV     DP VECTOR CROSS PRODUCT.
#       3.      VXSC    DP VECTOR TIMES SCALAR.
#       4.      V/SC    DP VECTOR DIVIDED BY SCALAR.
#       5.      VPROJ   DP VECTOR PROJECTION.  ( (MPAC.X)MPAC ).
#       6.      VXM     DP VECTOR POST-MULTIPLIED BY MATRIX.
#       7.      MXV     DP VECTOR PRE-MULTIPLIED BY MATRIX.

DOT             TC      PREDOT          # DO THE DOT PRODUCT AND EXIT, CHANGING
DMODE           CAF     ZERO            # THE MODE TO DP SCALAR.
                TCF     NEWMODE

MXV             CAF     TWO             # SET UP MATINC AND DOTINC FOR ROW
                TS      MATINC          # VECTORS.
                TCF     VXM/MXV         # GO TO COMMON PORTION.

VXM             CS      TEN             # SET MATINC AND DOTINC TO REFER TO MATRIX
                TS      MATINC          # AS THREE COLUMN VECTORS.
                CAF     SIX
```

Uses `DOTINC` 142, `MATINC` 142, `MODE` 145, `MPAC` 145, `TC` 169, and `V` 229.

1579 ⟨*Page CM1144* 1579⟩≡ (1544 2721)

```
# COMMON PORTION OF MXV AND VXM.

VXM/MXV         TS      DOTINC

# ITRACE (2) REFERS TO "VXM/MXV".

                TC      MPACVBUF        # SAVE VECTOR IN MPAC FOR FURTHER USE.

                TC      DOTSUB          # GO DOT TO GET X COMPONENT OF ANSWER.
                EXTEND
                DCA     VBUF            # MOVE MPAC VECTOR BACK INTO MPAC, SAVING
                DXCH    MPAC            # NEW X COMPONENT IN BUF2.
                DXCH    BUF2
                EXTEND
                DCA     VBUF +2
                DXCH    MPAC +3
                EXTEND
                DCA     VBUF +4
                DXCH    MPAC +5
                CA      MATINC          # INITIALIZE ADDRWD FOR NEXT DOT PRODUCT.
                ADS     ADDRWD          # FORMS HAS ADDRESS OF NEXT COLUMN(ROW).

                TC      DOTSUB
                DXCH    VBUF            # MORE GIVEN VECTOR BACK TO MPAC, SAVING Y
                DXCH    MPAC            # COMPONENT OF ANSWER IN VBUF +2.
                DXCH    VBUF +2
                DXCH    MPAC +3
                DXCH    VBUF +4
                DXCH    MPAC +5
                CA      MATINC          # FORM ADDRESS OF LAST COLUMN OR ROW.
                ADS     ADDRWD

                TC      DOTSUB
                DXCH    BUF2            # ANSWER NOW COMPLETE. PUT COMPONENTS INTO
                DXCH    MPAC            # PROPER MPAC REGISTERS.
                DXCH    MPAC +5
                DXCH    VBUF +2
                DXCH    MPAC +3
                TCF     DANZIG          # EXIT.
```

Uses ADDRWD 140, BUF2 142, DOTINC 142, MATINC 142, MPAC 145, SAVE 191, TC 169, and VBUF 140.

1580 ⟨*Page CM1145* 1580⟩≡ (1544 2721)

```
# VXSC -- VECTOR TIMES SCALAR.

VXSC            CCS     MODE            # TEST PRESENT MODE.
                TCF     DVXSC           # SEPARATE ROUTINE WHEN SCALAR IS IN MPAC.
                TCF     DVXSC

VVXSC           TC      DMPSUB          # COMPUTE X COMPONENT
                TC      VROUND          # AND ROUND IT.
                DXCH    MPAC +3         # PUT Y COMPONENT INTO MPAC SAVING MPAC IN
                DXCH    MPAC            # MPAC +3.
                DXCH    MPAC +3

                TC      DMPSUB          # DO SAME FOR Y AND Z COMPONENTS.
                TC      VROUND
                DXCH    MPAC +5
                DXCH    MPAC
                DXCH    MPAC +5

                TC      DMPSUB
                TC      VROUND
VROTATEX        DXCH    MPAC            # EXIT USED TO RESTORE MPAC AFTER THIS
                DXCH    MPAC +5         # TYPE OF ROTATION.  CALLED BY VECTOR SHIFT
                DXCH    MPAC +3         # RIGHT, V/SC, ETC.
                DXCH    MPAC
                TCF     DANZIG
```

Uses IT 185, MODE 145, MPAC 145, TC 169, V 229, and Z 80.

1581 ⟨*Page CM1146* 1581⟩≡ (1544 2721)

```
# DP VECTOR PROJECTION ROUTINE.

VPROJ           TC      PREDOT          # (MPAC.X)MPAC IS COMPUTED AND LEFT IN
                CS      FOUR            # MPAC.  DO DOT AND FALL INTO DVXSC.
                ADS     ADDRWD

# VXSC WHEN SCALAR ARRIVES IN MPAC AND VECTOR IS AT X.

DVXSC           EXTEND                  # SAVE SCALAR IN MPAC +3 AND GET X
                DCA     MPAC            # COMPONENT OF ANWER.
                DXCH    MPAC +3
                TC      DMPSUB
                TC      VROUND

                CAF     TWO             # ADVANCE ADDRWD TO Y COMPONENT OF X.
                ADS     ADDRWD
                EXTEND
                DCA     MPAC +3         # PUT SCALAR BACK INTO MPAC AND SAVE
                DXCH    MPAC            # X RESULT IN MPAC +5.
                DXCH    MPAC +5
                TC      DMPSUB
                TC      VROUND

                CAF     TWO
                ADS     ADDRWD          # TO Z COMPONENT.
                DXCH    MPAC +3         # BRING SCALAR BACK, PUTTING Y RESULT IN
                DXCH    MPAC            # THE PROPER PLACE.
                DXCH    MPAC +3
                TC      DMPSUB
                TC      VROUND

                DXCH    MPAC            # PUT Z COMPONENT IN PROPER PLACE, ALSO
                DXCH    MPAC +5         # POSITIONING X.
                DXCH    MPAC

                TCF     VMODE           # MODE HAS CHANGED TO VECTOR.
```

Uses ADDRWD 140, MODE 145, MPAC 145, SAVE 191, TC 169, and Z 80.

1582 ⟨*Page CM1147* 1582⟩≡ (1544 2721)

```
# VECTOR CROSS PRODUCT ROUTINE CALCULATES (X M -X M ,X M -X M ,X M -X M ) WHERE M IS
#                                          3 2  2 3  1 3  3 1  2 1  1 2
# MPAC AND X THE VECTOR AT THE GIVEN ADDRESS.

VXV             EXTEND
                DCA     MPAC +5         # FORM UP M3X1, LEAVING M1 IN VBUF.
                DXCH    MPAC
                DXCH    VBUF
                TC      DMPSUB          # BY X1.

                EXTEND
                DCS     MPAC +3         # CALCULATE -X1M2, SAVING X1M3 IN VBUF +2.
                DXCH    MPAC
                DXCH    VBUF +2
                TC      DMPSUB

                CAF     TWO             # ADVANCE ADDRWD TO X2.
                ADS     ADDRWD
                EXTEND
                DCS     MPAC +5         # PREPARE TO GET -X2M3, SAVING -X1M2 IN
                DXCH    MPAC            # MPAC +5.
                DXCH    MPAC +5
                TC      DMPSUB

                EXTEND
                DCA     VBUF            # GET X2M1, SAVING -X2M3 IN VBUF +4.
                DXCH    MPAC
                DXCH    VBUF +4
                TC      DMPSUB

                CAF     TWO             # ADVANCE ADDRWD TO X3.
                ADS     ADDRWD
                EXTEND
                DCS     VBUF            # GET -X3M1, ADDING X2M1 TO MPAC +5 TO
                DXCH    MPAC            # COMPLETE THE Z COMPONENT OF THE ANSWER.
                DAS     MPAC +5

                EXTEND
                BZF      +2
                TC      OVERFLWZ

                TC      DMPSUB
                DXCH    VBUF +2         # MOVE X1M3 TO MPAC +3 SETTING UP FOR X3M2
                DXCH    MPAC +3         # AND ADD -X3M1 TO MPAC +3 TO COMPLETE THE
                DXCH    MPAC            # Y COMPONENT OF THE RESULT.
```

```
DAS     MPAC +3

EXTEND
BZF     +2
```

Uses ADDRWD 140, MPAC 145, TC 169, VBUF 140, X1 85, X2 85, and Z 80.

1584 ⟨*Page CM1148* 1584⟩≡ (1544 2721)

```
                TC OVERFLWY

                TC      DMPSUB
                DXCH    VBUF +4         # GO ADD -X2M3 TO X3M2 TO COMPLETE THE X
                TCF     ENDVXV          # COMPONENT (TAIL END OF DAD).

# THE MPACVBUF SUBROUTINE SAVES THE VECTOR IN MPAC IN VBUF WITHOUT CLOBBERING MPAC.

MPACVBUF        EXTEND                  # CALLED BY MXV, VXM, AND UNIT.
                DCA     MPAC
                DXCH    VBUF
                EXTEND
                DCA     MPAC +3
                DXCH    VBUF +2
                EXTEND
                DCA     MPAC +5
                DXCH    VBUF +4
                TC      Q               # RETURN TO CALLER.

# DOUBLE PRECISION SIGN AGREE ROUTINE.  ARRIVE WITH INPUT IN A+L.  OUTPUT IS IN A + L

ALSIGNAG        CCS     A               # TEST UPPER PART.
                TCF     UPPOS           # IT IS POSITIVE
                TC      Q               # ZERO
                TCF     UPNEG           # NEGATIVE
                TC      Q               # ZERO

UPPOS           XCH     L               # SAVE DECREMENTED UPPER PART.
                AD      HALF
                AD      HALF
                TS      A               # SKIPS ON OVERFLOW
                TCF     +2
                INCR    L               # RESTORE UPPER TO ROIGINAL VALUE
                XCH     L               # SWAP A + L BACK.
                TC      Q

UPNEG           XCH     L               # SAVE COMPLEMENTED + DECREMENTED UPPER PT
                AD      NEGMAX
                AD      NEGONE
                TS      A
                TCF     +2              # DON'T INCREMENT IF NO OVERFLOW.
                INCR    L
                XCH     L
                COM                     # MAKE NEGATIVE AGAIN.
                TC      Q
```

Uses A 80, IT 185, L 80, MPAC 145, Q 80, SAVE 191, TC 169, and VBUF 140.

1585 ⟨*Page CM1149* 1585⟩≡ (1544 2721)

```
# INTERPRETIVE INSTRUCTIONS WHOSE EXECUTION CONSISTS OF PRINCIPALLY CALLING SUBROUTINES.

DMP1            TC      DMPSUB          # DMP INSTRUCTIONS
                TCF     DANZIG

DMPR            TC      DMPSUB
                TC      ROUNDSUB +1     # (C(A) = +0).
                TCF     DANZIG

DDV             EXTEND
                INDEX   ADDRWD          # MOVE DIVIDEND INTO BUF.
                DCA     0
                TCF     BDDV +4

BDDV            EXTEND                  # MOVE DIVISOR INTO MPAC SAVING MPAC, THE
                INDEX   ADDRWD          # DIVIDEND, IN BUF.
                DCA     0
                DXCH    MPAC
        +4      DXCH    BUF
                CAF     ZERO            # DIVIDE ROUTINES IN BANK 0.
                TS      FBANK
                TCF     DDV/BDDV

SETPD           CA      ADDRWD          # MUST SET TO WORK AREA, OR EBANK TROUBLE.
                TS      PUSHLOC
                TCF     NOIBNKSW        # NO FBANK SWITCH REQUIRED.

TSLC            CAF     ZERO            # SHIFTING ROUTINES LOCATED IN BANK 00.
                TS      FBANK
                TCF     TSLC2

GSHIFT          CAF     LOW7            # USED AS MASK AT GENSHIFT. THIS PROCESSES
                TS      FBANK           # ANY SHIFT INSTRUCTION (EXCEPT TSLC) WITH
                TCF     GENSHIFT        # AN ADDRESS (ROUTINES IN BANK 0).
```

Uses A 80, ADDRWD 140, BUF 142, EBANK 80, FBANK 80, MPAC 145, PUSHLOC 145, and TC 169.

1586 ⟨*Page CM1150* 1586⟩≡ (1544 2721)

```
# THE FOLLOWING IS THE PROLOGUE TO V/SC.  IF THE PRESENT MODE IS VECTOR, IT SAVES THE
# AND CALLS THE V/SC ROUTINE IN BANK 0.  IF THE PRESENT MODE IS SCALAR, IT MOVES THE
# THE SCALAR IN MPAC IN BUF BEFORE CALLING THE V/SC ROUTINE IN BANK 0.

V/SC            CCS     MODE
                TCF     DV/SC           # MOVE VECTOR INTO MPAC.
                TCF     DV/SC

VV/SC           EXTEND
                INDEX   ADDRWD
                DCA     0
V/SC1           DXCH    BUF             # IN BOTH CASES, VECTOR IS NOW IN MPAC AND
                CAF     ZERO            # SCALAR IN BUF.
                TS      FBANK
                TCF     V/SC2

DV/SC           EXTEND
                INDEX   ADDRWD
                DCA     2
                DXCH    MPAC +3
                EXTEND
                INDEX   ADDRWD
                DCA     4
                DXCH    MPAC +5

                CS      ONE             # CHANGE MODE TO VECTOR.
                TS      MODE

                EXTEND
                INDEX   ADDRWD
                DCA     0
                DXCH    MPAC
                TCF     V/SC1
```

Uses ADDRWD 140, BUF 142, DV 241, FBANK 80, IT 185, MODE 145, MPAC 145, and V 229.

1587 ⟨*Page CM1151* 1587⟩≡ (1544 2721)

```
# SIGN AND COMPLEMENT INSTRUCTIONS.

SIGN            INDEX   ADDRWD          # CALL COMP INSTRUCTION IF WORD AT X IS
                CCS     0               # NEGATIVE NON-ZERO.
                TCF     DANZIG
                TCF     +2
                TCF     COMP            # DO THE COMPLEMENT.

                INDEX   ADDRWD
CCSL            CCS     1
                TCF     DANZIG
                TCF     DANZIG
                TCF     COMP
                TCF     DANZIG
COMP            EXTEND                  # COMPLEMENT DP MPAC IN EVERY CASE.
                DCS     MPAC
                DXCH    MPAC

                CCS     MODE            # EITHER COMPLEMENT MPAC +3 OR THE REST OF
                TCF     DCOMP           # THE VECTOR ACCUMULATOR.
                TCF     DCOMP

                EXTEND                  # VECTOR COMPLEMENT.
                DCS     MPAC +3
                DXCH    MPAC +3
                EXTEND
                DCS     MPAC +5
                DXCH    MPAC +5
                TCF     DANZIG

DCOMP           CS      MPAC +2
                TS      MPAC +2
                TCF     DANZIG
```

Uses `ADDRWD` 140, `MODE` 145, and `MPAC` 145.

1588 ⟨*Page CM1152* 1588⟩≡ (1544 2721)

```
# THE FOLLOWING SHORT SHIFT CODES REQUIRE NO ADDRESS WORD:
#       1.      SR1 TO SR4      SCALAR SHIFT RIGHT.
#       2.      SR1R TO SR4R    SCALAR SHIFT RIGHT AND ROUND.
#       3.      SL1 TO SL4      SCALAR SHIFT LEFT.
#       4.      SL1R TO SL4R    SCALAR SHIFT LEFT AND ROUND.
#       5.      VSR1 TO VSR8    VECTOR SHIFT RIGHT (ALWAYS ROUNDS).
#       6.      VSL1 TO VSL8    VECTOR SHIFT LEFT (NEVER ROUNDS).
# THE FOLLOWING CODES REQUIRE AN ADDRESS WHICH MAY BE INDEXED:*
#       1.      SR              SCALAR SHIFT RIGHT.
#       2.      SRR             SCALAR SHIFT RIGHT AND ROUND.
#       3.      SL              SCALAR SHIFT LEFT.
#       4.      SLR             SCALAR SHIFT LEFT AND ROUND.
#       5.      VSR             VECTOR SHIFT RIGHT.
#       6.      VSL             VECTOR SHIFT LEFT.
# * IF THE ADDRESS IS INDEXED, AND THE INDEX MODIFICATION RESULTS IN A NEGATIVE SHIFT
# ABSOLUTE VALUE OF THE COUNT IS DONE IN THE OPPOSITE DIRECTION.

                BANK    00

                COUNT   00/INTER

SHORTT          CAF     SIX             # SCALAR SHORT SHIFTS COME HERE.  THE SHIFT
                MASK    CYR             # COUNT-1 IS NOW IN BITS 2-3 OF CYR.  THE
                TS      SR              # ROUNDING BIT IS IN BIT1 AT THIS POINT.

                CCS     CYR             # SEE IF RIGHT OR LEFT SHIFT DESIRED.
                TCF     TSSL            # SHIFT LEFT.

SRDDV           DEC     20              # MPTEMP SETTING FOR SR BEFORE DDV.

TSSR            INDEX   SR              # GET SHIFTING BIT.
                CAF     BIT14
                TS      MPTEMP

                CCS     CYR             # SEE IF A ROUND IS DESIRED.
RIGHTR          TC      MPACSRND        # YES -- SHIFT RIGHT AND ROUND.
                TCF     NEWMODE         # SET MODE TO DP (C(A) = 0).
MPACSHR         CA      MPTEMP          # DO A TRIPLE PRECISION SHIFT RIGHT.
                EXTEND
                MP      MPAC +2
        +3      TS      MPAC +2         # (EXIT FROM SQRT AND ABVAL).
                CA      MPTEMP
                EXTEND
```

Uses A 80, COUNT 142, CYR 80, MODE 145, MPAC 145, MPTEMP 142, SR 80, and TC 169.

1589 ⟨*Page CM1153* 1589⟩≡ (1544 2721)

```
                MP      MPAC            # SHIFT MAJOR PART INTO A,L AND PLACE IN
                DXCH    MPAC            # MPAC,+1.
                CA      MPTEMP
                EXTEND
                MP      L               # ORIGINAL C(MPAC +1).
                DAS     MPAC +1         # GUARANTEED NO OVERFLOW.
                TCF     DANZIG

# MPAC SHIFT RIGHT AND ROUND SUBROUTINES

MPACSRND        CA      MPAC +2         # WE HAVE TO DO ALL THREE MULTIPLIES SINCE
                EXTEND                  # MPAC +1 AND MPAC +2 MIGHT HAVE SIGN
                MP      MPTEMP          # DISAGREEMENT WITH A SHIFT RIGHT OF L.
                XCH     MPAC +1
                EXTEND
                MP      MPTEMP
                XCH     MPAC +1         # TRIAL MINOR PART.
                AD      L

VSHR2           DOUBLE                  # (FINISH VECTOR COMPONENT SHIFT RIGHT
                TS      MPAC +2         # AND ROUND.)
                TCF     +2
                ADS     MPAC +1         # GUARANTEED NO OVERFLOW.

                CAF     ZERO
                TS      MPAC +2
                XCH     MPAC            # SETTING TO ZERO SO FOLLOWING DAS WORKS.
                EXTEND
                MP      MPTEMP
                DAS     MPAC            # AGAIN NO OVERFLOW.
                TC      Q

VSHRRND         CA      MPTEMP          # ENTRY TO SHIFT RIGHT AND ROUND MPAC WHEN
                EXTEND                  # MPAC CONTAINS A VECTOR COMPONENT.
                MP      MPAC +1
                TS      MPAC +1
                XCH     L
                TCF     VSHR2           # GO ADD ONE IF NECESSARY AND FINISH.
```

Uses `A` 80, `L` 80, `MPAC` 145, `MPTEMP` 142, `Q` 80, and `TC` 169.

1590 ⟨*Page CM1154* 1590⟩≡ (1544 2721)

```
# ROUTINE FOR SHORT SCALAR SHIFT LEFT (AND MAYBE ROUND).

TSSL            CA      SR              # GET SHIFT COUNT FOR SR.
        +1      TS      MPTEMP

        +2      EXTEND                  # ENTRY HERE FROM SL FOR SCALARS.
                DCA     MPAC +1         # SHIFTING LEFT ONE PLACE AT A TIME IS
                DAS     MPAC +1         # FASTER THAN DOING THE WHOLE SHIFT WITH
                AD      MPAC            # MULTIPLIES ASSUMING THAT FREQUENCY OF
                AD      MPAC            # SHIFT COUNTS GOES DOWN RAPIDLY AS A
                TS      MPAC            # FUNCTION OF THEIR MAGNITUDE.
                TCF     +2
                TS      OVFIND          # OVERFLOW.  (LEAVES OVERFLOW-CORRECTED
                                        # RESULT ANYWAY).
                CCS     MPTEMP          # LOOP ON DECREMENTED SHIFT COUNT.
                TCF     TSSL +1

                CCS     CYR             # SEE IF ROUND WANTED.
ROUND           TC      ROUNDSUB        # YES -- ROUND AND EXIT.
                TCF     DANZIG          # SL LEAVES A ZERO IN CYR FOR NO ROUND.
                TCF     DANZIG          # NO -- EXIT IMMEDIATELY
```

Uses `A` 80, `COUNT` 142, `CYR` 80, `MPAC` 145, `MPTEMP` 142, `OVFIND` 140, `SR` 80, and `TC` 169.

1591 ⟨*Page CM1155* 1591⟩≡ (1544 2721)

```
# VECTOR SHIFTING ROUTINES.

SHORTV          CAF     LOW3            # SAVE 3 BIT SHIFT COUNT -- 1 WITHOUT
                MASK    CYR             # EDITING CYR.
                TS      MPTEMP
                CCS     CYR             # SEE IF LEFT OR RIGHT SHIFT.
                TCF     VSSL            # VECTOR SHIFT LEFT.
OCT176          OCT     176             # USED IN PROCESSED SHIFTS WITH - COUNT.

VSSR            INDEX   MPTEMP          # (ENTRY FROM SR).  PICK UP SHIFTING BIT.
                CAF     BIT14           # MPTEMP CONTAINS THE SHIFT COUNT - 1.
                TS      MPTEMP
                TC      VSHRRND         # SHIFT X COMPONENT.

                DXCH    MPAC            # SWAP X AND Y COMPONENTS.
                DXCH    MPAC +3
                DXCH    MPAC
                TC      VSHRRND         # SHIFT Y COMPONENT.

                DXCH    MPAC            # SWAP Y AND Z COMPONENTS.
                DXCH    MPAC +5
                DXCH    MPAC
                TC      VSHRRND         # SHIFT Z COMPONENT.

                TCF     VROTATEX        # RESTORE COMPONENTS TO PROPER PLACES.
```

Uses COUNT 142, CYR 80, MPAC 145, MPTEMP 142, SAVE 191, SR 80, TC 169, and Z 80.

1592 ⟨*Page CM1156* 1592⟩≡ (1544 2721)

```
# VECTOR SHIFT LEFT -- DONE ONE PLACE AT A TIME.

        -1      TS      MPTEMP          # SHIFTING LOOP.

VSSL            EXTEND
                DCA     MPAC
                DAS     MPAC
                EXTEND
                BZF     +2
                TC      OVERFLOW

                EXTEND
                DCA     MPAC +3
                DAS     MPAC +3
                EXTEND
                BZF     +2
                TC      OVERFLWY

                EXTEND
                DCA     MPAC +5
                DAS     MPAC +5
                EXTEND
                BZF     +2
                TC      OVERFLWZ

                CCS     MPTEMP          # LOOP ON DECREMENTED SHIFT COUNTER.
                TCF     VSSL -1
                TCF     DANZIG          # EXIT.
```

Uses `A` 80, `MPAC` 145, `MPTEMP` 142, and `TC` 169.

1593 ⟨*Page CM1157* 1593⟩≡ (1544 2721)

```
# TSLC -- TRIPLE SHIFT LEFT AND COUNT.  SHIFTS MPAC LEFT UNTIL GREATER THAN .5 IN MAGNITUDE, LE
# THE COMPLEMENT OF THE NUMBER OF SHIFTS REQUIRED IN X.

TSLC2           TS      MPTEMP          # START BY ZEROING SHIFT COUNT (IN A NOW).
                TC      BRANCH          # EXIT WITH NO SHIFTING IF ARGUMENT ZERO.
                TCF     +2
                TCF     ENDTSLC         # STORES ZERO SHIFT COUNT IN THIS CASE.

                TC      TPAGREE         # MAY CAUSE UPSHIFT OF ONE EXTRA PLACE.

                CA      MPAC            # BEGIN NORMALIZATION LOOP.
                TCF     TSLCTEST

TSLCLOOP        INCR    MPTEMP          # INCREMENT SHIFT COUNTER.
                EXTEND
                DCA     MPAC +1
                DAS     MPAC +1
                AD      MPAC
                ADS     MPAC
TSLCTEST        DOUBLE                  # SEE IF (ANOTHER) SHIFT IS REQUIRED
                OVSK
                TCF     TSLCLOOP        # YES -- INCREMENT COUNT AND SHIFT AGAIN.

ENDTSLC         CS      MPTEMP
                TCF     STORE1          # STORE SHIFT COUNT AND RETURN TO DANZIG.
```

Uses `A` 80, `COUNT` 142, `MPAC` 145, `MPTEMP` 142, and `TC` 169.

1594 ⟨*Page CM1158* 1594⟩≡ (1544 2721)

```
# THE FOLLOWING ROUTINE PROCESSES THE GENERAL SHIFT INSTRUCTIONS SR, SRR, SL, AND SLR
# THE GIVEN ADDRESS IS DECODED AS FOLLOWS:
#       BITS 1-7        SHIFT COUNT (SUBADDRESS) LESS THAN 125 DECIMAL.
#       BIT 8           PSEUDO SIGN BIT (DETECTS CHANGE IN SIGN IN INDEXED SHIFTS).
#       BIT 9           0 FOR LEFT SHIFT, AND 1 FOR RIGHT SHIFT.
#       BIT 10          1 FOR TERMINAL ROUND ON SCALAR SHIFTS, 0 OTHERWISE
#       BITS 11-13      0.
#       BIT 14          1.
#       BIT 15          0.
# THE ABOVE ENCODING IS DONE BY THE YUL SYSTEM.

GENSHIFT        MASK    ADDRWD          # GET SHIFT COUNT, TESTING FOR ZERO.
                CCS     A               # (ARRIVES WITH C(A) = LOW7).
                TCF     GENSHFT2        # IF NON-ZERO, PROCEED WITH DECREMENTED CT

                CAF     BIT10           # ZERO SHIFT COUNT.  NO SHIFTS NEEDED BUT
                MASK    ADDRWD          # WE MIGHT HAVE TO ROUND MPAC ON SLR AND
                CCS     A               # SRR (SCALAR ONLY).
                TC      ROUNDSUB
                TCF     DANZIG

GENSHFT2        TS      MPTEMP          # DECREMENTED SHIFT COUNT TO MPTEMP.
                CAF     BIT8            # TEST MEANING OF LOW SEVEN BIT COUNT IN
                EXTEND                  # MPTEMP NOW.
                MP      ADDRWD
                MASK    LOW2            # JUMPS ON SHIFT DIRECTION (BIT8) AND
                INDEX   A
                TCF     +1              # ORIGINAL SHIFT DIRECTION (BIT 9)
                TCF     RIGHT-          # NEGATIVE SHIFT COUNT FOR SL OR SLR.
                TCF     LEFT            # SL OR SLR.
                TCF     LEFT-           # NEGATIVE SHIFT COUNT WITH SR OR SRR.
```

Uses `A` 80, `ADDRWD` 140, `COUNT` 142, `MPAC` 145, `MPTEMP` 142, `SR` 80, and `TC` 169.

1595 ⟨*Page CM1159* 1595⟩≡ (1544 2721)

```
# GENERAL SHIFT RIGHT

RIGHT           CCS     MODE            # SET IF VECTOR OR SCALAR.
                TCF     GENSCR
                TCF     GENSCR

                CA      MPTEMP          # SEE IF SHIFT COUNT LESS THAN 14D.
VRIGHT2         AD      NEG12
                EXTEND
                BZMF    VSSR            # IF SO, BRANCH AND SHIFT IMMEDIATELY.

                AD      NEGONE          # IF NOT, REDUCE MPTEMP BY A TOTAL OF 14.
                TS      MPTEMP          # AND DO A SHIFT RIGHT AND ROUND BY 14.
                CAF     ZERO            # THE ROUND AT THIS STAGE MAY INTRODUCE A
                TS      L               # ONE BIT ERROR IN A SHIFT RIGHT 15D.
                XCH     MPAC
                XCH     MPAC +1
                TC      SETROUND        # X COMPONENT NOW SHIFTED, SO MAKE UP THE
                DAS     MPAC            # ROUNDING QUANTITY (0 IN A AND 0 OR +-1
                                        # IN L).
                XCH     MPAC +3         # REPEAT THE ABOVE PROCESS FOR Y AND Z/
                XCH     MPAC +4
                TC      SETROUND
                DAS     MPAC +3         # NO OVERFLOW ON THESE ADDS.

                XCH     MPAC +5
                XCH     MPAC +6
                TC      SETROUND
                DAS     MPAC +5

                CCS     MPTEMP          # SEE IF DONE, DOING FINAL DECREMENT.
                TS      MPTEMP
                TCF     VRIGHT2
BIASLO          DEC     .2974 B-1       # SQRT CONSTANT

                TCF     DANZIG

SETROUND        DOUBLE                  # MAKES UP ROUNDING QUANTITY FROM ARRIVING
                TS      MPAC +2         # C(A).  L IS ZERO INITIALLY.
                CAF     ZERO
                XCH     L
                TC      Q               # RETURN AND DO THE DAS, RESETTING L TO 0.
```

Uses A 80, COUNT 142, L 80, MODE 145, MPAC 145, MPTEMP 142, Q 80, TC 169, and Z 80.

1596 ⟨*Page CM1160* 1596⟩≡ (1544 2721)

```
# PROCESS SR AND SRR FOR SCALARS.

GENSCR          CA      MPTEMP          # SEE IF THE ORIGINAL SHIFT COUNT WAS LESS
        +1      AD      NEG12           # THAN 14D.
                EXTEND
                BZMF    DOSSHFT         # DO THE SHIFT IMMEDIATELY IF SO.

        +4      AD      NEGONE          # IF NOT, DECREMENT SHIFT COUNT BY 14D AND
                TS      MPTEMP          # SHIFT MPAC RIGHT 14 PLACES.
                CAF     ZERO
                XCH     MPAC
                XCH     MPAC +1
                TS      MPAC +2
                CCS     MPTEMP          # SEE IF FINISHED, DO FINAL DECREMENT.
                TS      MPTEMP
                TC      GENSCR +1
SLOPEHI         DEC     .5884           # SQRT CONSTANT.
                CAF     BIT10           # FINISHED WITH SHIFT.  SEE IF ROUND
                MASK    ADDRWD          # WANTED.
                CCS     A
                TC      ROUNDSUB
                TCF     DANZIG          # DO SO AND/OR EXIT.

DOSSHFT         INDEX   MPTEMP          # PICK UP SHIFTING BIT.
                CAF     BIT14
                TS      MPTEMP
                CAF     BIT10           # SEE IF TERMINAL ROUND DESIRED.
                MASK    ADDRWD
                CCS     A
                TCF     RIGHTR          # YES.
                TCF     MPACSHR         # JUST SHIFT RIGHT.
```

Uses `A` 80, `ADDRWD` 140, `COUNT` 142, `MPAC` 145, `MPTEMP` 142, `SR` 80, and `TC` 169.

1597 ⟨*Page CM1161* 1597⟩≡ (1544 2721)

```
# PROCESS THE RIGHT- (SL(R) WITH A NEGATIVE COUNT), LEFT-, AND LEFT OPTIONS.

RIGHT-          CS      MPTEMP          # GET ABSOLUTE VALUE - 1 OF SHIFT COUNT
                AD      OCT176          # UNDERSTANDING THAT BIT8 (PSEUDO-SIGN)
                TS      MPTEMP          # WAS 1 INITIALLY.
                TCF     RIGHT           # DO NORMAL SHIFT RIGHT.

LEFT-           CS      OCT176          # SAME PROLOGUE TO LEFT FOR INDEXED RIGHT
                AD      MPTEMP          # SHIFT WHOSE NET SHIFT COUNT IS NEGATIVE
                COM
                TS      MPTEMP

LEFT            CCS     MODE            # SINCE LEFT SHIFTING IS DONE ONE PLACE AT
                TCF     GENSCL          # A TIME, NO COMPARISON WITH 14 NEED BE
                TCF     GENSCL          # DONE.  FOR SCALARS, SEE IF TERMINAL ROUND
                TCF     VSSL            # DESIRED.  FOR VECTORS, SHIFT IMMEDIATELY.

GENSCL          CS      ADDRWD          # PUT ROUNDING BIT (BIT 10 OF ADDRWD) INTO
                EXTEND                  # BIT 15 OF CYR WHERE THE ROUNDING BIT OF
                MP      BIT6            # A SHORT SHIFT LEFT WOULD BE
                TS      CYR
                TCF     TSSL +2         # DO THE SHIFT.
```

Uses `A` 80, `ADDRWD` 140, `COUNT` 142, `CYR` 80, `MODE` 145, and `MPTEMP` 142.

1598 ⟨*Page CM1162* 1598⟩≡ (1544 2721)

```
# SCALAR DIVISION INSTRUCTIONS, DDV AND BDDV, ARE EXECUTED HERE.  AT THIS POINT, THE
# AND THE DIVISOR IS IN BUF.

DDV/BDDV        CS      ONE             # INITIALIZATION
                TS      DVSIGN          # +-1 FOR POSITIVE QUOTIENT -- -0 FOR NEG.
                TS      DVNORMCT        # DIVIDEND NORMALIZATION COUNT.
                TS      MAXDVSW         # NEAR-ONE DIVIDE FLAG.

                CCS     BUF             # FORCE BUF POSITIVE WITH THE MAJOR PART
                TCF     BUFPOS          # NON-ZERO.
                TCF     +2
                TCF     BUFNEG

BUFZERO         TS      MPAC +2         # ZERO THIS.
                TC      TPAGREE         # FORCE SIGN AGREEMENT BEFORE OVERFLOW

                CCS     MPAC            # TEST TO SEE IF MPAC NON-ZERO.  (TOO BIG)
                TCF     OVF+            # MAJOR PART OF DIVIDEND IS POSITIVE NON-0
                TCF     +2
                TCF     OVF+ -1         # MAJOR PART OF DIVIDEND IS NEG. NON-ZERO

                XCH     BUF +1          # SHIFT DIVIDEND AND DIVISOR LEFT 14
                XCH     BUF
                XCH     MPAC +1
                XCH     MPAC
                CCS     BUF             # TRY AGAIN ON FORMER MINOR PART.
                TCF     BUF+
                TCF     +2              # OVERFLOW ON ZERO DIVISOR.
                TCF     BUF-

                CS      MPAC            # SIGN OF MPAC DETERMINES SIGN OF RESULT.
SGNDVOVF        EXTEND
                BZMF    +2
                INCR    DVSIGN          # NEGMAX IN MPAC PERHAPS.
DVOVF           CAF     POSMAX          # ON DIVISION OVERFLOW OF ANY SORT, SET
                TS      MPAC            # SET DP MPAC TO +-POSMAX.
                TC      FINALDV +3
                CAF     ONE             # SET OVERFLOW INDICATOR AND EXIT.
                TS      OVFIND
                TC      DANZIG

        -1      INCR    DVSIGN
OVF+            CS      BUF +1          # LOAD LOWER ORDER PART OF DIVISOR.
                TCF     SGNDVOVF        # GET SIGN OF RESULT.
```

```
BUF-            EXTEND                  # IF BUF IS NEGATIVE, COMPLEMENT IT AND
                DCS     BUF             # MAINTAIN DVSIGN FOR FINAL QUOTIENT SIGN.
                DXCH    BUF
                INCR    DVSIGN          # NOW -0.
```

Uses BUF 142, COUNT 142, DVNORMCT 142, DVSIGN 142, IT 185, MAXDVSW 142, MPAC 145, OVFIND 140, and TC 169.

1599 ⟨*Page CM1163* 1599⟩≡ (1544 2721)

```
BUF+            CCS     MPAC            # FORCE MPAC POSITIVE, CHECKING FOR ZERO
                TCF     MPAC+           # DIVIDEND IN THE PROCESS.
                TCF     +2
                TCF     MPAC-
                CCS     MPAC +1
                TCF     MPAC+
                TCF     DANZIG          # EXIT IMMEDIATELY ON ZERO DIVIDEND.
                TCF     MPAC-
                TCF     DANZIG

MPAC-           EXTEND                  # FORCE MPAC POSITIVE AS BUF IN BUF-.
                DCS     MPAC
                DXCH    MPAC
                INCR    DVSIGN          # NOW +1 OR -0.
```

Uses BUF 142, DVSIGN 142, and MPAC 145.

1600 ⟨*Page CM1164* 1600⟩≡ (1544 2721)

```
MPAC+           CS      MPAC            # CHECK FOR DIVISION OVERFLOW.  IF THE
                AD      NEGONE          # MAJOR PART OF THE DIVIDEND IS LESS THAN
                AD      BUF             # THE MAJOR PART OF THE DIVISOR BY AT
                CCS     A               # LEAST TWO, WE CAN PROCEED IMMEDIATELY
                TCF     DVNORM          # WITHOUT NORMALIZATION PRODUCING A DVMAX.
-1/2+2          OCT     60001           # USED IN SQRTSUB.

                TCF     +1              # IF THE ABOVE DOES NOT HOLD, FORCE SIGN
                CAF     HALF            # AGREEMENT IN NUMERATOR AND DENOMINATOR
                DOUBLE                  # TO FACILITATE OVERFLOW AND NEAR-ONE
                AD      MPAC +1         # CHECKING.
                TS      MPAC +1
                CAF     ZERO
                AD      POSMAX
                ADS     MPAC

                CAF     HALF            # SAME FOR BUF.
                DOUBLE
                AD      BUF +1
                TS      BUF +1
                CAF     ZERO
                AD      POSMAX
                ADS     BUF

                CS      MPAC            # CHECK MAGNITUDE OF SIGN-CORRECTED
                AD      BUF             # OPERANDS.
                CCS     A
                TCF     DVNORM          # DIVIDE OK -- WILL NOT BECOME MAXOV CASE.
LBUF2           ADRES   BUF2
                TCF     DVOVF           # DIVISOR NOT LESS THAN DIVIDEND -- OVF.

                TS      MAXDVSW         # IF THE MAJOR PARTS OF THE DIVIDEND AND
                CS      MPAC +1         # DIVISOR ARE EQUAL, A SPECIAL APPROXIMA-
                AD      BUF +1          # TION IS USED (PROVIDED THE DIVISION IS
                EXTEND                  # POSSIBLE, OF COURSE).
                BZMF    DVOVF
                TCF     DVNORM          # IF NO OVERFLOW.
```

Uses `A` 80, `BUF` 142, `BUF2` 142, `MAXDVSW` 142, and `MPAC` 145.

1601 ⟨*Page CM1165* 1601⟩≡ (1544 2721)

```
BUFNORM         EXTEND                  # ADD -1 TO AUGMENT SHIFT COUNT AND SHIFT
                AUG     DVNORMCT        # LEFT ONE PLACE.
                EXTEND
                DCA     BUF
                DAS     BUF

DVNORM          CA      BUF             # SEE IF DIVISOR NORMALIZED YET.
                DOUBLE
                OVSK
                TCF     BUFNORM         # NO -- SHIFT LEFT ONE AND TRY AGAIN.

                DXCH    MPAC            # CALL DIVIDEND NORMALIZATION SEQUENCE
                INDEX   DVNORMCT        # PRIOR TO DOING THE DIVIDE.
                TC      MAXTEST

                TS      MPAC +2         # RETURNS WITH DIVISION DONE AND C(A) = 0.
                TCF     DANZIG

BUFPOS          CCS     A
                TCF     BUF+            # TO BUF+ IF BUF IS GREATER THAN +1.

                CS      BUF +1          # IF BUF IS +1, FORCING SIGN AGREEMENT
                EXTEND                  # MAY CAUSE BUF TO BECOME ZERO.
                BZMF    BUF+            # BRANCH IF SIGNS AGREE.

                CA      HALF            # SIGNS DISAGREE.  FORCE AGREEMENT.
        +6      DOUBLE
                ADS     BUF +1
                CA      ZERO
                TS      BUF
                TCF     BUFZERO

BUFNEG          CCS     A
                TCF     BUF-            # TO BUF- IF BUF IS LESS THAN -1.

                CA      BUF +1          # IF BUF IS -1, FORCING SIGN AGREEMENT
                EXTEND                  # MAY CAUSE BUF TO BECOME ZERO.
                BZMF    BUF-            # BRANCH IF SIGNS AGREE.

                CS      HALF            # SIGNS DISAGREE.  FORCE AGREEMENT.
                TCF     BUFPOS +6
```

Uses `A` 80, `BUF` 142, `COUNT` 142, `DVNORMCT` 142, `MPAC` 145, and `TC` 169.

1602 ⟨*Page CM1166* 1602⟩≡ (1544 2721)

```
# THE FOLLOWING ARE PROLOGUES TO SHIFT THE DIVIDEND ARRIVING IN A AND L BEFORE THE DI

        -21D    LXCH    SR              # SPECIAL PROLOGUE FOR UNIT WHEN THE
                EXTEND                  # LENGTH OF THE ARGUMENT WAS NOT LESS THAN
                MP      HALF            # .5.  IN THIS CASE, EACH COMPONENT MUST BE
                XCH     L               # SHIFTED RIGHT ONE TO PRODUCE A HALF-UNIT
                AD      SR              # VECTOR.
                XCH     L
                TCF     GENDDV +1       # WITH DP DIVIDEND IN A,L.

                DDOUBL                  # PROLOGUE WHICH NORMALIZES THE DIVIDEND
                DDOUBL                  # WHEN IT IS KNOWN THAT NO DIVISION
                DDOUBL                  # OVERFLOW WILL OCCUR.
                DDOUBL
                DDOUBL
                DDOUBL
                DDOUBL
                DDOUBL
                DDOUBL
                DDOUBL
                DDOUBL
                DDOUBL
                DDOUBL
                DXCH    MPAC

MAXTEST         CCS     MAXDVSW         # 0 IF MAJORS MIGHT BE =, -1 OTHERWISE.
BIASHI          DEC     .4192 B-1       # SQRT CONSTANTS.

                TCF     MAXDV           # CHECK TO SEE IF THEY ARE NOW EQUAL.
```

Uses `A` 80, `IT` 185, `L` 80, `MAXDVSW` 142, `MPAC` 145, and `SR` 80.

1603 ⟨*Page CM1167* 1603⟩≡ (1544 2721)

```
# THE FOLLOWING IS A GENERAL PURPOSE DOUBLE PRECISION DIVISION ROUTINE.  IT DIVIDES MPAC BY BUF
# THE RESULT IN MPAC.  THE FOLLOWING CONDITIONS MUST BE SATISFIED:
#
#       1.      THE DIVISOR (BUF) MUST BE POSITIVE AND NOT LESS THAN .5.
#
#       2.      THE DIVIDEND (MPAC) MUST BE POSITIVE WITH THE MAJOR PART OF MPAC STRICTLY LESS
#               (A SPECIAL APPROXIMATION, MAXDV, IS USED WHEN THE MAJOR PARTS ARE EQUAL).
#
# UNDERSTANDING THAT A/B = Q + S(R/B) WHERE S = 2(-14) AND Q AND R ARE QUOTIENT AND REMAINDER,
# TIVELY, THE FOLLOWING APPROXIMATION IS OBTAINED BY MULTIPLYING ABOVE AND BELOW BY C - SD AND
# ORDER S-SQUARED (POSSIBLY INTRODUCING ERROR INTO THE LOW TWO BITS OF THE RESULT).  SIGN AGREE
#
#       A + SB .      (R - CD)                                          A + SB
#       ------ = Q + S(------) WHERE Q AND R ARE QUOTIENT AND REMAINDER OF ------ RESPECTIVELY.
#       C + SD        (  C   }                                             C

GENDDV          DXCH    MPAC            # WE NEED A AND B ONLY FOR FIRST DV.
        +1      EXTEND                  # (SPECIAL UNIT PROLOGUE ENTERS HERE).
                DV      BUF             # A NOW CONTAINS Q AND L, R.
                DXCH    MPAC

                CS      MPAC            # FORM DIVIDEND FOR MINOR PART OF RESULT.
                EXTEND
                MP      BUF +1
                AD      MPAC +1         # OVERFLOW AT THIS POINT IS POSITIVE SINCE
                OVSK                    # R IS POSITIVE IN EVERY CASE.
                TCF     +5

                EXTEND                  # OVERFLOW CAN BE REMOVED BY SUBTRACTING C
                SU      BUF             # (BUF) ONCE SINCE R IS ALWAYS LESS THAN C
                INCR    MPAC            # IN THIS CASE.  INCR COMPENSATES SUBTRACT.
                TCF     +DOWN           # (SINCE C(A) IS STILL POSITIVE).

        +5      EXTEND                  # C(A) CAN BE MADE LESS THAN C IN MAGNI-
                BZMF    -UP             # TUDE BY DIMINISHING IT BY C (SINCE C IS
                                        # NOT LESS THAN .5) UNLESS C(A) = 0.
```

Uses `A` 80, `BUF` 142, `DV` 241, `IT` 185, `L` 80, `MPAC` 145, and `Q` 80.

1604a ⟨*Page CM1168* 1604a⟩≡ (1544 2721)

```
+DOWN           EXTEND
                SU      BUF             # IF POSITIVE, REDUCE ONLY IF NECESSARY
                EXTEND                  # SINCE THE COMPENSATING INCR MIGHT CAUSE
                BZF     +3              # OVERFLOW.
                EXTEND                  # DON'T SUBTRACT UNLESS RESULT IS POSITIVE
                BZMF    ENDMAXDV        # OR ZERO.

        +3      INCR    MPAC            # KEEP SUBTRACT HERE AND COMPENSATE.
                TCF     FINALDV

-UP             EXTEND                  # IF ZERO, SET MINOR PART OF RESULT TO
                BZF     FINALDV +3      # ZERO.

                EXTEND                  # IF NEGATIVE, ADD C TO A, SUBTRACTING ONE
                DIM     MPAC            # TO COMPENSATE.  DIM IS OK HERE SINCE THE
ENDMAXDV        AD      BUF             # MAJOR PART NEVER GOES NEGATIVE.
```

Uses `A` 80, `BUF` 142, and `MPAC` 145.

1604b ⟨*Page CM1169* 1604b⟩≡ (1544 2721)

```
FINALDV         ZL                      # DO DV TO OBTAIN MINOR PART OF RESULT.
                EXTEND
                DV      BUF
        +3      TS      MPAC +1

                CCS     DVSIGN          # LEAVE RESULT POSITIVE UNLESS C(DVSIGN).
                TC      Q
                TC      Q
                TC      Q

                EXTEND
                DCS     MPAC
                DXCH    MPAC
                CAF     ZERO            # SO WE ALWAYS RETURN WITH C(A) = 0.
                TC      Q
```

Uses `A` 80, `BUF` 142, `DV` 241, `DVSIGN` 142, `MPAC` 145, `Q` 80, and `TC` 169.

1605 ⟨*Page CM1170* 1605⟩≡ (1544 2721)

```
# IF THE MAJOR PARTS OF THE DIVISOR AND DIVIDEND ARE EQUAL, BUT THE MINOR PARTS ARE SUCH THAT T
# DIVIDEND IS STRICTLY LESS THAN THE DIVISOR IN MAGNITUDE, THE FOLLOWING APPROXIMATION IS USED.
# ARE THE SAME AS THE GENERAL ROUTINE WITH THE ADDITION THAT SIGN AGREEMENT IS NECESSARY (B, C,
#
#       C + SB .          (C + B - D)
#       ------ = 37777 + S(---------)
#       C + SD            (    C    )
#
# THE DIVISION MAY BE PERFORMED IMMEDIATELY SINCE B IS STRICTLY LESS THAN D AND C IS NOT LESS T

MAXDV           CS      MPAC            # SEE IF MAXDV CASE STILL HOLDS AFTER
                AD      BUF             # NORMALIZATION.
                EXTEND
                BZF     +2
                TCF     GENDDV          # MPAC NOW LESS THAN BUFF -- DIVIDE AS USUAL.

        +2      CAF     POSMAX          # SET MAJOR PART OF RESULT.
                TS      MPAC

                CS      BUF +1          # FORM DIVIDEND OF MINOR PART OF RESULT.
                AD      MPAC +1
                TCF     ENDMAXDV        # GO ADD C AND DO DIVIDE, ATTACHING SIGN
                                        # BEFORE EXITING.
```

Uses `BUF` 142, `D` 226, and `MPAC` 145.

1606 ⟨*Page CM1171* 1606⟩≡ (1544 2721)

```
# VECTOR DIVIDED BY SCALAR, V/SC, IS EXECUTED HERE.  THE VECTOR IS NOW IN MPAC WITH S

V/SC2           CS      ONE             # INITIALIZE DIVIDEND NORMALIZATION COUNT
                TS      DVNORMCT        # AND DIVISION SIGN REGISTER.
                TS      VBUF +5

                TC      VECAGREE        # FORCE SIGN AGREEMENT IN VECTOR

                DXCH    BUF
                TC      ALSIGNAG        # SIGN AGREE BUF
                DXCH    BUF
                CCS     BUF             # FORCE DIVISOR POSITIVE WITH MAJOR PART
                TCF     /BUF+           # NON-ZERO (IF POSSIBLE).
                TCF     +2
                TCF     /BUF-

                XCH     BUF +1          # SHIFT VECTOR AND SCALAR LEFT 14.
                XCH     BUF
                XCH     MPAC +1
                XCH     MPAC
                EXTEND                  # CHECK FOR OVERFLOW IN EACH CASE.
                BZF     +2
                TCF     DVOVF

                XCH     MPAC +4
                XCH     MPAC +3
                EXTEND
                BZF     +2
                TCF     DVOVF

                XCH     MPAC +6
                XCH     MPAC +5
                EXTEND
                BZF     +2
                TCF     DVOVF

                CCS     BUF
                TCF     /BUF+
                TCF     DVOVF           # ZERO DIVISOR - OVERFLOW.
                TCF     /BUF-
                TCF     DVOVF

/BUF-           EXTEND                  # ON NEGATIVE, COMPLEMENT BUF AND MAINTAIN
                DCS     BUF             # DVSIGN IN VBUF +5.
                DXCH    BUF
```

```
                INCR    VBUF +5
```

Uses BUF 142, COUNT 142, DVNORMCT 142, DVSIGN 142, MPAC 145, TC 169, V 229, and VBUF 140.

1607 ⟨*Page CM1172* 1607⟩≡ (1544 2721)

```
/BUF+           EXTEND
                DCA     BUF             # LEAVE ABS(ORIG DIVISOR) IN BUF2
                DXCH    BUF2            # FOR OVERFLOW TESTING
                TCF     /NORM           # NORMALIZE DIVISOR IN BUF.

/NORM2          EXTEND                  # IF LESS THAN .5, AUGMENT DVNORMCT AND
                AUG     DVNORMCT        # DOUBLE DIVISOR.
                EXTEND
                DCA     BUF
                DAS     BUF

/NORM           CA      BUF             # SEE IF DIVISOR NORMALIZED.
                DOUBLE
                OVSK
                TCF     /NORM2          # DOUBLE AND TRY AGAIN IF NOT.

                TC      V/SCDV          # DO X COMPONENT DIVIDE.
                DXCH    MPAC +3         # SUPPLY ARGUMENTS IN USUAL SEQUENCE.
                DXCH    MPAC
                DXCH    MPAC +3

                TC      V/SCDV          # Y COMPONENT.
                DXCH    MPAC +5
                DXCH    MPAC
                DXCH    MPAC +5

                TC      V/SCDV          # Z COMPONENT.
                TCF     VROTATEX        # GO RE-ARRANGE COMPONENTS BEFORE EXIT.
```

Uses BUF 142, BUF2 142, DVNORMCT 142, MPAC 145, TC 169, V 229, and Z 80.

1608 ⟨*Page CM1173* 1608⟩≡ (1544 2721)

```
# SUBROUTINE USED BY V/SC TO DIVIDE VECTOR COMPONENT IN MPAC,+1 BY THE SCALAR GIVEN I

V/SCDV          CA      VBUF +5         # REFLECTS SIGN OF SCALAR.
                TS      DVSIGN

                CCS     MPAC            # FORCE MPAC POSITIVE, EXITING ON ZERO.
                TCF     /MPAC+
                TCF     +2
                TCF     /MPAC-

                CCS     MPAC +1
                TCF     /MPAC+
                TC      Q
                TCF     /MPAC-
                TC      Q

/MPAC-          EXTEND                  # USUAL COMPLEMENTING AND SETTING OF SIGN.
                DCS     MPAC
                DXCH    MPAC
                INCR    DVSIGN

/MPAC+          CS      ONE             # INITIALIZE NEAR-ONE SWITCH.
                TS      MAXDVSW

                CS      MPAC            # CHECK POSSIBLE OVERFLOW.
                AD      BUF2            # UNNORMALIZED INPUT DIVISOR.
                CCS     A
                TCF     DDVCALL         # NOT NEAR-ONE
                TCF     +2              # +0 IS JUST POSSIBLE
                TCF     DVOVF           # NO HOPE
                TS      MAXDVSW         # SIGNAL POSSIBLE NEAR-ONE CASE
                CS      MPAC +1         # SEE IF DIVISION CAN BE DONE
                AD      BUF2 +1
                EXTEND
                BZMF    DVOVF

DDVCALL         DXCH    MPAC            # CALL PRE-DIVIDE NORMALIZATION.
                INDEX   DVNORMCT
                TCF     MAXTEST
```

Uses `A` 80, `BUF` 142, `BUF2` 142, `DVNORMCT` 142, `DVSIGN` 142, `MAXDVSW` 142, `MPAC` 145, `Q` 80, `TC` 169, `V` 229, and `VBUF` 140.

1609 ⟨*Page CM1174* 1609⟩≡ (1544 2721)

```
SLOPELO         DEC     .8324

VECAGREE        XCH     Q               # SAVE Q IN A
                DXCH    MPAC
                TC      ALSIGNAG        # SIGNAGREE MPAC
                DXCH    MPAC
                DXCH    MPAC +3
                TC      ALSIGNAG        # SIGN AGREE MPAC +3
                DXCH    MPAC +3
                DXCH    MPAC +5
                TC      ALSIGNAG        # SIGNAGREE MPAC +5
                DXCH    MPAC +5
                TC      A
```

Uses `A` 80, `MPAC` 145, `Q` 80, `SAVE` 191, and `TC` 169.

1610 ⟨*Page CM1175* 1610⟩≡ (1544 2721)

```
# THE FOLLOWING ROUTINE EXECUTES THE UNIT INSTRUCTION, WHICH TAKES THE UNIT OF THE VE

UNIT            TC      VECAGREE        # FORCE SIGN AGREEMENT IN VECTOR
                TC      MPACVBUF        # SAVE ARGUMENT IN VBUF
                CAF     ZERO            # MUST SENSE OVERFLOW IN FOLLOWING DOT.
                XCH     OVFIND
                TS      TEM1
                TC      VSQSUB          # DOT MPAC WITH ITSELF.
                CA      TEM1
                XCH     OVFIND
                EXTEND
                BZF     +2
                TCF     DVOVF
                EXTEND
                DCA     MPAC            # LEAVE THE SQUARE OF THE LENGTH OF THE
                INDEX   FIXLOC          # ARGUMENT IN LVSQUARE.
                DXCH    LVSQUARE

                TC      SQRTSUB         # GO TAKE THE NORMALIZED SQUARE ROOT.

                CCS     MPAC            # CHECK FOR UNIT OVERFLOW.
                TCF     +5              # MPAC IS NOT LESS THAN .5 UNLESS
                TS      L
                INDEX   FIXLOC
                DXCH    LV
                TCF     DVOVF           # INPUT TO SQRTSUB WAS 0.

                CS      FOURTEEN        # SEE IF THE INPUT WAS SO SMALL THAT THE
                AD      MPTEMP          # FIRST TWO REGISTERS OF THE SQUARE WERE 0
                CCS     A
                COM                     # IF SO, SAVE THE NEGATIVE OF THE SHIFT
                TCF     SMALL           # COUNT -15D.

                TCF     LARGE           # (THIS IS USUALLY THE CASE.)

                CS      THIRTEEN        # IF THE SHIFT COUNT WAS EXACTLY 14, SET
                TS      MPTEMP          # THE PRE-DIVIDE NORM COUNT TO -13D.

                CA      MPAC            # SHIFT THE LENGTH RIGHT 14 BEFORE STORING
SMALL2          TS      L               # (SMALL EXITS TO THIS POINT).
                CAF     ZERO
                TCF     LARGE2          # GO TO STORE LENGTH AND PROCEED.

LARGE           CCS     MPTEMP          # MOST ALL CASES COME HERE.
                TCF     LARGE3          # SEE IF NO NORMALIZATION WAS REQUIRED BY
```

```
CS      SRDDV           # SQRT, AND IF SO, SET UP FOR A SHIFT
TS      MPTEMP          # RIGHT 1 BEFORE DIVIDING TO PRODUCE
EXTEND                  # THE DESIRED HALF UNIT VECTOR.
DCA     MPAC
```

Uses A 80, COUNT 142, FIXLOC 140, L 80, LV 85, LVSQUARE 85, MPAC 145, MPTEMP 142, OVFIND 140, SAVE 191, TC 169, TEM1 142, and VBUF 140.

1611 ⟨*Page CM1176* 1611⟩≡ (1544 2721)

```
TCF     LARGE2
```

1612 ⟨*Page CM1177* 1612⟩≡ (1544 2721)

```
LARGE3          COM                     # LEAVE NEGATIVE OF SHIFT COUNT-1 FOR
                TS      MPTEMP          # PREDIVIDE LEFT SHIFT.

                COM                     # PICK UP REQUIRED SHIFTING BIT TO UNNORM-
                INDEX   A               # ALIZE THE SQRT RESULT.
                CAF     BIT14
                TS      BUF
                EXTEND
                MP      MPAC +1
                XCH     BUF
                EXTEND                  # (UNNORMALIZE THE SQRT FOR LV).
                MP      MPAC
                XCH     L
                AD      BUF
                XCH     L

LARGE2          INDEX   FIXLOC
                DXCH    LV              # LENGTH NOW STORED IN WORK AREA.

                CS      ONE
                TS      MAXDVSW         # NO MAXDV CASES IN UNIT.

                DXCH    VBUF            # PREPARE X COMPONENT FOR DIVIDE, SETTING
                DXCH    MPAC            # LENGTH OF VECTOR AS DIVISOR IN BUF.
                DXCH    BUF
                TC      UNITDV

                DXCH    VBUF +2         # DO Y AND Z IN USUAL FASHION SO WE CAN
                DXCH    MPAC            # EXIT THROUGH VROTATEX.
                DXCH    MPAC +3
                TC      UNITDV

                DXCH    VBUF +4
                DXCH    MPAC
                DXCH    MPAC +5
                TC      UNITDV
                TCF     VROTATEX        # AND EXIT.
```

Uses A 80, BUF 142, COUNT 142, FIXLOC 140, L 80, LV 85, MAXDVSW 142, MPAC 145, MPTEMP 142, TC 169, VBUF 140, and Z 80.

1613 ⟨*Page CM1178* 1613⟩≡ (1544 2721)

```
# IF THE LENGTH OF THE ARGUMENT VECTOR WAS LESS THAN 2(-28), EACH COMPONENT MUST BE SHIFTED LEF
# 14 PLACES BEFORE THE DIVIDE, NOTE THAT IN THIS CASE, THE MAJOR PART OF EACH COMPONENT IS ZERO

SMALL           TS      MPTEMP          # NEGATIVE OF PRE-DIVIDE SHIFT COUNT.

                CAF     ZERO            # SHIFT EACH COMPONENT LEFT 14.
                XCH     VBUF +1
                XCH     VBUF
                XCH     VBUF +3
                XCH     VBUF +2
                XCH     VBUF +5
                XCH     VBUF +4

                CS      MPTEMP
                INDEX   A
                CAF     BIT14
                EXTEND
                MP      MPAC
                TCF     SMALL2

THIRTEEN        =       OCT15
FOURTEEN        =       OCT16
OCT16           =       R1D1
```

Uses `A` 80, `COUNT` 142, `MPAC` 145, `MPTEMP` 142, and `VBUF` 140.

1614 ⟨*Page CM1179* 1614⟩≡ (1544 2721)

```
# THE FOLLOWING ROUTINE SETS UP THE CALL TO THE DIVIDE ROUTINES.

UNITDV          CCS     MPAC            # FORCE MPAC POSITIVE IF POSSIBLE, SETTING
                TCF     UMPAC+          # DVSIGN ACCORDING TO THE SIGN OF MPAC
                TCF     +2              # SINCE THE DIVISOR IS ALWAYS POSITIVE
                TCF     UMPAC-          # HERE.

                CCS     MPAC +1
                TCF     UMPAC+
                TC      Q               # EXIT IMMEDIATELY ON ZERO.
                TCF     UMPAC-
                TC      Q

UMPAC-          CS      ZERO            # IF NEGATIVE, SET -0 IN DVSIGN FOR FINAL
                TS      DVSIGN          # COMPLEMENT.
                EXTEND
                DCS     MPAC            # PICK UP ABSOLUTE VALUE OF ARG AND JUMP.
                INDEX   MPTEMP
                TCF     MAXTEST -1

UMPAC+          TS      DVSIGN          # SET DVSIGN FOR POSITIVE QUOTIENT.
                DXCH    MPAC
                INDEX   MPTEMP
                TCF     MAXTEST -1
```

Uses DVSIGN 142, MPAC 145, MPTEMP 142, Q 80, and TC 169.

1615 ⟨*Page CM1180* 1615⟩≡ (1544 2721)

```
# MISCELLANEOUS UNARY OPERATIONS.

DSQ             TC      DSQSUB          # SQUARE THE DP CONTENTS OF MPAC.
                TCF     DANZIG

ABVALABS        CCS     MODE            # ABVAL OR ABS INSTRUCTION.
                TCF     ABS             # DO ABS ON SCALAR.
                TCF     ABS

ABVAL           TC      VSQSUB          # DOT MPAC WITH ITSELF.
                LXCH    MODE            # MODE IS NOW DP (L ZERO AFTER DAS).

                EXTEND                  # STORE SQUARE OF LENGTH IN WORK AREA.
                DCA     MPAC
                INDEX   FIXLOC
                DXCH    LVSQUARE
```

Uses `FIXLOC` 140, `L` 80, `LVSQUARE` 85, `MODE` 145, `MPAC` 145, and `TC` 169.

1616 ⟨*Page CM1181* 1616⟩≡ (1544 2721)

```
# PROGRAM DESCRIPTION -- SUBROUTINE SQRT
#
# FUNCTIONAL DESCRIPTION -- DOUBLE PRECISION SQUARE ROOT ROUTINE
#       THIS PROGRAM TAKES THE SQUARE ROOT OF THE 27 OR 28 MOST SIGNIFICANT BITS IN T
#       NUMBERS -- MPAC, MPAC+1, AND MPAC+2.  THE ROOT IS RETURNED DOUBLE PRECISION I
#
# WARNING -- THIS SUBROUTINE USES A TRIPLE PRECISION INPUT.  THE PROGRAMMER MUST ASSU
#       ESPECIALLY IF THE CONTENTS OF MPAC IS SMALL OR ZERO.  FOR DETAILS SEE STG MEN
#
# CALLING SEQUENCE -- IN INTERPRETIVE MODE, I.E., FOLLOWING ‘TC INTPRET’, ‘SQRT’, NO
#       INPUT SCALING: THE BINARY POINT IS ASSUMED TO THE RIGHT OF BIT 15.  THE ANSWE
#
# SUBROUTINES -- GENSCR, MPACSHR, SQRTSUB, ABORT
#
# ABORT EXIT MODE -- ABORTS ON NEGATIVE INPUT -1.2X10E-4 (77775 OCTAL) OR LESS.
#       DISPLAYS ERROR CODE 1302
#               TC      ABORT
#               OCT     1302
#
# DEBRIS -- LOCATIONS BUF, MPTEMP, ADDRWD ARE USED

SQRT            TC      SQRTSUB         # TAKE THE SQUARE ROOT OF MPAC.
                CCS     MPTEMP          # RETURNED NORMALIZED SQUARE ROOT.  SEE IF
                TCF     +2              # ANY UN-NORMALIZATION REQUIRED AND EXIT
                TCF     DANZIG          # IF NOT.

                AD      NEG12           # A RIGHT SHIFT OF MORE THAN 13 COULD BE
                EXTEND                  # REQUIRED IF INPUT WAS ZERO IN MPAC,+1.
                BZMF    SQRTSHFT        # GOES HERE IN MOST CASES.
                ZL                      # IF A LONG SHIFT IS REQUIRED, GO TO
                LXCH    ADDRWD          # GENERAL RIGHT SHIFT ROUTINES.
                TCF     GENSCR +4       # ADDRWD WAS ZERO TO PREVENT ROUND.

SQRTSHFT        INDEX   MPTEMP          # SELECT SHIFTING BIT AND EXIT THROUGH
                CAF     BIT15           # SHIFT ROUTINES.
                TS      MPTEMP
                CAF     ZERO            # TO ZERO MPAC +2 IN THE PROCESS.
                TCF     MPACSHR +3

ABS             TC      BRANCH          # TEST SIGN OF MPAC AND COMPLEMENT IF
                TCF     DANZIG
                TCF     DANZIG
                TCF     COMP
```

Uses A 80, ADDRWD 140, BUF 142, CODE 140, DISPLAYS 59, I 206, LONG 157, MODE 145, MPAC 145,

MPTEMP 142, TC 169, and UN 188.

1618 ⟨*Page CM1182* 1618⟩≡ (1544 2721)

```
VDEF            CS      FOUR            # VECTOR DEFINE -- ESSENTIALLY TREATS
                ADS     PUSHLOC         # SCALAR IN MPAC AS X COMPONENT, PUSHES UP
                EXTEND                  # FOR Y AND THEN AGAIN FOR Z.
                INDEX   A
                DCA     2
                DXCH    MPAC +3
                EXTEND
                INDEX   PUSHLOC
                DCA     0
                DXCH    MPAC +5
                TCF     VMODE           # MODE IS NON VECTOR.

VSQ             TC      VSQSUB          # DOT MPAC WITH ITSELF.
                TCF     DMODE           # MODE IS NOW DP.

PUSH            EXTEND                  # PUSH DOWN MPAC LEAVING IT LOADED.
                DCA     MPAC
                INDEX   PUSHLOC         # PUSH DOWN FIRST TWO REGISTERS IN EACH
                DXCH    0

                INDEX   MODE            # INCREMENT PUSHDOWN POINTER.
                CAF     NO.WDS
                ADS     PUSHLOC

                CCS     MODE
                TCF     TPUSH           # PUSH DOWN MPAC +2.
                TCF     DANZIG          # DONE FOR DP.

                EXTEND                  # ON VECTOR, PUSH DOWN Y AND Z COMPONENTS.
                DCA     MPAC +3
                INDEX   PUSHLOC
                DXCH    0 -4
                EXTEND
                DCA     MPAC +5
                INDEX   PUSHLOC
                DXCH    0 -2
                TCF     DANZIG

TPUSH           CA      MPAC +2
                TCF     ENDTPUSH +2

RVQ             INDEX   FIXLOC          # RVQ -- RETURN IVA QPRET.
                CA      QPRET
                TS      POLISH
                TCF     GOTO +4         # (ASSUME QPRET POINTS TO FIXED ONLY.)
```

Uses A 80, FIXLOC 140, IT 185, MODE 145, MPAC 145, POLISH 140, PUSHLOC 145, QPRET 85, TC 169, and Z 80.

1620 ⟨*Page CM1183* 1620⟩≡ (1544 2721)

```
# THE FOLLOWING SUBROUTINES ARE USED IN SQUARING MPAC, IN BOTH THE SCALAR AND VECTOR
# SPECIAL CASES OF DMPSUB AND DOTSUB, PUT IN TO SAVE SOME TIME.

DSQSUB          CA      MPAC +1         # SQUARES THE SCALAR CONTENTS OF MPAC.
                EXTEND
                SQUARE
                TS      MPAC +2
                CAF     ZERO            # FORM 2(CROSS TERM).
                XCH     MPAC +1
                EXTEND
                MP      MPAC
                DDOUBL                  # AND MAYBE OVERFLOW.
                DAS     MPAC +1         # AND SET A TO NET OVERFLOW.
                XCH     MPAC
                EXTEND
                SQUARE
                DAS     MPAC
                TC      Q

VSQSUB          EXTEND                  # DOTS THE VECTOR IN MPAC WITH ITSELF.
                QXCH    DOTRET
                TC      DSQSUB          # SQUARE THE X COMPONENT.
                DXCH    MPAC +3
                DXCH    MPAC
                DXCH    BUF             # SO WE CAN END IN DOTSUB.
                CA      MPAC +2
                TS      BUF +2

                TC      DSQSUB          # SQUARE Y COMPONENT.
                DXCH    MPAC +1
                DAS     BUF +1
                AD      MPAC
                AD      BUF
                TS      BUF
                TCF     +2
                TS      OVFIND          # IF OVERFLOW.

                DXCH    MPAC +5
                DXCH    MPAC
                TC      DSQSUB          # SQUARE Z COMPONENT.
                TCF     ENDDOT          # END AS IN DOTSUB.
```

Uses `A` 80, `BUF` 142, `DOTRET` 142, `MPAC` 145, `OVFIND` 140, `Q` 80, `SAVE` 191, `TC` 169, and `Z` 80.

1621 ⟨*Page CM1184* 1621⟩≡ (1544 2721)

```
# DOUBLE PRECISION SQUARE ROOT ROUTINE.  TAKE THE SQUARE ROOT OF THE TRIPLE PRECISION (MPAC +2
# IN NORMALIZATION) CONTENTS OF MPAC AND LEAVE THE NORMALIZED RESULT IN MPAC (C(MPAC) GREATER T
# .5).  THE RIGHT SHIFT COUNT (TC UNNORMALIZE) IS LEFT IN MPTEMP.

SQRTSUB         CAF     ZERO            # START BY ZEROING RIGHT SHIFT COUNT.
                TS      MPTEMP

                CCS     MPAC            # CHECK FOR POSITIVE ARGUMENT, SHIFTING
                TCF     SMPAC+          # FIRST SIGNIFICANT MPAC REGISTER INTO
                TCF     +2              # MPAC ITSELF.
                TCF     SQRTNEG         # SEE IF MAG OF ARGUMENT LESS THAN 10(-4).

                XCH     MPAC +2         # MPAC IS ZERO -- SHIFT LEFT 14.
                XCH     MPAC +1
                TS      MPAC
                CAF     SEVEN           # AUGMENT RIGHT SHIFT COUNTER.
                TS      MPTEMP

                CCS     MPAC            # SEE IF MPAC NOW PNZ.
                TCF     SMPAC+
                TCF     +2
                TCF     ZEROANS         # NEGATIVE BUT LESS THAN 10(-4) IN MAG.

                XCH     MPAC +1         # XERO -- SHIFT LEFT 14 AGAIN.
                TS      MPAC
                CAF     SEVEN           # AUGMENT RIGHT SHIFT COUNTER.
                ADS     MPTEMP

                CCS     MPAC
                TCF     SMPAC+
                TC      Q               # SQRT(0) = 0.
                TCF     ZEROANS
                TCF     FIXROOT         # DO NOT LEAVE SQRTSUB WITH -0 IN MPAC.

SQRTNEG         CCS     A               # ARGUMENT IS NEGATIVE, BUT SEE IF SIGN-
                TCF     SQRTABRT        # CORRECTED ARGUMENT IS LESS THAN 10(-4)

                CCS     MPAC +1         # IN MAGNITUDE.  IF SO, CALL ANSWER ZERO.
ZEROANS         CAF     ZERO            # FORCE ANSWER TO ZERO HERE.
                TCF     FIXROOT
                TCF     SQRTABRT
                TCF     FIXROOT

SQRTABRT        TC      P00DOO
                OCT     1302
```

Uses `A` 80, `COUNT` 142, `MPAC` 145, `MPTEMP` 142, `Q` 80, and `TC` 169.

1623 ⟨*Page CM1185* 1623⟩≡ (1544 2721)

```
SMPAC+          AD      -1/2+2          # SEE IF ARGUMENT GREATER THAN OR EQUAL TO
                EXTEND                  # .5.
                BZMF    SRTEST          # IF SO, SEE IF LESS THAN .25.

                DXCH    MPAC            # WE WILL TAKE THE SQUARE ROOT OF MPAC/2.
                LXCH    SR              # SHIFT RIGHT 1 AND GO TO THE SQRT ROUTINE
                EXTEND
                MP      HALF
                DXCH    MPAC
                XCH     SR
                ADS     MPAC +1         # GUARANTEED NO OVERFLOW.

ARGHI           CAF     SLOPEHI         # ARGUMENT BETWEEN .25 AND .5, GET A
                EXTEND                  # LINEAR APPROXIMATION FOR THIS RANGE.
                MP      MPAC
                AD      BIASHI          # X0/2 = (MPAC/2)(SLOPHI) + BIASHI/2.

        +4      TS      BUF             # X0/2 (ARGLO ENTERS HERE).
                CA      MPAC            # SINGLE-PRECISION THROUGHOUT.
                ZL
                EXTEND
                DV      BUF             # (MPAC/2)/(X0/2)
                EXTEND
                MP      HALF
                ADS     BUF             # X1 = X0/2 + .5(MPAX/2)/(X0/2)

                EXTEND
                MP      HALF            # FORM UP X1/2.
                DXCH    MPAC            # SAVE AND BRING OUT ARGUMENT.
                EXTEND                  # TAKE DP QUOTIENT WITH X1.
                DV      BUF
                TS      BUF +1          # SAVE MAJOR PART OF QUOTIENT.
                CAF     ZERO            # FORM MINOR PART OF QUOTIENT USING
                XCH     L               # (REMAINDER,0).
                EXTEND
                DV      BUF
                TS      L               # IN PREPARATION FOR DAS.
                CA      BUF +1
                DAS     MPAC            # X2 = X1/2 + (MPAC/2)X1

                EXTEND                  # OVERFLOWS IF ARG. NEAR POSMAX.
                BZF     TCQBNK00
                CAF     POSMAX
FIXROOT         TS      MPAC
                TS      MPAC +1
```

```
TCQBNK00        TC      Q               # RETURN TO CALLER TO UNNORMALIZE, ETC.
```

Uses A 80, BUF 142, DV 241, L 80, MPAC 145, Q 80, RANGE 179, SAVE 191, SR 80, TC 169, X1 85, and X2 85.

1624 ⟨*Page CM1186* 1624⟩≡ (1544 2721)

```
SRTEST          AD      QUARTER         # ARGUMENT WAS LESS THAN .5, SEE IF LESS
                EXTEND                  # THAN .25.
                BZMF    SQRTNORM        # IF SO, BEGIN NORMALIZATION.

                DXCH    MPAC            # IF BETWEEN .5 AND .25, SHIFT RIGHT 1 AND
                LXCH    SR              # START AT ARGLO.
                EXTEND
                MP      HALF
                DXCH    MPAC
                XCH     SR
                ADS     MPAC +1         # NO OVERFLOW.

ARGLO           CAF     SLOPELO         # (NORMALIZED) ARGUMENT BETWEEN .125 AND
                EXTEND                  # .25
                MP      MPAC
                AD      BIASLO
                TCF     ARGHI +4        # BEGIN SQUARE ROOT.

SQRTNM2         EXTEND                  # SHIFT LEFT 2 AND INCREMENT RIGHT SHIFT
                DCA     MPAC +1         # COUNT (FOR TERMINAL UNNORMALIZATION).
                DAS     MPAC +1
                AD      MPAC
                ADS     MPAC            # (NO OVERFLOW).

SQRTNORM        INCR    MPTEMP          # FIRST TIME THROUGH, JUST SHIFT LEFT 1
                EXTEND                  # (PUTS IN EFFECTIVE RIGHT SHIFT SINCE
                DCA     MPAC +1         # WE WANT MPAC/2).
                DAS     MPAC +1
                AD      MPAC
                ADS     MPAC            # (AGAIN NO OVERFLOW).
                DOUBLE
                TS      CYL

NORMTEST        CCS     CYL             # SEE IF ARGUMENT NOW NORMALIZED AT
                CCS     CYL             # GREATER THAN .125.
                TCF     SQRTNM2         # NO -- SHIFT LEFT 2 MORE AND TRY AGAIN.
                TCF     ARGHI           # YES -- NOW BETWEEN .5 AND .25.
                TCF     ARGLO           # ARGUMENT NOW BETWEEN .25 AND .125.
```

Uses COUNT 142, CYL 80, MPAC 145, MPTEMP 142, and SR 80.

1625 ⟨*Page CM1187* 1625⟩≡ (1544 2721)

```
# TRIGONOMETRIC FUNCTION PACKAGE.
#       THE FOLLOWING TRIGONOMETRIC FUNCTIONS ARE AVAILABLE AS INTERPRETIVE OPERATIONS:
#       1.      SIN             COMPUTES (1/2)SINE(2 PI MPAC).
#       2.      COS             COMPUTES (1/2)COSINE(2 PI MPAC).
#       3.      ASIN            COMPUTES (1/2PI)ARCSINE(2 MPAC).
#       4.      ACOS            COMPUTES (1/2PI)ARCCOSINE(2 MPAC).
#
# SIN-ASIN AND COS-ACOS ARE MUTUALLY INVERSE, I.E., SIN(ASIN(X)) = X.

COSINE          TC      BRANCH          # FINDS COSINE USING THE IDENTITY
                TCF     +3              # COS(X) = SIN(PI/2 - ABS(X)).
                TCF     PRESINE
                TCF     PRESINE

        +3      EXTEND
                DCS     MPAC
                DXCH    MPAC

PRESINE         CAF     QUARTER         # PI/2 SCALED.
                ADS     MPAC

SINE            DXCH    MPAC            # DOUBLE ARGUMENT.
                DDOUBL
                OVSK                    # SEE IF OVERFLOW PRESENT.
                TCF     +3              # IF NOT, ARGUMENT OK AS IS.

                EXTEND                  # IF SO, WE LOST (OR GAINED) PI, SO
                DCOM                    # COMPLEMENT MPAC USING THE IDENTITY
                                        # SIN(X-(+)PI) = SIN(-X).
        +3      DXCH    MPAC
                CA      MPAC            # SEE IF ARGUMENT GREATER THAN .5 IN
                DOUBLE                  # MAGNITUDE.  IF SO, REDUCE IT TO LESS THAN
                TS      L               # .5 (+-PI/2 SCALED) AS FOLLOWS:
                TCF     SN1

                INDEX   A               # IF POSITIVE, FORM PI - X, IF NEGATIVE
                CAF     NEG1/2 +1       # USE -PI -X.
                DOUBLE
                EXTEND
                SU      MPAC            # GUARANTEED NO OVERFLOW.
                TS      MPAC
                CS      MPAC +1
                TS      MPAC +1
```

Uses `A` 80, `I` 206, `IT` 185, `L` 80, `MPAC` 145, and `TC` 169.

1626 ⟨*Page CM1188* 1626⟩≡ (1544 2721)

```
SN1             EXTEND                  # SET UP TO EVALUATE HASTINGS POLYNOMIAL
                DCA     MPAC
                DXCH    BUF2
                TC      DSQSUB          # SQUARE MPAC.

                TC      POLY            # EVALUATE FOURTH ORDER POLYNOMIAL.
                DEC     3
                2DEC    +.3926990796
                2DEC    -.6459637111
                2DEC    +.318758717
                2DEC    -.074780249
                2DEC    +.009694988

                CAF     LBUF2           # MULTIPLY BY ARGUMENT AND SHIFT LEFT 2.
                TC      DMPSUB -1

                EXTEND
                DCA     MPAC +1
                DAS     MPAC +1
                AD      MPAC
                ADS     MPAC            # NEITHER SHIFT OVERFLOWS.
                EXTEND
                DCA     MPAC +1
                DAS     MPAC +1
                AD      MPAC
                ADS     MPAC
                TCF     DANZIG
```

Uses `BUF2` 142, `MPAC` 145, and `TC` 169.

1627 ⟨*Page CM1189* 1627⟩≡ (1544 2721)

```
# ARCSIN/ARCCOS ROUTINE.

ARCSIN          CAF     LASINEX         # COMPUTE ARCSIN BY USING THE IDENTITY
                TCF     +2              # ARCSIN(X) = PI/2 - ARCCOS(X).

ARCCOS          CAF     LDANZIG         # (EXITS IMMEDIATELY).
                TS      ESCAPE
                TC      BRANCH          # TEST SIGN OF INPUT.
                TCF     ACOSST          # START IMMEDIATELY IF POSITIVE.
                TCF     ACOSZERO        # ARCCOS(0) = PI/2 = .25.
                EXTEND                  # IF NEGATIVE, USE THE IDENTITY
                DCS     MPAC            # ARCCOS(X) = PI - ARCCOS(-X), FORCING
                DXCH    MPAC            # ARGUMENT POSITIVE.
                CAF     TCSUBTR         # SET EXIT TO DO ABOVE BEFROE
                XCH     ESCAPE          # ARCSIN/ARCCOS CONSIDERATIONS.
                TS      ESCAPE2

ACOSST          CS      HALF            # TEST MAGNITUDE OF INPUT.
                AD      MPAC
                CCS     A
                TCF     ACOSOVF         # THIS IS PROBABLY AN OVERFLOW CASE.

LASINEX         TCF     ASINEX

                TCF     ACOSST2         # NO OVERFLOW -- PROCEED.

                CCS     MPAC +1         # IF MAJOR PART IS .5, CALL ANSWER 0
                CAF     ZERO            # UNLESS MINOR PART NEGATIVE.
                TCF     ACOS=0

                TCF     ACOSST2

ACOS=0          TS      MPAC +1
                TS      MPAC
                TC      ESCAPE

ACOSST2         EXTEND                  # NOW THAT ARGUMENT IS IN PROPER RANGE,
                DCS     MPAC            # BEGIN COMPUTATION.  USE HASTINGS
                AD      HALF            # APPROXIMATION ARCCOS(X) = SQRT(1-X)P(X)
                DXCH    MPAC            # IN A SCALED VERSION WHERE P(X) IS A
                DXCH    BUF2            # SEVENTH ORDER POLYNOMIAL.

                TC      SQRTSUB         # RETURNS WITH NORMALIZED SQUARE ROOT.

                CCS     MPTEMP          # SEE IF UN-NORMALIZATION REQUIRED.
```

```
                TCF     ACOSSHR
```

Uses A 80, BUF2 142, ESCAPE 142, ESCAPE2 142, MPAC 145, MPTEMP 142, P 188, RANGE 179, TC 169, and UN 188.

1628 ⟨*Page CM1190* 1628⟩≡ (1544 2721)

```
ACOS3           DXCH    MPAC            # SET UP FOR POLYNOMIAL EVALUATION.
                DXCH    BUF2
                DXCH    MPAC

                TC      POLY
                DEC     6
                2DEC    +.353553385     # COEFFICIENTS ARE C 2(+I)/PISQRT(2) WHERE
                2DEC*   -.0483017006 B+1*       # I
                2DEC*   +.0200273085 B+2*       # WEHRE C STANDS FOR ORIGINAL COEFFS.
                2DEC*   -.0112931863 B+3*
                2DEC*   +.00695311612 B+4*
                2DEC*   -.00384617957 B+5*
                2DEC*   +.001501297736 B+6*
                2DEC*   -.000284160334 B+7*

                CAF     LBUF2           # DO FINAL MULTIPLY AND GO TO ANY
                TC      DMPSUB -1       # EPILOGUE SEQUENCES.
                TC      ESCAPE

SUBTR           EXTEND                  # EPILOGUE FOR NEGATIVE INPUTS TO ARCCOS.
                DCS     MPAC
                AD      HALF            # FORMS PI - ARCCOS(-X) = ARCCOS(X).
                DXCH    MPAC
                TC      ESCAPE2         # GO TO POSSIBLE ARCSIN EPILOGUE.

ASINEX          EXTEND
                DCS     MPAC            # ARCSIN EPILOGUE -- GET ARCSIN(X)
                AD      QUARTER         # = PI/2 - ARCCOS(X).
                DXCH    MPAC
LDANZIG         TCF     DANZIG
```

Uses BUF2 142, ESCAPE 142, ESCAPE2 142, I 206, MPAC 145, and TC 169.

1629 ⟨*Page CM1191* 1629⟩≡ (1544 2721)

```
ACOSSHR         INDEX   A               # THE SHIFT RIGHT IS LESS THAN 14 SINCE
                CAF     BIT14           # THE INPUT WAS NON-ZERO DP.
                TS      MPTEMP
                TC      VSHRRND         # DP SHIFT RIGHT AND ROUND.
                TCF     ACOS3           # PROCEED.

ACOSOVF         EXTEND                  # IF MAJOR PART WAS ONLY 1 MORE THAN .5,
                BZF     ACOS=0          # CALL ANSWER ZERO.

ACOSABRT        TC      ALARM           # IF OVERFLOW, CALL ANSWER ZERO BUT
                OCT     1301            # SOUND AN ALARM.

                CAF     ZERO
                TCF     ACOS=0

ACOSZERO        CAF     QUARTER         # ACOS(0) = PI/2.
                TCF     ACOS=0 +1       # SET MPAC AND EXIT VIA ESCAPE.

NEG12           DEC     -12
TCSUBTR         TCF     SUBTR
```

Uses `A` 80, `ESCAPE` 142, `MPAC` 145, `MPTEMP` 142, and `TC` 169.

1630 ⟨*Page CM1192* 1630⟩≡ (1544 2721)

```
# THE FOLLOWING INSTRUCTIONS ARE AVAILABLE FOR SETTING, MODIFYING, AND BRANCHING ON I
#       1.      AXT     ADDRESS TO INDEX TRUE.
#       2.      AXC     ADDRESS TO INDEX COMPLEMENTED.
#       3.      LXA     LOAD INDEX FROM ERASABLE.
#       4.      LXC     LOAD INDEX COMPLEMENTED FROM ERASABLE.
#       5.      SXA     STORE INDEX IN ERASABLE.
#       6.      XCHX    EXCHANGE INDEX REGISTER WITH ERASABLE.
#       7.      INCR    INCREMENT INDEX REGISTER.
#       8.      XAD     ERASABLE ERASABLE ADD TO INDEX REGISTER.
#       9.      XSU     ERASABLE SUBTRACT FROM INDEX REGISTER.
#       10.     TIX     BRANCH ON INDEX REGISTER AND DECREMENT.

                BANK    01

                COUNT   01/INTER

AXT             TC      TAGSUB          # SELECT APPROPRIATE INDEX REGISTER.
                CA      POLISH
XSTORE          INDEX   INDEXLOC        # CONTAINS C(FIXLOC) OR C(FIXLOC)+1
                TS      X1
                TCF     DANZIG

AXC             TC      TAGSUB
                CS      POLISH
                TC      XSTORE

LXA             TC      15ADRERS        # LOAD INDEX REGISTER FROM ERASABLE.
                INDEX   POLISH
                CA      0
                TCF     XSTORE

LXC             TC      15ADRERS        # LOAD NDX REG FROM ERASABLE COMPLEMENTED.
                INDEX   POLISH
                CS      0
                TCF     XSTORE

SXA             TC      15ADRERS        # STORE INDEX REGISTER IN ERASABLE.
                INDEX   INDEXLOC
                CA      X1
MSTORE1         INDEX   POLISH
                TS      0
                TCF     DANZIG
```

Uses COUNT 142, FIXLOC 140, INDEXLOC 142, POLISH 140, TC 169, and X1 85.

1631 ⟨*Page CM1193* 1631⟩≡ (1544 2721)

```
XCHX        TC      15ADRERS        # EXCHANGE INDEX REGISTER WITH ERASABLE.
            INDEX   POLISH
            CA      0
            INDEX   INDEXLOC
            XCH     X1
            TCF     MSTORE1

XAD         TC      15ADRERS        # ADD ERASABLE TO INDEX REGISTER.
            INDEX   POLISH
            CA      0
XAD2        INDEX   INDEXLOC
            ADS     X1              # IGNORING OVERFLOWS.
            TCF     DANZIG

INCR        TC      TAGSUB          # INCREMENT INDEX REGISTER.
            CA      POLISH
            TCF     XAD2

XSU         TC      15ADRERS        # SUBTRACT ERASABLE FROM INDEX REGISTER.
            INDEX   POLISH
            CS      0
            TCF     XAD2

TIX         TC      TAGSUB          # BRANCH AND DECREMENT ON INDEX.
            INDEX   INDEXLOC
            CS      S1
            INDEX   INDEXLOC
            AD      X1
            EXTEND                  # NO OPERATION IF DECREMENTED INDEX IS
            BZMF    DANZIG          # NEGATIVE OR ZERO.

DOTIXBR     INDEX   INDEXLOC
            XCH     X1              # IGNORING OVERFLOWS.

            TCF     GOTO            # DO THE BRANCH USING THE CADR IN POLISH.
```

Uses INDEXLOC 142, POLISH 140, S1 85, TC 169, and X1 85.

1632 ⟨*Page CM1194* 1632⟩≡ (1544 2721)

```
# SUBROUTINE TO CONVERT AN ERASABLE ADDRESS (11 BITS) TO AN EBANK SETTING AND SUBADDR

15ADRERS        CS      POLISH
                AD      DEC45
                CCS     A               # DOES THE ADDRESS POINT TO THE WORK AREA?
                CA      FIXLOC          # YES.  ADD FIXLOC.  EBANK OK AS IS.
                TCF     +5

                CA      OCT1400         # NO. SET EBANK & MAKE UP SUBADDRESS.
                XCH     POLISH
                TS      EBANK
                MASK    LOW8
        +5      ADS     POLISH          # FALL INTO TAGSUB, AND RETURN VIA Q.

# SUBROUTINE WHICH SETS THE ADDRESS OF THE SPECIFIED INDEX IN INDEXLOC.  (ACTUALLY, T

TAGSUB          CA      FIXLOC
                TS      INDEXLOC

                CCS     CYR             # BIT 15 SPECIFIES INDEX.
                INCR    INDEXLOC        # 0 MEANS USE X2.
                TC      Q
                TC      Q               # 1 FOR X1.
```

Uses `A` 80, `CYR` 80, `EBANK` 80, `FIXLOC` 140, `INDEXLOC` 142, `POLISH` 140, `Q` 80, `TC` 169, `X1` 85, and `X2` 85.

1633 ⟨*Page CM1195* 1633⟩≡ (1544 2721)

```
# MISCELLANEOUS OPERATION CODES WITH DIRECT ADDRESSES.  INCLUDED HERE ARE:
#       1.      ITA     STORE CPRET (RETURN ADDRESS) IN ERASABLE.
#       2.      CALL    CALL A SUBROUTINE, LEAVING RETURN IN QPRET.
#       3.      RTB     RETURN TO BASIC LANGUAGE AT THE GIVEN ADDRESS.
#       4.      BHIZ    BRANCH IF THE HIGHORDER OF MPAC IS ZERO (SINGLE PRECISION).
#       5.      BOV     BRANCH ON OVERFLOW.
#       6.      GOTO    SIMPLE SEQUENCE CHANGE.

RTB/BHIZ        CCS     CYR
RTB             CA      POLISH
                TC      SWCALL  -1      # SO A "TC Q" FROM ROUTINE LEADS TO DANZIG

BHIZ            CCS     MPAC
                TCF     DANZIG
                TCF     GOTO
                TCF     DANZIG
                TCF     GOTO

BOV(B)          CCS     OVFIND          # BRANCH ON OVERFLOW TO BASIC OR INTERP.
                TCF     +2
                TCF     DANZIG
                TS      OVFIND
                CCS     CYR
                TCF     RTB             # IF BASIC.
B5TOBB          OCT     360
                TCF     GOTO
```

Uses `A` 80, `CYR` 80, `MPAC` 145, `OVFIND` 140, `POLISH` 140, `Q` 80, `QPRET` 85, and `TC` 169.

1634 ⟨*Page CM1196* 1634⟩≡ (1544 2721)

```
BZE/GOTO        CCS     CYR             # SEE WHICH OP-CODE IS DESIRED.
                TC      BRANCH          # DO BZE.
                TCF     DANZIG
                TCF     GOTO            # DO GOTO.
                TCF     DANZIG

BPL/BMN         CCS     CYR
                TCF     BPL
5B10            #DEC    5       B+10    # SHIFTS OP CODE IN SWITCH INSTRUCTION ADR
                DEC     5       B-4     # RSB 2009

                TC      BRANCH          # DO BMN
                TCF     DANZIG
                TCF     DANZIG
                TCF     GOTO            # ONLY IF NNZ.

BPL             TC      BRANCH
                TCF     GOTO            # IF POSITIVE OR ZERO.
                TCF     GOTO
                TCF     DANZIG

CALL/ITA        CCS     CYR
                TCF     CALL

                TC      CCSHOLE
                TC      15ADRERS        # STORE QPRET.  (TAGSUB AFTER 15ADRERS IS
                INDEX   FIXLOC          # SLOW IN THIS CASE, BUT SAVES STORAGE.)
                CA      QPRET
                TCF     MSTORE1
```

Uses CODE 140, CYR 80, FIXLOC 140, QPRET 85, and TC 169.

1635 ⟨*Page CM1197* 1635⟩≡ (1544 2721)

```
# THE FOLLOWING OPERATIONS ARE AVAILABLE FOR ALTERING AND TESTING INTERPRETATIVE SWITCHES:
#       00      BONSET          SET A SWITCH AND DO A GOTO IF IT WAS ON.
#       01      SETGO           SET A SWITCH AND DO A GOTO.
#       02      BOFSET          SET A SWITCH AND DOA GOTO IF IT WAS OFF
#       03      SET             SET A SWITCH.
#       04      BONINV          INVERT A SWITCH AND BRANCH IF IT WAS ON.
#       05      INVGO           INVERT A SWITCH AND DO A GOTO.
#       06      BOFINV          INVERT A SWITCH AND BRANCH IF IT WAS OFF
#       07      INVERT          INVERT A SWITCH.
#       10      BONCLR          CLEAR A SWITCH AND BRANCH IF IT WAS ON.
#       11      CLRGO           CLEAR A SWITCH AND DO A GOTO.
#       12      BOFCLR          CLEAR A SWITCH AND BRANCH IF IT WAS OFF.
#       13      CLEAR           CLEAR A SWITCH.
#       14      BON             BRANCH IF A SWITCH WAS ON.
#       16      BOFF            BRANCH IF A SWITCH WAS OFF.
# THE ADDRESS SUPPLIED WITH THE SWITCH INSTRUCTION IS INTERPRETED AS FOLLOWS:
#       BITS 1-4        SWITCH BIT NUMBER (1-15).
#       BITS 5-8        SWITCH OPERATION NUMBER
#       BITS 9-         SWITCH WORD NUMBER (UP TO 64 SWITCH WORDS).
# THE ADDRESS ITSELF IS MADE UP BY THE YUL SYSTEM ASSEMBLER.  THE BRANCH INSTRUCTIONS REQUIRE T
# ADDRESSES, THE SECOND TAKEN AS THE DIRECT (OR INDIRECT IF IN ERASABLE) ADDRESS OF THE BRANCH.

SWITCHES        CAF     LOW4            # LEAVE THE SWITCH BIT IN SWBIT.
                MASK    POLISH
                INDEX   A
                CAF     BIT15           # (NUMBER FROM LEFT TO RIGHT.)
                TS      SWBIT

                CAF     BIT7            # LEAVE THE SWITCH NUMBER IN SWWORD.
                EXTEND
                MP      POLISH
                TS      SWWORD

                INHINT                  # DURING SWITCH CHANGE SO RUPT CAN USE TOO
                INDEX   A               # LEAVE THE SWITCH WORD ITSELF IN L.
                CA      STATE
                TS      Q               # Q WILL BE USED AS A CHANNEL.
```

Uses A 80, IT 185, L 80, POLISH 140, Q 80, STATE 138, SWBIT 142, and SWWORD 142.

1636 ⟨*Page CM1198* 1636⟩≡ (1544 2721)

```
                CAF     BIT11
                EXTEND                  # DISPATCH SWITCH BIT OPERATION AS IN BITS
                MP      POLISH          # 7-8 OF POLISH.
                MASK    B3TOB4          # GETS 4X2-BIT CODE.
                INDEX   A
                TCF     +1

        +1      CA      SWBIT           # 00 -- SET SWITCH IN QUESTION.
                EXTEND
                ROR     QCHAN
                TCF     SWSTORE

        +5      CA      SWBIT           # 01 -- INVERT SWITCH.
                EXTEND
                RXOR    QCHAN
                TCF     SWSTORE

        +9D     CS      SWBIT           # 10 -- CLEAR.
                MASK    Q
SWSTORE         INDEX   SWWORD
                TS      STATE           # NEW SWITCH WORD.
```

Uses `A` 80, `CODE` 140, `POLISH` 140, `Q` 80, `QCHAN` 87, `STATE` 138, `SWBIT` 142, and `SWWORD` 142.

1637a ⟨*Page CM1199* 1637a⟩≡ (1544 2721)

```
        +13D    RELINT                  # 11 -- NOOP.
                CAF     BIT13
                EXTEND                  # DISPATCH SEQUENCE CHANGING OR BRANCING
                MP      POLISH          # CODE.
                MASK    B3TOB4
                INDEX   A
                TCF     +1              # ORIGINALLY STORED IN BITS 5-6

        +1      CS      Q               # 00 -- BRANCH IF ON.
TEST            MASK    SWBIT
                CCS     A
                TCF     SWSKIP

        +5      TCF     SWBRANCH        # 01 -- GO TO.

                TCF     SWSKIP          # HERE ONLY ON BIT 15.

                TC      CCSHOLE
                TC      CCSHOLE

        +9D     CA      Q               # 10 -- BRANCH IF OFF.
                TCF     TEST

B3TOB4          OCT     0014
SWSKIP          INCR    LOC

SW/             EQUALS  SWITCHES

        +13D    TCF     DANZIG          # 11 -- NOOP.
```

Uses `A` 80, `CODE` 140, `LOC` 145, `POLISH` 140, `Q` 80, `SWBIT` 142, and `TC` 169.

3.7.4 fixed fixed constant pool

1637b ⟨*fixed fixed constant pool* 1637b⟩≡ (1523a)

⟨*Page CM1200* 1638⟩
⟨*Page CM1201* 1640⟩
⟨*Page CM1202* 1642⟩
⟨*Page CM1203* 1643⟩
⟨*Page CM1204* 1644⟩

1638 ⟨*Page CM1200* 1638⟩≡ (1637b 2697)

```
                    BLOCK   02
                    COUNT   02/FCONS

  # THE FOLLOWING TABLE OF 18 VALUES IS INDEXED.  DO NOT INSERT OR REMOVE ANY QUANTITI

  DPOSMAX           OCT     37777           # MUST PRECED POSMAX
  POSMAX            OCT     37777

  LIMITS            =       NEG1/2

  NEG1/2            OCT     -20000          # USED BY SIN ROUTINE (MUST BE TWO
                                            # LOCATIONS IN FRONT OF BIT14)

  # BIT TABLE

  BIT15             OCT     40000
  BIT14             OCT     20000
  BIT13             OCT     10000
  BIT12             OCT     04000
  BIT11             OCT     02000
  BIT10             OCT     01000
  BIT9              OCT     00400
  BIT8              OCT     00200
  BIT7              OCT     00100
  BIT6              OCT     00040
  BIT5              OCT     00020
  BIT4              OCT     00010
  BIT3              OCT     00004
  BIT2              OCT     00002
  BIT1              OCT     00001

  # DO NOT DESTROY THIS COMBINATION, SINCE IT IS USED IN DOUBLE PRECISION INSTRUCTIONS
  NEG0              OCT     -0              # MUST PRECEDE ZERO
  ZERO              OCT     0               # MUST FOLLOW NEG0
  # BIT1            OCT     00001
  # NO.WDS          OCT     2               # INTERPRETER
  # OCTAL3          OCT     3               # INTERPRETER
  # R3D1            OCT     4               # PINBALL
  FIVE              OCT     5
  # REVCNT          OCT     6               # INTERPRETER
  SEVEN             OCT     7
  # BIT4            OCT     00010
  # R2D1            OCT     11              # PINBALL
  OCT11             =       R2D1            # P20S
  # BINCON          DEC     10              # PINBALL               (OCTAL 12)
```

```
ELEVEN          DEC     11
# OCT14         OCT     14              # ALARM AND ABORT (FILLER)
OCT15           OCT     15
# R1D1          OCT     16              # PINBALL
```

Uses COUNT 142, IT 185, and P20S 69.

1640 ⟨*Page CM1201* 1640⟩≡ (1637b 2697)

```
LOW4            OCT     17
# BIT5          OCT     00020
# ND1           OCT     21              # PINBALL
# VD1           OCT     23              # PINBALL
# OCT24         OCT     24              # SERVICE ROUTINES
# MD1           OCT     25              # PINBALL
BITS4&5         OCT     30
# OCT31         OCT     31              # SERVICE ROUTINES
CALLCODE        OCT     00032
# LOW5          OCT     37              # PINBALL
# 33DEC         DEC     33              # PINBALL               (OCTAL 41)
# 34DEC         DEC     34              # PINBALL               (OCTAL 42)
TBUILDFX        DEC     37              # BUILDUP FOR CONVENIENCE IN DAPTESTING
TDECAYFX        DEC     38              # CONVENIENCE FOR DAPTESTING
# BIT6          OCT     00040
OCT50           OCT     50
DEC45           DEC     45
SUPER011        OCT     60              # BITS FOR SUPERBNK SETTING 011.
.5SEC           DEC     50
# BIT7          OCT     00100

SUPER100        =       BIT7            # BITS FOR SUPERBNK SETTING 100
                                        # (LAST 4K OF ROPE)
SUPER101        OCT     120             # BITS FOR SUPERBNK SETTING 101
# OCT121        OCT     121             # SERVICE ROUTINES
                                        # (FIRST 8K OF ACM)
SUPER110        OCT     140             # BITS FOR SUPERBNK SETTING 110.
                                        # (LAST BK OF ACM)
1SEC            DEC     100
# LOW7          OCT     177             # INTERPRETER
# BIT8          OCT     00200
# OT215         OCT     215             # ALARM AND ABORT
# 8,5           OCT     00220           # P20-P25 SUNDANCE
2SECS           DEC     200
# LOW8          OCT     377             # PINBALL
# BIT9          OCT     00400
GN/CCODE        OCT     00401           # SET S/C CONTROL SWITCH TO G/N
3SECS           DEC     300
4SECS           DEC     400
LOW9            OCT     777
# BIT10         OCT     01000
# 5.5DEGS       DEC     .03056          # P20-P25 SUNDANCE      (OCTAL 00765)
# OCT1103       OCT     1103            # ALARM AND ABORT
C5/2            DEC     .0363551        #                       (OCTAL 01124)
V05N09          VN      0509            # (SAME AS OCTAL 1211)
```

```
OCT1400         OCT     01400
V06N22          VN      0622
# MID5          OCT     1740            # PINBALL
BITS2-10        OCT     1776
LOW10           OCT     1777
```

Uses N 206, SUPERBNK 87, and VN 159.

1642 ⟨*Page CM1202* 1642⟩≡ (1637b 2697)

```
# BIT11         OCT     02000
# 2K+3          OCT     2003            # PINBALL
LOW7+2K         OCT     2177            # OP CODE MASK + BANK 1 FBANK SETTING
EBANK5          OCT     02400
PRIO3           OCT     03000
EBANK7          OCT     03400
# LOW11         OCT     3777            # PINBALL
# BIT12         OCT     04000
# RELTAB        OCT     04025           # T4RUPT
PRIO5           OCT     05000
PRIO6           OCT     06000
PRIO7           OCT     07000

# BIT13         OCT     10000
#               OCT     10003           # T4RUPT        RELTAB +1D
# 13,7,2        OCT     10102           # P20-P25 SUNDANCE
PRIO11          OCT     11000
# PRIO12        OCT     12000           # BANKCALL
PRIO13          OCT     13000
PRIO14          OCT     14000
#               OCT     14031           # T4RUPT        RELTAB +2D
PRIO15          OCT     15000
PRIO16          OCT     16000
# 85DEGS        DEC     .45556          # P20-P25 SUNDANCE      (OCTAL 16450)
PRIO17          OCT     17000
OCT17770        OCT     17770
# BIT14         OCT     20000
#               OCT     20033           # T4RUPT        RELTAB +3D
PRIO21          OCT     21000
                BLOCK   03
                COUNT   03/FCONS

PRIO22          OCT     22000           # SERVICE ROUTINES
PRIO23          OCT     23000
PRIO24          OCT     24000
# 5/8+1         OCT     24001           # SINGLE PRECISION SUBROUTINES
#               OCT     24017           # T4RUPT        RELTAB +4D
PRIO25          OCT     25000
PRIO26          OCT     26000
PRIO27          OCT     27000
# CHRPRIO       OCT     30000           # PINBALL
#               OCT     30036           # T4RUPT        RELTAB +5D
PRIO31          OCT     31000
C1/2            DEC     .7853134        #                       (OCTAL 31103)
PRIO32          OCT     32000
```

```
PRIO33          OCT     33000
PRIO34          OCT     34000
#               OCT     34034           # T4RUPT        RELTAB +6D
PRIO35          OCT     35000
PRIO36          OCT     36000
```

Uses CODE 140, COUNT 142, and FBANK 80.

1643 ⟨*Page CM1203* 1643⟩≡ (1637b 2697)

```
PRIO37          OCT     37000
63/64+1         OCT     37401
# MID7          OCT     37600           # PINBALL
OCT37766        OCT     37766
OCT37774        OCT     37774
OCT37776        OCT     37776
# DPOSMAX       OCT     37777
# BIT15         OCT     40000
# OCT40001      OCT     40001           # INTERPRETER (CS 1 INSTRUCTION)
DLOADCOD        OCT     40014
DLOAD*          OCT     40015
#               OCT     40023           # T4RUPT        RELTAB +7D
BIT15+6         OCT     40040
OCT40200        OCT     40200
#               OCT     44035           # T4RUPT        RELTAB +8D
#               OCT     50037           # T4RUPT        RELTAB +9D
#               OCT     54000           # T4RUPT        RELTAB +10D
-BIT14          OCT     57777
# RELTAB11      OCT     60000           # T4RUPT
C3/2            DEC     -.3216147       #                       (OCTAL 65552)
13,14,15        OCT     70000
-1/8            OCT     73777
HIGH4           OCT     74000
-ENDERAS        DEC     -2001           #                       (OCTAL 74056)
# HI5           OCT     76000           # PINBALL
HIGH9           OCT     77700
# -ENDVAC       DEC     -45             # INTERPRETER           (OCTAL 77722)
# -OCT10        OCT     -10             #                       (OCTAL 77767)
# NEG4          DEC     -4              #                       (OCTAL 77773)
NEG3            DEC     -3
NEG2            OCT     77775
NEGONE          DEC     -1
```

1644 ⟨*Page CM1204* 1644⟩≡ (1637b 2697)

```
# DEFINED BY EQUALS

# IT WOULD BE TO THE USERS ADVANTAGE TO OCCASIONALLY CHECK ANY OF THESE SYMBOLS IN OR
# ACCIDENTAL DEFINITION CHANGES.

MINUS1          =       NEG1
NEG1            =       NEGONE
ONE             =       BIT1
TWO             =       BIT2
THREE           =       OCTAL3
LOW2            =       THREE
FOUR            =       BIT3
SIX             =       REVCNT
LOW3            =       SEVEN
EIGHT           =       BIT4
NINE            =       R2D1
TEN             =       BINCON
NOUTCON         =       ELEVEN
OCT23           =       VD1
OCT25           =       MD1
PRIO1           =       BIT10
EBANK3          =       OCT1400
PRIO2           =       BIT11
OCT120          =       SUPER101
OCT140          =       SUPER110
2K              =       BIT11
EBANK4          =       BIT11
PRIO4           =       BIT12
EBANK6          =       PRIO3
QUARTER         =       BIT13
PRIO10          =       BIT13
OCT10001        =       CCSL
POS1/2          =       HALF
PRIO20          =       BIT14
HALF            =       BIT14
PRIO30          =       CHRPRIO
BIT13-14        =       PRIO30          # INTERPRETER USES IN PROCESSING STORECODE
OCT30002        =       TLOAD +1
B12T14          =       PRIO34
NEGMAX          =       BIT15
VLOADCOD        =       BIT15
VLOAD*          =       OCT40001
OCT60000        =       RELTAB11
BANKMASK        =       HI5
```

Uses IT 185.

3.7.5 interpretive constants

1645a ⟨*interpretive constants* 1645a⟩≡ (1523a)

```
# Page 1205
⟨Page CM1205 1645b⟩
# Page 1206
⟨Page CM1206 1646a⟩
```

1645b ⟨*Page CM1205* 1645b⟩≡ (1645a 2727)

```
                  SETLOC  INTPRET1
                  BANK

                  COUNT   23/ICONS

DP1/4TH           2DEC    .25

UNITZ             2DEC    0

UNITY             2DEC    0

UNITX             2DEC    .5

ZEROVECS          2DEC    0

                  2DEC    0

                  2DEC    0

DPHALF            =       UNITX
DPPOSMAX          OCT     37777
                  OCT     37777
```

Uses COUNT 142 and INTPRET1 65.

1646a ⟨*Page CM1206* 1646a⟩≡ (1645a 2727)

```
# INTERPRETIVE CONSTANTS IN THE OTHER HALF-MEMORY

                SETLOC  INTPRET2
                BANK

                COUNT   14/ICONS

ZUNIT           2DEC    0

YUNIT           2DEC    0

XUNIT           2DEC    .5

ZEROVEC         2DEC    0

                2DEC    0

                2DEC    0

                OCT     77777           # -0, -6, -12 MUST REMAIN IN THIS ORDER
DEC-6           DEC     -6
DEC-12          DEC     -12
LODPMAX         2OCT    3777737777      # THESE TWO CONSTANTS MUST REMAIN

LODPMAX1        2OCT    3777737777      # ADJACENT AND THE SAME FOR INTEGRATION

ZERODP          =       ZEROVEC
HALFDP          =       XUNIT
```

Uses COUNT 142 and INTPRET2 57.

3.7.6 single precision subroutines

1646b ⟨*single precision subroutines* 1646b⟩≡ (1523a 2805)

⟨*Page CM1207* 1647⟩

1647 ⟨*Page CM1207* 1647⟩≡ (1646b)

```
# Page 1207
                BLOCK   02

# SINGLE PRECISION SINE AND COSINE

                COUNT   02/INTER

SPCOS           AD      HALF            # ARGUMENTS SCALED AT PI
SPSIN           TS      TEMK
                TCF     SPT
                CS      TEMK
SPT             DOUBLE
                TS      TEMK
                TCF     POLLEY
                XCH     TEMK
                INDEX   TEMK
                AD      LIMITS
                COM
                AD      TEMK
                TS      TEMK
                TCF     POLLEY
                TCF     ARG90
POLLEY          EXTEND
                MP      TEMK
                TS      SQ
                EXTEND
                MP      C5/2
                AD      C3/2
                EXTEND
                MP      SQ
                AD      C1/2
                EXTEND
                MP      TEMK
                DDOUBL
                TS      TEMK
                TC      Q
ARG90           INDEX   A
                CS      LIMITS
                TC      Q               # RESULT SCALED AT 1.

# SPROOT WAS DELETED IN REV 51 OF MASTER. ASS. CONT. HAS CARDS.
```

Uses `A` 80, `COUNT` 142, `Q` 80, `SQ` 156, `TC` 169, and `TEMK` 156.

3.7.7 executive code

1648 ⟨*executive code* 1648⟩≡ (1523a)
⟨*Page CM1208* 1649⟩
⟨*Page CM1209* 1650⟩
⟨*Page CM1210* 1651⟩
⟨*Page CM1211* 1652⟩
⟨*Page CM1212* 1653⟩
⟨*Page CM1213* 1654⟩
⟨*Page CM1214* 1655⟩
⟨*Page CM1215* 1656⟩
⟨*Page CM1216* 1657⟩
⟨*Page CM1217* 1658⟩
⟨*Page CM1218* 1659⟩
⟨*Page CM1219* 1660⟩
⟨*Page CM1220* 1661⟩

1649 ⟨*Page CM1208* 1649⟩≡ (1648 2690)

```
                BLOCK   02

# TO ENTER A JOB REQUEST REQUIRING NO VAC AREA:

                COUNT   02/EXEC

NOVAC           INHINT
                AD      FAKEPRET        # LOC(MPAC +6) - LOC(QPRET)
                TS      NEWPRIO         # PRIORITY OF NEW JOB + NOVAC C(FIXLOC)

                EXTEND
                INDEX   Q               # Q WILL BE UNDISTURBED THROUGHOUT.
                DCA     0               # 2CADR OF JOB ENTERED.
                DXCH    NEWLOC
                CAF     EXECBANK
                XCH     FBANK
                TS      EXECTEM1
                TCF     NOVAC2          # ENTER EXECUTIVE BANK.

# TO ENTER A JOB REQUEST REQUIRING A VAC AREA -- E.G., ALL (PARTIALLY) INTERPRETIVE JOBS.

FINDVAC         INHINT
                TS      NEWPRIO
                EXTEND
                INDEX   Q
                DCA     0
SPVACIN         DXCH    NEWLOC
                CAF     EXECBANK
                XCH     FBANK
                TCF     FINDVAC2        # OFF TO EXECUTIVE SWITCHED-BANK.

# TO ENTER A FINDVAC WITH THE PRIORITY IN NEWPRIO TO THE 2CADR ARRIVING IN A AND L:
# USERS OF SPVAC MUST INHINT BEFORE STORING IN NEWPRIO.

SPVAC           XCH     Q
                AD      NEG2
                XCH     Q
                TCF     SPVACIN

# TO SUSPEND A BASIC JOB SO A HIGHER PRIORITY JOB MAY BE SERVICED:

CHANG1          LXCH    Q
                CAF     EXECBANK
                XCH     BBANK
                TCF     CHANJOB
```

```
# TO SUSPEND AN INTERPRETIVE JOB:

CHANG2          CS      LOC             # NEGATIVE LOC SHOWS JOB = INTERPRETIVE.
# ITRACE (4) REFERS TO "CHANG2"
```

Uses A 80, BBANK 80, COUNT 142, EXECTEM1 138, FBANK 80, FIXLOC 140, L 80, LOC 145, MPAC 145, NEWLOC 138, NEWPRIO 138, PRIORITY 145, Q 80, and QPRET 85.

1650 ⟨*Page CM1209* 1650⟩≡ (1648 2690)

```
                TS      L
        +2      CAF     EXECBANK
                TS      BBANK
                TCF     CHANJOB -1
```

Uses BBANK 80 and L 80.

1651 ⟨*Page CM1210* 1651⟩≡ (1648 2690)

```
# TO VOLUNTARILY SUSPEND A JOB UNTIL THE COMPLETION OF SOME ANTICIPATED EVENT (I/O EVENT ETC.):

JOBSLEEP        TS      LOC
                CAF     EXECBANK
                TS      FBANK
                TCF     JOBSLP1

# TO AWAKEN A JOB PUT TO SLEEP IN THE ABOVE FASHION:

JOBWAKE         INHINT
                TS      NEWLOC
                CS      TWO             # EXIT IS VIA FINDVAC/NOVAC PROCEDURES.
                ADS     Q
                CAF     EXECBANK
                XCH     FBANK
                TCF     JOBWAKE2

# TO CHANGE THE PRIORITY OF A JOB CURRENTLY UNDER EXECUTION:

PRIOCHNG        INHINT                  # NEW PRIORITY ARRIVES IN A.  RETURNS TO
                TS      NEWPRIO         # CALLER AS SOON AS NEW JOB PRIORITY IS
                CAF     EXECBANK        # HIGHEST.  PREPARE FOR POSSIBLE BASIC-
                XCH     BBANK           # STYLE CHANGE-JOB.
                TS      BANKSET
                CA      Q
                TCF     PRIOCH2

# TO REMOVE A JOB FROM EXECUTIVE CONSIDERATIONS:

ENDOFJOB        CAF     EXECBANK
                TS      FBANK
                TCF     ENDJOB1

ENDFIND         CA      EXECTEM1        # RETURN TO CALLER AFTER JOB ENTRY
                TS      FBANK           # COMPLETE.
                TCF     Q+2
EXECBANK        CADR    FINDVAC2

FAKEPRET        ADRES   MPAC -36D       # LOC(MPAC +6) - LOC(QPRET)
```

Uses A 80, BANKSET 145, BBANK 80, EXECTEM1 138, FBANK 80, I 206, LOC 145, MPAC 145, NEWLOC 138, NEWPRIO 138, PRIORITY 145, Q 80, and QPRET 85.

1652 ⟨*Page CM1211* 1652⟩≡ (1648 2690)

```
# LOCATE AN AVAILABLE VAC AREA

                BANK    01
                COUNT   01/EXEC

FINDVAC2        TS      EXECTEM1        # (SAVE CALLER'S BANK FIRST.)
                CCS     VAC1USE
                TCF     VACFOUND
                CCS     VAC2USE
                TCF     VACFOUND
                CCS     VAC3USE
                TCF     VACFOUND
                CCS     VAC4USE
                TCF     VACFOUND
                CCS     VAC5USE
                TCF     VACFOUND
                TC      BAILOUT
                OCT     1201            # NO VAC AREAS.

VACFOUND        AD      TWO             # RESERVE THIS VAC AREA BY STORING A ZERO
                ZL                      # IN ITS VAC USE REGISTER AND STORE THE
                INDEX   A               # ADDRESS OF THE FIRST WORD OF IT IN THE
                LXCH    0       -1      # LOW NINE BITS OF THE PRIORITY WORD.
                ADS     NEWPRIO

NOVAC2          CAF     ZERO            # NOVAC ENTERS HERE.  FIND A CORE SET.
                TS      LOCCTR
                CAF     NO.CORES        # SEVEN SETS OF ELEVEN REGISTERS EACH.
NOVAC3          TS      EXECTEM2
                INDEX   LOCCTR
                CCS     PRIORITY        # EACH PRIORITY REGISTER CONTAINS -0 IF
                TCF     NEXTCORE        # THE CORRESPONDING CORE SET IS AVAILABLE.
NO.CORES        DEC     6
                TCF     NEXTCORE        # AN ACTIVE JOB HAS A POSITIVE PRIORITY
                                        # BUT A DORMANT JOB'S PRIORITY IS NEGATIVE
```

Uses A 80, COUNT 142, EXECTEM1 138, EXECTEM2 138, IT 185, LOCCTR 138, NEWPRIO 138, PRIORITY 145, SAVE 191, TC 169, VAC1USE 150, VAC2USE 150, VAC3USE 150, VAC4USE 150, and VAC5USE 150.

1653 ⟨*Page CM1212* 1653⟩≡ (1648 2690)

```
CORFOUND        CA      NEWPRIO         # SET THE PRIORITY OF THIS JOB IN THE CORE
                INDEX   LOCCTR          # SET'S PRIORITY REGISTER AND SET THE
                TS      PRIORITY        # JOB'S PUSH-DOWN POINTER AT THE BEGINNING
                MASK    LOW9            # OF THE WORK AREA AND OVERFLOW INDICATOR.
                INDEX   LOCCTR
                TS      PUSHLOC         # OFF TO PREPARE FOR INTERPRETIVE PROGRAMS.

                CCS     LOCCTR          # IF CORE SET ZERO IS BEING LOADED, SET UP
                TCF     SETLOC          # OVFIND AND FIXLOC IMMEDIATELY.
                TS      OVFIND
                CA      PUSHLOC
                TS      FIXLOC

SPECTEST        CCS     NEWJOB          # SEE IF ANY ACTIVE JOBS WAITING (RARE).
                TCF     SETLOC          # MUST BE AWAKENED OUT UNCHANGED JOB.
                TC      CCSHOLE
                TC      CCSHOLE
                TS      NEWJOB          # +0 SHOWS ACTIVE JOB ALREADY SET.
                DXCH    NEWLOC
                DXCH    LOC
                TCF     ENDFIND

SETLOC          DXCH    NEWLOC          # SET UP THE LOCATION REGISTERS FOR THIS
                INDEX   LOCCTR
                DXCH    LOC
                INDEX   NEWJOB          # THIS INDEX INSTRUCTION INSURES THAT THE
                CS      PRIORITY        # HIGHEST ACTIVE PRIORITY WILL BE COMPARED
                AD      NEWPRIO         # WITH THE NEW PRIORITY TO SEE IF NEWJOB
                EXTEND                  # SHOULD BE SET TO SIGNAL A SWITCH.
                BZMF    ENDFIND
                CA      LOCCTR          # LOCCTR IS LEFT SET AT THIS CORE SET IF
                TS      NEWJOB          # THE CALLER WANTS TO LOAD ANY MPAC
                TCF     ENDFIND         # REGISTERS, ETC.

NEXTCORE        CAF     COREINC
                ADS     LOCCTR
                CCS     EXECTEM2
                TCF     NOVAC3
                TC      BAILOUT         # NO CORE SETS.
                OCT     1202
```

Uses A 80, EXECTEM2 138, FIXLOC 140, LOC 145, LOCCTR 138, MPAC 145, NEWJOB 138, NEWLOC 138, NEWPRIO 138, OVFIND 140, PRIORITY 145, PUSHLOC 145, and TC 169.

1654 ⟨*Page CM1213* 1654⟩≡ (1648 2690)

```
# THE FOLLOWING ROUTINE SWAPS CORE SET 0 WITH THAT WHOSE RELATIVE ADDRESS IS IN NEWJO

        -2      LXCH    LOC
        -1      CAE     BANKSET         # BANKSET, NOT BBANK, HAS RIGHT CONTENTS.
CHANJOB         INHINT
                EXTEND
                ROR     SUPERBNK        # PICK UP CURRENT SBANK FOR BBCON
                XCH     L               # LOC IN A AND BBCON IN L.
        +4      INDEX   NEWJOB          # SWAP LOC AND BANKSET.
                DXCH    LOC
                DXCH    LOC

                CAE     BANKSET
                EXTEND
                WRITE   SUPERBNK        # SET SBANK FOR NEW JOB.
                DXCH    MPAC            # SWAP MULTI-PURPOSE ACCUMULATOR AREAS.
                INDEX   NEWJOB
                DXCH    MPAC
                DXCH    MPAC
                DXCH    MPAC +2
                INDEX   NEWJOB
                DXCH    MPAC +2
                DXCH    MPAC +2
                DXCH    MPAC +4
                INDEX   NEWJOB
                DXCH    MPAC +4
                DXCH    MPAC +4
                DXCH    MPAC +6
                INDEX   NEWJOB
                DXCH    MPAC +6
                DXCH    MPAC +6

                CAF     ZERO
                XCH     OVFIND          # MAKE PUSHLOC NEGATIVE IF OVFIND NZ.
                EXTEND
                BZF     +3
                CS      PUSHLOC
                TS      PUSHLOC

                DXCH    PUSHLOC
                INDEX   NEWJOB
                DXCH    PUSHLOC
                DXCH    PUSHLOC         # SWAPS PUSHLOC AND PRIORITY.
                CAF     LOW9            # SET FIXLOC TO BASE OF VAC AREA.
                MASK    PRIORITY
```

```
                TS      FIXLOC

                CCS     PUSHLOC         # SET OVERFLOW INDICATOR ACCORDING TO
                CAF     ZERO
                TCF     ENDPRCHG -1
```

Uses A 80, BANKSET 145, BBANK 80, FIXLOC 140, L 80, LOC 145, MPAC 145, NEWJOB 138, OVFIND 140, PRIORITY 145, PUSHLOC 145, and SUPERBNK 87.

1655 ⟨*Page CM1214* 1655⟩≡ (1648 2690)

```
                CS      PUSHLOC
                TS      PUSHLOC
                CAF     ONE
                XCH     OVFIND
                TS      NEWJOB

  ENDPRCHG      RELINT
                DXCH    LOC             # BASIC JOBS HAVE POSITIVE ADDRESSES, SO
                EXTEND                  # DISPATCH WITH A DTCB.
                BZMF    +2              # IF INTERPRETIVE, SET UP EBANK, ETC.
                DTCB
```

Uses A 80, EBANK 80, LOC 145, NEWJOB 138, OVFIND 140, and PUSHLOC 145.

1656 ⟨*Page CM1215* 1656⟩≡ (1648 2690)

```
                COM                     # EPILOGUE TO JOB CHANGE FOR INTERPRETIVE
                AD      ONE
                TS      LOC             # RESUME
                TCF     INTRSM

  # COMPLETE JOBSLEEP PREPARATIONS.

  JOBSLP1       INHINT
                CS      PRIORITY        # NNZ PRIORITY SHOWS JOB ASLEEP.
                TS      PRIORITY
                CAF     LOW7
                MASK    BBANK
                EXTEND
                ROR     SUPERBNK        # SAVE OLD SUPERBANK VALUE.
                TS      BANKSET
                CS      ZERO
  JOBSLP2       TS      BUF     +1      # HOLDS -- HIGHEST PRIORITY.
                TCF     EJSCAN          # SCAN FOR HIGHEST PRIORITY ALA ENDOFJOB.

  NUCHANG2      INHINT                  # QUICK... DON'T LET NEWJOB CHANGE TO +0.
                CCS     NEWJOB
                TCF             +3      # NEWJOB STILL PNZ
                RELINT                  # NEW JOB HAS CHANGED TO +0.  WAKE UP JOB
                TCF     ADVAN   +2      # VIA NUDIRECT.  (VERY RARE CASE.)

                CAF     TWO
                EXTEND
                WOR     DSALMOUT        # TURN ON ACTIVITY LIGHT
                DXCH    LOC             # AND SAVE ADDRESS INFO FOR BENEFIT OF
                TCF     CHANJOB +4      #       POSSIBLE SLEEPING JOB.
```

Uses BANKSET 145, BBANK 80, BUF 142, DSALMOUT 87, LOC 145, NEWJOB 138, PRIORITY 145, SAVE 191, and SUPERBNK 87.

1657 ⟨*Page CM1216* 1657⟩≡ (1648 2690)

```
# TO WAKE UP A JOB, EACH CORE SET IS FOUND TO LOCATE ALL JOBS WHICH ARE ASLEEP.  IF THE FCADR I
# LOC REGISTER OF ANY SUCH JOB MATCHES THAT SUPPLIED BY THE CALLER, THAT JOB IS AWAKENED.  IF N
# LOCCTR IS SET TO -1 AND NO FURTHER ACTION TAKES PLACE.

JOBWAKE2        TS      EXECTEM1
                CAF     ZERO            # BEGIN CORE SET SCAN
                TS      LOCCTR
                CAF     NO.CORES
JOBWAKE4        TS      EXECTEM2
                INDEX   LOCCTR
                CCS     PRIORITY
                TCF     JOBWAKE3        # ACTIVE JOB -- CHECK NEXT CORE SET.
COREINC         DEC     12              # 12 REGISTERS PER CORE SET.
                TCF     WAKETEST        # SLEEPING JOB -- SEE IF CADR MATCHES.

JOBWAKE3        CAF     COREINC
                ADS     LOCCTR
                CCS     EXECTEM2
                TCF     JOBWAKE4
                CS      ONE             # EXIT IF SLEEPING JOB NOT FOUND.
                TS      LOCCTR
                TCF     ENDFIND

WAKETEST        CS      NEWLOC
                INDEX   LOCCTR
                AD      LOC
                EXTEND
                BZF     +2              # IF MATCH.
                TCF     JOBWAKE3        # EXAMINE NEXT CORE SET IF NO MATCH.

                INDEX   LOCCTR          # RE-COMPLEMENT PRIORITY TO SHOW JOB AWAKE
                CS      PRIORITY
                TS      NEWPRIO
                INDEX   LOCCTR
                TS      PRIORITY

                CS      FBANKMSK        # MASK UP THE 2CADR OF THE WAKE ADDRESS
                MASK    NEWLOC          # USING THE CADR IN NEWLOC AND THE EBANK
                AD      2K              # HALF OF BBANK SAVED IN BANKSET.
                XCH     NEWLOC
                MASK    FBANKMSK
                INDEX   LOCCTR
                AD      BANKSET
                TS      NEWLOC +1
```

```
                CCS     LOCCTR          # SPECIAL TREATMENT IF THIS JOB WAS
                TCF     SETLOC          # ALREADY IN THE RUN (0) POSITION.
                TCF     SPECTEST
```

Uses A 80, BANKSET 145, BBANK 80, EBANK 80, EXECTEM1 138, EXECTEM2 138, LOC 145, LOCCTR 138, NEWLOC 138, NEWPRIO 138, PRIORITY 145, and RUN 191.

1658 ⟨*Page CM1217* 1658⟩≡ (1648 2690)

```
  # PRIORITY CHANGE.  CHANGE THE CONTENTS OF PRIORITY AND SCAN FOR THE JOB OF HIGHEST P

  PRIOCH2       TS      LOC
                CAF     ZERO            # SET FLAG TO TELL ENDJOB SCANNER IF THIS
                TS      BUF             # JOB IS STILL HIGHEST PRIORITY.
                CAF     LOW9
                MASK    PRIORITY
                AD      NEWPRIO
                TS      PRIORITY
                COM
                TCF     JOBSLP2         # AND TO EJSCAN.
```

Uses BUF 142, LOC 145, NEWPRIO 138, and PRIORITY 145.

1659 ⟨*Page CM1218* 1659⟩≡ (1648 2690)

```
# RELEASE THIS CORE SET AND VAC AREA AND SCAN FOR THE JOB OF HIGHEST ACTIVE PRIORITY.

ENDJOB1         INHINT
                CS      ZERO
                TS      BUF +1
                XCH     PRIORITY
                MASK    LOW9
                TS      L

                CS      FAKEPRET
                AD      L

                EXTEND
                BZMF    EJSCAN          # NOVAC ENDOFJOB

                CCS     L
                INDEX   A
                TS      0

EJSCAN          CCS     PRIORITY +12D
                TC      EJ1
                TC      CCSHOLE
                TCF     +1

                CCS     PRIORITY +24D   # EXAMINE EACH PRIORITY REGISTER TO FIND
                TC      EJ1             # THE JOB OF HIGHEST ACTIVE PRIORITY.
                TC      CCSHOLE
                TCF     +1

                CCS     PRIORITY +36D
                TC      EJ1
-CCSPR          -CCS    PRIORITY
                TCF     +1

                CCS     PRIORITY +48D
                TC      EJ1
                TC      CCSHOLE
                TCF     +1

                CCS     PRIORITY +60D
                TC      EJ1
                TC      CCSHOLE
                TCF     +1

                CCS     PRIORITY +72D
```

```
                TC      EJ1
                TC      CCSHOLE
                TCF     +1
```

Uses A 80, BUF 142, L 80, PRIORITY 145, and TC 169.

1660 ⟨*Page CM1219* 1660⟩≡ (1648 2690)

```
  # EVALUATE THE RESULTS OF THE SCAN.

                CCS     BUF     +1      # SEE IF THERE ARE ANY ACTIVE JOBS WAITING
                TC      CCSHOLE
                TC      CCSHOLE

                TCF     +2
                TCF     DUMMYJOB
                CCS     BUF             # BUF IS ZERO IS THIS IS A PRIOCHNG AND
                TCF     +2              # CHANGED PRIORITY IS STILL HIGHEST.
                TCF     ENDPRCHG -1

                INDEX   A               # OTHERWISE, SET NEWJOB TO THE RELATIVE
                # Was CAF --- RSB 2004
                CA      0       -1      # ADDRESS OF THE NEW JOB'S CORE SET.
                AD      -CCSPR
                TS      NEWJOB
                TCF     CHANJOB -2

  EJ1           TS      BUF     +2
                AD      BUF     +1      # - OLD HIGH PRIORITY.
                CCS     A
                CS      BUF     +2
                TCF     EJ2             # NEW HIGH PRIORITY.
                NOOP
                INDEX   Q
                TC      2               # PROCEED WITH SEARCH.

  EJ2           TS      BUF     +1
                EXTEND
                QXCH    BUF             # FOR LOCATING CCS PRIORITY + X INSTR.
                INDEX   BUF
                TC      2
```

Uses A 80, BUF 142, NEWJOB 138, PRIORITY 145, Q 80, and TC 169.

1661 ⟨*Page CM1220* 1661⟩≡ (1648 2690)

```
# IDLING AND COMPUTER ACTIVITY (GREEN) LIGHT MAINTENANCE. THE IDLING ROUTINE IS NOT A JOB IN IT
# BUT RATHER A SUBROUTINE OF THE EXECUTIVE.

                EBANK=  SELFRET         # SELF-CHECK STORAGE IN EBANK.

DUMMYJOB        CS      ZERO            # SET NEWJOB TO -0 FOR IDLING.
                TS      NEWJOB
                RELINT
                CS      TWO             # TURN OFF THE ACTIVITY LIGHT.
                EXTEND
                WAND    DSALMOUT
ADVAN           CCS     NEWJOB          # IS THE NEWJOB ACTIVE?
                TCF     NUCHANG2        # YES... ONE REQUIRING A CHANGE JOB.
                CAF     TWO             # NEW JOB ALREADY IN POSITION FOR
                TCF     NUDIRECT        # EXECUTION

                CA      SELFRET
                TS      L               # PUT RETURN ADDRESS IN L.
                CAF     SELFBANK
                TCF     SUPDXCHZ +1     # AND DISPATCH JOB.

                EBANK=  SELFRET
SELFBANK        BBCON   SELFCHK

NUDIRECT        EXTEND                  # TURN THE GREEN LIGHT BACK ON.
                WOR     DSALMOUT
                DXCH    LOC             # JOBS STARTED IN THIS FASHION MUST BE
                TCF     SUPDXCHZ

                BLOCK   2               # IN FIXED-FIXED SO OTHERS MAY USE.

                COUNT   02/EXEC

# SUPDXCHZ -- ROUTINE TO TRANSFER TO SUPERBANK.
# CALLING SEQUENCE:
#               TCF     SUPDXCHZ        # WITH 2CADR OF DESIRED LOCATION IN A + 1.

SUPDXCHZ        XCH     L               # BASIC.
        +1      EXTEND
                WRITE   SUPERBNK
                TS      BBANK
                TC      L

NEG100          OCT     77677
```

Uses `A` 80, `BBANK` 80, `COMPUTER` 115, `COUNT` 142, `DSALMOUT` 87, `EBANK` 80, `L` 80, `LOC` 145, `NEWJOB` 138, `SELFRET` 165, `SUPERBNK` 87, and `TC` 169.

3.7.8 waitlist code

1662 ⟨*waitlist code* 1662⟩≡ (1523a 2832)
⟨*Page CM1221* 1663⟩

1663 ⟨*Page CM1221* 1663⟩≡ (1662)

```
# Page 1221
# PROGRAM DESCRIPTION                                          DATE -- 10 OCTOBER 1966
# MOD NO -- 2                                                  LOG SECTION -- WAITLIST
# MOD BY -- MILLER      (DTMAX INCREASED TO 162.5 SEC)         ASSEMBLY -- SUNBURST REV 5
# MOD 3 BY KERNAN       (INHINT INSERTED AT WAITLIST) 2/28/68 SKIPPER REV 4
# MOD 4 BY KERNAN       (TWIDDLE IN 54) 3/28/68 SKIPPER REV 13.
#
# FUNCTIONAL DESCRIPTION --
#       PART OF A SECTION OF PROGRAMS -- WAITLIST, TASKOVER, T3RUPT, USED TO CALL A PROGRAM (CA
#       WHICH IS TO BEGIN IN C(A) CENTISECONDS.  WAITLIST UPDATES TIME3, LST1, AND LST2.  THE M
#       FOLLOW.
#
#               C(TIME3) = 16384 -(T1-T) CENTISECONDS, (T=PRESENT TIME, T1-TIME FOR TASK1)
#
#                       C(LST1)         =       -(T2-T1)+1
#                       C(LST1 +1)      =       -(T3-T2)+1
#                       C(LST1 +2)      =       -(T4-T3)+1
#                                      ...
#                       C(LST1 +6)      =       -(T8-T7)+1
#                       C(LST1 +7)      =       -(T9-T8)+1
#
#                       C(LST2)         =       2CADR OF TASK1
#                       C(LST2 +2)      =       2CADR OF TASK2
#                                      ...
#                       C(LST2 +14)     =       2CADR OF TASK8
#                       C(LST2 +16)     =       2CADR OF TASK9
#
# WARNINGS --
#       1)      1 <= C(A) <= 16250D (1 CENTISECOND TO 162.5 SEC)
#       2)      9 TASKS MAXIMUM
#       3)      TASKS CALLED UNDER INTERRUPT INHIBITED
#       4)      TASKS END BY TC TASKOVER
#
# CALLING SEQUENCE --
#       L-1     CA      DELTAT  (TIME IN CENTISECONDS TO TASK START)
#       L       TC      WAITLIST
#       L+1     2CADR   DESIRED TASK
#       L+2     (MINOR OF 2CADR)
#       L+3     RELINT          (RETURNS HERE)
#
# TWIDDLE --
#       TWIDDLE IS FOR USE WHEN THE TASK BEING SET UP IS IN THE SAME EBANK AND FBANK AS THE USE
#       SUCH CASES, IT IMPROVES UPON WAITLIST BY ELIMINATING THE NEED FOR THE BBCON HALF OF THE
# Page 1222
#       SAVING A WORD.  TWIDDLE IS LIKE WAITLIST IN EVERY RESPECT EXCEPT CALLING SEQUENCE, TO W
```

```
#               L-1     CA      DELTAT
#               L       TC      TWIDDLE
#               L+1     ADRES   DESIRED TASK
#               L+2     RELINT          (RETURNS HERE)
#
# NORMAL EXIT MODES --
#       AT L+3 OF CALLING SEQUENCE.
#
# ALARM OR ABORT EXIT MODES --
#       TC      ABORT
#       OCT     1203    (WAITLIST OVERFLOW -- TOO MANY TASKS)
#
# ERASABLE INITIALIZATION REQUIRED --
#       ACCOMPLISHED BY FRESH START --  LST2, ..., LST2 +16 = ENDTASK
#                                       LST1, ..., LST1 +7  = NEG1/2
#
# OUTPUT --
#       LST1 AND LST2 UPDATED WITH NEW TASK AND ASSOCIATED TIME.
#
# DEBRIS --
#       CENTRALS -- A,Q,L
#       OTHER    -- WAITEXIT, WAITADR, WAITTEMP, WAITBANK
#
# DETAILED ANALYSIS OF TIMING --
#       CONTROL WILL NOT BE RETURNED TO THE SPECIFIED ADDRESS (2CADR) IN EXACTLY DELT
#       THE APPROXIMATE TIME MAY BE CALCULATED AS FOLLOWS:
#               LET T0 = THE TIME OF THE TC WAITLIST
#               LET TS = T0 +147U + COUNTER INCREMENTS (SET UP TIME)
#               LET X  = TS -(100TS)/100  (VARIANCE FROM COUNTERS)
#               LET Y  = LENGTH OF TIME OF INHIBIT INTERRUPT AFTER T3RUPT
#               LET Z  = LENGTH OF TIME TO PROCESS TASKS WHICH ARE DUE THIS T3RUPT BU
#               (Z=0, USUALLY).
#               LET DELTD = THE ACTUAL TIME TAKEN TO GIVE CONTROL TO 2CADR
#       THEN DELTD = TS+DELTA T -X +Y +Z +1.05MS* +COUNTERS*
#               *THE TIME TAKEN BY WAITLIST ITSELF AND THE COUNTER TICKING DURING THI
#       IN SHORT, THE ACTUAL TIME TO RETURN CONTROL TO A 2CADR IS AUGMENTED BY THE TI
#       INTERRUPT, ALL COUNTERS TICKING, THE T3RUPT PROCESSING TIME, THE WAITLIST PRO
#       OF OTHER TASKS INHIBITING THE INTERRUPT.

                BLOCK   02
# Page 1223
                EBANK=  LST1            # TASK LISTS IN SWITCHED E BANK.

                COUNT   02/WAIT

TWIDDLE         INHINT
```

```
                TS      L               # SAVE DELAY TIME IN L
                CA      POSMAX
                ADS     Q               # CREATING OVERFLOW AND Q-1 IN Q
                CA      BBANK
                EXTEND
                ROR     SUPERBNK
                XCH     L

WAITLIST        INHINT
                EXTEND
                BZMF    WATLST0-
                XCH     Q               SAVE DELTA T IN Q AND RETURN IN
                TS      WAITEXIT        WAITEXIT.
                EXTEND
                INDEX   WAITEXIT        # IF TWIDDLING, THE TS SKIPS TO HERE
                DCA     0               # PICK UP 2CADR OF TASK.
        -1      TS      WAITADR         # BBCON WILL REMAIN IN L
DLY2            CAF     WAITBB          # ENTRY FROM FIXDELAY AND VARDELAY.
                XCH     BBANK
                TCF     WAIT2

WATLST0-        TC      P00DOO
                OCT     1204            # WAITLIST CALL WITH ZERO OR NEG DT

# RETURN TO CALLER AFTER TASK INSERTION:

LVWTLIST        DXCH    WAITEXIT
                AD      TWO
                DTCB

                EBANK=  LST1
WAITBB          BBCON   WAIT2

# RETURN TO CALLER +2 AFTER WAITING DT SPECIFIED AT CALLER +1.

FIXDELAY        INDEX   Q               # BOTH ROUTINES MUST BE CALLED UNDER
                # Was CAF --- RSB 2004.
                CA      0               # WAITLIST CONTROL AND TERMINATE THE TASK
                INCR    Q               # IN WHICH THEY WERE CALLED.

# RETURN TO CALLER +1 AFTER WAITING THE DT AS ARRIVING IN A.

VARDELAY        XCH     Q               # DT TO Q.  TASK ADRES TO WAITADR.
                TS      WAITADR
                CA      BBANK           # BBANK IS SAVED DURING DELAY.
                EXTEND
```

```
# Page 1224
                ROR     SUPERBNK        # ADD SBANK TO BBCON.
                TS      L
                CAF     DELAYEX
                TS      WAITEXIT        # GO TO TASKOVER AFTER TASK ENTRY.
                TCF     DLY2

DELAYEX         TCF     TASKOVER -2     # RETURNS TO TASKOVER.

# Page 1225
# ENDTASK MUST ENTERED IN FIXED-FIXED SO IT IS DISTINGUISHABLE BY ITS ADRES ALONE.

                EBANK=  LST1
ENDTASK         -2CADR  SVCT3

SVCT3           CCS     FLAGWRD2        # DRIFT FLAG
                TCF     TASKOVER
                TCF     TASKOVER
                TCF     +1

                CCS     IMUCADR         # DON'T DO NBDONLY IF SOMEONE ELSE IS IN
                TCF     SVCT3X
                TCF     +3
                TCF     SVCT3X
                TCF     SVCT3X
        +3      CAF     PRIO35          # COMPENSATE FOR NBD COEFFICIENTS ONLY.
                TC      NOVAC           #       ENABLE EVERY 81.93 SECONDS
                EBANK=  NBDX
                2CADR   NBDONLY

                TCF     TASKOVER

                SETLOC  FFTAG6
                BANK

SVCT3X          TC      FIXDELAY        # DELAY MAX OF 2 TIMES FOR IMU ZERO
                DEC     500
                TC      SVCT3

# Page 1226
# BEGIN TASK INSERTION.

                BANK    01
                COUNT   01/WAIT

WAIT2           TS      WAITBANK        # BBANK OF CALLING PROGRAM.
```

```
                CS      TIME3
                AD      BIT8            # BIT 8 = OCT 200
                CCS     A               # TEST 200 - C(TIME3).  IF POSITIVE,
                                        # IT MEANS THAT TIME3 OVERFLOW HAS OCCURRED PRIOR TO CS
                                        # C(TIME3) = T - T1, INSTEAD OF 1.0 - (T1 - T).  THE FO
                                        # ORDERS SET C(A) = TD - T1 + 1 IN EITHER CASE.

                AD      OCT40001        # OVERFLOW HAS OCCURRED.  SET C(A) =
                CS      A               # T - T1 + 1.0 - 201

# NORMAL CASE (C(A) NNZ) YIELDS SAME C(A):  -( -(1.0-(T1-T)) + 200) - 1

                AD      OCT40201
                AD      Q               # RESULT = TD - T1 + 1.

                CCS     A               # TEST TD - T1 +1.

                AD      LST1            # IF TD - T1 POS, GO TO WTLST5 WITH
                TCF     WTLST5          # C(A) = (TD - T1) + C(LST1) = TD-T2+1

                NOOP
                CS      Q

# NOTE THAT THIS PROGRAM SECTION IS NEVER ENTERED WHEN T-T1 G/E -1,
# SINCE TD-T1+1 = (TD-T) + (T-T1+1), AND DELTA T = TD-T G/E +1.  (G/E
# SYMBOL MEANS GREATER THAN OR EQUAL TO).  THUS THERE NEED BE NO CON-
# CERN OVER A PREVIOUS OR IMMINENT OVERFLOW OF TIME3 HERE.

                AD      POS1/2          # WHEN TD IS NEXT, FORM QUANTITY
                AD      POS1/2          #       1.0 - DELTA T = 1.0 - (TD - T)
                XCH     TIME3
                AD      NEGMAX
                AD      Q               # 1.0 - DELTAT T NOW COMPLETE.
                EXTEND                  # ZERO INDEX Q.
                QXCH    7               # (ZQ)

# Page 1227
WTLST4          XCH     LST1
                XCH     LST1    +1
                XCH     LST1    +2
                XCH     LST1    +3
                XCH     LST1    +4
                XCH     LST1    +5
                XCH     LST1    +6
                XCH     LST1    +7
```

```
                CA      WAITADR         # (MINOR PART OF TASK CADR HAS BEEN IN L.)
                INDEX   Q
                TCF     +1

                DXCH    LST2
                DXCH    LST2    +2
                DXCH    LST2    +4
                DXCH    LST2    +6
                DXCH    LST2    +8D
                DXCH    LST2    +10D    # AT END, CHECK THAT C(LST2 +10) IS STD
                DXCH    LST2    +12D
                DXCH    LST2    +14D
                DXCH    LST2    +16D
                AD      ENDTASK         # END ITEM, AS CHECK FOR EXCEEDING
                                        # THE LENGTH OF THE LIST.
                EXTEND                  # DUMMY TASK ADRES SHOULD BE IN FIXED-
                BZF     LVWTLIST        # FIXED SO ITS ADRES ALONE DISTINGUISHES
                TCF     WTABORT         # IT.

# Page 1228
WTLST5          CCS     A               # TEST TD - T2 + 1
                AD      LST1 +1
                TCF     +4
                AD      ONE
                TC      WTLST2
                OCT     1

        +4      CCS     A               # TEST TD - T3 + 1
                AD      LST1 +2
                TCF     +4
                AD      ONE
                TC      WTLST2
                OCT     2

        +4      CCS     A               # TEST TD - T4 + 1
                AD      LST1 +3
                TCF     +4
                AD      ONE
                TC      WTLST2
                OCT     3

        +4      CCS     A               # TEST TD - T5 + 1
                AD      LST1 +4
                TCF     +4
                AD      ONE
                TC      WTLST2
```

```
                OCT     4

        +4      CCS     A               # TEST TD - T6 + 1
                AD      LST1 +5
                TCF     +4
                AD      ONE
                TC      WTLST2
                OCT     5

        +4      CCS     A               # TEST TD - T7 + 1
                AD      LST1 +6
                TCF     +4
                AD      ONE
                TC      WTLST2
                OCT     6

# Page 1229
        +4      CCS     A
                AD      LST1 +7
                TCF     +4
                AD      ONE
                TC      WTLST2
                OCT     7

        +4      CCS     A
WTABORT         TC      BAILOUT         # NO ROOM IN THE INN
                OCT     1203

                AD      ONE
                TC      WTLST2
                OCT     10

OCT40201        OCT     40201

# Page 1230
# THE ENTRY TC WTLST2 JUST PRECEDING OCT N IS FOR T  LE TD LE T   -1.
#                                                  N           N+1
#
# (LE MEANS LESS THAN OR EQUAL TO).  AT ENTRY, C(A) = -(TD - T   + 1)
#                                                                N+1
#
# THE LST1 ENTRY-(T   -T +1) IS TO BE REPLACED BY -(TD - T  + 1), AND
#                  N+1  N                                  N
#
# THE ENTRY-(T   - TD + 1) IS TO BE INSERTED IMMEDIATELY FOLLOWING.
#             N+1
```

```
WTLST2          TS      WAITTEMP        # C(A) = -(TD - T + 1)
                INDEX   Q
                # Was CAF --- RSB 2004.
                CA      0
                TS      Q               # INDEX VALUE INTO Q.

                CAF     ONE
                AD      WAITTEMP
                INDEX   Q               # C(A) = -(TD - T ) + 1.
                ADS     LST1 -1         #                N

                CS      WAITTEMP
                INDEX   Q
                TCF     WTLST4

# Page 1231
# ENTERS HERE ON T3 RUPT TO DISPATCH WAITLISTED TASK.

T3RUPT          EXTEND
                ROR     SUPERBNK        # READ CURRENT SUPERBANK VALUE AND
                TS      BANKRUPT        # SAVE WITH E AND F BANK VALUES.
                EXTEND
                QXCH    QRUPT

T3RUPT2         CAF     NEG1/2          # DISPATCH WAITLIST TASK.
                XCH     LST1 +7
                XCH     LST1 +6
                XCH     LST1 +5
                XCH     LST1 +4         # 1. MOVE UP LST1 CONTENTS, ENTERING
                XCH     LST1 +3         #    A VALUE OF 1/2 +1 AT THE BOTTOM
                XCH     LST1 +2         #    FOR T6-T5, CORRESPONDING TO THE
                XCH     LST1 +1         #    INTERVAL 81.91 SEC FOR ENDTASK.
                XCH     LST1
                AD      POSMAX          # 2. SET T3 = 1.0 - T2 - T USING LIST 1.
                ADS     TIME3           #    SO T3 WON'T TICK DURING UPDATE.
                TS      RUPTAGN
                CS      ZERO
                TS      RUPTAGN         # SETS RUPTAGN TO +1 ON OVERFLOW.

                EXTEND                  # DISPATCH TASK.
                DCS     ENDTASK
                DXCH    LST2 +16D
                DXCH    LST2 +14D
                DXCH    LST2 +12D
                DXCH    LST2 +10D
```

```
                DXCH    LST2 +8D
                DXCH    LST2 +6
                DXCH    LST2 +4
                DXCH    LST2 +2
                DXCH    LST2

                XCH     L
                EXTEND
                WRITE   SUPERBNK        # SET SUPERBANK FROM BBCON OF 2CADR
                XCH     L               # RESTORE TO L FOR DXCH Z.
                DTCB

# Page 1232
# RETURN, AFTER EXECUTION OF T3 OVERFLOW TASK:

                BLOCK   02
                COUNT   02/WAIT

TASKOVER        CCS     RUPTAGN         # IF +1 RETURN TO T3RUPT, IF -0 RESUME.
                CAF     WAITBB
                TS      BBANK
                TCF     T3RUPT2         # DISPATCH NEXT TASK IF IT WAS DUE.

                CA      BANKRUPT
                EXTEND
                WRITE   SUPERBNK        # RESTORE SUPERBANK BEFORE RESUME IS DONE

RESUME          EXTEND
                QXCH    QRUPT
NOQRSM          CA      BANKRUPT
                XCH     BBANK
NOQBRSM         DXCH    ARUPT
                RELINT
                RESUME

# Page 1233
# LONGCALL
# PROGRAM DESCRIPTION                           DATE -- 17 MARCH 1967
# PROGRAM WRITTEN BY W.H.VANDEVER               LOG SECTION WAITLIST
# MOD BY -- R. MELANSON TO ADD DOCUMENTATION    ASSEMBLY SUNDISK REV. 100
#
# FUNCTIONAL DESCRIPTION --
#       LONGCALL IS CALLED WITH THE DELTA TIME ARRIVING IN A,L SCALED AS TIME2,TIME1 WITH THE 2
#       IMMEDIATELY FOLLOWING THE TC LONGCALL.  FOR EXAMPLE, IT MIGHT BE DONE AS FOLLOWS WHERE
#       A DP REGISTER CONTAINING A DELTA TIME AND WHERE TASKTODO IS THE NAME OF THE LOCATION AT
#       START.
```

```
#
# CALLING SEQUENCE --
#               EXTEND
#               DCA     TIMELOC
#               TC      LONGCALL
#               2CADR   TASKTODO
#
# NORMAL EXIT MODE --
#       1)      TC      WAITLIST
#       2)      DTCB    (TC L+3 OF CALLING ROUTINE 1ST PASS THRU LONGCYCL)
#       3)      DTCB    (TO TASKOVER ON SUBSEQUENT PASSES THRU LONGCYCL)
#
# ALARM OR ABORT EXIT MODE --
#       NONE
#
# OUTPUT --
#       LONGTIME AND LONGTIME+1 = DELTA TIME
#       LONGEXIT AND LONGEXIT+1 = RETURN 2CADR
#       LONGCADR AND LONGCADR+1 = TASK 2CADR
#       A = SINGLE PRECISION TIME FOR WAITLIST
#
# ERASABLE INITIALIZATION --
#       A = MOST SIGNIFICANT PART OF DELTA TIME
#       L = LEAST SIGNIFICANT PART OF DELTA TIME
#       Q = ADDRESS OF 2CADR TASK VALUE
#
# DEBRIS --
#       A,Q,L
#       LONGCADR AND LONGCADR+1
#       LONGEXIT AND LONGEXIT+1
#       LONGTIME AND LONGTIME+1
#
# *** THE FOLLOWING IS TO BE IN FIXED-FIXED AND UNSWITCHED ERRASIBLE ***

                BLOCK   02
                EBANK=  LST1
LONGCALL        DXCH    LONGTIME        # OBTAIN THE DELTA TIME

                EXTEND                  # OBTAIN THE 2CADR
# Page 1234
                NDX     Q
                DCA     0
                DXCH    LONGCADR

                EXTEND                  # NO GO TO THE APPROPRIATE SWITCHED BANK
                DCA     LGCL2CDR        # FOR THE REST OF LONGCALL
```

```
                DTCB

                EBANK=  LST1
LGCL2CDR        2CADR   LNGCALL2

# *** THE FOLLOWING MAY BE IN A SWITCHED BANK, INCLUDING ITS ERASABLE ***

                BANK    01
                COUNT   01/WAIT

LNGCALL2        LXCH    LONGEXIT +1     # SAVE THE CORRECT BB FOR RETURN
                CA      TWO             # OBTAIN THE RETURN ADDRESS
                ADS     Q
                TS      LONGEXIT

# *** WAITLIST TASK LONGCYCL ***

LONGCYCL        EXTEND                  # CAN WE SUCCESFULLY TAKE ABOUT 1.25
                DCS     DPBIT14         # MINUTES OFF OF LONGTIME
                DAS     LONGTIME

                CCS     LONGTIME +1     # THE REASONING BEHIND THIS PART IS
                TCF     MUCHTIME        # INVOLVED, TAKING INTO ACCOUNT THAT THE
                                        # WORDS MAY NOT BE SIGNED CORRECTED (DP
                                        # BASIC INSTRUCTIONS
                                        # DO NOT SIGN CORRECT) AND THAT WE SUBTRAC-
                                        # TED BIT14 (1 OVER HALF THE POS. VALUE
                                        # REPRESENTABLE IN SINGLE WORD)
                NOOP                    # CAN'T GET HERE *************
                TCF     +1
                CCS     LONGTIME
                TCF     MUCHTIME
DPBIT14         OCT     00000
                OCT     20000

                                        # LONGCALL
LASTTIME        CA      BIT14           # GET BACK THE CORRECT DELTA TFOR WAITLIST
                ADS     LONGTIME +1
                TC      WAITLIST
                EBANK=  LST1
                2CADR   GETCADR         # THE ENTRY TO OUR LONGCADR

LONGRTRN        CA      TSKOVCDR        # SET IT UP SO THAT ONLY THE FIRST EXIT IS
# Page 1235
                DXCH    LONGEXIT        # TO THE CALLER OF LONGCALL
                DTCB                    # THE REST ARE TO TASKOVER
```

```
MUCHTIME        CA      BIT14           # WE HAVE OVER OUR ABOUT 1.25 MINUTES
                TC      WAITLIST        # SO SET UP FOR ANOTHER CYCLE THROUGH HERE
                EBANK=  LST1
                2CADR   LONGCYCL

                TCF     LONGRTRN        # NOW EXIT PROPERLY

# *** WAITLIST TASK GETCADR ***

GETCADR         DXCH    LONGCADR        # GET THE LONGCALL THAT WE WISHED TO START
                DTCB                    # AND TRANSFER CONTROL TO IT

TSKOVCDR        GENADR  TASKOVER
```

Uses A 80, ARUPT 80, BANKRUPT 80, BBANK 80, COUNT 142, DELTAT 241, EBANK 80, F 238, FBANK 80, FFTAG6 57, FLAGWRD2 101, H 177, IMUCADR 163, IT 185, L 80, LONGCADR 157, LONGEXIT 167, LONGTIME 157, LST1 167, LST2 167, MODE 145, N 206, NBDX 167, Q 80, QRUPT 80, RUPTAGN 150, SAVE 191, SUPERBNK 87, T1 241, T2 241, TC 169, TIME1 80, TIME2 80, TIME3 80, VARIANCE 232, W 183, WAITADR 138, WAITBANK 138, WAITEXIT 138, WAITTEMP 138, and Z 80.

3.7.9 latitude longitude subroutines

1674 ⟨*latitude longitude subroutines* 1674⟩≡ (1523a)

⟨*Page CM1236* 1675⟩
⟨*Page CM1237* 1676⟩
⟨*Page CM1238* 1677⟩
⟨*Page CM1239* 1679⟩
⟨*Page CM1240* 1680⟩
⟨*Page CM1241* 1681⟩
⟨*Page CM1242* 1682⟩

1675 ⟨*Page CM1236* 1675⟩≡ (1674 2737)

```
# SUBROUTINE TO CONVERT RAD VECTOR AT GIVEN TIME TO LAT,LONG AND ALT
#
# CALLING SEQUENCE
#       L-1     CALL
#       L               LAT-LONG
#
# SUBROUTINES USED
#       R-TO-RP, ARCTAN, SETGAMMA, SETRE
#
# ERASABLE INIT. REQ.
#       AXO, -AYO, AZO, TEPHEM (SET AT LAUNCH TIME)
#       ALPHAV = POSITION VECTOR METERS B-29
#       MPAC -- TIME (CSECS B-28)
#       ERADFLAG =1, TO COMPUTE EARTH RADIUS, =0 FOR FIXED EARTH RADIUS
#       LUNAFLAG=0 FOR EARTH, 1 FOR MOON
#
# OUTPUT
#       LATITUDE IN LAT         (REVS. B-0)
#       LONGITUDE IN LONG       (REVS. B-0)
#       ALTITUDE IN ALT METERS  B-29

                BANK    30
                SETLOC  LATLONG
                BANK

                COUNT   13/LT-LG

                EBANK=  ALPHAV
LAT-LONG        STQ     SETPD
                        INCORPEX
                        0D
                STOVL   6D              # SAVE TIME IN 6-7D FOR R-TO-RP
                        ALPHAV
                PUSH    ABVAL           # 0-5D= R FOR R-TO-RP
                STODL   ALPHAM          # ABS. VALUE OF R FOR ALT FORMULA BELOW
                        ZEROVEC         # SET MPAC=0 FOR EARTH, NON-ZERO FOR MOON
                BOFF    COS             # USE COS(0) TO GET NON-ZERO IN MPAC
                        LUNAFLAG        # 0=EARTH, 1=MOON
                        CALLRTRP
CALLRTRP        CALL
                        R-TO-RP         # RP VECTOR CONVERTED FROM R B-29
                UNIT                    # UNIT RP B-1
                STCALL  ALPHAV          # U2= 1/2 SINL FOR SETRE SUBR BELOW
                        SETGAMMA        #       SET GAMMA=B2/A2 FOR EARTH, =1 FOR MOON
                CALL                    #       SCALED B-1.
```

```
        SETRE           # CALC RE METERS B-29
DLOAD   DSQ
        ALPHAV
PDDL    DSQ
        ALPHAV +2
```

Uses -AYO 172, ALPHAM 177, ALPHAV 177, ALT 157, AXO 172, AZO 172, COUNT 142, EBANK 80, ERADFLAG 99, GAMMA 232, INCORPEX 177, L 80, LAT 157, LATITUDE 191, LATLONG 61, LONG 157, LUNAFLAG 107, MPAC 145, RAD 219, REVS 206, SAVE 191, TEPHEM 172, and U2 188.

1676 ⟨*Page CM1237* 1676⟩≡ (1674 2737)

```
DAD     SQRT
DMP     SL1R
        GAMRP
STODL   COSTH           # COS(LAT) B-1
        ALPHAV +4
STCALL  SINTH           # SIN(LAT) B-1
        ARCTAN
STODL   LAT             # LAT B0
        ALPHAV
STODL   COSTH           # COS(LONG) B-1
        ALPHAV +2
STCALL  SINTH           # SIN(LONG) B-1
        ARCTAN
STODL   LONG            # LONG. REVS B-0 IN RANGE -1/2 TO 1/2
        ALPHAM
DSU                     # ALT= R-RE METERS B-29
        ERADM
STCALL  ALT             # EXIT WITH ALT METERS B-29
        INCORPEX
```

Uses ALPHAM 177, ALPHAV 177, ALT 157, COSTH 148, ERADM 177, INCORPEX 177, LAT 157, LONG 157, RANGE 179, REVS 206, and SINTH 148.

1677 ⟨*Page CM1238* 1677⟩≡ (1674 2737)

```
# SUBROUTINE TO CONVERT LAT,LONG.ALT AT GIVEN TIME TO RADIUS VECTOR
#
# CALLING SEQUENCE
#       L-1     CALL
#       L               LALOTORV
#
# SUBROUTINES USED
#       SETGAMMA, SETRE, RP-TO-R
#
# ERASABLE INIT. REQ.
#       AXO, AYO, AZO, TEPHEM SET AT LAUNCH TIME
#       LAT -- LATITUDE         (REVS B0)
#       LONG -- LONGITUDE       (REVS B0)
#       ALT -- ALTITUDE         (METERS) B-29
#       MPAC -- TIME            (CSECS B-28)
#       ERADFLAG =1 TO COMPUTE EARTH RADIUS, =0 FOR FIXED EARTH RADIUS
#       LUNAFLAG=0 FOR EARTH, 1 FOR MOON
#
# OUTPUT
#       R-VECTOR IN ALPHAV      (METERS B-29)

LALOTORV        STQ     SETPD           # LAT,LONG,ALT TO R VECTOR
                        INCORPEX
                        0D
                STCALL  6D              #     6-7D = TIME FOR RP-TO-R
                        SETGAMMA        #    GAMMA = B2/A2 FOR EARTH, 1 FOR MOON B-1
                DLOAD   SIN             #           COS(LONG)COS(LAT) IN MPAC
                        LAT             # UNIT  RP = SIN(LONG)COS(LAT)    2-3D
                DMPR    PDDL            # PD 2      GAMMA*SIN(LAT)       0-1D
                        GAMRP
                        LAT             #     0-1D = GAMMA*SIN(LAT) B-2
                COS     PDDL            # PD4 2-3D= COS(LAT) B-1 TEMPORARILY
                        LONG
                SIN     DMPR            # PD 2
                PDDL    COS             # PD 4 2-3D= SIN(LONG)COS(LAT) B-2
                        LAT
                PDDL    COS             # PD 6 4-5D= COS(LAT) B-1 TEMPORARILY
                        LONG
                DMPR    VDEF            # PD4 MPAC = COS(LONG)COS(LAT) B-2
                UNIT    PUSH            #     0-5D = UNIT RP FOR RP-TO-R SUBR.
                STCALL  ALPHAV          # ALPHAV +4= SINL FOR SETRE SUBR.
                        SETRE           # RE METERS B-29
                DLOAD   BOFF            # SET MPAC = 0 FOR EARTH, NON-ZERO FOR MOON
                        ZEROVEC
                        LUNAFLAG
```

```
                        CALLRPRT
                COS                     # USE COS(0) TO GET NON-ZERO IN MPAC
CALLRPRT        CALL
                        RP-TO-R         # EXIT WITH UNIT R VECTOR IN MPAC
                STODL   ALPHAV
                        ERADM
```

Uses ALPHAV 177, ALT 157, AXO 172, AZO 172, ERADFLAG 99, ERADM 177, GAMMA 232, INCORPEX 177, L 80, LAT 157, LATITUDE 191, LONG 157, LUNAFLAG 107, MPAC 145, REVS 206, and TEPHEM 172.

1679 ⟨*Page CM1239* 1679⟩≡ (1674 2737)

```
                DAD     VXSC            # (RE + ALT)(UNIT R) METERS B-30
                        ALT
                        ALPHAV
                VSL1                    # R METERS B-29
                STCALL  ALPHAV          # EXIT WITH R IN METERS B-29
                        INCORPEX

# SUBROUTINE TO COMPUTE EARTH RADIUS
#
# INPUT
#       1/2 SIN LAT IN ALPHAV +4
#
# OUTPUT
#       EARTH RADIUS IN ERADM AND MPAC (METERS B-29)

GETERAD         DLOAD   DSQ
                        ALPHAV  +4      # SIN**2(L)
                SL1     BDSU
                        DP1/2           # COS**2(L)
                DMPR    BDSU
                        EE
                        DP1/2
                BDDV    SQRT
                        B2XSC
                SR4R
                STORE   ERADM
                        RVQ

# THE FOLLOWING CONSTANTS WERE COMPUTED WITH A=6378166, B=6356784 METERS
# B2XSC = B**2 SCALED B-51
# B2/A2 = B**2/A**2 SCALED B-1
# EE = (1-B**2/A**2) SCALED B-0

B2XSC           2DEC    .0179450689     # B**2 SCALED B-51

DP1/2           =       XUNIT
B2/A2           2DEC    .9933064884 B-1 # GAMMA= B**2/A**2 B-1

EE              2DEC    6.6935116 E-3   # (1-B**2/A**2) B-0

ERAD            2DEC    6373338 B-29    # PAD RADIUS
```

Uses A 80, ALPHAV 177, ALT 157, ERADM 177, GAMMA 232, INCORPEX 177, L 80, LAT 157, and MPAC 145.

1680 ⟨*Page CM1240* 1680⟩≡ (1674 2737)

```
# ARCTAN SUBROUTINE
#
# CALLING SEQUENCE
#       SIN THETA IN SINTH B-1
#       COS THETA IN COSTH B-1
#       CALL ARCTAN
#
# OUTPUT
#       ARCTAN THETA IN MPAC AND THETA B-0 IN RANGE -1/2 TO +1/2

ARCTAN          BOV
                        CLROVFLW
CLROVFLW        DLOAD   DSQ
                        SINTH
                PDDL    DSQ
                        COSTH
                DAD
                BZE     SQRT
                        ARCTANXX        # ATAN=0/0.  SET THETA=0
                BDDV    BOV
                        SINTH
                        ATAN=90
                SR1     ASIN
                STORE   THETA
                PDDL    BMN
                        COSTH
                        NEGCOS
                DLOAD   RVQ
NEGCOS          DLOAD   DCOMP
                BPL     DAD
                        NEGOUT
                        DP1/2
ARCTANXX        STORE   THETA
                RVQ

NEGOUT          DSU     GOTO
                        DP1/2
                        ARCTANXX
ATAN=90         DLOAD   SIGN
                        LODP1/4
                        SINTH
                STORE   THETA
                RVQ

2DZERO          =       DPZERO
```

Uses COSTH 148, LODP1/4 71, MPAC 145, RANGE 179, SINTH 148, and THETA 148.

1681 ⟨*Page CM1241* 1681⟩≡ (1674 2737)

```
# ***** SETGAMMA SUBROUTINE *****
# SUBROUTINE TO SET GAMMA FOR THE LAT-LONG AND LALOTORV SUBROUTINES
#
# GAMMA = B**2/A**2 FOR EARTH (B-1)
# GAMMA = 1 FOR MOON (B-1)
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             SETGAMMA
#
# INPUT
#       LUNAFLAG=0 FOR EARTH, =1 FOR MOON
#
# OUTPUT
#       GAMMA IN GAMRP (B-1)

SETGAMMA        DLOAD   BOFF            # BRANCH FOR EARTH
                        B2/A2           # EARTH GAMMA
                        LUNAFLAG
                        SETGMEX
                SLOAD
                        1B1             # MOON GAMMA
SETGMEX         STORE   GAMRP
                RVQ
GAMRP           =       8D
```

Uses A 80, GAMMA 232, L 80, LAT 157, LONG 157, and LUNAFLAG 107.

1682 ⟨*Page CM1242* 1682⟩≡ (1674 2737)

```
# ***** SETRE SUBROUTINE *****
# SUBROUTINE TO SET RE (EARTH OR MOON RADIUS)
#
#       RE = RM FOR MOON
#       RE = RREF FOR FIXED EARTH RADIUS OR COMPUTED RF FOR FISCHER ELLIPSOID
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             SETRE
#
# SUBROUTINES USED
#       CETERAD
#
# INPUT
#       ERADFLAG = 0 FOR FIXED RE, 1 FOR COMPUTED RE
#       ALPHAV +4 = 1/2 SINL IF GETERAD IS CALLED
#       LUNAFLAG = 0 FOR EARTH, =1 FOR MOON
#
# OUTPUT
#       ERADM = 504RM FOR MOON (METERS B-29)
#       ERADM = ERAD OR COMPUTED RE FOR EARTH (METERS B-29)

SETRE           STQ     DLOAD
                        SETREX
                        504RM
                BON     DLOAD           # BRANCH FOR MOON
                        LUNAFLAG
                        TSTRLSRM
                        ERAD
                BOFF    CALL            # ERADFLAG=0 FOR FIXED RE, 1 FOR COMPUTED
                        ERADFLAG
                        SETRXX
                        GETERAD
SETRXX          STCALL  ERADM           # EXIT WITH RE OR RM METERS B-29
                        SETREX
TSTRLSRM        BON     VLOAD           # ERADFLAG=0, SET R0=RLS
                        ERADFLAG        #         =1      R0=RM
                        SETRXX
                        RLS
                ABVAL   SR2R            # SCALE FROM B-27 TO B-29
                GOTO
                        SETRXX
SETREX          =       S2
504RM           2DEC    1738090 B-29    # METERS B-29 (MOON RADIUS)
```

Uses ALPHAV 177, ERADFLAG 99, ERADM 177, L 80, LUNAFLAG 107, RLS 175, RM 239, and S2 85.

3.7.10 planetary inertial orientation

1683 ⟨*planetary inertial orientation* 1683⟩≡ (1523a 2780)
⟨*Page CM1243* 1684⟩

1684 ⟨*Page CM1243* 1684⟩≡ (1683)

```
# Page 1243
# PLANETARY INERTIAL ORIENTATION
#
# ***** RP-TO-R SUBROUTINE *****
# SUBROUTINE TO CONVERT RP (VECTOR IN PLANETARY COORDINATE SYSTEM, EITHER
# EARTH-FIXED OR MOON-FIXED) TO R (SAME VECTOR IN BASIC REF. SYSTEM)
#       R = MT(T) * (RP + LP X RP)      MT = M MATRIX TRANSPOSE
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             RP-TO-R
#
# SUBROUTINES USED
#       EARTHMX, MOONMX, EARTHL
#
#       ITEMS AVAILABLE FROM LAUNCH DATA
#               504LM = THE LIBRATION VECTOR L OF THE MOON AT TIME TIMSUBL, EXPRESSED
#               IN THE MOON-FIXED COORD. SYSTEM         RADIANS B0
#
#       ITEMS NECESSARY FOR SUBR. USED (SEE DESCRIPTION OF SUBR.)
#
# INPUT
#       MPAC = 0 FOR EARTH, NON-ZERO FOR MOON
#       0-5D = RP VECTOR
#       6-7D = TIME
#
# OUTPUT
#       MPAC = R VECTOR METERS B-29 FOR EARTH, B-27 FOR MOON

                SETLOC  PLANTIN
                BANK

                COUNT*  $$/LUROT

RP-TO-R         STQ     BHIZ
                        RPREXIT
                        RPTORA
                CALL                    # COMPUTE M MATRIX FOR MOON
                        MOONMX          # LP=LM FOR MOON        RADIANS B0
                VLOAD
                        504LM
RPTORB          VXV     VAD
                        504RPR
                        504RPR
                VXM     GOTO
```

```
                        MMATRIX         # MPAC=R=MT(T)*(RP+LPXRP)
                        RPRPXXXX        # RESET PUSHLOC TO 0 BEFORE EXITING
RPTORA          CALL                    # EARTH COMPUTATIONS
                        EARTHMX         # M MATRIX B-1
                CALL
                        EARTHL          # L VECTOR RADIANS B0
                MXV     VSL1            # LP=M(T)*L     RAD B-0
                        MMATRIX
# Page 1244
                GOTO
                        RPTORB

# Page 1245
# ***** R-TO-RP SUBROUTINE *****
# SUBROUTINE TO CONVERT R (VECTOR IN REFERENCE COORD. SYSTEM) TO RP
# (VECTOR IN PLANETARY COORD SYSTEM) EITHER EARTH-FIXED OR MOON-FIXED
#       RP = M(T) * (R - L X R)
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             R-TO-RP
#
# SUBROUTINES USED
#       EARTHMX, MOONMX, EARTHL
#
# INPUT
#       MPAC = 0 FOR EARTH, NON-ZERO FOR MOON
#       0-5D = R VECTOR
#       6-7D = TIME
#
#       ITEMS AVAILABLE FROM LAUNCH DATA
#               504LM = THE LIBRATION VECTOR L OF THE MOON AT TIME TIMSUBL, EXPRESSED
#               IN THE MOON-FIXED COORD. SYSTEM                 RADIANS B0
#
#       ITEMS NECESSARY FOR SUBROUTINES USED (SEE DESCRIPTION OF SUBR.)
#
# OUTPUT
#       MPAC = RP VECTOR METERS B-29 FOR EARTH, B-27 FOR MOON

R-TO-RP         STQ     BHIZ
                        RPREXIT
                        RTORPA
                CALL
                        MOONMX
                VLOAD   VXM
                        504LM           # LP=LM
```

```
                        MMATRIX
                VSL1                    # L = MT(T)*LP          RADIANS B0
RTORPB          VXV     BVSU
                        504RPR
                        504RPR
                MXV                     # M(T)*(R-LXR)          B-2
                        MMATRIX
RPRPXXXX        VSL1    SETPD
                        0D
                GOTO
                        RPREXIT
RTORPA          CALL                    # EARTH COMPUTATIONS
                        EARTHMX
                CALL
                        EARTHL
                GOTO                    # MPAC=L=(-AX,-AY,0)    RAD B-0
                        RTORPB

# Page 1246
# ***** MOONMX SUBROUTINE *****
# SUBROUTINE TO COMPUTE THE TRANSFORMATION MATRIX M FOR THE MOON
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             MOONMX
#
# SUBROUTINES USED
#       NEWANGLE
#
# INPUT
#       6-7D = TIME
#
#       ITEMS AVAILABLE FROM LAUNCH DATA
#               BSUBO, BDOT
#               TIMSUBO, NODIO, NODDOT, FSUBO, FDOT
#               COSI = COS(I)   B-1
#               SINI = SIN(I)   B-1
#               I IS THE ANGLE BETWEEN THE MEAN LUNAR EQUATORIAL PLANE AND THE
#               PLANE OF THE ECLIPTIC (1 DEGREE 32.1 MINUTES)
#
# OUTPUT
#       MMATRIX = 3X3 M MATRIX          B-1 (STORED IN VAC AREA)

MOONMX          STQ     SETPD
                        EARTHMXX
                        8D
```

```
        AXT,1                   # B REQUIRES SL 0, SL 5 IN NEWANGLE
                5
        DLOAD   PDDL            # PD 10D        8-9D=BSUBO
                BSUBO           #               10-11D=BDOT
                BDOT
        PUSH    CALL            # PD 12D
                NEWANGLE        # EXIT WITH PD 8D AND MPAC= B   REVS B0
        PUSH    COS             # PD 10D
        STODL   COB             # PD 8D         COS(B) B-1
        SIN                     #               SIN(B) B-1
        STODL   SOB             #               SETUP INPUT FOR NEWANGLE
                FSUBO           #                       8-9D=FSUBO
        PDDL    PUSH            # PD 10D THEN 12D       10-11D=FDOT
                FDOT
        AXT,1   CALL            # F REQUIRES SL 1, SL 6 IN NEWANGLE.
                4
                NEWANGLE        # EXIT WITH PD 8D AND MPAC= F REVS B0
        STODL   AVECTR +2       # SAVE F TEMP
                NODIO           #                       8-9D=NODIO
        PDDL    PUSH            # PD 10D THEN 12D       10-11D=NODDOT
                NODDOT          #                       MPAC=5
        AXT,1   CALL            # NODE REQUIRES SL 0, SL 5 IN NEWANGLE
                5
                NEWANGLE        # EXIT WITH PD 8D AND MPAC= NODI REVS B0
# Page 1247
        PUSH    COS             # PD 10D        8-9D= NODI REVS B0
        PUSH                    # PD 12D        10-11D= COS(NODI) B-1
        STORE   AVECTR
        DMP     SL1R
                COB             #                       COS(NODI) B-1
        STODL   BVECTR +2       # PD 10D  20-25D=AVECTR=COB*SIN(NODI)
        DMP     SL1R            #                       SOB*SIN(NODI)
                SOB
        STODL   BVECTR +4       # PD 8D
        SIN     PUSH            # PD 10D                -SIN(NODI) B-1
        DCOMP                   #         26-31D=BVECTR=COB*COS(NODI)
        STODL   BVECTR          # PD 8D                 SOB*COS(NODI)
                AVECTR +2       # MOVE F FROM TEMP LOC. TO 504F
        STODL   504F
        DMP     SL1R
                COB
        STODL   AVECTR +2
                SINNODI         # 8-9D=SIN(NODI) B-1
        DMP     SL1R
                SOB
        STODL   AVECTR +4       #                       0
```

```
                        HI6ZEROS        #       8-13D= CVECTR=  -SOB B-1
                PDDL    DCOMP           # PD 10D                COB
                        SOB
                PDDL    PDVL            # PD 12D THEN PD 14D
                        COB
                        BVECTR
                VXSC    PDVL            # PD 20D        BVECTR*SINI B-2
                        SINI
                        CVECTR
                VXSC    VAD             # PD 14D        CVECTR*COSI B-2
                        COSI
                VSL1
                STOVL   MMATRIX +12D    # PD 8D  M2=BVECTR*SINI+CVECTR*COSI B-1
                VXSC    PDVL            # PD 14D
                        SINI            #               CVECTR*SINI B-2
                        BVECTR
                VXSC    VSU             # PD 8D         BVECTR*COSI B-2
                        COSI
                VSL1    PDDL            # PD 14D
                        504F            # 8-13D=DVECTR=BVECTR*COSI-CVECTR*SINI B-1
                COS     VXSC
                        DVECTR
                PDDL    SIN             # PD 20D  14-19D= DVECTR*COSF B-2
                        504F
                VXSC    VSU             # PD 14D        AVECTR*SINF B-2
                        AVECTR
                VSL1
                STODL   MMATRIX +6      # M1= AVECTR*SINF-DVECTR*COSF B-1
                        504F
# Page 1248
                SIN     VXSC            # PD 8D
                PDDL    COS             # PD 14D  8-13D=DVECTR*SINF B-2
                        504F
                VXSC    VAD             # PD 8D         AVECTR*COSF B-2
                        AVECTR
                VSL1    VCOMP
                STCALL  MMATRIX         # M0= -(AVECTR*COSF+DVECTR*SINF) B-1
                        EARTHMXX

# COMPUTE X=X0+(XDOT)(T+T0)
# 8-9D= X0 (REVS B-0), PUSHLOC SET AT 12D
# 10-11D=XDOT (REVS/CSEC) SCALED B+23 FOR WEARTH,B+28 FOR NODDOT AND BDOT
#                         AND B+27 FOR FDOT
# X1=DIFFERENCE IN 23 AND SCALING OF XDOT, =0 FOR WEARTH, 5 FOR NDDOT AND
#                                         BDOT AND 4 FOR FDOT
# 6-7D=T (CSEC B-28), TIMSUB0= (CSEC B-42 TRIPLE PREC.)
```

```
NEWANGLE        DLOAD   SR              # ENTER PD 12D
                        6D
                        14D
                TAD     TLOAD           # CHANGE MODE TO TP
                        TIMSUBO
                        MPAC
                STODL   TIMSUBM         # T+T0 CSEC B-42
                        TIMSUBM +1
                DMP                     # PD 10D        MULT BY XDOT IN 10-11D
                SL*     DAD             # PD 8D         ADD X0 IN 8-9D AFTER SHIFTING
                        5,1             #               SUCH THAT SCALING IS B-0
                PUSH    SLOAD           # PD 10D  SAVE PARTIAL (X0+XDOT*T) IN 8-9D
                        TIMSUBM
                SL      DMP
                        9D
                        10D             # XDOT
                SL*     DAD             # PD 8D         SHIFT SUCH THAT THIS PART OF X
                        10D,1           #               IS SCALED REVS/CSEC B-0
                BOV                     # TURN OFF OVERFLOW IF SET BY SHIFT
                        +1              # INSTRUCTION BEFORE EXITING.
                RVQ                     # MPAC=X= X0+(XDOT)(T+T0)       REVS B0

# Page 1249
# ***** EARTHMX SUBROUTINE *****
# SUBROUTINE TO COMPUTE THE TRANSFORMATION MATRIX M FOR THE EARTH
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             EARTHMX
#
# SUBROUTINE USED
#       NEWANGLE
#
# INPUT
#       INPUT AVAILABLE FROM LAUNCH DATA        AZO REVS B-0
#                                               TEPHEM CSEC B-42
#       6-7D= TIME CSEC B-28
#
# OUTPUT
#       MMATRIX= 3X3 M MATRIX B-1 (STORED IN VAC AREA)

EARTHMX         STQ     SETPD           # SET 8-9D=AZO
                        EARTHMXX
                        8D              # 10-11D=WEARTH
                AXT,1                   # FOR SL 5, AND SL 10 IN NEWANGLE
```

```
                        0
                DLOAD   PDDL            # LEAVING PD SET AT 12D FOR NEWANGLE
                        AZO
                        WEARTH
                PUSH    CALL
                        NEWANGLE
                SETPD   PUSH            # 18-19D=504AZ
                        18D             #                        COS(AZ)   SIN(AZ)
                COS     PDDL            # 20-37D=  MMATRIX=     -SIN(AZ)   COS(AZ)
                        504AZ           #                           0         0
                SIN     PDDL
                        HI6ZEROS
                PDDL    SIN
                        504AZ
                DCOMP   PDDL
                        504AZ
                COS     PDVL
                        HI6ZEROS
                PDDL    PUSH
                        HIDPHALF
                GOTO
                        EARTHMXX

# Page 1250
# ***** EARTHL SUBROUTINE *****
# SUBROUTINE TO COMPUTE L VECTOR FOR EARTH
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             EARTHL
#
# INPUT
#       AXO,AYO SET AT LAUNCH TIME WITH AYO IMMEDIATELY FOLLOWING AXO IN CORE
#
# OUTPUT
#               -AX
#       MPAC=   -AY     RADIANS B-0
#                 0

EARTHL          DLOAD   DCOMP
                        AXO
                STODL   504LPL
                        -AYO
                STODL   504LPL +2
                        HI6ZEROS
                STOVL   504LPL +4
```

```
                        504LPL
                RVQ

  # Page 1251
  # CONSTANTS AND ERASABLE ASSIGNMENTS

  1B1           =       DP1/2           # 1 SCALED B-1
  COSI          2DEC    .99964173 B-1   # COS(5521.5 SEC) B-1

  SINI          2DEC    .02676579 B-1   # SIN(5521.T SEC) B-1

  RPREXIT       =       S1              # R-TO-RP AND RP-TO-R SUBR EXIT
  EARTHMXX      =       S2              # EARTHMX, MOONMX SUBR. EXITS
  504RPR        =       0D              # 6 REGS        R OR RP VECTOR
  SINNODI       =       8D              # 2             SIN(NODI)
  DVECTR        =       8D              # 6             D VECTOR MOON
  CVECTR        =       8D              # 6             C VECTR MOON
  504AZ         =       18D             # 2             AZ
  TIMSUBM       =       14D             # 3             TIME SUB M (MOON) T+10 IN GETAZ
  504LPL        =       14D             # 6             L OR LP VECTOR
  AVECTR        =       20D             # 6             A VECTOR (MOON)
  BVECTR        =       26D             # 6             B VECTOR (MOON)
  MMATRIX       =       20D             # 18            M MATRIX
  COB           =       32D             # 2             COS(B) B-1
  SOB           =       34D             # 2             SIN(B) B-1
  504F          =       6D              # 2             F(MOON)
  NODDOT        2DEC    -.457335121 E-2 # REVS/CSEC B+28=-1.07047011 E-8  RAD/SEC

  FDOT          2DEC    .570863327      # REVS/CSEC B+27= 2.67240410 E-6  RAD/SEC

  BDOT          2DEC    -3.07500686 E-8 # REVS/CSEC B+28=-7.19757301 E-14 RAD/SEC

  NODIO         2DEC    .986209434      # REVS B-0      = 6.19653663041   RAD

  FSUBO         2DEC    .829090536      # REVS B-0      = 5.20932947829   RAD

  BSUBO         2DEC    .0651201393     # REVS B=0      = 0.40916190299   RAD

  WEARTH        2DEC    .973561595      # REVS/CSEC B+23= 7.29211494 E-5  RAD/SEC
```

Uses -AYO 172, 504LM 175, A 80, AXO 172, AZO 172, COUNT 142, D 226, F 238, HI6ZEROS 71, HIDPHALF 71, I 206, L 80, LOC 145, MODE 145, MPAC 145, PLANTIN 65, PUSHLOC 145, RAD 219, REVS 206, S1 85, S2 85, SAVE 191, SR 80, TEMP 191, TEPHEM 172, TIMSUBO 174, and X1 85.

3.7.11 measurement incorporation

1692 ⟨*measurement incorporation* 1692⟩≡ (1523a)

⟨*Page CM1252* 1693⟩
⟨*Page CM1253* 1695⟩
⟨*Page CM1254* 1697⟩
⟨*Page CM1255* 1698⟩
⟨*Page CM1256* 1699⟩
⟨*Page CM1257* 1701⟩
⟨*Page CM1258* 1703⟩
⟨*Page CM1259* 1705⟩
⟨*Page CM1260* 1707⟩
⟨*Page CM1261* 1709⟩

1693 ⟨*Page CM1252* 1693⟩≡ (1692 2746)

```
# INCORP1 -- PERFORMS THE SIX DIMENSIONAL STATE VECTOR DEVIATION FOR POSITION
# AND VELOCITY OR THE NINE-DIMENSIONAL DEVIATION OF POSITION, VELOCITY, AND
# RADAR OR LANDMARK BIAS.  THE OUTPUT OF THE BVECTOR ROUTINE ALONG WITH THE
# ERROR TRANSITION MATRIX (W) ARE USED AS INPUT TO THE ROUTINE.  THE DEVIATION
# IS OBTAINED BY COMPUTING AN ESTIMATED TRACKING MEASUREMENT FROM THE
# CURRENT STATE VECTOR AND COMPARING IT WITH AN ACTUAL TRACKING MEASUREMENT
# AND APPLYING A STATISTICAL WEIGHTING VECTOR.
#
# INPUT
#        DMENFLG = 0 (6-DIMENSIONAL BVECTOR), =1 (9-DIMENSIONAL)
#              W = ERROR TRANSITION MATRIX 6X6 OR 9X9
#       VARIANCE = VARIANCE (SCALAR)
#         DELTAQ = MEASURED DEVIATION (SCALAR)
#        BVECTOR = 6 OR 9 DIMENSIONAL BVECTOR
#
# OUTPUT
#         DELTAX = STATE VECTOR DEVIATIONS 6 OR 9 DIMENSIONAL
#             ZI = VECTOR USED FOR THE INCORPORATION 6 OR 9 DIMENSIONAL
#          GAMMA = SCALAR
#          OMEGA = OMEGA WEIGHTING VECTOR 6 OR 9 DIMENSIONAL
#
# CALLING SEQUENCE
#       L       CALL    INCORP1
#
# NORMAL EXIT
#       L+1 OF CALLING SEQUENCE

                BANK    37
                SETLOC  MEASINC
                BANK

                COUNT*  $$/INCOR

                EBANK=  W

INCORP1         STQ
                        EGRESS
                AXT,1   SSP
                        54D
                        S1
                        18D             # IX1 = 54      S1= 18
                AXT,2   SSP
                        18D
                        S2
                        6               # IX2 = 18      S2=6
```

```
Z123            VLOAD   MXV*
                        BVECTOR         # BVECTOR (0)
                        W       +54D,1
                STORE   ZI      +18D,2
                VLOAD
                        BVECTOR +6      # BVECTOR (1)
```

Uses A 80, BIAS 211, BVECTOR 232, COUNT 142, DELTAQ 232, DELTAX 161, DMENFLG 115, EBANK 80, EGRESS 179, GAMMA 232, IT 185, L 80, LANDMARK 190, MEASINC 69, OMEGA 232, S1 85, S2 85, STATE 138, VARIANCE 232, W 183, and ZI 190.

1695 ⟨*Page CM1253* 1695⟩≡ (1692 2746)

```
                MXV*    VAD*
                        W +108D,1
                        ZI +18D,2
                STORE   ZI +18D,2
                VLOAD
                        BVECTOR +12D    # BVECTOR (2)
                MXV*    VAD*
                        W       +162D,1
                        ZI      +18D,2  # B(0)*W+B(1)*(W+54)+B(2)*(W+108) FIRST PASS
                STORE   ZI      +18D,2  # ZI THEN Z2 THEN Z3
                TIX,1
                        INCOR1
INCOR1          TIX,2   BON
                        Z123            # LOOP FOR Z1,Z2,Z3
                        DMENFLG
                        INCOR1A
                VLOAD
                        ZEROVECS
                STORE   ZI      +12D
INCOR1A         SETPD   VLOAD
                        0
                        ZI
                VSQ     RTB
                        TPMODE
                PDVL    VSQ
                        ZI      +6
                RTB     TAD
                        TPMODE
                PDVL    VSQ
                        ZI      +12D
                RTB     TAD
                        TPMODE
                TAD     AXT,2
                        VARIANCE
                        0
                STORE   TRIPA           # ZI*2 + Z2*2 + Z3*2 + VARIANCE
                TLOAD   BOV
                        VARIANCE        # CLEAR OVFIND
                        +1
                STORE   TEMPVAR         # TEMP STORAGE FOR VARIANCE
                BZE
                        INCOR1C
INCOR1B         SL2     BOV
                        INCOR1C
                STORE   TEMPVAR
```

```
                INCR,2  GOTO
                DEC     1
                        INCOR1B
INCOR1C         TLOAD   ROUND
                        TRIPA
```

Uses BVECTOR 232, DMENFLG 115, OVFIND 140, TEMP 191, TEMPVAR 161, TRIPA 161, VARIANCE 232, W 183, and ZI 190.

1697 ⟨*Page CM1254* 1697⟩≡ (1692 2746)

```
                DMP     SQRT
                        TEMPVAR
                SL*     TAD
                        0,2
                        TRIPA
                NORM    INCR,2
                        X2
                DEC     -2
                SXA,2   AXT,2
                        NORMGAM         # NORMALIZATION COUNT -2 FOR GAMMA
                        162D
                BDDV    SETPD
                        DP1/4TH
                        0
                STORE   GAMMA
                TLOAD   NORM
                        TRIPA
                        X1
                DLOAD   PDDL            # PD 0-1 = NORM (A)
                        MPAC
                        DELTAQ
                NORM
                        S1
                XSU,1   SR1
                        S1
                DDV     PUSH            # PD 0-1 = DELTAQ/A
                GOTO
                        NEWZCOMP
        -3      SSP
                        S2
                        54D
INCOR2          VLOAD   VXM*            # COMPUT OMEGA1,2,3
                        ZI
                        W       +162D,2
                PUSH    VLOAD
                        ZI      +6
                VXM*    VAD
                        W       +180D,2
                PUSH    VLOAD
                        ZI      +12D
                VXM*    VAD
                        W       +198D,2
                PUSH    TIX,2           # PD 2-7=OMEGA1, 8-13=OMEGA2, 14-19=OMEGA3
                        INCOR2
                VLOAD   STADR
```

```
                STORE   OMEGA   +12D
                VLOAD   STADR
                STORE   OMEGA   +6
                VLOAD   STADR
                STORE   OMEGA
```

Uses A 80, COUNT 142, DELTAQ 232, GAMMA 232, MPAC 145, NORMGAM 177, OMEGA 232, S1 85, S2 85, TEMPVAR 161, TRIPA 161, W 183, X1 85, X2 85, and ZI 190.

1698 ⟨*Page CM1255* 1698⟩≡ (1692 2746)

```
                BON     VLOAD
                        DMENFLG
                        INCOR2AB
                        ZEROVECS
                STORE   OMEGA   +12D
  INCOR2AB      AXT,2   SSP
                        18D
                        S2
                        6
  INCOR3        VLOAD*
                        OMEGA   +18D,2
                VXSC    VSL*
                        0               # DELTAQ/A
                        0,1
                STORE   DELTAX  +18D,2
                TIX,2   VLOAD
                        INCOR3
                        DELTAX  +6
                VSL3
                STORE   DELTAX  +6
                GOTO
                        EGRESS
```

Uses A 80, DELTAQ 232, DELTAX 161, DMENFLG 115, EGRESS 179, OMEGA 232, and S2 85.

1699 ⟨*Page CM1256* 1699⟩≡ (1692 2746)

```
# INCORP2 -- INCORPORATES THE COMPUTED STATE VECTOR DEVIATIONS INTO THE
# ESTIMATED STATE VECTOR.  THE STATE VECTOR UPDATED MAY BE FOR EITHER THE
# LEM OR THE CSM.  DETERMINED BY FLAG VEHUPFLG.  (ZERO = LEM) (1 = CSM)
#
# INPUT
#       PERMANENT STATE VECTOR FOR EITHER THE LEM OR CSM
#       VEHUPFLG = UPDATE VEHICLE C=LEM 1=CSM
#       W = ERROR TRANSITION MATRIX
#       DELTAX = COMPUTED STATE VECTOR DEVIATIONS
#       DMENFLG = SIZE OF W MATRIX (ZERO=6X6) (1=9X9)
#       GAMMA = SCALAR FOR INCORPORATION
#       ZI = VECTOR USED IN INCORPORATION
#       OMEGA = WEIGHTING VECTOR
#
# OUTPUT
#       UPDATED PERMANENT STATE VECTOR
#
# CALLING SEQUENCE
#       L       CALL    INCORP2
#
# NORMAL EXIT
#       L+1 OF CALLING SEQUENCE
#

                SETLOC  MEASINC1
                BANK

                COUNT*  $$/INCOR

INCORP2         STQ     CALL
                        EGRESS
                        INTSTALL
                VLOAD   VXSC            # CALC. GAMMA*OMEGA1,2,3
                        OMEGA
                        GAMMA
                STOVL   OMEGAM1
                        OMEGA +6
                VXSC
                        GAMMA
                STOVL   OMEGAM2
                        OMEGA +12D
                VXSC
                        GAMMA
                STORE   OMEGAM3
                EXIT
```

```
                CAF     54DD            # INITIAL IX 1 SETTING FOR W MATRIX
                TS      WIXA
                TS      WIXB
                CAF     ZERO
                TS      ZIXA            # INITIAL IX 2 SETTING FOR Z COMPONENT
                TS      ZIXB
FAZA            TC      PHASCHNG
```

Uses COUNT 142, DELTAX 161, DMENFLG 115, EGRESS 179, GAMMA 232, L 80, MEASINC1 69, OMEGA 232, OMEGAM1 190, OMEGAM2 190, OMEGAM3 190, STATE 138, TC 169, VEHUPFLG 99, W 183, WIXA 161, WIXB 161, Z 80, ZI 190, ZIXA 161, and ZIXB 161.

1701 ⟨*Page CM1257* 1701⟩≡ (1692 2746)

```
                OCT     04022
                TC      UPFLAG
                ADRES   REINTFLG
  FAZA1         CA      WIXB            # START FIRST PHASE OF INCORP2
                TS      WIXA            # TO UPDATE 6 OR 9 DIM. W MATRIX IN TEMP
                CA      ZIXB
                TS      ZIXA
                TC      INTPRET
                LXA,1   LXA,2
                        WIXA
                        ZIXA
                SSP     DLOAD*
                        S1
                        6
                        ZI,2
                DCOMP   NORM            # CALC UPPER 3X9 PARTITION OF W MATRIX
                        S2
                VXSC    XCHX,2
                        OMEGAM1
                        S2
                LXC,2   XAD,2
                        X2
                        NORMGAM
                VSL*    XCHX,2
                        0,2
                        S2
                VAD*
                        W +54D,1
                STORE   HOLDW
                DLOAD*  DCOMP           # CALC MIDDLE 3X9 PARTITION OF W MATRIX
                        ZI,2
                NORM    VXSC
                        S2
                        OMEGAM2
                XCHX,2  LXC,2
                        S2
                        X2
                XAD,2   VSL*
                        NORMGAM
                        0,2
                XCHX,2  VAD*
                        S2
                        W +108D,1
                STORE   HOLDW +6
                BOFF
```

```
        DMENFLG         # BRANCH IF 6 DIMENSIONAL
        FAZB
DLOAD*  DCOMP           # CALC LOWER 3X9 PARTITION OF W MATRIX
        ZI,2
NORM    VXSC
```

Uses DMENFLG 115, HOLDW 190, NORMGAM 177, OMEGAM1 190, OMEGAM2 190, REINTFLG 135, S1 85, S2 85, TC 169, TEMP 191, W 183, WIXA 161, WIXB 161, X2 85, ZI 190, ZIXA 161, and ZIXB 161.

1703 ⟨*Page CM1258* 1703⟩≡ (1692 2746)

```
                        S2
                        OMEGAM3
                XCHX,2  LXC,2
                        S2
                        X2
                XAD,2   VSL*
                        NORMGAM
                        0,2
                XCHX,2  VAD*
                        S2
                        W +162D,1
                STORE   HOLDW +12D
FAZB            CALL
                        GRP2PC
                EXIT
FAZB1           CA      WIXA            # START 2ND PHASE OF INCORP2 TO TRANSFER
                AD      6DD             #       TEMP REG TO PERM W MATRIX
                TS      WIXB
                CA      ZIXA
                AD      MINUS2
                TS      ZIXB
                TC      INTPRET
                LXA,1   SSP
                        WIXA
                        S1
                        6
                VLOAD
                        HOLDW
                STORE   W +54D,1
                VLOAD
                        HOLDW +6
                STORE   W +108D,1
                BOFF    VLOAD
                        DMENFLG
                        FAZB5
                        HOLDW +12D
                STORE   W +162D,1
FAZB2           TIX,1   GOTO
                        +2
                        FAZC            # DONE WITH W MATRIX.  UPDATE STATE VECTOR
                RTB
                        FAZA
FAZB5           SLOAD   DAD
                        ZIXB
                        12DD
```

```
                BHIZ    GOTO
                        FAZC
                        FAZB2
FAZC            CALL
                        GRP2PC
```

Uses DMENFLG 115, HOLDW 190, NORMGAM 177, OMEGAM3 190, S1 85, S2 85, STATE 138, TC 169, TEMP 191, W 183, WIXA 161, WIXB 161, X2 85, ZIXA 161, and ZIXB 161.

1705 ⟨*Page CM1259* 1705⟩≡ (1692 2746)

```
                VLOAD   VAD             # START 3RD PHASE OF INCORP2
                        X789            # 7TH,8TH,9TH,COMPONENT OF STATE VECTOR
                        DELTAX  +12D    # INCORPORATION FOR X789
                STORE   TX789
                BON     RTB
                        VEHUPFLG
                        DOCSM
                        MOVEPLEM
FAZAB           BOVB    AXT,2
                        TCDANZIG
                        0
                BOFF    AXT,2
                        MOONTHIS
                        +2
                        2
                VLOAD   VSR*
                        DELTAX          # B27 IF MOON ORBIT, B29 IF EARTH
                        0 -7,2
                VAD     BOV
                        TDELTAV
                        FAZAB1
                STOVL   TDELTAV
                        DELTAX  +6      # B5 IF MOON ORBIT, B7 IF EARTH
                VSR*    VAD
                        0 -4,2
                        TNUV
                BOV
                        FAZAB2
                STCALL  TNUV
                        FAZAB3
FAZAB1          VLOAD   VAD
                        RCV
                        DELTAX
                STORE   RCV
FAZAB2          VLOAD   VAD
                        VCV
                        DELTAX  +6
                STORE   VCV
                SXA,2   CALL
                        PBODY
                        RECTIFY
FAZAB3          CALL
                        GRP2PC
                BON     RTB
                        VEHUPFLG
```

```
                        DOCSM1
                        MOVEALEM
                CALL
                        SVDWN2          # STORE DOWNLINK STATE VECTOR
FAZAB4          CALL
```

Uses DELTAX 161, MOONTHIS 71, PBODY 177, RCV 169, STATE 138, TDELTAV 169, TNUV 169, TX789 232, VCV 169, VEHUPFLG 99, and X789 172.

1707 ⟨*Page CM1260* 1707⟩≡ (1692 2746)

```
                        GRP2PC          # PHASE CHANGE
                BOFF    VLOAD
                        DMENFLG
                        FAZAB5          # 6 DIMENSIONAL
                        TX789           # 9 DIMENSIONAL
                STORE   X789
FAZAB5          LXA,1   SXA,1
                        EGRESS
                        QPRET
                EXIT
                TC      POSTJUMP        # EXIT
                CADR    INTWAKE
DOCSM           RTB     GOTO
                        MOVEPCSM
                        FAZAB
DOCSM1          RTB     CALL
                        MOVEACSM
                        SVDWN1          # STORE DOWNLINK STATE VECTOR
                GOTO
                        FAZAB4
ZEROD           =       ZEROVECS
54DD            DEC     54
6DD             DEC     -6
12DD            DEC     12
                SETLOC  MEASINC2
                BANK
                COUNT*  $$/INCOR

NEWZCOMP        VLOAD   ABVAL
                        ZI
                STOVL   NORMZI
                        ZI +6
                ABVAL   PUSH
                DSU     BMN
                        NORMZI
                        +3
                DLOAD   STADR
                STORE   NORMZI
                VLOAD   ABVAL
                        ZI +12D
                PUSH    DSU
                        NORMZI
                BMN     DLOAD
                        NEWZCMP1
                STADR
```

```
STCALL  NORMZI          # LARGEST ABVAL
        NEWZCMP1

SETLOC  MEASINC3
BANK
```

Uses COUNT 142, DMENFLG 115, EGRESS 179, MEASINC2 61, MEASINC3 69, QPRET 85, STATE 138, TC 169, TX789 232, X789 172, and ZI 190.

1709 ⟨*Page CM1261* 1709⟩≡ (1692 2746)

```
NEWZCMP1                DLOAD   SXA,1
                        NORMZI
                        NORMZI          # SAVE X1
                NORM    INCR,1
                        X1
                DEC     2
                VLOAD   VSL*
                        ZI
                        0,1
                STOVL   ZI
                        ZI +6
                VSL*
                        0,1
                STOVL   ZI +6
                        ZI +12D
                VSL*    SXA,1
                        0,1
                        NORMZI +1       # SAVE SHIFT
                STORE   ZI +12D
                LXA,1   XSU,1
                        NORMGAM
                        NORMZI +1
                XSU,1
                        NORMZI +1
                SXA,1   LXC,1
                        NORMGAM
                        NORMZI +1
                XAD,1   SETPD
                        NORMZI
                        2D
                GOTO
                        INCOR2 -3
NORMZI          =       36D
```

Uses NORMGAM 177, SAVE 191, X1 85, and ZI 190.

3.7.12 conic subroutines

1710 ⟨*conic subroutines* 1710⟩≡ (1523a)

```
# Page 1262
⟨Page CM1262 1712⟩
# Page 1263
⟨Page CM1263 1713⟩
# Page 1264
⟨Page CM1264 1714⟩
# Page 1265
⟨Page CM1265 1715⟩
# Page 1266
⟨Page CM1266 1716⟩
# Page 1267
⟨Page CM1267 1717⟩
# Page 1268
⟨Page CM1268 1718⟩
# Page 1269
⟨Page CM1269 1719⟩
# Page 1270
⟨Page CM1270 1720⟩
# Page 1271
⟨Page CM1271 1721⟩
# Page 1272
⟨Page CM1272 1722⟩
# Page 1273
⟨Page CM1273 1723⟩
# Page 1274
⟨Page CM1274 1724⟩
# Page 1275
⟨Page CM1275 1725⟩
# Page 1276
⟨Page CM1276 1726⟩
# Page 1277
⟨Page CM1277 1727⟩
# Page 1278
⟨Page CM1278 1729⟩
# Page 1279
⟨Page CM1279 1731⟩
# Page 1280
⟨Page CM1280 1733⟩
# Page 1281
⟨Page CM1281 1735⟩
# Page 1282
⟨Page CM1282 1736⟩
# Page 1283
```

⟨*Page CM1283* 1737⟩
Page 1284
⟨*Page CM1284* 1738⟩
Page 1285
⟨*Page CM1285* 1739⟩
Page 1286
⟨*Page CM1286* 1740⟩
Page 1287
⟨*Page CM1287* 1741⟩
Page 1288
⟨*Page CM1288* 1742⟩
Page 1289
⟨*Page CM1289* 1743⟩
Page 1290
⟨*Page CM1290* 1744⟩
Page 1291
⟨*Page CM1291* 1745⟩
Page 1292
⟨*Page CM1292* 1746⟩
Page 1293
⟨*Page CM1293* 1748⟩
Page 1294
⟨*Page CM1294* 1750⟩
Page 1295
⟨*Page CM1295* 1751⟩
Page 1296
⟨*Page CM1296* 1752⟩
Page 1297
⟨*Page CM1297* 1754⟩
Page 1298
⟨*Page CM1298* 1756⟩
Page 1299
⟨*Page CM1299* 1758⟩
Page 1300
⟨*Page CM1300* 1759⟩
Page 1301
⟨*Page CM1301* 1760⟩
Page 1302
⟨*Page CM1302* 1762⟩
Page 1303
⟨*Page CM1303* 1763⟩
Page 1304
⟨*Page CM1304* 1764⟩
Page 1305
⟨*Page CM1305* 1765⟩
Page 1306

⟨*Page CM1306* 1767⟩
Page 1307
⟨*Page CM1307* 1769⟩
Page 1308
⟨*Page CM1308* 1770⟩

1712 ⟨*Page CM1262* 1712⟩≡ (1710 2662)

```
# PROGRAM DESCRIPTION -- ENTIRE CONIC SUBROUTINE LOG SECTION    DATE -- 1 SEPTEMBER 1
# MOD NO. -- 0                                                 LOG SECTION -- CONIC
# MOD BY KRAUSE                                                ASSEMBLY -- COLOSSUS
#
# FUNCTIONAL DESCRIPTION --
#       THE FOLLOWING SET OF SUBROUTINES SOLVE VARIOUS PROBLEMS INVOLVING THE TRAJECT
#       INVERSE-SQUARE FORCE ACTING ON A POINT MASS, AS OUTLINED IN THE CMC AND LGC I
#       5.5.1.2.  A GENERAL USAGE POINT-OF-VIEW WAS TAKEN IN FORMULATING, MECHANIZING
#       RATHER THAN OPTIMIZING EACH FOR A PARTICULAR USE.  THEREFORE, MULTIPLE USAGE
#       INVOLVING ANY REALISTIC SET OF CONSTRAINTS.  IT SHOULD BE NOTED THAT ONLY ONE
#       EARTH, MOON, OR ANY OTHER CELESTIAL BODY IS SPECIFIED AS THE CENTRAL BODY OF
#       THE INHERENT SCALE CHANGE REQUIRED IN POSITION, VELOCITY, MU, AND TIME, AS OU
#       DEFINITION MEMO NO. 10.  THIS CAN BE ACCOMPLISHED BY SIMPLY ADDING TO THE MUT
#       APPROPRIATELY.
#
#       DUE TO THE UNIFORMITY OF THE EQUATIONS INVOLVED, CODING WAS MINIMIZED BY TREA
#       BLOCKS OF EQUATIONS AS SUBROUTINES OF LOWER RANK WHENEVER POSSIBLE.  AS A RES
#       DIRECTLY USABLE AS INDEPENDENT SUBROUTINES, WERE GENERATED.
#
# RESTRICTIONS --
#       THE ONLY LIMITATION IN THE SCOPE OF THE PROBLEM WHICH CAN BE SOLVED BY A PART
#       LIMIT OF EACH PARAMETER AS SPECIFIED IN THE GSOP.  THESE SCALING LIMITS WERE
#       COULD BE HANDLED.
#
#       SINCE THE SUBROUTINES (EXCEPT KEPLER) USE COMMON SUBROUTINES OF LOWER RANK WH
#       THE PUSHLIST (DUE TO ITS LIMITED SIZE) AND COMMON INTERPRETIVE SWITCHES, THE
#       TO INTERRUPT EACH OTHER.  IT IS UP TO THE USER TO GUARANTEE THIS CONDITION.
```

Uses A 80, IT 185, and MASS 200.

1713 ⟨*Page CM1263* 1713⟩≡ (1710 2662)

```
# PROGRAM DESCRIPTION -- KEPLER SUBROUTINE                    DATE -- 11 OCTOBER 1967
# MOD NO. -- 1                                                LOG SECTION -- CONIC SUBROUTINE
# MOD BY KRAUSE                                               ASSEMBLY -- COLOSSUS 103 AND SU
# MOD NO. -- 2 (AUGUST 1968) BY ROBERTSON: TO PERMIT BACKDATING BY MORE THAN ONE ORBITAL PERIOD
# MOD NO. -- 3 (DEC 1968) BY ROBERTSON: SUPPRESSION OF X-MODULO-ING
# MOD NO. -- 4 (JAN 1969) BY ROBERTSON: CLEAR OVFIND AT KEPLER ENTRY
#
# FUNCTIONAL DESCRIPTION --
#       THIS SUBROUTINE, GIVEN AN INITIAL STATE VECTOR AND THE DESIRED TRANSFER TIME THROUGH WH
#       BE UPDATED ALONG A CONIC TRAJECTORY, COMPUTES THE NEW, UPDATED STATE VECTOR.  THE TRAJE
#       SECTION -- CIRCULAR, ELLIPTIC, PARABOLIC, HYPERBOLIC, OR RECTILINEAR WITH RESPECT TO TH
#       USE OF THE SUBROUTINE CAN BE EXTENDED USING OTHER PRIMARY BODIES BY SIMPLE ADDITIONS TO
#       INTRODUCING ANY CODING CHANGES, ACCEPTING THE INHERENT SCALE FACTOR CHANGES IN POSITION
#       TECHNIQUE IS UTILIZED IN THE COMPUTATION.
#
#       IF A NEGATIVE TIME-OF-FLIGHT IS INPUT, THE PROGRAM WILL SOLVE FOR THE STATE WHICH WOULD
#       EXTRAPOLATING THE POSITION BACKWARD IN TIME.
#
#       IF THE ABSOLUTE VALUE DESIRED TRANSFER TIME EXCEEDS THE ORBITAL PERIOD, THE SUBROUTINE,
#       MODULAR TECHNIQUE, WILL COMPUTE THE STATE CORRESPONDING TO THE DESIRED TIME AS USUAL.
#
# THE RESTRICTIONS ARE --
#       1.      (PREVIOUS RESTRICTION ON THE NEGATIVE DESIRED TRANSFER TIME IS NOW DELETED.)
#       2.      THE PARAMETERS IN THE PROBLEM CANNOT EXCEED THEIR SCALING LIMITS AS SPECIFIED I
#               ANY OF THESE LIMITS ARE EXCEEDED, THE RESULTING SOLUTION WILL BE MEANINGLESS.
#
#       THE NUMBER OF ITERATIONS AND, THEREFORE, THE COMPUTATION SPEED IS DEPENDENT ON THE ACCU
#       GUESS, XKFPNEW.  THE AGC COMPUTATION TIME IS APPROXIMATELY .061 SECONDS FOR INITIALIZAT
#       FINAL COMPUTATIONS, PLUS .083 SECONDS FOR EACH ITERATION.
#
# REFERENCES --
#       R-479, MISSION PROGRAMMING DEFINITION MEMO NO. 10, LUNAR LANDING MISSION GSOP, SECTION
#       MEMO 67-4.
#
# INPUT -- ERASABLE INITIALIZATION REQUIRED
#                        SCALE FACTOR
#       VARIABLE        IN POWERS OF 2          DESCRIPTION AND REMARKS
#       --------        --------------          -----------------------
#       RRECT           +29 FOR EARTH           DP INITIAL POSITION VECTOR IN METERS
#                       +27 FOR MOON
```

Uses A 80, FACTOR 226, ORBITAL 59, OVFIND 140, RRECT 169, and STATE 138.

1714 ⟨*Page CM1264* 1714⟩≡ (1710 2662)

```
#       VRECT           +7 FOR EARTH            DP INITIAL VELOCITY VECTOR IN METERS/
#                       +5 FOR MOON
#       X1 (38D)        NONE                    INDEX REGISTER SET TO -2D OR -10D ACC
#                                                       RESPECTIVELY, IS THE CENTRAL
#       TAU             +28                     DESIRED TRANSFER TIME IN CENTISECONDS
#                                                       MAY BE POS OR NEG AND ABSOLUT
#       XKEPNEW         +17 FOR EARTH           DP GUESS OF ROOT X OF KEPLERS EQN IN
#                       +16 FOR MOON                    AND ABS VALUE SHOULD BE LESS
#                                                       MAJOR AXIS), FOR SPEED OF CON
#                                                       BY KEPLER TO A POOR BUT VALID
#       TC              +28                     DP PREV. VALUE OF TIME IN CENTISECS.
#       XPREV           +17 FOR EARTH           PRVIOUS VALUE OF X IN SQRT(METERS).
#                       +16 FOR MOON                    ORBITAL PERIOD, VIZ, 2PI SQRT
#
# SUBROUTINES CALLED --
#       DELTIME
#
# CALLING SEQUENCE AND NORMAL EXIT MODES --
#       KEPRTN-2        GOTO                    # MUST BE IN INTERPRETIVE MODE BUT OV
#       KEPRTN-1                KEPLER          # RETURNS WITH XPREV IN MPAC.  PL IS
#       KEPRTN          ...                     # CONTINUE
#
#       KEPLER MUST NOT BE CALLED DIRECTLY SINCE AN INTERRUPTION OF IT WOULD DESTROY
#       THE INTERRUPTED JOB.  THEREFORE THE USER MUST CALL CSMCONIC OR LEMCONIC WHICH
#       ALSO CALLS KEPPREP TO COMPUTE A GUESS OF XKEPNEW.
#
# ABORT EXIT MODE --
#       NONE
#
# OUTPUT --
#                        SCALE FACTOR
#       VARIABLE        IN POWERS OF 2          DESCRIPTION AND REMARKS
#       --------        --------------          -----------------------
#       RCV             +29 FOR EARTH           DP TERMINAL POSITION VECTOR IN METERS
#                       +27 FOR MOON
#       VCV             +7 FOR EARTH            DP TERMINAL VELOCITY VECTOR IN METERS
#                       +5 FOR MOON
#       TC              +28                     DP TRANSFER TIME IN CENTISECS TO WHIC
#       XPREV           +17 FOR EARTH           DP VALUE OF X IN SQRT(METERS) TO WHIC
#                       +16 FOR MOON                    CORRESPONDING TO ONE PERIOD.
```

Uses A 80, FACTOR 226, IT 185, KEPRTN 177, MODE 145, MPAC 145, ORBITAL 59, OVFIND 140, RCV 169, TAU 211, TAU. 177, TC 169, VCV 169, VRECT 169, X1 85, XKEPNEW 177, and XPREV 188.

1715 ⟨*Page CM1265* 1715⟩≡ (1710 2662)

```
#       FOR OTHER OUTPUT WHICH MAY BE OF USE, SEE DEBRIS.
#
# DEBRIS --
#       PARAMETERS WHICH MAY BE OF USE --
#                        SCALE FACTOR
#       VARIABLE        IN POWERS OF 2          DESCRIPTION AND REMARKS
#       --------        --------------          -----------------------
#       URRECT          +1                      DP UNIT VECTOR OF INITIAL POSITION
#       R1              +29 FOR EARTH           DP MAGNITUDE OF INITIAL POSITION IN METERS
#                       +27 FOR MOON
#       ALPHA           -22 FOR EARTH           DP INVERSE OF SEMI-MAJOR AXIS IN 1/METERS
#                       -20 FOR MOON
#       TMODULO         +28                     DP INTEGRAL NUMBER OF PERIODS IN CENTISECS, WHI
#                                                       TAU. OF LESS THAN ONE PERIOD.
#
# PARAMETERS OF NO USE --
#       DP PARAMETERS -- FPSILENT, DELX, DELT, RCNORM, XMODULO, PLUS PUSHLIST REGISTERS 0 THROU
```

Uses `A` 80, `DELT` 188, `DELX` 188, `FACTOR` 226, `RCNORM` 188, `TAU` 211, `TAU.` 177, `TMODULO` 165, `URRECT` 188, and `XMODULO` 165.

1716 ⟨*Page CM1266* 1716⟩≡ (1710 2662)

```
# PROGRAM DESCRIPTION -- LAMBERT SUBROUTINE                    DATE -- 1 SEPTEMBER 1
# MOD NO. -- 0                                                 LOG SECTION -- CONIC
# MOD BY KRAUSE                                                ASSEMBLY -- COLOSSUS
#
# FUNCTIONAL DESCRIPTION --
#       THIS SUBROUTINE CALCULATES THE INITIAL VELOCITY REQUIRED TO TRANSFER A POINT-
#       FROM AN INITIAL POSITION TO A TERMINAL POSITION IN A PRESCRIBED TIME INTERVAL
#       A SECTION OF A CIRCLE, ELLIPSE, PARABOLA, OR HYPERBOLA WITH RESPECT TO THE EA
#       SUBROUTINE CAN BE EXTENDED USING OTHER PRIMARY BODIES BY SIMPLE ADDITIONS TO
#       CODING CHANGES, ACCEPTING THE INHERENT SCALE FACTOR CHANGES IN POSITION AND V
#       UTILIZED IN THE COMPUTATION.
#
# THE RESTRICTIONS ARE: --
#       1. RECTILINEAR TRAJECTORIES CANNOT BE COMPUTED.
#       2. AN ACCURACY DEGRADATION OCCURS AS THE COSINE OF THE TRUE ANOMALY DIFFERENC
#       3. THE ANGLE BETWEEN ANY POSITION VECTOR AND ITS VELOCITY VECTOR MUST BE GREA
#          AND LESS THAN 178 DEGREES 12.5 MINUTES.
#       4. NEGATIVE TRANSFER TIME IS AMBIGUOUS AND WILL RESULT IN NO SOLUTION.
#       5. THE PARAMETERS IN THE PROBLEM MUST NOT EXCEED THEIR SCALING LIMITS SPECIFI
#          LIMITS ARE EXCEEDED, THE RESULTING SOLUTION WILL BE MEANINGLESS.
#
#       THE NUMBER OF ITERATIONS AND, THEREFORE, THE COMPUTATION'S SPEED IS DEPENDENT
#       GUESS OF THE INDEPENDENT VARIABLE, COGA.  THE AGC COMPUTATION TIME IS APPROXI
#       .105 SECONDS FOR INITIALIZATION, .069 SECONDS FOR FINAL COMPUTATIONS, PLUS .2
#
# REFERENCES --
#       R-479, MISSION PROGRAMMING DEFINITION MEMO NO. 10, LUNAR LANDING MISSION GSOP
#       SGA MEMO 67-4.
#
# INPUT -- ERASABLE INITIALIZATION REQUIRED
#                        SCALE FACTOR
#       VARIABLE        IN POWERS OF 2          DESCRIPTION AND REMARKS
#       --------        --------------          -----------------------
#       R1VEC           +29 FOR EARTH           DP INITIAL POSITION VECTOR IN METERS
#                       +27 FOR MOON
#       R2VEC           +29 FOR EARTH           DP TARGET OR TERMINAL POSITION VECTOR
#                       +27 FOR MOON
#       TDESIRED        +28                     DP DESIRED TRANSFER TIME IN CENTISECO
#       X1 (38D)        NONE                    INDEX REGISTER SET TO -2D OR -10D ACC
#                                                       RESPECTIVELY, IS THE CENTRAL
#       GEOMSGN         NONE                    SP +.5 IF DESIRED TRANSFER ANGLE IS I
#       GUESSW          NONE                    AN INTERPRETER SWITCH TO BE SET IF NO
```

Uses A 80, FACTOR 226, GEOMSGN 188, GUESSW 101, MASS 200, R1VEC 188, R2VEC 188, TDESIRED 188, and X1 85.

1717 ⟨*Page CM1267* 1717⟩≡ (1710 2662)

```
#                                                       COGA IS TO BE USED BY LAMBERT
#       COGA            +5                      DP GUESS OF COTANGENT OF FLIGHT PATH ANGLE (MEA
#                                               IGNORED IF GUESSW IS SET.
#       NORMSW          NONE                    AN INTERPRETER SWITCH TO BE SET IF UN IS TO BE
#                                                       LAMBERT IS TO COMPUTE ITS OWN NORMAL (U
#       UN              +1                      DP UNIT NORMAL TO THE DESIRED ORBIT PLANE IN TH
#                                                       MOMENTUM VECTOR.  THIS WILL BE IGNORED
#       VTARGTAG        NONE                    A S.P. TAG TO BE SET TO ZERO IF LAMBERT IS TO C
#                                                       AT R1VEC.
#
# SUBROUTINES CALLED --
#       GEOM, GETX, DELTIME, ITERATOR, LAMENTER (PART OF NEWSTATE)
#
# CALLING SEQUENCE AND NORMAL EXIT MODES --
#       L       CALL                    # MUST BE IN INTERPRETIVE MODE BUT OVFIND ARBITRARY.
#       L+1             LAMBERT         # RETURNS WITH PL AT 0 AND WITH VVEC IN MPAC IF VTARGTA
#                                       #       IN MPAC IF VTARGTAG WAS ZERO
#       L+2     BON                     # CONTINUE IF SOLNSW CLEAR SINCE SOLUTION IS ACCEPTABLE
#       L+3             SOLNSW
#       L+4             LAMABORT
#
#       IF A LAMBER RESULT IS TO BE A FIRST GUESS FOR THE NEXT LAMBERT CALCULATION, COGA MUST B
#       GUESSW MUST BE CLEAR FOR EACH SUCCEEDING LAMBERT CALL.
#
# ABORT EXIT MODES --
#       IF SOLNSW WAS SET UPON EXITING, EITHER LAMBERT WAS ASKED TO COMPUTE A TRANSFER TOO NEAR
#       WAS TOO SMALL TO PRODUCE A REALISTIC TRANSFER BETWEEN R1VEC AND R2FEC.  IN EITHER CASE
#       ACCORDING TO THE NEEDS OF THE PARTICULAR USER.  THE ABORT EXIT MODE MAY BE CODED AS ...
#       LAMBERT         DLOAD   ABS             # A MEASURE OF THE PROXIMITY TO 0 OR
#                               1-CHTH          # 360 DEGREES.
#                       DSU     BWM
#                               ONEBIT
#                               CHANGER2        # CHANGE R2VEC DIRECTION SLIGHTLY.
#                       DLOAD   DAD
#                               TDESIRED
#                               SOMETIME
#                       STCALL  TDESIRED        # INCRESE TDESIRED
#                               LAMBERT
#
# OUTPUT --
#                        SCALE FACTOR
#       VARIABLE        IN POWERS OF 2          DESCRIPTION AND REMARKS
```

Uses A 80, FACTOR 226, GUESSW 101, L 80, MODE 145, MPAC 145, NORMSW 123, OVFIND 140, P 188, R1VEC 188, R2VEC 188, SOLNSW 115, TDESIRED 188, UN 188, VTARGET 188, VTARGTAG 188, and VVEC 188.

1718 ⟨*Page CM1268* 1718⟩≡ (1710 2662)

```
#       --------        --------------          ------------------------
#       VVEC            +7 FOR EARTH            DP INITIAL VELOCITY VECTOR IN METERS/
#                       +5 FOR MOON                     PROBLEM.
#       VTARGET         +7 FOR EARTH            DP RESULTANT VELOCITY VECTOR AT R2VEC
#                       +5 FOR MOON
#       SOLNSW          NONE                    INTERPRETER SWITCH WHICH IS SET IF TH
#                                                       SOLUTION EXISTS.
#
#       FOR OTHER OUTPUT WHICH MAY BE OF USE, SEE DEBRIS.
#
# DEBRIS --
#       PARAMETERS WHICH MAY BE OF USE --
#                        SCALE FACTOR
#       VARIABLE        IN POWERS OF 2          DESCRIPTION AND REMARKS
#       --------        --------------          ------------------------
#       SNTH            +1                      DP SIN OF ANGLE BETWEEN R1VEC AND R2V
#       CSTH            +1                      DP COSINE OF ANGLE
#       1-CSTH          +2                      DP 1-CSTH
#       COGA            +5                      DP COTAN OF INITIAL REQUIRED FLIGHT P
#       P               +4                      DP RATIO OF SEMILATUS RECTUM TO INITI
#       R1A             +6                      DP RATIO OF INITIAL RADIUS TO SEMI-MA
#       R1 (32D)        +29 FOR EARTH           DP INITIAL RADIUS IN METERS
#                       +27 FOR MOON
#       UR1             +1                      DP UNIT VECTOR OF R1VEC
#       U2              +1                      DP UNIT VECTOR OF R2VEC
#
#       PARAMETERS OF NO USE --
#               DP PARAMETERS -- EPSILONL, CSTH-RHO, TPREV, TERRLAMB, R2, RTNLAMB (SE
#               ADDITIONAL INTERPRETIVE SWITCHES USED -- INFINFLG, 360SW, SLOPESW, OR
```

Uses 1-CSTH 188, CSTH 188, CSTH-RHO 188, FACTOR 226, INFINFLG 127, ORDERSW 127, P 188, R1A 188, R1VEC 188, R2 188, R2VEC 188, RHO 211, RTNLAMB 188, SLOPESW 101, SNTH 188, SOLNSW 115, TERRLAMB 188, TPREV 188, U2 188, UR1 188, VTARGET 188, and VVEC 188.

1719 ⟨*Page CM1269* 1719⟩≡ (1710 2662)

```
# PROGRAM DESCRIPTION -- TIME-THETA SUBROUTINE                    DATE -- 1 SEPTEMBER 1967
# MOD NO. -- 0                                                    LOG SECTION -- CONIC SUBROUTINE
# MOD BY KRAUSE                                                   ASSEMBLY -- COLOSSUS REVISION 8
#
# FUNCTIONAL DESCRIPTION --
#       THIS SUBROUTINE, GIVEN AN INITIAL STATE VECTOR AND A DESIRED TRUE-ANOMALY-DIFFERENCE TH
#       STATE IS TO BE UPDATED ALONG A CONIC TRAJECTORY, CALCULATES THE CORRESPONDING TIME-OF-F
#       PROVIDES THE OPTION OF COMPUTING THE NEW UPDATED STATE VECTOR.  THE RESULTING TRAJECTOR
#       CIRCLE, ELLIPSE, PARABOLA, OR HYPERBOLA WITH RESPECT TO THE EARTH OR THE MOON.  THE USE
#       EXTENDED USING OTHER PRIMARY BODIES BY SIMPLE ADDITIONS TO THE MUTABLE WITHOUT INTRODUC
#       ACCEPTING THE INHERENT SCALE FACTOR CHANGES IN POSITION AND VELOCITY.
#
# THE RESTRICTIONS ARE --
#       1. THE ANGLE BETWEEN ANY POSITION VECTOR AND ITS VELOCITY VECTOR MUST BE GREATER THAN 1
#          AND LESS THAN 178 DEGREES 12.5 MINUTES.
#       2. THE PARAMETERS IN THE PROBLEM MUST NOT EXCEED THEIR SCALING LIMITS SPECIFIED IN THE
#          ARE EXCEEDED, THE RESULTING SOLUTION WILL BE MEANINGLESS.
#
#       THE AGC COMPUTATION TIME IS APPROXIMATELY .292 SECONDS.
#
# REFERENCES --
#       R-479, MISSION PROGRAMMING DEFINITION MEMO NO. 10, LUNAR LANDING MISSION GSOP-SECTION 5
#
# INPUT -- ERASABLE INITIALIZATION REQUIRED
#                        SCALE FACTOR
#       VARIABLE        IN POWERS OF 2          DESCRIPTION AND REMARKS
#       --------        --------------          -----------------------
#       RVEC            +29 FOR EARTH           DP INITIAL POSITION VECTOR IN METERS
#                       +27 FOR MOON
#       VVEC            +7 FOR EARTH            DP INITIAL VELOCITY VECTOR IN METERS/CENTISECON
#                       +5 FOR MOON
#       SNTH            +1              '       DP SINE OF THE TRUE-ANOMALY-DIFFERENCE THROUGH
#       CSTH            +1                      DP COSINE OF THE ANGLE
#       RVSW            NONE                    AN INTERPRETIVE SWITCH TO BE SET IF ONLY TIME I
#                                                       IS TO BE COMPUTED ALSO.
#       X1 (38D)        NONE                    INDEX REGISTER TO BE SET TO -2D OR -10D ACCORDI
#                                                       RESPECTIVELY, IS THE CENTRAL BODY.
#
# SUBROUTINES CALLED --
```

Uses A 80, CSTH 188, FACTOR 226, RVEC 188, RVSW 123, SNTH 188, STATE 138, THETA 148, VVEC 188, and X1 85.

1720 ⟨*Page CM1270* 1720⟩≡ (1710 2662)

```
#       PARAM, GEOM, GETX, DELTIME, NEWSTATE
#
# CALLING SEQUENCE AND NORMAL EXIT MODES --
#       IF ONLY TIME IS DESIRED AS OUTPUT --
#       L       SET     CALL            # MUST BE IN INTERPRETIVE MODE BUT OVFIND ARE
#       L+1             RVSW
#       L+2             TIMETHET        # RETURN WITH PL AT 0 AND T IN MPAC
#       L+3     ...                     # CONTINUE
#
#       IF THE UPDATE STATE VECTOR IS DESIRED AS WELL --
#       L       CLEAR   CALL            # MUST BE IN INTERPRETIVE MODE BUT OVFIND ARE
#       L+1             RVSW
#       L+2             TIMETHET        # RETURNS WITH PL AT 6.  THE INITIAL POSITION
#                                       # THE INITIAL VELOCITY VECTOR IN MPAC.
#       L+3     STOVL   NEWVVEC
#       L+4     STADR
#       L+5     STORE   NEWRVEC         # NEWVVEC AND NEWRVEC ARE SYMBOLIC REPRESENTA
#       L+6     ...                     # CONTINUE.
#
# ABORT EXIT MODES --
#       IF COGAFLAG AND/OR INFINFLG IS SET AT THE EXIT TO TIME-THETA, TIME-THETA WILL
#       AN ALARM CODE (ORIGINALLY 00607), AND NOT RETURN TO THE CALLING PROGRAM.  (PO
#
# OUTPUT --
#                        SCALE FACTOR
#       VARIABLE        IN POWERS OF 2          DESCRIPTION AND REMARKS
#       --------        --------------          -----------------------
#       T(30D)          +28                     DP TRANSFER TIME IN CENTISECONDS
#       INFINFLG        NONE                    AN INTERPRETIVE SWITCH WHICH IS SET I
#                                                       INFINITY (NO SOLUTION), CLEAR
#       COGAFLAG        NONE                    AN INTERPRETIVE SWITCH WHICH IS SET I
#                                                       CLEAR IF NOT.
#
#       IN ADDITION, IF RVSW IS CLEAR, THE FOLLOWING ARE OUTPUT --
#       MPAC -          +7 FOR EARTH            DP TERMINAL VELOCITY VECTOR IN METERS
#          MPAC+5       +5 FOR MOON
#       0D - 5D         +29 FOR EARTH           DP TERMINAL POSITION VECTOR IN METERS
#                       +27 FOR MOON
#
#       FOR OTHER OUTPUT WHICH MAY BE OF USE, SEE DEBRIS.
```

Uses A 80, CODE 140, COGAFLAG 127, FACTOR 226, INFINFLG 127, L 80, MODE 145, MPAC 145, OVFIND 140, RVSW 123, STATE 138, and THETA 148.

1721 ⟨*Page CM1271* 1721⟩≡ (1710 2662)

```
#
# DEBRIS --
#       PARAMETERS WHICH MAY BE OF USE --
#                        SCALE FACTOR
#       VARIABLE        IN POWERS OF 2          DESCRIPTION AND REMARKS
#       --------        --------------          -----------------------
#       R1 (32D)        +29 FOR EARTH           DP MAGNITUDE OF INITIAL POSITION VECTOR, RVEC,
#                       +27 FOR MOON
#       R1A             +6                      DP RATIO OF R1 TO SEMI-MAJOR AXIS (NEG. FOR HYP
#       P               +4                      DP RATIO OF SEMILATUS RECTUM TO R1
#       COGA            +5                      DP COTAN OF ANGLE BETWEEN RVEC AND VVEC
#       UR1             +1                      DP UNIT VECTOR OF RVEC
#       U2              +1                      DP UNIT VECTOR OF VVEC
#       UN              +1                      DP UNIT VECTOR OF UR1*U2
#
# PARAMETERS OF NO USE --
#       SP PARAMETERS -- RTNTT, GEOMSGN, RTNPRM, MAGVEC2=R2 (DP), PLUS PUSHLIST LOCATIONS 0-11D
#       ADDITIONAL INTERPRETIVE SWITCHES USED -- NORMSW, 360SW
```

Uses FACTOR 226, GEOMSGN 188, MAGVEC2 188, NORMSW 123, P 188, R1A 188, R2 188, RTNPRM 188, RTNTT 188, RVEC 188, U2 188, UN 188, UR1 188, and VVEC 188.

1722 ⟨*Page CM1272* 1722⟩≡ (1710 2662)

```
# PROGRAM DESCRIPTION -- TIME-RADIUS SUBROUTINE          DATE -- 11 OCTOBER 1967
# MOD NO. -1                                             LOG SECTION -- CONIC SUBROUTI
# MOD BY KRAUSE                                          ASSEMBLY -- COLOSSUS REVISION
#
# FUNCTIONAL DESCRIPTION --
#       THIS SUBROUTINE, GIVEN AN INITIAL STATE VECTOR AND A DESIRED RADIUS TO WHICH
#       STATE IS TO BE UPDATED ALONG A CONIC TRAJECTORY, CALCULATES THE CORRESPONDING
#       PROVIDES THE OPTION OF COMPUTING THE NEW UPDATED STATE VECTOR.  THE RESULTING
#       CIRCLE, ELLIPSE, PARABOLA, OR HYPERBOLA WITH RESPECT TO THE EARTH OR THE MOON
#       EXTENDED USING OTHER PRIMARY BODIES BY SIMPLE ADDITIONS TO THE MUTABLE WITHOU
#       ACCEPTING THE INHERENT SCALE FACTOR CHANGES IN POSITION AND VELOCITY.
#
#       IF THE DESIRED RADIUS IS BEYOND THE RADIUS OF APOCENTER OF THE CONIC OR BELOW
#       APSESW WILL BE SET AND THE SUBROUTINE WILL RETURN THE APOCENTER OR PERICENTER
#
# THE RESTRICTIONS ARE --
#       1. THE ANGLE BETWEEN ANY POSITION VECTOR AND ITS VELOCITY VECTOR MUST BE GREA
#          AND LESS THAN 178 DEGREES 12.5 MINUTES.
#       2. THE PARAMETERS IN THE PROBLEM MUST NOT EXCEED THEIR SCALING LIMITS SPECIFI
#          EXCEEDED, THE RESULTING SOLUTION WILL BE MEANINGLESS.
#       3. AN ACCURACY DEGRADATION OCCURS AS THE SENSITIVITIES OF TIME AND UPDATED ST
#          RDESIRED INCREASE.  THIS WILL OCCUR NEAR EITHER APSIS OF THE CONIC AND WHE
#          PARTICULAR, IF THE CONIC IS AN EXACT CIRCLE, THE PROBLEM IS UNDEFINED AND
#
#       THE AGC COMPUTATION TIME IS APPROXIMATELY .363 SECONDS.
#
# REFERENCES --
#       R-479, MISSION PROGRAMMING DEFINITION MEMO NO. 10, LUNAR LANDING MISSION GSOP
#
# INPUT -- ERASABLE INITIALIZATION REQUIRED.
#                        SCALE FACTOR
#       VARIABLE        IN POWERS OF 2          DESCRIPTION AND REMARKS
#       --------        --------------          -----------------------
#       RVEC            +29 FOR EARTH           DP INITIAL POSITION VECTOR IN METERS
#                       +27 FOR MOON
#       VVEC            +7 FOR EARTH            DP INITIAL VELOCITY VECTOR IN METERS/
#                       +5 FOR MOON
#       RDESIRED        +29 FOR EARTH           DP TERMINAL RADIAL DISTANCE ON CONIC
#                       +27 FOR MOON                    COMPUTED
#       SGNRDOT         NONE                    SP TAG SET TO +.5 OR -.5 ACCORDING TO
#                                                       POSITIVE OR NEGATIVE, RESPECT
```

Uses A 80, APSESW 127, FACTOR 226, RDESIRED 188, RVEC 188, SGNRDOT 188, STATE 138, and VVEC 188.

1723 ⟨*Page CM1273* 1723⟩≡ (1710 2662)

```
#                                                       SINGLE-VALUED PROBLEM.
#       X1 (38D)        NONE                    INDEX REGISTER TO BE SET TO -2D OR -10D ACCORDI
#                                                       RESPECTIVELY, IS THE CENTRAL BODY.
#       RVSW            NONE                    AN INTERPRETIVE SWITCH TO BE SET IF ONLY TIME I
#                                                       IS TO BE COMPUTED ALSO.
#
# SUBROUTINES CALLED --
#       PARAM, GEOM, GETX, DELTIME, NEWSTATE
#
# CALLING SEQUENCE AND NORMAL EXIT MODES --
#       IF ONLY TIME IS DESIRED AS OUTPUT --
#       L       SET     CALL            # MUST BE IN INTERPRETIVE MODE BUT OVFIND ARBITRARY.
#       L+1             RVSW
#       L+2             TIMERAD         # RETURN WITH PL AT 0 AND T IN MPAC
#       L+3     ...                     # CONTINUE
#
#       IF THE UPDATE STATE VECTOR IS DESIRED AS WELL --
#       L       CLEAR   CALL            # MUST BE IN INTERPRETIVE MODE BUT OVFIND ARBITRARY.
#       L+1             RVSW
#       L+2             TIMERAD         # RETURNS WITH PL AT 6.  THE INITIAL POSITION VECTOR IS
#                                       # THE INITIAL VELOCITY VECTOR IN MPAC.
#       L+3     STOVL   NEWVVEC
#       L+4     STADR
#       L+5     STORE   NEWRVEC         # NEWVVEC AND NEWRVEC ARE SYMBOLIC REPRESENTATIONS OF T
#       L+6     ...                     # CONTINUE
#
# ABORT EXIT MODES --
#       IF SOLNSW AND/OR COGAFLAG AND/OR INFINFLG IS SET AT THE EXIT TO TIME-RADIUS, TIME-RADIU
#       TO POODOO WITH AN ALARM CODE (ORIGINALLY 00607), AND NOT RETURN TO THE CALLING PROGRAM.
#
# OUTPUT --
#                        SCALE FACTOR
#       VARIABLE        IN POWERS OF 2          DESCRIPTION AND REMARKS
#       --------        --------------          -----------------------
#       T (30D)         +28                     DP TRANSFER TIME IN CENTISECONDS.
#       INFINFLG        NONE                    AN INTERPRETIVE SWITCH WHICH IS SET IF RDESIRED
#                                                       INFINITY (NO SOLUTION), CLEAR IF A PHYS
#       COGAFLAG        NONE                    AN INTERPRETIVE SWITCH WHICH IS SET IF RESTRICT
#                                                       CLEAR IF NOT.
#       APSESW          NONE                    AN INTERPRETIVE SWITCH WHICH IS SET IF RDESIRED
```

Uses A 80, APSESW 127, CODE 140, COGAFLAG 127, FACTOR 226, INFINFLG 127, L 80, MODE 145, MPAC 145, OVFIND 140, RDESIRED 188, RVSW 123, SGNRDOT 188, SOLNSW 115, STATE 138, and X1 85.

1724 ⟨*Page CM1274* 1724⟩≡ (1710 2662)

```
#                                                       LESS THAN RADIUS OF PERICENTE
#                                                       WILL THEN BE RETURNED.  THE S
#                                                       APOCENTER.
#       SOLNSW          NONE                    AN INTERPRETIVE SWITCH WHICH IS SET I
#                                                       POINT IS AMBIGUOUS, VIOLATING
#                                                       MINUS-18, THE SWITCH IS CLEAR
#
#       IN ADDITION, IF RVSW IS CLEAR, THE FOLLOWING ARE OUTPUT --
#       MPAC -          +7 FOR EARTH            DP TERMINAL VELOCITY VECTOR IN METERS
#          MPAC+5       +5 FOR MOON
#       OD - 5D         +29 FOR EARTH           DP TERMINAL POSITION VECTOR IN METERS
#                       +27 FOR MOON
#
#       FOR OTHER OUTPUT WHICH MAY BE OF USE, SEE DEBRIS.
#
# DEBRIS --
#       PARAMETERS WHICH MAY BE OF USE --
#                        SCALE FACTOR
#       VARIABLE        IN POWERS OF 2          DESCRIPTION AND REMARKS
#       --------        --------------          -----------------------
#       R1 (32D)        +29 FOR EARTH           DP MAGNITUDE OF INITIAL POSITION VECT
#                       +27 FOR MOON
#       R1A             +6                      DP RATIO OF R1 TO SEMI-MAJOR AXIS (NE
#       P               +4                      DP RATIO OF SEMILATUS RECTUM TO R1
#       COGA            +5                      DP COTAN OF ANGLE BETWEEN RVEC AND VV
#       UR1             +1                      DP UNIT VECTOR OF RVEC
#       U2              +1                      DP UNIT VECTOR OF VVEC
#       UN              +1                      DP UNIT VECTOR OF UR1*U2
#       CSTH            +1                      DP COSINE OF TRUE ANOMALY DIFFERENCE
#       SNTH            +1                      DP SINE OF TRUE ANOMALY DIFFERENCE.
#
#       PARAMETERS OF NO USE --
#               SP PARAMETERS -- RTNTT, GEOMSGN, RTNPRM, MAGVEC2*R2 (DP), PLUS PUSHLI
#               ADDITIONAL INTERPRETIVE SWITCHES USED -- NORMSW, 360SW
#
```

Uses A 80, CSTH 188, FACTOR 226, GEOMSGN 188, MAGVEC2 188, MPAC 145, NORMSW 123, P 188, R1A 188, R2 188, RDESIRED 188, RTNPRM 188, RTNTT 188, RVEC 188, RVSW 123, SNTH 188, SOLNSW 115, U2 188, UN 188, UR1 188, and VVEC 188.

1725 ⟨*Page CM1275* 1725⟩≡ (1710 2662)

```
# PROGRAM DESCRIPTION -- APSIDES SUBROUTINE            DATE -- 1 SEPTEMBER 1967
# MOD NO. -- 0                                         LOG SECTION -- CONIC SUBROUTINES
# MOD BY KRAUSE                                        ASSEMBLY -- COLOSSUS REVISION 88
#
# FUNCTIONAL DESCRIPTION --
#       THIS SUBROUTINE, GIVEN AN INITIAL STATE VECTOR, CALCULATES THE RADIUS OF PERICENTER AND
#       ECCENTRICITY OF THE RESULTING CONIC TRAJECTORY, WHICH MAY BE A STRAIGHT LINE,
#       CIRCLE, ELLIPSE, PARABOLA, OR HYPERBOLA WITH RESPECT TO THE EARTH OR THE MOON.  THE USE
#       BE EXTENDED USING OTHER PRIMARY BODIES BY SIMPLE ADDITIONS TO THE MUTABLE WITHOUT INTRO
#       ACCEPTING THE INHERENT SCALE FACTOR CHANGES IN POSITION AND VELOCITY.
#
# THE RESTRICTIONS ARE --
#       1. IF APOCENTER IS BEYOND THE SCALING OF POSITION, THE SCALE FACTOR LIMIT (536,870,910
#          TO THE EARTH OR 134,217,727.5 METERS WITH RESPECT TO THE MOON) WILL BE RETURNED.
#       2. THE PARAMETERS IN THE PROBLEM MUST NOT EXCEED THEIR SCALING LIMITS SPECIFIED IN THE
#          ARE EXCEEDED, THE RESULTING SOLUTION WILL BE MEANINGLESS.
#
#       THE AGC COMPUTATION TIME IS APPROXIMATELY .103 SECONDS.
#
# REFERENCES --
#       MISSION PROGRAMMING DEFINITION MEMO NO. 10, LUNAR LANDING MISSION GSOP-SECTION 5.5.
#
# INPUT -- ERASABLE INITIALIZATION REQUIRED
#                        SCALE FACTOR
#       VARIABLE        IN POWERS OF 2          DESCRIPTION AND REMARKS
#       --------        --------------          -----------------------
#       RVEC            +29 FOR EARTH           DP INITIAL POSITION VECTOR IN METERS
#                       +27 FOR MOON
#       VVEC            +7 FOR EARTH            DP INITIAL VELOCITY VECTOR IN METERS/CENTISECON
#                       +5 FOR MOON
#       X1 (38D)        NONE                    INDEX REGISTER TO BE SET TO -2D OR -10D ACCORDI
#                                                       RESPECTIVELY, IS THE CENTRAL BODY.
#
# SUBROUTINES CALLED --
#       PARAM, GEOM
#
# CALLING SEQUENCE AND NORMAL EXIT MODES --
```

Uses `A` 80, `FACTOR` 226, `RVEC` 188, `STATE` 138, `VVEC` 188, and `X1` 85.

1726 ⟨*Page CM1276* 1726⟩≡ (1710 2662)

```
#       IF ONLY TIME IS DESIRED AS OUTPUT --
#       L       CALL                    # MUST BE IN INTERPRETIVE MODE BUT OVFIND ARE
#       L+1             APSIDES         # RETURNS WITH PL AT 0, RADIUS OF APOCENTER I
#       L+2     STODL   APOAPSE
#       L+3             OD
#       L+4     STORE   PERIAPSE        # APOAPSE AND PERIAPSE ARE SYMBOLIC REPRESENT
#       L+5     ...                     # CONTINUE
#
# OUTPUT --
#                        SCALE FACTOR
#       VARIABLE        IN POWERS OF 2          DESCRIPTION AND REMARKS
#       --------        --------------          -----------------------
#       MPAC            +29 FOR EARTH           DP RADIUS OF APOCENTER IN METERS
#                       +27 FOR MOON
#       OD-1D           +29 FOR EARTH           DP RADIUS OF PERICENTER IN METERS
#                       +27 FOR MOON
#       ECC             +3                      DP ECCENTRICITY OF CONIC TRAJECTORY
#
#       FOR OTHER OUTPUT WHICH MAY BE OF USE, SEE DEBRIS.
#
# DEBRIS --
#       PARAMETERS WHICH MAY BE OF USE --
#                        SCALE FACTOR
#       VARIABLE        IN POWERS OF 2          DESCRIPTION AND REMARKS
#       --------        --------------          -----------------------
#       R1 (32D)        +29 FOR EARTH           DP MAGNITUDE OF INITIAL POSITION VECT
#                       +27 FOR MOON
#       R1A             +6                      DP RATIO OF R1 TO SEMI-MAJOR AXIS (NE
#       P               +4                      DP RATIO OF SEMILATUS RECTUM TO R1
#       COGA            +5                      DP COTAN OF ANGLE BETWEEN RVEC AND VV
#       UR1             +1                      DP UNIT VECTOR OF RVEC
#       U2              +1                      DP UNIT VECTOR OF VVEC
#       UN              +1                      DP UNIT VECTOR OF UR1*U2
#       MAGVEC2         +7 FOR EARTH            DP MAGNITUDE OF VVEC
#                       +5 FOR MOON
#
#       PARAMETERS OF NO USE --
#               SP PARAMETERS -- RTNAPSE, GOMSGN, RTNPRM, PLUS PUSHLIST LOCATIONS 0-5
#               ADDITIONAL INTERPRETIVE SWITCHES USED -- NORMSW

                SETLOC  CONICS
```

Uses CONICS 61, ECC 188, FACTOR 226, L 80, MAGVEC2 188, MODE 145, MPAC 145, NORMSW 123, OVFIND 140, P 188, R1A 188, RTNAPSE 188, RTNPRM 188, RVEC 188, U2 188, UN 188, UR1 188, and VVEC 188.

1727 ⟨*Page CM1277* 1727⟩≡ (1710 2662)

```
                BANK

                COUNT   12/CONIC

                EBANK=  UR1
KEPLERN         SETPD   BOV
                        0
                        +1
                VLOAD*
                        MUTABLE,1
                STOVL   14D
                        RRECT
                UNIT    SSP
                        ITERCTR
                        20D
                STODL   URRECT
                        36D
                STOVL   R1
                        RRECT
                DOT     SL1R
                        VRECT
                DMP     SL1R
                        1/ROOTMU        # 1/ROOTMU (-17 OR -14)
                STOVL   KEPC1           # C1=R.V/ROOTMU (+17 OR +16)

                        VRECT
                VSQ     DMPR
                        1/MU            # 1/MU (-34 OR -28)
                DMP     SL3
                        R1
                DSU     ROUND
                        D1/64
                STORE   KEPC2           # C2=RV.V/MU -1 (+6)

                BDSU    SR1R
                        D1/64
                DDV
                        R1
                STORE   ALPHA           # ALPHA=(1-C2)/R1 (-22 OR -20)

                BPL     DLOAD           # MAXIMUM X DEPENDS ON TYPE OF CONIC
                        1REV
                        -50SC           # -50SC (+12)
                DDV     BOV
                        ALPHA
```

```
        STOREMAX
SQRT    GOTO
        STOREMAX
```

Uses COUNT 142, EBANK 80, RRECT 169, UR1 188, URRECT 188, V 229, and VRECT 169.

1729 ⟨*Page CM1278* 1729⟩≡ (1710 2662)

```
1REV        SQRT    BDDV
                    2PISC           # 2PISC (+6)
            BOV
                    STOREMAX
STOREMAX    STORE   XMAX
            DMP     PDDL
                    1/ROOTMU
                    ALPHA
            NORM    PDDL
                    X1
            SL*     DDV
                    0       -6,1
            BOV     BMN
                    MODDONE
                    MODDONE         # MPAC=PERIOD
PERIODCH    PDDL    ABS             # OD=PERIOD
                    TAU.
            DSU     BMN
                    OD
                    MODDONE
            SIGN
                    TAU.
            STODL   TAU.
            GOTO
                    PERIODCH
MODDONE     SETPD   DLOAD
                    0
                    XKEPNEW
            STORE   X
            SIGN    BZE
                    TAU.
                    BADX
            BMN     ABS
                    BADX
            DSU     BPL
                    XMAX
                    BADX
STORBNDS    DLOAD   BPL
                    TAU.
                    STOREMIN
            DLOAD   DCOMP
                    XMAX
            STODL   XMIN
                    KEPZERO
            STCALL  XMAX
```

```
                        DXCOMP
STOREMIN        DLOAD
                        KEPZERO
                STORE   XMIN
DXCOMP          DLOAD   DMPR
```

Uses MPAC 145, TAU 211, TAU. 177, X1 85, and XKEPNEW 177.

1731 ⟨*Page CM1279* 1731⟩≡ (1710 2662)

```
                        TAU.
                        BEE22
                ABS
                STODL   EPSILONT
                        XPREV
XDIFF           BDSU
                        X
                STORE   DELX

KEPLOOP         DLOAD   DSQ
                        X               # X=XKEP
                NORM    PUSH            # OD=XSQ (+34 OR +32 -N1)       PL AT 2
                        X1
                DMP     SRR*
                        ALPHA
                        0       -6,1
                STCALL  XI              # XI=ALPHA XSQ (+6)
                        DELTIME
                BOV     BDSU
                        TIMEOVFL        # UNLIKELY
                        TAU.
                STORE   DELT            # DELT=DELINDEP
                ABS     BDSU
                        EPSILONT
                BPL     DLOAD
                        KEPCONVG
                        T
                DSU     NORM
                        TC
                        X1
                PDDL    NORM
                        DELX
                        X2
                XSU,1   DMP
                        X2
                        DELT
                SLR*    DDV
                        1,1
                SR1     PUSH            # OD=TRIAL DELX         PL AT 2
                BPL     DLOAD
                        POSDELX
                        X
                STORE   XMAX            # MOVE MAX BOUND IN
                BDSU    DSU             #                       PL AT 0
                        XMIN
```

```
BOV     BPL
        NDXCHNGE
        NDXCHNGE
DLOAD   GOTO
```

Uses DELT 188, DELX 188, EPSILONT 165, TAU 211, TAU. 177, TC 169, X1 85, X2 85, XKEP 169, and XPREV 188.

1733 ⟨*Page CM1280* 1733⟩≡ (1710 2662)

```
                        OD
                        NEWDELX

NDXCHNGE        DLOAD   DSU
                        XMIN
                        X
                DMPR    GOTO            # TO FORCE MPAC +2 TO ZERO
                        DP9/10
                        NEWDELX

POSDELX         DLOAD
                        X
                STORE   XMIN            # MOVE MIN BOUND IN
                BDSU    DSU             #                       PL AT 0
                        XMAX
                BOV     BMN
                        PDXCHNGE
                        PDXCHNGE
                DLOAD
                        OD
NEWDELX         STORE   DELX
                BZE     DAD
                        KEPCONVG
                        X
                STODL   X
                        T
                STORE   TC
BRNCHCTR        RTB     BHIZ
                        CHECKCTR
                        KEPCONVG
                GOTO
                        KEPLOOP         # ITERATE

PDXCHNGE        DLOAD   DSU
                        XMAX
                        X
                DMPR    GOTO            # TO FORCE MPAC +2 TO ZERO
                        DP9/10
                        NEWDELX

BADX            DLOAD   SR1
                        XMAX
                SIGN
                        TAU.
                STCALL  X
```

STORBNDS

Uses DELX 188, MPAC 145, TAU 211, TAU. 177, and TC 169.

1735 ⟨*Page CM1281* 1735⟩≡ (1710 2662)

```
TIMEOVFL        DLOAD   BMN             # X WAS TOO BIG
                        X
                        NEGTOVFL
                STORE   XMAX
CMNTOVFL        DLOAD   SR1
                        DELX
                STORE   DELX
                BZE     BDSU
                        KEPRTN
                        X
                STODL   X
                        TC
                STCALL  T
                        BRNCHCTR
NEGTOVFL        STCALL  XMIN
                        CMNTOVFL
KEPCONVG        DLOAD   SR4R
                        R1
                DSU     VXSC
                        XSQC(XI)
                        URRECT
                VSL1    PDDL            # OD=(R1-XSQC(XI))URRECT (+33 OR +31)
                        X
                DSQ     NORM
                        X1
                DMPR    DMPR
                        1/ROOTMU
                        X
                DMP     SRR*
                        S(XI)
                        0       -7,1
                BDSU
                        T
                SL1     VXSC
                        VRECT
                VSL1    VAD
                VSL4
                STORE   RCV             # RCV (+29 OR +27)

                ABVAL   NORM
                        X2
                STODL   RCNORM
                        XI
                DMPR    DSU
                        S(XI)
```

```
        D1/128
DMP     SL1R
        ROOTMU
DMP     SLR*
```

Uses DELX 188, KEPRTN 177, RCNORM 188, RCV 169, TC 169, URRECT 188, VRECT 169, X1 85, and X2 85.

1736 ⟨*Page CM1282* 1736⟩≡ (1710 2662)

```
        X
        0       -3,2
DDV     VXSC
        RCNORM
        URRECT
VSL1    PDDL            # OD=URRECT(XI S(XI)-1)X ROOTMU/RCV (+15
        XSQC(XI)        # OR +13)                        PL AT 6
SLR*    DDV
        0       -4,2
        RCNORM
BDSU    VXSC
        D1/256
        VRECT
VAD     VSL8
STADR                   #                                PL AT 0
STODL   VCV             # VCV (+7 OR +5)
        T
STODL   TC
        X
STCALL  XPREV
        KEPRTN
```

Uses KEPRTN 177, RCNORM 188, RCV 169, TC 169, URRECT 188, VCV 169, VRECT 169, and XPREV 188.

1737 ⟨*Page CM1283* 1737⟩≡ (1710 2662)

```
DELTIME         EXIT                    # MPAC=XI (+6), OD=XSQ (+34 OR +32 -N1)
                TC      POLY
                DEC     8
                2DEC    .083333334

                2DEC    -.266666684

                2DEC    .406349155

                2DEC    -.361198675

                2DEC    .210153242

                2DEC    -.086221951

                2DEC    .026268812

                2DEC    -.006163316

                2DEC    .001177342

                2DEC    -.000199055

                TC      INTPRET
                STODL   S(XI)
                        XI
                EXIT
                TC      POLY
                DEC     8
                2DEC    .031250001

                2DEC    -.166666719

                2DEC    .355555413

                2DEC    -.406347410

                2DEC    .288962094

                2DEC    -.140117894

                2DEC    .049247387

                2DEC    -.013081923
```

```
2DEC    .002806389

2DEC    -.000529414

TC      INTPRET
```

Uses MPAC 145 and TC 169.

1738 ⟨*Page CM1284* 1738⟩≡ (1710 2662)

```
DMP     SRR*            #                                PL AT 0
        OD
        0       -5,1
STORE   XSQC(XI)        # XSQC(XI) (+33 OR +31)
DMP     SL1
        KEPC1
RTB     PDDL            # XCH WITH PL. OD=C1 XSQ C(XI) (+49 OR +46)
        TPMODE          #                                PL AT 0,3
DMP     SRR*
        S(XI)
        0       -5,1
DMP     SL1
        KEPC2
RTB     PDDL            # 3D=C2 XSQ S(XI) (+35 OR +33)  PL AT 6
        TPMODE
        R1
SR      TAD             #                                PL AT 3
        6
NORM    DMP             # TO PRESERVE SIGNIF.
        X1
        X
SR*     TAD             # X(C2 XSQ S(XI) +R1) (+49 OR +46)  PL AT 0
        0       -3,1
SL4R    DMPR
        1/ROOTMU
STORE   T
RVQ
```

Uses SR 80 and X1 85.

1739 ⟨*Page CM1285* 1739⟩≡ (1710 2662)

```
ITERATOR        BONCLR  DLOAD
                        SLOPESW
                        FIRSTIME
                        DEP
                DSU     NORM
                        DEPREV
                        X1
                PDDL    NORM
                        DELINDEP
                        X2
                XSU,1   DMP
                        X2
                        DELDEP
                SLR*    DDV             #                               PL UP 2
                        1,1
                SR1     BOFF
                        ORDERSW
                        SGNCHECK
                ABS     SIGN            # IN CASE 2ND DERIV. CHANGED SIGN, MUST
                        DELDEP          # DISREGARD IT TO FIND MIN.

SGNCHECK        PUSH    BPL             # TRIAL DELINDEP                PL DOWN 2
                        POSDEL
                DLOAD   BON
                        INDEP
                        ORDERSW
                        MINCHECK
                STORE   MAX             # IF NOT 2ND ORDER, CAN MOVE MAX BOUND IN.

MINCHECK        BDSU    DSU
                        MIN
                BOV     BPL
                        MODNGDEL
                        MODNGDEL
                GOTO
                        DELOK

MODNGDEL        DLOAD   DSU             # TRIAL DELINDEP WOULD EXCEED MIN BOUND
                        MIN
                        INDEP
                DMP     GOTO
                        DP9/10
                        NEWDEL

FIRSTIME        DLOAD   DMP
```

```
                        MIN
                        TWEEKIT         # DLOAD TWEEKIT(40D) SENSITIVE TO CHANGE.
                PDDL    DMP             # S2(41D) SHOULDN'T CONTAIN HI ORDER ONES
```

Uses DELDEP 188, DEPREV 188, IT 185, ORDERSW 127, S2 85, SLOPESW 101, X1 85, and X2 85.

1740 ⟨*Page CM1286* 1740⟩≡ (1710 2662)

```
                        MAX
                        TWEEKIT
                DSU
                SIGN    GOTO
                        DELDEP
                        SGNCHECK

POSDEL          DLOAD   BON
                        INDEP
                        ORDERSW
                        MAXCHECK
                STORE   MIN             # IF NOT 2ND ORDER, CAN MOVE MIN BOUND IN.

MAXCHECK        BDSU    DSU
                        MAX
                BOV     BMN
                        MODPSDEL
                        MODPSDEL
DELOK           DLOAD
                        OD
NEWDEL          STORE   DELINDEP
                RVQ

MODPSDEL        DLOAD   DSU
                        MAX
                        INDEP
                DMP     GOTO
                        DP9/10
                        NEWDEL

CHECKCTR        CS      ONE
                INDEX   FIXLOC
                AD      ITERCTR
                INDEX   FIXLOC
                TS      ITERCTR
                TS      MPAC
                TC      DANZIG
```

Uses DELDEP 188, FIXLOC 140, MPAC 145, ORDERSW 127, and TC 169.

1741 ⟨*Page CM1287* 1741⟩≡ (1710 2662)

```
NEWSTATE        DLOAD   SR4R
                        R1
                DSU     VXSC
                        XSQC(XI)
                        UR1
                VSL1    PDDL            # 0D=(R1-XSQC(XI))UR1 (+33 OR 31) PL AT 6
                        X
                DSQ     NORM
                        X1
                DMPR    DMPR
                        1/ROOTMU
                        X
                DMP     SRR*
                        S(XI)
                        0       -7,1
                BDSU
                        T
                SL1     VXSC
                        VVEC
                VSL1    VAD             #                                PL AT 0
                VSL4    PUSH
                ABVAL
LAMENTER        NORM
                        X1
                STODL   R2
                        XI
                DMP     DSU
                        S(XI)
                        D1/128
                DMP     SL1R
                        ROOTMU
                DMP     SLR*
                        X
                        0 -3,1
                DDV     VXSC
                        R2
                        UR1
                VSL1    PDDL            # 6D=V2VEC PART (+15 OR 13)     PL AT 12
                        XSQC(XI)
                SLR*    DDV
                        0 -4,1
                        R2
                BDSU
                        D1/256
                VXSC    VAD
```

```
                        VVEC            #                                PL AT 6
                VSL8    RVQ
```

Uses R2 188, UR1 188, VVEC 188, and X1 85.

1742 ⟨*Page CM1288* 1742⟩≡ (1710 2662)

```
                SETLOC  CONICS1
                BANK

                COUNT   04/CONIC
# DO NOT DISTURB THE ORDER OF THESE CDS, OVERLAYS HAVE BEEN MADE.
BEE17           DEC     0               # KEEP WITH D1/8 2DEC 1.0B-17 (0000004000)
D1/8            2DEC    1.0 B-3

D1/128          2DEC    1.0 B-7

D1/64           2DEC    1.0 B-6

D1/4            2DEC    1.0 B-2

D1/16           2DEC    1.0 B-4

D1/32           2DEC    1.0 B-5

D1/1024         2DEC    1.0 B-10

D1/256          2DEC    1.0 B-8

DP9/10          2DEC    .9

KEPZERO         EQUALS  LO6ZEROS
-50SC           2DEC    -50.0 B-12

2PISC           2DEC    6.28318530 B-6

BEE19           EQUALS  D1/32 -1        # 2DEC 1.0 B-19 (00000 01000)
BEE22           EQUALS  D1/256 -1       # 2DEC 1.0 B-22 (00000 00100)
ONEBIT          2DEC    1.0 B-28

COGUPLIM        2DEC    .999511597

COGLOLIM        2DEC    -.999511597
```

Uses CONICS1 57, COUNT 142, and LO6ZEROS 71.

1743 ⟨*Page CM1289* 1743⟩≡ (1710 2662)

```
                SETLOC  CONICS
                BANK

                COUNT   12/CONIC

TIMETHET        STQ     SETPD           #                               PL AT 0
                        RTNTT
                        0
                BOV
                        +1
                VLOAD   PDVL            # SETUP FOR PARAM CALL          PL AT 6
                        RVEC
                        VVEC
                CALL
                        PARAM
                BOV     CALL
                        COGAOVFL        #                               PL AT 0
                        GETX
COMMNOUT        DLOAD   BON
                        XI
                        INFINFLG
                        ABTCONIC
                CLEAR   CALL
                        COGAFLAG
                        DELTIME
                BON     CALL
                        RVSW
                        RTNTT
                        NEWSTATE
                GOTO
                        RTNTT

COGAOVFL        SETGO
                        COGAFLAG
                        ABTCONIC
                BANK    4
                SETLOC  CONICS1
                BANK
                COUNT*  $$/CONIC
PARAM           STQ     CLEAR           # MPAC=V1VEC, 0D=R1VEC          PL AT 6
                        RTNPRM
                        NORMSW
                CLEAR
                        COGAFLAG
                SSP     CALL
```

```
                GEOMSGN
                37777           # GAMMA ALWAYS LESS THAN 180DEG
                GEOM            # MPAC=SNGA (+1), 0D=CSGA (+1)  PL AT 2
        STODL   36D             # 36D=SIN GAMMA (+1)            PL AT 0
```

Uses COGAFLAG 127, CONICS 61, CONICS1 57, COUNT 142, GAMMA 232, GEOMSGN 188, INFINFLG 127, MPAC 145, NORMSW 123, R1VEC 188, RTNPRM 188, RTNTT 188, RVEC 188, RVSW 123, and VVEC 188.

1744 ⟨*Page CM1290* 1744⟩≡ (1710 2662)

```
        SR      DDV
                5

                36D
        STOVL*  COGA
                MUTABLE,1
        STODL   1/MU
                MAGVEC2
        DSQ     NORM
                X1
        DMPR    DMP
                1/MU
                R1
        SRR*
                0       -3,1
        PUSH    BDSU            # 0D=R1 V1SQ/MU (+6)          PL AT 2
                D1/32
        STODL   R1A             # R1A (+6)                     PL AT 0

        DMP     NORM
                36D
                X1
        DMP     SR*
                36D
                0       -4,1
        STCALL  P               # P (+4)
                RTNPRM
```

Uses MAGVEC2 188, P 188, R1A 188, RTNPRM 188, SR 80, and X1 85.

1745 ⟨*Page CM1291* 1745⟩≡ (1710 2662)

```
GEOM        UNIT                # MPAC=V2VEC, 0D=R1VEC        PL AT 6
            STODL   U2          # U2 (+1)
                    36D
            STOVL   MAGVEC2     #                             PL AT 0
            UNIT
            STORE   UR1         # UR1 (+1)
            DOT     SL1
                    U2
            PDDL                # 0D=CSTH (+1)                PL AT 2
                    36D
            STOVL   R1          # R1 (+29 OR +27)
                    UR1
            VXV     VSL1
                    U2
            BON     SIGN
                    NORMSW
                    HAVENORM
                    GEOMSGN
            UNIT    BOV
                    COLINEAR
UNITNORM    STODL   UN          # UN (+1)
                    36D
            SIGN    RVQ         # MPAC=SNTH (+1), 34D=SNTH.SNTH (+2)
                    GEOMSGN

COLINEAR    VSR1    GOTO
                    UNITNORM

HAVENORM    ABVAL   SIGN
                    GEOMSGN
            RVQ                 # MPAC=SNTH (+1), 34D=SNTH.SNTH (+2)
```

Uses CSTH 188, GEOMSGN 188, MAGVEC2 188, MPAC 145, NORMSW 123, R1VEC 188, SNTH 188, U2 188, UN 188, and UR1 188.

1746 ⟨*Page CM1292* 1746⟩≡ (1710 2662)

```
                BANK     12
                SETLOC   CONICS
                BANK

                COUNT    12/CONIC

GETX            AXT,2    SSP            # ASSUMES P (+4) IN MPAC
                         3
                         S2
                         1
                CLEAR
                         360SW
                SQRT     PDDL           # 0D=SQRT(P)                    PL AT 2
                         CSTH
                SR1      BDSU
                         D1/4
                PDDL     SRR            #                              PL AT 4D
                         SNTH
                         6
                DDV                     #                              PL AT 2
                BOV
                         360CHECK
                DSU      DMP
                         COGA           #                              PL AT 0
                SL2R     BOV
                         360CHECK
WLOOP           PUSH     DSQ            # 0D=W (+5)                    PL AT 2
                TLOAD    PDDL           # 2D=WSQ (+10)                  PL AT 5
                         MPAC
                         R1A
                SR4      TAD            #                              PL AT 2
                BMN      SQRT
                         INFINITY
                ROUND    DAD            #                              PL AT 0D
                BOV      TIX,2
                         RESETX2
                         WLOOP

                BDDV     BOV
                         D1/128
                         INFINITY
POLYCOEF        BMN      PUSH           # 0D=1/W (+2) OR 16/W (+6)      PL AT 2
                         INFINITY
                DSQ
                NORM     DMP
```

```
        X1
        R1A
SRR*    EXIT
        0       -10D,1
```

Uses CONICS 61, COUNT 142, CSTH 188, MPAC 145, P 188, R1A 188, S2 85, SNTH 188, W 183, and X1 85.

1748 ⟨*Page CM1293* 1748⟩≡ (1710 2662)

```
                TC      POLY
                DEC     5
                2DEC    .5

                2DEC    -.166666770

                2DEC    .100000392

                2DEC    -.071401086

                2DEC    .055503292

                2DEC    -.047264098

                2DEC    .040694204

                TC      INTPRET
                DMP     SL1R            #                               PL AT 0D
                PUSH    BON
                        360SW
                        TRUE360X
  XCOMMON       DSQ     NORM
                        X1
                DMP     SRR*
                        R1A
                        0       -12D,1
                STODL   XI              # XI (+6)

                        R1
                SR1     SQRT
                ROUND   DMP
                SL4R                    #                               PL AT 0
                STORE   X               # X (+17 OR +16)

                DSQ     NORM
                        X1
                PDDL    DMP             # 0D=XSQ (+34 OR +32 -N1)       PL AT 2
                        P
                        R1
                SL3     SQRT
                DMP     SL3R
                        COGA
                STODL   KEPC1
                        R1A
                BDSU    CLEAR
```

```
        D1/64
        INFINFLG
STORE   KEPC2
```

Uses INFINFLG 127, P 188, R1A 188, TC 169, and X1 85.

1750 ⟨*Page CM1294* 1750⟩≡ (1710 2662)

```
                RVQ

RESETX2         AXT,2
                        3

360CHECK        SETPD   BPL
                        OD
                        INVRSEQN
                SET
                        360SW

INVRSEQN        DLOAD   SQRT
                        P
                PDDL    DMP             # OD=SQRT(P) (+2)               PL AT 2
                        SNTH
                        COGA
                SL1     PDDL            # 2D=SNTH COGA (+5)              PL AT 4
                        CSTH
                SR4     DAD
                        D1/32
                DSU     DMP             #                               PL AT 2,0
                NORM    BDDV
                        X1
                        SNTH
                SLR*    ABS             # NOTE: NEAR 360 CASE TREATED DIFFERENTLY
                        0       -5,1
                PUSH    DSQ             # OD=1/W (-1)                   PL AT 2
                STODL   34D
                        D1/16
1/WLOOP         PUSH    DSQ             # 2D=G (+4)                     PL AT 4
                RTB     PDDL            #                               PL AT 7
                        TPMODE
                        R1A
                DMP     SR4
                        34D
                TAD
                BMN     SQRT            #                               PL AT 4
                        INFINITY
                DAD                     #                               PL AT 2
                TIX,2   NORM
                        1/WLOOP
                        X1
                BDDV
                SLR*    GOTO            #                               PL AT 0
                        0       -7,1
```

```
                        POLYCOEF
```

Uses CSTH 188, P 188, R1A 188, SNTH 188, W 183, and X1 85.

1751 ⟨*Page CM1295* 1751⟩≡ (1710 2662)

```
TRUE360X        DLOAD   BMN
                        R1A
                        INFINITY
                SQRT    NORM
                        X1
                BDDV    SL*
                        2PISC
                        0       -3,1
                DSU     PUSH            # OD=2PI/SQRT(R1A) -X          PL AT 0,2
                GOTO
                        XCOMMON
INFINITY        SETPD   BOV             # NO SOLUTION EXISTS SINCE CLOSURE THROUGH
                        0               # INFINITY IS REQUIRED
                        OVFLCLR
OVFLCLR         SET     RVQ
                        INFINFLG
```

Uses INFINFLG 127, R1A 188, and X1 85.

1752 ⟨*Page CM1296* 1752⟩≡ (1710 2662)

```
LAMBERT         STQ     SETPD
                        RTNLAMB
                        0D
                BOV
                        +1
                SSP     VLOAD*
                        ITERCTR
                        20D
                        MUTABLE,1
                STODL   1/MU
                        TDESIRED
                DMPR
                        BEE19
                STORE   EPSILONL
                SET     VLOAD
                        SLOPESW
                        R1VEC
                PDVL    CALL            # 0D=R1VEC (+29 OR +27)         PL AT 6
                        R2VEC           # MPAC=R2VEC (+29 OR +27)
                        GEOM
                STODL   SNTH            # 0D=CSTH (+1)                  PL AT 2
                        MAGVEC2
                NORM    PDDL            #                               PL AT 4
                        X1
                        R1
                SR1     DDV             #                               PL AT 2
                SL*     PDDL            # DXCH WITH 0D, 0D=R1/R2 (+7)   PL AT 0,2
                        0       -6,1
                STADR
                STORE   CSTH            # CSTH (+1)
                SR1     BDSU
                        D1/4
                STORE   1-CSTH          # 1-CSTH (+2)

                ROUND   BZE
                        360LAMB
                NORM    PDDL            #                               PL AT 4
                        X1
                        0D
                SR1     DDV             #                               PL AT 2
                SL*     SQRT
                        0       -3,1
                PDDL    SR              # 2D=SQRT(2R1/R2(1-CSTH)) (+5)  PL AT 4
                        SNTH
                        6
```

```
DDV     DAD             #                               PL AT 2
        1-CSTH
STADR
STORE   COGAMAX
BOV     BMN             # IF OVFL, COGAMAX=COGUPLIM
```

Uses 1-CSTH 188, CSTH 188, MAGVEC2 188, MPAC 145, R1VEC 188, R2 188, R2VEC 188, RTNLAMB 188, SLOPESW 101, SNTH 188, SR 80, TDESIRED 188, and X1 85.

1754 ⟨*Page CM1297* 1754⟩≡ (1710 2662)

```
                        UPLIM           # IF NEG, USE EVEN IF LT COGLOLIM, SINCE
                        MAXCOGA         #       THIS WOULD BE RESET IN LAMBLOOP
                DSU     BMN             # IF COGAMAX GT COGUPLIM, COGAMAX=COGUPLIM
                        COGUPLIM
                        MAXCOGA         # OTHERWISE OK, SO GO TO MAXCOGA
UPLIM           DLOAD
                        COGUPLIM        # COGUPLIM=.999511597 = MAX VALUE OF COGA
                STORE   COGAMAX         #       NOT CAUSING OVFL IN R1A CALCULATION
MAXCOGA         DLOAD
                        CSTH
                SR      DSU             #                               PL AT 0
                        6
                STADR
                STODL   CSTH-RHO
                        GEOMSGN
                BMN     DLOAD
                        LOLIM
                        CSTH-RHO
                SL1     DDV
                        SNTH
                BOV
                        LOLIM
MINCOGA         STORE   COGAMIN         # COGAMIN (+5)
                BON     SSP
                        GUESSW
                        NOGUESS
                        TWEEKIT
                        00001
                DLOAD
                        COGA

LAMBLOOP        DMP
                        SNTH
                SR1     DSU
                        CSTH-RHO
                NORM    PDDL            # 0D=SNTH COGA-(CSTH-RHO) (+7+C(XI)) PL=2
                        X1
                        1-CSTH
                SL*     DDV             # 1-CSTH (+2)                   PL AT 0
                        0 -9D,1
                BMN     BZE
                        NEGP
                        NEGP
                STODL   P               # P=(1-CSTH)/(SNTH COGA-(CSTH-RHO)) (+4)
                        COGA
```

```
DSQ     DAD
        D1/1024
NORM    DMP
        X1
```

Uses 1-CSTH 188, CSTH 188, CSTH-RHO 188, GEOMSGN 188, GUESSW 101, P 188, R1A 188, RHO 211, SNTH 188, SR 80, and X1 85.

1756 ⟨*Page CM1298* 1756⟩≡ (1710 2662)

```
                        P
                SR*     BDSU
                        0       -8D,1
                        D1/32
                STODL   R1A             # R1A=2-P(1+COGA COGA) (+6)

                        P
                BOV     CALL
                        HIENERGY
                        GETX
                DLOAD
                        T
                STODL   TPREV
                        XI
                BON     CALL
                        INFINFLG
                        NEGP            # HAVE EXCEEDED THEORETICAL BOUNDS
                        DELTIME
                BOV     BDSU
                        BIGTIME
                        TDESIRED
                STORE   TERRLAMB
                ABS     BDSU
                        EPSILONL
                BPL     RTB
                        INITV
                        CHECKCTR
                BHIZ    CALL
                        SUFFCHEK
                        ITERATOR
                DLOAD   BZE
                        MPAC
                        SUFFCHEK
                DAD
                        COGA
                STCALL  COGA
                        LAMBLOOP

NEGP            DLOAD   BPL             # IMPOSSIBLE TRAJECTORY DUE TO INACCURATE
                        DCOGA           # BOUND CALCULATION.  TRY NEW COGA.
                        LOENERGY

HIENERGY        SETPD   DLOAD           # HIGH ENERGY TRAJECTORY RESULTED.
                        0
                        COGA            # IN OVFL OF P OR R1A, OR XI EXCEEDING 50.
```

```
                STORE   COGAMIN         # THIS IS THE NEW BOUND.
COMMONLM        DLOAD   SR1
                        DCOGA
```

Uses INFINFLG 127, MPAC 145, P 188, R1A 188, SR 80, TDESIRED 188, TERRLAMB 188, and TPREV 188.

1758 ⟨*Page CM1299* 1758⟩≡ (1710 2662)

```
                STORE   DCOGA           # USE DCOGA/2 AS DECREMENT
                BZE     BDSU
                        SUFFCHEK
                        COGA
                STCALL  COGA
                        LAMBLOOP

BIGTIME         DLOAD
                        TPREV
                STORE   T

LOENERGY        SETPD   DLOAD           # LOW ENERGY TRAJECTORY RESULTED
                        0
                        COGA            # IN OVERFLOW OF TIME.
                STCALL  COGAMAX         # THIS IS THE NEW BOUND.
                        COMMONLM

SUFFCHEK        DLOAD   ABS
                        TERRLAMB
                PDDL    DMP
                        TDESIRED        #                               PL AT 2D
                        D1/4
                DAD     DSU             #                               PL AT 0D
                        ONEBIT
                BPL     SETGO
                        INITV
                        SOLNSW
                        RTNLAMB

360LAMB         SETPD   SETGO           # LAMBERT CANNOT HANDLE CSTH=1
                        0
                        SOLNSW
                        RTNLAMB

NOGUESS         SSP     DLOAD
                        TWEEKIT
                        20000
                        COGAMIN
                SR1     PDDL            #                               PL AT 2
                        COGAMAX
                SR1     DAD
                STADR                   #                               PL AT 0
                STORE   COGA
                STCALL  DCOGA
                        LAMBLOOP
```

Uses CSTH 188, RTNLAMB 188, SOLNSW 115, TDESIRED 188, TERRLAMB 188, and TPREV 188.

1759 ⟨*Page CM1300* 1759⟩≡ (1710 2662)

```
LOLIM           DLOAD   GOTO
                        COGLOLIM        # COGLOLIM=-.999511597
                        MINCOGA

INITV           DLOAD   NORM
                        R1
                        X1
                PDDL    SR1             #                               PL AT 2
                        P
                DDV                     #                               PL AT 0
                SL*     SQRT
                        0       -4,1
                DMP     SL1
                        ROOTMU
                PUSH    DMP             # OD=VTAN (+7)                  PL AT 2
                        COGA
                SL      VXSC
                        5
                        UR1
                PDDL                    # XCH WITH OD                   PL AT 0,6
                VXSC    VSL1
                        UN
                VXV     VAD
                        UR1             #                               PL AT 0
                VSL1    CLEAR
                        SOLNSW
                STORE   VVEC
                SLOAD   BZE
                        VTARGTAG
                        TARGETV
                GOTO
                        RTNLAMB

TARGETV         DLOAD   CALL
                        MAGVEC2
                        LAMENTER
                STCALL  VTARGET
                        RTNLAMB
```

Uses MAGVEC2 188, P 188, RTNLAMB 188, SOLNSW 115, UN 188, UR1 188, VTARGET 188, VTARGTAG 188, VVEC 188, and X1 85.

1760 ⟨*Page CM1301* 1760⟩≡ (1710 2662)

```
TIMERAD     STQ     SETPD       #                           PL AT 0
                    RTNTR
                    0
            BOV
                    +1
            VLOAD   PDVL        #                           PL AT 6
                    RVEC
                    VVEC
            CALL
                    PARAM
            BOV     DLOAD
                    COGAOVFL    #                           PL AT 0
                    D1/32
            DSU     DMP
                    R1A
                    P
            SQRT    DMP
                    COGA
            SL4     VXSC
                    U2
            PDDL    DSU         #                           PL AT 6
                    D1/64
                    R1A
            VXSC    VSU         #                           PL AT 0
                    UR1
            VSL4    UNIT
            BOV
                    CIRCULAR
            PDDL    NORM        # 0D=UNIT(ECC) (+3)         PL AT 6
                    RDESIRED    # 35D=ECC (+3)
                    X1
            PDDL    DMP         #                           PL AT 8
                    R1
                    P
            SL*     DDV         #                           PL AT 6
                    0,1
            DSU     DDV
                    D1/16
                    36D         # 36D=ECC (+3)
            STORE   COSF
            BOV     DSQ
                    BADR2
            BDSU    BMN
                    D1/4
                    BADR2
```

```
SQRT    SIGN
        SGNRDOT
CLEAR
        APSESW
```

Uses APSESW 127, ECC 188, P 188, R1A 188, RDESIRED 188, RTNTR 188, RVEC 188, SGNRDOT 188, U2 188, UR1 188, VVEC 188, and X1 85.

1762 ⟨*Page CM1302* 1762⟩≡ (1710 2662)

```
TERMNVEC        VXSC    VSL1
                        UN
                VXV     PDVL            # VXCH WITH OD          PL AT 0,6
                        OD
                VXSC    VAD             #                       PL AT 0
                        COSF
                VSL1    PUSH            # OD=U2                  PL AT 6

                DOT     DDV             # LIMITS RESULT TO POSMAX OR NEGMAX
                        UR1
                        DP1/4
                SR1     BOV             # SCALE BACK DOWN TO NORMAL
                        +1              # CLEAR OVFIND IF SET
                STOVL   CSTH            # CSTH (+1)
                        UR1
                VXV     VSL1
                DOT     SL1
                        UN
                STODL   SNTH            # SNTH (+1)
                        P
                CALL
                        GETX
                CLRGO
                        SOLNSW
                        COMMNOUT

CIRCULAR        SETPD   SETGO
                        0
                        SOLNSW
                        ABTCONIC

BADR2           DLOAD   SIGN
                        LODPHALF
                        COSF
                STODL   COSF
                        KEPZERO
                SETGO
                        APSESW
                        TERMNVEC
```

Uses APSESW 127, CSTH 188, LODPHALF 71, OVFIND 140, P 188, SNTH 188, SOLNSW 115, U2 188, UN 188, and UR1 188.

1763 ⟨*Page CM1303* 1763⟩≡ (1710 2662)

```
APSIDES         STQ     SETPD           #                       PL AT 0
                        RTNAPSE
                        OD
                BOV
                        +1
                VLOAD   PDVL            #                       PL AT 6
                        RVEC
                        VVEC
                CALL
                        PARAM
                BOV                     #                       PL AT 0
                        GETECC
GETECC          DMP     SL4
                        R1A
                BDSU    SQRT
                        D1/64
                STORE   ECC
                DAD     PDDL            #                       PL AT 2
                        D1/8
                        R1
                DMP     SL1
                        P
                DDV                     #                       PL AT 0
                PDDL    NORM            # OD=RP (+29 OR +27)    PL AT 2
                        R1A
                        X1
                PDDL    SL*             #                       PL AT 4
                        R1
                        0       -5,1
                DDV     DSU             #                       PL AT 2,0
                BOV     BMN
                        INFINAPO
                        INFINAPO
                GOTO
                        RTNAPSE
INFINAPO        DLOAD   GOTO            # RETURNS WITH APOAPSIS IN MPAC, PERIAPSIS
                        LDPOSMAX
                        RTNAPSE         # THAT PL IS AT 0.
```

Uses `ECC` 188, `MPAC` 145, `P` 188, `R1A` 188, `RTNAPSE` 188, `RVEC` 188, `VVEC` 188, and `X1` 85.

1764 ⟨*Page CM1304* 1764⟩≡ (1710 2662)

```
ABTCONIC        EXIT
                TC      P00D00
                OCT     00607
```

Uses TC 169.

1765 ⟨*Page CM1305* 1765⟩≡ (1710 2662)

```
                SETLOC  CONICS1
                BANK

                COUNT   04/CONIC

MUTABLE         2DEC*   3.986032 E10 B-36*      # MUE

                2DEC*   .25087606 E-10 B+34*    # 1/MUE

                2DEC*   1.99650495 E5 B-18*     # SQRT(MUE)

                2DEC*   .50087529 E-5 B+17*     # 1/SQRT(MUE)

                2DEC    4.902778 E8 B-30        # MUM

                2DEC    .203966 E-8 B+28        # 1/MUM

                2DEC*   2.21422176 E4 B-15*     # SQRT(MUM)

                2DEC*   .45162595 E-4 B+14*     # 1/SQRT(MUM)

LDPOSMAX        EQUALS  LODPMAX                 # DPPOSMAX IN LOW MEMORY.

# ERASABLE ASSIGNMENTS

# KEPLER SUBROUTINE

# INPUT --
# RRECT         ERASE   +5
# VRECT         ERASE   +5
# TAU.          ERASE   +1
# XKEP          ERASE   +1
# TC            ERASE   +1
# XPREV         ERASE   +1
1/MU            EQUALS  14D
ROOTMU          EQUALS  16D
1/ROOTMU        EQUALS  18D

# OUTPUT --
# RCV           ERASE   +5
# VCV           ERASE   +5
# RC            ERASE   +1
# XPREV         ERASE   +1

# DEBRIS --
```

```
ALPHA           EQUALS  8D
XMAX            EQUALS  10D
```

Uses CONICS1 57, COUNT 142, RCV 169, RRECT 169, TAU 211, TAU. 177, TC 169, VCV 169, VRECT 169, XKEP 169, and XPREV 188.

1767 ⟨*Page CM1306* 1767⟩≡ (1710 2662)

```
XMIN            EQUALS  12D
X               EQUALS  20D
XI              EQUALS  24D
S(XI)           EQUALS  26D
XSQC(XI)        EQUALS  28D
T               EQUALS  30D
R1              EQUALS  32D
KEPC1           EQUALS  34D
KEPC2           EQUALS  36D

# DELX          ERASE   +1
# DELT          ERASE   +1
# URRECT        ERASE   +5
# RCNORM        ERASE   +1
# XPREV         EQUALS  XKEP


# LAMBERT SUBROUTINE
#
# INPUT --
# R1VEC         ERASE   +5
# R2VEC         ERASE   +5
# TDESIRED      ERASE   +1
# GEOMSGN       ERASE   +0
# GUESSW                        # 0 IF COGA GUESS AVAILABLE, 1 IF NOT
# COGA          ERASE   +1      # INPUT ONLY IF GUESS IS ZERO.
# NORMSW                        # 0 IF UN TO BE COMPUTED, 1 IF UN INPUT
# UN            ERASE   +5      # ONLY USED IF NORMSW IS 1
# VTARGTAG      ERASE   +0
# TWEEKIT       EQUALS  40D     # ONLY USED IF GUESSW IS 0

# OUTPUT --
# VTARGET       ERASE   +5      # AVAILABLE ONLY IF VTARGTAG IS ZERO.
# V1VEC         EQUALS  MPAC

# DEBRIS --
# RTNLAMB       ERASE   +0
# U2            ERASE   +5
# MAGVEC2       ERASE   +1
# UR1           ERASE   +5
# R1            EQUALS  31D
# UN            ERASE   +5
# SNTH          ERASE   +1
# CSTH          ERASE   +1
# 1-CSTH        ERASE   +1
```

```
# CSTH-RHO      ERASE   +1

COGAMAX         EQUALS  14D     # CLOBBERS 1/MU
COGAMIN         EQUALS  8D
DCOGA           EQUALS  12D

# TWEEKIT       EQUALS  40D
# P             ERASE   +1
```

Uses 1-CSTH 188, CSTH 188, CSTH-RHO 188, DELT 188, DELX 188, GEOMSGN 188, GUESSW 101, MAGVEC2 188, MPAC 145, NORMSW 123, P 188, R1VEC 188, R2VEC 188, RCNORM 188, RHO 211, RTNLAMB 188, SNTH 188, TDESIRED 188, U2 188, UN 188, UR1 188, URRECT 188, VTARGET 188, VTARGTAG 188, XKEP 169, and XPREV 188.

1769 ⟨*Page CM1307* 1769⟩≡ (1710 2662)

```
# COGA          ERASE   +1
# R1A           ERASE   +1
# X             EQUALS  20D
# XSQ           EQUALS  22D
# XI            EQUALS  24D
# S(XI)         EQUALS  26D
# XSQC(XI)      EQUALS  28D
# T             EQUALS  30D
# KEPC1         EQUALS  34D
# KEPC2         EQUALS  36D
# SLOPSW
# SOLNSW

# OTHERS --
# RVEC          EQUALS  R1VEC
# VVEC          ERASE   +5
# COGAFLAG
# RVSW
# INFINFLG
# APSESW
# 360SW
# RTNTT         EQUALS  RTNLAMB
# ECC           ERASE   +1
# RTNTR         EQUALS  RTNLAMB
# RTNAPSE       EQUALS  RTNLAMB
# R2            EQUALS  MAGVEC2

COSF            EQUALS  24D

# RTNPRM        ERASE   +0
# SCNRDOT       ERASE   +0
# RDESIRED      ERASE   +1


# ITERATOR SUBROUTINE

# ORDERSW
MAX             EQUALS  14D             # CLOBBERS 1/MU
MIN             EQUALS  8D

# INDEP         ERASE   +1

DELINDEP        EQUALS  12D
ITERCTR         EQUALS  22D
DEP             EQUALS  30D
```

```
# DELDEP        ERASE   +1
# DEPREV        ERASE   +1

TWEEKIT         EQUALS  40D


# MORE KEPLER

# EPSILONT      ERASE   +1
```

Uses APSESW 127, COGAFLAG 127, DELDEP 188, DEPREV 188, ECC 188, EPSILONT 165, INFINFLG 127, MAGVEC2 188, ORDERSW 127, R1A 188, R1VEC 188, R2 188, RDESIRED 188, RTNAPSE 188, RTNLAMB 188, RTNPRM 188, RTNTR 188, RTNTT 188, RVEC 188, RVSW 123, SOLNSW 115, and VVEC 188.

1770 ⟨*Page CM1308* 1770⟩≡ (1710 2662)

```
# MORE LAMBERT

# TERRLAMB      EQUALS  DELDEP
# TPREV         EQUALS  DEPREV

# EPSILONL      EQUALS  EPSILONT +2     # DOUBLE PRECISION WORD
```

Uses DELDEP 188, DEPREV 188, EPSILONT 165, TERRLAMB 188, and TPREV 188.

3.7.13 integration initialization

1771 ⟨*integration initialization* 1771⟩≡ (1523a)

⟨*Page CM1309* 1772⟩
⟨*Page CM1310* 1774⟩
⟨*Page CM1311* 1776⟩
⟨*Page CM1312* 1778⟩
⟨*Page CM1313* 1780⟩
⟨*Page CM1314* 1782⟩
⟨*Page CM1315* 1784⟩
⟨*Page CM1316* 1786⟩
⟨*Page CM1317* 1788⟩
⟨*Page CM1318* 1790⟩
⟨*Page CM1319* 1792⟩
⟨*Page CM1320* 1794⟩
⟨*Page CM1321* 1796⟩
⟨*Page CM1322* 1797⟩
⟨*Page CM1323* 1798⟩
⟨*Page CM1324* 1800⟩
⟨*Page CM1325* 1802⟩
⟨*Page CM1326* 1803⟩
⟨*Page CM1327* 1804⟩
⟨*Page CM1328* 1805⟩
⟨*Page CM1329* 1806⟩
⟨*Page CM1330* 1808⟩
⟨*Page CM1331* 1810⟩
⟨*Page CM1332* 1812⟩
⟨*Page CM1333* 1813a⟩

1772 ⟨*Page CM1309* 1772⟩≡ (1771 2718)

```
# 1.0 INTRODUCTION
# ----------------
#
# FROM A USER'S POINT OF VIEW, ORBITAL INTEGRATION IS ESSENTIALLY THE SAME AS THE 278
# PROGRAM.  THE SAME ENTRANCES TO THE PROGRAM WILL BE MAINTAINED, THE SAME STALLING P
# OUTPUT WILL STILL BE VIA THE PUSHLIST.  THE PRIMARY DIFFERENCES TO A USER INVOLVE T
# TERMINATING INTEGRATION AT A SPECIFIC FINAL RADIUS AND THE DIFFERENCE IN STATE VECT
# THE LUNAR SPHERE OF INFLUENCE.
#
# IN ORDER TO MAKE THE CSM(LEM)PREC AND CSM(LEM)CONIC ENTRANCES SIMILAR TO FLIGHT 278
# WILL ITSELF SET THE FINAL RADIUS (RFINAL) TO 0 SO THAT REACHING THE DESIRED TIME ON
# INTEGRATION.  THE DP REGISTER RFINAL MUST BE SET BY USERS OF INTEGRVS AND INTEGRV,
# CALL TC INTSTALL.
#
# WHEN THE LM IS ON THE LUNAR SURFACE (INDICATED BY LUNAR SURFACE FLAG SET) CALLS TO
# INTEGRV WITH VINFLAG = 0 WILL RESULT IN THE USE OF THE PLANETARY INERTIAL ORIENTATI
# BOTH THE LM'S POSITION AND VELOCITY IN THE REFERENCE COORDINATE SYSTEM.
# THE PROGRAM WILL PROVIDE OUTPUT AS IF INTEGRATION WAS USED.  THAT IS, THE PUSHLIST
# THE PERMANENT STATE VECTOR UPDATED WHEN SPECIFIED BY AN INTEGRV CALL.
#
# USERS OF INTEGRVS DESIRING INTEGRATION (INTYPFLG = 0) SHOULD NOTE THAT THE OBLATENE
# IN LUNAR ORBIT IS TIME DEPENDENT.  THEREFORE, THE USER SHOULD SUPPLY AN INITIAL STA
# TIME AND THE DESIRED TIME (TDEC1) ALSO AT SOME REAL TIME.  FOR CONIC "INTEGRATION"
# AS THE INITIAL TIME AND DELTA TIME AS THE DESIRED TIME.
#
# 2.0 CENTRAL DESCRIPTION
# -----------------------
#
# THE INTEGRATION PROGRAM OPERATES AS A CLOSED INTERPRETIVE SUBROUTINE AND PERFORMS T
#       1) INTEGRATES (PRECISION OR CONIC) EITHER CSM OR LM STATE VECTOR
#       2) INTEGRATES THE W-MATRIX
#       3) PERMANENT OR TEMPORARY UPDATE OF THE STATE VECTOR
#
# THERE ARE SIX ENTRANCES TO THE INTEGRATION PROGRAM.  FOUR OF THESE (CSMPREC, LEMPRE
# ALL THE FLAGS REQUIRED IN THE INTEGRATION PROGRAM ITSELF TO CAUSE THE PRECISION OR
# THE LM OR CSM STATE VECTOR, AS THE NAMES SUGGEST.  ONE ENTRANCE (INTEGRVS) PERMITS
# PROVIDE A STATE VECTOR TO BE INTEGRATED.  THE CALLING PROGRAM MUST SET THE FLAGS IN
# CONIC INTEGRATION, (2) IN OR OUT OF LUNAR SPHERE, (3) MIDCOURSE OR NOT, AND THE INT
# THE FLAG SETTING TO BYPASS W-MATRIX INTEGRATION.  THE LAST ENTRANCE (INTEGRV, USED
# NAVIGATION PROGRAMS) PERMITS THE CALLER TO SET FIVE FLAGS (NOT MOONFLAG OR MIDFLAG)
# VECTOR.  ANY PROGRAM WHICH CALLS INTEGRVS OR INTEGRV MUST CALL INTSTALL BEFORE IT S
# AND/OR STATE VECTOR.
#
# THREE SETS OF 42 REGISTERS AND 2 FLAGS ARE USED FOR THE STATE VECTORS.  TWO SETS, W
# USED FOR THE PERMANENT STATE VECTORS FOR THE CSM AND LM.  THE THIRD SET, WHICH MAY
```

```
# IS NOT BEING DONE, IS USED IN THE COMPUTATIONS.
#
# THE PERMANENT STATE VECTORS WILL BE PERIODICALLY UPDATED SO THAT THE VECTORS WILL NOT BE OLDE
# THE PERMANENT STATE VECTORS WILL ALSO BE UPDATED WHENEVER THE W-MATRIX IS INTEGRATED OR WHEN
# SETS STATEFLG (THE NAVIGATION PROGRAMS P20, P22.)
#
```

Uses `A` 80, `INTYPFLG` 107, `IT` 185, `MIDFLAG` 95, `MOONFLAG` 95, `ORBITAL` 59, `STATE` 138, `STATEFLG` 107, `TC` 169, and `W` 183.

1774 ⟨*Page CM1310* 1774⟩≡ (1771 2718)

```
# APPENDIX B OF THE USERS' GUIDE LISTS THE STATE VECTOR QUANTITIES.
#
# 2.1 RESTARTS
#
# PHASE CHANGES WILL BE MADE IN THE INTEGRATION PROGRAM ONLY FOR THE INTEGRV ENTRANCE
# INTEGRATED OR PERMANENT STATE VECTOR IS UPDATED.)  THE GROUP NUMBER USED WILL BE TH
# (I.E., GROUP2) WINCE THE INTEGRV ENTRANCE WILL ONLY BE USED BY THESE PROGRAMS.  IF
# INTEGRATION OF THE STATE VECTOR ONLY, THE RECOVERY WILL BE TO THE LAST PHASE IN THE
# PROGRAMS WHICH USE THE INTEGRV OR INTEGRVS ENTRANCE OF INTEGRATION WHOULD ENSURE TH
# THAT IT IS PRIOR TO SETTING THE INTEGRATION INPUTS IN THE PUSHLIST.
# THIS IS BECAUSE THE PUSHLIST IS LOST DURING A RESTART.
#
# 2.2 SCALING
#
# THE INTEGRATION ROUTINE WILL MAINTAIN THE PERMANENT MEMORY STATE VECTORS IN THE SCA
# APPENDIX B OF THE USERS' GUIDE.  THE SCALING OF THE OUTPUT POSITION VECTOR DEPENDS
# SYSTEM AT THE DESIRED INTEGRATION TIME.  THE COORDINATE SYSTEM TRANSFORMATION WILL
# MULTIPLE TIMESTEP ENCKE INTEGRATION ONLY.  THUS IT IS POSSIBLE TO HAVE OUTPUT FROM
# DIFFERENT SCALING.
# HOWEVER, RATT, VATT WILL ALWAYS BE SCALED THE SAME.
#
# 3.0 INPUT/OUTPUT
# ----------------
#
# PROGRAM INPUTS ARE THE FLAGS DESCRIBED IN APPENDIX A AND THE PERMANENT STATE VECTOR
# APPENDIX B OF THE USERS' GUIDE, PLUS THE DESIRED TIME TO INTEGRATE TO IN TDEC1 (A P
# FOR INTEGRVS, THE RCV,VCV,TET OR THE TEMPORARY STATE VECTOR MUST BE SET, PLUS MOONP
#
# FOR SIMULATION THE FOLLOWING QUANTITIES MUST BE PRESET ---
#                                                                          EARTH
#                                                                           29
#       RRECTCSM(LEM)           RECTIFIED POSITION VECTOR       METERS     2
#
#                                                                           7
#       VRECTCSM(LEM)           RECTIFIED VELOCITY VECTOR       M/CSEC     2
#
#                                                                           28
#       TETCSM(LEM)             TIME STATE VECTOR IS VALID      CSEC       2
#                               CUSTOMARILY 0, BUT NOTE LUNAR
#                               ORBIT DEPENDENCE ON REAL TIME.
#
#                                                                           22
#       DELTAVCSM(LEM)          POSITION DEVIATION              METERS     2
#                               0 IF TCCSM(LEM) = 0
#
```

```
#                                                                                  3       -1
#       NUVCSM(LEM)             VELOCITY DEVIATION              M/CSEC          2       2
#                               0 IF TCCSM(LEM) = 0
```

Uses A 80, I 206, IT 185, MIDFLAG 95, MOONFLAG 95, NUVCSM 172, RCV 169, RESTART 57, RRECTCSM 172, STATE 138, TCCSM 172, TET 169, TETCSM 172, VCV 169, VRECTCSM 172, and W 183.

1776 ⟨*Page CM1311* 1776⟩≡ (1771 2718)

```
#                                                                          29
#       RCVSM(LEM)              CONIC POSITION                  METERS     2
#                               EQUALS RRECTCSM(LEM) IF
#                               TCCSM(LEM) = 0
#
#                                                                           7
#       VCVCSM(LEM)             CONIC VELOCITY                  M/CSEC     2
#                               EQUALS VRECTCSM(LEM) IF
#                               TCCSM(LEM) = 0
#
#                                                                          28
#       TCCSM(LEM)              TIME SINCE RECTIFICATION        CSECS      2
#                               CUSTOMARILY 0
#
#                                                                 1/2      17
#       XKEPCSM(LEM)            RDOT OF KEPLER'S EQUATION       M          2
#                               0 IF TCCSM(LEM) = 0
#
#       CMOONFLG                PERMANENT FLAGS CORRESPONDING              0
#       CMIDFLAG                TO MOONFLAG AND MIDFLAG                    0,1
#       LMOONFLG                C = CSM, L = LM                            0
#       LMIDFLG                                                            0,1
#
#       SURFFLAG                LUNAR SURFACE FLAG                         0,1
#
# IN ADDITION, IF (L)CMIDFLAG IS SET, THE INITIAL INPUT VALUES FOR LUNAR
# SOLAR EPHEMERIDES SUBROUTINE AND PLANETARY INERTIAL ORIENTATION SUB-
# ROUTINE MUST BE PRESET.
#
# OUTPUT
#       AFTER EVERY CALL TO INTEGRATION
#                                                                 EARTH   MOON
#                                                                  29      29
#       0D      RATT    POSITION                        METERS    2       2
#
#                                                                   7       7
#       6D      VATT    VELOCITY                        M/CSEC    2       2
#
#                                                                  28      28
#       12D     TAT     TIME                                      2       2
#
#                                                                  29      27
#       14D     RATT1   POSITION                        METERS    2       2
#
#                                                                   7       5
```

```
#       20D     VATT1   VELOCITY                        M/CSEC          2       2
#
#                                                        3   2           36      30
#       26D     MU(P)   MU                              M /CS           2       2
#
#       X1              MUTABLE ENTRY                                   -2      -10D
#
#       X2              COORDINT
#       X2              COORDINATE SYSTEM ORIGIN                        0       2
#                       (THIS, NOT MOONFLAG, SHOULD BE
```

Uses CMOONFLG 125, L 80, LMOONFLG 125, MIDFLAG 95, MOONFLAG 95, P 188, RDOT 229, RRECTCSM 172, SURFFLAG 127, TCCSM 172, VCVCSM 172, VRECTCSM 172, X1 85, X2 85, and XKEPCSM 172.

1778 ⟨*Page CM1312* 1778⟩≡ (1771 2718)

```
#                       USED TO DETERMINE ORIGIN.)
#
# IN ADDITION TO THE ABOVE, THE PERMANENT STATE VECTOR IS UPDATED WHENEVER
# STATEFLG WAS SET AND WHENEVER A W-MATRIX IS TO BE INTEGRATED.  THE PUSH
# COUNTER IS SET TO 0 AND OVERFLOW IS CLEARED BEFORE RETURNING TO THE
# CALLING PROGRAM.
#
# 4.0 CALLING SEQUENCES AND SAMPLE CODE
# -------------------------------------
#
#       A) PRECISION ORBITAL INTEGRATION.  CSMPREC, LEMPREC ENTRANCES
#               L-X     STORE TIME TO 96T5791T5 T 95 PUS L9ST (T4531)
#               L       CALL
#               L+1             CSMPREC (OR LEMPREC)
#               L+2     RETURN
#          INPUT                                                          28
#               TDEC1 (PD 32D) TIME TO INTEGRATE TO...CENTISECONDS SCALED 2
#          OUTPUT
#               THE DATA LISTED IN SECTION 3.2 PLUS
#               RQVV    POSITION VECTOR OF VEHICLE WITH RESPECT TO SECONDARY
#               BODY... METERS B-29 ONLY IF MIDFLAG = DIMOFLAG = 1
#       B) CONIC INTEGRATION.  CSMCONIC, LEMCONIC ENTRANCES
#               L-X     STORE TIME IN PUSH LIST (TDEC1)
#               L       CALL
#               L+1             CSMCONIC (OR LEMCONIC)
#          INPUT/OUTPUT
#               SAME AS PRECISION INTEGRATION, EXCEPT RQVV NOT SET
#       C) INTEGRATE GIVEN STATE VECTOR.  INTEGRVS ENTRANCE
#               CALL
#                               INTSTALL
#               VLOAD
#                               POSITION VECTOR
#               STOVL           RCV
#                               VELOCITY VECTOR
#               STODL           VCV
#                               TIME STATE VECTOR VALID
#               STODL           TET
#                               FINAL RADIUS
#               STORE           RFINAL
#               SET(CLEAR)      SET(CLEAR)
#                               INTYPFLAG
#                               MOONFLAG
#               SET(CLEAR)      DLOAD
#                               DESIRED TIME
#               STCALL          TDEC1
```

```
#                                INTEGRVS
#         INPUT
#               RCV     POSITION VECTOR                 METERS
#               VCV     VELOCITY VECTOR                 M/CSEC
#               TET     TIME OF STATE VECTOR (MAY = 0)  CSEC B-28
```

Uses A 80, CODE 140, DIMOFLAG 109, L 80, MIDFLAG 95, MOONFLAG 95, ORBITAL 59, RCV 169, RQVV 177, STATE 138, STATEFLG 107, TET 169, VCV 169, and W 183.

1780 ⟨*Page CM1313* 1780⟩≡ (1771 2718)

```
#               TDEC1   TIME TO INTEGRATE TO            CSEC B-28 (PD 32D)
#                       (MAY BE INCREMENT IF TET=0)
#         OUTPUT
#               SAME AS FOR PRECISION OR CONIC INTEGRATION,
#               DEPENDING ON INTYPFLG.
#       D) INTEGRATE STATE VECTOR.  INTGRV ENTRANCE
#               L-X     STORE TIME IN PUSH LIST (TDEC1) (MAY BE DONE AFTER CALL TO IN
#               L-8     CALL
#               L-7
#               L-6     SET(CLEAR)      SET(CLEAR)
#               L-5                     VINTFLAG        1=CSM, 0=LM
#               L-4                     INTYPFLAG       1=CONIC, 0=PRECISION
#               L-3     SET(CLEAR)      SET(CLEAR)
#               L-2                     DIM0FLAG        1=W-MATRIX, 0=NO W-MATRIX
#               L-1                     D6OR9FLG        1=9X9, 0=6X6
#               L       SET             DLOAD
#               L+1                     STATEFLG        DESIRE PERMANENT UPDATE
#               L+2                     FINAL RAD.      OF STATE VECTOR
#               L+3     STCALL          RFINAL
#               L+4                     INTEGRV
#               L       CALL                            NORMAL USE -- WILL UPDATE STA
#               L+1                     INTEGRV         VECTOR IF DIM0FLAG=1. (STATE
#               L+2     RETURN                          ALWAYS RESET IN INTEGRATION A
#                                                       IT USED.)
#         INPUT
#               TDEC1 (PD 32D) TIME TO INTEGRATE TO     CSEC B-28
#         OUTPUT
#               SAME AS FOR PRECISION OR CONIC INTEGRATION
#         THE PROGRAM WILL SET MOONFLAG, MIDFLAG DEPENDING ON
#         THE PERMANENT STATE VECTOR REPRESENTATION.

                BANK    11
                SETLOC  INTINIT
                BANK
                EBANK=  RRECTCSM
                COUNT   13/INTIN

STATEINT        TC      PHASCHNG
                OCT     00052
                CAF     PRIO5
                TC      FINDVAC
                EBANK=  RRECTCSM
                2CADR   STATINT1

                TC      TASKOVER
```

```
STATINT1        TC      INTPRET
                BON     RTB
                        QUITFLAG
                        NOINT           # NO STATEINT IF V96
                        LOADTIME
```

Uses COUNT 142, D 226, D6OR9FLG 109, DIMOFLAG 109, EBANK 80, INTINIT 61, INTYPFLG 107, IT 185, L 80, MIDFLAG 95, MOONFLAG 95, QUITFLAG 131, RAD 219, RRECTCSM 172, STATE 138, STATEFLG 107, TC 169, TET 169, VINTFLAG 109, and W 183.

1782 ⟨*Page CM1314* 1782⟩≡ (1771 2718)

```
                STORE   TDEC1
                CLEAR   CALL
                        V96ONFLG
                        INTSTALL
                SET     CALL
                        NODOFLAG
                        SETIFLGS
                GOTO
                        STATEUP
600SECS         2DEC    60000

ENDINT          CLEAR   EXIT
                        STATEFLG
                TC      PHASCHNG
                OCT     20032
                EXTEND
                DCA     600SECS
                TC      LONGCALL
                EBANK=  RRECTHIS
                2CADR   STATEINT

                TC      ENDOFJOB
SETIFLGS        SET     CLEAR
                        STATEFLG
                        INTYPFLG
                CLEAR   CLEAR
                        DIMOFLAG
                        D6OR9FLG
                RVQ
NOINT           EXIT
                TC      PHASCHNG
                OCT     2

                TC      DOWNFLAG
                ADRES   QUITFLAG

                TC      ENDOFJOB

# ATOPCSM TRANSFERS RRECT TO RRECT +41 TO RRECTCSM TO RRECTCSM +41
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             ATOPCSM
#
# NORMAL EXIT AT L+2
```

```
ATOPCSM         STQ     RTB
                        S2
                        MOVEACSM
                SET     CALL
```

Uses D6OR9FLG 109, DIMOFLAG 109, EBANK 80, INTYPFLG 107, L 80, NODOFLAG 105, QUITFLAG 131, RRECT 169, RRECTCSM 172, RRECTHIS 172, S2 85, STATEFLG 107, and TC 169.

1784 ⟨*Page CM1315* 1784⟩≡ (1771 2718)

```
                        CMOONFLG
                        SVDWN1
                BON     CLRGO
                        MOONFLAG
                        S2
                        CMOONFLG
                        S2
MOVEACSM        TC      SETBANK
                TS      DIFEQCNT        # INITIALIZE INDEX
                INDEX   DIFEQCNT
                CA      RRECT
                INDEX   DIFEQCNT
                TS      RRECTCSM
                CCS     DIFEQCNT        # IS TRANSFER COMPLETE
                TCF     MOVEACSM +1     # NO-LOOP
                TC      DANZIG          # COMPLETE -- RETURN

# PTOACSM TRANSFERS RRECTCSM TO RRECTCSM +41 TO RRECT TO RRECT +41
#
# CALLING SEQUENCE
#       L       CALL
#                       PTOACSM
#
# NORMAL EXIT AT L+2

PTOACSM         RTB     BON
                        MOVEPCSM
                        CMOONFLG
                        SETMOON
CLRMOON         CLEAR   SSP
                        MOONFLAG
                        PBODY
                        0
                RVQ
SETMOON         SET     SSP
                        MOONFLAG
                        PBODY
                        2
                RVQ
MOVEPCSM        TC      SETBANK
                TS      DIFEQCNT
                INDEX   DIFEQCNT
                CA      RRECTCSM
                INDEX   DIFEQCNT
                TS      RRECT
```

```
CCS     DIFEQCNT
TCF     MOVEPCSM +1
TC      DANZIG
```

Uses CMOONFLG 125, DIFEQCNT 169, L 80, MOONFLAG 95, PBODY 177, RRECT 169, RRECTCSM 172, S2 85, and TC 169.

1786 ⟨*Page CM1316* 1786⟩≡ (1771 2718)

```
# ATOPLEM TRANSFERS RRECT TO RRECT +41 TO RRECTLEM TO RRECTLEM +41
ATOPLEM         STQ     RTB
                        S2
                        MOVEALEM
                SET     CALL
                        LMOONFLG
                        SVDWN2
                BON     CLRGO
                        MOONFLAG
                        S2
                        LMOONFLG
                        S2
MOVEALEM        TC      SETBANK
                TS      DIFEQCNT
                INDEX   DIFEQCNT
                CA      RRECT
                INDEX   DIFEQCNT
                TS      RRECTLEM
                CCS     DIFEQCNT
                TCF     MOVEALEM +1
                TC      DANZIG

# PTOALEM TRANSFERS RRECTLEM TO RRECTLEM +41 TO RRECT TO RRECT +41

PTOALEM         BON     RTB
                        SURFFLAG
                        USEPIOS
                        MOVEPLEM
                BON     GOTO
                        LMOONFLG
                        SETMOON
                        CLRMOON
MOVEPLEM        TC      SETBANK
                TS      DIFEQCNT
                INDEX   DIFEQCNT
                CA      RRECTLEM
                INDEX   DIFEQCNT
                TS      RRECT
                CCS     DIFEQCNT
                TCF     MOVEPLEM +1
                TC      DANZIG

USEPIOS         SETPD   VLOAD
                        0
                        RLS
```

```
PDDL     PUSH
         TDEC1
```

Uses DIFEQCNT 169, LMOONFLG 125, MOONFLAG 95, RLS 175, RRECT 169, RRECTLEM 172, S2 85, SURFFLAG 127, and TC 169.

1788 ⟨*Page CM1317* 1788⟩≡ (1771 2718)

```
                STODL   TET
                        5/8
                CALL
                        RP-TO-R
                STOVL   RCV
                        ZUNIT
                STODL   OD
                        TET
                STODL   6D
                        5/8
                SET     CALL            # NEEDED FOR SETTING X1 ON EXIT
                        MOONFLAG
                        RP-TO-R
                VXV     VXSC
                        RCV
                        OMEGMOON
                STOVL   VCV
                        ZEROVEC
                STORE   TDELTAV
                AXT,2   SXA,2
                        2
                        PBODY
                STCALL  TNUV
                        A-PCHK
OMEGMOON        2DEC*   2.66169947 E-8 B+23*

SETBANK         CAF     INTBANK
                TS      BBANK
                CAF     FORTYONE
                TC      Q
                EBANK=  RRECTCSM
INTBANK         BBCON   INTEGRV

# SPECIAL PURPOSE ENTRIES TO ORBITAL INTEGRATION.  THESE ROUTINES PROVIDE ENTRANCES T
# APPROPRIATE SWITCHES SET OR CLEARED FOR THE DESIRED INTEGRATION.
#
# CSMPREC AND LEMPREC PERFORM ORBIT INTEGRATION BY THE ENCKE METHOD TO THE TIME INDIC
# ACCELERATIONS DUE TO OBLATENESS ARE INCLUDED.  NO W-MATRIX INT. IS DONE.
# THE PERMANENT STATE VECTOR IS NOT UPDATED.
# CSMCONIC AND LEMCONIC PERFORM ORBIT INTEG. BY KEPLER'S METHOD TO THE TIME INDICATED
# NO DISTURBING ACCELERATIONS ARE INCLUDED.  IN THE PROGRAM FLOW THE GIVEN
# STATE VECTOR IS RECTIFIED BEFORE SOLUTION OF KEPLER'S EQUATION.
#
# THE ROUTINES ASSUME THAT THE CSM (LEM) STATE VECTOR IN P-MEM IS VALID.
# SWITCHES SET PRIOR TO ENTRY TO THE MAIN INTEG. PROG ARE AS FOLLOWS:
```

```
#                       CSMPREC         CSMCONIC        LEMPREC         LEMCONIC
#       VINTFLAG        SET             SET             CLEAR           CLEAR
#       INTYPFLG        CLEAR           SET             CLEAR           SET
#       DIMOFLAG        CLEAR           CLEAR           CLEAR           CLEAR
```

Uses A 80, BBANK 80, DIMOFLAG 109, EBANK 80, INTYPFLG 107, MOONFLAG 95, ORBITAL 59, P 188, PBODY 177, Q 80, RCV 169, RRECTCSM 172, STATE 138, TC 169, TDELTAV 169, TET 169, TNUV 169, VCV 169, VINTFLAG 109, W 183, and X1 85.

1790 ⟨*Page CM1318* 1790⟩≡ (1771 2718)

```
#
# CALLING SEQUENCE
#       L-X     STORE   TDEC1
#       L       CALL                    (STCALL TDEC1)
#       L+1             CSMPREC         (CSMCONIC, LEMPREC, LEMCONIC)
#
# NORMAL EXIT TO L+2
#
# SUBROUTINES CALLED
#       INTEGRV1
#       PRECOUT FOR CSMPREC AND LEMPREC
#       CONICOUT FOR CSMCONIC AND LEMCONIC
#
# OUTPUT -- SEE PAGE 2 OF THIS LOG SECTION
#
# INPUT
#       TDEC1           TIME TO INTEGRATE TO.  CSECS B-28

CSMPREC         STQ     CALL
                        X1
                        INTSTALL
                SXA,1   SET
                        IRETURN
                        VINTFLAG

IFLAGP          SET     CLEAR
                        PRECIFLG
                        DIMOFLAG
                CLRGO
                        INTYPFLG
                        INTEGRV1
LEMPREC         STQ     CALL
                        X1
                        INTSTALL
                SXA,1   CLRGO
                        IRETURN
                        VINTFLAG
                        IFLAGP

CSMCONIC        STQ     CALL
                        X1
                        INTSTALL
                SXA,1   SET
                        IRETURN
                        VINTFLAG
```

```
IFLAGC          CLEAR   SETGO
                        DIMOFLAG
                        INTYPFLG
                        INTEGRV1
LEMCONIC        STQ     CALL
                        X1
```

Uses DIMOFLAG 109, INTYPFLG 107, IRETURN 177, L 80, PRECIFLG 107, VINTFLAG 109, and X1 85.

1792 ⟨*Page CM1319* 1792⟩≡ (1771 2718)

```
                        INTSTALL
                SXA,1   CLRGO
                        IRETURN
                        VINTFLAG
                        IFLAGC

INTEGRVS        SET     SSP
                        PRECIFLG
                        PBODY
                        0
                BOF     SSP
                        MOONFLAG
                        +3
                        PBODY
                        2
                STQ     VLOAD
                        IRETURN
                        ZEROVEC
                STORE   TDELTAV
                STCALL  TNUV
                        RECTIFY
                CLEAR   SET
                        DIMOFLAG
                        NEWIFLG
                SETGO
                        RPQFLAG
                        ALOADED

# INTEGRV IS AN ENTRY TO ORBIT INTEGRATION WHICH PERMITS THE CALLER,
# NORMALLY THE NAVIGATION PROGRAM, TO SET THE INTEG. FLAGS.  THE ROUTINE
# IS ENTERED AT INTEGRV1 BY CSMPREC ET. AL. AND AT ALOADED BY INTEGRVS.
# THE ROUTINE SETS UP A-MEMORY IF ENTERED AT INTEGRV,1 AND SETS THE INTEG.
# PROGRAM FOR PRECISION OR CONIC.
#
# THE CALLER MUST FIRST CALL INTSTALL TO CHECK IF INTEG. IS IN USE BEFORE
# SETTING ANY FLAGS.
#
# THE FLAGS WHICH SHOULD BE SET OR CLEARED ARE
#       VINTFLAG        (IGNORED WHEN ENTERED FROM INTEGRVS)
#       INTYPFLG
#       DIMOFLAG
#       D6OR9FLG
#
# CALLING SEQUENCE
#       L-X     CALL
```

```
#       L-Y             INTSTALL
#       L-1     SET OR CLEAR ALL FOUR FLAGS.  ALSO CAN SET STATEFLG IF DESIRED
#               AND DIMOFLAG IS CLEAR.
#       L       CALL
#       L+1             INTEGRV
#
# INITIALIZATION
#       FLAGS AS ABOVE
#       STORE TIME TO INTEGRATE TO IN TDEC1
#
```

Uses A 80, D6OR9FLG 109, DIMOFLAG 109, INTYPFLG 107, IRETURN 177, L 80, MOONFLAG 95, NEWIFLG 125, PBODY 177, PRECIFLG 107, RPQFLAG 125, STATEFLG 107, TDELTAV 169, TNUV 169, and VINTFLAG 109.

1794 ⟨*Page CM1320* 1794⟩≡ (1771 2718)

```
# OUTPUT
#       RATT    AS
#       VATT          DEFINED
#       TAT                     BEFORE

INTEGRV         STQ
                        IRETURN
INTEGRV1        SET     SET
                        RPQFLAG
                        NEWIFLG
INTEGRV2        SSP
                        QPRET
                        ALOADED
                BON     GOTO
                        VINTFLAG
                        PTOACSM
                        PTOALEM
                SETLOC  INTINIT1
                BANK
ALOADED         DLOAD
                        TDEC1
                STORE   TDEC
                BOFF    GOTO
                        INTYPFLG
                        TESTLOOP
                        RVCON
                SETLOC  INTINIT
                BANK
A-PCHK          BOF     CALL
                        MIDFLAG
                        ANDOUT          # DON'T MAKE ORIGIN CHANGE CHECK
                        CHKSWTCH
                BPL     CALL
                        ANDOUT          # NO ORIGIN CHANGE
                        ORIGCHNG        # MAKE THE SWITCH
ANDOUT          BOFCLR  EXIT
                        STATEFLG
                        RECTOUT
                TC      PHASCHNG
                OCT     04022
                TC      UPFLAG          # PHASE CHANGE HAS OCCURRED BETWEEN
                ADRES   REINTFLG        # INTSTALL AND INTWAKE
                TC      INTPRET
                SSP
                        QPRET
```

```
        PHEXIT
BON     GOTO
        VINTFLAG
        ATOPCSM
```

Uses A 80, INTINIT 61, INTINIT1 61, INTYPFLG 107, IRETURN 177, MIDFLAG 95, NEWIFLG 125, QPRET 85, REINTFLG 135, RPQFLAG 125, STATEFLG 107, TC 169, TDEC 157, and VINTFLAG 109.

1796 ⟨*Page CM1321* 1796⟩≡ (1771 2718)

```
                        ATOPLEM
PHEXIT          CALL
                        GRP2PC
RECTOUT         SETPD   CALL
                        0
                        RECTIFY
                VLOAD   VSL*
                        RRECT
                        0,2
                PDVL    VSL*            # RATT TO PD0
                        VRECT
                        0,2
                PDDL    PDVL            # VATT TO PD6   TAT TO PD12
                        TET
                        RRECT
                PDVL    PDDL*
                        VRECT
                        MUEARTH,2
                PUSH    AXT,1
                DEC     -10
                BON     AXT,1
                        MOONFLAG
                        +2
                DEC     -2
INTEXIT         SETPD   BOV
                        0
                        +1
                CLEAR
                        MIDAVFLG
                CLEAR   CLEAR
                        AVEMIDSW        # ALLOW UPDATE OF DOWNLINK STATE VECTOR
                        PRECIFLG
                SLOAD   EXIT
                        IRETURN
                CA      MPAC
                INDEX   FIXLOC
                TS      QPRET
                TC      INTWAKE

# RVCON SETS UP ORBIT INTEGRATION TO DO A CONIC SOLUTION FOR POSITION AND
# VELOCITY FOR THE INTERVAL (TET-TDEC)

RVCON           DLOAD   DSU
                        TDEC
                        TET
```

```
        STCALL  TAU.
                RECTIFY
        CALL
                KEPPREP
        DLOAD   DAD
                TC
```

Uses A 80, AVEMIDSW 133, FIXLOC 140, IRETURN 177, MIDAVFLG 131, MOONFLAG 95, MPAC 145, PRECIFLG 107, QPRET 85, RRECT 169, STATE 138, TAU 211, TAU. 177, TC 169, TDEC 157, TET 169, and VRECT 169.

1797 ⟨*Page CM1322* 1797⟩≡ (1771 2718)

```
                TET
        STCALL  TET
                RECTOUT
```

Uses TET 169.

1798 ⟨*Page CM1323* 1798⟩≡ (1771 2718)

```
TESTLOOP        BOF     CLRGO
                        QUITFLAG
                        +3
                        STATEFLG
                        INTEXIT         # STOP INTEGRATION
        +3      SETPD   LXA,2
                        10D
                        PBODY
                VLOAD   ABVAL
                        RCV
                PUSH    CLEAR           # RC TO 10D
                        MIDFLAG
                DSU*    BMN             # MIDFLAG=0 IF R G.T. RMP
                        RME,2
                        +3
                SET
                        MIDFLAG
NORFINAL        DLOAD   DMP
                        10D
                        34D
                SR1R    DDV*
                        MUEARTH,2
                SQRT    DMP
                        .3D
                SR3     SR4             # DT IS TRUNCATED TO A MULTIPLE
                DLOAD   SL
                        MPAC
                        15D             #       OF 128 CSECS.
                PUSH    BOV
                        MAXDT
                BDSU    BMN
                        DT/2MAX
                        MAXDT
DT/2COMP        DLOAD   DSU
                        TDEC
                        TET
                RTB     SL
                        SGNAGREE
                        8D
                STORE   DT/2            # B-19
                BOV     ABS
                        GETMAXDT
                DSU     BMN             # IS TIME TO INTEG. TO GR THAN MAXTIME
                        12D
                        POOHCHK
```

```
USEMAXDT        DLOAD   SIGN
                        12D
                        DT/2
```

Uses A 80, DT/2 177, MIDFLAG 95, MPAC 145, PBODY 177, QUITFLAG 131, RCV 169, STATEFLG 107, TDEC 157, and TET 169.

1800 ⟨*Page CM1324* 1800⟩≡ (1771 2718)

```
                STCALL  DT/2
                        POOHCHK
MAXDT           DLOAD   PDDL            # EXCHANGE DT/2MAX WITH COMPUTED MAX.
                        DT/2MAX
                GOTO
                        DT/2COMP
GETMAXDT        RTB
                        SIGNMPAC
                STCALL  DT/2
                        USEMAXDT
POOHCHK         DLOAD   ABS
                        DT/2
                DSU     BMN
                        DT/2MIN
                        A-PCHK
                SLOAD   BHIZ
                        MODREG
                        +3
                GOTO
                        TIMESTEP
                BON                     # WAS THIS CALL VIA CSM(LEM)PREC
                        PRECIFLG
                        TIMESTEP        # YES
                DLOAD   DSU
                        DT/2
                        12D
                BMN     BOFCLR
                        A-PCHK
                        NEWIFLG
                        TIMESTEP
                DLOAD   DSU
                        TDEC
                        TET
                BMN                     # NO BACKWARD INTEGRATION
                        INTEXIT
                PDDL    SR4
                        DT/2            # IS 4(DT) LS (TDEC - TET)
                SR2R    BDSU
                BMN     GOTO
                        INTEXIT
                        TIMESTEP
DT/2MIN         2DEC    3 B-20

DT/2MAX         2DEC    4000 E2 B-20
```

```
INTSTALL        EXIT
                CAF     ZERO
ALLSTALL        TS      L
                CA      RASFLAG
                INDEX   L
```

Uses A 80, DT/2 177, E2 236, L 80, MODREG 154, NEWIFLG 125, PRECIFLG 107, RASFLAG 133, TDEC 157, and TET 169.

1802 ⟨*Page CM1325* 1802⟩≡ (1771 2718)

```
                MASK    INTBITAB        # IS THIS STALL AREA FREE
                EXTEND
                BZF     OKTOGRAB        # YES
                INDEX   L
                CAF     WAKESTAL
                TC      JOBSLEEP
INTWAKE0        EXIT
                TCF     INTWAKE1

INTWAKE         CS      RASFLAG         # IS THIS INTSTALLED ROUTINE TO BE
                MASK    REINTBIT        #       RESTARTED
                CCS     A
                TC      INTWAKE1        # NO

                INDEX   FIXLOC
                CA      QPRET
                TS      TBASE2          # YES, DON'T RESTART WITH SOMEONE ELSE'S Q

                TC      PHASCHNG
                OCT     04022

                CA      TBASE2
                INDEX   FIXLOC
                TS      QPRET

                CAF     REINTBIT
                MASK    RASFLAG
                EXTEND
                BZF     GOBAC           # DON'T INTWAKE IF WE CAME HERE VIA RESTART

INTWAKE1        CAF     ZERO
WAKE            TS      STALTEM         # INDEX OF ANY STALL USER
WAKE1           INDEX   STALTEM
                CAF     WAKESTAL
                INHINT
                TC      JOBWAKE
                CCS     LOCCTR
                TCF     WAKE1           # MAY BE MORE TO WAKE UP
FORTYONE        DEC     41
                INDEX   STALTEM
                CS      INTBITAB
                MASK    RASFLAG
                TS      RASFLAG         # RELEASE STALL AREA
                RELINT
                TCF     GOBAC
```

```
OKTOGRAB        INDEX   L               # NO, WAIT UNTIL AVAILABLE
                CAF     INTFLBIT
                ADS     RASFLAG
GOBAC           TC      INTPRET
                RVQ
```

Uses A 80, FIXLOC 140, INTFLBIT 133, L 80, LOCCTR 138, Q 80, QPRET 85, RASFLAG 133, REINTBIT 135, RESTART 57, TBASE2 154, and TC 169.

1803 ⟨*Page CM1326* 1803⟩≡ (1771 2718)

```
ERASTAL1        EXIT
                CAF     ONE
                TCF     ALLSTALL
ERASTAL2        EXIT
                CAF     TWO
                TCF     ALLSTALL
ERASWAK1        CAF     ONE
                TCF     WAKE
ERASWAK2        CAF     TWO
                TCF     WAKE
WAKESTAL        CADR    INTSTALL +1
                CADR    ERASTAL1 +1
                CADR    ERASTAL2 +1
STALTEM         EQUALS  MPAC
INTBITAB        OCT     20100
                OCT     10040
                OCT     04020
```

Uses MPAC 145.

1804 ⟨*Page CM1327* 1804⟩≡ (1771 2718)

```
# AVETOMID
#
# THIS ROUTINE PERFORMS THE TRANSITION FROM A THRUSTING PHASE TO THE COAST
# PHASE BY INITIALIZING THIS VEHICLE'S PERMANENT STATE VECTOR WITH THE
# VALUES LEFT BY THE AVERAGEG ROUTINE IN RN,VN,PIPTIME.
#
# BEFORE THIS IS DONE THE W-MATRIX, IF IT'S VALID (OR WFLAG OR RENDWFLT IS
# SET) IS INTEGRATED FORWARD TO PIPTIME WITH THE PRE-THRUST STATE VECTOR.
#
# IN ADDITION, THE OTHER VEHICLE IS INTEGRATED (PERMANENT) TO PIPTIME.
#
# FINALLY TRKMKCNT IS ZEROED.

                SETLOC  INTINIT2
                BANK

                COUNT*  $$/INTIN
AVETOMID        STQ     BON
                        EGRESS
                        RENDWFLG
                        INT/W           # W-MATRIX VALID, GO INTEGRATE IT
                BON
                        ORBWFLAG
                        INT/W           # W-MATRIX VALID, GO INTEGRATE IT.

SETCOAST        AXT,2   CALL            # NOW MOVE PROPERLY SCALED RN,UN AS WELL AS
                        2               # PIPTIME TO INTEGRATION ERASABLES.
                        INTSTALL
                BON     AXT,2
                        AMOONFLG
                        +2
                        0
                VLOAD   VSR*
                        RN
                        0,2
                STORE   RRECT
                STODL   RCV
                        PIPTIME
                STOVL   TET
                        VN
                VSR*    CALL
                        0,2
                        MINIRECT        # FINISH SETTING UP STATE VECTOR
                RTB     SSP
                        MOVATHIS        # PUT TEMP STATE VECTOR INTO PERMANENT
```

```
                        TRKMKCNT
                        0
                SET     BON
                        CMOONFLG
```

Uses A 80, AMOONFLG 97, CMOONFLG 125, COUNT 142, EGRESS 179, INTINIT2 69, IT 185, MOVATHIS 73, ORBWFLAG 107, PIPTIME 159, RCV 169, RENDWFLG 117, RN 159, RRECT 169, STATE 138, TEMP 191, TET 169, THRUST 85, TRKMKCNT 157, UN 188, VN 159, and W 183.

1805 ⟨*Page CM1328* 1805⟩≡ (1771 2718)

```
                        AMOONFLG
                        +3
                CLEAR
                        CMOONFLG

                BON     DLOAD           # NOW DO LM
                        SURFFLAG
                        FAZAB5          # NO COASTING LM
                        PIPTIME
                STCALL  TDEC1
                        SETIFLGS
                CLEAR   CALL
                        VINTFLAG
                        INTEGRV
                GOTO
                        EGRESS
  INT/W         DLOAD   CALL
                        PIPTIME         # INTEGRATE W THRU BURN
                        INTSTALL
                SET     SET
                        DIMOFLAG        # DO W-MATRIX
                        AVEMIDSW        # SO WON'T CLOBBER RN,VN,PIPTIME
                CLEAR   SET
                        D6OR9FLG
                        VINTFLAG
                STCALL  TDEC1
                        INTEGRV
                GOTO
                        SETCOAST
```

Uses AMOONFLG 97, AVEMIDSW 133, CMOONFLG 125, D6OR9FLG 109, DIMOFLAG 109, EGRESS 179, PIPTIME 159, RN 159, SURFFLAG 127, VINTFLAG 109, VN 159, and W 183.

1806 ⟨*Page CM1329* 1806⟩≡ (1771 2718)

```
# MIDTOAV1
#
# THIS ROUTINE INTEGRATES (PRECISION) TO THE TIME SPECIFIED IN TDEC1.
# IF, AT THE END OF AN INTEGRATION TIME STEP, CURRENT TIME PLUS A DELTA
# TIME (SEE TIMEDELT.....BASED ON THE COMPUTATION TIME FOR ONE TIME STEP)
# IS GREATER THAN THE DESIRED TIME, ALARM 1703 IS SET AND THE INTEGRATION
# IS DONE TO THE CURRENT TIME.
# RETURN IS IN BASIC TO THE RETURN ADDRESS PLUS ONE.
#
# IF THE INTEGRATION IS FINISHED TO THE DESIRED TIME, RETURN IS IN BASIC
# TO THE RETURN ADDRESS.
#
# IN EITHER CASE, BEFORE RETURNING, THE EXTRAPOLATED STATE VECTOR IS TRANSFERRED
# FROM R,VATT TO R,VN1 -- PIPTIME1 IS SET TO THE FINISHING INTEGRATION
# TIME AND MPAC IS SET TO THE DELTA TIME --
#                       TAT MINUS CURRENT TIME

# MIDTOAV2
#
# THIS ROUTINE INTEGRATES THIS VEHICLE'S STATE VECTOR TO THE CURRENT TIME PLUS
# INCREMENTS OF TIMEDELT SUCH THAT THE DIFFERENCE BETWEEN CURRENT TIME
# AND THE STATE VECTOR TIME AT THE END OF THE LAST STEP IS AT LEAST 5.6
# SECS.
# NO INPUTS ARE REQUIRED OF THE CALLER.  RETURN IS IN BASIC TO THE RETURN
# ADDRESS WITH THE ABOVE TRANSFERS TO R,VN1 -- PIPTIME1 -- AND MPAC DONE

                SETLOC  INTINIT
                BANK
                EBANK=  IRETURN1
MIDTOAV2        STQ     CALL
                        IRETURN1
                        INTSTALL
                DLOAD   CLEAR
                        TIMEDELT
                        MID1FLAG
                STCALL  T-TO-ADD
                        ENTMID2

MIDTOAV1        STQ     CALL
                        IRETURN1
                        INTSTALL
                SET     RTB
                        MID1FLAG
                        LOADTIME
                DAD     BDSU            # INITIAL CHECK, IS TDEC1 IN THE FUTURE
```

```
                TIMEDELT
                TDEC1
        BPL     CALL
                ENTMID1
```

Uses A 80, EBANK 80, INTINIT 61, IRETURN1 157, MID1FLAG 131, MPAC 145, PIPTIME1 159, STATE 138, T-TO-ADD 238, and VN1 159.

1808 ⟨*Page CM1330* 1808⟩≡ (1771 2718)

```
                        NOTIME          # NO, SET ALARM, SWITCH TO MIDTOAV2

ENTMID2         RTB     DAD
                        LOADTIME
                        T-TO-ADD
                STORE   TDEC1

ENTMID1         CLEAR   CALL
                        DIMOFLAG        # NO W-MATRIX
                        THISVINT
                CLEAR   SET
                        INTYPFLG
                        MIDAVFLG        # LET INTEG. KNOW THE CALL IS FOR MIDTOAV.
                CALL
                        INTEGRV         # GO INTEGRATE
                SXA,2   SXA,1
                        RTX2
                        RTX1
                CLEAR   SLOAD
                        AMOONFLG
                        RTX2
                BZE     SET
                        +2
                        AMOONFLG
                VLOAD
                        RATT
                STOVL   RN1
                        VATT
                STODL   VN1
                        TAT
                STORE   PIPTIME1
                EXIT

                INHINT
                EXTEND
                DCS     TIME2
                DAS     MPAC
                TC      TPAGREE

                CA      IRETURN1
                TC      BANKJUMP
CKMID2          BOF     RTB
                        MID1FLAG
                        MID2
                        LOADTIME
```

```
DAD     BDSU
        TIMEDELT
        TDEC
BPL     CALL
        TESTLOOP        # YES
```

Uses AMOONFLG 97, DIMOFLAG 109, INTYPFLG 107, IRETURN1 157, MID1FLAG 131, MIDAVFLG 131, MPAC 145, PIPTIME1 159, RN1 159, T-TO-ADD 238, TC 169, TDEC 157, TIME2 80, VN1 159, and W 183.

1810 ⟨*Page CM1331* 1810⟩≡ (1771 2718)

```
                        NOTIME

TIMEINC         RTB     DAD
                        LOADTIME
                        T-TO-ADD
                STCALL  TDEC
                        TESTLOOP

MID2            DLOAD   DSU
                        TDEC
                        TET
                ABS     DSU
                        3CSECS
                BPL
                        TIMEINC

                RTB     BDSU            # SEE IF 5.6 SECS. AVAILABLE TO CALLER
                        LOADTIME
                        TET
                DSU     BPL
                        5.6SECS
                        A-PCHK          # YES. GET OUT.

                DLOAD   DAD             # NO. ADD TIMEDELT TO T-TO-ADD AND TRY
                        T-TO-ADD        # AGAIN.
                        TIMEDELT
                STCALL  T-TO-ADD
                        TIMEINC
NOTIME          CLEAR   EXIT            # TOO LATE
                        MID1FLAG
                INCR    IRETURN1        # SET ERROR EXIT (CALLOC +2)
                TC      ALARM           # INSUFFICIENT TIME FOR INTEGRATION --
                OCT     1703            #       TIG WILL BE SLIPPED...
                TC      INTPRET
                DLOAD
                        TIMEDELT
                STORE   T-TO-ADD
                RVQ

3CSECS          2DEC    3

TIMEDELT        2DEC    1250

5.6SECS         2DEC    560
```

```
BANK     27
SETLOC   UPDATE2
BANK
EBANK=   INTWAKUQ
```

Uses A 80, EBANK 80, IRETURN1 157, MID1FLAG 131, T-TO-ADD 238, TC 169, TDEC 157, TET 169, TIG 224, and UPDATE2 67.

1812 ⟨*Page CM1332* 1812⟩≡ (1771 2718)

```
                COUNT*  $$/INTIN

INTWAKUQ        =       INTWAK1Q        # TEMPORARY UNTIL NAME OF INTWAK1Q IS CHNG

INTWAKEU        RELINT
                EXTEND
                QXCH    INTWAKUQ        # SAVE Q FOR RETURN

                TC      INTPRET

                SLOAD   BZE             # IS THIS A CSM/LEM STATE VECTOR UPDATE
                        UPSVFLAG        # REQUEST.  IF NOT GO TO INTWAKUP.
                        INTWAKUP

                VLOAD                   # MOVE PRECT(6) AND VRECT(6) INTO
                        RRECT           #       RCV(6) AND VCV(6) RESPECTIVELY.
                STOVL   RCV
                        VRECT           # NOW GO TO 'RECTIFY +13D' TO
                CALL                    # STORE VRECT INTO VCV AND ZERO OUT
                        RECTIFY +13D    # TDELTAV(6),TNUV(6),TC(2), AND XKEP(2)
                SLOAD   ABS             # COMPARE ABSOLUTE VALUE OF 'UPSVFLAG'
                        UPSVFLAG        # TO 'UPDATE MOON STATE VECTOR CODE'
                DSU     BZE             # TO DETERMINE WHETHER THE STATE VECTOR TO
                        UPMNSVCD        # BE UPDATED IS IN THE EARTH OR LUNAR
                        INTWAKEM        # SPHERE OF INFLUENCE........
                AXT,2   CLRGO           # EARTH SPHERE OF INFLUENCE.
                DEC     0
                        MOONFLAG
                        INTWAKEC
INTWAKEM        AXT,2   SET             # LUNAR SPHERE OF INFLUENCE.
                DEC     2
                        MOONFLAG
INTWAKEC        SLOAD   BMN             # COMMON CODING AFTER X2 INITIALIZED AND
                                        # MOONFLAG SET (OR CLEARED).
                        UPSVFLAG        # IS THIS A REQUEST FOR A LEM OR CSM
                        INTWAKLM        #       STATE VECTOR UPDATE......
                CALL                    # UPDATE CSM STATE VECTOR
                        ATOPCSM

                CLEAR   GOTO
                        ORBWFLAG
                        INTWAKEX

INTWAKLM        CALL                    # UPDATE LM STATE VECTOR
                        ATOPLEM
```

```
INTWAKEX        CLEAR
                        RENDWFLG

INTWAKUP        SSP     CALL            # REMOVE 'UPDATE STATE VECTOR INDICATOR'
```

Uses A 80, COUNT 142, INTWAK1Q 145, MOONFLAG 95, ORBWFLAG 107, Q 80, RCV 169, RENDWFLG 117, RRECT 169, SAVE 191, STATE 138, TC 169, TDELTAV 169, TNUV 169, UPSVFLAG 169, VCV 169, VRECT 169, X2 85, and XKEP 169.

1813a ⟨*Page CM1333* 1813a⟩≡ (1771 2718)

```
                        UPSVFLAG
                        0
                        INTWAKE0        # RELEASE 'GRAB' OF ORBIT INTEG.
                EXIT

                TC      PHASCHNG
                OCT     04026
                TC      INTWAKUQ

UPMNSVCD        OCT     2
                OCT     0

GRP2PC          STQ     EXIT
                        GRP2SVQ
                TC      PHASCHNG
                OCT     04022
                TC      INTPRET
                GOTO
                        GRP2SVQ
```

Uses GRP2SVQ 232, TC 169, and UPSVFLAG 169.

3.7.14 orbital integration

1813b ⟨*orbital integration* 1813b⟩≡ (1523a 2748)
⟨*Page CM1334* 1814⟩

1814 ⟨*Page CM1334* 1814⟩≡ (1813b)

```
# Page 1334
# ORBITAL INTEGRATION

# DELETE
                BANK    13
                SETLOC  ORBITAL
                BANK
                COUNT   11/ORBIT

# DELETE
KEPPREP         LXA,2   SETPD
                        PBODY
                        0
                DLOAD*  SQRT            # SQRT(MU) (+18 OR +15)         0D      PL 2D
                        MUEARTH,2
                PDVL    UNIT            #                                       PL 8D
                        RCV
                PDDL    NORM            # NORM R (+29 OR +27 - N1)      2D      PL 4D
                        36D
                        X1
                PDVL
                DOT     PDDL            # F*SQRT(MU) (+7 OR +5)         4D      PL 6D
                        VCV
                        TAU.            # (+28)
                DSU     NORM
                        TC
                        S1
                SR1
                DDV     PDDL
                        2D
                DMP     PUSH            # FS (+6 +N1-N2)                6D      PL 8D
                        4D
                DSQ     PDDL            # (FS)SQ (+12 +2(N1-N2))        8D      PL 10
                        4D
                DSQ     PDDL*           # SSQ/MU (-2 OR +2(N1-N2))      10D     PL 12
                        MUEARTH,2
                SR3     SR4
                PDVL    VSQ             # PREALIGN MU (+43 OR +37)      12D     PL 14
                        VCV
                DMP     BDSU            #                                       PL 12
                        36D
                DDV     DMP             #                                       PL 10
                        2D              # -(1/R-ALPHA) (+12 +3N1-2N2)
                DMP     SL*
                        DP2/3
```

```
                        0       -3,1    # 10L(1/R-ALPHA) (+13 +2(N1-N2))
                XSU,1   DAD             # 2(FS)SQ - ETCETERA                    PL 8D
                        S1              # X1 = N2-N1
                SL*     DSU             # -FS+2(FS)SQ ETC (+6 +N1-N2)           PL 6D
                        8D,1
                DMP     DMP
                        0D
                        4D
                SL*     SL*
# Page 1335
                        8D,1
                        0,1             # S(-FS(1-2FS)-1/6...) (+17 OR +16)
                DAD     PDDL            #                                      PL 6D
                        XKEP
                DMP     SL*             # S(+17 OR +16)
                        0D
                        1,1
                BOVB    DAD
                        TCDANZIG
                STADR
                STORE   XKEPNEW
                STQ     AXC,1
                        KEPRTN
                DEC     10
                BON     AXC,1
                        MOONFLAG
                        KEPLERN
                DEC     2
                GOTO
                        KEPLERN

# Page 1336
FBR3            LXA,1   SSP
                        DIFEQCNT
                        S1
                DEC     -13
                DLOAD   SR
                        DT/2
                        9D
                TIX,1   ROUND
                        +1
                PUSH    DAD
                        TC
                STODL   TAU.
                DAD
                        TET
```

```
                STCALL  TET
                        KEPPREP

# Page 1337
# AGC ROUTINE TO COMPUTE ACCELERATION COMPONENTS.

ACCOMP          LXA,1   LXA,2
                        PBODY
                        PBODY
                VLOAD
                        ZEROVEC
                STOVL   FV
                        ALPHAV
                VSL*    VAD
                        0 -7,2
                        RCV
                STORE   BETAV
                BOF     XCHX,2
                        DIMOFLAG
                        +5
                        DIFEQCNT
                STORE   VECTAB,2
                XCHX,2
                        DIFEQCNT
                VLOAD   UNIT
                        ALPHAV
                STODL   ALPHAV
                        36D
                STORE   ALPHAM
                CALL
                        GAMCOMP
                VLOAD   SXA,1
                        BETAV
                        S2
                STODL   ALPHAV
                        BETAM
                STORE   ALPHAM
                BOF     DLOAD
                        MIDFLAG
                        OBLATE
                        TET
                CALL
                        LSPOS
                AXT,2   LXA,1
                        2
                        S2
```

```
                BOF
                        MOONFLAG
                        +3
                VCOMP   AXT,2
                        0
                STORE   BETAV
                STOVL   RPQV
# Page 1338
                        2D
                STORE   RPSV
                BOF     VLOAD
                        DIMOFLAG
                        GETRPSV
                        ALPHAV
                VXSC    VSR*
                        ALPHAM
                        1,2
                VSU     XCHX,2
                        BETAV
                        DIFEQCNT
                STORE   VECTAB +6,2
                XCHX,2
                        DIFEQCNT
GETRPSV         VLOAD   INCR,1
                        RPQV
                        4
                CLEAR   BOF
                        RPQFLAG
                        MOONFLAG
                        +5
                VSR     VAD
                        9D
                        RPSV
                STORE   RPSV
                CALL
                        GAMCOMP
                AXT,2   INCR,1
                        4
                        4
                VLOAD
                        RPSV
                STCALL  BETAV
                        GAMCOMP
                GOTO
                        OBLATE
GAMCOMP         VLOAD   VSR1
```

```
                        BETAV
                VSQ     SETPD
                        0
                NORM    ROUND
                        31D
                PDDL    NORM            # NORMED B SQUARED TO PD LIST
                        ALPHAM          # NORMALIZE (LESS ONE) LENGTH OF ALPHA
                        32D             # SAVING NORM SCALE FACTOR IN X1
                SR1     PDVL
                        BETAV           # C(PDL+2) = ALMOST NORMED ALPHA
                UNIT
                STODL   BETAV
# Page 1339
                        36D
                STORE   BETAM
                NORM    BDDV            # FORM NORMALIZED QUOTIENT ALPHAM/BETAM
                        33D
                SR1R    PUSH            # C(PDL+2) = ALMOST NORMALIZED RHO.
                DLOAD*
                        ASCALE,1
                STORE   S1
                XCHX,2  XAD,2
                        S1
                        32D
                XSU,2   DLOAD
                        33D
                        2D
                SR*     XCHX,2
                        0       -1,2
                        S1
                PUSH    SR1R            # RHO/4 TO 4D
                PDVL    DOT
                        ALPHAV
                        BETAV
                SL1R    BDSU            # (RHO/4) - 2(ALPHAV/2.BETAV/2)
                PUSH    DMPR            # TO PDL+6
                        4
                SL1
                PUSH    DAD
                        DQUARTER
                PUSH    SQRT
                DMPR    PUSH
                        10D
                SL1     DAD
                        DQUARTER
                PDDL    DAD             # (1/4)+2((Q+1)/4)      TO PD+14D
```

```
                        10D
                        HALFDP
                DMPR    SL1
                        8D
                DAD     DDV
                        THREE/8
                        14D
                DMPR    VXSC
                        6
                        BETAV
                PDVL    VSR3            # (G/2)(C(PD+4))B/2 TO PD+16D
                        ALPHAV
                VAD     PUSH            # A12 + C(PD+16D) TO PD+16D
                DLOAD   DMP
                        0
                        12D
                NORM    ROUND
# Page 1340
                        30D
                BDDV    DMP*
                        2
                        MUEARTH,2
                DCOMP   VXSC
                XCHX,2  XAD,2
                        S1
                        S2
                XSU,2   XSU,2
                        30D
                        31D
                BOV                     # CLEAR OVIND
                        +1
                VSR*    XCHX,2
                        0       -1,2
                        S1
                VAD
                        FV
                STORE   FV
                BOV     RVQ             # RETURN IF NO OVERFLOW
                        +1
GOBAQUE         VLOAD   ABVAL
                        TDELTAV
                BZE
                        INT-ABRT
                DLOAD   SR
                        H
                        9D
```

```
                PUSH    BDSU
                        TC
                STODL   TAU.
                        TET
                DSU     STADR
                STCALL  TET
                        KEPPREP
                CALL
                        RECTIFY
                SETGO
                        RPQFLAG
                        TESTLOOP

INT-ABRT        EXIT
                TC      P00DOO
                OCT     00430

# Page 1341
# THE OBLATE ROUTINE COMPUTES THE ACCELERATION DUE TO OBLATENESS.  IT USES THE UNIT (
# POSITION VECTOR FOUND IN ALPHAV AND THE DISTANCE TO THE CENTER IN ALPHAM.  THIS IS
# DISTURBING ACCELERATIONS IN FV AND THE PROPER DIFEQ STAGE IS CALLED VIA X1.

OBLATE          LXA,2   DLOAD
                        PBODY
                        ALPHAM
                SETPD   DSU*
                        0
                        RDE,2
                BPL     BOF             # GET URPV
                        NBRANCH
                        MOONFLAG
                        COSPHIE
                VLOAD   PDDL
                        ALPHAV
                        TET
                PDDL    CALL
                        3/5
                        R-TO-RP
                STORE   URPV
                VLOAD   VXV
                        504LM
                        ZUNIT
                VAD     VXM
                        ZUNIT
                        MMATRIX
                UNIT                    # PROBABLY UNNECESSARY.
```

```
COMTERM         STORE   UZ
                DLOAD   DMPR
                        COSPHI/2
                        3/32
                PDDL    DSQ             # P2/64 TO PD0
                        COSPHI/2
                DMPR    DSU
                        15/16
                        3/64
                PUSH    DMPR            # P3/32 TO PD2
                        COSPHI/2
                DMP     SL1R
                        7/12
                PDDL    DMPR
                        0
                        2/3
                BDSU    PUSH            # P4/128 TO PD4
                DMPR    DMPR
                        COSPHI/2        # BEGIN COMPUTING P5/1024
                        9/16
                PDDL    DMPR
                        2
                        5/128
# Page 1342
                BDSU
                DMP*
                        J4REQ/J3,2
                DDV     DAD             #               -3
                        ALPHAM          # (((P5/256)B 2  /R+P4/32)  /R+P3/8)ALPHAV
                        4               #            4             3
                DMPR*   DDV
                        2J3RE/J2,2
                        ALPHAM
                DAD     VXSC
                        2
                        ALPHAV
                STODL   TVEC
                DMP*    SR1
                        J4REQ/J3,2
                DDV     DAD
                        ALPHAM
                DMPR*   SR3
                        2J3RE/J2,2
                DDV     DAD
                        ALPHAM
                VXSC    VSL1
```

```
                        UZ
                BVSU
                        TVEC
                STODL   TVEC
                        ALPHAM
                NORM    DSQ
                        X1
                DSQ     NORM
                        S1              #         4
                PUSH    BDDV*           # NORMED R  TO OD
                        J2REQSQ,2
                VXSC    BOV
                        TVEC
                        +1              # (RESET OVERFLOW INDICATOR)
                XAD,1   XAD,1
                        X1
                        X1
                XAD,1   VSL*
                        S1
                        0       -22D,1
                VAD     BOV
                        FV
                        GOBAQUE
                STCALL  FV
                        QUALITY1
QUALITY3        DSQ                     # J22 TERM X R**4 IN 2D.  SCALED B61
                                        # AS VECTOR.
                PUSH    DMP             # STORE COSPHI**2 SCALED B2 IN 8D.
# Page 1343
                        5/8             # 5 SCALED B3
                PDDL    SR2             # PUT 5 COSPHI**2, D5, IN 8D. GET
                                        # COSPHI**2 D2 FROM 8D
                DAD     BDSU            # END UP WITH (1-7 COSPHI**2), B5
                        8D              # ADDING COSPHI**2 B4 SAME AS COSPHI**2
                                        # X 2 D5
                        D1/32           # 1 SCALED B5
                DMP     DMP
                        URPV            # X COMPONENT
                        5/8             # 5 SCALED B3
                VXSC    VSL5            # AFTER SHIFT, SCALED B5
                        URPV            # VECTOR, B1.
                PDDL                    # VECTOR INTO 8D, 10D, 12D, SCALED B5.
                                        # GET 5 COSPHI**2 OUT OF 8D
                DSU     DAD
                        D1/32           # 1 B5
                        8D              # X COMPONENT (SAME AS MULTIPLYING
```

```
                                        # BY UNITX)
                STODL   8D
                        URPV            # X COMPONENT
                DMP     DMP
                        URPV    +4      # Z COMPONENT
                        5/8             # 5 B3 ANSWER B5
                SL1     DAD             # FROM 12D FOR Z COMPONENT (SL1 GIVES 10
                                        # INSTEAD OF 5 FOR COEFFICIENT)
                PDDL    NORM            # BACK INTO 12D FOR Z COMPONENT
                        ALPHAM          # SCALED B27 FOR MOON
                        X2
                PUSH    SLOAD           # STORE IN 14D, DESTROYING URPV
                                        # X COMPONENT
                        E32C31RM
                DDV     VXSC            # IF X2 = 0, DIVISION GIVES B53, VXSC
                                        # out of 8D B5 GIVES B58
                VSL*    VAD             # SHIFT MAKES B61, FOR ADDITION OF
                                        # VECTOR IN 2D
                        0       -3,2
                VSL*    V/SC            # OPERAND FROM 0D, B108 FOR X1 = 0
                        0       -27D,1  # FOR X1 = 0, MAKES B88, GIVING B-20
                                        # FOR RESULT.
                PDDL    PDDL
                        TET
                                5/8     # ANY NON-ZERO CONSTANT
                LXA,2   CALL            # POSITION IN 0D, TIME IN 6D. X2 LEFT
                                        # ALONE.
                        PBODY
                        RP-TO-R
                VAD     BOV             # OVERFLOW INDICATOR RESET IN *RP-TO-R*
                        FV
                        GOBAQUE
                STORE   FV
# Page 1344
NBRANCH         SLOAD   LXA,1
                        DIFEQCNT
                        MPAC
                DMP     CGOTO
                        -1/12
                        MPAC
                        DIFEQTAB
COSPHIE         DLOAD
                        ALPHAV +4
                STOVL   COSPHI/2
                        ZUNIT
                GOTO
```

```
                        COMTERM
DIFEQTAB        CADR    DIFEQ+0
                CADR    DIFEQ+1
                CADR    DIFEQ+2

TIMESTEP        BOF     CALL
                        MIDFLAG
                        RECTEST         # SKIP ORIGIN CHANGE LOGIC
                        CHKSWTCH
                BMN
                        DOSWITCH

RECTEST         VLOAD   ABVAL           # RECTIFY IF
                        TDELTAV
                BOV
                        CALLRECT
                DSU     BPL             #       1) EITHER TDELTAV OR TNUV EQUALS OR
                        3/4             #          EXCEEDS 3/4 IN MAGNITUDE
                        CALLRECT        #
                DAD     SL*             #                       OR
                        3/4             #
                        0 -7,2          #       2) ABVAL(TDELTAV) EQUALS OR EXCEEDS
                DDV     DSU             #          .01(ABVAL(RCV))
                        10D
                        RECRATIO
                BPL     VLOAD
                        CALLRECT
                        TNUV
                ABVAL   DSU
                        3/4
                BOV
                        CALLRECT
                BMN
                        INTGRATE
CALLRECT        CALL
                        RECTIFY
INTGRATE        VLOAD
                        TNUV
# Page 1345
                STOVL   ZV
                        TDELTAV
                STORE   YV
                CLEAR
                        JSWITCH
DIFEQ0          VLOAD   SSP
                        YV
```

```
                        DIFEQCNT
                        0
                STODL   ALPHAV
                        DPZERO
                STORE   H               # START H AT ZERO.  GOES 0(DELT/2)DELT.
                BON     GOTO
                        JSWITCH
                        DOW..
                        ACCOMP

CHKSWTCH        STQ     BOF
                        ORIGEX
                        RPQFLAG
                        RPQOK           # MOON POSITION IS AVAILABLE
                DLOAD   CALL
                        TET
                        LUNPOS          # GET MOON POSITION
                BOF     VCOMP
                        MOONFLAG
                        +1
                STORE   RPQV

RPQOK           LXA,2   VLOAD           # RESTORE X2 AFTER USING LUNPOS
                        PBODY
                        TDELTAV         #  _
                VSL*    VAD             # |RQC|-RSPHERE WHEN OUTSIDE THE SPHERE.
                        0       -7,2    # _   _            _
                        RCV             # R = RDEVIATION + RCONIC
                BOF     ABVAL
                        MOONFLAG
                        EARSPH
                SR2     BDSU            # INSIDE
                        RSPHERE
                GOTO
                        ORIGEX
EARSPH          VSU     ABVAL           # OUTSIDE
                        RPQV
                DSU     GOTO
                        RSPHERE
                        ORIGEX

DOSWITCH        CALL
                        ORIGCHNG
                GOTO
                        INTGRATE
```

```
# Page 1346
ORIGCHNG        STQ     CALL
                        ORIGEX
                        RECTIFY
                VLOAD   VSL*
                        RCV
                        0,2
                VSU     VSL*
                        RPQV
                        2,2
                STORE   RRECT
                STODL   RCV
                        TET
                CALL
                        LUNVEL
                BOF     VCOMP
                        MOONFLAG
                        +1
                PDVL    VSL*
                        VCV
                        0,2
                VSU
                VSL*
                        0 +2,2
                STORE   VRECT
                STORE   VCV
                LXA,2   SXA,2
                        ORIGEX
                        QPRET
                BON     GOTO
                        MOONFLAG
                        CLRMOON
                        SETMOON
# Page 1347
# THE RECTIFY SUBROUTINE IS CALLED BY THE INTEGRATION PROGRAM AND OCCASIONALLY BY THE
# ROUTINES TO ESTABLISH A NEW CONIC.

RECTIFY         LXA,2   VLOAD
                        PBODY
                        TDELTAV
                VSL*    VAD
                        0       -7,2
                        RCV
                STORE   RRECT
                STOVL   RCV
                        TNUV
```

```
                VSL*    VAD
                        0       -4,2
                        VCV
MINIRECT        STORE   VRECT
                STOVL   VCV
                        ZEROVEC
                STORE   TDELTAV
                STODL   TNUV
                        ZEROVEC
                STORE   TC
                STORE   XKEP
                RVQ

# Page 1348
# THE THREE DIFEQ ROUTINES -- DIFEQ+0, DIFEQ+12, DIFEQ+24 -- ARE ENTERED TO PROCESS THE CONTRIB
# BEGINNING, MIDDLE, AND END OF THE TIMESTEP, RESPECTIVELY.  THE UPDATING IS DONE BY THE NYSTRO

DIFEQ+0         VLOAD   VSR3
                        FV
                STCALL  PHIV
                        DIFEQCOM
DIFEQ+1         VLOAD   VSR1
                        FV
                PUSH    VAD
                        PHIV
                STOVL   PSIV
                VSR1    VAD
                        PHIV
                STCALL  PHIV
                        DIFEQCOM
DIFEQ+2         DLOAD   DMPR
                        H
                        DP2/3
                PUSH    VXSC
                        PHIV
                VSL1    VAD
                        ZV
                VXSC    VAD
                        H
                        YV
                STOVL   YV
                        FV
                VSR3    VAD
                        PSIV
                VXSC    VSL1
                VAD
```

```
                        ZV
                STORE   ZV
                BOFF    CALL
                        JSWITCH
                        ENDSTATE
                        GRP2PC
                LXA,2   VLOAD
                        COLREG
                        ZV
                VSL3                    # ADJUST W-POSITION FOR STORAGE
                STORE   W       +54D,2
                VLOAD
                        YV
                VSL3    BOV
                        WMATEND
                STORE   W,2

                CALL
                        GRP2PC
# Page 1349
                LXA,2   SSP
                        COLREG
                        S2
                        0
                INCR,2  SXA,2
                        6
                        YV
                TIX,2   CALL
                        RELOADSV
                        GRP2PC
                LXA,2   SXA,2
                        YV
                        COLREG

NEXTCOL         CALL
                        GRP2PC
                LXA,2   VLOAD*
                        COLREG
                        W,2
                VSR3                    # ADJUST W-POSITION FOR INTEGRATION
                STORE   YV
                VLOAD*  AXT,1
                        W       +54D,2
                        0
                VSR3                    # ADJUST W-VELOCITY FOR INTEGRATION
                STCALL  ZV
```

```
                        DIFEQ0

ENDSTATE        BOV     VLOAD
                        GOBAQUE
                        ZV
                STOVL   TNUV
                        YV
                STORE   TDELTAV
                BON     BOFF
                        MIDAVFLG
                        CKMID2          # CHECK FOR MID2 BEFORE GOING TO TIMEINC
                        DIMOFLAG
                        TESTLOOP
                EXIT
                TC      PHASCHNG
                OCT     04022           # PHASE 1
                TC      UPFLAG          # PHASE CHANGE HAS OCCURRED BETWEEN
                ADRES   REINTFLG        # INTSTALL AND INTWAKE
                TC      INTPRET
                SSP
                        QPRET
                        AMOVED
                BON     GOTO
                        VINTFLAG
# Page 1350
                        ATOPCSM
                        ATOPLEM
AMOVED          SET     SSP
                        JSWITCH
                        COLREG
                DEC     -30
                BOFF    SSP
                        D6OR9FLG
                        NEXTCOL
                        COLREG
                DEC     -48
                GOTO
                        NEXTCOL

RELOADSV        DLOAD                   # RELOAD TEMPORARY STATE VECTOR
                        TDEC            # FROM PERMANENT IN CASE OF
                STCALL  TDEC1
                        INTEGRV2        # BY STARTING AT INTEGRV2.
DIFEQCOM        DLOAD   DAD             # INCREMENT H AND DIFEQCNT.
                        DT/2
                        H
```

```
                INCR,1  SXA,1
                DEC     -12
                        DIFEQCNT        # DIFEQCNT SET FOR NEXT ENTRY.
                STORE   H
                VXSC    VSR1
                        FV
                VAD     VXSC
                        ZV
                        H
                VAD
                        YV
                STORE   ALPHAV
                BON     GOTO
                        JSWITCH
                        DOW..
                        FBR3

WMATEND         CLEAR   CLEAR
                        DIMOFLAG        # DON'T INTEGRATE W THIS TIME
                        ORBWFLAG        # INVALIDATE W
                CLEAR
                        RENDWFLG
                SET     EXIT
                        STATEFLG        # PICK UP STATE VECTOR UPDATE
                TC      ALARM
                OCT     421
                TC      INTPRET
# Page 1351
                GOTO
                        TESTLOOP        # FINISH INTEGRATING STATE VECTOR

# Page 1352
# ORBITAL ROUTINE FOR EXTRAPOLATION OF THE W MATRIX.  IT COMPUTES THE SECOND DERIVATI
# VECTOR OF THE MATRIX AND CALLS THE NYSTROM INTEGRATION ROUTINES TO SOLVE THE DIFFER
# USES A TABLE OF VEHICLE POSITION VECTORS COMPUTED DURING THE INTEGRATION OF THE VEH

DOW..           LXA,2   DLOAD*
                        PBODY
                        MUEARTH,2
                STCALL  BETAM
                        DOW..1
                STORE   FV
                BOF     INCR,1
                        MIDFLAG
                        NBRANCH
                DEC     -6
```

```
                LXC,2   DLOAD*
                        PBODY
                        MUEARTH         -2,2
                STCALL  BETAM
                        DOW..1
                BON     VSR6
                        MOONFLAG
                        +1
                VAD
                        FV
                STCALL  FV
                        NBRANCH
DOW..1          VLOAD   VSR4
                        ALPHAV
                PDVL*   UNIT
                        VECTAB,1
                PDVL    VPROJ
                        ALPHAV
                VXSC    VSU
                        3/4
                PDDL    NORM
                        36D
                        S2
                PUSH    DSQ
                DMP
                NORM    PDDL
                        34D
                        BETAM
                SR1     DDV
                VXSC
                LXA,2   XAD,2
                        S2
                        S2
                XAD,2   XAD,2
                        S2
                        34D
                VSL*    RVQ
# Page 1353
                        0 -8D,2

                SETLOC  ORBITAL1
                BANK

3/5             2DEC    .6 B-2

THREE/8         2DEC    .375
```

```
.3D             2DEC    .3 B-2

3/64            2DEC    3 B-6

DP1/4           2DEC    .25

DQUARTER        EQUALS  DP1/4
POS1/4          EQUALS  DP1/4
3/32            2DEC    3 B-5

15/16           2DEC    15. B-4

3/4             2DEC    3.0 B-2

7/12            2DEC    .5833333333

9/16            2DEC    9 B-4

5/128           2DEC    5 B-7

DPZERO          EQUALS  ZEROVEC
DP2/3           2DEC    .6666666667

2/3             EQUALS  DP2/3
OCT27           OCT     27

                BANK    13
                SETLOC  ORBITAL2
                BANK
# IT IS VITAL THAT THE FOLLOWING CONSTANTS NOT BE SHUFFLED
                DEC     -11
                DEC     -2
                DEC     -9
                DEC     -6
                DEC     -2
                DEC     -2
                DEC     0
                DEC     -12
                DEC     -9
                DEC     -4
ASCALE          DEC     -7
                DEC     -6
# Page 1354
                2DEC*   1.32715445 E16 B-54*    # S
```

```
                2DEC*   4.9027780 E8 B-30*      # M

MUEARTH         2DEC*   3.986032 E10 B-36*

                2DEC    0

J4REQ/J3        2DEC*   .4991607391 E7 B-26*

                2DEC    -176236.02 B-25

2J3RE/J2        2DEC*   -.1355426363 E5 B-27*

                2DEC*   .3067493316 E18 B-60*

J2REQSQ         2DEC*   1.75501139 E21 B-72*

3J22R2MU        2DEC*   9.20479048 E16 B-58*

5/8             2DEC    5 B-3

-1/12           2DEC    -.1

MUM             =       MUEARTH -2
RECRATIO        2DEC    .01

RSPHERE         2DEC    64373.76 E3 B-29

RDM             2DEC    16093.44 E3 B-27

RDE             2DEC    80467.20 E3 B-29

RATT            EQUALS  00
VATT            EQUALS  6D
TAT             EQUALS  12D
RATT1           EQUALS  14D
VATT1           EQUALS  20D
MU(P)           EQUALS  26D
TDEC1           EQUALS  32D
URPV            EQUALS  14D
COSPHI/2        EQUALS  URPV    +4
UZ              EQUALS  20D
TVEC            EQUALS  26D
```

Uses 504LM 175, A 80, ALPHAM 177, ALPHAV 177, BETAM 177, BETAV 177, COLREG 157, COUNT 142,

D6OR9FLG 109, DELT 188, DIFEQCNT 169, DIMOFLAG 109, DT/2 177, E32C31RM 174, F 238, FACTOR 226, FV 177, H 177, IT 185, JSWITCH 95, KEPRTN 177, MIDAVFLG 131, MIDFLAG 95, MOONFLAG 95, MPAC 145, ORBITAL 59, ORBITAL1 59, ORBITAL2 61, ORBWFLAG 107, ORIGEX 177, P 188, PBODY 177, PHIV 177, PSIV 177, Q 80, QPRET 85, RCV 169, REINTFLG 135, RENDWFLG 117, RHO 211, RPQFLAG 125, RPQV 177, RPSV 177, RRECT 169, S1 85, S2 85, SQ 156, SR 80, STATE 138, STATEFLG 107, TAU 211, TAU. 177, TC 169, TDEC 157, TDELTAV 169, TET 169, TNUV 169, V 229, VCV 169, VECTAB 177, VINTFLAG 109, VRECT 169, W 183, X1 85, X2 85, XKEP 169, XKEPNEW 177, YV 157, Z 80, and ZV 157.

3.7.15 inflight alignment routines

1834 ⟨*inflight alignment routines* 1834⟩≡ (1523a)

⟨*Page CM1355* 1835⟩
⟨*Page CM1356* 1836⟩
⟨*Page CM1357* 1837⟩
⟨*Page CM1358* 1838⟩
⟨*Page CM1359* 1839⟩
⟨*Page CM1360* 1840⟩
⟨*Page CM1361* 1841⟩
⟨*Page CM1362* 1842a⟩
⟨*Page CM1363* 1842b⟩
⟨*Page CM1364* 1843a⟩

1835 ⟨*Page CM1355* 1835⟩≡ (1834 2715)

```
                BANK    22
                SETLOC  INFLIGHT
                BANK

                EBANK=  XSM

# CALCGTA COMPUTES THE GYRO TORQUE ANGLES REQUIRED TO BRING THE STABLE MEMBER INTO THE DESIRED
#
# THE INPUT IS THE DESIRED STABLE MEMBER COORDINATES REFERRED TO PRESENT STABLE MEMBER COORDINA
# HALF-UNIT VECTORS ARE STORED AT XDC, YDC, AND ZDC.
#
# THE OUTPUTS ARE THE THREE GYRO TORQUE ANGLES TO BE APPLIED TO THE Y, Z, AND X GYROS AND ARE S
# MGC, AND OGC RESPECTIVELY.

                COUNT   23/INFLT

CALCGTA         ITA     DLOAD           # PUSHDOWN 00-03, 16D-27D, 34D-37D
                        S2              # XDC = (XD1 XD2 XD3)
                        XDC             # YDC = (YD1 YD2 YD3)
                PDDL    PDDL            # ZDC = (ZD1 ZD2 ZD3)
                        HI6ZEROS
                        XDC     +4
                DCOMP   VDEF
                UNIT
                STODL   ZPRIME          # ZP = UNIT(-XD3 0 XD1) = (ZP1 ZP2 ZP3)
                        ZPRIME

                SR1
                STODL   SINTH           # SIN(IGC) = ZP1
                        ZPRIME  +4
                SR1
                STCALL  COSTH           # COS(IGC) = ZP3
                        ARCTRIG

                STODL   IGC             # Y GYRO TORQUING ANGLE   FRACTION OF REV.
                        XDC     +2
                SR1
                STODL   SINTH           # SIN(MGC) = XD2
                        ZPRIME

                DMP     PDDL
                        XDC     +4      # PD00 = (ZP1)(XD3)
                        ZPRIME  +4

                DMP     DSU
```

```
        XDC             # MPAC = (ZP3)(XD1)
STADR
STCALL  COSTH           # COS(MGC) = MPAC - PD00
        ARCTRIG
```

Uses COSTH 148, COUNT 142, EBANK 80, HI6ZEROS 71, IGC 186, INFLIGHT 65, MGC 186, MPAC 145, OGC 186, S2 85, SINTH 148, XDC 186, XSM 186, YDC 186, Z 80, ZDC 186, and ZPRIME 148.

1836 ⟨*Page CM1356* 1836⟩≡ (1834 2715)

```
STOVL   MGC             # Z GYRO TORQUING ANGLE   FRACTION OF REV.
        ZPRIME
DOT
        ZDC
STOVL   COSTH           # COS(OGC) = ZP . ZDC
        ZPRIME
DOT
        YDC
STCALL  SINTH           # SIN(OGC) = ZP . YDC
        ARCTRIG

STCALL  OGC             # X GYRO TORQUING ANGLE   FRACTION OF REV.
        S2
```

Uses COSTH 148, MGC 186, OGC 186, S2 85, SINTH 148, YDC 186, Z 80, ZDC 186, and ZPRIME 148.

1837 ⟨*Page CM1357* 1837⟩≡ (1834 2715)

```
# ARCTRIG COMPUTES AN ANGLE GIVEN THE SINE AND COSINE OF THIS ANGLE.
#
# THE INPUTS ARE SIN/4 AND COS/4 STORED DP AT SINTH AND COSTH.
#
# THE OUTPUT IS THE CALCULATED ANGLE BETWEEN +.5 AND -.5 REVOLUTIONS AND STORED AT THETA.  THE
# AVAILABLE AT MPAC.

ARCTRIG         DLOAD   ABS             # PUSHDOWN  16D-21D
                        SINTH
                DSU     BMN
                        QTSN45          # ABS(SIN/4) - SIN(45)/4
                        TRIG1           # IF (-45,45) OR (135,-135)

                DLOAD   SL1             # (45,135) OR (-135,-45)
                        COSTH
                ACOS    SIGN
                        SINTH
                STORE   THETA           # X = ARCCOS(COS) WITH SIGN(SIN)
                RVQ

TRIG1           DLOAD   SL1             # (-45,45) OR (135,-135)
                        SINTH
                ASIN
                STODL   THETA           # X = ARCSIN(SIN) WITH SIGN(SIN)
                        COSTH
                BMN
                        TRIG2           # IF (135,-135)

                DLOAD   RVQ
                        THETA           # X = ARCSIN(SIN)   (-45,45)

TRIG2           DLOAD   SIGN            # (135,-135)
                        HIDPHALF
                        SINTH
                DSU
                        THETA
                STORE   THETA           # X = .5 WITH SIGN(SIN) - ARCSIN(SIN)
                RVQ                     #       (+) - (+) OR (-) - (-)
```

Uses COSTH 148, HIDPHALF 71, MPAC 145, SINTH 148, and THETA 148.

1838 ⟨*Page CM1358* 1838⟩≡ (1834 2715)

```
# SMNB, NBSM, AND AXISROT, WHICH USED TO APPEAR HERE, HAVE BEEN
# COMBINED IN A ROUTINE CALLED AX*SR*T, WHICH APPEARS AMONG THE POWERED
# FLIGHT SUBROUTINES.
```

Uses `A` 80 and `SR` 80.

1839 ⟨*Page CM1359* 1839⟩≡ (1834 2715)

```
# CALCGA COMPUTES THE CDU DRIVING ANGLES REQUIRED TO BRING THE STABLE MEMBER INTO THE DESIRED C
#
# THE INPUTS ARE  1) THE NAVIGATION BASE COORDINATES REFERRED TO ANY COORDINATE SYSTEM.  THE TH
# VECTORS ARE STORED AT XNB, YNB, AND ZNB.  2) THE DESIRED STABLE MEMBER COORDINATES REFERRED T
# COORDINATE SYSTEM ARE STORED AT XSM, YSM, AND ZSM.
#
# THE OUTPUTS ARE THE THREE CDU DRIVING ANGLES AND ARE STORED SP AT THETAD, THETAD +1, AND THET

CALCGA          SETPD                   # PUSHDOWN 00-05, 16D-21D, 34D-37D
                        0
                VLOAD   VXV
                        XNB             # XNB = OGA (OUTER GIMBAL AXIS)
                        YSM             # YSM = IGA (INNER GIMBAL AXIS)
                UNIT    PUSH            # PD0 = UNIT(OGA X IGA) = MGA

                DOT     ITA
                        ZNB
                        S2
                STOVL   COSTH           # COS(OG) = MGA . ZNB
                        0
                DOT
                        YNB
                STCALL  SINTH           # SIN(OG) = MGA . YNB
                        ARCTRIG
                STOVL   OGC
                        0

                VXV     DOT             # PROVISION FOR MG ANGLE OF 90 DEGREES
                        XNB
                        YSM
                SL1
                STOVL   COSTH           # COS(MG) = IGA . (MGA X OGA)
                        YSM
                DOT
                        XNB
                STCALL  SINTH           # SIN(MG) = IGA . OGA
                        ARCTRIG
                STORE   MGC

                ABS     DSU
                        .166...
                BPL
                        GIMLOCK1        # IF ANGLE GREATER THAN 60 DEGREES

CALCGA1         VLOAD   DOT
```

```
                        ZSM
                        0
                STOVL   COSTH           # COS(IG) = ZSM . MGA
                        XSM
```

Uses COSTH 148, MGC 186, OGA 206, OGC 186, S2 85, SINTH 148, THETAD 157, XNB 186, XSM 186, YNB 186, YSM 186, ZNB 186, and ZSM 186.

1840 ⟨*Page CM1360* 1840⟩≡ (1834 2715)

```
                DOT     STADR
                STCALL  SINTH           # SIN(IG) = XSM . MGA
                        ARCTRIG

                STOVL   IGC
                        OGC
                RTB     BONCLR
                        V1STO2S
                        CPHIFLAG
                        S2
                STCALL  THETAD
                        S2

GIMLOCK1        EXIT
                TC      ALARM
                OCT     00401
                TC      UPFLAG          # GIMBAL LOCK HAS OCCURRED
                ADRES   GLOKFAIL

                TC      INTPRET
                GOTO
                        CALCGA1
```

Uses CPHIFLAG 95, GLOKFAIL 105, IGC 186, OGC 186, S2 85, SINTH 148, TC 169, THETAD 157, and XSM 186.

1841 ⟨*Page CM1361* 1841⟩≡ (1834 2715)

```
# AXISGEN COMPUTES THE COORDINATES OF ONE COORDINATE SYSTEM REFERRED TO ANOTHER COORDINATE SYST
#
# THE INPUTS ARE  1) THE STAR1 VECTOR REFERRED TO COORDINATE SYSTEM A STORED AT STARAD.  2) THE
# REFERRED TO COORDINATE SYSTEM A STORED AT STARAD +6.  3) THE STAR1 VECTOR REFERRED TO COORDIN
# AT LOCATION 6 OF THE VAC AREA.  4) THE STAR2 VECTOR REFERRED TO COORDINATE SYSTEM B STORED AT
# THE VAC AREA.
#
# THE OUTPUT DEFINES COORDINATE SYSTEM A REFERRED TO COORDINATE SYSTEM B.  THE THREE HALF-UNIT
# AT LOCATIONS XDC, XDC +6, XDC +12D, AND STARAD, STARAD +6, STARAD +12D.

AXISGEN         AXT,1   SSP             # PUSHDOWN 00-30D, 34D-37D
                        STARAD  +6
                        S1
                        STARAD  -6

                SETPD
                        0
AXISGEN1        VLOAD*  VXV*            # 06D   UA = S1
                        STARAD  +12D,1  #       STARAD +00D     UB = S1
                        STARAD  +18D,1
                UNIT                    # 12D   VA = UNIT(S1 X S2)
                STORE   STARAD  +18D,1  #       STARAD +06D     VB = UNIT(S1 X S2)
                VLOAD*
                        STARAD  +12D,1

                VXV*    VSL1
                        STARAD  +18D,1  # 18D   WA = UA X VA
                STORE   STARAD  +24D,1  #       STARAD +12D     WB = UB X VB

                TIX,1
                        AXISGEN1

                AXC,1   SXA,1
                        6
                        30D

                AXT,1   SSP
                        18D
                        S1
                        6

                AXT,2   SSP
                        6
                        S2
                        2
```

```
AXISGEN2        XCHX,1  VLOAD*
                        30D             # X1=-6 X2=+6   X1=-6 X2=+4     X1=-6 X2=+2
                        0,1
```

Uses `A` 80, `S1` 85, `S2` 85, `STARAD` 186, `X1` 85, `X2` 85, and `XDC` 186.

1842a ⟨*Page CM1362* 1842a⟩≡ (1834 2715)

```
                VXSC*   PDVL*           # J=(UA)(UB1)   J=(UA)(UB2)     J=(UA)(UB3)
                        STARAD  +6,2
                        6,1
                VXSC*
                        STARAD  +12D,2
                STOVL*  24D             # K=(VA)(VB1)   J=(VA)(VB2)     J=(VA)(VB3)
                        12D,1

                VXSC*   VAD
                        STARAD  +18D,2  # L=(WA)(WB1)   J=(WA)(WB2)     J=(WA)(WB3)
                VAD     VSL1
                        24D
                XCHX,1  UNIT
                        30D
                STORE   XDC     +18D,1  # XDC = L+J+K   YDC = L+J+K     ZDC = L+J+K

                TIX,1
                        AXISGEN3

AXISGEN3        TIX,2
                        AXISGEN2

                VLOAD
                        XDC
                STOVL   STARAD
                        YDC
                STOVL   STARAD  +6
                        ZDC
                STORE   STARAD  +12D

                RVQ
```

Uses `L` 80, `STARAD` 186, `XDC` 186, `YDC` 186, and `ZDC` 186.

1842b ⟨*Page CM1363* 1842b⟩≡ (1834 2715)

```
QTSN45          2DEC    .1768
.166...         2DEC    .1666666667
```

1843a ⟨*Page CM1364* 1843a⟩≡ (1834 2715)

3.7.16 powered flight subroutines

1843b ⟨*powered flight subroutines* 1843b⟩≡ (1523a 2781)
⟨*Page CM1365* 1844⟩

1844 ⟨*Page CM1365* 1844⟩≡ (1843b)

```
# Page 1365
                BANK    14              # SAME FBANK AS THE FINDCDUD SUB-PROGRAM
                SETLOC  POWFLITE
                BANK

                EBANK=  DEXDEX
                COUNT*  $$/POWFL

# CDUTRIG, CDUTRIG1, CDUTRIG2, AND CD*GR*GS ALL COMPUTE THE SINES AND
# COSINES OF THREE 2'S COMPLEMENT ANGLES AND PLACE THE RESULT, DOUBLE
# PRECISION, IN THE SAME ORDER AS THE INPUTS, AT SINCDU AND COSCDU.  AN
# ADDITIONAL OUTPUT IS THE 1'S COMPLENT ANGLES AT CDUSPOT.  THESE
# ROUTINES GO OUT OF THEIR WAY TO LEAVE THE MPAC AREA AS THEY FIND IT.
# EXCEPT FOR THE GENERALLY UNIMPORTANT MPAC +2.  THEY DIFFER ONLY IN
# WHERE THEY GET THE ANGLES, AND IN METHOD OF CALLING.
#
# CDUTRIG (AND CDUTRIG1, WHICH CAN BE CALLED IN BASIC) COMPUTE THE
# SINES AND COSINES FROM THE CURRENT CONTENTS OF THE CDU REGISTERS.
# THE CONTENTS OF CDUTEMP, ETC., ARE NOT TOUCHED SO THAT THEY MAY
# CONTINUE TO FORM A CONSISTENT SET WITH THE LATEST PIPA READINGS.
#
# CDUTRIG1 IS LIKE CDUTRIG EXCEPT THAT IT CAN BE CALLED IN BASIC.
#
# CD*TR*GS FINDS CDU VALUES IN CDUSPOT RATHER THAN IN CDUTEMP.  THIS
# ALLOWS USERS TO MAKE TRANSFORMATIONS USING ARBITRARY ANGLES, OR REAL
# ANGLES IN AN ORDER OTHER THAN X Y Z.  A CALL TO THIS ROUTINE IS
# NECESSARY IN PREPARATION FOR A CALL TO AX*SR*T IN EITHER OF ITS TWO
# MODES (SMNB OR NBSM).  SINCE AX*SR*T EXPECTS TO FIND THE SINES AND
# COSINES IN THE ORDER Y Z X THE ANGLES MUST HAVE BEEN PLACED IN CDUSPOT
# IN THIS ORDER.  CD*TR*GS NEED NOT BE REPEATED WHEN AX*SR*T IS CALLED
# MORE THAN ONCE, PROVIDED THE ANGLES HAVE NOT CHANGED.  NOTE THAT SINCE
# IT CLOBBERS BUF2 (IN THE SINE AND COSINE ROUTINES) CD*TR*GS CANNOT BE
# CALLED USING BANKCALL.  SORRY.
#
# CD*TR*G IS LIKE CD*TR*GS EXCEPT THAT IT CAN BE CALLED IN
# INTERPRETIVE.

CDUTRIG         EXIT
                TC      CDUTRIGS
                TC      INTPRET
                RVQ

CD*TR*G         EXIT
                TC      CD*TR*GS
                TC      INTPRET
```

```
                RVQ

CDUTRIGS        CA      CDUX
                TS      CDUSPOT +4
                CA      CDUY
                TS      CDUSPOT
# Page 1366
                CA      CDUZ
                TS      CDUSPOT +2

CD*TR*GS        EXTEND
                QXCH    TEM2
                CAF     FOUR
TR*GL**P        MASK    SIX             # MAKE IT EVEN AND SMALLER
                TS      TEM3
                INDEX   TEM3
                CA      CDUSPOT
                DXCH    MPAC            # STORING 2'S COMP ANGLE, LOADING MPAC
                DXCH    VBUF +4         # STORING MPAC FOR LATER RESTORATION
                TC      USPRCADR
                CADR    CDULOGIC
                EXTEND
                DCA     MPAC
                INDEX   TEM3
                DXCH    CDUSPOT         # STORING 1'S COMPLEMENT ANGLE
                TC      USPRCADR
                CADR    COSINE
                DXCH    MPAC
                INDEX   TEM3
                DXCH    COSCDU          # STORING COSINE
                EXTEND
                INDEX   TEM3
                DCA     CDUSPOT         # LOADING 1'S COMPLEMENT ANGLE
                TC      USPRCADR
                CADR    SINE +1         # SINE +1 EXPECTS ARGUMENT IN A AND L
                DXCH    VBUF +4         # BRINGING UP PRIOR MPAC TO BE RESTORED
                DXCH    MPAC
                INDEX   TEM3
                DXCH    SINCDU
                CCS     TEM3
                TCF     TR*GL**P
                TC      TEM2
# Page 1367
# ******************************************************************************************
# QUICTRIG, INTENDED FOR QUIDANCE CYCLE USE WHERE TIME IS CRITICAL, IS A MUCH FASTER VERSION OF
# QUICTRIG COMPUTES AND STORES THE SINES AND COSINES OF THE 2'S COMPLEMENT ANGLES AT CDUSPOT, C
```

```
# AND CDUSPOT +4.  UNLIKE CD*TR*GS, QUICTRIG DOES NOT LEAVE THE 1'S COMPLEMENT VERSIO
# CDUSPOT.  QUICTRIG'S EXECUTION TIME IS 4.1 MS;    THIS IS 10 TIMES AS FAST AS CD*TR
# CALLED FROM INTERPRETIVE AS AN RTB OP-CODE, OR FROM BASIC VIA BANKCALL OR IBNKCALL.

QUICTRIG        INHINT                  # INHINT SINCE DAP USES THE SAME TEMPS
                EXTEND
                QXCH    ITEMP1
                CAF     FOUR
        +4      MASK    SIX
                TS      ITEMP2
                INDEX   ITEMP2
                CA      CDUSPOT
                TC      SPSIN
                EXTEND
                MP      BIT14           # SCALE DOWN TO MATCH INTERPRETER OUTPUTS
                INDEX   ITEMP2
                DXCH    SINCDU
                INDEX   ITEMP2
                CA      CDUSPOT
                TC      SPCOS
                EXTEND
                MP      BIT14
                INDEX   ITEMP2
                DXCH    COSCDU
                CCS     ITEMP2
                TCF     QUICTRIG +4
                CA      ITEMP1
                RELINT
                TC      A
# Page 1368
#*************************************************************************
# THESE INTERFACE ROUTINES MAKE IT POSSIBLE TO CALL AX*SR*T, ETC., IN
# INTERPRETIVE.  LATER, WHERE POSSIBLE, THEY WILL BE ELIMINATED.
#
# NBSM WILL BE THE FIRST TO GO.  IT SHOULD NOT BE USED.

NBSM            STQ
                        X2
                LXC,1   VLOAD*
                        S1              # BASE ADDRESS OF THE CDU ANGLES IS IN S1
                        0,1
                STOVL   CDUSPOT
                        32D             # VECTOR TO BE TRANSFORMED IS IN 32D
                CALL
                        TRG*NBSM
                STCALL  32D             # SINCE THERE'S NO STGOTO
```

```
                        X2

# THESE INTERFACE ROUTINES ARE PERMANENT.  ALL RESTORE USER'S EBANK
# SETTING. ALL ARE STRICT INTERPRETIVE SUBROUTINES, CALLED USING "CALL",
# RETURNING VIA QPRET.  ALL EXPECT AND RETURN THE VECTOR TO BE TRANSFOR-
# MED INTERPRETER-STYLE IN MPAC: COMPONENTS AT MPAC, MPAC +3, AND MPAC +5.
#
# TRG*SMNB AND TRG*NBSM BOTH EXPECT TO SEE THE 2'S COMPLEMENT ANGLES
# AT CDUSPOT (ORDER Y Z X, AT CDUSPOT, CDUSPOT +2, AND CDUSPOT +4. ODD
# LOCATIONS NEED NOT BE ZEROED).  TRG*NBSM DOES THE NB TO SM TRANSFOR-
# MATION:  TRG*SMNB, VICE VERSA.
#
# CDU*NBSM DOES ITS TRANSFORMATION USING THE PRESENT CONTENTS OF
# THE CDL COUNTERS.  OTHERWISE IT IS LIKE TRG*NBSM.
#
# CDU*SMNB IS THE COMPLEMENT OF CDU*NBSM.

CDU*SMNB        EXIT
                TC      CDUTRIGS
                TCF     C*MM*N1

TRG*SMNB        EXIT
                TC      CD*TR*GS
C*MM*N1         TC      MPACVBUF        # AX*SR*T EXPECTS VECTOR IN VBUF
                CS      THREE           # SIGNAL FOR SM TO NB TRANSFORMATION.
C*MM*N2         TC      AX*SR*T
                TC      INTPRET
                VLOAD   RVQ
                        VBUF

CDU*NBSM        EXIT
                TC      CDUTRIGS

# Page 1369

                TCF     C*MM*N3

TRG*NBSM        EXIT
                TC      CD*TR*GS
C*MM*N3         TC      MPACVBUF        # FOR AX*SR*T
                CA      THREE           # SIGNAL FOR NB TO SM TRANSFORMATION
                TCF     C*MM*N2

# *NBSM* AND *SMNB* EXPECT TO SEE THE SINES AND COSINES (AT SINCDU
# AND COSCDU) RATHER THAN THE ANGLES THEMSELVES.  OTHERWISE THEY ARE
# LIKE TRG*NBSM AND TRG*SMNB.
```

```
#
# NOTE THAT JUST AS CD*TR*GS NEED BE CALLED ONLY ONCE FOR EACH SERIES
# OF TRANSFORMATIONS USING THE SAME ANGLES, SO TOO ONLY ONE OF TRG*NBSM
# AND TRG*SMNB NEED BE CALLED FOR EACH SERIES.  FOR SUBSEQUENT TRANFOR-
# MATIONS USE *NBSM* AND *SMNB*.

*SMNB*          EXIT
                TCF     C*MM*N1

*NBSM*          EXIT
                TCF     C*MM*N3

# AX*SR*T COMBINES THE OLD SMNB AND NBSM.  FOR THE NB TO SM
# TRANSFORMATION, ENTER WITH +3 IN A.  FOR SM TO NB, ENTER WITH -3.
# THE VECTOR TO BE TRANSFORMED ARRIVES, AND IS RETURNED, IN VBUF.
# AX*SR*T EXPECTS TO FIND THE SINES AND COSINES OF THE ANGLES OF ROTATION
# AT SINCDU AND COSCDU, IN THE ORDER Y Z X.  A CALL TO CD*TR*GS, WITH
# THE 2'S COMPLEMENT ANGLES (ORDER Y Z X) AT CDUSPOT, WILL TAKE CARE OF
# THIS.  HERE IS A SAMPLE CALLING SEQUENCE:--
#               TC      CDUTRIGS
#               CS      THREE           # ("CA THREE" FOR NBSM)
#               TC      AX*SR*T
# THE CALL TO CD*TR*GS NEED NOT BE REPEATED, WHEN AX*SR*T IS CALLED MORE
# THAN ONCE, UNLESS THE ANGLES HAVE CHANGED.
#
# AX*SR*T IS GUARANTEED SAFE ONLY FOR VECTORS OF MAGNITUDE LESS THAN
# UNITY.  A LOOK AT THE CASE IN WHICH A VECTOR OF GREATER MAGNITUDE
# HAPPENS TO LIE ALONG AN AXIS OF THE SYSTEM TO WHICH IT IS TO BE TRANS-
# FORMED CONVINCES ONE THAT THIS IS A RESTRICTION WHICH MUST BE ACCEPTED.

AX*SR*T         TS      DEXDEX          # WHERE IT BECOMES THE INDEX OF INDEXES.
                EXTEND
                QXCH    RTNSAVER

R*TL**P         CCS     DEXDEX          #               +3 --> 0        -3 --> 2
                CS      DEXDEX          # THUS:         +2 --> 1        -2 --> 1
                AD      THREE           #               +1 --> 2        -1 --> 0
# Page 1370
                EXTEND
                INDEX   A
                DCA     INDEXI
                DXCH    DEXI

                CA      ONE
                TS      BUF
                EXTEND
```

```
                INDEX   DEX1
                DCS     VBUF
                TCF     LOOP1           # REALLY BE A SUBTRACT, AND VICE VERSA

LOOP2           DXCH    BUF             # LOADING VECTOR COMPONENT, STORING INDEX

LOOP1           DXCH    MPAC
                CA      SINESLOC
                AD      DEX1
                TS      ADDRWD

                TC      DMPSUB          # MULTIPLY BY SIN(CDUANGLE)
                CCS     DEXDEX
                DXCH    MPAC            # NBSM CASE
                TCF     +3
                EXTEND                  # SMNB CASE
                DCS     MPAC
                DXCH    TERM1TMP

                CA      SIX             # SINCDU AND COSCDU (EACH 6 WORDS) MUST
                ADS     ADDRWD          #       BE CONSECUTIVE AND IN THAT ORDER

                EXTEND
                INDEX   BUF
                INDEX   DEX1
                DCA     VBUF
                DXCH    MPAC
                TC      DMPSUB          # MULTIPLY BY COS(CDUANGLE)
                DXCH    MPAC
                DAS     TERM1TMP
                DXCH    TERM1TMP
                DDOUBL
                INDEX   BUF
                INDEX   DEX1
                DXCH    VBUF
                DXCH    BUF             # LOADING INDEX, STORING VECTOR COMPONENT
                CCS     A               # 'CAUSE THAT'S WHERE THE INDEX NOW IS
                TCF     LOOP2

                EXTEND
                DIM     DEXDEX          # DECREMENT MAGNITUDE PRESERVING SIGN

# Page 1371
TSTPOINT        CCS     DEXDEX          # ONLY THE BRANCHING FUNCTION IS USED
                TCF     R*TL**P
                TC      RTNSAVER
```

```
                TCF     R*TL**P
                TC      RTNSAVER

SINESLOC        ADRES   SINCDU          # FOR USE IN SETTING ADDRWD

INDEXI          DEC     4               # **********   DON'T   ***********
                DEC     2               # **********   TOUCH   ***********
                DEC     0               # **********   THESE   ***********
                DEC     4               # ********** CONSTANTS ***********

# ****************************************************************************
# Page 1372
# THIS SUBROUTINE COMPUTES INCREMENTAL CHANGES IN CDU(GIMBAL) ANGLES FROM INCREMENTAL
# REQUIRES SM INCREMENTS AS A DP VECTOR SCALED AT ONE REVOLUTION(DTHETASM,+2,+4).  SI
# SINCDU,+2,+4 AND COSCDU,+2,+4 RESPECTIVELY, SCALED TO ONE HALF.  CDU INCREMENTS ARE
# ONE REVOLUTION.
#
#       *  COS(IGA)SEC(MGA)             0               -SIN(IGA)SEC(MGA) *
#       *                                                                  *
#       * -COS(IGA)TAN(MGA)             1                SIN(IGA)TAN(MGA) *
#       *                                                                  *
#       *      SIN(IGA)                 0                    COS(IGA)     *

                BANK    14
                SETLOC  POWFLIT1
                BANK

SMCDURES        DLOAD   DMP
                        DTHETASM
                        COSCDUY

                PDDL    DMP
                        DTHETASM +4
                        SINCDUY

                BDSU
                DDV
                        COSCDUZ
                STORE   DCDU

                DMP     SL1             # SCALE
                        SINCDUZ
                BDSU

                        DTHETASM +2
                STODL   DCDU +2
```

```
        DTHETASM

DMP     PDDL
        SINCDUY
        DTHETASM +4

DMP     DAD
        COSCDUY
SL1
STORE   DCDU +4
RVQ
```

Uses A 80, ADDRWD 140, BUF 142, BUF2 142, CDUSPOT 152, CDUX 80, CDUY 80, CDUZ 80, CODE 140, COSCDU 150, COSCDUY 150, COSCDUZ 150, COUNT 142, DCDU 211, DEX1 144, DEXDEX 144, DEXI 144, DTHETASM 211, EBANK 80, FBANK 80, IT 185, ITEMP1 138, ITEMP2 138, L 80, MM 226, MPAC 145, P 188, POWFLIT1 65, POWFLITE 65, QPRET 85, RTNSAVER 144, S1 85, SINCDU 150, SINCDUY 150, SINCDUZ 150, SR 80, TC 169, TEM2 142, TEM3 142, TERM1TMP 144, VBUF 140, X2 85, and Z 80.

3.7.17 time of free fall

1851 ⟨*time of free fall* 1851⟩≡ (1523a 2820)
⟨*Page CM1373* 1852⟩

1852 ⟨*Page CM1373* 1852⟩≡ (1851)

```
# Page 1373
# THE TFF SUBROUTINES MAY BE USED IN EITHER EARTH OR MOON CENTERED COORDINATES.  THE
# KNOW WHICH ORIGIN APPLIES.  IT IS THE USER WHO KNOWS, AND WHO SUPPLIES RONE, VONE,
# APPROPRIATE SCALE LEVEL FOR THE PROPER PRIMARY BODY.
#
#       EARTH ORIGIN    POSITION        -29     METERS
#                       VELOCITY        -7      METERS/CENTISECOND
#                       1/SQRT(MU)      +17     SQRT(CS SQ/METERS CUBED)
#
#       MOON ORIGIN     POSITION        -27     METERS
#                       VELOCITY        -5      METERS/CENTISECONDS
#                       1/SQRT(MU)      +14     SQRT(CS SQ/METERS CUBED)
#
# ALL DATA PROVIDED TO AND RECEIVED FROM ANY TFF SUBROUTINE WILL BE AT ONE OF THE LEV
# THE FREE FALL TIME IS RETURNED IN CENTISECONDS AT (-28).  PROGRAM TFF/CONIC WILL GE
# LEAVE IT IN VONE' AT (+10) IF EARTH ORIGIN AND (+9) IF MOON ORIGIN.
#
# THE USER MUST STORE THE STATE VECTOR IN RONE, VONE, AND MU IN THE FORM 1/SQRT(MU) I
# AT THE PROPER SCALE BEFORE CALLING TFF/CONIC.  SINCE RONE, VONE ARE IN THE EXTENDED
# THE USER MUST ALSO LOCK OUT THE EXTENDED VERBS, AND RELEASE THEM WHEN FINISHED.
#
# PROGRAMS CALC/TFF AND CALC/TPER ASSUME THAT THE TERMINAL RADIUS IS LESS THAN THE PE
# RADIUS.  THIS RESTRICTION CAN BE REMOVED BY A 15 W CODING CHANGE, BUT AT PRESENT IT
#
# THE FOLLOWING ERASABLE QUANTITIES ARE USED BY THE TFF ROUTINES, AND ARE LOCATED IN
#
#                                       BELOW   E:  IS USED FOR EARTH ORIGIN SCALE
#                                               M:  IS USED FOR MOON  ORIGIN SCALE
#
#TFFSW          =       119D    # BIT1  0 = CALCTFF             1 = CALCTPER
TFFDELQ         =       10D     #       Q2-Q1                   E: (-16)  M: (-15)
RMAG1           =       12D     #       ABVAL(RN)  M            E: (-29)  M: (-27)
#RPER           =       14D     #       PERIGEE RADIUS  M       E: (-29)  M: (-27)
TFFQ1           =       14D     #       R.V / SQRT(MUE)         E: (-16)  M: (-15)
#SDELF/2                        #       SIN(THETA) /2
CDELF/2         =       14D     #       COS(THETA) /2
#RAPO           =       16D     #       APOGEE RADIUS  M        E: (-29)  M: (-27)
NRTERM          =       16D     #       TERMINAL RADIUS  M      E: (-29+NR)
                                #                                         M: (-27+NR)
RTERM           =       18D     #       TERMINAL RADIUS  M      E: (-29)  M: (-27)
TFFVSQ          =       20D     #       -(V SQUARED/MU)  1/M    E: (20)   M: (18)
TFF1/ALF        =       22D     #       SEMI MAJ AXIS  M        E: (-22-2 NA)
                                #                                         M: (-20-2 N
TFFRTALF        =       24D     #       SQRT(ALFA)              E:(10+NA) M: (9+NA)
TFFALFA         =       26D     #       ALFA  1/M               E:(26-NR) M: (24-NR)
```

```
TFFNP           =       28D     #       SEMI LATUS RECTUM  M    E: (-38+2 NR)
                                #                                      M: (-36+2 NR)
TFF/RTMU        =       30D     #       1/SQRT(MU)              E: (17)   M: (14)
NRMAG           =       32D     #       PRESENT RADIUS  M       E: (-29+NR)
                                #                                      M: (-27+NR)
TFFX            =       34D     #
TFFTEM          =       36D     #       TEMPORARY
# Page 1374
#               REGISTERS S1, S2 ARE UNTOUCHED BY ANY TFF SUBROUTINE
#               INDEX REGISTERS X1, X2 ARE USED BY ALL TFF SUBROUTINES.  THEY ARE ESTAB-
#               LISHED IN TFF/CONIC AND MUST BE PRESERVED BETWEEN CALLS TO SUBSEQUENT
#               SUBROUTINES.
#               -NR                             C(X1) = NORM COUNT OF RMAG
#               -NA                             C(X2) = NORM COUNT OF SQRT(ABS(ALFA))

# Page 1375
# SUBROUTINE NAME:  TFFCONIC                    DATE:  01.29.67
# MOD NO:  0                                    LOG SECTION:  TIME OF FREE FALL
# MOD BY:  RR BAIRNSFATHER
# MOD NO:  1    MOD BY:  RR BAIRNSFATHER        DATE: 11 APR 67
# MOD NO:  2    MOD BY:  RR BAIRNSFATHER        DATE: 21 NOV 67         ADD MOON MU.
# MOD NO:  3    MOD BY:  RR BAIRNSFATHER        DATE: 21 MAR 68         ACCEPT DIFFERENT EARTH/
#
# FUNCTIONAL DESCRIPTION:  THIS SUBROUTINE IS CALLED TO COMPUTE THOSE CONIC PARAMETERS REQUIRED
#       SUBROUTINES AND TO ESTABLISH THEM IN THE PUSH LIST AREA.  THE PARAMETERS ARE LISTED UND
#       THE EQUATIONS ARE:
#               _   __ __
#               H = RN*VN                       ANGULAR MOMENTUM
#                     _ _
#               LCP = H.H / MU                  SEMI LATUS RECTUM
#                             __ __
#               ALFA = 2/RN - VN.VN / MU        RECIPROCAL SEMI MAJ AXIS, SIGNED
#
#       AND ALFA IS POS FOR ELLIPTIC ORBITS
#                    0 FOR PARABOLIC ORBITS
#                  NEG FOR HYPERBOLIC ORBITS.
#       SUBROUTINE ALSO COMPUTES AND SAVES RMAG.
#
# CALLING SEQUENCE:
#       TFFCONIC EXPECTS CALLER TO ENTER WITH CORRECT GRAVITATIONAL CONSTANT IN MPAC, IN THE FO
#       1/SQRT(MU).  THE PROGRAM WILL SAVE IN TFF/RTMU.  THE SCALE IS DETERMINED BY WHETHER EAR
#       ORIGIN IS USED.  THE CALLER MUST LOCK OUT THE EXTENDED VERBS BEFORE PROVIDING STATE VEC
#       VONE AT PROPER SCALE.  THE EXTENDED VERBS MUST BE RESTORED WHEN THE CALLER IS FINISHED
#       TFF ROUTINES.
#
#       ENTRY POINT TFFCONMU EXPECTS THAT TFF/RTMU IS ALREADY LOADED.
```

```
#
#       TO SPECIFY MU:  DLOAD   CALL            # IF MU ALREADY STORED:         CALL
#                               YOURMU          # 1/RTMU E:(17) M:(14)
#                               TFFCONIC
#       PUSHLOC = PDL+0, ARBITRARY IF LEQ 18D
#
# SUBROUTINES CALLED:  NONE
#
# NORMAL EXIT MODES:  RVQ
#
# ALARMS:  NONE
#
# OUTPUT:       THE FOLLOWING ARE STORED IN THE PUSH LIST AREA.
#               RMAG1           E:(-29) M:(-27)         M  RN, PRESENT RADIUS LENGTH
#               NRMAG           E:(-29+NR)              M  RMAG, NORMALIZED
#                               M:(-27+NR)
#               X1                                      -NR, NORM COUNT
#               TFFNP           E:(-38+2NR)             M  LCP, SEMI LATUS RECTUM, WE
#                               M:(-36+2NR)
#               TFF/RTMU        E:(17) M:(14)           1/SQRT(MU)
#               TFFVSQ          E:(20) M:(18)           1/M  -(V SQ/MU):  PRESENT VEL
#               TFFALFA         E:(26-NR)               1/M  ALFA, WEIGHTED BY NR
#                               M:(24-NR)
#               TFFRTALF        E:(10+NA)               SQRT(ALFA), NORMALIZED
#                               M:(9+NA)
# Page 1376
#               X2                                      -NA, NORM COUNT
#               TFF1/ALF        E:(-22-2NA)             SIGNED SEMI MAJ AXIS, WEIGHTE
#                               M:(-20-2NA)
#               PUSHLOC AT PDL+0
#
#       THE FOLLOWING IS STORED IN GENERAL ERASABLE
#               VONE'           E:(10) M:(9)            V/RT(MU), NORMALIZED VELOCITY
#
# ERASABLE INITIALIZATION REQUIRED:
#               RONE            E:(-29) M:(-27)         M  STATE VECTOR         LEFT
#               VONE            E:(-7) M:(-5)           M/CS  STATE VECTOR      LEFT
#               TFF/RTMU        E:(17) M:(14)           1/RT(CS SQ/M CUBE)      IF EN
#
# DEBRIS:       QPRET           PDL+0 ... PDL+3

                BANK    33
                SETLOC  TOF-FF
                BANK

                COUNT*  $$/TFF
```

```
TFFCONIC        STORE   TFF/RTMU        # 1/SQRT(MU)    E:(17) M:(14)

TFFCONMU        VLOAD   UNIT            # COME HERE WITH TFFRTMU LOADED.
                        RONE            # SAVED RN.  M  E:(-29) M:(-27)
                PDDL                    # UR/2 TO PDL+0, +5
                        36D             # MAGNITUDE
                STORE   RMAG1           # M  E:(-29) M:(-27)

                NORM
                        X1              # -NR
                STOVL   NRMAG           # RMAG  M  E:(-29+NR) M:(-27+NR)
                        VONE            # SAVED VN.  M/CS  E:(-7) M:(-5)
                VXSC
                        TFF/RTMU        # E:(17) M:(14)
                STORE   VONE'           # VN/SQRT(MU)  E:(10) M:(9)

                VXSC    VXV
                        NRMAG           # E:(-29+NR) M:(-27+NR)
                                        # UR/2 FROM PDL
                VSL1    VSQ             # BEFORE:  E:(-19+NR) M:(-18+NR)
                STODL   TFFNP           # LC P  M  E:(-38+2NR) M:(-36+2NR)
                                        # SAVE ALSO FOR VGAMCALC
                        TFF1/4
                DDV     PDVL            # (2/RMAG)  1/M  E:(26-NR) M:(24-NR)
                        NRMAG           # RMAG  M  E:(-29+NR) M:(-27+NR)
                        VONE'           # SAVED VN.  E:(10) M:(9)
                VSQ     DCOMP           # KEEP MPAC+2 HONEST FOR SQRT.
                STORE   TFFVSQ          # -(V SQ/MU)  E:(20) M:(18)
                                        # SAVE FOR VGAMCALC
                SR*     DAD
# Page 1377
                        0 -6,1          # GET -VSQ/MU  E:(26-NR) M:(24-NR)
                STADR
                                        # 2/RMAG  FROM PDL+2
                STORE   TFFALFA         # ALFA  1/M  E:(26-NR) M:(24-NR)
                SL*     PUSH            # TEMP SAVE ALFA  E:(20) M:(18)
                        0 -6,1
                ABS     SQRT            # E:(10) M:(9)
                NORM
                        X2              # X2 = -NA
                STORE   TFFRTALF        # SQRT( ABS(ALFA) )  E:(10+NA) M:(9+NA)
                DSQ     SIGN            # NOT SO ACCURATE, BUT OK
                                        # ALFA FROM PDL+2  E:(20) M:(18)
                BZE     BDDV            # SET 1/ALFA =0, TO SHOW SMALL ALFA
                        +2
```

```
                        TFF1/4
        +2      STORE   TFF1/ALF        # 1/ALFA  E:(-22-2NA) M:(-20-2NA)
DUMPCNIC        RVQ
                                        #                       39 W
# Page 1378
# SUBROUTINE NAME:  TFFRP/RA                    DATE: 01.17.67
# MOD NO:  0                                    LOG SECTION:  TIME OF FREE FALL
# MOD NO:  1    MOD BY:  RR BAIRNSFATHER        DATE: 11 APR 67
# MOD NO:  2    MOD BY:  RR BAIRNSFATHER        DATE: 21 MAR 68         ACCEPT DIFFER
#                                                                       ALSO IMPROVE
#
# FUNCTIONAL DESCRIPTION:  USED BY CALCTPER AND TFF DISPLAYS TO CALCULATE PERIGEE RAD
#       APOGEE RADIUS FOR A GENERAL CONIC.
#       PROGRAM GIVES PERIGEE RADIUS AS         APOGEE RADIUS IS GIVEN BY
#               RP = P/(1+E)                            RA = (1+E) / ALFA
#       WHERE    2
#               E  = 1 - P ALFA
#       IF RA IS NEGATIVE OR SHOWS DIVIDE OVERFLOW, THEN RA = POSMAX BECAUSE
#               1. APOGEE RADIUS IS NOT MEANINGFUL FOR HYPERBOLA
#               2. APOGEE RADIUS IS NOT DEFINED FOR PARABOLA
#               3. APOGEE RADIUS EXCEEDS THE SCALING FOR ELLIPSE.
#
#       THIS SUBROUTINE REQUIRED THE SIGNED RECIPROCAL SEMI MAJ AXIS, ALFA, AND SEMI
#
# CALLING SEQUENCE:     CALL
#                               TFFRP/RA
#       PUSHLOC = PDL+0, ARBITRARY IF LEQ 10D
#       C(MPAC) UNSPECIFIED
#
# SUBROUTINES CALLED:   NONE
#
# NORMAL EXIT MODE:     RVQ
#       IF ELLIPSE, WITHIN NORMAL SCALING, RAPO IS CORRECT.
#       OTHERWISE, RAPO = POSMAX.
#
# ALARMS:       NONE
#
# OUTPUT:       STORED IN PUSH LIST AREA.  SCALE OF OUTPUT AGREES WITH DATA SUPPLIED
#       RPER    E:(-29) M:(-27)         M       PERIGEE RADIUS          DESTROYED BY
#       RAPO    E:(-29) M:(-27)         M       APOGEE RADIUS           WILL BE DESTR
#       PUSHLOC AT PDL+0
#
# ERASABLE INITIALIZATION REQUIRED:
#       TFFALFA E:(26-NR)               M       1/SEMI MAJ AXIS LEFT BY TFFCONIC
#               M:(24-NR)
#       TFFNP   E:(-38+2NR)             M       LC P, SEMI LATUS RECTUM LEFT BY TFFCO
```

```
#               M:(-36+2NR)
#       X1                              -NR, NORM COUNT OF RMAG         LEFT BY TFFCONIC
#       X2                              -NA, NORM COUNT OF ALFA         LEFT BY TFFCONIC
#
# DEBRIS:       QPRET, PDL+0 ... PDL+1

# Page 1379
RAPO            =       16D             # APOGEE RADIUS  M  E:(-29) M:(-27)
RPER            =       14D             # PERIGEE RADIUS  M  E:(-29) M:(-27)

TFFRP/RA        DLOAD   DMP
                        TFFALFA         # ALFA  1/M  E:(26-NR) M:(24-NR)
                        TFFNP           # LC P  M E:(-38+2NR) M:(-36+2NR)
                SR*     DCOMP           # ALFA P (-12+NR)
                        0 -8D,1         # ALFA P (-4)
                DAD     ABS             # (DCOMP GIVES VALID TP RESULT FOR SQRT)
                                        # (ABS PROTECTS SQRT IF E IS VERY NEAR 0)
                        DP2(-4)
                SQRT    DAD             # E SQ = (1- P ALFA) (-4)
                        TFF1/4
                PUSH    BDDV            # (1+E)  (-2)  TO PDL+0
                        TFFNP           # LCP  M  E:(-38+2NR) M:(-36+2NR)
                SR*     SR*             # (DOES SR THEN SL TO AVOID OVFL)
                        0,1             # X1=-NR
                        0 -7,1          # (EFFECTIVE SL)
                STODL   RPER            # PERIGEE RADIUS  M  E:(-29) M:(-27)
                                        # (1+E)  (-2)  FROM PDL+0
                DMP     BOVB
                        TFF1/ALF        # E:(-22-2NA) M:(-20-2NA)
                        TCDANZIG        # CLEAR OVFIND, IF ON.
                BZE     SL*
                        MAXRA           # SET POSMAX IF ALFA=0
                        0 -5,2          # -5+NA
                SL*     BOV
                        0,2
                        MAXRA           # SET POSMAX IF OVFL.
                BPL                     # CONTINUE WITH VALID RAPO.
                        +3
MAXRA           DLOAD                   # RAPO CALC IS NOT VALID.  SET RAPO =
                        NEARONE         # POSMAX AS A TAG.
        +3      STORE   RAPO            # APOGEE RADIUS  M  E:(-29) M:(-27)
DUMPRPRA        RVQ
                                        #                       30 W
# Page 1380
# SUBROUTINE NAME:  CALCTPER / CALCTFF          DATE:  01.29.67
# MOD NO:  0                                    LOG SECTION:  TIME OF FREE FALL
```

```
# MOD BY:  RR BAIRNSFATHER
# MOD NO:  1    MOD BY:  RR BAIRNSFATHER        DATE: 21 MAR 67
# MOD NO:  2    MOD BY:  RR BAIRNSFATHER        DATE: 14 APR 67
# MOD BY:  3    MOD BY:  RR BAIRNSFATHER        DATE: 8 JUL 67          NEAR EARTH MU
# MOD BY:  4    MOD BY:  RR BAIRNSFATHER        DATE: 21 NOV 67         ADD VARIABLE
# MOD BY:  5    MOD BY:  RR BAIRNSFATHER        DATE: 21 MAR 68         ACCEPT DIFFER
#
# FUNCTIONAL DESCRIPTION:  PROGRAM CALCULATES THE FREE-FALL TIME OF FLIGHT FROM PRESE
#       VELOCITY VN TO A RADIUS LENGTH SPECIFIED BY RTERM, SUPPLIED BY THE USER.  THE
#       RN MAY BE ON EITHER SIDE OF THE CONIC, BUT RTERM IS CONSIDERED ON THE INBOUND
#       THE EQUATIONS ARE:
#
#               Q2 = -SQRT(RTERM (2-RTERM ALFA) - LCP)  (INBOUND SIDE)  LEQ +- LCE/SQ
#                    -- --
#               Q1 = RN.VN / SQRT(MU)                                   LEQ +- LCE/SQ
#
#               Z = NUM / DEN                                           LEQ +- 1/SQRT
#
#       WHERE, IF INBOUND
#               NUM = RTERM -RN                                         LEQ +- 2 LCE/
#               DEN = Q2+Q1                                             LEQ +- 2 LCE/
#
#       AND, IF OUTBOUND
#               NUM = Q2-Q1                                             LEQ +- 2 LCE/
#               DEN = 2 - ALFA (RTERM + RN).                            LEQ +- 2 LCE
#
#       IF      ALFA ZZ < 1.0           (FOR ALL CONICS EXCEPT ELLIPSES HAVING ABS(DE
#       THEN    X = ALFA Z Z
#       AND     TFF = (RTERM +RN -2 ZZ T(X) ) Z/SQRT(MU)
#               EXCEPT  IF ALFA PNZ, AND IF TFF NEG,
#               THEN    TFF = 2 PI /(ALFA SQRT(ALFA)) + TFF
#       OR      IF ALFA ZZ GEQ 1.0      (FOR ELLIPSES HAVING ABS(DEL ECC ANOM) GEQ 90
#       THEN    X = 1/ALFA Z Z
#       AND     TFF = (PI/SQRT(ALFA) -Q2 +Q1 +2(X T(X) -1) /ALFA Z) /ALFA SQRT(MU)
#       WHERE   T(X) IS A POLYNOMIAL APPROXIMATION TO THE SERIES
#                            2      3             2
#               1/3 - X/5 + X /7 - X /8 ...     (X  < 1.0)
#
# CALLING SEQUENCE:     TIME TO RTERM                   TIME TO PERIGEE
#                       CALL                            CALL
#                               CALCTFF                         CALCTPER
#                       C(MPAC) = TERMNL RAD M          C(MPAC) = PERIGEE RAD M
#       FOR EITHER, E:(-29) M:(-27)
#       FOR EITHER, PUSHLOC = PDL+0, ARBITRARY IF LEQ 8D.
# Page 1381
#
```

```
# SUBROUTINES CALLED:   T(X), VIA RTB
#
# NORMAL EXIT MODE:     RVQ
#       HOWEVER, PROGRAM EXITS WITH ONE OF THE FOLLOWING VALUES FOR TFF (-28) CS IN MPAC.  USER
#               A. TFF = FLIGHT TIME.  NORMAL CASE FOR POSITIVE FLIGHT TIME LESS THAN ONE ORBIT
#               B. (THIS OPTION IS NO LONGER USED.)
#               C. TFF = POSMAX.  THIS INDICATES THAT THE CONIC FROM THE PRESENT POSITION WILL
#                  THE SPECIFIED ALTITUDE.  ALSO INDICATES OUTBOUND PARABOLA OR HYPERBOLA.
#
# OUTPUT:       C(MPAC)         (-28) CS        TIME OF FLIGHT, OR TIME TO PERIGEE
#               TFFX            (0)             X,                                      LEFT FO
#               NRTERM          E:(-29+NR) M    RTERM, WEIGHTED BY NR                   LEFT FO
#                               M:(-27+NR)
#               TFFTEM          E:(-59+2NR)     LCP Z Z SGN(SDELF)                      LEFT FO
#                               M:(-55+2NR)     LCP /ALFA SGN(SDELF)                    LEFT FO
#               NOTE:   TFFTEM = PDL 36D AND WILL BE DESTROYED BY .:UNIT:.
#               RMAG1           E:(-29) M:(-27) PDL 12 NOT TOUCHED.
#               TFFQ1           E:(-16) M:(-15) PDL 14D
#               TFFDELQ         E:(-16) M:(-15) PDL 10D
#               PUSHLOC AT PDL+0
#
# ERASABLE INITIALIZATION REQUIRED:
#               RONE            E:(-29) M:(-27) M  STATE VECTOR                         LEFT BY
#               VONE'           E:(+10) M:(+9)  VN/SQRT(NU)                             LEFT BY
#               RMAG1           E:(-29) M:(-27) PRESENT RADIUS, M                       LEFT BY
#               C(MPAC)         E:(-29) M:(-27) RTERM, TERMINAL RADIUS LENGTH, M        LEFT BY
#
#               THE FOLLOWING ARE STORED IN THE PUSH LIST AREA.
#               TFF/RTMU        E:(17) M:(14)   1/SQRT(MU)                              LEFT BY
#               NRMAG           E:(-29+NR)      M  RMAG, NORMALIZED                     LEFT BY
#                               M:(-27+NR)
#               X1                              -NR, NORM COUNT                         LEFT BY
#               TFFNP           E:(-38+2NR)     M  LCP, SEMI LATUS RECTUM, WEIGHT NR    LEFT BY
#                               M:(-36+2N4)
#               TFFALFA         E:(26-NR)       1/M  ALFA, WEIGHT NR                    LEFT BY
#                               M:(24-NR)
#               TFFRTALF        E:(10+NA)       SQRT(ALFA), NORMALIZED                  LEFT BY
#                               M:(9+NA)
#               X2                              -NA, NORM COUNT                         LEFT BY
#               TFF1/ALF        E:(-22-2NA)     SIGNED SEMIMAJ AXIS, WEIGHTED BY NA     LEFT BY
#                               M:(-20-2NA)
#
# DEBRIS:       QPRET, PDL+0 ... PDL+3
#               RTERM           E:(-29) M(-27)  RTERM, TERMINAL RADIUS LENGTH
#               RAPO            E:(-29) M(-27)  PDL 16D (=NRTERM)
#               RPER            E:(-29) M(-27)  PDL 14D (=TFFQ1)
```

```
# Page 1382
CALCTPER        SETGO                   # ENTER WITH RPER IN MPAC
                        TFFSW
                        +3
CALCTFF         CLEAR                   # ENTER WITH RTERM IN MPAC
                        TFFSW
        +3      STORE   RTERM           # E:(-29) M:(-27)
                SL*
                        0,1             # X1=-NR
                STORE   NRTERM          # RTERM  E:(-29+NR) M:(-27+NR)
                DMP     BDSU
                        TFFALFA         # ALFA  E:(26-NR) M:(24-NR)
                        TFF1/4
                PUSH    DMP             # (2-ALFA RTERM)  (-3)  TO PDL+0
                        NRTERM          # E:(-29+NR) M:(-27+NR)
                PDDL    SR*             # RTERM(2-ALFA RTERM) TO PDL+2
                                        # E:(-32+NR) M:(-30+NR)
                        TFFNP           # LC P  E:(-38+2NR) M:(-36+2NR)
                        0 -6,1          # X1 = -NR
                DCOMP   DAD             # DUE TO SHIFTS, KEEP PRECISION FOR SQRT
                                        # RTERM(2-ALFA RTERM) FROM PDL +2
                                        # E:(-32+NR) M:(-30+NR)
                SR*                     # LEAVE  E:(-32) M:(-30)
                        0,1             # X1 = -NR
                BOFF    DLOAD           # CHECK TFF /TPER SWITCH
                        TFFSW
                        +2              # IF TFF, CONTINUE
                        TFFZEROS        # IF TPER, SET Q2 = 0
        +2      BMN     SQRT            # E:(-16) M:(-15)
                        MAXTFF1         # NO FREE FALL CONIC TO RTERM FROM HERE
                                        # RESET PDL, SET TFF=POSMAX, AND EXIT.

                DCOMP   BOVB            # RT IS ON INBOUND SIDE.  ASSURE OVFIND=0
                        TCDANZIG        # ANY PORT IN A STORM.
                STOVL   TFFTEM          # Q2  E:(-16) M:(-15)
                        VONE'           # VN/SQRT(MU)  E:(10) M:(9)
                DOT     SL3
                        RONE            # SAVED RN.  E:(-29) M:(-27)
                STORE   TFFQ1           # Q1, SAVE FOR GONEPAST TEST.
                                        # E:(-16) M:(-15)
                BMN     BDSU
                        INBOUND         # USE ALTERNATE Z
                        TFFTEM          # Q2  E:(-16) M:(-15)

# OUTBOUND Z CALC CONTINUES HERE
```

```
                STODL   TFFX            # NUM=Q2-Q1  E:(-16) M:(-15)
                        TFFALFA         # ALFA  E:(26-NR) M:(24-NR)
                DMP     BDSU
# Page 1383
                        NRMAG           # RMAG  E:(-29+NR) M:(-27+NR)
                                        # (2-RTERM ALFA)  (-3) FROM PDL+0
SAVEDEN         PUSH    ABS             # DEN TO PDL+0  E:(-3) OR (-16)
                                        #               M:(-3) OR (-15)
                DAD     BOV             # INDETERMINANCY TEST
                        LIM(-22)        # =1.0-B(-22)
                        TFFXTEST        # GO IF DEN >/= B(-22)
                DLOAD   PDDL            # SET DEN=0 OTHERWISE
                        TFFZEROS
                                        # XCH ZERO WITH PDL+0
                DLOAD   DCOMP
                        TFFALFA         # ALFA  E:(26-NR) M:(24-NR)
                BMN     DLOAD           # FOR TPER:  Z INDET AT DELE/2=0 AND 90.
                        TFFEL1          # ASSUME 90, AND LEAVE 0 IN PDL: 1/Z=D/N

                                        # Z INDET. AT PERIGEE FOR PARAB OR HYPERB.
DUMPTFF1        RVQ                     # RETURN TFF =0

# INBOUND Z CALC CONTINUES HERE

INBOUND         DLOAD                   # RESET PDL+0
                DLOAD   DSU             # ALTERNATE Z CALC
                        RTERM           # E:(-29) M:(-27)
                        RMAG1           # E:(-29) M:(-27)
                STODL   TFFX            # NUM=RTERM-RN  E:(-29) M:(-27)
                        TFFTEM          # Q2  E:(-16) M:(-15)
                DAD     GOTO
                        TFFQ1           # Q1  E:(-16) M:(-15)
                        SAVEDEN         # DEN = Q2+Q1  E:(-16) M:(-15)

TFFXTEST        DAD     PDDL            # (ABS(DEN) TO PDL+2)   E:(-3) OR (-16)
                                        #                       M:(-3) OR (-15)
                        DP(-22)         # RESTORE ABS(DEN) TO MPAC
                        TFFX            # NUM  E:(-16) OR (-29)  M:(-15) OR (-27)
                DMP     SR*
                        TFFRTALF        # SQRT(ALFA)  E:(10+NA) M:(9+NA)
                        0 -3,2          # X2=-NA
                DDV                     # C(MPAC) =NUM SQRT(ALFA)       E:(-3) OR (-16)
                                        #                               M:(-3) OR (-15)
                                        # ABS(DEN) FROM PDL+2   E:(-3) OR (-16)
                                        #                       M:(-3) OR (-15)
```

```
                DLOAD   BOV             # (THE DLOAD IS SHARED WITH TFFELL)
                        TFFX            # NUM  E:(-16) OR (-29)  M:(-15) OR (-27)
                        TFFELL          # USE EQN FOR DELE GEQ 90, LEQ -90

# OTHERWISE, CONTINUE FOR GENERAL CONIC FOR TFF EQN

                DDV     STADR
                                        # DEN FROM PDL+0        E:(-3) OR (-16)
                                        #                        M:(-3) OR (-15)
                STORE   TFFTEM          # Z SAVE FOR SIGN OF SDELF.
# Page 1384
                                        # E:(-13) M:(-12)
                PUSH    DSQ             # Z TO PDL+0
                PUSH    DMP             # Z SQ TO PDL+2  E:(-26) M:(-24)
                        TFFNP           # LC P  E:(-38+2NR) M:(-36+NR)
                SL      SIGN
                        5
                        TFFTEM          # AFFIX SIGN FOR SDELF (ENTRY DISPLAY)
                STODL   TFFTEM          # P ZSQ  E:(-59+2NR) M:(-55+2NR)
                                        # (ARG IS USED IN TFF/TRIG)
                                        # ZSQ FROM PDL+2  E:(-26) M:(-24)
                PUSH    DMP             # RESTORE PUSH LOC
                        TFFALFA         # ALFA  E:(26-NR) M:(24-NR)
                SL*
                        0,1             # X1=-NR
                STORE   TFFX            # X
                RTB     DMP
                        T(X)            # POLY
                                        # ZSQ FROM PDL+2  E:(-26) M:(-24)
                SR2     BDSU            # 2 ZSQ T(X)  E:(-29) M:(-27)
                        RTERM           # RTERM  E:(-29) M:(-27)
                DAD     DMP
                        RMAG1           # E:(-29) M:(-27)
                                        # Z FROM PDL+0  E:(-13) M:(-12)
                SR3     BPL             # TFF SQRT(MU)  E:(-45) M:(-42)
                        ENDTFF          # (NO PUSH UP)
                PUSH    SIGN            # TFF SQRT(MU) TO PDL+0
                        TFFQ1           # Q1 FOR GONEPAST TEST
                BPL     DLOAD           # GONE PAST ?
                        NEGTFF          # YES. TFF < 0.
                        TFF1/ALF        # 1/ALFA  E:(-22-2NA) M:(-20-2NA)
                DCOMP   BPL             # ALFA > 0 ?
                        NEGTFF          # NO. TFF IS NEGATIVE.

# CORRECT FOR ORBITAL PERIOD.
```

```
                DCOMP                   # YES.  CORRECT FOR ORB PERIOD.
                DMP     DDV
                        PI/16           # 2 PI (-5)
                        TFFRTALF        # SQRT(ALFA)  E:(10+NA) M:(9+NA)
                SL*     SL*
                        0 -4,2          # X2=-NA
                        0 -4,2
                SL*     DAD
                        0,2
                                        # TFF SQRT(MU) FROM PDL+0       E:(-45) M:(-42)
ENDTFF          DMP     BOV             # TFF SQRT(MU) IN MPAC          E:(-45) M:(-42)
                        TFF/RTMU        # E:(17) M:(14)
                        MAXTFF          # SET POSMAX IN OVFL.

DUMPTFF2        RVQ                     # RETURN TFF (-28) CS IN MPAC.

# Page 1385
NEGTFF          DLOAD
                                        # TFF SQRT(MU) FROM PDL+0, NEGATIVE.
                GOTO
                        ENDTFF

MAXTFF1         DLOAD                   # RESET PDL
MAXTFF          DLOAD   RVQ
                        NEARONE

# TIME OF FLIGHT ELLIPSE WHEN DEL (ECCENTRIC ANOM) GEQ 90 AND LEQ -90.

                                        # NUM FROM TFFX.        E:(-16) OR (-29)
                                        #                       M:(-15) OR (-27)
TFFELL          SL2                     # NUM  E:(-14) OR (-27)  M:(-13) OR (-25)
                BDDV    PUSH            # TEMP SAVE D/N IN PDL+0
                                        # DEN FROM PDL+0  E:(-3)/(-16)  M:(-3)/(-15)
                                        # N/D TO PDL+0  E:(11) M:(10)
TFFEL1          DLOAD   DSU             # (ENTER WITH D/N=0 IN PDL+0)
                        TFFTEM          # Q2  E:(-16) M:(-15)
                        TFFQ1           # Q1  E:(-16) M:(-15)
                STODL   TFFDELQ         # Q2-Q1  E:(-16) M:(-15)
                                        # D/N FROM PDL+0
                STADR
                STORE   TFFTEM          # D/N  E:(11) M:(10)
                DMP     SL*
                        TFF1/ALF        # 1/ALFA  E:(-22-2NA) M:(-20-2NA)
                        0,2             # 1/ALFA Z  E:(-11-NA) M:(-10-NA)
                PUSH    DMP             # TO PDL+0
                        TFFTEM          # 1/Z  E:(11) M:(10)
```

```
                SL*     BOVB
                        0,2             # X2= -NA
                        SIGNMPAC        # IN CASE X= 1.0, CONTINUE
                STORE   TFFX            # X=1/ALFA ZSQ
                RTB     DMP
                        T(X)            # POLY
                        TFFX
                SR3     DSU
                        DP2(-3)
                DMP     PUSH            # 2(X T(X)-1) /Z ALFA   E:(-15-NA)
                                        #                       M:(-14-NA)
                                        # 1/ALFA Z FROM PDL+0   E:(-11-NA)
                                        #                       M:(-10-NA)
                DLOAD   DMP             # GET SIGN FOR SDELF
                        TFFTEM          # 1/Z  E:(11) M:(10)
                        RMAG1           # E:(-29) M:(-27)
                SL2     DAD
                        TFFQ1           # Q1  E:(-16) M:(-15)
                STODL   TFFTEM          # (Q1+R 1/Z) =SGN OF SDELF  E:(-16) M:(-15)
                        TFFNP           # LC P  E:(-38+2NR) M:(-36+2NR)
                DMP     SL*             # CALC FOR ARG FOR TFF/TRIG.
# Page 1386
                        TFF1/ALF        # 1/ALFA  E:(-22-2NA) M:(-20-2NA)
                        1,2             # X2=-NA
                SIGN    SL*
                        TFFTEM          # AFFIX SIGN FOR SDELF
                        0,2
                STODL   TFFTEM          # P/ALFA  E:(-59+2NR) M:(-55+2NR)
                                        # (ARG FOR USE IN TFF/TRIG)
                        TFF1/ALF        # 1/ALFA  E:(-22-2NA) M:(-20-2NA)
                SQRT    DMP
                        PI/16           # PI (-4)
                DAD
                                        # 2(XT(X)-1)/Z ALFA FROM PDL    E:(-15-NA)
                                        #                               M:(-14-NA)
                SL*     DSU
                        0 -1,2
                        TFFDELQ         # Q2-Q1  E:(-16) M:(-15)
                DMP     SL*
                        TFF1/ALF        # 1/ALFA  E:(-22-2NA) M:(-20-2NA)
                        0 -3,2
                SL*     GOTO
                        0 -4,2
                        ENDTFF          # TFF SQRT(MU) IN MPAC E:(-145) M:(-42)

# Page 1387
```

```
# PROGRAM NAME:  T(X)                          DATE:  01.17.67
# MOD NO:  0                                   LOG SECTION:  TIME OF FREE FALL
# MOD BY:  RR BAIRNSFATHER
#
# FUNCTIONAL DESCRIPTION:  THE POLYNOMIAL T(X) IS USED BY TIME OF FLIGHT SUBROUTINES CALCTFF AN
#       CALCTPER TO APPROXIMATE THE SERIES
#                          2     3
#              1/3 -X/5 +X /7 -X /9 ...
#
#       WHERE   X = ALFA Z Z            IF ALFA Z Z LEQ 1
#               X = 1/(ALFA Z Z)        IF ALFA Z Z G 1
#
#       ALSO    X IS NEG FOR HYPERBOLIC ORBITS
#               X = 0 FOR PARABOLIC ORBITS
#               X IS POSITIVE FOR ELLIPTIC ORBITS
#
#       FOR FLIGHT 278, THE POLYNOMIAL T(X) IS FITTED OVER THE RANGE (0,+1) AND HAS A MAXIMUM
#       DEVIATION FROM THE SERIES OF 2 E-5.  (T(X) IS A CHEBYCHEV TYPE FIT AND WAS OBTAINED USI
#       MAC PROGRAM AUTCURFIT294RRB AND IS VALID TO THE SAME TOLERANCE OVER THE RANGE (-.08,+1)
#
# CALLING SEQUENCE:     RTB
#                               T(X)
#       C(MPAC) = X
#
# SUBROUTINE CALLED:  NONE
#
# NORMAL EXIT MODE:  TC DANZIG
#
# ALARMS:  NONE
#
# OUTPUT:  C(MPAC) = T(X)
#
# ERASABLE INITIALIZATION REQUIRED:
#       C(MPAC) = X
#
# DEBRIS:  NONE

T(X)            TC      POLY
                DEC     4               # N-1
                2DEC    3.333333333 E-1
                2DEC*   -1.999819135 E-1*
                2DEC*   1.418148467 E-1*
                2DEC*   -1.01310997 E-1*
                2DEC*   5.609004986 E-2*
                2DEC*   -1.536156925 E-2*
```

```
ENDT(X)         TC      DANZIG

TCDANZIG        =       ENDT(X)

# Page 1388
# TFF CONSTANTS

                BANK    32

                SETLOC  TOF-FF1
                BANK

#                                           # NOTE _  NOTE _ ADJUSTED MUE FOR NEA
#MUE            =       3.990815471 E10     # M CUBE/CS SQ
#RTMUE          =       1.997702549 E5 B-18*    # MODIFIED EARTH MU

1/RTMU          2DEC*   .5005750271 E-5 B17*    # MODIFIED EARTH MU

#                                           # NOTE _  NOTE _ ADJUSTED MUE FOR NEA
#MUM            =       4.902778 E8         # M CUBE/CS SQ
#RTMUM          2DEC*   2.21422176 E4 B-18*
PI/16           2DEC    3.141592653 B-4
LIM(-22)        2OCT    3777737700          # 1.0 -B(-22)
DP(-22)         2OCT    0000000100          # B(-22)
DP2(-3)         2DEC    1 B-3
DP2(-4)         2DEC    1 B-4               # 1/16

# RPAD1         2DEC    6373338 B-29        # M (-29) = 20909901.57 FT
RPAD1           =       RPAD

R300K           2DEC    6464778 B-29        # (-29) M
NEARONE         2DEC    .999999999
TFFZEROS        EQUALS  HI6ZEROS
TFF1/4          EQUALS  HIDP1/4
```

Uses A 80, CONICS 61, COUNT 142, D 226, DEL 232, DISPLAYS 59, ECC 188, GONEPAST 119, H 177, HI6ZEROS 71, HIDP1/4 71, IT 185, LEQ 226, LOC 145, MODE 145, MPAC 145, N 206, ORBITAL 59, OVFIND 140, P 188, PUSHLOC 145, Q2 229, QPRET 85, RAD 219, RANGE 179, RMAG 174, RN 159, RONE 179, RT 226, S1 85, S2 85, SAVE 191, SQ 156, SR 80, STATE 138, TC 169, TEMP 191, TFF 179, TFFSW 125, THETA 148, TOF-FF 65, TOF-FF1 65, V 229, VN 159, VONE 179, VONE' 182, W 183, X1 85, X2 85, and Z 80.

3.7.18 star tables

1867 ⟨*star tables* 1867⟩≡ (1523a 2808)
⟨*Page CM1389* 1868⟩

1868 ⟨*Page CM1389* 1868⟩≡ (1867)

```
# Page 1389
                BANK    32
                SETLOC  STARTAB
                BANK

                COUNT   14/STARS

                2DEC    +.8342971408 B-1        # STAR 37       X
                2DEC    -.2392481515 B-1        # STAR 37       Y
                2DEC    -.4966976975 B-1        # STAR 37       Z

                2DEC    +.8139832631 B-1        # STAR 36       X
                2DEC    -.5557243189 B-1        # STAR 36       Y
                2DEC    +.1691204557 B-1        # STAR 36       Z

                2DEC    +.4541086270 B-1        # STAR 35       X
                2DEC    -.5392368197 B-1        # STAR 35       Y
                2DEC    +.7092312789 B-1        # STAR 35       Z

                2DEC    +.3201817378 B-1        # STAR 34       X
                2DEC    -.4436021946 B-1        # STAR 34       Y
                2DEC    -.8370786986 B-1        # STAR 34       Z

                2DEC    +.5520184464 B-1        # STAR 33       X
                2DEC    -.7933187400 B-1        # STAR 33       Y
                2DEC    -.2567508745 B-1        # STAR 33       Z

                2DEC    +.4537196908 B-1        # STAR 32       X
                2DEC    -.8779508801 B-1        # STAR 32       Y
                2DEC    +.1527766153 B-1        # STAR 32       Z

                2DEC    +.2069525789 B-1        # STAR 31       X
                2DEC    -.8719885748 B-1        # STAR 31       Y
                2DEC    -.4436288486 B-1        # STAR 31       Z

                2DEC    +.1217293692 B-1        # STAR 30       X
# Page 1390
                2DEC    -.7702732847 B-1        # STAR 30       Y
                2DEC    +.6259880410 B-1        # STAR 30       Z

                2DEC    -.1124304773 B-1        # STAR 29       X
                2DEC    -.9694934200 B-1        # STAR 29       Y
                2DEC    +.2178116072 B-1        # STAR 29       Z

                2DEC    -.1146237858 B-1        # STAR 28       X
```

```
                2DEC    -.3399692557 B-1        # STAR 28       Y
                2DEC    -.9334250333 B-1        # STAR 28       Z

                2DEC    -.3516499609 B-1        # STAR 27       X
                2DEC    -.8240752703 B-1        # STAR 27       Y
                2DEC    -.4441196390 B-1        # STAR 27       Z

                2DEC    -.5326876930 B-1        # STAR 26       X
                2DEC    -.7160644554 B-1        # STAR 26       Y
                2DEC    +.4511047742 B-1        # STAR 26       Z

                2DEC    -.7861763936 B-1        # STAR 25       X
                2DEC    -.5217996305 B-1        # STAR 25       Y
                2DEC    +.3311371675 B-1        # STAR 25       Z

                2DEC    -.6898393233 B-1        # STAR 24       X
                2DEC    -.4182330640 B-1        # STAR 24       Y
                2DEC    -.5909338474 B-1        # STAR 24       Z

                2DEC    -.5812035376 B-1        # STAR 23       X
                2DEC    -.2909171294 B-1        # STAR 23       Y
                2DEC    +.7599800468 B-1        # STAR 23       Z

                2DEC    -.9170097662 B-1        # STAR 22       X
                2DEC    -.3502146628 B-1        # STAR 22       Y
# Page 1391
                2DEC    -.1908999176 B-1        # STAR 22       Z

                2DEC    -.4523440203 B-1        # STAR 21       X
                2DEC    -.0493710140 B-1        # STAR 21       Y
                2DEC    -.8904759346 B-1        # STAR 21       Z

                2DEC    -.9525211695 B-1        # STAR 20       X
                2DEC    -.0593434796 B-1        # STAR 20       Y
                2DEC    -.2986331746 B-1        # STAR 20       Z

                2DEC    -.9656605484 B-1        # STAR 19       X
                2DEC    +.0525933156 B-1        # STAR 19       Y
                2DEC    +.2544280809 B-1        # STAR 19       Z

                2DEC    -.8608205219 B-1        # STAR 18       X
                2DEC    +.4636213989 B-1        # STAR 18       Y
                2DEC    +.2098647835 B-1        # STAR 18       Z

                2DEC    -.7742591356 B-1        # STAR 17       X
                2DEC    +.6152504197 B-1        # STAR 17       Y
```

```
                2DEC    -.1482892839 B-1        # STAR 17       Z

                2DEC    -.4657947941 B-1        # STAR 16       X
                2DEC    +.4774785033 B-1        # STAR 16       Y
                2DEC    +.7450164351 B-1        # STAR 16       Z

                2DEC    -.3612508532 B-1        # STAR 15       X
                2DEC    +.5747270840 B-1        # STAR 15       Y
                2DEC    -.7342932655 B-1        # STAR 15       Z

                2DEC    -.4118589524 B-1        # STAR 14       X
                2DEC    +.9065485360 B-1        # STAR 14       Y
                2DEC    +.0924226975 B-1        # STAR 14       Z

# Page 1392
                2DEC    -.1820751783 B-1        # STAR 13       X
                2DEC    +.9404899869 B-1        # STAR 13       Y
                2DEC    -.2869271926 B-1        # STAR 13       Z

                2DEC    -.0614937230 B-1        # STAR 12       X
                2DEC    +.6031563286 B-1        # STAR 12       Y
                2DEC    -.7952489957 B-1        # STAR 12       Z

                2DEC    +.1371725575 B-1        # STAR 11       X
                2DEC    +.6813721061 B-1        # STAR 11       Y
                2DEC    +.7189685267 B-1        # STAR 11       Z

                2DEC    +.2011399589 B-1        # STAR 10       X
                2DEC    +.9690337941 B-1        # STAR 10       Y
                2DEC    -.1432348512 B-1        # STAR 10       Z

                2DEC    +.3507315038 B-1        # STAR 9        X
                2DEC    +.8926333307 B-1        # STAR 9        Y
                2DEC    +.2831839492 B-1        # STAR 9        Z

                2DEC    +.4105636020 B-1        # STAR 8        X
                2DEC    +.4988110001 B-1        # STAR 8        Y
                2DEC    +.7632988371 B-1        # STAR 8        Z

                2DEC    +.7032235469 B-1        # STAR 7        X
                2DEC    +.7075846047 B-1        # STAR 7        Y
                2DEC    +.0692868685 B-1        # STAR 7        Z

                2DEC    +.5450107404 B-1        # STAR 6        X
                2DEC    +.5314955466 B-1        # STAR 6        Y
                2DEC    -.6484410356 B-1        # STAR 6        Z
```

```
                2DEC    +.0130968840 B-1        # STAR 5        X
# Page 1393
                2DEC    +.0078062795 B-1        # STAR 5        Y
                2DEC    +.9998837600 B-1        # STAR 5        Z

                2DEC    +.4917678276 B-1        # STAR 4        X
                2DEC    +.2204887125 B-1        # STAR 4        Y
                2DEC    -.8423473935 B-1        # STAR 4        Z

                2DEC    +.4775639450 B-1        # STAR 3        X
                2DEC    +.1166004340 B-1        # STAR 3        Y
                2DEC    +.8708254803 B-1        # STAR 3        Z

                2DEC    +.9342640400 B-1        # STAR 2        X
                2DEC    +.1735073142 B-1        # STAR 2        Y
                2DEC    -.3115219339 B-1        # STAR 2        Z

                2DEC    +.8748658918 B-1        # STAR 1        X
                2DEC    +.0260879174 B-1        # STAR 1        Y
                2DEC    +.4836621670 B-1        # STAR 1        Z

CATLOG          DEC     6970
```

Uses COUNT 142, STAR 186, STARTAB 61, and Z 80.

3.7.19 agc block two self check

1871 ⟨*cm agc block two self check* 1871⟩≡ (1523a)
⟨*Page CM1394* 1872⟩
⟨*Page CM1395* 1874⟩
⟨*Page CM1396* 1876⟩
⟨*Page CM1397* 1878⟩
⟨*Page CM1398* 1880⟩
⟨*Page CM1399* 1882⟩
⟨*Page CM1400* 1884⟩
⟨*Page CM1401* 1886⟩
⟨*Page CM1402* 1888⟩
⟨*Page CM1403* 1889⟩

1872 ⟨*Page CM1394* 1872⟩≡ (1871 2636)

```
# PROGRAM DESCRIPTION                          DATE  20 DECEMBER 1967
# PROGRAM NAME - SELF-CHECK                    LOG SECTION  AGC BLOCK TWO SELF-CHECK
# MOD NO - 1                                   ASSEMBLY SUBROUTINE UTILITYM REV 25
# MOD BY - GAUNTT
#
#
# FUNCTIONAL DESCRIPTION
#
#       PROGRAM HAS TWO MAIN PARTS. THE FIRST IS SELF-CHECK WHICH RUNS AS A ZERO PRIO
# PART OF THE BACK-UP IDLE LOOP. THE SECOND IS SHOW-BANKSUM WHICH RUNS AS A REGULAR P
#  STARTING VERB.
#       THE PURPOSE OF SELF-CHECK IS TO CHECK OUT VARIOUS PARTS OF THE COMPUTER AS OU
#       THE PURPOSE OF SHOW-BANKSUM IS TO DISPLAY THE SUM OF EACH BANK , ONE AT A TIM
#       IN ALL THERE ARE  7 POSSIBLE OPTIONS IN THIS BLOCK II VERSION OF SELF-CHECK.
# FOUND IN E-2065 BLOCK II AGC SELF-CHECK AND SHOW BANKSUM BY EDWIN D. SMALLY DECEMBE
#       THE DIFFERENT OPTIONS ARE CONTROLLED BY PUTTING DIFFERENT NUMBERS IN THE SMOD
# A DESCRIPTION OF WHAT PARTS OF THE COMPUTER THAT ARE CHECKED BY THE OPTIONS, AND TH
# OCTAL, TO LOAD INTO SMODE.
# +-4           ERASABLE MEMORY
# +-5           FIXED MEMORY
# +-1,2,3,6,7,10        EVERYTHING IN OPTIONS 4 AND 5.
# -0            SAME AS +-10 UNTIL AN ERROR IS DETECTED.
# +0            NO CHECK, PUTS COMPUTER INTO THE BACKUP IDLE LOOP.
#
#
# WARNINGS
#       USE OF E MEMORY RESERVED FOR SELF-CHECK (EVEN IN IDLE LOOP) AS TEMP STORAGE P
#       SMODE SET GREATER THAN OCT 10 PUTS COMPUTER INTO BACKUP IDLE LOOP.
#
#
# CALLING SEQUENCE
#
#       TO CALL SELF-CHECK KEY IN
#               V 21 N 27 E     OPTION NUMBER E
#       TO CALL SHOW-BANKSUM KEY IN
#               V 91 E          DISPLAYS FIRST BANK
#               V 33 E          PROCEED, DISPLAYS NEXT BANK
#
#
# EXIT MODES, NORMAL AND ALARM
#
#       SELF-CHECK NORMALLY CONTINUES INDEFINITELY UNLESS THERE IS AN ERROR DETECTED.
# COMPUTER INTO BACKUP IDLE LOOP, - OPTION NUMBERS RESTART THE OPTION.
#       THE -0 OPTION PROCEEDS FROM THE LINE FOLLOWING THE LINE WHERE THE ERROR WAS D
#       SHOW-BANKSUM PROCEEDS UNTIL A TERMINATE IS KEYED IN (V 34 E). THE COMPUTER IS
```

```
#
#
#
# OUTPUT
```

Uses A 80, COMPUTER 115, D 226, DISPLAYS 59, N 206, PRIORITY 145, RESTART 57, SMODE 165, TEMP 191, and V 229.

1874 ⟨*Page CM1395* 1874⟩≡ (1871 2636)

```
#       SELF-CHECK UPON DETECTING AN ERROR LOADS THE SELF-CHECK ALARM CONSTANT (01102
# TURNS ON THE ALARM LIGHT. THE OPERATOR MAY THEN DISPLAY THE THREE FAILREGS BY KEYIN
# INFORMATION HE MAY KEY IN V 05 N 08 E, THE DSKY DISPLAY IN R1 WILL BE ADDRESS+1 OF
# IN R2 THE BBCON OF SELF-CHECK, AND IN R3 THE TOTAL NUMBER OF ERRORS DETECTED BY SEL
# INITIATED FRESH START (SLAP1).
#       SHOW-BANKSUM STARTING WITH BANK 0 DISPLAYS IN R1 THE BANK SUM (A +-NUMBER EQU
# THE BANK NUMBER, AND IN R3 THE BUGGER WORD.
#
#
# ERASABLE INITIALIZATION REQUIRED
#       ACCOMPLISHED BY FRESH START
#               SMODE SET TO +0
#
# DEBRIS
#       ALL EXITS FROM THE CHECK OF ERASABLE (ERASCHK) RESTORE ORIGINAL CONTENTS TO E
# EXCEPTION IS A RESTART. RESTART THAT OCCURS DURING ERASCHK RESTORES ERASABLE, UNLES
# E MEMORY, IN WHICH CASE PROGRAM THEN DOES A FRESH START (DOFSTART).

                BANK    25
                SETLOC  SELFCHEC
                BANK

                COUNT   43/SELF

SBIT1           EQUALS  BIT1
SBIT2           EQUALS  BIT2
SBIT3           EQUALS  BIT3
SBIT4           EQUALS  BIT4
SBIT5           EQUALS  BIT5
SBIT6           EQUALS  BIT6
SBIT7           EQUALS  BIT7
SBIT8           EQUALS  BIT8
SBIT9           EQUALS  BIT9
SBIT10          EQUALS  BIT10
SBIT11          EQUALS  BIT11
SBIT12          EQUALS  BIT12
SBIT13          EQUALS  BIT13
SBIT14          EQUALS  BIT14
SBIT15          EQUALS  BIT15

S+ZERO          EQUALS  ZERO
S+1             EQUALS  BIT1
S+2             EQUALS  BIT2
S+3             EQUALS  THREE
S+4             EQUALS  FOUR
```

```
S+5              EQUALS  FIVE
```

Uses A 80, COUNT 142, DISPLAYS 59, FAILREG 150, N 206, R2 188, RESTART 57, SELFCHEC 71, SMODE 165, and V 229.

1876 ⟨*Page CM1396* 1876⟩≡ (1871 2636)

```
S+6             EQUALS  SIX
S+7             EQUALS  SEVEN
S8BITS          EQUALS  LOW8            # 00377
CNTRCON         =       OCT50           # USED IN CNTRCHK
ERASCON1        OCTAL   00061           # USED IN ERASCHK
ERASCON2        OCTAL   01373           # USED IN ERASCHK
ERASCON6        =       OCT1400         # USED IN ERASCHK
ERASCON3        OCTAL   01461           # USED IN ERASCHK
ERASCON4        OCTAL   01773           # USED IN ERASCHK
S10BITS         EQUALS  LOW10           # 01777, USED IN ERASCHK
SBNK03          EQUALS  PRIO6           # 06000, USED IN ROPECHK
-MAXADRS        =       HI5             # FOR ROPECHK
SIXTY           OCTAL   00060
SUPRCON         OCTAL   60017           # USED IN ROPECHK
S13BITS         OCTAL   17777
CONC+S1         OCTAL   25252           # USED IN CYCLSHFT
CONC+S2         OCTAL   52400           # USED IN CYCLSHFT
ERASCON5        OCTAL   76777
S-7             =       OCT77770
S-4             EQUALS  NEG4
S-3             EQUALS  NEG3
S-2             EQUALS  NEG2
S-1             EQUALS  NEGONE
S-ZERO          EQUALS  NEG0

                EBANK=  LST1
ADRS1           ADRES   SKEEP1
SELFADRS        ADRES   SELFCHK         # SELFCHK RETURN ADDRESS. SHOULD BE PUT
                                        # IN SELFRET WHEN GOING FROM SELFCHK TO
                                        # SHOWSUM AND PUT IN SKEEP1 WHEN GOING
                                        # FROM SHOWSUM TO SELF-CHECK.

PRERRORS        CA      ERESTORE        # IS IT NECESSARY TO RESTORE ERASABLE
                EXTEND
                BZF     ERRORS          # NO
                EXTEND
                DCA     SKEEP5
                INDEX   SKEEP7
                DXCH    0000            # RESTORE THE TWO ERASABLE REGISTERS
                CA      S+ZERO
                TS      ERESTORE
ERRORS          INHINT
                CA      Q
                TS      SFAIL           # SAVE Q FOR FAILURE LOCATION
                TS      ALMCADR         # FOR DISPLAY WITH BBANK AND ERCOUNT
```

```
                INCR    ERCOUNT         # KEEP TRACK OF NUMBER OF MALFUNCTIONS.
TCALARM2        TC      ALARM2
                OCT     01102           # SELF-CHECK MALFUNCTION INDICATOR
                CCS     SMODE
SIDLOOP         CA      S+ZERO
```

Uses ALMCADR 165, BBANK 80, EBANK 80, ERCOUNT 165, ERESTORE 165, IT 185, LST1 167, Q 80, S1 85, S2 85, SAVE 191, SELFRET 165, SFAIL 165, SKEEP1 165, SKEEP5 165, SKEEP7 165, SMODE 165, and TC 169.

1878 ⟨*Page CM1397* 1878⟩≡ (1871 2636)

```
                TS      SMODE
                TC      SELFCHK         # GO TO IDLE LOOP
                TC      SFAIL           # CONTINUE WITH SELF-CHECK

-1CHK           CCS     A
                TCF     PRERRORS
                TCF     PRERRORS
                CCS     A
                TCF     PRERRORS
                TC      Q

SMODECHK        EXTEND
                QXCH    SKEEP1
                TC      CHECKNJ         # CHECK FOR NEW JOB
                CCS     SMODE
                TC      SOPTIONS
                TC      SMODECHK +2     # TO BACKUP IDLE LOOP
                TC      SOPTIONS
                INCR    SCOUNT
                TC      SKEEP1          # CONTINUE WITH SELF-CHECK

SOPTIONS        AD      S-7
                EXTEND
                BZMF    +2              # FOR OPTIONS BELOW NINE.
BNKOPTN         TC      SIDLOOP         # ILLEGAL OPTION.  GO TO IDLE LOOP.
                INCR    SCOUNT          # FOR OPTIONS BELOW NINE.
                AD      S+7

                INDEX   A
                TC      SOPTION1
SOPTION1        TC      SKEEP1          # WAS TC+TCF
SOPTION2        TC      SKEEP1          # WAS IN:OUT1
SOPTION3        TC      SKEEP1          # WAS COUNTCHK
SOPTION4        TC      ERASCHK
SOPTION5        TC      ROPECHK
SOPTION6        TC      SKEEP1
SOPTION7        TC      SKEEP1
SOPTON10        TC      SKEEP1          # CONTINUE WITH SELF-CHECK

CHECKNJ         EXTEND
                QXCH    SELFRET         # SAVE RETURN ADDRESS WHILE TESTING NEWJOB
                TC      POSTJUMP        # TO SEE IF ANY JOBS HAVE BECOME ACTIVE.
                CADR    ADVAN

SELFCHK         TC      SMODECHK        # ** CHARLEY, COME IN HERE
```

```
# SKEEP7 HOLDS LOWEST OF TWO ADDRESSES BEING CHECKED.
# SKEEP6 HOLDS B(X+1).
# SKEEP5 HOLDS B(X).
# SKEEP4 HOLDS C(EBANK) DURING ERASLOOP AND CHECKNJ
```

Uses A 80, EBANK 80, NEWJOB 138, Q 80, SAVE 191, SCOUNT 165, SELFRET 165, SFAIL 165, SKEEP1 165, SKEEP4 165, SKEEP5 165, SKEEP6 165, SKEEP7 165, SMODE 165, and TC 169.

1880 ⟨*Page CM1398* 1880⟩≡ (1871 2636)

```
# SKEEP3 HOLDS LAST ADDRESS BEING CHECKED (HIGHEST ADDRESS).
# SKEEP2 CONTROLS CHECKING OF NON-SWITCHABLE ERASABLE MEMORY WITH BANK NUMBERS IN EB
# ERASCHK TAKES APPROXMATELY 7 SECONDS
ERASCHK         CA      S+1
                TS      SKEEP2
OEBANK          CA      S+ZERO
                TS      EBANK
                CA      ERASCON3        # 01461
                TS      SKEEP7          # STARTING ADDRESS
                CA      S10BITS         # 01777
                TS      SKEEP3          # LAST ADDRESS CHECKED
                TC      ERASLOOP

E134567B        CA      ERASCON6        # 01400
                TS      SKEEP7          # STARTING ADDRESS
                CA      S10BITS         # 01777
                TS      SKEEP3          # LAST ADDRESS CHECKED
                TC      ERASLOOP

2EBANK          CA      ERASCON6        # 01400
                TS      SKEEP7          # STARTING ADDRESS
                CA      ERASCON4        # 01773
                TS      SKEEP3          # LAST ADDRESS CHECKED
                TC      ERASLOOP

NOEBANK         TS      SKEEP2          # +0
                CA      ERASCON1        # 00061
                TS      SKEEP7          # STARTING ADDRESS
                CA      ERASCON2        # 01373
                TS      SKEEP3          # LAST ADDRESS CHECKED

ERASLOOP        INHINT
                CA      EBANK           # STORES C(EBANK)
                TS      SKEEP4
                EXTEND
                NDX     SKEEP7
                DCA     0000
                DXCH    SKEEP5          # STORES C(X) AND C(X+1) IN SKEEP6 AND 5.
                CA      SKEEP7
                TS      ERESTORE        # IF RESTART, RESTORE C(X) AND C(X+1)
                TS      L
                INCR    L
                NDX     A
                DXCH    0000            # PUTS OWN ADDRESS IN X AND X +1
                NDX     SKEEP7
```

```
CS      0001            # CS X+1
NDX     SKEEP7
AD      0000            # AD X
TC      -1CHK
CA      ERESTORE        # HAS ERASABLE BEEN RESTORED
```

Uses A 80, EBANK 80, ERESTORE 165, L 80, RESTART 57, SKEEP2 165, SKEEP3 165, SKEEP4 165, SKEEP5 165, SKEEP6 165, SKEEP7 165, and TC 169.

1882 ⟨*Page CM1399* 1882⟩≡ (1871 2636)

```
                EXTEND
                BZF     ELOOPFIN        # YES, EXIT ERASLOOP.
                EXTEND
                NDX     SKEEP7
                DCS     0000            # COMPLEMENT OF ADDRESS OF X AND X+1
                NDX     SKEEP7
                DXCH    0000            # PUT COMPLEMENT OF ADDRESS OF X AND X+1
                NDX     SKEEP7
                CS      0000            # CS X
                NDX     SKEEP7
                AD      0001            # AD X+1
                TC      -1CHK
                CA      ERESTORE        # HAS ERASABLE BEEN RESTORED
                EXTEND
                BZF     ELOOPFIN        # YES, EXIT ERASLOOP.
                EXTEND
                DCA     SKEEP5
                NDX     SKEEP7
                DXCH    0000            # PUT B(X) AND B(X+1) BACK INTO X AND X+1
                CA      S+ZERO
                TS      ERESTORE        # IF RESTART, DO NOT RESTORE C(X), C(X+1)
ELOOPFIN        RELINT
                TC      CHECKNJ         # CHECK FOR NEW JOB
                CA      SKEEP4          # REPLACES B(EBANK)
                TS      EBANK
                INCR    SKEEP7
                CS      SKEEP7
                AD      SKEEP3
                EXTEND
                BZF     +2
                TC      ERASLOOP        # GO TO NEXT ADDRESS IN SAME BANK
                CCS     SKEEP2
                TC      NOEBANK
                INCR    SKEEP2          # PUT +1 IN SKEEP2.
                CA      EBANK
                AD      SBIT9
                TS      EBANK
                AD      ERASCON5        # 76777, CHECK FOR BANK E2
                EXTEND
                BZF     2EBANK
                CCS     EBANK
                TC      E134567B        # GO TO EBANKS 1,3,4,5,6, AND 7
                CA      ERASCON6        # END OF ERASCHK
                TS      EBANK
# CNTRCHK PERFORMS A CS OF ALL REGISTERS FROM OCT. 60 THROUGH OCT. 10.
```

```
# INCLUDED ARE ALL COUNTERS, T6-1, CYCLE AND SHIFT, AND ALL RUPT REGISTERS
CNTRCHK         CA      CNTRCON         # 00050
CNTRLOOP        TS      SKEEP2
                AD      SBIT4           # +10 OCTAL
                INDEX   A
```

Uses A 80, E2 236, EBANK 80, ERESTORE 165, RESTART 57, SKEEP2 165, SKEEP3 165, SKEEP4 165, SKEEP5 165, SKEEP7 165, and TC 169.

1884 ⟨*Page CM1400* 1884⟩≡ (1871 2636)

```
                CS      0000
                CCS     SKEEP2
                TC      CNTRLOOP

# CYCLSHFT CHECKS THE CYCLE AND SHIFT REGISTERS
CYCLSHFT        CA      CONC+S1         # 25252
                TS      CYR             # C(CYR) = 12525
                TS      CYL             # C(CYL) = 52524
                TS      SR              # C(SR) = 12525
                TS      EDOP            # C(EDOP) = 00125
                AD      CYR             # 37777         C(CYR) = 45252
                AD      CYL             # 00-12524      C(CYL) = 25251
                AD      SR              # 00-25251      C(SR) = 05252
                AD      EDOP            # 00-25376      C(EDOP) = +0
                AD      CONC+S2         # C(CONC+S2) = 52400
                TC      -1CHK
                AD      CYR             # 45252
                AD      CYL             # 72523
                AD      SR              # 77775
                AD      EDOP            # 77775
                AD      S+1             # 77776
                TC      -1CHK

                INCR    SCOUNT +1
                TC      SMODECHK
# SKEEP1 HOLDS SUM
# SKEEP2 HOLDS PRESENT CONTENTS OF ADDRESS IN ROPECHK AND SHOWSUM ROUTINES
# SKEEP2 HOLDS BANK NUMBER IN LOW ORDER BITS DURING SHOWSUM DISPLAY
# SKEEP3 HOLDS PRESENT ADDRESS (00000 TO 01777 IN COMMON FIXED BANKS)
#                              (04000 TO 07777 IN FXFX BANKS)
# SKEEP3 HOLDS BUGGER WORD DURING SHOWSUM DISPLAY
# SKEEP4 HOLDS BANK NUMBER AND SUPER BANK NUMBER
# SKEEP5 COUNTS 2 SUCCESSIVE TC SELF WORDS
# SKEEP6 CONTROLS ROPECHK OR SHOWSUM OPTION
# SKEEP7 CONTROLS WHEN ROUNTINE IS IN COMMON FIXED OR FIXED FIXED BANKS

ROPECHK         CA      S-ZERO          # *
                TS      SKEEP6          # * -0 FOR ROPECHK
STSHOSUM        CA      S+ZERO          # * SHOULD BE ROPECHK

                TS      SKEEP4          # BANK NUMBER
                CA      S+1
COMMFX          TS      SKEEP7
                CA      S+ZERO
                TS      SKEEP1
```

```
                TS      SKEEP3
                CA      S+1
                TS      SKEEP5          # COUNTS DOWN 2 TC SELF WORDS
COMADRS         CA      SKEEP4
                TS      L               # TO SET SUPER BANK
```

Uses CYL 80, CYR 80, EDOP 80, L 80, S1 85, S2 85, SCOUNT 165, SKEEP1 165, SKEEP2 165, SKEEP3 165, SKEEP4 165, SKEEP5 165, SKEEP6 165, SKEEP7 165, SR 80, and TC 169.

1886 ⟨*Page CM1401* 1886⟩≡ (1871 2636)

```
                MASK    HI5
                AD      SKEEP3
                TC      SUPDACAL        # SUPER DATA CALL
                TC      ADSUM
                AD      SBIT11          # 02000
                TC      ADRSCHK

FXFX            CS      A
                TS      SKEEP7
                EXTEND
                BZF     +3
                CA      SBIT12          # 04000, STARTING ADDRESS OF BANK 02
                TC      +2
                CA      SBNK03          # 06000, STARTING ADDRESS OF BANK 03
                TS      SKEEP3
                CA      S+ZERO
                TS      SKEEP1
                CA      S+1
                TS      SKEEP5          # COUNTS DOWN 2 TC SELF WORDS
FXADRS          INDEX   SKEEP3
                CA      0000
                TC      ADSUM
                TC      ADRSCHK

ADSUM           TS      SKEEP2
                AD      SKEEP1
                TS      SKEEP1
                CAF     S+ZERO
                AD      SKEEP1
                TS      SKEEP1
                CS      SKEEP2
                AD      SKEEP3
                TC      Q

ADRSCHK         LXCH    A
                CA      SKEEP3
                MASK    LOW10           # RELATIVE ADDRESS
                AD      -MAXADRS        # SUBTRACT MAX RELATIVE ADDRESS = 1777.
                EXTEND
                BZF     SOPTION         # CHECKSUM FINISHED IF LAST ADDRESS.
                CCS     SKEEP5          # IS CHECKSUM FINISHED
                TC      +3              # NO
                TC      +2              # NO
                TC      SOPTION         # GO TO ROPECHK SHOWSUM OPTION
                CCS     L               # -0 MEANS A TC SELF WORD.
```

```
TC      CONTINU
TC      CONTINU
TC      CONTINU
CCS     SKEEP5
TC      CONTINU +1
```

Uses A 80, L 80, Q 80, SKEEP1 165, SKEEP2 165, SKEEP3 165, SKEEP5 165, SKEEP7 165, and TC 169.

1888 ⟨*Page CM1402* 1888⟩≡ (1871 2636)

```
                CA      S-1
                TC      CONTINU +1      # AD IN THE BUGGER WORD
CONTINU         CA      S+1             # MAKE SURE TWO CONSECUTIVE TC SELF WORDS
                TS      SKEEP5
                CCS     SKEEP6          # *
                CCS     NEWJOB          # * +1, SHOWSUM
                TC      CHANG1          # *
                TC      +2              # *
                TC      CHECKNJ         # -0 IN SKEEP6 FOR ROPECHK

ADRS+1          INCR    SKEEP3
                CCS     SKEEP7
                TC      COMADRS
                TC      COMADRS
                TC      FXADRS
                TC      FXADRS

NXTBNK          CS      SKEEP4
                AD      LSTBNKCH        # LAST BANK TO BE CHECKED
                EXTEND
                BZF     ENDSUMS         # END OF SUMMING OF BANKS.
                CA      SKEEP4
                AD      SBIT11
                TS      SKEEP4          # 37 TO 40 INCRMTS SKEEP4 BY END RND CARRY
                TC      CHKSUPR
17TO20          CA      SBIT15
                ADS     SKEEP4          # SET FOR BANK 20
                TC      GONXTBNK
CHKSUPR         MASK    HI5
                EXTEND
                BZF     NXTSUPR         # INCREMENT SUPER BANK
27TO30          AD      S13BITS
                EXTEND
                BZF     +2              # BANK SET FOR 30
                TC      GONXTBNK
                CA      SIXTY           # FIRST SUPER BANK
                ADS     SKEEP4
                TC      GONXTBNK
NXTSUPR         AD      SUPRCON         # SET BNK 30 + INCR SUPR BNK AND CANCEL
                ADS     SKEEP4          # ERC BIT OF THE 37 TO 40 ADVANCE.
GONXTBNK        CCS     SKEEP7
                TC      COMMFX
                CA      S+1
                TC      FXFX
                CA      SBIT7           # HAS TO BE LARGER THAN NO OF FXSW BANKS.
```

```
                TC      COMMFX

SOPTION         CA      SKEEP4
                MASK    HI5             # = BANK BITS
                TC      LEFT5
```

Uses NEWJOB 138, SKEEP3 165, SKEEP4 165, SKEEP5 165, SKEEP6 165, SKEEP7 165, and TC 169.

1889 ⟨*Page CM1403* 1889⟩≡ (1871 2636)

```
                TS      L               # BANK NUMBER BEFORE SUPER BANK
                CA      SKEEP4
                MASK    S8BITS          # = SUPER BANK BITS
                EXTEND
                BZF     SOPT            # BEFORE SUPER BANK
                TS      SR              # SUPER BANK NECESSARY
                CA      L
                MASK    SEVEN
                AD      SR
                TS      L               # BANK NUMBER WITH SUPER BANK
SOPT            CA      SKEEP6          # *
                EXTEND                  # *
                BZF     +2              # * ON -0 CONTINUE WITH ROPE CHECK.
                TC      SDISPLAY        # * ON +1 GO TO DISPLAY OF SUM.
                CCS     SKEEP1          # FORCE SUM TO ABSOLUTE VALUE.
                TC      +2
                TC      +2
                AD      S+1
                TS      SKEEP1
BNKCHK          CS      L               # = - BANK NUMBER
                AD      SKEEP1
                AD      S-1
                TC      -1CHK           # CHECK SUM
                TC      NXTBNK

                EBANK=  NEWJOB
LSTBNKCH        BBCON*                  # * CONSTANT, LAST BANK.
                SBANK=  LOWSUPER
```

Uses EBANK 80, L 80, LOWSUPER 67, NEWJOB 138, SKEEP1 165, SKEEP4 165, SKEEP6 165, SR 80, and TC 169.

3.7.20 phase table maintenance

1890 ⟨*phase table maintenance* 1890⟩≡ (1523a)

⟨*Page CM1404* 1891⟩
⟨*Page CM1405* 1892⟩
⟨*Page CM1406* 1893⟩
⟨*Page CM1407* 1894⟩
⟨*Page CM1408* 1895⟩
⟨*Page CM1409* 1896⟩
⟨*Page CM1410* 1898⟩
⟨*Page CM1411* 1900⟩
⟨*Page CM1412* 1902⟩
⟨*Page CM1413* 1903⟩

1891 ⟨*Page CM1404* 1891⟩≡ (1890 2771)

```
# SUBROUTINE TO UPDATE THE PROGRAM NUMBER DISPLAY ON THE DSKY.

                COUNT   02/PHASE
                BLOCK   02
                SETLOC  FFTAG1
                BANK

NEWMODEX        INDEX   Q               # UPDATE MODREG.  ENTRY FOR MODE IN FIXED.
                CAF     0
                INCR    Q

NEWMODEA        TS      MODREG          # ENTRY FOR MODE IN A.
MMDSPLAY        CAF     +3              # DISPLAY MAJOR MODE.
PREBJUMP        LXCH    BBANK           # PUTS BBANK IN L
                TCF     BANKJUMP        # PUTS Q INTO A
                CADR    SETUPDSP

# RETURN TO CALLER +3 IF MODE = THAT AT CALLER +1.  OTHERWISE RETURN TO CALLER +2.

CHECKMM         INDEX   Q
                CS      0
                AD      MODREG
                EXTEND
                BZF     Q+2
                TCF     Q+1             # NO MATCH

TCQ             =       Q+2 +1

                BANK    14
                SETLOC  PHASETAB
                BANK

                COUNT   10/PHASE

SETUPDSP        INHINT
                DXCH    RUPTREG1        # SAVE CALLER'S RETURN 2CADR
                CAF     PRIO30          #       EITHER A TASK OR JOB CAN COME TO
                TC      NOVAC           #       NEWMODEX
                EBANK=  MODREG
                2CADR   DSPMMJOB

                DXCH    RUPTREG1
                RELINT
                DXCH    Z               # RETURN
```

```
DSPMMJOB        EQUALS  DSPMMJB

                BLOCK   02
```

Uses A 80, BBANK 80, COUNT 142, EBANK 80, FFTAG1 57, L 80, MODE 145, MODREG 154, PHASETAB 59, Q 80, RUPTREG1 138, SAVE 191, TC 169, and Z 80.

1892 ⟨*Page CM1405* 1892⟩≡ (1890 2771)

```
                SETLOC  FFTAG1
                BANK
```

Uses FFTAG1 57.

1893 ⟨*Page CM1406* 1893⟩≡ (1890 2771)

```
# PHASCHNG IS THE MAIN WAY OF MAKING PHASE CHANGES FOR RESTARTS.  THERE ARE THREE FORMS OF PHAS
# A, TYPE B, AND TYPE C.  THEY ARE ALL CALLED AS FOLLOWS, WHERE OCT XXXXX CONTAINS THE PHASE IN
#               TC      PHASCHNG
#               OCT     XXXXX
# TYPE A IS CONCERNED WITH FIXED PHASE CHANGES, THAT IS, PHASE INFORMATION THAT IS STORED PERMA
# OPTIONS ARE, WHERE G STANDS FOR A GROUP AND .X FOR THE PHASE,
#       G.0             INACTIVE, WILL NOT PERMIT A GROUP G RESTART
#       G.1             WILL CAUSE THE LAST DISPLAY TO BE REACTIVATED, USED MAINLY IN MANNED FL
#       G.EVEN          A DOUBLE TABLE RESTART, CAN CAUSE ANY COMBINATION OF TWO JOBS, TASKS, A
#                       LONGCALL TO BE RESTARTED.
#       G.ODD NOT .1    A SINGLE TABLE RESTART, CAN CAUSE EITHER A JOB, TASK, OR LONGCALL RESTA
#
# THIS INFORMATION IS PUT INTO THE OCTAL WORD AFTER TC PHASCHNG AS FOLLOWS
#       TL0 00P PPP PPP GGG
# WHERE EACH LETTER OR NUMBER STANDS FOR A BIT.  THE G'S STAND FOR THE GROUP, OCTAL 1-7, THE P'
# OCTAL 0 - 127.  0'S MUST BE 0.  IF ONE WISHES TO HAVE THE TBASE OF GROUP G TO BE SET AT THIS
# T IS SET TO 1, OTHERWISE IT IS SET TO 0.  SIMILARLY IF ONE WISHES TO SET LONGBASE, THEN L IS
# IT IS SET TO 0.  SOME EXAMPLES,
#               TC      PHASCHNG        # THIS WILL CAUSE GROUP 3 TO BE SET TO 0,
#               OCT     00003           # MAKING GROUP 3 INACTIVE
#
#               TC      PHASCHNG        # IF A RESTART OCCURS THIS WOULD CAUSE
#               OCT     00012           # GROUP 2 TO RESTART THE LAST DISPLAY
#
#               TC      PHASCHNG        # THIS SETS THE TBASE OF GROUP 4 AND IN
#               OCT     40064           # CASE OF A RESTART WOULD START UP THE TWO
#                                       # THINGS LOCATED IN THE DOUBLE 4.6 RESTART
#                                       # LOCATION.
#
#               TC      PHASCHNG        # THIS SETS LONGBASE AND UPON A RESTART
#               OCT     20135           # CAUSES 5.13 TO BE RESTARTED (SINCE
#                                       # LONGBASE WAS SET THIS SINGLE ENTRY
#                                       # SHOULD BE A LONGCALL)
#
#               TC      PHASCHNG        # SINCE BOTH TBASE4 AND LONGBASE ARE SET,
#               OCT     60124           # 4.12 SHOULD CONTAIN BOTH A TASK AND A
#                                       # LONGCALL TO BE RESTARTED
#
# TYPE C PHASCHNG CONTAINS THE VARIABLE TYPE OF PHASCHNG INFORMATION.  INSTEAD OF THE INFORMATI
# PERMANENT FORM, ONE STORES THE DESIRED RESTART INFORMATION IN A VARIABLE LOCATION.  THE BITS
#       TL0 1AD XXX CJW GGG
# WHERE EACH LETTER OR NUMBER STANDS FOR A BIT.  THE G'S STAND FOR THE GROUP, OCTAL 1 - 7.  IF
# BE BY WAITLIST, W IS SET TO 1, IF IT IS A JOB, J IS SET TO 1, IF IT IS A LONGCALL, C IS SET T
# THESE THREE BITS MAY BE SET.  X'S ARE IGNORED, 1 MUST BE 1, AND 0 MUST BE 0.  AGAIN T STANDS
```

Uses A 80, IT 185, L 80, LONGBASE 157, RESTART 57, TBASE4 154, TC 169, and W 183.

1894 ⟨*Page CM1407* 1894⟩≡ (1890 2771)

```
# AND L FOR LONGBASE.  THE BITS A AND D ARE CONCERNED WITH THE VARIABLE INFORMATION.
# OR DELTA TIME WILL BE READ FROM THE NEXT LOCATION AFTER THE OCTAL INFORMATION., IF
# IS, THE NAME OF A LOCATION CONTAINING THE INFORMATION (DELTA TIME ONLY), THEN THIS
# THAT LOCATION WHICH CONTAINS THE DELTA TIME.  IF THE OLD PRIORITY OR DELTA TIME IS
# ALREADY IN THE VARIABLE STORAGE, THEN D IS SET TO 0.  NEXT THE A BIT IS USED.  IF I
# THAT WOULD BE RESTARTED DURING A RESTART IS THE NEXT LOCATION AFTER THE PHASE INFOR
# (TC PHASCHNG) +2 OR +3, DEPENDING ON WHETHER D HAD BEEN SET OR NOT.  IF A IS SET TO
# WOULD BE RESTARTED IS THE 2CADR THAT IS READ FROM THE NEXT TWO LOCATION.  EXAMPLES,
#       AD      TC      PHASCHNG        # THIS WOULD CAUSE LOCATION AD +3 TO BE
#       AD+1    OCT     05023           # RESTARTED BY GROUP THREE WITH A PRIORITY
#       AD+2    OCT     23000           # OF 23.  NOTE UPON RETURNING IT WOULD
#       AD+3                            # ALSO GO TO AD+3
#
#       AD      TC      PHASCHNG        # GROUP 1 WOULD CAUSE CALLCALL TO BE
#       AD+1    OCT     27441           # BE STARTED AS A LONGCALL FROM THE TIME
#       AD+2    -GENADR DELTIME         # STORED IN LONGBASE (LONGBASE WAS SET) BY
#       AD+3    2CADR   CALLCALL        # A DELTATIME STORED IN DELTIME.  THE
#       AD+4                            # BBCON OF THE 2CADR SHOULD CONTAIN THE E
#       AD+5                            # BANK OF DELTIME.  PHASCHNG RETURNS TO
#                                       # LOCATION AD+5
#
# NOTE THAT IF A VARIABLE PRIORITY IS GIVEN FOR A JOB, THE JOB WILL BE RESTARTED AS A
# NEGATIVE, AS A FINDVAC IF THE PRIORITY IS POSITIVE.
#
# TYPE B PHASCHNG IS A COMBINATION OF VARIABLE AND FIXED PHASE CHANGES.  IT WILL STAR
# BELOW AND ALSO START UP ONE FIXED RESTART, THAT IS EITHER AN G.1 OR A G.ODD OR THE
# DOUBLE ENTRY.  THE BIT INFORMATION IS AS FOLLOW,
#       TL1 DAP PPP PPP GGG
# WHERE EACH LETTER OR NUMBER STANDS FOR A BIT.  THE G'S STAND FOR THE GROUP, OCTAL 1
# PHASE INFORMATION, OCTAL 0 - 127.  1 MUST BE 1.  AND AGAIN T STANDS FOR THE TBASE A
# TIME STANDS ONLY FOR PRIORITY SINCE THIS WILL BE CONSIDERED A JOB, AND IT MUST BE C
# AGAIN A STANDS FOR THE ADDRESS OF THE LOCATION TO BE RESTARTED, 1 IF THE 2CADR IS C
# THE NEXT LOCATION.  (THE RETURN LOCATION OF PHASCHNG) EXAMPLES,
#       AD      TC      PHASCHNG        # TBASE IS SET AND A RESTART CAUSE GROUP 3
#       AD+1    OCT     56043           # TO START THE JOB AJOBAJOB WITH PRIORITY
#       AD+2    OCT     31000           # 31 AND THE FIRST ENTRY OF 3.4SPOT (WE CAN
#       AD+3    2CADR   AJOBAJOB        # ASSUME IT IS A TASK SINCE WE SET TBASE3)
#       AD+4                            # UPON RETURN FROM PHASCHNG CONTROL WOULD
#       AD+5                            # GO TO AD+5
#
#       AD      TC      PHASCHNG        # UPON A RESTART THE LAST DISPLAY WOULD BE
#       AD+1    OCT     10015           # RESTARTED AND A JOB WITH THE PREVIOUSLY
#       AD+2                            # STORED PRIORITY WOULD BE BEGUN AT AD+2
#                                       # BY MEANS OF GROUP 5
```

Uses A 80, D 226, IT 185, L 80, LONGBASE 157, PRIORITY 145, RESTART 57, TBASE3 154,

and TC 169.

1895 ⟨*Page CM1408* 1895⟩≡ (1890 2771)

```
# THE NOVAC-FINDVAC CHOICE FOR JOBS HOLDS HERE ALSO -- NEGATIVE PRIORITY CAUSES A NOVAC CALL, P

# SUMMARY OF BITS:
#       TYPE A          TL0 00P PPP PPP GGG
#       TYPE B          TL1 DAP PPP PPP GGG
#       TYPE C          TL0 1AD XXX CJW GGG
```

Uses A 80 and PRIORITY 145.

1896 ⟨*Page CM1409* 1896⟩≡ (1890 2771)

```
# 2PHSCHNG IS USED WHEN ONE WISHES TO START UP A GROUP OR CHANGE A GROUP WHILE UNDER
# GROUP.  FOR EXAMPLE, CHANGE THE PHASE OF GROUP 3 WHILE THE PORTION OF THE PROGRAM I
# CALLS ARE MADE IN THE FOLLOWING MANNER,
#               TC      2PHSCHNG
#               OCT     XXXXX
#               OCT     YYYYY
# WHERE OCT XXXXX MUST BE OF TYPE A AND OCT YYYYY MAY BE OF EITHER TYPE A OR TYPE B (
# DIFFERENCE --- NOTE: IF LONGBASE IS TO BE SET THIS INFORMATION IS GIVEN IN THE OCT
# BE DISREGARDED IF GIVEN WITH THE OCT XXXXX INFORMATION.  A COUPLE OF EXAMPLES MAY B
#       AD      TC      2PHACHNG        # SET TBASE3 AND IF A RESTART OCCURS START
#       AD+1    OCT     40083           # THE TWO ENTRIES IN 3.8 TABLE LOCATION
#       AD+2    OCT     05025           # THIS IS OF TYPE C, SET THE JOB TO BE
#       AD+3    OCT     18000           # TO BE LOCATION AD+4, WITH A PRIORITY 18,
#       AD+4                            # FOR GROUP 5 PHASE INFORMATION.

                COUNT   02/PHASE

2PHSCHNG        INHINT                  # THE ENTRY FOR A DOUBLE PHASE CHANGE
                NDX     Q
                CA      0
                INCR    Q
                TS      TEMPP2

                MASK    OCT7
                DOUBLE
                TS      TEMPG2

                CA      TEMPP2
                MASK    OCT17770        # NEED ONLY 1770, BUT WHY GET A NEW CONST.
                EXTEND
                MP      BIT12
                XCH     TEMPP2

                MASK    BIT15
                TS      TEMPSW2         # INDICATES WHETHER TO SET TBASE OR NOT

                TCF     PHASCHNG +3

PHASCHNG        INHINT
                CA      ONE             # INDICATES CAME FROM A PHASCHNG ENTRY
                TS      TEMPSW2

                NDX     Q
                CA      0
                INCR    Q
```

TS TEMPSW

Uses A 80, COUNT 142, IT 185, LONGBASE 157, PRIORITY 145, Q 80, RESTART 57, TBASE3 154, and TC 169.

1898 ⟨*Page CM1410* 1898⟩≡ (1890 2771)

```
                EXTEND
                DCA     ADRPCHN2        # OFF TO SWITCHED BANK
                DTCB

                EBANK=  LST1
ADRPCHN2        2CADR   PHSCHNG2

ONEORTWO        LXCH    TEMPBBCN
                LXCH    BBANK
                LXCH    TEMPBBCN

                MASK    OCT14000        # SEE WHAT KIND OF PHASE CHANGE IT IS
                CCS     A
                TCF     CHECKB          # IT IS OF TYPE ‘B’.

                CA      TEMPP
                MASK    BIT7
                CCS     A               # SHALL WE USE THE OLD PRIORITY
                TCF     GETPRIO         # NO GET A NEW PRIORITY (OR DELTA T)

OLDPRIO         NDX     TEMPG           # USE THE OLD PRIORITY (OR DELTA T)
                CA      PHSPRDT1 -2
                TS      TEMPPR

CON1            CA      TEMPP           # SEE IF A 2CADR IS GIVEN
                MASK    BIT8
                CCS     A
                TCF     GETNEWNM

                CA      Q
                TS      TEMPNM
                CA      BB
                EXTEND                  # PICK UP USER’S SUPERBANK
                ROR     SUPERBNK
                TS      TEMPBB

TOCON2          CA      CON2ADR         # BACK TO SWITCHED BANK
                LXCH    TEMPBBCN
                DTCB

CON2ADR         GENADR  CON2

GETPRIO         NDX     Q               # DON’T CARE IF DIRECT OR INDIRECT
                CA      0               # LEAVE THAT DECISION TO RESTARTS
                INCR    Q               # OBTAIN RETURN ADDRESS
```

```
                TCF     CON1 -1

GETNEWNM        EXTEND
```

Uses A 80, BBANK 80, EBANK 80, IT 185, LST1 167, PHSPRDT1 154, PRIORITY 145, Q 80, and SUPERBNK 87.

1900 ⟨*Page CM1411* 1900⟩≡ (1890 2771)

```
                INDEX   Q
                DCA     0
                DXCH    TEMPNM
                CA      TWO
                ADS     Q               # OBTAIN RETURN ADDRESS

                TCF     TOCON2

OCT14000        EQUALS  PRIO14
TEMPG           EQUALS  ITEMP1
TEMPP           EQUALS  ITEMP2
TEMPNM          EQUALS  ITEMP3
TEMPBB          EQUALS  ITEMP4
TEMPSW          EQUALS  ITEMP5
TEMPSW2         EQUALS  ITEMP6
TEMPPR          EQUALS  RUPTREG1
TEMPG2          EQUALS  RUPTREG2
TEMPP2          EQUALS  RUPTREG3

TEMPBBCN        EQUALS  RUPTREG4
BB              EQUALS  BBANK

                BANK    14
                SETLOC  PHASETAB
                BANK

                EBANK=  PHSNAME1
                COUNT   10/PHASE

PHSCHNG2        LXCH    TEMPBBCN
                CA      TEMPSW
                MASK    OCT7
                DOUBLE
                TS      TEMPG

                CA      TEMPSW
                MASK    OCT17770
                EXTEND
                MP      BIT12
                TS      TEMPP

                CA      TEMPSW
                MASK    OCT60000
                XCH     TEMPSW
                MASK    OCT14000
```

```
CCS     A
TCF     ONEORTWO
```

Uses A 80, BBANK 80, COUNT 142, EBANK 80, ITEMP1 138, ITEMP2 138, ITEMP3 138, ITEMP4 138, ITEMP5 138, ITEMP6 138, PHASETAB 59, PHSNAME1 167, Q 80, RUPTREG1 138, RUPTREG2 138, RUPTREG3 138, and RUPTREG4 138.

1902 ⟨*Page CM1412* 1902⟩≡ (1890 2771)

```
                CA      TEMPP           # START STORING THE PHASE INFORMATION
                NDX     TEMPG
                TS      PHASE1 -2

BELOW1          CCS     TEMPSW2         # IS IT A PHASCHNG OR A 2PHSCHNG
                TCF     BELOW2          # IT'S A PHASCHNG

                TCF     +1              # IT'S A 2PHSCHNG
                CS      TEMPP2
                LXCH    TEMPP2
                NDX     TEMPG2
                DXCH    -PHASE1 -2

                CCS     TEMPSW2
                NOOP                    # CAN'T GET HERE
                TCF     BELOW2

                CS      TIME1
                NDX     TEMPG2
                TS      TBASE1 -2

BELOW2          CCS     TEMPSW          # SEE IF WE SHOULD SET TBASE OR LONGBASE
                TCF     BELOW3          # SET LONGBASE ONLY
                TCF     BELOW4          # SET NEITHER

                CS      TIME1           # SET TBASE TO BEGIN WITH
                NDX     TEMPG
                TS      TBASE1 -2

                CA      TEMPSW          # SHALL WE NOW SET LONGBASE
                AD      BIT14COM
                CCS     A
                NOOP                    # ***** CAN'T GET HERE *****
BIT14COM        OCT     17777           # ***** CAN'T GET HERE *****
                TCF     BELOW4          # NO WE NEED ONLY SET TBASE

BELOW3          EXTEND                  # SET LONGBASE
                DCA     TIME2
                DXCH    LONGBASE

BELOW4          CS      TEMPP           # AND STORE THE FINAL PART OF THE PHASE
                NDX     TEMPG
                TS      -PHASE1 -2

                CA      Q
```

```
                LXCH    TEMPBBCN
                RELINT
                DTCB
CON2            LXCH    TEMPBBCN
```

Uses -PHASE1 152, A 80, IT 185, LONGBASE 157, PHASE1 152, Q 80, TBASE1 154, TIME1 80, and TIME2 80.

1903 ⟨*Page CM1413* 1903⟩≡ (1890 2771)

```
                CA      TEMPP
                NDX     TEMPG
                TS      PHASE1 -2

                CA      TEMPPR
                NDX     TEMPG
                TS      PHSPRDT1 -2

                EXTEND
                DCA     TEMPNM
                NDX     TEMPG
                DXCH    PHSNAME1 -2

                TCF     BELOW1

                BLOCK   02
                SETLOC  FFTAG1
                BANK

                COUNT   02/PHASE

CHECKB          MASK    BIT12           # SINCE THIS IS OF TYPE B, THIS BIT SHOULD
                CCS     A               # BE HERE IF WE ARE TO GET A NEW PRIORITY
                TCF     GETPRIO         # IT IS, SO GET NEW PRIORITY

                TCF     OLDPRIO         # IT ISN'T, USE THE OLD PRIORITY.
```

Uses A 80, COUNT 142, FFTAG1 57, IT 185, PHASE1 152, PHSNAME1 167, PHSPRDT1 154, and PRIORITY 145.

3.7.21 restarts routine

1904 ⟨*restarts routine* 1904⟩≡ (1523a)
⟨*Page CM1414* 1905⟩
⟨*Page CM1415* 1907⟩
⟨*Page CM1416* 1909⟩
⟨*Page CM1417* 1911⟩
⟨*Page CM1418* 1913⟩
⟨*Page CM1419* 1915⟩

1905 ⟨*Page CM1414* 1905⟩≡ (1904 2794)

```
                BANK    01
                SETLOC  RESTART
                BANK

                EBANK=  PHSNAME1        # GOPROG MUST SWITCH TO THIS EBANK

                COUNT   01/RSROU

RESTARTS        CA      MPAC +5         # GET GROUP NUMBER -1
                DOUBLE                  # SAVE FOR INDEXING
                TS      TEMP2G

                CA      PHS2CADR        # SET UP EXIT IN CASE IT IS AN EVEN
                TS      TEMPSWCH        # TABLE PHASE

                CA      RTRNCADR        # TO SAVE TIME ASSUME IT WILL GET NEXT
                TS      GOLOC +2        # GROUP AFTER THIS

                CA      TEMPPHS
                MASK    OCT1400
                CCS     A               # IS IT A VARIABLE OR TABLE RESTART
                TCF     ITSAVAR         # IT'S A VARIABLE RESTART

GETPART2        CCS     TEMPPHS         # IS IT AN X.1 RESTART
                CCS     A
                TCF     ITSATBL         # NO, IT'S A TABLE RESTART

                CA      PRIO14          # IT IS AN X.1 RESTART, THEREFORE START
                TC      FINDVAC         # THE DISPLAY RESTART JOB
                EBANK=  LST1
                2CADR   INITDSP

                TC      RTRNCADR        # FINISHED WITH THIS GROUP, GET NEXT ONE

ITSAVAR         MASK    OCT1400         # IS IT TYPE B ?
                CCS     A
                TCF     ITSLIKEB        # YES, IT IS TYPE B

                EXTEND                  # STORES THE JOB (OR TASK) 2CADR FOR EXIT
                NDX     TEMP2G
                DCA     PHSNAME1
                DXCH    GOLOC

                CA      TEMPPHS         # SEE IF THIS IS A JOB, TASK, OR A LONGCALL
                MASK    OCT7
```

```
AD      MINUS2
CCS     A
TCF     ITSLNGCL        # IT'S A LONGCALL
```

Uses A 80, COUNT 142, EBANK 80, IT 185, LST1 167, MPAC 145, PHSNAME1 167, RESTART 57, SAVE 191, and TC 169.

1907 ⟨*Page CM1415* 1907⟩≡ (1904 2794)

```
RTRNCADR        TC      SWRETURN        # CAN'T GET HERE.
                TCF     ITSAWAIT

                TCF     ITSAJOB         # IT'S A JOB

ITSAWAIT        CA      WTLTCADR        # SET UP WAITLIST CALL
                TS      GOLOC -1

                NDX     TEMP2G          # DIRECTLY STORED
                CA      PHSPRDT1
TIMETEST        CCS     A               # IS IT AN IMMEDIATE RESTART
                INCR    A               # NO.
                TCF     FINDTIME        # FIND OUT WHEN IT SHOULD BEGIN

                TCF     ITSINDIR        # STORED INDIRECTLY

                TCF     IMEDIATE        # IT WANTS AN IMMEDIATE RESTART

# ***** THIS MUST BE IN FIXED FIXED *****

                BLOCK   02
                SETLOC  FFTAG2
                BANK

                COUNT   02/RSROU

ITSINDIR        LXCH    GOLOC +1        # GET THE CORRECT E BANK IN CASE THIS IS
                LXCH    BB              # SWITCHED ERASABLE

                NDX     A               # GET THE TIME INDIRECTLY
                CA      1

                LXCH    BB              # RESTORE THE BB AND GOLOC
                LXCH    GOLOC +1

                TCF     FINDTIME        # FIND OUT WHEN IT SHOULD BEGIN

# ***** YOU MAY RETURN TO SWITCHED FIXED *****

                BANK    01
                SETLOC  RESTART
                BANK

                COUNT   01/RSROU
```

```
FINDTIME        COM                     # MAKE NEGATIVE SINCE IT WILL BE SUBTRACTED
                TS      L               # AND SAVE
                NDX     TEMP2G
                CS      TBASE1
                EXTEND
```

Uses A 80, COUNT 142, FFTAG2 57, IT 185, L 80, PHSPRDT1 154, RESTART 57, SAVE 191, TBASE1 154, and TC 169.

1909 ⟨*Page CM1416* 1909⟩≡ (1904 2794)

```
                SU      TIME1
                CCS     A
                COM
                AD      OCT37776
                AD      ONE
                AD      L
                CCS     A
                CA      ZERO
                TCF     +2
                TCF     +1
IMEDIATE        AD      ONE
                TC      GOLOC -1
ITSLIKEB        CA      RTRNCADR        # TYPE B, SO STORE RETURN IN
                TS      TEMPSWCH        # TEMPSWCH IN CASE OF AN EVEN PHASE

                CA      PRT2CADR        # SET UP EXIT TO GET TABLE PART OF THIS
                TS      GOLOC +2        # VARIABLE TYPE OF PHASE

                CA      TEMPPHS         # MAKE THE PHASE LOOK RIGHT FOR THE TABLE
                MASK    OCT177          # PART OF THIS VARIABLE PHASE
                TS      TEMPPHS

                EXTEND
                NDX     TEMP2G          # OBTAIN THE JOB'S 2CADR
                DCA     PHSNAME1
                DXCH    GOLOC

ITSAJOB         NDX     TEMP2G          # NOW ADD THE PRIORITY AND LET'S GO
                CA      PHSPRDT1
CHKNOVAC        TS      GOLOC -1        # SAVE PRIO UNTIL WE SEE IF IT'S
                EXTEND                  # A FINDVAC OR A NOVAC
                BZMF    ITSNOVAC

                CAF     FVACCADR        # POSITIVE, SET UP FINDVAC CALL.
                XCH     GOLOC -1        # PICK UP PRIO
                TC      GOLOC -1        AND GO

ITSNOVAC        CAF     NOVACADR        # NEGATIVE,
                XCH     GOLOC -1        # SET UP NOVAC CALL,
                COM                     # CORRECT PRIO,
                TC      GOLOC -1        # AND GO

ITSATBL         TS      CYR             # FIND OUT IF THE PHASE IS ODD OR EVEN
                CCS     CYR
                TCF     +1              # IT'S EVEN
```

```
TCF     ITSEVEN

CA      RTRNCADR        # IN CASE THIS IS THE SECOND PART OF A
TS      GOLOC +2        # TYPE B RESTART, WE NEED PROPER EXIT
```

Uses A 80, CYR 80, L 80, PHSNAME1 167, PHSPRDT1 154, PRIORITY 145, RESTART 57, SAVE 191, TC 169, and TIME1 80.

1911 ⟨*Page CM1417* 1911⟩≡ (1904 2794)

```
                CA      TEMPPHS         # SET UP POINTER FOR FINDING OUR PLACE IN
                TS      SR              # THE RESTART TABLES
                AD      SR
                NDX     TEMP2G
                AD      SIZETAB +1
                TS      POINTER

CONTBL2         EXTEND                  # FIND OUT WHAT'S IN THE TABLE
                NDX     POINTER
                DCA     CADRTAB         # GET THE 2CADR

                LXCH    GOLOC +1        # STORE THE BB INFORMATION

                CCS     A               # IS IT A JOB OR IT IT TIMED
                INCR    A               # POSITIVE, MUST BE A JOB
                TCF     ITSAJOB2

                INCR    A               # MUST BE EITHER A WAITLIST OR LONGCALL
                TS      GOLOC           # LET'S STORE THE CORRECT CADR

                CA      WTLTCADR        # SET UP OUR EXIT TO WAITLIST
                TS      GOLOC -1

                CA      GOLOC +1        # NOW FIND OUT IF IT IS A WAITLIST CALL
                MASK    BIT10           # THIS SHOULD BE ONE IF WE HAVE -BB
                CCS     A               # FOR THAT MATTER SO SHOULD BE BITS 9,8,7,
                                        # 6,5, AND LAST BUT NOT LEAST (PERHAPS NOT
                                        # IN IMPORTANCE ANYWAY.  BUT 4
                TCF     ITSWTLST        # IT IS A WAITLIST CALL

                NDX     POINTER         # OBTAIN THE ORIGINAL DELTA T
                CA      PRDTTAB         # ADDRESS FOR THIS LONGCALL

                TCF     ITSLGCL1        # NOW GO GET THE DELTA TIME

# ***** THIS MUST BE IN FIXED FIXED *****

                BLOCK   02
                SETLOC  FFTAG2
                BANK

                COUNT   02/RSROU

ITSLGCL1        LXCH    GOLOC +1        # OBTAIN THE CORRECT E BANK
                LXCH    BB
```

```
LXCH    GOLOC +1        # AND PRESERVE OUR E AND F BANKS

EXTEND                  # GET THE DELTA TIME
NDX     A
DCA     0
```

Uses A 80, COUNT 142, F 238, FFTAG2 57, IT 185, RESTART 57, and SR 80.

1913 ⟨*Page CM1418* 1913⟩≡ (1904 2794)

```
                LXCH    GOLOC +1        # RESTORE OUR E AND F BANK
                LXCH    BB              # RESTORE THE TASKS E AND F BANKS
                LXCH    GOLOC +1        # AND PRESERVE OUR L
                TCF     ITSLGCL2        # NOT GET'S PROCESS THIS LONGCALL

# ***** YOU MAY RETURN TO SWITCHED FIXED *****

                BANK    01
                SETLOC  RESTART
                BANK

                COUNT   01/RSROU
ITSLGCL2        DXCH    LONGTIME

                EXTEND                  # CALCULATE TIME LEFT
                DCS     TIME2
                DAS     LONGTIME
                EXTEND
                DCA     LONGBASE
                DAS     LONGTIME

                CCS     LONGTIME        # FIND OUT HOW THIS SHOULD BE RESTARTED
                TCF     LONGCLCL
                TCF     +2
                TCF     IMEDIATE -3
                CCS     LONGTIME +1
                TCF     LONGCLCL
                NOOP                    # CAN'T GET HERE ************
                TCF     IMEDIATE -3
                TCF     IMEDIATE

LONGCLCL        CA      LGCLCADR        # WE WILL GO TO LONGCALL
                TS      GOLOC -1

                EXTEND                  # PREPARE OUR ENTRY TO LONGCALL
                DCA     LONGTIME
                TC      GOLOC -1

ITSLNGCL        CA      WTLTCADR        # ASSUME IT WILL GO TO WAITLIST
                TS      GOLOC -1

                NDX     TEMP2G
                CS      PHSPRDT1        # GET THE DELTA T ADDRESS

                TCF     ITSLGCL1        # NOW GET THE DELTA TIME
```

```
ITSWTLST        CS      GOLOC +1        # CORRECT THE BBCON INFORMATION
                TS      GOLOC +1
```

Uses COUNT 142, F 238, IT 185, L 80, LONGBASE 157, LONGTIME 157, PHSPRDT1 154, RESTART 57, TC 169, and TIME2 80.

1915 ⟨*Page CM1419* 1915⟩≡ (1904 2794)

```
                NDX     POINTER         # GET THE DT AND FIND OUT IF IT WAS STORED
                CA      PRDTTAB         # DIRECTLY OR INDIRECTLY

                TCF     TIMETEST        # FIND OUT HOW THE TIME IS STORED

ITSAJOB2        XCH     GOLOC           # STORE THE CADR

                NDX     POINTER         # ADD THE PRIORITY AND LET'S GO
                CA      PRDTTAB

                TCF     CHKNOVAC

ITSEVEN         CA      TEMPSWCH        # SET FOR EITHER THE SECOND PART OF THE
                TS      GOLOC +2        # TABLE, OR A RETURN FOR THE NEXT GROUP

                NDX     TEMP2G          # SET UP POINTER FOR OUR LOCATION WITHIN
                CA      SIZETAB         # THE TABLE
                AD      TEMPPHS         # THIS MAY LOOK BAD BUT LET'S SEE YOU DO
                AD      TEMPPHS         # BETTER IN TIME OR NUMBER OF LOCATIONS
                AD      TEMPPHS
                TS      POINTER

                TCF     CONTBL2         # NO PROCESS WHAT IS IN THE TABLE

PHSPART2        CA      THREE           # SET THE POINTER FOR THE SECOND HALF OF
                ADS     POINTER         # THE TABLE

                CA      RTRNCADR        # THIS WILL BE OUR LAST TIME THROUGH THE
                TS      GOLOC +2        # EVEN TABLE, SO AFTER IT GET THE NEXT
                                        # GROUP
                TCF     CONTBL2         # SO LET'S GET THE SECOND ENTRY IN THE TBL

TEMPPHS         EQUALS  MPAC
TEMP2G          EQUALS  MPAC +1
POINTER         EQUALS  MPAC +2
TEMPSWCH        EQUALS  MPAC +3
GOLOC           EQUALS  VAC5 +20D
MINUS2          EQUALS  NEG2
OCT177          EQUALS  LOW7

PHS2CADR        GENADR  PHSPART2
PRT2CADR        GENADR  GETPART2
LGCLCADR        GENADR  LONGCALL
FVACCADR        GENADR  FINDVAC
WTLTCADR        GENADR  WAITLIST
```

```
NOVACADR        GENADR  NOVAC
```

Uses `A` 80, `IT` 185, `MPAC` 145, `PRIORITY` 145, and `VAC5` 150.

3.7.22 imu mode switching routines

1916 ⟨*imu mode switching routines* 1916⟩≡ (1523a)

⟨*Page CM1420* 1917⟩
⟨*Page CM1421* 1918⟩
⟨*Page CM1422* 1919⟩
⟨*Page CM1423* 1920⟩
⟨*Page CM1424* 1921⟩
⟨*Page CM1425* 1922⟩
⟨*Page CM1426* 1923⟩
⟨*Page CM1427* 1924⟩
⟨*Page CM1428* 1925⟩
⟨*Page CM1429* 1926⟩
⟨*Page CM1430* 1927⟩
⟨*Page CM1431* 1928⟩
⟨*Page CM1432* 1929⟩
⟨*Page CM1433* 1930⟩
⟨*Page CM1434* 1931⟩
⟨*Page CM1435* 1932⟩
⟨*Page CM1436* 1933a⟩
⟨*Page CM1437* 1933b⟩
⟨*Page CM1438* 1934⟩
⟨*Page CM1439* 1935⟩
⟨*Page CM1440* 1936⟩
⟨*Page CM1441* 1937⟩
⟨*Page CM1442* 1938⟩
⟨*Page CM1443* 1939⟩
⟨*Page CM1444* 1940a⟩
⟨*Page CM1445* 1940b⟩
⟨*Page CM1446* 1941⟩
⟨*Page CM1447* 1943⟩
⟨*Page CM1448* 1944a⟩

1917 ⟨*Page CM1420* 1917⟩≡ (1916 2709)

```
                BLOCK   02
                SETLOC  FFTAG3
                BANK

                EBANK=  COMMAND

  # FIXED-FIXED ROUTINES

                COUNT   02/IMODE

  ZEROICDU      CAF     ZERO            # ZERO ICDU COUNTERS.
                TS      CDUX
                TS      CDUY
                TS      CDUZ
                TC      Q

  SPSCODE       =       BIT9
```

Uses CDUX 80, CDUY 80, CDUZ 80, COMMAND 169, COUNT 142, EBANK 80, FFTAG3 57, Q 80, and TC 169.

1918 ⟨*Page CM1421* 1918⟩≡ (1916 2709)

```
# IMU ZEROING ROUTINE.

                BANK    11
                SETLOC  MODESW
                BANK

                COUNT   07/IMODE

IMUZERO         INHINT                  # ROUTINE TO ZERO ICDUS.
                CS      DSPTAB +11D     # DON'T ZERO CDUS IS IMU IN GIMBAL LOCK AND
                MASK    BITS4&6         # COARSE ALIGN (GIMBAL RUNAWAY PROTECTION)
                CCS     A
                TCF     IMUZEROA

                TC      ALARM           # IF SO.
                OCT     00206

                TCF     CAGETSTJ +4     # IMMEDIATE FAILURE.

IMUZEROA        TC      CAGETSTJ

# DO ALL THE WORK.

                CS      IMODES33        # DISABLE DAP AUTO AND HOLD MODES
                MASK    SUPER011        #       BIT5 FOR GROUND
                ADS     IMODES33

                CS      IMODES30        # INHIBIT ICDUFAIL AND IMUFAIL (IN CASE WE
                MASK    BITS3&4         # JUST CAME OUT OF COARSE ALIGN).
                ADS     IMODES30

                CS      BITS4&6         # SEND ZERO ENCODE WITH COARSE AND ERROR
                EXTEND                  # COUNTER DISABLED.
                WAND    CHAN12

                TC      NOATTOFF        # TURN OFF NO ATT LAMP.

                CAF     BIT5
                EXTEND
                WOR     CHAN12

                TC      ZEROICDU
                CAF     BIT6            # WAIT 320 MS TO GIVE AGS ADEQUATE TIME TO
                TC      WAITLIST        # RECEIVE ITS PULSE TRAIN.
                EBANK=  CDUIND
```

```
                2CADR   IMUZERO2

                CS      IMODES30        # SEE IF IMU OPERATING AND ALARM IF NOT.
                MASK    BIT9
                CCS     A
                TCF     MODEEXIT
```

Uses A 80, CDUIND 169, CDUS 80, CHAN12 87, COUNT 142, DSPTAB 154, EBANK 80, IMODES30 163, IMODES33 163, MODESW 59, and TC 169.

1919 ⟨*Page CM1422* 1919⟩≡ (1916 2709)

```
                TC      ALARM
                OCT     210

  MODEEXIT      RELINT                  # GENERAL MODE-SWITCHING EXIT.
                TCF     SWRETURN

  IMUZERO2      TC      CAGETEST
                TC      ZEROICDU        # ZERO CDUX, CDUY, CDUZ

                CS      BIT5            # REMOVE ZERO DISCRETE.
                EXTEND
                WAND    CHAN12

                CAF     BIT11           # WAIT 10 SECS FOR CTRS TO FIND GIMBALS
                TC      VARDELAY

  IMUZERO3      TC      CAGETEST
                CS      BITS3&4         # REMOVE IMUFAIL AND ICDUFAIL INHIBIT.
                MASK    IMODES30
                TS      IMODES30

                CS      SUPER011        # ENABLE DAP AUTO AND HOLD MODES
                MASK    IMODES33        #       BIT5 FOR GROUND
                TS      IMODES33

                TC      IBNKCALL        # SET ISS WARNING IF EITHER OF ABOVE ARE
                CADR    SETISSW         # PRESENT.

                TCF     ENDIMU
```

Uses CDUX 80, CDUY 80, CDUZ 80, CHAN12 87, IMODES30 163, IMODES33 163, MODE 145, and TC 169.

1920 ⟨*Page CM1423* 1920⟩≡ (1916 2709)

```
# IMU COARSE ALIGN MODE.

IMUCOARS        INHINT
                TC      CAGETSTJ
                TC      SETCOARS

                CAF     SIX
                TC      WAITLIST
                EBANK=  CDUIND
                2CADR   COARS

                TCF     MODEEXIT

COARS           TC      CAGETEST
                CAF     BIT6            # ENABLE ALL THREE ISS CDU ERROR COUNTERS
                EXTEND
                WOR     CHAN12

                CAF     TWO             # SET CDU INDICATOR
COARS1          TS      CDUIND

                INDEX   CDUIND          # COMPUTE THETAD -- THETAA IN 1'S
                CA      THETAD          #       COMPLEMENT FORM
                EXTEND
                INDEX   CDUIND
                MSU     CDUX
                EXTEND
                MP      BIT13           # SHIFT RIGHT 2
                XCH     L               # ROUND
                DOUBLE
                TS      ITEMP1
                TCF     +2
                ADS     L

                INDEX   CDUIND          # DIFFERENCE TO BE COMPUTED
                LXCH    COMMAND
                CCS     CDUIND
                TC      COARS1

                CAF     TWO             # MINIMUM OF 4 MS WAIT
                TC      VARDELAY
```

Uses CDUIND 169, CDUX 80, CHAN12 87, COMMAND 169, EBANK 80, ITEMP1 138, L 80, MODE 145, TC 169, and THETAD 157.

1921 ⟨*Page CM1424* 1921⟩≡ (1916 2709)

```
COARS2          TC      CAGETEST        # DON'T CONTINUE IF CAGED.
                TS      ITEMP1          # SET TO +0.
                CAF     TWO             # SET CDU INDICATOR.
        +3      TS      CDUIND

                INDEX   CDUIND
                CCS     COMMAND         # NUMBER OF PULSES REQUIRED
                TC      COMPOS          # GREATER THAN MAX ALLOWED
                TC      NEXTCDU +1
                TC      COMNEG
                TC      NEXTCDU +1

COMPOS          AD      -COMMAX         # COMMAX = MAX NUMBER OF PULSES ALLOWED
                EXTEND                  #       MINUS ONE
                BZMF    COMZERO
                INDEX   CDUIND
                TS      COMMAND         # REDUCE COMMAND BY MAX NUMBER OF PULSES
                CS      -COMMAX-        #       ALLOWED

NEXTCDU         INCR    ITEMP1
                AD      NEG0
                INDEX   CDUIND
                TS      CDUXCMD         # SET UP COMMAND REGISTER.

                CCS     CDUIND
                TC      COARS2 +3

                CCS     ITEMP1          # SEE IF ANY PULSES TO GO OUT.
                TCF     SENDPULS

                TC      FIXDELAY        # WAIT FOR GIMBALS TO SETTLE.
                DEC     150

                CAF     TWO             # AT END OF COMMAND, CHECK TO SEE THAT
CHKCORS         TS      ITEMP1          # GIMBALS ARE WITHIN 2 DEGREES OF THETAD.
                INDEX   A
                CA      CDUX
                EXTEND
                INDEX   ITEMP1
                MSU     THETAD
                CCS     A
                TCF     COARSERR
                TCF     CORSCHK2
                TCF     COARSERR
```

Uses A 80, CDUIND 169, CDUX 80, CDUXCMD 80, COMMAND 169, ITEMP1 138, TC 169, and THETAD 157.

1922 ⟨*Page CM1425* 1922⟩≡ (1916 2709)

```
CORSCHK2        CCS     ITEMP1
                TCF     CHKCORS
                TCF     ENDIMU          # END OF COARSE ALIGNMENT

COARSERR        AD      COARSTOL        # 2 DEGREES.
                EXTEND
                BZMF    CORSCHK2

                TC      ALARM           # COARSE ALIGN ERROR.
                OCT     211

                TCF     IMUBAD

COARSTOL        DEC     -.01111         # 2 DEGREES SCALED AT HALF-REVOLUTIONS

COMNEG          AD      -COMMAX
                EXTEND
                BZMF    COMZERO
                COM
                INDEX   CDUIND
                TS      COMMAND
                CA      -COMMAX-
                TC      NEXTCDU

COMZERO         CAF     ZERO
                INDEX   CDUIND
                XCH     COMMAND
                TC      NEXTCDU

SENDPULS        CAF     13,14,15
                EXTEND
                WOR     CHAN14
                CAF     600MS
                TCF     COARS2 -1       # THEN TO VARDELAY

CA+ECE          CAF     BIT6            # ENABLE ALL THREE ISS CDU ERROR COUNTERS
                EXTEND
                WOR     CHAN12
                TC      TASKOVER
```

Uses CDUIND 169, CHAN12 87, CHAN14 87, COMMAND 169, ITEMP1 138, and TC 169.

1923 ⟨*Page CM1426* 1923⟩≡ (1916 2709)

```
SETCOARS        CAF     BIT4            # BYPASS IF ALREADY IN COARSE ALIGN
                EXTEND
                RAND    CHAN12
                CCS     A
                TC      Q

                CS      BIT6            # CLEAR ISS ERROR COUNTERS
                EXTEND
                WAND    CHAN12

                CS      BIT10           # KNOCK DOWN GYRO ACTIVITY
                EXTEND
                WAND    CHAN14
                CS      ZERO
                TS      GYROCMD

                CAF     BIT4            # PUT ISS IN COARSE ALIGN
                EXTEND
                WOR     CHAN12

                CS      DSPTAB +11D     # TURN ON NO ATT LAMP
                MASK    OCT40010
                ADS     DSPTAB +11D

                CS      IMODES33        # DISABLE DAP AUTO AND HOLD MODES
                MASK    BIT6
                ADS     IMODES33

                CS      IMODES30        # DISABLE IMUFAIL
                MASK    BIT4
                ADS     IMODES30

RNDREFDR        CS      BIT5            # KNOCK DOWN TRACK FLAG
                MASK    FLAGWRD1
                TS      FLAGWRD1

                CS      BIT15           # KNOCK DOWN DRIFT FLAG
                MASK    FLAGWRD2
                TS      FLAGWRD2

                CS      BIT13           # KNOCK DOWN REFSMMAT FLAG
                MASK    FLAGWRD3
                TS      FLAGWRD3

                TC      Q
```

```
OCT40010        OCT     40010
```

Uses A 80, CHAN12 87, CHAN14 87, DSPTAB 154, FLAGWRD1 97, FLAGWRD2 101, FLAGWRD3 105, GYROCMD 80, IMODES30 163, IMODES33 163, Q 80, REFSMMAT 172, and TC 169.

1924 ⟨*Page CM1427* 1924⟩≡ (1916 2709)

```
# IMU FINE ALIGN MODE SWITCH.

IMUFINE         INHINT
                TC      CAGETSTJ        # SEE IF IMU BEING CAGED.

                CS      BITS4-5         # RESET ZERO AND COARSE
                EXTEND
                WAND    CHAN12

                CS      BIT6            # INSURE DAP AUTO AND HOLD MODES ENABLED
                MASK    IMODES33
                TS      IMODES33

                TC      NOATTOFF

                CAF     BIT10           # IMU FAIL WAS INHIBITED DURING THE
                TC      WAITLIST        # PRESUMABLY PRECEDING COARSE ALIGN.  LEAVE
                EBANK=  CDUIND
                2CADR   IFAILOK         # IT ON FOR THE FIRST 5 SECS OF FINE ALIGN

                CAF     2SECS
                TC      WAITLIST
                EBANK=  CDUIND
                2CADR   IMUFINED

                TCF     MODEEXIT

IMUFINED        TC      CAGETEST        # SEE THAT NO ONE HAS CAGED THE IMU.
                TCF     ENDIMU
```

Uses CDUIND 169, CHAN12 87, EBANK 80, IMODES33 163, IT 185, MODE 145, and TC 169.

1925 ⟨*Page CM1428* 1925⟩≡ (1916 2709)

```
IFAILOK         TC      CAGETSTQ        # ENABLE IMU FAIL UNLESS IMU BEING CAGED.
                TCF     TASKOVER        # IT IS.

                CAF     BIT4            # DON'T RESET IMU FAIL INHIBIT IF SOMEONE
                EXTEND                  # HAS GONE INTO COARSE ALIGN.
                RAND    CHAN12
                CCS     A
                TCF     TASKOVER

                CS      IMODES30        # RESET IMUFAIL.
                MASK    BIT13
                ADS     IMODES30
                CS      BIT4
PFAILOK2        MASK    IMODES30
                TS      IMODES30
                TC      IBNKCALL        # THE ISS WARNING LIGHT MAY COME ON NOW
                CADR    SETISSW         # THAT THE INHIBIT WAS BEEN REMOVED.
                TCF     TASKOVER

PFAILOK         TC      CAGETSTQ        # ENABLE PIP FAIL PROG ALARM.
                TCF     TASKOVER

                CS      IMODES30        # RESET IMU AND PIPA FAIL BITS.
                MASK    BIT10
                ADS     IMODES30

                CS      IMODES33
                MASK    BIT13
                ADS     IMODES33

                CS      BIT5
                TCF     PFAILOK2

NOATTOFF        CS      OCT40010        # SUBROUTINE TO TURN OFF NO ATT LAMP.
                MASK    DSPTAB +11D
                AD      BIT15
                TS      DSPTAB +11D
                TC      Q
```

Uses `A` 80, `CHAN12` 87, `DSPTAB` 154, `IMODES30` 163, `IMODES33` 163, `IT` 185, `Q` 80, and `TC` 169.

1926 ⟨*Page CM1429* 1926⟩≡ (1916 2709)

```
# ROUTINES TO INITIATE AND TERMINATE PROGRAM USE OF THE PIPAS.  NO IMUSTALL REQUIRED

PIPUSE          CS      ZERO
                TS      PIPAX
                TS      PIPAY
                TS      PIPAZ

PIPUSE1         TC      CAGETSTQ        # DO NOT ENABLE PIPA FAIL IF IMU IS CAGED
                TCF     SWRETURN

                INHINT
                CS      BIT1            # IF PIPA FAILS FROM NOW ON (UNTIL
                MASK    IMODES30        # PIPFREE), LIGHT ISS WARNING.
                TS      IMODES30

PIPFREE2        TC      IBNKCALL        # ISS WARNING MIGHT COME ON NOW.
                CADR    SETISSW         # (OR GO OFF ON PIPFREE).

                TCF     MODEEXIT

PIPFREE         INHINT                  # PROGRAM DONE WITH PIPAS.  DON'T LIGHT
                CS      IMODES30        # ISS WARNING.
                MASK    BIT1
                ADS     IMODES30

                MASK    BIT10           # IF PIP FAIL ON, DO PROG ALARM AND RESET
                CCS     A               # ISS WARNING.
                TCF     MODEEXIT

                TC      ALARM
                OCT     212

                INHINT

                TCF     PIPFREE2
```

Uses `A` 80, `IMODES30` 163, `PIPAX` 80, `PIPAY` 80, `PIPAZ` 80, and `TC` 169.

1927 ⟨*Page CM1430* 1927⟩≡ (1916 2709)

```
# THE FOLLOWING ROUTINE TORQUES THE IRIGS ACCORDING TO DOUBLE PRECISION INPUTS IN THE SIX REGIS
# BEGINNING AT THE ECADR ARRIVING IN A.  THE MINIMUM SIZE OF ANY PULSE TRAIN IS 16 PULSES (.25
# UNSENT PORTION OF THE COMMAND IS LEFT INTACT IN THE INPUT COMMAND REGISTERS.

                EBANK=  1400            # VARIABLE, ACTUALLY.

IMUPULSE        TS      MPAC +5         # SAVE ARRIVING ECADR.
                TC      CAGETSTJ        # DONT PROCEED IF IMU BEING CAGED.

                CCS     LGYRO           # SEE IF GYROS BUSY.
                TC      GYROBUSY        # SLEEP.

                TS      MPAC +2
                CAF     BIT6            # ENABLE THE POWER SUPPLY.
                EXTEND
                WOR     CHAN14

                CAF     FOUR
GWAKE2          TC      WAITLIST        # (IF A JOB WAS PUT TO SLEEP, THE POWER
                EBANK=  CDUIND          # SUPPLY IS LEFT ON BY THE WAKING JOB).
                2CADR   STRTGYRO

                CA      MPAC +5         # SET UP EBANK, SAVING CALLER'S EBANK FOR
                XCH     EBANK           # RESTORATION ON RETURN.
                XCH     MPAC +5
                TS      LGYRO           # RESERVES GYROS.
                MASK    LOW8
                TS      ITEMP1

                CAF     TWO             # FORCE SIGN AGREEMENT ON INPUTS.
GYROAGRE        TS      MPAC +3
                DOUBLE
                AD      ITEMP1
                TS      MPAC +4
                EXTEND
                INDEX   A
                DCA     1400
                DXCH    MPAC
                TC      TPAGREE
                DXCH    MPAC
                INDEX   MPAC +4
                DXCH    1400

                CCS     MPAC +3
                TCF     GYROAGRE
```

```
                CA      MPAC +5         # RESTORE CALLER'S EBANK.
                TS      EBANK
                TCF     MODEEXIT
```

Uses A 80, CDUIND 169, CHAN14 87, COMMAND 169, EBANK 80, ITEMP1 138, LGYRO 161, MPAC 145, SAVE 191, and TC 169.

1928 ⟨*Page CM1431* 1928⟩≡ (1916 2709)

```
# ROUTINES TO ALLOW TORQUING ONLY ONE JOB AT A TIME.

GYROBUSY        EXTEND                  # SAVE RETURN 2FCADR.
                DCA     BUF2
                DXCH    MPAC
REGSLEEP        CAF     LGWAKE
                TCF     JOBSLEEP

GWAKE           CCS     LGYRO           # WHEN AWAKENED, SEE IF GYROS STILL BUSY.
                TCF     REGSLEEP        # IF SO, SLEEP SOME MORE.

                TS      MPAC +2
                EXTEND
                DCA     MPAC
                DXCH    BUF2            # RESTORE SWRETURN INFO.
                CAF     ONE
                TCF     GWAKE2

LGWAKE          CADR    GWAKE
```

Uses A 80, BUF2 142, LGYRO 161, MPAC 145, and SAVE 191.

1929 ⟨*Page CM1432* 1929⟩≡ (1916 2709)

```
# GYRO-TORQUING WAITLIST TASKS.

STRTGYRO        CS      GDESELCT        # DE-SELECT LAST GYRO.
                EXTEND
                WAND    CHAN14

                TC      CAGETEST

STRTGYR2        CA      LGYRO           # JUMP ON PHASE COUNTER IN BITS 13-14.
                EXTEND
                MP      BIT4
                INDEX   A
                TCF     +1
                TC      GSELECT         # =0.  DO Y GYRO.
                OCT     00202

                TC      GSELECT         # =1.  DO Z GYRO.
                OCT     00302

                TC      GSELECT -2      # =2.  DO X GYRO.
                OCT     00100

                CAF     ZERO            # =3.  DONE
                TS      LGYRO
                CAF     LGWAKE          # WAKE A POSSIBLE SLEEPING JOB.
                TC      JOBWAKE

NORESET         TCF     IMUFINED        # DO NOT RESET POWER SUPPLY.
```

Uses A 80, CHAN14 87, LGYRO 161, TC 169, and Z 80.

1930 ⟨*Page CM1433* 1930⟩≡ (1916 2709)

```
        -2      CS      FOUR            # SPECIAL ENTRY TO REGRESS LGYRO FOR X.
                ADS     LGYRO

GSELECT         INDEX   Q               # SELECT GYRO.
                CAF     0               # PACKED WORD CONTAINS GYRO SELECT BITS
                TS      ITEMP4          # AND INCREMENT TO LGYRO.
                MASK    SEVEN
                AD      BIT13
                ADS     LGYRO
                TS      EBANK
                MASK    LOW8
                TS      ITEMP1

                CS      SEVEN
                MASK    ITEMP4
                TS      ITEMP4

                EXTEND                  # MOVE DP COMMAND TO RUPTREGS FOR TESTING.
                INDEX   ITEMP1
                DCA     1400
                DXCH    RUPTREG1

                CCS     RUPTREG1
                TCF     MAJ+
                TCF     +2
                TCF     MAJ-

                CCS     RUPTREG2
                TCF     MIN+
                TCF     STRTGYR2
                TCF     MIN-
                TCF     STRTGYR2
```

Uses COMMAND 169, EBANK 80, ITEMP1 138, ITEMP4 138, LGYRO 161, Q 80, RUPTREG1 138, and RUPTREG2 138.

1931 ⟨*Page CM1434* 1931⟩≡ (1916 2709)

```
MIN+            AD      -GYROMIN        # SMALL POSITIVE COMMAND.  SEE IF AT LEAST
                EXTEND                  # 16 GYRO PULSES.
                BZMF    STRTGYR2

MAJ+            EXTEND                  # DEFINITE POSITIVE OUTPUT.
                DCA     GYROFRAC
                DAS     RUPTREG1

                CA      ITEMP4          # SELECT POSITIVE TORQUING FOR THIS GYRO.
                EXTEND
                WOR     CHAN14

                CAF     LOW7            # LEAVE NUMBER OF POSSIBLE 8192 AUGMENTS
                MASK    RUPTREG2        # TO INITIAL COMMAND IN MAJOR PART OF LONG
                XCH     RUPTREG2        # TERM STORAGE AND TRUNCATED FRACTION
GMERGE          EXTEND                  # IN MINOR PART.  THE MAJOR PART WILL BE
                MP      BIT8            # COUNTED DOWN TO ZERO IN THE COURSE OF
                TS      ITEMP2          # PUTTING OUT THE ENTIRE COMMAND.
                CA      RUPTREG1
                EXTEND
                MP      BIT9
                TS      RUPTREG1
                CA      L
                EXTEND
                MP      BIT14
                ADS     ITEMP2          # INITIAL COMMAND.

                EXTEND                  # SEE IF MORE THAN ONE PULSE TRAIN NEEDED
                DCA     RUPTREG1        # (MORE THAN 16383 PULSES).
                AD      MINUS1
                CCS     A
                TCF     LONGGYRO
-GYROMIN        OCT     -176            # MAY BE ADJUSTED TO SPECIFY MINIMUM CMD
                TCF     +4

                CAF     BIT14
                ADS     ITEMP2
                CAF     ZERO

        +4      INDEX   ITEMP1
                DXCH    1400
```

Uses A 80, CHAN14 87, COMMAND 169, ITEMP1 138, ITEMP2 138, ITEMP4 138, L 80, LONG 157, RUPTREG1 138, and RUPTREG2 138.

1932 ⟨*Page CM1435* 1932⟩≡ (1916 2709)

```
                CA      ITEMP2          # ENTIRE COMMAND.
LASTSEG         TS      GYROCMD
                EXTEND
                MP      BIT10           # WAITLIST DT
                AD      THREE           # TRUNCATION AND PHASE UNCERTAINTIES.
                TC      WAITLIST
                EBANK=  CDUIND
                2CADR   STRTGYRO

GYROEXIT        CAF     BIT10
                EXTEND
                WOR     CHAN14
                TCF     TASKOVER

LONGGYRO        INDEX   ITEMP1
                DXCH    1400            # INITIAL COMMAND OUT PLUS N AUGMENTS OF
                CAF     BIT14           # 8192.  INITIAL COMMAND IS AT LEAST 8192.
                AD      ITEMP2
                TS      GYROCMD

AUG3            EXTEND                  # GET WAITLIST DT TO TIME WHEN TRAIN IS
                MP      BIT10           # ALMOST OUT.
                AD      NEG3
                TC      WAITLIST
                EBANK=  CDUIND
                2CADR   8192AUG

                TCF     GYROEXIT

8192AUG         TC      CAGETEST

                CAF     BIT4
                EXTEND
                RAND    CHAN12
                CCS     A
                TCF     IMUBAD
                CA      LGYRO           # ADD 8192 PULSES TO GYROCMD
                TS      EBANK
                MASK    LOW8
                TS      ITEMP1

                INDEX   ITEMP1          # SEE IF THIS IS THE LAST AUG.
                CCS     1400
                TCF     AUG2            # MORE TO COME.
```

```
                CAF     BIT14
                ADS     GYROCMD
                TCF     LASTSEG +1
```

Uses A 80, CDUIND 169, CHAN12 87, CHAN14 87, COMMAND 169, EBANK 80, GYROCMD 80, ITEMP1 138, ITEMP2 138, LGYRO 161, N 206, and TC 169.

1933a ⟨*Page CM1436* 1933a⟩≡ (1916 2709)

```
AUG2            INDEX   ITEMP1
                TS      1400
                CAF     BIT14
                ADS     GYROCMD
                TCF     AUG3            # COMPUTE DT.
```

Uses GYROCMD 80 and ITEMP1 138.

1933b ⟨*Page CM1437* 1933b⟩≡ (1916 2709)

```
MIN-            AD      -GYROMIN        # POSSIBLE NEGATIVE OUTPUT.
                EXTEND
                BZMF    STRTGYR2

MAJ-            EXTEND                  # DEFINITE NEGATIVE OUTPUT.
                DCS     GYROFRAC
                DAS     RUPTREG1

                CA      ITEMP4          # SELECT NEGATIVE TORQUING FOR THIS GYRO.
                AD      BIT9
                EXTEND
                WOR     CHAN14

                CS      RUPTREG1        # SET UP RUPTREGS TO FALL INTO GMERGE.
                TS      RUPTREG1        # ALL NUMBERS PUT INTO GYROCMD ARE
                CS      RUPTREG2        # POSITIVE -- BIT9 OF CHAN 14 DETERMINES
                MASK    LOW7            # THE SIGN OF THE COMMAND.
                COM
                XCH     RUPTREG2
                COM
                TCF     GMERGE

GDESELCT        OCT     1700            # TURN OFF SELECT AND ACTIVITY BITS.

GYROFRAC        2DEC    .215 B-21
```

Uses CHAN 191, CHAN14 87, COMMAND 169, GYROCMD 80, ITEMP4 138, RUPTREG1 138, and RUPTREG2 138.

1934 ⟨*Page CM1438* 1934⟩≡ (1916 2709)

```
# IMU MODE SWITCHING ROUTINES COME HERE WHEN ACTION COMPLETE.

ENDIMU          EXTEND                  # MODE IS BAD IF CAGE HAS OCCURRED OR IF
                READ    DSALMOUT        # ISS WARNING IS ON.
                MASK    BIT1
                CCS     A
                TCF     IMUBAD

IMUGOOD         TCF     GOODEND         # WITH C(A) = 0.

IMUBAD          CAF     ZERO
                TCF     BADEND

CAGETEST        CAF     BIT6            # SUBROUTINE TO TERMINATE IMU MODE
                MASK    IMODES30        # SWITCH IF IMU HAS BEEN CAGED.
                CCS     A
                TCF     IMUBAD          # DIRECTLY.
                TC      Q               # WITH C(A) = +0.

CAGETSTQ        CS      IMODES30        # SKIP IF IMU NOT BEING CAGED.
                MASK    BIT6
                CCS     A
                INCR    Q
                TC      Q

CAGETSTJ        CS      IMODES30        # IF DURING MODE SWITCH INITIALIZATION.
                MASK    BIT6            # IT IS FOUND THAT THE IMU IS BEING CAGED.
                CCS     A               # SET IMUCADR TO -0 TO INDICATE OPERATION
                TC      Q               # COMPLETE BUT FAILED.  RETURN IMMEDIATELY
                CS      ZERO            # TO SWRETURN.
                TS      IMUCADR
                TCF     MODEEXIT
```

Uses `A` 80, `DSALMOUT` 87, `IMODES30` 163, `IMUCADR` 163, `IT` 185, `MODE` 145, `Q` 80, and `TC` 169.

1935 ⟨*Page CM1439* 1935⟩≡ (1916 2709)

```
# GENERALIZED MODE SWITCHING TERMINATION.  ENTER AT GOODEND FOR SUCCESSFUL COMPLETION OF AN I/O
# OR AT BADEND FOR AN UNSUCCESSFUL ONE.  C(A) OR ARRIVAL =0 FOR IMU, 1 FOR OPTICS.

BADEND          TS      RUPTREG2        # DEVICE INDEX.
                CS      ZERO            # FOR FAILURE.
                TCF     GOODEND +2

GOODEND         TS      RUPTREG2
                CS      ONE             # FOR SUCCESS.

                TS      RUPTREG3
                INDEX   RUPTREG2        # SEE IF USING PROGRAM ASLEEP.
                CCS     MODECADR
                TCF     +2              # YES -- WAKE IT UP.
                TCF     ENDMODE         # IF 0, PROGRAM NOT IN YET.

                CAF     ZERO            # WAKE SLEEPING PROGRAM.
                INDEX   RUPTREG2
                XCH     MODECADR
                TC      JOBWAKE

                CS      RUPTREG3        # ADVANCE LOC IF SUCCESSFUL.
                INDEX   LOCCTR
                ADS     LOC

                TCF     TASKOVER

ENDMODE         CA      RUPTREG3        # -0 INDICATES OPERATION COMPLETE BUT
                INDEX   RUPTREG2        # UNSUCCESSFUL:  -1 INDICATES COMPLETE AND
                TS      MODECADR        # SUCCESSFUL.
                TCF     TASKOVER
```

Uses `A` 80, `I` 206, `IT` 185, `LOC` 145, `LOCCTR` 138, `MODE` 145, `MODECADR` 163, `RUPTREG2` 138, `RUPTREG3` 138, and `TC` 169.

1936 ⟨*Page CM1440* 1936⟩≡ (1916 2709)

```
# GENERAL STALLING ROUTINE.  USING PROGRAMS COME HERE TO WAIT FOR I/O COMPLETION.
#
# PROGRAM DESCRIPTION                          DATE -- 21 FEB 1967
#                                              LOG SECTION IMU MODE SWITCHING
# MOD BY -- R. MELANSON TO ADD DOCUMENTATION   ASSEMBLY SUNDISK REV. 82
#
# FUNCTIONAL DESCRIPTION --
#       TO DELAY FURTHER EXECUTION OF THE CALLING ROUTINE UNTIL ITS SELECTED
#       I/O FUNCTION IS COMPLETE.  THE FOLLOWING CHECKS ON THE CALLING ROUTINES
#       MODEECADR ARE MADE AND ACTED UPON.
#       1) +0 INDICATES INCOMPLETE I/O OPERATION.  CALLING ROUTINE IS PUT TO
#          SLEEP.
#       2) -1 INDICATES COMPLETED I/O OPERATION.  STALL BYPASSES JOBSLEEP
#          CALL AND RETURNS TO CALLING ROUTINE AT L+3.
#       3) -0 INDICATES COMPLETED I/O WITH FAILURE.  STALL CLEARS MODECADR
#          AND RETURNS TO CALLING ROUTINE AT L+2.
#       4) VALUE GREATER THAN 0 INDICATES TWO ROUTINES CALLING FOR USE OF
#          SAME DEVICE.  STALL EXITS TO ABORT WHICH EXECUTES A PROGRAM
#          RESTART WHICH IN TURN CLEARS ALL MODECADR REGISTERS.
#
# CALLING SEQUENCE --
#       L       TC      BANKCALL
#       L+1     CADR    (ONE OF 5 STALL ADDRESSES.  I.E., IMUSTALL, OPTSTALL, RADSTAL
#                       AOTSTALL, OR ATTSTALL)
#
# NORMAL-EXIT MODE --
#       TCF JOBSLEEP    OR      TCF MODEXIT
#
# ALARM OR ABORT EXIT MODE --
#       TC      ABORT
#
# OUTPUT --
#       MODECADR=CADR   IF JOBSLEEP
#       MODECADR=+0     IF I/O COMPLETE
#       BUF2=L+3        IF I/O COMPLETE AND GOOD.
#       BUF2=L+2        IF I/O COMPLETE BUT FAILED.
#
# ERASABLE INITIALIZATION --
#       BUF2 CONTAINS RETURN ADDRESS PLUS 1,(L+2)
#       BUF2+1 CONTAINS FBANK VALUE OF CALLING ROUTINE.
#       MODECADR OF CALLING ROUTINE CONTAINS +0,-1,-0 OR CADR RETURN ADDRESS.
#
# DEBRIS --
#       RUPTREG2 AND CALLING ROUTINE MODECADR.
```

```
AOTSTALL        CAF     ONE             # AOT.
                TC      STALL

RADSTALL        CAF     TWO
                TCF     STALL
```

Uses A 80, BUF2 142, FBANK 80, I 206, L 80, MODE 145, MODECADR 163, RESTART 57, RUPTREG2 138, and TC 169.

1937 ⟨*Page CM1441* 1937⟩≡ (1916 2709)

```
OPTSTALL        EQUALS  AOTSTALL

IMUSTALL        CAF     ZERO            # IMU.

STALL           INHINT
                TS      RUPTREG2        # SAVE DEVICE INDEX.
                INDEX   A               # SEE IF OPERATION COMPLETE.
                CCS     MODECADR
                TCF     MODABORT        # ALLOWABLE STATES ARE +0, -1, AND -0.
                TCF     MODESLP         # OPERATION INCOMPLETE.
                TCF     MODEGOOD        # COMPLETE AND GOOD IF = -1.

MG2             INDEX   RUPTREG2        # COMPLETE FAILED IF -0.  RESET TO +0.
                TS      MODECADR        # RETURN TO CALLER.
                TCF     MODEEXIT

MODEGOOD        CCS     A               # MAKE SURE INITIAL STATE -1.
                TCF     MODABORT

                INCR    BUF2            # IF SO, INCREMENT RETURN ADDRESS AND
                TCF     MG2             # RETURN IMMEDIATELY, SETTIN CADR = +0.

MODESLP         TC      MAKECADR        # CALL FROM SWITCHABLE FIXED ONLY.
                INDEX   RUPTREG2
                TS      MODECADR
                TCF     JOBSLEEP

MODABORT        TC      P00DOO          # TWO PROGRAMS USING THE SAME DEVICE.
                OCT     1210
```

Uses A 80, BUF2 142, MODECADR 163, RUPTREG2 138, SAVE 191, STATE 138, and TC 169.

1938 ⟨*Page CM1442* 1938⟩≡ (1916 2709)

```
# CONSTANTS FOR MODE SWITCHING ROUTINES

BITS3&4         =       OCT14
BITS4&6         =       OCT50
BITS4-5         EQUALS  BITS4&5
IMUSEFLG        EQUALS  BIT8            # INTERPRETER SWITCH 7.
-COMMAX         DEC     -191
-COMMAX-        DEC     -192
600MS           DEC     60
IMUFIN20        =       IMUFINE
GOMANUR         CA      ATTCADR         # IS KALCMANU FREE
                EXTEND
                BZF     +3
                TC      P00D00          # NO
                OCT     1210            # 2 TRYING TO USE SAME DEVICE

        +3      EXTEND
                DCA     BUF2
                DXCH    ATTCADR         # SAVE FINAL RETURN FOR KALCMAN3

                CA      BBANK
                MASK    SEVEN
                ADS     ATTCADR +1

                CA      PRIORITY
                MASK    PRIO37
                TS      ATTPRIO         # SAVE USER'S PRIO

                CAF     KALEBCON        # SET EBANK FOR KALCMAN3
                TS      EBANK
                TC      POSTJUMP
                CADR    KALCMAN3
KALEBCON        ECADR   BCDU
```

Uses ATTCADR 163, ATTPRIO 163, BBANK 80, BCDU 219, BUF2 142, EBANK 80, MODE 145, PRIORITY 145, SAVE 191, and TC 169.

1939 ⟨*Page CM1443* 1939⟩≡ (1916 2709)

```
# PROGRAM DESCRIPTION
# IMU STATUS CHECK ROUTINE R02 (SUBROUTINE UTILITY)
# MOD NO -- 1
# MOD BY -- N.BRODEUR
#
# FUNCTIONAL DESCRIPTION
#       TO CHECK WHETHER IMU IS ON AND IF ON WHETHER IT IS ALIGNED TO AN
#       ORIENTATION KNOWN BY THE CMC.  TO REQUEST SELECTION OF THE APPROPRIATE
#       PROGRAM IF THE IMU IS OFF OR NOT ALIGNED TO AN ORIENTATION KNOWN BY THE
#       CMC.  CALLED THROUGH BANKCALL
#
# CALLING SEQUENCE --
#       L       TC      BANKCALL
#       L+1     CADR    R02BOTH
#
# SUBROUTINES CALLED
#       VARALARM
#       FLAGUP
#
# NORMAL EXIT MODES
#       AT L+2 OF CALLING SEQUENCE
#
# ALARM OR ABORT EXIT MODES
#       GOTOPOOH, WITH ALARM
#
# ERASABLE INITIALIZATION REQUIRED
#       NONE
#
# DEBRIS
#       CENTRALS -- A,Q,L

                BANK    34
                SETLOC  R02
                BANK
                COUNT   04/R02          # COUNT*

DEC51           DEC     51
R02BOTH         CAF     BIT13
                MASK    STATE +3        # REFSMFLG
                CCS     A
                TC      R02ZERO         # ZERO IMUS

                CA      IMODES30
                MASK    BIT9            # IS ISS INITIALIZED
                EXTEND
```

```
                BZF     +2
                CS      BIT4            # SEND IMU ALARM CODE 210
                AD      OCT220          # SEND REFSMM ALARM
                TC      VARALARM

                TC      GOTOP00H
```

Uses A 80, CODE 140, COUNT 142, IMODES30 163, IT 185, L 80, N 206, Q 80, R02 59, REFSMFLG 107, STATE 138, and TC 169.

1940a ⟨*Page CM1444* 1940a⟩≡ (1916 2709)

```
R02ZERO         TC      UPFLAG
                ADRES   IMUSE
                TCF     SWRETURN
OCT220          OCT     220
```

Uses IMUSE 95 and TC 169.

1940b ⟨*Page CM1445* 1940b⟩≡ (1916 2709)

```
# PROGRAM DESCRIPTION:  P06             10 FEB 67
#
# TRANSFER THE ISS/CMC FROM THE OPERATE TO THE STANDBY CONDITION.
#
# THE NORMAL CONDITION OF READINESS OF THE GNCS WHEN NOT IN USE IS STANDBY.  IN THIS
# HEATER POWER IS ON.  THE IMU OPERATE POWER IS OFF.  THE COMPUTER POWER IS ON.  THE
# CMC STANDBY ON THE MAIN AND LEB DISKYS IS ON.
#
# CALLING SEQUENCE:
#       ASTRONAUT REQUEST THROUGH DSKY  V37E 06E.
#
# SUBROUTINES CALLED:
#       GOPERF1
#       BANKCALL
#       FLAGDOWN
#
```

Uses COMPUTER 115.

1941 ⟨*Page CM1446* 1941⟩≡ (1916 2709)

```
# PRESTAND PREPARES FOR STANDBY BY SNAPSHOTTING THE SCALER AND TIME1 TIME2.
# THE LOW 5 BITS OF THE SCALER ARE INSPECTED TO INSURE COMPATIBILITY
# BETWEEN THE SCALER READING AND THE TIME1 TIME2 READING.

                SETLOC  P05P06
                BANK

                EBANK=  TIME2SAV
                COUNT*  $$/P06

P06             TC      UPFLAG          # SET NODOV37 BIT
                ADRES   NODOFLAG

PRESTAND        INHINT
                EXTEND
                DCA     TIME2           # SNAPSHOT TIME1 TIME2
                DXCH    TIME2SAV
                TC      SCALPREP
                TC      PRESTAND        # T1,T2,SCALER NOT COMPATIBLE
                DXCH    MPAC            # T1,T2 AND SCALER OK
                DXCH    SCALSAVE        # STORE SCALER
                INHINT
                TC      BANKCALL
                CADR    RNDREFDR        # REFSMM, DRIFT, TRACK FLAGS DOWN

                TC      DOWNFLAG
                ADRES   IMUSE           # IMUSE DOWN
                TC      DOWNFLAG
                ADRES   RNDVZFLG        # RNDVZFLG DOWN

                CAF     BIT11
                EXTEND
                WOR     CHAN13          # SET STANDBY ENABLE BIT

                TC      PHASCHNG        # SET RESTART TO POSTAND WHEN STANDBY
                OCT     07024           #       RECOVERS
                OCT     20000
                EBANK=  SCALSAVE
                2CADR   POSTAND

                CAF     OCT62
                TC      BANKCALL
                CADR    GOPERF1
                TCF     -3
                TCF     -4
```

```
                TCF     -5

OCT62           EQUALS  .5SEC          # DEC 50 = OCT 62

# THE LOW 5 BITS OF THE SCALER READS 10000 FOR THE FIRST INTERVAL AFTER A
```

Uses A 80, CHAN13 87, COUNT 142, EBANK 80, IMUSE 95, MPAC 145, NODOFLAG 105, PO5PO6 65, RESTART 57, RNDVZFLG 97, SCALSAVE 157, T1 241, T2 241, TC 169, TIME1 80, TIME2 80, and TIME2SAV 157.

1943 ⟨*Page CM1447* 1943⟩≡ (1916 2709)

```
# T1 INCREMENT.  IF SCALPREP DETECTS THIS INTERVAL THE T1,T2 AND SCALER
# DATA ARE NOT COMPATIBLE AND RETURN IS TO L+1 FOR ANOTHER READING OF THE
# DATA.  OTHERWISE, THE RETURN IS TO L+2 TO PROCEED.  ROUTINE ALSO PREPARES
# THE SCALER READING FOR COMPUTATION OF THE INCREMENT TO UPDATE T1T2.  (THE
# 10 MS BIT (BIT 6) OF THE SCALER IS INCREMENTED 5 MS OUT OF PHASE FROM
# T1.) ADDITION OF 5 MS (BIT 5) TO THE SCALER READING HAS THE EFFECT OF
# ADJUSTING BIT 6 IN THE SCALER TO BE IN PHASE WITH BIT 1 OF T1.  THE LOW 5
# BITS OF THE SCALER READING ARE THEN SET TO ZERO, TO TRUNCATE THE SCALER
# DATA TO 10 MS.  RESULTS ARE STORED IN MPAC, +1.

SCALPREP        EXTEND
                QXCH    MPAC +2
                TC      FINETIME +1
                RELINT
                DXCH    MPAC
                CA      BIT5            # ADD 5 MS TO THE SCALER READING.
                TS      L
                CA      ZERO
                DAS     MPAC
                CS      LOW5            # SET LOW 5 BITS OF (SCALER+5MS) TO ZERO
                MASK    MPAC +1         # AND STORE RESULTS IN MPAC,+1.
                XCH     MPAC +1
                MASK    LOW5            # TEST LOW 5 BITS OF SCALER FOR THE FIRST
                                        # INTERVAL AFTER THE T1 INCREMENT
                                        # (NOW = 00000, SINCE BIT 5 ADDED).
                CCS     A               # IS IT 1ST INTERVAL AFTER T1 INCREMENT
                INCR    MPAC +2         # NO
                TC      MPAC +2         # YES

# POSTAND RECOVERS TIME AFTER STANDBY.  THE SCALER IS SNAPSHOTTED AND THE
# TIME1 TIME2 COUNTER IS SET TO ZERO.  THE LOW 5 BITS OF THE SCALER ARE
# INSPECTED TO INSURE COMPATIBILITY BETWEEN THE SCALER READING AND THE
# CLEARING OF THE TIME COUNTER.  IT THEN COMPUTES THE DIFFERENCE IN SCALER
# VALUES (IN DP) AND ADDS THIS TO THE PREVIOUSLY SNAPSHOTTED VALUES OF
# TIME1 TIME2 AND PLACES THIS NEW TIME INTO THE TIME1 TIME2 COUNTER.

                COUNT*  $$/P05

POSTAND         CS      BIT11           # RECOVER TIME AFTER STANDBY
                EXTEND
                WAND    CHAN13          # CLEAR STANDBY ENABLE BIT
                INHINT
                CA      ZERO
                TS      L
                DXCH    TIME2           # CLEAR TIME1 TIME2
```

```
                TC      SCALPREP        # STORE SCALER IN MPAC, MPAC+1
                TC      POSTAND +3      # T1,T2,SCALER NOT COMPATIBLE
                EXTEND                  # T1,T2 AND SCALER OK
                DCS     SCALSAVE
                DAS     MPAC            # FORM DP DIFFERENCE OF POST-STANDBY SCALER
```

Uses A 80, CHAN13 87, COUNT 142, IT 185, L 80, MPAC 145, SCALSAVE 157, T1 241, T2 241, TC 169, TIME1 80, and TIME2 80.

1944a ⟨*Page CM1448* 1944a⟩≡ (1916 2709)

```
                CAF     BIT10           # MINUS PRE-STANDBY SCALER AND SHIFT RIGHT
                TC      SHORTMP         # 5 TO ALIGN BITS WITH TIME1 TIME2.
                CAF     ZERO
                TS      MPAC +2         # NEEDED FOR TP AGREE
                TC      TPAGREE         # MAKE DP DIFF AGREE
                CCS     MPAC
                TC      POSTCOM         # IF DP DIFF NET +, NO SCALER OVERFLOW
                TC      POSTCOM         # BETWEEN PRE AND POST STANDBY.
                TC      +1              # IF DP DIFF NET -, SCALER OVERFLOWED.  ADD
                CAF     BIT10           # BIT 10 TO HIGH DIFF TO CORRECT.
                ADS     MPAC
POSTCOM         EXTEND                  # C(MPAC,+1) IS MAGNITUDE OF DELTA SCALER.
                DCA     TIME2SAV        # PRE-STANDBY TIME1 TIME2
                DAS     MPAC
                TC      TPAGREE         # FORCE SIGN AGREEMENT
                DXCH    MPAC            # UPDATED VALUE FOR T1,T2.
                DAS     TIME2           # LOAD UPDATED VALUE INTO T1,T2, WITH
                TC      DOWNFLAG        # CLEAR NODOFLAG
                ADRES   NODOFLAG

                TC      GOTOPOOH
```

Uses DIFF 226, MPAC 145, NODOFLAG 105, T1 241, T2 241, TC 169, TIME1 80, TIME2 80, and TIME2SAV 157.

3.7.23 keyrupt uprupt

1944b ⟨*keyrupt uprupt* 1944b⟩≡ (1523a)

```
# Page 1449
```
⟨*Page CM1449* 1945⟩
```
# Page 1450
```
⟨*Page CM1450* 1946⟩
```
# Page 1451
```
⟨*Page CM1451* 1947⟩

1945 ⟨*Page CM1449* 1945⟩≡ (1944b 2733)

```
                BANK     14
                SETLOC   KEYRUPT
                BANK
                COUNT*   $$/KEYUP

KEYRUPT1        TS       BANKRUPT
                XCH      Q
                TS       QRUPT
                TC       LODSAMPT        # TIME IS SNATCHED IN RUPT FOR NOUN 65.
                CAF      LOW5
                EXTEND
                RAND     MNKEYIN         # CHECK IF KEYS 5M-1M ON
KEYCOM          TS       RUPTREG4
                CS       FLAGWRD5
                MASK     BIT15
                ADS      FLAGWRD5

ACCEPTUP        CAF      CHRPRIO         # (NOTE: RUPTREG4 = KEYTEMP1)
                TC       NOVAC
                EBANK=   DSPCOUNT
                2CADR    CHARIN

                CA       RUPTREG4
                INDEX    LOCCTR
                TS       MPAC            # LEAVE 5 BIT KEY CODE IN MPAC FOR CHARIN
                TC       RESUME
```

Uses BANKRUPT 80, CODE 140, COUNT 142, DSPCOUNT 152, EBANK 80, FLAGWRD5 113, KEYRUPT 59, KEYTEMP1 138, LOCCTR 138, MNKEYIN 87, MPAC 145, Q 80, QRUPT 80, RUPTREG4 138, and TC 169.

1946 ⟨*Page CM1450* 1946⟩≡ (1944b 2733)

```
# UPRUPT PROGRAM

UPRUPT          TS      BANKRUPT
                XCH     Q
                TS      QRUPT
                TC      LODSAMPT        # TIME IS SNATCHED IN RUPT FOR NOUN 65.
                CAF     ZERO
                XCH     INLINK
                TS      KEYTEMP1
                CAF     BIT3            # TURN ON UPACT LIGHT
                EXTEND                  # (BIT 3 OF CHANNEL 11)
                WOR     DSALMOUT
UPRPT1          CAF     LOW5            # TEST FOR TRIPLE CHAR REDUNDANCY
                MASK    KEYTEMP1        # LOW5 OF WORD
                XCH     KEYTEMP1        # LOW5 INTO KEYTEMP1
                EXTEND
                MP      BIT10           # SHIFT RIGHT 5
                TS      KEYTEMP2
                MASK    LOW5            # MID 5
                AD      HI10
                TC      UPTEST
                CAF     BIT10
                EXTEND
                MP      KEYTEMP2        # SHIFT RIGHT 5
                MASK    LOW5            # HIGH 5
                COM
                TC      UPTEST

UPOK            CS      ELRCODE         # CODE IS GOOD.  IF CODE = ‘ERROR RESET’,
                AD      KEYTEMP1        # CLEAR UPLOCKFL (SET BIT4 OF FLAGWRD7 = 0)
                EXTEND                  # IF CODE DOES NOT = ‘ERROR RESET’, ACCEPT
                BZF     CLUPLOCK        # CODE ONLY IF UPLOCKFL IS CLEAR (=0).

                CAF     BIT4            # TEST UPLOCKFL FOR 0 OR 1
                MASK    FLAGWRD7
                CCS     A
                TC      RESUME          # UPLOCKFL = 1
                TC      ACCEPTUP        # UPLOCKFL = 0

CLUPLOCK        CS      BIT4            # CLEAR UPLOCKFL (I.E., SET BIT 4 OF
                MASK    FLAGWRD7        # FLAGWRD7 = 0)
                TS      FLAGWRD7
                TC      ACCEPTUP

                                        # CODE IS BAD
```

```
TMFAIL2         CS      FLAGWRD7        # LOCK OUT FURTHER UPLINK ACTIVITY
                MASK    BIT4            # (BY SETTING UPLOCKFL = 1) UNTIL
                ADS     FLAGWRD7        # ‘ERROR RESET’ IS SENT VIA UPLINK.
                TC      RESUME
UPTEST          AD      KEYTEMP1
```

Uses A 80, BANKRUPT 80, CHAR 140, CODE 140, DSALMOUT 87, FLAGWRD7 121, I 206, INLINK 80, KEYTEMP1 138, KEYTEMP2 150, Q 80, QRUPT 80, TC 169, and UPLOCKFL 125.

1947 ⟨*Page CM1451* 1947⟩≡ (1944b 2733)

```
                CCS     A
                TC      TMFAIL2
HI10            OCT     77740
                TC      TMFAIL2
                TC      Q

ELRCODE         OCT     22

# ‘UPLINK ACTIVITY LIGHT’ IS TURNED OFF BY .....
#       1.      VBRELDSP
#       2.      ERROR RESET
#       3.      UPDATE PROGRAM (P27) ENTERED BY V70,V71,V72, AND V73.
#
# THE RECEPTION OF A BAD CODE (I.E., CCC FAILURE) LOCKS OUT FURTHER UPLINK ACTIVITY BY SETTING
# THIS INDICATION WILL BE TRANSFERRED TO THE GROUND BY THE DOWNLINK WHICH DOWNLINKS ALL FLAGWOR
# WHEN UPLINK ACTIVITY IS LOCKED OUT, IT CAN BE ALLOWED WHEN THE GROUND UPLINKS AND ‘ERROR RESE
# (IT IS RECOMMENDED THAT THE ‘ERROR LIGHT RESET’ CODE IS PRECEEDED BY 16 BITS THE FIRST OF WHI
# BY 15 ZEROS.  THIS WILL ELIMINATE EXTRANEOUS BITS FROM INLINK WHICH MAY HAVE BEEN LEFT OVER F
# FAILURE).
#
# UPLINK ACTIVITY IS ALSO ALLOWED (UNLOCKED) DURING FRESH START WHEN FRESH START SETS BIT4 OF F
```

Uses A 80, CODE 140, FLAGWRD7 121, I 206, INLINK 80, IT 185, Q 80, and TC 169.

3.7.24 display interface routines

1948 ⟨*display interface routines* 1948⟩≡ (1523a)

⟨*Page CM1452* 1949⟩
⟨*Page CM1453* 1950⟩
⟨*Page CM1454* 1951⟩
⟨*Page CM1455* 1952⟩
⟨*Page CM1456* 1953⟩
⟨*Page CM1457* 1954⟩
⟨*Page CM1458* 1955⟩
⟨*Page CM1459* 1956⟩
⟨*Page CM1460* 1957⟩
⟨*Page CM1461* 1958⟩
⟨*Page CM1462* 1959⟩
⟨*Page CM1463* 1961⟩
⟨*Page CM1464* 1962⟩
⟨*Page CM1465* 1963⟩
⟨*Page CM1466* 1965⟩
⟨*Page CM1467* 1967⟩
⟨*Page CM1468* 1969⟩
⟨*Page CM1469* 1971⟩
⟨*Page CM1470* 1973⟩
⟨*Page CM1471* 1975⟩
⟨*Page CM1472* 1977⟩
⟨*Page CM1473* 1979⟩
⟨*Page CM1474* 1981⟩
⟨*Page CM1475* 1983⟩
⟨*Page CM1476* 1985⟩
⟨*Page CM1477* 1987⟩
⟨*Page CM1478* 1989⟩
⟨*Page CM1479* 1991⟩
⟨*Page CM1480* 1993⟩
⟨*Page CM1481* 1995⟩
⟨*Page CM1482* 1997⟩
⟨*Page CM1483* 1999⟩
⟨*Page CM1484* 2000a⟩

1949 ⟨*Page CM1452* 1949⟩≡ (1948 2673)

```
# DISPLAYS CAN BE CLASSIFIED INTO THE FOLLOWING CATEGORIES --
#       1.  PRIORITY DISPLAYS -- DISPLAYS WHICH TAKE PRIORITY OVER ALL OTHER DISPLAYS.  USUALLY
#           OUT UNDER CRITICAL ALARM CONDITIONS.
#       2.  EXTENDED VERB DISPLAYS -- ALL EXTENDED VERBS AND MARK ROUTINES SHOULD USE EXTENDED
#       3.  NORMAL DISPLAYS -- ALL MISSION PROGRAM DISPLAYS WHICH INTERFACE WITH THE ASTRONAUT
#           SEQUENCE OF EVENTS.
#       4.  MISC. DISPLAYS -- ALL DISPLAYS NOT HANDLED BY THE DISPLAY INTERFACE ROUTINES.  THES
#           MM DISPLAYS AND SPECIAL PURPOSE DISPLAYS HANDLED BY PINBALL.
#       5.  ASTRONAUT INITIATED DISPLAYS -- ALL DISPLAYS INITIATED EXTERNALLY.
#
# THE FOLLOWING TERMS ARE USED TO DESCRIBE THE STATUS OF DISPLAYS --
#       1.  ACTIVE -- THE DISPLAY WHICH IS (1) BEING DISPLAYED TO THE ASTRONAUT AND WAITING FOR
#           (2) WAITING FIRST IN LINE FOR THE ASTRONAUT TO FINISH USING THE DSKY OR (3) BEING D
#           BUT NOT WAITING FOR A RESPONSE.
#       2.  INACTIVE -- A DISPLAY WHICH HAS (1) BEEN ACTIVE BUT WAS INTERRUPTED BY A DISPLAY OF
#           (2) BEEN PUT INTO THE WAITING LIST AT TIME IT WAS REQUESTED DUE TO THE FACT A HIGHE
#           WAS ALREADY DOING, (3) BEEN INTERRUPTED BY THE ASTRONAUT (CALLED A PINBRANCH CONDIT
#           OF INACTIVE DISPLAY IS USUALLY REACTIVATED ONLY BY PINBALL) OR (4) A DISPLAY WHICH
#           HAS INFO SAVED FOR RESTART PURPOSES.
#
# DISPLAY PRIORITIES WORK AS FOLLOWS --
#       INTERRUPTS --
#               1.  THE ASTRONAUT CAN INTERRUPT ANY DISPLAY WITH AN EXTERNAL DISPLAY REQUEST.
#               2.  INTERNAL DISPLAYS CAN NOT BE SENT OUT WHEN THE ASTRONAUT IS USING THE DSKY.
#               3.  PRIORITY DISPLAYS INTERRUPT ALL OTHER TYPES OF INTERNAL DISPLAYS.  A PRIORI
#                   PRIORITY DISPLAY WILL CAUSE AN ABORT UNLESS BIT14 IS SET FOR THE LINUS ROUT
#               4.  A MARK DISPLAY INTERRUPTS ANY NORMAL DISPLAY.
#               5.  A MARK THAT INTERRUPTS A MARK COMPLETELY REPLACES IT.
#
#       ORDER OF WAITING DISPLAYS --
#               1.  ASTRONAUT
#               2.  PRIORITY
#               3.  INTERRUPTED MARK
#               4.  INTERRUPTED NORMAL
#               5.  MARK TO BE REQUESTED (SEE DESCRIPTION OF ENDMARK)
#               6.  MARK WAITING
#               7.  NORMAL WAITING
#
```

Uses A 80, DISPLAYS 59, IT 185, MM 226, PRIORITY 145, and RESTART 57.

1950 ⟨*Page CM1453* 1950⟩≡ (1948 2673)

```
# THE DISPLAY ROUTINES ARE INTENDED TO SERVE AS AN INTERFACE BETWEEN THE USER AND PIN
# FOLLOWING STATEMENTS CAN BE MADE ABOUT NORMAL DISPLAYS AND PRIORITY DISPLAYS (A DES
# WILL FOLLOW LATER):
#       1.  ALL ROUTINES THAT END IN R HAVE AN IMMEDIATE RETURN TO THE USER.  FOR ALL
#           IS TO THE USER'S CALL CADR +4.  FOR THE ONLY NON-FLASHING IMMEDIATE RETUR
#           IS TO THE USER'S CALLING LOC +1.
#       2.  ALL ROUTINES NOT ENDING IN R DO NOT DO AN IMMEDIATE RETURN TO THE USER.
#       3.  ALL ROUTINES THAT END IN R START A SEPARATE JOB (MAKEPLAY) WITH USER'S JO
#       4.  ALL ROUTINES NOT ENDING IN R BRANCH DIRECTLY TO MAKEPLAY WHICH MAKES THES
#           USER'S JOB.
#       5.  ALL DISPLAY ROUTINES ARE CALLED VIA BANKCALL.
#       6.  TO RESTART A DISPLAY THE USER WILL GENERALLY USE A PHASE OF ONE WITH DESI
#           DESCRIPTION OF RESTARTS).
#       7.  ALL FLASHING DISPLAYS HAVE 3 RETURNS TO THE USER FROM ASTRONAUT RESPONSES
#           TO THE USER'S CALL CADR +1.  A PROCEED (V33) BRANCHES TO THE USER'S CALL
#           (V32) BRANCHES TO THE USER'S CALL CADR +3.
#       8.  ALL ROUTINES MUST BE USED UNDER EXECUTIVE CONTROL
#
# A DESCRIPTION OF EACH ROUTINE WITH AN EXAMPLE FOLLOWS:

#       GODSP IS USED TO DISPLAY A VERB NOUN ARRIVING IN A.  NO RETURN IS MADE TO THE
#               1.  GODSP IS NOT RESTARTABLE
#               2.  A VERB PASTE WITH GODSP ALWAYS TURNS ON THE FLASH.
#                               CAF     VXXNYY
#                               TC      BANKCALL
#                               CADR    GODSP
#                       VXXNYY  OCT     OXXYY

#       GODSPR IS THE SAME AS GODSP ONLY RETURN IS TO THE USER.
#                               CAF     VXXNYY
#                               TC      BANKCALL
#                               CADR    GODSPR
#                               ...     ...             # IMMEDIATE RETURN OF GODSPR

#       GOFLASH DISPLAYS A FLASHING VERB NOUN WITH NO IMMEDIATE RETURN TO THE USER.
#       THE ASTRONAUT (SEE NO. 7 ABOVE).
#                               CAF     VXXNYY          # VXX NYY WILL BE A FLASHING
#                               TC      BANKCALL
#                               CADR    GOFLASH
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER OR RECYCLE RETURN

#       GOPERF1 IS ENTERED WITH DESIRED CHECKLIST VALUE IN A.  GOPERF1 WILL DISPLAY T
```

Uses A 80, DISPLAYS 59, LOC 145, PRIORITY 145, RESTART 57, and TC 169.

1951 ⟨*Page CM1454* 1951⟩≡ (1948 2673)

```
#       V01 N25.  A FLASHING PLEASE PERFORM ON CHECKLIST (V50 N25) IS THEN DISPLAYED.  NO IMMED
#       USER (SEE NO. 7 ABOVE).
#       GOPERF1 BLANKS REGISTERS R2 AND R3
#                               CAF     OCTXX           # CODE FOR CHECKLIST VALUE XX
#                               TC      BANKCALL
#                               CADR    GOPERF1
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER RETURN
#       GOPERF2 IS ENTERED WITH A VARIABLE NOUN AND V01 (V00 FOR N10 OR N11) IN A.  GOPERF2 WIL
#       REQUESTED NOUN BY MEANS OF A V01NYY OR A V00NYY.  PLEASE PERFORM ON NOUN (V50 NYY) THEN
#       DISPLAY.  NO IMMEDIATE RETURN IS MADE TO THE USER (SEE NO. 7 ABOVE).
#       GOPERF2 DOES NOT BLANK ANY REGISTERS
#                               CAF     VXXNYY          # VARIABLE NOUN YY. XX=0 OR 01.
#                               TC      BANKCALL
#                               CADR    GOPERF2
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER RETURN
#       GOPERF3 IS USED FOR A PLEASE PERFORM ON A PROGRAM NUMBER.  THE DESIRED PROGRAM NO. IS E
#       DISPLAYS THE NO. BY MEANS OF A V06 N07 FOLLOWED BY A FLASHING V50 N07 FOR A PLEASE PERF
#       IS MADE TO THE USER (SEE NO. 7 ABOVE).
#       GOPERF3 BLANKS REGISTERS R2 AND R3
#                               CAF     DECXX           # REQUEST PERFORM ON PXX
#                               TC      BANKCALL
#                               CADR    GOPERF3
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER RETURN

#       GOPERF4 IS USED FOR A PLEASE PERFORM ON AN OPTION.  THE DESIRED OPTION IS ENTERED IN A
#       GOPERF4 DISPLAYS R1 AND R2 BY MEANS OF A V04N06 FOLLOWED BY A FLASHING V50N06 FOR A PLE
#       IMMEDIATE RETURN IS MADE TO THE USER (SEE NO. 7 ABOVE).
#                               CAF     OCTXX           # REQUEST PERFORM ON OPTION XX
#                               TC      BANKCALL
#                               CADR    GOPERF4
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER RETURN
#       GOPERF4 BLANKS REGISTER R3.
#
```

Uses `A` 80, `CODE` 140, `DISPLAYS` 59, `N10` 206, `OPTION1` 157, `R2` 188, and `TC` 169.

1952 ⟨*Page CM1455* 1952⟩≡ (1948 2673)

```
#       GODSPRET IS USED TO DISPLAY A VERB NOUN ARRIVING IN A WITH A RETURN TO THE US
#       OUT.
#                               CAF     VXXXNYY
#                               TC      BANKCALL
#                               CADR    GODSPRET
#                               ...     ...             # RETURN TO USER.

#       REGODSP IS USED TO DISPLAY A VERB NOUN ARRIVING IN A.  REGODSP IS THE SAME AS
#       ACTIVE NORMAL DISPLAY IF ONE WAS ACTIVE.
#                               CAF     VXXNYY
#                               TC      BANKCALL
#                               CADR    REGODSP

#       REFLASH IS THE SAME AS GOFLASH ONLY REFLASH REPLACES ANY ACTIVE NORMAL DISPLA
#                               CAF     VXXNYY          # VXX NYY WILL BE A FLASHING
#                               TC      BANKCALL
#                               CADR    REFLASH
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER RETURN

#       GOFLASHR IF SAME AS GOFLASH ONLY AN IMMEDIATE RETURN IS MADE TO THE USER'S CA
#                               CAF     VXXNYY
#                               TC      BANKCALL
#                               CADR    GOFLASHR
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER OR RECYCLE RETURN
#                               ...     ...             # IMMEDIATE RETURN FROM GOFLA

#       GOPERF1R IS THE SAME AS GOPERF1 ONLY GOPERF1R HAS AN IMMEDIATE RETURN TO USER
#       GOPERF1R BLANKS REGISTERS R2 AND R3
#                               CAF     OCTXX           # CODE FOR CHECKLIST VALUE XX
#                               TC      BANKCALL
#                               CADR    GOPERF1R
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER RETURN
#                               ...     ...             # IMMEDIATE RETURN FROM GOPER

#       GOPERF2R IS THE SAME AS GOPERF2 ONLY AN IMMEDIATE RETURN IS MADE TO USER'S CA
```

Uses `A` 80, `CODE` 140, `R2` 188, and `TC` 169.

1953 ⟨*Page CM1456* 1953⟩≡ (1948 2673)

```
#       GOPERF2R DOES NOT BLANK ANY REGISTERS
#                               CAF     VXXXNYY         # VARIABLE NOUN YY REQUESTED.  XX=00 OR
#                               TC      BANKCALL
#                               CADR    GOPERF2R
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER RETURN
#                               ...     ...             # IMMEDIATE RETURN HERE FROM GOPERF2R

#       GOPERF3R IS THE SAME AS GOPERF3 ONLY AN IMMEDIATE RETURN IS MADE TO USER'S CALL CADR +4
#       GOPERF3R BLANKS REGISTERS R2 AND R3
#                               CAF     PROGXX          # PERFORM PROGRAM XX
#                               TC      BANKCALL
#                               CADR    GOPERF3R
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER RETURN
#                               ...     ...             # GOPERF3R IMMEDIATELY RETURNS HERE

#       GOPERF4R IS THE SAME AS GOPERF4 ONLY AN IMMEDIATE RETURN IS MADE TO USER'S CALL CADR +4
#                               CAF     OCTXX           # REQUEST PERFORM ON OPTIONXX
#                               TC      BANKCALL
#                               CADR    GOPERF4R
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER RETURN
#                               ...     ...             # IMMEDIATE RETURN TO USER
#       GOPERF4R BLANKS REGISTER R3.
#
#       REFLASHR IS THE SAME AS REFLASH ONLY AN IMMEDIATE RETURN IS MADE TO THE USER'S CALL CAD
#                               CAF     VXXNYY          # VXX NYY WILL BE A FLASHING VERB NOUN
#                               TC      BANKCALL
#                               CADR    REFLASHR
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER RETURN
#                               ...     ...             # IMMEDIATE RETURN TO USER

#       REGODSPR IS THE SAME AS REGODSP ONLY A RETURN (IMMEDIATE) IS MADE TO THE USER.
```

Uses `A` 80, `R2` 188, and `TC` 169.

1954 ⟨*Page CM1457* 1954⟩≡ (1948 2673)

```
#          CAF     VXXNYY
#          TC      BANKCALL
#          CADR    REGODSPR
#          ...     ...          # IMMEDIATE RETURN TO USER
```

Uses TC 169.

1955 ⟨*Page CM1458* 1955⟩≡ (1948 2673)

```
#       GOMARK IS USED TO DISPLAY A MARK VERB NOUN ARRIVING IN A.  NO RETURN IS MADE TO THE USE
#       GOXDSP = GOMARK
#                               CAF     VXXNYY          # VXXNYY CONTAINS VERB AND NOUN
#                               TC      BANKCALL
#                               CADR    GOMARK          # OTHER EXTENDED VERBS USE CADR GOXDSP

#       GOMARKR IS THE SAME AS GOMARK ONLY RETURN IS TO THE USER.
#       GOXDSPR = GOMARKR
#                               CAF     VXXNYY
#                               TC      BANKCALL
#                               CADR    GOMARKR         # OTHER EXTENDED VERBS USE CADR GOXDSPR
#                               ...     ...             # IMMEDIATE RETURN OF GOMARKR

#       GOMARKF DISPLAYS A FLASHING MARK VERB NOUN WITH NO IMMEDIATE RETURN TO THE USER.  3 RET
#       THE ASTRONAUT (SEE NO. 7 ABOVE).
#       GOXDSPF = GOMARKF
#                               CAF     VXXNYY          # VXXNYY WILL BE A FLASHING MARK VERB N
#                               TC      BANKCALL
#                               CADR    GOMARKFR        # OTHER EXTENDED VERBS USE CADR GOXDSPF
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER OR RECYCLE RETURN
#                               ...     ...             # IMMEDIATE RETURN TO THE USER

#       GOMARKFR IS THE SAME AS GOMARKF ONLY AN IMMEDIATE RETURN IS MADE TO THE USER CALL CADR
#       GOXDSPFR = GOMARKFR
#                               CAF     VXXNYY          # FLASHING MARK VERB NOUN
#                               TCF     BANKCALL
#                               CADR    GOMARKFR        # OTHER EXTENDED VERBS USE CADR GOXDSPF
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER OR RECYCLE RETURN
#
#                               ...     ...             # IMMEDIATE RETURN TO THE USER

#       GOMARK1 IS USED FOR A PLEASE PERFORM ON A MARK REQUEST WITH ONLY 1 ASTRONAUT RETURN TO
#       RETURN IS MADE.  THE DESIRED MARK PLEASE PERFORM VERB AND DESIRED NOUN IS ENTERED IN A.
#       MEANS OF A V05NYY FOLLOWED BY A FLASHING V5XNYY FOR A PLEASE PERFORM.  THE ASTRONAUT WI
#       OR MARK REJECT OR AN ENTER.  THE ENTER IS THE ONLY ASTRONAUT RESPONSE THAT WILL COME BA
#                               CAF     V5XNYY          # X=1,2,3,4     YY=NOUN
#                               TC      BANKCALL
```

Uses `A` 80, `DISPLAYS` 59, `R2` 188, and `TC` 169.

1956 ⟨*Page CM1459* 1956⟩≡ (1948 2673)

```
#                               CADR    GOMARK1
#                               ...     ...             # ENTER RETURN

#       *** IF BLANKING DESIRED ON NON-R ROUTINES, NOTIFY DISPLAYER.
#
#       GOMARK1R IS THE SAME AS A GOMARK1 ONLY AN IMMEDIATE RETURN IS MADE TO THE USE
#                               CAF     V5XNYY          # X=1,2,3,4     YY=NOUN
#                               TC      BANKCALL
#                               CADR    GOMARK1R
#                               ...     ...             # ASTRONAUT ENTER RETURN
#                               ...     ...             # IMMEDIATE RETURN TO USER

#       GOMARK2 IS THE SAME AS GOMARK1 ONLY 3 RETURNS ARE MADE TO THE USER FROM THE A
#                               CAF     V5XNYY          # X=1,2,3,4     YY=NOUN
#                               TC      BANKCALL
#                               CADR    GOMARK2
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER RETURN

#       GOMARK2R IS THE SAME AS GOMARK1R ONLY 3 ASTRONAUT RETURNS ARE MADE TO THE USE
#                               CAF     V5XNYY          # X=0,1,2,3,4   YY=NOUN
#                               TCF     BANKCALL
#                               CADR    GOMARK24
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER RETURN
#                               ...     ...             # IMMEDIATE RETURN TO THE USE

#       GOMARK3 IS USED FOR A PLEASE PERFORM ON A MARK REQUEST WITH A 3 COMP. DEC DIS
#       PERFORM VERB AND NOUN ARE ENTERED IN A.  GOMARK3 DISPLAYS R1, R2, R3 BY MEANS
#       V5XNYY FOR A PLEASE PERFORM.  GOMARK3 HAS 3 ASTRONAUT RETURNS TO THE USER WIT
#                               CAF     V5XNYY          # X=1,2,3,4     YY=NOUN
#                               TC      BANKCALL
#                               CADR    GOMARK3
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER RETURN

#       GOMARK4 IS THE SAME AS GOMARK3 ONLY R2 AND R3 ARE BLANKED AND R1 IS DISPLAYED
#                               CAF     V5XNYY          # X=1,2,3,4     YY=NOUN
#                               TC      BANKCALL
#                               CADR    GOMARK4
#                               ...     ...             # TERMINATE RETURN
#                               ...     ...             # PROCEED RETURN
```

Uses A 80, DISPLAYS 59, R2 188, and TC 169.

1957 ⟨*Page CM1460* 1957⟩≡ (1948 2673)

```
#                        ...     ...                    # ENTER RETURN
#       EXDSPRET IS USED TO DISPLAY A VERB NOUN ARRIVING IN A WITH A RETURN MADE TO THE USER AF
#       SENT OUT.
#                                CAF     VXNYY
#                                TC      BANKCALL
#                                CADR    EXDSPRET
#                                ...     ...            # RETURN TO USER

#       KLEENEX CLEANS OUT ALL MARK DISPLAYS (ACTIVE AND INACTIVE). A RETURN IS MADE TO THE USE
#       HAVE BEEN CLEANED OUT.
#                                TC      BANKCALL
#                                CADR    KLEENEX
#                                ...     ...            # RETURN TO USER

#       MARKBRAN IS A SPECIAL PURPOSE ROUTINE USED FOR SAVING JOB VAC AREAS (SEE DESCRIPTION OF
#                                TC      BANKCALL
#                                CADR    MARKBRAN
#                                ...     ...            # BAD RETURN IF MARK DISPLAY NOT ACTIVE
#                                                       # (GOOD RETURN TO IMMEDIATE RETURN LOC
#                                                       # LAST FLASHING MARK R ROUTINE)

#       PINBRNCH REESTABLISHES THE LAST ACTIVE FLASHING DISPLAY.  IF THERE IS NO ACTIVE FLASHIN
#       BLANKED AND CONTROL IS SENT TO ENDOFJOB.
#                                TC      POSTJUMP
#                                CADR    PINBRNCH

#       PRIODSP IS USED AS A PRIORITY DISPLAY.  IT WILL DISPLAY A GOFLASH TYPE DISPLAY WITH THR
#       THE ASTRONAUT (SEE NO. 7 ABOVE).
#
#       THE MAIN PURPOSE OF PRIODSP IS TO REPLACE THE PRESENT DISPLAY WITH A DISPLAY OF HIGHER
#       PROVIDE A MEANS FOR RESTORING THE OLD DISPLAY WHEN THE PRIORITY DISPLAY
#       IS RESPONDED TO BY THE ASTRONAUT.
#
#       THE FORMER DISPLAY IS RESTORED BY AN AUTOMATIC BRANCH TO WAKE UP THE DISPLAY THAT WAS I
#       PRIO DISPLAY
#                                CAF     VXXNYY         # VXXNYY WILL BE A FLASHING VERB NOUN
#                                TC      BANKCALL
#                                CADR    PRIODSP
#                                ...     ...            # TERMINATE RETURN
#                                ...     ...            # PROCEED RETURN
```

Uses A 80, DISPLAYS 59, IT 185, LOC 145, PRIORITY 145, and TC 169.

1958 ⟨*Page CM1461* 1958⟩≡ (1948 2673)

```
#                               ...     ...             # ENTER OR RECYCLE RETURN

#       PRIODSPR IS THE SAME AS PRIODSP ONLY AN IMMEDIATE RETURN IS MADE TO THE USER
#                               CAF     VXXNYY          # VXXNYY WILL BE A FLASHING V
#                               TC      BANKCALL
#                               CADR    PRIODSPR
#                               ...     ...             # TERMINATE ACTION
#                               ...     ...             # PROCEED RETURN
#                               ...     ...             # ENTER OR RECYCLE RETURN
#                               ...     ...             # IMMEDIATE RETURN

#       PRIOLARM DOES A V05N09 PRIODSPR.
#
#       CLEANDSP CLEANS OUT ALL NORMAL DISPLAYS (ACTIVE AND INACTIVE).  A RETURN IS N
#       DISPLAYS ARE CLEANED OUT.
#                               TC      BANKCALL
#                               CADR    CLEANDSP
#                               ...     ...             # RETURN TO USER
```

Uses `A` 80, `DISPLAYS` 59, and `TC` 169.

1959 ⟨*Page CM1462* 1959⟩≡ (1948 2673)

```
#
# GENERAL INFORMATION
# -------------------
#
# ALARM OR ABORT EXIT MODE --
#       PRIOBORT        TC      ABORT
#                       OCT     1502
#
#       PRIOBORT IS BRANCHED TO WHEN (1) A NORMAL DISPLAY IS REQUESTED AND ANOTHER NORMAL DISPL
#       (REFLASH AND REGODSP ARE EXCEPTIONS) OR (2) A PRIORITY DISPLAY IS REQUESTED WHEN ANOTHE
#       ALREADY ACTIVE (A PRIORITY WITH LINUS BIT14 IS AN EXCEPTION).
#
# ERASABLE INITIALIZATION REQUIRED --
#       ACCOMPLISHED BY FRESH START --  1.  FLAGWRD4 (USED EXCLUSIVELY BY DISPLAY INTERFACE ROU
#                                       2.  NVSAVE = NORMAL VERB AND NOUN REGISTER.
#                                       3.  EBANKTEM = NORMAL INACTIVE FLAGWORD (ALSO CONTAINS
#                                       5.  R1SAVE = MARKBRAN CONTROL WORD
#                                       4.  RESTREG = PRIORITY 30 AND SUPERBANK 3.
#
# OUTPUT --
#       NVWORD = PRIO VERB AND NOUN
#       NVWORD +1 (MARKNV) = MARK VERB AND NOUN
#       NVWORD +2 (NVSAVE) = NORMAL VERB AND NOUN
#       DSPFLG (EBANKSAV) = PRIO FLAGWORD (INCLUDING EBANK)
#       DSPFLG +1 (MARKEBAN) = MARK FLAGWORD (INCLUDING EBANK)
#       DSPFLG +2 (EBANKTEM) = NORMAL FLAGWORD (INCLUDING EBANK)
#       CADRFLSH = PRIO USER'S CALL CADR +1 LOCATION
#       CADRFLSH +1 (MARKFLSH) = MARK USER'S CALL CADR +1 LOCATION
#       CADRFLSH +2 (TEMPFLSH) = NORMAL USER'S CALL CADR +1 LOCATION
#       PRIOTIME = TIME EACH PRIO REQUEST FIRST SENT OUT
#       OPTION1 = DESIRED OPTION FROM GOPERF4
#       FLAGWRD4 = BIT INFO FOR CONTROL OF ALL DISPLAY ROUTINES
#       DSPTEM1 = R1 INFO FOR ASTRONAUT FROM PERFORM DISPLAYS (NORMAL)
#
# SUBROUTINES USED -- NVSUB, FLAGUP, FLAGDOWN, ENDOFJOB, BLANKSUB, ABORT, JOBWAKE, JOBSLEEP, FI
#       JAMTERM, NVSUBUSY, FLASHON, ENDIDLE, CHANG1, BANKJUMP, MAKECADR, NOVAC
#
# DEBRIS -- (STORED INTO)
#       TEMPORARY TEMPORARIES -- A, Q, L, MPAC +2, MPAC +3, MPAC +4, MPAC +5, MPAC +6, RUPREG2,
#               EBANK, RUPTREG4, LOC, BANKSET, MODE, MPAC, MPAC +1, FACEREG
#       ERASABLES (SHARED AND USED WITH OTHER PROGRAMS) -- CADRSTOR, DSPLIST, LOC, DSPTEM1, OPT
#       ERASABLES (USED ONLY BY DISPLAY ROUTINES) -- NVWORD,+1,+2, DSPFLAG,+1,+2, CADRFLSH,+1,+
```

Uses A 80, BANKSET 145, CADRFLSH 150, CADRSTOR 154, CYL 80, DISPLAYS 59, DSPLIST 154, DSPTEM1 154, EBANK 80, EBANKSAV 156, EBANKTEM 156, FLAGWRD4 109, L 80, LOC 145, MARKEBAN 156, MARKNV 150, MODE 145, MPAC 145, NVSAVE 150, NVWORD 150, OPTION1 157,

PRIORITY 145, PRIOTIME 157, Q 80, R1SAVE 156, RESTREG 150, RUPTREG3 138, RUPTREG4 138, TC 169, and TEMPFLSH 150.

1961 ⟨*Page CM1463* 1961⟩≡ (1948 2673)

```
#               R1SAVE, MARK2PAC
#
# DEBRIS -- (USED BUT NOT STORED INTO) -- NOUNREG, VERBREG, LOCCTR, MONSAVE1
#
# FLAGWORD DESCRIPTIONS --
#       FLAGWRD4 -- SEE DESCRIPTION UNDER LOG SECTION ERASABLE ASSIGNMENTS
#
#       DSPFLG, DSPFLG+1, DSPFLG+2
#       --------------------------
#       BITS 1  BLANK R1
#            2  BLANK R2
#            3  BLANK R3
#            4  FLASHING DISPLAY REQUESTED
#            5  PERFORM DISPLAY REQUESTED
#            6  -----                   EXDSPRET                GODSPRET
#            7  PRIO DISPLAY            -----                   -----
#            8  -----                   DEC MARK PERFORM        -----
#            9  EBANK
#           10  EBANK
#           11  EBANK
#           12  -----                   -----                   V99PASTE
#           13  2ND PART OF PERFORM
#           14  REFLASH OR REDO         -----                   REFLASH OR REDO
#           15  -----                   MARK REQUEST            -----
#
# RESTARTING DISPLAYS --
#
# RULES FOR THE DSKY OPERATOR --
#       1.  PROCEED AND TERMINATE SERVE AS RESPONSES TO REQUESTS FOR OPERATOR RESPONSE (FLASHIN
#           AS THERE IS ANY REQUEST AWAITING OPERATOR RESPONSE, ANY USE OF PROCEED OR TERMINATE
#           RESPONSES TO THAT REQUEST.  CARE SHOULD BE EXERCISED IN ATTEMPTING TO KILL AN OPERA
#           WITH PROCEED AND TERMINATE FOR THIS REASON.
#       2.  THE ASTRONAUT MUST RESPOND TO A PRIORITY DISPLAY NO SOONER THAN 2 SECONDS FROM THE
#           PROGRAM SENT OUT THE REQUEST FOR OPERATOR RESPONSE (THE ASTRONAUT WOULD SEE THIS DI
#           DUE TO TIME IT TAKES TO GET DISPLAY SENT OUT.)  IF THE ASTRONAUT RESPONDS TOO SOON,
#           IS SENT OUT AGAIN -- AND AGAIN UNTIL AN ACCUMULATED 2 SECS FROM THE TIME THE FIRST
#           OUT.  THE SAME 2 SEC. DELAY WILL OCCUR AT 163.84 SECS OR IN ANY MULTIPLE OF THAT TI
#           CONSIDERATION.
#       3.  KEY RELEASE BUTTON --
#           A)  IF THE KEY RELEASE LIGHT IS ON, IT SIMPLY RELEASES THE KEYBOARD AND DISPLAY FOR
#           B)  IF THE KEY RELEASE LIGHT IS OFF, AND IF SOME REQUEST FOR OPERATOR RESPONSE (FLA
#               AWAITING RESPONSE THEN IT RE-ESTABLISHES THE DISPLAYS THAT ORIGINALLY REQUESTED
#           IF AN OPERATOR WANTS THEREFORE TO RE-ESTABLISH BUT CONDITION (A) IS ENCOUNTERED, A
#           KEY RELEASE BUTTON MAY BE NECESSARY.
#       4.  IT IS IMPORTANT TO ANSWER ALL REQUESTS FOR OPERATOR RESPONSE.
```

```
#       5.  IT IS ALWAYS GOOD PRACTICE TO TERMINATE AN EXTENDED VERB BEFORE ASKING FO
#           OVER AGAIN.
#
# SPECIAL CONSIDERATIONS --
```

Uses A 80, DISPLAYS 59, EBANK 80, FLAGWRD4 109, IT 185, LOCCTR 138, LONG 157, MARK2PAC 156, MONSAVE1 154, N 206, NOUNREG 152, PRIORITY 145, R1SAVE 156, R2 188, V 229, and VERBREG 152.

1962 ⟨*Page CM1464* 1962⟩≡ (1948 2673)

```
#       1.  MPAC +2 SAVED ONLY IN MARK DISPLAYS
#       2.  GODSP(R), REGODSP(R), GOMARK(R) ALWAYS TURN ON THE FLASH IF ENTERED WITH
#       3.  ALL NORMAL DISPLAYS ARE RESTARTABLE EXCEPT GODSP(R), REGODSP(R)
#       4.  ALL EXTENDED VERBS WITH DISPLAYS SHOULD START WITH A TC TESTXACT AND FINI
#       5.  GODSP(R) AND REGODSP(R) MUST BE IN THE SAME EBANK AND SUPERBANK AS THE LA
#           BY A .1 RESTART PHASE CHANGE.
#       6.  IN ORDER TO SET UP A NON DISPLAY .1 RESTART POINT, THE USER MUST MAKE CER
#           CORRECT PRIORITY AND SUPERBANK AND THAT EBANKTEM CONTAINS THE CO
#       7.  IF CLEANDSP IS RESTARTED VIA A .1 PHASE CHANGE, CAF ZERO SHOULD BE EXECUT
```

Uses A 80, DISPLAYS 59, EBANK 80, EBANKTEM 156, MPAC 145, PRIORITY 145, RESTART 57, RESTREG 150, and TC 169.

1963 ⟨*Page CM1465* 1963⟩≡ (1948 2673)

```
# CALLING SEQUENCE FOR BLANKING
#               CAF     BITX            # X=1,2,3 BLANK R1,R2,R3 RESPECTIVELY
#               TC      BLANKET
#               ...     ...             # RETURN TO USER HERE
# IN ORDER TO USE BLANKET CORRECTLY, THE USER MUST USE A DISPLAY ROUTINE THAT ENDS IN R FIRST F
# TO BLANKET AT THE IMMEDIATE RETURN LOC.
                BLOCK   02
                SETLOC  FFTAG4
                BANK

                COUNT   02/DSPLA

BLANKET         TS      MPAC +6
                CS      PLAYTEM4
                MASK    MPAC +6
                INDEX   MPAC +5
                ADS     PLAYTEM4

                TC      Q

ENDMARK         TC      POSTJUMP
                CADR    MARKEND

CLEARMRK        CAF     ZERO
                TS      EXTVBACT

                INHINT
                CS      BIT1
                MASK    FLAGWRD4
                TS      FLAGWRD4

                RELINT
                TC      Q

# *** ALL EXTENDED VERB ROUTINES THAT HAVE AT LEAST ONE FLASHING DISPLAY MUST TCF ENDMARK OR TC
# FINISHED.

                BANK    10
                SETLOC  DISPLAYS
                BANK

                COUNT   10/DSPLA

# NTERONLY IS USED TO DIFFERENTIATE THE MARK ROUTINE WITH ONLY ONE RETURN TO THE USER FROM THE
# 3 RETURNS TO THE USER.  THIS ROUTINE IS ONLY USED BY GOMARK1 AND GOMARK1R.
```

```
MARKEND         TC      CLEARMRK
                TCF     MARKOVER
```

Uses A 80, COUNT 142, DISPLAYS 59, EXTVBACT 154, FFTAG4 57, FLAGWRD4 109, LOC 145, MPAC 145, Q 80, R2 188, and TC 169.

1965 ⟨*Page CM1466* 1965⟩≡ (1948 2673)

```
GOMARK          TS      PLAYTEM1        # ENTRANCE FOR MARK GODSP

GOMARS          CAF     BIT15           # BIT15 SET FOR ALL MARK REQUESTS
                TCF     GOFLASH2

KLEENEX         CAF     ZERO            # CLEAN OUT EXTENDED VERBS
GOMARKF         TS      PLAYTEM1        # ENTRANCE FOR MARK GOFLASH

                CAF     MARKFMSK        # MARK, FLASH
                TCF     GOFLASH2

GOMARK2         TS      PLAYTEM1        # MARK GOPERFS-3 AST. RETURNS
MARKFORM        CAF     MPERFMSK        # MARK, PERFORM, FLASH
                TCF     GOFLASH2

GOMARK3         TS      PLAYTEM1        # USED FOR 3COMP DECIMAL PERFORM
                CAF     MARK3MSK
                TCF     GOFLASH2

GOMARK4         TS      PLAYTEM1
                CAF     MARK4MSK        # MARK,PERFORM,FLASH,BLANK
                TCF     GOFLASH2

GOMARKR         TS      PLAYTEM1        # ENTRANCE FOR MARK GODSPR

                CAF     BIT15
                TCF     GODSPR2

GOMARKFR        TS      PLAYTEM1        # ENTRANCE FOR MARK GOFLASHR

                CAF     MARKFMSK
                TCF     GODSPRS

GOMARK2R        TS      PLAYTEM1        # MARK GOPERFS-3 AST. RETS+ IMMEDIATE RET.
                CAF     MPERFMSK        # MARK, PERFORM, FLASH
                TCF     GODSPRS

GOMARK3R        TS      PLAYTEM1
                CAF     MARK3MSK
                TCF     GODSPRS

MAKEMARK        CAF     ONE
                TC      COPIES

                CA      FLAGWRD4        # IS NORM OR PRIO BUSY OR WAITING
```

```
MASK    OCT34300
CCS     A
TCF     CHKPRIO

CA      FLAGWRD4        # IS MARK SLEEPING DUE TO ASTRO BUSY?
```

Uses `A` 80, `FLAGWRD4` 109, and `TC` 169.

1967 ⟨*Page CM1467* 1967⟩≡ (1948 2673)

```
                MASK    BIT9

                EXTEND
                BZF     MARKPLAY        # NO

                TCF     ENDOFJOB

MARKPLAY        INHINT
                CS      FIVE            # RESET MARK OVER NORM, SET MARK
                MASK    FLAGWRD4
                AD      ONE
                TS      FLAGWRD4
                RELINT

GOGOMARK        CS      MARKFLAG        # PERFORM
                MASK    BIT5
                CCS     A
                TCF     MARKCOP
                CS      MARKNV
                TS      MARKNV

MARKCOP         CAF     ONE             # MARK INDEX
                TCF     PRIOPLAY

COPYTOGO        CA      MPAC2SAV
                TS      MPAC +2

COPYPACS        INDEX   COPINDEX
                CAF     PRIOOCT
                TS      GENMASK

                INDEX   COPINDEX
                CA      EBANKSAV        # Was CAF --- RSB 2004.
                TS      TEMPOR2         # ACTIVE EBANK AND FLAG

                TS      EBANK

                TC      Q

# PINCHEK CHECKS TO SEE IF THE CURRENT MARK REQUEST IS MADE BY THE ASTRONAUT WHILE INTERRUPTING
# (A NORMAL OR A PRIO).  IF THE ASTRONAUT TRIES TO MARK DURING A PRIO, THE CHECK FAIL LIGHT GOE
# REQUEST IS ENDED.  IF HE TRIES TO MARK DURING A NORM, THE MARK IS ALLOWED.  IN THIS CASE THE
# UNTIL ALL MARKING IS FINISHED.
#
# IF THE MARK REQUEST COMES FROM THE PROGRAM DURING A TIME THE ASTRONAUT IS NOT INTERRUPTING A
```

```
# PRIO, THE MARK REQUEST IS PUT TO SLEEP UNTIL THE PRESENT ACTIVE DISPLAY IS RESPONDE

CHKPRIO         CA      FLAGWRD4        # MARK ATTEMPT DURING PRIO
                MASK    OCT24100
                CCS     A
                TCF     MARSLEEP
```

Uses A 80, EBANK 80, EBANKSAV 156, FLAGWRD4 109, MARKNV 150, MPAC 145, Q 80, and TC 169.

1969 ⟨*Page CM1468* 1969⟩≡ (1948 2673)

```
                CS      FLAGWRD4
                MASK    BIT3            # SET MARK OVER NORM
                INHINT
                ADS     FLAGWRD4

                TCF     SETNORM

MARKPERF        CA      MARKNV
                MASK    VERBMASK
                TCF     NV50DSP

GODSP           TS      PLAYTEM1

GODSP2          CAF     ZERO
                TCF     GOFLASH2

GODSPRET        TS      PLAYTEM1        # ENTRANCE FOR A GODSP WITH A PASTE

                CAF     BIT6            # SET BIT6 TO GO BACK TO USER AFTER NVSUB
                TCF     GOFLASH2

GODSPR          TS      PLAYTEM1

GODSPR1         CAF     ZERO
GODSPR2         TS      PLAYTEM4

                CAF     ZERO            # * DON'T MOVE
                TCF     GODSPRS1

# CLEANDSP IS USED FOR CLEARING OUT A NORMAL DISPLAY THAT IS PRESENTLY ACTIVE OR A NORMAL DISPL
# SET UP TO BE STARTED OR RESTARTED.
#
# NORMALLY THE USER WILL NOT NEED TO USE THIS ROUTINE SINCE A NEW NORMAL DISPLAY AUTOMATICALLY
# OLD DISPLAY.
#
# CALLING SEQUENCE FOR CLEANDSP --
#
#               TC      BANKCALL
#               CADR    CLEANDSP

CLEANDSP        CAF     ZERO
REFLASH         TS      PLAYTEM1

                CAF     REDOMASK        # FLASH AND PERMIT
                TCF     GOFLASH2
```

```
REGODSP         TS      PLAYTEM1

                CAF     BIT14
                TCF     GOFLASH2
```

Uses `A` 80, `FLAGWRD4` 109, `MARKNV` 150, and `TC` 169.

1971 ⟨*Page CM1469* 1971⟩≡ (1948 2673)

```
REGODSPR        TS      PLAYTEM1
                CAF     BIT14
                TCF     GODSPR2

CLOCPLAY        TS      PLAYTEM1
                CAF     CLOCKCON
                TCF     GOFLASH2
GOFLASH         TS      PLAYTEM1

                CAF     BIT4            # LEAVE ONLY FLASH BIT SET
GOFLASH2        TS      PLAYTEM4

                TC      SAVELOCS

                RELINT

                TCF     MAKEPLAY        # BRANCH DIRECT WITH NO SEPARATE JOB CALL

PRIODSPR        TS      PLAYTEM1

                CAF     BITS7+4
                TCF     GODSPRS

PRIODSP         TS      PLAYTEM1

SETPRIO         CAF     BITS7+4
                TCF     GOFLASH2

MAKEPRIO        CAF     ZERO
                TS      COPINDEX

                TC      LINUSCHR
                TCF     HIPRIO          # LINUS RETURN
                CA      FLAGWRD4
                MASK    OCT20100        # IS PRIO IN ENDIDLE OR BUSY
                CCS     A
                TCF     PRIOBORT        # YES, ABORT

HIPRIO          CA      FLAGWRD4        # MARK ACTIVE
                MASK    OCT40400
                EXTEND
                BZF     ASKIFNRM        # NO

SETMARK         CAF     ZERO
```

```
                TCF     JOBXCHS

  ASKIFNRM      CA      FLAGWRD4        # NORMAL ACTIVE
                MASK    OCT10200        # BITS 13+8
                EXTEND
```

Uses `A` 80, `FLAGWRD4` 109, and `TC` 169.

1973 ⟨*Page CM1470* 1973⟩≡ (1948 2673)

```
                BZF     OKTOCOPY        # NO

SETNORM         CAF     ONE
                TCF     JOBXCHS

OKTOCOPY        TC      COPYNORM
                TC      WITCHONE

                TC      JOBWAKE

                TC      XCHTOEND

REDOPRIO        CA      TIME1           # SAVE TIME PRIODSP SENT OUT
                TS      PRIOTIME

KEEPPRIO        CAF     ZERO            # START UP PRIO DISPLAY
                TCF     PRIOPLAY

MAKEPLAY        CA      PRIORITY        # SAVE USER'S PRIORITY
                MASK    PRIO37
                TS      USERPRIO

                CAF     PRIO33          # RAISE PRIORITY FOR FAST JOBS AFTER WAKE
                TC      PRIOCHNG

                CA      PLAYTEM4        # IS IT MARK OR PRIO OR NORM
                MASK    BITS15+7
                CCS     A
                TCF     MAKEPRIO        # ITS PRIO
                TCF     IFLEGAL
                TCF     MAKEMARK        # ITS MARK

IFLEGAL         CAF     TWO
                TS      COPINDEX

                TC      LINUSCHR

                TCF     OKTOPLAY        # LINUS RETURN
                CS      EBANKTEM
                MASK    BIT4
                CCS     A
                TCF     OKTOPLAY        # NO

                CA      FLAGWRD4        # WAS NORM ASLEEP
                MASK    NBUSMASK        # ARE ANY NORMS ASLEEP
```

```
                EXTEND
                BZF     OKTOPLAY        # NO

PRIOBORT        TC      POODOO
                OCT     1502
```

Uses A 80, EBANKTEM 156, FLAGWRD4 109, IT 185, PRIORITY 145, PRIOTIME 157, SAVE 191, TC 169, and TIME1 80.

1975 ⟨*Page CM1471* 1975⟩≡ (1948 2673)

```
OKTOPLAY        TC      COPIES2

                CA      USERPRIO
                EXTEND
                ROR     SUPERBNK
                TS      RESTREG

                CA      FLAGWRD4        # PRIO OR MARK GOING
                MASK    PMMASK
                CCS     A
                TCF     GOSLEEPS        # MARK GOING

                TCF     +2
                TCF     GOSLEEPS

# COULD PUT NORM BUSY CHECK HERE TO SAVE TIME

                TC      WITCHONE        # IS IT NVSUB BUSY, ENDIDLE OR NOONE
                TC      JOBWAKE

                TC      XCHTOEND

PLAYJUM1        CAF     TWO
PRIOPLAY        TS      COPINDEX

                TCF     GOPLAY

EXDSPRET        TS      PLAYTEM1

                CAF     BIT15+6
                TCF     GOFLASH2

GOPERF1         TS      NORMTEM1        # STORE DESIRED CHECKLIST VALUE
                CAF     V01N25          # USED TO DISPLAY CHECKLIST VALUE IN R1

GOPERFS         TS      PLAYTEM1

                CAF     PERFMASK        # LEAVE ONLY FLASH, PERFORM, BLANKING
                TCF     GOFLASH2

GOPERF2         TS      PLAYTEM1        # DESIRED VERB-NOUN TO DISPLAY R1,R2,R3

                CAF     PERF2MSK
                TCF     GOFLASH2
```

```
GOPERF4         TC      PURRS4

                TCF     GOFLASH2

GOFLASHR        TS      PLAYTEM1
```

Uses A 80, FLAGWRD4 109, IT 185, NORMTEM1 154, R2 188, RESTREG 150, SAVE 191, SUPERBNK 87, and TC 169.

1977 ⟨*Page CM1472* 1977⟩≡ (1948 2673)

```
                CAF     BIT4            # LEAVE ONLY FLASH BIT SET
GODSPRS         TS      PLAYTEM4

                CAF     THREE

GODSPRS1        INHINT                  # IMMEDIATE RETURN IS CALL CADR +4
                TS      RUPTREG3

                CA      PRIORITY        # MAKE DISPLAY ONE HIGHER THAN USER
                MASK    PRIO37
                TS      NEWPRIO

                CA      PLAYTEM4        # IS THIS A FLASHING R DISPLAY
                MASK    BIT4
                CCS     A
                TCF     VACDSP          # YES, MAKE DSPLAY JOB A VAC
                CA      NEWPRIO         # NO, MAKE DSPLAY JOB A NOVAC
                TC      NOVAC
                EBANK=  WHOCARES
                2CADR   MAKEPLAY

                TCF     BOTHJOBS

VACDSP          CA      BBANK
                EXTEND
                ROR     SUPERBNK
                TS      L
                CAF     MAKEGEN
                TC      SPVAC

BOTHJOBS        TC      SAVELOCS        # COPY TEMPS INTO PERMANENT REGISTERS

                EXTEND                  # SAVE NVWORD AND USER'S MPAC +2
                DCA     MPAC +1
                INDEX   LOCCTR
                DXCH    MPAC +1

                EXTEND                  # SAVE USER'S CADR, FLAGS AND EBANK
                DCA     MPAC +3
                INDEX   LOCCTR
                DXCH    MPAC +3

                CA      LOCCTR
                TS      MPAC +5
                TC      SAVELOCR
```

```
                RELINT
                TCF     BANKJUMP        # CALL CADR +4
```

Uses A 80, BBANK 80, EBANK 80, L 80, LOCCTR 138, MPAC 145, NEWPRIO 138, NVWORD 150, PRIORITY 145, RUPTREG3 138, SAVE 191, SUPERBNK 87, TC 169, and WHOCARES 244.

1979 ⟨*Page CM1473* 1979⟩≡ (1948 2673)

```
GOPERF1R        TS      NORMTEM1        # DESIRED CHECKLIST VALUE

                CAF     V01N25          # DISPLAYS CHECKLIST VALUE IN R1

GOPERFRS        TS      PLAYTEM1

                CAF     PERFMASK        # LEAVE ONLY FLASH, PERFORM, BLANKING
                TCF     GODSPRS

GOPERF2R        TS      PLAYTEM1        # DESIRED VERB-NOUN TO DISPLAY R1,R2,R3

                CAF     PERF2MSK
                TCF     GODSPRS

GOPERF4R        TC      PURRS4

                TCF     GODSPRS

PURRS4          TS      OPTION1         # DESIRED OPTION CODE

                CAF     V04N06
                TS      PLAYTEM1

                CAF     PERF4MSK        # FLASH, PERFORM AND EBANK R3
                TC      Q

SAVELOCS        INHINT

                CS      OCT3400         # EBANK BITS
                MASK    PLAYTEM4
                AD      EBANK
                TS      PLAYTEM4

SAVELOCR        LXCH    Q

                TC      MAKECADR
                TS      PLAYTEM3

                AD      RUPTREG3        # NOT USED FOR NON R ROUTINES
                TC      L

COPYNORM        CAF     ZERO
COPIES          TS      COPINDEX
COPIES2         INHINT
                CA      PLAYTEM4        # FLAGWORD
```

```
INDEX   COPINDEX
TS      EBANKSAV        # EQUIV TO DSPFLG
MASK    CADRMASK        # FLASH AND GODSPRET
EXTEND
```

Uses CODE 140, DISPLAYS 59, EBANK 80, EBANKSAV 156, L 80, NORMTEM1 154, OPTION1 157, Q 80, R2 188, RUPTREG3 138, and TC 169.

1981 ⟨*Page CM1474* 1981⟩≡ (1948 2673)

```
                BZF     SKIPADD

                CA      PLAYTEM3
                INDEX   COPINDEX
                TS      CADRFLSH

SKIPADD         CA      PLAYTEM1        # VERB NOUN
                INDEX   COPINDEX
                TS      NVWORD

                TCF     RELINTQ

GOSLEEPS        INDEX   COPINDEX
                CA      PRIOOCT
                MASK    WAITMASK
                TC      UPENT2
WAITMASK        OCT     3004
                CS      ONE
                AD      COPINDEX
                TS      FACEREG

XCHSLEEP        INDEX   FACEREG
                CAF     WAKECADR
                INHINT
                TC      JOBWAKE         # FIND CADR IN JOB AREA

                TC      XCHTOEND        # CAUSES AWAKENED JOB TO GO TO ENDOFJOB

                INDEX   FACEREG         # REPLACE SAME CADR BUT NEW JOB AREA
                CAF     WAKECADR
                TCF     JOBSLEEP

JOBXCHS         TS      FACEREG         # CONTROLS TYPE OF DISPLAY PUT TO SLEEP
                TC      WITCHONE
                TC      JOBWAKE
                CA      FACEREG
                INDEX   LOCCTR
                TS      FACEREG

                CAF     XCHQADD
                TC      XCHNYLOC

                INDEX   FACEREG
                CA      MARKOCT
                MASK    IDLESLEP
```

```
                TC      DOWNENT2
IDLEMASK        OCT     74004           # * DON'T MOVE
                INDEX   FACEREG         # BIT SHOWS PRIO INTERRUPTED NORM OR MARK
                CA      BIT5            # BIT5 FOR MARK, BIT4 FOR NORMAL
```

Uses CADRFLSH 150, LOCCTR 138, NVWORD 150, and TC 169.

1983 ⟨*Page CM1475* 1983⟩≡ (1948 2673)

```
                AD      FOUR
                TC      UPENT2          # FLAG ROUTINE DOES RELINT
XCHQADD         GENADR  XCHSLEEP        # * DON'T MOVE
                CA      FLAGWRD4
                MASK    BIT3            # MARK OVER NORM?
                CCS     A
GENMARK         TC      MARKPLAY        # USED AS GENADR FOR JOBWAKE
                TCF     OKTOCOPY

MARKWAKE        CAF     ZERO
WAKEPLAY        TS      TEMPOR2

                INDEX   TEMPOR2
                CA      BITS5+11
                AD      FOUR
                TC      DOWNENT2
MARKFMSK        OCT     40010           # *** DON'T MOVE

                INDEX   TEMPOR2
                CAF     WAKECADR
                INHINT
                TC      JOBWAKE

                TCF     ENDRET

# ALL .1 RESTARTS BRANCH DIRECTLY TO INITDSP.  NORMAL DISPLAYS ARE THE ONLY DISPLAYS ALLOWED TO
# INITDSP FIRST RESTORES THE EBANK AND THE SUPERBANK TO THE MOST RECENT NORMAL EBANK AND SUPERE
#
# IF THE MOST RECENT NORMAL DISPLAY REQUEST WAS NOT FINISHED, CONTROL IS SENT BACK TO THE LAST
# OTHERWISE THE NORMAL DISPLAY SET UP IN THE NORMAL DISPLAY REGS IS STARTED UP IMMEDIATELY.

INITDSP         CA      EBANKTEM        # RESTORE MOST RECENT NORMAL EBANK
                TS      EBANK

                CA      RESTREG         # SUPERBANK AND JOB PRIORITY
                TC      SUPERSW         # RESTORE SUPERBANK

                MASK    PRIO37
                TC      PRIOCHNG

                CS      THREE
                AD      TEMPFLSH
                TCF     BANKJUMP

PINBRNCH        RELINT                  # FOR GOPIN USERS
```

```
CA      MARK2PAC        # NEEDED TO SAVE MPAC +2 FOR MARK USERS
TS      MPAC +2         # ONLY

CA      FLAGWRD4        # PINBRANCH CONDITION
MASK    PINMASK
CCS     A
```

Uses A 80, DISPLAYS 59, EBANK 80, EBANKTEM 156, FLAGWRD4 109, MARK2PAC 156, MPAC 145, PRIORITY 145, RESTREG 150, SAVE 191, TC 169, and TEMPFLSH 150.

1985 ⟨*Page CM1476* 1985⟩≡ (1948 2673)

```
                TCF     +3
                TCF     ERASER          # ** NOTHING IN ENDIDLE
                TCF     MARKPLAY

NORMBNCH        TC      UPFLAG          # SET PINBRANCH BIT
                ADRES   PINBRFLG

                CAF     BIT14           # PRIO INTERRUPTED
                MASK    FLAGWRD4
                CCS     A
                TCF     KEEPPRIO

                TCF     PLAYJUM1

NVDSP           TC      COPYPACS

                CA      TEMPOR2         # SET UP BLANK BITS FOR NVMONOPT IN CASE
                MASK    SEVEN           # USER REQUESTS BLANKING MONITOR
                TS      L

                CS      BIT13
                INDEX   COPINDEX
                MASK    DSPFLG
                INDEX   COPINDEX
                TS      DSPFLG

                MASK    BIT8            # BIT8 SET IF DEC MARK PERFORM DISPLAY
                TS      TEM1

                CA      MPAC +2
                TS      MPAC2SAV

                TS      MARK2PAC        # * FOR DISK ONLY *
                INDEX   COPINDEX
                CCS     NVWORD
                TCF     NVDSP1
                TCF     CLEANEND
                CS      MARKNV
                TS      MARKNV          # IN CASE MARKPLAY AWAKENED AFTER SLEEPING
                MASK    LOW7
                AD      V05N00M1
                AD      TEM1
NVDSP1          AD      ONE
NV50DSP         TC      NVMONOPT
                TCF     REST            # IF BUSY
```

```
TC      FLASHOFF        # IN CASE OF EXTENDED VERB NON-FLASH

TC      COPYTOGO        # MPACS DESTROYED BY NVSUB
TC      DOWNFLAG        # UNSET SLEEPING BITS
ADRES   MRKNVFLG
```

Uses A 80, FLAGWRD4 109, L 80, MARK2PAC 156, MARKNV 150, MPAC 145, MRKNVFLG 111, NVWORD 150, PINBRFLG 111, TC 169, and TEM1 142.

1987 ⟨*Page CM1477* 1987⟩≡ (1948 2673)

```
                TC      DOWNFLAG
                ADRES   NRMNVFLG
                TC      DOWNFLAG
                ADRES   PRONVFLG
BLANKCHK        CA      TEMPOR2         # BLANK BITS 1,2,3 IF SET
                TC      BLANKSUB
                TCF     NVDSP
PERFCHEK        CAF     BIT5            # BIT 5 FOR PERFORM
                MASK    TEMPOR2
                CCS     A               # IS THIS A GOPERF DISPLAY
                TCF     1STOR2ND        # YES

GOANIDLE        CAF     BIT4
                MASK    TEMPOR2
                CCS     A
                TCF     FLASHSUB        # IT IS

                CS      TEMPOR2         # IS THIS A GODSPRET
                MASK    BIT6
                CCS     A
                TCF     ISITN00

                INDEX   COPINDEX
                CA      CADRFLSH
                TS      MPAC +3
                TCF     ENDIT

ISITN00         INDEX   COPINDEX        # IS THIS A PASTE
                CA      NVWORD
                MASK    LOW7            # CHECK MADE FOR PINBRNCH AND PRIO ON MARK
                EXTEND
                BZF     FLASHSUB        # YES, ASSUME PASTE ALWAYS ON FLASH

                TCF     ENDOFJOB        # NOT FLASH, NOT GOPERF, THEREFORE EXIT

1STOR2ND        CA      TEMPOR2
                MASK    BIT13
                CCS     A
                TCF     GOANIDLE        # SECOND

                CA      BIT13
                INDEX   COPINDEX
                ADS     DSPFLG

                ZL
```

```
EXTEND                  # IS IT MARK
BZMF    MARKPERF        # YES
MASK    BIT12
EXTEND
```

Uses A 80, CADRFLSH 150, IT 185, MPAC 145, NRMNVFLG 111, NVWORD 150, PRONVFLG 111, and TC 169.

1989 ⟨*Page CM1478* 1989⟩≡ (1948 2673)

```
                BZF     V50PASTE
                CS      NVWORD1         # NVOWRD1= -0 IS V97.  NVWORD1= -400 IS V99
                AD      V97N00
                TCF     NV50DSP
V50PASTE        CAF     V50N00
                TCF     NV50DSP         # DISPLAY SECOND PART OF GOPERF

WITCHONE        CS      BIT5            # TURN OFF KEY RELEASE LIGHT
                EXTEND
                WAND    DSALMOUT

                CA      FLAGWRD4
                MASK    NVBUSMSK        # IS IT NVSUB ALEEP
                CCS     A
                CAF     ONE
                TS      L
                CAF     ZERO
                INDEX   L
                XCH     CADRSTOR

                INHINT
                TC      Q

XCHTOEND        CAF     ENDINST         # TC ENDOFJOB REPLACES GENADR IN LOC FOR
XCHNYLOC        XCH     LOCCTR          # WAS THIS ADDRESS SLEEPING
                EXTEND
                BZMF    RELINTQ         # NO
                XCH     LOCCTR          # YES
                INDEX   LOCCTR
                TS      LOC

RELINTQ         RELINT
                TC      Q               # BACK TO USER

CLEANEND        CAF     PRIO32          # ONE LOWER THAN DISPLAYS SLEEPING
                TC      FINDVAC
                EBANK=  NVSAVE
                2CADR   JAMTERM

                TCF     FLASHSUB +1

ISITPRIO        CA      FLAGWRD4
                MASK    ITISMASK        # IS PINBRFLG, MARKIDFLG SET
                EXTEND
                BZF     PRIOBORT
```

```
                TCF     ENDOFJOB
REST            CCS     CADRSTOR        # IS SOMEONE IN ENDIDLE
                TCF     ENDOFJOB        # YES
```

Uses A 80, CADRSTOR 154, DISPLAYS 59, DSALMOUT 87, EBANK 80, FLAGWRD4 109, IT 185, L 80, LOC 145, LOCCTR 138, NVSAVE 150, NVWORD1 157, PINBRFLG 111, Q 80, and TC 169.

1991 ⟨*Page CM1479* 1991⟩≡ (1948 2673)

```
                TCF     RESTSLEP

                TCF     ENDOFJOB

RESTSLEP        CA      GENMASK         # SET NVSLEEP BITS
                MASK    ASTROMSK
                TC      UPENT2
OCT24100        OCT     24100           # *** DON'T MOVE

                INDEX   COPINDEX
                CAF     NVCADR
                TC      NVSUBUSY        # BUSY OR ABORT IF ILLEGAL

FLASHSUB        TC      FLASHON

                CA      COPINDEX        # COPINDEX DESTROYED BY ENDIDLE
                TS      COPMPAC

                CA      GENMASK
                MASK    IDLEMASK
                TC      UPENT2
ITISMASK        OCT     40040           # *** ENDIDLE ALLOW *** DON'T MOVE

                CA      R1SAVE          # IS THIS A REPEAT AND RETURN DISPLAY
                INDEX   COPINDEX
                MASK    BIT3
                CCS     A
                TCF     UNSETR1         # YES

                CCS     CADRSTOR        # SEE IF SOMEONE ALREADY IN ENDIDLE
                TCF     ISITPRIO
                TCF     +2
                TCF     ISITPRIO

                TC      ENDIDLE
IDLERET1        TCF     TERMATE

                TCF     PROCEED         # ENDIDLE RETURNS HERE ON PROCEED

                CS      LOWLOAD
                AD      MPAC            # VERBREG
                EXTEND
                DIM     A
                EXTEND
                BZF     LOADITIS        # V21 OR V22 OR V23 ON DSKY
```

```
OKTOENT         CAF     TWO
ENDOUT          TS      OUTHERE
                CA      FLAGWRD4        # CHECK NATURE OF ENDIDLE RETURN
                MASK    OCT60000
```

Uses A 80, CADRSTOR 154, FLAGWRD4 109, MPAC 145, R1SAVE 156, TC 169, and VERBREG 152.

1993 ⟨*Page CM1480* 1993⟩≡ (1948 2673)

```
                CCS     A
                TCF     TIMECHEK        # PRIO ENDIDLE RETURN
                TCF     NORMRET         # NORMAL ENDIDLE RETURN
                TCF     MARKRET         # MARK ENDIDLE RETURN

TIMECHEK        CS      TIME1
                AD      PRIOTIME
                CCS     A
                COM
                AD      OCT37776
                AD      ONE
                AD      -2SEC
                EXTEND
                BZMF    KEEPPRIO

                TCF     NORMRET

NORMWAKE        CAF     ONE
                TCF     WAKEPLAY

ENDRET          CCS     OUTHERE
                AD      ONE
                TCF     +2              # NORMAL ENDIDLE EXIT
                TCF     ENDOFJOB
                INDEX   COPMPAC
                AD      CADRFLSH
                TS      MPAC +3

                CA      GENMASK         # REMOVE ENDIDLE AND PINBRANCH BITS
                MASK    PINIDMSK
                TC      DOWNENT2
PINIDMSK        OCT     74044           # *** DON'T MOVE

                CS      THREE           # BLANK EVERYTHING EXCEPT MM
                TC      NVSUB
                TCF     +1

ENDIT           CA      USERPRIO        # RETURN TO USER'S PRIORITY
                MASK    PRIO37
                TC      PRIOCHNG
                CA      MPAC +3
                TCF     BANKJUMP

UNSETR1         INDEX   COPINDEX        # RESET REPEAT AND RETURN REQUEST
                CS      BIT3
```

```
MASK    R1SAVE
TS      R1SAVE
CAF     ZERO            # *** 205 ONLY MARKBRAN USERS IN
TC      SUPERSW         # SUPERBANK 0
```

Uses A 80, CADRFLSH 150, MM 226, MPAC 145, PRIORITY 145, PRIOTIME 157, R1SAVE 156, TC 169, and TIME1 80.

1995 ⟨*Page CM1481* 1995⟩≡ (1948 2673)

```
        -1      CAF     THREE           # RETURN TO USER'S IMMEDIATE RETURN LOC
IMMEDRET        INDEX   COPINDEX
                AD      CADRFLSH
                TCF     BANKJUMP

TERMATE         CAF     ZERO            # ASTRONAUT TERMINATE (V34) RETURNS TO
                TCF     ENDOUT

LINUSCHR        CS      PLAYTEM4        # IS THIS A LINUS
                MASK    BIT14
                CCS     A
                TCF     Q+1             # NO
                CS      PLAYTEM3        # YES, IS IT ALREADY IN ENDIDLE
                INDEX   COPINDEX
                AD      CADRFLSH
                EXTEND
                BZF     +2              # YES

                TC      Q               # NO
                CCS     DSPLOCK         # IS THE ASTRONAUT BUSY
                TC      ENDOFJOB        # END THE NEW DISPLAY, IT'S ALREADY ACTIVE
                TC      Q

# MORE LOGIC COULD BE INCORPORATED HERE TO MAKE SURE A RECYCLE IS A RECYCLE AND CONVERSELY THAT

PROCEED         CAF     ONE             # ASTRONAUT PROCEED (V33) RETURNS
                TCF     ENDOUT

# LASTPLAY CHECKS TO SEE IF (1) THE LAST NORMAL DISPLAY WAS EITHER INTERRUPTED BY A PRIO OR A M
# COULD ONLY HAPPEN DURING PINBRANCH) OR IF (2) THE LAST NORMAL DISPLAY WAS REQUESTED WHILE A H
# DISPLAY WAS GOING, RESULTING IN THE NORMAL BEING PUT TO SLEEP.
#
# IF EITHER OF THE ABOVE 2 CONDITIONS EXISTS, THE NORMAL DISPLAY IS AWAKENED TO GO TO PLAYJUM1
# UP THE MOST RECENT VALID NORMAL DISPLAY.  IF THESE 2 CONDITIONS DO NOT EXIST, CONTROL GOES TO
# STARTED IMMEDIATELY WITH THE ASSUMPTION THAT THE MOST RECENT NORMAL DISPLAY IS ALREADY IN END
# PINBRNCH) OR THAT A RESTART HAS OCCURRED AND THE DISPLAY CAN BE STARTED AS A .1 RESTART.

MARKRET         CS      SIX
                MASK    FLAGWRD4
                INHINT                  # *** MAY MOVE DISPLAY FLAGWORD OUT OF
                TS      FLAGWRD4

                RELINT                  # INHINT REALM
                TCF     ENDRET
```

```
MARKOVER        CAF     MINUS1          # RUPTREG2 IS - MEANS ENDOFJOB TO ENDRET
                TS      OUTHERE
                CA      FLAGWRD4        # IS ENDIDFLG SET
                MASK    PRIO30          # IS NORMAL OR PRIO IN ENDIDLE
                CCS     A
```

Uses A 80, CADRFLSH 150, DSPLOCK 154, FLAGWRD4 109, IT 185, LOC 145, PRIORITY 145, Q 80, RESTART 57, RUPTREG2 138, and TC 169.

1997 ⟨*Page CM1482* 1997⟩≡ (1948 2673)

```
                TCF     NORMBNCH

NORMRET         CA      FLAGWRD4        # IS MARK SLEEPING
                MASK    BITS5+11        # OR WAITING
                CCS     A
                TCF     MARKWAKE

                CA      FLAGWRD4        # NO
                MASK    BITS4+10        # IS NORMAL INTERRUPTED OR WAITING
                CCS     A
                TCF     NORMWAKE        # YES

                CA      EBANKTEM        # NO, WAS IT A FLASH REQUEST
                MASK    OCT50           # OR A GODSPRET
                CCS     A
                TCF     ENDRET          # YES
                CA      NVSAVE
                EXTEND
                BZF     ENDRET

                CAF     PRIO15
                INHINT
                TC      NOVAC
                EBANK=  NVWORD
                2CADR   PLAYJUM1

                TCF     ENDRET

MARSLEEP        CA      FLAGWRD4        # IS MARK ALREADY ON
                MASK    BITS5+11
                CCS     A
                TCF     ENDOFJOB        # YES
                TCF     GOSLEEPS

LOADITIS        INDEX   COPMPAC
                CA      NVWORD
                MASK    LOW7
                COM
                AD      MPAC +1         # NOUNREG
                EXTEND
                BZF     OKTOENT         # NO, THEN LOAD IS VALID
                TCF     PINBRNCH        # YES, ACCEPT LOAD BUT ASK FOR LAST AGAIN

ERASER          CS      THREE           # BLANK EVERYTHING EXCEPT MM
                TC      NVSUB
```

```
                TCF     ENDOFJOB
                TCF     ENDOFJOB

PERFMASK        OCT     0036            # FLASH, PERFORM, BLANK R2 AND R3
```

Uses A 80, EBANK 80, EBANKTEM 156, FLAGWRD4 109, IT 185, MM 226, MPAC 145, NOUNREG 152, NVSAVE 150, NVWORD 150, R2 188, and TC 169.

1999 ⟨*Page CM1483* 1999⟩≡ (1948 2673)

```
V01N25          VN      00125
V06N07          VN      00607           # GOPERF3 VN DISPLAY BEFORE V50
V50N00          VN      5000
PERF2MSK        OCT     00030           # FLASH, PERFORM
V04N06          VN      00406
PERF4MSK        OCT     14              # FLASH, BLANK R3
GOAGIN          EQUALS  PINBRNCH
REDOMASK        OCT     20010           # BITS 4 AND 14
MARK3MSK        OCT     40230           # MARK, DECIMAL NOUN, PERFORM, FLASH
MARK4MSK        OCT     40036           # MARK, PERFORM, FLASH, BLANK 2 AND 3
NVCADR          CADR    REDOPRIO
WAKECADR        CADR    MARKPLAY
                CADR    PLAYJUM1

OCT3400         OCT     3400            # EBANK MASK
NBUSMASK        OCT     11210
PMMASK          OCT     66521
VERBMASK        =       MID7            # (OCT 37600)
V05N00M1        OCT     1177            # V05 MINUS ONE
GOXDSP          EQUALS  GOMARK
GOXDSPR         EQUALS  GOMARKR
GOXDSPF         EQUALS  GOMARKF
GOXDSPFR        EQUALS  GOMARKFR
ENDEXT          EQUALS  ENDMARK
MPAC2SAV        EQUALS  BANKSET
NVBUSMSK        OCT     700
ASTROMSK        OCT     704
MPERFMSK        OCT     40030           # BIT 15,5,4 FOR MARK,PERFORM,FLASH
OCT34300        OCT     34300
BITS15+7        OCT     40100
BITS7+4         OCT     110
DSPFLG          EQUALS  EBANKSAV
MARKFLAG        EQUALS  MARKEBAN
SAVEFLAG        EQUALS  EBANKTEM
BITS5+11        OCT     2020            # * DON'T MOVE
BITS4+10        OCT     1010            # * DON'T MOVE
LOWLOAD         DEC     22
BUSYMASK        OCT     77730
CADRMASK        OCT     50
PINMASK         EQUALS  13,14,15
GOPLAY          EQUALS  NVDSP
PRIOSAVE        EQUALS  R1SAVE
COPMPAC         EQUALS  MPAC +3
TEMPOR2         EQUALS  MPAC +4
OUTHERE         EQUALS  MPAC +5
```

```
COPINDEX        EQUALS  LOC
USERPRIO        EQUALS  MODE
GENMASK         EQUALS  MPAC +6
PRIOOCT         OCT     20144           # PRIO
MARKOCT         OCT     42424           # MARK
```

Uses BANKSET 145, EBANK 80, EBANKSAV 156, EBANKTEM 156, LOC 145, MARKEBAN 156, MODE 145, MPAC 145, R1SAVE 156, and VN 159.

2000a ⟨*Page CM1484* 2000a⟩≡ (1948 2673)

```
                OCT     11254           # NORM

IDLESLEP        OCT     74704
OCT67777        OCT     67777
LINUS           EQUALS  BLANKET
FACEREG         EQUALS  MPAC
PLAYTEM1        EQUALS  MPAC +1
PLAYTEM3        EQUALS  MPAC +3
PLAYTEM4        EQUALS  MPAC +4
OCT40420        OCT     40420
MAKEGEN         GENADR  MAKEPLAY
OCT10200        OCT     10200
V97N00          VN      09700           # PASTE FOR V97 OR V99
OCT20100        OCT     20100
CLOCKCON        OCT     24030
```

Uses MPAC 145 and VN 159.

3.7.25 service routines

2000b ⟨*service routines* 2000b⟩≡ (1523a 2803)
⟨*Page CM1485* 2001⟩

2001 ⟨*Page CM1485* 2001⟩≡ (2000b)

```
# Page 1485
                BLOCK   3
                SETLOC  FFTAG6
                BANK
                COUNT   03/FLAG

UPENT2          TS      L               # WHICH FLAGWORD IS IT
                MASK    OCT7
                XCH     L               # SAVE IN L FOR INDEXING

                MASK    OCT77770        # OBTAIN THE BIT INFORMATION
                INHINT                  # PREVENT INTERRUPTS
                TS      ITEMP1          # STORE THE BIT INFORMATION TEMPORARILY

                NDX     L
                CS      FLAGWRD0
                MASK    ITEMP1
                NDX     L
                ADS     FLAGWRD0
                RELINT                  # RELEASE INTERRUPT INHIBIT

                INCR    Q               # OBTAIN THE CORRECT RETURN ADDRESS
                TC      Q               # RETURN

DOWNENT2        TS      L               # WHICH FLAGWORD IS IT
                MASK    OCT7
                XCH     L               # SAVE IN L FOR INDEXING

                MASK    OCT77770        # OBTAIN THE BIT INFORMATION
                COM                     # START TO PROCESS THE INFORMATION

                INHINT                  # PREVENT INTERRUPTS
                NDX     L
                MASK    FLAGWRD0
                NDX     L
                TS      FLAGWRD0
                RELINT                  # RELEASE INTERRUPT INHIBIT

                INCR    Q               # OBTAIN THE CORRECT RETURN ADDRESS
                TC      Q

OCT7            EQUALS  SEVEN
                BANK    10

# Page 1486
```

```
# UPFLAG AND DOWNFLAG ARE ENTIRELY GENERAL FLAG SETTING AND CLEARING SUBROUTINES.  US
# NOT IN INTERRUPT, ONE MAY SET OR CLEAR ANY SINGLE, NAMED BIT IN ANY ERASABLE REGIST
# EBANK SETTING.  A "NAMED" BIT, AS THE WORD IS USED HERE, IS ANY BIT WITH A NAME FOR
# ASSEMBLER.
#
# AT PRESENT THE ONLY NAMED BITS ARE THOSE IN THE FLAGWORDS.  ASSEMBLER CHANGES WILL
# NAME ANY BIT IN ERASABLE MEMORY.
#
# CALLING SEQUENCES ARE AS FOLLOWS --
#               TC      UPFLAG                  TC      DOWNFLAG
#               ADRES   NAME OF FLAG            ADRES   NAME OF FLAG
#
# RETURN IS TO THE LOCATION FOLLOWING THE "ADRES" ABOUT .58 MS AFTER THE "TC".
# UPON RETURN A CONTAINS THE CURRENT FLAGWRD SETTING.

                BLOCK   02
                SETLOC  FFTAG1
                BANK
                COUNT*  $$/FLAG

UPFLAG          CA      Q
                TC      DEBIT
                COM                     # +(15 - BIT)
                EXTEND
                ROR     LCHAN           # SET BIT
COMFLAG         INDEX   ITEMP1
                TS      FLAGWRD0
                LXCH    ITEMP3
                RELINT
                TC      L

DOWNFLAG        CA      Q
                TC      DEBIT
                MASK    L               # RESET BIT
                TCF     COMFLAG

DEBIT           AD      ONE             # CET DE BITS
                INHINT
                TS      ITEMP3
                CA      LOW4            # DEC15
                TS      ITEMP1
                INDEX   ITEMP3
                CA      0 -1            # ADRES
                TS      L
                CA      ZERO
# Page 1487
```

```
                EXTEND
                DV      ITEMP1          # A = FLAGWRD, L = (15 - BIT)
                DXCH    ITEMP1
                INDEX   ITEMP1
                CA      FLAGWRD0
                TS      L               # CURRENT STATE
                INDEX   ITEMP2
                CS      BIT15           # -(15 - BIT)
                TC      Q

# Page 1488
# DELAYJOB -- A GENERAL ROUTINE TO DELAY A JOB A SPECIFIC AMOUNT OF TIME BEFORE PICKING UP AGAI
#
# ENTRANCE REQUIREMENTS ...
#               CAF     DT              # DELAY JOB FOR DT CENTISECS
#               TC      BANKCALL
#               CADR    DELAYJOB

                BANK    06
                SETLOC  DLAYJOB
                BANK

# THIS MUST REMAIN IN BANK 0 ****************************************

                COUNT   00/DELAY

DELAYJOB        INHINT
                TS      Q               # STORE DELAY DT IN Q FOR DLY -1 IN
                CAF     DELAYNUM        # WAITLIST
DELLOOP         TS      RUPTREG1
                INDEX   A
                CA      DELAYLOC        # IS THIS DELAYLOC AVAILABLE
                EXTEND
                BZF     OK2DELAY        # YES

                CCS     RUPTREG1        # NO, TRY NEXT DELAYLOC
                TCF     DELLOOP

                TC      BAILOUT         # NO AVAILABLE LOCS.
                OCT     1104

OK2DELAY        CA      TCSLEEP         # SET WAITLIST IMMEDIATE RETURN
                TS      WAITEXIT

                CA      FBANK
                AD      RUPTREG1        # STORE BBANK FOR TASK CALL
```

```
                TS      L

                CAF     WAKECAD         # STORE CADR FOR TASK CALL
                TCF     DLY2 -1         # DLY IS IN WAITLIST ROUTINE

TCGETCAD        TC      MAKECADR        # GET CALLER'S FCADR

                INDEX   RUPTREG1
                TS      DELAYLOC        # SAVE DELAY CADRS

                TC      JOBSLEEP

WAKER           CAF     ZERO
                INDEX   BBANK
                XCH     DELAYLOC        # MAKE DELAYLOC AVAILABLE
# Page 1489
                TC      JOBWAKE

                TC      TASKOVER

TCSLEEP         GENADR  TCGETCAD -2
WAKECAD         GENADR  WAKER

# Page 1490
# GENTRAN, A BLOCK TRANSFER ROUTINE
# WRITTEN BY D. EYLES
# MOD 1 BY KERNAN                                UTILITYM REV 17 11/18/67
# MOD 2 BY SCHULENBERG -- (REMOVE RELINT) -- SKIPPER REV 4 2/28/68
#
# THIS ROUTINE IS USEFUL FOR TRANSFERRING N CONSECUTIVE ERASABLE OR FIXED QUANTITIES
# CONSECUTIVE ERASABLE LOCATIONS.  IF BOTH BLOCKS OF DATA ARE IN SWITCHABLE EBANKS, T
#
# GENTRAN IS CALLABLE IN A JOB AS WELL AS A RUPT.  THE CALLING SEQUENCE IS:
#       I       CA      N-1             # NO. NUMBER OF QUANTITIES MINUS ONE.
#       I +1    TC      GENTRAN         # IN FIXED-FIXED.
#       I +2    ADRES   L               # STARTING ADRES OF DATA TO BE MOVED.
#       I +3    ADRES   M               # STARTING ADRES OF DUPLICATION BLOCK.
#       I +4                            # RETURNS HERE.
#
# GENTRAN TAKES 25 MCT'S (300 MICROSECONDS) PER ITEM + 5 MCT'S (60 MICS) FOR ENTERING
# A, L, AND ITEMP1 ARE NOT PRESERVED.

                BLOCK   02
                SETLOC  FFTAG4
                BANK
```

```
                EBANK=  ITEMP1

                COUNT*  $$/TRAN

GENTRAN         INHINT
                TS      ITEMP1          # SAVE N-1
                INDEX   Q               # C(Q) = ADRES L.
                AD      0               # ADRES (L + N - 1).
                INDEX   A
                CA      0               # C(ABOVE).
                TS      L               # SAVE DATA.
                CA      ITEMP1
                INDEX   Q
                AD      1               # ADRES (M + N - 1).
                INDEX   A
                LXCH    0               # STUFF IT.
                CCS     ITEMP1          # LOOP UNTIL N-1 = 0.
                TCF     GENTRAN +1
                TCF     Q+2             # RETURN TO CALLER.

# Page 1491
# B5OFF         ZERO BIT 5 OF EXTVBACK, WHICH IS SET BY TESTXACT.
# MAY BE USED AS NEEDED BY ANY EXTENDED VERB WHICH HAS DONE TESTXACT

                COUNT*  $$/EXTVB

B5OFF           CS      BIT5
                MASK    EXTVBACT
                TS      EXTVBACT
                TC      ENDOFJOB

# Page 1492
# SUBROUTINES TO TURN OFF AND TURN ON TRACKER FAIL LIGHT.

TRFAILOF        INHINT
                CS      OCT40200        # TURN OFF TRACKER LIGHT
                MASK    DSPTAB +11D
                AD      BIT15
                TS      DSPTAB +11D
                CS      OPTMODES        # TO INSURE THAT OCDU FAIL WILL GO ON
                MASK    BIT7            # AGAIN IF IT WAS ON IN ADDITION TO
                ADS     OPTMODES        # TRACKER FAIL.

REQ             RELINT
                TC      Q
```

```
TRFAILON        INHINT
                CS      DSPTAB  +11D    # TURN ON
                MASK    OCT40200
                ADS     DSPTAB +11D
                TCF     REQ
```

Uses A 80, BBANK 80, COUNT 142, D 226, DELAYLOC 157, DELAYNUM 73, DLAYJOB 57, DSPTAB 154, DV 241, EBANK 80, EXTVBACT 154, FBANK 80, FFTAG1 57, FFTAG4 57, FFTAG6 57, FLAGWRD0 95, I 206, IT 185, ITEMP1 138, ITEMP2 138, ITEMP3 138, L 80, LCHAN 87, N 206, OPTMODES 163, Q 80, RUPTREG1 138, SAVE 191, STATE 138, TC 169, and WAITEXIT 138.

3.7.26 alarm and abort

2006 ⟨*alarm and abort* 2006⟩≡ (1523a)

⟨*Page CM1493* 2007⟩
⟨*Page CM1494* 2009⟩
⟨*Page CM1495* 2011⟩
⟨*Page CM1496* 2013⟩

2007 ⟨*Page CM1493* 2007⟩≡ (2006 2640)

```
#       THE FOLLOWING SUBROUTINE MAY BE CALLED TO DISPLAY A NON-ABORTIVE ALARM CONDITION. IT MA
# EITHER IN INTERRUPT OR UNDER EXECUTIVE CONTROL.
#
#       THE CALLING SEQUENCE IS AS FOLLOWS:
#               TC      ALARM
#               OCT     NNNNN
#                                       # (RETURNS HERE)

                BLOCK   02
                SETLOC  FFTAG7
                BANK

                EBANK=  FAILREG

                COUNT   02/ALARM

# ALARM TURNS ON THE PROGRAM ALARM LIGHT, BUT DOES NOT DISPLAY.

ALARM           INHINT

                CA      Q
ALARM2          TS      ALMCADR
                INDEX   Q
                CA      0
BORTENT         TS      L

PRIOENT         CA      BBANK
 +1             EXTEND
                ROR     SUPERBNK        # ADD SUPER BITS.
                TS      ALMCADR +1

LARMENT         CA      Q               # STORE RETURN FOR ALARM
                TS      ITEMP1

                CA      LOC
                TS      LOCALARM
                CA      BANKSET
                TS      BANKALRM

CHKFAIL1        CCS     FAILREG         # IS ANYTHING IN FAILREG
                TCF     CHKFAIL2        # YES TRY NEXT REG
                LXCH    FAILREG
                TCF     PROGLARM        # TURN ALARM LIGHT ON FOR FIRST ALARM

CHKFAIL2        CCS     FAILREG +1
```

```
                TCF     FAIL3
                LXCH    FAILREG +1
                TCF     MULTEXIT

FAIL3           CA      FAILREG +2
```

Uses A 80, ALMCADR 165, BANKALRM 85, BANKSET 145, BBANK 80, COUNT 142, EBANK 80, FAILREG 150, FFTAG7 57, IT 185, ITEMP1 138, L 80, LOC 145, LOCALARM 85, Q 80, SUPERBNK 87, and TC 169.

2009 ⟨*Page CM1494* 2009⟩≡ (2006 2640)

```
                MASK    POSMAX
                CCS     A
                TCF     MULTFAIL
                LXCH    FAILREG +2
                TCF     MULTEXIT

PROGLARM        CS      DSPTAB +11D
                MASK    OCT40400
                ADS     DSPTAB +11D

MULTEXIT        XCH     ITEMP1          # OBTAIN RETURN ADDRESS IN A
                RELINT
                INDEX   A
                TC      1

MULTFAIL        CA      L
                AD      BIT15
                TS      FAILREG +2

                TCF     MULTEXIT

# PRIOLARM DISPLAYS V05N09 VIA PRIODSPR WITH 3 RETURNS TO THE USER FROM THE ASTRONAUT AT CALL L
# AN IMMEDIATE RETURN TO THE USER AT CALL LOC +4. EXAMPLE FOLLOWS,
#               CAF     OCTXX           # ALARM CODE
#               TC      BANKCALL
#               CADR    PRIOLARM
#               ...     ...
#               ...     ...
#               ...     ...             # ASTRONAUT RETURN
#               TC      PHASCHNG        # IMMEDIATE RETURN TO USER. RESTART
#               OCT     X.1             # PHASE CHANGE FOR PRIO DISPLAY

                BANK    10
                SETLOC  DISPLAYS
                BANK

                COUNT   10/DSPLA

PRIOLARM        INHINT                  # * * * KEEP IN DISPLAY ROUTINES BANK
                TS      L               # SAVE ALARM CODE

                CA      BUF2            # 2 CADR OF PRIOLARM USER
                TS      ALMCADR
                CA      BUF2 +1
                TC      PRIOENT +1      # * LEAVE L ALONE
```

```
-2SEC           DEC     -200            # *** DONT MOVE
                CAF     V05N09
                TCF     PRIODSPR
```

Uses A 80, ALMCADR 165, BUF2 142, CODE 140, COUNT 142, DISPLAYS 59, DSPTAB 154, FAILREG 150, ITEMP1 138, L 80, LOC 145, RESTART 57, SAVE 191, and TC 169.

2011 ⟨*Page CM1495* 2011⟩≡ (2006 2640)

```
                BLOCK   02
                SETLOC  FFTAG13
                BANK

                COUNT   02/ALARM

BAILOUT         INHINT
                CA      Q
                TS      ALMCADR

                TC      BANKCALL
                CADR    VAC5STOR

                INDEX   ALMCADR
                CAF     0
                TC      BORTENT
OCT40400        OCT     40400

                INHINT
WHIMPER         CA      TWO
                AD      Z
                TS      BRUPT
                RESUME
                TC      POSTJUMP        # RESUME SENDS CONTROL HERE
                CADR    ENEMA

                SETLOC  FFTAG7
                BANK

P00DOO          INHINT
                CA      Q
                TS      ALMCADR

                TC      BANKCALL
                CADR    VAC5STOR        # STORE ERASABLES FOR DEBUGGING PURPOSES.

                INDEX   ALMCADR
                CAF     0
ABORT2          TC      BORTENT

OCT77770        OCT     77770           # DONT MOVE
                CA      V37FLBIT        # IS AVERAGE G ON
                MASK    FLAGWRD7
                CCS     A
```

```
TC      WHIMPER -1      # YES.  DONT DO POODOO.  DO BAILOUT.

TC      DOWNFLAG
ADRES   STATEFLG

TC      DOWNFLAG
```

Uses A 80, ALMCADR 165, BRUPT 80, COUNT 142, FFTAG13 57, FFTAG7 57, FLAGWRD7 121, Q 80, STATEFLG 107, TC 169, V37FLBIT 123, and Z 80.

2013 ⟨*Page CM1496* 2013⟩≡ (2006 2640)

```
                ADRES   REINTFLG

                TC      DOWNFLAG
                ADRES   NODOFLAG

                TC      BANKCALL
                CADR    MR.KLEAN
                TC      WHIMPER

CCSHOLE         INHINT
                CA      Q
                TS      ALMCADR
                TC      BANKCALL
                CADR    VAC5STOR
                CA      OCT1103
                TC      ABORT2
OCT1103         OCT     1103
CURTAINS        INHINT
                CA      Q
                TC      ALARM2
OCT217          OCT     00217
                TC      ALMCADR         # RETURN TO USER

DOALARM         EQUALS  ENDOFJOB
# CALLING SEQUENCE FOR VARALARM
#               CAF     (ALARM)
#               TC      VARALARM
#
# VARALARM TURNS ON PROGRAM ALARM LIGHT BUT DOES NOT DISPLAY
VARALARM        INHINT

                TS      L               # SAVE USERS ALARM CODE

                CA      Q               # SAVE USERS Q
                TS      ALMCADR

                TC      PRIOENT
OCT14           OCT     14              # DONT MOVE

                TC      ALMCADR         # RETURN TO USER

ABORT           EQUALS  BAILOUT         # *** TEMPORARY UNTIL ABORT CALLS OUT
```

Uses ALMCADR 165, CODE 140, L 80, NODOFLAG 105, Q 80, REINTFLG 135, SAVE 191, and TC 169.

3.7.27 update program

2014 ⟨*update program* 2014⟩≡ (1523a 2831)
⟨*Page CM1497* 2015⟩

2015 ⟨*Page CM1497* 2015⟩≡ (2014)

```
# Page 1497
# PROGRAM NAME:         P27
# WRITTEN BY:           KILROY/ DE WOLF
#
# MOD NO:               0
# MOD BY:               KILROY
# DATE:                 01DEC67
#
# LOG SECTION:          UPDATE PROGRAM.
#
# FUNCT. DESCR.:        P27 (THE UPDATE PROGRAM) PROCESSES COMMANDS AND DATA
#                       INSERTIONS REQUESTED BY THE GROUND VIA UPLINK.
#                       THE P27 PROGRAM WILL ACCEPT UPDATES
#                       ONLY DURING P00 FOR THE LM, AND ONLY DURING P00,
#                       P02, AND FRESH START FOR THE CSM.
#
# CALLING SEQ:          PROGRAM IS INITIATED BY UPLINK ENTRY OF VERBS 70, 71, 72, AND 73.
#
# SUBROUTINES:          TESTXACT, NEWMODEX, NEWMODEX +3, GOXDSPF, BANKCALL, FINDVAC, INTPRET, I
#                       INTWAKEU, ENDEXT, POSTJUMP, FALTON, NEWPHASE, PHASCHNG
#
# NORMAL EXIT:          TC ENDEXT
#
# ALARM/ABORT:          TC FALTON FOLLOWED BY TC ENDEXT
#
# RESTARTS:             P27 IS RESTART PROTECTED IN TWO WAYS ...
#                       1.      PRIOR TO VERIFLAG INVERSION (WHICH IS CAUSED BY THE GROUND/ASTR
#                               DATA BY SENDING A V33E WHEN V21N02 IS FLASHING)---
#                               NO PROTECTION EXCEPT PRE-P27 MODE IS RESTROED, COAST + ALIGN DO
#                               ACTIVITY LIGHT IS TURNED OFF.  (JUST AS IF A V34E WAS SENT DURI
#                               V70,V71,V72, OR V73 WILL HAVE TO BE COMPLETELY RESENT BY USER.
#                       2.      AFTER VERIFLAG INVERSION (WHEN UPDATE OF THE SPECIFIED ERASABLE
#                               PROTECTED AGAINST RESTARTS.
#
# DEBRIS:               UPBUFF  (20D)   TEMP STORAGE FOR ADDRESSES AND CONTENTS.
#                       UPVERB  (1)     VERB NUMBER MINUS 70D (E.G., FOR V72, UPVERB = 72D - 70
#                       UPOLDMOD(1)     FOR MAJOR MODE INTERRUPTED BY P27.
#                       COMPNUMB(1)     TOTAL NUMBER OF COMPONENTS TO BE TRANSMITTED.
#                       UPCOUNT (1)     ACTUAL NUMBER OF COMPONENTS RECEIVED.
#                       UPTEMP  (1)     SCRATCH, BUT USUALLY CONTAINS COMPONENT NUMBER TO BE CH
#
# INPUT:
#
#       ENTRY                   DESCRIPTION
#       V70EXXXXXXXXXXXXE       (LIFTOFF TIME INCREMENT) DOUBLE PRECISION OCTAL TIME INCREMENT,
```

```
#                               IS ADDED TO TEPHEM, SUBTRACTED FROM AGC CLOCK(TIME2,T
#                               VECTOR TIME(TETCSM) AND SUBTRACTED FROM LEM STATE VEC
#                               THE DP OCTAL TIME INCREMENT IS SCALED AT 2(28).
# Page 1498
#       V71EIIEAAAAE            (CONTIGUOUS BLOCK UPDATE) II-2 OCTAL COMPONENTS, XXXX
#       XXXXXE                  ARE LOADED INTO ERASABLE STARTING AT ECADR, AAAA.
#       XXXXXE                  IT IS .GE. 3 .AND. .LE. 20D.,
#                               AND (AAAA + II -3) DOES NOT PRODUCE AN ADDRESS IN THE
#       9 NEXT BANK
#         .                     SCALING IS SAME AS INTERNAL REGISTERS.
#       V72EIIE                 (SCATTER UPDATE) (II-1)/2 OCTAL COMPONENTS, XXXXX, AR
#       AAAAEXXXXXE             LOADED INTO ERASABLE LOCATIONS, AAAA.
#       AAAAEXXXXXE             II IS .GE. 3 .AND. .LE. 19D, AND MUST BE ODD.
#         .                     SCALING IS SAME AS INTERNAL REGISTERS.
#
#       V73EXXXXXEXXXXXE        (OCTAL CLOCK INCREMENT) DOUBLE PRECISION OCTAL TIME
#                               INCREMENT XXXXX XXXXX, IS ADDED TO THE AGC CLOCK, IN
#                               CENTISECONDS SCALED AT (2)28).
#                               THIS LOAD IS THE OCTAL EQUIVALENT OF V55.
#
# OUTPUT:               IN ADDITION TO THE ABOVE REGISTER LOADS, ALL UPDATES
#                       COMPLEMENT BIT3 OF FLAGWORD7.
#
# ADDITIONAL NOTES:     VERB 71, JUST DEFINED ABOVE WILL BE USED TO PERFORM BUT NOT I
#                       1.  CSM/LM STATE VECTOR UPDATE
#                       2.  REFSMMAT UPDATE
#
#       THE FOLLOWING COMMENTS DELINEATE EACH SPECIAL UPDATE ---
#
#       1.  CSM/LM STATE VECTOR UPDATE (ALL DATA ENTRIES IN OCTAL)
#               ENTRIES:        DATA DEFINITION:                                SCALI
#               V71E            CONTIGUOUS BLOCK UPDATE VERB
#                  21E          NUMBER OF COMPONENTS FOR STATE VECTOR UPDATE
#                 AAAAE         ECADR OF 'UPSVFLAG'
#               XXXXXE          STATE VECTOR IDENTIFIER: 00001 FOR CSM, 77776 FOR LEM
#                                                        00002 FOR CSM, 77775 FOR LEM
#               XXXXXEXXXXXE    X POSITION
#               XXXXXEXXXXXE    Y POSITION
#               XXXXXEXXXXXE    Z POSITION
#               XXXXXEXXXXXE    X VELOCITY
#               XXXXXEXXXXXE    Y VELOCITY
#               XXXXXEXXXXXE    Z VELOCITY
#               XXXXXEXXXXXE    TIME FROM AGC CLOCK ZERO
#               V33E            VERB 33 TO SIGNAL THAT THE STATE VECTOR IS READY TO B
#
#       2.  REFSMMAT (ALL DATA ENTRIES IN OCTAL)
```

```
#               ENTRIES         DATA DEFINITIONS                                SCALE FACTORS:
# Page 1499
#               V71E            CONTIGUOUS BLOCK UPDATE VERB
#                  24E          NUMBER OF COMPONENTS FOR REFSMMAT UPDATE
#                AAAAE          ECADR OF 'REFSMMAT'
#               XXXXXEXXXXXE    ROW 1 COLUMN 1                                  2(-1)
#               XXXXXEXXXXXE    ROW 1 COLUMN 2                                  2(-1)
#               XXXXXEXXXXXE    ROW 1 COLUMN 3                                  2(-1)
#               XXXXXEXXXXXE    ROW 2 COLUMN 1                                  2(-1)
#               XXXXXEXXXXXE    ROW 2 COLUMN 2                                  2(-1)
#               XXXXXEXXXXXE    ROW 2 COLUMN 3                                  2(-1)
#               XXXXXEXXXXXE    ROW 3 COLUMN 1                                  2(-1)
#               XXXXXEXXXXXE    ROW 3 COLUMN 2                                  2(-1)
#               XXXXXEXXXXXE    ROW 3 COLUMN 3                                  2(-1)
#               V33E            VERB 33 TO SIGNAL THAT REFSMMAT IS READY TO BE STORED

                BANK    07
                SETLOC  EXTVERBS
                BANK

                EBANK=  TEPHEM

                COUNT*  $$/P27
V70UPDAT        CAF     UP70            # COMES HERE ON V70E
                TCF     V73UPDAT +1

V71UPDAT        CAF     UP71            # COMES HERE ON V71E
                TCF     V73UPDAT +1

V72UPDAT        CAF     UP72            # COMES HERE ON V72E
                TCF     V73UPDAT +1

V73UPDAT        CAF     UP73            # COMES HERE ON V73E

        +1      TS      UPVERBSV        # SAVE UPVERB UNTIL IT'S OK TO ENTER P27

                TC      TESTXACT        # GRAB DISPLAY IF AVAILABLE, OTHERWISE
                                        # TURN *OPERATOR ERROR* ON AND TERMINATE JOB

                CA      MODREG          # CHECK IF UPDATE ALLOWED
                EXTEND                  # FIRST CHECK FOR MODREG = +0, -0
                BZF     +2              # (+0 = P00, -0 = FRESHSTART)
                TC      CKMDMORE        # NOW CHECK FOR PROGRAM WHICH CAN BE
                                        # INTERRUPTED BY P27.

                CAE     MODREG          # UPDATE ALLOWED
```

```
                TS      UPOLDMOD        # SAVE CURRENT MAJOR MODE
# Page 1500
                CAE     UPVERBSV        # SET UPVERB TO INDICDATE TO P27
                TS      UPVERB          # WHICH EXTENDED VERB CALLED IT.

                CAF     ONE
                TS      UPCOUNT         # INITIALIZE UPCOUNT TO 1

                TC      POSTJUMP        # LEAVE EXTENDED VERB BANK AND
                CADR    UPPART2         # GO TO UPDATE PROGRAM (P27) BANK.

CKMDMORE        CS      FLAGWRD5
                MASK    BIT8            # CHECK IF COMPUTER IS LGC
                CCS     A               # IS COMPUER LGC OR AGC
UPERLEM         TCF     UPERROR         # ERROR: IT'S THE LEM + MODE IS NOT P00.
                CS      TWO
                MASK    MODREG
                CCS     A
UPERCMC         TCF     UPERROR         # ERROR: IT'S THE CMC AND MODE IS NOT
                                        # P00 OR P02.
                TC      Q               # ALLOW UPDATE TO PROCEED.

UPERROR         TC      POSTJUMP        # TURN ON 'OPERATOR ERROR' LIGHT
                CADR    UPERROUT +2     # GO TO COMMON UPDATE PROGRAM EXIT

                SBANK=  LOWSUPER
UP70            EQUALS  ZERO
UP71            EQUALS  ONE
UP72            EQUALS  TWO
UP73            EQUALS  THREE

                BANK    04
                SETLOC  UPDATE2
                BANK

                COUNT*  $$/P27

UPPART2         EQUALS                  # UPDATE PROGRAM -- PART 2

                TC      PHASCHNG        # SET RESTART GROUP 6 TO RESTORE OLD MODE
                OCT     07026           # AND DOWNLIST AND EXIT IF RESTART OCCURS.
                OCT     30000           # PRIORITY SAME AS CHRPRIO
                EBANK=  UPBUFF
                2CADR   UPOUT +1

                CAF     ONE
```

```
                TS      DNLSTCOD        # DOWNLIST

                TC      NEWMODEX        # SET MAJOR MODE = 27
# Page 1501
                DEC     27

                INDEX   UPVERB          # BRANCH DEPENDING ON WHETHER THE UPDATE
                TCF     +1              # VERB REQUIRES A FIXED OR VARIABLE NUMBER
                TCF     +3              # V70 FIXED                (OF COMPONENTS)
                TCF     OHWELL1         # V71 VARIABLE -- GO GET NO. OF COMPONENTS
                TCF     OHWELL1         # V72 VARIABLE -- GO GET NO. OF COMPONENTS
                CA      TWO             # V73 (AND V70) FIXED
                TS      COMPNUMB        # SET NUMBER OF COMPONENTS TO 2.
                TCF     OHWELL2         # GO GET THE TWO UPDATE COMPONENTS

OHWELL1         CAF     ADUPBUFF        # * REQUEST USER TO SEND NUMBER *
                TS      MPAC +2         # * OF COMPONENTS PARAMETER(II) *
        +2      CAF     UPLOADNV        # (CKV432 RETURNS HERE IF V32 ENCOUNTERED)
                TC      BANKCALL        # DISPLAY A FLASHING V21N01
                CADR    GOXDSPF         # TO REQUEST II.
                TCF     UPOUT4          # V32 TERMINATE UPDATE (P27) RETURN
                TCF     OHWELL1 +2
                TC      CK4V32          # DATA OR V32 RETURN
                CS      BIT2
                AD      UPBUFF          # IS II (NUMBER OF COMPONENTS PARAMETER)
                EXTEND                  # .GE. 3 AND .LE. 20D.
                BZMF    OHWELL1 +2
                CS      UPBUFF
                AD      UP21
                EXTEND
                BZMF    OHWELL1 +2
                CAE     UPBUFF
                TS      COMPNUMB        # SAVE II IN COMPNUMB

# UPBUFF LOADING SEQUENCE

                INCR    UPCOUNT         # INCREMENT COUNT OF COMPONENTS RECEIVED.
OHWELL2         CAF     ADUPBFM1        # CALCULATE LOCATION (ECADR) IN UPBUFF
                AD      UPCOUNT         # WHERE NEXT COMPONENT SHOULD BE STORED
        +2      TS      MPAC +2         # PLACE ECADR INTO R3.
        +3      CAF     UPLOADNV        # (CK4V32 RETURNS HERE IF V32 ENCOUNTERED)
                TC      BANKCALL        # DISPLAY A FLASHING V21N01
                CADR    GOXDSPF         # TO REQUEST DATA.
                TCF     UPOUT4          # V34 TERMINATE UPDATE (P27) RETURN.
                TCF     OHWELL2 +3      # V33 PROCEED RETURN
                TC      CK4V32          # DATA OR V32 RETURN
```

```
                CS      UPCOUNT         # HAVE WE FINISHED RECEIVING ALL
                AD      COMPNUMB        # THE DATA WE EXPECTED.
                EXTEND
                BZMF    UPVERIFY        # YES -- GO TO VERIFICATION SEQUENCE
                TCF     OHWELL2 -1      # NO -- REQUEST ADDITIONAL DATA.

# Page 1502
# VERIFY SEQUENCE
UPVERIFY        CAF     ADUPTEMP        # PLACE ECADR WHERE COMPONENT NO. INDEX
                TS      MPAC +2         # IS TO BE STORED INTO R3.
                CAF     UPVRFYNV        # (CK4V32 RETURNS HERE IF V32 ENCOUNTERED)
                TC      BANKCALL        # DISPLAY A FLASHING V21N02 TO REQUEXT
                CADR    GOXDSPF         # DATA CORRECTION OR VERIFICATION.
                TCF     UPOUT4          # V34 TERMINATE UPDATE (P27) RETURN
                TCF     UPSTORE         # V33 DATA SENT IS GOOD.  GO STORE IT.
                TC      CK4V32          # COMPONENT NO. INDEX OR V32 RETURN
                CA      UPTEMP          # DOES THE COMPONENT NO. INDEX JUST SENT
                EXTEND                  # SPECIFY A LEGAL COMPONENT NUMBER?
                BZMF    UPVERIFY        # NO, IT IS NOT POSITIVE NONZERO
                CS      UPTEMP
                AD      COMPNUMB
                AD      BIT1
                EXTEND
                BZMF    UPVERIFY        # NO
                CAF     ADUPBFM1        # YES -- BASED ON THE COMPONENT NO. INDEX
                AD      UPTEMP          # CALCULATE THE ECADR OF LOCATION IN
                TCF     OHWELL2 +2      # UPBUFF WHICH USER WANTS TO CHANGE.

UPOUT4          EQUALS  UPOUT +1        # COMES HERE ON V34 TC TERMINATE UPDATE.

# CHECK FOR VERB 32 SEQUENCE

CK4V32          CS      MPAC            # ON DATA RETURN FROM 'GOXDSPF'
                MASK    BIT6            # ON DATA RETURN FROM "GOXDSP" & THE CON-
                CCS     A               # TENTS OF MPAC = VERB.  SO TEST FOR V32.
                TC      Q               # IT'S NOT A V32, IT'S DATA.  PROCEED.
                INDEX   Q
                TC      0 -6            # V32 ENCOUNTERED -- GO BACK AND GET DATA

ADUPTEMP        ADRES   UPTEMP          # ADDRESS OF TEMP STORAGE FOR CORRECTIONS
ADUPBUFF        ADRES   UPBUFF          # ADDRESS OF UPDATE DATA STORAGE BUFFER
UPLOADNV        VN      2101            # VERB 21 NOUN 01
UPVRFYNV        VN      2102            # VERB 21 NOUN 02
UP21            =       MD1             # DEC 21 = MAX NO OF COMPONENTS +1
UPDTPHAS        EQUALS  FIVE
```

```
# PRE-STORE AND FAN TO APPROPRIATE BRANCH SEQUENCE

UPSTORE         EQUALS                  # GROUND HAS VERIFIED UPDATE.  STORE DATA.

                INHINT

                CAE     FLAGWRD7        # INVERT VERIFLAG (BIT 3 OF FLAGWRD7) TO
                XCH     L               # INDICATE TO THE GROUND (VIA DOWNLINK)
                CAF     BIT3            # THAT THE V33 (WHICH THE GROUND SENT TO
# Page 1503
                EXTEND                  # VERIFY THE UPDATE) HAS BEEN SUCCESSFULLY
                RXOR    LCHAN           # RECEIVED BY THE UPDATE PROGRAM
                TS      FLAGWRD7

                TC      PHASCHNG        # SET RESTART GROUP 6 TO REDO THE UPDATE
                OCT     04026           # DATA STORE IF A RESTART OCCURS.
                INHINT                  # (BECAUSE PHASCHNG DID A RELINT)

                CS      TWO             # GO TO UPFNDVAC IF INSTALL IS REQUIRED.
                AD      UPVERB          # THAT IS, IF IT'S A V70 - V72.
                EXTEND                  # GO TO UPEND73 IF IT'S A V73.
                BZMF    UPFNDVAC

# VERB 73 BRANCH

UPEND73         EXTEND                  # V73 -- PERFORM DP OCTAL AGC CLOCK INCREMENT
                DCA     UPBUFF
                DXCH    UPBUFF +8D
                TC      TIMEDIDL
                TC      FALTON          # ERROR -- TURN ON *OPERATOR ERROR* LIGHT
                TC      UPOUT +1        # GO TO COMMON UPDATE PROGRAM EXIT

UPFNDVAC        CAF     CHRPRIO         # (USE EXTENDED VERB PRIORITY)
                TC      FINDVAC         # GET VAC AREA FOR 'CALL INTSTALL'
                EBANK=  TEPHEM
                2CADR   UPJOB           # (NOTE:  THIS WILL ALSO SET EBANK FOR
                TC      ENDOFJOB        # 'TEPHEM' UPDATE BY V70)

UPJOB           TC      INTPRET         # THIS COULD BE A STATE VECTOR UPDATE -- SO
                CALL                    # WAIT (PUT JOB TO SLEEP) IF ORBIT INT(OI)
                        INTSTALL        # IS IN PROGRESS -- OR -- GRAB OI AND RETURN
                                        # TO UPWAKE IF OI IS NOT IN PROGRESS.

UPWAKE          EXIT

                TC      PHASCHNG        # RESTART PROTECT (GROUP 6)
```

```
                OCT     04026

                TC      UPFLAG          # SET INTEGRATION RESTART BIT
                ADRES   REINTFLG
                INHINT
UPPART3         EQUALS

                INDEX   UPVERB          # BRANCH TO THE APPROPRIATE UPDATE VERB
                TCF     +1              # ROUTINE TO ACTUALLY PERFORM THE UPDATE
                TCF     UPEND70         # V70
                TCF     UPEND71         # V71
                TCF     UPEND72         # V72

# Page 1504
# ROUTINE TO INCREMENT CLOCK (TIME2,TIME1) WITH CONTENTS OF DP WORD AT UPBUFF.
TIMEDIDL        EXTEND
                QXCH    UPTEMP          # SAVE Q FOR RETURN
                CAF     ZERO            # ZERO AND SAVE TIME2,TIME1
                ZL
                DXCH    TIME2
                DXCH    UPBUFF +18D     # STORE IN CASE OF OVERFLOW

                CAF     UPDTPHAS        # DO
                TS      L               # A
                COM                     # QUICK
                DXCH    -PHASE6         # PHASCHNG

TIMEDIDR        INHINT
                CAF     ZERO
                ZL                      # PICK UP INCREMENTER(AND ZERO
                TS      MPAC +2         # IT IN CASE OF RESTARTS) AND
                DXCH    UPBUFF +8D      # STORE IT
                DXCH    MPAC            # INTO MPAC FOR TPAGREE.

                EXTEND
                DCA     UPBUFF +18D
                DAS     MPAC            # FORM SUM IN MPAC
                EXTEND
                BZF     DELTAOK         # TEST FOR OVERFLOW
                CAF     ZERO
                DXCH    UPBUFF +18D     # OVERFLOW, RESTORE OLD VALUE OF CLOCK
                DAS     TIME2           # AND TURN ON OPERATOR ERROR

                TC      PHASCHNG        # RESTART PROTECT (GROUP 6)
                OCT     04026
```

```
                TC      UPTEMP          # GO TO ERROR EXIT

DELTAOK         TC      TPAGREE         # FORCE SIGN AGREEMENT
                DXCH    MPAC
                DAS     TIME2           # INCREMENT TIME2,TIME1

                TC      PHASCHNG        # RESTART PROTECT (GROUP 6)
                OCT     04026

                INHINT
                INDEX   UPTEMP          # (CODED THIS WAY FOR RESTART PROTECTION)
                TC      1               # NORMAL RETURN

# VERB 71 BRANCH

UPEND71         CAE     UPBUFF +1       # SET EBANK
                TS      EBANK           #       AND
# Page 1505
                MASK    LOW8            # CALCULATE
                TS      UPTEMP          # S-REG VALUE OF RECEIVING AREA
                AD      NEG3            # IN THE PROCESS OF
                AD      COMPNUMB        # PERFORMING
                EXTEND                  # THIS UPDATE
                BZF     STORLP71        # WILL WE
                MASK    BIT9            # OVERFLOW
                CCS     A               # INTO THE NEXT EBANK....
                TCF     UPERROUT        # YES

                CA      NEG3            # NO -- CALCULATE NUMBER OF
                AD      COMPNUMB        # WORDS TO BE STORED MINUS ONE
STORLP71        TS      MPAC            # SAVE NO. OF WORDS REMAINING MINUS ONE
                INDEX   A               # TAKE NEXT UPDATE WORD FROM
                CA      UPBUFF +2       # UPBUFF AND
                TS      L               # SAVE IT IN L
                CA      MPAC            # CALCULATE NEXT
                AD      UPTEMP          # RECEIVING ADDRESS
                INDEX   A
                EBANK=  1400
                LXCH    1400            # UPDATE THE REGISTER BY CONTENTS OF L
                EBANK=  TEPHEM
                CCS     MPAC            # ARE THERE ANY WORDS LEFT TO BE STORED
                TCF     STORLP71        # YES
                TCF     UPOUT           # NO -- THEN EXIT UPDATE PROGRAM
ADUPBFM1        ADRES   UPBUFF -1       # SAME AS ADUPBUFF BUT LESS 1 (DON'T MOVE)
                TCF     UPOUT           # NO -- EXIT UPDATE (HERE WHEN COMPNUMB = 3)
```

```
# VERB 72 BRANCH

UPEND72         CAF     BIT1            # HAVE AN ODD NO. OF COMPONENTS
                MASK    COMPNUMB        # BEEN SENT FOR A V72 UPDATE ...
                CCS     A
                TCF     +2              # YES
                TCF     UPERROUT        # ERROR -- SHOULD BE ODD NO. OF COMPONENTS
                CS      BIT2
                AD      COMPNUMB
LDLOOP72        TS      MPAC            # NOW PERFORM THE UPDATE
                INDEX   A
                CAE     UPBUFF +1       # PICK UP NEXT UPDATE WORD
                LXCH    A
                CCS     MPAC            # SET POINTER TO ECADR (MUST BE CCS)
                TS      MPAC
                INDEX   A
                CAE     UPBUFF +1       # PICK UP NEXT ECADR OF REG TO BE UPDATED
                TS      EBANK           # SET EBANK
                MASK    LOW8            # ISOLATE RELATIVE ADDRESS
                INDEX   A

# Page 1506
                EBANK=  1400
                LXCH    1400            # UPDATE THE REGISTER BY CONTENTS OF L
                EBANK=  TEPHEM
                CCS     MPAC            # ARE WE THORUGH THE V72 UPDATE...
                TCF     LDLOOP72        # NO

# NORMAL FINISH OF P27

UPOUT           EQUALS
                TC      INTWAKEU        # RELEASE GRAB OF ORBITAL INTEGRATION
        +1      CAE     UPOLDMOD        # RESTORE PRIOR P27 MODE
                TC      NEWMODEX +3
                CAF     ZERO
                TS      DNLSTCOD
                TC      UPACTOFF        # TURN OFF 'UPLINK ACTIVITY' LIGHT
                EXTEND                  # KILL GROUP 6
                DCA     NEGO
                DXCH    -PHASE6

                TC      ENDEXT          # EXTENDED VERB EXIT

# VERB TO BRANCH

UPEND70         EXTEND                  # V70 DOES THE FOLLOWING WITH DP DELTA
```

```
                DCS     UPBUFF          # TIME IN UPBUFF
                DXCH    UPBUFF +8D
                TC      TIMEDIDL        # DECREMENT AGC CLOCK

                TC      UPERROUT        # ERROR WHILE DECREMENTING CLOCK -- EXIT

                EBANK=  TEPHEM
                EXTEND
                DCS     UPBUFF          # COPY DECREMENTERS FOR
                DXCH    UPBUFF +10D     # RESTART PROTECTION
                EXTEND
                DCS     UPBUFF
                DXCH    UPBUFF +12D

                TC      PHASCHNG        # RESTART PROTECT (GROUP 6)
                OCT     04026

                CAF     ZERO
                ZL
                DXCH    UPBUFF +10D     # DECREMENT CSM STATE VECTOR TIME
                DAS     TETCSM

                CAF     ZERO

# Page 1507
                ZL
                DXCH    UPBUFF +12D     # DECREMENT LEM STATE VECTOR TIME
                DAS     TETLEM
                CAF     ZERO
                ZL
                DXCH    UPBUFF
                DAS     TEPHEM +1       # INCREMENT TP TEPHEM
                ADS     TEPHEM

                TC      PHASCHNG        # RESTART PROTECT (GROUP 6)
                OCT     04026

                EBANK=  UPBUFF

                TC      UPOUT           # GO TO STANDARD UPDATE PROGRAM EXIT

# ERROR SEQUENCE

UPERROUT        TC      FALTON          # TURN ON *OPERATOR ERROR* LIGHT
                TCF     UPOUT           # GO TO COMMON UPDATE PROGRAM EXIT
```

```
        +2      TC      FALTON          # TURN ON ‘OPERATOR ERROR’ LIGHT
                TC      UPACTOFF        # TURN OFF ‘UPLINK ACTIVITY’ LIGHT
                TC      ENDEXT          # EXTENDED VERB EXIT
                                        # (THE PURPOSE OF UPERROUT +2 EXIT IS
                                        # TO PROVIDE AN ERROR EXIT WHICH DOES NOT
                                        # RESET ANY RESTART GROUPS)

# ‘UPACTOFF’ IS A ROUTINE TO TURN OFF UPLINK ACTIVITY LIGHT ON ALL EXITS FROM UPDATE

UPACTOFF        CS      BIT3
                EXTEND                  # TURN OFF UPLINK ACTIVITY LIGHT
                WAND    DSALMOUT        # (BIT 3 OF CHANNEL 11)
                TC      Q
```

Uses -PHASE6 152, A 80, COMPNUMB 145, COMPUTER 115, COUNT 142, DNLSTCOD 148, DSALMOUT 87, EBANK 80, EXTVERBS 71, FLAGWRD5 113, FLAGWRD7 121, IT 185, L 80, LCHAN 87, LOWSUPER 67, MODE 145, MODREG 154, MPAC 145, ORBITAL 59, PHASE6 152, PRIORITY 145, Q 80, REFSMMAT 172, REINTFLG 135, RESTART 57, SAVE 191, STATE 138, TC 169, TEMP 191, TEPHEM 172, TETCSM 172, TETLEM 172, TIME1 80, TIME2 80, UPBUFF 145, UPCOUNT 145, UPDATE2 67, UPOLDMOD 145, UPTEMP 145, UPVERB 145, UPVERBSV 145, VERIFLAG 125, VN 159, and Z 80.

3.7.28 rt8 op codes

2027 ⟨*rt8 op codes* 2027⟩≡ (1523a 2798)

```
# Page 1508
                BANK    22
                SETLOC  RTBCODES
                BANK

                EBANK=  XNB
                COUNT*  $$/RTB

# LOAD TIME2, TIME1 INTO MPAC:

LOADTIME        EXTEND
                DCA     TIME2
                TCF     SLOAD2

# CONVERT THE SINGLE PRECISION 2'S COMPLEMENT NUMBER ARRIVING IN MPAC (SCALED IN HALF-REVOLUTIO
# DP 1'S COMPLEMENT NUMBER SCALED IN REVOLUTIONS.

CDULOGIC        CCS     MPAC
                CAF     ZERO
                TCF     +3
                NOOP
                CS      HALF

                TS      MPAC +1
                CAF     ZERO
                XCH     MPAC
                EXTEND
                MP      HALF
                DAS     MPAC
                TCF     DANZIG          # MODE IS ALREADY AT DOUBLE-PRECISION

# READ THE PIPS INTO MPAC WITHOUT CHANGING THEM:

READPIPS        INHINT
                CA      PIPAX
                TS      MPAC
                CA      PIPAY
                TS      MPAC +3
                CA      PIPAZ
                RELINT
                TS      MPAC +5

                CAF     ZERO
```

```
                TS      MPAC +1
                TS      MPAC +4
                TS      MPAC +6
VECMODE         TCF     VMODE

# FORCE TP SIGN AGREEMENT IN MPAC:

SGNAGREE        TC      TPAGREE

# Page 1509

                TCF     DANZIG

# CONVERT THE DP 1'S COMPLEMENT ANGLE SCALED IN REVOLUTIONS TO A SINGLE PRECISION 2'S
# SCALED IN HALF-REVOLUTIONS.

1STO2S          TC      1TO2SUB
                CAF     ZERO
                TS      MPAC +1
                TCF     NEWMODE

# DO 1STO2S ON A VECTOR OF ANGLES:

V1STO2S         TC      1TO2SUB         # ANSWER ARRIVES IN A AND MPAC.

                DXCH    MPAC +5
                DXCH    MPAC
                TC      1TO2SUB
                TS      MPAC +2

                DXCH    MPAC +3
                DXCH    MPAC
                TC      1TO2SUB
                TS      MPAC +1

                CA      MPAC +5
                TS      MPAC

TPMODE          CAF     ONE             # MODE IS TP.
                TCF     NEWMODE

# V1STO2S FOR 2 COMPONENT VECTOR. USED BY RR.

2V1STO2S        TC      1TO2SUB
                DXCH    MPAC +3
                DXCH    MPAC
```

```
                TC      1TO2SUB
                TS      L
                CA      MPAC +3
                TCF     SLOAD2

# SUBROUTINE TO DO DOUBLING AND 1'S TO 2'S CONVERSION:

1TO2SUB         DXCH    MPAC            # FINAL MPAC +1 UNSPECIFIED.
                DDOUBL
                CCS     A
                AD      ONE
                TCF     +2
                COM                     # THIS WAS REVERSE OF MSU.

                TS      MPAC            # AND SKIP ON OVERFLOW.
# Page 1510
                TC      Q

                INDEX   A               # OVERFLOW UNCORRECT AND IN MSU.
                CAF     LIMITS
                ADS     MPAC
                TC      Q

# Page 1511
# SUBROUTINE TO INCREMENT CDUS

INCRCDUS        CAF     LOCTHETA
                TS      BUF             # PLACE ADRES(THETA) IN BUF.
                CAE     MPAC            # INCREMENT IN 1'S COMPL.
                TC      CDUINC

                INCR    BUF
                CAE     MPAC +3
                TC      CDUINC

                INCR    BUF
                CAE     MPAC +5
                TC      CDUINC

                TCF     VECMODE

LOCTHETA        ADRES   THETAD

# THE FOLLOWING ROUTINE INCREMENTS IN 2'S COMPLEMENT THE REGISTER WHOSE ADDRESS IS IN BUF BY TH
# QUANTITY FOUND IN TEM2.  THIS MAY BE USED TO INCREMENT DESIRED IMU AND OPTICS CDU ANGLES OR A
# (+0 UNEQUAL TO -0) QUANTITY.  MAY BE CALLED BY BANKCALL/SWCALL.
```

```
CDUINC          TS      TEM2            # 1'S COMPL. QUANT. ARRIVES IN ACC.  STORE IT
                INDEX   BUF
                CCS     0               # CHANGE 2'S COMPLE. ANGEL (IN BUF) INTO 1'S
                AD      ONE
                TCF     +4
                AD      ONE
                AD      ONE             # OVERFLOW HERE IF 2'S COMPL. IS 180 DEG.
                COM

                AD      TEM2            # SULT MOVES FROM 2ND TO 3D QUAD. (OR BACK)
                CCS     A               # BACK TO 2'S COMPL.
                AD      ONE
                TCF     +2
                COM
                TS      TEM2            # STORE 14-BIT QUANTITY WITH PRESENT SIGN
                TCF     +4
                INDEX   A               # SIGN.
                CAF     LIMITS          # FIX IT, BY ADDING IN 37777 OR 40000
                AD      TEM2

                INDEX   BUF
                TS      0               # STORE NEW ANGLE IN 2'S COMPLEMENT.
                TC      Q

# Page 1512
# RTB TO TORQUE GYROS, EXCEPT FOR THE CALL TO IMUSTALL.  ECADR OF COMMANDS ARRIVES IN

PULSEIMU        INDEX   FIXLOC          # ADDRESS OF GYRO COMMANDS SHOULD BE IN X1
                CA      X1
                TC      BANKCALL
                CADR    IMUPULSE
                TCF     DANZIG

# Page 1513
# EACH ROUTINE TAKES A 3X3 MATRIX STORED IN DOUBLE PRECISION IN A FIXED AREA OF ERASA
# WITH THE TRANSPOSE MATRIX.  TRANSP1 USES LOCATIONS XNB+0,+1 THROUGH XNB+16D,+17D AN
# XNB1+0,+1 THROUGH XNB1+16D,+17D.  EACH MATRIX IS STORED BY ROWS.

XNBEB           ECADR   XNB
XNB1EB          ECADR   XNB1

                EBANK=  XNB

TRANSP1         CAF     XNBEB
                TS      EBANK
```

```
                DXCH    XNB +2
                DXCH    XNB +6
                DXCH    XNB +2

                DXCH    XNB +4
                DXCH    XNB +12D
                DXCH    XNB +4

                DXCH    XNB +10D
                DXCH    XNB +14D
                DXCH    XNB +10D
                TCF     DANZIG
                EBANK=  XNB1

TRANSP2         CAF     XNB1EB
                TS      EBANK
                DXCH    XNB1 +2
                DXCH    XNB1 +6
                DXCH    XNB1 +2

                DXCH    XNB1 +4
                DXCH    XNB1 +12D
                DXCH    XNB1 +4

                DXCH    XNB1 +10D
                DXCH    XNB1 +14D
                DXCH    XNB1 +10D
                TCF     DANZIG

# Page 1514
# THE SUBROUTINE SIGNMPAC SETS C(MPAC, MPAC +1) TO SIGN(MPAC).
# FOR THIS, ONLY THE CONTENTS OF MPAC ARE EXAMINED.  ALSO +0 YIELDS POSMAX AND -0 YIELDS NEGMAX
#
# ENTRY MAY BE BY EITHER OF THE FOLLOWING:
#       1.      LIMIT THE SIZE OF MPAC ON INTERPRETIVE OVERFLOW:
#               ENTRY:          BOVB
#                                       SIGNMPAC
#       2.      GENERATE IN MPAC THE SIGNUM FUNCTION OF MPAC:
#               ENTRY:          RTB
#                                       SIGNMPAC
# IN EITHER CASE, RETURN IS TO  THE NEXT INTERPRETIVE INSTRUCTION IN THE CALLING SEQUENCE.

SIGNMPAC        EXTEND
                DCA     DPOSMAX
                DXCH    MPAC
                CCS     A
```

```
DPMODE          CAF     ZERO            # SETS MPAC +2 TO ZERO IN THE PROCESS
                TCF     SLOAD2 +2
                TCF     +1
                EXTEND
                DCS     DPOSMAX
                TCF     SLOAD2

# RTB OP CODE NORMUNIT IS LIKE INTERPRETIVE INSTRUCTION UNIT, EXCEPT THAT IT CAN BE I
# UP WHEN THE VECTOR BEING UNITIZED IS VERY SMALL -- IT WILL BLOW UP WHEN ALL COMPONE
# IS USED AND THE UPPER ORDER HALVES OF ALL COMPONENTS ARE ZERO, THE MAGNITUDE RETURN
# BY A FACTOR OF 2(13) AND THE SQUARED MAGNITUDE RETURNED AT 34D WILL BE TOO BIG BY A

NORMUNX1        CAF     ONE
                TCF     NORMUNIT +1
NORMUNIT        CAF     ZERO
                AD      FIXLOC
                TS      MPAC +2
                TC      BANKCALL        # GET SIGN AGREEMENT IN ALL COMPONENTS
                CADR    VECAGREE
                CCS     MPAC
                TCF     NOSHIFT
                TCF     +2
                TCF     NOSHIFT
                CCS     MPAC +3
                TCF     NOSHIFT
                TCF     +2
                TCF     NOSHIFT
                CCS     MPAC +5
                TCF     NOSHIFT
                TCF     +2
                TCF     NOSHIFT
# Page 1515
                CA      MPAC +1         # SHIFT ALL COMPONENTS LEFT 13
                EXTEND
                MP      BIT14
                DAS     MPAC            # DAS GAINS A LITTLE ACCURACY
                CA      MPAC +4
                EXTEND
                MP      BIT14
                DAS     MPAC +3
                CA      MPAC +6
                EXTEND
                MP      BIT14
                DAS     MPAC +5
                CAF     THIRTEEN
                INDEX   MPAC +2
```

```
                TS      37D
OFFTUNIT        TC      POSTJUMP
                CADR    UNIT +1         # SKIP THE "TC VECAGREE" DONE AT UNIT

NOSHIFT         CAF     ZERO
                TCF     OFFTUNIT -2

# RTB VECSGNAG ... FORCES SIGN AGREEMENT OF VECTOR IN MPAC.

VECSGNAG        TC      BANKCALL
                CADR    VECAGREE
                TC      DANZIG

# Page 1516
# MODULE CHANGE FOR NEW LUNAR GRAVITY MODEL
                SETLOC  MODCHG3
                BANK
QUALITY1        BOF     DLOAD
                        MOONFLAG
                        NBRANCH
                        URPV
                DSQ     GOTO
                        QUALITY2
                SETLOC  MODCHG2
                BANK
QUALITY2        PDDL    DSQ             # SQUARE INTO 2D, B2
                        URPV    +2      # Y COMPONENT, B1
                DSU
                DMP     VXSC            # 5(Y**2-X**2)UR
                        5/8             # CONSTANT, 5B3
                        URPV            # VECTOR, RESULT MAXIMUM IS 5, SCALING
                                        # HERE B6
                VSL3    PDDL            # STORE SCALED B3 IN 2D, 4D, 6D FOR XYZ
                        URPV            # X COMPONENT, B1
                SR1     DAD             # 2 X X COMPONENT FOR B3 SCALING
                        2D              # ADD TO VECTOR X COMPONENT OF ANSWER.
                                        # SAME AS MULTIPLYING BY UNITX.  MAX IS 7.
                STODL   2D
                        URPV    +2      # Y COMPONENT, B1
                SR1     BDSU            # 2 X Y COMPONENT FOR B3 SCALING
                        4D              # SUBTRACT FROM VECTOR Y COMPONENT OF
                                        # ANSWER, SAME AS MULTIPLYING BY UNITY.
                                        # MAX IS 7.
                STORE   4D              # 2D HAS VECTOR, B3.
                SLOAD   VXSC            # MULTIPLY COEFFICIENT TIMES VECTOR IN 2D
                        E3J22R2M
```

```
                PDDL    RVQ             # J22 TERM X R**4 IN 2D, SCALED B61
                        COSPHI/2        # SAME AS URPV +4, Z COMPONENT

  # *** END OF CHIEFTAN.028 ***
```

Uses A 80, BUF 142, CDUS 80, CODE 140, COUNT 142, E3J22R2M 174, EBANK 80, FACTOR 226, FIXLOC 140, IT 185, L 80, MODCHG2 61, MODCHG3 61, MODE 145, MOONFLAG 95, MPAC 145, PIPAX 80, PIPAY 80, PIPAZ 80, Q 80, RTBCODES 63, TC 169, TEM2 142, THETA 148, THETAD 157, TIME1 80, TIME2 80, X1 85, XNB 186, XNB1 183, and Z 80.

3.7.29 rtb op codes

2034 ⟨*rtb op codes* 2034⟩≡ (2799)
⟨*Page LM1397* 2035⟩

2035 ⟨*Page LM1397* 2035⟩≡ (2034)

```
# Page 1397
                BANK    22
                SETLOC  RTBCODES
                BANK

                EBANK=  XNB
                COUNT*  $$/RTB

# LOAD TIME2, TIME1 INTO MPAC:

LOADTIME        EXTEND
                DCA     TIME2
                TCF     SLOAD2

# CONVERT THE SINGLE PRECISION 2'S COMPLEMENT NUMBER ARRIVING IN MPAC (SCALED IN HALF-REVOLUTIO
# DP 1'S COMPLEMENT NUMBER SCALED IN REVOLUTIONS.

CDULOGIC        CCS     MPAC
                CAF     ZERO
                TCF     +3
                NOOP
                CS      HALF

                TS      MPAC +1
                CAF     ZERO
                XCH     MPAC
                EXTEND
                MP      HALF
                DAS     MPAC
                TCF     DANZIG          # MODE IS ALREADY AT DOUBLE-PRECISION

# FORCE TP SIGN AGREEMENT IN MPAC:

SGNAGREE        TC      TPAGREE
                TCF     DANZIG

# CONVERT THE DP 1'S COMPLEMENT ANGLE SCALED IN REVOLUTIONS TO A SINGLE PRECISION 2'S COMPLEMEN
# SCALED IN HALF-REVOLUTIONS.

1STO2S          TC      1TO2SUB
                CAF     ZERO
                TS      MPAC +1
                TCF     NEWMODE

# DO 1STO2S ON A VECTOR OF ANGLES:
```

```
V1STO2S         TC      1TO2SUB         # ANSWER ARRIVES IN A AND MPAC.

                DXCH    MPAC +5
                DXCH    MPAC
                TC      1TO2SUB
# Page 1398
                TS      MPAC +2

                DXCH    MPAC +3
                DXCH    MPAC
                TC      1TO2SUB
                TS      MPAC +1

                CA      MPAC +5
                TS      MPAC

TPMODE          CAF     ONE             # MODE IS TP.
                TCF     NEWMODE

# V1STO2S FOR 2 COMPONENT VECTOR. USED BY RR.

2V1STO2S        TC      1TO2SUB
                DXCH    MPAC +3
                DXCH    MPAC
                TC      1TO2SUB
                TS      L
                CA      MPAC +3
                TCF     SLOAD2

# SUBROUTINE TO DO DOUBLING AND 1'S TO 2'S CONVERSION:

1TO2SUB         DXCH    MPAC            # FINAL MPAC +1 UNSPECIFIED.
                DDOUBL
                CCS     A
                AD      ONE
                TCF     +2
                COM                     # THIS WAS REVERSE OF MSU.

                TS      MPAC            # AND SKIP ON OVERFLOW.
                TC      Q

                INDEX   A               # OVERFLOW UNCORRECT AND IN MSU.
                CAF     LIMITS
                ADS     MPAC
                TC      Q
```

```
# THE FOLLOWING ROUTINE INCREMENTS IN 2S COMPLEMENT THE REGISTER WHOSE ADDRESS IS IN BUF BY THE
# QUANTITY FOUND IN TEM2.  THIS MAY BE USED TO INCREMENT DESIRED IMU AND OPTICS CDU ANGLES OR A
# (+0 UNEQUAL TO -0) QUANTITY.  MAY BE CALLED BY BANKCALL/SWCALL.

CDUINC          TS      TEM2            # 1S COMPL.QUANT. ARRIVES IN ACC.  STORE IT
                INDEX   BUF
                CCS     0               # CHANGE 2S COMPL. ANGLE(IN BUF)INTO 1S
                AD      ONE
                TCF     +4
                AD      ONE
# Page 1399
                AD      ONE             # OVERFLOW HERE IF 2S COMPL. IS 180 DEG.
                COM

                AD      TEM2            # SULT MOVES FROM 2ND TO 3D QUAD. (OR BACK)
                CCS     A               # BACK TO 2S COMPL.
                AD      ONE
                TCF     +2
                COM
                TS      TEM2            # STORE 14BIT QUANTITY WITH PRESENT SIGN
                TCF     +4
                INDEX   A               # SIGN.
                CAF     LIMITS          # FIX IT, BY ADDING IN 37777 OR 40000
                AD      TEM2

                INDEX   BUF
                TS      0               # STORE NEW ANGLE IN 2S COMPLEMENT.
                TC      Q

# Page 1400
# RTB TO TORQUE GYROS, EXCEPT FOR THE CALL TO IMUSTALL.  ECADR OF COMMANDS ARRIVES IN X1.

PULSEIMU        INDEX   FIXLOC          # ADDRESS OF GYRO COMMANDS SHOULD BE IN X1
                CA      X1
                TC      BANKCALL
                CADR    IMUPULSE
                TCF     DANZIG

# Page 1401
# THE SUBROUTINE SIGNMPAC SETS C(MPAC, MPAC +1) TO SIGN(MPAC).
# FOR THIS, ONLY THE CONTENTS OF MPAC ARE EXAMINED.  ALSO +0 YIELDS POSMAX AND -0 YIELDS NEGMAX
#
# ENTRY MAY BE BY EITHER OF THE FOLLOWING:
#       1.      LIMIT THE SIZE OF MPAC ON INTERPRETIVE OVERFLOW:
#               ENTRY:          BOVB
```

```
#                                       SIGNMPAC
#       2.      GENERATE IN MPAC THE SIGNUM FUNCTION OF MPAC:
#               ENTRY:          RTB
#                                       SIGNMPAC
# IN EITHER CASE, RETURN IS TO  THE NEXT INTERPRETIVE INSTRUCTION IN THE CALLING SEQU

SIGNMPAC        EXTEND
                DCA     DPOSMAX
                DXCH    MPAC
                CCS     A
DPMODE          CAF     ZERO            # SETS MPAC +2 TO ZERO IN THE PROCESS
                TCF     SLOAD2 +2
                TCF     +1
                EXTEND
                DCS     DPOSMAX
                TCF     SLOAD2

# RTB OP CODE NORMUNIT IS LIKE INTERPRETIVE INSTRUCTION UNIT, EXCEPT THAT IT CAN BE I
# UP WHEN THE VECTOR BEING UNITIZED IS VERY SMALL -- IT WILL BLOW UP WHEN ALL COMPONE
# IS USED AND THE UPPER ORDER HALVES OF ALL COMPONENTS ARE ZERO, THE MAGNITUDE RETURN
# BY A FACTOR OF 2(13) AND THE SQUARED MAGNITUDE RETURNED ATE 34D WILL BE TOO BIG BY

NORMUNX1        CAF     ONE
                TCF     NORMUNIT +1
NORMUNIT        CAF     ZERO
                AD      FIXLOC
                TS      MPAC +2
                TC      BANKCALL        # GET SIGN AGREEMENT IN ALL COMPONENTS
                CADR    VECAGREE
                CCS     MPAC
                TCF     NOSHIFT
                TCF     +2
                TCF     NOSHIFT
                CCS     MPAC +3
                TCF     NOSHIFT
                TCF     +2
                TCF     NOSHIFT
                CCS     MPAC +5
                TCF     NOSHIFT
                TCF     +2
                TCF     NOSHIFT
# Page 1402
                CA      MPAC +1         # SHIFT ALL COMPONENTS LEFT 13
                EXTEND
                MP      BIT14
                DAS     MPAC            # DAS GAINS A LITTLE ACCURACY
```

```
                CA      MPAC +4
                EXTEND
                MP      BIT14
                DAS     MPAC +3
                CA      MPAC +6
                EXTEND
                MP      BIT14
                DAS     MPAC +5
                CAF     THIRTEEN
                INDEX   MPAC +2
                TS      37D
OFFTUNIT        TC      POSTJUMP
                CADR    UNIT +1         # SKIP THE "TC VECAGREE" DONE AT UNIT

NOSHIFT         CAF     ZERO
                TCF     OFFTUNIT -2

# RTB VECSGNAG ... FORCES SIGN AGREEMENT OF VECTOR IN MPAC.

VECSGNAG        TC      BANKCALL
                CADR    VECAGREE
                TC      DANZIG

# *** END OF SKIPPER .087 ***
```

Uses A 80, BUF 142, CODE 140, COUNT 142, EBANK 80, FACTOR 226, FIXLOC 140, IT 185, L 80, MODE 145, MPAC 145, Q 80, RTBCODES 63, TC 169, TEM2 142, TIME1 80, TIME2 80, X1 85, and XNB 186.

Chapter 4

Luminary099

2041 ⟨*Luminary099.agc* 2041⟩≡
⟨*controlled constants* 2042⟩
⟨*input output channel bit descriptions* 2058⟩
⟨*flagword assignments* 2065⟩
⟨*rcs failure monitor* 2108⟩
⟨*ags initialization* 2111⟩
⟨*aotmark routine* 2120⟩
⟨*lem geometry* 2143⟩
⟨*r63 routine* 2148⟩
⟨*attitude maneuver routine* 2151⟩
⟨*imu performance test 2* 2188b⟩
⟨*imu performance tests 4* 2202a⟩
⟨*s band antenna for lm* 2213⟩
⟨*radar leadin routines* 2217⟩
⟨*p30-p37 routines* 2218⟩
⟨*p32-p35 p72-p75 routines* 2223⟩
⟨*lambert aimpoint guidance* 2253⟩
⟨*burn-baby-burn master ignition routine* 2259⟩
⟨*the lunar landing* 2299⟩
⟨*throttle control routines* 2306⟩
⟨*lunar landing guidance equations* 2311⟩
⟨*p70-p71 routines* 2343⟩
⟨*p12 routine* 2353⟩
⟨*ascent guidance* 2358⟩
⟨*servicer routine* 2382⟩
⟨*landing analog displays* 2419⟩
⟨*findcduw-guidap interface* 2439⟩
⟨*lm down-telemetry program* 2460⟩
⟨*interpretive constant* 2475b⟩
⟨*lm agc block two self check* 2477b⟩
⟨*lm rtb op codes* 2495b⟩

⟨*t6 rupt programs* 2496⟩
⟨*dap interface subroutines* 2499a⟩
⟨*dapidler program* 2503b⟩
⟨*p axis rcs autopilot* 2519⟩
⟨*q-r axis rcs autopilot* 2542⟩
⟨*tjet law* 2561⟩
⟨*kalman filter* 2571⟩
⟨*trim gimbal cntrol system* 2574⟩
⟨*aostask and aosjob* 2587⟩
⟨*sps back up rcs control* 2625⟩

This code is written to file `Luminary099.agc`.

4.1 controlled constants

2042 ⟨*controlled constants* 2042⟩≡ (2041)
⟨*Page LM0038* 2043⟩
⟨*Page LM0039* 2044⟩
⟨*Page LM0040* 2045⟩
⟨*Page LM0041* 2046⟩
⟨*Page LM0042* 2047⟩
⟨*Page LM0043* 2048⟩
⟨*Page LM0044* 2049⟩
⟨*Page LM0045* 2050⟩
⟨*Page LM0046* 2051⟩
⟨*Page LM0047* 2052⟩
⟨*Page LM0048* 2053⟩
⟨*Page LM0049* 2054⟩
⟨*Page LM0050* 2055⟩
⟨*Page LM0051* 2056⟩
⟨*Page LM0052* 2057a⟩
⟨*Page LM0053* 2057b⟩

2043 ⟨*Page LM0038* 2043⟩≡ (2042 2666)

```
# DPS AND APS ENGINE PARAMETERS

                SETLOC  P40S
                BANK
                COUNT*  $$/P40

# *** THE ORDER OF THE FOLLOWING SIX CONSTANTS MUST NOT BE CHANGED ***

FDPS            2DEC    4.3670 B-7              # 9817.5 LBS FORCE IN NEWTONS
MDOTDPS         2DEC    0.1480 B-3              # 32.62 LBS/SEC IN KGS/CS
DTDECAY         2DEC    -38
FAPS            2DEC    1.5569 B-7              # 3500 LBS FORCE IN NEWTONS
MDOTAPS         2DEC    0.05135 B-3             # 11.32 LBS/SEC IN KGS/CS
ATDECAY         2DEC    -10

# ******************************************************************

FRCS4           2DEC    0.17792 B-7             # 400 LBS FORCE IN NEWTONS
FRCS2           2DEC    0.08896 B-7             # 200 LBS FORCE IN NEWTONS

                SETLOC  P40S1
                BANK
                COUNT*  $$/P40

# *** APS IMPULSE DATA FOR P42 ***************************************

K1VAL           2DEC    124.55 B-23             # 2800 LB-SEC
K2VAL           2DEC    31.138 B-24             # 700 LB-SEC
K3VAL           2DEC    1.5569 B-10             # FAPS (3500 LBS THRUST)

# ******************************************************************

S40.136         2DEC    .4671 B-9               # .4671 M NEWTONS (DPS)
S40.136_        2DEC    .4671 B+1               # S40.136 SHIFTED LEFT 10.

                SETLOC  ASENT1
                BANK
                COUNT*  $$/P70

(1/DV)A         2DEC    15.20 B-7               # 2 SECONDS WORTH OF INITIAL ASCENT
```

Uses A 80, COUNT 142, DV 241, P40S 65, P40S1 61, and THRUST 85.

2044 ⟨*Page LM0039* 2044⟩≡ (2042 2666)

```
                                                  # STAGE ACCELERATION -- INVERTED (M/C
                                                  # 1) PREDICATED ON A LIFTOFF MASS OF
                                                  #    4869.9 KG (SNA-8-D-027 7/11/68)
                                                  # 2) PREDICATED ON A CONTRIBUTION TO
                                                  #    ICLE ACCELERATION FROM RCS THRUS
                                                  #    EQUIV. TO 1 JET ON CONTINUOUSLY.

K(1/DV)         2DEC    436.70 B-9                # DPS ENGINE THRUST IN NEWTONS / 100

(AT)A           2DEC    3.2883 E-4 B9             # INITIAL ASC. STG. ACCELERATION ** N
                                                  # ASSUMPTIONS SAME AS FOR (1/DV)A.
(TBUP)A         2DEC    91902 B-17                # ESTIMATED BURN-UP TIME OF THE ASCEN
                                                  # ASSUMPTIONS SAME AS FOR (1/DV)A WIT
                                                  # ADDITIONAL ASSUMPTION THAT NET MASS
                                                  # RATE = 5.299 KG/SEC = 5.135 (APS) +
                                                  # .164 (1 RCS JET).
                SETLOC  ASENT
                BANK
                COUNT*  $$/ASENT
AT/RCS          2DEC    .0000785 B+10             # 4 JETS IN A DRY LEM

                SETLOC  SERVICES
                BANK
                COUNT*  $$/SERV

# *** THE ORDER OF THE FOLLOWING TWO CONSTANTS MUST NOT BE CHANGED *******

APSVEX          DEC     -3030 E-2 B-5             # 9942 FT/SEC IN M/CS.
DPSVEX          DEC*    -2.95588868 E+1 B-05*     # VE (DPS) +2.95588868E+ 3

# ***********************************************************************

                SETLOC  F2DPS*31
                BANK
                COUNT*  $$/F2DPS

TRIMACCL        2DEC*   +3.50132708 E-5 B+08*      # A (T) +3.50132708E- 1
```

Uses `A` 80, `COUNT` 142, `D` 226, `DV` 241, `MASS` 200, `SERVICES` 69, and `THRUST` 85.

2045 ⟨*Page LM0040* 2045⟩≡ (2042 2666)

```
# THROTTLING AND THRUST DETECTION PARAMETERS

                SETLOC  P40S
                BANK
                COUNT*  $$/P40

THRESH1         DEC     24
THRESH3         DEC     12
HIRTHROT        =       BIT13

                SETLOC  FFTAG5
                BANK
                COUNT*  $$/P40

THRESH2         DEC     308

                SETLOC  FTHROT
                BANK
                COUNT*  $$/THROT

FMAXODD         DEC     +3841                   # FSAT          +4.81454413 E+4
FMAXPOS         DEC     +3467                   # FMAX          +4.34546769 E+4
THROTLAG        DEC     +20                     # TAU (TH)      +1.99999999 E-1
SCALEFAC        2DEC*   +7.97959872 E+2 B-16*   # BITPERF       +7.97959872 E-2

                SETLOC  F2DPS*32
                BANK
                COUNT*  $$/F2DPS

DPSTHRSH        DEC     36                      # (THRESH1 + THRESH3 FOR P63)
```

Uses COUNT 142, FFTAG5 57, P40S 65, TAU 211, and THRUST 85.

2046 ⟨*Page LM0041* 2046⟩≡ (2042 2666)

```
# LM HARDWARE-RELATED PARAMETERS

                SETLOC  RADARUPT
                BANK
                COUNT*  $$/RRUPT

LVELBIAS        DEC     -12288                  # LANDING RADAR BIAS FOR 153.6 KC.
RDOTBIAS        2DEC    17000                   # BIAS COUNT FOR RR RANGE RATE.

                SETLOC  LRS22
                BANK
                COUNT*  $$/LRS22

RDOTCONV        2DEC    -.0019135344 B7         # CONVERTS RR RDOT READING TO M/CS AT
RANGCONV        2DEC    2.859024 B-3            # CONVERTS RR RANGE READING TO M. AT

                SETLOC  SERVICES
                BANK
                COUNT*  $$/SERV

HBEAMANT        2DEC    -.4687018041            # RANGE BEAM IN LR ANTENNA COORDINATE
                2DEC    0
                2DEC    -.1741224271

HSCAL           2DEC    -.3288792               # SCALES 1.079 FT/BIT TO 2(22)M.

# ***** THE SEQUENCE OF THE FOLLOWING CONSTANTS MUST BE PRESERVED *********

VZSCAL          2DEC    +.5410829105            # SCALES .8668 FT/SEC/BIT TO 2(18) M/
VYSCAL          2DEC    +.7565672446            # SCALES 1.212 FT/SEC/BIT TO 2(18) M/
VXSCAL          2DEC    -.4020043770            # SCALES -.644 FT/SEC/BIT TO 2(18) M/

# ************************************************************************

KPIP            DEC     .0512                   # SCALES DELV TO UNITS OF 2(5) M/CS.
KPIP1           2DEC    .0128                   # SCALES DELV TO UNITS OF 2(7) M/CS.
KPIP2           2DEC    .0064                   # SCALES DELV TO UNITS OF 2(8) M/CS.
```

Uses BIAS 211, COUNT 142, DELV 159, RANGE 179, RDOT 229, and SERVICES 69.

2047 ⟨*Page LM0042* 2047⟩≡ (2042 2666)

```
ALTCONV         2DEC    1.399078846 B-4         # CONVERTS M*2(-24) TO BIT UNITS *2(-28).
ARCONV1         2DEC    656.167979 B-10         # CONV. ALTRATE COMP. TO BIT UNITS<

                SETLOC  R10
                BANK
                COUNT*  $$/R10

ARCONV          OCT     24402                   # 656.1679798B-10 CONV ALTRATE TO BIT UNIT
ARTOA           DEC     .1066098 B-1            # .25/2.345 B-1 4X/SEC CYCLE RATE.
ARTOA2          DEC     .0021322 B8             # (.5)/(2.345)(100)
VELCONV         OCT     22316                   # 588.914 B-10 CONV VEL. TO BIT UNITS.
KPIP1(5)        DEC     .0512                   # SCALES DELV TO M/CS*2(-5).
MAXVBITS        OCT     00547                   # MAX. DISPLAYED VELOCITY 199.9989 FT/SEC.

                SETLOC  DAPS3
                BANK
                COUNT*  $$/DAPAO

TORKJET1        DEC     .03757                  # 550 / .2 SCALED AT (+16) 64 / 180
```

Uses COUNT 142, DAPS3 63, DELV 159, and VEL 226.

2048 ⟨*Page LM0043* 2048⟩≡ (2042 2666)

```
# PARAMETERS RELATING TO MASS, INERTIA, AND VEHICLE DIMENSIONS

                SETLOC  FRANDRES
                BANK
                COUNT*  $$/START

FULLAPS         DEC     5050 B-16               # NOMINAL FULL ASCENT MASS -- 2(16) K

                SETLOC  LOADDAP1
                BANK
                COUNT*  $$/R03

MINLMD          DEC     -2850 B-16              # MIN. DESCENT STAGE MASS -- 2(16) KG
MINMINLM        DEC     -2200 B-16              # MIN ASCENT STAGE MASS -- 2(16) KG.
MINCSM          =       BIT11                   # MIN CSM MASS (OK FOR 1/ACCS) = 9050

                SETLOC  DAPS3
                BANK
                COUNT*  $$/DAPAD

LOASCENT        DEC     2200 B-16               # MIN ASCENT LEM MASS -- 2(16) KG.
HIDESCNT        DEC     15300 B-16              # MAX DESCENT LEM MASS -- 2(16) KG.
LODESCNT        DEC     1750 B-16               # MIN DESCENT STAGE (ALONE) -- 2(16)
```

Uses COUNT 142, DAPS3 63, FRANDRES 59, and MASS 200.

2049 ⟨*Page LM0044* 2049⟩≡ (2042 2666)

```
# PHYSICAL CONSTANTS ( TIME - INVARIANT )

                SETLOC  IMU2
                BANK
                COUNT*  $$/P07

OMEG/MS         2DEC    .24339048

                SETLOC  R30LOC
                BANK
                COUNT*  $$/R30

# *** THE ORDER OF THE FOLLOWING TWO CONSTANTS MUST BE PRESERVED ***********

1/RTMUM         2DEC*   .45162595 E-4 B14*
1/RTMUE         2DEC*   .50087529 E-5 B17*

# ************************************************************************

                SETLOC  P40S1
                BANK
                COUNT*  $$/S40.9

EARTHMU         2DEC*   -3.986032 E10 B-36*     # M(3)/CS(2)

                SETLOC  ASENT1
                BANK
                COUNT*  $$/P12

MUM(-37)        2DEC*   4.9027780 E8 B-37*
MOONRATE        2DEC*   .26616994890062991 E-7 B+19*    # RAD/CS.

                SETLOC  SERVICES
                BANK
                COUNT*  $$/SERV

# *** THE ORDER OF THE FOLLOWING TWO CONSTANTS MUST BE PRESERVED ***********

-MUDT           2DEC*   -7.9720645 E+12 B-44*
-MUDT1          2DEC*   -9.8055560 E+10 B-44*

# ************************************************************************

-MUDTMUN        2DEC*   -9.8055560 E+10 B-38*
RESQ            2DEC*   40.6809913 E12 B-58*
```

Uses COUNT 142, P40S1 61, R30LOC 65, RAD 219, and SERVICES 69.

2050 ⟨*Page LM0045* 2050⟩≡ (2042 2666)

```
20J             2DEC    3.24692010 E-2
2J              2DEC    3.24692010 E-3

                SETLOC  P50S1
                BANK
                COUNT*  $$/LOSAM

RSUBEM          2DEC    384402000 B-29
RSUBM           2DEC    1738090 B-29
RSUBE           2DEC    6378166 B-29
ROE             2DEC    .00257125

                SETLOC  CONICS1
                BANK
                COUNT*  $$/LT-LG

ERAD            2DEC    6373338 B-29            # PAD RADIUS
504RM           2DEC    1738090 B-29            # METERS B-29 (EQUATORIAL MOON RADIUS

                SETLOC  CONICS1
                BANK
                COUNT*  $$/CONIC

# *** THE ORDER OF THE FOLLOWING CONSTANTS MUST BE PRESERVED **************

MUTABLE         2DEC*   3.986032 E10 B-36*      # MUE
                2DEC*   .25087606 E-10 B+34*     # 1/MUE
                2DEC*   1.99650495 E5 B-18*      # SQRT(MUE)
                2DEC*   .50087529 E-5 B+17*      # 1/SQRT(MUE)
                2DEC*   4.902778 E8 B-30*        # MUM
                2DEC*   .203966 E-8 B+28*        # 1/MUM
                2DEC*   2.21422176 E4 B-15*      # SQRT(MUM)
                2DEC*   .45162595 E-4 B+14*      # 1/SQRT(MUM)

# ************************************************************************
```

Uses CONICS1 57, COUNT 142, and P50S1 61.

2051 ⟨*Page LM0046* 2051⟩≡ (2042 2666)

```
                SETLOC  INTINIT
                BANK
                COUNT*  $$/INTIN

OMEGMOON        2DEC*   2.66169947 E-8 B+23*

                SETLOC  ORBITAL2
                BANK
                COUNT*  $$/ORBIT

# *** THE ORDER OF THE FOLLOWING CONSTANTS MUST NOT BE CHANGED ************

                2DEC*   1.32715445 E16 B-54*
MUM             2DEC*   4.9027780 E8 B-30*
MUEARTH         2DEC*   3.986032 E10 B-36*
                2DEC    0
J4REQ/J3        2DEC*   .4991607391 E7 B-26*
                2DEC    -176236.02 B-25
2J3RE/J2        2DEC*   -.1355426363 E5 B-27*
                2DEC*   .3067493316 E18 B-60*
J2REQSQ         2DEC*   1.75501139 E21 B-72*
3J22R2MU        2DEC*   9.20479048 E16 B-58*

# ************************************************************************

                SETLOC  TOF-FF1
                BANK
                COUNT*  $$/TFF

1/RTMU          2DEC*   .5005750271 E-5 B17*    # MODIFIED EARTH MU

                SETLOC  SBAND
                BANK
                COUNT*  $$/R05

REMDIST         2DEC    384402000 B-29          # MEAN DISTANCE BETWEEN EARTH AND MOON.
```

Uses COUNT 142, INTINIT 61, ORBITAL2 61, SBAND 71, TFF 179, and TOF-FF1 65.

2052 ⟨*Page LM0047* 2052⟩≡ (2042 2666)

```
# PHYSICAL CONSTANTS (TIME - VARIANT)

                SETLOC  STARTAB
                BANK
                COUNT*  $$/STARS

                2DEC    +.8342971408 B-1        # STAR 37       X
                2DEC    -.2392481515 B-1        # STAR 37       Y
                2DEC    -.4966976975 B-1        # STAR 37       Z

                2DEC    +.8139832631 B-1        # STAR 36       X
                2DEC    -.5557243189 B-1        # STAR 36       Y
                2DEC    +.1691204557 B-1        # STAR 36       Z

                2DEC    +.4541086270 B-1        # STAR 35       X
                2DEC    -.5392368197 B-1        # STAR 35       Y
                2DEC    +.7092312789 B-1        # STAR 35       Z

                2DEC    +.3201817378 B-1        # STAR 34       X
                2DEC    -.4436021946 B-1        # STAR 34       Y
                2DEC    -.8370786986 B-1        # STAR 34       Z

                2DEC    +.5520184464 B-1        # STAR 33       X
                2DEC    -.7933187400 B-1        # STAR 33       Y
                2DEC    -.2567508745 B-1        # STAR 33       Z

                2DEC    +.4537196908 B-1        # STAR 32       X
                2DEC    -.8779508801 B-1        # STAR 32       Y
                2DEC    +.1527766153 B-1        # STAR 32       Z

                2DEC    +.2069525789 B-1        # STAR 31       X
                2DEC    -.8719885748 B-1        # STAR 31       Y
                2DEC    -.4436288486 B-1        # STAR 31       Z

                2DEC    +.1217293692 B-1        # STAR 30       X
                2DEC    -.7702732847 B-1        # STAR 30       Y
```

Uses COUNT 142, STAR 186, STARTAB 61, and Z 80.

2053 ⟨*Page LM0048* 2053⟩≡ (2042 2666)

```
2DEC    +.6259880410 B-1        # STAR 30       Z

2DEC    -.1124304773 B-1        # STAR 29       X
2DEC    -.9694934200 B-1        # STAR 29       Y
2DEC    +.2178116072 B-1        # STAR 29       Z

2DEC    -.1146237858 B-1        # STAR 28       X
2DEC    -.3399692557 B-1        # STAR 28       Y
2DEC    -.9334250333 B-1        # STAR 28       Z

2DEC    -.3516499609 B-1        # STAR 27       X
2DEC    -.8240752703 B-1        # STAR 27       Y
2DEC    -.4441196390 B-1        # STAR 27       Z

2DEC    -.5326876930 B-1        # STAR 26       X
2DEC    -.7160644554 B-1        # STAR 26       Y
2DEC    +.4511047742 B-1        # STAR 26       Z

2DEC    -.7861763936 B-1        # STAR 25       X
2DEC    -.5217996305 B-1        # STAR 25       Y
2DEC    +.3311371675 B-1        # STAR 25       Z

2DEC    -.6898393233 B-1        # STAR 24       X
2DEC    -.4182330640 B-1        # STAR 24       Y
2DEC    -.5909338474 B-1        # STAR 24       Z

2DEC    -.5812035376 B-1        # STAR 23       X
2DEC    -.2909171294 B-1        # STAR 23       Y
2DEC    +.7599800468 B-1        # STAR 23       Z

2DEC    -.9170097662 B-1        # STAR 22       X
2DEC    -.3502146628 B-1        # STAR 22       Y
2DEC    -.1908999176 B-1        # STAR 22       Z
```

Uses STAR 186 and Z 80.

2054 ⟨*Page LM0049* 2054⟩≡ (2042 2666)

```
2DEC    -.4523440203 B-1        # STAR 21       X
2DEC    -.0493710140 B-1        # STAR 21       Y
2DEC    -.8904759346 B-1        # STAR 21       Z

2DEC    -.9525211695 B-1        # STAR 20       X
2DEC    -.0593434796 B-1        # STAR 20       Y
2DEC    -.2986331746 B-1        # STAR 20       Z

2DEC    -.9656605484 B-1        # STAR 19       X
2DEC    +.0525933156 B-1        # STAR 19       Y
2DEC    +.2544280809 B-1        # STAR 19       Z

2DEC    -.8608205219 B-1        # STAR 18       X
2DEC    +.4636213989 B-1        # STAR 18       Y
2DEC    +.2098647835 B-1        # STAR 18       Z

2DEC    -.7742591356 B-1        # STAR 17       X
2DEC    +.6152504197 B-1        # STAR 17       Y
2DEC    -.1482892839 B-1        # STAR 17       Z

2DEC    -.4657947941 B-1        # STAR 16       X
2DEC    +.4774785033 B-1        # STAR 16       Y
2DEC    +.7450164351 B-1        # STAR 16       Z

2DEC    -.3612508532 B-1        # STAR 15       X
2DEC    +.5747270840 B-1        # STAR 15       Y
2DEC    -.7342932655 B-1        # STAR 15       Z

2DEC    -.4118589524 B-1        # STAR 14       X
2DEC    +.9065485360 B-1        # STAR 14       Y
2DEC    +.0924226975 B-1        # STAR 14       Z

2DEC    -.1820751783 B-1        # STAR 13       X
```

Uses STAR 186 and Z 80.

2055 ⟨*Page LM0050* 2055⟩≡ (2042 2666)

```
2DEC    +.9404899869 B-1        # STAR 13       Y
2DEC    -.2869271926 B-1        # STAR 13       Z

2DEC    -.0614937230 B-1        # STAR 12       X
2DEC    +.6031563286 B-1        # STAR 12       Y
2DEC    -.7952489957 B-1        # STAR 12       Z

2DEC    +.1371725575 B-1        # STAR 11       X
2DEC    +.6813721061 B-1        # STAR 11       Y
2DEC    +.7189685267 B-1        # STAR 11       Z

2DEC    +.2011399589 B-1        # STAR 10       X
2DEC    +.9690337941 B-1        # STAR 10       Y
2DEC    -.1432348512 B-1        # STAR 10       Z

2DEC    +.3507315038 B-1        # STAR 9        X
2DEC    +.8926333307 B-1        # STAR 9        Y
2DEC    +.2831839492 B-1        # STAR 9        Z

2DEC    +.4105636020 B-1        # STAR 8        X
2DEC    +.4988110001 B-1        # STAR 8        Y
2DEC    +.7632988371 B-1        # STAR 8        Z

2DEC    +.7032235469 B-1        # STAR 7        X
2DEC    +.7075846047 B-1        # STAR 7        Y
2DEC    +.0692868685 B-1        # STAR 7        Z

2DEC    +.5450107404 B-1        # STAR 6        X
2DEC    +.5314955466 B-1        # STAR 6        Y
2DEC    -.6484410356 B-1        # STAR 6        Z

2DEC    +.0130968840 B-1        # STAR 5        X
2DEC    +.0078062795 B-1        # STAR 5        Y
```

Uses STAR 186 and Z 80.

2056 ⟨*Page LM0051* 2056⟩≡ (2042 2666)

```
                  2DEC    +.9998837600 B-1        # STAR 5        Z

                  2DEC    +.4917678276 B-1        # STAR 4        X
                  2DEC    +.2204887125 B-1        # STAR 4        Y
                  2DEC    -.8423473935 B-1        # STAR 4        Z

                  2DEC    +.4775639450 B-1        # STAR 3        X
                  2DEC    +.1166004340 B-1        # STAR 3        Y
                  2DEC    +.8708254803 B-1        # STAR 3        Z

                  2DEC    +.9342640400 B-1        # STAR 2        X
                  2DEC    +.1735073142 B-1        # STAR 2        Y
                  2DEC    -.3115219339 B-1        # STAR 2        Z

                  2DEC    +.8748658918 B-1        # STAR 1        X
                  2DEC    +.0260879174 B-1        # STAR 1        Y
                  2DEC    +.4836621670 B-1        # STAR 1        Z

CATLOG            DEC     6970

# ****************************************************************************

                  SETLOC  EPHEM1
                  BANK
                  COUNT*  $$/EPHEM

KONMAT            2DEC    1.0 B-1                 # ********************
                  2DEC    0                       #                    *
                  2DEC    0                       #                    *
                  2DEC    0                       #                    *
                  2DEC    .91745 B-1              # K1 COS(OBL)        *
                  2DEC    -.03571 B-1             # K2 SIN(OBL)SIN(IM) *
                  2DEC    0                       #                    *
                  2DEC    .39784 B-1              # K3 SIN(OBL)        *
```

Uses COUNT 142, EPHEM 65, STAR 186, and Z 80.

2057a ⟨*Page LM0052* 2057a⟩≡ (2042 2666)

```
                2DEC    .082354 B-1            # K4 COS(OBL)SIN(IM) *
CSTODAY         2DEC    8640000 B-33           #                  * NOTE:          *
RCB-13          OCT     00002                  #                  * TABLES CONTAIN *
                OCT     00000                  #                  * CONSTANTS FOR  *
RATESP          2DEC    .03660098 B+4          # LOMR             * 1969 - 1970    *
                2DEC    .00273779 B+4          # LOSR
                2DEC    -.00014719 B+4         # LONR
                2DEC    .815282336             # LOMO
                2DEC    .274674910             # LOSO
                2DEC    .986209499             # LONO
VAL67           2DEC*   .01726666666 B+1*      # AMOD
                2DEC    .530784445             # AARG
                2DEC    .036291712 B+1         # 1/27
                2DEC    .003505277 B+1         # BMOD
                2DEC    .585365625             # BARG
                2DEC    .03125 B+1             # 1/32
                2DEC    .005325277 B+1         # CMOD
                2DEC    -.01106341036          # CARG
                2DEC    .002737925 B+1         # 1/365

# ******************************************************************************

                SETLOC  PLANTIN2
                BANK
                COUNT*  $$/LUROT

COSI            2DEC    .99964173 B-1          # COS (5521.5 SEC.) B-1
SINI            2DEC    .02676579 B-1          # SIN (5521.5 SEC.) B-1
NODDOT          2DEC    -.457335121 E-2        # REV/CSEC B+28 = -1.07047011 E-8 RAD/SEC
FDOT            2DEC    .570863327             # REV/CSEC B+27 =  2.67240410 E-6 RAD/SEC
```

Uses COUNT 142 and RAD 219.

2057b ⟨*Page LM0053* 2057b⟩≡ (2042 2666)

```
BDOT            2DEC    -3.07500686 E-8        # REV/CSEC B+28 = -7.19757301 E-14 RAD/SEC
NODIO           2DEC    .986209434             # REVS B-D      = 6.19653663041 RAD
FSUBO           2DEC    .829090536             # REVS B-D      = 5.20932947829 RAD
BSUBO           2DEC    .0651201393            # REVS B-D      = 0.40916190299 RAD
WEARTH          2DEC    .973561595             # REV/CSEC B+23 = 7.29211494 E-5 RAD/SEC
```

Uses D 226, RAD 219, and REVS 206.

4.2 input output channel bit descriptions

2058 ⟨*input output channel bit descriptions* 2058⟩≡ (2041)

⟨*Page LM0054* 2059⟩
⟨*Page LM0055* 2060⟩
⟨*Page LM0056* 2061⟩
⟨*Page LM0057* 2062⟩
⟨*Page LM0058* 2063⟩
⟨*Page LM0059* 2064a⟩
⟨*Page LM0060* 2064b⟩

2059 ⟨*Page LM0054* 2059⟩≡ (2058 2717)

```
# *** CHANNEL DESCRIPTION WORDS ARE ALLOCATED IN ERASABLE ASSIGNMENTS ***

# CHANNEL 1     IDENTICAL TO COMPUTER REGISTER L (0001)

# CHANNEL 2     IDENTICAL TO COMPUTER REGISTER Q (0002)

# CHANNEL 3     HISCALAR: INPUT CHANNEL; MOST SIGNIFICANT 14 BITS FROM 33 STAGE BINARY COUNTER.
#               FACTOR IS B23 IN CSEC, SO MAX VALUE ABOUT 23.3 HOURS AND LEAST SIGNIFICANT BIT

# CHANNEL 4     LOSCALAR: INPUT CHANNEL; NEXT MOST SIGNIFICANT 14 BITS FROM THE 33 STAGE BINARY
#               ASSOCIATED WITH CHANNEL 3. SCALE FACTOR IS B9 IN CSEC. SO MAX VAL IS 5.12 SEC A
#               SIGNIFICANT BIT IS 1/3200 SEC. SCALE FACTOR OF D.P. WORD WITH CHANNEL 3 IS B23

# CHANNEL 5     PYJETS:  OUTPUT CHANNEL; PITCH RCS JET CONTROL.  (REACTION CONTROL SYSTEM) USES

# CHANNEL 6     ROLLJETS: OUTPUT CHANNEL; ROLL RCS JET CONTROL.  (REACTION CONTROL SYSTEM) USES

# CHANNEL 7     SUPERBNK: OUTPUT CHANNEL; NOT RESET BY RESTART; FIXED EXTENSION BITS USED TO SE
#               APPROPRIATE FIXED MEMORY BANK IF FBANK IS 30 OCTAL OR MORE.  USES BITS 5-7.

# CHANNEL 10    OUT0: OUTPUT CHANNEL; REGISTER USED TO TRANSMIT LATCHING-RELAY DRIVING INFORMAT
#               THE DISPLAY SYSTEM.  BITS 15-12 ARE SET TO THE ROW NUMBER (1-14 OCTAL) OF THE R
#               CHANGED AND BITS 11-1 CONTAIN THE REQUIRED SETTINGS FOR THE RELAYS IN THE ROW.

# CHANNEL 11    DSALMOUT: OUTPUT CHANNEL; REGISTER WHOSE BITS ARE USED FOR ENGINE ON-OFF CONTRO
#               DRIVE INDIVIDUAL INDICATORS OF THE DISPLAY SYSTEM.  BITS 1-7 ARE A RELAYS.
#
#               BIT 1           ISS WARNING
#               BIT 2           LIGHT COMPUTER ACTIVITY LAMP
#               BIT 3           LIGHT UPLINK ACTIVITY LAMP
#               BIT 4           LIGHT TEMP CAUTION LAMP
#               BIT 5           LIGHT KEYBOARD RELEASE LAMP
#               BIT 6           FLASH VERB AND NOUN LAMPS
#               BIT 7           LIGHT OPERATOR ERROR LAMP
```

Uses A 80, COMPUTER 115, D 226, DSALMOUT 87, FACTOR 226, FBANK 80, HISCALAR 87, L 80, LOSCALAR 87, OUT0 87, P 188, PYJETS 87, Q 80, RESTART 57, ROLLJETS 87, SUPERBNK 87, and TEMP 191.

2060 ⟨*Page LM0055* 2060⟩≡ (2058 2717)

```
#               BIT 8           SPARE
#               BIT 9           TEST CONNECTOR OUTBIT
#               BIT 10          CAUTION RESET
#               BIT 11          SPARE
#               BIT 12          SPARE
#               BIT 13          ENGINE ON
#               BIT 14          ENGINE OFF
#               BIT 15          SPARE

# CHANNEL 12    CHAN12: OUTPUT CHANNEL; BITS USED TO DRIVE NAVIGATION AND SPACECRAFT
#
#               BIT 1           ZERO RR CDU; CDU'S GIVE RRADAR INFORMATION FOR LM
#               BIT 2           ENABLE CDU RADAR ERROR COUNTERS
#               BIT 3           NOT USED
#               BIT 4           COARSE ALIGN ENABLE OF IMU
#               BIT 5           ZERO IMU CDU'S
#               BIT 6           ENABLE IMU ERROR COUNTER, CDU ERROR COUNTER.
#               BIT 7           SPARE
#               BIT 8           DISPLAY INERTIAL DATA
#               BIT 9           -PITCH GIMBAL TRIM (BELL MOTION) DESCENT ENGINE
#               BIT 10          +PITCH GIMBAL TRIM (BELL MOTION) DESCENT ENGINE
#               BIT 11          -ROLL GIMBAL TRIM (BELL MOTION) DESCENT ENGINE
#               BIT 12          +ROLL GIMBAL TRIM (BELL MOTION) DESCENT ENGINE
#               BIT 13          LR POSITION 2 COMMAND
#               BIT 14          ENABLE RENDEZVOUS RADAR LOCK-ON; AUTO ANGLE TRACK'G
#               BIT 15          ISS TURN ON DELAY COMPLETE
```

Uses CHAN12 87 and COMMAND 169.

2061 ⟨*Page LM0056* 2061⟩≡ (2058 2717)

```
# CHANNEL 13    CHAN13: OUTPUT CHANNEL.
#
#               BIT 1           RADAR C         PROPER SETTING OF THE A,B,C MATRIX
#               BIT 2           RADAR B         SELECTS CERTAIN RADAR
#               BIT 3           RADAR A         PARAMETERS TO BE READ.
#               BIT 4           RADAR ACTIVITY
#               BIT 5           NOT USED (CONNECTS AN ALTERNATE INPUT TO UPLINK)
#               BIT 6           BLOCK INPUTS TO UPLINK CELL
#               BIT 7           DOWNLINK TELEMETRY WORD ORDER CODE BIT
#               BIT 8           RHC COUNTER ENABLE (READ HAND CONTROLLER ANGLES)
#               BIT 9           START RHC READ INTO COUNTERS IS BIT 8 SET
#               BIT 10          TEST ALARMS, TEST DSKY LIGHTS
#               BIT 11          ENABLE STANDBY
#               BIT 12          RESET TRAP 31-A         ALWAYS APPEAR TO BE SET TO 0
#               BIT 13          RESET TRAP 31-B         ALWAYS APPEAR TO BE SET TO 0
#               BIT 14          RESET TRAP 32           ALWAYS APPEAR TO BE SET TO 0
#               BIT 15          ENABLE T6 RUPT

# CHANNEL 14    CHAN14: OUTPUT CHANNEL; USED TO CONTROL COMPUTER COUNTER CELLS (CDU, GYRO, SPAC
#
#               BIT 1           OUTLINK ACTIVITY (NOT USED)
#               BIT 2           ALTITUDE RATE OR ALTITUDE SELECTOR
#               BIT 3           ALTITUDE METER ACTIVITY
#               BIT 4           THRUST DRIVE ACTIVITY FOR DESCENT ENGINE
#               BIT 5           SPARE
#               BIT 6           GYRO ENABLE POWER FOR PULSES
#               BIT 7           GYRO SELECT B           PAIR OF BITS IDENTIFIES AXIS OF
#               BIT 8           GYRO SELECT A           GYRO SYSTEM TO BE TORQUED.
#               BIT 9           GYRO TORQUING COMMAND IN NEGATIVE DIRECTION.
```

Uses A 80, CHAN13 87, CHAN14 87, CODE 140, COMMAND 169, COMPUTER 115, and THRUST 85.

2062 ⟨*Page LM0057* 2062⟩≡ (2058 2717)

```
#               BIT 10          GYRO ACTIVITY
#               BIT 11          DRIVE CDU S
#               BIT 12          DRIVE CDU T
#               BIT 13          DRIVE CDU Z
#               BIT 14          DRIVE CDU Y
#               BIT 15          DRIVE CDU X

# CHANNEL 15    MNKEYIN: INPUT CHANNEL; KEY CODE INPUT FROM KEYBOARD OF DSKY, SENSED
#               PROGRAM INTERRUPT #5 IS RECEIVED.  USED BITS 5-1

# CHANNEL 16    NAVKEYIN: INPUT CHANNEL; OPTICS MARK INFORMATION AND NAVIGATION PANEL
#               CONTROL (LM) SENSED BY PROGRAM THEN PROGRAM INTERRUPT #6 IS RECEIVED.
#
#               BIT 1           NOT ASSIGNED
#               BIT 2           NOT ASSIGNED
#               BIT 3           OPTICS X-AXIS MARK SIGNAL FOR ALIGN OPTICAL TSCOPE
#               BIT 4           OPTICS Y-AXIS MARK SIGNAL FOR AOT
#               BIT 5           OPTICS MARK REJECT SIGNAL
#               BIT 6           DESCENT+ ; CREW DESIRED SLOWING RATE OF DESCENT
#               BIT 7           DESCENT- ; CREW DESIRED SPEEDING UP RATE OF D'CENT

# NOTE: ALL BITS IN CHANNELS 30-33 ARE INVERTED AS SENSED BY THE PROGRAM, SO THAT A V
# THAT THE INDICATED SIGNAL IS PRESENT.

# CHANNEL 30    INPUT CHANNEL
#
#               BIT 1           ABORT WITH DESCENT STAGE
#               BIT 2           UNUSED
#               BIT 3           ENGINE ARMED SIGNAL
#               BIT 4           ABORT WITH ASCENT ENGINE STAGE
#               BIT 5           AUTO THROTTLE; COMPUTER CONTROL OF DESCENT ENGINE
```

Uses A 80, CODE 140, COMPUTER 115, MNKEYIN 87, NAVKEYIN 87, THRUST 85, and Z 80.

2063 ⟨*Page LM0058* 2063⟩≡ (2058 2717)

```
#               BIT 6           DISPLAY INERTIAL DATA
#               BIT 7           RR CDU FAIL
#               BIT 8           SPARE
#               BIT 9           IMU OPERATE WITH NO MALFUNCTION
#               BIT 10          LM COMPUTER (NOT AGS) HAS CONTROL OF LM.
#               BIT 11          IMU CAGE COMMAND TO DRIVE IMU GIMBAL ANGLES TO 0.
#               BIT 12          IMU CDU FAIL (MALFUNCTION OF IMU CDU,S)
#               BIT 13          IMU FAIL (MALFUNCTION OF IMU STABILIZATION LOOPS)
#               BIT 14          ISS TURN ON REQUESTED
#               BIT 15          TEMPERATURE OF STABLE MEMBER WITHIN DESIGN LIMITS

# CHANNEL 31    INPUT CHANNEL; BITS ASSOCIATED WITH THE ATTITUDE CONTROLLER, TRANSLATIONAL CONT
#               AND SPACECRAFT ATTITUDE CONTROL; USED BY RCS DAP.
#
#               BIT 1           ROTATION (BY RHC) COMMANDED IN POSITIVE PITCH DIRECTION; MUST B
#                               ALSO POSITIVE ELEVATION CHANGE FOR LANDING POINT DESIGNATOR
#               BIT 2           AS BIT 1 EXCEPT NEGATIVE PITCH AND ELEVATION.
#               BIT 3           ROTATION (BY RHC) COMMANDED IN POSITIVE YAW DIRECTION; MUST BE
#               BIT 4           AS BIT 3 EXCEPT NEGATIVE YAW
#               BIT 5           ROTATION (BY RHC) COMMANDED IN POSITIVE ROLL DIRECTION; MUST BE
#                               ALSO POSITIVE AZIMUTH CHANGE FOR LANDING POINT DESIGNATOR.
#               BIT 6           AS BIT 5 EXCEPT NEGATIVE ROLL AND AZIMUTH
#               BIT 7           TRANSLATION IN +X DIRECTION COMMANDED BY THC
#               BIT 8           TRANSLATION IN -X DIRECTION COMMANDED BY THC
#               BIT 9           TRANSLATION IN +Y DIRECTION COMMANDED BY THC
#               BIT 10          TRANSLATION IN -Y DIRECTION COMMANDED BY THC
#               BIT 11          TRANSLATION IN +Z DIRECTION COMMANDED BY THC
#               BIT 12          TRANSLATION IN -Z DIRECTION COMMANDED BY THC
```

Uses AZIMUTH 191, COMMAND 169, COMPUTER 115, MODE 145, and Z 80.

2064a ⟨*Page LM0059* 2064a⟩≡ (2058 2717)

```
#               BIT 13          ATTITUDE HOLD MODE ON SCS MODE CONTROL SWITCH
#               BIT 14          AUTO STABILIZATION OF ATTITUDE ON SCS MODE SWITCH
#               BIT 15          ATTITUDE CONTROL OUT OF DETENT (RHC NOT IN NEUTRAL)

# CHANNEL 32    INPUT CHANNEL.
#
#               BIT 1           THRUSTERS 2 & 4 DISABLED BY CREW
#               BIT 2           THRUSTERS 5 & 8 DISABLED BY CREW
#               BIT 3           THRUSTERS 1 & 3 DISABLED BY CREW
#               BIT 4           THRUSTERS 6 & 7 DISABLED BY CREW
#               BIT 5           THRUSTERS 14 & 16 DISABLED BY CREW
#               BIT 6           THRUSTERS 13 & 15 DISABLED BY CREW
#               BIT 7           THRUSTERS 9 & 12 DISABLED BY CREW
#               BIT 8           THRUSTERS 10 & 11 DISABLED BY CREW
#               BIT 9           DESCENT ENGINE DISABLED BY CREW
#               BIT 10          APPARENT DESCENT ENGINE GIMBAL FAILURE
#               BIT 14          INDICATES PROCEED KEY IS DEPRESSED

# CHANNEL 33    CHAN33: INPUT CHANNEL; FOR HARDWARE STATUS AND COMMAND INFORMATION.
#               FLOP BITS RESET BY A CHANNEL "WRITE" COMMAND THAT ARE RESET BY A REST
#
#               BIT 1           SPARE
#               BIT 2           RR AUTO-POWER ON
#               BIT 3           RR RANGE LOW SCALE
#               BIT 4           RR DATA GOOD
#               BIT 5           LR RANGE DATA GOOD
#               BIT 6           LR POS1
#               BIT 7           LR POS2
```

Uses `A` 80, `CHAN33` 87, `COMMAND` 169, `MODE` 145, `RANGE` 179, and `RESTART` 57.

2064b ⟨*Page LM0060* 2064b⟩≡ (2058 2717)

```
#               BIT 8           LR VEL DATA GOOD
#               BIT 9           LR RANGE LOW SCALE
#               BIT 10          BLOCK UPLINK INPUT
#               BIT 11          UPLINK TOO FAST
#               BIT 12          DOWNLINK TOO FAST
#               BIT 13          PIPA FAIL
#               BIT 14          WARNING OF REPEATED ALARMS: RESTART, COUNTER FAIL, VC
#               BIT 15          LGC OSCILLATOR STOPPED

# CHANNEL 34    DNT M1: OUTPUT CHANNEL; DOWNLINK 1: FIRST OF TWO WORDS SERIALIZATION.
# CHANNEL 35    DNT M2: OUTPUT CHANNEL; DOWNLINK 2: SECOND OF TWO WORDS SERIALIZATION
```

Uses `RANGE` 179, `RESTART` 57, and `VEL` 226.

4.3 flagword assignments

2065 ⟨*flagword assignments* 2065⟩≡ (2041)

⟨*Page LM0061* 2066⟩
⟨*Page LM0062* 2068⟩
⟨*Page LM0063* 2070⟩
⟨*Page LM0064* 2072⟩
⟨*Page LM0065* 2074⟩
⟨*Page LM0066* 2075⟩
⟨*Page LM0067* 2076⟩
⟨*Page LM0068* 2078⟩
⟨*Page LM0069* 2079⟩
⟨*Page LM0070* 2080⟩
⟨*Page LM0071* 2081⟩
⟨*Page LM0072* 2082⟩
⟨*Page LM0073* 2084⟩
⟨*Page LM0074* 2086⟩
⟨*Page LM0075* 2087⟩
⟨*Page LM0076* 2089⟩
⟨*Page LM0077* 2091⟩
⟨*Page LM0078* 2092⟩
⟨*Page LM0079* 2094⟩
⟨*Page LM0080* 2096⟩
⟨*Page LM0081* 2098⟩
⟨*Page LM0082* 2100⟩
⟨*Page LM0083* 2102⟩
⟨*Page LM0084* 2103⟩
⟨*Page LM0085* 2104⟩
⟨*Page LM0086* 2105⟩
⟨*Page LM0087* 2106⟩
⟨*Page LM0088* 2107a⟩
⟨*Page LM0089* 2107b⟩

2066 ⟨*Page LM0061* 2066⟩≡ (2065 2698)

```
# FLAGWORDS 0-11        ARE DOWNLINKED AND CAN BE SET AND CLEARED BY UP-FLAG AND DOWN
#                       INTERPRETER.  THESE WERE PREVIOUSLY LISTED UNDER "INTERPRETIV
#                       THE ERASABLE LOG SECTION.  FLAGWORDS 12 & 13 WERE PREVIOUSLY
#                       ARE STILL DOWNLINKED UNDER THOSE NAMES.

#               ALPHABETICAL LIST OF FLAGWORDS

#
# FLAGWORD      DEC. NUMBER     BIT AND FLAG            BIT NAME

# ACCOKFLG      207             BIT  3 FLAG 13          ACCSOKAY
# ACC4-2FL      199             BIT 11 FLAG 13          ACC4OR2X
# ACMODFLG      032             BIT 13 FLAG  2          ACMODBIT
# ALTSCALE      186             BIT  9 FLAG 12          ALTSCBIT
# ANTENFLG      183             BIT 12 FLAG 12          ANTENBIT
# AORBSFLG      205             BIT  5 FLAG 13          AORBSYST
# AORBTFLG      200             BIT 10 FLAG 13          AORBTRAN
# APSESW        130             BIT  5 FLAG  8          APSESBIT
# APSFLAG       152             BIT 13 FLAG 10          APSFLBIT
# ASTNFLAG      108             BIT 12 FLAG  7          ASTNBIT
# ATTFLAG       104             BIT  1 FLAG  6          ATTFLBIT
# AUTOMODE      193             BIT  2 FLAG 12          AUTOMBIT
# AUTR1FLG      209             BIT  1 FLAG 13          AUTRATE1
# AUTR2FLG      208             BIT  2 FLAG 13          AUTRATE2
# AUXFLAG       103             BIT  2 FLAG  6          AUXFLBIT
# AVEGFLAG      115             BIT  5 FLAG  7          AVEGFBIT
# AVEMIDSW      149             BIT  1 FLAG  9          AVEMDBIT
# AVFLAG        040             BIT  5 FLAG  2          AVFLBIT
# CALCMAN2      043             BIT  2 FLAG  2          CALC2BIT
# CALCMAN3      042             BIT  3 FLAG  2          CALC3BIT
# CDESFLAG      180             BIT 15 FLAG 12          CDESBIT
# CMOONFLG      123             BIT 12 FLAG  8          CMOONBIT
# COGAFLAG      131             BIT  4 FLAG  8          COGAFBIT
# CSMDKFLG      197             BIT 13 FLAG 13          CSMDOCKD
# CULTFLAG      053             BIT  7 FLAG  3          CULTBIT
# DAPBOOLS                      FLGWRD13
# DBSELFLG      206             BIT  4 FLAG 13          DBSELECT
# DESIGFLG      185             BIT 10 FLAG 12          DESIGBIT
# DIDFLAG       016             BIT 14 FLAG             DIDFLBIT
# DIMOFLAG      059             BIT  1 FLAG  3          DIMOBIT
# DMENFLG       081             BIT  9 FLAG  5          DMENFBIT
# DRIFTDFL      202             BIT  8 FLAG 13          DRIFTBIT
# DRIFTFLG      030             BIT 15 FLAG  2          DRFTBIT
# DSKYFLAG      075             BIT 15 FLAG  5          DSKYFBIT
```

Uses APSESBIT 127, APSESW 127, ASTNBIT 123, ASTNFLAG 123, AVEGFLAG 101, AVEMDBIT 133,

AVEMIDSW 133, AVFLAG 105, AVFLBIT 105, CALC2BIT 105, CALCMAN2 105, CMOONBIT 125, CMOONFLG 125, COGAFBIT 127, COGAFLAG 127, CULTBIT 107, CULTFLAG 107, DMENFBIT 115, DMENFLG 115, DRFTBIT 101, DRIFTFLG 101, and DSKYFLAG 113.

2068 ⟨*Page LM0062* 2068⟩≡ (2065 2698)

```
# D6OR9FLG      058            BIT  2 FLAG  3          D6OR9BIT
# ENGONFLG      083            BIT  7 FLAG  5          ENGONBIT
# ERADFLAG      017            BIT 13 FLAG  1          ERADFBIT
# ETPIFLAG      038            BIT  7 FLAG  2          ETPIBIT         EQUIVALENT FI
# FINALFLG      039            BIT  6 FLAG  2          FINALBIT
# FLAGWRD0      (000-014)      (STATE +0)
# FLAGWRD1      (015-029)      (STATE +1)
# FLAGWRD2      (030-044)      (STATE +2)
# FLAGWRD3      (045-059)      (STATE +3)
# FLAGWRD4      (060-074)      (STATE +4)
# FLAGWRD5      (075-089)      (STATE +5)
# FLAGWRD6      (090-104)      (STATE +6)
# FLAGWRD7      (105-119)      (STATE +7)
# FLAGWRD8      (120-134)      (STATE +8D)
# FLAGWRD9      (135-149)      (STATE +9D)
# FLAP          142            BIT  8 FLAG  9          FLAPBIT
# FLGWRD10      (150-164)      (STATE +10D)
# FLGWRD11      (165-179)      (STATE +11D)
# FLGWRD12      (180-194)      (STATE +12D)
# FLGWRD13      (195-209)      (STATE +13D)
# FLPC          138            BIT 12 FLAG  9          FLPCBIT
# FLPI          139            BIT 11 FLAG  9          FLPIBIT
# FLRCS         149            BIT 10 FLAG  9          FLRCSBIT
# FLUNDISP      125            BIT 10 FLAG  8          FLUNDBIT
# FLVR          136            BIT 14 FLAG  9          FLVRBIT
# FREEFLAG      012            BIT  3 FLAG  0          FREEFBIT
# FSPASFLG      005            BIT 10 FLAG  0          FSPASBIT
# GLOKFAIL      046            BIT 14 FLAG  3          GLOKFBIT
# GMBDRVSW      095            BIT 10 FLAG  6          GMBDRBIT
# GUESSW        028            BIT  2 FLAG  1          GUESSBIT
# HFLSHFLG      179            BIT  1 FLAG 11          HFLSHBIT
# IDLEFLAG      113            BIT  7 FLAG  7          IDLEFBIT
# IGNFLAG       107            BIT 13 FLAG  7          IGNFLBIT
# IMPULSW       036            BIT  9 FLAG  2          IMPULBIT
# IMUSE         007            BIT  8 FLAG  0          IMUSEBIT
# INFINFLG      128            BIT  7 FLAG  8          INFINBIT
# INITALGN      133            BIT  2 FLAG  8          INITABIT
# INTFLAG       151            BIT 14 FLAG 10          INTFLBIT
# INTYPFLG      056            BIT  4 FLAG  3          INTYPBIT
# ITSWICH       105            BIT 15 FLAG  7          ITSWBIT
# JSWITCH       001            BIT 14 FLAG  0          JSWCHBIT
# LETABORT      141            BIT  9 FLAG  9          LETABBIT
# LMOONFLG      124            BIT 11 FLAG  8          LMOONBIT
# LOKONSW       010            BIT  5 FLAG  0          LOKONBIT
# LOSCMFLG      033            BIT 12 FLAG  2          LOSCMBIT
```

```
# LRALTFLG      190             BIT  5 FLAG 12          LRALTBIT
# LRBYPASS      165             BIT 15 FLAG 11          LRBYBIT
# LRINH         172             BIT  8 FLAG 11          LRINHBIT
# LRPOSFLG      189             BIT  6 FLAG 12          LRPOSBIT
# LRVELFLG      187             BIT  8 FLAG 12          LRVELBIT
```

Uses D6OR9BIT 109, D6OR9FLG 109, ENGONBIT 115, ENGONFLG 115, ERADFBIT 99, ERADFLAG 99, ETPIFLAG 103, FINALBIT 105, FINALFLG 105, FLAGWRD0 95, FLAGWRD1 97, FLAGWRD2 101, FLAGWRD3 105, FLAGWRD4 109, FLAGWRD5 113, FLAGWRD6 117, FLAGWRD7 121, FLAGWRD8 125, FLGWRD10 133, FLGWRD11 135, FREEFBIT 97, FREEFLAG 97, GLOKFAIL 105, GLOKFBIT 105, GUESSBIT 101, GUESSW 101, IGNFLAG 123, IGNFLBIT 123, IMPULBIT 103, IMPULSW 103, IMUSE 95, IMUSEBIT 97, INFINBIT 127, INFINFLG 127, INTFLAG 133, INTFLBIT 133, INTYPFLG 107, ITSWBIT 123, ITSWICH 121, JSWCHBIT 95, JSWITCH 95, LMOONBIT 125, LMOONFLG 125, and STATE 138.

2070 ⟨*Page LM0063* 2070⟩≡ (2065 2698)

```
# LUNAFLAG      048          BIT 12 FLAG  3        LUNABIT
# MANUFLAG      106          BIT 14 FLAG  7        MANUFBIT
# MGLVFLAG      088          BIT  2 FLAG  5        MGLVFBIT
# MIDAVFLG      148          BIT  2 FLAG  9        MIDAVBIT
# MIDFLAG       002          BIT 13 FLAG  0        MIDFLBIT
# MID1FLAG      147          BIT  3 FLAG  9        MID1BIT
# MKOVFLAG      072          BIT  3 FLAG  4        MKOVBIT
# MOONFLAG      003          BIT 12 FLAG  0        MOONBIT
# MRKIDFLG      060          BIT 15 FLAG  4        MRKIDBIT
# MRKNVFLG      066          BIT  9 FLAG  4        MRKNVBIT
# MRUPTFLG      070          BIT  5 FLAG  4        MRUPTBIT
# MUNFLAG       097          BIT  8 FLAG  6        MUNFLBIT
# MWAITFLG      064          BIT 11 FLAG  4        MWAITBIT
# NEEDLFLG      011          BIT  4 FLAG  0        NEEDLBIT
# NEWIFLG       122          BIT 13 FLAG  8        NEWIBIT
# NJETSFLG      015          BIT 15 FLAG           NJETSBIT
# NODOFLAG      044          BIT  1 FLAG  2        NODOBIT
# NOLRREAD      170          BIT 10 FLAG 11        NOLRRBIT
# NORMSW        110          BIT 10 FLAG  7        NORMSBIT
# NORRMON       086          BIT  4 FLAG  5        NORRMBIT
# NOR29FLG      049          BIT 11 FLAG  3        NR29FBIT
# NOTHROTL      078          BIT 12 FLAG  5        NOTHRBIT
# NOUPFLAG      024          BIT  6 FLAG  1        NOUPFBIT
# NRMNVFLG      067          BIT  8 FLAG  4        NRMNVBIT
# NRMIDFLG      062          BIT 13 FLAG  4        NRMIDBIT
# NRUPTFLG      071          BIT  4 FLAG  4        NRUPTBIT
# NTARGFLG      102          BIT  3 FLAG  6        NTARGBIT
# NWAITFLG      065          BIT 10 FLAG  4        NWAITBIT
# OLDESFLG      014          BIT  1 FLAG  0        OLDESBIT
# OPTNSW        038          BIT  7 FLAG  2        OPTNBIT         EQUIVALENT FI
# ORBWFLAG      054          BIT  6 FLAG  3        ORBWFBIT
# ORDERSW       129          BIT  6 FLAG  8        ORDERBIT
# OURRCFLG      198          BIT 12 FLAG 13        OURRCBIT
# PDSPFLAG      063          BIT 12 FLAG  4        PDSPFBIT
# PFRATFLG      041          BIT  4 FLAG  2        PFRATBIT
# PINBRFLG      069          BIT  6 FLAG  4        PINBRBIT
# PRECIFLG      052          BIT  8 FLAG  3        PRECIBIT
# PRIODFLG      061          BIT 14 FLAG  1        PRIODBIT
# PRONVFLG      068          BIT  7 FLAG  4        PRONVBIT
# PSTHIGAT      169          BIT 11 FLAG 11        PSTHIBIT
# PULSEFLG      195          BIT 15 FLAG 13        PULSES
# P21FLAG       004          BIT 11 FLAG  0        P21FLBIT
# P25FLAG       006          BIT  9 FLAG  0        P25FLBIT
# P39/79SW      126          BIT  9 FLAG  8        P39SWBIT
# QUITFLAG      145          BIT 5 FLAG 9          QUITBIT
```

```
# RADMODES                    FLGWRD12
# RASFLAG                     FLGWRD10
# RCDUFAIL      188           BIT  7 FLAG 12          RCDUFBIT
# RCDU0FLG      182           BIT 13 FLAG 12          RCDU0BIT
# READLR        174           BIT  6 FLAG 11          READLBIT
```

Uses ETPIFLAG 103, FLGWRD10 133, LUNABIT 107, LUNAFLAG 107, MGLVFBIT 117, MGLVFLAG 117, MID1FLAG 131, MIDAVBIT 133, MIDAVFLG 131, MIDFLAG 95, MIDFLBIT 95, MKOVBIT 113, MKOVFLAG 113, MOONBIT 95, MOONFLAG 95, MRKIDBIT 109, MRKIDFLG 109, MRKNVBIT 111, MRKNVFLG 111, MRUPTBIT 111, MRUPTFLG 111, MWAITBIT 111, MWAITFLG 109, NEEDLBIT 95, NEEDLFLG 95, NEWIBIT 125, NEWIFLG 125, NJETSBIT 97, NJETSFLG 97, NODOBIT 105, NODOFLAG 105, NORMSBIT 123, NORMSW 123, NRMIDBIT 109, NRMIDFLG 109, NRMNVBIT 111, NRMNVFLG 111, NRUPTBIT 113, NRUPTFLG 113, NWAITBIT 111, NWAITFLG 111, OPTNSW 105, ORBWFBIT 107, ORBWFLAG 107, ORDERBIT 127, ORDERSW 127, P21FLAG 103, P39/79SW 127, P39SWBIT 127, PDSPFBIT 109, PDSPFLAG 109, PFRATBIT 105, PFRATFLG 105, PINBRBIT 111, PINBRFLG 111, PRECIBIT 107, PRECIFLG 107, PRIODBIT 109, PRIODFLG 109, PRONVBIT 111, PRONVFLG 111, QUITBIT 131, QUITFLAG 131, and RASFLAG 133.

2072 ⟨*Page LM0064* 2072⟩≡ (2065 2698)

```
# READRFLG      051          BIT  9 FLAG  3        READRBIT        EQUIVALENT FI
# READVEL       175          BIT  5 FLAG 11        READVBIT
# REDFLAG       099          BIT  6 FLAG  6        REDFLBIT
# REFSMFLG      047          BIT 13 FLAG  3        REFSMBIT
# REINTFLG      158          BIT  7 FLAG 10        REINTBIT
# REMODFLG      181          BIT 14 FLAG 12        REMODBIT
# RENDWFLG      089          BIT  1 FLAG  5        RENDWBIT
# REPOSMON      184          BIT 11 FLAG 12        REPOSBIT
# RHCSCFLG      203          BIT  7 FLAG 13        RHCSCALE
# RNDVZFLG      008          BIT  7 FLAG  0        RNDVZBIT
# RNGEDATA      176          BIT  4 FLAG 11        RNGEDBIT
# RNGSCFLG      080          BIT 10 FLAG  5        RNGSCBIT
# RODFLAG       018          BIT 12 FLAG  1        RODFLBIT
# ROTFLAG       144          BIT  6 FLAG  9        ROTFLBIT
# RPQFLAG       120          BIT 15 FLAG  8        RPQFLBIT
# RRDATAFL      191          BIT  4 FLAG 12        RRDATABT
# RRNBSW        009          BIT  6 FLAG  0        RRNBBIT
# RRRSFLAG      192          BIT  3 FLAG 12        RRRSBIT
# RVSW          111          BIT  9 FLAG  7        RVSWBIT
# R04FLAG       051          BIT  9 FLAG  3        R04FLBIT        EQUIVALENT FI
# R10FLAG       013          BIT  2 FLAG  0        R10FLBIT
# R61FLAG       020          BIT 10 FLAG  1        R61FLBIT
# R77FLAG       079          BIT 11 FLAG  5        R77FLBIT
# SCALBAD       177          BIT  3 FLAG 11        SCABBIT
# SLOPESW       027          BIT  3 FLAG  1        SLOPEBIT
# SNUFFER       077          BIT 13 FLAG  5        SNUFFBIT
# SOLNSW        087          BIT  3 FLAG  5        SOLNSBIT
# SRCHOPTN      031          BIT 14 FLAG  2        SRCHOBIT
# STATEFLG      055          BIT  5 FLAG  3        STATEBIT
# STEERSW       034          BIT 11 FLAG  2        STEERBIT
# SURFFLAG      127          BIT  8 FLAG  8        SURFFBIT
# SWANDISP      109          BIT 11 FLAG  7        SWANDBIT
# S32.1F1       090          BIT 15 FLAG  6        S32BIT1
# S32.1F2       091          BIT 14 FLAG  6        S32BIT2
# S32.1F3A      092          BIT 13 FLAG  6        S32BIT3A
# S32.1F3B      093          BIT 12 FLAG  6        S32BIT3B
# TFFSW         119          BIT  1 FLAG  7        TFFSWBIT
# TRACKFLG      025          BIT  5 FLAG  1        TRACKBIT
# TURNONFL      194          BIT  1 FLAG 12        TURNONBT
# ULLAGFLG      204          BIT  6 FLAG 13        ULLAGER
# UPDATFLG      023          BIT  7 FLAG  1        UPDATBIT
# UPLOCKFL      116          BIT  4 FLAG 7         UPLOCBIT
# USEQRFLG      196          BIT 14 FLAG 13        USEQRJTS
# VEHUPFLG      022          BIT  8 FLAG  1        VEHUPBIT
# VELDATA       173          BIT  7 FLAG 11        VELDABIT
```

```
# VERIFLAG      117             BIT  3 FLAG  7          VERIFBIT
# VFLAG         050             BIT 10 FLAG  3          VFLAGBIT
# VFLSHFLG      178             BIT  2 FLAG 11          VFLSHBIT
# VINTFLAG      057             BIT  3 FLAG  3          VINTFBIT
# VXINH         168             BIT 12 FLAG 11          VXINHBIT
```

Uses REFSMBIT 107, REFSMFLG 107, REINTBIT 135, REINTFLG 135, RENDWBIT 117, RENDWFLG 117, RNDVZBIT 97, RNDVZFLG 97, RNGSCFLG 115, RPQFLAG 125, RPQFLBIT 125, RVSW 123, RVSWBIT 123, S32.1F1 135, S32.1F2 135, S32.1F3A 135, S32.1F3B 135, S32BIT1 135, S32BIT2 135, S32BIT3A 135, SLOPEBIT 101, SLOPESW 101, SOLNSBIT 117, SOLNSW 115, STATEBIT 107, STATEFLG 107, STEERBIT 103, STEERSW 103, SURFFBIT 127, SURFFLAG 127, TFFSW 125, TFFSWBIT 125, TRACKBIT 101, TRACKFLG 101, UPDATBIT 101, UPDATFLG 99, UPLOCBIT 125, UPLOCKFL 125, VEHUPBIT 99, VEHUPFLG 99, VERIFBIT 125, VERIFLAG 125, VFLAG 107, VFLAGBIT 107, VINTFBIT 109, and VINTFLAG 109.

2074 ⟨*Page LM0065* 2074⟩≡ (2065 2698)

```
# V37FLAG       114             BIT  6 FLAG  7          V37FLBIT
# V67FLAG       112             BIT  8 FLAG  7          V67FLBIT
# V82EMFLG      118             BIT  2 FLAG  7          V82EMBIT
# XDELVFLG      037             BIT  8 FLAG  2          XDELVBIT
# XDSPFLAG      074             BIT  1 FLAG  4          XDSPBIT
# XORFLG        171             BIT  9 FLAG 11          XORFLBIT
# XOVINFLG      201             BIT  9 FLAG 13          XOVINHIB
# 3AXISFLG      084             BIT  6 FLAG  5          3AXISBIT
# 360SW         134             BIT  1 FLAG  8          360SWBIT

# ASSIGNMENT AND DESCRIPTION OF FLAGWORDS

FLAGWRD0        =       STATE +0                # (000-014)

                                                #       (SET)                   (RES

# BIT 15 FLAG 0 (S)
                =       000D
                =       BIT15

# BIT 14 FLAG 0 (S)
JSWITCH         =       001D                    #       INTEGRATION OF W        INTE
JSWCHBIT        =       BIT14                   #       MATRIX                  VECT

# BIT 13 FLAG 0 (S)
MIDFLAG         =       002D                    #       INTEGRATION WITH        INTE
                                                #       SECONDARY BODY AND      SOLA
MIDFLBIT        =       BIT13                   #       SOLAR PERTURBATIONS

# BIT 12 FLAG 0 (L)
MOONFLAG        =       003D                    #       MOON IS SPHERE OF       EART
MOONBIT         =       BIT12                   #       INFLUENCE               INFL

# BIT 11 FLAG 0
P21FLAG         =       004D                    #       USE BASE VECTORS        1ST
P21FLBIT        =       BIT11                   #       ALREADY CALCULATED      ULAT

# BIT 10 FLAG 0
FSPASFLG        =       005D                    #       FIRST PASS THROUGH      NOT
FSPASBIT        =       BIT10                   #       REPOSITION ROUTINE      REPO
```

Uses 3AXISBIT 115, 3AXISFLG 115, FLAGWRD0 95, JSWCHBIT 95, JSWITCH 95, L 80, MIDFLAG 95, MIDFLBIT 95, MOONBIT 95, MOONFLAG 95, P21FLAG 103, STATE 138, V37FLAG 123, V37FLBIT 123, W 183, XDELVBIT 103, XDELVFLG 103, XDSPBIT 113, and XDSPFLAG 113.

2075 ⟨*Page LM0066* 2075⟩≡ (2065 2698)

```
# BIT 9 FLAG 0  (S)
P25FLAG         =       006D                    #       P25 OPERATING           P25 NOT OPERATI
P25FLBIT        =       BIT9

# BIT 8 FLAG 0  (S)
IMUSE           =       007D                    #       IMU IN USE              IMU NOT IN USE
IMUSEBIT        =       BIT8

# BIT 7 FLAG 0  (S)
RNDVZFLG        =       008D                    #       P20 RUNNING (RADAR      P20 NOT RUNNING
RNDVZBIT        =       BIT7                    #       IN USE)

# BIT 6 FLAG 0  (S)
RRNBSW          =       009D                    #       RADAR TARGET IN         RADAR TARGET IN
RRNBBIT         =       BIT6                    #       NB COORDINATES          SM COORDINATES

# BIT 5 FLAG 0  (S)
LOKONSW         =       010D                    #       RADAR LOCK-ON           RADAR LOCK-ON N
LOKONBIT        =       BIT5                    #       DESIRED                 DESIRED

# BIT 4 FLAG 0  (S)
NEEDLFLG        =       011D                    #       TOTAL ATTITUDE          A/P FOLLOWING
NEEDLBIT        =       BIT4                    #       ERROR DISPLAYED         ERROR DISPLAYED

# BIT 3 FLAG 0
FREEFLAG        =       012D                    # (USED BY P51-53 TEMP IN MANY DIFFERENT
                                                # ROUTINES & BY LUNAR + SOLAR EPHEMERIDES)
FREEFBIT        =       BIT3

# BIT 2 FLAG 0
R10FLAG         =       013D                    #       R10 OUTPUTS DATA TO     BESIDES OUTPUT
R10FLBIT        =       BIT2                    #       ALTITUDE & ALTITUDE     SET, R10 ALSO C
                                                #       RATE METERS ONLY        TO FORWARD & LA
                                                #                               VELOCITY CROSSP

# BIT 1 FLAG 0  (L)
OLDESFLG        =       014D                    #       R29 GYRO CMD LOOP       R29 GYRO CMD LO
OLDESBIT        =       BIT1                    #       REQUESTED               NOT REQUESTED


FLAGWRD1        =       STATE +1                # (015-029)
```

Uses A 80, FLAGWRD1 97, FREEFBIT 97, FREEFLAG 97, IMUSE 95, IMUSEBIT 97, L 80, NEEDLBIT 95, NEEDLFLG 95, P 188, RNDVZBIT 97, RNDVZFLG 97, STATE 138, and TEMP 191.

2076 ⟨*Page LM0067* 2076⟩≡ (2065 2698)

```
                                                    #       (SET)                   (RESE

# BIT 15 FLAG 1 (S)
NJETSFLG        =       015D                        #       TWO JET RCS BURN        FOUR
NJETSBIT        =       BIT15

# BIT 14 FLAG 1 (L)
DIDFLAG         =       016D                        #       INERTIAL DATA IS        PERFO
DIDFLBIT        =       BIT14                       #       AVAILABLE               INITI

# BIT 13 FLAG 1 (S)
ERADFLAG        =       017D                        #       COMPUTE REARTH          USE C
ERADFBIT        =       BIT13                       #       FISCHER ELLIPSOID       PAD F

# BIT 12 FLAG 1
RODFLAG         =       018D                        #       IF IN P66, NORMAL       IF IN
RODFLBIT        =       BIT12                       #       OPERATION CONTINUES.    IALIZ
                                                    #       RESTART CLEARS FLAG     FORME

# BIT 11 FLAG 1
                =       019D
                =       BIT11

# BIT 10 FLAG 1 (L)
R61FLAG         =       020D                        #       RUN R61 LEM             RUN F
R61FLBIT        =       BIT10

# BIT 9 FLAG 1
                =       021D
                =       BIT9

# BIT 8 FLAG 1  (S)
VEHUPFLG        =       022D                        #       CSM STATE-VECTOR        LEM S
VEHUPBIT        =       BIT8                        #       BEING UPDATED           BEING

# BIT 7 FLAG 1  (S)
UPDATFLG        =       023D                        #       UPDATING BY MARKS       UPDAT
UPDATBIT        =       BIT7                        #       ALLOWED                 NOT A

# BIT 6 FLAG 1  (S)
NOUPFLAG        =       024D                        #       NEITHER CSM             EITHE
                                                    #       NOR LM STATE VECTOR     VECTO
NOUPFBIT        =       BIT6                        #       MAY BE UPDATED          UPDAT
```

Uses ERADFBIT 99, ERADFLAG 99, L 80, NJETSBIT 97, NJETSFLG 97, RESTART 57, RUN 191,

STATE 138, UPDATBIT 101, UPDATFLG 99, VEHUPBIT 99, and VEHUPFLG 99.

2078 ⟨*Page LM0068* 2078⟩≡ (2065 2698)

```
# BIT 5 FLAG 1  (S)
TRACKFLG        =       025D                    #       TRACKING ALLOWED        TRACK
TRACKBIT        =       BIT5

# BIT 4 FLAG 1
                =       026D
                =       BIT4

# BIT 3 FLAG 1  (S)
SLOPESW         =       027D                    #       ITERATE WITH BIAS       ITERA
                                                #       METHOD IN ITERATOR      FALSI
SLOPEBIT        =       BIT3                    #                               ITERA

# BIT 2 FLAG 1  (S)
GUESSW          =       028D                    #       NO STARTING VALUE       START
GUESSBIT        =       BIT2                    #       FOR ITERATION           ITERA

# BIT 1 FLAG 1
                =       029D
                =       BIT1                    # OH 2009-05-15 Scan does not have th

FLAGWRD2        =       STATE +2                # (030-044)

                                                #       (SET)                   (RESE

# BIT 15 FLAG 2 (S)
DRIFTFLG        =       030D                    #       T3RUPT CALLS GYRO       T3RUP
DRFTBIT         =       BIT15                   #       COMPENSATION            COMPE

# BIT 14 FLAG 2 (S)
SRCHOPTN        =       031D                    #       RADAR IN AUTOMATIC      RADAR
SRCHOBIT        =       BIT14                   #       SEARCH OPTION (R24)     MATIC

# BIT 13 FLAG 2 (S)
ACMODFLG        =       032D                    #       MANUAL ACQUISITION      AUTO
ACMODBIT        =       BIT13                   #       BY RENDEZVOUS RADAR     BY RE

# BIT 12 FLAG 2 (S)
LOSCMFLG        =       033D                    #       LINE OF SIGHT BEING     LINE
                                                #       COMPUTED (R21)          BEING
LOSCMBIT        =       BIT12
```

Uses BIAS 211, DRFTBIT 101, DRIFTFLG 101, FLAGWRD2 101, GUESSBIT 101, GUESSW 101, SLOPEBIT 101, SLOPESW 101, STATE 138, TRACKBIT 101, and TRACKFLG 101.

2079 ⟨*Page LM0069* 2079⟩≡ (2065 2698)

```
# BIT 11 FLAG 2 (S)
STEERSW         =       034D                    #       SUFFICIENT THRUST       INSUFFICIENT TH
STEERBIT        =       BIT11                   #       IS PRESENT              IS PRESENT

# BIT 10 FLAG 2 (S)
                =       035D                    # OH 2009-05-15 These two line don't appear in
                =       BIT10

# BIT 9 FLAG 2 (S)
IMPULSW         =       036D                    #       MINIMUM IMPULSE         STEERING BURN (
                                                #       BURN (CUTOFF TIME       CUTOFF TIME YET
IMPULBIT        =       BIT9                    #       SPECIFIED)              AVAILABLE)

# BIT 8 FLAG 2 (S)
XDELVFLG        =       037D                    #       EXTERNAL DELTAV VG      LAMBERT (AIMPOI
XDELVBIT        =       BIT8                    #       COMPUTATION             VG COMPUTATION

# BIT 7 FLAG 2 (S)
ETPIFLAG        =       038D                    #       ELEVATION ANGLE         TPI TIME SUPPLI
                                                #       SUPPLIED FOR            FOR P34,74 TO C
ETPIBIT         =       BIT7                    #       P34,74                  ELEVATION

# BIT 7 FLAG 2 (L)
OPTNSW          =       ETPIFLAG                #       SOI PHASE OF P38/78     SOR PHASE OF P3
OPTNBIT         =       BIT7

# BIT 6 FLAG 2 (S)
FINALFLG        =       039D                    #       LAST PASS THROUGH       INTERIM PASS TH
                                                #       RENDEZVOUS PROGRAM      RENDEZVOUS PROG
FINALBIT        =       BIT6                    #       COMPUTATIONS            COMPUTATIONS

# BIT 5 FLAG 2 (S)
AVFLAG          =       040D                    #       LEM IS ACTIVE           CSM IS ACTIVE
AVFLBIT         =       BIT5                    #       VEHICLE                 VEHICLE

# BIT 4 FLAG 2 (S)
PFRATFLG        =       041D                    #       PREFERRED ATTITUDE      PREFERRED ATTIT
PFRATBIT        =       BIT4                    #       COMPUTED                NOT COMPUTED

# BIT 3 FLAG 2 (S)
```

Uses AVFLAG 105, AVFLBIT 105, ETPIFLAG 103, FINALBIT 105, FINALFLG 105, IMPULBIT 103, IMPULSW 103, L 80, OPTNSW 105, PFRATBIT 105, PFRATFLG 105, STEERBIT 103, STEERSW 103, THRUST 85, VG 234, XDELVBIT 103, and XDELVFLG 103.

2080 ⟨*Page LM0070* 2080⟩≡ (2065 2698)

```
CALCMAN3        =       042D                    #       NO FINAL ROLL           FINAL
CALC3BIT        =       BIT3                    #                               NECES

# BIT 2 FLAG 2 (S)
CALCMAN2        =       043D                    #       PERFORM MANEUVER        BYPAS
CALC2BIT        =       BIT2                    #       STARTING PROCEDURE      PROCE

# BIT 1 FLAG 2 (S)
NODOFLAG        =       044D                    #       V37 NOT PERMITTED       V37 I
NODOBIT         =       BIT1

FLAGWRD3        =       STATE +3                # (045-059)

                                                #       (SET)                   (RESE

# BIT 15 FLAG 3
                =       045D                    #
                =       BIT15                   # OH 2009-05-15 This line is not in s

# BIT 14 FLAG 3 (S)
GLOKFAIL        =       046D                    #       GIMBAL LOCK HAS         NOT I
GLOKFBIT        =       BIT14                   #       OCCURRED

# BIT 13 FLAG 3 *** PROTECTED FROM FRESH START ***
REFSMFLG        =       047D                    #       REFSMMAT GOOD           REFSM
REFSMBIT        =       BIT13

# BIT 12 FLAG 3 (S)
LUNAFLAG        =       048D                    #       LUNAR LAT-LONG          EARTH
LUNABIT         =       BIT12

# BIT 11 FLAG 3 (L)
NOR29FLG        =       049D                    #       R29 NOT ALLOWED         R29 A
NR29FBIT        =       BIT11                   #                               IGNAT

# BIT 10 FLAG 3 (S)
VFLAG           =       050D                    #       LESS THAN TWO STARS     TWO S
VFLAGBIT        =       BIT10                   #       IN FIELD OF VIEW        OF VI

# BIT 9 FLAG 3  (S)
R04FLAG         =       051D                    #       ALARM 521               ALARM
                                                #       SUPPRESSED
```

Uses CALC2BIT 105, CALCMAN2 105, FLAGWRD3 105, GLOKFAIL 105, GLOKFBIT 105, L 80, LAT 157, LONG 157, LUNABIT 107, LUNAFLAG 107, NODOBIT 105, NODOFLAG 105, REFSMBIT 107, REFSMFLG 107, REFSMMAT 172, STATE 138, VFLAG 107, and VFLAGBIT 107.

2081 ⟨*Page LM0071* 2081⟩≡ (2065 2698)

```
R04FLBIT        =       BIT9

# BIT 9 FLAG 3  (L)
READRFLG        =       R04FLAG                 #       READING RR DATA         NOT READING RR
READRBIT        =       BIT9                    #       PURSUANT TO R29         PURSUANT TO R29

# BIT 8 FLAG 3  (S)
PRECIFLG        =       052D                    #       NORMAL INTEGRATION      ENGAGES 4-TIME
                                                #       IN P00                  (P00) LOGIC IN
PRECIBIT        =       BIT8                    #                               GRATION

# BIT 7 FLAG 3  (S)
CULTFLAG        =       053D                    #       STAR OCCULTED           STAR NOT OCCULT
CULTBIT         =       BIT7

# BIT 6 FLAG 3  (S)
ORBWFLAG        =       054D                    #       W MATRIX VALID FOR      W MATRIX INVALI
ORBWFBIT        =       BIT6                    #       ORBITAL NAVIGATION      ORBITAL NAVIGAT

# BIT 5 FLAG 3  (S)
STATEFLG        =       055D                    #       PERMANENT STATE         PERMANENT STATE
STATEBIT        =       BIT5                    #       VECTOR UPDATED          VECTOR NOT UPDA

# BIT 4 FLAG 3  (S)
INTYPFLG        =       056D                    #       CONIC INTEGRATION       ENCKE INTEGRATI
INTYPBIT        =       BIT4

# BIT 3 FLAG 3  (S)
VINTFLAG        =       057D                    #       CSM STATE VECTOR        LEM STATE VECTO
VINTFBIT        =       BIT3                    #       BEING INTEGRATED        BEING INTEGRATE

# BIT 2 FLAG 3 (S)
D6OR9FLG        =       058D                    #       DIMENSION OF W IS 9     DIMENSION OF W
D6OR9BIT        =       BIT2                    #       FOR INTEGRATION         FOR INTEGRATION

# BIT 1 FLAG 3  (S)
DIMOFLAG        =       059D                    #       W MATRIX IS TO BE       W MATRIX IS NOT
DIMOBIT         =       BIT1                    #       USED                    USED

FLAGWRD4        =       STATE +4                # (060-074)
```

Uses CULTBIT 107, CULTFLAG 107, D6OR9BIT 109, D6OR9FLG 109, DIMOBIT 109, DIMOFLAG 109, FLAGWRD4 109, INTYPFLG 107, L 80, ORBITAL 59, ORBWFBIT 107, ORBWFLAG 107, PRECIBIT 107, PRECIFLG 107, STAR 186, STATE 138, STATEBIT 107, STATEFLG 107, VINTFBIT 109, VINTFLAG 109, and W 183.

2082 ⟨*Page LM0072* 2082⟩≡ (2065 2698)

```
                                                    #       (SET)                   (RESE

# BIT 15 FLAG 4 (S)
MRKIDFLG        =       060D                        #       MARK DISPLAY IN         NO MA
MRKIDBIT        =       BIT15                       #       ENDIDLE                 ENDID

# BIT 14 FLAG 4 (S)
PRIODFLG        =       061D                        #       PRIORITY DISPLAY IN     NO PR
PRIODBIT        =       BIT14                       #       ENDIDLE                 IN EN

# BIT 13 FLAG 4 (S)
NRMIDFLG        =       062D                        #       NORMAL DISPLAY IN       NO NO
NRMIDBIT        =       BIT13                       #       ENDIDLE                 IN EN

# BIT 12 FLAG 4 (S)
PDSPFLAG        =       063D                        #       P20 SETS SO AS TO       LEAVE
                                                    #       TURN A NORMAL DIS-
PDSPFBIT        =       BIT12                       #       PLAY INTO A PRIORITY
                                                    #       DISPLAY IN R60

# BIT 11 FLAG 4 (S)
MWAITFLG        =       064D                        #       HIGHER PRIORITY         NO HI
                                                    #       DISPLAY OPERATING       DISPL
MWAITBIT        =       BIT11                       #       WHEN MARK               WHEN
                                                    #       DISPLAY INITIATED       INITI

# BIT 10 FLAG 4 (S)
NWAITFLG        =       065D                        #       HIGHER PRIORITY         NO HI
                                                    #       DISPLAY OPERATING       DISPL
NWAITBIT        =       BIT10                       #       WHEN NORMAL             WHEN
                                                    #       DISPLAY INITIATED       INITI

# BIT 9 FLAG 4  (S)
MRKNVFLG        =       066D                        #       ASTRONAUT USING         ASTRO
                                                    #       KEYBOARD WHEN MARK      KEYBO
MRKNVBIT        =       BIT9                        #       DISPLAY INITIATED       DISPL

# BIT 8 FLAG 4  (S)
NRMNVFLG        =       067D                        #       ASTRONAUT USING         ASTRO
                                                    #       KEYBOARD WHEN           KEYBO
NRMNVBIT        =       BIT8                        #       NORMAL DISPLAY          NORMA
                                                    #       INITIATED               INITI

# BIT 7 FLAG 4  (S)
PRONVFLG        =       068D                        #       ASTRONAUT USING         ASTRO
```

Uses A 80, MRKIDBIT 109, MRKIDFLG 109, MRKNVBIT 111, MRKNVFLG 111, MWAITBIT 111, MWAITFLG 109, NRMIDBIT 109, NRMIDFLG 109, NRMNVBIT 111, NRMNVFLG 111, NWAITBIT 111, NWAITFLG 111, PDSPFBIT 109, PDSPFLAG 109, PRIODBIT 109, PRIODFLG 109, PRIORITY 145, and PRONVFLG 111.

2084 ⟨*Page LM0073* 2084⟩≡ (2065 2698)

```
                                                    #       KEYBOARD WHEN           KEYBO
PRONVBIT        =       BIT7                        #       PRIORITY DISPLAY        PRIOR
                                                    #       INITIATED               INITI

# BIT 6 FLAG 4  (S)
PINBRFLG        =       069D                        #       ASTRONAUT HAS           ASTRO
                                                    #       INTERFERED WITH         INTER
PINBRBIT        =       BIT6                        #       EXISTING DISPLAY        EXIST

# BIT 5 FLAG 4  (S)
MRUPTFLG        =       070D                        #       MARK DISPLAY            MARK
                                                    #       INTERRUPTED BY          INTER
MRUPTBIT        =       BIT5                        #       PRIORITY DISPLAY        PRIOR

# BIT 4 FLAG 4  (S)
NRUPTFLG        =       071D                        #       NORMAL DISPLAY          NORMA
                                                    #       INTERRUPTED BY          INTER
NRUPTBIT        =       BIT4                        #       PRIORITY OR MARK        PRIOR
                                                    #       DISPLAY                 DISPL

# BIT 3 FLAG 4  (S)
MKOVFLAG        =       072D                        #       MARK DISPLAY OVER       NO MA
MKOVBIT         =       BIT3                        #       NORMAL                  NORMA

# BIT 2 FLAG 4
                =       073D
                =       BIT2                        # OH 2009-05-15 Not in scan.


# BIT 1 FLAG 4  (S)
XDSPFLAG        =       074D                        #       MARK DISPLAY NOT        NO SP
XDSPBIT         =       BIT1                        #       TO BE INTERRUPTED       INFOR

FLAGWRD5        =       STATE +5                    # (075-089)

                                                    #       (SET)                   (RESE

# BIT 15 FLAG 5 (S)
DSKYFLAG        =       075D                        #       DISPLAYS SENT TO        NO DI
DSKYFBIT        =       BIT15                       #       DSKY

# BIT 14 FLAG 5
                =       076D
                =       BIT14
```

Uses DISPLAYS 59, DSKYFLAG 113, FLAGWRD5 113, MKOVBIT 113, MKOVFLAG 113, MRUPTBIT 111, MRUPTFLG 111, NRUPTBIT 113, NRUPTFLG 113, PINBRBIT 111, PINBRFLG 111, PRIORITY 145, PRONVBIT 111, STATE 138, XDSPBIT 113, and XDSPFLAG 113.

2086 ⟨*Page LM0074* 2086⟩≡ (2065 2698)

```
# BIT 13 FLAG 5 (S,L)
SNUFFER         =       077D                    #       U,V JETS DISABLED       U,V J
                                                #       DURING DPS              DURIN
SNUFFBIT        =       BIT13                   #       BURNS (V65)             BURNS

# BIT 12 FLAG 5 (S)
NOTHROTL        =       078D                    #       INHIBIT FULL            PERMI
NOTHRBIT        =       BIT12                   #       THROTTLE

# BIT 11 FLAG 5 (S,L)
R77FLAG         =       079D                    #       R77 IS ON,              R77 I
                                                #       SUPPRESS ALL RADAR
                                                #       ALARMS AND TRACKER
R77FLBIT        =       BIT11                   #       FAILS

# BIT 10 FLAG 5 (S)
RNGSCFLG        =       080D                    #       SCALE CHANGE HAS        NO SC
                                                #       OCCURRED DURING         OCCUR
RNGSCBIT        =       BIT10                   #       RR READING              RR RE

# BIT 9 FLAG 5  (S)
DMENFLG         =       081D                    #       DIMENSION OF W IS 9     DIMEN
DMENFBIT        =       BIT9                    #       FOR INCORPORATION       FOR I

# BIT 8 FLAG 5  (S)
                =       082D
                =       BIT8

# BIT 7 FLAG 5  (S)
ENGONFLG        =       083D                    #       ENGINE TURNED ON        ENGIN
ENGONBIT        =       BIT7                    #

# BIT 6 FLAG 5  (S)
3AXISFLG        =       084D                    #       MANEUVER SPECIFIED      MANEU
                                                #       BY THREE AXES           BY ON
3AXISBIT        =       BIT6                    #                               CALLS

# BIT 5 FLAG 5
                =       085D
                =       BIT5                    # OH 2009-05-15 Not in scan

# BIT 4 FLAG 5  (S)
```

Uses 3AXISBIT 115, 3AXISFLG 115, DMENFBIT 115, DMENFLG 115, ENGONBIT 115, ENGONFLG 115, L 80, RNGSCFLG 115, V 229, and W 183.

2087 ⟨*Page LM0075* 2087⟩≡ (2065 2698)

```
NORRMON         =       086D                    #       BYPASS RR GIMBAL        PERFORM
NORRMBIT        =       BIT4                    #       MONITOR                 RR GIMBAL MONIT

# BIT 3 FLAG 5  (S)
SOLNSW          =       087D                    #       LAMBERT DOES NOT        LAMBERT CONVERG
                                                #       CONVERGE, OR TIME-RAD   TIME-RADIUS NON
SOLNSBIT        =       BIT3                    #       NEARLY CIRCULAR         CIRCULAR

# BIT 2 FLAG 5  (S)
MGLVFLAG        =       088D                    #       LOCAL VERTICAL          MIDDLE GIMBAL A
                                                #       COORDINATES             COMPUTED
MGLVFBIT        =       BIT2                    #       COMPUTED

# BIT 1 FLAG 5  (S)
RENDWFLG        =       089D                    #       W MATRIX VALID          W MATRIX INVALI
                                                #       FOR RENDEZVOUS          FOR RENDEZVOUS
RENDWBIT        =       BIT1                    #       NAVIGATION              NAVIGATION


FLAGWRD6        =       STATE +6                # (090-104)

                                                #       (SET)                   (RESET)

# BIT 15 FLAG 6 (S)
S32.1F1         =       090D                    #       DELTA V AT CSI TIME     DVT1 LESS THAN
S32BIT1         =       BIT15                   #       ONE EXCEEDS MAX

# BIT 14 FLAG 6 (S)
S32.1F2         =       091D                    #       FIRST PASS OF           REITERATION OF
S32BIT2         =       BIT14                   #       NEWTON ITERATION        NEWTON

# BIT 13 FLAG 6 (S)
S32.1F3A        =       092D                    # BIT 13 AND BIT 12 FUNCTION AS AN ORDERED
S32BIT3A        =       BIT13                   # PAIR (13,12) INDICATING THE POSSIBLE OC-
                                                # CURRENCE OF 2 NEWTON ITERATIONS FOR S32.1
                                                # IN THE PROGRAM IN THE FOLLOWING ORDER:
# BIT 12 FLAG 6 (S)                             # (0,1) (I.E. BIT 13 RESET, BIT 12 SET)
S32.1F3B        =       093D                    #      = FIRST NEWTON ITERATION BEING DONE
S32BIT3B        =       BIT12                   # (0,0)= FIRST PASS OF SECOND NEWTON ITERATION
                                                # (1,1)= 50 FT/SEC STAGE OF SECOND NEWTON ITERA
                                                # (1,0)= REMAINDER OF SECOND NEWTON ITERATION
# BIT 11 FLAG 6 (S)
                =       094D                    #
                =       BIT11                   #
```

Uses FLAGWRD6 117, I 206, MGLVFBIT 117, MGLVFLAG 117, RAD 219, RENDWBIT 117, RENDWFLG 117,

S32.1F1 135, S32.1F2 135, S32.1F3A 135, S32.1F3B 135, S32BIT1 135, S32BIT2 135, S32BIT3A 135, SOLNSBIT 117, SOLNSW 115, STATE 138, V 229, and W 183.

2089 ⟨*Page LM0076* 2089⟩≡ (2065 2698)

```
# BIT 10 FLAG 6 (S)
GMBDRVSW        =       095D                    #       TRIMGIMB OVER           TRIMGIMB NOT OV
GMBDRBIT        =       BIT10                   #

# BIT 9 FLAG 6
                =       096D                    #
                =       BIT9                    #

# BIT 8 FLAG 6  (S)
MUNFLAG         =       097D                    #       SERVICER CALLS          SERVICER CALLS
MUNFLBIT        =       BIT8                    #       MUNRVG                  CALCRVG

# BIT 7 FLAG 6  (L)
                =       098D                    #
                =       BIT7                    #

# BIT 6 FLAG 6  (L)
REDFLAG         =       099D                    #       LANDING SITE            LANDING SITE
                                                #       REDESIGNATION           REDESIGNATION N
REDFLBIT        =       BIT6                    #       PERMITTED               PERMITTED

# BIT 5 FLAG 6
                =       100D                    #
                =       BIT5                    # OH 2009-05-15 Not in scan

# BIT 4 FLAG 6
                =       101D                    #
                =       BIT4                    # OH 2009-05-15 Not in scan

# BIT 3 FLAG 6  (S)
NTARGFLG        =       102D                    #       ASTRONAUT DID           ASTRONAUT DID N
                                                #       OVERWRITE DELTA         OVERWRITE DELTA
NTARGBIT        =       BIT3                    #       VELOCITY AT TPI         VELOCITY
                                                #       OR TPM (P34,35)

# BIT 2 FLAG 6
AUXFLAG         =       103D                    #       PROVIDING IDLEFLAG      SERVICER WILL S
AUXFLBIT        =       BIT2                    #       IS NOT SET, SERV-       DVMON ON ITS NE
                                                #       ICER WILL EXERCISE      PASS EVEN IF TH
                                                #       DVMON ON ITS NEXT       IDLEFLAG IS NOT
                                                #       PASS.                   IT WILL THEN SE
                                                #                               AUXFLAG.

# BIT 1 FLAG 6  (L)
ATTFLAG         =       104D                    #       LEM ATTITUDE EXISTS     NO LEM ATTITUDE
```

```
#       IN MOON-FIXED           AVAIL
```

Uses IT 185 and L 80.

2091 ⟨*Page LM0077* 2091⟩≡ (2065 2698)

```
ATTFLBIT        =       BIT1                    #       COORDINATES             FIXED COORDINAT

FLAGWRD7        =       STATE +7                # (105-119)

                                                #       (SET)                   (RESET)

# BIT 15 FLAG 7 (S)
ITSWICH         =       105D                    #       R34;TPI TIME TO BE      TPI HAS BEEN
ITSWBIT         =       BIT15                   #       COMPUTED                COMPUTED

# BIT 14 FLAG 7 (S)
MANUFLAG        =       106D                    #       ATTITUDE MANEUVER       NO ATTITUDE MAN
                                                #       GOING DURING RR         DURING RR SEARC
MANUFBIT        =       BIT14                   #       SEARCH

# BIT 13 FLAG 7 (S)
IGNFLAG         =       107D                    #       TIG HAS ARRIVED         TIG HAS NOT ARR
IGNFLBIT        =       BIT13                   #

# BIT 12 FLAG 7 (S)
ASTNFLAG        =       108D                    #       ASTRONAUT HAS           ASTRONAUT HAS N
ASTNBIT         =       BIT12                   #       OKAYED IGNITION         OKAYED IGNITION

# BIT 11 FLAG 7 (L)
SWANDISP        =       109D                    #       LANDING ANALOG          LANDING ANALOG
SWANDBIT        =       BIT11                   #       DISPLAYS ENABLED        DISPLAYS SUPPRE

# BIT 10 FLAG 7 (S)
NORMSW          =       110D                    #       UNIT NORMAL INPUT       LAMBERT COMPUTE
NORMSBIT        =       BIT10                   #       TO LAMBERT              OWN UNIT NORMAL

# BIT 9 FLAG 7  (S)
RVSW            =       111D                    #       DO NOT COMPUTE          COMPUTE FINAL S
                                                #       FINAL STATE VECTOR      VECTOR IN TIME-
RVSWBIT         =       BIT9                    #       IN TIME-DELTA

# BIT 8 FLAG 7  (S)
V67FLAG         =       112D                    #       ASTRONAUT OVERWRITE     ASTRONAUT DOES
                                                #       W-MATRIX INITIAL        OVERWRITE W-MAT
V67FLBIT        =       BIT8                    #       VALUES                  INITIAL VALUES
```

Uses ASTNBIT 123, ASTNFLAG 123, DISPLAYS 59, FLAGWRD7 121, IGNFLAG 123, IGNFLBIT 123, ITSWBIT 123, ITSWICH 121, L 80, NORMSBIT 123, NORMSW 123, R34 67, RVSW 123, RVSWBIT 123, STATE 138, THETA 148, TIG 224, and W 183.

2092 ⟨*Page LM0078* 2092⟩≡ (2065 2698)

```
# BIT 7 FLAG 7  (S)
IDLEFLAG        =       113D                    #       NO DV MONITOR           CONNE
IDLEFBIT        =       BIT7                    #

# BIT 6 FLAG 7  (S)
V37FLAG         =       114D                    #       AVERAGEG (SERVICER)     AVERA
V37FLBIT        =       BIT6                    #       RUNNING                 OFF

# BIT 5 FLAG 7  (S)
AVEGFLAG        =       115D                    #       AVERAGEG (SERVICER)     AVERA
AVEGFBIT        =       BIT5                    #       DESIRED                 NOT I

# BIT 4 FLAG 7  (S)
UPLOCKFL        =       116D                    #       K-KBAR-K FAIL           NO K-
UPLOCBIT        =       BIT4                    #

# BIT 3 FLAG 7  (S)
VERIFLAG        =       117D                    # CHANGED WHEN V33E OCCURS AT END OF
VERIFBIT        =       BIT3                    #

# BIT 2 FLAG 7  (L,C)
V82EMFLG        =       118D                    #       MOON VICINITY           EARTH
V82EMBIT        =       BIT2                    #

# BIT 1 FLAG 7  (S)
TFFSW           =       119D                    #       CALCULATE TPERIGEE      CALCU
TFFSWBIT        =       BIT1                    #


FLAGWRD8        =       STATE +8D               # (120-134)

                                                #       (SET)                   (RESE

# BIT 15 FLAG 8 (S)
RPQFLAG         =       120D                    #       RPQ NOT COMPUTED        RPQ (
                                                #       (RPQ = VECTOR BE-
RPQFLBIT        =       BIT15                   #       TWEEN SECONDARY BODY
                                                #       AND PRIMARY BODY)

# BIT 14 FLAG 8
                =       121D                    #
                =       BIT14                   #
```

Uses AVEGFLAG 101, DV 241, FLAGWRD8 125, L 80, RPQFLAG 125, RPQFLBIT 125, STATE 138, TFF 179, TFFSW 125, TFFSWBIT 125, UPLOCBIT 125, UPLOCKFL 125, V37FLAG 123,

`V37FLBIT` 123, `VERIFBIT` 125, and `VERIFLAG` 125.

2094 ⟨*Page LM0079* 2094⟩≡ (2065 2698)

```
# BIT 13 FLAG 8 (S)
NEWIFLG         =       122D                    #       FIRST PASS THROUGH      SUCCE
NEWIBIT         =       BIT13                   #       INTEGRATION             OF IN

# BIT 12 FLAG 8 *** PROTECTED FROM FRESH START ***
CMOONFLG        =       123D                    #       PERMANENT CSM STATE     PERMA
CMOONBIT        =       BIT12                   #       IN LUNAR SPHERE         IN EA

# BIT 11 FLAG 8 *** PROTECTED FROM FRESH START ***
LMOONFLG        =       124D                    #       PERMANENT LM STATE      PERMA
LMOONBIT        =       BIT11                   #       IN LUNAR SPHERE         IN EA

# BIT 10 FLAG 8 (L)
FLUNDISP        =       125D                    #       CURRENT GUIDANCE        CURRE
FLUNDBIT        =       BIT10                   #       DISPLAYS INHIBITED      DISPL

# BIT 9 FLAG 8  (L)
P39/79SW        =       126D                    #       P39/79 OPERATING        P38/7
P39SWBIT        =       BIT9                    #

# BIT 8 FLAG 8  *** PROTECTED FROM FRESH START ***
SURFFLAG        =       127D                    #       LM ON LUNAR SURFACE     LM NO
SURFFBIT        =       BIT8                    #                               SURFA

# BIT 7 FLAG 8  (S)
INFINFLG        =       128D                    #       NO CONIC SOLUTION       CONIC
                                                #       (CLOSURE THROUGH        EXIST
INFINBIT        =       BIT7                    #       INFINITY REQUIRED)

# BIT 6 FLAG 8  (S)
ORDERSW         =       129D                    #       ITERATOR USES 2ND       ITERA
ORDERBIT        =       BIT6                    #       ORDER MINIMUM MODE      ORDER

# BIT 5 FLAG 8  (S)
APSESW          =       130D                    #       RDESIRED OUTSIDE        RDESI
                                                #       PERICENTER-APOCENTER    PERIC
APSESBIT        =       BIT5                    #       RANGE IN TIME-RADIUS    RANGE

# BIT 4 FLAG 8  (S)
COGAFLAG        =       131D                    #       NO CONIC SOLUTION --    CONIC
                                                #       TOO CLOSE TO RECTI-     EXIST
```

Uses APSESBIT 127, APSESW 127, CMOONBIT 125, CMOONFLG 125, COGAFLAG 127, DISPLAYS 59, INFINBIT 127, INFINFLG 127, L 80, LMOONBIT 125, LMOONFLG 125, MODE 145, NEWIBIT 125, NEWIFLG 125, ORDERBIT 127, ORDERSW 127, P39/79SW 127, P39SWBIT 127, RANGE 179,

RDESIRED 188, STATE 138, SURFFBIT 127, and SURFFLAG 127.

2096 ⟨*Page LM0080* 2096⟩≡ (2065 2698)

```
COGAFBIT        =       BIT4                    #       LINEAR (COGA OVERFLWS)  OVERF

# BIT 3 FLAG 8  (S)
                =       132D                    #
                =       BIT3                    # OH 2009-05-15 Line not in scan

# BIT 2 FLAG 8  (L)
INITALGN        =       133D                    #       INITIAL PASS THRU       SECON
INITABIT        =       BIT2                    #       P57                     (CHEC

# BIT 1 FLAG 8  (S)
360SW           =       134D                    #       TRANSFER ANGLE NEAR     TRANS
360SWBIT        =       BIT1                    #       360 DEGREES             NEAR


FLAGWRD9        =       STATE +9D               # (135-149)

                                                #       (SET)                   (RESE

# BIT 15 FLAG 9
                =       135D                    #
                =       BIT15                   #

# BIT 14 FLAG 9 (L)
FLVR            =       136D                    #       VERTICAL RISE           NON-V
FLVRBIT         =       BIT14                   #       (ASCENT GUIDANCE)

# BIT 13 FLAG 9
                =       137D                    #
                =       BIT13                   # OH 2009-05-15 Line not in scan

# BIT 12 FLAG 9 (L)
FLPC            =       138D                    #       NO POSITION CONTROL     POSIT
FLPCBIT         =       BIT12                   #       (ASCENT GUIDANCE)

# BIT 11 FLAG 9 (L)
FLPI            =       139D                    #       PRE-IGNITION PHASE      REGUL
FLPIBIT         =       BIT11                   #       (ASCENT GUIDANCE)

# BIT 10 FLAG 9 (L)
FLRCS           =       140D                    #       RCS INJECTION MODE      MAIN
FLRCSBIT        =       BIT10                   #       (ASCENT GUIDANCE)

# BIT 9 FLAG 9  (L)
```

Uses `COGAFBIT` 127, `L` 80, `MODE` 145, and `STATE` 138.

2098 ⟨*Page LM0081* 2098⟩≡ (2065 2698)

```
LETABORT        =       141D                    #       ABORT PROGRAMS          ABORT
LETABBIT        =       BIT9                    #       ARE ENABLED             ARE N

# BIT 8 FLAG 9  (L)
FLAP            =       142D                    #       APS CONTINUED ABORT     APS A
                                                #       AFTER DPS STAGING       CONTI
FLAPBIT         =       BIT8                    #       (ASCENT GUIDANCE)

# BIT 7 FLAG 9  (L)
                =       143D
                =       BIT7                    # OH 2009-05-15 Line not in scan


# BIT 6 FLAG 9  (L)
ROTFLAG         =       144D                    #       P70 AND P71 WILL        P70 A
ROTFLBIT        =       BIT6                    #       FORCE VEHICLE           FORCE
                                                #       ROTATION IN THE         ROTAT
                                                #       PREFERRED DIRECTION     PREFE

# BIT 5 FLAG 9  (S)
QUITFLAG        =       145D                    #       DISCONTINUE INTEGR.     CONTI
QUITBIT         =       BIT5                    #

# BIT 4 FLAG 9
                =       146D                    #
                =       BIT4                    #

# BIT 3 FLAG 9  (L)
MID1FLAG        =       147D                    #       INTEGRAT TO TDEC        INTEG
MID1FBIT        =       BIT3                    #                               THEN-

# BIT 2 FLAG 9  (L)
MIDAVFLG        =       148D                    #       INTEGRATION ENTERED     INTEG
                                                #       FROM ONE OF MIDTOAV     NOT F
MIDAVBIT        =       BIT2                    #       PORTALS                 MIDTO

# BIT 1 FLAG 9  (S)
AVEMIDSW        =       149D                    #       AVETOMID CALLING        NO AV
                                                #       FOR W.MATRIX INTEGR     ALLOW
AVEMDBIT        =       BIT1                    #       DON'T WRITE OVER RN,    PIPTI
                                                #       VN,PIPTIME


RASFLAG         EQUALS  FLGWRD10                # WAS ONLY AN INSTALL-ERASTALL FLAG
```

Uses A 80, AVEMDBIT 133, AVEMIDSW 133, FLGWRD10 133, L 80, MID1FBIT 131, MID1FLAG 131, MIDAVBIT 133, MIDAVFLG 131, PIPTIME 159, QUITBIT 131, QUITFLAG 131, RASFLAG 133, RM 239, RN 159, TDEC 157, VN 159, and W 183.

2100 ⟨*Page LM0082* 2100⟩≡ (2065 2698)

```
FLGWRD10        =       STATE +10D              # (150-164)

                                                #       (SET)                   (RESE

# BIT 15 FLAG 10 (S)
                =       150D                    #
                =       BIT15                   # OH 2009-05-15 Line not in scan

# BIT 14 FLAG 10 (L,C)
INTFLAG         =       151D                    #       INTEGRATION IN          INTEG
INTFLBIT        =       BIT14                   #       PROGRESS                PROGR

# BIT 13 FLAG 10 (S,L)
APSFLAG         =       152D                    #       ASCENT STAGE            DESCE
APSFLBIT        =       BIT13                   #        *** PROTECTED FROM FRESH STA

# BIT 12 FLAG 10
                =       153D                    #
                =       BIT12                   # OH 2009-05-15 Line not in scan

# BIT 11 FLAG 10
                =       154D                    #
                =       BIT11                   # OH 2009-05-15 Line not in scan

# BIT 10 FLAG 10
                =       155D                    #
                =       BIT10                   # OH 2009-05-15 Line not in scan

# BIT 9 FLAG 10
                =       156D                    #
                =       BIT9                    # OH 2009-05-15 Line not in scan

# BIT 8 FLAG 10
                =       157D                    #
                =       BIT8                    # OH 2009-05-15 Line not in scan

# BIT 7 FLAG 10 (L,C)
REINTFLG        =       158D                    #       INTEGRATION ROUTINE     INTEG
REINTBIT        =       BIT7                    #       TO BE RESTARTED         NOT T

# BIT 6 FLAG 10
                =       159D                    #
                =       BIT6                    # OH 2009-05-15 Line not in scan

# BIT 5 FLAG 10
```

```
=       160D                    #
=       BIT5                    # OH 2009-05-15 Line not in scan
```

Uses FLGWRD10 133, INTFLAG 133, INTFLBIT 133, L 80, REINTBIT 135, REINTFLG 135, and STATE 138.

2102 ⟨*Page LM0083* 2102⟩≡ (2065 2698)

```
# BIT 4 FLAG 10
                =       161D                    #
                =       BIT4                    # OH 2009-05-15 Line not in scan

# BIT 3 FLAG 10
                =       162D                    #
                =       BIT3                    # OH 2009-05-15 Line not in scan

# BIT 2 FLAG 10
                =       163D                    #
                =       BIT2                    # OH 2009-05-15 Line not in scan

# BIT 1 FLAG 10
                =       164D                    #
                =       BIT1                    # OH 2009-05-15 Line not in scan



FLGWRD11        =       STATE +11D              # (165-179)

                                                #       (SET)                   (RESE

# BIT 15 FLAG 11 (L)(R12)
LRBYPASS        =       165D                    #       BYPASS ALL LANDING      DO NO
LRBYBIT         =       BIT15                   #       RADAR UPDATES           UPDAT

# BIT 14 FLAG 11
                =       166D                    #
                =       BIT14                   #

# BIT 13 FLAG 11
                =       167D                    #
                =       BIT13                   #

# BIT 12 FLAG 11 (L)(R12)
VXINH           =       168D                    #       IF Z VELOCITY DATA      UPDAT
                                                #       UNREASONABLE,           VELOC
VXINHBIT        =       BIT12                   #       BYPASS X VELOCITY
                                                #       UPDATE ON NEXT PASS

# BIT 11 FLAG 11 (L)(R12)
PSTHIGAT        =       169D                    #       PAST HIGATE             PREHI
PSTHIBIT        =       BIT11                   #

# BIT 10 FLAG 11 (L)(R12)
```

Uses FLGWRD11 135, L 80, STATE 138, and Z 80.

2103 ⟨*Page LM0084* 2103⟩≡ (2065 2698)

```
NOLRREAD        =       170D            #       LANDING RADAR           LR NOT REPOSITI
                                        #       REPOSITIONING;
NOLRRBIT        =       BIT10           #       BYPASS UPDATE

# BIT 9 FLAG 11 (L)(R12)
XORFLG          =       171D            #       BELOW LIMIT             ABOVE LIMIT DO
                                        #       INHIBIT X AXIS          NOT INHIBIT
XORFLBIT        =       BIT9            #       OVERRIDE

# BIT 8 FLAG 11
LRINH           =       172D            #       LANDING RADAR UP-       LR UPDATES INHI
LRINHBIT        =       BIT8            #       DATES PERMITTED         BY ASTRONAUT
                                        #       BY ASTRONAUT

# BIT 7 FLAG 11 (L)(R12)
VELDATA         =       173D            #       LR VELOCITY             LR VELOCITY MEA
VELDABIT        =       BIT7            #       MEASUREMENT MADE        NOT MADE

# BIT 6 FLAG 11 (L)(R12)
READLR          =       174D            #       OK TO READ LR           DO NOT READ LR
READLBIT        =       BIT6            #       RANGE DATA              DATA

# BIT 5 FLAG 11 (L)(R12)
READVEL         =       175D            #       OK TO READ LR           DO NOT READ LR
READVBIT        =       BIT5            #       VELOCITY DATA           VELOCITY DATA

# BIT 4 FLAG 11 (L)(R12)
RNGEDATA        =       176D            #       LR ALTITUDE             LR ALTITUDE MEA
RNGEDBIT        =       BIT4            #       MEASUREMENT MADE        NOT MADE

# BIT 3 FLAG 11
SCALBAD         =       177D            #       LR LOW SCALE DISP-      LS SCALE DISCRE
SCABBIT         =       BIT3            #       CRETE NOT PRESENT       APPEARS OK
                                        #       WHEN IT SHOULD

# BIT 2 FLAG 11 (L)(R12)
VFLSHFLG        =       178D            #       LR VELOCITY FAIL        LR VEL FAIL LAM
                                        #       LAMP SHOULD BE          SHOULDN'T FLASH
VFLSHBIT        =       BIT2            #       FLASHING

# BIT 1 FLAG 11 (L)(R12)
```

Uses IT 185, L 80, RANGE 179, and VEL 226.

2104 ⟨*Page LM0085* 2104⟩≡ (2065 2698)

```
HFLSHFLG        =       179D                    #       LR ALTITUDE FAIL        LR AI
HFLSHBIT        =       BIT1                    #       LAMP SHOULD BE          LAMP
                                                #       FLASHING                FLASH

RADMODES        EQUALS  FLGWRD12                # RADAR FLAG WORD

FLGWRD12        =       STATE +12D              # (180-194)             WAS RADMODES

                                                #       (SET)                   (RESE

# BIT 15 FLAG 12
CDESFLAG        =       180D                    #       CONTINUOUS DESIG-       LGC C
CDESBIT         =       BIT15                   #       NATE, LGC COMMANDS      ON WH
                                                #       RR REGARDLESS OF        BEING
                                                #       LOCK-ON

# BIT 14 FLAG 12
REMODFLG        =       181D                    #       CHANGE IN ANTENNA       NO RE
REMODBIT        =       BIT14                   #       MODE BEEN REQUESTED     OR OC
                                                #       I.E., REMODE

# BIT 13 FLAG 12
RCDU0FLG        =       182D                    #       RR CDU'S BEING          RR CD
RCDU0BIT        =       BIT13                   #       ZEROED                  ZEROE

# BIT 12 FLAG 12
ANTENFLG        =       183D                    #       RR ANTENNA MODE IS      RR AN
ANTENBIT        =       BIT12                   #       MODE 2

# BIT 11 FLAG 12
REPOSMON        =       184D                    #       REPOSITION MONITOR.     NO RE
REPOSBIT        =       BIT11                   #       RR REPOSITION IS        PLACE
                                                #       TAKING PLACE

# BIT 10 FLAG 12
DESIGFLG        =       185D                    #       RR DESIGNATE            RR DE
DESIGBIT        =       BIT10                   #       REQUESTED OR IN         REQUE
                                                #       PROGRESS                PROGR

# BIT 9 FLAG 12
ALTSCALE        =       186D                    #       LR ALTITUDE READING     LR AI
ALTSCBIT        =       BIT9                    #       IS ON HIGH SCALE        IS ON
```

Uses I 206, MODE 145, and STATE 138.

2105 ⟨*Page LM0086* 2105⟩≡ (2065 2698)

```
# BIT 8 FLAG 12
LRVELFLG        =       187D                    #       LR VELOCITY DATA        NO LR VELOCITY
LRVELBIT        =       BIT8                    #       FAIL                    FAIL

# BIT 7 FLAG 12
RCDUFAIL        =       188D                    #       RR CDU FAIL HAS         RR CDU FAIL OCC
RCDUFBIT        =       BIT7                    #       NOT OCCURRED

# BIT 6 FLAG 12
LRPOSFLG        =       189D                    #       LANDING RADAR           LR POSITION 1
LRPOSBIT        =       BIT6                    #       POSITION 2

# BIT 5 FLAG 12
LRALTFLG        =       190D                    #       LR ALTITUDE DATA        NO LR ALTITUDE
LRALTBIT        =       BIT5                    #       FAIL.  COULD NOT BE     FAIL
                                                #       READ SUCCESSFULLY.

# BIT 4 FLAG 12
RRDATAFL        =       191D                    #       RR DATA FAIL.           NO RR DATA FAIL
RRDATABT        =       BIT4                    #       DATA COULD NOT BE
                                                #       READ SUCCESSFULLY

# BIT 3 FLAG 12
RRRSFLAG        =       192D                    #       RR RANGE READING        RR RANGE READIN
RRRSBIT         =       BIT3                    #       ON THE HIGH SCALE       THE LOW SCALE

# BIT 2 FLAG 12
AUTOMODE        =       193D                    #       RR NOT IN AUTO MODE.    RR IN AUTO MODE
AUTOMBIT        =       BIT2                    #       AUTO MODE DISCRETE
                                                #       IS NOT PRESENT

# BIT 1 FLAG 12
TURNONFL        =       194D                    #       RR TURN-ON SEQUENCE     NO RR TURN-ON
TURNONBT        =       BIT1                    #       IN PROGRESS.  (ZERO     SEQUENCE IN PRO
                                                #       CDU'S, FIX ANTENNA
                                                #       MODE)

DAPBOOLS        EQUALS  FLGWRD13                # DIGITAL AUTOPILOT FLAGWORD
```

Uses MODE 145 and RANGE 179.

2106 ⟨*Page LM0087* 2106⟩≡ (2065 2698)

```
FLGWRD13        =       STATE +13D              # (195-209)     WAS DAPBOOLS

                                                #       (SET)                   (RESE

# BIT 15 FLAG 13
PULSEFLG        =       195D                    #       MINIMUM IMPUSE          NOT I
PULSES          =       BIT15                   #       COMMAND MODE IN         IMPUL
                                                #       "ATT HOLD" (V76)        (V77)

# BIT 14 FLAG 13
USEQRFLG        =       196D                    #       GIMBAL UNUSABLE.        TRIM
USEQRJTS        =       BIT14                   #       USE JETS ONLY.          USED.

# BIT 13 FLAG 13
CSMDKFLG        =       197D                    #       CSM DOCKED.  USE        CSM N
CSMDOCKD        =       BIT13                   #       BACKUP DAP

# BIT 12 FLAG 13
OURRCFLG        =       198D                    #       CURRENT DAP PASS        CURRE
OURRCBIT        =       BIT12                   #       IS RATE COMMAND         NOT R

# BIT 11 FLAG 13
ACC4-2FL        =       199D                    #       4 JET X-AXIS TRANS-     2 JET
ACC4OR2X        =       BIT11                   #       LATION REQUESTED        LATIO

# BIT 10 FLAG 13
AORBTFLG        =       200D                    #       B SYSTEM FOR X-         A SYS
AORBTRAN        =       BIT10                   #       TRANSLATION             TRANS

# BIT 9 FLAG 13
XOVINFLG        =       201D                    #       X-AXIS OVERRIDE         X-AXI
XOVINHIB        =       BIT9                    #       LOCKED OUT

# BIT 8 FLAG 13
DRIFTDFL        =       202D                    #       ASSUME 0 OFFSET         USE C
DRIFTBIT        =       BIT8                    #       DRIFTING FLIGHT         ION R

# BIT 7 FLAG 13
RHCSCFLG        =       203D                    #       NORMAL RHC SCALING      FINE
RHCSCALE        =       BIT7                    #       REQUESTED               REQUE
```

Uses A 80, COMMAND 169, MODE 145, and STATE 138.

2107a ⟨*Page LM0088* 2107a⟩≡ (2065 2698)

```
# BIT 6 FLAG 13
ULLAGFLG        =       204D                    #       ULLAGE REQUEST BY       NO INTERNAL ULL
ULLAGER         =       BIT6                    #       MISSION PROGRAM         REQUEST

# BIT 5 FLAG 13
AORBSFLG        =       205D                    #       P-AXIS COUPLES 7.15     P-AXIS COUPLES
AORBSYST        =       BIT5                    #       AND 8.16 PREFERRED      AND 3.11 PREFER

# BIT 4 FLAG 13
DBSELFLG        =       206D                    #       MAX DB SELECTED         MIN DB SELECTED
DBSELECT        =       BIT4                    #       BY CREW (5 DEG)         CREW (0.3 DEG)

# BIT 3 FLAG 13
ACCOKFLG        =       207D                    #       CONTROL AUTHORITY       RESTART OR FRES
ACCSOKAY        =       BIT3                    #       VALUES FROM 1/ACCS      SINCE LAST 1/AC
                                                #       USABLE                  OUTPUTS SUSPECT

# BIT 2 FLAG 13
AUTR2FLG        =       208D                    # THESE FLAGS ARE USED TOGETHER TO INDICATE
AUTRATE2        =       BIT2                    # ASTRONAUT-CHOSEN KALCMANU MANEUVER RATES
                                                # (0,0)=(BIT2,BIT1)=    0.2 DEG/SEC
# BIT 1 FLAG 13                                 # (0,1)=                0.5 DEG/SEC
AUTR1FLG        =       209D                    # (1,0)=                2.0 DEG/SEC
AUTRATE1        =       BIT1                    # (1,1)=               10.0 DEG/SEC
```

Uses P 188 and RESTART 57.

2107b ⟨*Page LM0089* 2107b⟩≡ (2065 2698)

4.4 rcs failure monitor

2108 ⟨*rcs failure monitor* 2108⟩≡ (2041 2792)

```
# Page 190
# PROGRAM DESCRIPTION:
#
# AUTHOR: J. S. MILLER
#
# MODIFIED 6 MARCH 1968 BY P. S. WEISSMAN TO SET UP JOB FOR 1/ACCS WHEN THE MASKS ARE
#
# THIS ROUTINE IS ATTACHED TO T4RUPT, AND IS ENTERED EVERY 480 MS.  ITS FUNCTION IS T
# OF CHANNEL 32 TO SEE IF ANY ISOLATION-VALVE CLOSURE BITS HAVE APPEARED OR DISAPPEAR
# FAILURES BY LAMPS LIT BY THE GRUMMAN FAILURE-DETECTION CIRCUITRY; THEY MAY RESPOND
# ISOLATE PAIRS OF JETS FROM THE PROPELLANT TANKS AND SET BITS IN CHANNEL 32).  IN TH
# DIFFER FROM 'PVALVEST', THE RECORD OF ACTIONS TAKEN BY THIS ROUTINE, THE APPROPRIAT
# 'CH6MASK', USED BY THE DAP JET-SELECTION LOGIC, ARE UPDATED, AS IS 'PVALVEST'.  TO
# ROUTINE, NO MORE THAN ONE CHANGE IS ACCEPTED PER ENTRY.  THE HIGHEST-NUMBERED BIT I
# ACTION IS THE ONE PROCESSED.
#
# THE CODING IN THE FAILURE MONITOR HAS BEEN WRITTEN SO AS TO HAVE ALMOST COMPLETE RE
# EXAMPLE, NO ASSUMPTION IS MADE WHEN SETTING A 'CH5MASK' BIT TO 1 THAT THE PREVIOUS
# COURSE SHOULD BE.  ONE CASE WHICH MAY BE SEEN TO EVADE PROTECTION IS THE OCCURRENCE
# ONE OR BOTH DAP MASK-WORDS BUT BEFORE UPDATING 'PVALVEST', COUPLED WITH A CHANGE IN
# FORMER STATE.  THE CONSEQUENCE OF THIS IS THAT THE NEXT ENTRY WOULD NOT SEE THE CHA
# ORATED BY THE LAST PASS (BECAUSE IT WENT AWAY AT JUST THE RIGHT TIME), BUT THE DAP
# THIS COMBINATION OF EVENTS SEEMS QUITE REMOTE, BUT NOT IMPOSSIBLE UNLESS THE CREW C
# SECOND INTERVALS OR LONGER.  IN ANY EVENT, A DISAGREEMENT BETWEEN REALITY AND THE D
# THE MISINTERPRETED SWITCH IS REVERSED AND THEN RESTORED TO ITS CORRECT POSITION (SI
#
# CALLING SEQUENCE:
#
#       TCF     RCSMONIT                # (IN INTERRUPT MODE, EVERY 480 MS.)
#
# EXIT: TCF RCSMONEX (ALL PATHS EXIT VIA SUCH AN INSTRUCTION)

RCSMONEX        EQUALS  RESUME

# ERASABLE INITIALIZATION REQUIRED:
#
#       VIA FRESH START:        PVALVEST        =       +0      (ALL JETS ENABLED)
#                               CH5MASK,CH6MASK =       +0      (ALL JETS OK)
#
# OUTPUT:       CH5MASK & CH6MASK UPDATED (1'S WHERE JETS NOT TO BE USED, IN CHANNEL
#               PVALTEST UPDATED (1'S WHEN VALVE CLOSURES HAVE BEEN TRANSLATED INTO C
#               JOB TO DO 1/ACCS.
#
```

```
# DEBRIS:  A, L, AND Q AND DEBRIS OF NOVAC.
#
# SUBROUTINE CALLED:  NOVAC.

                EBANK=  CH5MASK

                BANK    23
                SETLOC  RCSMONT
                BANK
# Page 191
                COUNT*  $$/T4RCS

RCSMONIT        EQUALS  RCSMON

RCSMON          CS      ZERO
                EXTEND
                RXOR    CHAN32                  # PICK UP + INVERT INVERTED CHANNEL 32.
                MASK    LOW8                    # KEEP JET-FAIL BITS ONLY.
                TS      Q

                CS      PVALVEST                #       _   _
                MASK    Q                       # FORM PC + PC.
                TS      L                       #       (P = PREVIOUS ISOLATION VALVE STATE,
                CS      Q                       #        C = CURRENT VALVE STATE (CH32)).
                MASK    PVALVEST
                ADS     L                       # RESULT NZ INDICATES ACTION REQUIRED.

                EXTEND
                BZF     RCSMONEX                # QUIT IF NO ACTION REQUIRED.

                EXTEND
                MP      BIT7                    # MOVE BITS 8-1 OF A TO 14-7 OF L.
                XCH     L                       # ZERO TO L IN THE PROCESS.

 -3             INCR    L
                DOUBLE                          # BOUND TO GET OVERFLOW IN THIS LOOP,
                OVSK                            # SINCE WE ASSURED INITIAL NZ IN A.
                TCF     -3

                INDEX   L
                CA      BIT8 -1                 # SAVE THE RELEVANT BIT (8-1).
                TS      Q
                MASK    PVALVEST                # LOOK AT PREVIOUS VALVE STATE BIT.
                CCS     A
                TCF     VOPENED                 # THE VALVE HAS JUST BEEN OPENED.
```

```
                CS      CH5MASK                 # THE VALVE HAS JUST BEEN CLOSED.
                INDEX   L
                MASK    5FAILTAB
                ADS     CH5MASK                 # SET INHIBIT BIT FOR CHANNEL 5 JET.

                CS      CH6MASK
                INDEX   L
                MASK    6FAILTAB
                ADS     CH6MASK                 # SET INGIBIT BIT FOR CHANNEL 6 JET

                CA      Q
                ADS     PVALVEST                # RECORD ACTION TAKEN.

                TCF     1/ACCFIX                # SET UP 1/ACCJOB AND EXIT.

# Page 192
VOPENED         INDEX   L                       # A VALVE HAS JUST BEEN OPENED.
                CS      5FAILTAB
                MASK    CH5MASK
                TS      CH5MASK                 # REMOVE INHIBIT BIT FOR CHANNEL 5 JE

                INDEX   L
                CS      6FAILTAB
                MASK    CH6MASK
                TS      CH6MASK                 # REMOVE INHIBIT BIT FOR CHANNEL 6 JE

                CS      Q
                MASK    PVALVEST
                TS      PVALVEST                # RECORD ACTION TAKEN.

1/ACCFIX        CAF     PRIO27                  # SET UP 1/ACCS SO THAT THE SWITCH CU
                TC      NOVAC                   #       FOR TJETLAW CAN BE MODIFIED I
                EBANK=  AOSQ                    #       HAS BEEN ALTERED.
                2CADR   1/ACCJOB

                TCF     RCSMONEX                # EXIT.

5FAILTAB        EQUALS  -1                      # CH 5 JET BIT CORRESPONDING TO CH 32
                OCT     00040                   # 8
                OCT     00020                   # 7
                OCT     00100                   # 6
                OCT     00200                   # 5
                OCT     00010                   # 4
                OCT     00001                   # 3
                OCT     00004                   # 2
                OCT     00002                   # 1
```

```
6FAILTAB        EQUALS  -1                      # CH 6 JET BIT CORRESPONDING TO CH 32 BIT:
                OCT     00010                   # 8
                OCT     00020                   # 7
                OCT     00004                   # 6
                OCT     00200                   # 5
                OCT     00001                   # 4
                OCT     00002                   # 3
                OCT     00040                   # 2
                OCT     00100                   # 1
```

Uses A 80, CHAN 191, CHAN32 87, COUNT 142, EBANK 80, IT 185, L 80, MODE 145, P 188, Q 80, RESTART 57, SAVE 191, STATE 138, and TC 169.

4.5 ags initialization

2111 ⟨*ags initialization* 2111⟩≡ (2041)
⟨*Page LM0206* 2112⟩
⟨*Page LM0207* 2114⟩
⟨*Page LM0208* 2116⟩
⟨*Page LM0209* 2118⟩
⟨*Page LM0210* 2119⟩

2112 ⟨*Page LM0206* 2112⟩≡ (2111 2639)

```
# PROGRAM NAME:  AGS INITIALIZATION (R47)
#
# WRITTEN BY:  RHODE/KILROY/FOLLETT
#
# MOD NO.:      0
# DATE:         23 MARCH 1967
# MOD BY:       KILROY
#
# MOD NO.:      1
# DATE:         28 OCTOBER 1967
# MOD BY:       FOLLETT
#
# FUNCT. DESC.: (1) TO PROVIDE THE AGS ABORT ELECTRONICS ASSEMBLY (AEA) WITH THE LEM
#               (POSITION,VELOCITY,TIME) IN LEM IMU COORDINATES BY MEANS OF THE LGC I
#
#               (2) TO ZERO THE ICDU, LGC, AND AEA GIMBAL ANGLE COUNTER SIMULTANEOUSI
#               COMMON ZERO REFERENCE FOR THE MEASUREMENT OF GIMBAL (EULER) ANGLES WI
#
#               (3) TO ESTABLISH THE GROUND ELAPSED TIME OF AEA CLOCK ZERO.  (IF AN A
#               REQUESTED DURING THIS PROGRAM
#
# LOG SECTION:  AGS INITIALIZATION
#
# CALLING SEQ:  PROGRAM IS ENTERED WHEN ASTRONAUT KEYS V47E ON DSKY.
#               R47 MAY BE CALLED AT ANY TIME EXCEPT WHEN ANOTHER EXTENDED VERB IS IN
#
# SUBROUTINES
# CALLED:
#
# NORMAL EXIT:  ENDEXT
#
# ALARM/ABORT:  ALARM -- BAD REFSMMAT -- CODE:220
#               OPERATOR ERROR IF V47 SELECTED DURING ANOTHER EXTENDED VERB.
#
# ERASABLES
# USED:         SAMPTIME        (2)     TIME OF :ENTER: KEYSTROKE
#               AGSK            (2)     GROUND ELAPSED TIME OF THE AEA CLOCK :ZERO:
#               AGSBUFF         (140)   CONTAINS AGS INITIALIZATION DATA (SEE :OUTPUT
#               AGSWORD         (1)     PREVIOUS DOWNLIST SAVED HERE

                EBANK=  AGSBUFF

                BANK    40
                SETLOC  R47
```

```
                BANK

                COUNT*  $$/R47

AGSINIT         CAF     REFSMBIT
                MASK    FLAGWRD3                        # CHECK REFSMFLG.
                CCS     A
```

Uses A 80, CODE 140, COUNT 142, EBANK 80, FLAGWRD3 105, REFSMBIT 107, REFSMFLG 107, REFSMMAT 172, SAMPTIME 80, and STATE 138.

2114 ⟨*Page LM0207* 2114⟩≡ (2111 2639)

```
                TC      REDSPTEM                # REFSMMAT IS OK
                TC      ALARM                   # REFSMMAT IS BAD
                OCT     220
                TC      ENDEXT

NEWAGS          EXTEND
                DCA     SAMPTIME                # TIME OF THE :ENTER: KEYSTRO
                DXCH    AGSK                    # BECOMES NEW AEA CLOCK :ZERO

REDSPTEM        EXTEND
                DCA     AGSK
                DXCH    DSPTEMX
AGSDISPK        CAF     V06N16
                TC      BANKCALL                # R1 = 00XXX. HRS., R2 = 000X
                CADR    GOMARKF                 # R3 = 0XX.XX SEC.
                TC      ENDEXT                  # TERMINATE RETURN
                TC      AGSVCALC                # PROCEED RETURN
                CS      BIT6                    # IS ENTER VIA A V32
                AD      MPAC
                EXTEND
                BZF     NEWAGS                  # YES, USE KEYSTROKE TIME FOR

                EXTEND                          # NO, NEW AGSK LOADED VIA V25
                DCA     DSPTEMX                 # LOADED INTO DSPTEMX BY KEY
                TC      REDSPTEM -1             # V25E FOLLOWED BY HRS.,MINS.
                                                # DISPLAY THE NEW K.

AGSVCALC        TC      INTPRET
                SET
                        NODOFLAG                # DON'T ALLOW V37
                SET     EXIT
                        XDSPFLAG

                CAF     V06N16
                TC      BANKCALL
                CADR    EXDSPRET

                TC      INTPRET                 # EXTRAPOLATE LEM AND CSM STA
                RTB                             # TO THE PRESENT TIME
                        LOADTIME                # LOAD MPAC WITH TIME2,TIME1
                STCALL  TDEC1                   # CALCULATE LEM STATE VECTOR
                        LEMPREC
                CALL                            # CALL ROUTINE TO CONVERT TO
                        SCALEVEC                # PROVIDE PROPER SCALING
                STODL   AGSBUFF                 # (LEMPREC AND CSMPREC LEAVE
```

```
        TAT                          # TAT = TIME TO WHICH RATT1 AND VATT1 A
STCALL  TDEC1                        # COMPUTED (CSEC SINCE CLOCK START B-28
        CSMPREC                      # CALCULATE CSM STATE VECTOR FOR SAME T
CALL
        SCALEVEC
```

Uses A 80, DSPTEMX 154, MPAC 145, NODOFLAG 105, R2 188, REFSMMAT 172, SAMPTIME 80, STATE 138, TC 169, TIME1 80, TIME2 80, and XDSPFLAG 113.

2116 ⟨*Page LM0208* 2116⟩≡ (2111 2639)

```
                STODL   AGSBUFF +6
                        TAT
                DSU     DDV                     # CALCULATE AND STORE THE TIN
                        AGSK
                        TSCALE
                STORE   AGSBUFF +12D
                EXIT

                CAF     LAGSLIST
                TS      DNLSTCOD

                CAF     20SEC                   # DELAY FOR 20 SEC WHILE THE
                TC      BANKCALL                # DOWNLIST IS TRANSMITTED
                CADR    DELAYJOB

                CA      AGSWORD
                TS      DNLSTCOD                # RETURN TO THE OLD DOWNLIST
                CAF     IMUSEBIT
                MASK    FLAGWRD0                # CHECK IMUSE FLAG.
                CCS     A
                TC      AGSEND                  # IMU IS BEING USED -- DO NOT
CKSTALL         CCS     IMUCADR                 # CHECK FOR IMU USAGE WHICH A
                TCF     +3                      # IMUSE BIT:  I.E., IMU COMPE
                TCF     +6                      # FREE.  GO AHEAD WITH THE IN
                TCF     +1
 +3             CAF     TEN                     # WAIT .1 SEC AND TRY AGAIN.
                TC      BANKCALL
                CADR    DELAYJOB
                TCF     CKSTALL

 +6             TC      BANKCALL                # IMU IS NOT IN USE
                CADR    IMUZERO                 # SET IMU ZERO DISCRETE FOR 3
                TC      BANKCALL                # WAIT 3 SEC FOR COUNTERS TO
                CADR    IMUSTALL
                TC      AGSEND
AGSEND          TC      DOWNFLAG                # ALLOW V37
                ADRES   NODOFLAG

                CAF     V50N16
                TC      BANKCALL
                CADR    GOMARK3
                TCF     ENDEXT
                TCF     ENDEXT
                TC      ENDEXT
```

```
SCALEVEC        VLOAD   MXV
                        VATT1
                        REFSMMAT
                VXSC    VSL2
                        VSCALE
```

Uses A 80, DNLSTCOD 148, FLAGWRD0 95, I 206, IMUCADR 163, IMUSE 95, IMUSEBIT 97, NODOFLAG 105, REFSMMAT 172, and TC 169.

2118 ⟨*Page LM0209* 2118⟩≡ (2111 2639)

```
                VAD     VAD                     # THIS SECTION ROUNDS THE VEC
                        AGSRND1                 # CORRECTS FOR THE FACT THAT
                        AGSRND2                 # IS A 2'S COMPLEMENT MACHINE
                RTB                             # LGC IS A 1'S COMPLEMENT MAC
                        VECSGNAG
                STOVL   VATT1
                        RATT1
                MXV     VXSC
                        REFSMMAT
                        RSCALE
                VSL8    VAD                     # AGAIN THIS SECTION ROUNDS.
                        AGSRND1                 # ARE ADDED TO DEFEAT ALSIGNA
                VAD     RTB                     # CASE OF A HIGH-ORDER ZERO C
                        AGSRND2                 # A LOW ORDER NEGATIVE PART.
                        VECSGNAG
                LXA,1
                        VATT1
                SXA,1   LXA,1
                        MPAC +1
                        VATT1 +2
                SXA,1   LXA,1
                        MPAC +4
                        VATT1 +4
                SXA,1   RVQ
                        MPAC +6

LAGSLIST        =       ONE
V01N14          VN      0114
V50N00A         VN      5000
V00N25          EQUALS  OCT31
V06N16          VN      0616
V00N34          EQUALS  34DEC
V50N16          VN      5016
TSCALE          2DEC    100 B-10                # CSEC TO SEC SCALE FACTOR
20SEC           DEC     2000
RSCALE          2DEC    3.280839 B-3            # METERS TO FEET SCALE FACTOR
VSCALE          2DEC    3.280839 E2 B-9         # METERS/CS TO FEET/SEC SCALE
AGSRND1         2OCT    0000060000
                2OCT    0000060000
                2OCT    0000060000
AGSRND2         2OCT    0000037777
                2OCT    0000037777
S
```

Uses `A` 80, `E2` 236, `FACTOR` 226, `MPAC` 145, `REFSMMAT` 172, and `VN` 159.

2119 ⟨*Page LM0210* 2119⟩≡ (2111 2639)

```
2OCT    0000037777

SBANK=  LOWSUPER                    # FOR SUBSEQUENT LOW 2CADRS.
```

Uses LOWSUPER 67.

4.6 aotmark routine

2120 ⟨*aotmark routine* 2120⟩≡ (2041)

```
# Page 244
⟨Page LM0244 2121⟩
# Page 245
⟨Page LM0245 2122⟩
# Page 246
⟨Page LM0246 2123⟩
# Page 247
⟨Page LM0247 2124⟩
# Page 248
⟨Page LM0248 2125⟩
# Page 249
⟨Page LM0249 2126⟩
# Page 250
⟨Page LM0250 2128⟩
# Page 251
⟨Page LM0251 2129⟩
# Page 252
⟨Page LM0252 2130⟩
# Page 253
⟨Page LM0253 2132⟩
# Page 254
⟨Page LM0254 2134⟩
# Page 255
⟨Page LM0255 2136⟩
# Page 256
⟨Page LM0256 2137⟩
# Page 257
⟨Page LM0257 2138⟩
# Page 258
⟨Page LM0258 2139⟩
# Page 259
⟨Page LM0259 2140⟩
# Page 260
⟨Page LM0260 2141⟩
# Page 261
⟨Page LM0261 2142⟩
```

2121 ⟨*Page LM0244* 2121⟩≡ (2120 2645)

```
                BANK    12
                SETLOC  AOTMARK1
                BANK

                EBANK=  XYMARK
                COUNT*  $$/MARK

AOTMARK         INHINT
                CCS     MARKSTAT        # SEE IF AOTMARK BUSY
                TC      +2              # MARK SYSTEM BUSY -- DO ALARM
                TC      EXTVBCHK
                TC      P00D00
                OCT     00105

EXTVBCHK        CAF     SIX             # SEE IF EXT. VERB WORKING
                MASK    EXTVBACT
                CCS     A
                TCF     MKABORT         # YES -- ABORT

                CAF     BIT2            # NO -- DISALLOW SOME EXTENDED VERB ACTION
                ADS     EXTVBACT        # BIT2 RESET IN ENDMARK
MKVAC           CCS     VAC1USE         # LOOK FOR A VAC AREAD -- DO ABORT IF
                TCF     MKVACFND        # NONE AVAILABLE
                CCS     VAC2USE
                TCF     MKVACFND
                CCS     VAC3USE
                TCF     MKVACFND
                CCS     VAC4USE
                TCF     MKVACFND
                CCS     VAC5USE
                TCF     MKVACFND
                DXCH    BUF2
                TC      BAILOUT1        # ALL VAC AREAS OCCUPIED -- ABORT.
                OCT     01207

MKVACFND        AD      TWO
                TS      MARKSTAT        # STORE VAC ADR IN LOW 9 OF MARKSTAT

                CAF     ZERO
                INDEX   MARKSTAT
                TS      0 -1            # ZERO IN VACUSE REG TO SHOW VAC OCCUPIED

                CAF     PRIO15
                TC      FINDVAC         # SET UP JOB FOR GETDAT
                EBANK=  XYMARK
```

```
                2CADR   GETDAT

                RELINT
                TCF     SWRETURN
```

Uses A 80, BUF2 142, COUNT 142, EBANK 80, EXTVBACT 154, MARKSTAT 163, TC 169, VAC1USE 150, VAC2USE 150, VAC3USE 150, VAC4USE 150, and VAC5USE 150.

2122 ⟨*Page LM0245* 2122⟩≡ (2120 2645)

```
MKABORT         DXCH    BUF2
                TC      BAILOUT1        # CONFLICT WITH EXTENDED VERB
                OCT     01211

MKRELEAS        CAF     ZERO
                XCH     MARKSTAT        # SET MARKSTAT TO ZERO
                MASK    LOW9            # PICK UP VAC AREA AOR
                CCS     A
                INDEX   A
                TS      0               # SHOW MKVAC AREA AVAILABLE
                CAF     ONE
                TC      IBNKCALL
                CADR    GOODEND         # GO WAKE UP CALLING JOB
```

Uses A 80, BUF2 142, MARKSTAT 163, and TC 169.

2123 ⟨*Page LM0246* 2123⟩≡ (2120 2645)

```
KILLAOT         CAF     ZERO
                TS      EXTVBACT        # TERMINATE AOTMARK -- ALLOW EXT VERB
                TC      GOTOP00H
GETDAT          CS      MARKSTAT        # SET BIT12 TO DISCOURAGE MARKRUPT
                MASK    BIT12           #       BIT12 RESET AT GETMARK
                ADS     MARKSTAT

                CAF     V01N71          # DISPLAY DETENT AND STAR CODE
                TC      BANKCALL
                CADR    GOMARKF

                TCF     KILLAOT         # V34 -- DOES GOTOP00H
                TCF     DODAT           # V33 -- PROCEED -- USE THIS STAR FOR MARKS
ENTERDAT        TCF     GETDAT          # ENTER -- REDISPLAY STAR CODE

DODAT           CAF     HIGH9           # PICK DETENT CODE FROM BITS7-9 OF AOTCODE
                MASK    AOTCODE         # AND SEE IF CODE 1 TO 6
                EXTEND
                MP      BIT9
                TS      XYMARK          # STORE DETENT

                EXTEND
                BZMF    GETDAT          # COAS CALIBRATION CODE - NO GOOD HERE

                AD      NEG7            # SEE IF DETENT 7 FOR COAS
                EXTEND
                BZF     CODE7

                TCF     CODE1TO6

CODE7           CAF     V06N87*         # CODE 7, COAS SIGHTING, GET OPTIC AXIS
                TC      BANKCALL        # AZ AND EL OF SIGHTING DEVICE FROM ASTRO
                CADR    GOMARKF

                TCF     KILLAOT         # V34 -- DOES GOTOP00H
                TCF     +2              # PROCEED
                TCF     CODE7           # ON ENTER, RECYCLE
                EXTEND
                DCA     AZ              # PICK UP AZ AND EL IN SP 25 COMP
                INDEX   FIXLOC
                DXCH    8D              # STORE IN 8D AND 9D OF LOCAL VAC
                CAF     ZERO            # BACKUP SYSTEM TO BE USED
                TCF     COASCODE        # ZERO APPARENT ROTATION

CODE1TO6        INDEX   XYMARK          # INDEX AOT POSITION BY DET CODE
```

```
                CA      AOTEL -1
                INDEX   FIXLOC
                TS      9D              # STORE ELEVATION IN VAC+9D

                INDEX   XYMARK          # INDEX DET CODE 1,2 OR 3
```

Uses CODE 140, EXTVBACT 154, FIXLOC 140, MARKSTAT 163, STAR 186, and TC 169.

2124 ⟨*Page LM0247* 2124⟩≡ (2120 2645)

```
                CA      AOTAZ -1
                INDEX   FIXLOC
                TS      8D              # STORE AZIMUTH IN VAC +8D

                CA      AOTAZ +1        # COMPENSATION FOR APPARENT ROTATION OF
                EXTEND                  # AOT FIELD OF VIEW IN LEFT AND RIGHT
                INDEX   FIXLOC          # DETENTS IS STORED IN VAC +10D IN SP
                MSU     8D              # PRECISION ONE'S COMPLEMENT
  COASCODE      INDEX   FIXLOC
                TS      10D             # ROT ANGLE

                TC      INTPRET         # COMPUTE X AND Y PLANE VECTORS
```

Uses AZIMUTH 191, FIXLOC 140, and TC 169.

2125 ⟨*Page LM0248* 2125⟩≡ (2120 2645)

```
# THE OPTAXIS SUBROUTINE COMPUTES THE X AND Y MARK PLANE VECS AND
# ROTATES THEM THRU THE APPARENT FIELD OF VIEW ROTATION UNIQUE TO AOT
# OPTAXIS USES OANB TO COMPUTE THE OPTIC AXIS
#
#       INPUT --        AZIMUTH ANGLE IN SINGLE PREC AT CDU SCALE IN 8D OF JOB VAC
#                       ELEVATION ANGLE IN SINGLE PREC AT CDU SCALE IN 9D OF JOB VAC
#                       ROTATION ANGLE IN SINGLE PREC IS COMP SCALED BY PI IN 10D OF VAC
#
#       OUTPUT --       OPTIC AXIS VEC IN NG COORDS IN SCAXIS
#                       X-MARK PLANE 1/4VEC IN NB COORDS AT 18D OF JOB VAC
#                       Y-MARK PLANE 1/4VEC IN NB COORDS AT 12D OF JOB VAC

OPTAXIS         CALL                    # GO COMPUTE OA AN X AND Y PLANE VECS
                        OANB
                SLOAD   SR1             # LOAD APP ROTATION IN ONES COMP
                        10D             # RESCALE BY 2PI
                PUSH    SIN             # 1/2SIN(ROT) 0-1
                PDDL    COS
                PUSH    VXSC            # 1/2COS(ROT) 2-3
                        18D
                PDDL    VXSC            # 1/4COS(ROT)UYP 4-9
                        0
                        24D             # 1/4SIN(ROT)UXP
                BVSU    STADR           # UP 4-9
                STODL   12D             # YPNB=1/4(COS(ROT)UYP-SIN(ROT)UXP)
                VXSC    PDDL            # UP 2-3 UP 0-1 FOR EXCHANGE
                        24D             # 1/4COS(ROT)UXP        PUSH 0-5
                VXSC    VAD             # 1/4SIN(ROT)UYP
                        18D             # UP 0-5
                STADR
                STOVL   18D             # XPNB=1/4(COS(ROT)UXP+SIN(ROT)UYP)
                        LO6ZEROS        # INITIALIZE AVE STAR VEC ACCUMULATOR
                STORE   STARAD +6
                EXIT
                TCF     GETMKS
```

Uses AZIMUTH 191, LO6ZEROS 71, SCAXIS 219, STAR 186, and STARAD 186.

2126 ⟨*Page LM0249* 2126⟩≡ (2120 2645)

```
# THE OANB SUBROUTINE COMPUTES THE OPTIC AXIS OF THE SIGHTING INSTRUMENT
# FROM AZIMUTH AND ELEVATION INPUT FROM THE ASTRONAUT.
#
#       INPUT --        AZIMUTH ANGLE IN SINGLE PREC 2'S COMP IN 8D OF JOB VAC
#                       ELEVATION ANGLE IN SINGLE PREC 2'S COMP IN 9D OF VAC
#
#       OUTPUT --       OPTIC AXIS IN NB COORDS. IN SCAXIS
#                       X-PLANE 1/2VEC IN NB COORDS AT 24D OF VAC
#                       Y-PLANE 1/2VEC IN NB COORDS AT 18D OF VAC

                BANK    05
                SETLOC  AOTMARK2
                BANK

                COUNT*  $$/MARK

OANB            SETPD   STQ
                        0
                        GCTR            # STORE RETURN
                SLOAD   RTB
                        9D              # PICK UP SP ELV
                        CDULOGIC
                PUSH    COS
                PDDL    SIN             # 1/2COS(ELV)   PD 0-1
                STADR
                STODL   SCAXIS          # OAX=1/2SIN(ELV)
                        8D
                RTB
                        CDULOGIC
                PUSH    COS
                STORE   20D             # STORE UYP(Y)  20-21
                PDDL    SIN             # 1/2COS(AZ)    PD 2-3
                PUSH    DCOMP           # PUSH 1/2S IN (AZ)     4-5
                STODL   22D             # STORE UYP(Z)  22-23
                        LO6ZEROS
                STODL   18D             # STORE UYP(X)  18-19
                DMP     SL1
                        0
                STODL   SCAXIS +2       # OAY=1/2COS(ELV)SIN(AZ)
                DMP     SL1             # UP    2-3
                STADR                   # UP    0-1
                STOVL   SCAXIS +4       # OAZ=1/2COS(ELV)COS(AZ)
                        18D             # LOAD UYP VEC
                VXV     UNIT
                        SCAXIS          # UXP VEC=UYP X OA
```

```
STORE   24D             # STORE UXP
GOTO
        GCTR
```

Uses AZIMUTH 191, COUNT 142, LO6ZEROS 71, SCAXIS 219, and Z 80.

2128 ⟨*Page LM0250* 2128⟩≡ (2120 2645)

```
# SURFSTAR COMPUTES A STAR VECTOR IN SM COORDINATES FOR LUNAR
# SURFACE ALIGNMENT AND EXITS TO AVEIT TO AVERAGE STAR VECTORS.
#
#       GIVEN   X-MARK PLANE 1/4 VEC IN NB AT 18D OF LOCAL VAC
#               Y-MARK PLANE 1/4 VEC IN NB AT 12D OF LOCAL VAC
#               CURSOR SP 2COMP AT POSITION 1 OF INDEXED MARKVAC
#               SPIRAL SP 2COMP AT POSITION 3 OF INDEXED MARKVAC
#               CDUY,Z,X AT POSITIONS 0,2,4 OF INDEXED MARKVAC

                BANK    15
                SETLOC  P50S
                BANK
                COUNT*  $$/R59

SURFSTAR        VLOAD*
                        0,1             # PUT X-MARK CDUS IN CDUSPOT FOR TRG*NBSM
                STORE   CDUSPOT
                SLOAD*  RTB
                        1,1             # PICK UP YROT
                        CDULOGIC
                STORE   24D             # STORE CURSOR FOR SPIRAL COMP (REVS)
                BZE
                        YZCHK           # IF YROT ZERO -- SEE IF SROT ZERO
JUSTZY          PUSH    COS
                PDDL    SIN             # 1/2COS(YROT)  0-1
                VXSC    PDDL            # UP 0-1        1/8SIN(YROT)UXP 0-5
                        18D
                VXSC    VSU             # UP    0-5
                        12D             # UYP
                UNIT    VXV
                        SCAXIS
                UNIT    PUSH
                SLOAD*  RTB
                        3,1             # PICK UP SPIRAL
                        CDULOGIC
                STORE   26D             # STORE SPIRAL (REVS)
                DSU     DAD
                        24D
                        ABOUTONE
                DMP
                        DP1/12
                STORE   26D             # SEP=(360 + SPIRAL -CURSOR)/12
                SIN     VXSC            # UP    0-5
                VSL1    PDDL            # 1/2SIN(SEP)(UPP X OA) 0-5
                        26D
```

```
                COS     VXSC
                        SCAXIS
                VSL1    VAD             # UP    0-5
JUSTOA          UNIT    CALL
                        TRG*NBSM
                STCALL  24D             # STAR VEC IN SM
                        AVEIT           # GO AVERAGE
```

Uses A 80, CDUS 80, CDUSPOT 152, CDUY 80, COUNT 142, P50S 61, REVS 206, SCAXIS 219, STAR 186, and Z 80.

2129 ⟨*Page LM0251* 2129⟩≡ (2120 2645)

```
ABOUTONE        2DEC    .99999999

DP1/12          EQUALS  DEG30           # .08333333
                BANK    7
                SETLOC  AOTMARK1
                BANK
                COUNT*  $$/MARK
YZCHK           SLOAD*  BZE             # YROT ZERO AND IF SROT ZERO FORCE STAR
                        3,1             # ALONG OPTIC AXIS
                        YSZERO
                DLOAD   GOTO
                        24D
                        JUSTZY          # SROT NOT ZERO -- CONTINUE NORMALLY
YSZERO          VLOAD   GOTO
                        SCAXIS
                        JUSTOA
```

Uses COUNT 142, SCAXIS 219, and STAR 186.

2130 ⟨*Page LM0252* 2130⟩≡ (2120 2645)

```
# THE GETMKS ROUTINE INITIALIZES THE SIGHTING MARK PROCEDURE

GETMKS          CAF     ZERO            # INITIALIZE MARK ID REGISTER AND MARK CNT
                TS      XYMARK
                TS      MARKCNTR
                CAF     LOW9            # ZERO BITS10 TO 15 RETAINING MKVAC ADR
                MASK    MARKSTAT
                TS      MARKSTAT
                CAF     MKVB54*         # DISPLAY VB54 INITIALLY
PASTIT          TC      BANKCALL
                CADR    GOMARK4

                TCF     KILLAOT         # V34 -- DOES GOTOP00H
                TCF     MARKCHEX        # VB33 -- PROCEED, GOT MARKS, COMPUTE LOS
                TCF     GETDAT          # ENTER -- RECYCLE TO V01N71

MARKCHEX        CS      MARKSTAT        # SET BIT12 TO DISCOURAGE MARKRUPT
                MASK    BIT12
                ADS     MARKSTAT
                MASK    LOW9
                TS      XYMARK          # JAM MARK VAC ADR IN XYMARK FOR AVESTAR
                CAF     ZERO
                TS      MKDEX           # SET MKDEX ZERO FOR LOS VEC CNTR
                CA      MARKSTAT
                MASK    PRIO3           # SEE IF LAST MK PART COMPLETE
                TS      L
                CAF     PRIO3           # BITS10 AND 11
                EXTEND
                RXOR    LCHAN
                EXTEND
                BZF     AVESTAR         # LAST PAIR COMPLETE -- TO COMPUTE LOS
CNTCHK          CCS     MARKCNTR        # NO PAIR SHOWING -- SEE IF PAIR IN HOLD
                TCF     +2              # PAIR BURIED -- DECREMENT COUNTER
                TCF     MKALARM         # NO PAIR -- ALARM
                TS      MARKCNTR        # STORE DECREMENTED COUNTER

AVESTAR         CAF     BIT12           # INITIALIZE MKDEX FOR STAR LOS COUNTER
                ADS     MKDEX           # MKDEX WAS INITIALIZED ZERO IN MARKCHEX
                CS      MARKCNTR
                EXTEND
                MP      SIX             # GET C(L) = -6 MARKCNTR
                CS      XYMARK
                AD      L               # ADD -- MARK VAC ADR SET IN MARKCHEX
                INDEX   FIXLOC
                TS      X1              # JAM -- CDU ADR OF X-MARK IN X1
```

```
CA      FIXLOC          # SET PD POINTER TO ZERO
TS      PUSHLOC

TC      INTPRET
```

Uses CNTR 200, FIXLOC 140, L 80, LCHAN 87, MARKSTAT 163, PUSHLOC 145, STAR 186, TC 169, and X1 85.

2132 ⟨*Page LM0253* 2132⟩≡ (2120 2645)

```
                    BON     VLOAD*
                            SURFFLAG        # IF ON SURFACE COMPUTE VEC AT SURFSTAR
                            SURFSTAR
                            1,1             # PUT Y-MARK CDUS IN CDUSPOT FOR TRG*NBSM
                    STOVL   CDUSPOT
                            12D             # LOAD Y-PLANE VECTOR IN NG
                    CALL
                            TRG*NBSM        # CONVERT IT TO STABLE MEMBER
                    PUSH    VLOAD*
                            0,1             # PUT X-MARK CDUS IN CDUSPOT FOR TRG*NBSM
                    STOVL   CDUSPOT
                            18D             # LOAD X-PLANE VECTOR IN NB
                    CALL
                            TRG*NBSM        # CONVERT IT TO STABLE-MEMBER
                    VXV     UNIT            # UNIT(XPSM * YPSM)
                    STADR
                    STORE   24D

AVEIT               SLOAD   PDVL            # N(NUMBER OF VECS) IN 0-1
                            MKDEX
                            24D             # LOAD CURRENT VECTOR
                    VSR3    V/SC
                            0
                    STODL   24D             # VEC/N
                            0
                    DSU     DDV
                            DP1/8           # (N-1)/N
                    VXSC    VAD
                            STARAD +6       # ADD VEC TO PREVIOUSLY AVERAGED VECTOR
                            24D             # (N-1)/N AVESTVEC + VEC/N
                    STORE   STARAD +6       # AVERAGE STAR VECTOR
                    STORE   STARSAV2
                    EXIT
                    CCS     MARKCNTR        # SEE IF ANOTHER MARK PAIR IN MKVAC
                    TCF     AVESTAR -1      # THERE IS -- GO GET IT -- DECREMENT COUNTER
ENDMARKS            CAF     FIVE            # NO MORE MARKS -- TERMINATE AOTMARK
                    INHINT
                    TC      WAITLIST
                    EBANK=  XYMARK
                    2CADR   MKRELEAS

                    TC      ENDMARK

MKALARM             TC      ALARM           # NOT A PAIR TO PROCESS -- DO GETMKS
                    OCT     111
```

	TCF	GETMKS
V01N71	VN	171
V06N87*	VN	687

Uses A 80, CDUS 80, CDUSPOT 152, EBANK 80, IT 185, N 206, STAR 186, STARAD 186, STARSAV2 185, SURFFLAG 127, TC 169, V 229, and VN 159.

2134 ⟨*Page LM0254* 2134⟩≡ (2120 2645)

```
# MARKRUPT IS ENTERED FROM INTERRUPT LEAD-INS AND PROCESSES CHANNEL 16
# CAUSED BY X,Y MARK OR MARK REJECT OR BY THE RATE OF DESCENT SWITCH

MARKRUPT        TS      BANKRUPT
                CA      CDUY            # STORE CDUS AND TIME NOW -- THEN SEE IF
                TS      ITEMP3          # WE NEED THEM
                CA      CDUZ
                TS      ITEMP4
                CA      CDUX
                TS      ITEMP5
                EXTEND
                DCA     TIME2
                DXCH    ITEMP1
                XCH     Q
                TS      QRUPT

                CAF     OCT34           # SEE IF X OR Y MARK OR MKREJECT
                EXTEND
                RAND    NAVKEYIN
                CCS     A
                TCF     +2              # ITS A LIVE ONE -- SEE IF ITS WANTED
                TCF     SOMEKEY         # ITS SOME OTHER KEY

                CAF     BIT12           # ARE WE ASKING FOR A MARK
                MASK    MARKSTAT
                CCS     A
                TC      RESUME          # DON'T WANT MARK OR MKREJECT -- DO NOTHING

                CCS     MARKSTAT        # ARE MARKS BEING ACCEPTED
                TCF     FINDKEY         # THEY ARE -- WHICH ONE IS IT
                TC      ALARM           # MARKS NOT BEING ACCEPTED -- DO ALARM
                OCT     112
                TC      RESUME

FINDKEY         CAF     BIT5            # SEE IF MARK REJECT.
                EXTEND
                RAND    NAVKEYIN
                CCS     A
                TCF     MKREJ           # IT'S A MARK REJECT

                CAF     BIT4            # SEE IF Y MARK
                EXTEND
                RAND    NAVKEYIN
                CCS     A
```

```
TCF     YMKRUPT         # IT'S A Y MARK

CAF     BIT3            # SEE IF X MARK
EXTEND
RAND    NAVKEYIN
```

Uses A 80, BANKRUPT 80, CDUS 80, CDUX 80, CDUY 80, CDUZ 80, IT 185, ITEMP1 138, ITEMP3 138, ITEMP4 138, ITEMP5 138, MARKSTAT 163, NAVKEYIN 87, Q 80, QRUPT 80, TC 169, and TIME2 80.

2136 ⟨*Page LM0255* 2136⟩≡ (2120 2645)

```
                CCS     A
                TCF     XMKRUPT         # IT'S A X MARK

SOMEKEY         CAF     OCT140          # NOT MARK OR MKREJECT -- SEE IF DESCENT BITS
                EXTEND
                RAND    NAVKEYIN
                EXTEND
                BZF     +3              # IF NO BITS

                TC      POSTJUMP        # IF DESCENT BITS
                CADR    DESCBITS

                TC      ALARM           # NO INBITS IN CHANNEL 16.
                OCT     113

                TC      RESUME

XMKRUPT         CAF     ZERO
                TS      RUPTREG1        # SET X MARK STORE INDEX TO ZERO
                CAF     BIT10
                TCF     +4
YMKRUPT         CAF     ONE
                TS      RUPTREG1        # SET Y MARK STORE INDEX TO ONE
                CAF     BIT11
                TS      XYMARK          # SET MARK IDENTIFICATION

                TC      MARKTYPE        # SEE IF SURFACE MARK
                TCF     SURFSTOR        # SURFACE MARK -- JUST STORE CDUS

                CAF     BIT14           # GOT A MARK -- SEE IF MARK PARI MADE
                MASK    MARKSTAT
                EXTEND
                BZF     VERIFYMK        # NOT A PAIR, NORMAL PROCEDURE
                CS      MARKCNTR        # GO A PAIR, SEE IF ANOTHER CAN BE MADE
                AD      FOUR            # IF SO, INCREMENT POINTER, CLEAR BITS 10,11
                EXTEND
                BZMF    5MKALARM        # HAVE FIVE MARK PAIRS -- DON'T ALLOW MARK
                INCR    MARKCNTR        # OK FOR ANOTHER PAIR, INCR POINTER
                CS      PRIO23          # CLEAR BITS 10,11,14 FOR NEXT PAIR
                MASK    MARKSTAT
                TS      MARKSTAT

VERIFYMK        CA      XYMARK
                MASK    MARKSTAT
                CCS     A
```

```
                TCF     +2              # THIS MARK NOT DESIRED
                TCF     VACSTOR         # MARK DESIRED -- STORE CDUS
                TC      ALARM
                OCT     114
                TC      RESUME          # RESUME -- DISPLAY UNCHANGED -- WAIT FOR ACTION
```

Uses A 80, CDUS 80, MARKSTAT 163, NAVKEYIN 87, RUPTREG1 138, and TC 169.

2137 ⟨*Page LM0256* 2137⟩≡ (2120 2645)

```
  5MKALARM      TC      ALARM           # ATTEMPTING TO MAKE MORE THAN 5 MK PAIRS
                OCT     107
                TC      MARKTYPE        # SEE IF SURFACE MARK
                TCF     DSPV6N79        # IT IS
                TC      RESUME          # DON'T CHANGE DISPLAY -- DO NOTHING
```

Uses IT 185 and TC 169.

2138 ⟨*Page LM0257* 2138⟩≡ (2120 2645)

```
MKREJ           TC      MARKTYPE        # SEE IF SURFACE
                TCF     SURFREJ         # SURFACE -- JUST CHECK MARK COUNTER

                CAF     PRIO3           # INFLIGHT -- SEE IF MARKS MADE
                MASK    MARKSTAT
                CCS     A
                TCF     REJECT          # MARKS MADE -- REJECT ONE
REJALM          TC      ALARM           # NO MARK TO REJECT -- BAD PROCEDURE -- ALARM
                OCT     115
                TC      RESUME          # DESIRED ACTION DISPLAYED

REJECT          CS      PRIO30          # ZERO BIT14, SHOW REJ., SEE IF MARK SINCE
                MASK    MARKSTAT        # LAST REJECT
                AD      BIT13
                XCH     MARKSTAT
                MASK    BIT13
                CCS     A
                TCF     REJECT2         # ANOTHER REJECT SET BIT 10+11 TO ZERO

                CS      XYMARK          # MARK MADE SINCE REJECT -- REJECT MARK IN 1D
RENEWMK         MASK    MARKSTAT
                TS      MARKSTAT
                TCF     REMARK          # GO REQUEST NEW MARK ACTION

REJECT2         CS      PRIO3           # ON SECOND REJECT -- DISPLAY VB53 AGAIN
                TCF     RENEWMK

SURFREJ         CCS     MARKCNTR        # IF MARK DECREMENT COUNTER
                TCF     +2
                TCF     REJALM          # NO MARKS TO REJECT -- ALARM
                TS      MARKCNTR
                TC      RESUME
```

Uses `A` 80, `INFLIGHT` 65, `MARKSTAT` 163, and `TC` 169.

2139 ⟨*Page LM0258* 2139⟩≡ (2120 2645)

```
# MARKTYPE TESTS TO SEE IF LEM ON LUNAR SURFACE.  IF IT IS RETURN TO LOC+1

MARKTYPE        CS      FLAGWRD8        # SURFFLAG ******** TEMPORARY ******
                MASK    BIT8
                CCS     A
                INCR    Q               # IF SURFACE MARK RETURN TO LOC +1
                TC      Q               # IF INFLIGHT MARK RETURN TO LOC +2

SURFSTOR        CAF     ZERO            # FOR SURFACE MARK ZERO MARK KIND INDEX
                TS      RUPTREG1

                CS      MARKSTAT        # SET BITS10,11 TO SHOW SURFACE MARK
                MASK    PRIO3           # FOR MARKCHEX
                ADS     MARKSTAT

VACSTOR         CAF     LOW9
                MASK    MARKSTAT        # STORE MARK VAC ADR IN RUPTREG2
                TS      RUPTREG2
                EXTEND
                DCA     ITEMP1          # PICK UP MARKTIME
                DXCH    TSIGHT          # STORE LAST MARK TIME
                CA      MARKCNTR        # 6 X MARKCNTR FOR STORE INDEX
                EXTEND
                MP      SIX
                XCH     L               # GET INDEX FROM LOW ORDER PART
                AD      RUPTREG2        # SET CDU STORE INDEX TO MARKVAC
                ADS     RUPTREG1        # INCREMENT VAC PICKUP BY MARK FOR FLIGHT
                TS      MKDEX           # STORE HERE IN CASE OF SURFACE MARK
                CA      ITEMP3
                INDEX   RUPTREG1
                TS      0               # STORE CDUY
                CA      ITEMP4
                INDEX   RUPTREG1
                TS      2               # STORE CDUZ
                CA      ITEMP5
                INDEX   RUPTREG1
                TS      4               # STORE CDUX
                TC      MARKTYPE        # IF SURFACE MARK -- JUST DO SURFJOB
                TCF     SURFJOB

                CAF     BIT13           # CLEAR BIT13 TO SHOW MARK MADE
                AD      XYMARK          # SET MARK ID IN MARKSTAT
                COM
                MASK    MARKSTAT
                AD      XYMARK
```

```
TS      MARKSTAT
MASK    PRIO3           # SEE IF X, Y MARK MADE
TS      L
```

Uses A 80, CDUX 80, CDUY 80, CDUZ 80, FLAGWRD8 125, INFLIGHT 65, IT 185, ITEMP1 138, ITEMP3 138, ITEMP4 138, ITEMP5 138, L 80, LOC 145, MARKSTAT 163, MARKTIME 161, Q 80, RUPTREG1 138, RUPTREG2 138, SURFFLAG 127, TC 169, and TSIGHT 183.

2140 ⟨*Page LM0259* 2140⟩≡ (2120 2645)

```
CA      PRIO3
EXTEND
RXOR    LCHAN
CCS     A
TCF     REMARK          # NOT PAIR YET, DISPLAY MARK ACTION
CS      MARKSTAT        # MARK PAIR COMPLETE -- SET BIT14
MASK    BIT14
ADS     MARKSTAT
TCF     REMARK          # GO DISPLAY V54
```

Uses A 80, LCHAN 87, and MARKSTAT 163.

2141 ⟨*Page LM0260* 2141⟩≡ (2120 2645)

```
REMARK          CAF     PRIO3           # BITS 10 AND 11
                MASK    MARKSTAT
                EXTEND
                MP      BIT6            # SHIFT MARK IDS TO BE 0 TO 3 FOR INDEX
                TS      MKDEX           # STORE VERB INDEX
SURFJOB         CAF     PRIO15
                TC      NOVAC           # ENTER JOB TO CHANGE DISPLAY TO
                EBANK=  XYMARK          # REQUEST NEXT ACTION
                2CADR   CHANGEVB

                TC      RESUME

CHANGEVB        TC      MARKTYPE
                TCF     DSPV6N79        # SURFACE -- DISPLAY V 06 N 79
                INDEX   MKDEX           # INFLIGHT -- PICK UP MARK VB INDEX
                CAF     MKVB54
                TC      PASTIT          # PASTE UP NEXT MK VERB DISPLAY

# THE FOUR MKVBS ARE INDEXED -- THEIR ORDER CANNOT BE CHANGED

MKVB54          VN      5471            # MAKE X OR Y MARK
MKVB53          VN      5371            # MAKE Y MARK
MKVB52          VN      5271            # MAKE X MARK
MKVB54*         VN      5471            # MAKE X OR Y MARK
DP1/8           2DEC    .125

OCT34           OCT     34
V06N71          VN      671
V06N79*         VN      679
```

Uses EBANK 80, INFLIGHT 65, MARKSTAT 163, N 206, TC 169, V 229, and VN 159.

2142 ⟨*Page LM0261* 2142⟩≡ (2120 2645)

```
# ROUTINE TO REQUEST CURSOR AND SPIRAL MEASUREMENTS
                COUNT*  $$/R59

DSPV6N79        CAF     V06N79*         # CURSOR -- SPIRAL DISPLAY
                TC      BANKCALL
                CADR    GOMARKF

                TCF     KILLAOT         # V34 -- DOES GOTOP00H
                TCF     SURFEND         # V33 -- PROCEED, END MARKING
                CAF     BIT6            # IF V32(OCT40) IN MPAC DO RECYCLE
                MASK    MPAC            # OTHERWISE IT IS LOAD VB ENTER SO
                CCS     A               # RE-DISPLAY V06N79
                TCF     SURFAGAN        # VB32 -- RECYCLE
                TCF     DSPV6N79        # ENTER

SURFEND         CS      BIT14           # SET BIT14 TO SHOW MARK END
                MASK    MARKSTAT
                AD      BIT14
                TS      MARKSTAT

SURFAGAN        CA      CURSOR
                INDEX   MKDEX           # HOLDS VAC AREA POINTER FOR SURF MARKING
                TS      1               # STORE CURSOR SP 2COMP
                CA      SPIRAL
                INDEX   MKDEX
                TS      3               # STORE SPIRAL

                CS      MARKSTAT        # IF BIT 14 SET -- END MARKING
                MASK    BIT14
                EXTEND
                BZF     MARKCHEX
                CA      MARKCNTR        # THIS IS RECYCLE -- SEE IF 5 MARKS ALREADY
                AD      ONE
                COM
                AD      FIVE
                EXTEND
                BZMF    5MKALARM        # CAN'T RECYCLE -- TOO MANY MARKS -- ALARM
                INCR    MARKCNTR        # OF FOR RECYCLE -- INCR COUNTER
                TCF     GETMKS +3       # GO DISPLAY MARK VB
```

Uses `A` 80, `COUNT` 142, `IT` 185, `MARKSTAT` 163, `MPAC` 145, and `TC` 169.

4.7 lem geometry

2143 ⟨*lem geometry* 2143⟩≡ (2041 2738)

```
# Page 320
                BANK    23
                SETLOC  LEMGEOM
                BANK

                SBANK=  LOWSUPER
                EBANK=  XSM

# THESE TWO ROUTINES COMPUTE THE ACTUAL STATE VECTOR FOR LM,CSM BY ADDING
# THE CONIC R,V AND THE DEVIATIONS R,V.  THE STATE VECTORS ARE CONVERTED TO
# METERS B-29 AND METERS/CSEC B-7 AND STORED APPROPRIATELY IN RN,VN OR
# R-OTHER,V-OTHER FOR DOWNLINK.  THE ROUTINES NAMES ARE SWITCHED IN THE
# OTHER VEHICLES COMPUTER.
#
# INPUT
#       STATE VECTOR IN TEMPORARY STORAGE AREA
#       IF STATE VECTOR IS SCALED POS B27 AND VEL B5
#               SET X2 TO +2
#       IF STATE VECTOR IS SCALED POS B29 AND VEL B7
#               SET X2 TO 0
#
# OUTPUT
#       R(T) IN RN, V(T) IN VN, T IN PIPTIME
# OR
#       R(T) IN R-OTHER, V(T) IN V-OTHER        (T IS DEFINED BY T-OTHER)

                COUNT*  $$/GEOM
SVDWN2          BOF     RVQ             # SW=1=AVETOMID DOING W-MATRIX INTEG.
                        AVEMIDSW
                        +1
                VLOAD   VSL*
                        TDELTAV
                        0       -7,2
                VAD     VSL*
                        RCV
                        0,2
                STOVL   RN
                        TNUV
                VSL*    VAD
                        0       -4,2
                        VCV
                VSL*
                        0,2
```

```
                STODL   VN
                        TET
                STORE   PIPTIME
                RVQ
# Page 321
SVDWN1          VLOAD   VSL*
                        TDELTAV
                        0       -7,2
                VAD     VSL*
                        RCV
                        0,2
                STOVL   R-OTHER
                        TNUV
                VSL*    VAD
                        0       -4,2
                        VCV
                VSL*
                        0,2
                STORE   V-OTHER
                RVQ

# Page 322
# THE FOLLOWING ROUTINE TAKES A HALF UNIT TARGET VECTOR REFERRED TO NAV BASE COORDINA
# GIMBAL ORIENTATIONS AT WHICH THE RR MIGHT SIGHT THE TARGET.  THE GIMBAL ANGLES CORR
# ARE LEFT IN MODEA AND THOSE WHICH WOULD BE USED AFTER A REMODE IN MODEB.  THIS ROUT
# ANGLE LESS THAN 90 DEGS IN ABS VALUE WITH ARBITRARY SHAFT, WITH A CORRESPONDING DER
# SELECTION AND LIMIT CHECKING ARE DONE ELSEWHERE.
#
# THE MODE 1 CONFIGURATION IS CALCULATED FROM THE VECTOR AND THEN MODE 2 IS FOUND USI
#
#       S(2) = 180 + S(1)
#       T(2) = 180 - T(1)
#
# THE VECTOR ARRIVES IN MPAC WHERE TRG*SMNG OR *SMNB* WILL HAVE LEFT IT.

RRANGLES        STORE   32D
                DLOAD   DCOMP           # SINCE WE WILL FIND THE MODE 1 SHAFT
                        34D             # ANGLE LATER, WE CAN FIND THE MODE 1
                SETPD   ASIN            # TRUNNION BY SIMPLY TAKING THE ARCSIN OF
                        0               # THE Y COMPONENT, THE ASIN GIVIN AN
                PUSH    BDSU            # ANSWER WHOSE ABS VAL IS LESS THAN 90 DEG.
                        LODPHALF
                STODL   4               # MODE 2 TRUNNION TO 4.

                        LO6ZEROS
                STOVL   34D             # UNIT THE PROJECTION OF THE VECTOR
```

```
                        32D             #       IN THE X-Z PLANE
                UNIT    BOVB            # IF OVERFLOW, TARGET VECTOR IS ALONG Y
                        LUNDESCH        # CALL FOR MANEUVER UNLESS ON LUNAR SURF
                STODL   32D             # PROJECTION VECTOR.
                        32D
                SR1     STQ
                        S2
                STODL   SINTH           # USE ARCTRIG SINCE SHAFT COULD BE ARB.
                        36D
                SR1
                STCALL  COSTH
                        ARCTRIG
# Page 323
                PUSH    DAD             # MODE 1 SHAFT TO 2.
                        LODPHALF
                STOVL   6
                        4
                RTB                     # FIND MODE 2 CDU ANGLES.
                        2V1STO2S
                STOVL   MODEB
                        0
                RTB                     # MODE 1 ANGLES TO MODE A.
                        2V1STO2S
                STORE   MODEA
                EXIT

                CS      RADMODES        # SWAP MODEA AND MODEB IF RR IN MODE 2.
                MASK    ANTENBIT
                CCS     A
                TCF     +4

                DXCH    MODEA
                DXCH    MODEB
                DXCH    MODEA

                TC      INTPRET
                GOTO
                        S2
# Page 324
# GIVEN RR TRUNNION AND SHAFT (T,S) IN TANGNB,+1, FIND THE ASSOCIATED
# LINE OF SIGHT IN NAV BASE AXES.  THE HALF UNIT VECTOR, .5(SIN(S)COS(T),
# -SIN(T),COS(S)COS(T)) IS LEFT IN MPAC AND 32D.

                SETLOC  INFLIGHT
                BANK
```

```
                COUNT*  $$/GEOM

RRNB            SLOAD   RTB
                        TANGNB
                        CDULOGIC
                SETPD   PUSH            # TRUNNION ANGLE TO 0
                        0
                SIN     DCOMP
                STODL   34D             # Y COMPONENT

                COS     PUSH            # .5 COS(T) TO 0
                SLOAD   RTB
                        TANGNB +1
                        CDULOGIC
RRNB1           PUSH    COS             # SHAFT ANGLE TO 2
                DMP     SL1
                        0
                STODL   36D             # Z COMPONENT

                SIN     DMP
                SL1
                STOVL   32D
                        32D
                RVQ

# THIS ENTRY TO RRNB REQUIRES THE TRUNNION AND SHAFT ANGLES IN MPAC AND MPAC +1 RESPE

RRNBMPAC        STODL   20D             # SAVE SHAFT CDU IN 21.
                        MPAC            # SET MODE TO DP.  (THE PRECEEDING STORE
                                        # MAY BE DP, TP OR VECTOR.)
                RTB     SETPD
                        CDULOGIC
                        0
                PUSH    SIN             # TRUNNION ANGLE TO 0
                DCOMP
                STODL   34D             # Y COMPONENT
                COS     PUSH            # .5COS(T) TO 0
                SLOAD   RTB             # PICK UP CDU'S.
                        21D
                        CDULOGIC
                GOTO
                        RRNB1
# Page 325
# (This page has nothing on it.)
```

Uses A 80, AVEMIDSW 133, COMPUTER 115, COSTH 148, COUNT 142, EBANK 80, INFLIGHT 65, IT 185, LO6ZEROS 71, LODPHALF 71, LOWSUPER 67, MODE 145, MPAC 145, PIPTIME 159, R-OTHER 172, RCV 169, RN 159, S2 85, SAVE 191, SINTH 148, STATE 138, T-OTHER 172, TC 169, TDELTAV 169, TET 169, TNUV 169, V 229, V-OTHER 172, VCV 169, VEL 226, VN 159, W 183, X2 85, XSM 186, and Z 80.

4.8 r63 routine

2148 ⟨*r63 routine* 2148⟩≡ (2041 2788)

```
# Page 338
# SUBROUTINE NAME:      V89CALL
# MOD NO:       0                       DATE:           9 JAN 1968
# MOD BY:       DIGITAL DEVEL GROUP     LOG SECTION:    R63
#
# FUNCTIONAL DESCRIPTION:
#
# CALLED BY VERB 89 ENTER DURING P00.  PRIO 10 USED.  CALCULATES AND
# DISPLAYS FINAL FDAI BALL ANGLES TO POINT LM +X OR +Z AXIS AT CSM.
#
# 1. KEY IN V 89 E ONLY IF IN PROG 00.  IF NOT IN P00, OPERATOR ERROR AND
# EXIT R63, OTHERWISE CONTINUE.
#
# 2. IF IN P00, DO IMU STATUS CHECK ROUTINE (R02BOTH).  IF IMU ON AND ITS
# ORIENTATION KNOWN TO LGC, CONTINUE.
#
# 3. FLASH DISPLAY V 04 N 06.  R2 INDICATES WHICH SPACECRAFT AXIS IS TO
# BE POINTED AT CSM.  INITIAL CHOICE IS PREFERRED (+Z) AXIS (R2=1).
# ASTRONAUT CAN CHANGE TO (+X) AXIS (R2 NOT =1) BY V 22 E 2 E.  CONTINUE
# AFTER KEYING IN PROCEED.
#
# 4. BOTH VEHICLE STATE VECTORS UPDATED BY CONIC EQS.
#
# 5. HALF MAGNITUDE UNIT LOS VECTOR (IN STABLE MEMBER COORDINATES) AND
# HALF MAGNITUDE UNIT SPACECRAFT AXIS VECTOR (IN BODY COORDINATES)
# PREPARED FOR VECPOINT.
#
# 6. GIMBAL ANGLES FROM VECPOINT TRANSFORMED INTO FDAI BALL ANGLES BY
# BALLANGS.  FLASH DISPLAY V 06 N 18 AND AWAIT RESPONSE.
#
# 7     RECYCLE -- RETURN TO STEP 4.
#       TERMINATE -- EXIT R63
#       PROCEED -- RESET 3AXISFLAG AND CALL R60LEM FOR ATTITUDE MANEUVER.
#
# CALLING SEQUENCE:     V 89 E.
#
# SUBROUTINES CALLED:   CHECKP00H, R02BOTH, GOXDSPF, CSMCONIC, LEMCONIC,
#                       VECPOINT, BALLANGS, R60LEM.
#
# NORMAL EXIT MODES:    TC ENDEXT
#
# ALARMS:       1. OPERATOR ERROR IF NOT IN P00.
#               2. PROGRAM ALARM IF IMU IS OFF.
```

```
#               3. PROGRAM ALARM IF IMU ORIENTATION IS UNKNOWN.
#
# OUTPUT:       NONE
#
# ERASABLE INITIALIZATION REQUIRED:  NONE
#
# DEBRIS:       OPTION1, +1, TDEC1, PCINTVSM, SCAXIS, CPHI, CTHETA, CPSI,
# Page 339
#               3AXISFLAG.

                EBANK=  RONE
                BANK    32
                SETLOC  BAWLANGS
                BANK

                COUNT*  $$/R63
V89CALL         TC      BANKCALL        # IMU STATUS CHECK.  RETURNS IF ORIENTATION
                CADR    R02BOTH         # KNOWN.  ALARMS IF NOT.
                CAF     THREE           # ALLOW ASTRONAUT TO SELECT DESIRED
                TS      OPTIONX         # TRACKING ATTITUDE AXIS.
                CAF     ONE
                TS      OPTIONX  +1
                CAF     VB04N12         # V 04 N 12.
                TC      BANKCALL
                CADR    GOFLASH
                TC      ENDEXT          # TERMINATE
                TC      +2              # PROCEED
                TC      -5              # DATA IN.  OPTION1+1 = 1 FOR Z AXIS
V89RECL         TC      INTPRET         #                       2 FOR X AXIS
                RTB     DAD
                        LOADTIME        # READ PRESENT TIME
                        DP1MIN
                STORE   TSTART82        # SAVE TIME FOR LEMCONIC CALL
                STCALL  TDEC1           # STORE TIME FOR CSMCONIC CALL
                        CSMCONIC        # CSM STATE VECTOR UPDATE
                VLOAD                   # CSMCONIC LEFT R VECTOR IN RATT
                        RATT
                STODL   RONE            # SAVE FOR LINE OF SIGHT (LOS) COMPUTATION
                        TSTART82
                STCALL  TDEC1           # STORE TIME FOR LEMCONIC CALL
                        LEMCONIC        # LEM STATE VECTOR UPDATE
                VLOAD   VSU             # CSM POSITION -- LEM POSITION -- LOS
                        RONE            # LOS VECTOR LEFT IN MPAC
                        RATT
                MXV     RTB             # (REFSMAT X LOS).  TRANSFORMS LOS FROM
                        REFSMMAT        # REFERENCE COORD TO STAB MEMB COORD.
```

```
                        NORMUNIT
                STORE   POINTVSM        # STORE LOS FOR VECPOINT CALCULATION
                EXIT
                CS      OPTIONX +1      # 1 FOR Z AXIS.  2 FOR X AXIS.
                AD      ONE
                EXTEND
                BZF     ALINEZ
ALINEX          TC      INTPRET         # X AXIS ALIGNMENT
                VLOAD
                        UNITX           # READ (.5, 0, 0)
# Page 340
V89CALL1        STCALL  SCAXIS          # STORE SELECTED ALIGNMENT AXIS
                        VECPOINT        # PUTS DESIRED GIM ANG (OG,IG,MG) IN TMPAC
                STORE   CPHI            # STOR GIMBAL ANGLES FOR BALLANGS CALL
                EXIT
                TC      BANKCALL
                CADR    BALLANGS        # PUTS DESIRED BALL ANGLE IN FDAIX,Y,Z
                CAF     VB06N18         # V 06 N 18
                TC      BANKCALL        # NOUN 18 REFERS TO FDAIX,Y,Z
                CADR    GOFLASH
                TC      ENDEXT          # TERMINATE
                TC      +2              # PROCEED
                TC      V89RECL         # RECYCLE
                TC      DOWNFLAG        # RESET 3 AXIS FLAG
                ADRES   3AXISFLG        # RESET BIT6 FLAG WORD 5
                TC      BANKCALL        # PERFORMS LEM MANEUVER TO ALIGN SELECTED
                CADR    R60LEM          # SPACECRAFT AXIS TO CSM.
                TCF     ENDEXT          # TERMINATE R63

ALINEZ          TC      INTPRET         # Z AXIS ALIGNMENT
                VLOAD   GOTO
                        UNITZ           # READ (0, 0, .5)
                        V89CALL1

VB04N12         VN      412
VB06N18         VN      0618
# Page 341
DP1MIN          2DEC    6000
```

Uses 3AXISFLG 115, COUNT 142, CPHI 157, CPSI 157, CTHETA 157, DISPLAYS 59, EBANK 80, MPAC 145, N 206, OPTION1 157, OPTIONX 154, POINTVSM 219, R2 188, REFSMMAT 172, RONE 179, SAVE 191, SCAXIS 219, STATE 138, TC 169, TSTART82 179, V 229, VN 159, and Z 80.

4.9 attitude maneuver routine

2151 ⟨*attitude maneuver routine* 2151⟩≡ (2041)

⟨*Page LM0342* 2152⟩
⟨*Page LM0343* 2154⟩
⟨*Page LM0344* 2156⟩
⟨*Page LM0345* 2158⟩
⟨*Page LM0346* 2160⟩
⟨*Page LM0347* 2162⟩
⟨*Page LM0348* 2164⟩
⟨*Page LM0349* 2165⟩
⟨*Page LM0350* 2166⟩
⟨*Page LM0351* 2167⟩
⟨*Page LM0352* 2169⟩
⟨*Page LM0353* 2171⟩
⟨*Page LM0354* 2173⟩
⟨*Page LM0355* 2174⟩
⟨*Page LM0356* 2175⟩
⟨*Page LM0357* 2177⟩
⟨*Page LM0358* 2179⟩
⟨*Page LM0359* 2181⟩
⟨*Page LM0360* 2183⟩
⟨*Page LM0361* 2185⟩
⟨*Page LM0362* 2187⟩
⟨*Page LM0363* 2188a⟩

2152 ⟨*Page LM0342* 2152⟩≡ (2151 2651)

```
# BLOCK 2 LGC ATTITUDE MANEUVER ROUTINE -- KALCMANU
#
# MOD 2         DATE 5/1/67     BY DON KEENE
#
# PROGRAM DESCRIPTION
#
# KALCMANU IS A ROUTINE WHICH GENERATES COMMANDS FOR THE LM DAP TO CHANGE THE ATTITUD
# DURING FREE FALL.  IT IS DESIGNED TO MANEUVER THE SPACECRAFT FROM ITS INITIAL ORIEN
# ORIENTATION SPECIFIED BY THE PROGRAM WHICH CALLS KALCMANU, AVOIDING GIMBAL LOCK IN
# MOD 2 VERSION, THIS DESIRED ATTITUDE IS SPECIFIED BY A SET OF OF THREE COMMANDED CD
# SINGLE PRECISION ANGLES IN THE THREE CONSECUTIVE LOCATIONS, CPHI, CTHETA, CPSI, WHE
#
#       CPHI = COMMANDED OUTER GIMBAL ANGLE
#       CTHETA = COMMANDED INNER GIMBAL ANGLE
#       CPSI = COMMANDED MIDDLE GIMBAL ANGLE
#
# WHEN POINTING A SPACECRAFT AXIS (I.E., X, Y, Z, THE AOT, THRUST AXIS, ETC.) THE SUB
# USED TO GENERATE THIS SET OF DESIRED CDU ANGLES (SEE DESCRIPTION IN R60).
#
# WITH THIS INFORMATION KALCMANU DETERMINES THE DIRECTION OF THE SINGLE EQUIVALENT RO
# MAGNITUDE OF THE ROTATION (AM) TO BRING THE S/C FROM ITS INITIAL ORIENTATION TO ITS
# THIS DIRECTION REMAINS FIXED BOTH IN INERTIAL COORDINATES AND IN COMMANDED S/C AXES
#                  _
# MANEUVER.  ONCE COF AND AM HAVE BEEN DETERMINED, KALCMANU THEN EXAMINES THE MANEUVE
#                                    _
# THE S/C THROUGH GIMBAL LOCK.  IF SO, COF AND AM ARE READJUSTED SO THAT THE S/C WILL
# LOCK ZONE AND ALIGN THE X-AXIS.  IN GENERAL A FINAL YAW ABOUT X WILL BE NECESSARY T
# NEEDLESS TO SAY, NEITHER THE INITIAL NOR THE FINAL ORIENTATION CAN BE IN GIMBAL LOC
#
# FOR PROPER ATTITUDE CONTROL THE DIGITAL AUTOPILOT MUST BE GIVEN AN ATTITUDE REFEREN
# KALCMANU DOES THIS BY GENERATING A REFERENCE OF DESIRED GIMBAL ANGLES (CDUXD, CDUYD
# EVERY ONE SECOND DURING THE MANEUVER.  TO ACHIEVE A SMOOTHER SEQUENCE OF COMMANDS F
# THE PROGRAM ALSO GENERATES A SET OF INCREMENTAL CDU ANGLES (DELDCDU) TO BE ADDED TO
# AUTOPILOT.  KALCMANU ALSO CALCULATES THE COMPONENT MANEUVER RATES (OMEGAPD, OMEGAQD
#                                    _
# BE DETERMINED SIMPLY BY MULTIPLYING COF BY SOME SCALAR (ARATE) CORRESPONDING TO THE
#
# AUTOMATIC MANEUVERS ARE TIMED WTH THE HELP OF WAITLIST SO THAT AFTER A SPECIFIED IN
# DESIRED RATES ARE SET TO ZERO AND THE DESIRED CDU ANGLES (CDUYD, CDUZD) ARE SET EQU
# ANGLES (CTHETA, CPSI).  IF ANY YAW REMAINS DUE TO GIMBAL LOCK AVOIDANCE, THE FINAL
# CALCULATED AND THE DESIRED YAW RATE SET TO SOME FIXED VALUE (ROLLRATE = + OR - 2 DE
# IN THIS CASE ONLY AN INCREMENTAL CDUX ANGLE (DELFROLL) IS SUPPLIED TO THE DAP.  AT
# MANEUVER OR IN THE EVENT THAT THERE WAS NO FINAL YAW, CDUXD IS SET EQUAL TO CPHI AN
# RATE SET TO ZERO.  THUS, UPON COMPLETION OF THE MANEUVER THE S/C WILL FINISH UP IN
# DESIRED GIMBAL ANGLES.
```

```
#
# PROGRAM LOGIC FLOW
#
# KALCMANU IS CALLED AS A HIGH PRIORITY JOB WITH ENTRY POINTS AT KALCMAN3 AND VECPOINT.  IT FIR
# UP THE CURRENT CDU ANGLES TO BE USED AS THE BASIS FOR ALL COMPUTATIONS INVOLVING THE INITIAL
```

Uses A 80, AM 219, CDUX 80, CDUXD 213, CDUYD 213, CDUZD 213, COF 219, CPHI 157, CPSI 157, CTHETA 157, I 206, IT 185, PRIORITY 145, THRUST 85, Z 80, and ZONE 163.

2154 ⟨*Page LM0343* 2154⟩≡ (2151 2651)

```
# IT THEN DETERMINES THE DIRECTION COSINE MATRICES RELATING BOTH THE INITIAL AND FINA
#               *   *
# MEMBER AXES (MIS,MFS).  IT ALSO COMPUTES THE MATRIX RELATING FINAL S/C AXES TO INI
# ANGLE OF ROTATION (AM) IS THEN EXTRACTED FROM THIS MATRIX, AND TEST ARE MADE TO DE
#
#       A)      AM LESS THAN .25 DEGREES (MINANG)
#       B)      AM GREATER THAN 170 DEGREES (MAXANG)
#
# IF AM IS LESS THAN .25 DEGREES, NO COMPLICATED AUTOMATIC MANEUVERING IS NECESSARY.
# SET CDU DESIRED EQUAL TO THE FINAL CDU DESIRED ANGLES AND TERMINATE THE JOB.
#
# IF AM IS GREATER THAN .25 DEGREES BUT LESS THAN 170 DEGREES THE AXES OF THE SINGLE
#   _                                                          *
# (COF) IS EXTRACTED FROM THE SKEW SYMMETRIC COMPONENTS OF MFI.
#
# IF AM GREATER THAN 170 DEGREES AN ALTERNATE METHOD EMPLOYING THE SYMMETRIC PART OF
#               _
# TO DETERMINE COF.
#
# THE PROGRAM THEN CHECKS TO SEE IF THE MANEUVER AS COMPUTED WILL BRING THE S/C THROU
# SO, A NEW MANEUVER IS CALCULATED WHICH WILL JUST SKIM THE GIMBAL LOCK ZONE AND ALI
# METHOD ASSURES THAT THE ADDITIONAL MANEUVERING TO AVOID GIMBAL LOCK WILL BE KEPT T
# P AXIS YAW WILL BE NECESSARY, A SWITCH IS RESET (STATE SWITCH 31) TO ALLOW FOR THE
# YAW.
#
# AS STATED PREVIOUSLY, KALCMANU GENERATES A SEQUENCE OF DESIRED GIMBAL ANGLES WHICH
#
# SECOND.  THIS IS ACCOMPLISHED BY A SMALL ROTATION OF THE DESIRED S/C FRAME ABOUT T
# DESIRED REFERENCE MATRIX IS THEN,
#        *               *       *
#       MIS     =       MIS     DEL
#          N+1             N
#        *
# WHERE DEL IS THE MATRIX CORRESPONDING TO THIS SMALL ROTATION.  THE NEW CDU ANGLES
#       *
# FROM MIS.
#
# AT THE BEGINNING OF THE MANEUVER THE AUTOPILOT DESIRED RATES (OMEGAPD, OMEGAQD, OM
# MANEUVER TIMINGS ARE ESTABLISHED.  ON THE FIRST PASS AND ON ALL SUBSEQUENT UPDATES
# ANGLES ARE LOADED WITH THE APPROPRIATE VALUES AND THE INCREMENTAL CDU ANGLES ARE C
# (TIME1 AND TIME2) ARE THEN CHECKED TO SEE IF THE MANEUVER WILL TERMINATE BEFORE TH
# NOT, KALCMANU CALLS FOR ANOTHER UPDATE (RUN AS A JOB WITH PRIORITY TBD) IN ONE SEC
# CALLING SEQUENCE ARE AUTOMATICALLY COMPENSATED IN CALLING FOR THE NEXT UPDATE.
#
# IF IT IS FOUND THAT THE MANEUVER IS TO TERMINATE BEFORE THE NEXT UPDATE A ROUTINE
```

```
# LIST TASK) TO STOP THE MANEUVER AT THE APPROPRIATE TIME AS EXPLAINED ABOVE.
```

Uses A 80, AM 219, COF 219, DEL 232, IT 185, MFI 232, MFISYM 219, MFS 232, MIS 219, N 206, P 188, PRIORITY 145, RUN 191, STATE 138, TIME1 80, TIME2 80, and ZONE 163.

2156 ⟨*Page LM0344* 2156⟩≡ (2151 2651)

```
# CALLING SEQUENCE
#
# IN ORDER TO PERFORM A KALCMANU SUPERVISED MANEUVER, THE COMMANDED GIMBAL ANGLES MUS
# STORED IN LOCATIONS CPHI, CTHETA, CPSI.  THE USER'S PROGRAM MUST THEN CLEAR STATE S
# ATTITUDE MANEUVER ROUTINE TO PERFORM ANY FINAL P-AXIS YAW INCURRED BY AVOIDING GIMB
# THEN INITIATED BY ESTABLISHING THE FOLLOWING EXECUTIVE JOB
#                      *
#       CAF     PRIO XX
#                    --
#       INHINT
#       TC      FINDVAC
#       2CADR   KALCMAN3
#       RELINT
#
# THE USER'S PROGRAM MAY EITHER CONTINUE OR WAIT FOR THE TERMINATION OF THE MANEUVER.
# WAIT, HE MAY PUT HIS JOB TO SLEEP WITH THE FOLLOWING INSTRUCTIONS:
#
#       L       TC      BANKCALL
#       L+1     CADR    ATTSTALL
#       L+2     (BAD RETURN)
#       L+3     (GOOD RETURN)
#
# UPON COMPLETION OF THE MANEUVER, THE PROGRAM WILL BE AWAKENED AT L+3 IF THE MANEUVE
# SUCCESSFULLY, OR AT L+2 IF THE MANEUVER WAS ABORTED.  THIS ABORT WOULD OCCUR IF THE
# WAS IN GIMBAL LOCK.
#
# *** NOTA BENE ***  IF IT IS ASSUMED THAT THE DESIRED MANEUVERING RATE (0.5, 2, 5, 1
# KEYBOARD ENTRY PRIOR TO THE EXECUTION OF KALCMANU.
#
# IT IS ALSO ASSUMED THAT THE AUTOPILOT IS IN THE AUTO MODE.  IF THE MODE SWITCH IS O
# MANEUVER, KALCMANU WILL TERMINATE VIA GOODEND WITHIN 1 SECOND SO THAT R60 MAY REQUE
# SUBROUTINES.
#
# KALCMANU USES A NUMBER OF INTERPRETIVE SUBROUTINES WHICH MAY BE OF GENERAL INTEREST
# WERE PROGRAMMED EXCLUSIVELY FOR KALCMANU, THEY ARE NOT, AS YET, GENERALLY AVAILABLE
#
# MXM3
# ----
#
# THIS SUBROUTINE MULTIPLIES TWO 3X3 MATRICES AND LEAVES THE RESULT IN THE FIRST 18 I
# DOWN LIST, I.E.,
#                       [ M     M     M  ]
#                       [  0     1     2 ]
#       *               [               ]             *              *
#       M       =       [ M     M     M  ]      =      M1      X      M2
```

```
#                          [  3     4     5 ]
#                          [                ]
#                          [ M     M     M  ]
#                          [  6     7     8 ]
```

Uses A 80, CPHI 157, CPSI 157, CTHETA 157, I 206, IT 185, L 80, MODE 145, P 188, STATE 138, and TC 169.

2158 ⟨*Page LM0345* 2158⟩≡ (2151 2651)

```
#                                                                                    *
# INDEX REGISTER X1 MUST BE LOADED WITH THE COMPLEMENT OF THE STARTING ADDRESS FOR M1
#                                                        *
# LOADED WITH THE COMPLEMENT OF THE STARTING ADDRESS FOR M2.  THE ROUTINE USES THE FI
# DOWN LIST.  THE FIRST ELEMENT OF THE MATRIX APPEARS IN PDO.  PUSH UP FOR M .
#                                                                          8
# TRANSPOS
# --------
#
# THIS ROUTINE TRANSPOSES A 3X3 MATRIX AND LEAVES THE RESULT IN THE PUSH DOWN LIST, I
#
#       *               * T
#       M       =       M1
#
# INDEX REGISTER X1 MUST CONTAIN THE COMPLEMENT OF THE STARTING ADDRESS FOR M1.  PUSH
#                        *
# SEQUENT COMPONENTS OF M.  THIS SUBROUTINE ALSO USES THE FIRST 20 LOCATIONS OF THE P
#
# CDU TO DCM
# ----------
#
# THIS SUBROUTINE CONVERTS THREE CDU ANGLES IN T(MPAC) TO A DIRECTION COSINE MATRIX (
# THE CORRESPONDING S/C ORIENTATIONS TO THE STABLE MEMBER FRAME.  THE FORMULAS FOR TH
#
#       M       =       COSY COSZ
#        0
#
#       M       =       -COSY SINZ COSX + SINY SINX
#        1
#
#       M       =       COSY SINZ SINX + SINY COSX
#        2
#
#       M       =       SINZ
#        3
#
#       M       =       COSZ COSX
#        4
#
#       M       =       -COSZ SINX
#        5
#
#       M       =       -SINY COSZ
#        6
#
```

```
#       M       =       SINY SINZ COSX + COSY SINX
#        7
```

Uses `A` 80, `I` 206, `MPAC` 145, `X1` 85, and `X2` 85.

2160 ⟨*Page LM0346* 2160⟩≡ (2151 2651)

```
#       M       =       -SINY SINZ SINX + COSY COSX
#        8
#
# WHERE         X       =       OUTER GIMBAL ANGLE
#               Y       =       INNER GIMBAL ANGLE
#               Z       =       MIDDLE GIMBAL ANGLE
#
# THE INTERPRETATION OF THIS MATRIX IS AS FOLLOWS:
#
# IF A , A , A  REPRESENT THE COMPONENTS OF A VECTOR IN S/C AXES THEN THE COMPONENTS
#     X   Y   Z
# STABLE MEMBER AXES (B , B , B ) ARE
#                      X   Y   Z
#
#       [ B  ]                  [ A  ]
#       [  X ]                  [  X ]
#       [    ]                  [    ]
#       [ B  ]            *     [ A  ]
#       [  Y ]     =      M     [  Y ]
#       [    ]                  [    ]
#       [ B  ]                  [ B  ]
#       [  Z ]                  [  Z ]
#
# THE SUBROUTINE WILL STORE THIS MATRIX IN SEQUENTIAL LOCATIONS OF ERASABLE MEMORY AS
#
# PROGRAM.  TO DO THIS THE CALLING PROGRAM MUST FIRST LOAD X2 WITH THE COMPLEMENT OF
#
# INTERNALLY, THE ROUTINE USES THE FIRST 16 LOCATIONS OF THE PUSH DOWN LIST, ALSO STE
# REGISTER X2.
#
# DCM TO CDU
# ----------
#                                                                    *
# THIS ROUTINE EXTRACTS THE CDU ANGLES FROM A DIRECTION COSINE MATRIX (M SCALED BY 2)
#                                                                                   *
# STABLE MEMBER AXES.  X1 MUST CONTAIN THE COMPLEMENT OF THE STARTING ADDRESS FOR M.
# CORRESPONDING GIMBAL ANGLES IN V(MPAC) AS DOUBLE PRECISION 1'S COMPLEMENT ANGLES SC
# FOR THIS CONVERSION ARE
#
#       Z       =       ARCSIN (M  )
#                               3
#
#       Y       =       ARCSIN (-M /COSZ)
#                                 6
#
```

```
# IF M  IS NEGATIVE, Y IS REPLACED BY PI SGN Y - Y.
#     0
```

Uses `A` 80, `MPAC` 145, `S1` 85, `V` 229, `X1` 85, `X2` 85, and `Z` 80.

2162 ⟨*Page LM0347* 2162⟩≡ (2151 2651)

```
#       X       =       ARCSIN (-M /COSZ)
#                                5
#
# IF M  IS NEGATIVE, X IS REPLACED BY PI SGN X - X.
#     4
#
# THIS ROUTINE DOES NOT SET THE PUSH DOWN POINTER, BUT USES THE NEXT 8 LOCATIONS OF T
# RETURNS THE POINTER TO ITS ORIGINAL SETTING.  THIS PROCEDURE ALLOWS THE CALLER TO S
# THE PUSH DOWN LIST.
#
# DELCOMP
# -------
#                                                        *
# THIS ROUTINE COMPUTES THE DIRECTION COSINE MATRIX (DEL) RELATING ON
#                                                                                    _
# IS ROTATED WITH RESPECT TO THE FIRST BY AN ANGLE, A, ABOUT A UNIT VECTOR U.  THE FO
#
#        *              *        _ _T              *
#       DEL     =       I COSA + U U  (1 - COSA) + V  SINA
#                                                   X
#
# WHERE         *               [ 1    0    0 ]
#               I       =       [ 0    1    0 ]
#                               [ 0    0    1 ]
#
#                               [    2                            ]
#                               [  U           U  U          U  U  ]
#                               [   X           X  Y          X  Z ]
#                               [                                  ]
#               _ _T            [                2                 ]
#               U U     =       [ U  U          U            U  U  ]
#                               [  Y  X          Y            Y  Z ]
#                               [                                  ]
#                               [                              2  ]
#                               [ U  U         U  U          U    ]
#                               [  Z  X         Z  Y          Z   ]
#
#
#                               [   0           -U               U  ]
#                               [                Z               Y ]
#               *               [                                  ]
#               V       =       [  U             0             -U  ]
#                X              [   Z                            X ]
#                               [                                  ]
#                               [ -U             U               0  ]
```

```
#                                   [    Y              X                   ]
#
```

Uses `A` 80, `DEL` 232, `I` 206, `V` 229, and `Z` 80.

2164 ⟨*Page LM0348* 2164⟩≡ (2151 2651)

```
#       _
#       U       =       UNIT ROTATION VECTOR RESOLVED INTO S/C AXES.
#       A       =       ROTATION ANGLE
#
#                        *
# THE INTERPRETATION OF DEL IS AS FOLLOWS:
#
# IF A , A , A  REPRESENT THE COMPONENTS OF A VECTOR IN THE ROTATED FRAME, THEN THE C
#     X   Y   Z
# VECTOR IN THE ORIGINAL S/C AXES (B , B , B ) ARE
#                                   X   Y   Z
#
#       [ B  ]                  [ A  ]
#       [  X ]                  [  X ]
#       [    ]                  [    ]
#       [ B  ]            *     [ A  ]
#       [  Y ]     =     DEL    [  Y ]
#       [    ]                  [    ]
#       [ B  ]                  [ B  ]
#       [  Z ]                  [  Z ]
#
# THE ROUTINE WILL STORE THIS MATRIX (SCALED UNITY) IN SEQUENTIAL LOCATIONS OF ERASAB
#
# THE LOCATION CALLED DEL.  IN ORDER TO USE THE ROUTINE, THE CALLING PROGRAM MUST FIR
# DOUBLE PRECISION VECTOR) IN THE SET OF ERASABLE LOCATIONS BEGINNING WITH THE ADDRES
# MUST THEN BE LOADED INTO D(MPAC).
#
# INTERNALLY, THE PROGRAM ALSO USES THE FIRST 10 LOCATIONS OF THE PUSH DOWN LIST.
#
# READCDUK
# --------
#
# THIS BASIC LANGUAGE SUBROUTINE LOADS T(MPAC) WITH THE THREE CDU ANGLES.
#
# SIGNMPAC
# --------
#
# THIS IS A BASIC LANGUAGE SUBROUTINE WHICH LIMITS THE MAGNITUDE OF D(MPAC) TO + OR -
#
# PROGRAM STORAGE ALLOCATION
#
#       1)      FIXED MEMORY            1059 WORDS
#       2)      ERASABLE MEMORY           98
#       3)      STATE SWITCHES             3
```

Uses A 80, COF 219, D 226, DEL 232, MPAC 145, STATE 138, and Z 80.

2165 ⟨*Page LM0349* 2165⟩≡ (2151 2651)

```
#       4)      FLAGS                       1
#
# JOB PRIORITIES
#
#       1)      KALCMANU                TBD
#       2)      ONE SECOND UPDATE       TBD
#
# SUMMARY OF STATE SWITCHES AND FLAGWORDS USED BY KALCMANU.
#
#       STATE           FLAGWRD 2       SETTING         MEANING
#       SWITCH NO.      BIT NO.
#
#         *
#       31              14              0               MANEUVER WENT THROUGH GIMBAL LOCK
#                                       1               MANEUVER DID NOT GO THROUGH GIMBAL LOCK
#         *
#       32              13              0               CONTINUE UPDATE PROCESS
#                                       1               START UPDATE PROCESS
#
#       33              12              0               PERFORM FINAL P AXIS YAW IF REQUIRED
#                                       1               IGNORE ANY FINAL P-AXIS YAW
#
#       34              11              0               SIGNAL END OF KALCMANU
#                                       1               KALCMANU IN PROCESS.    USER MUST SET S
#
#       * INTERNAL TO KALCMANU
#
# SUGGESTIONS FOR PROGRAM INTEGRATION
#
# THE FOLLOWING VARIABLES SHOULD BE ASSIGNED TO UNSWITCH ERASABLE:
#
#       CPHI
#       CTHETA
#       CPSI
#       POINTVSM +5
#       SCAXIS   +5
#       DELDCDU
#       DELDCDU1
#       DELDCDU2
#       RATEINDX
#
# THE FOLLOWING SUBROUTINES MAY BE PUT IN A DIFFERENT BANK
#
#       MXM3
```

Uses A 80, CPHI 157, CPSI 157, CTHETA 157, P 188, POINTVSM 219, RATEINDX 157, SCAXIS 219,

and STATE 138.

2166 ⟨*Page LM0350* 2166⟩≡ (2151 2651)

```
#       TRANSPGS
#       SIGNMPAC
#       READCDUK
#       CDUTODCM
```

2167 ⟨*Page LM0351* 2167⟩≡ (2151 2651)

```
                BANK    15
                SETLOC  KALCMON1
                BANK

                EBANK=  BCDU

# THE THREE DESIRED CDU ANGLES MUST BE STORED AS SINGLE PRECISION TWO'S COMPLEMENT ANGLES IN TH
# LOCATIONS, CPHI, CTHETA, CPSI.

                COUNT*  $$/KALC
KALCMAN3        TC      INTPRET         # PICK UP THE CURRENT CDU ANGLES AND
                RTB                     #       COMPUTE THE MATRIX FROM INITIAL S/C
                        READCDUK        #       AXES TO FINAL S/C AXES.
                STORE   BCDU            # STORE INITIAL S/C ANGLES
                SLOAD   ABS             # CHECK THE MAGNITUDE OF THE DESIRED
                        CPSI            # MIDDLE GIMBAL ANGLE
                DSU     BPL
                        LOCKANGL        # IF GREATER THAN 70 DEG ABORT MANEUVER
                        TOOBADF
                AXC,2   TLOAD
                        MIS
                        BCDU
                CALL                    # COMPUTE THE TRANSFORMATION FROM INITIAL
                        CDUTODCM        # S/C AXES TO STABLE MEMBER AXES
                AXC,2   TLOAD
                        MFS             # PREPARE TO CALCULATE ARRAY MFS
                        CPHI
                CALL
                        CDUTODCM
SECAD           AXC,1   CALL            # MIS AND MFS ARRAYS CALCULATED         $2
                        MIS
                        TRANSPOS
                VLOAD   STADR
                STOVL   TMIS +12D
                STADR
                STOVL   TMIS +6
                STADR
                STORE   TMIS            # TMIS = TRANSPOSE(MIS) SCALED BY 2
                AXC,1   AXC,2
                        TMIS
                        MFS
                CALL
                        MXM3
                VLOAD   STADR
                STOVL   MFI +12D
```

```
                STADR
                STOVL   MFI +6
                STADR
                STORE   MFI             # MFI = TMIS MFS (SCALED BY 4)
                SETPD   CALL            # TRANSPOSE MFI IN PD LIST
```

Uses BCDU 219, COUNT 142, CPHI 157, CPSI 157, CTHETA 157, EBANK 80, KALCMON1 63, MFI 232, MFS 232, MIS 219, TC 169, and TMIS 219.

2169 ⟨*Page LM0352* 2169⟩≡ (2151 2651)

```
                        18D
                        TRNSPSPD
                VLOAD   STADR
                STOVL   TMFI    +12D
                STADR
                STOVL   TMFI    +6
                STADR
                STORE   TMFI            # TMFI = TRANSPOSE (MFI) SCALED BY 4

# CALCULATE COFSKEW AND MFISYM

                DLOAD   DSU
                        TMFI    +2
                        MFI     +2
                PDDL    DSU             # CALCULATE COF SCALED BY 2/SIN(AM)
                        MFI     +4
                        TMFI    +4
                PDDL    DSU
                        TMFI    +10D
                        MFI     +10D
                VDEF
                STORE   COFSKEW         # EQUALS MFISKEW

# CALCULATE AM AND PROCEED ACCORDING TO ITS MAGNITUDE

                DLOAD   DAD
                        MFI
                        MFI     +16D
                DSU     DAD
                        DP1/4TH
                        MFI     +8D
                STORE   CAM             # CAM = (MFI0+MFI4+MFI8-1)/2 HALF SCALE
                ARCCOS
                STORE   AM              # AM=ARCCOS(CAM)        (AM SCALED BY 2)
                DSU     BPL
                        MINANG
                        CHECKMAX
                TLOAD                   # MANEUVER LESS THAN .25 DEGREES
                        CPHI            # GO DIRECTLY INTO ATTITUDE HOLD
                STCALL  CDUXD           # ABOUT COMMANDED ANGLES
                        TOOBADI         # STOP RATE AND EXIT

CHECKMAX        DLOAD   DSU
                        AM
                        MAXANG
```

```
BPL     VLOAD
        ALTCALC         # UNIT
        COFSKEW         # COFSKEW
UNIT
STORE   COF             # COF IS THE MANEUVER AXIS
```

Uses AM 219, CAM 219, CDUXD 213, COF 219, COFSKEW 219, CPHI 157, MFI 232, MFISYM 219, and TMFI 219.

2171 ⟨*Page LM0353* 2171⟩≡ (2151 2651)

```
                GOTO                    # SEE IF MANEUVER GOES THRU GIMBAL LOCK
                        LOCSKIRT
 ALTCALC        VLOAD   VAD             # IF AM GREATER THAN 170 DEGREES
                        MFI
                        TMFI
                VSR1
                STOVL   MFISYM
                        MFI     +6
                VAD     VSR1
                        TMFI    +6
                STOVL   MFISYM  +6
                        MFI     +12D
                VAD     VSR1
                        TMFI    +12D
                STORE   MFISYM  +12D    # MFISYM=(MFI+TMFI)/2   SCALED BY 4

 # CALCULATE COF

                DLOAD   SR1
                        CAM
                PDDL    DSU             # PDO CAM                              $4
                        DPHALF
                        CAM
                BOVB    PDDL            # PS2 1 - CAM                          $2
                        SIGNMPAC
                        MFISYM  +16D
                DSU     DDV
                        0
                        2
                SQRT    PDDL            # COFZ = SQRT(MFISYM8-CAM)/(1-CAM)
                        MFISYM  +8D     #                              $ ROOT 2
                DSU     DDV
                        0
                        2
                SQRT    PDDL            # COFY = SQRT(MFISYM4-CAM)/(1-CAM)  $ROOT2
                        MFISYM
                DSU     DDV
                        0
                        2
                SQRT    VDEF            # COFX = SQRT(MFISYM-CAM)/(1-CAM)  $ROOT 2
                UNIT
                STORE   COF

 # DETERMINE LARGEST COF AND ADJUST ACCORDINGLY
```

```
COFMAXGO        DLOAD   DSU
                        COF
                        COF     +2
                BMN     DLOAD           # COFY G COFX
```

Uses AM 219, CAM 219, COF 219, MFI 232, MFISYM 219, and TMFI 219.

2173 ⟨*Page LM0354* 2173⟩≡ (2151 2651)

```
                        COMP12
                        COF
                DSU     BMN
                        COF     +4
                        METHOD3         # COFZ G COFX OR COFY
                GOTO
                        METHOD1         # COFX G COFY OR COFZ
COMP12          DLOAD   DSU
                        COF     +2
                        COF     +4
                BMN
                        METHOD3         # COFZ G COFY OR COFX

METHOD2         DLOAD   BPL             # COFY MAX
                        COFSKEW +2      # UY
                        U2POS
                VLOAD   VCOMP
                        COF
                STORE   COF
U2POS           DLOAD   BPL
                        MFISYM  +2      # UX UY
                        OKU21
                DLOAD   DCOMP           # SIGN OF UX OPPOSITE garbled
                        COF
                STORE   COF
OKU21           DLOAD   BPL
                        MFISYM +10D     # UY UZ
                        LOCSKIRT
                DLOAD   DCOMP           # SIGN OF UZ OPPOSITE TO UY
                        COF     +4
                STORE   COF     +4
                GOTO
                        LOCSKIRT
METHOD1         DLOAD   BPL             # COFX MAX
                        COFSKEW         # UX
                        U1POS
                VLOAD   VCOMP
                        COF
                STORE   COF
U1POS           DLOAD   BPL
                        MFISYM  +2      # UX UY
                        OKU12
                DLOAD   DCOMP
                        COF     +2      # SIGN OF UY OPPOSITE TO UX
                STORE   COF     +2
```

```
OKU12           DLOAD   BPL
                        MFISYM  +4      # UX UZ
                        LOCSKIRT
                DLOAD   DCOMP           # SIGN OF UZ OPPOSITE TO UY
                        COF     +4
```

Uses COF 219, COFSKEW 219, and MFISYM 219.

2174 ⟨*Page LM0355* 2174⟩≡ (2151 2651)

```
                STORE   COF     +4
                GOTO
                        LOCSKIRT
METHOD3         DLOAD   BPL             # COFZ MAX
                        COFSKEW +4      # UZ
                        U3POS
                VLOAD   VCOMP
                        COF
                STORE   COF
U3POS           DLOAD   BPL
                        MFISYM  +4      # UX UZ
                        OKU31
                DLOAD   DCOMP
                        COF             # SIGN OF UX OPPOSITE TO UZ
                STORE   COF
OKU31           DLOAD   BPL
                        MFISYM  +10D    # UY UZ
                        LOCSKIRT
                DLOAD   DCOMP
                        COF     +2      # SIGN OF UY OPPOSITE TO UZ
                STORE   COF     +2
                GOTO
                        LOCSKIRT
```

Uses COF 219, COFSKEW 219, and MFISYM 219.

2175 ⟨*Page LM0356* 2175⟩≡ (2151 2651)

```
# MATRIX OPERATIONS

                BANK    13
                SETLOC  KALCMON2
                BANK

                EBANK=  BCDU

MXM3            SETPD   VLOAD*          # MXM3 MULTIPLIES 2 3X3 MATRICES
                        0               # AND LEAVES RESULT IN PD LIST
                        0,1             # AND MPAC
                VXM*    PDVL*
                        0,2
                        6,1
                VXM*    PDVL*
                        0,2
                        12D,1
                VXM*    PUSH
                        0,2
                RVQ

# RETURN WITH MIXM2 IN PD LIST

TRANSPOS        SETPD   VLOAD*          # TRANSPOS TRANSPOSES A 3X3 MATRIX
                        0               #       AND LEAVES RESULT IN PD LIST
                        0,1             # MATRIX ADDRESS IN XR1
                PDVL*   PDVL*
                        6,1
                        12D,1
                PUSH                    # MATRIX IN PD
TRNSPSPD        EXIT                    # ENTER WITH MATRIX AT 0 IN PD LIST
                INDEX   FIXLOC
                DXCH    12
                INDEX   FIXLOC
                DXCH    16
                INDEX   FIXLOC
                DXCH    12
                INDEX   FIXLOC
                DXCH    14
                INDEX   FIXLOC
                DXCH    4
                INDEX   FIXLOC
                DXCH    14
                INDEX   FIXLOC
                DXCH    2
```

```
INDEX   FIXLOC
DXCH    6
INDEX   FIXLOC
DXCH    2
```

Uses `A` 80, `BCDU` 219, `EBANK` 80, `FIXLOC` 140, `KALCMON2` 63, and `MPAC` 145.

2177 ⟨*Page LM0357* 2177⟩≡ (2151 2651)

```
                TC      INTPRET
                RVQ

                BANK    15
                SETLOC  KALCMON1
                BANK

                EBANK=  BCDU

MINANG          2DEC    0.00069375

MAXANG          2DEC    0.472222222

# GIMBAL LOCK CONSTANTS

# D = MGA CORRESPONDING TO GIMBAL LOCK = 60 DEGREES
#       NGL = BUFFER ANGLE (TO AVOID DIVISIONS BY ZERO) = 2 DEGREES

SD              2DEC    .433015         # = SIN(D)                      $2

K3S1            2DEC    .86603          # = SIN(D)                      $1

K4              2DEC    -.25            # = -COS(D)                     $2

K4SQ            2DEC    .125            # = COS(D)COS(D)                $2

SNGLCD          2DEC    .008725         # = SIN(NGL)COS(D)              $2

CNGL            2DEC    .499695         # COS(NGL)                      $2

LOCKANGL        DEC     .388889         # = 70 DEGREES

# INTERPRETIVE SUBROUTINE TO READ THE CDU ANGLES

READCDUK        CA      CDUZ            # LOAD T(MPAC) WITH CDU ANGLES
                TS      MPAC    +2
                EXTEND
                DCA     CDUX            # AND CHANGE MODE TO TRIPLE PRECISION
                TCF     TLOAD   +6

CDUTODCM        AXT,1   SSP
                OCT     3
                        S1
                OCT     1               # SET XR1, S1, AND PD FOR LOOP
                STORE   7
```

```
                SETPD
                        0
LOOPSIN         SLOAD*  RTB
                        10D,1
                        CDULOGIC
```

Uses BCDU 219, CDUX 80, CDUZ 80, D 226, EBANK 80, KALCMON1 63, MODE 145, MPAC 145, S1 85, and TC 169.

2179 ⟨*Page LM0358* 2179⟩≡ (2151 2651)

```
STORE   10D             # LOAD PD WITH  0 SIN(PHI)
SIN     PDDL            #               2 COS(PHI)
        10D             #               4 SIN(THETA)
COS     PUSH            #               6 COS(THETA)
TIX,1   DLOAD           #               8 SIN(PSI)
        LOOPSIN         #               10 COS(PSI)
        6
DMP     SL1
        10D
STORE   0,2             # C0 = COS(THETA)COS(PSI)
DLOAD   DMP
        4
        0
PDDL    DMP             # (PD6 SIN(THETA)SIN(PHI))
        6
        8D
DMP     SL1
        2
BDSU    SL1
        12D
STORE   2,2             # C1=-COS(THETA)SIN(PSI)COS(PHI)
DLOAD   DMP
        2
        4
PDDL    DMP             # (PD7 COS(PHI)SIN(THETA)) SCALED 4
        6
        8D
DMP     SL1
        0
DAD     SL1
        14D
STORE   4,2             # C2=COS(THETA)SIN(PSI)SIN(PHI)
DLOAD
        8D
STORE   6,2             # C3=SIN(PSI)
DLOAD
        10D
DMP     SL1
        2
STORE   8D,2            # C4=COS(PSI)COS(PHI)
DLOAD   DMP
        10D
        0
DCOMP   SL1
STORE   10D,2           # C5=-COS(PSI)SIN(PHI)
```

```
DLOAD   DMP
        4
        10D
DCOMP   SL1
STORE   12D,2           # C6=-SIN(THETA)COS(PSI)
```

Uses THETA 148.

2181 ⟨*Page LM0359* 2181⟩≡ (2151 2651)

```
                DLOAD
                DMP     SL1             # (PUSH UP 7)
                        8D
                PDDL    DMP             # (PD7 COS(PHI)SIN(THETA)SIN(PSI)) SCALE 4
                        6
                        0
                DAD     SL1             # (PUSH UP 7)
                STADR                   # C7=COS(PHI)SIN(THETA)SIN(PSI)
                STORE   14D,2           #       +COS(THETA)SIN(PHI)
                DLOAD
                DMP     SL1             # (PUSH UP 6)
                        8D
                PDDL    DMP             # (PD6 SIN(THETA)SIN(PHI)SIN(PSI)) SCALE 4
                        6
                        2
                DSU     SL1             # (PUSH UP 6)
                STADR
                STORE   16D,2           # C8=-SIN(THETA)SIN(PHI)SIN(PSI)
                RVQ                     # +COS(THETA)COS(PHI)

# CALCULATION OF THE MATRIX DEL......
#
#        *         *           __T           *
#       DEL = (IDMATRIX)COS(A)+UU (1-COS(A))+UX SIN(A)          SCALED 1
#             _
#       WHERE U IS A UNIT VECTOR (DP SCALED 2) ALONG THE AXIS OF ROTATION.
#       A IS THE ANGLE OF ROTATION (DP SCALED 2)
#                                                _
#       UPON ENTRY, THE STARTING ADDRESS OF U IS COF, AND A IS IN MPAC

DELCOMP         SETPD   PUSH            # MPAC CONTAINS THE ANGLE A
                        0
                SIN     PDDL            # PD0 = SIN(A)
                COS     PUSH            # PD2 = COS(A)
                SR2     PDDL            # PD2 = COS(A)                          $8
                BDSU    BOVB
                        DPHALF
                        SIGNMPAC
                PDDL                    # PDA = 1-COS(A)

# COMPUTE THE DIAGONAL COMPONENTS OF DEL

                        COF
                DSQ     DMP
                        4
```

```
DAD     SL3
        2
BOVB
        SIGNMPAC
```

Uses `A` 80, `COF` 219, `DEL` 232, `MPAC` 145, `PDA` 148, and `THETA` 148.

2183 ⟨*Page LM0360* 2183⟩≡ (2151 2651)

```
        STODL   KEL             # UX UX(1-COS(A)) +COS(A)          $1
                COF     +2
        DSQ     DMP
                4
        DAD     SL3
                2
        BOVB
                SIGNMPAC
        STODL   KEL     +8D     # UY UY(1-COS(A)) +COS(A)          $1
                COF     +4
        DSQ     DMP
                4
        DAD     SL3
                2
        BOVB
                SIGNMPAC
        STORE   KEL     +16D    # UZ UZ(1-COS(A)) +COS(A)          $1

# COMPUTE THE OFF DIAGONAL TERMS OF DEL

        DLOAD   DMP
                COF
                COF     +2
        DMP     SL1
                4
        PDDL    DMP             # D6     UX UY (1-COS A)          $4
                COF     +4
                0
        PUSH    DAD             # D8    UZ SIN A                  $4
                6
        SL2     BOVB
                SIGNMPAC
        STODL   KEL     +6
        BDSU    SL2
        BOVB
                SIGNMPAC
        STODL   KEL     +2
                COF
        DMP     DMP
                COF     +4
                4
        SL1     PDDL            # D6    UX UZ (1-COS A)           $4
                COF     +2
        DMP     PUSH            # D8    UY SIN(A)
                0
```

```
DAD     SL2
        6
BOVB
        SIGNMPAC
STODL   KEL     +4      # UX UZ (1-COS(A))+UY SIN(A)
```

Uses A 80, COF 219, and DEL 232.

2185 ⟨*Page LM0361* 2185⟩≡ (2151 2651)

```
                BDSU    SL2
                BOVB
                        SIGNMPAC
                STODL   KEL      +12D   # UX UZ (1-COS(A))-UY SIN(A)
                        COF     +2
                DMP     DMP
                        COF     +4
                        4
                SL1     PDDL            # D6    UY UZ (1-COS(A))                $ 4
                        COF
                DMP     PUSH            # D8    UX SIN(A)
                        0
                DAD     SL2
                        6
                BOVB
                        SIGNMPAC
                STODL   KEL     +14D    # UY UZ(1-COS(A)) +UX SIN(A)
                BDSU    SL2
                BOVB
                        SIGNMPAC
                STORE   KEL     +10D    # UY UZ (1-COS(A)) -UX SIN(A)
                RVQ

# DIRECTION COSINE MATRIX TO CDU ANGLE ROUTINE
# X1 CONTAINS THE COMPLEMENT OF THE STARTING ADDRESS FOR MATRIX (SCALED 2).
# LEAVE CDU ANGLES SCALED 2PI IN V(MPAC).
# COS(MGA) WILL BE LEFT IN S1 (SCALED 1).
#
# THE DIRECTION COSINE MATRIX RELATING S/C AXES TO STABLE MEMBER AXES CAN BE WRITTEN AS:
#
#       C  = COS(THETA) COS(PSI
#        0
#
#       C  = -COS(THETA) SIN(PSI) COS(PHI) + SIN(THETA) SIN(PHI)
#        1
#
#       C  = COS(THETA) SIN(PSI) SIN(PHI) + SIN(THETA) COS(PHI)
#        2
#
#       C  = SIN(PSI)
#        3
#
#       C  = COS(PSI) COS(PHI)
#        4
#
```

```
#       C  = -COS(PSI) SIN(PHI)
#        5
#
#       C  = -SIN(THETA) COS(PSI)
#        6
#
#       C  = SIN(THETA) SIN(PSI) COS(PHI) + COS (THETA) SIN(PHI)
#        7
#
#       C  = -SIN(THETA) SIN(PSI) SIN(PHI) + COS(THETA)COS(PHI)
#        8
```

Uses `A` 80, `COF` 219, `MPAC` 145, `S1` 85, `THETA` 148, `V` 229, and `X1` 85.

2187 ⟨*Page LM0362* 2187⟩≡ (2151 2651)

```
#
# WHERE PHI = OGA
#       THETA = IGA
#       PSI = MGA

DCMTOCDU        DLOAD*  ARCSIN
                        6,1
                PUSH    COS             # PD +0         PSI
                SL1     BOVB
                        SIGNMPAC
                STORE   S1
                DLOAD*  DCOMP
                        12D,1
                DDV     ARCSIN
                        S1
                PDDL*   BPL             # PD +2         THETA
                        0,1             # MUST CHECK THE SIGN OF COS(THETA)
                        OKTHETA         # TO DETERMINE THE PROPER QUADRANT.
                DLOAD   DCOMP
                BPL     DAD
                        SUHALFA
                        DPHALF
                GOTO
                        CALCPHI
SUHALFA         DSU
                        DPHALF
CALCPHI         PUSH
OKTHETA         DLOAD*  DCOMP
                        10D,1
                DDV     ARCSIN
                        S1
                PDDL*   BPL             # PUSH DOWN PHI
                        8D,1
                        OKPHI
                DLOAD   DCOMP           # PUSH UP PHI
                BPL     DAD
                        SUHALFAP
                        DPHALF
                GOTO
                        VECOFANG
SUHALFAP        DSU     GOTO
                        DPHALF
                        VECOFANG
OKPHI           DLOAD                   # PUSH UP PHI
VECOFANG        VDEF    RVQ
```

Uses OGA 206, S1 85, and THETA 148.

2188a ⟨*Page LM0363* 2188a⟩≡ (2151 2651)

```
# ROUTINES FOR TERMINATING THE AUTOMATIC MANEUVER AND RETURNING TO USER.

TOOBADF         EXIT
                TC      ALARM
                OCT     00401

                TCF     NOGO            # DO NOT ZERO ATTITUDE ERRORS

                TC      BANKCALL
                CADR    ZATTEROR        # ZERO ATTITUDE ERRORS

NOGO            TC      BANKCALL
                CADR    STOPRATE        # STOP RATES

                CAF     TWO
                INHINT                  # ALL RETURNS ARE NOW MADE VIA GOODEND
                TC      WAITLIST
                EBANK=  BCDU
                2CADR   GOODMANU

                TCF     ENDOFJOB

TOOBADI         EXIT
                TCF     NOGO
```

Uses BCDU 219, EBANK 80, and TC 169.

4.10 imu performance test 2

2188b ⟨*imu performance test 2* 2188b⟩≡ (2041)

⟨*Page LM0373* 2189⟩
⟨*Page LM0374* 2191⟩
⟨*Page LM0375* 2193⟩
⟨*Page LM0376* 2195⟩
⟨*Page LM0377* 2196⟩
⟨*Page LM0378* 2197⟩
⟨*Page LM0379* 2198⟩
⟨*Page LM0380* 2199⟩
⟨*Page LM0381* 2201⟩

2189 ⟨*Page LM0373* 2189⟩≡ (2188b 2711)

```
# NAME --       IMU PERFORMANCE TESTS 2
#
# DATE --       MARCH 20, 1967
#
# BY --         SYSTEM TEST GROUP 864-6900 EXT. 1274
#
# MODNO. --     ZERO
#
# FUNCTIONAL DESCRIPTION
#
# POSITIONING ROUTINES FOR THE IMU PERFORMANCE TESTS AS WELL AS SOME OF
# THE TESTS THEMSELVES.  FOR A DESCRIPTION OF THESE SUBROUTINES AND THE
# OPERATING PROCEDURES (TYPICALLY) SEE STG MEMO 685.  THEORETICAL REF. E-1973

                BANK    33
                SETLOC  IMU2
                BANK
                EBANK=  POSITON
                COUNT*  $$/P07

REDO            TC      NEWMODEX
                MM      07

GEOIMUTT        TC      IMUZERR
IMUBACK         CA      ZERO
                TS      NDXCTR
                TS      TORQNDX
                TS      TORQNDX +1
                TS      OVFLOWCK
NBPOSPL         CA      DEC17
                TS      ZERONDX
                CA      XNBADR
                TC      ZEROING
                CA      HALF
                TS      XNB
GUESS           TC      INTPRET
LATAZCHK        DLOAD   SL2
                        LATITUDE
                STODL   DSPTEM1 +1
                        AZIMUTH
                RTB     EXIT
                        1STO2S
                XCH     MPAC
                TS      DSPTEM1
                CAF     VN0641
```

```
TC      BANKCALL
CADR    GOFLASH
TC      ENDTEST1
TC      +2
TC      -5
```

Uses A 80, AZIMUTH 191, COUNT 142, DSPTEM1 154, EBANK 80, LATITUDE 191, MM 226, MPAC 145, NDXCTR 191, POSITON 191, TC 169, TORQNDX 194, XNB 186, and ZERONDX 196.

2191 ⟨*Page LM0374* 2191⟩≡ (2188b 2711)

```
                TC      INTPRET
                SLOAD   RTB
                        DSPTEM1
                        CDULOGIC
                STORE   AZIMUTH
                SLOAD   SR2
                        DSPTEM1 +1
                STORE   LATITUDE
                COS     DCOMP
                SL1
                STODL   WANGI
                        LATITUDE
                SIN     SL1
                STODL   WANGO
                        AZIMUTH
                PUSH    SIN
                STORE   YNB     +2
                STODL   ZNB     +4
                COS
                STORE   YNB     +4
                DCOMP
POSGMBL         STCALL  ZNB     +2
                        CALCGA
                EXIT
                TC      BANKCALL
                CADR    IMUCOARS
                CAF     BIT14           # IF BIT14 SET, GIMBAL LOCK
                MASK    FLAGWRD3
                EXTEND
                BZF     +2
                INCR    NDXCTR          # +1 IF IN GIMBAL LOCK, OTHERWISE 0
                TC      DOWNFLAG
                ADRES   GLOKFAIL        # RESET GIMBAL LOCK FLAG
                TC      IMUSLLLG
                CCS     NDXCTR          # IF ONE GO AND DO A PIPA TEST ONLY
                TC      PIPACHK         # ALIGN AND MEASURE VERTICAL PIPA RATE
                TC      FINIMUDD
                EXTEND
                DCA     PERFDLAY
                TC      LONGCALL        # DELAY WHILE SUSPENSION STABILIZES
                EBANK=  POSITON
                2CADR   GOESTIMS

                CA      ESTICADR
                TC      JOBSLEEP
```

```
GOESTIMS        CA      ESTICADR
                TC      JOBWAKE
                TC      TASKOVER
ESTICADR        CADR    ESTIMS
TORQUE          CA      ZERO
```

Uses A 80, AZIMUTH 191, DSPTEM1 154, EBANK 80, FLAGWRD3 105, GLOKFAIL 105, LATITUDE 191, NDXCTR 191, PERFDLAY 196, POSITON 191, TC 169, WANGI 194, WANGO 194, YNB 186, and ZNB 186.

2193 ⟨*Page LM0375* 2193⟩≡ (2188b 2711)

```
                TS      DSPTEM2
                CA      DRIFTI
                TS      DSPTEM2 +1
                INDEX   POSITON
                TS      SOUTHDR -1
                TC      SHOW

PIPACHK         INDEX   NDXCTR          # PIPA TEST
                TC      +1
                TC      EARTHR*
                CA      DEC17           # ALLOW PIP COUNTER TO OVERFLOW 17 TIMES
                TS      DATAPL  +4      # IN THE ALLOTTED TIME INTERVAL
                CA      DEC58
                TS      LENGTHOT
                CA      ONE
                TS      RESULTCT
                CA      ZERO
                INDEX   PIPINDEX
                TS      PIPAX
                TS      DATAPL
                TC      CHECKG
                INHINT
                CAF     TWO
                TC      TWIDDLE
                EBANK=  XSM
                ADRES   PIPATASK
                TC      ENDOFJOB

PIPATASK        EXTEND
                DIM     LENGTHOT
                CA      LENGTHOT
                EXTEND
                BZMF    STARTPIP
                CAF     BIT10
                TC      TWIDDLE
                EBANK=  XSM
                ADRES   PIPATASK
STARTPIP        CAF     PRIO20
                TC      FINDVAC
                EBANK=  XSM
                2CADR   PIPJOBB

                TC      TASKOVER

PIPJOBB         INDEX   NDXCTR
```

```
TC      +1
TC      EARTHR*
CA      LENGTHOT
```

Uses DATAPL 194, DRIFTI 194, DSPTEM2 154, EBANK 80, LENGTHOT 191, NDXCTR 191, PIPAX 80, PIPINDEX 191, POSITON 191, RESULTCT 194, SOUTHDR 191, TC 169, and XSM 186.

2195 ⟨*Page LM0376* 2195⟩≡ (2188b 2711)

```
                EXTEND
                BZMF    +2
                TC      ENDOFJOB

                CA      FIVE
                TS      RESULTCT
                TC      CHECKG
                CCS     DATAPL  +1
                TC      +4
                TC      CCSHOLE
                CS      DATAPL  +4
                TS      DATAPL  +4
                EXTEND
                DCS     DATAPL
                DAS     DATAPL  +4

                TC      INTPRET
                DLOAD   DSU
                        DATAPL  +6
                        DATAPL  +2
                BPL     CALL
                        AINGOTN
                        OVERFFIX
AINGOTN         PDDL    DDV
                        DATAPL  +4
                DMPR    RTB
                        DEC585          # DEC585 HAS BEEN REDEFINED FOR LEM
                        SGNAGREE
                STORE   DSPTEM2
                EXIT
                CCS     NDXCTR
                TC      COAALIGN        # TAKE PLATFORM OUT OF GIMBAL LOCK
                TC      SHOW
VERTDRFT        CA      3990DEC         # ABOUT 1 HOUR VERTICAL DRIFT TEST
                TS      LENGTHOT
                INDEX   POSITON
                CS      SOUTHDR -2
                TS      DRIFTT
                CCS     PIPINDEX        # OFFSET PLATFORM TO MISS PIP DEAD-ZONES
                TCF     PON4            # Z-UP IN POS 4
PON2            CS      BIT5            # X-UP
                ADS     ERCOMP  +2
                CA      BIT5
                ADS     ERCOMP  +4
                TCF     PON
```

```
PON4            CS      BIT5
                ADS     ERCOMP  +2
                CA      BIT5
                ADS     ERCOMP
PON             TC      EARTHR*
```

Uses DATAPL 194, DRIFTT 194, DSPTEM2 154, ERCOMP 196, LENGTHOT 191, NDXCTR 191, PIPINDEX 191, POSITON 191, RESULTCT 194, SOUTHDR 191, TC 169, and Z 80.

2196 ⟨*Page LM0377* 2196⟩≡ (2188b 2711)

```
                CA      ZERO            # ALLOW ONLY SOUTH GYRO EARTH RATE COMPENS
                TS      ERVECTOR
                TS      ERVECTOR +1
GUESS1          CAF     POSMAX
                TS      TORQNDX
                TS      TORQNDX +1
                CA      CDUX
                TS      LOSVEC
                TC      ESTIMS
VALMIS          CA      DRIFTO
                TS      DSPTEM2 +1
                CA      ZERO
                TS      DSPTEM2
                TC      SHOW

ENDTEST1        TC      DOWNFLAG
                ADRES   IMUSE
                CS      ZERO
                TC      NEWMODEA
                TC      ENDEXT
```

Uses CDUX 80, DRIFTO 194, DSPTEM2 154, ERVECTOR 191, IMUSE 95, LOSVEC 191, TC 169, and TORQNDX 194.

2197 ⟨*Page LM0378* 2197⟩≡ (2188b 2711)

```
OVERFFIX        DAD     DAD
                        DPPOSMAX
                        ONEDPP
                RVQ

COAALIGN        EXTEND                  # COARSE ALIGN SUBROUTINE
                QXCH    ZERONDX
                CA      ZERO
                TS      THETAD
                TS      THETAD +1
                TS      THETAD +2
                TC      BANKCALL
                CADR    IMUCOARS
ALIGNCOA        TC      BANKCALL
                CADR    IMUSTALL
                TC      SOMERR2
                TC      ZERONDX

IMUSLLLG        EXTEND
                QXCH    ZERONDX
                TC      ALIGNCOA

FINIMUDD        EXTEND
                QXCH    ZERONDX
                TC      BANKCALL
                CADR    IMUFINE
                TC      ALIGNCOA

IMUZERR         EXTEND
                QXCH    ZERONDX
                TC      BANKCALL
                CADR    IMUZERO
                TC      ALIGNCOA

CHECKG          EXTEND                  # PIP PULSE CATCHING ROUTINE
                QXCH    QPLACE
                TC      +6
CHECKG1         RELINT
                CA      NEWJOB
                EXTEND
                BZMF    +6
                TC      CHANG1
                INHINT
                INDEX   PIPINDEX
                CS      PIPAX
```

```
                TS      ZERONDX
                INHINT
```

Uses NEWJOB 138, PIPAX 80, PIPINDEX 191, QPLACE 191, TC 169, THETAD 157, and ZERONDX 196.

2198 ⟨*Page LM0379* 2198⟩≡ (2188b 2711)

```
                INDEX   PIPINDEX
                CA      PIPAX
                AD      ZERONDX
                EXTEND
                BZF     CHECKG1
                INDEX   PIPINDEX
                CA      PIPAX
                INDEX   RESULTCT
                TS      DATAPL
                TC      FINETIME
                INDEX   RESULTCT
                TS      DATAPL +1
                INDEX   RESULTCT
                LXCH    DATAPL +2
                RELINT
  ENDCHKG       TC      QPLACE

  ZEROING       TS      L
                TCF     +2
  ZEROING1      TS      ZERONDX
                CAF     ZERO
                INDEX   L
                TS      0
                INCR    L
                CCS     ZERONDX
                TCF     ZEROING1
                TC      Q
```

Uses DATAPL 194, L 80, PIPAX 80, PIPINDEX 191, Q 80, QPLACE 191, RESULTCT 194, TC 169, and ZERONDX 196.

2199 ⟨*Page LM0380* 2199⟩≡ (2188b 2711)

```
ERTHRVSE        DLOAD   PDDL
                        SCHZEROS        # PD24 = (SIN              -COS     0)(OMEG/MS)
                        LATITUDE
                COS     DCOMP
                PDDL    SIN
                        LATITUDE
                VDEF    VXSC
                        OMEG/MS
                STORE   ERVECTOR
                RTB
                        LOADTIME
                STOVL   TMARK
                        SCHZEROS
                STORE   ERCOMP
                RVQ

EARTHR          ITA     RTB
                        S2
                        LOADTIME
                STORE   TEMPTIME
                DSU     BPL
                        TMARK
                        ERTHR
                CALL
                        OVERFFIX
ERTHR           SL      VXSC
                        9D
                        ERVECTOR
                MXV     VAD
                        XSM
                        ERCOMP
                STODL   ERCOMP
                        TEMPTIME
                STORE   TMARK
                AXT,1   RTB
                ECADR   ERCOMP
                        PULSEIMU
                GOTO
                        S2

EARTHR*         EXTEND
                QXCH    QPLACES
                TC      INTPRET
                CALL
                        EARTHR
```

```
                EXIT
                TC      IMUSLLLG
                TC      QPLACES

SHOW            EXTEND
```

Uses ERCOMP 196, ERVECTOR 191, LATITUDE 191, QPLACES 191, S2 85, TC 169, TEMPTIME 191, TMARK 191, and XSM 186.

2201 ⟨*Page LM0381* 2201⟩≡ (2188b 2711)

```
                QXCH    QPLACE
  SHOW1         CA      POSITON
                TS      DSPTEM2 +2
                CA      VB06N98
                TC      BANKCALL
                CADR    GOFLASH
                TC      ENDTEST1        # V34
                TC      QPLACE          # V33
                TCF     SHOW1

  3990DEC       DEC     3990
  VB06N98       VN      0698
  VN0641        VN      0641
  DEC17         =       ND1
  DEC58         DEC     58
  OGCPL         ECADR   OGC
  1SECX         =       1SEC
  XNBADR        GENADR  XNB
  XSMADR        GENADR  XSM
                BLOCK   2
                COUNT*  $$/P07
  FINETIME      INHINT                  # RETURNS WITH INTERRUPT INHIBITED
                EXTEND
                READ    LOSCALAR
                TS      L
                EXTEND
                RXOR    LOSCALAR
                EXTEND
                BZF     +4
                EXTEND
                READ    LOSCALAR
                TS      L
          +4    CS      POSMAX
                AD      L
                EXTEND
                BZF     FINETIME +1
                EXTEND
                READ    HISCALAR
                TC Q
```

Uses COUNT 142, DSPTEM2 154, HISCALAR 87, L 80, LOSCALAR 87, OGC 186, POSITON 191, Q 80, QPLACE 191, TC 169, VN 159, XNB 186, and XSM 186.

4.11 imu performance tests 4

2202a ⟨*imu performance tests 4* 2202a⟩≡ (2041)

⟨*Page LM0382* 2202b⟩
⟨*Page LM0383* 2203⟩
⟨*Page LM0384* 2204⟩
⟨*Page LM0385* 2205⟩
⟨*Page LM0386* 2207⟩
⟨*Page LM0387* 2209⟩
⟨*Page LM0388* 2211⟩
⟨*Page LM0389* 2212⟩

2202b ⟨*Page LM0382* 2202b⟩≡ (2202a 2713)

```
# PROGRAM --    IMU PERFORMANCE TESTS 4
# DATE --       NOV 15, 1966
# BY --         GEORGE SCHMIDT IL7-146 EXT 1126
# MOD NO-ZERO
#
# FUNCTIONAL DESCRIPTION
#
# THIS SECTION CONSISTS OF THE FILTER FOR THE GYRO DRIFT TESTS.  NO COMPASS
# IS DONE IN LEM.  FOR A DESCRIPTION OF THE FILTER SEE E-1973.  THIS
# SECTION IS ENTERED FROM IMU 2.  IT RETURNS THERE AT END OF TEST.
#
# EARTHR,OGC ZERO,ERTHRVSE
#
# NORMAL EXIT
#
# LENGTHOT GOES TO ZERO -- RETURN TO IMU PERF TESTS 2 CONTROL
#
# ALARMS
#
# 1600  OVERFLOW IN DRIFT TEST
# 1601  BAD IMU MODING IN ANY ROUTINE THAT USES IMUSTALL
#       OUTPUT
#
# FLASHING DISPLAY OF RESULTS -- CONTROLLED IN IMU PERF TESTS 2
#
# DEBRIS
#
# ALL CENTRALS -- ALL OF EBANK XSM
```

Uses `A` 80, `EBANK` 80, `IT` 185, `LENGTHOT` 191, `OGC` 186, and `XSM` 186.

2203 ⟨*Page LM0383* 2203⟩≡ (2202a 2713)

```
                BANK    33
                SETLOC  IMU4
                BANK
                COUNT*  $$/P07

                EBANK=  XSM

ESTIMS          INHINT
                CAE     1SECXT
                TC      TWIDDLE
                EBANK=  XSM
                ADRES   ALLOOP
                CAF     ZERO            # ZERO THE PIPAS
                TS      PIPAX
                TS      PIPAY
                TS      PIPAZ
                RELINT
                CA      77DECML
                TS      ZERONDX
                CA      ALXXXZ
                TC      ZEROING
                TC      INTPRET
                SLOAD
                        SCHZEROS
                STOVL   GCOMPSW -1
                        INTVAL  +2
                STOVL   ALX1S
                        SCHZEROS
                STORE   DELVX
                STORE   GCOMP
                SLOAD
                        TORQNDX
                DCOMP   BMN
                        VERTSKIP
                CALL
                        ERTHRVSE
VERTSKIP        EXIT
                TC      SLEEPIE +1
```

Uses 1SECXT 196, ALX1S 194, COUNT 142, DELVX 159, EBANK 80, GCOMP 169, GCOMPSW 169, PIPAX 80, PIPAY 80, PIPAZ 80, TC 169, TORQNDX 194, XSM 186, and ZERONDX 196.

2204 ⟨*Page LM0384* 2204⟩≡ (2202a 2713)

```
ALLOOP          CA      OVFLOWCK
                EXTEND
                BZF     +2
                TC      TASKOVER
                CCS     ALTIM
                CA      A               # SHOULD NEVER HIT THIS LOCATION
                TS      ALTIMS
                CS      A
                TS      ALTIM
                CS      ONE
                AD      GEOCOMPS
                EXTEND
                BZF     +4
                CA      LENGTHOT
                EXTEND
                BZMF    +5
                CAE     1SECXT
                TC      TWIDDLE
                EBANK=  XSM
                ADRES   ALLOOP
                CAF     ZERO
                XCH     PIPAX
                TS      DELVX
                CAF     ZERO
                XCH     PIPAY
                TS      DELVY
                CAF     ZERO
                XCH     PIPAZ
                TS      DELVZ
SPECSTS         CAF     PRIO20
                TC      FINDVAC
                EBANK=  XSM
                2CADR   ALFLT           # START THE JOB

                TC      TASKOVER
```

Uses 1SECXT 196, A 80, ALTIM 194, ALTIMS 194, DELVX 159, DELVY 159, DELVZ 159, EBANK 80, GEOCOMPS 196, LENGTHOT 191, PIPAX 80, PIPAY 80, PIPAZ 80, TC 169, and XSM 186.

2205 ⟨*Page LM0385* 2205⟩≡ (2202a 2713)

```
ALFLT           CCS     GEOCOMPS
                TC      +2
                TC      NORMLOP
                TC      BANKCALL
                CADR    1/PIPA
NORMLOP         TC      INTPRET
                DLOAD
                        INTVAL
                STOVL   S1
                        DELVX
                VXM     VSL1
                        XSM
                DLOAD   DCOMP
                        MPAC +3
                STODL   DPIPAY
                        MPAC +5
                STORE   DPIPAZ

                SETPD   AXT,1
                        0
                        8D
                SLOAD   DCOMP
                        GEOCOMPS
                BMN
                        PERFERAS
ALCGKK          SLOAD   BMN
                        ALTIMS
                        ALFLT3
ALKCG           AXT,2   LXA,1           # LOADS SLOPES AND TIME CONSTANTS AT RQST
                        12D
                        ALX1S
ALKCG2          DLOAD*  INCR,1
                        ALFDK   +144D,1
                DEC     -2
                STORE   ALDK    +10D,2
                TIX,2   SXA,1
                        ALKCG2
                        ALX1S

ALFLT3          AXT,1
                        8D
DELMLP          DLOAD*  DMP
                        DPIPAY  +8D,1
                        PIPASC
                SLR     BDSU*
```

```
        9D
        INTY    +8D,1
STORE   INTY    +8D,1
PDDL    DMP*
        VELSC
```

Uses ALDK 194, ALFDK 182, ALTIMS 194, ALX1S 194, DELVX 159, DPIPAY 194, DPIPAZ 194, GEOCOMPS 196, INTY 194, MPAC 145, S1 85, TC 169, and XSM 186.

2207 ⟨*Page LM0386* 2207⟩≡ (2202a 2713)

```
                        VLAUN   +8D,1
                SL2R
                DSU     STADR
                STORE   DELM    +8D,1
                STORE   DELM    +10D,1
                TIX,1   AXT,2
                        DELMLP
                        4
ALILP           DLOAD*  DMPR*
                        ALK     +4,2
                        ALDK    +4,2
                STORE   ALK     +4,2
                TIX,2   AXT,2
                        ALILP
                        8D
ALKLP           LXC,1   SXA,1
                        CMPX1
                        CMPX1
                DLOAD*  DMPR*
                        ALK     +1,1
                        DELM    +8D,2
                DAD*
                        INTY    +8D,2
                STORE   INTY    +8D,2
                DLOAD*  DAD*
                        ALK     +12D,2
                        ALDK    +12D,2
                STORE   ALK     +12D,2
                DMPR*   DAD*
                        DELM    +8D,2
                        INTY    +16D,2
                STORE   INTY    +16D,2
                DLOAD*  DMP*
                        ALSK    +1,1
                        DELM    +8D,2
                SL1R    DAD*
                        VLAUN   +8D,2
                STORE   VLAUN   +8D,2
                TIX,2   AXT,1
                        ALKLP
                        8D

LOOSE           DLOAD*  PDDL*
                        ACCWD   +8D,1
                        VLAUN   +8D,1
```

```
PDDL*   VDEF
        POSNV   +8D,1
MXV     VSL1
        TRANSM1
```

Uses ACCWD 194, ALDK 194, ALK 194, CMPX1 194, DELM 194, INTY 194, POSNV 194, TRANSM1 182, and VLAUN 194.

2209 ⟨*Page LM0387* 2209⟩≡ (2202a 2713)

```
                DLOAD
                        MPAC
                STORE   POSNV    +8D,1
                DLOAD
                        MPAC     +3
                STORE   VLAUN   +8D,1
                DLOAD
                        MPAC    +5
                STORE   ACCWD   +8D,1
                TIX,1
                        LOOSE

                AXT,2   AXT,1           # EVALUATE SINES AND COSINES
                        6
                        2
BOOP            DLOAD*  DMPR
                        ANGX    +2,1
                        GEORGEJ
                SR2R
                PUSH    SIN
                SL3R    XAD,1
                        X1
                STORE   16D,2
                DLOAD
                COS
                STORE   22D,2           # COSINES
                TIX,2
                        BOOP

PERFERAS        EXIT
                CA      EBANK7
                TS      EBANK
                EBANK=  ATIGINC
                TC      ATIGINC         # GOTO ERASABLE TO CALCULATE ONLY TO RETN

#                            CAUTION
#
# THE ERASABLE PROGRAM THAT DOES THE CALCULATIONS MUST BE LOADED
# BEFORE ANY ATTEMPT IS MAKE TO RUN THE IMU PERFORMANCE TEST

                EBANK=  AZIMUTH
                CCS     LENGTHOT
                TC      SLEEPIE
                CCS     TORQNDX
                TCF     +2
```

```
TC      SETUPER1
CA      CDUX
TS      LOSVEC   +1     # FOR TROUBLESHOOTING VD POSNS 2$4
```

Uses ACCWD 194, ANGX 194, ATIGINC 175, AZIMUTH 191, CDUX 80, EBANK 80, LENGTHOT 191, LOSVEC 191, MPAC 145, POSNV 194, RUN 191, TC 169, TORQNDX 194, VLAUN 194, and X1 85.

2211 ⟨*Page LM0388* 2211⟩≡ (2202a 2713)

```
SETUPER1        TC      INTPRET
                DLOAD   PDDL            # ANGLES FROM DRIFT TEST ONLY
                        ANGZ
                        ANGY
                PDDL    VDEF
                        ANGX
                VCOMP   VXSC
                        GEORGEJ
                MXV     VSR1
                        XSM
                STORE   OGC
                EXIT

                CA      OGCPL
                TC      BANKCALL
                CADR    IMUPULSE
                TC      IMUSLLLG
GEOSTRT4        CCS     TORQNDX         # ONLY POSITIVE IF IN VERTICAL DRIFT TEST
                TC      VALMIS
                TC      INTPRET
                CALL
                        ERTHRVSE
                EXIT
                TC      TORQUE

SLEEPIE         TS      LENGTHOT        # TEST NOT OVER-DECREMENT LENGTHOT
                CCS     TORQNDX         # ARE WE DOING VERTDRIFT
                TC      EARTHR*
                TC      ENDOFJOB

SOMEERRR        CA      EBANK5
                TS      EBANK
                CA      ONE
                TS      OVFLOWCK        # STOP ALLOOP FROM CALLING ITSELF
                TC      ALARM
                OCT     1600
                TC      ENDTEST1
SOMERR2         CAF     OCT1601
                TC      VARALARM
                TC      DOWNFLAG
                ADRES   IMUSE
                TC      ENDOFJOB

OCT1601         OCT     01601
DEC585          OCT     06200           # 3200 B+14 ORDER IS IMPORTANT
```

```
SCHZEROS        2DEC    .00000000
```

Uses ANGX 194, ANGY 194, ANGZ 194, EBANK 80, IMUSE 95, LENGTHOT 191, OGC 186, TC 169, TORQNDX 194, and XSM 186.

2212 ⟨*Page LM0389* 2212⟩≡ (2202a 2713)

```
                2DEC    .00000000

                OCT     00000
ONEDPP          OCT     00000           # ORDER IS IMPORTANT
                OCT     00001

INTVAL          OCT     4
                OCT     2
                DEC     144
                DEC     -1
SOUPLY          2DEC    .93505870       # INITIAL GAINS FOR PIP OUTPUTS

                2DEC    .26266423       # INITIAL GAINS/4 FOR ERECTION ANGLES

77DECML         DEC     77
ALXXXZ          GENADR  ALX1S   -1
PIPASC          2DEC    .13055869

VELSC           2DEC    -.52223476      # 512/980.402

ALSK            2DEC    .17329931       # SSWAY VEL GAIN X 980.402/4096

                2DEC    -.00835370      # SSWAY ACCEL GAIN X 980.402/4096

GEORGEJ         2DEC    .63661977

GEORGEK         2DEC    .59737013
```

Uses ALX1S 194 and VEL 226.

4.12 s band antenna for lm

2213 ⟨*s band antenna for lm* 2213⟩≡ (2041 2801)

```
# Page 486
# SUBROUTINE NAME: R05 -- S-BAND ANTENNA FOR LM
#
# MOD0 BY T. JAMES
# MOD1 BY P. SHAKIR
#
# FUNCTIONAL DESCRIPTION
#
# THE S-BAND ANTENNA ROUTINE, R05, COMPUTES AND DISPLAYS THE PITCH AND
# YAW ANTENNA GIMBAL ANGLES REQUIRED TO POINT THE LM STEERABLE ANTENNA
# TOWARD THE CENTER OF THE EARTH.  THIS ROUTINE IS SELECTED BY THE ASTRO-
# NAUT VIA DSKY ENTRY DURING COASTING FLIGHT OR WHEN THE LM IS ON THE MOON
# SURFACE.  THE EARTH OR MOON REFERENCE COORDINATE SYSTEM IS USED DEPENDING
# ON WHETHER THE LM IS ABOUT TO ENTER OR HAS ALREADY ENTERED THE MOON
# SPHERE OF INFLUENCE, RESPECTIVELY.
#
# TO CALL SUBROUTINE, ASTRONAUT KEYS IN V 64 E
#
# SUBROUTINES CALLED ---
#       R02BOTH
#       INTPRET
#       LOADTIME
#       LEMCONIC
#       LUNPOS
#       CDUTRIG
#       *SMNB*
#       BANKCALL
#       B50OFF
#       ENDOFJOB
#       BLANKRET
#
# RETURNS WITH
#       PITCH ANGLE IN PITCHANG         REV. B0
#       YAW ANGLE IN YAWANG             REV. B0
#
# ERASABLES USED
#       PITCHANG
#       YAWANG
#       RLM
#       VAC AREA

                BANK    41
                SETLOC  SBAND
```

```
                BANK

                EBANK=  WHOCARES
                COUNT*  $$/R05
SBANDANT        TC      BANKCALL
# Page 487
                CADR    R02BOTH         # CHECK IF IMU IS ON AND ALIGNED
                TC      INTPRET
                SETPD   RTB
                        0D
                        LOADTIME        # PICK UP CURRENT TIME
                STCALL  TDEC1           # ADVANCE INTEGRATION TO TIME IN TDEC1
                        LEMCONIC        # USING CONIC INTEGRATION
                SLOAD   BHIZ
                        X2              # X2 =0 EARTH SPHERE, X2 =2 MOON SPHERE
                        CONV4
                VLOAD
                        RATT
                STODL   RLM
                        TAT
CONV3           CALL
                        LUNPOS          # UNIT POSITION VECTOR FROM EARTH TO MOON
                VLOAD   VXSC
                        VMOON
                        REMDIST         # MEAN DISTANCE FROM EARTH TO MOON
                VSL1    VAD
                        RLM
                GOTO
                        CONV5
CONV4           VLOAD
                        RATT            # UE = -UNIT(RATT)              EARTH SPHERE
CONV5           SETPD   UNIT            # UE = -UNIT((REM)(UEM) + RL)   MOON SPHERE
                        0D              # SET PL POINTER TO 0
                VCOMP   CALL
                        CDUTRIG         # COMPUTE SINES AND COSINES OF CDU ANGLES
                MXV     VSL1            # TRANSFORM REF. COORDINATE SYSTEM TO
                        REFSMMAT        # STABLE MEMBER B-1 X B-1 X B+1 = B-1
                PUSH    DLOAD           # 8D
                        HI6ZEROS
                STORE   PITCHANG
                STOVL   YAWANG          # ZERO OUT ANGLES
                CALL
                        *SMNB*
                STODL   RLM             # PRE-MULTIPLY RLM BY (NBSA) MATRIX(B0)
                        RLM     +2
                PUSH    DSU
```

```
                        RLM
                DMP
                        1OVSQRT2
                STODL   RLM     +2
                DAD     DMP
                        RLM
                        1OVSQRT2
                STOVL   RLM             # R B-1
                        RLM
                UNIT    PDVL
# Page 488
                        RLM
                VPROJ   VSL2            # PROJECTION OF R ONTO LM XZ PLANE.
                        HIUNITY
                BVSU    BOV             # CLEAR OVERFLOW INDICATOR IF ON
                        RLM
                        COVCNV
COVCNV          UNIT    BOV             # EXIT ON OVERFLOW
                        SBANDEX
                PUSH    VXV             # URP VECTOR B-1
                        HIUNITZ
                VSL1    VCOMP           # UZ X URP = -(URP X UZ)
                STORE   RLM             # X VEC B-1
                DOT     PDVL            # SGN(X.UY) UNSCALED
                        HIUNITY
                        RLM
                ABVAL   SIGN
                ASIN                    # ASIN((SGN(X.UY))ABV(X))       REV B0
                STOVL   PITCHANG
                        URP
                DOT     BPL
                        HIUNITZ
                        NOADJUST        # YES, -90 TO +90
                DLOAD   DSU
                        HIDPHALF
                        PITCHANG
                STORE   PITCHANG
NOADJUST        VLOAD   VXV
                        UR              # Z = (UR X URP)
                        URP
                VSL1
                STODL   RLM             # Z VEC B-1
                        PITCHANG
                SIN     VXSC
                        HIUNITZ
                PDDL    COS
```

```
                        PITCHANG
                VXSC    VSU
                        HIUNITX         # (UX COS ALPHA) - (UZ SIN ALPHA)
                DOT     PDVL            # YAW.Z
                        RLM
                        RLM
                ABVAL   SIGN
                ASIN
                STORE   YAWANG
SBANDEX         EXIT
                CA      EXTVBACT
                MASK    BIT5            # IS BIT5 STILL ON
                EXTEND
                BZF     ENDEXT          # NO
                CAF     PRIO5
# Page 489
                TC      PRIOCHNG
                CAF     V06N51          # DISPLAY ANGLES
                TC      BANKCALL
                CADR    GOMARKFR
                TC      B5OFF           # TERMINATE
                TC      B5OFF           # PROCEED
                TC      ENDOFJOB        # RECYCLE
                CAF     BIT3            # IMMEDIATE RETURN
                TC      BLANKET         # BLANK R3
                CAF     PRIO4
                TC      PRIOCHNG
                TC      SBANDANT +2     # YES, CONTINUE DISPLAYING ANGLES.
V06N51          VN      0651
1OVSQRT2        2DEC    .7071067815     # 1/SQRT(2)

UR              EQUALS  0D
URP             EQUALS  6D
                SBANK=  LOWSUPER

# END OF LNYAIDE .001 ***
```

Uses BLANKRET 140, COUNT 142, DISPLAYS 59, EBANK 80, EXTVBACT 154, HI6ZEROS 71, HIDPHALF 71, HIUNITX 71, HIUNITY 71, HIUNITZ 71, LOWSUPER 67, P 188, REFSMMAT 172, SBAND 71, TC 169, V 229, VMOON 186, VN 159, WHOCARES 244, X2 85, and Z 80.

4.13 radar leadin routines

2217 ⟨*radar leadin routines* 2217⟩≡ (2041 2789)

```
# Page 490
                BANK    25
                SETLOC  RRLEADIN
                BANK

                EBANK=  RSTACK

# RADAR SAMPLING LOOP.

                COUNT*  $$/RLEAD
RADSAMP         CCS     RSAMPDT         # TIMES NORMAL ONCE-PER-SECOND SAMPLING.
                TCF     +2
                TCF     TASKOVER        # +0 INSERTED MANUALLY TERMINATES TEST.

                TC      WAITLIST
                EBANK=  RSTACK
                2CADR   RADSAMP

                CAF     PRIO25
                TC      NOVAC
                EBANK=  RSTACK
                2CADR   DORSAMP

                CAF     BIT14           # FOR CYCLIC SAMPLING, RTSTDEX =
                EXTEND                  # RTSTLOC/2 + RTSTBASE
                MP      RTSTLOC
                AD      RTSTBASE        # 0 FOR RR, 2 FOR LR.
                TS      RTSTDEX
                TCF     TASKOVER

# DO THE ACTUAL RADAR SAMPLE.

DORSAMP         TC      VARADAR         # SELECTS VARIABLE RADAR CHANNEL.
                TC      BANKCALL
                CADR    RADSTALL

                INCR    RFAILCNT        # ADVANCE FAIL COUNTER BUT ACCEPT BAD DATA

DORSAMP2        INHINT
                CA      FLAGWRD5        # DON'T UPDATE RSTACK IF IN R77.
                MASK    R77FLBIT
                CCS     A
                TCF     +4
```

```
                DXCH    SAMPLSUM
                INDEX   RTSTLOC
                DXCH    RSTACK

                CS      RTSTLOC         # CYCLE RTSTLOC.
                AD      RTSTMAX
                EXTEND

# Page 491
                BZF     +3
                CA      RTSTLOC
                AD      TWO             # STORAGE IS DP
                TS      RTSTLOC
                TCF     ENDOFJOB        # CONTINUOUS SAMPLING AND 2N TRIES -- GONE.

# VARIABLE RADAR DATA CALLER FOR ONE MEASUREMENT ONLY.

VARADAR         CAF     ONE             # WILL BE SENT TO RADAR ROUTINE IN A BY
                TS      BUF2            # SWCALL
                INDEX   RTSTDEX
                CAF     RDRLOCS
                TCF     SWCALL          # NOT TOUCHING Q.

RDRLOCS         CADR    RRRANGE         # =0
                CADR    RRRDOT          # =1
                CADR    LRVELX          # =2
                CADR    LRVELY          # =3
                CADR    LRVELZ          # =4
                CADR    LRALT           # =5
```

Uses `A` 80, `BUF2` 142, `COUNT` 142, `EBANK` 80, `FLAGWRD5` 113, `Q` 80, and `TC` 169.

4.14 p30-p37 routines

2218 ⟨*p30-p37 routines* 2218⟩≡ (2041 2756)
⟨*Page LM0624* 2219⟩

2219 ⟨*Page LM0624* 2219⟩≡ (2218)

```
# Page 614
# PROGRAM DESCRIPTION P30       DATE 3-6-67
#
# MOD.1 BY RAMA AIYAWAR
#
# FUNCTIONAL DESCRIPTIONS
#       ACCEPT ASTRONAUT INPUTS OF TIG,DELV(LV)
#       CALL IMU STATUS CHECK ROUTINE (R02)
#       DISPLAY TIME TO GO, APOGEE, PERIGEE, DELV(MAG), MGA AT IGN
#       REQUEST BURN PROGRAM
#
# CALLING SEQUENCE VIA JOB FROM V37
#
# EXIT VIA V37 CALL OR TO GOTOP00H (V34E)
#
# SUBROUTINE CALLS --   FLAGUP, PHASCHNG, BANKCALL, ENDOFJOB, GOFLASH, GOFLASHR
#                       GOPERF3R, INTPRET, BLANKET, GOTOP00H, R02BOTH, S30.1,
#                       TIG/N35, MIDGIM, DISPMGA
#
# ERASABLE INITIALIZATION -- STATE VECTOR
#
# OUTPUT --     RINIT, VINIT, +MGA, VTIG, RTIG, DELVSIN, DELVSAB, DELVSLV, HAPO,
#               HPER, TTOGO
#
# DEBRIS -- A, L, MPAC, PUSHLIST

                BANK    32
                SETLOC  P30S
                BANK
                EBANK=  +MGA
                COUNT*  $$/P30
P30             TC      UPFLAG          # SET UPDATE FLAG
                ADRES   UPDATFLG
                TC      UPFLAG          # SET TRACK FLAG
                ADRES   TRACKFLG

P30N33          CAF     V06N33          # T OF IGN
                TC      VNP00H          # RETURN ON PROCEED, P00H ON TERMINATE

                CAF     V06N81          # DISPLAY DELTA V (LV)
                TC      VNP00H          #       REDISPLAY ON RECYCLE

                TC      DOWNFLAG        # RESET UPDATE FLAG
                ADRES   UPDATFLG
                TC      INTPRET
```

```
                CALL
                        S30.1
                SET     EXIT
                        UPDATFLG
PARAM30         CAF     V06N42          # DISPLAY APOGEE,PERIGEE,DELTA V
                TC      VNP00H
# Page 615

                TC      INTPRET
                SETGO
                        XDELVFLG        # FOR P40'S: EXTERNAL DELTA-V GUIDANCE.
                        REVN1645        # TRKMKCNT, T60, +MGA  DISPLAY

V06N33          VN      0633
V06N42          VN      0642

# Page 616
# PROGRAM DESCRIPTION S30.1     DATE 9NOV66
# MOD NO 1                      LOG SECTION P30,P37
# MOD BY RAMA AIYAWAR **
#
# FUNCTIONAL DESCRIPTION
#       BASED ON STORED TARGET PARAMETERS (R OF IGNITION (RTIG), V OF
#       IGNITION (VTIG), TIME OF IGNITION (TIG)), COMPUTE PERIGEE ALTITUDE
#       APOGEE ALTITUDE AND DELTAV REQUIRED (DELVSIN).
#
# CALLING SEQUENCE
#       L       CALL
#       L+1             s30.1
#
# NORMAL EXIT MODE
#       AT L+2 OR CALLING SEQUENCE (GOTO L+2)
#
# SUBROUTINES CALLED
#       LEMPREC
#       PERIAPO
#
# ALARM OR ABORT EXIT MODES
#       NONE
#
# ERASABLE INITIALIZATION REQUIRED
#       TIG             TIME OF IGNITION        DP B28CS
#       DELVSLV         SPECIFIED DELTA-V IN LOCAL VERT.
#                       COORDS. OF ACTIVE VEHICLE AT
#                       TIME OF IGNITION        VECTOR B+7 METERS/CS
#
```

```
# OUTPUT
#       RTIG            POSITION AT TIG         VECTOR B+29 METERS
#       VTIG            VELOCITY AT TIG         VECTOR B+29 METERS/CS
#       PDL 4D          APOGEE ALTITUDE         DP B+29 M, B+27 METERS.
#       HAPO            APOGEE ALTITUDE         DP B+29 METERS
#       PDL 8D          PERIGEE ALTITUDE        DP B+29 M, B+27 METERS.
#       HPER            PERIGEE ALTITUDE        DP B+29 METERS
#       DELVSIN         SPECIFIED DELTA-V IN INTERTIAL
#                       COORD. OF ACTIVE VEHICLE AT
#                       TIME OF IGNITION        VECTOR B+7 METERS/CS
#       DELVSAB         MAG. OF DELVSIN         VECTOR B+7 METERS/CS
#
# DEBRIS        QTEMP   TEMP.ERASABLE
#               QPRET, MPAC
#               PUSHLIST

                SETLOC  P30S1
                BANK

                COUNT*  $$/S30S

S30.1           STQ     DLOAD
                        QTEMP
                        TIG             # TIME IGNITION SCALED AT 2(+28)CS
                STCALL  TDEC1
                        LEMPREC         # ENCKE ROUTINE FOR LEM

                VLOAD   SXA,2
# Page 617
                        RATT
                        RTX2
                STORE   RTIG            # RADIUS VECTOR AT IGNITION TIME
                UNIT    VCOMP
                STOVL   DELVSIN         # ZRF/LV IN DELVSIN SCALED AT 2
                        VATT            # VELOCITY VECTOR AT TIG, SCALED 2(7) M/CS
                STORE   VTIG
                VXV     UNIT
                        RTIG
                SETPD   SXA,1
                        0
                        RTX1
                PUSH    VXV             # YRF/LV PDL 0 SCALED AT 2
                        DELVSIN
                VSL1    PDVL
                PDVL    PDVL            # YRF/LV PDL 6 SCALED AT 2
                        DELVSIN         # ZRF/LV PDL 12D SCALED AT 2
```

```
        DELVSLV
VXM     VSL1
        0
STORE   DELVSIN         # DELTAV IN INERT. COOR. SCALED TO B+7M/CS
ABVAL
STOVL   DELVSAB         # DELTA V MAG.
        RTIG            # (FOR PERIAPO)
PDVL    VAD             # VREQUIRED = VTIG + DELVSIN (FOR PERIAPO)
        VTIG
        DELVSIN
CALL
        PERIAPO1
CALL
        SHIFTR1         # RESCALE IF NEEDED
CALL                    # LIMIT DISPLAY TO 9999.9 N. MI.
        MAXCHK
STODL   HPER            # PERIGEE ALT 2(29) METERS FOR DISPLAY
        4D
CALL
        SHIFTR1         # RESCALE IF NEEDED
CALL                    # LIMIT DISPLAY TO 9999.9 N. MI.
        MAXCHK
STCALL  HAPO            # APOGEE ALT 2(29) METERS FOR DISPLAY
        QTEMP
```

Uses +MGA 234, A 80, ALT 157, COUNT 142, DELV 159, DELVSAB 236, DELVSIN 236, DELVSLV 224, EBANK 80, HAPO 181, HPER 181, L 80, LV 85, MODE 145, MPAC 145, N 206, P30S 69, P30S1 69, QPRET 85, QTEMP 236, RO2 59, RINIT 234, RTIG 236, STATE 138, TC 169, TEMP 191, TIG 224, TRACKFLG 101, TRKMKCNT 157, TTOGO 236, UPDATFLG 99, V 229, VINIT 234, VN 159, VTIG 236, and XDELVFLG 103.

4.15 p32-p35 p72-p75 routines

2223 ⟨*p32-p35 p72-p75 routines* 2223⟩≡ (2041 2760)

```
# Page 618
# COELLIPTIC SEQUENCE INITIATION (CSI) PROGRAMS (P32 AND P72)
#
# MOD NO -1       LOG SECTION -- P32-P35, P72-P75
# MOD BY WHITE.P  DATE 1JUNE67
#
# PURPOSE

#       (1)     TO CALCULATE PARAMETERS ASSOCIATED WITH THE TIME FOLLOWING
#               CONCENTRIC FLIGHT PLAN MANEUVERS -- THE CO-ELLIPTIC SEQUENCE
#               INITIATION (CSI) MANEUVER AND THE CONSTANT DELTA ALTITUDE
#               (CDH) MANEUVER.

#       (2)     TO CALCULATE THESE PARAMETERS BASED UPON MANEUVER DATA
#               APPROVED AND KEYED INTO THE DSKY BY THE ASTRONAUT.

#       (3)     TO DISPLAY TO THE ASTRONAUT AND THE GROUND DEPENDENT VARIABLES
#               ASSOCIATED WITH THE CONCENTRIC FLIGHT PLAN MANEUVERS FOR
#               APPROVAL BY THE ASTRONAUT/GROUND.

#       (4)     TO STORE THE CSI TARGET PARAMETERS FOR USE BY THE DESIRED
#               THRUSTING PROGRAM.
#
# ASSUMPTIONS

#       (1)     AT A SELECTED TPI TIME THE LINE OF SIGHT BETWEEN THE ACTIVE
#               AND PASSIVE VEHICLES IS SELECTED TO BE A PRESCRIBED ANGLE (E)
#               FROM THE HORIZONTAL PLANE DEFINED BY THE ACTIVE VEHICLE
#               POSITION.

#       (2)     THE TIME BETWEEN CSI IGNITION AND CDH IGNITION MUST BE
#               COMPUTED TO BE GREATER THAN 10 MINUTES FOR SUCCESSFUL
#               COMPLETION OF THE PROGRAM.

#       (3)     THE TIME BETWEEN CDH IGNITION AND TPI IGNITION MUST BE
#               COMPUTED TO BE GREATER THAN 10 MINUTES FOR SUCCESSFUL
#               COMPLETION OF THE PROGRAM.

#       (4)     CDH DELTA V IS SELECTED TO MINIMIZE THE VARIATION OF THE
#               ALTITUDE DIFFERENCE BETWEEN THE ORBITS.

#       (5)     CSI BURN IS DEFINED SUCH THAT THE IMPULSIVE DELTA V IS IN THE
#               HORIZONTAL PLANE DEFINED BY THE ACTIVE VEHICLE POSITION AT CSI
```

```
#               IGNITION.

#       (6)     THE PERICENTER ALTITUDE OF THE ORBIT FOLLOWING CSI AND CDH
#               MUST BE GREATER THAN 35,000 FT (LUNAR ORBIT) OR 85 NM (EARTH
#               ORBIT) FOR SUCCESSFUL COMPLETION OF THIS PROGRAM.

#       (7)     THE CSI AND CDH MANEUVERS ARE ORIGINALLY ASSUMED TO BE
#               PARALLEL TO THE PLANE OF THE CSM ORBIT.  HOWEVER, CREW
# Page 619
#               MODIFICATION OF DELTA V (LV) COMPONENTS MAY RESULT IN AN
#               OUT-OF-PLANE CSI MANEUVER

#       (8)     STATE VECTOR UPDATES BY P27 ARE DISALLOWED DURING AUTOMATIC
#               STATE VECTOR UPDATING INITIATED BY P20 (SEE ASSUMPTION 10).

#       (9)     COMPUTED VARIABLES MAY BE STORED FOR LATER VERIFICATION BY
#               THE GROUND.  THESE STORAGE CAPABILITIES ARE NORMALLY LIMITED
#               ONLY TO THE PARAMETERS FOR ONE THRUSTING MANEUVER AT A TIME
#               EXCEPT FOR CONCENTRIC FLIGHT PLAN MANEUVER SEQUENCES.

#       (10)    THE RENDEZVOUS RADAR MAY OR MAY NOT BE USED TO UPDATE THE LM
#               OR CSM STATE VECTORS FOR THIS PROGRAM.  IF RADAR USE IS
#               DESIRED THE RADAR WAS TURNED ON AND LOCKED BY THE CSM BY
#               PREVIOUS SELECTION OF P20.  RADAR SIGHTING MARKS WILL BE MADE
#               AUTOMATICALLY APPROXIMATELY ONCE A MINUTE WHEN ENABLED BY THE
#               TRACK AND UPDATE FLAGS (SEE P20).  THE RENDEZVOUS TRACKING
#               MARK COUNTER IS ZEROED BY THE SELECTION OF P20 AND AFTER EACH
#               THRUSTING MANEUVER.

#       (11)    THE ISS NEED NOT BE ON TO COMPLETE THIS PROGRAM.

#       (12)    THE OPERATION OF THE PROGRAM UTILIZES THE FOLLOWING FLAGS --
#
#                       ACTIVE VEHICLE FLAG -- DESIGNATES THE VEHICLE WHICH IS
#                       DOING RENDEZVOUS THRUSTING MANEUVERS TO THE PROGRAM WHICH
#                       CALCULATES THE MANEUVER PARAMETERS.  SET AT THE START OF
#                       EACH RENDEZVOUS PRE-THRUSTING PROGRAM.
#
#                       FINAL FLAG -- SELECTS FINAL PROGRAM DISPLAYS AFTER CREW HAS
#                       COMPLETED THE FINAL MANEUVER COMPUTATION AND DISPLAY
#                       CYCLE.
#
#                       EXTERNAL DELTA V STEERING FLAG -- DESIGNATES THE TYPE OF
#                       STEERING REQUIRED FOR EXECUTION OF THIS MANEUVER BY THE
#                       THRUSTING PROGRAM SELECTED AFTER COMPLETION OF THIS
#                       PROGRAM.
```

```
#
#       (13)    IT IS NORMALLY REQUIRED THAT THE ISS BE ON FOR 1 HOUR PRIOR TO
#               A THRUSTING MANEUVER.
#
#       (14)    THIS PROGRAM IS SELECTED BY THE ASTRONAUT BY DSKY ENTRY
#
#                       P32 IF THIS VEHICLE IS ACTIVE VEHICLE.
#
#                       P72 IF THIS VEHICLE IS THE PASSIVE VEHICLE.
#
# INPUT

#       (1)     TCSI            TIME OF THE CSI MANEUVER

# Page 620
#       (2)     NN              NUMBER OF APSIDAL CROSSINGS THRU WHICH THE ACTIVE
#                               VEHICLE ORBIT CAN BE ADVANCED TO OBTAIN THE CDH
#                               MANEUVER POINT.
#       (3)     ELEV            DESIRED LOS ANGLE AT TPI
#       (4)     TTPI            TIME OF THE TPI MANEUVER
#
# OUTPUT

#       (1)     TRKMKCNT        NUMBER OF MARKS
#       (2)     TTOGO           TIME TO GO
#       (3)     +MGA            MIDDLE GIMBAL ANGLE
#       (4)     DIFFALT         DELTA ALTITUDE AT CDH
#       (5)     T1TOT2          DELTA TIME FROM CSI TO CDH
#       (6)     T2TOT3          DELTA TIME FROM CDH TO TPI
#       (7)     DELVLVC         DELTA VELOCITY AT CSI -- LOCAL VERTICAL COORDINATES
#       (8)     DELVLVC         DELTA VELOCITY AT CDH -- LOCAL VERTICAL COORDINATES
#
# DOWNLINK

#       (1)     TCSI            TIME OF THE CSI MANEUVER
#       (2)     TCDH            TIME OF THE CDH MANEUVER
#       (3)     TTPI            TIME OF THE TPI MANEUVER
#       (4)     TIG             TIME OF THE CSI MANEUVER
#       (5)     DELVEET1        DELTA VELOCITY AT CSI -- REFERENCE COORDINATES
#       (6)     DELVEET2        DELTA VELOCITY AT CDH -- REFERENCE COORDINATES
#       (7)     DIFFALT         DELTA ALTITUDE AT CDH
#       (8)     NN              NUMBER OF APSIDAL CROSSINGS THRU WHICH THE ACTIVE
#                               VEHICLE ORBIT CAN BE ADVANCED TO OBTAIN THE CDH
#                               MANEUVER POINT
#       (9)     ELEV            DESIRED LOS ANGLE AT TPI
#
```

```
# COMMUNICATION TO THRUSTING PROGRAM

#       (1)     TIG             TIME OF THE CSI MANEUVER
#       (2)     RTIG            POSITION OF ACTIVE VEHICLE AT CSI -- BEFORE ROTATION
#                               INTO PLANE OF PASSIVE VEHICLE
#       (3)     VTIG            VELOCITY OF ACTIVE VEHICLE AT CSE -- BEFORE ROTATION
#                               INTO PLANE OF PASSIVE VEHICLE
#       (4)     DELVSIN         DELTA VELOCITY AT CSI -- REFERENCE COORDINATES
#       (5)     DELVSAB         MAGNITUDE OF DELTA VELOCITY AT CSI
#       (6)     XDELVFLG        SET TO INDICATE EXTERNAL DELTA V VG COMPUTATION
#
# SUBROUTINES USED

#       AVFLAGA
#       AVFLAGP
#       P20FLGON
#       VARALARM
#       BANKCALL
#       GOFLASH
#       GOTOP00H
# Page 621
#       VNP00H
#       GOFLASHR
#       BLANKET
#       ENDOFJOB
#       SELECTMU
#       ADVANCE
#       INTINT
#       PASSIVE
#       CSI/A
#       S32/33.1
#       DISDVLVC
#       VN1645

                BANK    35
                SETLOC  CSI/CDH
                BANK
                EBANK=  SUBEXIT
                COUNT*  $$/P3272
P32             TC      AVFLAGA
                TC      P32STRT
P72             TC      AVFLAGP
P32STRT         EXTEND
                DCA     P30ZERO
                DXCH    CENTANG
                TC      P32/P72A
```

```
ALMXITA         SXA,2
                        CSIALRM
ALMXIT          LXC,1
                        CSIALRM
                SLOAD*  EXIT
                        ALARM/TB -1,1
                CA      MPAC
                TC      VARALARM
                CAF     V05N09
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H
                TC      -4
P32/P72A        TC      P20FLGON
                CAF     P30ZERO
                TS      NN      +1
                TS      TCSI
                TS      TCSI    +1
VN0611          CAF     V06N11          # TCSI
                TC      VNP00H
                TC      INTPRET
                DLOAD   DCOMP
                        TCSI
                BMN     DLOAD
                        VN0655
# Page 622
                        TETLEM
                STCALL  TDEC1
                        PRECSET
                VLOAD   VSR*
                        RACT3
                        0,2
                STOVL   RVEC
                        VACT3
                VSR*    SET
                        0,2
                        RVSW
                STODL   VVEC
                        DPPOSMAX
                STCALL  RDESIRED
                        TIMERAD
                DAD
                        TDEC2
                STORE   TCSI
                EXIT
                TC      VN0611
```

```
VN0655          EXIT
                CAF     V06N55          # NN, ELEV(RGLOS)
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H
                TC      +2
                TC      -5
                CAF     V06N37          # TTPI
                TC      VNP00H
                TC      INTPRET
                DLOAD
                        TCSI
                STCALL  TIG
                        SELECTMU
P32/P72B        CALL
                        ADVANCE
                SETPD   VLOAD
                        0D
                        VPASS1
                PDVL    PDDL
                        RPASS1
                        TCSI
                PDDL    PDDL
                        TTPI
                        TWOPI
                PUSH    CALL
                        INTINT
                CALL
                        PASSIVE
                CALL
# Page 623
                        CSI/A
P32/P72C        BON     SET
                        FINALFLG
                        P32/P72D
                        UPDATFLG
P32/P72D        DLOAD
                        T1TOT2
P32/P72E        STORE   T1TOT2
                DSU     BPL
                        60MIN
                        P32/P72E
                DLOAD
                        T2TOT3
P32/P72F        STORE   T2TOT3
                DSU     BPL
```

```
                        60MIN
                        P32/P72F
                EXIT
                CAF     V06N75
                TC      VNP00H
                TC      INTPRET
                VLOAD   CALL
                        DELVEET1
                        S32/33.1
                STOVL   DELVEET1
                        RACT2
                STOVL   RACT1
                        DELVEET2
                AXT,1   CALL
                VN      0682
                        DISDVLVC
                DLOAD
                        TTPI
                STCALL  TTPIO
                        VN1645
                GOTO
                        P32/P72B

# Page 624
# CONSTANT DELTA HEIGHT (CDH) PROGRAMS (P33 AND P73)
# MOD NO -1                     LOC SECTION -- P32-P35, P72-P75
# MOD BY WHITE, P.              DATE: 1 JUNE 67
#
# PURPOSE
#
#       (1)     TO CALCULATE PARAMETERS ASSOCIATED WITH THE CONSTANT DELTA
#               ALTITUDE MANEUVER (CDH).
#
#       (2)     TO CALCULATE THESE PARAMETERS BASED UPON MANEUVER DATA
#               APPROVED AND KEYED INTO THE DSKY BY THE ASTRONAUT.
#
#       (3)     TO DISPLAY TO THE ASTRONAUT AND THE GROUND DEPENDENT VARIABLES
#               ASSOCIATED WITH THE CDH MANEUVER FOR APPROVAL BY THE
#               ASTRONAUT/GROUND.
#
#       (4)     TO STORE THE CDH TARGET PARAMETERS FOR USE BY THE DESIRED
#               THRUSTING PROGRAM.
#
# ASSUMPTIONS
#
#       (1)     THIS PROGRAM IS BASED UPON PREVIOUS COMPLETION OF THE
```

```
#               CO-ELLIPTIC SEQUENCE INITIATION (CSI) PROGRAM (P32/P72).
#               THEREFORE --
#
#               (A)     AT A SELECTED TPI TIME (NOW IN STORAGE) THE LINE OF SIGHT
#                       BETWEEN THE ACTIVE AND PASSIVE VEHICLES WAS SELECTED TO BE
#                       A PRESCRIBED ANGLE (E) (NOW IN STORAGE) FROM THE
#                       HORIZONTAL PLANE DEFINED BY THE ACTIVE VEHICLE POSITION.
#
#               (B)     THE TIME BETWEEN CSI IGNITION AND CDH IGNITION WAS
#                       COMPUTED TO BE GREATER THAN 10 MINUTES.
#
#               (C)     THE TIME BETWEEN CDH IGNITION AND TPI IGNITION WAS
#                       COMPUTED TO BE GREATER THAN 10 MINUTES.
#
#               (D)     THE VARIATION OF THE ALTITUDE DIFFERENCE BETWEEN THE
#                       ORBITS WAS MINIMIZED.
#
#               (E)     CSI BURN WAS DEFINED SUCH THAT THE IMPULSIVE DELTA V WAS
#                       IN THE HORIZONTAL PLANE DEFINED BY ACTIVE VEHICLE
#                       POSITION AT CSI IGNITION.
#
#               (F)     THE PERICENTER ALTITUDES OF THE ORBITS FOLLOWING CSI AND
#                       CDH WERE COMPUTED TO BE GREATER THAN 35,000 FT FOR LUNAR
#                       ORBIT OR 85 NM FOR EARTH ORBIT.
#
#               (G)     THE CSI AND CDH MANEUVERS WERE ASSUMED TO BE PARALLEL TO
#                       THE PLANE OF THE PASSIVE VEHICLE ORBIT.  HOWEVER, CREW
# Page 625
#                       MODIFICATION OF DELTA V (LV) COMPONENTS MAY HAVE RESULTED
#                       IN AN OUT-OF-PLANE MANEUVER.
#
#       (2)     STATE VECTOR UPDATES BY P27 ARE DISALLOWED DURING AUTOMATIC
#               STATE VECTOR UPDATING INITIATED BY P20 (SEE ASSUMPTION 4).
#
#       (3)     COMPUTED VARIABLES MAY BE STORED FOR LATER VERIFICATION BY
#               THE GROUND.  THESE STORAGE CAPABILITIES ARE NORMALLY LIMITED
#               ONLY TO THE PARAMETERS FOR ONE THRUSTING MANEUVER AT A TIME
#               EXCEPT FOR CONCENTRIC FLIGHT PLAN MANEUVER SEQUENCES.
#
#       (4)     THE RENDEZVOUS RADAR MAY OR MAY NOT BE USED TO UPDATE THE LM.
#               OR CSM STATE VECTORS FOR THIS PROGRAM.  IF RADAR USE IS
#               DESIRED THE RADAR WAS TURNED ON AND LOCKED ON THE CSM BY
#               PREVIOUS SELECTION OF P20.  RADAR SIGHTING MARKS WILL BE MADE
#               AUTOMATICALLY APPROXIMATELY ONCE A MINUTE WHEN ENABLED BY THE
#               TRACK AND UPDATE FLAGS (SEE P20).  THE RENDEZVOUS TRACKING
#               MARK COUNTER IS ZEROED BY THE SELECTION OF P20 AND AFTER EACH
```

```
#               THRUSTING MANEUVER.
#
#       (5)     THE ISS NEED NOT BE ON TO COMPLETE THIS PROGRAM.
#
#       (6)     THE OPERATION OF THE PROGRAM UTILIZES THE FOLLOWING FLAGS --
#
#                       ACTIVE VEHICLE FLAG -- DESIGNATES THE VEHICLE WHICH IS
#                       DOING RENDEZVOUS THRUSTING MANEUVERS TO THE PROGRAM WHICH
#                       CALCULATES THE MANEUVER PARAMETERS.  SET AT THE START OF
#                       EACH RENDEZVOUS PRE-THRUSTING PROGRAM.
#
#                       FINAL FLAG -- SELECTS FINAL PROGRAM DISPLAYS AFTER CREW HAS
#                       COMPLETED THE FINAL MANEUVER COMPUTATION AND DISPLAY
#                       CYCLE.
#
#                       EXTERNAL DELTA V STEERING FLAG -- DESIGNATES THE TYPE OF
#                       STEERING REQUIRED FOR EXECUTION OF THIS MANEUVER BY THE
#                       THRUSTING PROGRAM SELECTED AFTER COMPLETION OF THIS
#                       PROGRAM.
#
#       (7)     IT IS NORMALLY REQUIRED THAT THE ISS BE ON FOR 1 HOUR PRIOR TO
#               A THRUSTING MANEUVER.
#
#       (8)     THIS PROGRAM IS SELECTED BY THE ASTRONAUT BY DSKY ENTRY.
#
#                       P33 IF THIS VEHICLE IS ACTIVE VEHICLE.
#
#                       P73 IF THIS VEHICLE IS PASSIVE VEHICLE.
#
# INPUT
#
#       (1)     TTPIO   TIME OF THE TPI MANEUVER -- SAVED FROM P32/P72
# Page 626
#       (2)     ELEV    DESIRED LOS ANGLE AT TPI -- SAVED FROM P32/P72
#       (3)     TCDH    TIME OF THE CDH MANEUVER
#
# OUTPUT
#
#       (1)     TRKMKCNT        NUMBER OF MARKS
#       (2)     TTOGO           TIME TO GO
#       (3)     +MGA            MIDDLE GIMBAL ANGLE
#       (4)     DIFFALT         DELTA ALTITUDE AT CDH
#       (5)     T2TOT3          DELTA TIME FROM CDH TO COMPUTED TPI
#       (6)     NOMTPI          DELTA TIME FROM NOMINAL TPI TO COMPUTED TPI
#       (7)     DELVLVC         DELTA VELOCITY AT CDH -- LOCAL VERTICAL COORDINATES
#
```

```
# DOWNLINK
#
#       (1)     TCDH            TIME OF THE CDH MANEUVER
#       (2)     TTPI            TIME OF THE TPI MANEUVER
#       (3)     TIG             TIME OF THE CDH MANEUVER
#       (4)     DELLVEET2       DELTA VELOCITY AT CDH -- REFERENCE COORDINATES
#       (5)     DIFFALT         DELTA ALTITUDE AT CDH
#       (6)     ELEV            DESIRED LOS ANGLE AT TPI
#
# COMMUNICATION TO THRUSTING PROGRAMS
#
#       (1)     TIG             TIME OF THE CDH MANEUVER
#       (2)     RTIG            POSITION OF ACTIVE VEHICLE AT CDH -- BEFORE ROTATION
#                               INTO PLANE OF PASSIVE VEHICLE.
#       (3)     VTIG            VELOCITY OF ACTIVE VEHICLE AT CDH -- BEFORE ROTATION
#                               INTO PLANE OF PASSIVE VEHICLE.
#       (4)     DELVSIN         DELTA VELOCITY AT CDH -- REFERENCE COORDINATES.
#       (5)     DELVSAB         MAGNITUDE OF DELTA VELOCITY AT CDH.
#       (6)     XDELVFLG        SET TO INDICATE EXTERNAL DELTA V VG COMPUTATION.
#
# SUBROUTINES USED
#
#       AVFLAGA
#       AVFLAGP
#       P20FLGON
#       VNP00H
#       SELECTMU
#       ADVANCE
#       CDHMVR
#       INTINT3P
#       ACTIVE
#       PASSIVE
#       S33/S34.1
#       ALARM
#       BANKCALL
#       GOFLASH
#       GOTOP00H
#       S32/33.1
# Page 627
#       VN1645

                COUNT*  $$/P3373
P33             TC      AVFLAGA
                TC      P33/P73A
P73             TC      AVFLAGP
P33/P73A        TC      P20FLGON
```

```
                CAF     V06N13          # TCDH
                TC      VNP00H
                TC      INTPRET
                DLOAD
                        TTPI0
                STODL   TTPI
                        TCDH
                STCALL  TIG
                        SELECTMU
P33/P73B        CALL
                        ADVANCE
                CALL
                        CDHMVR
                SETPD   VLOAD
                        0D
                        VACT3
                PDVL    CALL
                        RACT2
                        INTINT3P
                CALL
                        ACTIVE
                SETPD   VLOAD
                        0D
                        VPASS2
                PDVL    CALL
                        RPASS2
                        INTINT3P
                CALL
                        PASSIVE
                DLOAD   SET
                        P30ZERO
                        ITSWICH
                STCALL  NOMTPI
                        S33/34.1
                BZE     EXIT
                        P33/P73C
                TC      ALARM
                OCT     611
                CAF     V05N09
                TC      BANKCALL
                CADR    GOFLASH
                TC      GOTOP00H
                TC      +2
# Page 628
                TC      P33/P73A
                TC      INTPRET
```

```
                DLOAD
                        P30ZERO
                STORE   NOMTPI
P33/P73C        BON     SET
                        FINALFLG
                        P33/P73D
                        UPDATFLG
P33/P73D        DLOAD   DAD
                        NOMTPI
                        TTPI
                STORE   TTPI
                DSU
                        TCDH
P33/P73E        DSU     BPL
                        60MIN
                        P33/P73E
                DAD
                        60MIN
                STODL   T1TOT2
                        TTPI
                DSU     PUSH
                        TTPIO
P33/P73F        ABS     DSU
                        60MIN
                BPL     DAD
                        P33/P73F
                        60MIN
                SIGN    STADR
                STORE   T2TOT3
                EXIT
                CAF     V06N75
                TC      VNP00H
                TC      INTPRET
                VLOAD   CALL
                        DELVEET2
                        S32/33.1
                STCALL  DELVEET2
                        VN1645
                GOTO
                        P33/P73B

# Page 629
# ***** ADFLAG/P *****
#
# SUBROUTINES USED
#
```

```
#       UPFLAG
#       DOWNFLAG

AVFLAGA         EXTEND                  # AVFLAG = LEM
                QXCH    SUBEXIT
                TC      UPFLAG
                ADRES   AVFLAG
                TC      SUBEXIT
AVFLAGP         EXTEND                  # AVFLAG = CSM
                QXCH    SUBEXIT
                TC      DOWNFLAG
                ADRES   AVFLAG
                TC      SUBEXIT
P20FLGON        EXTEND
                QXCH    SUBEXIT
                TC      UPFLAG
                ADRES   UPDATFLG        # SET UPDATFLG
                TC      UPFLAG
                ADRES   TRACKFLG        # SET TRACKFLG
                TC      SUBEXIT

# Page 630
# ***** DISDVLVC *****
#
# SUBROUTINES USED
#
#       S32/33.X
#       VNPOOH

DISDVLVC        STORE   DELVLVC
                STQ     CALL
                        NORMEX
                        S32/33.X
                VLOAD   MXV
                        DELVLVC
                        OD
                VSL1    SXA,1
                        VERBNOUN
                STORE   DELVLVC
                EXIT
                CA      VERBNOUN
                TC      VNPOOH
                TC      INTPRET
                GOTO
                        NORMEX
```

```
# Page 631
# ***** CONSTANTS *****

V06N11          VN      0611
V06N13          VN      0613
V06N75          VN      0675
SN359+          2DEC    -.000086601

CS359+          2DEC    +.499999992

P30ZERO         2DEC    0

60MIN           2DEC    360000

ALARM/TB        OCT     00600           # NO 1
                OCT     00601           #    2
                OCT     00602           #    3
                OCT     00603           #    4
                OCT     00604           #    5
                OCT     00605           #    6
                OCT     00606           #    7

# Page 632
# ***** CSI/A *****
#
# SUBROUTINES USED
#
#       VECSHIFT
#       TIMETHET
#       PERIAPO
#       SHIFTR1
#       INTINT2C
#       CDHMVR
#       PERIAPO1
#       INTINT
#       ACTIVE

                BANK    34
                SETLOC  CSI/CDH1
                BANK
                EBANK=  SUBEXIT
                COUNT*  $$/CSI
LOOPMX          2DEC    16

INITST          2DEC    .03048 B-7      # INITIAL DELDV = 10 FPS
```

```
DVMAX1          2DEC    3.0480 B-7      # MAXIMUM DV1 = 1000 FPS

DVMAX2          2DEC    3.014472 B-7    #                989 FPS

1DPB2           2DEC    1.0 B-2

1DPB28          2DEC    1

PMINE           2DEC    157420 B-29     # 85 NM -- MUST BE 8 WORDS BEFORE PMINM

EPSILN1         2DEC    .0003048 B-7    # .1 FPS

NICKELDP        2DEC    .021336 B-7     # 7 FPS (CHANGED FROM .05 FPS)

FIFPSDP         2DEC    -.152400 B-7    # 50 FPS

PMINM           2DEC    10668 B-29      # 35000 FT -- MUST BE 8 WORDS AFTER PMINE

DELMAX1         2DEC    .6096000 B-7    # 200 FPS

ONETHTH         2DEC    .0001 B-3

TMIN            2DEC    60000           # 10 MIN

CSI/A           CLEAR   SET             # INITIALIZE INDICATORS
                        S32.1F1         # DVT1 HAS EXCEEDED MAX INDICATOR
                        S32.1F2         # FIRST PASS FOR NEWTON ITERATION INDICATOR
# Page 633
                CLEAR   SET
                        S32.1F3A        # 00=1ST 2 PASSES 2ND CYCLE, 01=FIRST CYCLE
                        S32.1F3B        # 10=2ND CYCLE, 11=50 FPS STAGE 2ND CYCLE
                DLOAD
                        P30ZERO
                STORE   LOOPCT
                STORE   CSIALRM
CSI/B           SETPD   VLOAD
                        0D
                        RACT1
                ABVAL   PUSH            # RA1                        B29 PL02D
                NORM    SR1
                        X2              #                      B29-N2+ B1 PL04D
                PDVL    ABVAL
                        RPASS3
                NORM    BDDV            # RA1/RP3                     B1 PL02D
                        X1
                XSU,2   SR*             #                             B2
```

```
                        X1
                        1,2
                DAD     DMP             # (1+(RA1/RP3))RA1      B29+B2=B31 PL00D
                        1DPB2
                NORM    PDDL            #                                 PL02D
                        X1
                        RTMU
                SR1     DDV             #                      B38-B31= B7 PL00D
                SL*     SQRT            #                               B7
                        0       -7,1
                PDVL    UNIT            #                                 PL02D
                        RACT1
                PDVL    VXV
                        UP1
                UNIT                    # UNIT(URP1 X UVP1 X URA1) = UH1
                DOT     SL1             # VA1 . UH1                     B7
                        VACT1
                BDSU    STADR           #                                 PL00D
                STODL   DELVCSI
                        INITST          # 10 FPS
                STORE   DELDV
CSI/B1          DLOAD   DAD             # IF LOOPCT = 16
                        LOOPCT
                        1DPB28
                STORE   LOOPCT
                DSU     AXT,2
                        LOOPMX
                        6
                BPL
                        SCNDSOL
CSI/B2          SETPD
                        0D
# Page 634
                DLOAD   ABS
                        DELVCSI
                DSU     BMN
                        DVMAX1
                        CSI/B23
                AXT,2   BON
                        7
                        S32.1F1
                        SCNDSOL
                BOFF    BON
                        S32.1F3A
                        CSI/B22         # FLAG 3 NEQ 3
                        S32.1F3B
```

```
                        SCNDSOL
CSI/B22         SET     DLOAD
                        S32.1F1
                        DVMAX2
                SIGN
                        DELVCSI
                STORE   DELVCSI
CSI/B23         VLOAD   PUSH
                        RACT1
                UNIT    PDVL
                        UP1
                VXV     UNIT            # UNIT (URP1 X UVP1 X URA1) = UH1
                VXSC    VSL1
                        DELVCSI
                STORE   DELVEET1
                VAD     BOV
                        VACT1
                        CSI/B23D
CSI/B23D        STCALL  VACT4
                        VECSHIFT
                STOVL   VVEC
                SET
                        RVSW
                STOVL   RVEC
                        SN359+
                STCALL  SNTH            # ALSO CSTH
                        TIMETHET
                SR1     LXA,1
                        RTX1
                STCALL  HAFPA1
                        PERIAPO
                CALL
                        SHIFTR1
                STODL   POSTCSI
                        CENTANG
                BZE     GOTO
                        +2
# Page 635
                        CIRCL
                DLOAD
                        ECC
                DSU     BMN
                        ONETHTH
                        CIRCL
                DLOAD   CALL
                        R1
```

```
                        SHIFTR1
                SETPD   NORM
                        2D
                        X1
                PDVL    DOT             #                                       PL04D
                        RACT1
                        VACT4
                ABS     DDV
                        02D             # (/RDOTV/)/R1             B38-B29= B7
                SL*     DSU
                        0,1
                        NICKELDP
                BMN     DLOAD
                        CIRCL
                        P
                SL2     DSU
                        1DPB2
                STODL   14D
                        RTSR1/MU
                SR1     DDV             # (1/ROOTMU)/R1         B-16-B29 = B-45 PL02D
                PDDL    DMP
                        P
                        R1
                CALL
                        SHIFTR1
                SL4     SL1
                SQRT    DMP             # ((P/MU)**.5)/R1       B14+B-14 = B-31 PL02D
                BOFF    SL3
                        CMOONFLG
                        CSI/B3
CSI/B3          PDVL    DOT
                        RACT1
                        VACT4
                STORE   RDOTV
                ABS
                NORM    DMP             # ((P/MU)**.5)RDOTV/R1                  PL02D
                        X2
                XSU,1   SL*             #                      B-31+B36-B3 = B2
                        X2
                        3,1
                STODL   12D
                        P30ZERO
# Page 636
                STORE   16D
                VLOAD   UNIT
                        12D
```

```
                STOVL   SNTH            # ALSO STORES CSTH AND 0
                        RACT1
                PDVL    SIGN
                        VACT4
                        RDOTV
                VCOMP   CALL
                        VECSHIFT
                STOVL   VVEC
                SET
                        RVSW
                STCALL  RVEC
                        TIMETHET
                PDDL    BPL
                        RDOTV
                        NTP/2
                DLOAD   DSU
                        HAFPA1
                PUSH    GOTO
                        NTP/2
CIRCL           SETPD   DLOAD
                        OOD
                        P30ZERO
                PUSH
NTP/2           DLOAD   DMP
                        NN
                        HAFPA1
                SL      DSU
                        14D
                DAD
                        TCSI
                STORE   TCDH
                BDSU    AXT,2
                        TTPI
                        5D
                BMN     SETPD
                        SCNDSOL
                        OD
                VLOAD   PDVL
                        VACT4
                        RACT1
                CALL
                        INTINT2C
                STOVL   RACT2
                        VATT
                STOVL   VACT2
                        VPASS1
```

```
                SETPD   PDVL
# Page 637
                        0D
                        RPASS1
                CALL
                        INTINT2C
                STOVL   RPASS2
                        VATT
                STCALL  VPASS2
                        CDHMVR
                VLOAD   SETPD
                        RACT2
                        0D
                PDVL    CALL
                        VACT3
                        PERIAPO1
                CALL
                        SHIFTR1
                STOVL   POSTCDH
                        VACT3
                SETPD   PDVL
                        0D
                        RACT2
                PDDL    PDDL
                        TCDH
                        TTPI
                PDDL    PUSH
                        TWOPI
                CALL
                        INTINT
                CALL
                        ACTIVE
                DLOAD
                        ELEV
                SETPD   SINE
                        6D
                PDVL    UNIT
                        RACT3
                STORE   00D             # URA3 AT 00D
                PDVL    VXV             # PL14D, PL08D
                        UP1
                UNIT
                PDDL    COSINE          # UNIT(URA3 X UVA3 X URA3) = UH3        B1 PI
                        ELEV
                VXSC    STADR           # (COSLOS)(UH3)                         B2 PI
                STORE   18D             #       PLUS
```

```
                DLOAD   VXSC            # (SINLOS)(URA3) = U                    B2 PL00D
                VAD     VSL1
                        18D             #                                      B1
                PUSH    DOT             #                                         PL06D
                        RACT3           # (U . RA3) = TEMP1           B1 +B29 = B30
                SL1     PUSH            #                                     B29 PL08D
# Page 638
                DSQ     TLOAD           # TEMP1**2                            B58
                        MPAC
                PDVL    DOT             #                                         PL11D
                        RACT3
                        RACT3
                TLOAD   DCOMP           # RA3 . RA3
                        MPAC
                PDVL    DOT             # RP3 . RP3                           B58 PL14D
                        RPASS3
                        RPASS3          #                                         PL11D
                TAD     TAD             # TEMP1**2 + RA3.RA3 + RP3.RP3 = TEMP2     PL08D
                BPL     DLOAD
                        K10RK2
                        LOOPCT
                DSU     AXT,2
                        1DPB28
                        1D
                BZE
                        ALMXITA
                DLOAD   SR1
                        DELDV
                STORE   DELDV
                BDSU
                        DVPREV
                STCALL  DELVCSI
                        CSI/B1
K10RK2          SQRT    PUSH            # TEMP3 = TEMP2**.5                  B29 PL10D
                DCOMP   DSU
                        06D             # -TEMP1-TEMP3 = K2 AT 10D
                STODL   10D             #                                         PL08D
                DSU     STADR           #                                         PL06D
                STORE   12D             # -TEMP1+TEMP3 = K1 AT 12D
                ABS
                STODL   14D
                        10D
                ABS     DSU
                        14D
                BMN     DLOAD
                        K2.
```

```
                        12D
                STORE   10D             # K = K1
K2.             DLOAD
                        10D
                VXSC    VSL1
                VAD     UNIT            # V = RA3 + KU UNIT                    B1
                        RACT3
                PDVL    UNIT
                        RPASS3          #                                        PI
                PDVL    UNIT
                        VPASS3          #                                        PI
# Page 639
                VXV     PDVL            # UVP3 X URP3                            PI
                        06D
                        06D
                VXV     DOT
                        00D
                STADR                   #                                        PI
                STOVL   12D             # (URP3 X V).(UVP3 X URP3)=TEMP          PI
                DOT     SL1             #                                        PI
                ARCCOS  SIGN
                        12D             #                                     B0
                SR1     PUSH            # GAMMA = SIGN(TEMP)ARCOS(UNITV.URP3)    PI
                BON     DLOAD
                        S32.1F2
                        FRSTPAS
                        00D             # NOT THE FIRST PASS OF A CYCLE
                DSU     PDDL            # GAMMA-GAMPREV                         B1 PI
                        GAMPREV
                        DELVCSI
                DSU     NORM            #                                     B7
                        DVPREV
                        X1
                BDDV    PDDL            # (GAM-GAMPREV)/(DV-DVPREV)          B-6+N1 P
                        02D             #       = SLOPE
                        DELVCSI
                STORE   DVPREV
                BOFF    BOFF
                        S32.1F3A
                        THRDCHK
                        S32.1F3B
                        THRDCHK
                DLOAD   DMP
                        02D
                        GAMPREV
                BPL     DLOAD
```

```
                        FIFTYFPS
                        INITST
                SIGN
                        DELDV
                STORE   DELDV
                SET     CLEAR
                        S32.1F3A
                        S32.1F3B
FRSTPAS         DLOAD
                        OOD
                STODL   GAMPREV
                        DELVCSI
                STORE   DVPREV
                DSU     CLEAR
                        DELDV
                        S32.1F2
# Page 640
                STCALL  DELVCSI
                        CSI/B1
THRDCHK         BON     BON
                        S32.1F3A
                        NEWTN
                        S32.1F3B
                        NEWTN
FIFTYFPS        DLOAD   SIGN
                        FIFPSDP
                        O4D
                SIGN
                        GAMPREV
                STORE   DELDV
                DCOMP   DAD
                        DELVCSI
                STODL   DELVCSI
                        OOD
                SET     SET
                        S32.1F3B
                        S32.1F3A
                STCALL  GAMPREV
                        CSI/B2
NEWTN           DLOAD   NORM
                        O4D
                        X2
                BDDV    XSU,1
                        OOD
                        X2
                SR*
```

```
                        0,1
                STODL   DELDV
                        OOD
                STORE   GAMPREV
                DLOAD   ABS
                        DELDV           #                                       PI
                PUSH    DSU
                        EPSILN1
                BMN     DLOAD
                        CSI/SOL
                DSU     BMN
                        DELMAX1
                        CSISTEP
                DLOAD   SIGN
                        DELMAX1
                        DELDV
                STORE   DELDV
CSISTEP         DLOAD   DSU
                        DELVCSI
                        DELDV
                STCALL  DELVCSI
# Page 641
                        CSI/B1
CSI/SOL         DLOAD   AXT,2
                        POSTCSI
                        2
                LXA,1
                        RTX1
                DSU*    BMN
                        PMINE   -2,1
                        SCNDSOL
                AXT,2   DLOAD
                        3
                        POSTCDH
                DSU*    BMN
                        PMINE   -2,1
                        SCNDSOL
                DLOAD   DSU
                        TCDH
                        TCSI
                STORE   T1TOT2
                AXT,2   DSU
                        4
                        TMIN
                BMN     AXT,2
                        SCNDSOL
```

```
                        5
                DLOAD   DSU
                        TTPI
                        TCDH
                STORE   T2TOT3
                DSU     BPL
                        TMIN
                        P32/P72C
SCNDSOL         BON     BOFF
                        S32.1F3A
                        ALMXIT
                        S32.1F3B
                        ALMXIT
                SXA,2   DLOAD
                        CSIALRM
                        P30ZERO
                CLEAR   SET
                        S32.1F1
                        S32.1F2
                CLEAR   CLEAR
                        S32.1F3A
                        S32.1F3B
                STCALL  LOOPCT
                        CSI/B

# Page 642
# ***** ADVANCE *****
#
# SUBROUTINES USED
#       PRECSET
#       ROTATE

ADVANCE         STQ     DLOAD
                        SUBEXIT
                        TIG
                STCALL  TDEC1
                        PRECSET
                SET     VLOAD
                        XDELVFLG
                        VPASS3
                STORE   VPASS2
                STOVL   VPASS1
                        RPASS3
                STORE   RPASS2
                STORE   RPASS1
                UNIT    VXV
```

```
                        VPASS1
                UNIT
                STOVL   UP1
                        RACT3
                STCALL  RTIG
                        ROTATE
                STORE   RACT2
                STOVL   RACT1
                        VACT3
                STCALL  VTIG
                        ROTATE
                STORE   VACT2
                STCALL  VACT1
                        SUBEXIT

# Page 643
# ***** ROTATE *****

ROTATE          PUSH    PUSH
                DOT     VXSC
                        UP1
                        UP1
                VSL2    BVSU
                UNIT    PDVL
                ABVAL   VXSC
                VSL1    RVQ

# Page 644
# ***** INTINTNA *****

INTINT2C        PDDL    PDDL
                        TCSI
                        TCDH
                PDDL    PUSH
                        TWOPI
                GOTO
                        INTINT
INTINT3P        PDDL    PDDL
                        TCDH
                        TTPI
                PDDL    PUSH
                        P3OZERO
                GOTO
                        INTINT

# Page 645
```

```
# ***** S32/33.1 *****
#
# SUBROUTINES USED
#       S32/33.X

S32/33.1        STQ     AXT,1
                        SUBEXIT
                VN      0681
                CALL
                        DISDVLVC
                CALL
                        S32/33.X
                VLOAD   VXM
                        DELVLVC
                        0D
                VSL1
                STORE   DELVSIN
                PUSH    ABVAL
                STOVL   DELVSAB
                GOTO
                        SUBEXIT

# Page 646
# ***** S32/33.X *****

S32/33.X        SETPD   VLOAD
                        6D
                        UP1
                VCOMP   PDVL
                        RACT1
                UNIT    VCOMP
                PUSH    VXV
                        UP1
                VSL1
                STORE   0D
                RVQ

# Page 647
# ***** CDHMVR *****
#
# SUBROUTINES USED
#       VECSHIFT
#       TIMETHET
#       SHIFTR1

CDHMVR          STQ     VLOAD
```

```
                SUBEXIT
                RACT2
        PUSH    UNIT
        STOVL   UNVEC           # UR SUB A
                RPASS2
        UNIT    DOT
                UNVEC
        PUSH    SL1
        STODL   CSTH
        DSQ     PDDL
                DP1/4TH
        SR2     DSU
        SQRT    SL1
        PDVL    VCOMP
        VXV
                RPASS2
        DOT     PDDL
                UP1
        SIGN    STADR
        STOVL   SNTH
                RPASS2
        PDVL    CALL
                VPASS2
                VECSHIFT
        STOVL   VVEC
        CLEAR
                RVSW
        STCALL  RVEC
                TIMETHET
        LXA,2   VSL*
                RTX2
                0,2
        STORE   18D
        DOT     SL1R
                UNVEC
        PDVL    ABVAL           # 0D = V SUB PV
        SL*     PDVL
                0,2
                RACT2
        ABVAL   PDDL            # 2D = LENGTH OF R SUB A
        DSU
# Page 648
                02D
        STODL   DIFFALT         # DELTA H IN METERS             B+29
                R1A
        NORM    PDDL            # 2 - R V**/MU                          04D
```

```
        X1
        R1
CALL
        SHIFTR1
SR1R    DDV
SL*     PUSH
        0       -5,1
DSU     PDDL            # A SUB A                      B+29    04D
        DIFFALT
SR2     DDV             # A SUB P                      B+31
        04D             #                              B+2
PUSH    SQRT            # A SUB P/A SUB A                      06D
DMPR    DMP
        06D
        00D
SL3R    PDDL            # V SUB AV METERS/CS           B+7     08D
        02D             # R SUB A MAGNITUDE            B+29
NORM    PDDL
        X1
        RTMU
SR1     DDV             # 2MU                          B+38
SL*     PDDL            # 2 MU/R SUBAA                 B+14    10D
        0       -5,1
        04D             # ASUBA                        B+29
NORM    PDDL
        X2
        RTMU
SR1     DDV
SL*     BDSU
        0       -6,2    # 2U/R - U/A            B+14 (METERS/CS)SQ
PDDL    DSQ             #                                     10D
        08D
BDSU    SQRT
PDVL    VXV             # SQRT(MU(2/R SUB A-1/A SUB A)-VSUBA2)  10D
        UP1
        UNVEC
UNIT    VXSC
        10D
PDVL    VXSC
        UNVEC
        08D
VAD     VSL1
STADR
STORE   VACT3
VSU
        VACT2
```

```
# Page 649
                STCALL  DELVEET2        # DELTA VCDH -- REFERENCE COORDINATES
                        SUBEXIT

# Page 650
# ***** COMPTGO *****
#
# SUBROUTINES USED
#       CLOKTASK
#       2PHSCHNG

                BANK    35
                SETLOC  CSI/CDH
                BANK

                EBANK=  RTRN

                COUNT*  $$/P3575

COMPTGO         EXTEND
                QXCH    RTRN
                CAF     ZERO
                TS      DISPDEX
                CAF     BIT2
                INHINT
                TC      WAITLIST
                EBANK=  WHICH
                2CADR   CLOKTASK

                TC      2PHSCHNG
                OCT     40036
                OCT     05024
                OCT     13000
                TC      RTRN
```

Uses +MGA 234, A 80, AVFLAG 105, CMOONFLG 125, COUNT 142, CSI/CDH 69, CSI/CDH1 57, CSIALRM 244, CSTH 188, D 226, DELDV 244, DELVCSI 244, DELVEET1 197, DELVEET2 244, DELVLVC 224, DELVSAB 236, DELVSIN 236, DIFFALT 197, DISPDEX 165, DISPLAYS 59, DV 241, DVPREV 244, EBANK 80, ECC 188, F 238, FINALFLG 105, GAMMA 232, GAMPREV 244, H 177, HAFPA1 244, IT 185, ITSWICH 121, LOC 145, LOOPCT 244, LV 85, MPAC 145, NN 244, NOMTPI 181, NORMEX 165, P 188, POSTCDH 244, POSTCSI 244, R1A 188, RACT1 197, RACT2 197, RACT3 234, RDESIRED 188, RDOTV 244, RPASS1 244, RPASS2 197, RPASS3 234, RTIG 236, RTRN 181, RVEC 188, RVSW 123, S32.1F1 135, S32.1F2 135, S32.1F3A 135, S32.1F3B 135, SLOPE 213, SNTH 188, SQ 156, SR 80, STATE 138, SUBEXIT 181, T1TOT2 197, T2TOT3 244, TC 169, TCDH 197, TCSI 197, TDEC2 183, TEMP 191, TETLEM 172, TIG 224, TRACKFLG 101, TRKMKCNT 157, TTOGO 236, TTPI 236, TTPIO 197, UNITV 226, UNVEC 244, UP1 197, UPDATFLG 99, V 229, VACT1 244, VACT2 197, VACT3 234, VACT4 244, VERBNOUN 181, VG 234, VN 159, VPASS1 244, VPASS2 197, VPASS3 234, VTIG 236, VVEC 188, X1 85, X2 85, and XDELVFLG 103.

4.16 lambert aimpoint guidance

2253 ⟨*lambert aimpoint guidance* 2253⟩≡ (2041)
⟨*Page LM0651* 2254⟩
⟨*Page LM0652* 2256⟩
⟨*Page LM0653* 2258⟩

2254 ⟨*Page LM0651* 2254⟩≡ (2253 2734)

```
# GENERAL LAMBERT AIMPOINT GUIDANCE **
# WRITTEN BY RAMA M AIYAWAR

# PROGRAM P-31 DESCRIPTION **
#
# 1.    TO ACCEPT TARGETING PARAMETERS OBTAINED FROM A SOURCE EXTERNAL
#       TO THE LEM AND COMPUTE THERE FROM THE REQUIRED-VELOCITY AND
#       OTHER INITIAL CONDITIONS REQUIRED BY LM FOR DESIRED MANEUVER.
#       THE TARGETING PARAMETERS ARE TIG (TIME OF IGNITION), TARGET
#       VECTOR (RTARG), AND THE TIME FROM TIG UNTIL THE TARGET IS
#       REACHED (DELLT4), DESIRED TIME OF FLIGHT FROM RINIT TO RTARG.

# ASSUMPTIONS **
#
# 1.    THE TARGET PARAMETERS MAY HAVE BEEN LOADED PRIOR TO THE
#       EXECUTION OF THIS PROGRAM.
# 2.    THIS PROGRAM IS APPLICABLE IN EITHER EARTH OR LUNAR ORBIT.
# 3.    THIS PROGRAM IS DESIGNED FOR ONE-MAN OPERATION, AND SHOULD
#       BE SELECTED BY THE ASTRONAUT BY DSKY ENTRY V37 E31.

# SUBROUTINES USED **
#
# MANUPARM, TTG/N35, R02BOTH, MIDGIM, DISPMGA, FLAGDOWN, BANKCALL,
# GOTOPOOH, ENDOFJOB, PHASCHNG, GOFLASHR, GOFLASH.
#
# MANUPARM      CALCULATES APOGEE, PERIGEE ALTITUDES AND DELTAV DESIRED
#               FOR THE MANEUVER.
#
# TTG/N35       CLOCKTASK - UPDATES CLOCK.
#
# MIDGIM        CALCULATES MIDDLE GIMBAL ANGLE FOR DISPLAY.
#
# R02BOTH       IMU - STATUS CHECK ROUTINE.

# DISPLAYS USED IN P-31LM **
#
# V06N33        DISPLAY SOTRED TIG (IN HRS. MINS. SECS.)
# V06N42        DISPLAY APOGEE, PERIGEE, DELTAV.
# V16N35        DISPLAY TIME FROM TIG.
# V06N45        TIME FROM IGNITION AND MIDDLE GIMBAL ANGLE.

# ERASABLE INITIALIZATION REQUIRED **
#
# TIG           TIME OF IGNITION                DP      (B+28) CS.
```

```
#
# DELLT4        DESIRED TIME OF FLIGHT          DP      (B+28) CS
#               FROM RINIT TO RTARG.
#
# RTARG         RADIUS VECTOR OF TARGET POSITION VECTOR
#               RADIUS VECTOR SCALED TO (B+29)METERS IF EARTH ORBIT
```

Uses A 80, DELLT4 224, DISPLAYS 59, P 188, RINIT 234, RTARG 224, and TIG 224.

2256 ⟨*Page LM0652* 2256⟩≡ (2253 2734)

```
#               RADIUS VECTOR SCALED TO (B+27)METERS IF MOON ORBIT

# OUTPUT **
#
# HAPO          APOGEE ALTITUDE
# HPER          PERIGEE ALTITUDE
# VGDISP        MAG. OF DELTAV FOR DISPLAY, SCALING     B+7 M/CS EARTH
#               MAG. OF DELTAV FOR DISPLAY, SCALING     B+5 M/CS MOON
# MIDGIM        MIDDLE GIMBAL ANGLE
# XDELVFLG      RESETS XDELVFLG FOR LAMBERT VG COMPUTATIONS

# ALARMS OR ABORTS      NONE **

# RESTARTS ARE VIA GROUP 4 **

                SETLOC  GLM
                BANK

                EBANK=  SUBEXIT

                COUNT*  $$/P31
P31             TC      P20FLGON
                CAF     V06N33          # T16
                TC      VNP00H
                TC      INTPRET
                CLEAR   DLOAD
                        UPDATFLG
                        TIG
                STCALL  TDEC1           # INTEGRATE STATE VECTORS TO TIG
                        LEMPREC
                VLOAD   SETPD
                        RATT
                        OD
                STORE   RTIG
                STOVL   RINIT
                        VATT
                STORE   VTIG
                STODL   VINIT
                        P30ZERO
                PUSH    PDDL            # E4 AND NUMIT = 0
                        DELLT4
                DAD     SXA,1
                        TIG
                        RTX1
                STORE   TPASS4
```

```
SXA,2   CALL
        RTX2
        INITVEL
VLOAD   PUSH
```

Uses COUNT 142, DELLT4 224, EBANK 80, HAPO 181, HPER 181, RINIT 234, RTIG 236, STATE 138, SUBEXIT 181, TC 169, TIG 224, TPASS4 236, UPDATFLG 99, VG 234, VGDISP 231, VINIT 234, VTIG 236, and XDELVFLG 103.

2258 ⟨*Page LM0653* 2258⟩≡ (2253 2734)

```
                        DELVEET3
                STORE   DELVSIN
                ABVAL   CLEAR
                        XDELVFLG
                STCALL  VGDISP
                        GET.LVC
                VLOAD   PDVL
                        RTIG
                        VIPRIME
                CALL
                        PERIAPO1
                CALL
                        SHIFTR1
                CALL                    # LIMIT DISPLAY TO 9999.9 N. MI.
                        MAXCHK
                STODL   HPER
                        4D
                CALL
                        SHIFTR1
                CALL                    # LIMIT DISPLAY TO 9999.9 N. MI.
                        MAXCHK
                STORE   HAPO
                EXIT
                CAF     V06N81          # DELVLVC
                TC      VNP00H
                CAF     V06N42          # HAPO, HPER, VGDISP
                TC      VNP00H
                TC      INTPRET
REVN1645        SET     CALL            # TRKMKCNT, TTOGO, +MGA
                        FINALFLG
                        VN1645
                GOTO
                        REVN1645


# *** END OF LEMP30S .103 ***
```

Uses +MGA 234, DELVEET3 236, DELVLVC 224, DELVSIN 236, FINALFLG 105, HAPO 181, HPER 181, N 206, RTIG 236, TC 169, TRKMKCNT 157, TTOGO 236, VGDISP 231, VIPRIME 234, and XDELVFLG 103.

4.17 burn-baby-burn master ignition routine

2259 ⟨*burn-baby-burn master ignition routine* 2259⟩≡ (2041)

⟨*Page LM0731* 2260⟩
⟨*Page LM0732* 2262⟩
⟨*Page LM0733* 2263⟩
⟨*Page LM0734* 2265⟩
⟨*Page LM0735* 2267⟩
⟨*Page LM0736* 2269⟩
⟨*Page LM0737* 2271⟩
⟨*Page LM0738* 2273⟩
⟨*Page LM0739* 2275⟩
⟨*Page LM0740* 2277⟩
⟨*Page LM0741* 2279⟩
⟨*Page LM0742* 2281⟩
⟨*Page LM0743* 2283⟩
⟨*Page LM0744* 2285⟩
⟨*Page LM0745* 2287⟩
⟨*Page LM0746* 2289⟩
⟨*Page LM0747* 2291⟩
⟨*Page LM0748* 2293⟩
⟨*Page LM0749* 2294⟩
⟨*Page LM0750* 2295⟩
⟨*Page LM0751* 2297⟩

2260 ⟨*Page LM0731* 2260⟩≡ (2259 2655)

```
## At the get-together of the AGC developers celebrating the 40th anniversary
## of the first moonwalk, Don Eyles (one of the authors of this routine along
## with Peter Adler) has related to us a little interesting history behind the
## naming of the routine.
##
## It traces back to 1965 and the Los Angeles riots, and was inspired
## by disc jockey extraordinaire and radio station owner Magnificent Montague.
## Magnificent Montague used the phrase "Burn, baby! BURN!" when spinning the
## hottest new records. Magnificent Montague was the charismatic voice of
## soul music in Chicago, New York, and Los Angeles from the mid-1950s to
## the mid-1960s.
# BURN, BABY, BURN -- MASTER IGNITION ROUTINE

                BANK    36
                SETLOC  P40S
                BANK
                EBANK=  WHICH
                COUNT*  $$/P40

# THE MASTER IGNITION ROUTINE IS DESIGNED FOR USE BY THE FOLLOWING LEM PROGRAMS:  P12
# IT PERFORMS ALL FUNCTIONS IMMEDIATELY ASSOCIATED WITH APS OR DPS IGNITION:  IN PART
# BETWEEN THE PRE-IGNITION TIME CHECK -- ARE WE WITHIN 45 SECONDS OF TIG? -- AND TIG
# PROGRAMS THROTTLE UP.
#
# VARIATIONS AMONG PROGRAMS ARE ACCOMODATED BY MEANS OF TABLES CONTAINING CONSTANTS
# WAITLIST, FOR PINBALL) AND TCF INSTRUCTIONS.  USERS PLACE THE ADRES OF THE HEAD OF
# (OF P61TABLE FOR P61LM, FOR EXAMPLE) IN ERASABLE REGISTER 'WHICH' (E4).  THE IGNITI
# WHICH TO OBTAIN OR EXECUTE THE PROPER TABLE ENTRY.  THE IGNITION ROUTINE IS INITIAT
# THROUGH BANKJUMP IF NECESSARY.  THERE IS NO RETURN.
#
# THE MASTER IGNITION ROUTINE WAS CONCEIVED AND EXECUTED, AND (NOTA BENE) IS MAINTAIN
#
#                  HONI SOIT QUI MAL Y PENSE
#
#       ***********************************************
#               TABLES FOR THE IGNITION ROUTINE
#       ***********************************************
#
#                       NOLI SE TANGERE

P12TABLE        VN      0674            # (0)
                TCF     ULLGNOT         # (1)
                TCF     COMFAIL3        # (2)
                TCF     GOCUTOFF        # (3)
                TCF     TASKOVER        # (4)
```

```
                TCF     P12SPOT         # (5)
                DEC     0               # (6)   NO ULLAGE
                EBANK=  WHICH
                2CADR   SERVEXIT        # (7)

                TCF     DISPCHNG        # (11)
                TCF     WAITABIT        # (12)
                TCF     P12IGN          # (13)

P40TABLE        VN      0640            # (0)
                TCF     ULLGNOT         # (1)
                TCF     COMFAIL4        # (2)
                TCF     GOPOST          # (3)
                TCF     TASKOVER        # (4)
                TCF     P40SPOT         # (5)
```

Uses `A` 80, `AVEGEXIT` 159, `COUNT` 142, `EBANK` 80, `IT` 185, `P40S` 65, `TIG` 224, and `VN` 159.

2262 ⟨*Page LM0732* 2262⟩≡ (2259 2655)

```
                DEC     2240            # (6)
                EBANK=  OMEGAQ
                2CADR   STEERING        # (7)

                TCF     P40SJUNK        # (11)
                TCF     WAITABIT        # (12)
                TCF     P40IGN          # (13)
                TCF     REP40ALM        # (14)

P41TABLE        TCF     P41SPOT         # (5)
                DEC     -1              # (6)
                EBANK=  OMEGAQ
                2CADR   CALCN85         # (7)

                TCF     COMMON          # (11)
                TCF     TIGTASK         # (12)

P42TABLE        VN      0640            # (0)
                TCF     WANTAPS         # (1)
                TCF     COMFAIL4        # (2)
                TCF     GOPOST          # (3)
                TCF     TASKOVER        # (4)
                TCF     P42SPOT         # (5)
                DEC     2640            # (6)
                EBANK=  OMEGAQ
                2CADR   STEERING        # (7)

                TCF     P40SJUNK        # (11)
                TCF     WAITABIT        # (12)
                TCF     P42IGN          # (13)
                TCF     P42STAGE        # (14)

P63TABLE        VN      0662            # (0)
                TCF     ULLGNOT         # (1)
                TCF     COMFAIL3        # (2)
                TCF     V99RECYC        # (3)
                TCF     TASKOVER        # (4)
                TCF     P63SPOT         # (5)
                DEC     2240            # (6)
                EBANK=  WHICH
                2CADR   SERVEXIT        # (7)

                TCF     DISPCHNG        # (11)
                TCF     WAITABIT        # (12)
```

Uses `EBANK` 80 and `VN` 159.

2263 ⟨*Page LM0733* 2263⟩≡ (2259 2655)

```
                TCF     P63IGN          # (13)

ABRTABLE        VN      0663            # (0)
                TCF     ULLGNOT         # (1)
                TCF     COMFAIL3        # (2)
                TCF     GOCUTOFF        # (3)
                TCF     TASKOVER        # (4)
                NOOP                    # (5)
                NOOP                    # (6)
                NOOP                    # (7)
                NOOP
                TCF     DISPCHNG        # (11)
                TCF     WAITABIT        # (12)
                TCF     ABRTIGN         # (13)

#       ********************************
#       GENERAL PURPOSE IGNITION ROUTINES
#       ********************************

BURNBABY        TC      PHASCHNG        # GROUP 4 RESTARTS HERE
                OCT     04024

                CAF     ZERO            # EXTIRPATE JUNK LEFT IN DVTOTAL
                TS      DVTOTAL
                TS      DVTOTAL +1

                TC      BANKCALL        # P40AUTO MUST BE BANKCALLED EVEN FROM ITS
                CADR    P40AUTO         # OWN BANK TO SET UP RETURN PROPERLY

B*RNB*B*        EXTEND
                DCA     TIG             # STORE NOMINAL TIG FOR OBLATENESS COMP.
                DXCH    GOBLTIME        # AND FOR P70 OR P71.

                INHINT
                TC      IBNKCALL
                CADR    ENGINOF3
                RELINT

                INDEX   WHICH
                TCF     5

P42SPOT         =       P40SPOT         # (5)
P12SPOT         =       P40SPOT         # (5)
P63SPOT         =       P41SPOT         # (5)   IN P63 CLOKTASK ALREADY GOING
P40SPOT         CS      CNTDNDEX        # (5)
```

Uses `DVTOTAL` 224, `TC` 169, `TIG` 224, and `VN` 159.

2265 ⟨*Page LM0734* 2265⟩≡ (2259 2655)

```
                TC      BANKCALL        # MUST BE BANKCALLED FOR GENERALIZED
                CADR    STCLOK2         #       RETURN
P41SPOT         TC      INTPRET         # (5)
                DLOAD   DSU
                        TIG
                        D29.9SEC
                STCALL  TDEC1
                        INITCDUW
                BOFF    CALL
                        MUNFLAG
                        GOMIDAV
                        CSMPREC
                VLOAD   MXV
                        VATT1
                        REFSMMAT
                VSR1
                STOVL   V(CSM)          # CSM VELOCITY -- M/CS*2(7)
                        RATT1
                VSL4    MXV
                        REFSMMAT
                STCALL  R(CSM)          # CSM POSITION -- M*2(24)
                        MUNGRAV
                STODL   G(CSM)          # CSM GRAVITY VEC. -- M/CS*2(7)
                        TAT
                STORE   TDEC1           # RELOAD TDEC1 FOR MIDTOAV.
GOMIDAV         CALRB
                        MIDTOAV1
                TCF     CALLT-35        # MADE IT IN TIME.

                EXTEND                  # TIG WAS SLIPPED, SO RESET TIG TO 29.9
                DCA     PIPTIME1        # SECONDS AFTER THE TIME TO WHICH WE DID
                DXCH    TIG             # INTEGRATE.
                EXTEND
                DCA     D29.9SEC
                DAS     TIG

CALLT-35        DXCH    MPAC
                DXCH    SAVET-30        # DELTA-T UNTIL TIG-30
                EXTEND
                DCS     5SECDP
                DAS     SAVET-30        # DELTA-T UNTIL TIG-35
                EXTEND
                DCA     SAVET-30
                TC      LONGCALL
                EBANK=  TTOGO
```

```
2CADR   TIG-35

TC      PHASCHNG
OCT     20254           # 4.25SPOT FOR TIG-35 RESTART.
```

Uses EBANK 80, IT 185, MPAC 145, PIPTIME1 159, REFSMMAT 172, RESTART 57, TC 169, TIG 224, TTOGO 236, and V 229.

2267 ⟨*Page LM0735* 2267⟩≡ (2259 2655)

```
                TC      CHECKMM
                DEC     63
                TCF     ENDOFJOB        # NOT P63
                CS      CNTDNDEX        # P63 CAN START DISPLAYING NOW.
                TS      DISPDEX
                TC      INTPRET
                VLOAD   ABVAL
                        VN1
                STORE   ABVEL           # INITIALIZE ABVEL FOR P63 DISPLAY
                EXIT
                TCF     ENDOFJOB

#       ********************************

TIG-35          CAF     5SEC
                TC      TWIDDLE
                ADRES   TIG-30

                TC      PHASCHNG
                OCT     40154           # 4.15SPOT FOR TIG-30 RESTART

                CS      BLANKDEX        # BLANK DSKY FOR 5 SECONDS
                TS      DISPDEX

                INDEX   WHICH
                CS      6               # CHECK ULLAGE TIME.
                EXTEND
                BZMF    TASKOVER
                CAF     4.9SEC          # SET UP TASK TO RESTORE DISPLAY AT TIG-30
                TC      TWIDDLE
                ADRES   TIG-30.1

                CAF     PRIO17          # A NEGATIVE ULLAGE TIME INDICATES P41, IN
                TC      NOVAC           # WHICH CASE WE HAVE TO SET UP A JOB TO
                EBANK=  TTOGO           # BLANK THE DSKY FOR FIVE SECONDS, SINCE
                2CADR   P41BLANK        # CLOKJOB IS NOT RUNNING DURING P41.

                TCF     TASKOVER

P41BLANK        TC      BANKCALL        # BLANK DSKY.
                CADR    CLEANDSP
                TCF     ENDOFJOB

TIG-30.1        CAF     PRIO17          # SET UP JOB TO RESTORE DISPLAY AT TIG-30
                TC      NOVAC
```

```
EBANK=  TTOGO
2CADR   TIG-30A

TCF     TASKOVER
```

Uses A 80, DISPDEX 165, EBANK 80, RESTART 57, TC 169, TIG 224, TTOGO 236, and VN1 159.

2269 ⟨*Page LM0736* 2269⟩≡ (2259 2655)

```
TIG-30A         CAF     V16N85B
                TC      BANKCALL        # RESTORE DISPLAY.
                CADR    REGODSP         # REGODSP DOES A TCF ENDOFJOB

#       ********************************

TIG-30          CAF     S24.9SEC
                TC      TWIDDLE
                ADRES   TIG-5

                CS      CNTDNDEX        # START UP CLOKTASK AGAIN
                TS      DISPDEX

                INDEX   WHICH           # PICK UP APPROPRIATE ULLAGE -- ON TIME
                CA      6               # Was CAF --- RSB 2009.
                EXTEND
                BZMF    ULLGNOT         # DON'T SET UP ULLAGE IF DT IS NEG OR ZERO
                TS      SAVET-30        # SAVE DELTA-T FOR RESTART
                TC      TWIDDLE
                ADRES   ULLGTASK

                CA      THREE           # RESTART PROTECT ULLGTASK (1.3SPOT)
                TS      L
                CS      THREE
                DXCH    -PHASE1
                CS      TIME1
                TS      TBASE1

                INDEX   WHICH
                TCF     1

WANTAPS         CS      FLGWRD10        # (1) FOR P42 ENSURE APSFLAG IS SET.  IF IT
                MASK    APSFLBIT        # WASN'T SET, DAP WILL BE INITIALIZED TO
                ADS     FLGWRD10        # ASCENT VALUES BY 1/ACCS IN 2 SECONDS.

ULLGNOT         EXTEND                  # (1)
                INDEX   WHICH
                DCA     7               # LOAD AVEGEXIT WITH APPROPRIATE 2CADR
                DXCH    AVEGEXIT

                CAF     TWO             # 4.2SPOT RESTARTS IMMEDIATELY AT REDO4.2
                TS      L
                CS      TWO             # AND ALSO AT TIG-5 AT THE CORRECT TIME.
                DXCH    -PHASE4
```

```
                CS      TIME1
                TS      TBASE4          # SET TBASE4 FOR TIG-5 RESTART

REDO2.17        EXTEND
```

Uses -PHASE1 152, -PHASE4 152, A 80, AVEGEXIT 159, DISPDEX 165, FLGWRD10 133, IT 185, L 80, PHASE1 152, PHASE4 152, RESTART 57, SAVE 191, TBASE1 154, TBASE4 154, TC 169, TIG 224, and TIME1 80.

2271 ⟨*Page LM0737* 2271⟩≡ (2259 2655)

```
                DCA     NEG0            # CLEAR OUT GROUP 2 SO LAMBERT CAN START
                DXCH    -PHASE2         # IF NEEDED.

RED04.2         CCS     PHASE5          # IF SERVICER GOING?
                TCF     TASKOVER        # YES, DON'T START IT UP AGAIN.

                TC      POSTJUMP
                CADR    PREREAD         # PREREAD END THIS TASK

#       *********************************

ULLGTASK        TC      ONULLAGE        # THIS COMES AT TIG-7.5 OR TIG-3.5
                TC      PHASCHNG
                OCT     1
                TCF     TASKOVER

#       *********************************

TIG-5           EXTEND
                DCA     NEG0            # INSURE THAT GROUP 3 IS INACTIVE.
                DXCH    -PHASE3

                CAF     5SEC
                TC      TWIDDLE
                ADRES   TIG-0

                TC      DOWNFLAG        # RESET IGNFLAG AND ASINFLAG
                ADRES   IGNFLAG         #       FOR LIGHT-UP LOGIC.
                TC      DOWNFLAG
                ADRES   ASTNFLAG

                INDEX   WHICH
                TCF     11

P40SJUNK        CCS     PHASE3          # (11) P40 AND P42.  S40.13 IN PROGRESS?
                TCF     DISPCHNG        # YES

                CAF     PRIO20
                TC      FINDVAC
                EBANK=  TTOGO
                2CADR   S40.13

                TC      PHASCHNG        # 3.5SPOT FOR S40.13
                OCT     00053
DISPCHNG        CS      VB99DEX         # (11)
```

TS DISPDEX

Uses -PHASE2 152, -PHASE3 152, ASTNFLAG 123, DISPDEX 165, EBANK 80, IGNFLAG 123, IT 185, PHASE2 152, PHASE3 152, PHASE5 152, TC 169, TIG 224, and TTOGO 236.

2273 ⟨*Page LM0738* 2273⟩≡ (2259 2655)

```
COMMON          TC      PHASCHNG        # RESTART TIG-0 (4.7SPOT)
                OCT     40074
                TCF     TASKOVER

#       ********************************

TIG-0           CS      FLAGWRD7        # SET IGNFLAG SINCE TIG HAS ARRIVED
                MASK    IGNFLBIT
                ADS     FLAGWRD7

                TC      CHECKMM         # IN P63 CASE, THROTTLE-UP IS ZOOMTIME
                DEC     63              # AFTER NOMINAL IGNITION, NOT ACTUAL
                TCF     IGNYET?
                CA      ZOOMTIME
                TC      WAITLIST
                EBANK=  DVCNTR
                2CADR   P63ZOOM

                TC      2PHSCHNG
                OCT     40033

                OCT     05014
                OCT     77777

IGNYET?         CAF     ASTNBIT         # CHECK ASTNFLAG:  HAS ASTRONAUT RESPONDED
                MASK    FLAGWRD7        # TO OUR ENGINE ENABLE REQUEST?
                EXTEND
                INDEX   WHICH
                BZF     12              # BRANCH IF HE HAS NOT RESPONDED YET

IGNITION        CS      FLAGWRD5        # INSURE ENGONFLG IS SET.
                MASK    ENGONBIT
                ADS     FLAGWRD5
                CS      PRIO30          # TURN ON THE ENGINE.
                EXTEND
                RAND    DSALMOUT
                AD      BIT13
                EXTEND
                WRITE   DSALMOUT
                EXTEND                  # SET TEVENT FOR DOWNLINK
                DCA     TIME2
                DXCH    TEVENT

                EXTEND                  # UPDATE TIG USING TGO FROM S40.13
                DCA     TGO
```

```
DXCH    TIG
EXTEND
DCA     TIME2
DAS     TIG
```

Uses ASTNBIT 123, ASTNFLAG 123, DSALMOUT 87, DVCNTR 224, EBANK 80, ENGONBIT 115, ENGONFLG 115, FLAGWRD5 113, FLAGWRD7 121, IGNFLAG 123, IGNFLBIT 123, RESTART 57, TC 169, TEVENT 163, TGO 224, TIG 224, and TIME2 80.

2275 ⟨*Page LM0739* 2275⟩≡ (2259 2655)

```
                CS      FLUNDBIT        # PERMIT GUIDANCE LOOP DISPLAYS
                MASK    FLAGWRD8
                TS      FLAGWRD8

                INDEX   WHICH
                TCF     13

P63IGN          EXTEND                  # (13)  INITIATE BURN DISPLAYS
                DCA     DSP2CADR
                DXCH    AVGEXIT

                CA      Z               # ASSASSINATE CLOKTASK
                TS      DISPDEX

                CS      FLAGWRD9        # SET FLAG FOR P70-P71
                MASK    LETABBIT
                ADS     FLAGWRD9

                CS      FLAGWRD7        # SET SWANDISP TO ENABLE R10.
                MASK    SWANDBIT
                ADS     FLAGWRD7

                CS      PULSES          # MAKE SURE DAP IS NOT IN MINIMUM-IMPULSE
                MASK    DAPBOOLS        # MODE, IN CASE OF SWITCH TO P66
                TS      DAPBOOLS

                EXTEND                  # INITIALIZE TIG FOR P70 AND P71.
                DCA     TIME2
                DXCH    TIG

                CAF     ZERO            # INITIALIZE WCHPHASE, AND FLPASS0
                TS      WCHPHASE
                TS      WCHPHOLD        # ALSO WHCPHOLD
                CA      TWO
                TS      FLPASS0

                TCF     P42IGN
P40IGN          CS      FLAGWRD5        # (13)
                MASK    NOTHRBIT
                EXTEND
                BZF     P42IGN
                CA      ZOOMTIME
                TC      WAITLIST
                EBANK=  DVCNTR
                2CADR   P40ZOOM
```

```
P63IGN1         TC      2PHSCHNG
                OCT     40033           # 3.3SPOT FOR ZOOM RESTART.
                OCT     05014           # TYPE C RESTARTS HERE IMMEDIATELY
                OCT     77777
```

Uses AVGEXIT 159, DISPDEX 165, DISPLAYS 59, DVCNTR 224, EBANK 80, FLAGWRD5 113, FLAGWRD7 121, FLAGWRD8 125, MODE 145, RESTART 57, TC 169, TIG 224, TIME2 80, and Z 80.

2277 ⟨*Page LM0740* 2277⟩≡ (2259 2655)

```
                TCF     P42IGN
P12IGN          CAF     EBANK6
                TS      EBANK
                EBANK=  AOSQ

                CA      IGNAOSQ         # INITIALIZE DAP BIAS ACCELERATION
                TS      AOSQ            # ESTIMATES AT P12 IGNITION.
                CA      IGNAOSR
                TS      AOSR

                CAF     EBANK7
                TS      EBANK
                EBANK=  DVCNTR

ABRTIGN         CA      Z               # (13) KILL CLOKTASK
                TS      DISPDEX

                EXTEND                  # CONNECT ASCENT GYIDANCE TO SERVICER.
                DCA     ATMAGADR
                DXCH    AVGEXIT

                CS      FLAGWRD7        # ENABLE R10.
                MASK    SWANDBIT
                ADS     FLAGWRD7

P42IGN          CS      DRIFTBIT        # ENSURE THAT POWERED-FLIGHT SWITCHING
                MASK    DAPBOOLS        # CURVES ARE USED.
                TS      DAPBOOLS
                CAF     IMPULBIT        # EXAMINE IMPULSE SWITCH
                MASK    FLAGWRD2
                CCS     A
                TCF     IMPLBURN

DVMONCON        TC      DOWNFLAG
                ADRES   IGNFLAG         # CONNECT DVMON
                TC      DOWNFLAG
                ADRES   ASTNFLAG
                TC      DOWNFLAG
                ADRES   IDLEFLAG

                TC      PHASCHNG
                OCT     40054

                TC      FIXDELAY        # TURN ULLAGE OFF HALF A SECOND AFTER
                DEC     50              # LIGHT UP.
```

```
ULLAGOFF        TC      NOULLAGE

WAITABIT        EXTEND                  # KILL GROUP 4
                DCA     NEGO
```

Uses A 80, ASTNFLAG 123, AVGEXIT 159, BIAS 211, DISPDEX 165, DVCNTR 224, EBANK 80, FLAGWRD2 101, FLAGWRD7 121, IGNFLAG 123, IMPULBIT 103, TC 169, and Z 80.

2279 ⟨*Page LM0741* 2279⟩≡ (2259 2655)

```
                DXCH    -PHASE4

                TCF     TASKOVER

TIGTASK         TC      POSTJUMP        # (12)
                CADR    TIGTASK1

#       ********************************

                BANK    31
                SETLOC  P40S3
                BANK
                COUNT*  $$/P40

TIGTASK1        CAF     PRIO16
                TC      NOVAC
                EBANK=  TRKMKCNT
                2CADR   TIGNOW

                TC      PHASCHNG
                OCT     6               # KILL GROUP 6

                TCF     TASKOVER

#       ********************************

P63ZOOM         EXTEND
                DCA     LUNLANAD
                DXCH    AVEGEXIT

                TC      IBNKCALL
                CADR    FLATOUT
                TCF     P40ZOOMA

P40ZOOM         CAF     BIT13
                TS      THRUST
                CAF     BIT4

                EXTEND
                WOR     CHAN14

P40ZOOMA        TC      PHASCHNG
                OCT     3
                TCF     TASKOVER
```

```
                EBANK=  DVCNTR
LUNLANAD        2CADR   LUNLAND
```

Uses -PHASE4 152, AVEGEXIT 159, CHAN14 87, COUNT 142, DVCNTR 224, EBANK 80, P40S3 67, PHASE4 152, TC 169, THRUST 85, and TRKMKCNT 157.

2281 ⟨*Page LM0742* 2281⟩≡ (2259 2655)

```
ZOOM            =       P40ZOOMA
                BANK    36
                SETLOC  P40S
                BANK
                COUNT*  $$/P40

#       ********************************

COMFAIL         TC      UPFLAG          # (15)
                ADRES   IDLEFLAG
                TC      UPFLAG          # SET FLAG TO SUPPRESS CONFLICTING DISPLAY
                ADRES   FLUNDISP
                CAF     FOUR            # RESET DVMON
                TS      DVCNTR
                CCS     PHASE6          # CLOCKTASK ACTIVE?
                TCF     +3              # YES
                TC      BANKCALL        # OTHERWISE, START IT UP
                CADR    STCLOK1
        +3      CS      VB97DEX
                TS      DISPDEX
                TC      PHASCHNG        # TURN OFF GROUP 4.
                OCT     00004
                TCF     ENDOFJOB

COMFAIL1        INDEX   WHICH
                TCF     2

COMFAIL3        CA      Z               # (15)  KILL CLOKTASK USING Z
                TCF     +2

COMFAIL4        CS      CNTDNDEX
                TS      DISPDEX

                TC      DOWNFLAG        # RECONNECT DV MONITOR
                ADRES   IDLEFLAG
                TC      DOWNFLAG        # PERMIT GUIDANCE LOOP DISPLAYS
                ADRES   FLUNDISP
                TCF     ENDOFJOB

COMFAIL2        TC      PHASCHNG        # KILL ZOOM RESTART PROTECTION
                OCT     00003

                INHINT
                TC      KILLTASK        # KILL ZOOM IN CASE IT'S STILL TO COME
                CADR    ZOOM
```

```
TC      IBNKCALL        # COMMAND ENGINE OFF
CADR    ENGINOF4
TC      UPFLAG          # SET THE DRIFT BIT FOR THE DAP.
ADRES   DRIFTDFL
```

Uses COMMAND 169, COUNT 142, DISPDEX 165, DISPLAYS 59, DV 241, DVCNTR 224, IT 185, P40S 65, PHASE6 152, RESTART 57, TC 169, and Z 80.

2283 ⟨*Page LM0743* 2283⟩≡ (2259 2655)

```
                TC      INVFLAG         # USE OTHER RCS SYSTEM
                ADRES   AORBTFLG
                TC      UPFLAG          # TURN ON ULLAGE
                ADRES   ULLAGFLG
                CAF     BIT1
                INHINT
                TC      TWIDDLE
                ADRES   TIG-5
                TCF     ENDOFJOB

#       ***********************************
#       SUBROUTINES OF THE IGNITION ROUTINE
#       ***********************************

INVFLAG         CA      Q
                TC      DEBIT
                COM
                EXTEND
                RXOR    LCHAN
                TCF     COMFLAG

#       ***********************************

NOULLAGE        CS      ULLAGER         # MUST BE CALLED IN A TASK OR UNDER INHINT
                MASK    DAPBOOLS
                TS      DAPBOOLS
                TC      Q

#       ***********************************

ONULLAGE        CS      DAPBOOLS        # TURN ON ULLAGE.  MUST BE CALLED IN
                MASK    ULLAGER         # A TASK OR WHILE INHINTED.
                ADS     DAPBOOLS
                TC      Q

#       ***********************************

STCLOK1         CA      ZERO            # THIS ROUTINE STARTS THE COUNT-DOWN
STCLOK2         TS      DISPDEX         # (CLOKTASK AND CLOKJOB).  SETTING
STCLOK3         TC      MAKECADR        # SETTING DISPDEX POSITIVE KILLS IT.
                TS      TBASE4          # RETURN SAVE (NOT FOR RESTARTS).
                EXTEND
                DCA     TIG
                DXCH    MPAC
                EXTEND
```

DCS TIME2

Uses A 80, COUNT 142, DISPDEX 165, IT 185, LCHAN 87, MPAC 145, Q 80, SAVE 191, TBASE4 154, TC 169, TIG 224, and TIME2 80.

2285 ⟨*Page LM0744* 2285⟩≡ (2259 2655)

```
                DAS     MPAC            # HAVE TIG -- TIME2, UNDOUBTEDLY A + NUMBER
                TC      TPAGREE         # POSITIVE, SINCE WE PASSED THE
                CAF     1SEC            # 45 SECOND CHECK.
                TS      Q
                DXCH    MPAC
                MASK    LOW5            # RESTRICT MAGNITUDE OF NUMBER IN A
                EXTEND
                DV      Q
                CA      L               # GET REMAINDER
                AD      TWO
                INHINT
                TC      TWIDDLE
                ADRES   CLOKTASK
                TC      2PHSCHNG
                OCT     40036           # 6.3SPOT FOR CLOKTASK
                OCT     05024
                OCT     13000

                CA      TBASE4
                TC      BANKJUMP

CLOKTASK        CS      TIME1           # SET TBASE6 FOR GROUP 6 RESTART
                TS      TBASE6

                CCS     DISPDEX
                TCF     KILLCLOK
                NOOP
                CAF     PRIO27
                TC      NOVAC
                EBANK=  TTOGO
                2CADR   CLOKJOB

                TC      FIXDELAY        # WAIT A SECOND BEFORE STARTING OVER
                DEC     100
                TCF     CLOKTASK

KILLCLOK        EXTEND                  # KILL RESTART
                DCA     NEGO
                DXCH    -PHASE6
                TCF     TASKOVER

CLOKJOB         EXTEND
                DCS     TIG
                DXCH    TTOGO
                EXTEND
```

Uses -PHASE6 152, A 80, DISPDEX 165, DV 241, EBANK 80, L 80, MPAC 145, PHASE6 152, Q 80, RESTART 57, TBASE4 154, TBASE6 154, TC 169, TIG 224, TIME1 80, TIME2 80, and TTOGO 236.

2287 ⟨*Page LM0745* 2287⟩≡ (2259 2655)

```
                DCA     TIME2
                DAS     TTOGO
                INHINT
                CCS     DISPDEX         # IF DISPDEX HAS BEEN SET POSITIVE BY A
                TCF     ENDOFJOB        # TASK OR A HIGHER PRIORITY JOB SINCE THE
                TCF     ENDOFJOB        # LAST CLOKTASK, AVOID USING IT AS AN
                COM                     # INDEX.
                RELINT                  # ***** DISPDEX MUST NEVER B -0 *****
                INDEX   A
                TCF     DISPNOT -1      # (-1 DUE TO EFFECT OF CCS)

VB97DEX         =       OCT35           # NEGATIVE OF THIS IS PROPER FOR DISPDEX

        -35     CS      ZERO            # INDICATE VERB 97 PASTE
                TS      NVWORD1
                CA      NVWORD  +2      # NVWORD+2 CONTAINS V06 & APPROPRIATE NOUN
                TC      BANKCALL
                CADR    CLOCPLAY
                TCF     STOPCLOK        # TERMINATE CLOKTASK ON THE WAY TO POOH
                TCF     COMFAIL1
                TCF     COMFAIL2

                                        # THIS DISPLAY IS CALLED VIA ASTNCLOK
        -25     CAF     V06N61          # IT IS PRIMARILY USED BY THE CREW IN P63
                TC      BANKCALL        # TO RESET HIS EVENT TIMER TO AGREE WITH
                CADR    REFLASH         # TIG.
                TCF     STOPCLOK
                TCF     ASTNRETN
                TCF     -6

CNTDNDEX        =       LOW4            # OCT17:  NEGATIVE PROPER FOR DISPDEX

        -17     INDEX   WHICH           # THIS DISPLAY COMES UP AT ONE SECOND
                # Was CAF --- RSB 2009
                CA      0               # INTERVALS.  IT IS NORMALLY OPERATED
                TC      BANKCALL        # BETWEEN TIG-30 SECONDS AND TIG-5 SECONDS
                CADR    REGODSP         # REGODSP DOES ITS OWN TCF ENDOFJOB

VB99DEX         =       ELEVEN          # OCT13:  NEGATIVE PROPER FOR DISPDEX

V99RECYC        EQUALS

        -13     CS      BIT9            # INDICATE VERB 99 PASTE
                TS      NVWORD1
                INDEX   WHICH           # THIS IS THE "PLEASE ENABLE ENGINE"
```

```
# Was CAF --- RSB 2004
CA      0               # DISPLAY; IT IS INITIATED AT TIG-5 SEC.
TC      BANKCALL        # THE DISPLAY IS A V99NXX, WHERE XX IS
CADR    CLOCPLAY        # NOUN THAT HAD PREVIOUSLY BEEN DISPLAYED
TCF     STOPCLOK        # TERMINATE GOTOPOOH TURNS OFF ULLAGE.
TCF     *PROCEED
TCF     *ENTER
```

Uses A 80, DISPDEX 165, IT 185, NVWORD 150, NVWORD1 157, PRIORITY 145, TC 169, TIG 224, TIME2 80, TIMER 194, and TTOGO 236.

2289 ⟨*Page LM0746* 2289⟩≡ (2259 2655)

```
BLANKDEX        =       TWO             # NEGATIVE OF THIS IS PROPER FOR DISPDEX

        -2      TC      BANKCALL        # BLANK DSKY.  THE DSKY IS BLANKED FOR
                CADR    CLEANDSP        # 5 SECONDS AT TIG-35 TO INDICATE THAT
DISPNOT         TCF     ENDOFJOB        # AVERAGE G IS STARTING.

STOPCLOK        TC      NULLCLOK        # STOP CLOKTASK & TURN OFF ULLAGE ON THE
                TCF     GOTOPOOH        # WAY TO POO (GOTOPOOH RELINTS)

NULLCLOK        INHINT
                EXTEND
                QXCH    P40/RET
                TC      NOULLAGE        # TURN OFF ULLAGE ...
                TC      KILLTASK        #       DON'T LET IT COME ON, EITHER ...
                CADR    ULLGTASK
                TC      PHASCHNG        #               NOT EVEN IF THERE'S A RESTART.
                OCT     1
                CA      Z               # KILL CLOKTASK
                TS      DISPDEX
                TC      P40/RET

ASTNRETN        TC      PHASCHNG
                OCT     04024
                CAF     ZERO            # STOP DISPLAYING BUT KEEP RUNNING
                TS      DISPDEX
                CAF     PRIO13
                TC      FINDVAC
                EBANK=  STARIND
                2CADR   ASTNRET

                TCF     ENDOFJOB

*PROCEED        TC      UPFLAG
                ADRES   ASTNFLAG

                TCF     IGNITE

*ENTER          INHINT
                INDEX   WHICH
                TCF     3

GOPOST          CAF     PRIO12          # (3) MUST BE LOWER PRIORITY THAN CLOKJOB
                TC      FINDVAC
                EBANK=  TTOGO
                2CADR   POSTBURN
```

Uses A 80, ASTNFLAG 123, DISPDEX 165, EBANK 80, IT 185, PRIORITY 145, RESTART 57, STARIND 145, TC 169, TIG 224, TTOGO 236, and Z 80.

2291 ⟨*Page LM0747* 2291⟩≡ (2259 2655)

```
                INHINT                  # SET UP THE DAP FOR COASTING FLIGHT.
                TC      IBNKCALL
                CADR    ALLCOAST
                TC      NULLCLOK
                TC      PHASCHNG        # 4.13 RESTART FOR POSTBURN
                OCT     00134

                TCF     ENDOFJOB

GOCUTOFF        CAF     PRIO17          # (3)
                TC      FINDVAC
                EBANK=  TGO
                2CADR   CUTOFF

                TC      DOWNFLAG
                ADRES   FLUNDISP

                INHINT                  # SET UP THE DAP FOR COASTING FLIGHT.
                TC      IBNKCALL
                CADR    ALLCOAST
                TC      NULLCLOK
                TC      PHASCHNG
                OCT     07024
                OCT     17000
                EBANK=  TGO
                2CADR   CUTOFF

                TCF     ENDOFJOB

IGNITE          CS      FLAGWRD7        # (2)
                MASK    IGNFLBIT
                CCS     A
                TCF     IGNITE1
                CAF     BIT1
                INHINT
                TC      TWIDDLE
                ADRES   IGNITION

                CAF     OCT23           # IMMEDIATE RESTART AT IGNITION
                TS      L
                COM
                DXCH    -PHASE4

IGNITE1         CS      CNTDNDEX        # RESTORE OLD DISPLAY.
                TS      DISPDEX
```

```
TCF     ENDOFJOB
```

Uses -PHASE4 152, A 80, DISPDEX 165, EBANK 80, FLAGWRD7 121, IGNFLBIT 123, L 80, PHASE4 152, RESTART 57, TC 169, and TGO 224.

2293 ⟨*Page LM0748* 2293⟩≡ (2259 2655)

```
#       ********************************

P40ALM          TC      ALARM           # PROGRAM SELECTION NOT CONSISTENT WITH
                OCT     1706            # VEHICLE CONFIGURATION

REP40ALM        CAF     V05N09          # (14)
                TC      BANKCALL
                CADR    GOFLASH

                TCF     GOTOP00H        # V34E          TERMINATE
                TCF     +2              # PROCEED       CHECK FOR P42
                TCF     REP40ALM        # V32E          REDISPLAY ALARM

                INDEX   WHICH           # FOR P42, ALLOW CREW TO PROCEED EVEN
                TCF     14              # THOUGH VEHICLE IS UNSTAGED.

#       ********************************

                BANK    31
                SETLOC  P40S2
                BANK

                COUNT*  $$/P40

P40AUTO         TC      MAKECADR        # HELLO THERE.
                TS      TEMPR60         # FOR GENERALIZED RETURN TO OTHER BANKS.
P40A/P          TC      BANKCALL        # SUBROUTINE TO CHECK PGNCS CONTROL
                CADR    G+N,AUTO        # AND AUTO STABILIZATION MODES
                CCS     A               # +0 INDICATES IN PGNCS, IN AUTO
                TCF     TURNITON        # + INDICATES NOT IN PGNCS AND/OR AUTO
                CAF     APSFLBIT        # ARE WE ON THE DESCENT STAGE?
                MASK    FLGWRD10
                CCS     A
                TCF     GOBACK          # RETURN
                CAF     BIT5            # YES, CHECK FOR AUTO-THROTTLE MODE
                EXTEND
                RAND    CHAN30
                EXTEND
                BZF     GOBACK          # IN AUTO-THROTTLE MODE -- RETURN
TURNITON        CAF     P40A/PMD        # DISPLAYS V50N25 R1=203 PLEASE PERFORM
                TC      BANKCALL        # CHECKLIST 203 TURN ON PGNCS ETC.
                CADR    GOPERF1
                TCF     GOTOP00H        # V34E TERMINATE
                TCF     P40A/P          # RECYCLE
GOBACK          CA      TEMPR60
```

```
                TC      BANKJUMP        # GOODBYE.  COME AGAIN SOON.

P40A/PMD        OCT     00203
```

Uses A 80, CHAN30 87, COUNT 142, DISPLAYS 59, FLGWRD10 133, MODE 145, N 206, P 188, P40S2 67, TC 169, and TEMPR60 157.

2294 ⟨*Page LM0749* 2294⟩≡ (2259 2655)

```
                BANK    36
                SETLOC  P40S
                BANK

                COUNT*  $$/P40

#       ***********************************
#       CONSTANTS FOR THE IGNITION ROUTINE
#       ***********************************

SERVCADR        =       P63TABLE +7

P40ADRES        ADRES   P40TABLE

P41ADRES        ADRES   P41TABLE -5

P42ADRES        ADRES   P42TABLE

                EBANK=  DVCNTR
DSP2CADR        2CADR   P63DISPS -2

                EBANK=  DVCNTR
ATMAGADR        2CADR   ATMAG

?               =       GOTOP00H

D29.9SEC        2DEC    2990

S24.9SEC        DEC     2490

4.9SEC          DEC     490

OCT20           =       BIT5

V06N61          VN      0661
```

Uses COUNT 142, DVCNTR 224, EBANK 80, P40S 65, and VN 159.

2295 ⟨*Page LM0750* 2295⟩≡ (2259 2655)

```
# KILLTASK
# MOD NO:  NEW PROGRAM
# MOD BY:  COVELLI
#
# FUNCTIONAL DESCRIPTION:
#
#       KILLTASK IS USED TO REMOVE A TASK FROM THE WAITLIST BY SUBSTITUTING A NULL TASK CALLED
#       WHICH MERELY DOES A TC TASKOVER.  IF THE SAME TASK IS SCHEDULED MORE THAN ONCE, ONLY TH
#       FIRST IS REMOVED.  IF THE TASK IS NOT SCHEDULED, KILLTASK TAKES NO ACTION AND RETURNS W
#       LEAVES INTERRUPTS INHIBITED SO CALLER MUST RELINT
#
# CALLING SEQUENCE
#       L       TC      KILLTASK        # IN FIXED-FIXED
#       L+1     CADR    ????????        # CADR (NOT 2CADR) OF TASK TO BE REMOVED.
#       L+2     (RELINT)                # RETURN
#
# EXIT MODE:  AT L+2 OF CALLING SEQUENCE.
#
# ERASABLE INITIALIZATION:  NONE.
#
# OUTPUT:  2CADR OF NULLTASK IN LST2
#
# DEBRIS:  ITEMP1 - ITEMP4, A, L, Q.

                EBANK=  LST2
                BLOCK   3               # KILLTASK MUST BE IN FIXED-FIXED.
                SETLOC  FFTAG6
                BANK
                COUNT*  $$/KILL
KILLTASK        CA      KILLBB
                INHINT
                LXCH    A
                INDEX   Q
                CA      0               # GET CADR.
                LXCH    BBANK
                TCF     KILLTSK2        # CONTINUE IN SWITCHED FIXED.

                EBANK=  LST2
KILLBB          BBCON   KILLTSK2

                BANK    27

                SETLOC  P40S1
                BANK
                COUNT*  $$/KILL
```

```
KILLTSK2        LXCH    ITEMP2          # SAVE CALLER'S BBANK
```

Uses A 80, BBANK 80, COUNT 142, EBANK 80, FFTAG6 57, ITEMP1 138, ITEMP2 138, ITEMP4 138, L 80, LST2 167, MODE 145, P40S1 61, Q 80, SAVE 191, and TC 169.

2297 ⟨*Page LM0751* 2297⟩≡ (2259 2655)

```
                INCR    Q
                EXTEND
                QXCH    ITEMP1          # RETURN 2ADR IN ITEMP1,ITEMP2

                TS      ITEMP3          # CADR IS IN A
                MASK    LOW10
                AD      BIT11
                TS      ITEMP4          # GENADR OF TASK

                CS      LOW10
                MASK    ITEMP3
                TS      ITEMP3          # FBANK OF TASK

                ZL
ADRSCAN         INDEX   L
                CS      LST2
                AD      ITEMP4          # COMPARE GENADRS
                EXTEND
                BZF     TSTFBANK        # IF THEY MATCH, COMPARE FBANKS
LETITLIV        CS      LSTLIM
                AD      L
                EXTEND                  # ARE WE DONE?
                BZF     DEAD            # YES -- DONE, SO RETURN
                INCR    L
                INCR    L
                TCF     ADRSCAN         # CONTINUE LOOP.

DEAD            DXCH    ITEMP1
                DTCB

TSTFBANK        CS      LOW10
                INDEX   L
                MASK    LST2    +1      # COMPARE FBANKS ONLY.
                EXTEND
                SU      ITEMP3
                EXTEND
                BZF     KILLDEAD        # MATCH -- KILL IT.
                TCF     LETITLIV        # NO MATCH -- CONTINUE.

KILLDEAD        CA      TCTSKOVR
                INDEX   L
                TS      LST2            # REMOVE TASK BY INSERTING TASKOVER
                TCF     DEAD

LSTLIM          EQUALS  BIT5            # DEC 16
```

Uses `A` 80, `FBANK` 80, `IT` 185, `ITEMP1` 138, `ITEMP2` 138, `ITEMP3` 138, `ITEMP4` 138, `L` 80, `LST2` 167, and `Q` 80.

4.18 the lunar landing

2299 ⟨*the lunar landing* 2299⟩≡ (2041 2818)

```
# Page 785
                BANK    32
                SETLOC  F2DPS*32
                BANK

                EBANK=  E2DPS

#       ************************************
#       P63: THE LUNAR LANDING, BRAKING PHASE
#       ************************************

                COUNT*  $$/P63

P63LM           TC      PHASCHNG
                OCT     04024

                TC      BANKCALL        # DO IMU STATUS CHECK ROUTINE R02
                CADR    R02BOTH

                CAF     P63ADRES        # INITIALIZE WHICH FOR BURNBABY
                TS      WHICH

                CAF     DPSTHRSH        # INITIALIZE DVMON
                TS      DVTHRUSH
                CAF     FOUR
                TS      DVCNTR

                CS      ONE             # INITIALIZE WCHPHASE AND FLPASS0
                TS      WCHPHASE

                CA      ZERO
                TS      FLPASS0

                CS      BIT14
                EXTEND
                WAND    CHAN12          # REMOVE TRACK-ENABLE DISCRETE.

FLAGORGY        TC      INTPRET         # DIONYSIAN FLAG WAVING
                CLEAR   CLEAR
                        NOTHROTL
                        REDFLAG
                CLEAR   SET
                        LRBYPASS
```

```
                        MUNFLAG
                CLEAR   CLEAR
                        P25FLAG         # TERMINATE P25 IF IT IS RUNNING.
                        RNDVZFLG        # TERMINATE P20 IF IT IS RUNNING.

                                        # ******************************

IGNALG          SETPD   VLOAD           # FIRST SET UP INPUTS FOR RP-TO-R:
# Page 786
                        0               #       AT 0D LANDING SITE IN MOON FIXED FRAN
                        RLS             #       AT 6D ESTIMATED TIME OF LANDING
                PDDL    PUSH            #       MPAC NON-ZERO TO INDICATE LUNAR CASE
                        TLAND
                STCALL  TPIP            # ALSO SET TPIP FOR FIRST GUIDANCE PASS
                        RP-TO-R
                VSL4    MXV
                        REFSMMAT
                STCALL  LAND
                        GUIDINIT        # GUIDINIT INITIALIZES WM AND /LAND/
                DLOAD   DSU
                        TLAND
                        GUIDDURN
                STCALL  TDEC1           # INTEGRATE STATE FORWARD TO THAT TIME
                        LEMPREC
                SSP     VLOAD
                        NIGNLOOP
                        40D
                        UNITX
                STOVL   CG
                        UNITY
                STOVL   CG +6
                        UNITZ
                STODL   CG +14
                        99999CON
                STOVL   DELTAH          # INITIALIZE DELTAH FOR V16N68 DISPLAY
                        ZEROVECS
                STODL   UNFC/2          # INITIALIZE TRIM VELOCITY CORRECTION TERM
                        HI6ZEROS
                STORE   TTF/8

IGNALOOP        DLOAD
                        TAT
                STOVL   PIPTIME1
                        RATT1
                VSL4    MXV
                        REFSMMAT
```

```
                STCALL  R
                        MUNGRAV
                STCALL  GDT/2
                        ?GUIDSUB        # WHICH DELIVERS N PASSES OF GUIDANCE

# DDUMCALC IS PROGRAMMED AS FOLLOWS:
#                                          2                                          ___
#              (RIGNZ - RGU )/16 + 16(RGU  )KIGNY/B8 + (RGU - RIGNX)KIGNX/B4 + (ABVAL(VGU) - VI
#                          2             1                 0
#       DDUM = ---------------------------------------------------------------------------------
#                                                 10
#                                                2   (VGU - 16 VGU KIGNX/B4)
#                                                         2        0
# Page 787 new page is actually one line earlier but this would put the indices on a separate l
# disconnected from their respective variables
# THE NUMERATOR IS SCALED IN METERS AT 2(28).  THE DENOMINATOR IS A VELOCITY IN UNITS OF 2(10)
# THE QUOTIENT IS THUS A TIME IN UNITS OF 2(18) CENTISECONDS.  THE FINAL SHIFT RESCALES TO UNIT
# THERE IS NO DAMPING FACTOR.  THE CONSTANTS KIGNX/B4, KIGNY/B8 AND KIGNV/B4 ARE ALL NEGATIVE I

DDUMCALC        TS      NIGNLOOP
                TC      INTPRET
                DLOAD   DMPR            # FORM DENOMINATOR FIRST
                        VGU
                        KIGNX/B4
                SL4R    BDSU
                        VGU +4
                PDDL    DSU
                        RIGNZ
                        RGU +4
                SR4R    PDDL
                        RGU +2
                DSQ     DMPR
                        KIGNY/B8
                SL4R    PDDL
                        RGU
                DSU     DMPR
                        RIGNX
                        KIGNX/B4
                PDVL    ABVAL
                        VGU
                DSU     DMPR
                        VIGN
                        KIGNV/B4
                DAD     DAD
                DAD     DDV
                SRR
```

```
                        10D

                PUSH    DAD
                        PIPTIME1
                STODL   TDEC1           # STORE NEW GUESS FOR NEXT INTEGRATION
                ABS     DSU
                        DDUMCRIT
                BMN     CALL
                        DDUMGOOD
                        INTSTALL
                SET     SET
                        INTYPFLG
                        MOONFLAG
                DLOAD
                        PIPTIME1
                STOVL   TET             # HOPEFULLY ?GUIDSUB DID NOT
                        RATT1           #       CLOBBER RATT1 AND VATT1
# Page 788
                STOVL   RCV
                        VATT1
                STCALL  VCV
                        INTEGRVS
                GOTO
                        IGNALOOP

DDUMGOOD        SLOAD   SR
                        ZOOMTIME
                        14D
                BDSU
                        TDEC1
                STOVL   TIG             # COMPUTE DISTANCE LANDING SITE WILL BE
                        V               #       OUT OF LM'S ORBITAL PLANE AT IGNITION
                VXV     UNIT            #       SIGN IS + IF LANDING SITE IS TO THE
                        R               #       RIGHT, NORTH; - IF TO THE LEFT, SOUTH
                DOT     SL1
                        LAND
R60INIT         STOVL   OUTOFPLN        # INITIALIZATION FOR CALCMANU
                        UNFC/2
                STORE   R60VSAVE                # STORE UNFC/2 TEMPORARILY IN R60SAVE
                EXIT
                                        # ****************************************

IGNALGRT        TC      PHASCHNG        # PREVENT REPEATING IGNALG
                OCT     04024

ASTNCLOK        CS      ASTNDEX
```

```
                TC      BANKCALL
                CADR    STCLOK2
                TCF     ENDOFJOB        # RETURN IN NEW JOB AND IN EBANK FIVE

ASTNRET         TC      INTPRET
                SSP     RTB             # GO PICK UP DISPLAY AT END OF R51:
                        QMAJ            #       "PROCEED" WILL DO A FINE ALIGNMENT
                FCADR   P63SPOT2        #       "ENTER" WILL RETURN TO P63SPOT2
                        R51P63
P63SPOT2        VLOAD   UNIT            # INITIALIZE KALCMANU FOR BURN ATTITUDE
                        R60VSAVE
                STOVL   POINTVSM
                        UNITX
                STORE   SCAXIS
                EXIT

                CAF     EBANK7
                TS      EBANK

                INHINT
                TC      IBNKCALL
                CADR    PFLITEDB
# Page 789
                RELINT

                TC      BANKCALL
                CADR    R60LEM

                TC      PHASCHNG        # PREVENT RECALLING R60
                OCT     04024

P63SPOT3        CA      BIT6            # IS THE LR ANTENNA IN POSITION 1 YET
                EXTEND
                RAND    CHAN33
                EXTEND
                BZF     P63SPOT4        # BRANCH IF ANTENNA ALREADY IN POSITION 1

                CAF     CODE500         # ASTRONAUT:    PLEASE CRANK THE
                TC      BANKCALL        #               SILLY THING AROUND
                CADR    GOPERF1
                TCF     GOTOP00H        # TERMINATE
                TCF     P63SPOT3        # PROCEED       SEE IF HE'S LYING

P63SPOT4        TC      BANKCALL        # ENTER         INITIALIZE LANDING RADAR
                CADR    SETPOS1
```

```
                TC      POSTJUMP        # OFF TO SEE THE WIZARD ...
                CADR    BURNBABY

#       ---------------------------------

# CONSTANTS FOR P63LM AND IGNALG

P63ADRES        GENADR  P63TABLE

ASTNDEX         =       MD1             # OCT 25:  INDEX FOR CLOKTASK

CODE500         OCT     00500

99999CON        2DEC    30479.7 B-24

GUIDDURN        2DEC    +66440          # GUIDDURN +6.64400314 E+2
DDUMCRIT        2DEC    +8 B-28         # CRITERION FOR IGNALG CONVERGENCE

# Page 790
#       --------------------------------

# Page 791
#       *************************
#       P68: LANDING CONFIRMATION
#       *************************

                BANK    31
                SETLOC  F2DPS*31
                BANK

                COUNT*  $$/P6567

LANDJUNK        TC      PHASCHNG
                OCT     04024

                INHINT
                TC      BANKCALL        # ZERO ATTITUDE ERROR
                CADR    ZATTEROR

                TC      BANKCALL        # SET 5 DEGREE DEADBAND
                CADR    SETMAXDB

                TC      INTPRET         # TO INTERPRETIVE AS TIME IS NOT CRITICAL
                SET     CLEAR
                        SURFFLAG
                        LETABORT
```

```
                SET     VLOAD
                        APSFLAG
                        RN
                STODL   ALPHAV
                        PIPTIME
                SET     CALL
                        LUNAFLAG
                        LAT-LONG
                SETPD   VLOAD           # COMPUTE RLS AND STORE IT AWAY
                        0
                        RN
                VSL2    PDDL
                        PIPTIME
                PUSH    CALL
                        R-TO-RP
                STORE   RLS
                EXIT
                CAF     V06N43*         # ASTRONAUT:  NOW LOOK WHERE YOU ENDED UP
                TC      BANKCALL
                CADR    GOFLASH
                TCF     GOTOP00H        # TERMINATE
                TCF     +2              # PROCEED
                TCF     -5              # RECYCLE

                TC      INTPRET
# Page 792
                VLOAD                   # INITIALIZE GSAV AND (USING REFMF)
                        UNITX           # YNBSAV, ZNBSAV AND ATTFLAG FOR P57
                STCALL  GSAV
                        REFMF
                EXIT

                TCF     GOTOP00H        # ASTRONAUT:  PLEASE SELECT P57

V06N43*         VN      0643
```

Uses A 80, ALPHAV 177, CHAN12 87, CHAN33 87, COUNT 142, DVCNTR 224, EBANK 80, FACTOR 226, GDT/2 159, HI6ZEROS 71, INTYPFLG 107, IT 185, LAT 157, LONG 157, LUNAFLAG 107, MOONFLAG 95, MPAC 145, N 206, ORBITAL 59, PIPTIME 159, PIPTIME1 159, POINTVSM 219, QMAJ 145, RO2 59, RCV 169, REFSMMAT 172, RLS 175, RN 159, RNDVZFLG 97, SCAXIS 219, SR 80, STATE 138, SURFFLAG 127, TC 169, TET 169, TIG 224, V 229, VCV 169, and VN 159.

4.19 throttle control routines

2306 ⟨*throttle control routines* 2306⟩≡ (2041 2819)

```
# Page 793
                BANK    31
                SETLOC  FTHROT
                BANK
                EBANK=  PIF
                COUNT*  $$/THROT

# * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
# HERE FC, DESIRED THRUST, AND FP, PRESENT THRUST, UNWEIGHTED, ARE COMPUTED.

THROTTLE        CA      ABDELV          # COMPUTE PRESENT ACCELERATION IN UNITS OF
                EXTEND                  # 2(-4) M/CS/CS, SAVING SERVICER TROUBLE
                MP      /AF/CNST
 +3             EXTEND
                QXCH    RTNHOLD
AFDUMP          TC      MASSMULT
                DXCH    FP              # FP = PRESENT THRUST
                EXTEND
                DCA     /AFC/
                TC      MASSMULT
                TS      FC              # FC = THRUST DESIRED BY GUIDANCE
                DXCH    FCODD           # FCODD = WHAT IT IS GOING TO GET

# IF IT HAS BEEN LESS THAN 3 SECONDS SINCE THE LAST THROTTLING, AUGMENT FP USING THE

                CS      TTHROT          # THIS CODING ASSUMES A FLATOUT WITHIN
                AD      TIME1           #       80 SECONDS BEFORE FIRST THROTTLE CALL
                MASK    POSMAX
                COM
                AD      3SECS
                EXTEND
                BZMF    WHERETO         # BRANCH IF (TIME1-TTHROT +1) > 3 SECONDS
                EXTEND
                DCA     FWEIGHT
                DAS     FP

# THIS LOGIC DETERMINES THE THROTTLING IN THE REGION 10% - 94%.  THE MANUAL THROTTLE,
# MINIMUM BY ASTRONAUT OR MISSION CONTROL PROGRAMS, PROVIDES THE LOWER BOUND.  A STOP
# PROVIDES THE UPPER.

WHERETO         CA      EBANK5          # INITIALIZE L*WCR*T AND H*GHCR*T FROM
                TS      EBANK           #       PAD LOADED ERASABLES IN W-MATRIX
#Page 794
```

```
                EBANK=  LOWCRIT
                EXTEND
                DCA     LOWCRIT
                DXCH    L*WCR*T
                CA      EBANK7
                TS      EBANK
                EBANK=  PIF
                CS      ZERO            # INITIALIZE PIFPSET
                TS      PIFPSET
                CS      H*GHCR*T
                AD      FCOLD
                EXTEND
                BZMF    LOWFCOLD        # BRANCH IF FCOLD < OR = HIGHCRIT
                CS      L*WCR*T
                AD      FCODD
                EXTEND
                BZMF    FCOMPSET        # BRANCH IF FC < OR = LOWCRIT
                CA      FP              # SEE NOTE 1
                TCF     FLATOUT1

FCOMPSET        CS      FMAXODD         # SEE NOTE 2
                AD      FP
                TCF     FLATOUT2

LOWFCOLD        CS      H*GHCR*T
                AD      FCODD
                EXTEND
                BZMF    DOPIF           # BRANCH IF FC < OR = HIGHCRIT

                CA      FMAXPOS         # NO:  THROTTLE-UP
FLATOUT1        DXCH    FCODD
                CA      FEXTRA
FLATOUT2        TS      PIFPSET

# NOTE 1        FC IS SET EQUAL TO FP SO PIF WILL BE ZERO.  THIS IS DESIRABLE
#               AS THERE IS ACTUALLY NO THROTTLE CHANGE.
#
# NOTE2         HERE, SINCE WE ARE ABOUT TO RETURN TO THE THROTTLEABLE REGION
#               (BELOW 55%) THE QUANTITY -(FMAXODD-FP) IS COMPUTED AND PUT
#               INTO PIFPSET TO COMPENSATE FOR THE DIFFERENCE BETWEEN THE
#               NUMBER OF BITS CORRESPONDING TO FULL THROTTLE (FMAXODD) AND THE
#               NUMBER CORRESPONDING TO ACTUAL THRUST (FP).  THUS THE TOTAL
#               THROTTLE COMMAND PIF = FC - FP - (FMAXODD - FP) = FC - FMAXODD.

DOPIF           TC      FASTCHNG
                EXTEND
```

```
                DCA     FCODD
                TS      FCOLD
                DXCH    PIF
                EXTEND
#Page 795
                DCS     FP
                DAS     PIF             # PIF = FC - FP, NEVER EQUALS +0

DOIT            CA      PIF
                AD      PIFPSET         # ADD IN PIFPSET, WITHOUT CHANGING PIF
                TS      PSEUDO55
                TS      THRUST
                CAF     BIT4
                EXTEND
                WOR     CHAN14
                CA      TIME1
                TS      TTHROT

# SINCE /AF/ IS NOT AN INSTANTANEOUS ACCELERATION, BUT RATHER AN "AVERAGE" OF THE ACC
# THE PRECEEDING PIPA INTERVAL, AND SINCE FP IS COMPUTED DIRECTLY FROM /AF/, FP IN OR
# ACTUAL THRUST LEVEL AT THE END OF THE INTERVAL MUST BE WEIGHTED BY
#
#                 PIF(PPROCESS + TL)     PIF /PIF/
#       FWEIGHT = ------------------ + -------------
#                      PGUID           2 PGUID FRATE
#
# WHERE PROCESS IS THE TIME BETWEEN PIPA READING AND THE START OF THROTTLING, PGUID I
# FRATE IS THE THROTTLING RATE (32 UNITS PER CENTISECOND).  PGUID IS EITHER 1 OR 2 SE
# FIRST TERM REPRESENTS THE ENGINE'S RESPONSE LAG.  HERE FWEIGHT IS COMPUTED FOR USE

                CA      THISTPIP +1             # INITIALIZE FWEIGHT COMP AS IF FOR P
                TS      BUF

                CS      MODREG                  # ARE WE IN FACT IN P66?
                AD      DEC66
                EXTEND
                BZF     FWCOMP                  # YES

                CA      PIPTIME +1              # NO:  INITIALIZE FOR TWO SECOND PERI
                TS      BUF
                CAF     4SECS
                TCF     FWCOMP +1

FWCOMP          CAF     2SECS
 +1             TS      Q
                EXTEND
```

```
                MP      BIT6
                LXCH    BUF +1
                CS      BUF             # TIME OF LAST PIPA READING.
                AD      TIME1
                AD      THROTLAG        # COMPENSATE FOR ENGINE RESPONSE LAG
                MASK    LOW8            # MAKE SURE SMALL AND POSITIVE
                ZL
                EXTEND
#Page 796
                DV      Q
                EXTEND
                MP      PIF
                DOUBLE
                DXCH    FWEIGHT
                CCS     PIF
                AD      ONE
                TCF     +2
                AD      ONE
                EXTEND
                MP      PIF
                EXTEND
                DV      BUF +1
                ZL
                DAS     FWEIGHT

THDUMP          TC      RTNHOLD

# FLATOUT THROTTLES UP THE DESCENT ENGINE, AND IS CALLED AS A BASIC SUBROUTINE.

FLATOUT         CAF     BIT13           # 4096 PULSES
WHATOUT         TS      PIFPSET         # USE PIFPSET SO FWEIGHT WILL BE ZERO
                CS      ZERO
                TS      FCOLD
                TS      PIF
                EXTEND
                QXCH    RTNHOLD
                TCF     DOIT

# MASSMULT SCALES ACCELERATION, ARRIVING IN A AND L IN UNITS OF 2(-4) M/CS/CS, TO FORCE IN PULS

MASSMULT        EXTEND
                QXCH    BUF
                DXCH    MPAC
                TC      DMP
                ADRES   MASS
                TC      DMP             # LEAVES PROPERLY SCALED FORCE IN MPAC
```

```
                ADRES   SCALEFAC
                TC      TPAGREE
                CA      MPAC
                EXTEND
                BZF     +3
                CAF     POSMAX
                TC      BUF
                DXCH    MPAC +1
                TC      BUF
#Page 797
# CONSTANTS --

FEXTRA          =       BIT13           # FEXT +5.13309020 E+4

/AF/CNST        DEC     .13107

# * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
```

Uses A 80, BUF 142, CHAN14 87, COMMAND 169, COUNT 142, DV 241, EBANK 80, H 177, IT 185, L 80, MASS 200, MODREG 154, MPAC 145, PIPTIME 159, Q 80, TC 169, THRUST 85, TIME1 80, and W 183.

4.20 lunar landing guidance equations

2311 ⟨*lunar landing guidance equations* 2311⟩≡ (2041 2740)

```
# Page 798
                EBANK=  E2DPS
                COUNT*  $$/F2DPS

# ******************************************************
# LUNAR LANDING FLIGHT SEQUENCE TABLES
# ******************************************************

# FLIGHT SEQUENCE TABLES ARE ARRANGED BY FUNCTION.  THEY ARE REFERENCED USING AS AN INDEX THE R
#       WCHPHASE = -1 ---> IGNALG
#       WCHPHASE =  0 ---> BRAKQUAD
#       WCHPHASE =  1 ---> APPRQUAD
#       WCHPHASE =  2 ---> VERTICAL

#******************************************************

# ROUTINES FOR STARTING NEW GUIDANCE PHASES:

                TCF     TTFINCR         # IGNALG
NEWPHASE        TCF     TTFINCR         # BRAKQUAD
                TCF     STARTP64        # APPRQUAD
                TCF     P65START        # VERTICAL

# PRE-GUIDANCE COMPUTATIONS:

                TCF     CALCRGVG        # IGNALG
PREGUIDE        TCF     RGVGCALC        # BRAKQUAD
                TCF     REDESIG         # APPRQUAD
                TCF     RGVGCALC        # VERTICAL

# GUIDANCE EQUATIONS:

                TCF     TTF/8CL         # IGNALG
WHATGUID        TCF     TTF/8CL         # BRAKQUAD
                TCF     TTF/8CL         # APPRQUAD
                TCF     VERTGUID        # VERTICAL

# POST GUIDANCE EQUATION COMPUTATIONS:

                TCF     CGCALC          # IGNALG
AFTRGUID        TCF     CGCALC          # BRAKQUAD
                TCF     CGCALC          # APPRQUAD
                TCF     STEER?          # VERTICAL
```

```
# Page 799
# WINDOW VECTOR COMPUTATIONS:

                TCF     EXGSUB          # IGNALG
WHATEXIT        TCF     EXBRAK          # BRAKQUAD
                TCF     EXNORM          # APPRQUAD

# DISPLAY ROUTINES:

WHATDISP        TCF     P63DISPS        # BRAKQUAD
                TCF     P64DISPS        # APPRQUAD
                TCF     VERTDISP        # VERTICAL

# ALARM ROUTINE FOR TTF COMPUTATION:

                TCF     1406P00         # IGNALG
WHATALM         TCF     1406ALM         # BRAKQUAD
                TCF     1406ALM         # APPRQUAD

# INDICES FOR REFERENCING TARGET PARAMETERS

                OCT     0               # IGNALG
TARGTDEX        OCT     0               # BRAKQUAD
                OCT     34              # APPRQUAD

#*************************************************************************
# ENTRY POINTS:  ?GUIDSUB FOR THE IGNITION ALGORITHM, LUNLAND FOR SERVOUT
#*************************************************************************

# IGNITION ALGORITHM ENTRY:  DELIVERS N PASSES OF QUADRATIC GUIDANCE

?GUIDSUB        EXIT
                CAF     TWO             # N = 3
                TS      NGUIDSUB
                TCF     GUILDRET +2

GUIDSUB         TS      NGUIDSUB        # ON SUCCEEDING PASSES SKIP TTFINCR
                TCF     CALCRGVG

# NORMAL ENTRY:  CONTROL COMES HERE FROM SERVOUT

LUNLAND         TC      PHASCHNG
                OCT     00035           # GROUP 5:  RETAIN ONLY PIPA TASK
                TC      PHASCHNG
                OCT     05023           # GROUP 3:  PROTECT GUIDANCE WITH PRIO 21
```

```
                OCT     21000           #       JUST HIGHER THAN SERVICER'S PRIORITY

# Page 800
#*****************************************************************
# GUILDENSTERN:  AUTO-MODES MONITOR (R13)
#*****************************************************************

                COUNT*  $$/R13

# HERE IS THE PHILOSOPHY OF GUILDENSTERN:       ON EVERY APPEARANCE OR DISAPPEARANCE OF THE MAN
# DISCRETE TO SELECT P67 OR P66 RESPECTIVELY:   ON EVERY APPEARANCE OF THE ATTITUDE-HOLD DISCRE
# UNLESS THE CURRENT PROGRAM IS P67 IN WHICH CASE THERE IS NO CHANGE

GUILDEN         EXTEND                  # IS UN-AUTO-THROTTLE DISCRETE PRESENT?
# STERN                                 # RSB 2009: Not originally a comment.
                READ CHAN30
                MASK    BIT5
                CCS     A
                TCF     STARTP67        # YES
P67NOW?         TC      CHECKMM         # NO:  ARE WE IN P67 NOW?
                DEC     67
                TCF     STABL?          # NO
STARTP66        TC      FASTCHNG        # YES
                TC      NEWMODEX
DEC66           DEC     66
                EXTEND
                DCA     HDOTDISP        # SET DESIRED ALTITUDE RATE = CURRENT
                DXCH    VDGVERT         #       ALTITUDE RATE.
STRTP66A        TC      INTPRET
                SLOAD   PUSH
                        PBIASZ
                SLOAD   PUSH
                        PBIASY
                SLOAD   VDEF
                        PBIASX
                VXSC    SET
                        BIASFACT
                        RODFLAG
                STOVL   VBIAS
                        TEMX
                VCOMP
                STOVL   OLDPIPAX
                        ZEROVECS
                STODL   DELVROD
                        RODSCALE
                STODL   RODSCAL1
```

```
                        PIPTIME
                STORE   LASTTPIP
                EXIT
                CAF     ZERO
                TS      FCOLD
                TS      FWEIGHT
                TS      FWEIGHT +1
VRTSTART        TS      WCHVERT
# Page 801
                CAF     TWO             # WCHPHASE = 2 ---> VERTICAL: P65,P66,P67
                TS      WCHPHOLD
                TS      WCHPHASE
                TC      BANKCALL        # TEMPORARY, I HOPE HOPE HOPE
                CADR    STOPRATE        # TEMPORARY, I HOPE HOPE HOPE
                TC      DOWNFLAG        # PERMIT X-AXIS OVERRIDE
                ADRES   XOVINFLG
                TC      DOWNFLAG
                ADRES   REDFLAG
                TCF     VERTGUID

STARTP67        TC      NEWMODEX        # NO HARM IN "STARTING" P67 OVER AND OVER
                DEC     67              # SO NO NEED FOR A FASTCHNG AND NO NEED
                CAF     ZERO            # TO SEE IF ALREADY IN P67.
                TS      RODCOUNT
                CAF     TEN
                TCF     VRTSTART

STABL?          CAF     BIT13           # IS UN-ATTITUDE-HOLD DISCRETE PRESENT?
                EXTEND
                RAND    CHAN31
                CCS     A
                TCF     GUILDRET        # YES ALL'S WELL

P66NOW?         CS      MODREG
                AD      DEC66
                EXTEND
                BZF     RESTART?

                CA      RODCOUNT        # NO. HAS THE ROD SWITCH BEEN "CLICKED"?
                EXTEND
                BZF     GUILDRET        # NO. CONTINUE WITH AUTOMATIC LANDING
                TCF     STARTP66        # YES. SWITCH INTO THE ROD MODE.

RESTART?        CA      FLAGWRD1        # HAS THERE BEEN A RESTART?
                MASK    RODFLBIT
                EXTEND
```

```
                BZF     STRTP66A        # YES.  REINITIALIZE BUT LEAVE VDGVERT AS
                                        #       IS.

                TCF     VERTGUID        # NO: CONTINUE WITH R.O.D.

# ******************************************************************************
# INITIALIZATION FOR THIS PASS
# ******************************************************************************

                COUNT*  $$/F2DPS

GUILDRET        CAF     ZERO
                TS      RODCOUNT

# Page 802
 +2             EXTEND
                DCA     TPIP
                DXCH    TPIPOLD

                TC      FASTCHNG

                EXTEND
                DCA     PIPTIME1
                DXCH    TPIP

                EXTEND
                DCA     TTF/8
                DXCH    TTF/8TMP

                CCS     FLPASS0
                TCF     TTFINCR

BRSPOT1         INDEX   WCHPHASE
                TCF     NEWPHASE

# ****************************************************************
# ROUTINES TO START NEW PHASES
# ****************************************************************

P65START        TC      NEWMODEX
                DEC     65
                CS      TWO
                TS      WCHVERT
                TC      DOWNFLAG        # PERMIT X-AXIS OVERRIDE
                ADRES   XOVINFLG
                TCF     TTFINCR
```

```
STARTP64        TC      NEWMODEX
                DEC     64
                CA      DELTTFAP        # AUGMENT TTF/8
                ADS     TTF/8TMP
                CA      BIT12           # ENABLE RUPT10
                EXTEND
                WOR     CHAN13
                TC      DOWNFLAG        # INITIALIZE REDESIGNATION FLAG
                ADRES   REDFLAG


#               (CONTINUE TO TTFINCR)

# ******************************************************************************
# INCREMENT TTF/8, UPDATE LAND FOR LUNAR ROTATION, DO OTHER USEFUL THINGS
# ******************************************************************************
#
#       TTFINCR COMPUTATIONS ARE AS FOLLOWS --
# Page 803
#               TTF/8 UPDATED FOR TIME SINCE LAST PASS:
#                       TTF/8 = TTF/8 + (TPIP - TPIPOLD)/8
#               LANDING SITE VECTOR UPDATED FOR LUNAR ROTATION:
#                       ----              ----   ----                  --
#                       LAND = /LAND/ UNIT(LAND - LAND(TPIP - TPIPOLD) * WM)
#               SLANT RANGE TO LANDING SITE, FOR DISPLAY:
#                                          ----   _
#                       RANGEDSP = ABVAL(LAND - R)

TTFINCR         TC      INTPRET
                DLOAD   DSU
                        TPIP
                        TPIPOLD
                SLR     PUSH            # SHIFT SCALES DELTA TIME TO 2(17) CSECS
                        11D
                VXSC    VXV
                        LAND
                        WM
                BVSU    RTB
                        LAND
                        NORMUNIT
                VXSC    VSL1
                        /LAND/
                STODL   LANDTEMP
                EXIT
```

```
                DXCH    MPAC
                DAS     TTF/8TMP        # NOW HAVE INCREMENTED TTF/8 IN TTF/8TMP

                TC      FASTCHNG

                EXTEND
                DCA     TTF/8TMP
                DXCH    TTF/8

                EXTEND
                DCA     LANDTEMP
                DXCH    LAND
                EXTEND
                DCA     LANDTEMP +2
                DXCH    LAND     +2
                EXTEND
                DCA     LANDTEMP +4
                DXCH    LAND     +4

# Page 804
                TC      TDISPSET
                TC      FASTCHNG        # SINCE REDESIG MAY CHANGE LANDTEMP

BRSPOT2         INDEX   WCHPHASE
                TCF     PREGUIDE

# ******************************************************************
# LANDING SITE PERTURBATION EQUATIONS
# ******************************************************************

REDESIG         CA      FLAGWRD6        # IS REDFLAG SET?
                MASK    REDFLBIT
                EXTEND
                BZF     RGVGCALC        # NO:  SKIP REDESIGNATION LOGIC

                CA      TREDES          # YES:  HAS TREDES REACHED ZERO?
                EXTEND
                BZF     RGVGCALC        # YES:  SKIP REDESIGNATION LOGIC

                INHINT
                CA      ELINCR1
                TS      ELINCR
                CA      AZINCR1
                TS      AZINCR
                TC      FASTCHNG
```

```
                CA      ZERO
                TS      ELINCR1
                TS      AZINCR1
                TS      ELINCR  +1
                TS      AZINCR  +1

                CA      FIXLOC          # SET PD TO 0
                TS      PUSHLOC

                TC      INTPRET
                VLOAD   VSU
                        LAND
                        R               #                 ____   _
                RTB     PUSH            # PUSH DOWN UNIT (LAND - R)
                        NORMUNIT
                VXV     VSL1
                        YNBPIP          #                    ___        ____   _
                VXSC    PDDL            # PUSH DOWN - ELINCR(YNB * UNIT(LAND - R))
                        ELINCR
                        AZINCR
                VXSC    VSU
                        YNBPIP
                VAD     PUSH            # RESULTING VECTOR IS 1/2 REAL SIZE

# Page 805

                DLOAD   DSU             # MAKE SURE REDESIGNATION IS NOT
                        0               #       TOO CLOSE TO THE HORIZON.
                        DEPRCRIT
                BMN     DLOAD
                        REDES1
                        DEPRCRIT
                STORE   0
REDES1          DLOAD   DSU
                        LAND
                        R
                DDV     VXSC
                        0
                VAD     UNIT
                        R
                VXSC    VSL1
                        /LAND/
                STORE   LANDTEMP
                EXIT                    # LOOKANGL WILL BE COMPUTED AT RGVGCALC

                TC      FASTCHNG
```

```
                EXTEND
                DCA     LANDTEMP
                DXCH    LAND
                EXTEND
                DCA     LANDTEMP +2
                DXCH    LAND +2
                EXTEND
                DCA     LANDTEMP +4
                DXCH    LAND +4

                TCF     RGVGCALC

# ******************************************************************
# COMPUTE STATE IN GUIDANCE COORDINATES
# ******************************************************************
#
#       RGVGCALC COMPUTATIONS ARE AS FOLLOWS:--
#       VELOCITY RELATIVE TO THE SURFACE:
#               _______   _   _   __
#               ANGTERM = V + R * WM
#       STATE IN GUIDANCE COORDINATES:
#               ___   *   _   ____
#               RGU = CG (R - LAND)
#               ___   *   _   __   _
#               VGU = CG (V - WM * R)
# Page 806 actually starts one line earlier but that would separate the markers from their vari
#
#       HORIZONTAL VELOCITY FOR DISPLAY
#
#               VHORIZ = 8 ABVAL (0, VG , VG )
#                                       2    1
#       DEPRESSION ANGLE FOR DISPLAY:
#                                       _   ____  ______
#               LOOKANGL = ARCSIN(UNIT(R - LAND).XMBPIP)

CALCRGVG        TC      INTPRET         # IN IGNALG, COMPUTE V FROM INTEGRATION
                VLOAD   MXV             #       OUTPUT AND TRIM CORRECTION TERM
                        VATT1           #       COMPUTED LAST PASS AND LEFT IN UNFC/2
                        REFSMMAT
                VSR1    VAD
                        UNFC/2
                STORE   V
                EXIT

RGVGCALC        TC      INTPRET         # ENTER HERE TO RECOMPUTE RG AND VG
```

```
                VLOAD   VXV
                        R
                        WM
                VAD     VSR2            # RESCALE TO UNITS OF 2(9) M/CS
                        V
                STORE   ANGTERM
                MXV
                        CG              # NO SHIFT SINCE ANGTERM IS DOUBLE SIZED
                STORE   VGU
                PDDL    VDEF            # FORM (0,VG ,VG ) IN UNITS OF 2(10) M/CS
                        ZEROVECS        #           2   1
                ABVAL   SL3
                STOVL   VHORIZ          # VHORIZ FOR DISPLAY DURING P65.
                        R               #           _   ____
                VSU     PUSH            # PUSH DOWN R - LAND
                        LAND
                MXV     VSL1
                        CG
                STORE   RGU
                ABVAL
                STOVL   RANGEDSP
                RTB     DOT             # NOW IN MPAC IS SINE(LOOKANGL)/4
                        NORMUNIT
                        XNBPIP
                EXIT

                CA      FIXLOC          # RESET PUSH DOWN POINTER
                TS      PUSHLOC

# Page 807
                CA      MPAC            # COMPUTE LOOKANGLE ITSELF
                DOUBLE
                TC      BANKCALL
                CADR    SPARCSIN -1
                AD      1/2DEG
                EXTEND
                MP      180DEGS
                TS      LOOKANGL        # LOOKANGL FOR DISPLAY DURING P64

BRSPOT3         INDEX   WCHPHASE
                TCF     WHATGUID

# ************************************************************************
# TTF/8 COMPUTATION
# ************************************************************************
```

```
TTF/8CL         TC      INTPRETX
                DLOAD*
                        JDG2TTF,1
                STODL*  TABLTTF +6      # A(3) = 8 JDG  TO TABLTTF
                        ADG2TTF,1       #             2
                STODL   TABLTTF +4      # A(2) = 6 ADG  TO TABLTTF
                        VGU     +4      #             2
                DMP     DAD*
                        3/4DP
                        VDG2TTF,1
                STODL*  TABLTTF +2      # A(1) = (6 VGU  + 18 VDG )/8 TO TABLTTF
                        RDG +4,1        #              2         2
                DSU     DMP
                        RGU +4
                        3/8DP
                STORE   TABLTTF         # A(0) = -24 (RGU  - RDG )/64 TO TABLTTF
                EXIT                    #                2      2

                CA      BIT8
                TS      TABLTTF +10     # FRACTIONAL PRECISION FOR TTF TO TABLE

                EXTEND
                DCA     TTF/8
                DXCH    MPAC            # LOADS TTF/8 (INITIAL GUESS) INTO MPAC
                CAF     TWO             # DEGREE - ONE
                TS      L
                CAF     TABLTTFL
                TC      ROOTPSRS        # YIELDS TTF/8 IN MPAC
                INDEX   WCHPHASE
                TCF     WHATALM

                EXTEND                  # GOOD RETURN
                DCA     MPAC            # FETCH TTF/8 KEEPING IT IN MPAC
                DXCH    TTF/8           # CORRECTED TTF/8

# Page 808
                TC      TDISPSET

#               (CONTINUE TO QUADGUID)

# ******************************************************************************
# MAIN GUIDANCE EQUATION
# ******************************************************************************
#
#       AS PUBLISHED --
#                            ---   --       ---   --
```

```
#               ___   ___   6(VDG + VG)   12(RDG - RG)
#               ACG = ADG + ----------- + ------------
#                                TTF        (TTF)(TTF)
#       AS HERE PROGRAMMED --
#                                ___   __
#                     3 (1/4(RDG - RG)   ___   __)
#                     - (------------- + VDG + VG)
#               ___   4 (    TTF/8               )   ___
#               ACG = ---------------------------- + ADG
#                                  TTF/8

QUADGUID        CS      TTF/8
                AD      LEADTIME        # LEADTIME IS A NEGATIVE NUMBER
                AD      POSMAX          # SAFEGUARD THE COMPUTATIONS THAT FOLLOW
                TS      L               #       BY FORCING -TTF*LEADTIME > OR = ZERO
                CS      L
                AD      L
                ZL
                EXTEND
                DV      TTF/8
                TS      BUF             # - RATIO OF LAG-DIMINISHED TTF TO TTF
                EXTEND
                SQUARE
                TS      BUF +1
                AD      BUF
                XCH     BUF +1          # RATIO SQUARED - RATIO
                AD      BUF +1
                TS      MPAC            # COEFFICIENT FOR VGU TERM
                AD      BUF +1
                INDEX   FIXLOC
                TS      26D             # COEFFICIENT FOR RDG-RGU TERM
                AD      BUF +1
                INDEX   FIXLOC
                TS      28D             # COEFFICIENT FOR VDG TERM
                AD      BUF
                AD      POSMAX
# Page 809
                AD      BUF +1
                AD      BUF +1
                INDEX   FIXLOC
                TS      30D             # COEFFICIENT FOR ADG TERM

                CAF     ZERO
                TS      MODE

                TC      INTPRETX
```

```
                VXSC    PDDL
                        VGU
                        28D
                VXSC*   PDVL*
                        VDG,1
                        RDG,1
                VSU     V/SC
                        RGU
                        TTF/8
                VSR2    VXSC
                        26D
                VAD     VAD
                V/SC    VXSC
                        TTF/8
                        3/4DP
                PDDL    VXSC*
                        30D
                        ADG,1
                VAD
AFCCALC1        VXM     VSL1            # VERGUID COMES HERE
                        CG
                PDVL    V/SC
                        GDT/2
                        GSCALE
                BVSU    STADR
                STORE   UNFC/2          # UNFC/2 NEED NOT BE UNITIZED
                ABVAL
AFCCALC2        STODL   /AFC/           # MAGNITUDE OF AFC FOR THROTTLE
                        UNFC/2          # VERTICAL COMPONENT
                DSQ     PDDL
                        UNFC/2 +2       # OUT-OF-PLANE
                DSQ     PDDL
                        HIGHESTF
                DDV     DSQ
                        MASS            #                        2    2    2
                DSU     DSU             # AMAXHORIZ = SQRT(ATOTAL - A  - A  )
                BPL     DLOAD           #                            1    0
                        AFCCALC3
                        ZEROVECS
AFCCALC3        SQRT    DAD
                        UNFC/2 +4
# Page 810
                BPL     BDSU
                        AFCCLEND
                        UNFC/2 +4
                STORE   UNFC/2 +4
```

```
AFCCLEND        EXIT
                TC      FASTCHNG

                CA      WCHPHASE        # PREPARE FOR PHASE SWITCHING LOGIC
                TS      WCHPHOLD
                INCR    FLPASS0         # INCREMENT PASS COUNTER

BRSPOT4         INDEX   WCHPHASE
                TCF     AFTRGUID

# ********************************************************************
# ERECT GUIDANCE-STABLE MEMBER TRANSFORMATION MATRIX
# ********************************************************************

CGCALC          CAF     EBANK5
                TS      EBANK
                EBANK=  TCGIBRAK
                EXTEND
                INDEX   WCHPHASE
                INDEX   TARGTDEX
                DCA     TCGFBRAK
                INCR    BBANK
                INCR    BBANK
                EBANK=  TTF/8
                AD      TTF/8
                XCH     L
                AD      TTF/8
                CCS     A
                CCS     L
                TCF     EXTLOGIC
                TCF     EXTLOGIC
                NOOP

                TC      INTPRETX
                VLOAD   UNIT
                        LAND
                STODL   CG
                        TTF/8
                DMP*    VXSC
                        GAINBRAK,1      # NUMERO MYSTERIOSO
                        ANGTERM
                VAD
                        LAND
                VSU     RTB
                        R
                        NORMUNIT
```

```
# Page 811
                VXV     RTB
                        LAND
                        NORMUNIT
                STOVL   CG +6           # SECOND ROW
                        CG
                VXV     VSL1
                        CG +6
                STORE   CG +14
                EXIT

#               (CONTINUE TO EXTLOGIC)
#
# ********************************************************************
# PREPARE TO EXIT
# ********************************************************************
#
# DECIDE (1) HOW TO EXIT, AND (2) WHETHER TO SWITCH PHASES
#
EXTLOGIC        INDEX   WCHPHASE        # WCHPHASE = 1   APPRQUAD
                CA      TENDBRAK        # WCHPHASE = 0   BRAKQUAD
                AD      TTF/8

EXSPOT1         EXTEND
                INDEX   WCHPHASE
                BZMF    WHATEXIT

                TC      FASTCHNG

                CA      WCHPHOLD
                AD      ONE
                TS      WCHPHASE
                CA      ZERO
                TS      FLPASS0         # RESET FLPASS0

                INDEX   WCHPHOLD
                TCF     WHATEXIT

# ********************************************************************
# ROUTINES FOR EXITING FROM LANDING GUIDANCE
# ********************************************************************
#
# 1.    EXGSUB IS THE RETURN WHEN GUIDSUB IS CALLED BY THE IGNITION ALGORITHM.
# 2.    EXBRAK IN THE EXIT USED DURING THE BRAKING PHASE.  IN THIS CASE UNIT(R) IS THE WINDOW P
# 3.    EXNORM IS THE EXIT USED AT OTHER TIMES DURING THE BURN.
# (EXOVFLOW IS A SUBROUTINE OF EXBRAK AND EXNORM CALLED WHEN OVERFLOW OCCURRED ANYWHERE IN GUID
```

```
EXGSUB          TC      INTPRET         # COMPUTE TRIM VELOCITY CORRECTION TERM.
# Page 812
                VLOAD   RTB
                        UNFC/2
                        NORMUNIT
                VXSC    VXSC
                        ZOOMTIME
                        TRIMACCL
                STORE   UNFC/2
                EXIT

                CCS     NGUIDSUB
                TCF     GUIDSUB
                CCS     NIGNLOOP
                TCF     +3
                TC      ALARM
                OCT     01412

 +3             TC      POSTJUMP
                CADR    DDUMCALC

EXBRAK          TC      INTPRET
                VLOAD
                        UNIT/R/
                STORE   UNWC/2
                EXIT
                TCF     STEER?

EXNORM          TC      INTPRET
                VLOAD   VSU
                        LAND
                        R
                RTB
                        NORMUNIT
                STORE   UNWC/2          # UNIT(LAND - R) IS TENTATIVE CHOICE
                VXV     DOT
                        XNBPIP
                        CG +6
                EXIT                    # WITH PROJ IN MPAC 1/8 REAL SIZE

                CS      MPAC            # GET COEFFICIENT FOR CG +14
                AD      PROJMAX
                AD      POSMAX
                TS      BUF
                CS      BUF
```

```
                ADS     BUF             # RESULT IS 0 IF PROJMAX - PROJ NEGATIVE

                CS      PROJMIN         # GET COEFFICIENT FOR UNIT(LAND - R)
                AD      MPAC
                AD      POSMAX
                TS      BUF +1
                CS      BUF +1
# Page 813
                ADS     BUF +1          # RESULT IS 0 IF PROJ - PROJMIN NEGATIVE

                CAF     FOUR
UNWCLOOP        MASK    SIX
                TS      Q
                CA      EBANK5
                TS      EBANK
                EBANK=  CG
                CA      BUF
                EXTEND
                INDEX   Q
                MP      CG +14
                INCR    BBANK
                EBANK=  UNWC/2
                INDEX   Q
                DXCH    UNWC/2
                EXTEND
                MP      BUF +1
                INDEX   Q
                DAS     UNWC/2
                CCS     Q
                TCF     UNWCLOOP

                INCR    BBANK
                EBANK=  PIF

STEER?          CA      FLAGWRD2        # IF STEERSW DOWN NO OUTPUTS
                MASK    STEERBIT
                EXTEND
                BZF     RATESTOP

EXVERT          CA      OVFIND          # IF OVERFLOW ANYWHERE IN GUIDANCE
                EXTEND                  #       DON'T CALL THROTTLE OR FINDCDUW
                BZF     +13

EXOVFLOW        TC      ALARM           # SOUND THE ALARM NON-ABORTIVELY
                OCT     01410
```

```
RATESTOP        CAF     BIT13           # ARE WE IN ATTITUDE-HOLD?
                EXTEND
                RAND    CHAN31
                EXTEND
                BZF     DISPEXIT        # YES

                TC      BANKCALL        # NO:  DO A STOPRATE
                CADR    STOPRATE

                TCF     DISPEXIT

GDUMP1          TC      THROTTLE
# Page 814
                TC      INTPRET
                CALL
                        FINDCDUW -2
                EXIT

#               (CONTINUE TO DISPEXIT)

# ********************************************************************
# GUIDANCE LOOP DISPLAYS
# ********************************************************************

DISPEXIT        EXTEND                  # KILL GROUP 3:  DISPLAYS WILL BE
                DCA     NEG0            #       RESTORED BY NEXT GUIDANCE CYCLE.
                DXCH    -PHASE3

 +3             CS      FLAGWRD8        # IF FLUNDISP IS SET, NO DISPLAY THIS PASS
                MASK    FLUNDBIT
                EXTEND
                BZF     ENDLLJOB        # TO PICK UP THE TAG

                INDEX   WCHPHOLD
                TCF     WHATDISP

-2              TC      PHASCHNG        # KILL GROUP 5
                OCT     00035

P63DISPS        CAF     V06N63
DISPCOMN        TC      BANKCALL
                CADR    REGODSPR

ENDLLJOB        TCF     ENDOFJOB

P64DISPS        CA      TREDES          # HAS TREDES REACHED ZERO?
```

```
                EXTEND
                BZF     RED-OVER        # YES: CLEAR REDESIGNATION FLAG

                CS      FLAGWRD6        # NO:  IS REDFLAG SET?
                MASK    REDFLBIT
                EXTEND
                BZF     REDES-OK        # YES:  DO STATIC DISPLAY

                CAF     V06N64          # OTHERWISE USE FLASHING DISPLAY
                TC      BANKCALL
                CADR    REFLASHR
                TCF     GOTOP00H        # TERMINATE
                TCF     P64CEED         # PROCEED       PERMIT REDESIGNATIONS
                TCF     P64DISPS        # RECYCLE
# Page 815
                TCF     ENDLLJOB

P64CEED         CAF     ZERO
                TS      ELINCR1
                TS      AZINCR1

                TC      UPFLAG          # ENABLE REDESIGNATION LOGIC
                ADRES   REDFLAG

                TCF     ENDOFJOB

RED-OVER        TC      DOWNFLAG
                ADRES   REDFLAG
REDES-OK        CAF     V06N64
                TCF     DISPCOMN


VERTDISP        CAF     V06N60
                TCF     DISPCOMN


# ************************************************************************
# GUIDANCE FOR P65
# ************************************************************************

VERTGUID        CCS     WCHVERT
                TCF     P67VERT         # POSITIVE NON-ZERO ---> P67
                TCF     P66VERT         # +0
#
#       THE P65 GUIDANCE EQUATION IS AS FOLLOWS --
#                     ----   ---
```

```
#                       V2FG - VGU
#               ACG = ----------
#                         TAUVERT

P65VERT         TC      INTPRET
                VLOAD   VSU
                        V2FG
                        VGU
                V/SC    GOTO
                        TAUVERT
                        AFCCALC1
# Page 816
# ************************************************************
# GUIDANCE FOR P66
# ************************************************************

P66VERT         TC      POSTJUMP
                CADR    P66VERTA

P67VERT         TC      PHASCHNG        # TERMINATE GROUP 3.
                OCT     00003

                TC      INTPRET
                VLOAD   GOTO
                        V
                        VHORCOMP

                SETLOC  P66LOC
                BANK
                COUNT*  $$/F2DPS

RODTASK         CAF     PRIO22
                TC      FINDVAC
                EBANK=  DVCNTR
                2CADR   RODCOMP

                TCF     TASKOVER

P66VERTA        TC      PHASCHNG        # TERMINATE GROUP 3.
                OCT     00003

                CAF     1SEC
                TC      TWIDDLE
                ADRES   RODTASK

RODCOMP         INHINT
```

```
                CAF     ZERO
                XCH     RODCOUNT
                EXTEND
                MP      RODSCAL1
                DAS     VDGVERT         # UPDATE DESIRED ALTITUDE RATE.

                EXTEND                  # SET OLDPIPAX,Y,Z = PIPAX,Y,Z
                DCA     PIPAX
                DXCH    OLDPIPAX
                DXCH    RUPTREG1        # SET RUPTREG1,2,3 = OLDPIPAX,Y,Z
                CA      PIPAZ
                XCH     OLDPIPAZ
                XCH     RUPTREG3

                EXTEND                  # SNAPSHOT TIME OF PIPA READING.
                DCA     TIME2
# Page 817
                DXCH    THISTPIP

                CA      OLDPIPAX
                AD      PIPATMPX
                TS      MPAC            # MPAC(X) = PIPAX + PIPATMPX
                CA      OLDPIPAY
                AD      PIPATMPY
                TS      MPAC +3         # MPAC(Y) = PIPAY + PIPATMPY
                CA      OLDPIPAZ
                AD      PIPATMPZ
                TS      MPAC +5         # MPAC(Z) = PIPAZ + PIPATMPZ

                CS      OLDPIPAX
                AD      TEMX
                AD      RUPTREG1
                TS      DELVROD
                CS      OLDPIPAY
                AD      TEMY
                AD      RUPTREG2
                TS      DELVROD +2
                CS      OLDPIPAZ
                AD      TEMZ
                AD      RUPTREG3
                TS      DELVROD +4

                CAF     ZERO
                TS      MPAC +1         # ZERO LO-ORDER MPAC COMPONENTS
                TS      MPAC +4
                TS      MPAC +6
```

```
                TS      TEMX            # ZERO TEMX, TEMY, AND TEMZ SO WE WILL
                TS      TEMY            #       KNOW WHEN READACCS CHANGES THEM.
                TS      TEMZ
                CS      ONE
                TS      MODE
                TC      INTPRET
ITRPNT1         VXSC    PDDL            # SCALE MPAC TO M/CS *2(-7) AND PUSH    (6)
                        KPIP1
                        THISTPIP
                DSU
                        PIPTIME
                STORE   30D             # 30-31D CONTAINS TIME IN CS SINCE PIPTIME
                DDV     PDVL            #                                       (8)
                        4SEC(28)
                        GDT/2
                VSU     VXSC            #                                       (6)
                        VBIAS
                VSL2    VAD
                        V
                VAD     STADR           #                                       (0)
                STOVL   24D             # STORE UPDATED VELOCITY IN 24-29D
# Page 818
                        R
                UNIT
                STORE   14D
                DOT     SL1
                        24D
                STODL   HDOTDISP        # UPDATE HDOTDISP RATE FOR NOUN 63.
                        30D
                SL      DMP
                        11D
                        HDOTDISP
                DAD     DSU
                        36D
                        /LAND/
                STODL   HCALC1          # UPDATE HCALC1 FOR NOUN 63.
                        HDOTDISP
                BDSU    DDV
                        VDGVERT
                        TAUROD
                PDVL    ABVAL           #                               (2)
                        GDT/2
                DDV     SR2
                        GSCALE
                STORE   20D
                DAD                     #                               (0)
```

```
                PDVL    CALL            #                               (2)
                        UNITX
                        CDU*NBSM
                DOT
                        14D
                STORE   22D
                BDDV    STADR           #                               (0)
                STOVL   /AFC/
                        DELVROD
                VXSC    VAD
                        KPIP1
                        VBIAS
                ABVAL   PDDL            #                               (2)
                        THISTPIP
                DSU     PDDL            #                               (4)
                        LASTTPIP
                        THISTPIP
                STODL   LASTTPIP        #                               (2)
                DDV     BDDV            #                               (0)
                        SHFTFACT
                PDDL    DMP             #                               (2)
                        FWEIGHT
                        BIT1H
                DDV     DDV
                        MASS
                        SCALEFAC
# Page 819
                DAD     PDDL            #                               (4)
                        0D
                        20D
                DDV     DSU             #                               (2)
                        22D
                DMP     DAD
                        LAG/TAU
                        /AFC/
                PDDL    DDV             #                               (4)
                        MAXFORCE
                        MASS
                PDDL    DDV             #                               (6)
                        MINFORCE
                        MASS
                PUSH    BDSU            #                               (8)
                        2D
                BMN     DLOAD           #                               (6)
                        AFCSPOT
                DLOAD   PUSH            #                               (6)
```

```
                BDSU    BPL
                        2D
                        AFCSPOT
                DLOAD                   #                               (4)
AFCSPOT         DLOAD                   #                               (2), (4), OR
                SETPD                   #                               (2)
                        2D
                STODL   /AFC/           #                               (0)
ITRPNT2         EXIT
                DXCH    MPAC            # MPAC = MEASURED ACCELERATION.
                TC      BANKCALL
                CADR    THROTTLE +3
                TC      INTPRET
                VLOAD                   # PICK UP UPDATED VELOCITY VECTOR.
                        24D
VHORCOMP        VSL2    VAD
                        DELVS
                VSR2    PDVL
                        R
                UNIT    VXSC
                        HDOTDISP
                VSL1    BVSU
                ABVAL
                STORE   VHORIZ
                EXIT
                TC      BANKCALL        # PUT UP V06N60 DISPLAY BUT AVOID PHASCHNG
                CADR    DISPEXIT +3

BIT1H           OCT     00001
SHFTFACT        2DEC    1 B-17
# Page 820
BIASFACT        2DEC    655.36 B-28

# ******************************************************************************
# REDESIGNATOR TRAP
# ******************************************************************************

                BANK    11
                SETLOC  F2DPS*11
                BANK

                COUNT*  $$/F2DPS

PITFALL         XCH     BANKRUPT
                EXTEND
                QXCH    QRUPT
```

```
                TC      CHECKMM         # IF NOT IN P64, NO REASON TO CONTINUE
                DEC     64
                TCF     RESUME

                EXTEND
                READ    CHAN31
                COM
                MASK    ALL4BITS
                TS      ELVIRA
                CAF     TWO
                TS      ZERLINA
                CAF     FIVE
                TC      TWIDDLE
                ADRES   REDESMON
                TCF     RESUME

# REDESIGNATOR MONITOR (INITIATED BY PITFALL)

PREMON1         TS      ZERLINA
PREMON2         CAF     SEVEN
                TC      VARDELAY
REDESMON        EXTEND
                READ    31
                COM
                MASK    ALL4BITS
                XCH     ELVIRA
                TS      L
                CCS     ELVIRA          # DO ANY BITS APPEAR THIS PASS?
                TCF     PREMON2         # Y:    CONTINUE MONITOR

                CCS     L               # N:    ANY LAST PASS?
                TCF     COUNT'EM        #       Y:      COUNT 'EM, RESET RUPT, TERMINATE
# Page 821
                CCS     ZERLINA         #       N:      HAS ZERLINA REACHED ZERO YET?
                TCF     PREMON1         #               N:      DIMINISH ZERLINA, CONTINUE
RESETRPT        CAF     BIT12           #               Y:      RESET RUPT. TERMINATE
                EXTEND
                WOR     CHAN13
                TCF     TASKOVER

COUNT'EM        CAF     BIT13           # ARE WE IN ATTITUDE-HOLD?
                EXTEND
                RAND    CHAN31
                EXTEND
                BZF     RESETRPT        # YES: SKIP REDESIGNATION LOGIC.
```

```
                CA      L               # NO.
                MASK    -AZBIT
                CCS     A
-AZ             CS      AZEACH
                ADS     AZINCR1
                CA      L
                MASK    +AZBIT
                CCS     A
+AZ             CA      AZEACH
                ADS     AZINCR1
                CA      L
                MASK    -ELBIT
                CCS     A
-EL             CS      ELEACH
                ADS     ELINCR1
                CA      L
                MASK    +ELBIT
                CCS     A
+EL             CA      ELEACH
                ADS     ELINCR1
                TCF     RESETRPT

# THESE EQUIVALENCES ARE BASED ON GSOP CHAPTER 4, REVISION 16 OF P64LM

+ELBIT          =       BIT2            # -PITCH
-ELBIT          =       BIT1            # +PITCH
+AZBIT          =       BIT5
-AZBIT          =       BIT6

# Page 822
ALL4BITS        OCT     00063
AZEACH          DEC     .03491          # 2 DEGREES
ELEACH          DEC     .00873          # 1/2 DEGREE

# ***************************************************************
# R.O.D. TRAP
# ***************************************************************

                BANK    20
                SETLOC  RODTRAP
                BANK
                COUNT*  $$/F2DPS        # ************************

DESCBITS        MASK    BIT7            # COME HERE FROM MARKRUPT CODING WITH BIT
                CCS     A               #       7 OR 6 OF CHANNEL 16 IN A; BIT 7 MEAN
```

```
                CS      TWO             #       - RATE INCREMENT, BIT 6 + INCREMENT.
                AD      ONE
                ADS     RODCOUNT
                TCF     RESUME          # TRAP IS RESET WHEN SWITCH IS RELEASED

                BANK    31
                SETLOC  F2DPS*31
                BANK

                COUNT*  $$/F2DPS

# ******************************************************************************
# DOUBLE PRECISION ROOT FINDER SUBROUTINE (BY ALLAN KLUMPP)
# ******************************************************************************
#
#                                                        N        N-1
#       ROOTPSRS FINDS ONE ROOT OF THE POWER SERIES A X  + A   X    + ... + A X + A
#                                                      N      N-1              1     0
# USING NEWTON'S METHOD STARTING WITH AN INITIAL GUESS FOR THE ROOT.  THE ENTERING DATA MUST BE
#       A       SP      LOC-3           ADRES FOR REFERENCING PWR COF TABL
#       L       SP      N-1             N IS THE DEGREE OF THE POWER SERIES
#       MPAC    DP      X               INITIAL GUESS FOR ROOT
#
#       LOC-2N  DP      A(0)
#               ...
#       LOC     DP      A(N)
#       LOC+2   SP      PRECROOT         PREC RQD OF ROOT (AS FRACT OF 1ST GUESS)
#
# Page 823
# THE DP RESULT IS LEFT IN MPAC UPON EXIT, AND A SP COUNT OF THE ITERATIONS TO CONVERGENCE IS L
# RETURN IS NORMALLY TO LOC(TC ROOTPSRS)+3.  IF ROOTPSRS FAILS TO CONVERGE TO IN 8 PASSES, RETU
# OUTPUTS ARE NOT TO BE TRUSTED.
#
# PRECAUTION:  ROOTPSRS MAKES NO CHECKS FOR OVERFLOW OR FOR IMPROPER USAGE.  IMPROPER USAGE COU
# PRECLUDE CONVERGENCE OR REQUIRE EXCESSIVE ITERATIONS.  AS A SPECIFIC EXAMPLE, ROOTPSRS FORMS
# COEFFICIENT TABLE BY MULTIPLYING EACH A(I) BY I, WHERE I RANGES FROM 1 TO N.  IF AN ELEMENT O
# COEFFICIENT TABLE = 1 OR >1 IN MAGNITUDE, ONLY THE EXCESS IS RETAINED.  ROOTPSRS MAY CONVERGE
# ROOT NONETHELESS, BUT IT MAY TAKE AN EXCESSIVE NUMBER OF ITERATIONS.  THEREFORE THE USER SHOU
#       1.  USER'S RESPONSIBILITY TO ASSUR THAT I X A(I) < 1 IN MAGNITUDE FOR ALL I.
#       2.  USER'S RESPONSIBILITY TO ASSURE OVERFLOW WILL NOT OCCUR IN EVALUATING EITHER THE RE
#           POWER SERIES.  THIS OVERFLOW WOULD BE PRODUCED BY SUBROUTINE POWRSERS, CALLED BY RO
#           PRECLUDE EVENTUAL CONVERGENCE.
#       3.  AT PRESENT, ERASABLE LOCATIONS ARE RESERVED ONLY FOR N UP TO 5.  AN N IN EXCESS OF
#           ALL ERASABLES USED BY ROOTPSRS ARE UNSWITCHED LOCATED IN THE REGION FROM MPAC-33 OC
#       4.  THE ITERATION COUNT RETURNED IN MPAC+2 MAY BE USED TO DETECT ABNORMAL PERFORMANCE.
```

```
                                        # STORE ENTERING DATA, INITIALIZE ERASABLES
ROOTPSRS        EXTEND
                QXCH    RETROOT         # RETURN ADRES
                TS      PWRPTR          # PWR TABLE POINTER
                DXCH    MPAC +3         # PWR TABLE ADRES, N-1
                CA      DERTABLL
                TS      DERPTR          # DER TABL POINTER
                TS      MPAC +5         # DER TABL ADRES
                CCS     MPAC +4         # NO POWER SERIES DEGREE 1 OR LESS
                TS      MPAC +6         # N-2
                CA      ZERO            # MODE USED AS ITERATION COUNTER.  MODE
                TS      MODE            # MUST BE POS SO ABS WON'T COMP MPAC+3 ETC.

                                        # COMPUTE CRITERION TO STOP ITERATING
                EXTEND
                DCA     MPAC            # FETCH ROOT GUESS, KEEPING IT IN MPAC
                DXCH    ROOTPS          # AND IN ROOTPS
                INDEX   MPAC +3         # PWR TABLE ADRES
                CA      5               # PRECROOT TO A
                TC      SHORTMP         # YIELDS DP PRODUCT IN MPAC
                TC      USPRCADR
                CADR    ABS             # YIELDS ABVAL OF CRITERION ON DX IN MPAC
                DXCH    MPAC
                DXCH    DXCRIT          # CRITERION

                                        # SET UP DER COF TABL
# Page 824
                EXTEND
                INDEX   PWRPTR
                DCA     3
                DXCH    MPAC            # A(N) TO MPAC

                CA      MPAC +4         # N-1 TO A

DERCLOOP        TS      PWRCNT          # LOOP COUNTER
                AD      ONE
                TC      DMPNSUB         # YIELDS DERCOF = I X A(I) IN MPAC
                EXTEND
                INDEX   PWRPTR
                DCA     1
                DXCH    MPAC            # (I-1) TO MPAC, FETCHING DERCOF
                INDEX   DERPTR
                DXCH    3               # DERCOF TO DER TABLE
                CS      TWO
                ADS     PWRPTR          # DECREMENT PWR POINTER
                CS      TWO
```

```
                ADS     DERPTR          # DECREMENT DER POINTER
                CCS     PWRCNT
                TCF     DERCLOOP

                                        # CONVERGE ON ROOT
ROOTLOOP        EXTEND
                DCA     ROOTPS          # FETCH CURRENT ROOT
                DXCH    MPAC            # LEAVE IN MPAC
                EXTEND
                DCA     MPAC +5         # LOAD A, L WITH DER TABL ADRES, N-2
                TC      POWRSERS        # YIELDS DERIVATIVE IN MPAC

                EXTEND
                DCA     ROOTPS
                DXCH    MPAC            # CURRENT ROOT TO MPAC, FETCHING DERIVATIVE
                DXCH    BUF             # LEAVE DERIVATIVE IN BUF AS DIVISOR
                EXTEND
                DCA     MPAC +3         # LOAD A, L WITH PWR TABL ADRES, N-1
                TC      POWRSERS        # YIELDS RESIDUAL IN MPAC

                TC      USPRCADR
                CADR    DDV/BDDV        # YIELDS -DX IN MPAC

                EXTEND
                DCS     MPAC            # FETCH DX, LEAVING -DX IN MPAC
                DAS     ROOTPS          # CORRECTED ROOT NOW IN ROOTPS

                TC      USPRCADR
                CADR    ABS             # YIELDS ABS(DX) IN MPAC
                EXTEND
# Page 825
                DCS     DXCRIT
                DAS     MPAC            # ABS(DX)-ABS(DXCRIT) IN MPAC

                CA      MODE
                MASK    BIT4            # KLUMPP SAYS GIVE UP AFTER EIGHT PASSES
                CCS     A
BADROOT         TC      RETROOT

                INCR    MODE            # INCREMENT ITERATION COUNTER
                CCS     MPAC            # TEST HI ORDER DX
                TCF     ROOTLOOP
                TCF     TESTLODX
                TCF     ROOTSTOR
TESTLODX        CCS     MPAC +1         # TEST LO ORDER DX
                TCF     ROOTLOOP
```

```
                TCF     ROOTSTOR
                TCF     ROOTSTOR
ROOTSTOR        DXCH    ROOTPS
                DXCH    MPAC
                CA      MODE
                TS      MPAC +2         # STORE SP ITERATION COUNT IN MPAC+2
                INDEX   RETROOT
                TCF     2

DERTABLL        ADRES   DERCOFN -3

# ****************************************************************************
# TRASHY LITTLE SUBROUTINES
# ****************************************************************************

INTPRETX        INDEX   WCHPHASE        # SET X1 ON THE WAY TO THE INTERPRETER
                CS      TARGTDEX
                INDEX   FIXLOC
                TS      X1
                TCF     INTPRET

TDISPSET        CA      TTF/8
                EXTEND
                MP      TSCALINV
                DXCH    TTFDISP

                CA      EBANK5          # TREDES BECOMES ZERO TWO PASSES
                TS      EBANK           #       BEFORE TCGFAPPR IS REACHED
                EBANK=  TCGFAPPR
                CA      TCGFAPPR
                INCR    BBANK
                INCR    BBANK
                EBANK=  TTF/8
# Page 826
                AD      TTF/8
                EXTEND
                MP      TREDESCL
                AD      -DEC103
                AD      NEGMAX
                TS      L
                CS      L
                AD      L
                AD      +DEC99
                AD      POSMAX
                TS      TREDES
                CS      TREDES
```

```
                ADS     TREDES
                TC      Q

1406P00         TC      P00DOO
                OCT     01406
1406ALM         TC      ALARM
                OCT     01406
                TCF     RATESTOP

# ******************************************************************
# SPECIALIZED "PHASCHNG" SUBROUTINE
# ******************************************************************

                EBANK=  PHSNAME2
FASTCHNG        CA      EBANK3          # SPECIALIZED 'PHASCHNG' ROUTINE
                XCH     EBANK
                DXCH    L
                TS      PHSNAME3
                LXCH    EBANK
                EBANK=  E2DPS
                TC      A

# ********************************************************************************
# PARAMETER TABLE INDIRECT ADDRESSES
# ********************************************************************************

RDG             =       RBRFG
VDG             =       VBRFG
ADG             =       ABRFG
VDG2TTF         =       VBRFG*
ADG2TTF         =       ABRFG*
JDG2TTF         =       JBRFG*

# ********************************************************************************
# LUNAR LANDING CONSTANTS
# ********************************************************************************

# Page 827
TABLTTFL        ADRES   TABLTTF +3      # ADDRESS FOR REFERENCING TTF TABLE
TTFSCALE        =       BIT12
TSCALINV        =       BIT4
-DEC103         DEC     -103
+DEC99          DEC     +99
TREDESCL        DEC     -.08
180DEGS         DEC     +180
1/2DEG          DEC     +.00278
```

```
PROJMAX         DEC     .42262 B-3      # SIN(25')/8 TO COMPARE WITH PROJ
PROJMIN         DEC     .25882 B-3      # SIN(15')/8 TO COMPARE WITH PROJ
V06N63          VN      0663            # P63
V06N64          VN      0664            # P64
V06N60          VN      0660            # P65, P66, P67

                BANK    22
                SETLOC  LANDCNST
                BANK
                COUNT*  $$/F2DPS

HIGHESTF        2DEC    4.34546769 B-12
GSCALE          2DEC    100 B-11
3/8DP           2DEC    .375
3/4DP           2DEC    .750
DEPRCRIT        2DEC    -.02 B-1

# Page 828
# ******************************************************************************
# ******************************************************************************
```

Uses -PHASE3 152, A 80, BANKRUPT 80, BBANK 80, BUF 142, CHAN13 87, CHAN30 87, CHAN31 87, COF 219, COUNT 142, D 226, DISPLAYS 59, DV 241, DVCNTR 224, EBANK 80, FIXLOC 140, FLAGWRD1 97, FLAGWRD2 101, FLAGWRD6 117, FLAGWRD8 125, GDT/2 159, HDOTDISP 221, HORIZON 190, I 206, IT 185, L 80, LOC 145, MASS 200, MODE 145, MODREG 154, MPAC 145, N 206, OVFIND 140, PBIASX 167, PBIASY 167, PBIASZ 167, PHASE3 152, PHSNAME2 167, PHSNAME3 167, PIPAX 80, PIPAY 80, PIPAZ 80, PIPTIME 159, PIPTIME1 159, PRIORITY 145, PUSHLOC 145, Q 80, QRUPT 80, RANGE 179, REFSMMAT 172, RESTART 57, RUPTREG1 138, RUPTREG2 138, RUPTREG3 138, STATE 138, STEERBIT 103, STEERSW 103, TAU 211, TC 169, TEMX 159, TEMY 159, TEMZ 159, TIME2 80, UN 188, V 229, VG 234, VN 159, X1 85, YNB 186, and Z 80.

4.21 p70-p71 routines

2343 ⟨*p70-p71 routines* 2343⟩≡ (2041 2768)

```
# Page 829
                BANK    21
                SETLOC  R11
                BANK

                EBANK=  DVCNTR
                COUNT*  $$/R11

R10,R11         CS      FLAGWRD7        # IS SERVICER STILL RUNNING?
                MASK    AVEGFBIT
                CCS     A
                TCF     TASKOVER        # LET AVGEND TAKE CARE OF GROUP 2.
                CCS     PIPCTR
                TCF     +2
                TCF     LRHTASK         # LAST PASS. CALL LRHTASK.
 +2             TS      PIPCTR1

PIPCTR1         =       LADQSAVE
PIPCTR          =       PHSPRDT2
                CAF     OCT31
                TC      TWIDDLE
                ADRES   R10,R11
R10,R11A        CS      IMODES33        # IF LAMP TEST, DO NTO CHANGE LR LITES
                MASK    BIT1
                EXTEND
                BZF     10,11

FLASHH?         MASK    FLGWRD11        # C(A) = 1 - HFLASH BIT
                EXTEND
                BZF     FLASHV?         # H FLASH OFF, SO LEAVE ALONE

                CA      HLITE
                TS      L
                TC      FLIP            # FLIP H LITE

FLASHV?         CA      VFLSHBIT        # VLASHBIT MUST BE BIT 2.
                MASK    FLGWRD11
                EXTEND
                BZF     10,11           # V FLASH OFF

                CA      VLITE
                TS      L
                TC      FLIP            # FLIP V LITE
```

```
10,11           CA      FLAGWRD9        # IS THE LETABORT FLAG SET ?
                MASK    LETABBIT
                EXTEND
                BZF     LANDISP         # NO. PROCEED TO R10.

P71NOW?         CS      MODREG          # YES.  ARE WE IN P71 NOW?
# Page 830
                AD      1DEC71
                EXTEND
                BZF     LANDISP         # YES.  PROCEED TO R10.

                EXTEND                  # NO. IS AN ABORT STAGE COMMANDED?
                READ    CHAN30
                COM
                TS      L
                MASK    BIT4
                CCS     A
                TCF     P71A            # YES.

P70NOW?         CS      MODREG          # NO. ARE WE IN P70 NOW?
                AD      1DEC70
                EXTEND
                BZF     LANDISP         # YES.  PROCEED TO R10.

                CA      L               # NO.  IS AN ABORT COMMANDED?
                MASK    BIT1
                CCS     A
                TCF     P70A            # YES.
                TCF     LANDISP         # NO.  PROCEED TO R10.

                COUNT*  $$/P70

P70             TC      LEGAL?
P70A            CS      ZERO
                TCF     +3
P71             TC      LEGAL?
P71A            CAF     TWO
 +3             TS      Q
                INHINT
                EXTEND
                DCA     CNTABTAD
                DTCB

                EBANK=  DVCNTR
CNTABTAD        2CADR   CONTABRT
```

```
1DEC70          DEC     70
1DEC71          DEC     71

                BANK    05
                SETLOC  ABORTS1
                BANK
                COUNT*  $$/P70

CONTABRT        CAF     ABRTJADR
                TS      BRUPT
                RESUME
# Page 831

ABRTJADR        TCF     ABRTJASK

ABRTJASK        CAF     OCTAL27
                AD      Q
                TS      L
                COM
                DXCH    -PHASE4
                INDEX   Q
                CAF     MODE70
                TS      MODREG

                TS      DISPDEX         # INSURE DISPDEX IS POSITIVE.

                CCS     Q               # SET APSFLAG IF P71.
                CS      FLGWRD10        # SET APSFLAG PRIOR TO THE ENEMA.
                MASK    APSFLBIT
                ADS     FLGWRD10
                CS      DAPBITS         # DAPBITS = OCT 640 = BITS 6, 8, 9
                MASK    DAPBOOLS        # (TURN OFF ULLAGE, DRIFT, AND XOVINHIB
                TS      DAPBOOLS

                CS      FLAGWRD5        # SET ENGONFLG.
                MASK    ENGONBIT
                ADS     FLAGWRD5

                CS      PRIO30          # INSURE THAT THE ENGINE IS ON, IF ARMED.
                EXTEND
                RAND    DSALMOUT
                AD      BIT13
                EXTEND
                WRITE   DSALMOUT
```

```
                CAF     LRBYBIT         # TERMINATE R12.
                TS      FLGWRD11

                CS      FLAGWRD0        # SET R10FLAG TO SUPPRESS OUTPUTS TO THE
                MASK    R10FLBIT        # CROSS-POINTER DISPLAY.
                ADS     FLAGWRD0        # THE FOLLOWING ENEMA WILL REMOVE THE
                                        # DISPLAY INERTIAL DATA OUTBIT.
                TC      CLRADMOD        # INSURE RADMODES PROPERLY SET FOR R29.

                EXTEND                  # LOAD TEVENT FOR THE DOWNLINK.
                DCA     TIME2
                DXCH    TEVENT

                EXTEND
                DCA     SVEXITAD
                DXCH    AVGEXIT

# Page 832
                EXTEND
                DCA     NEG0
                DXCH    -PHASE1

                EXTEND
                DCA     NEG0
                DXCH    -PHASE3

                EXTEND
                DCA     NEG0
                DXCH    -PHASE6

                CAF     THREE           # SET UP 4.3SPOT FOR GOABORT
                TS      L
                COM
                DXCH    -PHASE4

# the 3 in OCT37774 could be something else, garbled
                CAF     OCT37774        # SET T5RUPT TO CALL DAPIDLER IN
                TS      TIME5           # 40 MILLISECONDS.

                TC      POSTJUMP
                CADR    ENEMA

                EBANK=  DVCNTR
SVEXITAD        2CADR   SERVEXIT

MODE70          DEC     70
```

```
OCTAL27         OCT     27
MODE71          DEC     71

DAPBITS         OCT     00640

                BANK    32
                SETLOC  ABORTS
                BANK

                COUNT*  $$/P70

GOABORT         TC      INTPRET
                CALL
                        INITCDUW
                EXIT
                CAF     FOUR
                TS      DVCNTR

                CAF     WHICHADR
                TS      WHICH

                TC      DOWNFLAG
                ADRES   FLRCS
# Page 833
                TC      DOWNFLAG
                ADRES   FLUNDISP

                TC      DOWNFLAG
                ADRES   IDLEFLAG

                TC      UPFLAG          # INSURE 4-JET TRANSLATION CAPABILITY.
                ADRES   ACC4-2FL

                TC      CHECKMM
70DEC           DEC     70
                TCF     P71RET

P70INIT         TC      INTPRET
                CALL
                        TGOCOMP
                DLOAD   SL
                        MDOTDPS
                        4D
                BDDV
                        MASS
                STODL   TBUP
```

```
                        MASS
                DDV     SR1
                        K(1/DV)
                STORE   1/DV1
                STORE   1/DV2
                STORE   1/DV3
                BDDV
                        K(AT)
                STODL   AT
                        DTDECAY
                DCOMP   SL
                        11D
                STORE   TTO
                SLOAD   DCOMP
                        DPSVEX
                SR2
                STORE   VE              # INITIALIZE DPS EXHAUST VELOCITY
                SET     CALL
                        FLAP
                        COMMINIT
                AXC,1   GOTO            # RETURN HERE IN P70, SET X1 FOR DPS COEFF.
                        OD
                        BOTHPOLY
INJTARG         AXC,1                   # RETURN HERE IN P71, SET X1 FOR APS COEFF.
                        8D
BOTHPOLY        DLOAD*  DMP             # TGO D
                        ABTCOF,1
                        TGO
# Page 834
                DAD*    DMP
                        ABTCOF +2,1     #       TGO(C+TGO )
                        TGO
                DAD*    DMP
                        ABTCOF +4,1     # TGO(B+TGO d))
                        TGO
                DAD*
                        ABTCOF +6,1     # A+TGO(B+TGO(C+TGO D))
                STORE   ZDOTD           # STORE TENTATIVELY IN ZDOTD
                DSU     BPL             # CHECK AGAINST MINIMUM
                        VMIN
                        UPRATE          # IF BIG ENOUGH, LEAVE ZDOTD AS IS .
                DLOAD
                        VMIN
                STORE   ZDOTD           # IF TOO SMALL, REPLCAE WITH MINIMUM.
UPRATE          DLOAD
                        ABTRDOT
```

```
                STCALL  RDOTD           # INITIALZE RDOTD.
                        YCOMP           # COMPUTE Y
                ABS     DSU
                        YLIM            # /Y/-DYMAX
                BMN     SIGN            # IF <0, XR<.5DEG, LEAVE YCO AT 0
                        YOK             # IF >0, FIX SIGN OF DEFICIT.  THIS IS YCO.
                        Y
                STORE   YCO
YOK             DLOAD   DSU
                        YCO
                        Y               # COMPUTE XRANGE IN CASE ASTRONAUT WANTS
                SR
                        5D
                STORE   XRANGE          # TO LOOK.
UPTHROT         SET     EXIT
                        FLVR

                TC      UPFLAG          # SET ROTFLAG
                ADRES   ROTFLAG

                TC      THROTUP

                TC      PHASCHNG
                OCT     04024

-3              TC      BANKCALL        # VERIFY THAT THE PANEL SWITCHES
                CADR    P40AUTO         # ARE PROPERLY SET.

                TC      THROTUP

UPTHROT1        EXTEND                  # SET SERVICER TO CALL ASCENT GUIDANCE.
                DCA     ATMAGAD
                DXCH    AVGEXIT
# Page 835
GRP4OFF         TC      PHASCHNG        # TERMINATE USE OF GROUP 4.
                OCT     00004

                TCF     ENDOFJOB

P71RET          TC      DOWNFLAG
                ADRES   LETABORT

                CAF     THRESH2         # SET DVMON THRESHOLD TO THE ASCENT VALUE.
                TS      DVTHRUSH

                TC      INTPRET
```

```
                BON     CALL
                        FLAP
                        OLDTIME
                        TGOCOMP         # IF FLAP=0, TGO=T-TIG
                SSP     GOTO
                        QPRET
                CADR    INJTARG
                        P12INIT         # WILL EXIT P12INIT TO INJTARG
OLDTIME         DLOAD   SL1             # IF FLAP=1,GTO=2 TGO
                        TGO
                STCALL  TGO1
                        P12INIT
                EXIT
                TC      PHASCHNG
                OCT     04024

                EXTEND
                DCA     TGO1
                DXCH    TGO
                TCF     UPTHROT1 -3

TGO1            =       VGBODY
# ************************************************************************

                BANK    21
                SETLOC  R11
                BANK
                COUNT*  $$/P70

LEGAL?          CS      MMNUMBER        # IS THE DESIRED PGM ALREADY IN PROGRESS?
                AD      MODREG
                EXTEND
                BZF     ABORTALM

                CS      FLAGWRD9        # ARE THE ABORTS ENABLED?
                MASK    LETABBIT
                CCS     A
# Page 836
                TCF     ABORTALM

                CA      FLAGWRD7        # IS SERVICER ON THE AIR?
                MASK    AVEGFBIT
                CCS     A
                TC      Q               # YES. ALL IS WELL.
ABORTALM        TC      FALTON
                TC      RELDSP
```

```
                TC      POSTJUMP
                CADR    PINBRNCH

                BANK    32
                SETLOC  ABORTS
                BANK

                COUNT*  $$/P70

# ******************************************************************

TGOCOMP         RTB     DSU
                        LOADTIME
                        TIG
                SL
                        11D
                STORE   TGO
                RVQ

# *******************************************************************

THROTUP         CAF     BIT13
                TS      THRUST
                CAF     BIT4
                EXTEND
                WOR     CHAN14
                TC      Q

# *******************************************************************

10SECS          2DEC    1000
HINJECT         2DEC    18288 B-24      # 60,000 FEET EXPRESSED IN METERS.
(TGO)A          2DEC    37000 B-17
K(AT)           2DEC    .02             # SCALING CONSTANT
WHICHADR        REMADR  ABRTABLE

# *******************************************************************
# Page 837
                EBANK=  DVCNTR
ATMAGAD         2CADR   ATMAG
ORBMANAD        ADRES   ORBMANUV
```

Uses -PHASE1 152, -PHASE3 152, -PHASE4 152, -PHASE6 152, A 80, AVGEXIT 159, BRUPT 80, CHAN14 87, CHAN30 87, COUNT 142, D 226, DISPDEX 165, DSALMOUT 87, DV 241, DVCNTR 224, EBANK 80, ENGONBIT 115, ENGONFLG 115, FLAGWRD0 95, FLAGWRD5 113, FLAGWRD7 121, FLGWRD10 133, FLGWRD11 135, H 177, IMODES33 163, L 80, MASS 200, MMNUMBER 152,

MODREG 154, PHASE1 152, PHASE3 152, PHASE4 152, PHASE6 152, PHSPRDT2 154, PIPCTR 159, Q 80, QPRET 85, SR 80, TC 169, TEVENT 163, TGO 224, THRUST 85, TIG 224, TIME2 80, TIME5 80, V 229, VGBODY 238, and X1 85.

4.22 p12 routine

2353 ⟨*p12 routine* 2353⟩≡ (2041 2751)

```
# Page 838
                BANK    24
                SETLOC  P12
                BANK

                EBANK=  DVCNTR
                COUNT*  $$/P12

P12LM           TC      PHASCHNG
                OCT     04024

                TC      BANKCALL
                CADR    R02BOTH         # CHECK THE STATUS OF THE IMU.

                TC      UPFLAG
                ADRES   MUNFLAG

                TC      UPFLAG          # INSURE 4-JET TRANSLATION CAPABILITY.
                ADRES   ACC4-2FL

                TC      UPFLAG          # PREVENT R10 FROM ISSUING CROSS-POINTER
                ADRES   R10FLAG         # OUTPUTS.

                TC      CLRADMOD        # INITIALIZE RADMODES FOR R29.

                TC      DOWNFLAG        # CLEAR RENDEZVOUS FLAG FOR P22
                ADRES   RNDVZFLG

                CAF     THRESH2         # INITIALIZE DVMON
                TS      DVTHRUSH
                CAF     FOUR
                TS      DVCNTR

                CA      ZERO
                TS      TRKMKCNT        # SHOW THAT R29 DOWNLINK DATA IS NOT READY.
                CAF     V06N33A
                TC      BANKCALL        # FLASH TIG
                CADR    GOFLASH
                TCF     GOTOP00H
                TCF     +2              # PROCEED
                TCF     -5              # ENTER

                TC      PHASCHNG
```

```
                OCT     04024

                TC      INTPRET
                CALL                    # INITIALZE WM AND /LAND/
                        GUIDINIT
                SET     CALL
                        FLPI
                        P12INIT
# Page 839
P12LMB          DLOAD
                        (TGO)A          # SET TGO TO AN INITIAL NOMINAL VALUE.
                STODL   TGO
                        TIG
                STCALL  TDEC1
                        LEMPREC         # ROTATE THE STATE VECTORS TO THE
                VLOAD   MXV             # IGNITION TIME.
                        VATT
                        REFSMMAT
                VSL1
                STOVL   V1S             # COMPUTE V1S = VEL(TIG)*2(-7) M/CS.
                        RATT
                MXV     VSL6
                        REFSMMAT
                STCALL  R               # COMPUTE R = POS(TIG)*2(-24) M.
                        MUNGRAV         # COMPUTE GDT1/2(TIG)*2(-T)M/CS.
                VLOAD   UNIT
                        R
                STCALL  UNIT/R/         # COMPUTE UNIT/R/ FOR YCOMP.
                        YCOMP
                SR      DCOMP
                        5D
                STODL   XRANGE          # INITIALIZE XRANGE FOR NOUN 76
                        VINJNOM
                STODL   ZDOTD
                        RDOTDNOM
                STORE   RDOTD
                EXIT

                TC      PHASCHNG
                OCT     04024

NEWLOAD         CAF     V06N76          # FLASH CROSS-RANGE, AND APOLUNE VALUES.
                TC      BANKCALL
                CADR    GOFLASH
                TCF     GOTOP00H
                TCF     +2              # PROCEED
```

```
                TCF     NEWLOAD         # ENTER NEW DATA.

                CAF     P12ADRES
                TS      WHICH

                TC      PHASCHNG
                OCT     04024

                TC      INTPRET
                DLOAD   SL
                        XRANGE
                        5D
                DAD
# Page 840
                        Y
                STOVL   YCO
                        UNIT/R/
                VXSC    VAD
                        49FPS
                        V1S
                STORE   V               # V(TIPOVER) = V(IGN) + 57FPS (UNIT/R/)
                DOT     SL1
                        UNIT/R/
                STOVL   RDOT            # RDOT = 2(-7)
                        UNIT/R/
                VXV     UNIT
                        QAXIS
                STORE   ZAXIS1
                SETGO
                        FLVR
                        ASCENT
P12RET          DLOAD
                        ATP             # ATP(2)*2(18)
                DSQ     PDDL
                        ATY             # ATY(2)*2(18)
                DSQ     DAD
                BZE     SQRT
                        YAWDUN
                SL1     BDDV
                        ATY
                ARCSIN
YAWDUN          STOVL   YAW
                        UNFC/2
                UNIT    DOT
                        UNIT/R/
                SL1     ARCCOS
```

```
                DCOMP
                STORE   PITCH
                EXIT
                TC      PHASCHNG
                OCT     04024

                TC      DOWNFLAG
                ADRES   FLPI

                INHINT
                TC      IBNKCALL
                CADR    PFLITEDB
                RELINT

                TC      POSTJUMP
                CADR    BURNBABY

P12INIT         DLOAD                   # INITIALIZE ENGINE DATA.  USED FOR P12 AND
# Page 841
                        (1/DV)A         # P71.
                STORE   1/DV3
                STORE   1/DV2
                STODL   1/DV1
                        (AT)A
                STODL   AT
                        (TBUP)A
                STODL   TBUP
                        ATDECAY
                DCOMP   SL
                        11D
                STORE   TTO
                SLOAD   DCOMP
                        APSVEX
                SR2
                STORE   VE
                BOFF    RVQ
                        FLAP
                        COMMINIT
COMMINIT        DLOAD   DAD             # INITIALIZE TARGET DATA.  USED BY P12, P70
                        HINJECT         # AND P71 IF IT DOES NOT FOLLOW P70.
                        /LAND/
                STODL   RCO
                        HI6ZEROS
                STORE   TXO
                STORE   YCO
                STORE   RDOTD
```

```
                STOVL   YDOTD
                        VRECTCSM
                VXV     MXV
                        RRECTCSM
                        REFSMMAT
                UNIT
                STORE   QAXIS
                RVQ
P12ADRES        REMADR  P12TABLE

                SETLOC  P12A
                BANK
                COUNT*  $$/P12

GUIDINIT        STQ     SETPD
                        TEMPR60
                        OD
                VLOAD   PUSH
                        UNITZ
                RTB     PUSH
                        LOADTIME
                CALL
                        RP-TO-R
# Page 842
                MXV     VXSC
                        REFSMMAT
                        MOONRATE
                STOVL   WM
                        RLS
                ABVAL   SL3
                STCALL  /LAND/
                        TEMPR60

49FPS           2DEC    .149352 B-6     # EXPECTED RDOT AT TIPOVER
VINJNOM         2DEC    16.7924 B-7     # 5509.5 FPS(APO=30NM WITH RDOT=19.5FPS)
RDOTDNOM        2DEC    .059436 B-7     # 19.5 FPS
```

Uses A 80, COUNT 142, DV 241, DVCNTR 224, EBANK 80, GDT1/2 159, HI6ZEROS 71, IT 185, RANGE 179, RDOT 229, REFSMMAT 172, RLS 175, RNDVZFLG 97, RRECTCSM 172, SR 80, STATE 138, TC 169, TEMPR60 157, TGO 224, TIG 224, TRKMKCNT 157, V 229, VEL 226, and VRECTCSM 172.

4.23 ascent guidance

2358 ⟨*ascent guidance* 2358⟩≡ (2041)

⟨*Page LM0843* 2359⟩
⟨*Page LM0844* 2360⟩
⟨*Page LM0845* 2361⟩
⟨*Page LM0846* 2363⟩
⟨*Page LM0847* 2365⟩
⟨*Page LM0848* 2367⟩
⟨*Page LM0849* 2369⟩
⟨*Page LM0850* 2371⟩
⟨*Page LM0851* 2373⟩
⟨*Page LM0852* 2375⟩
⟨*Page LM0853* 2377⟩
⟨*Page LM0854* 2379⟩
⟨*Page LM0855* 2380⟩
⟨*Page LM0856* 2381⟩

2359 ⟨*Page LM0843* 2359⟩≡ (2358 2647)

```
                BANK     34
                SETLOC   ASCFILT
                BANK

                EBANK=   DVCNTR

                COUNT*   $$/ASENT

ATMAG           TC       PHASCHNG
                OCT      00035
                TC       INTPRET
                BON
                         FLRCS
                         ASCENT
                DLOAD    DSU
                         ABDVCONV
                         MINABDV
                BMN      CLEAR
                         ASCTERM4
                         SURFFLAG
                CLEAR    SLOAD
                         RENDWFLG
                         BIT3H
                DDV      EXIT
                         ABDVCONV
                DXCH     MPAC
                DXCH     1/DV3
                DXCH     1/DV2
                DXCH     1/DV1
                DXCH     1/DV0
                TC       INTPRET
                DLOAD    DAD
                         1/DV0
                         1/DV1
                DAD      DAD
                         1/DV2
                         1/DV3
                DMP      DMP
                         VE
                         2SEC(9)
                SL3      PDDL
                         TBUP
                SR1      DAD
                DSU
                         6SEC(18)
```

```
                STODL   TBUP
                        VE
                SR1     DDV
                        TBUP
                STCALL  AT
```

Uses COUNT 142, DVCNTR 224, EBANK 80, MPAC 145, RENDWFLG 117, SURFFLAG 127, and TC 169.

2360 ⟨*Page LM0844* 2360⟩≡ (2358 2647)

```
                        ASCENT
  BIT3H         OCT     4
```

2361 ⟨*Page LM0845* 2361⟩≡ (2358 2647)

```
                BANK    30
                SETLOC  ASENT
                BANK
                COUNT*  $$/ASENT

ASCENT          VLOAD   ABVAL
                        R
                STOVL   /R/MAG
                        ZAXIS1
                DOT     SL1
                        V               # Z.V = ZDOT*2(-8).
                STOVL   ZDOT            # ZDOT*2(-7)
                        ZAXIS1
                VXV     VSL1
                        UNIT/R/         # Z X UR = LAXIS*2(-2)
                STORE   LAXIS           # LAXIS*2(-1)
                DOT     SL1
                        V               # L.V = YDOT*2(-8).
                STCALL  YDOT            # YDOT * 2(-7)
                        YCOMP
                VLOAD
                        GDT1/2          # LOAD GDT1/2*2(-7) M/CS.
                V/SC    DOT
                        2SEC(18)
                        UNIT/R/         # G.UR*2(9) = GR*2(9).
                PDVL    VXV             # STORE IN PDL(0)
                        UNIT/R/         # LOAD UNIT/R/ *2(-1)
                        V               # UR*2(-1) X V*2(-7) = H/R*2(-8).
                VSQ     DDV             # H(2)/R(2)*2(-16).
                        /R/MAG          # H(2)/R(3)*2(9).
                SL1     DAD
                STADR
                STODL   GEFF            # GEFF*2(10)m/CS/CS.
                        ZDOTD
                DSU
                        ZDOT
                STORE   DZDOT           # DZDOT = (ZDOTD - ZDOT) * 2(7) M/CS.
                VXSC    PDDL
                        ZAXIS1
                        YDOTD
                DSU
                        YDOT
                STORE   DYDOT           # DYDOT = (YDOTD - YDOT) *2(7) M/CS.
                VXSC    PDDL
                        LAXIS
```

RDOTD

Uses COUNT 142, GDT1/2 159, H 177, L 80, V 229, and Z 80.

2363 ⟨*Page LM0846* 2363⟩≡ (2358 2647)

```
                DSU
                        RDOT
                STORE   DRDOT           # DRDOT = (RDOTD - RDOT) * 2(7) M/CS.
                VXSC    VAD
                        UNIT/R/
                VAD     VSL1
                STADR
                STORE   VGVECT          # VG = (DRDOT)R + (DVDOT)L + (DZDOT)Z.
                DLOAD   DMP             # LOAD TGO
                        TGO             # TGO GEFF
                        GEFF
                VXSC    VSL1
                        UNIT/R/         # TGO GEFF UR
                BVSU
                        VGVECT          # COMPENSATED FOR GEFF
                STORE   VGVECT          # STORE FOR DOWNLINK
                MXV     VSL1            # GET VGBODY FOR N85 DISPLAY
                        XNBPIP
                STOVL   VGBODY
                        VGVECT
                ABVAL   BOFF            # MAGNITUDE OF VGVECT
                        FLRCS           # IF FLRCS=0,DO NORMAL GUIDANCE
                        MAINENG
                DDV                     # USE TGO=VG/AT WITH RCS
                        AT/RCS
                STCALL  TGO             # THIS WILL BE USED ON NEXT CYCLE
                        ASCTERM2
MAINENG         DDV     PUSH            # VG/VE IN PDL(0)               (2)
                        VE
                DMP     BDSU            # 1 - KT VG/VE
                        KT1
                        NEARONE
                DMP     DMP             # TBUP VG(1-KT VG/VE)/VE        (0)
                        TBUP            #       = TGO
                DSU                     # COMPENSATE FOR TAILOFF
                        TTO
                STORE   TGO
                SR      DCOMP
                        11D
                STODL   TTOGO           # TGO *2(-28) CS
                        TGO
                BON     DSU
                        IDLEFLAG
                        T2TEST
                        4SEC(17)        # ( TGO - 4 )*2(-17) CS.
```

```
                BMN
                        ENGOFF
T2TEST          DLOAD
                        TGO
                DSU     BMN             # IF TGO - T2 NEG., GO TO CMPONENT
```

Uses DO 229, KT 181, L 80, RDOT 229, SR 80, T2 241, TGO 224, TTOGO 236, VG 234, VGBODY 238, and Z 80.

2365 ⟨*Page LM0847* 2365⟩≡ (2358 2647)

```
                T2A
                CMPONENT
        DLOAD   DSU
                TBUP
                TGO
        DDV     CALL            # 1- TGO/TBUP
                TBUP
                LOGSUB
        SL      PUSH            # -L IN PDL(0)                  (2)
                5
        BDDV    BDSU            # -TGO/L*2(-17)
                TGO
                TBUP            # TBUP + TGO/L = D12*2(-17)
        PUSH    BON             # STORE IN PDL(2)               (4)
                FLPC            # IF FLPC = 1, GO TO CONST
                NORATES
        DLOAD   DSU
                TGO
                T3
        BPL     SET             # FLPC=1
                RATES
                FLPC
NORATES         DLOAD
                HI6ZEROS
        STORE   PRATE           # B = 0
        STORE   YRATE           # D = 0
        GOTO
                CONST           # GO TO CONST
RATES           DLOAD   DSU
                TGO
                O2D             # TGO - D12 = D21*2(-17)
        PUSH    SL1             # IN PDL(4)                     (6)
        BDSU    SL3             # (1/2TGO - D21)*2(-13) = E * 2(-13)
                TGO             #                               (8)
        PDDL    DMP             # IN PDL(6)
                TGO
                RDOT            # RDOT TGO * 2(-24)
        DAD     DSU             # R + RDOT TGO
                /R/MAG          # R + RDOT TGO - RCO
                RCO             # MPAC = -DR *2(-24).
        PDDL    DMP             # -DR IN PDL(8)                 (10)
                DRDOT
                O4D             # D21 DRDOT*2(-24)
        DAD     SL2             # (D21 DRDOT-DR)*2(-22)         (8)
        DDV     DDV
```

```
                06D             # (D21 DRDOT-DR)/E*2(-9)
                TGO
        STORE   PRATE           # B * 2(8)
        BMN     DLOAD           # B>0 NOT PERMITTED
                CHKBMAG
```

Uses D 226, D21 219, HI6ZEROS 71, L 80, MPAC 145, RDOT 229, and TGO 224.

2367 ⟨*Page LM0848* 2367⟩≡ (2358 2647)

```
                        HI6ZEROS
                STCALL  PRATE
                        PROK
CHKBMAG         SR4     DDV             # B*2(4)
                        TBUP            # (B / TAU) * 2(21)
                DSU     BPL
                        PRLIMIT         # ( B / TAU ) = 2(21) MAX.
                        PROK
                DLOAD   DMP
                        PRLIMIT
                        TBUP            # B MAX. * 2(4)
                SL4                     # BMAX*2(8)
                STORE   PRATE
PROK            DLOAD
                        TGO
                DMP     DAD             # YDOT TGO
                        YDOT
                        Y               # Y + YDOT TGO
                DSU     PDDL            # Y + YDOT TGO - YCO
                        YCO             # MPAC = - DY*(-24.) IN PDL(8)  (10)
                        DYDOT
                DMP     DAD             # D21 DYDOT - DY                (8)
                        04D
                SL2     DDV             # (D21 DYDOT - DY)/E*2(-9)
                DDV     SETPD           # (D21 DYDOT - DY)/E TGO*2(8)
                        TGO             #       = D*2(8)
                        04
                STORE   YRATE
CONST           DLOAD   DMP             # LOAD B*2(8)
                        PRATE           # B D12*2(-9)
                        02D
                PDDL    DDV             # D12 B IN PDL(4)       (6)
                        DRDOT           # LOAD DRDOT*2(-7)
                        00D             # -DRDOT/L*2(-7)
                SR2     DSU             # (-DRDOT/L-D12 B)=A*2(-9)      (4)
                STADR
                STODL   PCONS
                        YRATE           # D*2(8)
                DMP     PDDL            # D12 D,EXCH WITH -L IN PDL(0)  (2,2)
                BDDV    SR2             # -DYDOT/L*2(-9)
                        DYDOT
                DSU                     # (-DYDOT/L-D12 D)=C*2(-9)
                        00D
                STORE   YCONS
CMPONENT        SETPD   DLOAD
```

```
                        00D
                        100CS
                DMP
                        PRATE           # B(T-T0)*2(-9)
                DAD     DDV             # (A+B(T-T0))*2(-9)
```

Uses A 80, D 226, D21 219, HI6ZEROS 71, L 80, MPAC 145, TAU 211, and TGO 224.

2369 ⟨*Page LM0849* 2369⟩≡ (2358 2647)

```
                PCONS           # (A+B(T-T0))/TBUP*2(8)
                TBUP
        SL1     DSU
                GEFF            # ATR*2(9)
        STODL   ATR
                100CS
        DMP     DAD
                YRATE
                YCONS           # (C+D(T-T0))*2(-9)
        DDV     SL1
                TBUP
        STORE   ATY             # ATY*2(9)
        VXSC    PDDL            # ATY UY*2(8)           (6)
                LAXIS
                ATR
        VXSC    VAD
                UNIT/R/
        VSL1    PUSH            # AH*2(9) IN PDL(0)     (6)
        ABVAL   PDDL            # AH(2) IN PDL(34)
                AT              # AHMAG IN PDL(6)       (8)
        DSQ     DSU             # (AT(2)-AH(2))*2(18)
                34D             # =ATP2*2(18)
        PDDL    PUSH            #                       (12)
                AT
        DSQ     DSU             # (AT(2)KR(2)-AH(2))*2(18)      (10)
                34D             # =ATP3*2(18)
        BMN     DLOAD           # IF ATP3 NEG,GO TO NO-ATP
                NO-ATP          # LOAD ATP2, IF ATP3 POS
                8D
        SQRT    GOTO            # ATP*2(9)
                AIMER
NO-ATP  DLOAD   BDDV            # KR AT/AH = KH         (8)
                6D
        VXSC                    # KH AG*2(9)
                00D
        STODL   00D             # STORE NEW AH IN PDL(0)
                HI6ZEROS
AIMER   SIGN
                DZDOT
        STORE   ATP
        VXSC
                ZAXIS1          # ATP ZAXIS *2(8).
        VSL1    VAD             # AT*2(0)
                00D
        STORE   UNFC/2          # WILL BE OVERWRITTEN IF IN VERT. RISE.
```

```
SETPD   BON
        OOD
        FLPI
        P12RET
BON
```

Uses `A` 80, `D` 226, and `HI6ZEROS` 71.

2371 ⟨*Page LM0850* 2371⟩≡ (2358 2647)

```
                        FLVR
                        CHECKALT
MAINLINE        VLOAD   VCOMP
                        UNIT/R/
                STODL   UNWC/2
                        TXO
                DSU     BPL
                        PIPTIME
                        ASCTERM
                BON
                        ROTFLAG
                        ANG1CHEK
CLRXFLAG        CLEAR   CLEAR
                        NOR29FLG        # START r29 IN ASCENT PHASE.
                        XOVINFLG        # ALLOW X-AXIS OVERRIDE
ASCTERM         EXIT
                CA      FLAGWRD9
                MASK    FLRCSBIT
                CCS     A
                TCF     ASCTERM3
                TC      INTPRET
                CALL
                        FINDCDUW -2
ASCTERM1        EXIT
 +1             CA      FLAGWRD9        # INSURE THAT THE NOUN 63 DISPLAY IS
                MASK    FLRCSBIT        # BYPASSED IF WE ARE IN THE RCS TRIMMING
                CCS     A               # MODE OF OPERATION
                TCF     ASCTERM3
                CA      FLAGWRD8        # BYPASS DISPLAYS IF ENGINE FAILURE IS
                MASK    FLUNDBIT        # INDICATED.
                CCS     A
                TCF     ASCTERM3
                CAF     V06N63*
                TC      BANKCALL
                CADR    GODSPR
                TCF     ASCTERM3
ASCTERM2        EXIT
ASCTERM3        TCF     ENDOFJOB
ASCTERM4        EXIT
                INHINT
                TC      IBNKCALL        # NO GUIDANCE THIS CYCLE -- HENCE ZERO
                CADR    ZATTEROR        # THE DAP COMMANDED ERRORS.
                TCF     ASCTERM1 +1

CHECKALT        DLOAD   DSU
```

```
                    /R/MAG
                    /LAND/
            DSU     BMN             # IF H LT 25K CHECK Z AXIS ORIENTATION
                    25KFT
                    CHECKYAW
```

Uses A 80, DISPLAYS 59, FLAGWRD8 125, H 177, MODE 145, PIPTIME 159, TC 169, and Z 80.

2373 ⟨*Page LM0851* 2373⟩≡ (2358 2647)

```
EXITVR          CLEAR   BON
                        FLVR
                        ROTFLAG
                        MAINLINE
                DLOAD   DAD
                        PIPTIME
                        10SECS
                STCALL  TXO
                        MAINLINE
EXITVR1         CLRGO
                        ROTFLAG
                        EXITVR

                SETLOC  ASENT1
                BANK
                COUNT*  $$/ASENT

ANG1CHEK        VLOAD   DOT
                        UNFC/2
                        XNBPIP
                DSU     BPL
                        COSTHET1
                        OFFROT
                VLOAD   DOT
                        XNBPIP
                        UNIT/R/
                DSU     BMN
                        COSTHET2
                        KEEPVR1
OFFROT          CLRGO
                        ROTFLAG
                        CLRXFLAG

                BANK    7
                SETLOC  ASENT2
                BANK
                COUNT*  $$/ASENT

SETXFLAG        =       CHECKYAW

CHECKYAW        SET
                        XOVINFLG        # PROHIBIT X-AXIS OVERRIDE
                DLOAD   VXSC
                        ATY
                        LAXIS
```

```
PDDL    VXSC
        ATP
        ZAXIS1
VAD     UNIT
PUSH    DOT
```

Uses COUNT 142 and PIPTIME 159.

2375 ⟨*Page LM0852* 2375⟩≡ (2358 2647)

```
                        YNBPIP
                ABS     DSU
                        SIN5DEG
                BPL     DLOAD
                        KEEPVR
                        RDOT
                DSU     BPL
                        40FPS
                        EXITVR1
                GOTO
                        KEEPVR

                BANK    5
                SETLOC  ASENT3
                BANK
                COUNT*  $$/ASENT

SIN5DEG         2DEC    0.08716 B-2
40FPS           2DEC    0.12192 B-7

                BANK    14
                SETLOC  ASENT4
                BANK
                COUNT*  $$/ASENT

KEEPVR          VLOAD   STADR          # RECALL LOSVEC FROM PUSHLIST
                STORE   UNWC/2
KEEPVR1         VLOAD
                        UNIT/R/
                STCALL  UNFC/2
                        ASCTERM

ENGOFF          RTB
                        LOADTIME
                DSU     DAD
                        PIPTIME
                        TTOGO
                DCOMP   EXIT
                TC      TPAGREE        # FORCE SIGN AGREEMENT ON MPAC, MPAC +1.
                CAF     EBANK7
                TS      EBANK
                EBANK=  TGO
                INHINT
                CCS     MPAC +1
                TCF     +3             # C(A) = DT - 1 BIT
```

```
TCF     +2              # C(A) = 0
CAF     ZERO            # C(A) = 0
AD      BIT1            # C(A) = 1 BIT OR DT.
```

Uses A 80, COUNT 142, EBANK 80, LOSVEC 191, MPAC 145, PIPTIME 159, RDOT 229, TC 169, TGO 224, and TTOGO 236.

2377 ⟨*Page LM0853* 2377⟩≡ (2358 2647)

```
                TS      ENGOFFDT
                TC      TWIDDLE
                ADRES   ENGOFF1
                TC      PHASCHNG
                OCT     47014
                -GENADR ENGOFFDT
                EBANK=  TGO
                2CADR   ENGOFF1

                TC      INTPRET
                SET     GOTO
                        IDLEFLAG        # DISABLE DELTA-V MONITOR
                        T2TEST

ENGOFF1         TC      IBNKCALL        # SHUT OFF THE ENGINE.
                CADR    ENGINOF2

                CAF     PRIO17          # SET UP A JOB FOR THE ASCENT GUIDANCE
                TC      FINDVAC         # POSTBURN LOGIC.
                EBANK=  WHICH
                2CADR   CUTOFF

                TC      PHASCHNG
                OCT     07024
                OCT     17000
                EBANK=  TGO
                2CADR   CUTOFF

                TCF     TASKOVER

CUTOFF          TC      UPFLAG          # SET FLRCS FLAG.
                ADRES   FLRCS

 -5             CAF     V16N63
                TC      BANKCALL
                CADR    GOFLASH
                TCF     +3
                TCF     CUTOFF1
                TCF     -5

 +3             TC      POSTJUMP
                CADR    TERMASC

CUTOFF1         INHINT
                TC      IBNKCALL        # ZERO ATTITUDE ERRORS BEFORE REDUCINT DB.
```

```
CADR    ZATTEROR
TC      IBNKCALL
CADR    SETMINDB
TC      POSTJUMP
CADR    CUTOFF2
```

Uses `A` 80, `EBANK` 80, `TC` 169, `TGO` 224, and `V` 229.

2379 ⟨*Page LM0854* 2379⟩≡ (2358 2647)

```
V16N63          VN      1663
                BANK    30
                SETLOC  ASENT5
                BANK
                COUNT*  $$/ASENT

CUTOFF2         TC      PHASCHNG
                OCT     04024

                CAF     V16N85C
                TC      BANKCALL
                CADR    GOFLASH
                TCF     TERMASC
                TCF     +2              # PROCEED
                TCF     CUTOFF2

TERMASC         TC      PHASCHNG
                OCT     04024

                INHINT                  # RESTORE DEADBAND DESIRED BY ASTRONAUT.
                TC      IBNKCALL
                CADR    RESTORDB
                TC      DOWNFLAG        # DISALLOW ABORTS AT THIS TIME.
                ADRES   LETABORT
                TCF     GOTOP00H

V16N85C         VN      1685

                BANK 27
                SETLOC  ASENT1
                BANK
                COUNT* $$/ASENT

YCOMP           VLOAD   DOT
                        UNIT/R/
                        QAXIS
                SL2     DMP
                        RCO
                STORE   Y
                RVQ

                BANK    30
                SETLOC  ASENT
                BANK
```

Uses COUNT 142, TC 169, and VN 159.

2380 ⟨*Page LM0855* 2380⟩≡ (2358 2647)

```
100CS           EQUALS  2SEC(18)
T2A             EQUALS  2SEC(17)
4SEC(17)        2DEC    400 B-17
2SEC(17)        2DEC    200 B-17
T3              2DEC    1000 B-17
6SEC(18)        2DEC    600 B-18
BIT4H           OCT     10
2SEC(9)         2DEC    200 B-9
V06N63*         VN      0663
V06N76          VN      0676
V06N33A         VN      0633

                BANK    33
                SETLOC  ASENT6
                BANK
                COUNT*  $$/ASENT

KT1             2DEC    0.5000
PRLIMIT         2DEC    -.0639          # (B/TBUP)MIN=-.1FT.SEC(-3)
MINABDV         2DEC    .0356 B-5       # 10 PERCENT BIGGER THAN GRAVITY
1/DV0           =       MASS1
```

Uses COUNT 142 and VN 159.

2381 ⟨*Page LM0856* 2381⟩≡ (2358 2647)

```
# THE LOGARITHM SUBROUTINE

                BANK    24
                SETLOC  FLOGSUB
                BANK

# INPUT ..... X IN MPAC
# OUTPUT ..... -LOG(X) IN MPAC

LOGSUB          NORM    BDSU
                        MPAC +6
                        NEARONE
                EXIT
                TC      POLY
                DEC     6
                2DEC    .0000000060
                2DEC    -.0312514377
                2DEC    -.0155686771
                2DEC    -.0112502068
                2DEC    -.0018545108
                2DEC    -.0286607906
                2DEC    .0385598563
                2DEC    -.0419361902

                CAF     ZERO
                TS      MPAC +2
                EXTEND
                DCA     CLOG2/32
                DXCH    MPAC
                DXCH    BUF +1
                CA      MPAC +6
                TC      SHORTMP
                DXCH    MPAC +1
                DXCH    MPAC
                DXCH    BUF +1
                DAS     MPAC
                TC      INTPRET
                DCOMP   RVQ

CLOG2/32        2DEC    .0216608494
```

Uses BUF 142, MPAC 145, and TC 169.

4.24 servicer routine

2382 ⟨*servicer routine* 2382⟩≡ (2041 2804)

```
# Page 857
                BANK    37
                SETLOC  SERV1
                BANK

                EBANK=  DVCNTR

# ************* PREREAD ******************

                COUNT*  $$/SERV

PREREAD         CAF     SEVEN           # 5.7 SPOT TO SKIP LASTBIAS AFTER
                TC      GNUFAZE5        # RESTART.
                CAF     PRIO21
                TC      NOVAC
                EBANK=  NBDX
                2CADR   LASTBIAS        # DO LAST GYRO COMPENSATION IN FREE FALL

BIBIBIAS        TC      PIPASR +3       # CLEAR + READ PIPS LAST TIME IN FRE5+F133
                                        # DO NOT DESTROY VALUE OF PIPTIME1

                CS      FLAGWRD7
                MASK    SUPER011        # SET V37FLAG AND AVEGFLAG (BITS 5 AND 6
                ADS     FLAGWRD7        #       OF FLAGWRD7)

                CS      DRFTBIT
                MASK    FLAGWRD2        # RESET DRIFTFLAG
                TS      FLAGWRD2

                CAF     FOUR            # INITIALIZE DV MONITOR
                TS      PIPAGE

                CAF     ENDJBCAD        # POINT OUTROUTE TO END-OF-JOB.
                TS      OUTROUTE

                CAF     PRIO22
                TC      FINDVAC         # TO FIRST ENTRY TO AVERAGE G
                EBANK=  DVCNTR
                2CADR   NORMLIZE

                CA      TWO             # 5.2SPOT FOR REREADAC AND NORMLIZE
GOREADAX        TC      GNUTFAZ5
                CA      2SECS           # WAIT TWO SECONDS FOR READACCS
```

```
                TC      VARDELAY

# Page 858
# ************* READACCS ****************

READACCS        CS      OCT37771        # THIS PIECE OF CODING ATTEMPTS TO
                AD      TIME5           # SYNCHRONIZE READACCS WITH THE DIGITAL
                CCS     A               # AUTOPILOT SO THAT A PAXIS RUPT WILL
                CS      ONE             # OCCUR APPROXIMATELY 70 MILLISECONDS
                TCF     +2              # FOLLOWING THE READACCS RUPT.  THE 70 MS
                CA      ONE             # OFFSET WAS CHOSEN SO THAT THE PAXIS
        +2      ADS     TIME5           # RUPT WOULD NOT OCCUR SIMULTANEOUSLY
                                        # WITH ANY OF THE 8 SUBSEQUENT R10,R11
                                        # INTERRUPTS -- THUS MINIMIZING THE POSS-
                                        # IBILITY OF LOSING DOWNRUPTS.

                TC      PIPASR          # READ THE PIPAS.

PIPSDONE        CA      FIVE
                TC      GNUFAZE5
REDO5.5         CAF     ONE
                TS      PIPAGE

                CA      PRIO20
                TC      FINDVAC
                EBANK=  DVCNTR
                2CADR   SERVICER        # SET UP SERVICER JOB

                CA      BIT9
                EXTEND
                WOR     DSALMOUT        # TURN ON TEST CONNECTOR OUTBIT

                CA      FLAGWRD7
                MASK    AVEGFBIT
                EXTEND
                BZF     AVEGOUT         # AVEGFLAG DOWN -- SET UP FINAL EXIT

                CA      FLAGWRD6
                MASK    MUNFLBIT
                EXTEND
                BZF     MAKEACCS        # MUNFLAG CLEAR -- BYPASS LR AND DISP.

                CCS     PHASE2
                TCF     MAKEACCS        # PHASE 2 ACTIVATED -- AVOID MULTIPLE R10.

                CAF     SEVEN           # SET PIPCTR FOR 4X/SEC RATE.
```

```
                TS      PIPCTR

                CS      TIME1           # SET TBASE2 .05 SECONDS IN THE PAST.
                AD      FIVE
                AD      NEG1/2
                AD      NEG1/2
                XCH     TBASE2
# Page 859
                CAF     DEC17           # 2.21SPOT FOR R10,R11
                TS      L
                COM
                DXCH    -PHASE2

                CAF     OCT24           # FIRST R10,R11 IN .200 SECONDS
                TC      WAITLIST
                EBANK=  UNIT/R/
                2CADR   R10,R11

MAKEACCS        CA      FOUR
                TCF     GOREADAX        # DO PHASE CHANGE AND RECALL READACCS

AVEGOUT         EXTEND
                DCA     AVOUTCAD        # SET UP FINAL SERVICER EXIT
                DXCH    AVGEXIT

                CA      FOUR            # SET 5.4 SPOT FOR REREADAC AND SERVICER
                TC      GNUTFAZ5        # IF REREADAC IS CALLED, IT WILL EXIT
                TC      TASKOVER        # END TASK WITHOUT CALLING READACCS

GNUTFAZ5        TS      L               # SAVE INPUT IN L
                CS      TIME1
                TS      TBASE5          # SET TBASE5
                TCF     +2

GNUFAZE5        TS      L               # SAVE INPUT IN L
                CS      L               # -PHASE IN A, PHASE IN L.
                DXCH    -PHASE5         # SET -PHASE5,PHASE5
                TC      Q

                EBANK=  DVCNTR
AVOUTCAD        2CADR   AVGEND

ENDJBCAD        CADR    SERVEXIT +2

OCT37771        OCT     37771
```

```
                BANK    33
                SETLOC  SERVICES
                BANK

                COUNT*  $$/SERV

# Page 860
# ************* SERVICER ****************

SERVICER        TC      PHASCHNG        # RESTART REREADAC + SERVICER
                OCT     16035
                OCT     20000
                EBANK=  DVCNTR
                2CADR   GETABVAL

                CAF     PRIO31          # INITIALIZE 1/PIPADT IN CASE RESTART HAS
                TS      1/PIPADT        # CAUSED LASTBIAS TO BE SKIPPED.

                TC      BANKCALL        # PIPA COMPENSATION CALL
                CADR    1/PIPA

GETABVAL        TC      INTPRET
                VLOAD   ABVAL
                        DELV
                EXIT
                CA      MPAC
                TS      ABDELV          # ABDELV = CM/SEC*2(-14).
                EXTEND
                MP      KPIP
                DXCH    ABDVCONV        # ABDVCONV = M/CS * 2(-5).
                EXTEND
                DCA     MASS
                DXCH    MASS1           # INITIALIZE MASS1 IN CASE WE SKIP MASSMON
MASSMON         CS      FLAGWRD8        # ARE WE ON THE SURFACE?
                MASK    SURFFBIT
                EXTEND
                BZF     MOONSPOT        # YES:  BYPASS MASS MESS

                CA      FLGWRD10        # NO:  WHICH VEX SHOULD BE USED?
                MASK    APSFLBIT
                CCS     A
                EXTEND                  # IF EXTEND IS EXECUTED, APSVEX --> A,
                DCA     APSVEX          #       OTHERWISE DPSVEX --> A
                TS      Q

                EXTEND
```

```
                DCA     ABDVCONV
                EXTEND
OCT10002        DV      Q               # WHERE APPROPRIATE VEX RESIDES
                EXTEND
                MP      MASS
                DAS     MASS1

MOONSPOT        CA      KPIP1           # TP MPAC = ABDELV AT 2(14) CM/SEC
                TC      SHORTMP         # MULTIPLY BY KPIP1 TO GET
# Page 861
                DXCH    MPAC            # ABDELV AT 2(7) M/CS
                DAS     DVTOTAL         # UPDATE DVTOTAL FOR DISPLAY

                TC      TMPTOSPT

                TC      BANKCALL
                CADR    QUICTRIG

                CAF     XNBPIPAD
                TC      BANKCALL
                CADR    FLESHPOT
                TC      INTPRET
AVERAGEG        BON     CALL
                        MUNFLAG
                        RVBOTH
                        CALCRVG
                EXIT
GOSERV          TC      QUIKFAZ5

COPYCYCL        TC      COPYCYC

#               CA      ZERO            # A IS ZERO ON RETURN FROM COPYCYC
                TS      PIPATMPX
                TS      PIPATMPY
                TS      PIPATMPZ

                CS      STEERBIT        # CLEAR STEERSW PRIOR TO DVMON.
                MASK    FLAGWRD2
                TS      FLAGWRD2

                CAF     IDLEFBIT        # IS THE IDLE FLAG SET?
                MASK    FLAGWRD7
                CCS     A
                TCF     NODVMON1        # IDLEFLAG = 1, HENCE SET AUXFLAG TO 0.

                CS      FLAGWRD6
```

```
                MASK    AUXFLBIT
                CCS     A
                TCF     NODVMON2        # AUXFLAG = 0, HENCE SET AUXFLAG TO 1.

DVMON           CS      DVTHRUSH
                AD      ABDELV
                EXTEND
                BZMF    LOTHRUST

                CS      FLAGWRD2        # SET STEERSW.
                MASK    STEERBIT
                ADS     FLAGWRD2

DVCNTSET        CAF     ONE             # ALLOW TWO PASSES MAXIMUM NOW THAT
# Page 862
                TS      DVCNTR          # THRUST HAS BEEN DETECTED.

                CA      FLGWRD10        # BRANCH IF APSFLAG IS SET.
                MASK    APSFLBIT
                CCS     A
                TCF     USEJETS

                CA      BIT9            # CHECK GIMBAL FAIL BIT
                EXTEND
                RAND    CHAN32
                EXTEND
                BZF     USEJETS

USEGTS          CS      USEQRJTS
                MASK    DAPBOOLS
                TS      DAPBOOLS
                TCF     SERVOUT

NODVMON1        CS      AUXFLBIT        # SET AUXFLAG TO 0.
                MASK    FLAGWRD6
                TS      FLAGWRD6
                TCF     USEJETS
NODVMON2        CS      FLAGWRD6        # SET AUXFLAG TO 1.
                MASK    AUXFLBIT
                ADS     FLAGWRD6
                TCF     USEJETS

LOTHRUST        TC      QUIKFAZ5
                CCS     DVCNTR
                TCF     DECCNTR
```

```
                CCS     PHASE4          # COMFAIL JOB ACTIVE?
                TCF     SERVOUT         # YES:  WON'T NEED ANOTHER.

                TC      PHASCHNG        # 4.37SPOT FOR COMFAIL.
                OCT     00374

                CAF     PRIO25
                TC      NOVAC
                EBANK=  WHICH
                2CADR   COMFAIL

                TCF     SERVOUT

DECCNTR         TS      DVCNTR1
                TC      QUIKFAZ5
                CA      DVCNTR1
                TS      DVCNTR
                INHINT
                TC      IBNKCALL        # IF THRUST IS LOW, NO STEERING IS DONE
# Page 863
                CADR    STOPRATE        # AND THE DESIRED RATES ARE SET TO ZERO.
USEJETS         CS      DAPBOOLS
                MASK    USEQRJTS
                ADS     DAPBOOLS
SERVOUT         RELINT
                TC      BANKCALL
                CADR    1/ACCS

                CA      PRIORITY
                MASK    LOW9
                TS      PUSHLOC
                ZL
                DXCH    FIXLOC          # FIXLOC AND DVFIND

                TC      QUIKFAZ5
                EXTEND                  # EXIT TO SELECTED ROUTINE WHETHER THERE
                DCA     AVGEXIT         # IS THRUST OR NOT.  THE STATE OF STEERSW
                DXCH    Z               # WILL CONVEY THIS INFORMATION.

XNBPIPAD        ECADR   XNBPIP

                BANK    32
                SETLOC  SERV2
                BANK
                COUNT*  $$/SERV
```

```
AVGEND          CA      PIPTIME +1      # FINAL AVERAGE G EXIT
                TS      1/PIPADT        # SET UP FREE FALL GYRO COMPENSATION.

                TC      UPFLAG          # SET DRIFT FLAG.
                ADRES   DRIFTFLG

                TC      BANKCALL
                CADR    PIPFREE

                CS      BIT9
                EXTEND
                WAND    DSALMOUT

                TC      2PHSCHNG
                OCT     5               # GROUP 5 OFF
                OCT     05022           # GROUP 2 ON
                OCT     20000

                TC      INTPRET
                SET     CLEAR
                        NOR29FLG        # SHUT OFF R29 WHEN SERVICER ENDS.
                        SWANDISP        # SHUT OFF R10 WHEN SERVICER ENDS.
                CLEAR   CALL            # RESET MUNFLAG.
                        MUNFLAG
# Page 864
                        AVETOMID
                CLEAR   EXIT
                        V37FLAG
AVERTRN         CA      OUTROUTE        # RETURN TO DESIRED POINT.
                TC      BANKJUMP

OUTGOAVE        =       AVERTRN
DVCNTR1         =       MASS1

# Page 865
                SETLOC  SERV3
                BANK
                COUNT*  $$/SERV

SERVIDLE        EXTEND                  # DISCONNECT SERVICER FROM ALL GUIDANCE
                DCA     SVEXTADR
                DXCH    AVGEXIT

                CS      FLAGWRD7        # DISCONNECT THE DELTA-V MONITOR
                MASK    IDLEFBIT
                ADS     FLAGWRD7
```

```
                CAF     LRBYBIT         # TERMINATE R12 IS RUNNING.
                TS      FLGWRD11

                EXTEND
                DCA     NEG0
                DXCH    -PHASE1

                CA      FLAGWRD6        # DO NOT TURN OFF PHASE 2 IF MUNFLAG SET.
                MASK    MUNFLBIT
                CCS     A
                TCF     +4

                EXTEND
                DCA     NEG0
                DXCH    -PHASE2

        +4      EXTEND
                DCA     NEG0
                DXCH    -PHASE3

                EXTEND
                DCA     NEG0
                DXCH    -PHASE6

                CAF     OCT33           # 4.33SPOT FOR GOP00FIX
                TS      L
                COM
                DXCH    -PHASE4

                TCF     WHIMPER         # PERFORM A SOFTWARE RESTART AND PROCEED
                                        # TO GOTOP00H WHILE SERVICER CONTINUES TO
                                        # RUN, ALBEIT IN A GROUND STATE WHERE
                                        # ONLY STATE-VECTOR DEPENDENT FUNCTIONS
                                        # ARE MAINTAINED.

                EBANK=  DVCNTR
# Page 866
SVEXTADR        2CADR   SERVEXIT

                BANK    32
                SETLOC  SERV
                BANK
                COUNT*  $$/SERV

SERVEXIT        TC      PHASCHNG
```

```
                OCT     00035

+2              TCF     ENDOFJOB

                BANK    23
                SETLOC  NORMLIZ
                BANK

                COUNT*  $$/SERV

# Page 867
NORMLIZE        TC      INTPRET
                VLOAD   BOFF
                        RN1
                        MUNFLAG
                        NORMLIZ1
                VSL6    MXV
                        REFSMMAT
                STCALL  R
                        MUNGRAV
                VLOAD   VSL1
                        VN1
                MXV
                        REFSMMAT
                STOVL   V
                        V(CSM)
                VXV     UNIT
                        R(CSM)
                STORE   UHYP
ASCSPOT         EXIT
                EXTEND                  # MAKE SURE GROUP 2 IS OFF
                DCA     NEG0
                DXCH    -PHASE2

                TC      POSTJUMP
                CADR    NORMLIZ2

                BANK    33
                SETLOC  SERVICES
                BANK
                COUNT*  $$/SERV

NORMLIZ1        CALL
                        CALCGRAV
                EXIT
```

```
NORMLIZ2        CA      EIGHTEEN
                TC      COPYCYC +1      # DO NOT COPY MASS IN NORMLIZE
                TC      ENDOFJOB

COPYCYC         CA      OCT24           # DEC 20
        +1      INHINT
        +2      MASK    NEG1            # REDUCE BY 1 IF ODD
                TS      ITEMP1
                EXTEND
                INDEX   ITEMP1
                DCA     RN1
                INDEX   ITEMP1
# Page 868
                DXCH    RN
                CCS     ITEMP1
                TCF     COPYCYC +2
                TC      Q               # RETURN UNDER INHINT

EIGHTEEN        DEC     18

# Page 869
# ************* PIPA READER *****************
# MOD NO. 00 BY D. LICKLY, DEC. 9 1966
#
# FUNCTIONAL DESCRIPTION
#       SUBROUTINE TO READ PIPA COUNTERS, TRYING TO BE VERY CAREFUL SO THAT WILL BE P
#       PIPA READINGS ARE STORED IN THE VECTOR DELV.  THE HIGH ORDER PART OF EACH CON
#       RESTARTS BEGIN AT REREADAC.
#
#       AT THE END OF THE PIPA READER THE CDUS ARE READ AND STORED AS A
#       VECTOR IN CDUTEMP.  THE HIGH ORDER PART OF EACH COMPONENT CONTAINS
#       THE CDU READING IN 25 COMP IN THE ORDER CDUX,Y,Z.  THE THRUST
#       VECTOR ESTIMATOR IN FINDCDUD REQUIRES THE CDUS BE READ AT PIPTIME.
#
# CALLING SEQUENCE AND EXIT
#       CALL VIA TC, ISWCALL, ETC.
#       EXIT IS VIA Q.
#
# INPUT
#       INPUT IS THROUGH THE COUNTERS PIPAX, PIPAY, PIPAZ, AND TIME2.
#
# OUTPUT
#       HIGH ORDER COMPONENTS OF THE VECTOR DELV CONTAIN THE PIPA READINGS.
#       PIPTIME CONTAINS TIME OF PIPA READING.
#
# DEBRIS (ERASABLE LOCATIONS DESTROYED BY PROGRAM)
```

```
#       TEMX, TEMY, TEMZ, PIPAGE

                BANK    37
                SETLOC  SERV1
                BANK

                COUNT*  $$/SERV

PIPASR          EXTEND
# Page 870
                DCA     TIME2
                DXCH    PIPTIME1        # CURRENT TIME POSITIVE VALUE
        +3      CS      ZERO            # INITIALIZE THESE AT NEG. ZERO.
                TS      TEMX
                TS      TEMY
                TS      TEMZ

                CA      ZERO
                TS      DELVZ
                TS      DELVZ +1
                TS      DELVY
                TS      DELVY +1
                TS      DELVX +1
                TS      PIPAGE          # SHOW PIPA READING IN PROGRESS

REPIP1          EXTEND
                DCS     PIPAX           # X AND Y PIPS READ
                DXCH    TEMX
                DXCH    PIPAX           # PIPAS SET TO NEG ZERO AS READ.
                TS      DELVX
                LXCH    DELVY

REPIP3          CS      PIPAZ           # REPEAT PROCESS FOR Z PIP
                XCH     TEMZ
                XCH     PIPAZ
DODELVZ         TS      DELVZ

REPIP4          EXTEND                  # COMPUTE GUIDANCE PERIOD
                DCA     PIPTIME1
                DXCH    PGUIDE
                EXTEND
                DCS     PIPTIME
                DAS     PGUIDE

                CA      CDUX            # READ CDUS INTO HIGH ORDER CDUTEMPS
                TS      CDUTEMPX
```

```
                CA      CDUY
                TS      CDUTEMPY
                CA      CDUZ
                TS      CDUTEMPZ
                CA      DELVX
                TS      PIPATMPX
                CA      DELVY
                TS      PIPATMPY
                CA      DELVZ
                TS      PIPATMPZ

                TC      Q

# Page 871
REREADAC        CCS     PIPAGE
                TCF     READACCS        # PIP READING NOT STARTED.  GO TO BEGINNING

                CAF     DONEADR         # SET UP RETURN FROM PIPASR
                TS      Q

                CCS     DELVZ
                TCF     REPIP4          # Z DONE, GO DO CDUS
                TCF     +3              # Z NOT DONE, CHECK Y.
                TCF     REPIP4
                TCF     REPIP4

                ZL
                CCS     DELVY
                TCF     +3
                TCF     CHKTEMX         # Y NOT DONE, CHECK X.
                TCF     +1
                LXCH    PIPAZ           # Y DONE, ZERO Z PIP.

                CCS     TEMZ
                CS      TEMZ            # TEMZ NOT = -0, CONTAINS -PIPAZ VALUE.
                TCF     DODELVZ
                TCF     -2
                LXCH    DELVZ           # TEMZ = -0, L HAS ZPIP VALUE.
                TCF     REPIP4

CHKTEMX         CCS     TEMX            # HAS THIS CHANGED
                CS      TEMX            # YES
                TCF     +3              # YES
                TCF     -2              # YES
                TCF     REPIP1          # NO
                TS      DELVX
```

```
                CS      TEMY
                TS      DELVY

                CS      ZERO            # ZERO X AND Y PIPS
                DXCH    PIPAX           # L STILL ZERO FROM ABOVE

                TCF     REPIP3

DONEADR         GENADR  PIPSDONE

# Page 872
                BANK    33
                SETLOC  SERVICES
                BANK

                COUNT*  $$/SERV

TMPTOSPT        CA      CDUTEMPY        # THIS SUBROUTINE, CALLED BY AN RTB FROM
                TS      CDUSPOTY        # INTERPRETIVE, LOADS THE CDUS CORRESPON-
                CA      CDUTEMPZ        # DING TO PIPTIME INTO THE CDUSPOT VECTOR.
                TS      CDUSPOTZ
                CA      CDUTEMPX
                TS      CDUSPOTX
                TC      Q

# LRHTASK IS A WAITLIST TASK SET BY READACCS DURING THE DESCENT BRAKING
# PHASE WHEN THE ALT TO THE LUNAR SURFACE IS LESS THAN 25,000 FT.  THIS
# TASK CLEARS THE ALTITUDE MEASUREMENT MADE DISCRETE AND INITIATES THE
# LANDING RADAR MEASUREMENT JOB (LRHJOB) TO TAKE A ALTITUDE MEASUREMENT
# 50 MS PRIOR TO THE NEXT READACCS TASK.

                BANK    21
                SETLOC  R10
                BANK

                COUNT*  $$/SERV

LRHTASK         CS      FLGWRD11
                MASK    LRBYBIT
                EXTEND
                BZF     GRP2OFF         # LR BYPASS SET -- BYPASS ALL LR READING.

                CA      READLBIT
                MASK    FLGWRD11        # IS READLR FLAG SET?
                EXTEND
```

```
                BZF     GRP2OFF         # NO.  BYPASS LR READ.

                CS      FLGWRD11
                MASK    NOLRRBIT        # IS LR READ INHIBITED?
                EXTEND
                BZF     GRP2OFF         # YES.  BYPASS LR READ.

                CA      PRIO32          # LR READ OK.  SET JOB TO DO IT
                TC      NOVAC           # ABOUT 50 MS. PRIOR TO PIPA READ.
                EBANK=  HMEAS
                2CADR   LRHJOB

GRP2OFF         EXTEND
                DCA     NEG0
                DXCH    -PHASE2
                TCF     R10,R11A

                BANK    33
                SETLOC  SERVICES
                BANK
# Page 873
                COUNT*  $$/SERV

# HIGATASK IS ENTERED APPROXIMATELY 6 SECS PRIOR TO HIGATE DURING THE
# DESCENT PHASE.  HIGATASK SETS THE HIGATE FLAG (BIT11) AND THE LR INHIBIT
# FLAG (BIT10) IN LRSTAT.  THE HIGATJOB IS SET UP TO REPOSITION THE LR
# ANTENNA FROM POSITION 1 TO POSITION 2.  IF THE REPOSITIONING IS
# SUCCESSFUL THE ALT BEAM AND VELOCITY BEAMS ARE TRANSFORMED TO THE NEW
# ORIENTATION IN NB COORDINATES AND STORED IN ERASABLE.

HIGATASK        INHINT
                CS      PRIO3           # SET HIGATE AND LR INHIBIT FLAGS
                MASK    FLGWRD11
                AD      PRIO3
                TS      FLGWRD11
                CAF     PRIO32
                TC      FINDVAC         # SET LR POSITIONING JOB (POS2)
                EBANK=  HMEAS
                2CADR   HIGATJOB

                TCF     CONTSERV        # CONTINUE SERVICER

# Page 874
# MUNRETRN IS THE RETURN LOC FROM SPECIAL AVE G ROUTINE (MUNRVG)

MUNRETRN        EXIT
```

```
                CS      FLGWRD11
                MASK    LRBYBIT
                EXTEND
                BZF     COPYCYC1        # BYPASS LR LOGIC IF BIT15 IS SET.

                CA      READLBIT        # SEE IF ALT < 35000 FT LAST CYCLE
                MASK    FLGWRD11
                EXTEND
                BZF     35KCHK          # ALT WAS > 35000 FT LAST CYCLE   CHK NOW

                CAF     XORFLBIT        # WERE WE BELOW 30000 FT LAST PASS?
                MASK    FLGWRD11
                EXTEND
                BZF     XORCHK          # NO -- TEST THIS PASS
HITEST          CAF     PSTHIBIT        # CHECK FOR HIGATE
                MASK    FLGWRD11
                EXTEND
                BZF     HIGATCHK        # NOT AT HIGATE LAST CYCLE -- CHK THIS CYCLE

POS2CHK         CAF     BIT7            # VERIFY LR IN POS2
                EXTEND
                RAND    CHAN33
                EXTEND
                BZF     UPDATCHK        # IT IS -- CHECK FOR LR UPDATE
                CAF     BIT13
                EXTEND
                RAND    CHAN12
                EXTEND
                BZF     LRPOSALM        # LR NOT IN POS2 OR REPOSITIONING -- BAD
                TCF     CONTSERV        # LR BEING REPOSITIONED -- CONTINUE SERV

HIGATCHK        CA      TTF/8           # IS TTF > CRITERION?  (TTF IS NEGATIVE)
                AD      RPCRTIME
                EXTEND
                BZMF    POS1CHK         # NO

                CA      EBANK4          # MUST SWITCH EBANKS
                XCH     EBANK
                TS      L               # SAVE IN L

                EBANK=  XNBPIP
                CS      XNBPIP          # UXBXP IN GSOP CH5
                EBANK=  DVCNTR
                LXCH    EBANK           # RESTORE EBANK
                AD      RPCRTQSW        # QSW - UXBXP
```

```
# Page 875

                EXTEND
                BZMF    HIGATASK        # IF UXBXP > QSW, THEN REPOSITION

POS1CHK         CAF     BIT6            # HIGATE NOT IN SIGHT -- DO POS1 CHK
                EXTEND
                RAND    33
                EXTEND
                BZF     UPDATCHK        # LR IN POS1 -- CHECK FOR LR UPDATE

LRPOSALM        TC      ALARM           # LR NOT IN PROPER POS-ALARM-BYPASS UPDATE
                OCT     511             # AND CONTINUE SERVICER
CONTSERV        INHINT
                CS      BITS4-7
                MASK    FLGWRD11        # CLEAR LR MEASUREMENT MADE DISCRETES.
                TS      FLGWRD11

                TC      IBNKCALL        # SET LR LITES PROPERLY
                CADR    R12LITES

# Page 876
COPYCYC1        TC      QUIKFAZ5

R29?            CA      FLAGWRD3
                MASK    NR29&RDR
                CCS     A               # IS NOR29FLG OR READRFLG SET?
                TCF     R29NODES        # YES, SO DON'T DESIGNATE.

                CA      RADMODES        # NO, SO R29 IS CALLED FOR.
                MASK    OCT10002        # IS THE RR NOT ZEROING ITS CDUS, AND
                CCS     A               # IS THE RENDEZVOUS RADAR IN AUTO MODE?
                TCF     R29NODES        # NO, SO DON'T DESIGNATE.

                CA      RADMODES
                MASK    PRIO22
                CCS     A               # IS RR REPOSITIONING OR REMODING?
                TCF     NOR29NOW        # YES:  COME BACK IN 2 SECONDS & TRY AGAIN.

                TCF     R29

R29NODES        INHINT                  # R29 NOT ALLOWED THIS CYCLE.
                CS      DESIGBIT        # SHOW THAT DESIGNATION IS OFF.
                MASK    RADMODES
                TS      RADMODES
```

```
NOR29NOW        TC      INTPRET         # INTPRET DOES A RELINT.
                VLOAD   ABVAL           # MPAC = ABVAL( NEW SM. POSITION VECTOR )
                        R1S
                PUSH    DSU             #                               (2)
                        /LAND/
                STORE   HCALC           # NEW HCALC*2(24)M.
                STORE   HCALC1
                DMPR    RTB
                        ALTCONV
                        SGNAGREE
                STOVL   ALTBITS         # ALTITUDE FOR R10 IN BIT UNITS.
                        UNIT/R/
                VXV     UNIT
                        UHYP
                STOVL   UHZP            # DOWNRANGE HALF-UNIT VECTOR FOR R10.
                        R1S
                VXM     VSR4
                        REFSMMAT
                STOVL   RN1             # TEMP. REF. POSITION VECTOR*2(29)M.
                        V1S
                VXM     VSL1
                        REFSMMAT
                STOVL   VN1             # TEMP. REF. VELOCITY VECTOR 2(7) M/CS.
                        UNIT/R/
                VXV     ABVAL
# Page 877
                        V1S
                SL1     DSQ
                DDV
                DMPR    RTB
                        ARCONV1
                        SGNAGREE
COPYCYC2        EXIT                    # LEAVE ALTITUDE RATE COMPENSATION IN MPAC
                INHINT
                CA      UNIT/R/         # UPDATE RUNIT FOR R10.
                TS      RUNIT
                CA      UNIT/R/ +2
                TS      RUNIT +1
                CA      UNIT/R/ +4
                TS      RUNIT +2
                CA      MPAC            # LOAD NEW DALTRATE FOR R10.
                TS      DALTRATE

                EXTEND
                DCA     R1S
                DXCH    R
```

```
                EXTEND
                DCA     R1S +2
                DXCH    R +2
                EXTEND
                DCA     R1S +4
                DXCH    R +4
                EXTEND
                DCA     V1S
                DXCH    V
                EXTEND
                DCA     V1S +2
                DXCH    V +2
                EXTEND
                DCA     V1S +4
                DXCH    V +4

                TCF     COPYCYCL        # COMPLETE THE COPYCYCL.

# Page 878
# ALTCHK COMPARES CURRENT ALTITUDE (IN HCALC) WITH A SPECIFIED ALTITUDE FROM A TABLE
# ITS CALLING SEQUENCE IS AS FOLLOWS:-
#
#       L       CAF     N
#       L+1     TC      BANKCALL
#       L+2     CADR    ALTCHK
#       L+3     RETURN HERE IF HCALC STILL > SPECIFIED CRITERION.   C(L) = +0.
#       L+4     RETURN HERE IF HCALC < OR = SPECIFIED CRITERION.   C(A) = C(L) = +0
#
# ALTCHK MUST BE BANKCALLED EVEN FROM ITS OWN BANK.   N IS THE LOCATION, RELATIVE TO
# OF THE BEGINNING OF THE DP CONSTANT TO BE USED AS A CRITERION.

ALTCHK          EXTEND
                INDEX   A
                DCA     ALTCRIT
                DXCH    MPAC +1
                EXTEND
                DCS     HCALC
                DAS     MPAC +1
                TC      BRANCH +4
                CAF     ZERO            # BETTER THAN A NOOP, PERHAPS
                INCR    BUF2
                TCF     SWRETURN

ALTCRIT         =       25KFT

25KFT           2DEC    7620 B-24               # (0)
```

```
50KFT           2DEC    15240 B-24              # (2)

50FT            2DEC    15.24 B-24              # (4)

30KFT           2DEC    9144 B-24               # (6)

2KFT/SEC        DEC     6.096 B-7               # 2000 FT/SEC AT 2(7) M/CS


# (A remark was likely to be needed here to explain XORCHK) 4/Jun/09,FB

XORCHK          CAF     SIX             # ARE WE BELOW 30000 FT?
                TC      BANKCALL
                CADR    ALTCHK
                TCF     HITEST          # CONTINUE LR UPDATE
                TC      UPFLAG          # YES: INHIBIT X-AXIS OVERRIDE
                ADRES   XOVINFLG
                TC      UPFLAG
                ADRES   XORFLG
                TCF     HITEST          # CONTINUE LR UPDATE

35KCHK          CAF     TWO             # ARE WE BELOW 35000 FT?

# Page 879
                TC      BANKCALL
                CADR    ALTCHK
                TCF     CONTSERV
                TC      UPFLAG
                ADRES   READLR          # SET READLR FLAG TO ENABLE LR READING.
                TCF     CONTSERV

# Page 880
# ***************************************************************

CALCGRAV        UNIT    PUSH            # SAVE UNIT/R/ IN PUSHLIST      (18)
                STORE   UNIT/R/
                LXC,1   SLOAD           # RTX2 = 0 IF EARTH ORBIT, =2 IF LUNAR.
                        RTX2
                        RTX2
                DCOMP   BMN
                        CALCGRV1
                VLOAD   DOT             #                               (12)
                        UNITZ
                        UNIT/R/
                SL1     PUSH            #                               (14)
```

```
                DSQ     BDSU
                        DP1/20
                PDDL    DDV
                        RESQ
                        34D             # (RN)SQ
                STORE   32D             # TEMP FOR (RE/RN)SQ
                DMP     DMP
                        20J
                VXSC    PDDL
                        UNIT/R/
                DMP     DMP
                        2J
                        32D
                VXSC    VSL1
                        UNITZ
                VAD     STADR
                STORE   UNITGOBL
                VAD     PUSH            # MPAC = UNIT GRAVITY VECTOR.   (18)
CALCGRV1        DLOAD   NORM            # PERFORM A NORMALIZATION ON RMAGSQ IN
                        34D             # ORDER TO BE ABLE TO SCALE THE MU FOR
                        X2              # MAXIMUM PRECISION.
                BDDV*   SLR*
                        -MUDT,1
                        0 -21D,2
                VXSC    STADR
                STORE   GDT1/2          # SCALED AT 2(+7) M/CS
                RVQ

CALCRVG         VLOAD   VXM
                        DELV
                        REFSMMAT
                VXSC    VSL1
                        KPIP1
                STORE   DELVREF
                VSR1    PUSH
                VAD     PUSH            # (DV-OLDGDT)/2 TO PD SCALED AT 2(+7) M/CS.
# Page 881
                        GDT/2
                VAD     PDDL
                        VN
                        PGUIDE
                SL      VXSC
                        6D
                VAD     STQ
                        RN
                        31D
```

```
                STCALL  RN1             # TEMP STORAGE OF RN SCALED 2(+29) M
                        CALCGRAV

                VAD     VAD
                VAD
                        VN
                STCALL  VN1             # TEMP STORAGE OF VN SCALED 2(+7) M/CS
                        31D

DP1/20          2DEC    0.05
SHIFT11         2DEC    1 B-11

# Page 882
#*************************************************************************
# MUNRVG IS A SPECIAL AVERAGE G INTEGRATION ROUTINE USED BY THRUSTING
# PROGRAMS WHICH FUNCTION IN THE VICINITY OF AN ASSUMED SPHERICAL MOON.
# THE INPUT AND OUTPUT QUANTITIES ARE REFERENCED TO THE STABLE MEMBER
# COORDINATE SYSTEM.

RVBOTH          VLOAD   PUSH
                        G(CSM)
                VAD     PDDL
                        V(CSM)
                        PGUIDE
                DDV     VXSC
                        SHIFT11
                VAD
                        R(CSM)
                STCALL  R1S
                        MUNGRAV
                VAD     VAD
                        V(CSM)
                STADR
                STORE   V1S
                EXIT
                TC      QUIKFAZ5
                TC      INTPRET
                VLOAD
                        GDT1/2
                STOVL   G(CSM)
                        R1S
                STOVL   R(CSM)
                        V1S
                STORE   V(CSM)
                EXIT
                TC      QUIKFAZ5
```

```
                TC      INTPRET
MUNRVG          VLOAD   VXSC
                        DELV
                        KPIP2
                PUSH    VAD             # 1ST PUSH:  DELV IN UNITS OF 2(8) M/CS
                        GDT/2
                PUSH    VAD             # 2ND PUSH:  (DELV + GDT)/2, UNITS OF 2(7)
                        V               #                                (12)
                PDDL    DDV
                        PGUIDE
                        SHIFT11
                VXSC
                VAD
                        R
                STCALL  R1S             # STORE R SCALED AT 2(+24) M
                        MUNGRAV
# Page 883
                VAD     VAD
                VAD
                        V
                STORE   V1S             # STORE V SCALED AT 2(+7) M/CS.
                ABVAL
                STOVL   ABVEL           # STORE SPEED FOR LR AND DISPLAYS.
                        UNIT/R/
                DOT     SL1
                        V1S
                STOVL   HDOTDISP        # HDOT = V. UNIT(R)*2(7) M/CS.
                        R1S
                VXV     VSL2
                        WM
                STODL   DELVS           # LUNAR ROTATION CORRECTION TERM*2(5) M/CS.
                        36D
                DSU
                        /LAND/
                STCALL  HCALC           # FOR NOW, DISPLAY WHETHER POS OR NEG
                        MUNRETRN
MUNGRAV         UNIT                    # AT 36D HAVE ABVAL(R), AT 34D R.R
                STODL   UNIT/R/
                        34D
                SL      BDDV
                        6D
                        -MUDTMUN
                DMP     VXSC
                        SHIFT11
                        UNIT/R/
                STORE   GDT1/2          # 1/2GDT SCALED AT 2(7) M/CS.
```

```
                RVQ

1.95SECS        DEC     195
7.5             2DEC    .02286 B-6      # 7.5 FT/SEC AT 2(6) M/CS

2SEC(18)        2DEC    200 B-18

2SEC(28)        2OCT    0000000310      # 2SEC AT 2(28)

4SEC(28)        2DEC    400 B-28

BITS4-7         OCT     110


# Page 884
UPDATCHK        CAF     NOLRRBIT        # SEE IF LR UPDATE INHIBITED.
                MASK    FLGWRD11
                CCS     A
                TCF     CONTSERV        # IT IS -- NO LR UPDATE
                CAF     RNGEDBIT        # NO INHIBIT -- SEE ALT MEAS. THIS CYCLE.
                MASK    FLGWRD11
                EXTEND
                BZF     VMEASCHK        # NO ALT MEAS THIS CYCLE -- CHECK FOR VEL

POSUPDAT        CA      FIXLOC          # SET PUSHLIST TO ZERO
                TS      PUSHLOC

                TC      INTPRET
                VLOAD   VXM
                        HBEAMNB
                        XNBPIP          # HBEAM SM AT 2(2)
                PDVL    VSL2            # STORE HBEAM IN PD 0-5
                        V1S             # SCALE V AT 2(5) M/CS
                VAD     DOT
                        DELVS           # V RELATIVE TO SURFACE AT 2(5) M/CS
                        OD              # V ALONG HBEAM AT 2(7) M/CS.
                DMP     EXIT
                        RADSKAL         # SCALE TO RADAR COUNTS X 5

                CS      FLGWRD12        # TEST LR ALTITUDE SCALE FACTOR
                MASK    ALTSCBIT
                EXTEND
                BZF     +3              # BRANCH IF HIGH SCALE

                CA      SKALSKAL        # RESCALE IF LOW SCALE
                TC      SHORTMP
```

```
        +3      TC      INTPRET
                DAD     SL              # CORRECT HMEAS FOR DOPPLER EFFECT
                        HMEAS
                        7D
                DMP     VXSC            # SLANT RANGE AT 2(21), PUSH UP FOR HBEAM
                        HSCAL           # SLANT RANGE VECTOR AT 2(23) M
                DOT     DSU
                        UNIT/R/         # ALTITUDE AT 2(24) M
                        HCALC           # DELTA H AT 2(24) M
                STORE   DELTAH
                EXIT

                CA      FLGWRD11
                MASK    PSTHIBIT
                EXTEND                  # DO NOT PERFORM DATA REASONABLENESS TEST
                BZF     NOREASON        # UNTIL AFTER HIGATE
# Page 885
                TC      INTPRET
                ABS     DSU
                        DELQFIX         # ABS(DELTAH) - DQFIX   50 FT NOM
                SL3     DSU             # SCALE TO 2(21)
                        HCALC           # ABS(DELTAH) - (50 + HCALC/8) AT 2(21)
                EXIT

                INCR    LRLCTR
                TC      BRANCH
                TCF     HFAIL           # DELTA H TOO LARGE
                TCF     HFAIL           # DELTA H TOO LARGE
                TC      DOWNFLAG        # TURN OFF ALT FAIL LAMP
                ADRES   HFLSHFLG

NOREASON        CS      FLGWRD11
                MASK    LRINHBIT
                CCS     A
                TCF     VMEASCHK        # UPDATE INHIBITED -- TEST VELOCITY ANYWAY

                TC      INTPRET         # DO POSITION UPDATE
                DLOAD   SR4
                        HCALC           # RESCALE H TO 2(28)M
                EXIT
                EXTEND
                DCA     DELTAH          # STORE DELTAH IN MPAC AND
                DXCH    MPAC            # BRING HCALC INTO A,L
                TC      ALSIGNAG
                EXTEND                  # IF HIGH PART OF HCALC IS NON-ZERO, THEN
```

```
                BZF     +2              # HCALC > HMAX,
                TCF     VMEASCHK        # SO UPDATE IS BYPASSED
                TS      MPAC +2         #       FOR LATER SHORTMP

                CS      L               # -H AT 2(14) M
                AD      LRHMAX          # HMAX - H
                EXTEND
                BZMF    VMEASCHK        # IF H >HMAX, BYPASS UPDATE
                EXTEND
                MP      LRWH            # WH(HMAX - H)
                EXTEND
                DV      LRHMAX          # WH(1 - H/HMAX)
                TS      MPTEMP
                TC      SHORTMP2        # DELTAH (WH)(1 - H/HMAX) IN MPAC
                TC      INTPRET         # MODE IS DP FROM ABOVE
                SL1
                VXSC    VAD
                        UNIT/R/         # DELTAR = DH(WH)(1 - H/HMAX) UNIT/R/
                        R1S
                STCALL  GNUR
                        MUNGRAV
                EXIT
# Page 886
                TC      QUIKFAZ5

                CA      ZERO
RUPDATED        TC      GNURVST

VMEASCHK        TC      QUIKFAZ5        # RESTART AT NEXT LOCATION
                CS      FLGWRD11
                MASK    VELDABIT        # IS V READING AVAILABLE?
                CCS     A
                TCF     VALTCHK         # NO:  SEE IF V READING TO BE TAKEN

VELUPDAT        CS      VSELECT         # PROCESS VELOCITY DATA
                TS      L
                ADS     L               # -2 VSELECT IN L
                AD      L
                AD      L               # -6 VSELECT IN A
                INDEX   FIXLOC
                DXCH    X1              # X1 = -6 VSELECT, X2 = -2 VSELECT

                CA      EBANK4
                TS      EBANK
                EBANK=  LRXCDU
```

```
                CA      LRYCDU          # STORE LRCDUS IN CDUSPOTS
                TS      CDUSPOT
                CA      LRZCDU
                TS      CDUSPOT +2
                CA      LRXCDU
                TS      CDUSPOT +4

                TC      BANKCALL
                CADR    QUICTRIG        # GET SINES AND COSINES FOR NBSM

                CA      FIXLOC
                TS      PUSHLOC         # SET PD TO ZERO

                TC      INTPRET
                VLOAD*  CALL
                        VZBEAMNB,1      # CONVERT VBEAM FROM NB TO SM
                        *NBSM*
                PDDL    SL              # STORE IN PD 0-5
                        VMEAS           # LOAD VELOCITY MEASUREMENT
                        12D
                DMP*    PUSH            # SCALE TO M/CS AT 2(6)
                        VZSCAL,2        # AND STORE IN PD 6-7
                EXIT
                CS      ONE
                TS      MODE            # CHANGE STORE MODE TO VECTOR

                CA      PIPTEM          # STORE DELV IN MPAC
# Page 887
                ZL
                DXCH    MPAC

                CA      PIPTEM +1
                ZL
                DXCH    MPAC +3

                CA      PIPTEM +2
                ZL
                DXCH    MPAC +5

                CA      EBANK7
                TS      EBANK           # RESTORE EBANK 7
                EBANK=  DVCNTR
                TC      INTPRET
                VXSC    PDDL
                        KPIP1           # SCALE DELV TO 2(7) M/CS AND PUSH
                        LRVTIME         # TIME OF DELV AT 2(28) CS
```

```
                DSU     DDV
                        PIPTIME         # TU - T(N-1)
                        2SEC(28)
                VXSC    VSL1            # G(N-1)(TU - T(N-1))
                        GDT/2           # SCALED AT 2(7) M/CS
                VAD     VAD             # PUSH UP FOR DELV
                        V               # VU = V(N-1) + DELVU + G(N-1) DTU
                VSL2    VAD             # SCALE TO 2(5) M/CS AND SUBTRACT
                        DELVS           #       MOON ROTATION.
                PUSH    ABVAL           # STORE IN PD
                SR4     DAD             # ABS(VM)/8 + 7.5 AT 2(6)
                        7.5
                STOVL   20D             # STORE IN 20D AND PICK UP VM
                DOT     BDSU            # V(EST) AT 2(6)
                        0               # DELTAV = VMEAS - V(EST)
                PUSH    ABS
                DSU     EXIT            # ABS(DV) - (7.5 + ABS(VM)/8))
                        20D

                INCR    LRMCTR
                TC      BRANCH
                TCF     VFAIL           # DELTA V TOO LARGE.    ALARM
                TCF     VFAIL           # DELTA V TOO LARGE.    ALARM

                TC      DOWNFLAG        # TURN OFF VEL FAIL LAMP
                ADRES   VFLSHFLG

                CA      FLGWRD11
                MASK    VXINHBIT
                EXTEND
                BZF     VUPDAT          # IF VX INHIBIT RESET, INCORPORATE DATA.
# Page 888
                TC      DOWNFLAG
                ADRES   VXINH           # RESET VX INHIBIT

                CA      VSELECT
                AD      NEG2            # IF VSELECT = 2 (X AXIS).
                EXTEND                  # BYPASS UPDATE
                BZF     ENDVDAT

VUPDAT          CS      FLGWRD11
                MASK    LRINHBIT
                CCS     A
                TCF     VALTCHK         # UPDATE INHIBITED

                TS      MPAC +1
```

```
                CA      ABVEL           # STORE E7 ERASABLES NEEDED IN TEMPS
                TS      ABVEL*
                CA      VSELECT
                TS      VSELECT*
                CA      EBANK5
                TS      EBANK           # CHANGE EBANKS

                EBANK=  LRVF
                CS      LRVF
                AD      ABVEL*          # IF V < VF, USE WVF
                EXTEND
                BZMF    USEVF

                CS      ABVEL*
                AD      LRVMAX          # VMAX - V
                EXTEND
                BZMF    WSTOR -1        # IF V > VMAX, W = 0

                EXTEND
                INDEX   VSELECT*
                MP      LRWVZ           # WV(VMAX - V)

                EXTEND
                DV      LRVMAX          # WV( 1 - V/VMAX )
                TCF     WSTOR

USEVF           INDEX   VSELECT*
                CA      LRWVFZ          # USE APPROPRIATE CONSTANT WEIGHT
                TCF     WSTOR

        -1      CA      ZERO
WSTOR           TS      MPAC
                CS      BIT7            # (=64D)
                AD      MODREG
                EXTEND
# Page 889
                BZMF    +3              # IF IN P65,P66,P67, USE ANOTHER CONSTANT

                CA      LRWVFF
                TS      MPAC

        +3      CA      EBANK7
                TS      EBANK           # CHANGE EBANKS

                EBANK=  ABVEL
```

```
                TC      INTPRET
                DMP     VXSC            # W(DELTA V)(VBEAMSM) UP 6-7, 0-5
                VAD
                        V1S             # ADD WEIGHTED DELTA V TO VELOCITY
                STORE   GNUV
                EXIT

                TC      QUIKFAZ5        # DO NOT RE-UPDATE

                CA      SIX
VUPDATED        TC      GNURVST         # STORE NEW VELOCITY VECTOR
ENDVDAT         =       VALTCHK

VALTCHK         TC      QUIKFAZ5        # DO NOT REPEAT ABOVE

                CAF     READVBIT        # TEST READVEL TO SEE IF VELOCITY READING
                MASK    FLGWRD11        # IS DESIRED.
                CCS     A
                TCF     READV           # YES -- READ VELOCITY
                CS      ABVEL           # NO -- SEE IF VELOCITY < 2000 FT/SEC
                AD      2KFT/SEC
                EXTEND
                BZMF    CONTSERV        # V > 2000 FT/SEC  DO NOT READ VEL

                TC      UPFLAG          # V < 2000 FT/SEC  SET READVEL AND READ.
                ADRES   READVEL

READV           CAF     PRIO32          # SET UP JOB TO READ VELOCITY BEAMS.
                TC      NOVAC
                EBANK=  HMEAS
                2CADR   LRVJOB

                TCF     CONTSERV        # CONTINUE WITH SERVICER

GNURVST         TS      BUF             # STORE GNUR (=GNUV) IN R1S OR V1S
                EXTEND                  # A = 0 FOR R, A = 6 FOR V
                DCA     GNUR
                INDEX   BUF
                DXCH    R1S
                EXTEND
# Page 890
                DCA     GNUR +2
                INDEX   BUF
                DXCH    R1S +2
                EXTEND
                DCA     GNUR +4
```

```
                INDEX   BUF
                DXCH    R1S +4
                TC      Q

QUIKFAZ5        CA      EBANK3
                XCH     EBANK           # SET EBANK 3
                DXCH    L               # Q TO A, A TO L
                EBANK=  PHSNAME5
                TS      PHSNAME5
                LXCH    EBANK
                EBANK=  DVCNTR
                TC      A

HFAIL           CS      LRRCTR
                EXTEND
                BZF     NORLITE         # IF R = 0, DO NOT TURN ON TRK FAIL
                AD      LRLCTR
                MASK    NEG3
                EXTEND                  # IF L-R LT 4, DO NOT TURN ON TRK FAIL
                BZF     +2
                TCF     NORLITE

                TC      UPFLAG          # AND SET BIT TO TURN ON TRACKER FAIL LITE
                ADRES   HFLSHFLG

NORLITE         CA      LRLCTR
                TS      LRRCTR          # SET R = L

                TCF     VMEASCHK

VFAIL           CS      LRSCTR          # DELTA Q LARGE
                EXTEND                  # IF S = 0, DO NOT TURN ON TRACKER FAIL
                BZF     NOLITE
                AD      LRMCTR          # M-S
                MASK    NEG3            # TEST FOR M-S > 3
                EXTEND                  # IF M-S > 3, THEN TWO OR MORE OF THE
                BZF     +2              #       LAST FOUR V READINGS WERE BAD,
                TCF     NOLITE          #       SO TURN ON VELOCITY FAIL LIGHT

                TC      UPFLAG          # AND SET BIT TO TURN ON TRACKER FAIL LITE
                ADRES   VFLSHFLG

# Page 891
NOLITE          CA      LRMCTR          # SET S = M
                TS      LRSCTR
```

```
                CCS     VSELECT         # TEST FOR Z COMPONENT
                TCF     ENDVDAT         # NOT Z, DO NOT SET VX INHIBIT

                TC      UPFLAG          # Z COMPONENT - SET FLAG TO SKIP X
                ADRES   VXINH           # COMPONENT, AS ERROR MAY BE DUE TO CROSS
                TCF     ENDVDAT         # LOBE LOCK UP NOT DETECTED ON X AXIS.

# Page 892
# ******************************************************************************
# LRVJOB IS SET WHEN THE LEM IS BELOW 15000 FT DURING THE LANDING PHASE
# THIS JOB INITIALIZES THE LANDING RADAR READ ROUTINE FOR 5 VELOCITY
# SAMPLES AND GOES TO SLEEP WHILE THE SAMPLING IS DONE -- ABOUT 500 MS.
# WITH A GOODEND RETURN THE DATA IS STORED IN VMEAS AND BIT7 OF LRSTAT
# IS SET.  THE GIMBAL ANGLES ARE READ ABOUT MIDWAY IN THE SAMPLINGS.

170MS           EQUALS  ND1

LRVJOB          CA      170MS           # SET TASK TO READ CDUS + PIPAS
                TC      WAITLIST
                EBANK=  LRVTIME
                2CADR   RDGIMS

                CCS     VSELECT         # SEQUENCE LR VEL BEAM SELECTOR
                TCF     +2
                CAF     TWO             # IF ZERO, RESET TO TWO
                DOUBLE                  # 2XVSELECT USED FOR VBEAM INDEX IN LRVEL
                TC      BANKCALL        # GO INITIALIZE LR VEL READ ROUTINE
                CADR    LRVEL
                TC      BANKCALL        # PUT LRVJOB TO SLEEP ABOUT 500 MS
                CADR    RADSTALL
                TCF     VBAD
                CCS     STILBADV        # IS DATA GOOD JUST PRESENT?
                TCF     VSTILBAD        # JUST GOOD -- MUST WAIT 4 SECONDS.

                INHINT
                EXTEND                  # GOOD RETURN -- STOW AWAY VMEAS
                DCA     SAMPLSUM
                DXCH    VMEAS
                CA      EBANK4          # FOR DOWNLINK
                TS      EBANK
                EBANK=  LRVTIME

                EXTEND
                DCA     LRVTIME
                DXCH    LRVTIMDL
                EXTEND
```

```
                DCA     LRXCDU
                DXCH    LRXCDUDL
                CA      LRZCDU
                TS      LRZCDUDL
                CA      EBANK7
                TS      EBANK
                EBANK=  VSELECT

                CS      FLGWRD11        # SET BIT TO INDICATE VELOCITY
                MASK    VELDABIT        # MEASUREMENT MADE
# Page 893
                ADS     FLGWRD11
ENDLRV          CCS     VSELECT         # UPDATE VSELECT
                TCF     +2
                CA      TWO
                TS      VSELECT
                TCF     ENDOFJOB

VBAD            CAF     TWO             # SET STILBAD TO WAIT 4 SECONDS
VSTILBAD        TS      STILBADV
                TCF     ENDLRV

# LRHJOB IS SET BY LRHTASK WHEN LEM IS BELOW 25000 FT.  THIS JOB
# INITIALIZES THE LR READ ROUTINE FOR AN ALT MEASUREMENT AND GOES TO
# SLEEP WHILE THE SAMPLING IS DONE -- ABOUT 95 MS.  WITH A GOODEND RETURN
# THE ALT DATA IS STORED IN HMEAS AND BIT7 OF LRSTAT IS SET.

                BANK    34
                SETLOC  R12STUFF
                BANK

                COUNT*  $$/SERV

LRHJOB          TC      BANKCALL        # INITIATE LR ALT MEASUREMENT
                CADR    LRALT
                TC      BANKCALL        # LRHJOB TO SLEEP ABOUT 95MS
                CADR    RADSTALL
                TCF     HBAD
                CCS     STILBADH        # IS DATA GOOD JUST PRESENT?
                TCF     HSTILBAD        # JUST GOOD -- MUST WAIT 4 SECONDS.

                INHINT
                EXTEND
                DCA     SAMPLSUM        # GOOD RETURN -- STORE AWAY LRH DATA
                DXCH    HMEAS           # LRH DATA 1.079 FT/BIT
                EXTEND                  # FOR DOWNLINK
```

```
                DCA     PIPTIME1
                DXCH    MKTIME

                EXTEND
                DCA     CDUTEMPY        # CDUY,Z = AIG,AMG
                DXCH    AIG

                CA      CDUTEMPX        # CDUX = AOG
                TS      AOG

                CS      FLGWRD11        # SET BIT TO INDICATE RANGE
                MASK    RNGEDBIT        # MEASUREMENT MADE.
                ADS     FLGWRD11
ENDLRH          TC      ENDOFJOB        # TERMATE LRHJOB

# Page 894
HBAD            CA      FLAGWRD5
                MASK    RNGSCBIT        # IS BAD RETURN DUE TO SCALE CHANGE?
                EXTEND
                BZF     HSTILBAD -1     # NO  RESET HSTILBAD
                TC      DOWNFLAG        # YES  RESET SCALE CHANGE BIT AND IGNORE
                ADRES   RNGSCFLG
                TC      ENDOFJOB

                CAF     TWO             # SET STILBAD TO WAIT 4 SECONDS
HSTILBAD        TS      STILBADH
                TC      ENDOFJOB

                BANK    34
                SETLOC  SERV4
                BANK

                COUNT*  $$/SERV

# RDGIMS IS A TASK SET UP BY LRVJOB TO PICK UP THE IMU CDUS AND TIME
# AT ABOUT THE MIDPOINT OF THE LR VEL READ ROUTINE WHEN 5 VEL SAMPLES
# ARE SPECIFIED.

                EBANK=  LRVTIME
RDGIMS          EXTEND
                DCA     TIME2           # PICK UP TIME2, TIME1
                DXCH    LRVTIME         #       AND SAVE IN LRVTIME

                EXTEND
                DCA     CDUX            # PICK UP CDUX AND CDUY
                DXCH    LRXCDU          #       AND SAVE IN LRXCDU AND LRYCDU
```

```
                CA      CDUZ
                TS      LRZCDU          # SAVE CDUZ IN LRZCDU

                CA      PIPAX
                TS      PIPTEM          # SAVE PIPAX IN PIPTEM

                EXTEND
                DCA     PIPAY           # PICK UP PIPAY AND PIPAZ
                DXCH    PIPTEM +1       #       AND SAVE IN PIPTEM +1 AND PIPTEM +2
                TC      TASKOVER

                BANK    33
                SETLOC  SERVICES
                BANK

                COUNT*  $$/SERV

                EBANK=  DVCNTR
# Page 895
# HIGATJOB IS SET APPROXIMATELY 6 SECONDS PRIOR TO HIGH GATE DURING
# THE DESCENT BURN PHASE OF LUNAR LANDING.  THIS JOB INITIATES THE
# LANDING RADAR REPOSITIONING ROUTINE AND GOES TO SLEEP UNTIL THE
# LR ANTENNA MOVES FROM POSITION 1 TO POSITION 2.  IF THE LR ANTENNA
# ACHIEVES POSITION 2 WITHIN 22 SECONDS THE ALTITUDE AND VELOCITY
# BEAM VECTORS ARE RECOMPUTED TO REFLECT THE NEW ORIENTATION WITH
# RESPECT TO THE NB.  BIT10 OF LRSTAT IS CLEARED TO ALLOW LR
# MEASUREMENTS AND THE JOB TERMINATES.

HIGATJOB        TC      BANKCALL        # START LRPOS2 JOB
                CADR    LRPOS2
                TC      BANKCALL        # PUT HIGATJOB TO SLEEP UNTIL JOB IS DONE
                CADR    RADSTALL
                TCF     POSALARM        # BAD END    ALARM

POSGOOD         CA      PRIO23          # REDUCE PRIORITY FOR INTERPRETIVE COMPS.
                TC      PRIOCHNG

                TC      SETPOS2         # LR IN POS2 -- SET UP TRANSFORMATIONS

                TC      DOWNFLAG
                ADRES   NOLRREAD        # RESET NOLRREAD FLAG TO ENABLE LR READING
                TC      ENDOFJOB

POSALARM        CA      OCT523
                TC      BANKCALL
```

```
                CADR    PRIOLARM        # FLASH ALARM CODE
                TCF     GOTOP00H        # TERMINATE
                TCF     +3              # PROCEED -- TRY AGAIN
                TCF     ENDOFJOB        # V 32 E    TERMINATE R12
                TC      ENDOFJOB

        +3      CA      BIT7            # SEE IF IN POS2 YET
                EXTEND
                RAND    CHAN33
                EXTEND
                BZF     POSGOOD         # POS2 ACHIEVED   SET UP ANTENNA BEAMS
                TCF     POSALARM        # STILL DIDN'T MAKE IT   REALARM

OCT523          OCT     00523



SETPOS1         TC      MAKECADR        # MUST BE CALLED BY BANKCALL
                TS      LRADRET1        # SAVE RETURN CADR.  SINCE BUP2 CLOBBERED

                CAF     TWO
                TS      STILBADH        # INITIALIZE STILBAD
                TS      STILBADV        # INITIALIZE STILBAD

                CA      ZERO            # INDEX FOR LRALPHA, LRBETA IN POS 1.
# Page 896
                TS      LRLCTR          # SET L,M,R, ANS S TO ZERO
                TS      LRMCTR
                TS      LRRCTR
                TS      LRSCTR
                TS      VSELECT         # INITIALIZE VSELECT

                TC      SETPOS          # CONTINUE WITH COMPUTATIONS.

                CA      LRADRET1
                TC      BANKJUMP        # RETURN TO CALLER

SETPOS2         CA      TWO             # INDEX FOR POS2
SETPOS          XCH     Q               # SAVE INDEX IN Q
                TS      LRADRET         # SAVE RETURN

                CA      EBANK5
                TS      EBANK
                EBANK=  LRALPHA

                EXTEND
```

```
INDEX   Q
DCA     LRALPHA         # LRALPHA IN A, LRBETA IN L
TS      CDUSPOT +4      # ROTATION ABOUT X
LXCH    CDUSPOT         # ROTATION ABOUT Y
CA      ZERO
TS      CDUSPOT +2      # ZERO ROTATION ABOUT Z.

CA      EBANK7
TS      EBANK
EBANK=  LRADRET

TC      INTPRET
VLOAD   CALL
        UNITY           # CONVERT UNITY(ANTENNA) TO NB
        TRG*SMNB
STOVL   VYBEAMNB
        UNITX           # CONVERT UNITX(ANTENNA) TO NB
CALL
        *SMNB*
STORE   VXBEAMNB
VXV     VSL1
        VYBEAMNB
STOVL   VZBEAMNB        # Z = X * Y
        HBEAMANT
CALL
        *SMNB*          # CONVERT TO NB
STORE   HBEAMNB
EXIT

# Page 897
TC      LRADRET
```

Uses -PHASE1 152, -PHASE2 152, -PHASE3 152, -PHASE4 152, -PHASE5 152, -PHASE6 152, 1/PIPADT 156, A 80, AIG 214, ALT 157, AMG 214, AOG 214, AVEGFLAG 101, AVGEXIT 159, BUF 142, BUF2 142, CDUS 80, CDUSPOT 152, CDUSPOTX 152, CDUSPOTY 152, CDUSPOTZ 152, CDUX 80, CDUY 80, CDUZ 80, CHAN12 87, CHAN32 87, CHAN33 87, CODE 140, COUNT 142, D 226, DELTAR 183, DELV 159, DELVREF 224, DELVX 159, DELVY 159, DELVZ 159, DISPLAYS 59, DRFTBIT 101, DRIFTFLG 101, DSALMOUT 87, DV 241, DVCNTR 224, DVTOTAL 224, EBANK 80, FACTOR 226, FIXLOC 140, FLAGWRD2 101, FLAGWRD3 105, FLAGWRD5 113, FLAGWRD6 117, FLAGWRD7 121, FLAGWRD8 125, FLGWRD10 133, FLGWRD11 135, GDT/2 159, GDT1/2 159, H 177, HDOT 231, HDOTDISP 221, IT 185, ITEMP1 138, L 80, LOC 145, MASS 200, MODE 145, MODREG 154, MPAC 145, MPTEMP 142, N 206, NBDX 167, PHASE1 152, PHASE2 152, PHASE3 152, PHASE4 152, PHASE5 152, PHASE6 152, PHSNAME5 167, PIPAGE 159, PIPAX 80, PIPAY 80, PIPAZ 80, PIPCTR 159, PIPTIME 159, PIPTIME1 159, PRIORITY 145, PUSHLOC 145, Q 80, RANGE 179, REFSMMAT 172, RESTART 57, RN 159, RN1 159, RNGSCFLG 115, RUN 191, SAVE 191, SERVICES 69, SQ 156, STATE 138, STEERBIT 103, STEERSW 103, SURFFBIT 127, TBASE2 154, TBASE5 154, TC 169, TEMP 191, TEMX 159, TEMY 159, TEMZ 159, THRUST 85, TIME1 80, TIME2 80, TIME5 80, V 229, V37FLAG 123, VEL 226, VMAX 175, VN 159, VN1 159, W 183, X1 85, X2 85, and Z 80.

4.25 landing analog displays

2419 ⟨*landing analog displays* 2419⟩≡ (2041)

⟨*Page LM0898* 2420⟩
⟨*Page LM0899* 2422⟩
⟨*Page LM0900* 2424⟩
⟨*Page LM0901* 2426⟩
⟨*Page LM0902* 2428⟩
⟨*Page LM0903* 2430⟩
⟨*Page LM0904* 2432⟩
⟨*Page LM0905* 2434⟩
⟨*Page LM0906* 2436⟩
⟨*Page LM0907* 2438⟩

2420 ⟨*Page LM0898* 2420⟩≡ (2419 2735)

```
                BANK    21
                SETLOC  R10
                BANK

                EBANK=  UNIT/R/
                COUNT*  $$/R10

LANDISP         LXCH    PIPCTR1         # UPDATE TBASE2 AND PIPCTR SIMULTANEOUSLY.
                CS      TIME1
                DXCH    TBASE2

                CS      FLAGWRD7        # IS LANDING ANALOG DISPLAYS FLAG SET?
                MASK    SWANDBIT
                CCS     A
                TCF     DISPRSET        # NO.
                CA      IMODES33        # BIT 7 = 0 (DO ALTRATE), =1 (DO ALT.)
                MASK    BIT7
                CCS     A
                TCF     ALTOUT
ALTROUT         TC      DISINDAT        # CHECK MODE SELECT SWITCH AND DIDFLG.
                CS      IMODES33
                MASK    BIT7
                ADS     IMODES33        # ALTERNATE ALTITUDE RATE WITH ALTITUDE.
                CAF     BIT2            # RATE COMMAND IS EXECUTED BEFORE RANGE.
                EXTEND
                WOR     CHAN14          # ALTRATE (BIT2 = 1), ALTITUDE (BIT2 = 0).
ARCOMP          CA      RUNIT           # COMPUTE ALTRATE = RUNIT.VVECT M/CS *(-6).
                EXTEND
                MP      VVECT           # MULTIPLY X-COMPONENTS.
                XCH     RUPTREG1        # SAVE SINGLE PRECISION RESULT M/CS*2(-6)
                CA      RUNIT +1        # MULTIPLY Y-COMPONENTS.
                EXTEND
                MP      VVECT +1
                ADS     RUPTREG1        # ACCUMULATE PARTIAL PRODUCTS.
                CA      RUNIT +2        # MULTIPLY Z-COMPONENTS.
                EXTEND
                MP      VVECT +2
                ADS     RUPTREG1        # ALTITUDE RATE IN M/CS *2(-6).
                CA      ARCONV          # CONVERT ALTRATE TO BIT UNITS (.5FPS/BIT)
                EXTEND
                MP      RUPTREG1
                DDOUBL
                DDOUBL
                XCH     RUPTREG1        # ALTITUDE RATE IN BIT UNITS*2(-14).
                CA      DALTRATE        # ALTITUDE RATE COMPENSATION FACTOR.
```

```
EXTEND
MP      DT
AD      RUPTREG1
TS      ALTRATE         # ALTITUDE RATE IN BIT UNITS*2(-14).
CS      ALTRATE
```

Uses A 80, ALT 157, CHAN14 87, COMMAND 169, COUNT 142, DISPLAYS 59, EBANK 80, FACTOR 226, FLAGWRD7 121, IMODES33 163, MODE 145, PIPCTR 159, RANGE 179, RUPTREG1 138, SAVE 191, TBASE2 154, TC 169, TIME1 80, and Z 80.

2422 ⟨*Page LM0899* 2422⟩≡ (2419 2735)

```
                EXTEND                  # CHECK POLARITY OF ALTITUDE RATE.
                BZMF    +2
                TCF     DATAOUT         # NEGATIVE -- SEND POS. PULSES TO ALTM REG.
                CA      ALTRATE         # POSITIVE OR ZERO -- SET SIGN BIT = 1 AND
                AD      BIT15           # SEND TO ALTM REGISTER.  *DO NOT SEND +0*
DATAOUT         TS      ALTM            # ACTIVATE THE LANDING ANALOG DISPLAYS
                CAF     BIT3
                EXTEND
                WOR     CHAN14          # BIT3 DRIVES THE ALT/ALTRATE METER.
                TCF     TASKOVER        # EXIT

ALTOUT          TC      DISINDAT        # CHECK MODE SELECT SWITCH AND DIDFLG.
                CS      BIT7
                MASK    IMODES33
                TS      IMODES33        # ALTERNATE ALTITUDE RATE WITH ALTITUDE.
                CS      BIT2
                EXTEND
                WAND    CHAN14
                CCS     ALTBITS         # = -1 IF OLD ALT. DATA TO BE EXTRAPOLATED.
                TCF     +4
                TCF     +3
                TCF     OLDDATA
                TS      ALTBITS         # SET ALTBITS FROM -0 TO +0.
                CS      ONE
                DXCH    ALTBITS         # SET ALTBITS = -1 FOR SWITCH USE NEXT PASS.
                DXCH    ALTSAVE
                CA      BIT10           # NEW ALTITUDE EXTRAPOLATION WITH ALTRATE.
                XCH     Q
                LXCH    7               # ZL
                CA      DT
                EXTEND
                DV      Q               # RESCALE DT*2(-14) TO *2(-9) TIME IN CS.
                EXTEND
                MP      ARTOA2          # .0021322 *2(+8)
                TCF     OLDDATA +1      # RATE APPLIES FOR DT CS.

ZDATA2          DXCH    ALTSAVE
                TCF     NEWDATA
OLDDATA         CA      ARTOA           # RATE APPLIES FOR .5 SEC. (4X/SEC. CYCLE)
                EXTEND
                MP      ALTRATE         # EXTRAPOLATE WITH ALTITUDE RATE.
                DDOUBL
                AD      ALTSAVE +1
                TS      ALTSAVE +1
                CAF     ZERO
```

```
ADS     ALTSAVE
CAF     POSMAX          # FORCE SIGN AGREEMENT ASSUMING A
AD      ONE             # NON-NEGATIVE ALTSAVE.
AD      ALTSAVE +1      # IF ALTSAVE IS NEGATIVE, ZERO ALTSAVE
TS      ALTSAVE +1      # AND ALTSAVE +1 AT ZERODATA.
```

Uses A 80, ALT 157, CHAN14 87, DISPLAYS 59, DV 241, IMODES33 163, MODE 145, Q 80, and TC 169.

2424 ⟨*Page LM0900* 2424⟩≡ (2419 2735)

```
                CAF     ZERO
                AD      POSMAX
                AD      ALTSAVE
                TS      ALTSAVE         # POSSIBLY SKIP TO NEWDATA.
                TCF     ZERODATA
NEWDATA         CCS     ALTSAVE +1
                TCF     +4
                TCF     +3
                CAF     ZERO            # SET NEGATIVE ALTSAVE +1 TO +0.
                TS      ALTSAVE +1
                CCS     ALTSAVE         # PROVIDE A 15 BIT UNSIGNED OUTPUT.
                CAF     BIT15           # THE HI-ORDER PART IS +1 OR +0.
                AD      ALTSAVE +1
                TCF     DATAOUT         # DISPATCH UNSIGNED BITS TO ALTM REG.
DISINDAT        EXTEND
                QXCH    LADQSAVE        # SAVE RETURN TO ALTROUT +1 OR ALTOUT +1
                CAF     BIT6
                EXTEND                  # WISHETH THE ASTRONAUT THE ANALOG
                RAND    CHAN30          # DISPLAYS?  I.E.,
                CCS     A               # IS THE MODE SELECT SWITCH IN PGNCS?
                TCF     DISPRSET        # NO.  ASTRONAUT REQUESTS NO INERTIAL DATA
                CS      FLAGWRD1        # YES.  CHECK STATUS OF DIDFLAG.
                MASK    DIDFLBIT
                EXTEND
                BZF     SPEEDRUN        # SET.  PERFORM DATA DISPLAY SEQUENCE.
                CS      FLAGWRD1        # RESET.  PERFORM INITIALIZATION FUNCTIONS.
                MASK    DIDFLBIT
                ADS     FLAGWRD1        # SET DIDFLAG.
                CS      BIT7
                MASK    IMODES33        # TO DISPLAY ALTRATE FIRST AND ALT. SECOND
                TS      IMODES33
                CS      FLAGWRD0        # ARE WE IN DESCENT TRAJECTORY?
                MASK    R10FLBIT
                EXTEND
                BZF     TASKOVER        # NO
                CAF     BIT8            # YES.
                EXTEND
                WOR     CHAN12          # SET DISPLAY INERTIAL DATA OUTBIT.
                CAF     ZERO
                TS      TRAKLATV        # LATERAL VELOCITY MONITOR FLAG
                TS      TRAKFWDV        # FORWARD VELOCITY MONITOR FLAG
                TS      LATVMETR        # LATVEL MONITOR METER
                TS      FORVMETR        # FORVEL MONITOR METER
                CAF     BIT4
                TC      TWIDDLE
```

```
                ADRES   INTLZE
                TCF     TASKOVER
  INTLZE        CAF     BIT2
                EXTEND
                WOR     CHAN12          # ENABLE RR ERROR COUNTER.
```

Uses A 80, ALT 157, CHAN12 87, CHAN30 87, DISPLAYS 59, FLAGWRD0 95, FLAGWRD1 97, I 206, IMODES33 163, MODE 145, SAVE 191, and TC 169.

2426 ⟨*Page LM0901* 2426⟩≡ (2419 2735)

```
                    CS      IMODES33
                    MASK    BIT8
                    ADS     IMODES33        # SET INERTIAL DATA FLAG.
                    TCF     TASKOVER

  SPEEDRUN          CS      PIPTIME +1      # UPDATE THE VELOCITY VECTOR
                    AD      TIME1           # COMPUTE T - TN
                    AD      HALF            # CORRECT FOR POSSIBLE OVERFLOW OF TIME1.
                    AD      HALF
                    XCH     DT              # SAVE FOR LATER USE
                    CA      1SEC
                    TS      ITEMP5          # INITIALIZE FOR DIVISION LATER
                    EXTEND
                    DCA     GDT/2           # COMPUTE THE X-COMPONENT OF VELOCITY.
                    DDOUBL
                    DDOUBL
                    EXTEND
                    MP      DT
                    EXTEND
                    DV      ITEMP5
                    XCH     VVECT           # VVECT = G(T-TN) M/CS *2(-5)
                    EXTEND
                    DCA     V               # M/CS *2(-7)
                    DDOUBL                  # RESCALE TO 2(-5)
                    DDOUBL
                    ADS     VVECT           # VVECT = VN + G(T-TN) M/CS *2(-5)
                    CA      PIPAX           # DELV CM/SEC *2(-14)
                    AD      PIPATMPX        # IN CASE PIPAX HAS BEEN ZEROED
                    EXTEND
                    MP      KPIP1(5)        # DELV M/CS *2(-5)
                    ADS     VVECT           # VVECT = VN + DELV + GN(T-TN) M/CS *2(-5)
                    EXTEND
                    DCA     GDT/2 +2        # COMPUTE THE Y-COMPONENT OF VELOCITY.
                    DDOUBL
                    DDOUBL
                    EXTEND
                    MP      DT
                    EXTEND
                    DV      ITEMP5
                    XCH     VVECT +1
                    EXTEND
                    DCA     V +2
                    DDOUBL
                    DDOUBL
                    ADS     VVECT +1
```

```
CA      PIPAY
AD      PIPATMPY
EXTEND
MP      KPIP1(5)
ADS     VVECT +1
```

Uses DELV 159, DV 241, GDT/2 159, IMODES33 163, ITEMP5 138, PIPAX 80, PIPAY 80, PIPTIME 159, SAVE 191, TIME1 80, V 229, and VN 159.

2428 ⟨*Page LM0902* 2428⟩≡ (2419 2735)

```
EXTEND
DCA     GDT/2 +4        # COMPUTE THE Z-COMPONENT OF VELOCITY.
DDOUBL
DDOUBL
EXTEND
MP      DT
EXTEND
DV      ITEMP5
XCH     VVECT +2
EXTEND
DCA     V +4
DDOUBL
DDOUBL
ADS     VVECT +2
CA      PIPAZ
AD      PIPATMPZ
EXTEND
MP      KPIP1(5)
ADS     VVECT +2

CAF     BIT3            # PAUSE 40 MS TO LET OTHER RUPTS IN.
TC      VARDELAY

CS      FLAGWRD0        # ARE WE IN DESCENT TRAJECTORY?
MASK    R10FLBIT
CCS     A
TCF     +2              # YES.
TC      LADQSAVE        # NO.

CA      DELVS           # HI X OF VELOCITY CORRECTION TERM.
AD      VVECT           # HI X OF UPDATED VELOCITY VECTOR.
TS      ITEMP1          # = VX - DVX M/CS *2(-5).
CA      DELVS +2        #    Y
AD      VVECT +1        #    Y
TS      ITEMP2          # = VY - DVY M/CS *2(-5)
CA      DELVS +4        #    Z
AD      VVECT +2        #    Z
TS      ITEMP3          # = VZ - DVZ M/CS *2(-5)
CA      ITEMP1          # COMPUTE VHY, VELOCITY DIRECTED ALONG THE
EXTEND                  # Y-COORDINATE.
MP      UHYP            # HI X OF CROSS-RANGE HALF-UNIT VECTOR
XCH     RUPTREG1
CA      ITEMP2
EXTEND
MP      UHYP +2         # Y
```

```
ADS     RUPTREG1        # ACCUMULATE PARTIAL PRODUCTS.
CA      ITEMP3
EXTEND
MP      UHYP +4         # Z
ADS     RUPTREG1
```

Uses A 80, DV 241, FLAGWRD0 95, GDT/2 159, ITEMP1 138, ITEMP2 138, ITEMP3 138, ITEMP5 138, PIPAZ 80, RANGE 179, RUPTREG1 138, TC 169, V 229, and Z 80.

2430 ⟨*Page LM0903* 2430⟩≡ (2419 2735)

```
                    CA      RUPTREG1
                    DOUBLE
                    XCH     VHY             # VHY=VMP.UHYP M/CS*2(-5).
                    CA      ITEMP1          # NO COMPUTE VHZ, VELOCITY DIRECTED ALONG
                    EXTEND                  # THE Z-COORDINATE.
                    MP      UHZP            # HI X OF DOWN-RANGE HALF-UNIT VECTOR.
                    XCH     RUPTREG1
                    CA      ITEMP2
                    EXTEND
                    MP      UHZP +2         # Y
                    ADS     RUPTREG1        # ACCUMULATE PARTIAL PRODUCTS.
                    CA      ITEMP3
                    EXTEND
                    MP      UHZP +4         # Z
                    ADS     RUPTREG1
                    CA      RUPTREG1
                    DOUBLE
                    XCH     VHZ             # VHZ = VMP.UHZP M/CS*2(-5).
GET22/32            CAF     EBANK6          # GET SIN(AOG),COS(AOG) FROM GPMATRIX.
                    TS      EBANK
                    EBANK=  M22
                    CA      M22
                    TS      ITEMP3
                    CA      M32
                    TS      ITEMP4
                    CAF     EBANK7
                    TS      EBANK
                    EBANK=  UNIT/R/
LATFWDV             CA      ITEMP4          # COMPUTE LATERAL AND FORWARD VELOCITIES.
                    EXTEND
                    MP      VHY
                    XCH     RUPTREG1
                    CA      ITEMP3
                    EXTEND
                    MP      VHZ
                    ADS     RUPTREG1        # = VHY(COS)AOG+VHZ(SIN)AOG M/CS *2(-5)
                    CA      VELCONV         # CONVERT LATERAL VELOCITY TO BIT UNITS.
                    EXTEND
                    MP      RUPTREG1
                    DDOUBL
                    XCH     LATVEL          # LATERAL VELOCITY IN BIT UNITS *2(-14).
                    CA      ITEMP4          # COMPUTE FORWARD VELOCITY.
                    EXTEND
                    MP      VHZ
                    XCH     RUPTREG1
```

```
CA      ITEMP3
EXTEND
MP      VHY
CS      A
ADS     RUPTREG1        # =VHZ(COS)AOG-VHY(SIN)AOG M/CS *2(-5).
```

Uses A 80, AOG 214, EBANK 80, ITEMP1 138, ITEMP2 138, ITEMP3 138, ITEMP4 138, RANGE 179, RUPTREG1 138, and Z 80.

2432 ⟨*Page LM0904* 2432⟩≡ (2419 2735)

```
                    CA      VELCONV         # CONVERT FORWARD VELOCITY TO BIT UNITS.
                    EXTEND
                    MP      RUPTREG1
                    DDOUBL
                    XCH     FORVEL          # FORWARD VELOCITY IN BIT UNITS *2(-14).

                    CS      MAXVBITS        # ACC.=-199.9989 FT./SEC.
                    TS      ITEMP6          # -547 BIT UNITS (OCTAL) AT 0.5571 FPS/BIT

                    CAF     ONE             # LOOP TWICE.
VMONITOR            TS      ITEMP5          # FORWARD AND LATERAL VELOCITY LANDING
                    INDEX   ITEMP5          #       ANALOG DISPLAYS MONITOR.
                    CCS     LATVEL
                    TCF     +4
                    TCF     LVLIMITS
                    TCF     +8D
                    TCF     LVLIMITS
                    INDEX   ITEMP5
                    CS      LATVEL
                    AD      MAXVBITS        # +199.9989 FT.SEC.
                    EXTEND
                    BZMF    CHKLASTY
                    TCF     LVLIMITS
                    INDEX   ITEMP5
                    CA      LATVEL
                    AD      MAXVBITS
                    EXTEND
                    BZMF    +2
                    TCF     LVLIMITS
CHKLASTY            INDEX   ITEMP5
                    CCS     LATVMETR
                    TCF     +4
                    TCF     LASTOK
                    TCF     +7
                    TCF     LASTOK
                    INDEX   ITEMP5
                    CA      LATVEL
                    EXTEND
                    BZMF    LASTPOSY +5
                    TCF     +5
                    INDEX   ITEMP5
                    CS      LATVEL
                    EXTEND
                    BZMF    LASTNEGY +4
LASTOK              INDEX   ITEMP5
```

```
CCS     TRAKLATV
TCF     LASTPOSY
TCF     +2
TCF     LASTNEGY
INDEX   ITEMP5
```

Uses DISPLAYS 59, ITEMP5 138, ITEMP6 138, and RUPTREG1 138.

2434 ⟨*Page LM0905* 2434⟩≡ (2419 2735)

```
                    CA      LATVEL
                    EXTEND
                    BZMF    NEGVMAXY
                    TCF     POSVMAXY
LASTPOSY            INDEX   ITEMP5
                    CA      LATVEL
                    EXTEND
                    BZMF    +2
                    TCF     POSVMAXY
                    CS      MAXVBITS
                    TCF     ZEROLSTY
POSVMAXY            INDEX   ITEMP5
                    CS      LATVMETR
                    AD      MAXVBITS
                    INDEX   ITEMP5
                    XCH     RUPTREG3
                    CAF     ONE
                    TCF     ZEROLSTY +3
LASTNEGY            INDEX   ITEMP5
                    CA      LATVEL
                    EXTEND
                    BZMF    NEGVMAXY
                    CA      MAXVBITS
                    TCF     ZEROLSTY
NEGVMAXY            INDEX   ITEMP5
                    CA      LATVMETR
                    AD      MAXVBITS
                    COM
                    INDEX   ITEMP5
                    XCH     RUPTREG3
                    CS      ONE
                    TCF     ZEROLSTY +3
LVLIMITS            INDEX   ITEMP5
                    CCS     TRAKLATV
                    TCF     LATVPOS
                    TCF     +2
                    TCF     LATVNEG
                    INDEX   ITEMP5
                    CS      LATVMETR
                    EXTEND
                    BZMF    +2
                    TCF     NEGLMLV
                    INDEX   ITEMP5

                    CS      LATVEL
```

```
EXTEND
BZMF    LVMINLM
AD      ITEMP6
INDEX   ITEMP5
AD      LATVMETR
EXTEND
```

Uses ITEMP5 138, ITEMP6 138, and RUPTREG3 138.

2436 ⟨*Page LM0906* 2436⟩≡ (2419 2735)

```
                    BZMF    LVMINLM
                    INDEX   ITEMP5
                    AD      LATVEL
                    EXTEND
                    INDEX   ITEMP5
                    SU      LATVMETR
                    TCF     ZEROLSTY
  LATVPOS           INDEX   ITEMP5
                    CS      LATVEL
                    EXTEND
                    BZMF    LVMINLM
                    TCF     +5
  LATVNEG           INDEX   ITEMP5
                    CA      LATVEL
                    EXTEND
                    BZMF    LVMINLM
                    INDEX   ITEMP5
                    CS      LATVMETR
                    TCF     ZEROLSTY
  NEGLMLV           INDEX   ITEMP5
                    CA      LATVEL
                    EXTEND
                    BZMF    LVMINLM
                    CA      MAXVBITS
                    INDEX   ITEMP5
                    AD      LATVMETR
                    COM
                    INDEX   ITEMP5
                    AD      LATVEL
                    EXTEND
                    BZMF    LVMINLM
                    EXTEND
                    INDEX   ITEMP5
                    SU      LATVEL
                    INDEX   ITEMP5
                    AD      LATVMETR
                    COM
                    TCF     ZEROLSTY
  LVMINLM           INDEX   ITEMP5
                    CS      LATVMETR
                    INDEX   ITEMP5
                    AD      LATVEL
  ZEROLSTY          INDEX   ITEMP5
                    XCH     RUPTREG3
                    CAF     ZERO
```

```
INDEX   ITEMP5
TS      TRAKLATV
INDEX   ITEMP5
CA      RUPTREG3
AD      NEG0            # AVOIDS +0 DINC HARDWARE MALFUNCTION
```

Uses ITEMP5 138 and RUPTREG3 138.

2438 ⟨*Page LM0907* 2438⟩≡ (2419 2735)

```
                INDEX   ITEMP5
                TS      CDUTCMD
                INDEX   ITEMP5
                CA      RUPTREG3
                INDEX   ITEMP5
                ADS     LATVMETR
                CCS     ITEMP5          # FIRST MONITOR FORWARD THEN LATERAL VEL.
                TCF     VMONITOR

                CAF     BITSET          # DRIVE THE X-POINTER DISPLAY.
                EXTEND
                WOR     CHAN14
                TC      LADQSAVE        # GO TO ALTROUT +1 OR TO ALTOUT +1
ZERODATA        CAF     ZERO            # ZERO ALTSAVE AND ALTSAVE +1
                TS      L               #       NO NEGATIVE ALTITUDES ALLOWED.
                TCF     ZDATA2

# ****************************************************************************

DISPRSET        CS      FLAGWRD0        # ARE WE IN DESCENT TRAJECTORY?
                MASK    R10FLBIT
                EXTEND
                BZF     ABORTON         # NO.
                CAF     BIT8            # YES.
                MASK    IMODES33        # CHECK IF INERTIAL DATA JUST DISPLAYED.
                CCS     A
                CAF     BIT2            # YES. DISABLE RR ERROR COUNTER
                AD      BIT8            # NO.  REMOVE DISPLAY INERTIAL DATA
                COM
                EXTEND
                WAND    CHAN12
ABORTON         CS      BITS8/7         # RESET INERTIAL DATA, INTERLEAVE FLAGS.
                MASK    IMODES33
                TS      IMODES33
                CS      DIDFLBIT
                MASK    FLAGWRD1
                TS      FLAGWRD1        # RESET DIDFLAG.
                TCF     TASKOVER

# ****************************************************************************

BITS8/7         OCT     00300           # INERTIAL DATA AND INTERLEAVE FLAGS.
BITSET          =       PRIO6

# ****************************************************************************
```

Uses A 80, CDUTCMD 85, CHAN12 87, CHAN14 87, FLAGWRD0 95, FLAGWRD1 97, IMODES33 163, ITEMP5 138, L 80, RUPTREG3 138, TC 169, and VEL 226.

4.26 findcduw-guidap interface

2439 ⟨*findcduw-guidap interface* 2439⟩≡ (2041)

⟨*Page LM0908* 2440⟩
⟨*Page LM0909* 2441⟩
⟨*Page LM0910* 2442⟩
⟨*Page LM0911* 2443⟩
⟨*Page LM0912* 2444⟩
⟨*Page LM0913* 2445⟩
⟨*Page LM0914* 2446⟩
⟨*Page LM0915* 2447⟩
⟨*Page LM0916* 2448⟩
⟨*Page LM0917* 2450⟩
⟨*Page LM0918* 2452⟩
⟨*Page LM0919* 2453⟩
⟨*Page LM0920* 2454⟩
⟨*Page LM0921* 2455⟩
⟨*Page LM0922* 2456⟩
⟨*Page LM0923* 2457⟩
⟨*Page LM0924* 2458⟩
⟨*Page LM0925* 2459⟩

2440 ⟨*Page LM0908* 2440⟩≡ (2439 2695)

```
# PROGRAM NAME:  FINDCDUW
# MOD NUMBER:  1        68-07-15
# MOD AUTHOR:  KLUMPP
#
# OBJECTS OF MOD:       1.      TO SUPPLY COMMANDED GIMBAL ANGLES FOR NOUN 22.
#                       2.      TO MAINTAIN CORRECT AND CURRENT THRUST
#                               DIRECTION DATA IN ALL MODES.  THIS IS DONE BY
#                               FETCHING FOR THE THRUST DIRECTION FILTER THE
#                               CDUD'S IN PNGCS-AUTO, THE CDU'S IN ALL OTHER
#                               MODES.
#                       3.      TO SUBSTITUDE A STOPRATE FOR THE NORMAL
#                               AUTOPILOT COMMANDS WHENEVER
#                               1) NOT IN PNGCS-AUTO, OR
#                               2) ENGINE IS OFF.
#
# FUNCTIONAL DESCRIPTION:
#
# FINDCDUW PROVIDES THE INTERFACES BETWEEN THE VARIOUS POWERED FLITE GUIDANCE PROGRAM
# AND THE DIGITAL AUTOPILOT.  THE INPUTS TO FINDCDUW ARE THE THRUST COMMAND VECTOR
# AND THE WINDOW COMMAND VECTOR, AND THE OUTPUTS ARE THE GIMBAL ANGLE
# INCREMENTS, THE COMMANDED ATTITUDE ANGLE RATES, AND THE COMMANDED
# ATTITUDE LAG ANGLES (WHICH ACCOUNT FOR THE ANGLES BY WHICH THE BODY WILL
# LAG BEHIND A RAMP COMMAND IN ATTITUDE ANGLE DUE TO THE FINITE ANGULAR
# ACCELERATIONS AVAILABLE).
#
# FINDCDUW ALIGNS THE ESTIMATED THRUST VECTOR FROM THE THRUST DIRECTION
# FILTER WITH THE THRUST COMMAND VECTOR, AND, WHEN XDVINHIB SET,
# ALIGNS THE +Z HALF OF THE LM ZX PLANE WITH THE WINDOW COMMAND VECTOR.
#
```

Uses A 80, COMMAND 169, THRUST 85, and Z 80.

2441 ⟨*Page LM0909* 2441⟩≡ (2439 2695)

```
# SPECIFICATIONS:
#
# INITIALIZATION:       A SINGLE INTERPRETIVE CALL TO INITCDUW IS REQUIRED
#                       BEFORE EACH GUIDED MANEUVER USING FINDCDUW.
#
# CALL:                 INTERPRETIVE CALL TO FINDCDUW WITH THE THRUST COMMAND
#                       VECTOR IN MPAC.  INTERPRETIVE CALL TO FINDCDUW -2 WITH
#                       THE THRUST COMMAND VECTOR IN UNFC/2 AND NOT IN MPAC.
#
# RETURNS:              NORMAL INTERPRETIVE IN ALL CASES
#                       1.      NORMALLY ALL AUTOPILOT CMDS ARE ISSUED.
#                       2.      IF NOT PNGCS AUTO, DO STOPRATE AND RETURN
#                               WITHOUT ISSUING AUTOPILOT CMDS.
#                       3.      IF ENGINE OFF, DO STOPRATE AND RETURN WITHOUT
#                               ISSUING AUTOPILOT CMDS.
#
# ALARMS:               00401   IF INPUTS DETERMINE AN ATTITUDE IN GIMBAL LOCK.
#                               FINDCDUW DRIVES CDUXD AND CDUYD TO THE RQD VALUES,
#                               BUT DRIVES CDUZD ONLY TO THE GIMBAL LOCK CONE.
#
#                       00402   IF UNFC/2 OR UNWC/2 PRODUCE OVERFLOW WHEN
#                               UNITIZED USING NORMUNIT.  FINDCDUW ISSUES
#                               STOPRATE AS ONLY INPUT TO AUTOPILOT.
#
# INPUTS:               UNFC/2          THRUST COMMAND VECTOR, NEED NOT BE SEMI-UNIT.
#                       UNWC/2          WINDOW COMMAND VECTOR, NEED NOT BE SEMI-UNIT.
#                       OGABIAS         POSSIBLE BIAS FOR OUTER GIMBAL ANGLE (ZEROED IN INITCDU
#                       XOVINHIB        FLAG DENOTING X AXIS OVERRIDE INHIBITED.
#                       CSMDOCKD        FLAG DENOTING CSM DOCKED.
#                       STEERSW         FLAG DENOTING INSUFF THRUST FOR THRUST DIR FLTR.
#
# OUTPUTS:              DELCDUX,Y,Z
#                       OMEGAPD,+1,+2
#                       DELPEROR,+1,+2
#                       CPHI,+1,+2 FOR NOUN22
#
# DEBRIS:               FINDCDUW DESTROYS SINCDUX,Y,Z AND COSCDUX,Y,Z BY
#                       WRITING INTO THESE LOCATIONS THE SINES AND COSINES
#                       OF THE CDUD'S IN PNGCS-AUTO, OF THE CDU'S OTHERWISE.
```

Uses A 80, BIAS 211, CDUXD 213, CDUYD 213, CDUZD 213, COMMAND 169, COSCDUX 150, CPHI 157, DELCDUX 211, MPAC 145, SINCDUX 150, STEERSW 103, THRUST 85, and Z 80.

2442 ⟨*Page LM0910* 2442⟩≡ (2439 2695)

```
# INITIALIZATION FOR FINDCDUW

                BANK    30
                SETLOC  FCDUW
                BANK

                EBANK=  ECDUW
                COUNT*  $$/FCDUW

INITCDUW        VLOAD
                        UNITX
                STORE   UNFV/2
                STORE   UNWC/2
                RVQ

# FINDCDUW PRELIMINARIES

                VLOAD                   # FINDCDUW -2:  ENTRY WHEN UNFC/2 PRE-STORD
                        UNFC/2          # INPUT VECTORS NEED NOT BE SEMI-UNIT
FINDCDUW        BOV     SETPD           # FINDCDUW: ENTRY WHEN UNFC/2 IN MPAC
                        FINDCDUW        # INTERPRETER NOW INITIALIZED
                        22              # LOCS 0 THRU 21 FOR DIRECTION COSINE MAT
                STQ     EXIT
                        QCDUWUSR        # SAVE RETURN ADDRESS

# MORE HAUSKEEPING
                CA      ECDUWL
                XCH     EBANK           # SET EBANK
                TS      ECDUWUSR        # SAVE USER'S EBANK

                CA      DAPBOOLS
                MASK    CSMDOCKD        # CSMDOCKD MUST NOT BE BIT15
                CCS     A
                CA      ONE             # INDEX IF CSM DOCKED
                TS      NDXCDUW

                CA      XOVINHIB        # XOVINHIB MUST NOT BE BIT15
                TS      FLPAUTNO        # SET TO POS-NON-ZERO FLAG PNGCS AUTO NOT

                MASK    DAPBOOLS
                TS      FLAGOODW        # FLAGOODW = ANY PNZ NUMBER IF XOV INHIBTD
```

Uses `A` 80, `COUNT` 142, `EBANK` 80, `MPAC` 145, and `SAVE` 191.

2443 ⟨*Page LM0911* 2443⟩≡ (2439 2695)

```
# FETCH BASIC DATA
                INHINT                  # RELINT AT PAUTNO (TC INTPRET)

                CA      CDUX            # FETCH CDUX,CDUY,CDUZ IN ALL CASES, BUT
                TS      CDUSPOTX        #       REPLACE BELOW IF PNGCS AUTO
                CA      CDUY
                TS      CDUSPOTY
                CA      CDUZ
                TS      CDUSPOTZ

                CA      BIT10           # PNGCS CONTROL BIT
                EXTEND
                RAND    CHAN30
                CCS     A
                TCF     PAUTNO          # NOT PNGCS (BITS INVERTED)

                CA      BIT14           # AUTO MODE BIT
                EXTEND
                RAND    CHAN31
                CCS     A
                TCF     PAUTNO          # NOT AUTO (BITS INVERTED)

                TS      FLPAUTNO        # RESET FLAG PNGCS AUTO NOT

                CA      CDUXD           # PNGCS AUTO:  FETCH CDUXD,CDUYD,CDUZD
                TS      CDUSPOTX
                CA      CDUYD
                TS      CDUSPOTY
                CA      CDUZD
                TS      CDUSPOTZ
```

Uses A 80, CDUSPOTX 152, CDUSPOTY 152, CDUSPOTZ 152, CDUX 80, CDUXD 213, CDUY 80, CDUYD 213, CDUZ 80, CDUZD 213, CHAN30 87, CHAN31 87, MODE 145, and TC 169.

2444 ⟨*Page LM0912* 2444⟩≡ (2439 2695)

```
# FETCH INPUTS
PAUTNO          TC      INTPRET         # ENTERING THRUST CMD STILL IN MPAC
                RTB
                        NORMUNIT
                STOVL   UNX/2           # SEMI-UNIT THRUST CMD AS INITIAL UNX/2
                        UNWC/2
                RTB     RTB
                        NORMUNIT
                        QUICTRIG        # ALWAYS RQD TO OBTAIN TRIGS OF CDUD'S
                STOVL   UNZ/2           # SEMI-UNIT WINDOW CMD AS INITIAL UNZ/2
                        DELV
                BOVB    UNIT
                        NOATTCNT        # AT LEAST ONE ENTERING CMD VCT ZERO
                BOV     CALL
                        AFTRFLTR        # IF UNIT DELV OVERFLOWS SKIP FILTER
                        *SMNB*          # YIELDS UNIT(DELV) IN VEH COORDS FOR FLTR

# THRUST DIRECTION FILTER

                EXIT

                CA      UNFVY/2         # FOR RESTARTS, UNFV/2 ALWAYS INTACT, MPAC
                LXCH    MPAC    +3      #       RENEWD AFTER RETURN FROM CALLER,
                TC      FLTRSUB         #       TWO FILTER UPDATES MAY BE DONE.
                TS      UNFVY/2         # UNFV/2 NEED NOT BE EXACTLY SEMI-UNIT.

                CA      UNFVZ/2
                LXCH    MPAC +5
                TC      FLTRSUB
                TS      UNFVZ/2

                TC      INTPRET         # COMPLETES FILTER
```

Uses DELV 159, MPAC 145, TC 169, and THRUST 85.

2445 ⟨*Page LM0913* 2445⟩≡ (2439 2695)

```
# FIND A SUITABLE WINDOW POINTING VECTOR

AFTRFLTR        SLOAD   BHIZ            # IF XOV NOT INHIBITED, GO FETCH ZNB
                        FLAGOODW
                        FETCHZNB
                VLOAD   CALL
                        UNZ/2
                        UNWCTEST

FETCHZNB        VLOAD
                        ZNBPIP
                STCALL  UNZ/2
                        UNWCTEST

                VLOAD   VCOMP           # Z AND -X CAN'T BOTH PARALLEL UNFC/2
                        XNBPIP
                STORE   UNZ/2

# COMPUTE THE REQUIRED DIRECTION COSINE MATRIX

DCMCL           VLOAD   VXV
                        UNZ/2
                        UNX/2
                UNIT    PUSH            # UNY/2 FIRST ITERATION
                VXV     VSL1
                        UNX/2
                STORE   UNZ/2           # -UNZ/2 FIRST ITERATION
                VXSC    PDVL            # EXCHANGE -UNFVZ/2 UNZ/2 FOR UNY/2
                        UNFVZ/2         # MUST BE SMALL
                VXSC    BVSU            # YIELDS -UNFVY/2 UNY/2-UNFVZ/2 UNZ/2
                        UNFVY/2         # MUST BE SMALL
                VSL1    VAD
                        UNX/2
                UNIT                    # TOTALLY ELIMINATES THRUST POINTING ERROR
                STORE   UNX/2           # UNX/2
                VXV     VSL1
                        UNZ/2           # -UNZ/2 WAS STORED HERE REMEMBER
                STORE   UNY/2           # UNY/2
                VCOMP   VXV
                        UNX/2
                VSL1
                STORE   UNZ/2           # UNZ/2
```

Uses A 80, THRUST 85, Z 80, and ZNB 186.

2446 ⟨*Page LM0914* 2446⟩≡ (2439 2695)

```
# COMPUTES THE REQUIRED GIMBAL ANGLES

                CALL
                        NB2CDUSP        # YIELDS THE RQD GIMBAL ANGLES, 2'S, PI
                EXIT

# LIMIT THE MIDDLE GIMBAL ANGLE & COMPUTE THE UNLIMITED GIMBAL ANGLE CHGS

                CA      MPAC +2         # LIMIT THE MGA
                TS      L               # CAN'T LXCH:  NEED UNLIMITED MGA FOR ALARM
                CA      CDUZDLIM
                TC      LIMITSUB        # YIELDS LIMITED MGA.  1 BIT ERROR POSSIBLE
                XCH     MPAC +2         #       BECAUSE USING 2'S COMP.  WHO CARES?
                EXTEND
                MSU     MPAC +2         # THIS BETTER YIELD ZERO
                EXTEND
                BZF     +2
                TCF     ALARMMGA

MGARET          INHINT                  # RELINT AT TC INTPRET AFTER TCQCDUW

                ZL
                CA      TWO
DELGMBLP        TS      TEM2

                CA      L               # TO PREVENT FALSE STARTS ABOUT X, ZERO
                EXTEND                  #       FLAGOODW IF DELGMBZ OR Y TOO BIG.
                SQUARE
                AD      HI5             # WITHIN 1 BIT OF -(45 DEG SQUARED)
                EXTEND
                BZMF    +3
                CA      ZERO
                TS      FLAGOODW

                INDEX   TEM2
                CA      MPAC
                INDEX   TEM2
                TS      CPHI            # OUTPUTS TO NOUN22
                EXTEND
                INDEX   TEM2
                MSU     CDUXD           # NO MATTER THAT THESE SLIGHTLY DIFFERENT
                COM                     # FROM WHEN WE INITIALLY FETCHED THEM
                INDEX   TEM2
                TS      -DELGMB         # -UNLIMITED GIMBAL ANGLE CHGS, 1'S, PI
                TS      L               # FOR PRECEDING TEST ON NEXT LOOP PASS
```

```
                CCS     TEM2
                TCF     DELGMBLP
```

Uses CDUXD 213, CPHI 157, L 80, MPAC 145, TC 169, and TEM2 142.

2447 ⟨*Page LM0915* 2447⟩≡ (2439 2695)

```
  # BRANCHES TO NOATTCNT
                CCS     FLPAUTNO
                TCF     NOATTCNT +2     # NO PNGCS AUTO

                CA      FLAGWRD5
                MASK    ENGONBIT
                EXTEND
                BZF     NOATTCNT +2     # ENGINE NOT ON
```

Uses ENGONBIT 115 and FLAGWRD5 113.

2448 ⟨*Page LM0916* 2448⟩≡ (2439 2695)

```
# LIMIT THE ATTITUDE ANGLE CHANGES
#
# THIS SECTION LIMITS THE ATTITUDE ANGLE CHANGES ABOUT A SET OF ORTHOGONAL VEHICLE AX
# THESE AXES COINCIDE WITH THE COMMANDED VEHICLE AXES IF AND ONLY IF CDUXD IS ZERO.
# THE COMMANDED VEHICLE SYSTEM ROTATED ABOUT THE X AXIS TO BRING THE Z AXIS INTO ALIG
# AXIS.  ATTITUDE ANGLE CHANGES IN THE PRIME SYSTEM ARE RELATED TO SMALL GIMBAL ANGLE
#
#       [   -DELATTX    ]   [ 1     SIN(CDUZD)     0 ] [ -DELGMBX ]
#       [               ]   [                        ] [          ]
#       [ -DELATTYPRIME ] = [ 0     COS(CDUZD)     0 ] [ -DELGMBY ]
#       [               ]   [                        ] [          ]
#       [ -DELATTZPRIME ]   [ 0         0          1 ] [ -DELGMBZ ]

                LXCH    -DELGMB +2      # SAME AS -DELATTZPRIME UNLIMITED
                INDEX   NDXCDUW
                CA      DAZMAX
                TC      LIMITSUB
                TS      -DELGMB +2      # -DELGMBZ

                CA      -DELGMB +1
                EXTEND
                MP      COSCDUZ         # YIELDS -DELATTYPRIME/2 UNLIMITED
                TS      L
                INDEX   NDXCDUW
                CA      DAY/2MAX
                TC      LIMITSUB
                EXTEND
                DV      COSCDUZ
                XCH     -DELGMB +1      # -DELGMBY, FETCHING UNLIMITED VALUE

                EXTEND
                MP      SINCDUZ
                DDOUBL
                COM
                EXTEND                  # YIELDS +DELATTX UNLIMITD, MAG < 180 DEG.
                MSU     -DELGMB         #       BASED ON UNLIMITED DELGMBV.
                TS      L               #       ONE BIT ERROR IF OPERANDS IN MSU
                INDEX   NDXCDUW         #       OF MIXED SIGNS.  WHO CARES?
                CA      DAXMAX
                TC      LIMITSUB
                TS      -DELGMB         # SAVE LIMITED +DELATTX
                CCS     FLAGOODW
                CS      -DELGMB         # FETCH IT BACK CHGING SIGN IF WINDOW GOOD
                TS      -DELGMB         # OTHERWISE USE ZERO FOR -DELATTX
                CS      -DELGMB +1
```

```
EXTEND
MP      SINCDUZ
DDOUBL                  # YIELDS -CNTRIB TO -DELATTX FROM -DELGMBY
ADS     -DELGMB         # -DELGMBX.  NO OVERFLOW SINCE LIMITED TO
                        # 20DEG(1+SIN(70DEG)/COS(70DEG)) < 180DEG
```

Uses A 80, CDUXD 213, CDUZD 213, COSCDUZ 150, DV 241, IT 185, L 80, SAVE 191, SINCDUZ 150, TC 169, Z 80, and ZPRIME 148.

2450 ⟨*Page LM0917* 2450⟩≡ (2439 2695)

```
# COMPUTE COMMANDED ATTITUDE RATES
#
#       [ OMEGAPD ]   [ -2         -4 SINCDUZ              +0    ] [ -DELGMBZ ]
#       [         ]   [                                         ] [          ]
#       [ OMEGAQD ] = [ +0     -8 COSCDUZ COSCDUX     -4 SINCDUX ] [ -DELGMBY ]
#       [         ]   [                                         ] [          ]
#       [ OMEGARD ]   [ +0     +8 COSCDUZ SINCDUX     -4 COSCDUX ] [ -DELGMBZ ]
#
# ATTITUDE ANGLE RATES IN UNITS OF PI/4 RAD/SEC = K TRIG FCNS IN UNITS OF 2 X GIMBAL
# PI/2 RAD/SEC.  THE CONSTANTS ARE BASED ON DELGMB BEING THE GIMBAL ANGLE CHANGES IN
# AND 2 SECONDS BEING THE COMPUTATION PERIOD (THE PERIOD BETWEEN SUCCESSIVE PASSES TH

                CS      -DELGMB
                TS      OMEGAPD
                CS      -DELGMB +1
                EXTEND
                MP      SINCDUZ
                DDOUBL
                ADS     OMEGAPD
                ADS     OMEGAPD

                CS      -DELGMB +1
                EXTEND
                MP      COSCDUX
                DDOUBL
                EXTEND
                MP      COSCDUZ
                TS      OMEGAQD
                CS      -DELGMB +2
                EXTEND
                MP      SINCDUX
                ADS     OMEGAQD
                ADS     OMEGAQD
                ADS     OMEGAQD

                CA      -DELGMB +1
                EXTEND
                MP      SINCDUX
                DDOUBL
                EXTEND
                MP      COSCDUZ
                TS      OMEGARD
                CS      -DELGMB +2
                EXTEND
                MP      COSCDUX
```

```
ADS     OMEGARD
ADS     OMEGARD
ADS     OMEGARD
```

Uses COSCDUX 150, COSCDUZ 150, RAD 219, SINCDUX 150, and SINCDUZ 150.

2452 ⟨*Page LM0918* 2452⟩≡ (2439 2695)

```
# FINAL TRANSFER

                CA      TWO
CDUWXFR         TS      TEM2
                INDEX   TEM2
                CA      -DELGMB
                EXTEND
                MP      DT/DELT         # RATIO OF DAP INTERVAL TO CDUW INTERVAL
                TC      ONESTO2S
                INDEX   TEM2
                TS      DELCDUX         # ANGLE INTERFACE

                INDEX   TEM2
                CCS     OMEGAPD
                AD      ONE
                TCF     +2
                AD      ONE
                EXTEND                  # WE NOW HAVE ABS(OMEGAPD,QD,RD)
                INDEX   TEM2
                MP      OMEGAPD
                EXTEND
                MP      BIT11           # 1/16
                EXTEND
                INDEX   TEM2            #                  2
                DV      1JACC           # UNITS PI/4 RAD/SEC
                TS      L
                CA      DELERLIM
                TC      LIMITSUB
                INDEX   TEM2
                TS      DELPEROR        # LAG ANGLE = OMEGA ABS(OMEGA)/2 ACCEL
                CCS     TEM2
                TCF     CDUWXFR

# HAUSKEEPING AND RETURN

TCQCDUW         CA      ECDUWUSR
                TS      EBANK           # RETURN USER'S EBANK

                TC      INTPRET
                SETPD   GOTO
                        0
                        QCDUWUSR        # NORMAL AND ABNORMAL RETURN TO USER
```

Uses DELCDUX 211, DELT 188, DV 241, EBANK 80, L 80, OMEGA 232, RAD 219, RD 241, TC 169, and TEM2 142.

2453 ⟨*Page LM0919* 2453⟩≡ (2439 2695)

```
# THRUST VECTOR FILTER SUBROUTINE

FLTRSUB         EXTEND
                QXCH    TEM2
                TS      TEM3            # SAVE ORIGINAL OFFSET
                COM                     # ONE MCT, NO WDS, CAN BE SAVED IF NEG OF
                AD      L               #       ORIG OFFSET ARRIVES IN A, BUT IT'S
                EXTEND                  #       NOT WORTH THE INCREASED OBSCURITY.
                INDEX   NDXCDUW
                MP      GAINFLTR
                TS      L               # INCR TO OFFSET, UNLIMITED
                CA      DUNFVLIM        # SAME LIMIT FOR Y AND Z
                TC      LIMITSUB        # YIELDS INCR TO OFFSET, LIMITED
                AD      TEM3            # ORIGINAL OFFSET
                TS      L               # TOTAL OFFSET, UNLIMITED
                CA      UNFVLIM         # SAME LIMIT FOR Y AND Z
                TC      LIMITSUB        # YIELDS TOTAL OFFSET, LIMITED
                TC      TEM2

# SUBR TO TEST THE ANGLE BETWEEN THE PROPOSED WINDOW AND THRUST CMD VCTS

UNWCTEST        DOT     DSQ
                        UNX/2
                DSU     BMN
                        DOTSWFMX
                        DCMCL
                SSP     RVQ             # RVQ FOR ALT CHOICE IF DOT MAGN TOO LARGE
                        FLAGOODW        #       ZEROING WINDOW GOOD FLAG
                        0
```

Uses A 80, ALT 157, L 80, SAVE 191, TC 169, TEM2 142, TEM3 142, THRUST 85, and Z 80.

2454 ⟨*Page LM0920* 2454⟩≡ (2439 2695)

```
# NB2CDUSP RETURNS THE 2'S COMPLEMENT, PI, SP CDU ANGLES X,Y,Z IN MPAC,+1,+2 GIVEN TH
# ARE THE SEMI-UNIT NAV BASE VECTORS X,Y,X EXPRESSED IN STABLE MEMBER COORDINATES, LO
# NB2CDUSP USES THE ARCTRGSP WHICH HAS A MAXIMUM ERROR OF +-4 BITS.

NB2CDUSP        DLOAD   DSQ
                        2
                BDSU    BPL
                        DP1/4TH
                        +3
                DLOAD
                        ZEROVECS        # IN CASE SIN WAS SLIGHTLY > 1/2
                SQRT    EXIT            # YIELDS COS(CDUZ) IN UNITS OF 2

                EXTEND
                DCA     MPAC
                DDOUBL
                TS      TEM5
                TCF     +3
                CA      POSMAX          # OVERFLOW.  FETCH POSMAX, MPAC ALWAYS POS
                TS      TEM5            # COS(CDUZ) IN TEM5, UNITS 1

                INDEX   FIXLOC
                CA      2
                LXCH    MPAC
                TC      ARCTRGSP
                TS      MPAC +2         # CDUZ

                CA      ZERO
                TC      DVBYCOSM
                CA      FOUR
                TC      DVBYCOSM
                CS      TEM1
                TC      ARCTRGSP
                TS      MPAC +1         # CDUY

                CA      BIT4
                TC      DVBYCOSM
                CA      16OCT
                TC      DVBYCOSM
                CS      TEM1
                TC      ARCTRGSP
                TS      MPAC            # CDUX

                TC      INTPRET
                RVQ
```

```
16OCT           OCT     16
```

Uses A 80, CDUX 80, CDUY 80, CDUZ 80, FIXLOC 140, MPAC 145, TC 169, TEM1 142, TEM5 142, and Z 80.

2455 ⟨*Page LM0921* 2455⟩≡ (2439 2695)

```
# THE ELEMENTS OF THE NAV BASE MATRIX WHICH WE MUST DIVIDE BY COS(MGA)
# ALREADY CONTAIN COS(MGA)/2 AS A FACTOR. THEREFORE THE QUOTIENT SHOULD
# ORDINARILY NEVER EXCEED 1/2 IN MAGNITUDE.  BUT IF THE MGA IS NEAR PI/2
# THEN COS(MGA) IS NEAR ZERO, AND THERE MAY BE SOME CHAFF IN THE OTHER
# ELEMENTS OF THE MATRIX WHICH WOULD PRODUCE CHAOS UNDER DIVISION.
# BEFORE DIVIDING WE MAKE SURE COS(MGA) IS AT LEAST ONE BIT LARGER
# THAN THE MAGNITUDE OF THE HIGH ORDER PART OF THE OPERAND.
#
# IF ONE OR MORE DIVIDES CANNOT BE PERFORMED, THIS MEANS THAT THE
# REQUIRED MGA IS VERY NEARLY +-PI/2 AND THEREFORE THE OTHER GIMBAL
# ANGLES ARE INDETERMINATE.  THE INNER AND OUTER GIMBAL ANGLES RETURNED
# IN THIS CASE WILL BE RANDOM MULTIPLES OF PI/2.

DVBYCOSM        AD      FIXLOC
                TS      ADDRWD          # ADRES OF OPERAND

                INDEX   ADDRWD          # FETCH NEG ABS OF OPERAND, AD TEM5, AND
                CA      0               #       SKIP DIVIDE IF RESULT NEG OR ZERO
                EXTEND
                BZMF    +2
                COM
                AD      TEM5            # C(A) ZERO OR NEG, C(TEM5) ZERO OR POS
                EXTEND
                BZMF    TSL&TCQ         # DIFFERENCE ALWAYS SMALL IF BRANCH

                EXTEND                  # TEM5 EXCEEDS ABS HIGH ORDER PART OF
                INDEX   ADDRWD          #       OPERAND BY AT LEAST ONE BIT.
                DCA     0               #       THEREFORE IT EXCEEDS THE DP OPERAND
                EXTEND                  #       AND DIVISION WILL ALWAYS SUCCEED.
                DV      TEM5
TSL&TCQ         TS      L
                LXCH    TEM1
                TC      Q
```

Uses A 80, ADDRWD 140, DV 241, FACTOR 226, FIXLOC 140, IT 185, L 80, Q 80, TC 169, TEM1 142, and TEM5 142.

2456 ⟨*Page LM0922* 2456⟩≡ (2439 2695)

```
# ARCTRGSP RETURNS THE 2'S COMPLEMENT, PI, SP ANGLE IN THE A REGISTER GIVEN ITS SINE
# UNITS OF 2.  THE RESULT IS AN UNAMBIGUOUS ANGLE ANYWHERE IN THE CIRCLE, WITH A MAXI
# THE ERROR IS PRODUCED BY THE SUBROUTINE SPARCSIN WHICH IS USED ONLY IN THE REGION -

ARCTRGSP        EXTEND
                BZF     SINZERO         # TO AVOID DIVIDING BY ZERO

                EXTEND
                QXCH    TEM4
                TS      TEM2
                CA      L
                TS      TEM3
                CA      ZERO
                EXTEND
                DV      TEM2
                EXTEND
                BZF     USECOS

                CCS     TEM3            # SIN IS SMALLER OR EQUAL
                CA      ZERO
                TCF     +4
                CS      TEM2            # IF COS NEG, REVERSE SIGN OF SIN,
                TS      TEM2            #       ANGLE = PI-ARCSIN(SIN)
                CA      NEGMAX          # PICK UP PI, 2'S COMPLEMENT
                TS      TEM3            # WE NO LONGER NEED COS
                CA      TEM2
                TC      SPARCSIN -1
                TC      ONESTO2S
                EXTEND
                MSU     TEM3
1TO2&TCQ        TC      ONESTO2S
                TC      TEM4

USECOS          CS      TEM3            # COS IS SMALLER
                TC      SPARCSIN -1     # ANGLE = SIGN(SIN)(FI/2-ARCSIN(COS))
                AD      HALF
                TS      TEM3            # WE NO LONGER NEED COS
                CCS     TEM2
                CA      TEM3
                TCF     1TO2&TCQ
                CS      TEM3
                TCF     1TO2&TCQ

SINZERO         CCS     L
                CA      ZERO
```

```
                TC      Q
                CA      NEGMAX          # PI, 2'S COMP
                TC      Q
```

Uses A 80, DV 241, L 80, Q 80, TC 169, TEM2 142, TEM3 142, and TEM4 142.

2457 ⟨*Page LM0923* 2457⟩≡ (2439 2695)

```
  # SPARCSIN TAKES AN ARGUMENT SCALED UNITY IN A AND RETURNS AN ANGLE SCALED
  # 180 DEGREES IN A.  IT HAS BEEN UNIT TESTED IN THE REGION +-.94 (+-70
  # DEGREES) AND THE MAXIMUM ERROR IS +-5 BITS WITH AN AVERAGE TIME OF
  # 450 MICROSECONDS.  SPARCSIN -1 TAKES THE ARGUMENT SCALED TWO.  (BOB CRISP)

                DOUBLE
  SPARCSIN      TS      SR
                TCF     +4
                INDEX   A
                CS      LIMITS
                TS      SR
                EXTEND
                MP      A
                TS      TEM1
                EXTEND
                MP      DPL9
                AD      DPL7
                EXTEND
                MP      TEM1
                AD      DPL5
                EXTEND
                MP      TEM1
                AD      DPL3
                EXTEND
                MP      TEM1
                AD      DPL1
                EXTEND
                MP      SR
                TC      Q
  DPL1          DEC     10502
  DPL3          DEC     432
  DPL5          DEC     7300
  DPL7          DEC     -11803
  DPL9          DEC     8397
```

Uses A 80, IT 185, Q 80, SR 80, TC 169, and TEM1 142.

2458 ⟨*Page LM0924* 2458⟩≡ (2439 2695)

```
# LIMITSUB LIMITS THE MAGNITUDE OF THE POSITIVE OR NEGATIVE VARIABLE
# ARRIVING IN L TO THE POSITIVE LIMIT ARRIVING IN A.
# THE SIGNED LIMITED VARIABLE IS RETURNED IN A.
#
# VERSION COUTESY HUGH BLAIR-SMITH

LIMITSUB        TS      TEM1
                CA      ZERO
                EXTEND
                DV      TEM1
                CCS     A
                LXCH    TEM1
                TCF     +2
                TCF     +3
                CA      L
                TC      Q
                CS      TEM1
                TC      Q

# SUBROUTINE TO CONVERT 1'S COMP SP TO 2'S COMP

ONESTO2S        CCS     A
                AD      ONE
                TC      Q
                CS      A
                TC      Q

# NO ATTITUDE CONTROL

NOATTCNT        TC      ALARM
                OCT     00402           # NO ATTITUDE CONTROL

 +2             INHINT                  # COME HERE FOR NOATTCNT WITHOUT ALARM
                TC      IBNKCALL        # RELINT AT TC INTPRET AFTER TCQCDUW
                FCADR   STOPRATE
                TCF     TCQCDUW         # RETURN TO USER SKIPPING AUTOPILOT CMDS

# MIDDLE GIMBAL ANGLE ALARM

ALARMMGA        TC      ALARM
                OCT     00401
                TCF     MGARET
```

Uses `A` 80, `DV` 241, `L` 80, `Q` 80, `TC` 169, and `TEM1` 142.

2459 ⟨*Page LM0925* 2459⟩≡ (2439 2695)

```
#*****************************************************************
# CONSTANTS
#*****************************************************************

# ADDRESS CONSTANTS

ECDUWL          ECADR   ECDUW

# THRUST DIRECTION FILTER CONSTANTS

GAINFLTR        DEC     .2              # GAIN FILTER SANS CSM
                DEC     .1              # GAIN FILTER WITH CSM

DUNFVLIM        DEC     .007 B-1        # 7 MR MAX CHG IN F DIR IN VEH IN 2 SECS.
                                        # THIS DOES NOT ALLOW FOR S/C ROT RATE.

UNFVLIM         DEC     .129 B-1        # 129 MR MAX THRUST OFFSET.  105 MR TRAVEL
                                        # +10MR DEFL+5MR MECH MOUNT+9MR ABLATION.

# CONSTANT RELATED TO GIMBAL ANGLE COMPUTATIONS

DOTSWFMX        DEC     .93302 B-4      # LIM COLNRTY OF UNWC/2 & UNFC/2 TO 85 DEG
                                        # LOWER PART COMES FROM NEXT CONSTANT

DAXMAX          DEC     .11111111111    # DELATTX LIM TO 20 DEG IN 2 SECS, 1'S, PI
                DEC     .0111111111     # 2 DEG WHEN CSM DOCKED

DAY/2MAX        DEC     .05555555555    # LIKEWISE FOR DELATTY
                DEC     .0055555555

DAZMAX          =       DAXMAX          # LIKEWISE FOR DELATTZ

CDUZDLIM        DEC     .3888888888     # 70 DEG LIMIT FOR MGA, 1'S, PI

# CONSTANTS FOR DATA TRANSFER

DT/DELT         DEC     .05             # .1 SEC/2 SEC WHICH IS THE AUTOPILOT
                                        # CONTROL SAMPLE PERIOD/COMPUTATION PERIOD

DELERLIM        =       DAY/2MAX        #       0 DEG LIMIT FOR LAG ANGLES, 1'S, PI

# *** END OF FLY        .132 ***
```

Uses DELT 188, F 238, and THRUST 85.

4.27 lm down-telemetry program

2460 ⟨*lm down-telemetry program* 2460⟩≡ (2041)
⟨*Page LM0988* 2461⟩
⟨*Page LM0989* 2462⟩
⟨*Page LM0990* 2463⟩
⟨*Page LM0991* 2465⟩
⟨*Page LM0992* 2467⟩
⟨*Page LM0993* 2469⟩
⟨*Page LM0994* 2471⟩
⟨*Page LM0995* 2472⟩
⟨*Page LM0996* 2474⟩
⟨*Page LM0997* 2475a⟩

2461 ⟨*Page LM0988* 2461⟩≡ (2460 2678)

```
# PROGRAM NAME -- DOWN TELEMETRY PROGRAM
# MOD NO. -- 0          TO COMPLETELY REWRITE THE DOWN TELEMETRY PROGRAM AND DOWNLINK ERASABLE
#                       PURPOSE OF SAVING APPROXIMATELY 150 WORDS OF CORE STORAGE.
#                       THIS CHANGE REQUIRES AN ENTIRELY NEW METHOD OF SPECIFYING DOWNLINK LIST
#                       LISTS LOG SECTION FOR MORE DETAILS.  HOWEVER THIS CHANGE WILL NOT AFFEC
#                       OF DOWN TELEMETRY DATA.
# MOD BY -- KILROY, SMITH, DEWITT
# DATE -- 02 OCT 67
# AUTHORS -- KILROY, SMITH, DWWITT, DEWOLF, FAGIN
# LOG SECTION -- DOWN-TELEMETRY PROGRAM
#
# FUNCTIONAL DESCRIPTION -- THIS ROUTINE IS INITIATED BY TELEMETRY END
#       PULSE FROM THE DOWNLINK TELEMETRY CONVERTER.  THIS PULSE OCCURS
#       AT 50 TIMES PER SEC (EVERY 20 MS) THEREFORE DODOWNTM IS
#       EXECUTED AT THESE RATES.  THIS ROUTINE SELECTS THE APPROPRIATE
#       AGC DATA TO BE TRANSMITTED DOWNLINK AND LOADS IT INTO OUTPUT
#       CHANNELS 34 AND 35.  THE INFORMATION IS THEN GATED OUT FROM THE
#       LGC IN SERIAL FASHION.
#
#       THIS PROGRAM IS CODED FOR A 2 SECOND DOWNLIST.  SINCE DOWNRUPTS
#       OCCUR EVERY 20 MS AND 2 AGC COMPUTER WORDS CAN BE PLACED IN
#       CHANNELS 34 AND 35 DURING EACH DOWNRUPT THE PROGRAM IS CAPABLE
#       OF SENDING 200 AGC WORDS EVERY 2 SECONDS.
#
# CALLING SEQUENCE -- NONE
#       PROGRAM IS ENTERED VIA TCF DODOWNTM WHICH IS EXECUTED AS A
#       RESULT OF A DOWNRUPT.  CONTROL IS RETURNED VIA TCF RESUME WHICH
#       IN EFFECT IS A RESUME.
#
# SUBROUTINES CALLED -- NONE
#
# NORMAL EXIT MODE -- TCF RESUME
#
# ALARM OR ABORT EXIT MODE -- NONE
#
# RESTART PROTECTION:
#       ON A FRESH START AND RESTART THE 'STARTSUB' SUBROUTINE WILL INITIALIZE THE DOWNLIST POI
#       DNTMGOTO) TO THE BEGINNING OF THE CURRENT DOWNLIST (I.E., CURRENT CONTENTS OF DNLSTADR)
#       EFFECT OF IGNORING THE REMAINDER OF THE DOWNLIST WHICH THE DOWN-TELEMETRY PROGRAM WAS W
#       THE RESTART (OR FRESH START) OCCURRED AND RESUME DOWN TELEMETRY FROM THE BEGINNING OF T
#       DOWNLIST.
#
#       ALSO OF INTEREST IS THE FACT THAT ON A RESTART THE AGC WILL ZERO DOWNLINK CHANNELS 13,
#
# DOWNLINK LIST SELECTION:
```

```
#       THE APPROPRIATE DOWNLINK LISTS ARE SELECTED BY THE FOLLOWING:
#       1.      FRESH START
#       2.      V37EXXE WHERE XX = THE MAJOR MODE BEING SELECTED.
#       3.      UPDATE PROGRAM (P27)
#       4.      NON-V37 SELECTABLE TYPE PROGRAMS (E.G., AGS INITIALIZATION (SUNDANCE,
#               TRANSITION (COLOSSUS) ETC.).
#
# DOWNLINK LIST RULES AND LIMITATIONS:
#       READ SECTION(S) WHICH FOLLOW ‘DEBRIS’ WRITEUP.
#
# OUTPUT -- EVERY 2 SECONDS 100 DOUBLE PRECISION WORDS (I.E., 200 LGC
#       COMPUTER WORDS) ARE TRANSMITTED VIA DOWNLINK.
#
# ERASABLE INITIALIZATION REQUIRED -- NONE
#       ‘DNTMGOTO’ AND ‘DNLSTADR’ ARE INITIALIZED BY THE FRESH START PROGRAM.
#
# DEBRIS (ERASABLE LOCATIONS DESTROYED BY THIS PROGRAM) --
#       LDATALST, DNTMBUFF TO DNTMBUFF +21D, TMINDEX, DNQ.
```

Uses A 80, COMPUTER 115, DNLSTADR 148, DNQ 148, DNTMBUFF 148, DNTMGOTO 148, I 206, IT 185, LDATALST 148, MODE 145, RESTART 57, and TMINDEX 148.

2462 ⟨*Page LM0989* 2462⟩≡ (2460 2678)

2463 ⟨*Page LM0990* 2463⟩≡ (2460 2678)

```
# DODOWNTM IS ENTERED EVERY 20 MS BY AN INTERRUPT TRIGGERED BY THE
# RECEIPT OF AN ENDPULSE FROM THE SPACECRAFT TELEMETRY PROGRAMMER.
#
# NOTES REGARDING DOWNLINK LISTS ASSOCIATED WITH THIS PROGRAM:
# 1.    DOWNLISTS.  DOWNLISTS MUST BE COMPILED IN THE SAME BANK AS THE
#       DOWN-TELEMETRY PROGRAM.  THIS IS DONE FOR EASE OF CODING, FASTER
#       EXECUTION.
# 2.    EACH DOWNLINK LIST CONSISTS OF A CONTROL LIST AND A NUMBER OF
#       SUBLISTS.
# 3.    A SUBLIST REFERS TO A SNAPSHOT OR DATA COMMON TO THE SAME OR OTHER
#       DOWNLINK LISTS.  ANY SUBLIST CONTAINING COMMON DATA NEEDS TO BE
#       CODED ONLY ONCE FOR THE APPLICABLE DOWNLINK LISTS.
# 4.    SNAPSHOT SUBLISTS REFER SPECIFICALLY TO HOMOGENEOUS DATA WHICH MUST BE
#       SAVED IN A BUFFER DURING ONE DOWNRUPT.
# 5.    THE 1DNADR FOR THE 1ST WORD OF SNAPSHOT DATA IS FOUND AT THE END
#       OF EACH SNAPSHOT SUBLIST, SINCE THE PROGRAM CODING SENDS THIS DP WORD
#       IMMEDIATELY AFTER STORING THE OTHERS IN THE SNAPSHOT BUFFER.
# 6.    ALL LISTS ARE COMBINATIONS OF CODED ERASABLE ADDRESS CONSTANTS
#       CREATED FOR THE DOWNLIST PROGRAM.
#       A.      1DNADR                  1-WORD DOWNLIST ADDRESS.
#               SAME AS ECADR, BUT USED WHEN THE WORD ADDRESSED IS THE LEFT
#               HALF OF A DOUBLE-PRECISION WORD FOR DOWN TELEMETRY.
#       B.      2DNADR - 6DNADR         N-WORD DOWNLIST ADDRESS, N = 2 - 6.
#               SAME AS 1DNADR, BUT WITH THE 4 UNUSED BITS OF THE ECADR FORMAT
#               FILLED IN WITH 0001-0101.  USED TO POINT TO A LIST OF N DOUBLE-
#               PRECISION WORDS, STORED CONSECUTIVELY, FOR DOWN TELEMETRY.
#       C.      DNCHAN                  DOWNLIST CHANNEL ADDRESS.
#               SAME AS 1DNADR, BUT WITH PREFIX BITS 0111.  USED TO POINT TO
#               A PAIR OF CHANNELS FOR DOWN TELEMETRY.
#       D.      DNPTR                   DOWN-TELEMETRY SUBLIST POINTER.
#               SAME AS CAF BUT TAGGED AS A CONSTANT.  USED IN CONTROL LIST TO POINT TO A SUBLI
#               CAUTION --- A DNPTR CANNOT BE USED IN A SUBLIST.
# 7.    THE WORD ORDER CODE IS SET TO ZERO AT THE BEGINNING OF EACH DOWNLIST (I.E., CONTROL LIS
#       A '1DNADR TIME2' IS DETECTED IN THE CONTROL LIST (ONLY).
# 8.    IN THE SNAPSHOT SUBLIST ONLY, THE DNADR'S CANNOT POINT TO THE FIRST WORD OF ANY EBANK.
#
# DOWNLIST LIST RESTRICTIONS:
# (THE FOLLOWING POINTS MAY BE LISTED ELSEWHERE BUT ARE LISTED HERE SO IT IS CLEAR THAT THESE T
# DONE)
# 1.    SNAPSHOT DOWNLIST:
#       (A) CANNOT CONTAIN THE FOLLOWING ECADRS (I.E., 1DNADR'S): Q, 400, 1000, 1400, 2000, 240
#       (B) CAN CONTAIN ONLY 1DNADR'S
# 2.    ALL DOWNLINKED DATA (EXCEPT CHANNELS) IS PICKED UP BY A DCA SO DOWNLINK LISTS CANNOT CO
#       EQUIVALENT OF THE FOLLOWING ECADRS (I.E., 1DNADRS): 377, 777, 1377, 1777, 2377, 2777, 3
#       (NOTE: THE TERM 'EQUIVALENT' MEANT THAT THE 1DNADR TO 6DNADR WILL BE PROCESSED LIKE 1 T
```

```
# 3.    CONTROL LISTS AND SUBLISTS CANNOT HAVE ENTRIES = OCTAL 00000 OR OCTAL 77777
```

Uses `A` 80, `CODE` 140, `D` 226, `EBANK` 80, `I` 206, `IT` 185, `N` 206, and `Q` 80.

2465 ⟨*Page LM0991* 2465⟩≡ (2460 2678)

```
# 4.    THE ‘1DNADR TIME2’ WHICH WILL CAUSE THE DOWNLINK PROGRAM TO SET THE WORDER CODE TO 3 MU
#       CONTROL SECTION OF THE DOWNLIST.
# 5.    ‘DNCHAN 0’ CANNOT BE USED.
# 6.    ‘DNPTR 0’ CANNOT BE USED.
# 7.    DNPTR CANNOT APPEAR IN A SUBLIST.
#
# EBANK SETTINGS
#       IN THE PROCESS OF SETTING THE EBANK (WHEN PICKING UP DOWNLINK DATA) THE DOWN TELEMETRY
#       ‘GARBAGE’ INTO BITS15-12 OF EBANK.  HUGH BLAIR-SMITH WARNS US THAT BITS15-12 OF EBANK M
#       SIGNIFICANT SOMEDAY IN THE FUTURE.  IF/WHEN THAT HAPPENS, THE PROGRAM SHOULD INSURE (BY
#       THAT BITS 15-12 OF EBANK ARE ZERO.
#
# INITIALIZATION REQUIRED -- TO INTERRUPT CURRENT LIST AND START A NEW ONE.
#       1. ADRES OF DOWNLINK LIST INTO DNLSTADR
#       2. NEGONE INTO SUBLIST
#       3. NEGONE INTO DNECADR

                BANK    22
                SETLOC  DOWNTELM
                BANK

                EBANK=  DNTMBUFF

                COUNT*  $$/DPROG
DODOWNTM        TS      BANKRUPT
                EXTEND
                QXCH    QRUPT           # SAVE Q
                TCF     WOTEST
WO1             EXTEND                  # SET WORD ORDER BIT TO 1 ONLY IF IT
                WOR     CHAN13          # ALREADY ISN’T
                TC      DNTMGOTO        # GOTO APPROPRIATE PHASE OF PROGRAM

DNPHASE1        CA      NEGONE          # INITIALIZE ALL CONTROL WORDS
                TS      SUBLIST         # WORDS TO MINUS ONE
                TS      DNECADR
                CA      LDNPHAS2        # SET DNTMGOTO = 0 ALL SUSEQUENT DOWRUPTS
                TS      DNTMGOTO        # GO TO DNPHASE2
                TCF     NEWLIST
DNPHASE2        CCS     DNECADR         # SENDING OF DATA IN PROGRESS
DODNADR         TC      FETCH2WD        # YES -- THEN FETCH THE NEXT 2 SP WORDS
MINTIME2        -1DNADR TIME2           # NEGATIVE OF TIME2 1DNADR
                TCF     +1              # (ECADR OF 3776 + 74001 = 77777)

                CCS     SUBLIST         # IS THE SUBLIST IN CONTROL
                TCF     NEXTINSL        # YES
```

Uses A 80, BANKRUPT 80, CHAN13 87, CODE 140, COUNT 142, DNLSTADR 148, DNTMBUFF 148, DNTMGOTO 148, DOWNTELM 59, EBANK 80, IT 185, Q 80, QRUPT 80, SAVE 191, TC 169, TIME2 80, and US 185.

2467 ⟨*Page LM0992* 2467⟩≡ (2460 2678)

```
DNADRDCR        OCT     74001           # DNADR COUNT AND ECADR DECREMENTER

CHKLIST         CA      CTLIST
                EXTEND
                BZMF    NEWLIST         # IT WILL BE NEGATIVE AT END OF LIST
                TCF     NEXTINCL
NEWLIST         INDEX   DNLSTCOD
                CA      DNTABLE         # INITIALIZE CTLIST WITH
                TS      CTLIST          #       STARTING ADDRESS OF NEW LIST
                CS      DNLSTCOD
                TCF     SENDID  +3
NEXTINCL        INDEX   CTLIST
                CA      0
                CCS     A
                INCR    CTLIST          # SET POINTER TO PICK UP NEXT CTLIST WORD
                TCF     +4              # ON NEXT ENTRY TO PROG.  (A SHOULD NOT =0)
                XCH     CTLIST          # SET CTLIST TO NEGATIVE AND PLACE(CODING)
                COM                     # UNCOMPLEMENTED DNADR INTO A.    (FOR LA)
                XCH     CTLIST          #                                 (ST IN )
        +4      INCR    A               #                                 (CTLIST)
                TS      DNECADR         # SAVE DNADR
                AD      MINTIME2        # TEST FOR TIME2 (NEG. OF ECADR)
                CCS     A
                TCF     SETWO   +1      # DON'T SET WORD ORDER CODE
MINB1314        OCT     47777           # MINUS BIT 13 AND 14 (CAN'T GET HERE)
                TCF     SETWO   +1      # DON'T SET WORD ORDER CODE
SETWO           TC      WOZERO          # GO SET WORD ORDER CODE TO ZERO.
        +1      CA      DNECADR         # RELOAD A WITH THE DNADR.
        +2      AD      MINB1314        # IS THIS A REGULAR DNADR?
                EXTEND
                BZMF    FETCH2WD        # YES.  (A MUST NEVER BE ZERO)
                AD      MINB12          # NO.  IS IT A POINTER (DNPTR) OR A
                EXTEND                  #       CHANNEL(DNCHAN)
                BZMF    DODNPTR         # IT'S A POINTER.  (A MUST NEVER BE ZERO)

DODNCHAN        TC      6               # (EXECUTED AS EXTEND)  IT'S A CHANNEL
                INDEX   DNECADR
                INDEX   0       -4000   # (EXECUTED AS READ)
                TS      L
                TC      6               # (EXECUTED AS EXTEND)
                INDEX   DNECADR
                INDEX   0       -4001   # (EXECUTED AS READ)
                TS      DNECADR         # SET DNECADR
                CA      NEGONE          #       TO MINUS
                XCH     DNECADR         #               WHILE PRESERVING A.
```

```
                TCF     DNTMEXIT        # GO SEND CHANNELS

WOZERO          CS      BIT7
                EXTEND
                WAND    CHAN13          # SET WORD ORDER CODE TO ZERO
```

Uses A 80, CHAN13 87, CODE 140, COUNT 142, DNLSTCOD 148, IT 185, L 80, SAVE 191, TC 169, and TIME2 80.

2469 ⟨*Page LM0993* 2469⟩≡ (2460 2678)

```
                TC      Q               # RETURN TO CALLER

DODNPTR         INDEX   DNECADR         # DNECADR CONTAINS ADRES OF SUBLIST
                0       0               # CLEAR AND ADD LIST ENTRY INTO A.
                CCS     A               # IS THIS A SNAPSHOT SUBLIST
                CA      DNECADR         # NO, IT IS A REGULAR SUBLIST.
                TCF     DOSUBLST        # A MUST NOT BE ZERO.

                XCH     DNECADR         # YES.  IT IS A SNAPSHOT SUBLIST.
                TS      SUBLIST         # C(DNECADR) INTO SUBLIST
                CAF     ZERO            #       A    INTO     A
                XCH     TMINDEX         # (NOTE:  TMINDEX = DNECADR)

# THE FOLLOWING CODING (FROM SNAPLOOP TO SNAPEND) IS FOR THE PURPOSE OF TAKING A SNAPSHOT OF 12
# THIS IS DONE BY SAVING 11 DP REGISTERS IN DNTMBUFF AND SENDING THE FIRST DP WORD IMMEDIATELY.
# THE SNAPSHOT PROCESSING IS THE MOST TIME CONSUMING AND THEREFORE THE CODING AND LIST STRUCTUR
# TO MINIMIZE TIME.  THE TIME OPTIMIZATION RESULTS IN RULES UNIQUE TO THE SNAPSHOT PORTION OF T
# THESE RULES ARE ......
#       1.      ONLY 1DNADR'S CAN APPEAR IN THE SNAPSHOT SUBLIST
#       2.      THE 1DNADR'S CANNOT REFER TO THE FIRST LOCATION IN ANY BANK.

SNAPLOOP        TS      EBANK           # SET EBANK
                MASK    LOW8            # ISOLATE RELATIVE ADDRESS
                EXTEND
                INDEX   A
                EBANK=  1401
                DCA     1401            # PICK UP 2 SNAPSHOT WORDS.
                EBANK=  DNTMBUFF
                INDEX   TMINDEX
                DXCH    DNTMBUFF        # STORE 2 SNAPSHOT WORDS IN BUFFER
                INCR    TMINDEX         # SET BUFFER INDEX FOR NEXT 2 WORDS.
                INCR    TMINDEX
SNAPAGN         INCR    SUBLIST         # SET POINTER TO NEXT 2 WORDS OF SNAPSHOT
                INDEX   SUBLIST
                0       0               # = CA SSSS (SSSS = NEXT ENTRY IN SUBLIST)
                CCS     A               # TEST FOR LAST TWO WORDS OF SNAPSHOT.
                TCF     SNAPLOOP        # NOT LAST TWO.
LDNPHAS2        GENADR  DNPHASE2
                TS      SUBLIST         # YES, LAST.  SAVE A.
                CA      NEGONE          # SET DNECADR AND
                TS      DNECADR         #       SUBLIST POINTERS
                XCH     SUBLIST         #               TO NEGATIVE VALUES
                TS      EBANK
                MASK    LOW8
                EXTEND
```

```
INDEX   A
EBANK=  1401
DCA     1401            # PICK UP FIRST 2 WORDS OF SNAPSHOT.
```

Uses A 80, DNTMBUFF 148, EBANK 80, IT 185, Q 80, SAVE 191, TC 169, and TMINDEX 148.

2471 ⟨*Page LM0994* 2471⟩≡ (2460 2678)

```
                EBANK=  DNTMBUFF
SNAPEND         TCF     DNTMEXIT        # NOW TO SEND THEM.

FETCH2WD        CA      DNECADR
                TS      EBANK           # SET EBANK
                MASK    LOW8            # ISOLATE RELATIVE ADDRESS
                TS      L
                CA      DNADRDCR        # DECREMENT COUNT AND ECADR
                ADS     DNECADR
                EXTEND
                INDEX   L
                EBANK=  1400
                DCA     1400            # PICK UP 2 DATA WORDS
                EBANK=  DNTMBUFF
                TCF     DNTMEXIT        # NOW GO SEND THEM.

DOSUBLST        TS      SUBLIST         # SET SUBLIST POINTER
NEXTINSL        INDEX   SUBLIST
                0       0               # = CA SSSS (SSSS = NEXT ENTRY IN SUBLIST)
                CCS     A               # IS IT THE END OF THE SUBLIST
                INCR    SUBLIST         # NO --
                TCF     +4
                TS      SUBLIST         # SAVE A.
                CA      NEGONE          # SET SUBLIST TO MINUS
                XCH     SUBLIST         # RETRIEVE A.
        +4      INCR    A
                TS      DNECADR         # SAVE DNADR
                TCF     SETWO +2        # GO USE COMMON CODING (PROLEMS WOULD
                                        # OCCUR IF THE PROGRAM ENCOUNTERED A
                                        # DNPTR NOW)

DNTMEXIT        EXTEND                  # DOWN-TELEMETRY EXIT
                WRITE   DNTM1           # TO SEND A + L TO CHANNELS 34 + 35
                CA      L               # RESPECTIVELY
TMEXITL         EXTEND
                WRITE   DNTM2
TMRESUME        TCF     RESUME          # EXIT TELEMETRY PROGRAM VIA RESUME.

MINB12          EQUALS  -1/8
DNECADR         EQUALS  TMINDEX
CTLIST          EQUALS  LDATALST
SUBLIST         EQUALS  DNQ
```

Uses A 80, COUNT 142, DNQ 148, DNTM1 87, DNTM2 87, DNTMBUFF 148, EBANK 80, IT 185, L 80, LDATALST 148, SAVE 191, and TMINDEX 148.

2472 ⟨*Page LM0995* 2472⟩≡ (2460 2678)

```
# SUBROUTINE NAME -- DNDUMP
#
# FUNCTIONAL DESCRIPTION -- TO SEND (DUMP) ALL ERASABLE STORAGE 'N' TIMES. (N=1 TO 4)
#       EACH BANK IS PRECEDED BY AN ID WORD, SYNCH BITS, ECADR AND TIME1 FOLLOWED BY
#       EBANK.  EBANKS ARE DUMPED IN ORDER (I.E., EBANK 0 FIRST, THEN EBANK1 ETC.)
#
# CALLING SEQUENCE -- THE GROUND OR ASTRONAUT BY KEYING V74E CAN INITIALIZE THE DUMP
#       AFTER KEYING IN V74E THE CURRENT DOWNLIST WILL BE IMMEDIATELY TERMINATED AND
#       WILL BEGIN.
#
#       ONCE INITIATED THE DOWNLINK ERASABLE DUMP CAN BE TERMINATED (AND INTERRUPTED
#       BY THE FOLLOWING:
#
#       1.      A FRESH START
#       2.      COMPLETION OF ALL DOWNLINK DUMPS REQUESTED (ACCORDING TO BITS SET IN
#               CAN BE ALTERED BY A V21N01.
#       3.      AND INVOLUNTARILY BY A RESTART.
#
# NORMAL EXIT MODE -- TCF DNPHASE1
#
# ALARM OR ABORT MODE -- NONE
#
# *SUBROUTINES CALLED -- NONE
#
# ERASABLE INITIALIZATION REQUIRED --
#       DUMPCNT         OCT 20000       IF 4 COMPLETE ERASABLE DUMPS ARE DESIRED
#       DUMPCNT         OCT 10000       IF 2 COMPLETE ERASABLE DUMPS ARE DESIRED
#       DUMPCNT         OCT 04000       IF 1 COMPLETE ERASABLE DUMP  IS  DESIRED
#
# DEBRIS -- DUMPLOC, DUMPSW, DNTMGOTO, EBANK, AND CENTRAL REGISTERS
#
# TIMING --     TIME (IN SECS) = ((NO.DUMPS)*(NO.EBANKS)*(WDSPEREBANK + NO.IDWDS)) /
#               TIME (IN SECS) =  (   4    )*(    8    )*(    256     +     4   )  /
#               THUS TIME (IN SECS TO SEND DUMP OF ERASABLE 4 TIMES VIA DOWNLINK) = 8
#
# STRUCTURE OF ONE EBANK AS IT IS SENT BY DOWNLINK PROGRAM --
#       (REMINDER -- THIS ONLY DESCRIBES ONE OF THE 8 EBANKS X 4 (DUMPS) = 32 EBANKS
#
#       DOWNLIST                                W
#         WORD  TAKEN FROM CONTENTS OF  EXAMPLE 0       COMMENTS
#           1   ERASID                   0177X  0       DOWNLIST I.D. FOR DOWNLINK EB
#           2   LOWIDCOD                 77340  1       DOWNLINK SYNCH BITS.  (SAME C
#           3   DUMPLOC                  13400  1       (SEE NOTES ON DUMPLOC) 1 = 3E
#           4   TIME1                    14120  1       TIME IN CENTISECONDS
#           5   FIRST WORD OF EBANK X    03400  1       IN THIS EXAMPLE THIS WORD = C
```

```
#           6   2ND   WORD OF EBANK X    00142  1       IN THIS EXAMPLE THIS WORD = CONTENTS OF
#           7   3RD   WORD OF EBANK X    00142  1       IN THIS EXAMPLE THIS WORD = CONTENTS OF
#           .
#           .
#           .
#        260D   256TH WORD OF EBANK X    03777  1       IN THIS EXAMPLE THIS WORD = CONTENTS OF
#
# NOTE --       DUMPLOC CONTAINS THE COUNTER AND ECADR FOR EACH WORD BEING SENT.
#               THE BIT STRUCTURE OF DUMPLOC IS FOLLOW --
#                                                 X = NOT USED
#               X ABC EEE RRRRRRRR            ABC = ERASABLE DUMP COUNTER (I.E. ABC = 0,1,2, OR
#                                                   COMPLETE ERASABLE DUMP NUMBER 1,2,3, OR 4 R
#                                             EEE = EBANK BITS
#                                        RRRRRRRR = RELATIVE ADDRESS WITHIN AN EBANK
```

Uses A 80, D 226, DNTMGOTO 148, DUMPCNT 148, DUMPLOC 148, EBANK 80, ERASID 73, I 206, IT 185, MODE 145, N 206, RESTART 57, TIME1 80, and W 183.

2474 ⟨*Page LM0996* 2474⟩≡ (2460 2678)

```
DNDUMPI         CA      ZERO            # INITIALIZE DOWNLINK
                TS      DUMPLOC         # ERASABLE DUMP
        +2      TC      SENDID          # GO SEND ID AND SYNCH BITS
                CA      LDNDUMP1        # SET DNTMGOTO
                TS      DNTMGOTO        # TO LOCATION FOR NEXT PASS
                CA      TIME1           # PLACE TIME1
                XCH     L               # INTO L
                CA      DUMPLOC         # AND ECADR OF THIS EBANK INTO A
                TCF     DNTMEXIT        # SEND DUMPLOC AND TIME1

LDNDUMP         ADRES   DNDUMP
LDNDUMP1        ADRES   DNDUMP1

DNDUMP          CA      TWO             # INCREMENT ECADR IN DUMPLOC
                ADS     DUMPLOC         # TO NEXT DP WORD TO BE
                MASK    LOW8            # DUMPED AND SAVE IT.
                CCS     A               # IS THIS THE BEGINNING OF A NEW EBANK
                TCF     DNDUMP2         # NO -- THEN CONTINUE DUMPING
                CA      DUMPLOC         # YES -- IS THIS THE END OF THE
                MASK    DUMPCNT         # N TH (N = 1 TO 4) COMPLETE ERASABLE
                MASK    PRIO34          # DUMP (BIT14 FOR 4, BIT13 FOR 2 OR BIT12
                CCS     A               # FOR 1 COMPLETE ERASABLE DUMP(S)).
                TCF     DNPHASE1        # YES -- START SENDING INTERRUPTED DOWNLIST
                                        # AGAIN
                TCF     DNDUMPI +2      # NO -- GO BACK AND INITIALIZE NEXT BANK

DNDUMP1         CA      LDNDUMP         # SET DNTMGOTO
                TS      DNTMGOTO        # FOR WORDS 3 TO 256D OF CURRENT EBANK

DNDUMP2         CA      DUMPLOC
                TS      EBANK           # SET EBANK
                MASK    LOW8            # ISOLATE RELATIVE ADDRESS.
                TS      Q               # (NOTE: MASK INSTRUCTION IS USED TO PICK
                CA      NEG0            # UP ERASABLE REGISTERS SO THAT EDITING
                TS      L               # REGISTERS 20-23 WILL NOT BE ALTERED.)
                INDEX   Q
                EBANK=  1400            # PICK UP LOW ORDER REGISTER OF PAIR
                MASK    1401            # OF ERASABLE REGISTERS.
                XCH     L
                INDEX   Q               # PICK UP HIGH ORDER REGISTER OF PAIR
                MASK    1400            # OF ERASABLE REGISTERS.
                EBANK=  DNTMBUFF
                TCF     DNTMEXIT        # GO SEND THEM

SENDID          EXTEND                  # ** ENTRANCE USED BY ERASABLE DUMP PROG. **
```

```
                QXCH    DNTMGOTO        # SET DNTMGOTO SO NEXT TIME PROG WILL GO
                CAF     ERASID          # TO LOCATION FOLLOWING 'TC SENDID'

                TS      L               # ** ENTRANCE USED BY REGULAR DOWNLINK PG **
```

Uses A 80, DNTMBUFF 148, DNTMGOTO 148, DUMPCNT 148, DUMPLOC 148, EBANK 80, ERASID 73, IT 185, L 80, N 206, Q 80, SAVE 191, TC 169, and TIME1 80.

2475a ⟨*Page LM0997* 2475a⟩≡ (2460 2678)

```
                TC      WOZERO          # GO SET WORD ORDER CODE TO ZERO
                CAF     LOWIDCOD        # PLACE SPECIAL ID CODE INTO L
                XCH     L               # AND ID BACK INTO A
                TCF     DNTMEXIT        # SEND DOWNLIST ID CODE(S).

  WOTEST        CA      BIT7            # AT THE BEGINNING OF THE LIST THE WORD
                EXTEND                  # ORDER BIT WILL BE SET BACK TO ZERO
                RAND    CHAN13
                CCS     A
                TC      DNTMGOTO
                CA      BIT7
                TCF     WO1
```

Uses A 80, CHAN13 87, CODE 140, DNTMGOTO 148, L 80, and TC 169.

4.28 interpretive constant

2475b ⟨*interpretive constant* 2475b⟩≡ (2041)
⟨*Page LM1100* 2476⟩
⟨*Page LM1101* 2477a⟩

2476 ⟨*Page LM1100* 2476⟩≡ (2475b 2726)

```
                SETLOC  INTPRET1
                BANK

                COUNT*  $$/ICONS
DP1/4TH         2DEC    .25

UNITZ           2DEC    0

UNITY           2DEC    0

UNITX           2DEC    .5

ZEROVECS        2DEC    0

                2DEC    0

                2DEC    0

DPHALF          =       UNITX
DPPOSMAX        OCT     37777
                OCT     37777
```

Uses COUNT 142 and INTPRET1 65.

2477a ⟨*Page LM1101* 2477a⟩≡ (2475b 2726)

```
# INTERPRETIVE CONSTANTS IN THE OTHER HALF-MEMORY

                SETLOC  INTPRET2
                BANK

                COUNT*  $$/ICONS
ZUNIT           2DEC    0

YUNIT           2DEC    0

XUNIT           2DEC    .5

ZEROVEC         2DEC    0

                2DEC    0

                2DEC    0

                OCT     77777           # -0, -6, -12 MUST REMAIN IN THIS ORDER
DFC-6           DEC     -6
DFC-12          DEC     -12
LODPMAX         2OCT    3777737777      # THESE TWO CONSTANTS MUST REMAIN

LODPMAX1        2OCT    3777737777      # ADJACENT AND THE SAME FOR INTEGRATION

ZERODP          =       ZEROVEC
HALFDP          =       XUNIT
```

Uses COUNT 142 and INTPRET2 57.

4.29 agc block two self-check

2477b ⟨*lm agc block two self check* 2477b⟩≡ (2041)

⟨*Page LM1284* 2478⟩
⟨*Page LM1285* 2480⟩
⟨*Page LM1286* 2482⟩
⟨*Page LM1287* 2484⟩
⟨*Page LM1288* 2486⟩
⟨*Page LM1289* 2488⟩
⟨*Page LM1290* 2490⟩
⟨*Page LM1291* 2492⟩
⟨*Page LM1292* 2494⟩
⟨*Page LM1293* 2495a⟩

2478 ⟨*Page LM1284* 2478⟩≡ (2477b 2638)

```
# PROGRAM DESCRIPTION                          DATE:  20 DECEMBER 1967
# PROGRAM NAME -- SELF-CHECK                   LOG SECTION:  AGC BLOCK TWO SELF-CHEC
# MOD NO -- 1                                  ASSEMBLY SUBROUTINE UTILITYM REV 25
# MOD BY -- GAUNTT
#
# FUNCTIONAL DESCRIPTION
#       PROGRAM HAS TWO MAIN PARTS.  THE FIRST IS SELF-CHECK WHICH RUNS AS A ZERO PRI
#       PART OF THE BACK-UP IDLE LOOP.  THE SECOND IS SHOW-BANKSUM WHICH RUNS AS A RE
#       STARTING VERB.
#
#       THE PURPOSE OF SELF-CHECK IS TO CHECK OUT VARIOUS PARTS OF THE COMPUTER AS OU
#
#       THE PURPOSE OF SHOW-BANKSUM IS TO DISPLAY THE SUM OF EACH BANK, ONE AT A TIME
#
#       IN ALL THERE ARE 7 POSSIBLE OPTIONS IN THIS BLOCK II VERSION OF SELF-CHECK.
#       FOUND IN E-2065 BLOCK II AGC SELF-CHECK AND SHOW BANKSUM BY EDWIN D. SMALLY I
#
#       THE DIFFERENT OPTIONS ARE CONTROLLED BY PUTTING DIFFERENT NUMBERS IN THE SMOD
#       A DESCRIPTION OF WHAT PARTS OF THE COMPUTER THAT ARE CHECKED BY THE OPTIONS,
#       OCTAL, TO LOAD INTO SMODE.
#               +-4             ERASABLE MEMORY
#               +-5             FIXED MEMORY
#               +-1,2,3,6,7,10  EVERYTHING IN OPTIONS 4 AND 5.
#               -0              SAME AS +-10 UNTIL AN ERROR IS DETECTED.
#               +0              NO CHECK, PUTS COMPUTER INTO THE BACKUP IDLE LOOP.
#
# WARNINGS
#       USE OF E MEMORY RESERVED FOR SELF-CHECK (EVEN IN IDLE LOOP) AS TEMP STORAGE F
#       SMODE SET GREATER THAN OCT 10 PUTS COMPUTER INTO BACKUP IDLE LOOP.
#
# CALLING SEQUENCE
#       TO CALL SELF-CHECK KEY IN
#               V 21 N 27 E     OPTION NUMBER E
#       TO CALL SHOW-BANKSUM KEY IN
#               V 91 E          DISPLAYS FIRST BANK
#               V 33 E          PROCEED, DISPLAYS NEXT BANK
#
# EXIT MODES, NORMAL AND ALARM
#       SELF-CHECK NORMALLY CONTINUES INDEFINITELY UNLESS THERE IS AN ERROR DETECTED.
#       COMPUTER INTO BACKUP IDLE LOOP, - OPTIONS NUMBERS RESTART THE OPTION.
#
#       THE -0 OPTION PROCEEDS FROM THE LINE FOLLOWING THE LINE WHERE THE ERROR WAS D
#
#       SHOW-BANKSUM PROCEEDS UNTIL A TERMINATE IS KEYED IN (V 34 E).  THE COMPUTER I
#
```

OUTPUT

Uses A 80, COMPUTER 115, D 226, DISPLAYS 59, N 206, PRIORITY 145, RESTART 57, SMODE 165, TEMP 191, and V 229.

2480 ⟨*Page LM1285* 2480⟩≡ (2477b 2638)

```
#       SELF-CHECK UPON DETECTING AN ERROR LOADS THE SELF-CHECK ALARM CONSTANT (01102
#       TURNS ON THE ALARM LIGHT.  THE OPERATOR MAY THEN DISPLAY THE THREE FAILREGS F
#       INFORMATION HE MAY KEY IN V 05 N 08 E, THE DSKY DISPLAY IN R1 WILL BE ADDRESS
#       IN R2 THE BBCON OF SELF-CHECK, AND IN R3 THE TOTAL NUMBER OF ERRORS DETECTED
#       INITIATED FRESH START (SLAP1).
#
#       SHOW-BANKSUM STARTING WITH BANK 0 DISPLAYS IN R1 THE BANK SUM (A +-NUMBER EQU
#       THE BANK NUMBER, AND IN R3 THE BUGGER WORD.
#
# ERASABLE INITIALIZATION REQUIRED
#       ACCOMPLISHED BY FRESH START
#               SMODE SET TO +0
#
# DEBRIS
#       ALL EXITS FROM THE CHECK OF ERASABLE (ERASCHK) RESTORE ORIGINAL CONTENTS TO E
#       EXCEPTION IS A RESTART.  RESTART THAT OCCURS DURING ERASCHK RESTORES ERASABLE
#       E MEMORY, IN WHICH CASE PROGRAM THEN DOES A FRESH START (DOFSTART).

                BANK    25
                SETLOC  SELFCHEC
                BANK

                COUNT*  $$/SELF
SBIT1           EQUALS  BIT1
SBIT2           EQUALS  BIT2
SBIT3           EQUALS  BIT3
SBIT4           EQUALS  BIT4
SBIT5           EQUALS  BIT5
SBIT6           EQUALS  BIT6
SBIT7           EQUALS  BIT7
SBIT8           EQUALS  BIT8
SBIT9           EQUALS  BIT9
SBIT10          EQUALS  BIT10
SBIT11          EQUALS  BIT11
SBIT12          EQUALS  BIT12
SBIT13          EQUALS  BIT13
SBIT14          EQUALS  BIT14
SBIT15          EQUALS  BIT15

S+ZERO          EQUALS  ZERO
S+1             EQUALS  BIT1
S+2             EQUALS  BIT2
S+3             EQUALS  THREE
S+4             EQUALS  FOUR
S+5             EQUALS  FIVE
```

```
S+6             EQUALS  SIX
```

Uses A 80, COUNT 142, DISPLAYS 59, FAILREG 150, N 206, R2 188, RESTART 57, SELFCHEC 71, SMODE 165, and V 229.

2482 ⟨*Page LM1286* 2482⟩≡ (2477b 2638)

```
S+7             EQUALS  SEVEN
S8BITS          EQUALS  LOW8            # 00377
CNTRCON         =       OCT50           # USED IN CNTRCHK
ERASCON1        OCTAL   00061           # USED IN ERASCHK
ERASCON2        OCTAL   01373           # USED IN ERASCHK
ERASCON6        =       OCT1400         # USED IN ERASCHK
ERASCON3        OCTAL   01461           # USED IN ERASCHK
ERASCON4        OCTAL   01773           # USED IN ERASCHK
S10BITS         EQUALS  LOW10           # 01777, USED IN ERASCHK
SBNK03          EQUALS  PRIO6           # 06000, USED IN ROPECHK
-MAXADRS        =       HI5             # FOR ROPECHK
SIXTY           OCTAL   00060
SUPRCON         OCTAL   60017           # USED IN ROPECHK
S13BITS         OCTAL   17777
CONC+S1         OCTAL   25252           # USED IN CYCLSHFT
CONC+S2         OCTAL   52400           # USED IN CYCLSHFT
ERASCON5        OCTAL   76777
S-7             =       OCT77770
S-4             EQUALS  NEG4
S-3             EQUALS  NEG3
S-2             EQUALS  NEG2
S-1             EQUALS  NEGONE
S-ZERO          EQUALS  NEG0

                EBANK=  LST1
ADRS1           ADRES   SKEEP1
SELFADRS        ADRES   SELFCHK         # SELFCHK RETURN ADDRESS.  SHOULD BE PUT
                                        # IN SELFRET WHEN GOING FROM SELFCHK TO
                                        # SHOWSUM AND PUT IN SKEEP1 WHEN GOING
                                        # FROM SHOWSUM TO SELF-CHECK.

PRERRORS        CA      ERESTORE        # IS IT NECESSARY TO RESTORE ERASABLE
                EXTEND
                BZF     ERRORS          # NO
                EXTEND
                DCA     SKEEP5
                INDEX   SKEEP7
                DXCH    0000            # RESTORE THE TWO ERASABLE REGISTERS
                CA      S+ZERO
                TS      ERESTORE
ERRORS          INHINT
                CA      Q
                TS      SFAIL           # SAVE Q FOR FAILURE LOCATION
                TS      ALMCADR         # FOR DISPLAY WITH BBANK AND ERCOUNT
                INCR    ERCOUNT         # KEEP TRACK OF NUMBER OF MALFUNCTIONS.
```

```
TCALARM2        TC      ALARM2
                OCT     01102           # SELF-CHECK MALFUNCTION INDICATOR
                CCS     SMODE
SIDLOOP         CA      S+ZERO
                TS      SMODE
```

Uses ALMCADR 165, BBANK 80, EBANK 80, ERCOUNT 165, ERESTORE 165, IT 185, LST1 167, Q 80, S1 85, S2 85, SAVE 191, SELFRET 165, SFAIL 165, SKEEP1 165, SKEEP5 165, SKEEP7 165, SMODE 165, and TC 169.

2484 ⟨*Page LM1287* 2484⟩≡ (2477b 2638)

```
                TC      SELFCHK         # GO TO IDLE LOOP
                TC      SFAIL           # CONTINUE WITH SELF-CHECK

-1CHK           CCS     A
                TCF     PRERRORS
                TCF     PRERRORS
                CCS     A
                TCF     PRERRORS
                TC      Q

SMODECHK        EXTEND
                QXCH    SKEEP1
                TC      CHECKNJ         # CHECK FOR NEW JOB
                CCS     SMODE
                TC      SOPTIONS
                TC      SMODECHK +2     # TO BACKUP IDLE LOOP
                TC      SOPTIONS
                INCR    SCOUNT
                TC      SKEEP1          # CONTINUE WITH SELF-CHECK

SOPTIONS        AD      S-7
                EXTEND
                BZMF    +2              # FOR OPTIONS BELOW NINE.
BNKOPTN         TC      SIDLOOP         # ILLEGAL OPTION.  GO TO IDLE LOOP.
                INCR    SCOUNT          # FOR OPTIONS BELOW NINE.
                AD      S+7

                INDEX   A
                TC      SOPTION1
SOPTION1        TC      SKEEP1          # WAS TC+TCF
SOPTION2        TC      SKEEP1          # WAS IN:OUT1
SOPTION3        TC      SKEEP1
SOPTION4        TC      ERASCHK
SOPTION5        TC      ROPECHK
SOPTION6        TC      SKEEP1
SOPTION7        TC      SKEEP1
SOPTON10        TC      SKEEP1          # CONTINUE WITH SELF-CHECK

CHECKNJ         EXTEND
                QXCH    SELFRET         # SAVE RETURN ADDRESS WHILE TESTING NEWJOB
                TC      POSTJUMP        # TO SEE IF ANY JOBS HAVE BECOME ACTIVE.
                CADR    ADVAN

SELFCHK         TC      SMODECHK        # ** CHARLEY, COME IN HERE
```

```
# SKEEP7 HOLDS LOWEST OF TWO ADDRESSES BEING CHECKED.
# SKEEP6 HOLDS B(X+1).
# SKEEP5 HOLDS B(X).
# SKEEP4 HOLDS C(EBANK) DURING ERASLOOP AND CHECKNJ
# SKEEP3 HOLDS LAST ADDRESS BEING CHECKED (HIGHEST ADDRESS).
```

Uses A 80, EBANK 80, NEWJOB 138, Q 80, SAVE 191, SCOUNT 165, SELFRET 165, SFAIL 165, SKEEP1 165, SKEEP3 165, SKEEP4 165, SKEEP5 165, SKEEP6 165, SKEEP7 165, SMODE 165, and TC 169.

2486 ⟨*Page LM1288* 2486⟩≡ (2477b 2638)

```
# SKEEP2 CONTROLS CHECKING OF NON-SWITCHABLE ERASABLE MEMORY WITH BANK NUMBERS IN EB
#
# ERASCHK TAKES APPROXIMATELY 7 SECONDS.

ERASCHK         CA      S+1
                TS      SKEEP2
OEBANK          CA      S+ZERO
                TS      EBANK
                CA      ERASCON3        # 01461
                TS      SKEEP7          # STARTING ADDRESS
                CA      S10BITS         # 01777
                TS      SKEEP3          # LAST ADDRESS CHECKED
                TC      ERASLOOP

E134567B        CA      ERASCON6        # 01400
                TS      SKEEP7          # STARTING ADDRESS
                CA      S10BITS         # 01777
                TS      SKEEP3          # LAST ADDRESS CHECKED
                TC      ERASLOOP

2EBANK          CA      ERASCON6        # 01400
                TS      SKEEP7          # STARTING ADDRESS
                CA      ERASCON4        # 01773
                TS      SKEEP3          # LAST ADDRESS CHECKED
                TC      ERASLOOP

NOEBANK         TS      SKEEP2          # +0
                CA      ERASCON1        # 00061
                TS      SKEEP7          # STARTING ADDRESS
                CA      ERASCON2        # 01373
                TS      SKEEP3          # LAST ADDRESS CHECKED

ERASLOOP        INHINT
                CA      EBANK           # STORES C(EBANK)
                TS      SKEEP4
                EXTEND
                NDX     SKEEP7
                DCA     0000
                DXCH    SKEEP5          # STORES C(X) AND C(X+1) IN SKEEP6 AND 5.
                CA      SKEEP7
                TS      ERESTORE        # IF RESTART, RESTORE C(X) AND C(X+1)
                TS      L
                INCR    L
                NDX     A
                DXCH    0000            # PUTS OWN ADDRESS IN X AND X +1
```

```
NDX     SKEEP7
CS      0001            # CS X+1
NDX     SKEEP7
AD      0000            # AD X
TC      -1CHK
CA      ERESTORE        # HAS ERASABLE BEEN RESTORED
EXTEND
```

Uses A 80, EBANK 80, ERESTORE 165, L 80, RESTART 57, SKEEP2 165, SKEEP3 165, SKEEP4 165, SKEEP5 165, SKEEP6 165, SKEEP7 165, and TC 169.

2488 ⟨*Page LM1289* 2488⟩≡ (2477b 2638)

```
                    BZF     ELOOPFIN        # YES, EXIT ERASLOOP.
                    EXTEND
                    NDX     SKEEP7
                    DCS     0000            # COMPLEMENT OF ADDRESS OF X AND X+1
                    NDX     SKEEP7
                    DXCH    0000            # PUT COMPLEMENT OF ADDRESS OF X AND X+1
                    NDX     SKEEP7
                    CS      0000            # CS X
                    NDX     SKEEP7
                    AD      0001            # AD X+1
                    TC      -1CHK
                    CA      ERESTORE        # HAS ERASABLE BEEN RESTORED
                    EXTEND
                    BZF     ELOOPFIN        # YES, EXIT ERASLOOP.
                    EXTEND
                    DCA     SKEEP5
                    NDX     SKEEP7
                    DXCH    0000            # PUT B(X) AND B(X+1) BACK INTO X AND X+1
                    CA      S+ZERO
                    TS      ERESTORE        # IF RESTART, DO NOT RESTORE C(X), C(X+1)
ELOOPFIN            RELINT
                    TC      CHECKNJ         # CHECK FOR NEW JOB
                    CA      SKEEP4          # REPLACES B(EBANK)
                    TS      EBANK
                    INCR    SKEEP7
                    CS      SKEEP7
                    AD      SKEEP3
                    EXTEND
                    BZF     +2
                    TC      ERASLOOP        # GO TO NEXT ADDRESS IN SAME BANK
                    CCS     SKEEP2
                    TC      NOEBANK
                    INCR    SKEEP2          # PUT +1 IN SKEEP2.
                    CA      EBANK
                    AD      SBIT9
                    TS      EBANK
                    AD      ERASCON5        # 76777, CHECK FOR BANK E2
                    EXTEND
                    BZF     2EBANK
                    CCS     EBANK
                    TC      E134567B        # GO TO EBANKS 1,3,4,5,6, AND 7
                    CA      ERASCON6        # END OF ERASCHK
                    TS      EBANK

# CNTRCHK PERFORMS A CS OF ALL REGISTERS FROM OCT. 60 THROUGH OCT. 10.
```

```
# INCLUDED ARE ALL COUNTERS, T6-1, CYCLE AND SHIFT, AND ALL RUPT REGISTERS

CNTRCHK         CA      CNTRCON         # 00050
CNTRLOOP        TS      SKEEP2
                AD      SBIT4           # +10 OCTAL
                INDEX   A
                CS      0000
```

Uses A 80, E2 236, EBANK 80, ERESTORE 165, RESTART 57, SKEEP2 165, SKEEP3 165, SKEEP4 165, SKEEP5 165, SKEEP7 165, and TC 169.

2490 ⟨*Page LM1290* 2490⟩≡ (2477b 2638)

```
                CCS     SKEEP2
                TC      CNTRLOOP

# CYCLSHFT CHECKS THE CYCLE AND SHIFT REGISTERS

CYCLSHFT        CA      CONC+S1         # 25252
                TS      CYR             # C(CYR) = 12525
                TS      CYL             # C(CYL) = 52524
                TS      SR              # C(SR) = 12525
                TS      EDOP            # C(EDOP) = 00125
                AD      CYR             # 37777         C(CYR) = 45252
                AD      CYL             # 00-12524      C(CYL) = 25251
                AD      SR              # 00-25251      C(SR) = 05252
                AD      EDOP            # 00-25376      C(EDOP) = +0
                AD      CONC+S2         # C(CONC+S2) = 52400
                TC      -1CHK
                AD      CYR             # 45252
                AD      CYL             # 72523
                AD      SR              # 77775
                AD      EDOP            # 77775
                AD      S+1             # 77776
                TC      -1CHK

                INCR    SCOUNT +1
                TC      SMODECHK

# SKEEP1 HOLDS SUM
# SKEEP2 HOLDS PRESENT CONTENTS OF ADDRESS IN ROPECHK AND SHOWSUM ROUTINES
# SKEEP2 HOLDS BANK NUMBER IN LOW ORDER BITS DURING SHOWSUM DISPLAY
# SKEEP3 HOLDS PRESENT ADDRESS (00000 TO 01777 IN COMMON FIXED BANKS)
#                              (04000 TO 07777 IN FXFX BANKS)
# SKEEP3 HOLDS BUGGER WORD DURING SHOWSUM DISPLAY
# SKEEP4 HOLDS BANK NUMBER AND SUPER BANK NUMBER
# SKEEP5 COUNTS 2 SUCCESSIVE TC SELF WORDS
# SKEEP6 CONTROLS ROPECHK OR SHOWSUM OPTION
# SKEEP7 CONTROLS WHEN ROUTINE IS IN COMMON FIXED OR FIXED FIXED BANKS

ROPECHK         CA      S-ZERO          # *
                TS      SKEEP6          # * -0 FOR ROPECHK
STSHOSUM        CA      S+ZERO          # * SHOULD BE ROPECHK

                TS      SKEEP4          # BANK NUMBER
                CA      S+1
COMMFX          TS      SKEEP7
                CA      S+ZERO
```

```
                TS      SKEEP1
                TS      SKEEP3
                CA      S+1
                TS      SKEEP5          # COUNTS DOWN 2 TC SELF WORDS
COMADRS         CA      SKEEP4
                TS      L               # TO SET SUPER BANK
                MASK    HI5
```

Uses CYL 80, CYR 80, EDOP 80, L 80, S1 85, S2 85, SCOUNT 165, SKEEP1 165, SKEEP2 165, SKEEP3 165, SKEEP4 165, SKEEP5 165, SKEEP6 165, SKEEP7 165, SR 80, and TC 169.

2492 ⟨*Page LM1291* 2492⟩≡ (2477b 2638)

```
                AD      SKEEP3
                TC      SUPDACAL        # SUPER DATA CALL
                TC      ADSUM
                AD      SBIT11          # 02000
                TC      ADRSCHK

FXFX            CS      A
                TS      SKEEP7
                EXTEND
                BZF     +3
                CA      SBIT12          # 04000, STARTING ADDRESS OF BANK 02
                TC      +2
                CA      SBNK03          # 06000, STARTING ADDRESS OF BANK 03
                TS      SKEEP3
                CA      S+ZERO
                TS      SKEEP1
                CA      S+1
                TS      SKEEP5          # COUNTS DOWN 2 TC SELF WORDS
FXADRS          INDEX   SKEEP3
                CA      0000
                TC      ADSUM
                TC      ADRSCHK

ADSUM           TS      SKEEP2
                AD      SKEEP1
                TS      SKEEP1
                CAF     S+ZERO
                AD      SKEEP1
                TS      SKEEP1
                CS      SKEEP2
                AD      SKEEP3
                TC      Q

ADRSCHK         LXCH    A
                CA      SKEEP3
                MASK    LOW10           # RELATIVE ADDRESS
                AD      -MAXADRS        # SUBTRACT MAX RELATIVE ADDRESS = 1777.
                EXTEND
                BZF     SOPTION         # CHECKSUM FINISHED IF LAST ADDRESS.
                CCS     SKEEP5          # IS CHECKSUM FINISHED
                TC      +3              # NO
                TC      +2              # NO
                TC      SOPTION         # GO TO ROPECHK SHOWSUM OPTION
                CCS     L               # -0 MEANS A TC SELF WORD.
                TC      CONTINU
```

```
TC      CONTINU
TC      CONTINU
CCS     SKEEP5
TC      CONTINU +1
CA      S-1
```

Uses A 80, L 80, Q 80, SKEEP1 165, SKEEP2 165, SKEEP3 165, SKEEP5 165, SKEEP7 165, and TC 169.

2494 ⟨*Page LM1292* 2494⟩≡ (2477b 2638)

```
                TC      CONTINU +1      # AD IN THE BUGGER WORD
CONTINU         CA      S+1             # MAKE SURE TWO CONSECUTIVE TC SELF WORDS
                TS      SKEEP5
                CCS     SKEEP6          # *
                CCS     NEWJOB          # * +1, SHOWSUM
                TC      CHANG1          # *
                TC      +2              # *
                TC      CHECKNJ         # -0 IN SKEEP6 FOR ROPECHK

ADRS+1          INCR    SKEEP3
                CCS     SKEEP7
                TC      COMADRS
                TC      COMADRS
                TC      FXADRS
                TC      FXADRS

NXTBNK          CS      SKEEP4
                AD      LSTBNKCH        # LAST BANK TO BE CHECKED
                EXTEND
                BZF     ENDSUMS         # END OF SUMMING OF BANKS.
                CA      SKEEP4
                AD      SBIT11
                TS      SKEEP4          # 37 TO 40 INCRMTS SKEEP4 BY END RND CARRY
                TC      CHKSUPR
17TO20          CA      SBIT15
                ADS     SKEEP4          # SET FOR BANK 20
                TC      GONXTBNK
CHKSUPR         MASK    HI5
                EXTEND
                BZF     NXTSUPR         # INCREMENT SUPER BANK
27TO30          AD      S13BITS
                EXTEND
                BZF     +2              # BANK SET FOR 30
                TC      GONXTBNK
                CA      SIXTY           # FIRST SUPER BANK
                ADS     SKEEP4
                TC      GONXTBNK
NXTSUPR         AD      SUPRCON         # SET BNK 30 + INCR SUPR BNK AND CANCEL
                ADS     SKEEP4          # ERC BIT OF THE 37 TO 40 ADVANCE.
GONXTBNK        CCS     SKEEP7
                TC      COMMFX
                CA      S+1
                TC      FXFX
                CA      SBIT7           # HAS TO BE LARGER THAN NO OF FXSW BANKS.
                TC      COMMFX
```

```
SOPTION         CA      SKEEP4
                MASK    HI5             # = BANK BITS
                TC      LEFT5
                TS      L               # BANK NUMBER BEFORE SUPER BANK
```

Uses L 80, NEWJOB 138, SKEEP3 165, SKEEP4 165, SKEEP5 165, SKEEP6 165, SKEEP7 165, and TC 169.

2495a ⟨*Page LM1293* 2495a⟩≡ (2477b 2638)

```
                CA      SKEEP4
                MASK    S8BITS          # = SUPER BANK BITS
                EXTEND
                BZF     SOPT            # BEFORE SUPER BANK
                TS      SR              # SUPER BANK NECESSARY
                CA      L
                MASK    SEVEN
                AD      SR
                TS      L               # BANK NUMBER WITH SUPER BANK
SOPT            CA      SKEEP6          # *
                EXTEND                  # *
                BZF     +2              # * ON -0 CONTINUE WITH ROPE CHECK.
                TC      SDISPLAY        # * ON +1 GO TO DISPLAY OF SUM.
                CCS     SKEEP1          # FORCE SUM TO ABSOLUTE VALUE.
                TC      +2
                TC      +2
                AD      S+1
                TS      SKEEP1
BNKCHK          CS      L               # = - BANK NUMBER
                AD      SKEEP1
                AD      S-1
                TC      -1CHK           # CHECK SUM
                TC      NXTBNK

                EBANK=  NEWJOB
LSTBNKCH        BBCON*                  # * CONSTANT, LAST BANK.
```

Uses EBANK 80, L 80, NEWJOB 138, SKEEP1 165, SKEEP4 165, SKEEP6 165, SR 80, and TC 169.

4.30 lm rtb op codes

2495b ⟨*lm rtb op codes* 2495b⟩≡ (2041)

```
# RTB-OP-CODES.agc:# Pages:     1397-1401
```

4.31 t6 rupt programs

2496 ⟨*t6 rupt programs* 2496⟩≡ (2041 2815)

```
# Page 1403
# PROGRAM NAMES:        (1) T6JOBCHK    MOD. NO. 5      OCTOBER 2, 1967
#                       (2) DOT6RUPT
# MODIFICATION BY:      LOWELL G. HULL (A.C.ELECTRONICS)
#
# THESE PROGRAMS ENABLE THE LM DAP TO CONTROL THE THRUST TIMES OF THE REACTION CONTRO
# SINCE THE LM DAP MAINTAINS EXCLUSIVE CONTROL OVER TIME6 AND ITS INTERRUPTS, THE FOL
# ESTABLISHED AND MUST NOT BE TAMPERED WITH:
#       1.      NO NUMBER IS EVER PLACED INTO TIME6 EXCEPT BY LM DAP.
#       2.      NO PROGRAM OTHER THAN LM DAP ENABLES THE TIME6 COUNTER.
#       3.      TO USE TIME6, THE FOLLOWING SEQUENCE IS ALWAYS EMPLOYED:
#               A.      A POSITIVE (NON-ZERO) NUMBER IS STORED IN TIME6.
#               B.      THE TIME6 CLOCK IS ENABLED.
#               C.      TIME6 IS INTERROGATED AND IS:
#                       I.      NEVER FOUND NEGATIVE (NON-ZERO) OR +0.
#                       II.     SOMETIMES FOUND POSITIVE (BETWEEN 1 AND 240D) INDICAT
#                       III.    SOMETIMES FOUND POSMAX INDICATING THAT IT IS INACTIVE
#                       IV.     SOMETIMES FOUND NEGATIVE ZERO INDICATING THAT:
#                               A.      A T6RUPT IS ABOUT TO OCCUR AT THE NEXT DINC,
#                               B.      A T6RUPT IS WAITING IN THE PRIORITY CHAIN, OR
#                               C.      A T6RUPT IS IN PROCESS NOW.
#       4.      ALL PROGRAMS WHICH OPERATE IN EITHER INTERRUPT MODE OR WITH INTERRUPT
#               EVERY 5 MILLISECONDS TO PROCESS A POSSIBLE WAITING T6RUPT BEFORE IT C
#      (5.      PROGRAM JTLST, IN Q,R-AXES, HANDLES THE INPUT LIST.)
#
# T6JOBCHK CALLING SEQUENCE:
#               L       TC      T6JOBCHK
#               L+1     (RETURN)
#
# DOT6RUPT CALLING SEQUENCE:
#                       DXCH    ARUPT           # T6RUPT LEAD IN AT LOCATION 4004.
#                       EXTEND
#                       DCA     T6ADR
#                       DTCB
#
# SUBROUTINES CALLED:   DOT6RUPT CALLS T6JOBCHK.
#
# NORMAL EXIT MODES:    T6JOBCHK RETURNS TO L +1.
#                       DOT6RUPT TRANSFERS CONTROL TO RESUME.
#
# ALARM/ABORT MODES:    NONE.
#
# INPUT:        TIME6           NXT6ADR         OUTPUT:         TIME6           NXT6A
```

```
#               T6NEXT          T6NEXT +1                       T6NEXT          T6NEXT +1
#               T6FURTHA        T6FURTHA +1                     T6FURTHA        T6FURTHA +1
#
# DEBRIS:       T6JOBCHK CLOBBERS A.  DOT6RUPT CLOBBERS NOTHING.

                BLOCK   02
# Page 1404
                BANK    17
                SETLOC  DAPS2
                BANK
                EBANK=  T6NEXT
                COUNT*  $$/DAPT6

T6JOBCHK        CCS     TIME6           # CHECK TIME6 FOR WAITING T6RUPT:
                TC      Q               # NONE: CLOCK COUNTING DOWN.
                TC      CCSHOLE
                TC      T6JOBCHK +3

# CONTROL PASSES TO T6JOB ONLY WHEN C(TIME6) = -0 (I.E., WHEN A T6RUPT MUST BE PROCESSED).

T6JOB           CAF     POSMAX          # DISABLE CLOCK: NEEDED SINCE RUPT OCCURS
                EXTEND                  # 1 DINC AFTER T6 = 77777. FOR 625 MUSECS
                WAND    CHAN13          # MUST NOT HAVE T6 = +0 WITH ENABLE SET

                CA      POSMAX
                ZL
                DXCH    T6FURTHA
                DXCH    T6NEXT
                LXCH    NXT6ADR
                TS      TIME6

                AD      PRIO37
                TS      A
                TCF     ENABLET6
                CA      POSMAX
                TS      TIME6
                TCF     GOCH56
ENABLET6        CA      BIT15
                EXTEND
                WOR     CHAN13
                CA      T6NEXT
                AD      PRIO37
                TS      A
                TCF     GOCH56
                CA      POSMAX
                TS      T6NEXT
```

```
GOCH56          INDEX   L
                TCF     WRITEP -1

                BLOCK   02
                SETLOC  FFTAG9
                BANK
                EBANK=  CDUXD
                COUNT*  $$/DAPT6

                CA      NEXTP
WRITEP          EXTEND
                WRITE   CHAN6
# Page 1405
                TC      Q

                CA      NEXTU
WRITEU          TS      L
                CS      00314OCT
                EXTEND
                RAND    CHAN5
                AD      L
                EXTEND
                WRITE   CHAN5
                TC      Q

                CA      NEXTV
WRITEV          TS      L
                CA      00314OCT
                TCF     -9D
00314OCT        OCT     00314

                BANK    17
                SETLOC  DAPS2
                BANK

                EBANK=  T6NEXT
                COUNT*  $$/DAPT6

DOT6RUPT        LXCH    BANKRUPT        # (INTERRUPT LEAD INS CONTINUED)
                EXTEND
                QXCH    QRUPT

                TC      T6JOBCHK        # CALL T6JOBCHK.

                TCF     RESUME          # END TIME6 INTERRUPT PROCESSOR.
```

Uses A 80, ARUPT 80, BANKRUPT 80, CDUXD 213, CHAN13 87, COUNT 142, DAPS2 63, EBANK 80, FFTAG9 57, I 206, IT 185, L 80, MODE 145, PRIORITY 145, Q 80, QRUPT 80, T6ADR 163, TC 169, THRUST 85, and TIME6 80.

4.32 dap interface subroutines

2499a ⟨*dap interface subroutines* 2499a⟩≡ (2041)
⟨*Page LM1406* 2499b⟩
⟨*Page LM1407* 2500⟩
⟨*Page LM1408* 2502⟩
⟨*Page LM1409* 2503a⟩

2499b ⟨*Page LM1406* 2499b⟩≡ (2499a 2672)

```
                 BANK    20
                 SETLOC  DAPS3
                 BANK

                 EBANK=  CDUXD
                 COUNT*  $$/DAPIF

# MOD 0          DATE    11/15/66        BY GEORGE W. CHERRY
# MOD 1                   1/23/67        MODIFICATION BY PETER ADLER
#
# FUNCTIONAL DESCRIPTION
#       HEREIN IS A COLLECTION OF SUBROUTINES WHICH ALLOW MISSION CONTROL PROGRAMS TO CONTROL T
#       AND INTERFACE WITH THE DAP.
#
# CALLING SEQUENCES
#       IN INTERRUPT OR WITH INTERRUPT INHIBITED
#               TC      IBNKCALL
#               FCADR   ROUTINE
#       IN A JOB WITHOUT INTERRUPT INHIBITED
#               INHINT
#               TC      IBNKCALL
#               FCADR   ROUTINE
#               RELINT
#
# OUTPUT
#       SEE INDIVIDUAL ROUTINES BELOW
#
# DEBRIS
#       A, L, AND SOMETIMES MDUETEMP                    ODE     NOT IN PULSES MODE
```

Uses A 80, CDUXD 213, COUNT 142, DAPS3 63, EBANK 80, L 80, MODE 145, TC 169, and W 183.

2500 ⟨*Page LM1407* 2500⟩≡ (2499a 2672)

```
# SUBROUTINE NAMES:
#       SETMAXDB, SETMINDB, RESTORDB, PFLITEDB
# MODIFIED:     30 JANUARY 1968 BY P. S. WEISSMAN TO CREATE RESTORDB.
# MODIFIED:     1 MARCH 1968 BY P. S. WEISSMAN TO SAVE EBANK AND CREATE PFLITEDB
#
# FUNCTIONAL DESCRIPTION:
#       SETMAXDB -- SET DEADBAND TO 5.0 DEGREES
#       SETMINDB -- SET DEADBAND TO 0.3 DEGREE
#       RESTORDB -- SET DEADBAND TO MAX OR MIN ACCORDING TO SETTINGS OF DBSELECT BIT
#       PFLITEDB -- SET DEADBAND TO 1.0 DEGREE AND ZERO THE COMMANDED ATTITUDE CHANGE
#
#       ALL ENTRIES SET UP A NOVAC JOB TO DO 1/ACCS SO THAT THE TJETLAW SWITCH CURVES
#       REFLECT THE NEW DEADBAND.  IT SHOULD BE NOTED THAT THE DEADBAND REFERS TO THE
#
# SUBROUTINE CALLED:    NOVAC
#
# CALLING SEQUENCE:     SAME AS ABOVE
#                       OR      TC RESTORDB +1    FROM ALLCOAST
#
# DEBRIS:               A, L, Q, RUPTREG1, (ITEMPS IN NOVAC)

RESTORDB        CAE     DAPBOOLS        # DETERMINE CREW-SELECTED DEADBAND.
                MASK    DBSELECT
                EXTEND
                BZF     SETMINDB

SETMAXDB        CAF     WIDEDB          # SET 5 DEGREE DEADBAND.
        +1      TS      DB

                EXTEND                  # SET UP JOB TO RE-POSITION SWITCH CURVES.
                QXCH    RUPTREG1
CALLACCS        CAF     PRIO27
                TC      NOVAC
                EBANK=  AOSQ
                2CADR   1/ACCJOB

                TC      RUPTREG1        # RETURN TO CALLER.

SETMINDB        CAF     NARROWDB        # SET 0.3 DEGREE DEADBAND.
                TCF     SETMAXDB +1

PFLITEDB        EXTEND                  # THE RETURN FROM CALLACCS IS TO RUPTREG1.
                QXCH    RUPTREG1
                TC      ZATTEROR        # ZERO THE ERRORS AND COMMANDED RATES.
                CAF     POWERDB         # SET DB TO 1.0 DEG.
```

```
                TS      DB
                TCF     CALLACCS        # SET UP 1/ACCS AND RETURN TO CALLER.
NARROWDB        OCTAL   00155           # 0.3 DEGREE SCALED AT 45.
```

Uses A 80, EBANK 80, IT 185, L 80, P 188, Q 80, RUPTREG1 138, SAVE 191, TC 169, and V 229.

2502 ⟨*Page LM1408* 2502⟩≡ (2499a 2672)

```
WIDEDB          OCTAL   03434           # 5.0 DEGREES SCALED AT 45.
POWERDB         DEC     .02222          # 1.0 DEGREE SCALED AT 45.

ZATTEROR        CAF     EBANK6
                XCH     EBANK
                TS      L               # SAVE CALLERS EBANK IN L.
                CAE     CDUX
                TS      CDUXD
                CAE     CDUY
                TS      CDUYD
                CAE     CDUZ
                TS      CDUZD
                TCF     STOPRATE +3

STOPRATE        CAF     EBANK6
                XCH     EBANK
                TS      L               # SAVE CALLERS EBANK IN L.
        +3      CAF     ZERO
                TS      OMEGAPD
                TS      OMEGAQD
                TS      OMEGARD
                TS      DELCDUX
                TS      DELCDUY
                TS      DELCDUZ
                TS      DELPEROR
                TS      DELQEROR
                TS      DELREROR
                LXCH    EBANK           # RESTORE CALLERS EBANK.
                TC      Q

# SUBROUTINE NAME:      ALLCOAST
# WILL BE CALLED BY FRESH STARTS AND ENGINE OFF ROUTINES.
#
# CALLING SEQUENCE:     (SAME AS ABOVE)
#
# EXIT:                 RETURN TO Q.
#
# SUBROUTINES CALLED:   STOPRATE, RESTORDB, NOVAC
#
# ZERO:                 (FOR ALL AXES) AOS, ALPHA, AOSTERM, OMEGAD, DELCDU, DELEROR
#
# OUTPUT:               DRIFTBIT/DAPBOOLS, OE, JOB TO DO 1/ACCS
#
# DEBRIS:               A, L, Q, RUPTREG1, RUPTREG2, (ITEMPS IN NOVAC)
```

```
ALLCOAST        EXTEND                  # SAVE Q FOR RETURN
                QXCH    RUPTREG2
```

Uses A 80, CDUX 80, CDUXD 213, CDUY 80, CDUYD 213, CDUZ 80, CDUZD 213, DELCDUX 211, DELCDUY 211, DELCDUZ 211, EBANK 80, L 80, Q 80, RUPTREG1 138, RUPTREG2 138, SAVE 191, and TC 169.

2503a ⟨*Page LM1409* 2503a⟩≡ (2499a 2672)

```
                TC      STOPRATE        # CLEAR RATE INTERFACE.  RETURN WITH A=0
                LXCH    EBANK           # AND L=EBANK6.  SAVE CALLER'S EBANK.
                TS      AOSQ
                TS      AOSQ +1
                TS      AOSR
                TS      AOSR +1
                TS      ALPHAQ          # FOR DOWNLIST.
                TS      ALPHAR
                TS      AOSQTERM
                TS      AOSRTERM
                LXCH    EBANK           # RESTORE EBANK (EBANK6 NO LONGER NEEDED)

                CS      DAPBOOLS        # SET UP DRIFTBIT
                MASK    DRIFTBIT
                ADS     DAPBOOLS
                TC      RESTORDB +1     # RESTORE DEADBANK TO CREW-SELECTED VALUE.

                TC      RUPTREG2        # RETURN.
```

Uses A 80, EBANK 80, L 80, RUPTREG2 138, SAVE 191, and TC 169.

4.33 dapidler program

2503b ⟨*dapidler program* 2503b⟩≡ (2041)

⟨*Page LM1410* 2504⟩
⟨*Page LM1411* 2505⟩
⟨*Page LM1412* 2507⟩
⟨*Page LM1413* 2509⟩
⟨*Page LM1414* 2510⟩
⟨*Page LM1415* 2512⟩
⟨*Page LM1416* 2513⟩
⟨*Page LM1417* 2514⟩
⟨*Page LM1418* 2515⟩
⟨*Page LM1419* 2517⟩
⟨*Page LM1420* 2518⟩

2504 ⟨*Page LM1410* 2504⟩≡ (2503b 2670)

```
# THE DAPIDLER PROGRAM IS STARTED BY FRESH START AND RESTART.  THE DAPIDLER PROGRAM I
# PER SECOND UNTIL THE ASTRONAUT DESIRES THE DAP TO WAKE UP, AND THE IMU AND CDUS ARE
# THE NECESSARY INITIALIZATION OF THE DAP IS DONE BY THE DAPIDLER PROGRAM.

                BANK    16
                SETLOC  DAPS1
                BANK

                EBANK=  AOSQ

                COUNT*  $$/DAPID

CHEKBITS        EXTEND
                READ    CHAN31          # IF BOTH BIT13 AND BIT14 ARE ONE, THEN
                COM                     # THE MODE SELECT SWITCH IS IN THE OFF
                MASK    BIT13-14        # POSITION, AND SO THE DAP SHOULD BE OFF,
                EXTEND                  # WITH NO ATTITUDE ERROR DISPLAY.
                BZF     MOREIDLE

                CS      IMODES33
                MASK    BIT6
                CCS     A
                TCF     JUMPDSP
                CS      RCSFLAGS        # IMU NOT USABLE.  SET UP INITIALIZATION
                MASK    BIT3            # FLAG FOR ATT ERROR DISPLAY ROUTINE.
                ADS     RCSFLAGS
                TCF     SHUTDOWN

CHEKMORE        CAF     BIT10           # BIT 10 OF 30 IS PGNCS CONTROL OF S/C
                EXTEND
                RAND    CHAN30          # BITS IN 30 ARE INVERTED
                CCS     A
                TCF     MOREIDLE

                RETURN
```

Uses A 80, CDUS 80, CHAN30 87, CHAN31 87, COUNT 142, DAPS1 63, EBANK 80, IMODES33 163, MODE 145, RCSFLAGS 200, and RESTART 57.

2505 ⟨*Page LM1411* 2505⟩≡ (2503b 2670)

```
# DAPIDLER ENTRY.

DAPIDLER        LXCH    BANKRUPT        # INTERRUPT LEAD INS (CONTINUED)
                EXTEND
                QXCH    QRUPT

                CA      RCSFLAGS
                MASK    BIT13
                CCS     A               # CHECK IF 1/ACCJOB HAS BEEN SET UP SINCE
                TCF     CHECKUP         # THE LAST FRESH START OR RESTART.
                CA      BIT13
                ADS     RCSFLAGS        # BIT 13 IS 1.
                CAF     PRIO27
                TC      NOVAC           # SET UP JOB TO DO A LITTLE INITIALIZATION
                EBANK=  AOSQ            #       AND EXECUTE 1/ACCS.
                2CADR   1/ACCSET        # (WILL BRANCH TO MOREIDLE ON ACCSOKAY)

CHECKUP         TC      CHEKBITS        # CHECK TO SEE IF LM DAP IS TO GO ON AND
                                        #       DO ERROR DISPLAY.

                CAE     DAPBOOLS        # IF 1/ACCS HAS NOT BEEN COMPLETED, IDLE.
                MASK    ACCSOKAY        #       NOTE:   ONLY FRESH START AND RESTART
                EXTEND                  #               KNOCK THIS BIT DOWN.
                BZF     MOREIDLE

STARTDAP        TC      IBNKCALL        # ZERO ATTITUDE ERROR AND DESIRED RATES.
                FCADR   ZATTEROR
                CAF     ZERO            # ************ INITIALIZE: *************
                TS      TJP
                TS      TJU
                TS      TJV
                TS      OMEGAP          # RATES IN BODY (PILOT) COORDINATES.
                TS      OMEGAQ
                TS      OMEGAR
                TS      TRAPEDP
                TS      TRAPEDQ
                TS      TRAPEDR
                TS      AOSQ            # OFFSET ACCELERATION ESTIMATES.
                TS      AOSQ +1
                TS      AOSR
                TS      AOSR +1
                TS      ALPHAQ          # COPIES OF OFFSET ESTIMATES FOR DOWNLIST.
                TS      ALPHAR
                TS      NEGUQ
                TS      NEGUR
```

```
TS      AOSQTERM        # QRAXIS RATE DERIVATION TERMS AND KALMAN
TS      AOSRTERM        # FILTER INITIALIZATION TERMS.
TS      QACCDOT         # DESCENT ACCELERATION DERIVATIVE EST.
TS      RACCDOT
```

Uses `A` 80, `BANKRUPT` 80, `EBANK` 80, `QRUPT` 80, `RCSFLAGS` 200, `RESTART` 57, and `TC` 169.

2507 ⟨*Page LM1412* 2507⟩≡ (2503b 2670)

```
                    TS      ALLOWGTS        # AOSTASK FLAG FOR QRAXIS RCS CONTROL USE.
                    TS      COTROLER        # DO TRYGTS ON FIRST PASS (WILL GO TO RCS)
                    TS      INGTS           # RECOGNIZE FIRST GTS PASS AS SUCH.
                    TS      QGIMTIMR        # STOP GIMBAL DRIVES.  (PROBABLY WOULD BE
                    TS      RGIMTIMR        #       GOOD ENOUGH JUST TO INACTIVATE TIMERS)
                    TS      OLDPMIN         # MINIMUM IMPULSE MODE ERASABLES
                    TS      OLDQRMIN
                    TS      PJETCTR         # INITIALIZE DOCKED JET INHIBITION
                    TS      UJETCTR         # COUNTERS
                    TS      VJETCTR
  CALLGMBL          EQUALS  BIT5            # RCSFLAGS INITIALIZATION.
                    CS      MANFLAG
                    MASK    RCSFLAGS        # NEGUQ(R) HAVE BEEN GENERATED.
                    TS      RCSFLAGS

  # SET UP "OLD" MEASURED CDU ANGLES:

                    EXTEND
                    DCA     CDUX            # OLDXFORP AND OLDYFORP
                    DXCH    OLDXFORP
                    CA      CDUZ
                    TS      OLDZFORQ
                    CS      RCSFLAGS
                    MASK    BIT12
                    ADS     RCSFLAGS        # BIT 12 SET TO 1.
                    CA      FOUR
                    TS      SKIPU
                    TS      SKIPV
                    CA      POSMAX
                    TS      TIME6
                    TS      T6NEXT
                    TS      T6FURTHA
                    CA      ZERO
                    TS      T6NEXT +1
                    TS      T6FURTHA +1
                    TS      NXT6ADR
                    TS      NEXTP
                    TS      NEXTU
                    TS      NEXTV
                    CS      TEN
                    TS      DAPZRUPT        # JASK NOT IN PROGRESS, INITIALIZE NEG.
                    CA      TWO
                    TS      NPTRAPS
                    TS      NQTRAPS
                    TS      NRTRAPS
```

```
                EXTEND
                DCA     PAXADIDL
                DXCH    T5ADR
SETTIME5        CAF     MS100
                TS      TIME5
```

Uses CDUX 80, CDUZ 80, MODE 145, RCSFLAGS 200, TIME5 80, and TIME6 80.

2509 ⟨*Page LM1413* 2509⟩≡ (2503b 2670)

```
                TCF     RESUME
                EBANK=  AOSQ
IDLERADR        2CADR   DAPIDLER

MOREIDLE        TC      IBNKCALL        # CALCULATE Q,R-AXES ATTITUDE ERRORS.
                CADR    QERRCALC

                TC      IBNKCALL
                CADR    CALCPERR        # CALCULATE P AXIS ATTITUDE ERRORS.

SHUTDOWN        EXTEND
                DCA     IDLERADR
                DXCH    T5ADR

                CAF     ZERO            # KILL ANY POSSIBLE JET REQUESTS
                TS      NEXTP
                TS      NEXTU
                TS      NEXTV
                EXTEND                  # COMMAND JETS OFF.
                WRITE   CHAN5
                EXTEND
                WRITE   CHAN6
                CS      BGIM23          # TURN TRIM GIMBAL OFF
                EXTEND
                WAND    CHAN12
                TCF     SETTIME5        # RETURN IN 100 MSEC.

MANFLAG         OCT     03021
BGIM23          OCTAL   07400
                EBANK=  OMEGAP
PAXADIDL        2CADR   PAXIS

MS100           =       OCT37766
COSMG           =       ITEMP1
JUMPDSP         EXTEND                  # TRANSFER TO BANK 20
                DCA     DSPCADR         # FOR ATTITUDE ERROR DISPLAYS
                DTCB

                EBANK=  AK
DSPCADR         2CADR   ALTDSPLY
```

Uses AK 200, CHAN12 87, COMMAND 169, DISPLAYS 59, EBANK 80, ITEMP1 138, P 188, Q 80, and TC 169.

2510 ⟨*Page LM1414* 2510⟩≡ (2503b 2670)

```
                BANK    20
                SETLOC  DAPS3
                BANK
                COUNT*  $$/NEEDL

# PROGRAM:      ALTDSPLY
# MOD 0.        6 DEC 1967
# AUTHOR:       CRAIG WORK, DON KEENE, MIT IL
# MOD 3 BY DON KEENE AUG 1, 1968 -- MOVED PROGRAM TO BANK 20
#
# PROGRAM DESCRIPTION:
#       ALTDSPLY REVERSES THE DSPLYALT BIT OF RCSFLAGS EACH TIME IT IS CALLED, WHICH
#       IF THE REVERSED BIT IS ONE, NEEDLER IS CALLED TO DISPLAY ATTITUDE ERRORS.  IF
#       ORS ARE CALCULATED AS 1) DAP FOLLOWING ERRORS, IF NEEDLFLG = 0, AND 2) TOTAL
#
#
# WARNING:      ALTDSPLY MAY ONLY BE CALLED WITH INTERRUPT INHIBITED
#
# WARNING:      EBANK MUST BE SET TO 6 WHEN USING THIS ROUTINE.
#
# INPUT:        RCSFLAGS AND    1) IF NEEDLFLG = 0, INPUT PERROR, QERROR, RERROR.
#                               2) IF NEEDLFLG = 1, INPUT CPHI,CTHETA,CPSI,CDUX,CDUY,
#
#
# OUTPUTS:      RCSFLAGS WITH DSPLYALT REVERSED, AK, AK1, AK2, + NEEDLER OUTPUTS.
#
# ENTRY:        TCF     ALTDSPLY
#
# EXIT:         TCF     CHEKMORE
#
# ALARM OR ABORT EXITS: NONE
#
# SUBPROGRAMS CALLED:  NEEDLER, OVERSUB2
#
# DEBRIS:       A, L, AND NEEDLER DEBRIS.

ALTDSPLY        CA      RCSFLAGS        # INVERT THE DISPLAY ALTERNATION BIT.
                TS      L
                CA      DSPLYALT
                EXTEND
                RXOR    LCHAN
                TS      RCSFLAGS

                MASK    DSPLYALT
                CCS     A               # IS ALTERNATION FLAG ZERO?
```

```
                    TCF     NEEDLER

                    CAE     FLAGWRD0        # NEEDLFLG WILL INDICATE TOTAL OR DAP AT-
```

Uses A 80, AK 200, AK1 200, AK2 200, CDUX 80, CDUY 80, CDUZ 80, COUNT 142, CPHI 157, CPSI 157, CTHETA 157, DAPS3 63, EBANK 80, FLAGWRD0 95, IT 185, L 80, LCHAN 87, NEEDLFLG 95, and RCSFLAGS 200.

2512 ⟨*Page LM1415* 2512⟩≡ (2503b 2670)

```
                MASK    NEEDLBIT        # TITUDE ERROR DISPLAY REQUEST.
                CCS     A
                TCF     DSPLYTOT        # TOTAL ERROR IS NEEDED IN AK, AK +1, AK +2

                CS      QERROR          # YES.  DISPLAY ATT ERRORS ON THE -BALL.
                TS      AK +1           # ERROR COMPLEMENTS ARE INPUT TO NEEDLER.
                CS      RERROR
                TS      AK +2
                CS      PERROR
                XCH     AK

                TCF     RETNMORE        # DISPLAY THESE THE NEXT TIME THROUGH

# CALCULATE GIMBAL ANGLE TOTAL ERRORS, RESOLVE INTO PILOT AXES, STORE TOTAL ERRORS FO

DSPLYTOT        EXTEND
                QXCH    ITEMP1          # SAVE Q FOR CHEKBITS RETURN.

                CA      CTHETA          # DESIRED ATTITUDE, Y-AXIS, 2'S COMP.
                EXTEND                  # SUBTRACT CURRENT ATTITUDE.
                MSU     CDUY            # DIFFERENCE SCALED AT PI, 1'S COMP.
                TS      AK              # SAVE FOR R-ERROR CALCULATION.
                EXTEND
                MP      M21             # (CTHETA-CDUY)*M21 SCALED AT PI RADIANS.
                XCH     AK +1           # STORE FIRST TERM OF Q ERROR.
                CA      CPSI            # DESIRED ATTITUDE, Z-AXIS, 2'S COMP.
                EXTEND                  # SUBTRACT CURRENT ATTITUDE.
                MSU     CDUZ            # DIFFERENCE SCALED AT PI, 1'S COMP.
                TS      AK +2           # SAVE Z-AXIS TERM FOR R ERROR CALCULATION
                EXTEND
                MP      M22             # (CPSI-CDUZ)*M22, SCALED AT PI RADIANS.
                AD      AK +1           # Q ERROR COMPLETE         , AT PI RAD.
                TC      OVERSUB2        # PIN NEEDLES IN CASE OF OVERFLOW
                TS      AK +1

# R ERROR CALCULATION NEXT.

                CA      AK              # Y-AXIS DIFFERENCE STORED BY Q-AXIS CALC.
                EXTEND
                MP      M31             # (CTHETA-CDUY)*M31, SCALED AT PI RADIANS.
                XCH     AK +2           # FIRST TERM OF R ERROR.
                                        # Z-AXIS DIFFERENCE, STORED BY A CALC. IS
                EXTEND                  # RECOVERED BY THE EXCHANGE.
                MP      M32             # (CPSI-CDUZ)*M32, SCALED AT PI RADIANS.
                AD      AK +2           # R ERROR COMPLETE         , AT PI RAD.
```

```
                TC      OVERSUB2        # PIN NEEDLES IN CASE OF OVERFLOW.
                TS      AK +2

  # NOW CALCULATE P ERROR.  (NOTE THAT M13 = 1, SCALED AT 1, SO THE MULTIPLICATION IS BY-PASSED.)
```

Uses A 80, AK 200, CDUY 80, CDUZ 80, CPSI 157, CTHETA 157, ITEMP1 138, NEEDLBIT 95, P 188, Q 80, RAD 219, SAVE 191, TC 169, and Z 80.

2513 ⟨*Page LM1416* 2513⟩≡ (2503b 2670)

```
                CA      AK              # Y-AXIS DIFFERENCE STORED BY Q AXIS CALC.
                EXTEND
                MP      M11             # (CTHETA-CDUY)*M11 SCALED AT PI RADIANS.
                XCH     AK              # FIRST TERM OF P ERROR IN AK, AT PI RAD.
                CAE     CPHI            # DESIRED ATTITUDE, X-AXIS, 2'S COMP.
                EXTEND                  # SUBTRACT CURRENT X ATTITUDE.
                MSU     CDUX            # X-AXIS DIFFERENCE, 1'S COMP, AT PI RAD.

  # M13 = 1, SO BYPASS THE MULTIPLICATION.
  #             EXTEND
  #             MP      M13             # (CPHI-CDUX)*M13 SCALED AT PI RADIANS.

                AD      AK              # P ERROR COMPLETE      , SCALED AT PI RAD
                TC      OVERSUB2        # PIN NEEDLES IN CASE OF OVERFLOW.
                TS      AK

                EXTEND
                QXCH    ITEMP1          # RESTORE Q FOR CHEKBITS RETURN.

                TCF     RETNMORE        # DISPLAY THESE THE NEXT TIME THROUGH
```

Uses AK 200, CDUX 80, CDUY 80, CPHI 157, CTHETA 157, ITEMP1 138, P 188, Q 80, RAD 219, and TC 169.

2514 ⟨*Page LM1417* 2514⟩≡ (2503b 2670)

```
# FDAI ATTITUDE ERROR DISPLAY SUBROUTINE
#
# PROGRAM DESCRIPTION:          D. KEENE        5/24/67
# MOD 1 BY CRAIG WORK, 12 DEC 67
# MOD 2 BY CRAIG WORK, 6 APRIL 68, CONVERTS ATTITUDE ERROR DISPLAY SCALING FROM 16 7/
#
# THIS SUBROUTINE IS USED TO DISPLAY ATTITUDE ERRORS ON THE FDAI VIA THE DIGITAL TO A
# IN THE CDUS.  CARE IS TAKEN TO METER OUT THE APPROPRIATE NUMBER OF PULSES TO THE IN
# OVERFLOW, TO CONTROL THE RELAY SEQUENCING, AND TO AVOID INTERFERENCE WITH THE COARS
# THE DACS.
#
# CALLING SEQUENCE:
#       DURING THE INITIALIZATION SECTION OF THE USER'S PROGRAM, BIT3 OF RCSFLAGS SHO
#       TURN-ON SEQUENCE WITHIN THE NEEDLES PROGRAM:
#               CS      RCSFLAGS        # IN EBANK6
#               MASK    BIT3
#               ADS     RCSFLAGS
#       THEREAFTER, THE ATTITUDE ERRORS GENERATED BY THE USER SHOULD BE TRANSFERRED T
#               AK      SCALED 180 DEGREES      NOTE:   THESE LOCATIONS ARE SUBJECT
#               AK1     SCALED 180 DEGREES              TO CHANGE
#               AK2     SCALED 180 DEGREES
#       FULL SCALED DEFLECTION OF THE NEEDLES CORRESPONDS TO 5 1/16 DEGREES, WHILE 38
#       CORRESPONDS TO 42 3/16 DEGREES.  (DAC MAXIMUM CAPACITY IS 384 BITS.)  46 BITS
#
#       A CALL TO NEEDLER WILL THE UPDATE THE DISPLAY:
#               INHINT
#               TC      IBNKCALL        # NOTE:  EBANK SHOULD BE SET TO E6
#               CADR    NEEDLER
#               RELINT
#       THIS PROCESS SHOULD BE REPEATED EACH TIME THE ERRORS ARE UPDATED.  AT LEAST 3
#       REQUIRED BEFORE ANYTHING IS ACTUALLY DISPLAYED ON THE ERROR METERS.
#       NOTE:  EACH CALL TO NEEDLER MUST BE SEPARATED BY AT LEAST 50 MS. TO ASSURE PR
#
# ERASABLES USED:
#       AK              CDUXCMD
#       AK1             CDUYCMD
#       AK2             CDUZCMD
#       EDRIVEX         A,L,Q
#       EDRIVEY         T5TEMP
#       EDRIVEZ         DINDX
```

Uses A 80, AK 200, AK1 200, AK2 200, CDUS 80, CDUXCMD 80, CDUYCMD 80, CDUZCMD 85, D 226, EBANK 80, EDRIVEX 200, EDRIVEY 200, EDRIVEZ 202, L 80, Q 80, RCSFLAGS 200, T5TEMP 200, and TC 169.

2515 ⟨*Page LM1418* 2515⟩≡ (2503b 2670)

```
#
# SWITCHES:             RCSFLAGS  BITS 3,2
#
# I/O CHANNELS:         CHAN12  BIT 4 (COARSE ALIGN -- READ ONLY)
#                       CHAN12  BIT 6 (IMU ERROR COUNTER ENABLE)
#                       CHAN14  BIT 13,14,15 (DAC ACTIVITY)
#
# SIGN CONVENTION:      AK = THETAC - THETA
#                       WHERE   THETAC = COMMAND ANGLE
#                               THETA = PRESENT ANGLE

NEEDLER         CA      RCSFLAGS
                MASK    SIX
                EXTEND
                BZF     NEEDLES3
                MASK    BIT3
                EXTEND
                BZF     NEEDLER2        # BIT3 = 0, BIT2 = 1

                CS      BIT6            # FIRST PASS BIT3 = 1
                EXTEND                  # DISABLE IMU ERROR COUNTER TO ZERO DACS
                WAND    CHAN12          # MUST WAIT AT LEAST 60 MS BEFORE
NEEDLE11        CS      ZERO            # ENABLING COUNTERS.
                TS      AK              # ZERO THE INPUTS ON FIRST PASS
                TS      AK1
                TS      AK2
                TS      EDRIVEX         # ZERO THE DISPLAY REGISTERS
                TS      EDRIVEY
                TS      EDRIVEZ
                TS      CDUXCMD         # ZERO THE OUT COUNTERS
                TS      CDUYCMD
                TS      CDUZCMD
                CS      SIX             # RESET RCSFLAGS FOR PASS2
                MASK    RCSFLAGS
                AD      BIT2
                TS      RCSFLAGS
                TCF     RETNMORE

NEEDLER2        CAF     BIT6            # ENABLE IMU ERROR COUNTERS
                EXTEND
                WOR     CHAN12
                CS      SIX             # RESET RCSFLAGS TO DISPLAY ATTITUDE
                MASK    RCSFLAGS        # ERRORS.  WAIT AT LEAST 4 MS FOR
                TS      RCSFLAGS        # RELAY CLOSURE.
                TCF     RETNMORE
```

```
NEEDLES3        CAF     BIT6            # CHECK TO SEE IF IMU ERROR COUNTER
                EXTEND                  # IS ENABLED
                RAND    CHAN12
```

Uses AK 200, AK1 200, AK2 200, CDUXCMD 80, CDUYCMD 80, CDUZCMD 85, CHAN12 87, CHAN14 87, COMMAND 169, EDRIVEX 200, EDRIVEY 200, EDRIVEZ 202, I 206, RCSFLAGS 200, and THETA 148.

2517 ⟨*Page LM1419* 2517⟩≡ (2503b 2670)

```
                CCS     A               # IF NOT, RE-INITIALIZE NEEDLER.
                TCF     NEEDLES

                CS      RCSFLAGS        # SET UP INITIALIZATION FLAG IN RCSFLAGS.
                MASK    BIT3
                ADS     RCSFLAGS
                TCF     RETNMORE

NEEDLES         CAF     TWO
DACLOOP         TS      DINDX
                CS      ONETENTH        # RESCALE INPUTS TO + OR - 1800 DEGREES.
                EXTEND
                INDEX   DINDX
                MP      AK
                TS      L
                CCS     A
                CA      DACLIMIT
                TCF     +2
                CS      DACLIMIT
                AD      L
                TS      T5TEMP          # OVFLO CHK
                TCF     +4
                INDEX   A               # ON OVERFLOW LIMIT OUTPUT TO +-384
                CAF     DACLIMIT
                TS      L
                INDEX   DINDX
                CS      EDRIVEX         # CURRENT VALUE OF DAC
                AD      L
                INDEX   DINDX
                ADS     CDUXCMD
                INDEX   DINDX
                LXCH    EDRIVEX
                CCS     DINDX
                TCF     DACLOOP
                CAF     13,14,15
                EXTEND
                WOR     CHAN14          # SET DAC ACTIVITY BITS
                TCF     RETNMORE

                DEC     -384
DACLIMIT        DEC     16000
                DEC     384

ONETENTH        OCT     03146           # DECIMAL +0.1, SCALED AT 1.
DSPLYALT        EQUALS  BIT4            # 100 MS ALTERNATION BIT IN RCSFLAGS
```

```
OVERSUB2        TS      7               # RETURNS A UNCHANGED OR LIMITED TO
                TC      Q               # POSMAX OR NEGMAX IF A HAS OVERFLOW
                INDEX   A
```

Uses A 80, AK 200, CDUXCMD 80, CHAN14 87, EDRIVEX 200, L 80, Q 80, RCSFLAGS 200, T5TEMP 200, and TC 169.

2518 ⟨*Page LM1420* 2518⟩≡ (2503b 2670)

```
                CS      LIMITS          # DUPLICATE CODING IN BANK 16
                TC      Q

RETNMORE        EXTEND                  # RETURN TO CHEKMORE
                DCA     MORECADR
                DTCB

                EBANK=  AOSQ
MORECADR        2CADR   CHEKMORE
```

Uses EBANK 80, Q 80, and TC 169.

4.34 p axis rcs autopilot

2519 ⟨*p axis rcs autopilot* 2519⟩≡ (2041 2770)

```
# Page 1421
                BANK    16
                SETLOC  DAPS1
                BANK

                EBANK=  PERROR
                COUNT*  $$/DAPP

# THE FOLLOWING T5RUPT ENTRY BEGINS THE PROGRAM WHICH CONTROLS THE P-AXIS ACTION OF THE LEM USI
# THE NOMINAL TIME BETWEEN THE P-AXIS RUPTS IS 100 MS IN ALL NON-IDLING MODES OF THE DAP.

PAXIS           CA      MS100
                ADS     TIME5           # *** NECESSARY IN ORDER TO ALLOW
                                        # SYNCHRONIZATION WITH OTHER INTERRUPTS ***

                LXCH    BANKRUPT        # INTERRUPT LEAD IN (CONTINUED)
                EXTEND
                QXCH    QRUPT

# CHECK IF DAP PASS IS PERMISSIBLE

                CCS     DAPZRUPT        # IF DAPZRUPT POSITIVE, DAP (JASK) IS
                TC      BAILOUT         # STILL IN PROGRESS AND A RESTART IS
                OCT     02000           # CALLED FOR.  IT IS NEVER ZERO

                TC      CHEKBITS        # RETURN IS TC I+1 IF DAP SHOULD STAY ON.

                CA      CDUX            # READ AND STORE CDU'S
                TS      DAPTREG4
                CA      CDUY
                TS      DAPTREG5
                CA      CDUZ
                TS      DAPTREG6

# ***** KALCMANU-DAP AND "RATE-HOLD"-DAP INTERFACE *****
#
# THE FOLLOWING SECTION IS EXECUTED EVERY 100 MS (10 TIMES A SECOND) WITHIN THE P-AXIS REACTION
# AUTOPILOT (WHENEVER THE DAP IS IN OPERATION).

                CA      CDUXD
                EXTEND
                MSU     DELCDUX
                TC      1STOTWOS
```

```
                TS      CDUXD
                CA      CDUYD
                EXTEND
                MSU     DELCDUY
                TC      1STOTWOS
                TS      CDUYD
                CA      CDUZD
                EXTEND
                MSU     DELCDUZ
# Page 1422
                TC      1STOTWOS
                TS      CDUZD
                EXTEND                  # DIMINISH MANUAL CONTROL DIRECT RATE
                DIM     TCP             # TIME COUNTERS.
                EXTEND
                DIM     TCQR

# RATFLOOP COMPUTES JETRATEQ, JRATER, AND 1JACC*NO. PJEETS IN ITEMP1.
# RETURNS TO BACKP.
#
# JETRATE = 1JACC*NO.PJETS*TJP          (NOTE TJ IS THE TIME FIRED DURING CSP)
# JETRATEQ = 1JACCQ(TJU*NO.UJETS - TJV*NO.VJETS)
# JETRATER = 1JACCR(TJU*NO.UJETS + TJV*NO.VJETS)

                TCF     PAXFILT         # PROCEEDS TO RATELOOP AFTER SUPERJOB
1STOTWOS        CCS     A
                AD      ONE
                TC      Q
                CS      A
                TC      Q
SUBDIVDE        EXTEND                  # OVERFLOW PROTECTION ROUTINE TO GIVE
                MP      DAPTEMP3        # POSMAX OR NEGMAX IF THE DIVIDE WOULD
                DAS     OMEGAU          # OVERFLOW

        +3      EXTEND
                DCA     OMEGAU
                DXCH    DAPTEMP5
                CCS     OMEGAU
                TCF     +2
                TCF     DIVIDER
                AD      -OCT630
                EXTEND
                BZMF    DIVIDER

                CCS     OMEGAU
                CA      POSMAX          # 45 DEG/SEC
```

```
                TC      Q
                CS      POSMAX
                TC      Q

DIVIDER         DXCH    OMEGAU
                EXTEND
                DV      DAPTREG4
                TC      Q

OVERSUB         TS      7               # RETURNS A UNCHANGED OR LIMITED TO
                TC      Q               # POSMAX OR NEGMAX IF A HAS OVERFLOW
                INDEX   A
                CS      BIT15   -1
# Page 1423
                TC      Q

-OCT630         OCT     77147

BACKP           CA      DAPTEMP1
                EXTEND
                MP      1JACC
                TS      JETRATE

# BEGINNING OF THE RATE DERIVATION
#       OMEGAP,Q,R      BODY RATES SCALED AT PI/4
#       TRAPEDP,Q,R     BODY ANGLE ERRORS FROM PREDICTED ANGLE (PI/40)
#       NP(QR)TRAPS     NUMBER OF TIMES ANGLE ERROR HAS BEEN ACCUMULATED
#       AOSQ(R)TERM     CHANGE IN RATE DUE TO OFFSET ACCELERATION.  (PI/4)
#       JETRATE,Q,R     CHANGE IN RATE DUE TO  JET   ACCELERATION.  (PI/4)
#       TRAPSIZE        NEGATIVE LIMIT OF MAGNITUDE OF TRAPEDP, ETC.
#       OMEGAU          DP-TEMPORARY STORAGE
# OMEGA = OMEGA + JETRATE + AOSTERM (+TRAPED/NTRAPS IF TRAPED BIG)

                CAE     DAPTREG4        # CDUX IS STORED HERE
                TS      L
                EXTEND
                MSU     OLDXFORP        # SCALED AT PI
                LXCH    OLDXFORP
                TS      DAPTEMP1
                CA      1/40
                TS      DAPTREG4
                CS      JETRATE
                EXTEND
                MP      BIT14
                ADS     TRAPEDP
                CA      JETRATEQ
```

```
                AD      AOSQTERM
                EXTEND
                MP      -BIT14
                ADS     TRAPEDQ
                CA      JETRATER
                AD      AOSRTERM
                EXTEND
                MP      -BIT14
                ADS     TRAPEDR

                CA      DAPTREG5        # CDUY IS STORED HERE
                TS      L
                EXTEND
                MSU     OLDYFORP        # SCALED AT PI
                LXCH    OLDYFORP
                TS      DAPTEMP2
                EXTEND
                MP      M11             # M11 SCALED AT 1
# Page 1424
                AD      DAPTEMP1
                DXCH    OMEGAU

                TC      SUBDIVDE +3     # RETURNS WITH CDU-RATE AT PI/4

                EXTEND
                SU      OMEGAP
                ADS     TRAPEDP
                TC      OVERSUB
                TS      TRAPEDP
                EXTEND
                DCA     DAPTEMP5
                DAS     DXERROR
                CS      PLAST
                EXTEND
                MP      1/40
                DAS     DXERROR         # MANUAL MODE X-ATTITUDE ERROR (DP)
                CA      DAPTREG6        # CDUZ IS STORED HERE
                TS      L
                EXTEND
                MSU     OLDZFORQ
                TS      DAPTEMP3
                LXCH    OLDZFORQ
                CA      M21
                EXTEND
                MP      DAPTEMP2
                DXCH    OMEGAU
```

```
                CA      M22
                TC      SUBDIVDE

                EXTEND
                SU      OMEGAQ
                ADS     TRAPEDQ
                TC      OVERSUB
                TS      TRAPEDQ
                EXTEND
                DCA     DAPTEMP5
                DAS     DYERROR
                CS      QLAST
                EXTEND
                MP      1/40
                DAS     DYERROR         # MANUAL MODE Y-ATTITUDE ERROR (DP)
                CA      M31
                EXTEND
                MP      DAPTEMP2
                DXCH    OMEGAU
                CA      M32

                TC      SUBDIVDE
# Page 1425
                EXTEND
                SU      OMEGAR
                ADS     TRAPEDR
                TC      OVERSUB
                TS      TRAPEDR         # TRAPEDS HAVE ALL BEEN COMPUTED

                EXTEND
                DCA     DAPTEMP5
                DAS     DZERROR
                CS      RLAST
                EXTEND
                MP      1/40
                DAS     DZERROR         # MANUAL MODE Z-ATTITUDE ERROR (DP)
                CA      DAPBOOLS        # PICK UP PAD LOADED STATE ESTIMATOR GAINS
                MASK    CSMDOCKD
                EXTEND
                BZF     LMONLY
                EXTEND                  # DOCKED
                DCA     DKOMEGAN
                DXCH    DAPTREG4
                CA      DKTRAP
                TCF     +5
LMONLY          EXTEND                  # UNDOCKED
```

```
                DCA     LMOMEGAN
                DXCH    DAPTREG4
                CA      LMTRAP
        +5      TS      DAPTREG6
                CCS     TRAPEDP
                TCF     +2
                TCF     SMALPDIF
                AD      DAPTREG6        # TRAPSIZE > ABOUT 77001 %-1.4DEG/SEC"
                EXTEND
                BZMF    SMALPDIF
                ZL
                LXCH    TRAPEDP
                CA      ZERO
                EXTEND
                DV      NPTRAPS
                ADS     OMEGAP
                TC      OVERSUB
                TS      OMEGAP
                CA      DAPTREG4        ABOUT 10 OR 0 FOR DOCKED OR UNDOCKED
                TS      NPTRAPS
SMALPDIF        INCR    NPTRAPS
P-RATE          CA      JETRATE
                ADS     OMEGAP
                TC      OVERSUB
                TS      OMEGAP

                CCS     TRAPEDQ
# Page 1426
                TCF     +2
                TCF     Q-RATE
                AD      DAPTREG6        # TRAPSIZE > ABOUT 77001 %-1.4DEG/SEC"
                EXTEND
                BZMF    Q-RATE
                ZL
                LXCH    TRAPEDQ
                CA      ZERO
                EXTEND
                DV      NQTRAPS
                TS      DAPTEMP1        # SAVE FOR OFFSET ESTIMATE
                ADS     OMEGAQ
                TC      OVERSUB
                TS      OMEGAQ
                CA      DAPTREG4        # ABOUT 10 OR 0 FOR DOCKED OR UNDOCKED
                XCH     NQTRAPS
                AD      DAPTREG5        # KAOS > ABOUT 60D %N/N_60"
                XCH     DAPTEMP1
```

```
                EXTEND
                MP      FIVE
                EXTEND
                DV      DAPTEMP1
                ADS     AOSQ
Q-RATE          INCR    NQTRAPS
                CA      JETRATEQ
                AD      AOSQTERM
                ADS     OMEGAQ
                TC      OVERSUB
                TS      OMEGAQ

                CCS     TRAPEDR
                TCF     +2
                TCF     R-RATE
                AD      DAPTREG6        # TRAPSIZE > ABOUT 77001 %-1.4DEG/SEC"
                EXTEND
                BZMF    R-RATE
                ZL
                LXCH    TRAPEDR
                CA      ZERO
                EXTEND
                DV      NRTRAPS
                TS      DAPTEMP2        # SAVE FOR OFFSET ESTIMATE
                ADS     OMEGAR
                TC      OVERSUB
                TS      OMEGAR
                CA      DAPTREG4        # ABOUT 10 OR 0 FOR DOCKED OR UNDOCKED
                XCH     NRTRAPS
                AD      DAPTREG5        # KAOS > ABOUT 60D %N/N_60"
                XCH     DAPTEMP2
                EXTEND
# Page 1427
                MP      FIVE
                EXTEND
                DV      DAPTEMP2
                ADS     AOSR
R-RATE          INCR    NRTRAPS
                CA      JETRATER
                AD      AOSRTERM
                ADS     OMEGAR
                TC      OVERSUB
                TS      OMEGAR

# END OF RATE DERIVATION
#       BEGIN OFFSET ESTIMATER
```

```
#               IN POWERED FLIGHT, AOSTASK WILL BE CALLED EVERY 2 SECONDS.
#                       AOS = AOS + K*SUMRATE

                CS      DAPBOOLS
                MASK    DRIFTBIT
                CCS     A
                TCF     WORKTIME
                TS      ALPHAQ          # ZERO THE OFFSET ACCELERATION VALUES.
                TS      ALPHAR
                TS      AOSQTERM
                TS      AOSRTERM
                TS      AOSQ
                TS      AOSR
                TCF     PRETIMCK
KAOS            DEC     60
WORKTIME        CA      QACCDOT
                EXTEND
                MP      CALLCODE        # OCTAL 00032 IS DECIMAL .1 AT 2(6).
                DAS     AOSQ
                CA      AOSQ
                TS      ALPHAQ
                EXTEND
                MP      200MS           # .2 AT 1
                TS      AOSQTERM
                CA      RACCDOT
                EXTEND
                MP      CALLCODE        # OCTAL 00032 IS DECIMAL .1 AT 2(6).
                DAS     AOSR
                CA      AOSR
                TS      ALPHAR
                EXTEND
                MP      200MS           # .2 AT 1
                TS      AOSRTERM
                TCF     PRETIMCK

# Page 1428
PAXFILT         CA      CALLGMBL        # EXECUTE ACDT+C12, IF NEEDED.
                MASK    RCSFLAGS
                CCS     A               # CALLGMBL IS NOT BIT15, SO THIS TEST IS
                TC      ACDT+C12        # VALID.

                DXCH    ARUPT
                DXCH    DAPARUPT
                CA      SUPERJOB        # SETTING UP THE SUPERJOB
                XCH     BRUPT
                LXCH    QRUPT
```

```
                DXCH    DAPBQRPT
                CA      SUPERADR
                DXCH    ZRUPT
                DXCH    DAPZRUPT
                TCF     NOQBRSM +1      # RELINT (JUST IN CASE) AND RESUME, IN THE
                                        #       FORM OF A JASK, AT SUPERJOB.

SUPERADR        GENADR  SUPERJOB +1

# COUNT DOWN GIMBAL DRIVE TIMERS AND TURN OFF DRIVES IF REQUIRED.

SUPERJOB        TCF     RATELOOP
PRETIMCK        CCS     QGIMTIMR
                TCF     DECQTIMR        # POSITIVE -- COUNTING DOWN
                TCF     TURNOFFQ        # NEGATIVE -- DRIVE SHOULD BE ENDED
CHKRTIMR        CCS     RGIMTIMR        # NEGATIVE -- INACTIVE
                TCF     DECRTIMR        # (NEG ZERO -- IMPOSSIBLE)
                TCF     TURNOFFR        # REPEATED (ABOVE) FOR R AXIS.

                EXTEND                  # DECREMENT DOCKED JET INHIBITION COUNTERS
                DIM     PJETCTR
                EXTEND
                DIM     UJETCTR
                EXTEND
                DIM     VJETCTR
                CA      BIT12
                MASK    RCSFLAGS
                EXTEND
                BZF     SKIPPAXS
                TC      CHKVISFZ
DECQTIMR        TS      QGIMTIMR        # COUNT TIMERS DOWN TO POS ZERO.
                TCF     CHKRTIMR
DECRTIMR        TS      RGIMTIMR
                TCF     CHKRTIMR +3

TURNOFFQ        TS      NEGUQ           # HALT DRIVES.
                TS      QACCDOT
                CS      QGIMBITS
                EXTEND
# Page 1429
                WAND    CHAN12
                CAF     NEGMAX
                TS      QGIMTIMR
                TCF     CHKRTIMR
TURNOFFR        TS      NEGUR
                TS      RACCDOT
```

```
                CS      RGIMBITS
                EXTEND
                WAND    CHAN12
                CAF     NEGMAX
                TS      RGIMTIMR
                TCF     CHKRTIMR +3
QGIMBITS        EQUALS  OCT1400         # BITS 9 AND 10 (OF CHANNEL 12).
RGIMBITS        EQUALS  PRIO6           # BITS 11 AND 12 (OF CHANNEL 12).

SKIPPAXS        CS      RCSFLAGS
                MASK    BIT12
                ADS     RCSFLAGS        # BIT 12 SET TO 1.
                TCF     QRAXIS          # GO TO QRAXIS OR TO CTS.

# Y-X TRANSLATION
#
# INPUT:        BITS 9-12 OF CH31 (FROM TRANSLATION CONTROLLER)
#
# OUTPUT:       NEXTP
#
#               NEXTP IS THE CHANNEL 6 CODE OF JETS FOR THE DESIRED TRANSLATION.
#               IF THERE ARE FAILURES IN THE DESIRED POLICY, THEN
#               (1) FOR DIAGONAL TRANS:         UNFAILED PAIR
#                                               ALARM (IF NO PAIR)
#               (2) FOR PRINCIPAL TRANS:        TRY TO TACK WITH DIAGONAL PAIRS
#                                               ALARM (IF DIAGONAL PAIRS ARE FAILED)

CHKVISFZ        EXTEND
                READ    CHAN31
                CS      A
                MASK    07400OCT
                EXTEND
                BZF     TSNEXTP
                EXTEND
                MP      BIT7
                INDEX   A
                CA      INDXYZ
                TS      ROTINDEX
TRYUORV         CA      SIX
                TC      SELECTYZ
                CS      SIX
                AD      NUMBERT
                EXTEND
# Page 1430
                BZF     TSNEXTP -1
                CS      FIVE
```

```
                AD      ROTINDEX
                EXTEND
                BZMF    ALTERYZ
                CS      NUMBERT
                AD      FOUR
                EXTEND
                BZMF    TSNEXTP -1
ABORTYZ         TC      ALARM
                OCT     02001
                CA      BIT1            # INVERT BIT 1 OF RCSFLAGS.
                LXCH    RCSFLAGS
                EXTEND
                RXOR    1
                TS      RCSFLAGS
                CA      ZERO
                TCF     TSNEXTP
ALTERYZ         CA      BIT1            # INVERT BIT 1 OF RCSFLAGS.
                LXCH    RCSFLAGS
                EXTEND
                RXOR    1
                TS      RCSFLAGS
                MASK    BIT1
                AD      FOUR
                ADS     ROTINDEX
                TCF     TRYUORV
                CA      POLYTEMP
TSNEXTP         TS      NEXTP

# STATE LOGIC
#       CHECK IN ORDER:         IF ON
#       LPDPHASE                GO TO PURGENCY
#       PULSES                  MINIMUM PULSE LOTIC
#       DETENT(BIT15 CH31)      RATE COMMAND
#       GOTO TO PURGENCY

                CA      BIT13           # CHECK STICK IF IN ATT. HOLD.
                EXTEND
                RAND    CHAN31
                EXTEND
                BZF     MANMODE

                CA      DAPBOOLS
                MASK    XOVINHIB
                CCS     A
                TCF     PURGENCY        # ATTITUDE STEER DURING VISIBILITY PHASE
```

```
                TCF     DETENTCK
MANMODE         CA      PULSES          # PULSES IS ONE FOR PULSE MODE
                MASK    DAPBOOLS
# Page 1431
                EXTEND
                BZF     DETENTCK        # BRANCH FOR RATE COMMAND

                CA      ZERO
                TS      PERROR

# MINIMUM IMPULSE MODE

                CA      CDUX
                TS      CDUXD

                CCS     OLDPMIN
                TCF     CHECKP

FIREP           CA      BIT3
                EXTEND
                RAND    CHAN31
                EXTEND
                BZF     +XMIN

                CA      BIT4
                EXTEND
                RAND    CHAN31
                EXTEND
                BZF     -XMIN

                TCF     JETSOFF

CHECKP          EXTEND
                READ    CHAN31
                CS      A
                MASK    OCT14
                TS      OLDPMIN
                TCF     JETSOFF

-XMIN           CS      TEN             # ANYTHING LESS THAN 14MS. CORRECTED
                TCF     +2              #       IN JET SELECTION ROUTINE
+XMIN           CA      TEN
                TS      TJP
                CA      ONE
                TS      OLDPMIN
                TCF     PJETSLEC -6
```

```
#                                       MANUAL RATE COMMAND MODE
#                                       ========================
#                                         BY ROBERT F. STENGEL
#
# THIS MODE PROVIDES RCAH MANUAL CONTROL THRU 2 CONTROL LAWS:  1) DIRECT RATE AND 2) PSEUDO-AUT
# THE DIRECT RATE MODE AFFORDS IMMEDIATE CONTROL WITHOUT OVERSHOOT.  THE PSEUDO-AUTO MODE PROVI
# RATE CONTROL AND ATTITUDE HOLD.
#
# Page 1432
# IN DIRECT RATE, JETS ARE FIRED WHEN STICK POSITION CHANGES BY A FIXED NUMBER OF INCREMENTS IN
# THE 'BREAKOUT LEVEL' IS .6 D/S FOR LM-ONLY AND .3 D/S FOR CSM-DOCKED.  THIS LAW NULLS THE RAT
# THE 'TARGET DEADBAND', WHICH EQUALS THE BREAKOUT LEVEL.
#
# IN PSEUDO-AUTO, BODY-FIXED RATE AND ATTITUDE ERRORS ARE SUPPLIED TO TJETLAW, WHICH EXERCISES
# CONTROL SWITCHES FROM DIRECT RATE TO PSEUDO-AUTO IF THE TARGET DB IS ACHIEVED OR IF TIME IN (
# IF THE INITIAL COMMAND DOES NOT EXCEED THE BREAKOUT LEVEL, CONTROL GOES TO PSEUDO-AUTO IMMEDI
#
# SINCE P-AXIS CONTROL IS SEPARATE FROM Q,R AXES CONTROL, IT IS POSSIBLE TO USE (1) IN P-AXIS A
# OR VICE VERSA.  THIS ALLOWS A DEGREE OF ATTITUDE HOLD IN UNCONTROLLED AXES.  DUE TO U,V CONTR
# R AXES ARE COUPLED AND MUST USE THE SAME CONTROL LAW.
#
# HAND CONTROLLER COMMANDS ARE SCALED BY A LINEAR/QUADRATIC LAW.  FOR THE LM-ALONE, MAXIMUM COM
# AND 4 D/S IN NORMAL AND FINE SCALING; HOWEVER, STICK SENSITIVITY AT ZERO COUNTS (OBTAINED AT
# OF 2 DEGREES FROM THE CENTERED POSITION) IS .5 OR .1 D/S PER DEGREE.  NORMAL AND FINE SCALING
# CASE IS AUTOMATICALLY SET TO 1/10 THE ABOVE VALUES.  SCALING IS DETERMINED IN ROUTINE 3.
#
# ZEROENBL      ENABLES COUNTERS SO THEY CAN BE READ NEXT TIME
# JUSTOUT       FIRST DETECTION OF OUT OF DETENT (BY OURRCBIT)

DETENTCK        EXTEND
                READ    CHAN31
                TS      CH31TEMP
                MASK    BIT15           # CHECK OUT-OF-DETENT BIT.
                EXTEND
                BZF     RHCMOVED        # BRANCH IF OUT OF DETENT.
                CAF     OURRCBIT        # IN DETENT.  CHECK THE RATE COMMAND BIT.
                MASK    DAPBOOLS
                EXTEND
                BZF     PURGENCY        # BRANCH IF NOT IN RATE COMMAND LAST PASS.

# ......................................................................

                CA      BIT9            # JUST IN DETENT??
                MASK    RCSFLAGS
                EXTEND
```

```
                BZF     RUTH
                CAF     BIT13           # CHECK FOR ATTITUDE HOLD.
                EXTEND
                RAND    CHAN31
                EXTEND
                BZF     RATEDAMP        # BRANCH IF IN ATTITUDE HOLD.

                CS      BITS9,11        # IN AUTO.
                MASK    RCSFLAGS        # (X-AXIS OVERRIDE)
                TS      RCSFLAGS        # ZERO ORBIT (BIT 11) AND JUST-IN BIT (9).
                TCF     RATEDAMP

RUTH            CA      RCSFLAGS
                MASK    PBIT            # IN ATTITUDE HOLD.
                EXTEND
                BZF     +2              # BRANCH IF P-RATE DAMPING IS FINISHED.
                TCF     RATEDAMP

# Page 1433
                CA      RCSFLAGS
                MASK    QRBIT
                EXTEND
                BZF     RATEDONE        # BRANCH IF Q,R RATE DAMPING IS FINISHED.
                TCF     RATEDAMP

# ============================================

1/10SEC         OCT     1
40CYC           OCT     50
PQRBIT          OCT     74777
BITS9,11        EQUALS  EBANK5
LINRATP         DEC     46

# ============================================

RATEDONE        CS      OURRCBIT        # MANUAL COMMAND AND DAMPING COMPLETED IN
                INHINT                  # ALL AXES.
                MASK    DAPBOOLS
                TS      DAPBOOLS

# READ CDUS INTO CDU DESIRED REGISTERS

                CAF     BIT13
                EXTEND
                RAND    CHAN31
                EXTEND
```

```
                BZF     +4
                CA      CDUX            # (X-AXIS OVERRIDE)
                TS      CDUXD
                TC      +3
                TC      IBNKCALL
                FCADR   ZATTEROR
                RELINT
                TCF     PURGENCY

                TS      PERROR
JUSTOUT         CA      OURRCBIT        # INITIALIZATION -- FIRST MANUAL PASS.
                ADS     DAPBOOLS
                CA      ZERO
                TS      DXERROR
                TS      DXERROR +1
                TS      DYERROR
                TS      DYERROR +1
                TS      DZERROR
                TS      DZERROR +1
                TS      PLAST
                TS      QLAST
                TS      RLAST
                TS      Q-RHCCTR
                TS      R-RHCCTR
                CA      PQRBIT
                MASK    RCSFLAGS
                TS      RCSFLAGS        # BITS 10 AND 11 OF RCSFLAGS ARE 0.
# Page 1434
                CS      RCSFLAGS        # SET 'JUST-IN' BIT TO 1.
                MASK    BIT9
                ADS     RCSFLAGS
                TC      ZEROENBL
                TCF     JETSOFF
ZEROENBL        LXCH    R-RHCCTR
                CA      Q-RHCCTR
                DXCH    SAVEHAND
                CA      ZERO
                TS      P-RHCCTR
                TS      Q-RHCCTR
                TS      R-RHCCTR
                CA      BITS8,9
                EXTEND
                WOR     CHAN13          # COUNTERS ZEROED AND ENABLED
                TC      Q
RATEDAMP        CA      ZERO
                TS      P-RHCCTR
```

```
                TCF     RATERROR

RHCMOVED        CA      OURRCBIT        # P CONTROL
                MASK    DAPBOOLS
                EXTEND
                BZF     JUSTOUT -1
RATERROR        CA      CDUX            # FINDCDUW REQUIRES THAT CDUXD=CDUX DURING
                TS      CDUXD           # X-AXIS OVERRIDE
                CCS     P-RHCCTR
                TCF     +3
                TCF     +2
                TCF     +1
                DOUBLE                  # LINEAR/QUADRATIC CONTROLLER SCALING
                DOUBLE                  # (SEE EXPLANATION OF Q,R-AXES RCS
                AD      LINRATP         # AUTOPILOT)
                EXTEND
                MP      P-RHCCTR
                CA      L
                EXTEND
                MP      STIKSENS
                XCH     PLAST
                COM
                AD      PLAST
                TS      DAPTEMP1
                TC      ZEROENBL        # INTERVAL.  ZERO AND ENABLE ACA COUNTERS.
                CS      PLAST
                AD      OMEGAP
                TS      EDOTP
                CCS     DAPTEMP1        # IF P COMMAND CHANGE EXCEEDS BREAKOUT
                TCF     +3              # LEVEL, GO TO DIRECT RATE CONTROL.  IF NOT
                TCF     +8D             # CHECK FOR DIRECT RATE CONTROL LAST TIME.
                TCF     +1
# Page 1435
                AD      -RATEDB
                EXTEND
                BZMF    +4
                CA      40CYC
                TS      TCP
                TC      PEGI
                CA      RCSFLAGS        # CHECK FOR DIRECT RATE COMMAND LAST TIME.
                MASK    PBIT
                EXTEND
                BZF     +2
                TC      PEGI            # TO PURE RATE COMMAND
                CA      DXERROR         # PSEUDO-AUTO CONTROL.
                TS      E               # X-ATTITUDE ERROR (SP)
```

```
                TS      PERROR          # LOAD P-AXIS ERROR FOR MODE1 FDAI DISPLAY
                TC      PURGENCY +4
PEGI            CA      CDUX            # DIRECT RATE CONTROL.
                TS      CDUXD
                CA      ZERO
                TS      DXERROR
                TS      DXERROR +1
                TS      PERROR          # ZERO P-AXIS ERROR FOR MODE1 FDAI DISPLAY
                CCS     EDOTP
                TC      +3
                TC      +2
                TC      +1
                TS      ABSEDOTP
                AD      TARGETDB
                EXTEND                  # IF RATE ERROR IS LESS THAN DEADBANK,
                BZMF    LAST            # FIRE, AN SWITCH TO PSEUDO-AUTO.
                CA      TCP
                EXTEND                  # IF TIME IN RATE COMMAND EXCEEDS 4 SEC.
                BZMF    LAST
                CS      RCSFLAGS
                MASK    PBIT
                ADS     RCSFLAGS        # BIT 10 IS 1.
                TCF     +4
LAST            CS      PBIT
                MASK    RCSFLAGS
                TS      RCSFLAGS        # BIT 10 IS 0.
                CS      EDOTP
                EXTEND
                MP      1/ANETP         # 1/2JTACC SCALED AT 2EXP(7)/PI
                DAS     A
                TC      OVERSUB
                EXTEND
                MP      25/32           # A CONTAINS TJET SCALED AT 2EXP(4)(16/25)
                TS      TJP             # 4.JET TIME
                CA      ABSEDOTP
                AD      -2JETLIM        # COMPARING DELTA RATE WITH 2 JET LIMIT
                EXTEND
# Page 1436
                BZMF    +3

                CA      SIX
                TCF     +8D
                CA      TJP
                ADS     TJP

# GOES TO PJETSLEC FOR TWO JETS
```

```
# P-JET-SELECTION-ROUTINE (ROTATION)
#
# INPUT:        NUMBERT         4,5,6 FOR WHICH PAIR OR 4 JETS
#               TJP             + FOR +P ROTATION
#
# OUTPUT:       CHANNEL 6
#               PJUMPADR        FOR P-AXIS SKIP
#               (JTLST CALL)    (SMALL TJP)
#
# ORDER OF POLICIES TRIED IN CASE OF FAILURE.
#       +P      -P
#       7,15    8,16
#       4,12    3,11
#       4,7     8,11
#       7,12    11,16
#       12,15   3,16
#       4,15    3,8
#       ALARM   ALARM

                CA      AORBSYST
                MASK    DAPBOOLS
                CCS     A
                CA      ONE
                AD      FOUR
                TS      NUMBERT
PJETSLEC        CA      ONE
                TS      L
                CCS     TJP
                TCF     +5
                TCF     JETSOFF
                TCF     +2
                TCF     JETSOFF
                ZL
                AD      ONE
                TS      ABSTJ
                LXCH    ROTINDEX
                TC      SELECTP
                CS      SIX
                AD      NUMBERT
                EXTEND
                BZF     +2

                CS      TWO

# Page 1437
                AD      FOUR
```

```
                TS      NO.PJETS
                CA      POLYTEMP
                TC      WRITEP
                CS      ABSTJ
                AD      +150MST6
                EXTEND
                BZMF    QRAXIS          # GO TO QRAXIS OR TO GTS.

                AD      -136MST6
                EXTEND
                BZMF    +5

                ADS     ABSTJ
                INDEX   ROTINDEX
                CA      MINTIMES
                TS      TJP

                CA      ABSTJ
                ZL
                INHINT
                DXCH    T6FURTHA
                TC      IBNKCALL
                CADR    JTLST
                CS      BIT12
                MASK    RCSFLAGS
                TS      RCSFLAGS        # BIT 12 SET TO 0.
                TC      ALTSYST
                TCF     QRAXIS

ALTSYST         CA      DAPBOOLS        # ALTERNATE P-AXIS JETS
                TS      L
                CA      AORBSYST
                EXTEND
                RXOR    LCHAN
                TS      DAPBOOLS
                RELINT
                TC      Q

DKALT           TC      ALTSYST

JETSOFF         TC      WRITEP  -1
                CA      ZERO
                TS      TJP
                TCF     QRAXIS

# (NOTE -- M13 = 1 IDENTICALLY IMPLIES NULL MULTIPLICATION.)
```

```
CALCPERR        CA      CDUY            # P-ERROR CALCULATION.
                EXTEND
                MSU     CDUYD           # CDU VALUE -- ANGLE DESIRED (Y-AXIS)
# Page 1438
                EXTEND
                MP      M11             # (CDUY-CDUYD)M11 SCALED AT PI RADIANS
                XCH     E               # SAVE FIRST TERM (OF TWO)
                CA      CDUX            # THIRD COMPONENT
                EXTEND
                MSU     CDUXD           # CDU VALUE -- ANGLE DESIRED (X-AXIS)
#               EXTEND
#               MP      M13
                AD      DELPEROR        # KALCMANU INTERFACE ERROR.
                ADS     E               # SAVE SUM OF TERMS.  COULD BE OVERFLOW.
                XCH     PERROR          # SAVE P-ERROR FOR EIGHT-BALL DISPLAY.
                TC      Q               # RETURN TO CALLER

# P-AXIS URGENCY FUNCTION CALCULATION.

PURGENCY        TC      CALCPERR        # CALCULATE P-AXIS ERRORS.
                CS      OMEGAPD         # THIS CODING IS COMMON TO BOTH LM DAP AND
                AD      OMEGAP          # SPS-BACKUP MODE.
                TS      EDOTP           # EDOTP = OMEGAP - OMEGAPD AT PI/4 RAD/SEC

                CS      ONE
                TS      AXISCTR
                CA      DAPBOOLS
                MASK    CSMDOCKD
                EXTEND
                BZF     HEADTJET
                INHINT                  # IF CSMDOCKD = 1, GOT TO DOCKED RCS LOGIC
                TC      IBNKCALL
                CADR    SPSRCS

                CA      TJP
                EXTEND
                BZF     DKALT           # IF TJP = ZERO, CHANGE AORBSYST.
                RELINT
                TCF     PJETSLEC -6     # SELECT AORBSYST AND USE TWO JETS.
HEADTJET        CA      ZERO
                TS      SENSETYP
                INHINT
                TC      IBNKCALL
                CADR    TJETLAW
                RELINT
```

```
                CS      FIREFCT
                AD      -FOURDEG
                EXTEND
                BZMF    PJETSLEC -6
                CCS     TJP
                TCF     +2
                TCF     JETSOFF
# Page 1439
                AD      -160MST6
                EXTEND
                BZMF    PJETSLEC -6
                CA      SIX
                TCF     PJETSLEC -1
-160MST6        DEC     -256
-FOURDEG        DEC     -.08888

# Page 1440
# JET POLICY CONSTRUCTION SUBROUTINE
#
# INPUT:        ROTINDEX, NUMBERT
#
# OUTPUT:       POLYTEMP (JET POLICY)
#
# THIS SUBROUTINE SELECT A SUBSET OF THE DESIRED JETS WHICH HAS NO FAILURE

SELECTP         CA      SIX
                TS      TEMPNUM
                INDEX   NUMBERT
                CA      TYPEP
                INDEX   ROTINDEX
                MASK    JETSALL
                TS      POLYTEMP
                MASK    CH6MASK
                CCS     A
                TCF     +2
                TC      Q
                CCS     TEMPNUM
                TCF     +4
                TC      ALARM
                OCT     02003
                TCF     JETSOFF         # ********** TCF ALARMJET **********
SELECTYZ        TS      NUMBERT
                TCF     SELECTP +1
        -1      TCF     ABORTYZ +2
JETSALL         OCT     00252
```

```
                OCT     00125           # +P
                OCT     00140           # -Y
                OCT     00006           # -Z
                OCT     00220           # +Y
                OCT     00011           # +Z
                OCT     00151           # +V
TYPEP           OCT     00146           # -U
                OCT     00226           # -V
                OCT     00231           # +U
                OCT     00151           # +V
                OCT     00132           # 1-3
                OCT     00245           # 2-4
                OCT     00377           # ALL
INDXYZ          =       -136MST6
-136MST6        DEC     -218
                DEC     4
                DEC     2
                OCT     07776
                DEC     5
                DEC     9
                DEC     10
                OCT     07776
                DEC     3
# Page 1441
                DEC     8
                DEC     7
                OCT     07776           # THESE INDEXES OF MASK JETSALL WILL
                OCT     07776           # CHANGE THE INSTRUCTION AT SELECTP +4
                OCT     07776           # TO BE         TC JETSALL -1
                OCT     07776           # ONLY USED FOR TRANSLATION FAILURE
                OCT     07776
+150MST6        DEC     240
07400OCT        OCT     07400

# T-JET LAW FIXED CONSTANTS

NORMSCL         OCT     266
-100MS          DEC     -.1
200MS           DEC     .2
25/32           =       PRIO31          # (DEC .78125)
BITS8,9         OCTAL   00600
1/40            DEC     .02500
MINTIMES        DEC     -22
                DEC     22
PSKIPADR        GENADR  SKIPPAXS
```

```
# GOES TO Q,R-AXES RCS AUTOPILOT

QRAXIS          CS      OMEGARD
                AD      OMEGAR
                TC      OVERSUB
                TS      EDOTR
                CS      OMEGAQD
                AD      OMEGAQ
                TC      OVERSUB
                TS      EDOTQ
                EXTEND
                DCA     QERRCALL
                DTCB

                EBANK=  AOSQ
QERRCALL        2CADR   CALLQERR
```

Uses A 80, ARUPT 80, BANKRUPT 80, BRUPT 80, CDUS 80, CDUX 80, CDUXD 213, CDUY 80, CDUYD 213, CDUZ 80, CDUZD 213, CH31TEMP 211, CHAN12 87, CHAN13 87, CHAN31 87, CODE 140, COMMAND 169, COUNT 142, D 226, DAPS1 63, DELCDUX 211, DELCDUY 211, DELCDUZ 211, DV 241, EBANK 80, F 238, I 206, IT 185, ITEMP1 138, L 80, LCHAN 87, MODE 145, N 206, OMEGA 232, P 188, Q 80, QRUPT 80, RAD 219, RCSFLAGS 200, RESTART 57, SAVE 191, STATE 138, TC 169, TIME5 80, V 229, Z 80, and ZRUPT 80.

4.35 q-r axis rcs autopilot

2542 ⟨*q-r axis rcs autopilot* 2542⟩≡ (2041 2782)

```
# Page 1442
                BANK    17
                SETLOC  DAPS2
                BANK

                EBANK=  CDUXD

                COUNT*  $$/DAPQR

CALLQERR        CA      BIT13           # CALCULATE Q,R ERRORS UNLESS THESE AXES
                EXTEND                  # ARE IN MANUAL RATE COMMAND.
                RAND    CHAN31
                CCS     A
                TCF     +5              # IN AUTO COMPUTE Q,R ERRORS
                CS      DAPBOOLS        # IN MANUAL RATE COMMAND?
                MASK    OURRCBIT
                EXTEND
                BZF     Q,RORGTS        # IF SO BYPASS CALCULATION OF ERRORS.
                TC      QERRCALC

Q,RORGTS        CCS     COTROLER        # CHOOSE CONTROL SYSTEM FOR THIS DAP PASS:
                TCF     GOTOGTS         #       GTS (ALTERNATES WITH RCS WHEN DOCKED)
                TCF     TRYGTS          #       GTS IF ALLOWED, OTHERWISE RCS
RCS             CAF     ZERO            #       RCS (TRYGTS MAY BRANCH TO HERE)
                TS      COTROLER

                DXCH    EDOTQ
                TC      ROT-TOUV
                DXCH    OMEGAU

# X - TRANSLATION
#
# INPUT:        BITS 7,8 OF CH31 (TRANSLATION CONTROLLER)
#               ULLAGER
#               APSFLAG, DRIFTBIT
#               ACC40R2X, ACRBTRAN
#
# OUTPUT:       NEXTU, NEXTV    CODES OF TRANSLATION FOR AFTER ROTATION
#               SENSETYP        TELL ROTATION DIRECTION AND DESIRE
#
# X-TRANS POLICIES ARE EITHER 4 JETS OR A DIAGONAL PAIR.  IN 2-JET TRANSLATION THE SY
# WILL OVERRIDE THIS SPECIFICATION.  AN ALARM RESULTS WHEN NO POLICY IS AVAILABLE BEC
```

```
SENSEGET        CA      BIT7            # INPUT BITS OVERRIDE THE INTERNAL BITS
                EXTEND                  # SENSETYP WILL NOT OPPOSE ANYTRANS
                RAND    CHAN31
                EXTEND
                BZF     +XORULGE
# Page 1443
                CA      BIT8
                EXTEND
                RAND    CHAN31
                EXTEND
                BZF     -XTRANS

                CA      ULLAGER
                MASK    DAPBOOLS
                CCS     A
                TCF     +XORULGE

                TS      NEXTU           # STORE NULL TRANSLATION POLICIES
                TS      NEXTV
                CS      DAPBOOLS        # BURNING OR DRIFTING?
                MASK    DRIFTBIT
                EXTEND
                BZF     TSENSE
                CA      FLGWRD10        # DPS (INCLUDING DOCKED) OR APS?
                MASK    APSFLBIT
                CCS     A
                CAF     TWO             # FAVOR +X JETS DURING AN APS BURN.
TSENSE          TS      SENSETYP
                TCF     QRCONTRL

+XORULGE        CAF     ONE
-XTRANS         AD      FOUR
                TS      ROTINDEX
                AD      NEG3
                TS      SENSETYP        # FAVOR APPROPRIATE JETS DURING TRANS.
                CA      DAPBOOLS
                MASK    ACC4OR2X
                CCS     A
                TCF     TRANS4

                CA      DAPBOOLS
                MASK    AORBTRAN
                CCS     A
                CA      ONE             # THREE FOR B
                AD      TWO             # TWO FOR A SYSTEM 2 JET X TRANS
TSNUMBRT        TS      NUMBERT
```

```
                TC      SELCTSUB

                CCS     POLYTEMP
                TCF     +3
                TC      ALARM
                OCT     02002
                CA      00314OCT
                MASK    POLYTEMP
TSNEXTS         TS      NEXTU
# Page 1444
                CS      00314OCT
                MASK    POLYTEMP
                TS      NEXTV

# Q,R-AXES RCS CONTROL MODE SELECTION
#       SWITCHES        INDICATION WHEN SET
#       BIT13/CHAN31    AUTO, GO TO ATTSTEER
#       PULSES          MINIMUM IMPULSE MODE
#       (OTHERWISE)     RATE COMMAND/ATTITUDE HOLD MODE

QRCONTRL        CA      BIT13           # CHECK MODE SELECT SWITCH.
                EXTEND
                RAND    CHAN31          # BITS INVERTED
                CCS     A
                TCF     ATTSTEER
CHKBIT10        CAF     PULSES          # PULSES = 1 FOR MIN IMP USE OF RHC
                MASK    DAPBOOLS
                EXTEND
                BZF     CHEKSTIK        # IN ATT-HOLD/RATE-COMMAND IF BIT10=0

# MINIMUM IMPULSE MODE

                INHINT
                TC      IBNKCALL
                CADR    ZATTEROR
                CA      ZERO
                TS      QERROR
                TS      RERROR          # FOR DISPLAYS
                RELINT

                EXTEND
                READ    CHAN31
                TS      TEMP31          # IS EQUAL TO DAPTEMP1
                CCS     OLDQRMIN
                TCF     CHECKIN
```

```
FIREQR          CA      TEMP31
                MASK    BIT1
                EXTEND
                BZF     +QMIN

                CA      TEMP31
                MASK    BIT2
                EXTEND
                BZF     -QMIN

                CA      TEMP31
                MASK    BIT5
# Page 1445
                EXTEND
                BZF     +RMIN

                CA      TEMP31
                MASK    BIT6
                EXTEND
                BZF     -RMIN

                TCF     XTRANS

CHECKIN         CS      TEMP31
                MASK    OCT63
                TS      OLDQRMIN
                TCF     XTRANS

+QMIN           CA      14MS
                TS      TJU
                CS      14MS
                TCF     MINQR
-QMIN           CS      14MS
                TS      TJU
                CA      14MS
                TCF     MINQR
+RMIN           CA      14MS
                TCF     +2
-RMIN           CS      14MS
                TS      TJU
MINQR           TS      TJV
                CA      MINADR
                TS      RETJADR
                CA      ONE
                TS      OLDQRMIN
```

```
MINRTN          TS      AXISCTR
                CA      DAPBOOLS
                MASK    CSMDOCKD
                EXTEND
                BZF     MIMRET
                INDEX   AXISCTR         # IF DOCKED, USE 60MS MINIMUM IMPULSE
                CCS     TJU
                CA      60MS
                TCF     +2
                CS      60MS
                INDEX   AXISCTR
                TS      TJU
MIMRET          CA      DAPBOOLS
                MASK    AORBTRAN
                CCS     A
                CA      ONE
                AD      TWO
                TS      NUMBERT
# Page 1446
                TCF     AFTERTJ

60MS            DEC     96              # RSB 2009 -- was 96.0.
MINADR          GENADR  MINRTN
OCT63           OCT     63
14MS            =       +TJMINT6

TRANS4          CA      FOUR
                TCF     TSNUMBRT

# RATE COMMAND MODE:
#
# DESCRIPTION (SAME AS P-AXIS)

CHEKSTIK        TS      INGTS           # NOT IN GTS WHEN IN ATT HOLD
                CS      ONE             # 1/ACCS WILL DO THE NULLING DRIVES
                TS      COTROLER        # COME BACK TO RCS NEXT TIME
                CA      BIT15
                MASK    CH31TEMP
                EXTEND
                BZF     RHCACTIV        # BRANCH IF OUT OF DETENT.
                CA      OURRCBIT        # ***********
                MASK    DAPBOOLS        # *IN DETENT*   CHECK FOR MANUAL CONTROL
                EXTEND                  # ***********   LAST TIME.
                BZF     STILLRCS
                CS      BIT9
                MASK    RCSFLAGS
```

```
                TS      RCSFLAGS        # BIT 9 IS 0.
                TCF     DAMPING
40CYCL          OCT     50
1/10S           OCT     1
LINRAT          DEC     46

# ==========================================================

DAMPING         CA      ZERO
                TS      SAVEHAND
                TS      SAVEHAND +1
RHCACTIV        CCS     SAVEHAND        # *****************
                TCF     +3              # Q,R MANUAL CONTROL    WC = A*(B+|D|)*D
                TCF     +2              # *****************
                TCF     +1
                DOUBLE                  # WHERE
                DOUBLE                  #
                AD      LINRAT          #       WC  = COMMANDED ROTATIONAL RATE
                EXTEND                  #       A   = QUADRATIC SENSITIVITY FACTOR
                MP      SAVEHAND        #       B   = LINEAR/QUADRATIC SENSITIVITY
                CA      L               #       |D| = ABS. VALUE OF DEFLECTION
                EXTEND                  #       D   = HAND CONTROLLER DEFLECTION
                MP      STIKSENS
                XCH     QLAST           # COMMAND Q RATE, SCALED 45 DEG/SEC
                COM
# Page 1447
                AD      QLAST
                TS      DAPTEMP3
                CCS     SAVEHAND +1
                TCF     +3
                TCF     +2
                TCF     +1
                DOUBLE
                DOUBLE
                AD      LINRAT
                EXTEND
                MP      SAVEHAND +1
                CA      L
                EXTEND
                MP      STIKSENS
                XCH     RLAST
                COM
                AD      RLAST
                TS      DAPTEMP4
                CS      QLAST           # INTERVAL.
                AD      OMEGAQ
```

```
                TS      QRATEDIF
                CS      RLAST
                AD      OMEGAR
                TS      RRATEDIF
ENTERQR         DXCH    QRATEDIF        # TRANSFORM RATES FROM Q,R TO U,V AXES
                TC      ROT-TOUV
                DXCH    URATEDIF
                CCS     DAPTEMP3        # CHECK IF Q COMMAND CHANGE EXCEEDS
                TC      +3              # BREAKOUT LEVEL.  IF NOT, CHECK R.
                TC      +2
                TC      +1
                AD      -RATEDB
                EXTEND
                BZMF    +2
                TCF     ENTERUV -2      # BREAKOUT LEVEL EXCEEDED.  DIRECT RATE.
                CCS     DAPTEMP4        # R COMMAND BREAKOUT CHECK.
                TC      +3
                TC      +2
                TC      +1
                AD      -RATEDB
                EXTEND
                BZMF    +2
                TCF     ENTERUV -2      # BREAKOUT LEVEL EXCEEDED.  DIRECT RATE.
                CA      RCSFLAGS        # BREAKOUT LEVEL NOT EXCEEDED.  CHECK FOR
                MASK    QRBIT           # DIRECT RATE CONTROL LAST TIME.
                EXTEND
                BZF     +2
                TCF     ENTERUV         # CONTINUE DIRECT RATE CONTROL.
                TCF     STILLRCS        # PSEUDO-AUTO CONTROL.
                CA      40CYCL
# Page 1448
                TS      TCQR
ENTERUV         INHINT                  # DIRECT RATE CONTROL
                TC      IBNKCALL
                FCADR   ZATTEROR
                RELINT
                CA      ZERO
                TS      DYERROR
                TS      DYERROR +1
                TS      DZERROR
                TS      DZERROR +1
                CCS     URATEDIF
                TCF     +3
                TCF     +2
                TCF     +1
                AD      TARGETDB        # IF TARGET DB IS EXCEEDED, CONTINUE
```

```
                EXTEND                  # DIRECT RATE CONTROL.
                BZMF    VDB
                CCS     VRATEDIF
                TCF     +3
                TCF     +2
                TCF     +1
                AD      TARGETDB
                EXTEND
                BZMF    +2
                TCF     QRTIME
                CA      ZERO
                TS      VRATEDIF
                TCF     QRTIME
VDB             CCS     VRATEDIF
                TC      +3
                TC      +2
                TC      +1
                AD      TARGETDB        # IF TARGET DB IS EXCEEDED, CONTINUE
                EXTEND                  # DIRECT RATE CONTROL.  IF NOT, FIRE AND
                BZMF    TOPSEUDO        # SWITCH TO PSEUDO-AUTO CONTROL ON NEXT
                CA      ZERO            # PASS.
                TS      URATEDIF
QRTIME          CA      TCQR            # DIRECT RATE TIME CHECK.
                EXTEND
                BZMF    +5              # BRANCH IF TIME EXCEEDS 4 SEC.
                CS      RCSFLAGS
                MASK    QRBIT
                ADS     RCSFLAGS        # BIT 11 IS 1.
                TC      +4
TOPSEUDO        CS      QRBIT
                MASK    RCSFLAGS
                TS      RCSFLAGS        # BIT 11 IS 0.
                CA      HANDADR
                TS      RETJADR
                CA      ONE

# Page 1449
BACKHAND        TS      AXISCTR

                CA      FOUR
                TS      NUMBERT

                INDEX   AXISCTR
                INDEX   SKIPU
                TCF     +1
                CA      FOUR
```

```
                INDEX   AXISCTR
                TS      SKIPU
                TCF     LOOPER

                INDEX   AXISCTR
                CCS     URATEDIF        #       INDEX   AXIS    QUANTITY
                CA      ZERO            #       0       -U      1/JETACC-AOSU
                TCF     +2              #       1       +U      1/JETACC+AOSU
                CA      ONE             #       16      -V      1/JETACC-AOSV
                INDEX   AXISCTR         #       17      +V      1/JETACC+AOSV
                AD      AXISDIFF        # JETACC = 2 JET ACCELERATION (1 FOR FAIL)

                INDEX   A
                CS      1/ANET2 +1
                EXTEND
                INDEX   AXISCTR         # UPRATEDIF IS SCALED AT PI/4 RAD/SEC
                MP      URATEDIF        # JET TIME IN A, SCALED 32 SEC
                TS      Q
                DAS     A
                AD      Q
                TS      A               # OVERFLOW SKIP
                TCF     +2
                CA      Q               # RIGHT SIGN AND BIGGER THAN 150MS
SETTIME         INDEX   AXISCTR
                TS      TJU             # SCALED AT 10.67 WHICH IS CLOSE TO 10.24
                TCF     AFTERTJ

ZEROTJ          CA      ZERO
                TCF     SETTIME

HANDADR         GENADR  BACKHAND

# GTS WILL BE TRIED IF
#       1. USEQRJTS = 0,
#       2. ALLOWGTS POS,
#       3. JETS ARE OFF (Q,R-AXES)

TRYGTS          CAF     USEQRJTS        # IS JET USE MANDATORY.         (AS LONG AS
                MASK    DAPBOOLS        # USEQRJTS BIT IS NOT BIT 15, CCS IS SAFE.)
                CCS     A
                TCF     RCS
                CCS     ALLOWGTS        # NO.  DOES AOSTASK OK CONTROL FOR GTS?
# Page 1450
                TCF     +2
                TCF     RCS
                EXTEND
```

```
                READ    CHAN5
                CCS     A
                TCF     CHKINGTS
GOTOGTS         EXTEND
                DCA     GTSCADR
                DTCB

CHKINGTS        CCS     INGTS           # WAS THE TRIM GIMBAL CONTROLLING
                TCF     +2              #       YES.  SET UP A DAMPED NULLING DRIVE.
                TCF     RCS             #       NO.  NULLING WAS SET UP BEFORE.  DO RCS.
                INHINT
                TC      IBNKCALL
                CADR    TIMEGMBL
                RELINT
                CAF     ZERO
                TS      INGTS
                TCF     RCS

                EBANK=  CDUXD
GTSCADR         2CADR   GTS

# Page 1451
# SUBROUTINE TO COMPUTE Q,R-AXES ATTITUDE ERRORS FOR USE IN THE RCS AND GTS CONTROL LAWS AND TH

QERRCALC        CAE     CDUY            # Q-ERROR CALCULATION
                EXTEND
                MSU     CDUYD           # CDU ANGLE -- ANGLE DESIRED (Y-AXIS)
                TS      DAPTEMP1        # SAVE FOR RERRCALC
                EXTEND
                MP      M21             # (CDUY-CDUYD)*M21 SCALED AT PI RADIANS
                TS      E
                CAE     CDUZ            # SECOND TERM CALCULATION:
                EXTEND
                MSU     CDUZD           # CDU ANGLE -ANGLE DESIRED (Z-AXIS)
                TS      DAPTEMP2        # SAVE FOR RERRCALC
                EXTEND
                MP      M22             # (CDUZ-CDUZD)*M22 SCALED AT PI RADIANS
                AD      DELQEROR        # KALCMANU INERFACE ERROR
                AD      E
                XCH     QERROR          # SAVE Q-ERROR FOR EIGHT-BALL DISPLAY.

RERRCALC        CAE     DAPTEMP1        # R-ERROR CALCULATION:
                EXTEND                  # CDU ANGLE -ANGLE DESIRED (Y-AXIS)
                MP      M31             # (CDUY-CDUYD)*M31 SCALED AT PI RADIANS
                TS      E
                CAE     DAPTEMP2        # SECOND TERM CALCULATION:
```

```
                EXTEND                  # CDU ANGLE -ANGLE DESIRED (Z-AXIS)
                MP      M32             # (CDUZ-CDUZD)*M32 SCALED AT PI RADIANS
                AD      DELRERROR       # KALCMANU INERFACE ERROR
                AD      E
                XCH     RERROR          # SAVE R-ERROR FOR EIGHT-BALL DISPLAY.
                TC      Q

# Page 1452
# "ATTSTEER" IS THE ENTRY POINT FOR Q,R-AXES (U,V-AXES) ATTITUDE CONTROL USING THE RE

ATTSTEER        EQUALS  STILLRCS        # "STILLRCS" IS THE RCS EXIT FROM TRYGTS.

STILLRCS        CA      RERROR
                LXCH    A
                CA      QERROR
                TC      ROT-TOUV
                DXCH    UERROR

# PREPARES CALL TO TJETLAW (OR SPSRCS(DOCKED))
# PREFORMS SKIP LOGIC ON U OR Y AXIS IF NEEDED.

TJLAW           CA      TJLAWADR
                TS      RETJADR
                CA      ONE
                TS      AXISCTR
                INDEX   AXISCTR
                INDEX   SKIPU
                TCF     +1
                CA      FOUR
                INDEX   AXISCTR
                TS      SKIPU
                TCF     LOOPER
                INDEX   AXISCTR
                CA      UERROR
                TS      E
                INDEX   AXISCTR
                CA      OMEGAU
                TS      EDOT
                CA      DAPBOOLS
                MASK    CSMDOCKD
                CCS     A
                TCF     +3
                TC      TJETLAW
                TCF     AFTERTJ
        +3      CS      DAPBOOLS        # DOCKED.  IF GIMBAL USABLE DO GTS CONTROL
                MASK    USEQRJTS        #       ON THE NEXT PASS.
```

```
                CCS     A               # USEQRJTS BIT MUST NOT BE BIT 15.
                TS      COTROLER        # GIMBAL USABLE.  STORE POSITIVE VALUE.
                INHINT
                TC      IBNKCALL
                CADR    SPSRCS          # DETERMINE RCS CONTROL
                RELINT
                CAF     FOUR            # ALWAYS CALL FOR 2-JET CONTROL ABOUT U,V.
                TS      NUMBERT         # FALL THROUGH TO JET SELECTION, ETC.

# Q,R-JET-SELECTION-LOGIC
#
# INPUT:        AXISCTR         0,1 FOR U,V
#               SNUFFBIT        ZERO TJETU,V AND TRANS. ONLY IF SET IN A DPS BURN
# Page 1453
#               TJU,TJV         JET TIME SCALED 10.24 SEC.
#               NUMBERT         INDICATES NUMBER OF JETS AND TYPE OF POLICY
#               RETJADR         WHERE TO RETURN TO
#
# OUTPUT:       NO.U(V)JETS     RATE DERIVATION FEEDBACK
#               CHANNEL 5
#               SKIPU,SKIPV     FOR LESS THAN 150MS FIRING
#
# NOTES:        IN CASE OF FAILURE IN DESIRED ROTATION POLICY, "ALL" UNFAILED
#               JETS OF THE DESIRED POLICY ARE SELECTED.  SINCE THERE ARE ONLY
#               TWO JETS, THIS MEANS THE OTHER ONE OR NONE.  THE ALARM IS SENT
#               IF NONE CAN BE FOUND.
#
#               TIMES LESS THAN 14 MSEC ARE TAKEN TO CALL FOR A SINGLE-JET
#               MINIMUM IMPULSE, WITH THE JET CHOSEN SEMI-RANDOMLY.

AFTERTJ         CA      FLAGWRD5        # IF SNUFFBIT SET DURING A DPS BURN GO TO
                MASK    SNUFFBIT        # XTRANS; THAT IS, INHIBIT CONTROL.
                EXTEND
                BZF     DOROTAT
                CS      FLGWRD10
                MASK    APSFLBIT
                EXTEND
                BZF     DOROTAT
                CA      DAPBOOLS
                MASK    DRIFTBIT
                EXTEND
                BZF     XTRANS

DOROTAT         CAF     TWO
                TS      L
                INDEX   AXISCTR
```

```
                CCS     TJU
                TCF     +5
                TCF     NOROTAT
                TCF     +2
                TCF     NOROTAT
                ZL
                AD      ONE
                TS      ABSTJ

                CA      AXISCTR
                AD      L
                TS      ROTINDEX        # 0 1 2 3 = -U -V +U +V

                CA      ABSTJ
                AD      -150MS
                EXTEND
                BZMF    DOSKIP
# Page 1454
                TC      SELCTSUB

                INDEX   AXISCTR
                CA      INDEXES
                TS      L

                CA      POLYTEMP
                INHINT
                INDEX   L
                TC      WRITEP

                RELINT
                TCF     FEEDBACK

NOROTAT         INDEX   AXISCTR
                CA      INDEXES
                INHINT
                INDEX   A
                TC      WRITEP  -1

                RELINT
LOOPER          CCS     AXISCTR
                TC      RETJADR
                TCF     CLOSEOUT
DOSKIP          CS      ABSTJ
                AD      +TJMINT6        # 14MS
                EXTEND
                BZMF    NOTMIN
```

```
                ADS     ABSTJ
                INDEX   AXISCTR
                CCS     TJU
                CA      +TJMINT6
                TCF     +2
                CS      +TJMINT6
                INDEX   AXISCTR
                TS      TJU

                CCS     SENSETYP        # ENSURE MIN-IMPULSE NOT AGAINST TRANS
                TCF     NOTMIN  -1
                EXTEND
                READ    LOSCALAR
                MASK    ONE
                TS      NUMBERT

NOTMIN          TC      SELCTSUB

                INDEX   AXISCTR
                CA      INDEXES
                INHINT
# Page 1455
                TS      T6FURTHA +1
                CA      POLYTEMP
                INDEX   T6FURTHA +1
                TC      WRITEP

                CA      ABSTJ
                TS      T6FURTHA
                TC      JTLST           # IN QR BANK BY NOW

                RELINT

                CA      ZERO
                INDEX   AXISCTR
                TS      SKIPU

FEEDBACK        CS      THREE
                AD      NUMBERT
                EXTEND
                BZMF    +3

                CA      TWO
                TCF     +2
                CA      ONE
```

```
                INDEX   AXISCTR
                TS      NO.UJETS
                TCF     LOOPER

XTRANS          CA      ZERO
                TS      TJU
                TS      TJV
                CA      FOUR
                INHINT
                XCH     SKIPU
                EXTEND
                BZF     +2
                TC      WRITEU  -1
                CA      FOUR
                XCH     SKIPV
                RELINT

                EXTEND
                BZF     CLOSEOUT
                INHINT
                TC      WRITEV  -1
                RELINT

                TCF     CLOSEOUT
INDEXES         DEC     4
                DEC     13
+TJMINT6        DEC     22
# Page 1456
-150MS          DEC     -240
BIT8,9          OCT     00600
SCLNORM         OCT     266
TJLAWADR        GENADR  TJLAW   +3      # RETURN ADDRESS FOR RCS ATTITUDE CONTROL

# THE JET LIST:
# THIS IS A WAITLIST FOR T6RUPTS.
#
# CALLED BY:
#               CA      TJ              # TIME WHEN NEXT JETS WILL BE WRITTEN
#               TS      T6FURTHA
#               CA      INDEX           # AXIS TO BE WRITTEN AT TJ (FROM NOW)
#               TS      T6FURTHA +1
#               TC      JTLST
#
# EXAMPLE -- U-AXIS AUTOPILOT WILL WRITE ITS ROTATION CODE OF
# JETS INTO CHANNEL 5.  IF IT DESIRES TO TURN OFF THIS POLICY WITHIN
# 150MS AND THEN FIRE NEXTU, A CALL TO JTLST IS MADE WITH T6FURTHA
```

```
# CONTAINING THE TIME TO TURN OFF THE POLICY, T6FURTHA +1 THE INDEX
# OF THE U-AXIS(4), AND NEXTU WILL CONTAIN THE "U-TRANS" POLICY OR ZERO.
#
# THE LIST IS EXACTLY 3 LONG.  (THIS LEADS UP TO SKIP LOGIC AND 150MS LIMIT)
# THE INPUT IS THE LAST MEMBER OF THE LIST.
#
# RETURNS BY:
#       +       TC      Q
#
# DEFINITIONS:  (OUTPUT)
#       TIME6           TIME OF NEXT RUPT
#       T6NEXT          DELTA TIME TO NEXT RUPT
#       T6FURTHA        DELTA TIME FROM 2ND TO LAST RUPT
#       NXT6ADR         AXIS INDEX      0 -- P-AXIS
#       T6NEXT +1       AXIS INDEX      4 -- U-AXIS
#       T6FURTHA +1     AXIS INDEX      13 -- V-AXIS

JTLST           CS      T6FURTHA
                AD      TIME6
                EXTEND
                BZMF    MIDORLST        # TIME6 -- TI IS IN A

                LXCH    NXT6ADR
                DXCH    T6NEXT
                DXCH    T6FURTHA
                TS      TIME6
                LXCH    NXT6ADR

TURNON          CA      BIT15
                EXTEND
                WOR     CHAN13
                TC      Q

# Page 1457
MIDORLST        AD      T6NEXT
                EXTEND
                BZMF    LASTCHG         # TIME6 + T6NEXT - T IS IN A

                LXCH    T6NEXT  +1
                DXCH    T6FURTHA
                EXTEND
                SU      TIME6
                DXCH    T6NEXT

                TC      Q
```

```
LASTCHG         CS      A
                AD      NEG0
                TS      T6FURTHA

                TC      Q

# ROT-TOUV IS ENTERED WITH THE Q-COMPONENT OF THE QUANTITY TO BE TRANSFORMED IN A AND
# ROT-TOUV TRANSFORMS THE QUANTITY INTO THE NON-ORTHOGONAL U-V AXIS SYSTEM.  IN THE U
# PRODUCED FROM RCS JET FIRINGS.  AT THE COMPLETION OF ROT-TOUV, THE U-COMPONENT OF T
# A AND THE V-COMPONENT IS IN L.

ROT-TOUV        LXCH    ROTEMP2         # (R) IS PUT INTO ROTEMP2
                EXTEND
                MP      COEFFQ
                XCH     ROTEMP2         # (R) GOES TO A AND COEFFQ.(Q) TO ROTEMP2
                EXTEND
                MP      COEFFR
                TS      L               # COEFFR.(R) IS PUT INTO L
                AD      ROTEMP2
                TS      ROTEMP1         # COEFFQ.(Q)+COEFFR.(R) IS PUT IN ROTEMP1
                TCF     +4
                INDEX   A               # COEFFQ.(Q) + COEFFR.(R) HAS OVERFLOWED
                CS      LIMITS          # AND IS LIMITED TO POSMAX OR NEGMAX
                TS      ROTEMP1
                CS      ROTEMP2
                AD      L               # -COEFFQ.(Q) + COEFFR.(R) IS NOW IN A
                TS      7
                TCF     +3
                INDEX   A               # -COEFFQ.(Q) + COEFFR.(R) HAS OVERFLOWED
                CS      LIMITS          # AND IS LIMITED TO POSMAX OR NEGMAX
                LXCH    ROTEMP1         # COEFFQ.(Q) + COEFFR.(R) IS PUT INTO L
                TC      Q
SELCTSUB        INDEX   ROTINDEX
                CA      ALLJETS
                INDEX   NUMBERT
                MASK    TYPEPOLY
                TS      POLYTEMP
# Page 1458
                MASK    CH5MASK
                CCS     A
                TCF     +2

                TC      Q

                CA      THREE
FAILOOP         TS      NUMBERT
```

```
                INDEX   ROTINDEX
                CA      ALLJETS
                INDEX   NUMBERT
                MASK    TYPEPOLY
                TS      POLYTEMP
                MASK    CH5MASK
                EXTEND
                BZF     FAILOOP -2
                CCS     NUMBERT
                TCF     FAILOOP
                INDEX   AXISCTR
                TS      TJU
                TC      ALARM
                OCT     02004
                TCF     NOROTAT
ALLJETS         OCT     00110           #       -U      6 13
                OCT     00022           #       -V      2 9
                OCT     00204           #       +U      5 14
                OCT     00041           #       +V      1 10
TYPEPOLY        OCT     00125           #       -X      1 5 9 13
                OCT     00252           #       +X      2 6 10 14
                OCT     00146           #       A       2 5 10 13
                OCT     00231           #       B       1 6 9 14
                OCT     00377           #       ALL     1 2 5 6 9 10 13 14

# THE FOLLOWING SETS THE INTERRUPT FLIP-FLOP AS SOON AS POSSIBLE, WHICH PERMITS A RETURN TO THE

CLOSEOUT        CA      ADRRUPT
                TC      MAKERUPT

ADRRUPT         ADRES   ENDJASK

ENDJASK         DXCH    DAPARUPT
                DXCH    ARUPT
                DXCH    DAPBQRPT
                XCH     BRUPT
                LXCH    Q
                CAF     NEGMAX          # NEGATIVE DAPZRUPT SIGNALS JASK IS OVER.
                DXCH    DAPZRUPT
                DXCH    ZRUPT
                TCF     NOQRSM
# Page 1459
                BLOCK   3
                SETLOC  FFTAG6
                BANK
```

```
                COUNT*  $$/DAP

MAKERUPT        EXTEND
                EDRUPT  MAKERUPT
```

Uses A 80, ARUPT 80, BRUPT 80, CDUXD 213, CDUY 80, CDUYD 213, CDUZ 80, CDUZD 213, CH31TEMP 211, CHAN13 87, CHAN31 87, CODE 140, COMMAND 169, COUNT 142, D 226, DAPS2 63, DISPLAYS 59, EBANK 80, EDOT 209, FACTOR 226, FFTAG6 57, FLAGWRD5 113, FLGWRD10 133, IT 185, L 80, LONG 157, LOSCALAR 87, MODE 145, P 188, Q 80, QMIN 186, RAD 219, RCSFLAGS 200, SAVE 191, TC 169, TIME6 80, V 229, XTRANS 211, Z 80, and ZRUPT 80.

4.36 tjet law

2561 ⟨*tjet law* 2561⟩≡ (2041 2821)

```
# Page 1460
# PROGRAM DESCRIPTION
# DESIGNED BY:  R. D. GOSS AND P. S. WEISSMAN
# CODED BY:  P. S. WEISSMAN, 28 FEBRUARY 1968
#
# TJETLAW IS CALLED AS A SUBROUTINE WHEN THE LEM IS NOT DOCKED AND THE AUTOPILOT IS IN THE AUTO
# ATTITUDE-HOLD MODE TO CALCULATE THE JET-FIRING-TIME (TJET) REQUIRED FOR THE AXIS INDICATED BY
#       -1      INDICATES THE P-AXIS
#       +0      INDICATES THE U-AXIS
#       +1      INDICATES THE V-AXIS
# THE REGISTERS E AND EDOT CONTAIN THE APPROPRIATE ATTITUDE ERROR AND ERROR RATE AND SENSETYP S
# UNBALANCED COUPLES ARE PREFERRED.  TJETLAW ALSO USES VARIOUS FUNCTIONS OF ACCELERATION AND DE
# COMPUTED IN THE 1/ACCONT SECTION OF 1/ACCS AND ARE STORED IN SUCH AN ORDER THAT THEY CAN BE C
# ACCESSED BY INDEXING.
#
# THE SIGN OF THE REQUIRED ROTATION IS CARRIED THROUGH TJETLAW AS ROTSENSE AND IS FINALLY APPLI
# PREVIOUS TO ITS STORAGE IN THE LOCATION CORRESPONDING TO THE AXIS (TJP, TJU, OR TJV).  THE NU
# TJETLAW ASSUMES WILL BE USED AS INDICATED BY THE SETTING OF NUMBERT FOR THE U- OR V-AXIS.  TW
# ASSUMED FOR THE P-AXIS ALTHOUGH FOUR JETS WILL BE FIRED WHEN FIREFCT IS MORE NEGATIVE THAN -4
# (FIREFCT IS THE DISTANCE TO A SWITCH CURVE IN THE PHASE PLANE) AND A LONG FIRING IS CALLED FO
#
# IN ORDER TO AVOID SCALING DIFFICULTIES, SIMPLE ALGORITHMS TAGGED RUFLAW1, -2 AND -3 ARE RESOR
# ERROR AND/OR ERROR RATE ARE LARGE.
#
# CALLING SEQUENCE:
#               TC      TJETLAW         # (MUST BE IN JASK)
#       OR
#               INHINT                  # (MUST BE IN JASK)
#               TC      IBNKCALL
#               CADR    TJETLAW
#               RELINT
#
# EXIT:         RETURN TO Q.
#
# INPUT:
#       FROM THE CALLER:  E, EDOT, AXISCTR, SENSETYP, TJP, -U, -V.
#       FROM 1/ACCONT:  48 ERASABLES BEGINNING AT BLOCKTOP (INCLUDING FLAT, ZONE3LIM AND ACCSWU
#
# OUTPUT:
#       TJP, -U OR -V, NUMBERT (DAPTEMP5), FIREFCT (DAPTEMP3).
#
# DEBRIS:
#       A, L, Q, E, EDOT, DAPTEMP1-6, DAPTEMP1-4.
```

```
#
# ALARM:  NONE

                BANK    17
                SETLOC  DAPS2
                BANK
                EBANK=  TJP
# Page 1461
                COUNT*  $$/DAPTJ

TJETLAW         EXTEND                  # SAVE Q FOR RETURN.
                QXCH    HOLDQ

# SET INDEXERS TO CORRESPOND TO THE AXIS AND TO THE SIGN OF EDOT

                INDEX   AXISCTR         # AXISDIFF(-1)=NO OF LOCATIONS BET P AND U
                CAF     AXISDIFF        # AXISDIFF(0)=0
                TS      ADRSDIF1        # AXISDIFF(+1)=NO OF LOCATIONS BET V AND U

                CAE     EDOT            # IF EDOT NEGATIVE, PICK UP SET OF VALUES
                EXTEND                  #       THAT ALLOW USE OF SAME CODING AS FOR
                BZMF    NEGEDOT         #       POSITIVE EDOT.
                CAE     ADRSDIF1        # SET A SECOND INDEXER WHICH MAY BE
                TS      ADRSDIF2        #       MODIFIED BY A DECISION FOR MAX JETS.
                CAF     SENSOR          # FOR POSITIVE EDOT, ROTSENSE IS
                TCF     SETSENSE        #       INITIALIZED POSITIVE.

NEGEDOT         CS      E               # IN ORDER FOR NEG EDOT CASE TO USE CODING
                TS      E               #       OF POS EDOT, MUST MODIFY AS FOLLOWS:
                CS      EDOT            #       1. COMPLEMENT E AND EDOT.
                TS      EDOT            #       2. SET SENSE OF ROTATION TO NEGATIVE
                CAF     BIT1            #          (REVERSED LATER IF NECESSARY).
                ADS     ADRSDIF1        #       3. INCREMENT INDEXERS BY ONE SO THAT
                TS      ADRSDIF2        #          THE PROPER PARAMETERS ARE ACCESSED
                CS      SENSOR
SETSENSE        TS      ROTSENSE

# TEST MAGNITUDE OF E (ATTITUDE ERROR, SINGLE-PRECISION, SCALED AT PI RADIANS):
#       IF GREATER THAN (OR EQUAL TO) PI/16 RADIANS, GO TO THE SIMPLIFIED TJET ROUTIN
#       IF LESS THAN PI/16 RADIANS, RESCALE TO PI/4

                CAE     E               # PICK UP ATTITUDE ERROR FOR THIS AXIS
                EXTEND
                MP      BIT5            # SHIFT RIGHT TEN BITS:  IF A-REGISTER IS
                CCS     A               #       ZERO, RESCALE AND TEST EDOT.
                TCF     RUFLAW2
```

```
                TCF     SCALEE
                TCF     RUFLAW1
SCALEE          CAF     BIT13           # ERROR IS IN L SCALED AT PI/16.  RESCALE
                EXTEND                  #       IT TO PI/4 AND SAVE IT.
                MP      L
                TS      E

# TEST MAGNITUDE OF EDOT (ERROR RATE SCALED AT PI/4 RADIANS/SECOND)
#       IF GREATER THAN (OR EQUAL TO) PI/32 RADIANS/SECOND, GO TO THE SIMPLIFIED TJET ROUTINE.
#       IF LESS THAN PI/32 RADIANS/SECOND, THEN RESCALE TO PI/32 RADIANS/SECOND.

                CAE     EDOT            # PICK UP SINGLE-PRECISION ERROR-RATE
# Page 1462
                EXTEND                  # FOR THIS AXIS=
                MP      BIT4            # SHIFT RIGHT ELEVEN BITS, IF THE A-REG IS
                EXTEND                  # ZERO, THEN RESCALE AND USE FINELAW.
                BZF     SCALEDOT
                TCF     RUFLAW3

# *** FINELAW STARTS HERE ***

SCALEDOT        LXCH    EDOT            # EDOT IS SCALED AT PI/32 RADIANS/SECOND.

                CAE     EDOT            # COMPUTE (EDOT)(EDOT)
                EXTEND
                SQUARE                  # PRODUCT SCALED AT PI(2)/2(10) RAD/SEC.
                EXTEND
                MP      BIT13           # SHIFT RIGHT TWO BITS TO RESCALE TO EDOTSQ
                TS      EDOTSQ          #       TO PI(2)/2(8) RAD(2)/SEC(2).

ERRTEST         CCS     E               # DOES BIG ERROR (THREE DEG BEYOND THE
                AD      -3DEG           # DEADBAND) REQUIRE MAXIMUM JETS?
                TCF     +2
                AD      -3DEG
                EXTEND
                INDEX   ADRSDIF1
                SU      FIREDB
                EXTEND
                BZMF    SENSTEST        # IF NOT:  ARE UNBALANCED JETS PREFERRED?
MAXJETS         CAF     TWO             # IF YES:  INCREMENT ADDRESS LOCATOR AND
                ADS     ADRSDIF2        #          SET SWITCH FOR JET SELECT LOGIC TO 4.
                CAF     FOUR            #          (ALWAYS DO THIS FOR P-AXIS)
                TCF     TJCALC
SENSTEST        CCS     SENSETYP        # DOES TRANSLATION PREFER MIN JETS.
                TCF     TJCALC          # YES.  USE MIN-JET PARAMETERS
                TCF     MAXJETS         # NO.  GET THE MAX-JET PARAMETERS.
```

```
TJCALC          TS      NUMBERT         # SET TO +0,1,4 FOR (U,V-AXES) JET SELECT.

# BEGINNING OF TJET CALCULATIONS:

                CS      EDOTSQ          # SCALED AT PI(2)/2(8).
                EXTEND
                INDEX   ADRSDIF2
                MP      1/ANET1         # .5/ACC SCALED AT 2(6)/PI SEC(2)/RADIAN.
                INDEX   ADRSDIF1
                AD      FIREDB          # DEADBAND SCALED AT PI/4 RADIAN.
                EXTEND
                SU      E               # ATTITUDE ERROR SCALED AT PI/4 RADIAN.
                TS      FIREFCT         # -E-.5(EDOTSQ)/ACC-DB AT PI/4 RADIAN.
                EXTEND
                BZMF    ZON1,2,3

ZONE4,5         INDEX   ADRSDIF1
                CAE     1/ACOAST        # .5/ACC SCALED AT 2(6)/PI WHERE
# Page 1463
                EXTEND                  # ACC = MAX(AMIN, AOS-).
                MP      EDOTSQ          # SCALED AT PI/2(8).
                AD      E               # SCALED AT PI/4
                INDEX   ADRSDIF1
                AD      COASTDB         # SCALED AT PI/4 POS. FOR NEG. INTERCEPT.
                EXTEND                  # TEST E+.5(EDOTSQ)/ACC+DB AT PI/4 RADIAN.
                BZMF    ZONE5           # IF FUNCTION NEGATIVE, FIND TJET.
                                        # IF FUNCTION POSITIVE, IN ZONE 4.

# ZONE 4 IS THE COAST REGION.  HOWEVER, IF THE JETS ARE ON AND DRIVING TOWARD
#       A. THE AXIS WITHIN + OR - (DB + FLAT) FOR DRIFTING FLIGHT, OR
#       B. THE USUAL TARGET PARABOLA FOR POWERED FLIGHT
# THEN THE THRUSTERS ARE KEPT ON.

ZONE4           INDEX   AXISCTR         # IS THE CURRENT VALUE IN TJET NON-ZERO
                CS      TJETU           #       WITH SENSE OPPOSITE TO EDOT,
                EXTEND                  #       (I.E., ARE JETS ON AND FIRING TOWARD
                MP      ROTSENSE        #       THE DESIRABLE STATE).
                EXTEND
                BZMF    COASTTJ         # NO.  COAST.

JETSON          CCS     FLAT            # YES.  IS THIS DRIFTING OR POWERED FLIGHT?
                TCF     DRIFT/ON        # DRIFTING.  GO MAKE FURTHER TEST.

                CS      FIREFCT         # POWERED (OR ULLAGE).  CAN TARGET PARABOLA
                INDEX   ADRSDIF1        #       BE REACHED FROM THIS POINT IN THE
                AD      AXISDIST        #       PHASE PLANE?
```

```
                EXTEND
                BZMF    COASTTJ         # NO. SET TJET = 0.
                TC      Z123COMP        # YES.  CALCULATE TJET AS THOUGH IN ZONE 1
                CAE     FIREFCT         #       AFTER COMPUTING THE REQUIRED
                TCF     ZONE1           #       PARAMETERS.

DRIFT/ON        INDEX   ADRSDIF1        # CAN TARGET STRIP OF AXIS BE REACHED FROM
                CS      FIREDB          #       THIS POINT IN THE PHASE PLANE?
                DOUBLE
                AD      FIREFCT
                EXTEND
                BZMF    +3
COASTTJ         CAF     ZERO            # NO.  SET TJET = 0.
                TCF     RETURNTJ

                TC      Z123COMP        # YES. CALCULATE TJET AS THOUGH IN ZONE 2
                TCF     ZONE2,3         #       OR 3 AFTER COMPUTING REQUIRED VALUES.

ZONE5           TS      L               # TEMPORARILY STORE FUNCTION IN L.
                CCS     ROTSENSE        # MODIFY ADRSDIF2 FOR ACCESSING 1/ANET2
                TCF     +4              # AND ACCFCTZ5, WHICH MUST BE PICKED UP
                TC      CCSHOLE         # FROM THE NEXT LOWER REGISTER IF THE
                CS      TWO             # (ACTUAL) ERROR RATE IS NEGATIVE.
# Page 1464
                ADS     ADRSDIF2

        +4      CAE     L
                EXTEND
                INDEX   ADRSDIF2        # TTOAXIS AND HH ARE THE PARAMETERS UPON
                MP      ACCFCTZ5        #       WHICH THE APPROXIMATIONS TO TJET ARE
                DDOUBL                  #       ABASED.
                DDOUBL
                DXCH    HH              # DOUBLE PRECISION H SCALED AT 8 SEC(2).
                INDEX   ADRSDIF2
                CAE     1/ANET2         # SCALED AT 2(7)/PI SEC(2)/RAD.
                EXTEND
                MP      EDOT            # SCALED AT PI/2(5)
                TS      TTOAXIS         # SCALED AT 4 SEC.

# TEST WHETHER TJET GREATER THAN 50 MSEC.

                EXTEND
                MP      -.05AT2         # H - .05 TTOAXIS - .00125 G.T. ZERO
                AD      HH              #       (SCALED AT 8 SEC(2) ).
                AD      NEG2
                EXTEND
```

```
                BZMF    FORMULA1

# TEST WHETHER TJET GREATER THAN 150 MSEC.

                CAE     TTOAXIS
                EXTEND
                MP      -.15AT2         # H - .15 TTOAXIS - .01125 G.T. ZERO
                AD      HH              #       (SCALED AT 8 SEC(2) )
                AD      -.0112A8
                EXTEND
                BZMF    FORMULA2

# IF TJET GREATER THAN 150 MSEC, ASSIGN IT VALUE OF 250 MSEC, SINCE THIS
# IS ENOUGH TO ASSURE NO SKIP NEXT CSP (100 MSEC).

FULLTIME        CAF     BIT11           # 250 MSEC SCALED AT 4 SEC.

# RETURN TO CALLING PROGRAM WITH JET TIME SCALED AS TIME6 AND SIGNED.

RETURNTJ        EXTEND                  # ALL BRANCHES TERMINATE HERE WITH TJET
                MP      ROTSENSE        #       (SCALED AT 4 SEC) IN THE ACCUMULATOR
                INDEX   AXISCTR         # ROTSENSE APPLIES SIGN AND CHANGES SCALE.
                TS      TJETU
                EXTEND
                INDEX   AXISCTR
                MP      ACCSWU          # SET SWITCH FOR JET SELECT IF ROTATION IS
                CAE     L
                EXTEND                  #       IN A SENSE FOR WHICH 1/ACCS HAS FORCE
                BZMF    +3              #       A MAX-JET CALCULATION.
                CAF     FOUR
# Page 1465
                TS      NUMBERT
                TC      HOLDQ           # RETURN VIA SAVED Q.

# TJET = H/(.025 + TTOAXIS)     FOR TJET LESS THAN 50 MSEC.

FORMULA1        CS      -.025AT4        # .025 SEC SCALED AT 4.
                AD      TTOAXIS         # SCALED AT 4 SECONDS.
                DXCH    HH              # STORE DENOMINATOR IN FIRST WORD OF H,
                EXTEND                  #       WHICH NEED NOT BE PRESERVED.  PICK UP
                DV      HH              #       DP H AND DIVIDE BY DENOMINATOR.
                EXTEND
                MP      BIT14           # RESCALE TJET FROM 2 TO USUAL 4 SEC.
                TCF     CHKMINTJ        # CHECK THAT TJET IS NOT LESS THAN MINIMUM

# TJET = (H + .00375)/(0.1 + TTOAXIS)   FOR TJET GREATER THAN 50 MSEC.
```

```
FORMULA2        EXTEND
                DCA     .00375A8        # .00375 SEC(2) SCALED AT 8.
                DAS     HH              # STORE NUMERATOR IN DP H, WHICH NEED NOT
                                        #       BE PRESERVED.
                CAE     TTOAXIS         # SCALED AT 4 SEC.
                AD      .1AT4           # 0.1 SEC SCALED AT 4.
                DXCH    HH              # STORE DENOMINATOR IN FIRST WORD OF H,
                EXTEND                  #       WHICH NEED NOT BE PRESERVED.  PICK UP
                DV      HH              #       DP NUMERATOR AND DIVIDE BY DENOMINATOR
                EXTEND
                MP      BIT14           # RESCALE TJET FROM 2 TO USUAL 4 SEC.
                TCF     RETURNTJ        # END SUBROUTINE.

# SUBROUTINIZED COMPUTATIONS REQUIRED FOR ALL ENTRIES INTO CODING FOR ZONES 1, 2, AND 3.
# REACHED BY TC FROM 3 POINTS IN TJETLAW.

Z123COMP        CS      ROTSENSE        # USED IN RETURNTJ SECTION TO RESCALE TJET
                TS      ROTSENSE        #       AS TIME6 AND GIVE IT PROPER SIGN.
                CAE     EDOT            # SCALED AT PI/2(5) RAD/SEC.
                EXTEND
                INDEX   ADRSDIF2
                MP      1/ANET1         # SCALED AT 2(7)/PI SEC(2)/RAD.
                TS      TTOAXIS         # STORE TIME-TO-AXIS SCALED AT 4 SECONDS.
                AD      -TJMAX
                EXTEND                  # IS TIME TO AXIS LESS THAN 150 MSEC.
                BZMF    +2
                TCF     FULLTIME        # NO. FIRE JETS, DO NOT CALCULATE TJET.
                RETURN                  # YES.  GO ON TO FIND TJET

ZON1,2,3        TC      Z123COMP        # SUBROUTINIZED PREPARATION FOR ZONE1,2,3.

# IF THE (NEG) DISTANCE BEYOND PARABOLA IS LESS THAN FLAT, USE SPECIAL
# LOGIC TO ACQUIRE MINIMUM IMPULSE LIMIT CYCLE.  DURING POWERED FLIGHT
# Page 1466
# OR ULLAGE, FLAT = 0

                CAE     FIREFCT         # SCALED AT PI/4 RAD.
                AD      FLAT
                EXTEND
                BZMF    ZONE1           # NOT IN SPECIAL ZONES.

# FIRE FOR AXIS OR, IF CLOSE, FIRE MINIMUM IMPULSE.  IF ON AXIS, COAST.

ZONE2,3         CS      ZONE3LIM        # HEIGHT OF MIN-IMPULSE ZONE SET BY 1/ACCS
                AD      TTOAXIS         #       35 MSEC IN DRIFTING FLIGHT
```

```
                EXTEND                  #       ZERO WHEN TRYING TO ENTER GTS CONTROL
                BZMF    ZONE3
ZONE2           CAE     TTOAXIS         # FIRE TO AXIS.
                TCF     RETURNTJ
ZONE3           CCS     EDOT            # CHECK IF EDOT IS ZERO.
                CAF     BIT6            # FIRE A ONE-JET MINIMUM IMPULSE.
                TCF     RETURNTJ        # TJET = +0.
                TC      CCSHOLE         # CANNOT BE BECAUSE NEG EDOT COMPLEMENTED.
                TCF     RETURNTJ        # TJET = +0.

ZONE1           EXTEND
                INDEX   ADRSDIF1
                SU      AXISDIST        # SCALED AT PI/4 RAD.
                EXTEND
                INDEX   ADRSDIF2
                MP      ACCFCTZ1        # SCALED AT 2(7)/PI SEC(2)/RAD.
                DDOUBL
                DDOUBL
                DXCH    HH              # DOUBLE PRECISION H SCALED AT 8 SEC(2).

# TEST WHETHER TOTAL TIME REQUIRED GREATER THAN 150 MSEC:
#                           2                                   2
#       IS .5(.150 - TTOAXIS)  - H  NEGATIVE (SCALED AT 8 SECONDS )

                CAE     TTOAXIS         # TTOAXIS SCALED AT 4 SECONDS.
                AD      -TJMAX          # -.150 SECOND SCALED AT 4.
                EXTEND
                SQUARE
                EXTEND
                SU      HH              # HIGH WORD OF H SCALED AT 8 SEC(2).
                EXTEND
                BZMF    FULLTIME        # YES.  NEED NOT CALCULATE TJET.

# TEST WHETHER TIME BEYOND AXIS GREATER THAN 50 MSEC TO DETERMINE WHICH APPROXIMATION

                CAE     HH
                AD      NEG2
                EXTEND
                BZMF    FORMULA3

# Page 1467
# TJET = H/0.1 + TTOAXIS + .0375        FOR APPROXIMATION OVER MORE THAN 50 MSEC.

                CAF     .1AT2           # STORE .1 SEC SCALED AT 2 FOR DIVISION.
                DXCH    HH              # DP H SCALED AT 8 SEC(2) NEED NOT BE
                EXTEND                  #       PRESERVED.
```

```
                DV      HH              # QUOTIENT SCALED AT 4 SECONDS.
                AD      TTOAXIS         # SCALED AT 4 SEC.
                AD      .0375AT4        # .0375 SEC SCALED AT 4.
                TCF     RETURNTJ        # END COMPUTATION.

# TJET - H/.025 + TTOAXIS       FOR APPROXIMATION OVER LESS THAN 50 MSEC.

FORMULA3        CS      -.025AT2        # STORE +.25 SEC SCALED AT 2 FOR DIVISION
                DXCH    HH              # PICK UP DP H AT 8, WHICH NEED NOT BE
                EXTEND                  #       PRESERVED.
                DV      HH              # QUOTIENT SCALED AT 4 SECONDS.
                AD      TTOAXIS         # SCALED AT 4 SEC.

# IF COMPUTED JET TIME IS LESS THAN TJMIN, TJET IS SET TO ZERO.
# MINIMUM IMPULSES REQUIRED IN ZONE 3 ARE NOT SUBJECT TO THIS CONSTRAINT, NATURALLY.

CHKMINTJ        AD      -TJMIN          # IS COMPUTED TIME LESS THAN THE MINIMUM.
                EXTEND
                BZMF    COASTTJ         # YES, SET TIME TO ZERO.
                AD      TJMIN           # NO, RESTORE COMPUTED TIME.
                TCF     RETURNTJ        # END COMPUTATION.

# Page 1468
# *** ROUGHLAW ***
#
# BEFORE ENTRY TO RUFLAW:
#       1. INDEXERS ADRSDIF1 AND ADRSDIF2 ARE SET ON BASIS OF AXIS, AND SIGN OF EDOT.
#       2. IF EDOT WAS NEGATIVE, E AND EDOT ARE ROTATED INTO UPPER HALF-PLANE AND ROTSENSE IS M
#       3. E IS SCALED AT PI RADIANS AND EDOT AT PI/4 RAD/SEC.
#          (EXCEPT THE RUFLAW3 ENTRY WHEN E IS AT PI/4)
#
# RUFLAW1:      ERROR MORE NEGATIVE THAN PI/16 RAD.  FIRE TO A RATE OF 6.5 DEG/SEC (IF JET TIME
# RUFLAW2:      ERROR MORE POSITIVE THAN PI/16 RAD.  FIRE TO AN OPPOSING RATE OF 6.5 DEG/SEC.
# RUFLAW3:      ERROR RATE GREATER THAN PI/32 RAD/SEC AND ERROR WITHIN BOUNDS.  COAST IF BELOW

RUFLAW1         CS      RUFRATE         # DECREMENT EDOT BY .1444 RAD/SEC AT PI/4
                ADS     EDOT            #       WHICH IS THE TARGET RATE
                EXTEND
                BZMF    SMALRATE        # BRANCH IF RATE LESS THAN TARGET.
                TC      RUFSETUP        # REVERSE ROTSENSE AND INDICATE MAX JETS.
                CAE     EDOT            # PICK UP DESIRED RATE CHANGE.

RUFLAW12        EXTEND                  # COMPUTE TJET
                INDEX   ADRSDIF2        #       = (DESIRED RATE CHANGE)/(2-JET ACCEL.)
                MP      1/ANET1 +2
                AD      -1/8            # IF TJET, SCALED AT 32 SEC, EXCEEDS
```

```
                EXTEND                  #       4 SECONDS, SET TJET TO TJMAX.
                BZMF    +2
                TCF     FULLTIME
                EXTEND
                BZF     FULLTIME
                AD      BIT12           # RESTORE COMPUTED TJET TO ACCUMULATOR
                DAS     A
                DAS     A
                DAS     A               # RESCALED TJET AT 4 SECONDS.
                TCF     CHKMINTJ        # RETURN AS FROM FINELAW.

SMALRATE        TC      RUFSETUP +2     # SET NUMBERT AND FIREFCT FOR MAXIMUM JETS
                CCS     ROTSENSE
                CAF     ONE             # MODIFY INDEXER TO POINT TO 1/ANET
                TCF     +2              #       CORRESPONDING TO THE PROPER SENSE.
                CAF     NEGONE
                ADS     ADRSDIF2

                CS      EDOT            # (.144 AT PI/4 - EDOT) = DESIRED RATE CHNG.
                TCF     RUFLAW12

RUFLAW2         TC      RUFSETUP        # REVERSE ROTSENSE AND INDICATE MAX JETS.
                CAF     RUFRATE
                AD      EDOT            # (.144 AT PI/4 + EDOT) = DESIRED RATE CHNG.
                TS      A               # IF OVERFLOW SKIP, FIRE FOR FULL TIME.
                TCF     RUFLAW12        # OTHERWISE, COMPUTE JET TIME.
                TCF     FULLTIME

# Page 1469
RUFLAW3         TC      RUFSETUP        # EXECUTE COMMON RUFLAW SUBROUTINE.
                INDEX   ADRSDIF1
                CS      FIREDB          # CALCULATE DISTANCE FROM SWITCH CURVE
                AD      E               #       1/ANET1*EDOT*EDOT +E - FIREDB = 0
                EXTEND                  #               SCALED AT 4 PI RADIANS
                MP      BIT11
                XCH     EDOT
                EXTEND
                SQUARE
                EXTEND
                INDEX   ADRSDIF1
                MP      1/ANET1 +2
                AD      EDOT
                EXTEND
                BZMF    COASTTJ         # COAST IF BELOW IT.
                TCF     FULLTIME        # FIRE FOR FULL PERIOD IF ABOVE IT.
```

```
# SUBROUTINE USED IN ALL ENTRIES TO ROUGHLAW.

RUFSETUP        CS      ROTSENSE        # REVERSE ROTSENSE WHEN ENTER HERE.
                TS      ROTSENSE
        +2      CAF     FOUR            # REQUIRE MAXIMUM (2) JETS IN U,V-AXES.
                TS      NUMBERT
                CAF     NEGMAX          # SUGGEST MAXIMUM (4) JETS IN P-AXIS.
                TS      FIREFCT
                TC      Q

# CONSTANTS FOR TJETLAW

                DEC     -16             # AXISDIFF(INDEX) = NUMBER OF REGISTERS
AXISDIFF        DEC     +0              #       BETWEEN STORED 1/ACCS PARAMETERS FOR
                DEC     16              #       THE INDEXED AXIS AND THE U-AXIS.
SENSOR          OCT     14400           # RATIO OF TJET SCALING WITHIN TJETLAW
                                        #       (4 SEC) TO SCALING FOR T6 (10.24 SEC).
-3DEG           DEC     -.06667         # -3.0 DEGREES SCALED AT 45.
-.0112A8        DEC     -.00141         # -.01125 SEC(2) SCALED AT 8.
.1AT4           DEC     .025            # 0.1 SECOND SCALED AT 4.
.1AT2           DEC     .05             # .1 SEC SCALED AT 2.
.0375AT4        DEC     .00938          # .0375 SEC SCALED AT 4.
-.025AT2        DEC     -.0125          # -.025 SEC SCALED AT 2.
-.025AT4        DEC     -.00625
-.05AT2         DEC     -.025
-.15AT2         DEC     -.075
.00375A8        2DEC    .00375 B-3

-TJMAX          DEC     -.0375          # LARGEST CALCULATED TIME.  .150 SEC AT 4.
TJMIN           DEC     .005            # SMALLEST ALLOWABLE TIME.  .020 SEC AT 4.
-TJMIN          DEC     -.005
RUFRATE         DEC     .1444           # CORRESPONDS TO TARGET RATE OF 6.5 DEG/S.
```

Uses A 80, COUNT 142, D 226, DAPS2 63, DV 241, EBANK 80, EDOT 209, H 177, I 206, IT 185, L 80, LONG 157, MODE 145, P 188, Q 80, RAD 219, SAVE 191, STATE 138, TC 169, TIME6 80, V 229, and ZONE 163.

4.37 kalman filter

2571 ⟨*kalman filter* 2571⟩≡ (2041)

```
# Page 1470
⟨Page LM1470 2572⟩
# Page 1471
⟨Page LM1471 2573⟩
```

2572 ⟨*Page LM1470* 2572⟩≡ (2571 2732)

```
                EBANK=  NO.UJETS
                BANK    16
                SETLOC  DAPS1
                BANK

                COUNT*  $$/DAP

RATELOOP        CA      TWO
                TS      DAPTEMP6
                DOUBLE
                TS      Q
                INDEX   DAPTEMP6
                CCS     TJP
                TCF     +2
                TCF     LOOPRATE
                AD      -100MST6
                EXTEND
                BZMF    SMALLTJU
                INDEX   DAPTEMP6
                CCS     TJP
                CA      -100MST6
                TCF     +2
                CS      -100MST6
                INDEX   DAPTEMP6
                ADS     TJP
                INDEX   DAPTEMP6
                CCS     TJP
                CS      -100MS          # 0.1 AT 1
                TCF     +2
                CA      -100MS
LOOPRATE        EXTEND
                INDEX   DAPTEMP6
                MP      NO.PJETS
                CA      L
                INDEX   DAPTEMP6
                TS      DAPTEMP1        # SIGNED TORQUE AT 1 JET-SEC FOR FILTER
                EXTEND
                MP      BIT10           # RESCALE TO 32; ONE BIT ABOUT 2 JET-MSEC
                EXTEND
                BZMF    NEGTORK
STORTORK        INDEX   Q               # INCREMENT DOWNLIST REGISTER.
                ADS     DOWNTORK        #       NOTE:  NOT INITIALIZED; OVERFLOWS.

                CCS     DAPTEMP6
                TCF     RATELOOP +1
```

```
                TCF     ROTORQUE
SMALLTJU        CA      ZERO
                INDEX   DAPTEMP6
                XCH     TJP
                EXTEND
```

Uses COUNT 142, DAPS1 63, EBANK 80, L 80, and Q 80.

2573 ⟨*Page LM1471* 2573⟩≡ (2571 2732)

```
                MP      ELEVEN          # 10.24 PLUS
                CA      L
                TCF     LOOPRATE
ROTORQUE        CA      DAPTEMP2
                AD      DAPTEMP3
                EXTEND
                MP      1JACCR
                TS      JETRATER
                CS      DAPTEMP3
                AD      DAPTEMP2
                EXTEND
                MP      1JACCQ
                TS      JETRATEQ
                TCF     BACKP
-100MST6        DEC     -160

NEGTORK         COM
                INCR    Q
                TCF     STORTORK
```

Uses L 80 and Q 80.

4.38 trim gimbal cntrol system

2574 ⟨*trim gimbal cntrol system* 2574⟩≡ (2041 2823)

```
# Page 1472
                BANK    21
                EBANK=  QDIFF
                SETLOC  DAPS4
                BANK

                COUNT*  $$/DAPGT

# CONTROL REACHES THIS POINT UNDER EITHER OF THE FOLLOWING TWO CONDITIONS ONCE THE DE
# AUTOPILOT ARE BOTH ON:
#       A) THE TRIM GIMBAL CONTROL LAW WAS ON DURING THE PREVIOUS Q,R-AXIS TIME5 INTE
#          INITIALIZATION WAS SET FOR TRIM GIMBAL CONTROL AND THIS IS THE FIRST PASS)
#       B) THE Q,R-AXES RCS AUTOPILOT DETERMINED THAT THE VEHICLE WAS ENTERING (OR HA
#          ZONE WITH A SMALL OFFSET ANGULAR ACCELERATION.
# GTS IS THE ENTRY TO THE GIMBAL TRIM SYSTEM FOR CONTROLLING ATTITUDE ERRORS AND RATE

GTS             CAF     NEGONE          # MAKE THE NEXT PASS THROUGH THE DAP BE
                TS      COTROLER        #       THROUGH RCS CONTROL,
                CAF     FOUR            #       AND ENSURE THAT IT IS NOT A SKIP.
                TS      SKIPU
                TS      SKIPV

                CAF     TWO
                TS      INGTS           # SET INDICATOR OF GTS CONTROL POSITIVE.
                TS      QGIMTIMR        # SET TIMERS TO 200 MSEC TO AVOID BOTH
                TS      RGIMTIMR        # RUNAWAY AND INTERFERENCE BY NULLING.

# THE DRIVE SETTING ALGORITHM
#
#       DEL = SGN(OMEGA + ALPHA*ABS(ALPHA)/(2*K))
#                                                       2               1/2
#       NEGUSUM = ERROR*K + ALPHA*(DEL*OMEGA + ALPHA /(3*K)) + DEL*K   (DEL*OMEGA + A
#
#       DRIVE = -SGN(NEGUSUM)

                CA      SR              # SAVE THE SR.  SHIFT IT LEFT TO CORRECT
                AD      A               # FOR THE RIGHT SHIFT DUE TO EDITING.
                TS      SAVESR

GTSGO+DN        CAF     TWO             # SET INDEXER FOR R-AXIS CALCULATIONS.
                TCF     GOQTRIMG +1

GOQTRIMG        CAF     ZERO            # SET INDEXER FOR Q-AXIS CALCULATIONS
```

```
                TS      QRCNTR
# Page 1473
# RSB 2009 ----------------------------------------------------------------------
# Everything between this line and the similar line below was simply filled-in
# as-is from Luminary 131, and then verified to assemble to the proper binary
# values.  This area is blank on the Luminary 099 print-out, as if the
# printer ribbon had run out.
                INDEX   QRCNTR          # AOS SCALED AT PI/2
                CA      AOSQ
                EXTEND
                MP      BIT2            # RESCALE AOS TO PI/4
                EXTEND
                BZF     GTSQAXIS -3     # USE FULL SCALE FOR LARGER AOS ESTIMATES.

                INDEX   A
                CS      LIMITS          # LIMITS +1 CONTAINS NEGMAX.
                XCH     L               # LIMITS -1 CONTAINS POSMAX.

                CCS     QRCNTR          # PICK UP RATE FOR THIS AXIS.  RATE CELLS
                INDEX   A               # USE ADJACENT, NOT SEPARATED.  AT PI/4
                CA      EDOTQ
GTSQAXIS        DXCH    WCENTRAL

                INDEX   QRCNTR          # COLLECT K FOR THIS AXIS
                CA      KQ
                TS      KCENTRAL

                EXTEND                  # CONTROL AUTHORITY ZERO.  AVOID DRIVING
                BZF     POSDRIVE +1     # ENGINE BELL TO THE STOPS.

                INDEX   QRCNTR          # QDIFF, RDIFF ARE STORED IN D.P.
                CAE     QDIFF

ALGORTHM        EXTEND                  # Q(R)DIFF IS THETA (ERROR) SCALED AT PI.
                MP      KCENTRAL        # FORM K*ERROR AT PI(2)/2(8), IN D.P.
                LXCH    K2THETA
                EXTEND
                MP      BIT5            # RESCALE TO 4*PI(2)
                DXCH    K2THETA
                EXTEND
                MP      BIT5            # FIRST TERM OF NEGUSUM IN K2THETA.
                ADS     K2THETA +1      # NO CARRY NEEDED       D.P. AT 4*PI(2)

                CS      ACENTRAL        # FORM ALPHA(2)/(2*K) AT 16*PI, IN D.P.,
                EXTEND                  # LIMITING QUOTIENT TO AVOID OVERFLOW.
                MP      BIT14           # -ALPHA/2 IN A, SCALED AT PI/4
```

```
                EXTEND
                MP      ACENTRAL        # -ALPHA(2)/2 IN A,L, SCALED AT PI(2)/16)
                AD      KCENTRAL
                EXTEND
                BZMF    HUGEQUOT        # K-ALPHA(2)/2 SHOULD BE PNZ FO DIVISION

                EXTEND
                DCS     A               # ALPHA(2)/2 - K
                AD      KCENTRAL
# RSB 2009 ----------------------------------------------------------------
                EXTEND
                DV      KCENTRAL        # HIGH ORDER OF QUOTIENT.
                XCH     A2CNTRAL
                CA      L               # SHIFT UP THE REMAINDER.
                LXCH    7               # ZERO LOW-ORDER DIVIDEND.
                EXTEND
# Page 1474
                DV      KCENTRAL
                XCH     A2CNTRAL +1     # QUOTIENT STORED AT 16*PI, D.P.
                TCF     HAVEQUOT

HUGEQUOT        CA      POSMAX
                TS      L
                DXCH    A2CNTRAL        # LIMITED QUOTIENT STORED AT 16*PI, D.P.

HAVEQUOT        CA      WCENTRAL
                EXTEND
                MP      BIT9            # RESCALE OMEGA AT 16*PI IN D.P.
                DXCH    K2CNTRAL        # LOWER WORD OVERLAYS OMEGA IN WCENTRAL

                EXTEND
                DCA     K2CNTRAL
                DXCH    FUNCTION

                CA      ACENTRAL        # GET ALPHA*ABS(ALPHA)/(2*K)
                EXTEND
                BZMF    +4

                EXTEND
                DCA     A2CNTRAL
                TCF     +3

                EXTEND
                DCS     A2CNTRAL

                DAS     FUNCTION        # OMEGA + ALPHA*ABS(ALPHA)/(2*K) AT 16*PI
```

```
                CCS     FUNCTION        # DEL = +1 FOR FUNCT1 GREATER THAN ZERO.
                TCF     POSFNCT1        # OTHERWISE DEL = -1
                TCF     +2
                TCF     NEGFNCT1

                CCS     FUNCTION +1     # USE LOW ORDER WORD SINCE HIGH IS ZERO
POSFNCT1        CAF     BIT1
                TCF     +2
NEGFNCT1        CS      BIT1
                TS      DEL

                CCS     DEL             # REPLACE OMEGA BY DEL*OMEGA
                TCF     FUNCT2          # POSITIVE DEL VALUE.  PROCEED.
                TCF     DEFUNCT
                TCF     NEGFNCT2

DEFUNCT         TS      K2CNTRAL
                TS      K2CNTRAL +1
                TCF     FUNCT2

# Page 1475
NEG1/3          DEC     -.33333

NEGFNCT2        EXTEND
                DCS     K2CNTRAL
                DXCH    K2CNTRAL

FUNCT2          EXTEND
                DCA     A2CNTRAL
                DAS     K2CNTRAL        # DEL*OMEGA + ALPHA(2)/(2*K) AT 16*PI, D.P.

FUNCT3          CA      A2CNTRAL
                EXTEND
                MP      NEG1/3
                DXCH    A2CNTRAL
                CA      L
                EXTEND
                MP      NEG1/3
                ADS     A2CNTRAL +1
                TS      L
                TCF     +2              # A2CNTRAL NOW CONTAINS -ALPHA(2)/(6*K),
                ADS     A2CNTRAL        # SCALED AT 16*PI, IN D.P.

                EXTEND
                DCA     K2CNTRAL        # DEL*OMEGA + ALPHA(2)/(3*K) IN A2CNTRAL,
```

```
                DAS     A2CNTRAL        # SCALED AT 16*PI, D.P.

                CA      A2CNTRAL
                EXTEND
                MP      ACENTRAL
                DAS     K2THETA
                CA      A2CNTRAL +1
                EXTEND
                MP      ACENTRAL        # ACENTRAL MAY NOW BE OVERLAID.
                ADS     K2THETA +1
                TS      L
                TCF     +2              # TWO TERMS OF NEGUSUM ACCUMULATED, SO FAR
                ADS     K2THETA         # SCALED AT 4*PI(2), IN D.P.

GETROOT         CA      K2CNTRAL        # K*(DEL*OMEGA + ALPHA(2)/(2*K)) IS THE
                EXTEND                  # TERM FOR WHICH A SQUARE ROOT IS NEEDED.
                MP      KCENTRAL        # K AT PI/2(8)
                DXCH    FUNCTION
                CA      K2CNTRAL +1
                EXTEND
                MP      KCENTRAL
                ADS     FUNCTION +1
                TS      L
                TCF     +2
                ADS     FUNCTION        # DESIRED TERM IN FUNCTION, AT PI(2)/16
# Page 1476
                CCS     DEL
                TCF     RSTOFGTS
                TCF     NEGUSUM
                TCF     NEGATE
                TCF     NEGUSUM

NEGATE          EXTEND
                DCS     K2CNTRAL
                DXCH    K2CNTRAL
                TCF     RSTOFGTS

                BANK    16
                EBANK=  NEGUQ
                SETLOC  DAPS1
                BANK

# THE WRCHN12 SUBROUTINE SETS BITS 9,10,11,12 OF CHANNEL 12 ON THE BASIS OF THE CONTE
# THE NEGATIVES OF THE DESIRED ACCELERATION CHANGES.  ACDT+C12 SETS Q(R)ACCDOT TO REF
#
# WARNING:  ACDT+C12 AND WRCHN12 MUST BE CALLED WITH INTERRUPT INHIBITED.
```

```
BGIM            OCTAL   07400
CHNL12          EQUALS  ITEMP6
ACDT+C12        CS      NEGUQ
                EXTEND                  # GIMBAL DRIVE REQUESTS.
                MP      ACCDOTQ
                LXCH    QACCDOT
                CS      NEGUR
                EXTEND
                MP      ACCDOTR
                LXCH    RACCDOT

                CCS     NEGUQ
                CAF     BIT10
                TCF     +2
                CAF     BIT9
                TS      CHNL12

                CCS     NEGUR
                CAF     BIT12
                TCF     +2
                CAF     BIT11
                ADS     CHNL12          # (STORED RESULT NOT USED AT PRESENT)

                CS      BGIM
                EXTEND
                RAND    CHAN12
                AD      CHNL12
                EXTEND
                WRITE   CHAN12
# Page 1477
                CS      CALLGMBL        # TURN OFF REQUEST FOR ACDT+C12 EXECUTION.
                MASK    RCSFLAGS
                TS      RCSFLAGS

                TC      Q               # RETURN TO CALLER.

                BANK    21
                EBANK=  QDIFF
                SETLOC  DAPS4
                BANK

# Page 1478
# SUBROUTINE TIMEGMBL:  MOD 0, OCTOBER 1967, CRAIG WORK
#
# TIMEGMBL COMPUTES THE DRIVE TIME NEEDED FOR THE TRIM GIMBAL TO POSITION THE DESCENT ENGINE NO
```

```
# THE OFFSET ANGULAR ACCELERATION ABOUT THE Q (OR R) AXIS.  INSTEAD OF USING AOSQ(R),
# SCALED AT PI/8.  FOR EACH AXIS, THE DRIVE TIME IS COMPUTED AS ABS(ALPHA/ACCDOT).  A
# ALPHA OR ACCDOT OR A ZERO QUOTIENT TURNS OFF THE GIMBAL DRIVE IMMEDIATELY.  OTHERWI
# DRIVING IN THE CORRECT DIRECTION.  THE Q(R)GIMTIMR IS SET TO TERMINATE THE DRIVE AN
# IS STORED TO REFLECT THE NEW ACCELERATION DERIVATIVE.  NEGUQ(R) WILL CONTAIN +1,+0,
# WHICH IS NEGATIVE, ZERO, OR POSITIVE.
#
# INPUTS:       AOSQ,AOSR, SCALED AT P1/2, AND ACCDOTQ, ACCDOTR AT PI/2(7).     PI/2(
#
# OUTPUTS:      NEW GIMBAL DRIVE BITS IN CHANNEL 12, NEGUQ, NEGUR, QACCDOT, AND RACCD
#               Q(R)GIMTIMR WILL BE SET TO TIME AND TERMINATE GIMBAL DRIVE(S).
#
# DEBRIS:       A, L, Q, ITEMPS 2, 3, 6, AND RUPTREG2 AND ACDT+C12 DEBRIS.
#
# EXITS:        VIA TC Q.
#
# ALARMS, ABORTS:  NONE.
#
# SUBROUTINES:  ACDT+C12, IBNKCALL
#
# WARNING:      THIS SUBROUTINE WRITES INTO CHANNEL 12 AND USES THE ITEMPS.  THEREFOR
#               INTERRUPT INHIBITED.
#
# ERASABLE STORAGE CONFIGURATION (NEEDED BY THE INDEXING METHODS):
#       NEGUQ           ERASE   +2              # NEGATIVE OF Q-AXIS GIMBAL DRIVE
#       (SPWORD)        EQUALS  NEGUQ +1        # ANY S.P. ERASABLE NUMBER, NOW THRST
#       NEGUR           EQUALS  NEGUQ +2        # NEGATIVE OF R-AXIS GIMBAL DRIVE
#       ACCDOTQ         ERASE   +2              # Q-JERK TERM SCALED AT PI/2(7) RAD/S
#       (SPWORD)        EQUALS  ACCDOTQ +1      # ANY S.P. ERASABLE NUMBER NOW QACCDO
#       ACCDOTR         EQUALS  ACCDOTQ +2      # R-JERK TERM SCALED AT PI/2(7) RAD/S
#                                               # ACCDOTQ, ACCDOTR ARE MAGNITUDES.
#       AOSQ            ERASE   +4              # Q-AXIS ACC., D.P. AT PI/2 R/SEC(2)
#       AOSR            EQUALS  AOSQ +2         # R-AXIS ACCELERATION SCALED AT PI/2

QRNDXER         EQUALS  ITEMP6
OCT23146        OCTAL   23146                   # DECIMAL .6
NZACCDOT        EQUALS  ITEMP3

TIMEGMBL        CAF     ONE                     # INITIALZE ALLOWGTS.
                TS      ALLOWGTS

                CAF     TWO                     # SET UP LOOP FOR R AXIS.
                LXCH    Q                       # SAVE RETURN ADDRESS.
                LXCH    RUPTREG2
# Page 1479
                TCF     +2
```

```
TIMQGMBL        CAF     ZERO                    # NOW DO THE Q-AXIS
                TS      QRNDXER
                INDEX   QRNDXER
                CA      ACCDOTQ                 # ACCDOT IS PRESUMED TO BE AT PI/2(7).
                EXTEND
                BZMF    TGOFFNOW                # IS ACCDOT LESS THAN OR EQUAL TO 0?
                TS      NZACCDOT                # NO.  STORE NON-ZERO, POSITIVE ACCDOT.

ALPHATRY        INDEX   QRNDXER
                CS      AOSQ
                EXTEND
                BZF     TGOFFNOW                # IS ALPHA ZERO?

                TS      Q                       # SAVE A COPY OF -AOS.
                EXTEND                          # NO.  RESCALE FOR TIMEGMBL USE.
                MP      OCT23146                # OCTAL 23146 IS DECIMAL .6
                AD      Q                       # -1.6*AOS AT PI/2 = -.4*AOS AT PI/8
                TS      L                       # WAS THERE OVERFLOW?
                TCF     SETNEGU                 # NO.  COMPUTE DRIVE TIME.

                CS      A                       # RECOVER -SGN(AOS) IN THE A REGISTER.
                INDEX   QRNDXER                 # YES.  START DRIVE WITHOUT WAITLIST.
                XCH     NEGUQ
                TCF     NOTALLOW                # KNOCK DOWN THE ALLOWGTS FLAG.

SETNEGU         EXTEND
                BZMF    POSALPH

                COM
                TS      ITEMP2                  # STORE -ABS(.4*AOS) SCALED AT PI/8.
                CS      BIT1
                TCF     POSALPH +2
POSALPH         TS      ITEMP2                  # STORE -ABS(.4*AOS) SCALED AT PI/8.
                CA      BIT1
        +2      INDEX   QRNDXER                 # SGN(AOS) INTO NEGU
                TS      NEGUQ                   # STORE SGN(ALPHA) AS NEGU

                CA      NZACCDOT
                EXTEND
                MP      BIT12                   # 2*ACCDOT, SCALED AT PI/8.
                AD      ITEMP2                  # -ABS(ALPHS) + 2*ACCDOT, AT PI/8.
                EXTEND
                BZMF    NOTALLOW                # IS DRIVE TIME MORE THAN TWO SECONDS?
                CS      ITEMP2                  # NO.  COMPUTE DRIVE TIME.
                EXTEND                          # ABS(ALPHA) AT PI/8.
                MP      OCT00240                # DECIMAL 10/1024
```

```
                EXTEND                          # QUOTIENT IS DRIVE TIME AT WAITLIST.
                DV      NZACCDOT                # ABS(ALPHA)/ACCDOT AT 2(14)/100
# Page 1480
                EXTEND
                BZF     TGOFFNOW                # DRIVE TIME MUST BE GREATER THAN ZER

                TCF     DRIVEON

TGOFFNOW        CAF     ZERO                    # TURN OFF GIMBAL NOW.
                INDEX   QRNDXER
                TS      NEGUQ

                TCF     DONEYET

NOTALLOW        CAF     OCT31
                INDEX   QRNDXER
                TS      QGIMTIMR
                CAF     ZERO                    # DRIVE TIME IS MORE THAN 2 SECONDS,
                TS      ALLOWGTS                # DO NOT PERMIT FURTHER GTS ATTITUDE-
                                                # CONTROL UNTIL AOSTASK APPROVES.
                TCF     DONEYET                 # NO WAITLIST CALL IS MADE.

DRIVEON         INDEX   QRNDXER
                TS      QGIMTIMR                # CHOOSE Q OR R AXIS.

DONEYET         CCS     QRNDXER
                TCF     TIMQGMBL

                DXCH    RUPTREG3                # PROTECT IBNKCALL ERASABLES.  ACDT+C
                DXCH    ITEMP2                  # LEAVES ITEMPS2,3 ALONE.

                TC      IBNKCALL                # TURN OFF CHANNEL BITS, SET Q(R)ACCD
                CADR    ACDT+C12

                DXCH    ITEMP2                  # RESTORE ERASABLES FOR IBNKCALL.
                DXCH    RUPTREG3

                TC      RUPTREG2                # RETURN TO CALLER.

OCT00240        OCTAL   00240                   # DECIMAL 10/1024

# Page 1481
# THE FOLLOWING SECTION IS A CONTINUATION OF THE TRIM GIMBAL CONTROL FROM THE LAST GT
# IS COMPUTED FOR EACH AXIS (Q,R), .707*DEL*FUNCTION(3/2) + K2THETA = NEGUSUM.  NEW D
#
# THE SUBROUTINE GTSQRT ACCEPTS A DOUBLE PRECISION VALUE IN FUNCTION, FUNCTION +1 AND
```

```
# SQUARE ROOT OF THE FOURTEEN MOST SIGNIFICANT BITS OF THE ARGUMENT.  ALSO, THE CELL SHFTFLAG C
# EXPONENT S, SUCH THAT THE SQUARE ROOT (RETURNED IN THE A REGISTER) MUST BE SHIFTED RIGHT (MUL
# POWER (-S)) IN ORDER TO BE THE TRUE SQUARE ROOT OF THE FOURTEEN MOST SIGNIFICANT BITS OF FUNC
# SQUARE ROOT ERROR IS NOT MORE THAN 2 IN THE 14TH SIGNIFICANT BIT.  CELLS CLOBBERED ARE A, L,
# HALFARG, SCRATCH, SR, FUNCTION, FUNCTION +1.  GTSQRT IS CALLED BY TC GTSQRT AND RETURNS VIA T
# ZERO OR NEGATIVE ARGUMENTS YIELD ZERO FOR SQUARE ROOTS.

GTSQRT          CCS     FUNCTION
                TCF     GOODARG         # FUNCTION IS POSITIVE.  TAKE SQUARE ROOT.
                TCF     +2              # HIGH ORDER WORD IS ZERO.  TRY THE LOWER.
                TCF     ZEROOT          # NEGATIVE.  USE ZERO FOR 1/2 POWER.

                CA      FUNCTION +1
                EXTEND
                BZMF    ZEROOT

                TCF     ZEROHIGH        # PROCEED.
ZEROOT          CA      ZERO
                TS      SHFTFLAG
                TC      Q

ZEROHIGH        XCH     FUNCTION        # 14 MOST SIGNIFICANT BITS ARE IN THE
                XCH     FUNCTION +1     # LOWER WORD.  EXCHANGE THEM.
                CA      SEVEN
                TCF     GOODARG +1

GOODARG         CA      ZERO
                TS      SHFTFLAG
                CA      TWELVE          # INITIALIZE THE SCALING LOOP.
                TS      ININDEX
                TCF     SCALLOOP

SCALSTRT        CA      FUNCTION
                TCF     SCALDONE

MULBUSH         CA      NEG2            # IF ARG IS NOT LESS THAN 1/4, INDEX IS
                ADS     ININDEX         # ZERO, INDICATING NO SHIFT NEEDED.
                EXTEND                  # BRANCH IF ARG IS NOT LESS THAN 1/4.
                BZMF    SCALSTRT        # OTHERWISE COMPARE ARG WITH A REFERENCE
                                        # WHICH IS 4 TIMES LARGER THAN THE LAST.
SCALLOOP        CS      FUNCTION
                INDEX   ININDEX
                AD      BIT15           # REFERENCE MAGNITUDE LESS OR EQUAL TO 1/4
                EXTEND
                BZMF    MULBUSH         # IF ARG IS NOT LESS THAN REFERENCE, GO
                                        # AROUND THE MULBERRY BUSH ONCE MORE.
```

```
# Page 1482
                INDEX   ININDEX
                CA      BIT15           # THIS IS THE SCALE MAGNITUDE
                XCH     HALFARG         # 2**(-ININDEX) IS THE SHIFT DIVISOR.
                EXTEND                  # RESCALE ARGUMENT.
                DCA     FUNCTION
                EXTEND
                DV      HALFARG
                                        # ININDEX AND SHFTFLAG PRESERVE INFO FOR
                                        # RESCALING AFTER ROOT PROCESS.
SCALDONE        EXTEND
                QXCH    FUNCTION +1     # SAVE Q FOR RETURN
                EXTEND
                MP      BIT14
                TS      HALFARG
                MASK    BIT13
                CCS     A
                CA      OCT11276
                AD      ROOTHALF        # INITIAL GUESS IS ROOT 1/2 OR POSMAX
                TC      ROOTCYCL
                TC      ROOTCYCL
                TC      ROOTCYCL
                TC      FUNCTION +1

# ************************************************************************

RSTOFGTS        TC      GTSQRT
PRODUCT         XCH     K2CNTRAL
                EXTEND
                MP      K2CNTRAL
                DXCH    K2CNTRAL
                EXTEND                  #               THE PRODUCT OF
                MP      L               #  1/2                   2       1/2
                ADS     K2CNTRAL +1     # K   *(DEL*OMEGA + ALPHA /(2*K))
                TS      L               #                     AND
                TCF     +2              #                       2
                ADS     K2CNTRAL        # DEL*(DEL*OMEGA + ALPHA /(2*K)) NOW IN
                                        # K2CNTRAL

DOSHIFT         CA      ININDEX
                EXTEND                  # MULTIPLY IN THE FACTOR 2(-S), RETURNED
                MP      BIT14           # BY THE GTSQRT SUBROUTINE
                ADS     SHFTFLAG
                EXTEND
                BZF     ADDITIN
                INDEX   SHFTFLAG
```

```
                CA      BIT15
# Page 1483
                XCH     K2CNTRAL
                EXTEND
                MP      K2CNTRAL
                DAS     K2THETA
                XCH     K2CNTRAL
                EXTEND
                MP      K2CNTRAL +1
                ADS     K2THETA +1
                TS      L
                TCF     +2
                ADS     K2THETA

                TCF     NEGUSUM

ADDITIN         EXTEND
                DCA     K2CNTRAL
                DAS     K2THETA         # NO ADD IN THE K2THETA TERM.
NEGUSUM         CCS     K2THETA         # TEST SIGN OF HIGH ORDER PART.
                TCF     NEGDRIVE
                TCF     +2
                TCF     POSDRIVE

                CCS     K2THETA +1      # SIGN TEST FOR LOW ORDER PART.
NEGDRIVE        CA      BIT1
                TCF     +2              # STOP GIMBAL DRIVE FOR A ZERO NEGUSUM.
POSDRIVE        CS      BIT1
                TS      L               # SAVE FOR DRIVE REVERSAL TEST.
                INDEX   QRCNTR
                XCH     NEGUQ

                EXTEND
                MP      L               # MULTIPLY OLD NEGU AND NEW NEGU.
                CCS     L
                TCF     LOUPE           # NON-ZERO GIMBAL DRIVE BEING CONTINUED.

                TCF     ZEROLOUP        # NO REVERSAL PROBLEM HERE.

                TCF     REVERSAL        # NON-ZERO GIMBAL DRIVE BEING REVERSED.
                TCF     ZEROLOUP        # NO REVERSAL PROBLEM HERE.

REVERSAL        INDEX   QRCNTR          # A ZERO-DRIVE PAUSE IS NEEDED HERE.  ZERO
                TS      QACCDOT         # IS IN A REGISTER FROM CCS ON (-1).
                INDEX   QRCNTR
                CS      GMBLBITA
```

```
                EXTEND
                WAND    CHAN12

ZEROLOUP        CS      RCSFLAGS        # SET UP REQUEST FOR ACDT+C12 CALL.
                MASK    CALLGMBL
                ADS     RCSFLAGS
# Page 1484
LOUPE           CCS     QRCNTR          # HAVE BOTH AXES BEEN PROCESSED?
                TCF     GOQTRIMG        # NO.  DO Q AXIS NEXT.

                CA      SAVESR          # RESTORE THE SR
                TS      SR

GOCLOSE         EXTEND                  # TERMINATE THE JASK.
                DCA     CLOSEADR
                DTCB

                EBANK=  AOSQ
CLOSEADR        2CADR   CLOSEOUT        # TERMINATE THE JASK.

TWELVE          EQUALS  OCT14
ROOTHALF        OCTAL   26501           # SQUARE ROOT OF 1/2
GMBLBITA        OCTAL   01400           # INDEXED WRT GMBLBITB  DO NOT MOVE *******
OCT11276        OCTAL   11276           # POSMAX -- ROOTHALF
GMBLBITB        OCTAL   06000           # INDEXED WRT GMBLBITA  DO NOT MOVE *******

# SUBROUTINE ROOTCYCL:  BY CRAIG WORK, 3 APRIL 68
#
# ROOTCYCL IS A SUBROUTINE WHICH EXECUTES ONE NEWTON SQUARE ALGORITHM ITERATION.  THE
# SQUARE ROOT IS PRESUMED TO BE IN THE A REGISTER AND ONE-HALF THE SQUARE IS TAKEN FR
# TO THE SQUARE ROOT IS RETURNED IN THE A REGISTER.  DEBRIS:  A, L, SR, SCRATCH.  ROO
# LOCATION (LOC) BY A TC ROOTCYCL, AND RETURNS (TC Q) TO LOC +1.
#
# WARNING:  IF THE INITIAL GUESS IS NOT GREATER THAN THE SQUARE, DIVIDE OR ADD OVERFL

ROOTCYCL        TS      SCRATCH         # STORE X
                TS      SR              # X/2 NOW IN SR
                CA      HALFARG         # ARG/2 IN THE A REG
                ZL                      # PREPARE FOR DIVISION
                EXTEND
                DV      SCRATCH         # (ARG/X)/2
                AD      SR              # (X + ARG/X)/2 IN THE A REG
                TC      Q
```

Uses A 80, CHAN12 87, COUNT 142, D 226, DAPS1 63, DAPS4 63, DEL 232, DIFF 226, DV 241,

EBANK 80, FACTOR 226, IT 185, ITEMP2 138, ITEMP3 138, ITEMP6 138, L 80, LOC 145, OMEGA 232, P 188, Q 80, RAD 219, RCSFLAGS 200, RUPTREG2 138, RUPTREG3 138, S2 85, SAVE 191, SR 80, TC 169, THETA 148, TIME5 80, and ZONE 163.

4.39 aostask and aosjob

2587 ⟨*aostask and aosjob* 2587⟩≡ (2041)

⟨*Page LM1485* 2588⟩
⟨*Page LM1486* 2590⟩
⟨*Page LM1487* 2592⟩
⟨*Page LM1488* 2594⟩
⟨*Page LM1489* 2596⟩
⟨*Page LM1490* 2598⟩
⟨*Page LM1491* 2599⟩
⟨*Page LM1492* 2600⟩
⟨*Page LM1493* 2601⟩
⟨*Page LM1494* 2603⟩
⟨*Page LM1495* 2605⟩
⟨*Page LM1496* 2606⟩
⟨*Page LM1497* 2607⟩
⟨*Page LM1498* 2609⟩
⟨*Page LM1499* 2611⟩
⟨*Page LM1500* 2613⟩
⟨*Page LM1501* 2615⟩
⟨*Page LM1502* 2617⟩
⟨*Page LM1503* 2619⟩
⟨*Page LM1504* 2621⟩
⟨*Page LM1505* 2623⟩
⟨*Page LM1506* 2624⟩

2588 ⟨*Page LM1485* 2588⟩≡ (2587 2643)

```
# PROGRAM NAME:         1/ACCS
# PROGRAM WRITTEN BY:   BOB COVELLI AND MIKE HOUSTON
# LAST MODIFICATION:    FEB. 14, 1969 BY G. KALAN
#
# PROGRAM DESCRIPTION:
#       1/ACCS PROVIDES THE INTERFACE BETWEEN THE GUIDANCE PROGRAMS AND THE DIGITAL A
#       CHANGE IN THE MASS OF THE VEHICLE, IN THE DEADBAND SELECTED, IN THE VEHICLE C
#       DOCKED), AND DURING A FRESH START OR A RESTART, 1/ACCS IS CALLED TO COMMUNICA
#
#       THE INPUTS TO 1/ACCS ARE MASS, ACCELERATION (ABDELV), DEADBAND (DB), OFFSET A
#       STAGE VERIFY BIT (CHAN30, BIT2), DOCKED BIT (DAPBOOLS, BIT13), DRIFT BIT (DAP
#       BIT14), AND SURFACE FLAG (FLAGWRDB, BIT8), AND CH5MASK.
#
#       1/ACCS COMPUTES THE JET ACCELERATIONS (1JACC, 1JACCQ, 1JACCR) AS FUNCTIONS OF
#       FORMED BY RESOLVING 1JACCQ AND 1JACCR.  IN THE DESCENT CASE, THE DESCENT ENGI
#       COMPUTED AS A FUNCTION OF MASS.  THE RATE OF CHANGE OF ACCELERATION DUE TO RO
#       ACCDOTR) IS ALSO COMPUTED IN THE DESCENT CASE.
#
#       AFTER THE ABOVE COMPUTATIONS, THE PROGRAM 1/ACCONT COMPUTES THE RECIPROCAL NE
#       AND V AXES (2 JETS FOR P-AXIS, BOTH 1 AND 2 JETS FOR U AND V AXES), AND THE F
#       THE P, U, AND V AXES.  THE ACCELERATION FUNCTIONS (ACCFCTZ1 AND ACCFCTZ5) ARE
#       FIRE AND COAST DEADBANDS AND AXISDIST ARE COMPUTED FOR EACH AXIS.  FLAT AND Z
#       MINIMUM IMPULSE ZONE, ARE COMPUTED.  1/ACCONT ALSO SETS ACCSWU AND ACCSWV, WH
#       IS NOT SUFFICIENT TO PRODUCE MINIMUM ACCELERATION.  AT THE COMPLETION OF 1/AC
#
# SUBROUTINES CALLED:
#       TIMEGMBL
#       MAKECADR
#       ROT45DEG
#
# CALLING SEQUENCE:
#               TC      BANKCALL        # (1/ACCS MUST BE CALLED BY BANKCALL)
#               CADR    1/ACCS
#
# NORMAL EXIT:  VIA BANKJUMP
#
# ALARM AND EXIT MODES:  NONE
#
# INPUT/OUTPUT:  SEE PROGRAM DESCRIPTION.
#
# DEBRIS:
#       ALL OF THE EXECUTIVE TEMPORARY REGISTERS, EXCEPT FIXLOC AND OVFIND, AND THE C
#
# RESTRICTIONS:
#       1/ACCS MUST BE CALLED BY BANKCALL
```

```
#       EBANK IS SET TO 6, BUT NOT RESTORED.
```

Uses A 80, BANKSET 145, CHAN30 87, EBANK 80, FIXLOC 140, L 80, MASS 200, MPAC 145, OVFIND 140, P 188, RESTART 57, TC 169, V 229, and ZONE 163.

2590 ⟨*Page LM1486* 2590⟩≡ (2587 2643)

```
                BANK    20
                SETLOC  DAPS3
                BANK

                COUNT*  $$/DAPAO

                EBANK=  AOSQ

# ENTRY IS THROUGH 1/ACCJOB OR 1/ACCSIT WHEN 1/ACCS IS TO BE DONE AS A SEPARATE NOVAC
# IT IS POSSIBLE FOR MORE THAN ONE OF THESE JOBS TO BE SET UP CONCURRENTLY.  HOWEVER,
# NEWJOB, A SECOND MANIFESTATION CANNOT BE STARTED UNTIL THE FIRST IS COMPLETED.

1/ACCSET        CAF     ZERO            # ENTRY FROM FRESH START/RESTART CODING.
                TS      AOSQ            #       NULL THE OFFSET ESTIMATES FOR 1/ACCS.
                TS      AOSR
                TS      ALPHAQ          #       NULL THE OFFSET ESTIMATES FOR DOWNLIS
                TS      ALPHAR

1/ACCJOB        TC      BANKCALL        # 1/ACCS ASSUMES ENTRY VIA BANKCALL.
                CADR    1/ACCS  +2      # SKIP EBANK SETTING.

                TC      ENDOFJOB

1/ACCS          CA      EBANK6          # ***** EBANK SET BUT NOT RESTORED *****
                TS      EBANK

                TC      MAKECADR        # SAVE RETURN SO THAT BUF2 MAY BE USED
                TS      ACCRETRN

# DETERMINE MASS OF THE LEM.

                CA      DAPBOOLS        # IS THE CSM DOCKED
                MASK    CSMDOCKD
                TS      DOCKTEMP        # STORE RECORD OF STATE IN TEMP (MPAC +3).
                CCS     A
                CS      CSMMASS         #       DOCKED:  LEMMAS = MASS - CSMMASS
                AD      MASS            #       LEM ALONE:  LEMMASS = MASS
                TS      LEMMASS

# ON THE BASIS OF APSFLAG:
#       SET THE P-AXIS RATE COMMAND LIMIT FOR 2-JET/2-JET CONTROL
#       SET MPAC, WHICH INDICATES THE PROPER SET OF COEFFICIENTS FOR THE LEM-ALONE F
#       ENSURE THAT THE LEM MASS VALUE IS WITHIN THE ACCEPTABLE RANGE
```

```
INHINT
CAE     FLGWRD10        # DETERMINE WHETHER STAGED.
MASK    APSFLBIT
EXTEND
BZF     DPSFLITE
```

Uses A 80, BUF2 142, COMMAND 169, COUNT 142, CSMMASS 200, DAPS3 63, EBANK 80, F 238, FLGWRD10 133, IT 185, LEMMASS 200, MASS 200, MPAC 145, NEWJOB 138, P 188, RANGE 179, RESTART 57, SAVE 191, STATE 138, TC 169, and TEMP 191.

2592 ⟨*Page LM1487* 2592⟩≡ (2587 2643)

```
                CS      POSMAX          # ASCENT (OR ON LUNAR SURFACE)
                TS      -2JETLIM        # ALWAYS 2 JETS FOR P-AXIS RATE COMMAND
                CAF     OCT14           # INITIALIZE INDEX AT 12.
                TS      MPAC
                CS      LEMMASS         # CHECK IF MASS TOO HIGH.  CATCH STAGING.
                AD      HIASCENT
                EXTEND
                BZMF    MASSFIX
                CS      LEMMASS         # CHECK IF MASS TOO LOW.  THIS LIMITS THE
                AD      LOASCENT        #       DECREMENTING BY MASSMON.
                EXTEND
                BZMF    F(MASS)

MASSFIX         ADS     LEMMASS         # STORE THE VIOLATED LIMIT AS LEMMASS.
                ZL                      #       ALSO CORRECT TOTAL MASS, ZEROING THE
                CCS     DOCKTEMP        #       LOW-ORDER WORD.
                CAE     CSMMASS         #               DOCKED:  MASS = LEMMASS + CSM
                AD      LEMMASS         #               LEM ALONE:  MASS = LEMMASS
                DXCH    MASS
                TCF     F(MASS)

DPSFLITE        CS      BIT10           # FOUR JETS FOR P-AXIS RATE COMMAND ERRORS
                TS      -2JETLIM        #       EXCEEDING 1.4 DEG/SEC (SCALED AT 45)
                CAF     SIX             # INITIALIZE INDEX AT 6.
                TS      MPAC
                CS      LEMMASS         # CHECK IF MASS TOO HIGH.  SHOULD NEVER
                AD      HIDESCNT        #       OCCUR EXCEPT PERHAPS BEFORE THE PAD
                EXTEND                  #       LOAD IS DONE.
                BZMF    MASSFIX
                CS      LEMMASS         # CHECK IF MASS TOO LOW.  THIS LIMITS THE
                AD      LODESCNT        #       DECREMENTING BY MASSMON.
                AD      HIASCENT
                EXTEND
                BZMF    F(MASS)
                TCF     MASSFIX

# COMPUTATION OF FUNCTIONS OF MASS

F(MASS)         RELINT
                CCS     DOCKTEMP
                TCF     DOCKED          # DOCKED:  USE SEPARATE COMPUTATION.
                CA      TWO
STCTR           TS      MPAC    +1      # J=2,1,0 FOR 1JACCR,1JACCQ,1JACC

                CS      TWO
```

```
                ADS     MPAC            # JX=10,8,6 OR 4,2,0 TO INDEX COEFS.

  STCTR1        CAE     LEMMASS
                INDEX   MPAC
                AD      INERCONC
                TS      MPAC    +2      # MASS + C
```

Uses COMMAND 169, CSMMASS 200, F 238, LEMMASS 200, MASS 200, MPAC 145, and P 188.

2594 ⟨*Page LM1488* 2594⟩≡ (2587 2643)

```
                EXTEND
                INDEX   MPAC
                DCA     INERCONA
                EXTEND
                DV      MPAC    +2
                INDEX   MPAC
                AD      INERCONB
                INDEX   MPAC    +1      # 1JACC(J)=A(JX)/(MASS+C(JX) + B(JX)
                TS      1JACC           # 1JACC(-1)=L,PVT-CG  SCALED AT 8 FEET

                CCS     MPAC    +1
                TCF     STCTR
                TCF     COMMEQS
                TCF     LRESC

# COEFFQ AND COEFFR ARE COMPUTED IN THIS SECTION.  THEY ARE USED TO RESOLVE Q-R COMPO
# U AND V COMPONENTS (SEE ROT-TOUV SECTION).

COMMEQS         CS      1JACCR
                AD      1JACCQ
                EXTEND
                BZMF    BIGIQ
                EXTEND                  # EPSILON IS A MEASURE OF COUPLING AND IS
                DV      1JACCQ          # DEFINED=1-IQ/IR FOR IR GREATER THAN IQ.
                TS      EPSILON         # THE COMPUTED EXPRESSION IS EQUIVALENT
                AD      -EPSMAX
                EXTEND
                BZMF    GOODEPS1
                CS      -EPSMAX
                TS      EPSILON         # EPSILON IS LIMITED TO A MAX. OF .42265
GOODEPS1        CA      EPSILON
                EXTEND
                MP      0.35356
                AD      .7071
                TS      COEFFR          # IN THIS CASE WHERE IR IS GREATER THAN
                CS      POSMAX          # IQ, COEFFQ=-.707(1+.5EPSILON)(1-EPSILON)
                AD      EPSILON         # AND COEFFR=.707(1+.5EPSILON)
                EXTEND
                MP      COEFFR
                TS      COEFFQ
                TCF     JACCUV
BIGIQ           EXTEND                  # EPSILON IS DEFINED AS 1-IR/IQ FOR IQ
                DV      1JACCR          # GREATER THAN IR.  -EPSILON IS COMPUTED
                TS      -EPSILON        # RATHER THAN EPSILON FOR CONVENIENCE
                CS      -EPSILON
```

```
AD      -EPSMAX
EXTEND
BZMF    GOODEPS2
CA      -EPSMAX
TS      -EPSILON        # EPSILON IS LIMITED TO A MAX. OF .42265
```

Uses A 80, DV 241, L 80, MASS 200, MPAC 145, Q 80, and V 229.

2596 ⟨*Page LM1489* 2596⟩≡ (2587 2643)

```
GOODEPS2        CA      -EPSILON
                EXTEND
                MP      0.35356
                AD      -.7071
                TS      COEFFQ          # IN THIS CASE WHERE IQ IS GREATER THAN
                CS      -EPSILON        # IR, COEFFQ=-.707(1+.5EPSILON) AND
                AD      NEGMAX          # COEFFR=.707(1+.5EPSILON)(1-EPSILON)
                EXTEND
                MP      COEFFQ
                TS      COEFFR
JACCUV          CS      COEFFQ
                EXTEND
                MP      1JACCQ          # 1JACCQ IS SCALED AT PI/4
                TS      1JACCU          # 1JACCU USED AS TEMPORARY STORAGE
                CA      COEFFR
                EXTEND
                MP      1JACCR
                AD      1JACCU
                EXTEND
                MP      BIT14           # SCALING CHANGED FROM PI/4 TO PI/2
                TS      1JACCU
                TS      1JACCV          # SCALED AT PI/2 RADIANS/SEC(2)
                CCS     MPAC            # COMPUTE L,PVT-CG IF IN DESCENT
                CAF     ZERO            # ZERO SWITCHES AND GO TO 1/ACCONT IN
                TS      ALLOWGTS        #       ASCENT
                TCF     1/ACCONT -1

                CS      TWO
                TS      MPAC
                CS      ONE
                TS      MPAC    +1
                TCF     STCTR1

# THIS SECTION COMPUTES THE RATE OF CHANGE OF ACCELERATION DUE TO THE ROTATION OF THE
# IMPLEMENTED IN BOTH THE Y-X PLANE AND THE Z-X PLANE IS -- D(ALPHA)/DT = TL/I*D(DELT
#       T = ENGINE THRUST FORCE
#       L = PIVOT TO CG DISTANCE OF ENGINE
#       I = MOMENT OF INERTIA

LRESC           CAE     ABDELV          # SCALED AT 2(13) CM/SEC(2)
                EXTEND
                MP      MASS            # SCALED AT B+16 KGS
                TC      DVOVSUB         # GET QUOTIENT WITH OVERFLOW PROTECTION
                ADRES   GFACTM
```

```
# MASS IS DIVIDED BY ACCELERATION OF GRAVITY IN ORDER TO MATCH THE UNITS OF IXX,IYY,IZZ, WHICH
# THE RATIO OF ACCELERATION FROM PIPAS TO ACCELERATION OF GRAVITY IS THE SAME IN METRIC OR ENGI
# THAT IS UNCONVERTED.  2.20462 CONVERTS KG. TO LB.  NOW T IN IN A SCALED AT 2(14).

                EXTEND
                MP      L,PVT-CG        # SCALED AT 8 FEET.
```

Uses A 80, D 226, I 206, IXX 200, L 80, MASS 200, MPAC 145, TC 169, THRUST 85, and Z 80.

2598 ⟨*Page LM1490* 2598⟩≡ (2587 2643)

```
                INHINT
                TS      MPAC
                EXTEND
                MP      1JACCR
                TC      DVOVSUB         # GET QUOTIENT WITH OVERFLOW PROTECTION
                ADRES   TORKJET1

                TS      ACCDOTR         # SCALED AT PI/2(7)
                CA      MPAC
                EXTEND
                MP      1JACCQ
                TC      DVOVSUB         # GET QUOTIENT WITH OVERFLOW PROTECTION
                ADRES   TORKJET1

SPSCONT         TS      ACCDOTQ         # SCALED AT PI/2(7)
                EXTEND
                MP      DGBF            # .3ACCDOTQ SCALED AT PI/2(8)
                TS      KQ
                CAE     ACCDOTR         # .3ACCDOTR AT PI/2(8)
                EXTEND
                MP      DGBF
                TS      KRDAP
                EXTEND                  # NOW COMPUTE QACCDOT, RACCDOT, THE SIGNED
                READ    CHAN12          # JERK TERMS.  STORE CHANNEL 12. WITH GIMBAL
                TS      MPAC    +1      # DRIVE BITS 9 THROUGH 12 SET LOOP
                CAF     BIT2            # INDEX TO COMPUTE RACCDOT, THEN QACCDOT.
                TCF     LOOP3
                CAF     ZERO            # ACCDOTQ AND ACCDOTR ARE NOT NEGATIVE,
LOOP3           TS      MPAC            # BECAUSE THEY ARE MAGNITUDES
                CA      MPAC    +1
                INDEX   MPAC            # MASK CHANNEL IMAGE FOR ANY GIMBAL MOTION
                MASK    GIMBLBTS
                EXTEND
                BZF     ZACCDOT         # IF NONE, Q(R)ACCDOT IS ZERO.
                CA      MPAC    +1
                INDEX   MPAC            # GIMBAL IS MOVING.  IS ROTATION POSITIVE.
                MASK    GIMBLBTS +1
                EXTEND
                BZF     FRSTZERO        # IF NOT POSITIVE, BRANCH
                INDEX   MPAC            # POSITIVE ROTATION, NEGATIVE Q(R)ACCDOT.
                CS      ACCDOTQ
                TCF     STACCDOT
FRSTZERO        INDEX   MPAC            # NEGATIVE ROTATION, POSITIVE Q(R)ACCDOT.
                CA      ACCDOTQ
                TCF     STACCDOT
```

```
ZACCDOT         CAF     ZERO
STACCDOT        INDEX   MPAC
                TS      QACCDOT         # STORE Q(R)ACCDOT.
                CCS     MPAC
                TCF     LOOP3   -1      # NOW DO QACCDOT.
```

Uses CHAN12 87, MPAC 145, Q 80, and TC 169.

2599 ⟨*Page LM1491* 2599⟩≡ (2587 2643)

```
                CS      DAPBOOLS        # IS GIMBAL USABLE?
                MASK    USEQRJTS
                EXTEND
                BZF     DOWNGTS         # NO. BE SURE THE GIMBAL SWITCHES ARE DOWN
                CS      T5ADR           # YES.  IS THE DAP RUNNINT?
                AD      PAXISADR
                EXTEND
                BZF     +2
                TCF     DOWNGTS         # NO. BE SURE THE GIMBAL SWITCHES ARE DOWN
                CCS     INGTS           # YES.  IS GTS IN CONTROL?
                TCF     DOCKTEST        # YES.  PROCEED WITH 1/ACCS.
                TC      IBNKCALL        # NO. NULL OFFSET AND FIND ALLOWGTS
                CADR    TIMEGMBL

DOCKTEST        CCS     DOCKTEMP        # BYPASS 1/ACCONT WHEN DOCKED.
                TCF     1/ACCRET
                TCF     1/ACCONT
```

Uses TC 169.

2600 ⟨*Page LM1492* 2600⟩≡ (2587 2643)

```
# SUBROUTINE:   DVOVSUB
# AUTHOR:       C. WORK, MOD 0, 12 JUNE 68
# PURPOSE:      THIS SUBROUTINE PROVIDES A SINGLE-PRECISION MACHINE LANGUAGE DIVISION
#               (1) THE QUOTIENT, IF THE DIVISION WAS NORMAL.
#               (2) NEGMAX, IF THE QUOTIENT WAS IMPROPER AND NEGATIVE.
#               (3) POSMAX, IF THE QUOTIENT WAS IMPROPER AND POSITIVE OR IF THERE WAS
#               THE CALLING PROGRAM IS PRESUMED TO BE A JOB IN THE F BANK WHICH CONTA
#               THE DIVISOR FOR THIS ROUTINE MAY BE IN EITHER FIXED OR ERASABLE STORA
#               ASSUMED BETWEEN THE TWO HALVES OF THE DIVIDEND.  (THIS IS CERTAIN IF
#               RESULT OF A MULTIPLICATION OPERATION.)
# CALL SEQUENCE:        L       TC      DVOVSUB
#                       L +1    ADRES   (DIVISOR)
#                       L +2    RETURN HERE, WITH RESULT IN A,L
# INPUT:        DIVIDEND IN A,L (SIGN AGREEMENT ASSUMED), DIVISOR IN LOCATION DESIGNA
#               DIVISOR MAY BE IN THE DVOVSUB FBANK,FIXED-FIXED FBANK,EBANK 6, OR UNS
# OUTPUT:       QUOTIENT AND REMAINDER, OR POSMAX (NEGMAX), WHICHEVER IS APPROPRIATE.
# DEBRIS:       SCRATCHX,SCRATCHY,SCRATCHZ,A,L  (NOTE: SCRATCHX,Y,Z ARE EQUATED TO ME
# ABORTS OR ALARMS:  NONE
# EXITS:        TO THE CALL POINT +2.
# SUBROUTINES CALLED:  NONE.

DVOVSUB         TS      SCRATCHY        # SAVE UPPER HALF OF DIVIDEND
                TS      SCRATCHX
                INDEX   Q               # OBTAIN ADDRESS OF DIVISOR.
                CA      0
                INCR    Q               # STEP Q FOR PROPER RETURN SEQUENCE.
                INDEX   A
                CA      0               # PICK UP THE DIVISOR.
                EXTEND                  # RETURN POSMAX FOR A ZERO DIVISOR.
                BZF     MAXPLUS

                TS      SCRATCHZ        # STORE DIVISOR.

                CCS     A               # GET ABS(DIVISOR) IN THE A REGISTER.
                AD      BIT1
                TCF     ZEROPLUS
                AD      BIT1

ZEROPLUS        XCH     SCRATCHY        # STORE ABS(DIVISOR).  PICK UP TOP HALF OF
                EXTEND                  # DIVIDEND.
                BZMF    GOODNEG         # GET -ABS(DIVIDEND)
```

Uses A 80, EBANK 80, F 238, FBANK 80, L 80, MPAC 145, Q 80, SAVE 191, TC 169, and Z 80.

2601 ⟨*Page LM1493* 2601⟩≡ (2587 2643)

```
                CS      A

GOODNEG         AD      SCRATCHY        # ABS(DIVISOR) - ABS(DIVIDEND)
                EXTEND
                BZMF    MAKEMAX         # BRANCH IF DIVISION IS NOT PROPER.

                CA      SCRATCHX        # RE-ESTABLISH THE DIVIDEND
                EXTEND
                DV      SCRATCHZ        # QUOTIENT IN THE A, REMAINDER IN L.
                TC      Q               # RETURN TO CALLER.

MAKEMAX         CCS     SCRATCHX        # DETERMINE THE SIGN OF THE QUOTIENT.
                CCS     SCRATCHZ        # SCRATCHX AND SCRATCHZ ARE NON-ZERO.
                TCF     MAXPLUS
                CCS     SCRATCHZ
                CAF     NEGMAX          # +,- OR -,+
                TC      Q
MAXPLUS         CAF     POSMAX          # -,- OR +,+
                TC      Q

# COEFFICIENTS FOR THE JET ACCELERATION CURVE FITS
# THE CURVE FITS ARE OF THE FORM --
#
#       1JACC = A/(MASS + C) + B
#
# A IS SCALED AT PI/4 RAD/SEC**2 B+16KG, B IS SCALED AT PI/4 RAD/SEC**2, AND C IS SCALED AT B +
#
# THE CURVE FIT FOR L,PVT-CG IS OF THE SAME FORM, EXCEPT THAT A IS SCALED AT 8 FT B+16 KG, B IS
# AND C IS SCALED AT B+16 KG.

                2DEC    +.0410511917    # L             A               DESCENT

INERCONA        2DEC    +.0059347674    # 1JACCP        A               DESCENT

                2DEC    +.0014979264    # 1JACCQ        A               DESCENT

                2DEC    +.0010451889    # 1JACCR        A               DESCENT

                2DEC    +.0065443852    # 1JACCP        A               ASCENT

                2DEC    +.0035784354    # 1JACCQ        A               ASCENT

                2DEC    +.0056946631    # 1JACCR        A               ASCENT

                DEC     +.155044        # L             B               DESCENT
```

```
                    DEC      -.025233        # L              C                DESCENT
```

Uses `A` 80, `DV` 241, `L` 80, `MASS` 200, `Q` 80, `RAD` 219, and `TC` 169.

2603 ⟨*Page LM1494* 2603⟩≡ (2587 2643)

```
INERCONB        DEC     +.002989        # 1JACCP        B               DESCENT
INERCONC        DEC     +.008721        # 1JACCP        C               DESCENT
                DEC     +.018791        # 1JACCQ        B               DESCENT
                DEC     -.068163        # 1JACCQ        C               DESCENT
                DEC     +.021345        # 1JACCR        B               DESCENT
                DEC     -.066027        # 1JACCR        C               DESCENT

                DEC     +.000032        # 1JACCP        B               ASCENT
                DEC     -.006923        # 1JACCP        C               ASCENT
                DEC     +.162862        # 1JACCQ        B               ASCENT
                DEC     +.002588        # 1JACCQ        C               ASCENT
                DEC     +.009312        # 1JACCR        B               ASCENT
                DEC     -.023608        # 1JACCR        C               ASCENT

GIMBLBTS        OCTAL   01400
                OCTAL   01000
                OCTAL   06000
                OCTAL   04000
DGBF            DEC     0.6             # .3 SCALED AT 1/2
0.35356         DEC     0.35356         # .70711 SCALED AT 2
GFACTM          OCT     337             # 979.24/2.20462 AT B+15
.7071           DEC     .70711
-.7071          DEC     -.70711
-EPSMAX         DEC     -.42265

# CSM-DOCKED INERTIA COMPUTATIONS

DOCKED          CA      ONE             # COEFTR  = 1 FOR INERTIA COEFFICIENTS
SPSLOOP1        TS      COEFCTR         #         = 7 FOR CG COEFFICIENTS
                CA      ONE             # MASSCTR = 1 FOR CSM
                TS      MASSCTR         #         = 0 FOR LEM

                INDEX   COEFCTR
                CA      COEFF   -1      # COEFF -1 = C
                EXTEND
                MP      LEMMASS
                EXTEND
                MP      CSMMASS         # LET X = CSMMASS AND Y = LEMMASS

                INDEX   COEFCTR
                AD      COEFF           # COEFF = F
                TS      MPAC            # MPAC = C X Y + F
                TCF     +4

SPSLOOP2        TS      MASSCTR         # LOOP TWICE THROUGH HERE TO OBTAIN
```

```
EXTEND                  # MPAC = MPAC + (A X +D)X + (B Y +E)Y
DIM     COEFCTR         #                LOOP #1     LOOP #2
INDEX   COEFCTR
CA      COEFF   +2      # COEFF +2 = A OR B
EXTEND
```

Uses `A` 80, `CSMMASS` 200, `D` 226, `F` 238, `LEMMASS` 200, and `MPAC` 145.

2605 ⟨*Page LM1495* 2605⟩≡ (2587 2643)

```
                INDEX   MASSCTR
                MP      LEMMASS
                INDEX   COEFCTR
                AD      COEFF   +4      # COEFF +4 = E OR D
                EXTEND
                INDEX   MASSCTR
                MP      LEMMASS
                ADS     MPAC

                CCS     MASSCTR
                TCF     SPSLOOP2
                CCS     COEFCTR         # IF COEFCTR IS POS, EXIT FROM LOOP WITH
                TCF     +7              # CG X DELDOT = MPAC X 4 PI RAD-CM/SEC
  TORQCONS      2DEC    0.51443 B-14    # CORRESPONDS TO 500 LB-FT

                CA      MPAC
                TS      MPAC    +1      # INERTIA = (MPAC +1) X 2(38) KG-CM(2)
                CA      SEVEN
                TCF     SPSLOOP1

                CA      1JACCCON        # 1JACC=1JACCCON/MASS
                ZL
                TC      DVOVSUB
                ADRES   MASS
                TS      1JACC           # SCALED AT PI/4

                CA      POSMAX          # SET INVERSE JET ACCELERATIONS TO POSMAX,
                TS      1/ANETP         # WHICH CORRESPONDS TO ACCEL. OF 1.4 D/SS.
                TS      1/ANET2 +1
                TS      1/ANET2 +2
                TS      1/ANET2 +17D
                TS      1/ANET2 +18D
                EXTEND
                DCA     TORQCONS
                EXTEND
                DV      MPAC    +1
                INHINT
                TS      1JACCQ          # SCALED AT PI/4
                TS      1JACCR

                CA      -.7071
                TS      COEFFQ          # COEFFQ AND COEFFR ARE CHOSEN TO MAKE U-
                CA      .7071           # AND V-AXES ORTHOGONAL FOR DOCKED CASE
                TS      COEFFR
                CA      MASS            # SCALED AT 2(16) KG
```

```
                EXTEND
                MP      MPAC            # SCALED AT 4 PI RAD-CM/SEC
                EXTEND
                MP      ABDELV          # SCALED AT 2(13) CM/SEC(2)
                TC      DVOVSUB         # GET QUOTIENT WITH OVERFLOW PROTECTION
```

Uses D 226, DV 241, LEMMASS 200, MASS 200, MPAC 145, RAD 219, TC 169, and V 229.

2606 ⟨*Page LM1496* 2606⟩≡ (2587 2643)

```
                ADRES   MPAC    +1

                TS      ACCDOTR
                TCF     SPSCONT         # CONTINUE K, KSQ CALCULATIONS

1JACCCON        OCT     00167           # SCALED AT PI/4X2(16) RAD/SEC(2)-KG

#                                                2     2
# COEFFICIENTS FOR CURVE FIT OF THE FORM Z = A X  +B Y  +C X Y +D X +E Y +F

COEFF           DEC     .19518          # C  COEFFICIENT OF INERTIA
                DEC     -.00529         # F             "
                DEC     -.17670         # B             "
                DEC     -.03709         # A             "
                DEC     .06974          # E             "
                DEC     .02569          # D             "

                DEC     .20096          # C  COEFFICIENT OF CG
                DEC     .13564          # F          "
                DEC     .75704          # B          "
                DEC     -.37142         # A          "
                DEC     -.63117         # E          "
                DEC     .41179          # D          "

# ASSIGNMENT OF TEMPORARIES FOR 1/ACCS (EXCLUDING 1/ACCONT)
# MPAC, MPAC +1, MPAC +2  USED EXPLICITLY
COEFCTR         EQUALS  MPAC    +4
MASSCTR         EQUALS  MPAC    +5
SCRATCHX        EQUALS  MPAC    +4      # SCRATCH AREA FOR DVOVSUB ROUTINE.
SCRATCHY        EQUALS  SCRATCHX +1
SCRATCHZ        EQUALS  SCRATCHX +2

DOCKTEMP        EQUALS  MPAC    +3      # RECORD OF CSMDOCKED BIT OF DAPBOOLS
EPSILON         EQUALS  MPAC    +1
-EPSILON        EQUALS  EPSILON
-.1875          DEC     -.18750
```

Uses A 80, D 226, F 238, MPAC 145, RAD 219, and Z 80.

2607 ⟨*Page LM1497* 2607⟩≡ (2587 2643)

```
                BANK    20
                SETLOC  DAPS3
                BANK

                EBANK=  AOSQ

                COUNT*  $$/DAPAO

        -1      TS      INGTS           # ZERO INGTS IN ASCENT
1/ACCONT        CA      DB              # INITIALIZE DBVAL1,2,3
                EXTEND
                MP      BIT13
                TS      L               # 0.25 DB
                AD      A
                TS      DBVAL3          # 0.50 DB
                CS      DBVAL1
                AD      L
                TS      DBVAL2          # -.75 DB

GETAOSUV        INHINT
                CAE     AOSR            # COMPUTE ASOU AND AOSV BY ROTATING
                TS      L               #       AOSQ AND AOSR.
                CAE     AOSQ
                TC      IBNKCALL
                CADR    ROT-TOUV
                DXCH    AOSU

                RELINT
                CA      DAPBOOLS
                MASK    DRIFTBIT        # ZERO DURING ULLAGE AND POWERED FLIGHT.
                CCS     A               # IF DRIFTING LIGHT,
                CA      ONE             #       SET DRIFTER TO 1
                TS      DRIFTER         # SAVE TO TEST FOR DRIFTING FLIGHT LATER
                AD      ALLOWGTS        # NON-ZERO IF DRIFT OR GTS NEAR
                CCS     A
                CA      FLATVAL         # DRIFTING FLIGHT, STORE .8 IN FLAT
                TS      FLATEMP         # IN POWERED FLIGHT, STORE ZERO IN FLAT
                EXTEND
                BZF     DOPAXIS         # IF POWERED AND NO GTS, START P AXIS,
                CCS     DRIFTER         # OTHERWISE SET ZONE3LIM
                CA      ZONE3MAX        # 17.5 MS, SCALED AT 4 SECONDS.
                TS      Z3TEM

DOPAXIS         CA      1JACC           # 1JACC AT PI/4 = 2JACC AT PI/2 =
                                        # ANET AT PI/2 = ANET/ACOAST AT 2(6).
```

```
                AD      BIT9            # 1 + ANET/ACOAST AT 2(6)
                TS      FUNTEM

                CA      1JACC
```

Uses A 80, COUNT 142, DAPS3 63, EBANK 80, L 80, P 188, SAVE 191, and TC 169.

2609 ⟨*Page LM1498* 2609⟩≡ (2587 2643)

```
                TC      INVERT
                INHINT                  # P AXIS DATA MUST BE CONSISTENT
                TS      1/ANETP         # SCALED AT 2(7)/PI.
                TS      1/ANETP +1

                CS      BIT9            # -1 AT 2(6)
                EXTEND
                MP      1/ANETP         # -1/ANET AT 2(13)/PI
                EXTEND
                DV      FUNTEM          # -1/(ANET + ANET**2/ACOAST) AT 2(7)/PI
                TS      PACCFUN
                TS      PACCFUN +1

                CA      1/.03           # NO AOS FOR P AXIS, ACOAST = AMIN
                TS      1/ACOSTP
                TS      1/ACOSTP +1
                RELINT

                ZL
                CCS     DRIFTER
                DXCH    AOSU            # ZERO AOSU,V IF IN DRIFT, JUST TO BE SURE

UAXIS           CA      ZERO            # DO U AXIS COMPUTATIONS
                TS      UV              # ZERO FOR U AXIS, ONE FOR V AXIS.

BOTHAXES        TS      SIGNAOS         # CODING COMMON TO U,V AXES
                INDEX   UV
                CCS     AOSU            # PICK UP ABS(AOSU OR AOSV)
                AD      ONE             # RESTORE TO PROPER VALUE
                TCF     +3              # AND LEAVE SIGNAOS AT ZERO
                AD      ONE             # NEGATIVE, RESTORE TO PROPER VALUE
                INCR    SIGNAOS         # AND SET SIGNAOS TO ONE TO SHOW AOS NEG
                TS      ABSAOS          # SAVE ABS(AOS)
                CS      SIGNAOS
                TS      -SIGNAOS        # USED AS AN INDEX

                CA      DBVAL1          # SET DB1, DB2 TO DBVAL1 (= DB)
                TS      DBB1
                TS      DBB2

                CA      ABSAOS          # TEST MAGNITUDE OF ABS(AOS)
                AD      -.03R/S2
                EXTEND
                BZMF    NOTMUCH         # ABS(AOS) LESS THAN AMIN
BIGAOS          CCS     FLATEMP         # AGS(AOS) GREATER THAN AMIN
```

```
                TCF     SKIPDB1         # I DRIFT OR GTS, DO NOT COMPUTE DB

                CA      DBVAL1
                INDEX   -SIGNAOS
```

Uses DV 241, I 206, P 188, S2 85, SAVE 191, TC 169, and V 229.

2611 ⟨*Page LM1499* 2611⟩≡ (2587 2643)

```
                ADS     DBB2            # DB2(1) = 2 DB
                INDEX   SIGNAOS
                TS      DBB4            # DB4(3) = 1 DB
                CA      -.1875          # -.1875 PI/2 RAD/SEC(2) SCALED AT PI/2
                AD      ABSAOS          # ABSAOS IS SCALED AT PI/2
                EXTEND
                BZMF    +3
                CS      DBVAL3          # -.5 DB
                TCF     DBONE
                CS      ABSAOS
                DOUBLE
                DOUBLE
                AD      BIT14
                DOUBLE                  # 1-8 ABSAOS.  (8 IS 16/PI SCALED AT 2/PI)
                EXTEND
                MP      DB
DBONE           INDEX   SIGNAOS         # DB1(2)=(1-8 ABSAOS) DB.  IF ABSAOS IS
                TS      DBB1            # GREATER THAN .1875 THEN DB1(2) = -.5 DB
                CA      DBVAL2
                INDEX   -SIGNAOS
                TS      DBB3            # DB3(4) = -.75 DB

SKIPDB1         CA      ABSAOS          # ABS(AOS) GREATER THAN AMIN, SO IT IS
                EXTEND
                MP      BIT12
                AD      ABSAOS          # (9/8) ABSAOS.
                TC      INVERT          # ALL RIGHT TO DIVIDE
                INDEX   -SIGNAOS
                TS      1/ACOSTT +1     # 1/ACOASTPOS(NET) = 1/ABS(AOS)
                CA      1/.03
                INDEX   SIGNAOS
                TS      1/ACOSTT        # 1/ACOASTNEG(POS) = 1/AIN

                CA      ABSAOS
                AD      1JACCU
                AD      1JACCU          # 2 JACC + ABS(AOS)
                AD      BIT9            # MAXIMUM VALUE IN COMPUTATIONS
                TS      A               # TEST FOR OVERFLOW
                TCF     SKIPDB2         # NO OVERFLOW, DO NORMAL COMPUTATION

                CA      ABSAOS          # RESCALE TO PI TO PREVENT OVERFLOW
                EXTEND
                MP      BIT14
                AD      1JACCU          # 1 JACC AT PI/2 = 2JACC AT PI
                TS      ANET            # ANETPOS(NEG) MAX SCALED AT PI =
```

```
                                # ANETPOS(NEG) MAX/ACOASTNEG(POS) AT 2(7)
        AD      BIT8            # 1 + ANETPOS/ACOASTNEG AT 2(7)
        XCH     ANET            # SAVE IN ANET, WHILE PICKING UP ANET
        TC      INVERT
        EXTEND
```

Uses A 80, IT 185, RAD 219, SAVE 191, and TC 169.

2613 ⟨*Page LM1500* 2613⟩≡ (2587 2643)

```
                MP      BIT14           # SCALE 1/ANET AT 2(7)/PI
                TS      1/ANET

                CA      ACCHERE         # SET UP RETURN FROM COMPUTATION ROUTINE
                TS      ARET
                CS      BIT8            # -1 AT 2(7)
                TCF     DOACCFUN        # FINISH ACCFUN COMPUTATION

ACCHERE         TCF     ACCTHERE

NOTMUCH         TS      L               # ABS(AOS) LESS THAN AMIN, SAVE IN L
                CA      1/.03           # ACOASTPOS,NEG = AMIN
                TS      1/ACOSTT
                TS      1/ACOSTT +1

                CCS     FLATEMP
                TCF     SKIPDB2         # DO NOT COMPUTE DB IF DRIFT OR GTS

                CA      .0125RS         # AMIN/2
                AD      L               # L HAS ABS(AOS) - AMIN
                EXTEND                  # RESULT IS ABS(AOS)- AMIN/2
                BZMF    NOAOS           # ABS(AOS) LESS THAN AMIN/2

SOMEAOS         CA      DBVAL3          # AMIN/2 LT ABS(AOS) LT AMIN
                INDEX   -SIGNAOS
                TS      DBB3            # DB3(4) = DB/2
                AD      A
                INDEX   SIGNAOS
                TS      DBB4            # DB4(3) = DB
                TCF     SKIPDB2

NOAOS           CA      DBVAL1
                TS      DBB3            # DB3,4 = DB
                TS      DBB4

SKIPDB2         CA      ABSAOS          # ANETPOS(NEG) MAX = 2 JACC + ABS(AOS)
                AD      1JACCU
                AD      1JACCU
                TS      ANET            # CANNOT OVERFLOW HERE
CL1/NET+        TC      DO1/NET+        # COMPUTE 1/ANET, ACCFUN

ACCTHERE        INDEX   -SIGNAOS
                TS      Z5TEM   +2      # STORE ACCFUN IN TEMPORARY BUFFER
                CA      1/ANET
                INDEX   -SIGNAOS
```

```
TS      1/ATEM2 +2      # STORE 1/ANET IN TEMPORARY BUFFER

CA      ABSAOS          # SEE IF OVERFLOW IN MIN CASE
AD      1JACCU
```

Uses `A` 80, `L` 80, `SAVE` 191, and `TC` 169.

2615 ⟨*Page LM1501* 2615⟩≡ (2587 2643)

```
                AD      BIT9            # MAXIMUM POSSIBLE VALUE
                TS      A               # OVERFLOW POSSIBLE BUT REMOTE
                TCF     +2
                CA      POSMAX          # IF OVERFLOW, TRUNCATE TO PI/2
                AD      -.03R/S2        # RESTORE TO CORRECT VALUE
                TS      ANET
                TC      DO1/NET+        # COMPUTE 1/ANET, ACCFUN

                INDEX   -SIGNAOS        # STORE MIN VALUES JUST AS MAX VALUES
                TS      Z5TEM
                CA      1/ANET
                INDEX   -SIGNAOS
                TS      1/ATEM2

                CS      ABSAOS          # NOW DO NEG(POS) CASES
                AD      1JACCU
                AD      1JACCU          # ANETNEG(POS) MAX
                TC      1/ANET-         # COMPUTE 1/ANET, ACCFUN, AND ACCSW
                INDEX   SIGNAOS         # STORE NEG(POS) VALUES JUST AS POS(NEG)
                TS      Z1TEM   +2
                TS      L               # SAVE IN L FOR POSSIBLE FUTURE USE
                CA      1/ANET
                INDEX   SIGNAOS
                TS      1/ATEM1 +2
                CS      ABSAOS
                AD      1JACCU          # 1/ANETNEG(POS) MIN
                TS      ANET
                AD      -.03R/S2        # TEST FOR AMIN
                EXTEND                  # IF ANET LESS THAN AMIN, STORE MAX JET
                BZMF    FIXMIN          # VALUES FOR MIN JETS AND SET ACCSW

                TC      1/NETMIN        # OTHERWISE DO MIN JET COMPUTATIONS
STMIN-          INDEX   SIGNAOS         # STORE VALUES
                TS      Z1TEM
                CA      1/ANET
                INDEX   SIGNAOS
                TS      1/ATEM1

                INDEX   UV
                CA      +UMASK
                MASK    CH5MASK         # TEST FOR +U (+V) JET FAILURES
                EXTEND
                BZF     FAIL-
                CA      1/ATEM2         # REPLACE FUNCTION VALUES DEPENDING ON THE
                TS      1/ATEM2 +2      # FAILED JET PAIR WITH CORRESPONDING ONE-
```

```
                  CA      Z5TEM           # JET (OR AMIN) FUNCTION VALUES
                  TS      Z5TEM   +2
  FAIL-           INDEX   UV
```

Uses A 80, L 80, S2 85, SAVE 191, TC 169, and V 229.

2617 ⟨*Page LM1502* 2617⟩≡ (2587 2643)

```
                CA      -UMASK
                MASK    CH5MASK         # TEST FOR -U (-V) JET FAILURES
                EXTEND
                BZF     DBFUN
                CA      1/ATEM1         # REPLACE FUNCTION VALUES DEPENDING ON THE
                TS      1/ATEM1 +2      # FAILED JET PAIR WITH CORRESPONDING ONE-
                CA      Z1TEM           # JET (OR AMIN) FUNCTION VALUES
                TS      Z1TEM   +2

DBFUN           CS      DBB3            # COMPUTE AXISDIST
                AD      DBB1
                AD      FLATEMP
                TS      AXDSTEM
                CS      DBB4
                AD      DBB2
                AD      FLATEMP
                TS      AXDSTEM +1

                INHINT
                CCS     UV              # TEST FOR U OR V AXIS
                TCF     STORV           # V AXIS        STORE V VALUES

                CA      ACCSW           # U AXIS        STORE U VALUES
                TS      ACCSWU

                CA      NINE            # TRANSFER 10 WORDS VIA GENTRAN
                TC      GENTRAN +1
                ADRES   1/ATEM1         # TEMPORARY BUFFER
                ADRES   1/ANET1         # THE REAL PLACE

                RELINT
                DXCH    DBB1            # SAVE U DBS FOR LATER STORING
                DXCH    UDB1
                DXCH    DBB4
                DXCH    UDB4

                DXCH    AXDSTEM
                DXCH    UAXDIST

                CA      ONE             # NOW DO V AXIS
                TS      UV
                CA      ZERO
                TCF     BOTHAXES        # AND DO IT AGAIN

STORV           CA      ACCSW           # STORE V AXIS VALUES
```

```
TS      ACCSWV
CA      NINE
TC      GENTRAN +1
```

Uses `IT` 185, `SAVE` 191, `TC` 169, and `V` 229.

2619 ⟨*Page LM1503* 2619⟩≡ (2587 2643)

```
        ADRES   1/ATEM1         # TEMPORARY BUFFER
        ADRES   1/ANET1 +16D    # THE REAL PLACE

                                # NOW STORE DEADBANDS FOR ALL AXES
        DXCH    FLATEMP         # FLAT AND ZONE3LIM
        DXCH    FLAT

        CA      DBVAL1          # COMPUTE P AXIS DEADBANDS
        TS      PDB1
        TS      PDB2
        AD      FLAT
        TS      PDB3
        TS      PDB4
        CA      ZERO
        TS      PAXDIST
        TS      PAXDIST +1

        CCS     FLAT
        TCF     DRFDB           # DRIFT OR GTS -- COMPUTE DBS

        DXCH    UDB1            # STORE U DEADBANDS
        DXCH    FIREDB          # CANNOT USE GENTRAN BECAUSE OF RELINT
        DXCH    UDB4
        DXCH    COASTDB
        DXCH    UAXDIST
        DXCH    AXISDIST
        DXCH    DBB1            # STORE V AXIS DEADBANDS
        DXCH    FIREDB  +16D    # COULD USE GENTRAN IF DESIRED
        DXCH    DBB4
        DXCH    COASTDB +16D
        DXCH    AXDSTEM
        DXCH    AXISDIST +16D

        TCF     1/ACCRET +1     # ALL DONE
DRFDB   CA      DBVAL1          # DRIFT DEADBANDS
        TS      FIREDB
        TS      FIREDB  +1
        TS      FIREDB  +16D
        TS      FIREDB  +17D
        AD      FLAT
        TS      COASTDB
        TS      COASTDB +1
        TS      COASTDB +16D
        TS      COASTDB +17D
        CA      ZERO
```

```
TS      AXISDIST
TS      AXISDIST +1
TS      AXISDIST +16D
TS      AXISDIST +17D
```

Uses P 188 and V 229.

2621 ⟨*Page LM1504* 2621⟩≡ (2587 2643)

```
1/ACCRET        INHINT
                CS      DAPBOOLS        # SET BIT TO INDICATE DATA GOOD.
                MASK    ACCSOKAY
                ADS     DAPBOOLS
                RELINT
                CA      ACCRETRN
                TC      BANKJUMP        # RETURN TO CALLER

INVERT          TS      HOLD            # ROUTINE TO INVERT -INPUT AT PI/2
                CA      BIT9            # 1 AT 2(6)
                ZL                      # ZERO L FOR ACCURACY AND TO PREVENT OVFLO
                EXTEND
                DV      HOLD
                TC      Q               # RESULT AT 2(7)/PI

DOWNGTS         CAF     ZERO            # ZERO SWITCHES WHEN USEQRJTS BIT IS UP
                TS      ALLOWGTS        #       OR DAP IS OFF
                TS      INGTS
                TCF     DOCKTEST

1/ANET-         ZL
                LXCH    ACCSW           # ZERO ACCSW
                TS      ANET            # SAVE ANET
                AD      -.03R/S2        # TEST FOR MIN VALUE
                EXTEND
                BZMF    NETNEG          # ANET LESS THAN AMIN, SO FAKE IT
1/NETMIN        CA      ANET
                EXTEND
                INDEX   -SIGNAOS
                MP      1/ACOSTT +1     # ANETNEG(POS)/ACOASTPOS(NEG) AT 2(6)

# THE FOLLOWING CODING IS VALID FOR BOTH POS OR NEG
#       VALUES OF AOS

DO1/NET+        AD      BIT9            # 1 + ANET/ACOAST AT 2(6)
                XCH     ANET            # SAVE AND PICK UP ANET
                EXTEND
                QXCH    ARET            # SAVE RETURN
                TC      INVERT
                TS      1/ANET          # 1/ANET AT 2(7)/PI
                CS      BIT9            # -1 AT 2(6)
DOACCFUN        EXTEND
                MP      1/ANET          # -1/ANET AT 2(13)/PI
                EXTEND
                DV      ANET            # ACCFUN AT 2(7)/PI
```

```
                TC      ARET            # RETURN

NETNEG          CS      -.03R/S2        # ANET LESS THAN AMIN -- SET EQUAL TO AMIN
                TS      ANET
```

Uses DV 241, IT 185, L 80, Q 80, S2 85, SAVE 191, and TC 169.

2623 ⟨*Page LM1505* 2623⟩≡ (2587 2643)

```
                TCF     1/NETMIN +1     # CONTINUE AS IF NOTHING HAPPENED.

FIXMIN          CCS     SIGNAOS
                CA      TWO             # IF AOS NEG, ACCSW = +1
                AD      NEGONE          # IF AOS POS, ACCSW = -1
                TS      ACCSW
                AD      UV              # IF ACCSW = +1, TEST FOR +U (+V) JET FAIL
                INDEX   A               # IF ACCSW = -1, TEST FOR -U (-V) JET FAIL
                CA      -UMASK  +1
                MASK    CH5MASK
                EXTEND
                BZF     +4
                CS      -.03R/S2        # JET FAILURE -- CANNOT USE 2-JET VALUES
                TS      ANET            # ANET = AMIN
                TCF     STMIN-  -1      # CALCULATE FUNCTIONS USING AMIN
                CA      L               # L HAS ACCFUN
                TCF     STMIN-          # STORE MAX VALUES FOR MIN JETS

# ERASABLE ASSIGNMENTS FOR 1/ACCONT

1/ANETP         EQUALS  BLOCKTOP +2
1/ACOSTP        EQUALS  BLOCKTOP +4
PACCFUN         EQUALS  BLOCKTOP +8D
PDB1            EQUALS  BLOCKTOP +10D
PDB2            EQUALS  BLOCKTOP +11D
PDB4            EQUALS  BLOCKTOP +12D
PDB3            EQUALS  BLOCKTOP +13D
PAXDIST         EQUALS  BLOCKTOP +14D

ACCSW           EQUALS  VBUF            # EXECUTIVE TEMPORARIES
                                        # CANNOT DO CCS NEWJOB DURING 1/ACCS
1/ATEM1         EQUALS  ACCSW   +1      # TEMP BUFFER FOR U AND V AXES
1/ATEM2         EQUALS  1/ATEM1 +1
1/ACOSTT        EQUALS  1/ATEM1 +4
Z1TEM           EQUALS  1/ATEM1 +6
Z5TEM           EQUALS  1/ATEM1 +7

UDB1            EQUALS  1/ATEM1 +10D    # UAXIS DEADBAND BUFFER
UDB2            EQUALS  1/ATEM1 +11D
UDB4            EQUALS  1/ATEM1 +12D
UDB3            EQUALS  1/ATEM1 +13D
UAXDIST         EQUALS  1/ATEM1 +14D

DBB1            EQUALS  1/ATEM1 +16D    # TEMP DEADBAND BUFFER, ALSO V AXIS
DBB2            EQUALS  1/ATEM1 +17D
```

```
DBB4            EQUALS  1/ATEM1 +18D
DBB3            EQUALS  1/ATEM1 +19D
AXDSTEM         EQUALS  1/ATEM1 +20D
```

Uses A 80, L 80, NEWJOB 138, S2 85, TEMP 191, V 229, and VBUF 140.

2624 ⟨*Page LM1506* 2624⟩≡ (2587 2643)

```
FLATEMP         EQUALS  1/ATEM1 +22D
Z3TEM           EQUALS  1/ATEM1 +23D    # MUST FOLLOW FLATEMP

DBVAL1          EQUALS  DB
DBVAL2          EQUALS  INTB15+
DBVAL3          EQUALS  INTB15+ +1

DRIFTER         EQUALS  INTB15+ +2

UV              EQUALS  MPAC
ANET            EQUALS  MPAC    +3
FUNTEM          EQUALS  MPAC    +3
1/ANET          EQUALS  MPAC    +4
ARET            EQUALS  MPAC    +5
ABSAOS          EQUALS  MPAC    +6
SIGNAOS         EQUALS  MPAC    +7
-SIGNAOS        EQUALS  MPAC    +8D
HOLD            EQUALS  MPAC    +9D
ACCRETRN        EQUALS  FIXLOC  -1

ZONE3MAX        DEC     .004375         # 17.5 MS (35 MS FOR 1 JET) AT 4 SECONDS
FLATVAL         DEC     .01778          # .8 AT PI/4 RAD
-.03R/S2        OCT     77377           # -PI/2(7) AT PI/2

.0125RS         EQUALS  BIT8            # PI/2(+8) AT PI/2
1/.03           EQUALS  POSMAX          # 2(7)/PI AT 2(7)/PI

PAXISADR        GENADR  PAXIS

                                        # THE FOLLOWING 4 CONSTANTS ARE JET
                                        # FAILURE MASKS AND ARE INDEXED
-UMASK          OCT     00110           # -U
                OCT     00022           # -V
+UMASK          OCT     00204           # +U
                OCT     00041           # +V
```

Uses FIXLOC 140, INTB15+ 140, MPAC 145, RAD 219, S2 85, and V 229.

4.40 sps back up rcs control

2625 ⟨*sps back up rcs control* 2625⟩≡ (2041 2806)

```
# Page 1507
# PROGRAM NAME:         SPSRCS
# AUTHOR:               EDGAR M. OSHIKA (AC ELECTRONICS)
# MODIFIED:             TO RETURN TO ALL AXES VIA Q BY P. S. WEISSMAN, OCT 7, 1968
# MODIFIED TO IMPROVE BENDING STABILITY BY G. KALAN, FEB. 14, 1969
#
# FUNCTIONAL DESCRIPTION:
#       THE PROGRAM CONTROLS THE FIRING OF ALL RCS JETS IN THE DOCKED CONFIGURATION ACCORDING T
#       PLANE LOGIC.
#
#       1. JET SENSE TEST (SPSRCS)
#               IF JETS ARE FIRING NEGATIVELY, SET OLDSENSE NEGATIVE AND CONTINUE
#               IF JETS ARE FIRING POSITIVELY, SET OLDSENSE POSITIVE AND CONTINUE
#               IF JETS ARE NOT FIRING, SET OLDSENSE TO ZERO AND GO TO OUTER RATE LIMIT TEST
#
#       2. RATE DEAD BAND TEST
#               IF JETS ARE FIRING NEGATIVELY AND RATE IS GREATER THAN TARGET RATE, LEAVE
#                       JETS ON AND GO TO INHIBITION LOGIC.  OTHERWISE, CONTINUE.
#               IF JETS ARE FIRING POSITIVELY AND RATE IS   LESS  THAN TARGET RATE, LEAVE
#                       JETS ON AND GO TO INHIBITION LOGIC.  OTHERWISE, CONTINUE.
#
#       3. OUTER RATE LIMIT TEST (SPSSTART)
#               IF MAGNITUDE OF EDOT IS GREATER THAN 1.73 DEG/SEC SET JET FIRING TIME
#                       TO REDUCE RATE AND GO TO INHIBITION LOGIC.  OTHERWISE, CONTINUE.
#
#       4. COAST ZONE TEST
#               IF STATE (E,EDOT) IS BELOW LINE E + 4 X EDOT > -1.4 DEG AND EDOT IS LESS THAN 1
#                       POSITIVE AND CONTINUE.  OTHERWISE, SET JET FIRING TIME TO ZERO AND CONT
#               IF STATE IS ABOVE LINE E + 4 X EDOT > +1.4 DEG AND EDOT IS GREATER THAN -1.30 D
#                       AND CONTINUE.  OTHERWISE, SET JET FIRING TIME TO ZERO AND CONTINUE.
#
#       5. INHIBITION LOGIC
#               IF OLDSENSE IS NON-ZERO:
#                       A) RETURN IF JET TIME AS THE SAME SIGN AS OLDSENSE
#                       B) SET INHIBITION COUNTER* AND RETURN IF JET TIME IS ZERO
#                       C) SET INHIBITION COUNTER,* SET JET TIME TO ZERO AND RETURN IF SIGN
#                          OF JET TIME IS OPPOSITE TO THAT OF OLDSENSE
#               IF OLDSENSE IS ZERO:
#                       A) RETURN IF INHIBITION COUNTER IS NOT POSITIVE
#                       B) SET JET TIME TO ZERO AND RETURN IF INHIBITION COUNTER IS POSITIVE
#               *NOTE: INHIBITION COUNTERS CAN BE SET TO 4 OR 10 FOR THE P AND UV AXES,
#               RESPECTIVELY, IN SPSRCS.  THEY ARE DECREMENTED BY ONE AT THE BEGINNING OF
# Page 1508
```

```
#               EACH DAP PASS.
#
#       THE MINIMUM PULSE WIDTH OF THIS CONTROLLER IS DETERMINED BY THE REPETITION RA
#       AND IS NOMINALLY 100 MS FOR ALL AXES IN DRIFTING FLIGHT.  DURING POWERED FLIG
#       P AXIS AND 200 MS FOR THE CONTROL OF THE U AND V AXES.
#
# CALLING SEQUENCE:
#               INHINT
#               TC      IBNKCALL
#               CADR    SPSRCE
#
# EXIT:
#               TC      Q
#
# ALARM/ABORT MODE:     NONE
#
# SUBROUTINES CALLED:   NONE
#
# INPUT:                E, EDOT
#                       TJP, TJV, TJU           TJ MUST NOT BE NEGATIVE ZERO
#
# OUTPUT:               TJP, TJV, TJU

                BANK    21
                SETLOC  DAPS4
                BANK

                COUNT*  $$/DAPBU

                EBANK=  TJU
RATELIM2        OCT     00632           # 1.125 DEG/SEC
POSTHRST        CA      HALF

                NDX     AXISCTR
                TS      TJU
                CCS     OLDSENSE
                TCF     POSCHECK        # JETS FIRING POSITIVELY
                TCF     CTRCHECK        # JETS OFF.  CHECK INHIBITION CTR
NEGCHECK        INDEX   AXISCTR         # JETS FIRING NEGATIVELY
                CS      TJU
                CCS     A
                TC      Q               # RETURN
                TCF     +2
                TCF     +1              # JETS COMMANDED OFF.  SET CTR AND RETURN
SETCTR          INDEX   AXISCTR         # JET FIRING REVERSAL COMMANDED.  SET CTR,
                CA      UTIME           # SET JET TIME TO ZERO, AND RETURN
```

```
# Page 1509
                INDEX   AXISCTR
                TS      UJETCTR
ZAPTJ           CA      ZERO
                INDEX   AXISCTR
                TS      TJU
                TC      Q
POSCHECK        INDEX   AXISCTR
                CA      TJU
                TCF     NEGCHECK +2
CTRCHECK        INDEX   AXISCTR         # CHECK JET INHIBITION COUNTER
                CCS     UJETCTR
                TCF     +2
                TC      Q               # CTR IS NOT POSITIVE.  RETURN
                TCF     ZAPTJ           # CTR IS POSITIVE.  INHIBIT FIRINGS
                TC      Q               # CTR IS NOT POSITIVE.  RETURN
                OCT     00004
UTIME           OCT     00012
                OCT     00012
OLDSENSE        EQUALS  DAPTREG1
NEGFIRE         CS      ONE             # JETS FIRING NEGATIVELY
                TS      OLDSENSE
                CA      EDOT
                TCF     +4
PLUSFIRE        CA      ONE
                TS      OLDSENSE
                CS      EDOT            # RATE DEAD BAND TEST
                LXCH    A
                CS      DAPBOOLS        # IF DRIFTBIT = 1, USE ZERO TARGET RATE
                MASK    DRIFTBIT        # IF DRIFTBIT = 0, USE 0.10 RATE TARGET
                CCS     A
                CA      RATEDB1
                AD      L
                EXTEND
                BZMF    SPSSTART
                TCF     POSTHRST +3

SPSRCS          INDEX   AXISCTR         # JET SENSE TEST
                CCS     TJU
                TCF     PLUSFIRE        # JETS FIRING POSITIVELY
                TCF     +2
                TCF     NEGFIRE         # JETS FIRING NEGATIVELY
                TS      OLDSENSE        # JETS OFF
SPSSTART        CA      EDOT            # OUTER RATE LIMIT TEST
                EXTEND
                MP      RATELIM1
```

```
                CCS     A
                TCF     NEGTHRST        # OUTER RATE LIMIT EXCEEDED
                TCF     +2
                TCF     POSTHRST        # OUTER RATE LIMIT EXCEEDED
                CA      EDOT            # COAST ZONE TEST
# Page 1510
                AD      E
                EXTEND
                MP      DKDB            # PAD LOADED DEADBAND.  FRESHSTART: 1.4 DEG
                EXTEND
                BZF     TJZERO

                EXTEND
                BZMF    +7
                CA      EDOT
                AD      RATELIM2
                EXTEND
                BZMF    TJZERO
NEGTHRST        CS      HALF
                TCF     POSTHRST +1
        +7      CS      RATELIM2
                AD      EDOT
                EXTEND
                BZMF    POSTHRST
TJZERO          CA      ZERO
                TCF     POSTHRST +1

RATELIM1        =       CALLCODE        # = 00032, CORRESPONDING TO 1.73 DEG/SEC
RATEDB1         =       TBUILDFX        # = 00045, CORRESPONDS TO 0.101 DEG/SEC

# *** END OF LMDAP  .015 ***
```

Uses A 80, COUNT 142, DAPS4 63, EBANK 80, EDOT 209, L 80, MODE 145, P 188, Q 80, STATE 138, TC 169, V 229, and ZONE 163.

Part II

Suplimentary Material

Appendices

Appendix A

Original Files

A.1 README.md

2633 ⟨*src/README.md* 2633⟩≡

```
Apollo-11
=========

Original Apollo 11 guidance computer (AGC) source code, in assembly, for Command Module (Comanc

####Attribution

     Copyright: Public domain.
     Filename:  CONTRACT_AND_APPROVALS.agc
     Purpose:   Part of the source code for Colossus 2A, AKA Comanche 055.
                It is part of the source code for the Command Module's (CM)
                Apollo Guidance Computer (AGC), for Apollo 11.
     Assembler: yaYUL
     Contact:   Ron Burkey <info@sandroid.org>.
     Website:   www.ibiblio.org/apollo.
     Mod history:   2009-05-06 RSB  Transcribed from page images.

     This source code has been transcribed or otherwise adapted from digitized
     images of a hardcopy from the MIT Museum.  The digitization was performed
     by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
     thanks to both.  The images (with suitable reduction in storage size and
     consequent reduction in image quality as well) are available online at
     www.ibiblio.org/apollo.  If for some reason you find that the images are
     illegible, contact me at info@sandroid.org about getting access to the
     (much) higher-quality images which Paul actually created.

     Notations on the hardcopy document read, in part:
```

```
    Assemble revision 055 of AGC program Comanche by NASA
    2021113-051.  10:28 APR. 1, 1969

 Page 1

#************************************************************************
#                                                                      *
#       THIS AGC PROGRAM SHALL ALSO BE REFERRED TO AS:                 *
#                                                                      *
#                                                                      *
#               COLOSSUS 2A                                            *
#                                                                      *
#                                                                      *
#   THIS PROGRAM IS INTENDED FOR USE IN THE CM AS SPECIFIED            *
#   IN REPORT R-577.  THIS PROGRAM WAS PREPARED UNDER DSR              *
#   PROJECT 55-23870, SPONSORED BY THE MANNED SPACECRAFT               *
#   CENTER OF THE NATIONAL AERONAUTICS AND SPACE                       *
#   ADMINISTRATION THROUGH CONTRACT NAS 9-4065 WITH THE                *
#   INSTRUMENTATION LABORATORY, MASSACHUSETTS INSTITUTE OF             *
#   TECHNOLOGY, CAMBRIDGE, MASS.                                       *
#                                                                      *
#************************************************************************


SUBMITTED:  MARGARET H. HAMILTON        DATE:   28 MAR 69
    M.H.HAMILTON, COLOSSUS PROGRAMMING LEADER
    APOLLO GUIDANCE AND NAVIGATION

APPROVED:   DANIEL J. LICKLY        DATE:   28 MAR 69
    D.J.LICKLY, DIRECTOR, MISSION PROGRAM DEVELOPMENT
    APOLLO GUIDANCE AND NAVIGATION PROGRAM

APPROVED:   FRED H. MARTIN          DATE:   28 MAR 69
    FRED H. MARTIN, COLOSSUS PROJECT MANAGER
    APOLLO GUIDANCE AND NAVIGATION PROGRAM

APPROVED:   NORMAN E. SEARS         DATE:   28 MAR 69
    N.E. SEARS, DIRECTOR, MISSION DEVELOPMENT
    APOLLO GUIDANCE AND NAVIGATION PROGRAM

APPROVED:   RICHARD H. BATTIN       DATE:   28 MAR 69
    R.H. BATTIN, DIRECTOR, MISSION DEVELOPMENT
    APOLLO GUIDANCE AND NAVIGATION PROGRAM

APPROVED:   DAVID G. HOAG           DATE:   28 MAR 69
```

```
        D.G. HOAG, DIRECTOR
        APOLLO GUIDANCE AND NAVIGATION PROGRAM

    APPROVED:   RALPH R. RAGAN          DATE:   28 MAR 69
        R.R. RAGAN, DEPUTY DIRECTOR
        INSTRUMENTATION LABORATORY
```

This code is written to file `src/README.md`.
Uses `D` 226, `H` 177, `MASS` 200, and `N` 206.

A.2 HeaderTemplate

2635 ⟨*src/Luminary099/HeaderTemplate.agc* 2635⟩≡

```
# Copyright:    Public domain.
# Filename:     XXXXXXXX.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        XXXX-XXXX
# Mod history:  2009-05-XX XXX  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969
```

This code is written to file `src/Luminary099/HeaderTemplate.agc`.

A.3 AGC BLOCK TWO SELF CHECK

2636 ⟨*src/Comanche055/AGC-BLOCK-TWO-SELF-CHECK.agc* 2636⟩≡

```
# Copyright:    Public domain.
# Filename:     AGC_BLOCK_TWO_SELF-CHECK.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1394-1403
# Mod history:  2009-05-10 SN   (Sergio Navarro).  Started adapting
#                               from the Colossus249/ file of the same
#                               name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#    Assemble revision 055 of AGC program Comanche by NASA
#    2021113-051.  10:28 APR. 1, 1969
#
#    This AGC program shall also be referred to as
#            Colossus 2A

# Page 1394
⟨Page CM1394 1872⟩
# Page 1395
⟨Page CM1395 1874⟩
# Page 1396
⟨Page CM1396 1876⟩
# Page 1397
⟨Page CM1397 1878⟩
# Page 1398
⟨Page CM1398 1880⟩
# Page 1399
⟨Page CM1399 1882⟩
# Page 1400
```

⟨*Page CM1400* 1884⟩
```
# Page 1401
```
⟨*Page CM1401* 1886⟩
```
# Page 1402
```
⟨*Page CM1402* 1888⟩
```
# Page 1403
```
⟨*Page CM1403* 1889⟩

This code is written to file `src/Comanche055/AGC-BLOCK-TWO-SELF-CHECK.agc`.

A.4 AGC BLOCK TWO SELF-CHECK

2638 ⟨*src/Luminary099/AGC-BLOCK-TWO-SELF-CHECK.agc* 2638⟩≡

```
# Copyright:    Public domain.
# Filename:     AGC_BLOCK_TWO_SELF_CHECK.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Onno Hommes <ohommes@cmu.edu>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1284-1293
# Mod history:  2009-05-27 OH   Transcribed from page images.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 1284
⟨Page LM1284 2478⟩
# Page 1285
⟨Page LM1285 2480⟩
# Page 1286
⟨Page LM1286 2482⟩
# Page 1287
⟨Page LM1287 2484⟩
# Page 1288
⟨Page LM1288 2486⟩
# Page 1289
⟨Page LM1289 2488⟩
# Page 1290
⟨Page LM1290 2490⟩
# Page 1291
⟨Page LM1291 2492⟩
# Page 1292
```

⟨*Page LM1292* 2494⟩
```
# Page 1293
```
⟨*Page LM1293* 2495a⟩

This code is written to file `src/Luminary099/AGC-BLOCK-TWO-SELF-CHECK.agc`.

A.5 AGS INITIALIZATION

2639 ⟨*src/Luminary099/AGS-INITIALIZATION.agc* 2639⟩≡
```
# Copyright:    Public domain.
# Filename:     AGS_INITIALIZATION.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Hartmuth Gutsche <hgutsche@xplornet.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        206-210
# Mod history:  2009-05-19 HG   Transcribed from page images.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 206
```
⟨*Page LM0206* 2112⟩
```
# Page 207
```
⟨*Page LM0207* 2114⟩
```
# Page 208
```
⟨*Page LM0208* 2116⟩
```
# Page 209
```
⟨*Page LM0209* 2118⟩
```
# Page 210
```
⟨*Page LM0210* 2119⟩

This code is written to file `src/Luminary099/AGS-INITIALIZATION.agc`.

A.6 ALARM AND ABORT

2640 ⟨*src/Comanche055/ALARM-AND-ABORT.agc* 2640⟩≡

```
# Copyright:    Public domain.
# Filename:     ALARM_AND_ABORT.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 1493-1496
# Contact:      Ron Burkey <info@sandroid.org>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-07 RSB  Adapted from Colossus249 file of the same
#                               name, and page images. Corrected various
#                               typos in the transcription of program
#                               comments, and these should be back-ported
#                               to Colossus249.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 1493
⟨Page CM1493 2007⟩
# Page 1494
⟨Page CM1494 2009⟩
# Page 1495
⟨Page CM1495 2011⟩
# Page 1496
⟨Page CM1496 2013⟩
```

This code is written to file `src/Comanche055/ALARM-AND-ABORT.agc`.

A.7 ANGLFIND

2641 ⟨*src/Comanche055/ANGLFIND.agc* 2641⟩≡

```
# Copyright:    Public domain.
# Filename:     ANGLFIND.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        399-411
# Mod history:  2009-05-09 RSB  Adapted from the Colossus249/ file
#                               of the same name, using Comanche055 page
#                               images.
#               2009-05-22 RSB  In NOGOM2, TC ZEROEROR corrected to
#                               CADR ZEROEROR.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 399
⟨Page CM0399 660⟩
# Page 400
⟨Page CM0400 662⟩
# Page 401
⟨Page CM0401 664⟩
# Page 402
⟨Page CM0402 666⟩
# Page 403
⟨Page CM0403 667⟩
# Page 404
```

⟨*Page CM0404* 668⟩
Page 405
⟨*Page CM0405* 670⟩
Page 406
⟨*Page CM0406* 672⟩
Page 407
⟨*Page CM0407* 674⟩
Page 408
⟨*Page CM0408* 676⟩
Page 409
⟨*Page CM0409* 678⟩
Page 410
⟨*Page CM0410* 680⟩
Page 411
⟨*Page CM0411* 681a⟩

This code is written to file `src/Comanche055/ANGLFIND.agc`.
Uses `TC` 169.

A.8 AOSTASK AND AOSJOB

2643 ⟨*src/Luminary099/AOSTASK-AND-AOSJOB.agc* 2643⟩≡

```
# Copyright:    Public domain.
# Filename:     AOSTASK_AND_AOSJOB.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1485-1506
# Mod history:  2009-05-27 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#               2009-06-05 RSB  Corrected a memory-bank error type.
#               2009-06-07 RSB  Corrected a typo.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 1485
⟨Page LM1485 2588⟩
# Page 1486
⟨Page LM1486 2590⟩
# Page 1487
⟨Page LM1487 2592⟩
# Page 1488
⟨Page LM1488 2594⟩
# Page 1489
⟨Page LM1489 2596⟩
# Page 1490
⟨Page LM1490 2598⟩
# Page 1491
```

⟨*Page LM1491* 2599⟩
```
# Page 1492
```
⟨*Page LM1492* 2600⟩
```
# Page 1493
```
⟨*Page LM1493* 2601⟩
```
# Page 1494
```
⟨*Page LM1494* 2603⟩
```
# Page 1495
```
⟨*Page LM1495* 2605⟩
```
# Page 1496
```
⟨*Page LM1496* 2606⟩
```
# Page 1497
```
⟨*Page LM1497* 2607⟩
```
# Page 1498
```
⟨*Page LM1498* 2609⟩
```
# Page 1499
```
⟨*Page LM1499* 2611⟩
```
# Page 1500
```
⟨*Page LM1500* 2613⟩
```
# Page 1501
```
⟨*Page LM1501* 2615⟩
```
# Page 1502
```
⟨*Page LM1502* 2617⟩
```
# Page 1503
```
⟨*Page LM1503* 2619⟩
```
# Page 1504
```
⟨*Page LM1504* 2621⟩
```
# Page 1505
```
⟨*Page LM1505* 2623⟩
```
# Page 1506
```
⟨*Page LM1506* 2624⟩

This code is written to file `src/Luminary099/AOSTASK-AND-AOSJOB.agc`.

A.9 AOTMARK

2645 ⟨*src/Luminary099/AOTMARK.agc* 2645⟩≡

```
# Copyright:    Public domain.
# Filename:     AOTMARK.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        244-261
# Mod history:  2009-05-10 SN   (Sergio Navarro).  Started adapting
#                               from the Luminary131/ file of the same
#                               name, using Luminary099 page images.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 244
⟨Page LM0244 2121⟩
# Page 245
⟨Page LM0245 2122⟩
# Page 246
⟨Page LM0246 2123⟩
# Page 247
⟨Page LM0247 2124⟩
# Page 248
⟨Page LM0248 2125⟩
# Page 249
⟨Page LM0249 2126⟩
# Page 250
⟨Page LM0250 2128⟩
# Page 251
```

⟨*Page LM0251* 2129⟩
```
# Page 252
```
⟨*Page LM0252* 2130⟩
```
# Page 253
```
⟨*Page LM0253* 2132⟩
```
# Page 254
```
⟨*Page LM0254* 2134⟩
```
# Page 255
```
⟨*Page LM0255* 2136⟩
```
# Page 256
```
⟨*Page LM0256* 2137⟩
```
# Page 257
```
⟨*Page LM0257* 2138⟩
```
# Page 258
```
⟨*Page LM0258* 2139⟩
```
# Page 259
```
⟨*Page LM0259* 2140⟩
```
# Page 260
```
⟨*Page LM0260* 2141⟩
```
# Page 261
```
⟨*Page LM0261* 2142⟩

This code is written to file `src/Luminary099/AOTMARK.agc`.

A.10 ASCENT GUIDANCE

2647 ⟨*src/Luminary099/ASCENT-GUIDANCE.agc* 2647⟩≡

```
# Copyright:    Public domain.
# Filename:     ASCENT_GUIDNCE.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Hartmuth Gutsche <hgutsche@xplornet.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        843-856
# Mod history:  2009-05-23 HG   Transcribed from page images.
#               2009-06-05 RSB  Fixed a couple of typos.
#               2009-06-07 RSB  Corrected a typo.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 843
⟨Page LM0843 2359⟩
# Page 844
⟨Page LM0844 2360⟩
# Page 845
⟨Page LM0845 2361⟩
# Page 846
⟨Page LM0846 2363⟩
# Page 847
⟨Page LM0847 2365⟩
#Page 848
⟨Page LM0848 2367⟩
# Page 849
⟨Page LM0849 2369⟩
# Page 850
```

⟨*Page LM0850* 2371⟩
```
# Page 851
```
⟨*Page LM0851* 2373⟩
```
# Page 852
```
⟨*Page LM0852* 2375⟩
```
# Page 853
```
⟨*Page LM0853* 2377⟩
```
# Page 854
```
⟨*Page LM0854* 2379⟩
```
# Page 855
```
⟨*Page LM0855* 2380⟩
```
# Page 856
```
⟨*Page LM0856* 2381⟩

This code is written to file `src/Luminary099/ASCENT-GUIDANCE.agc`.

A.11 ASSEMBLY AND OPERATION INFORMATION

2649 ⟨*src/Comanche055/CM0002INFO.agc* 2649⟩≡

```
# Copyright:    Public domain.
# Filename:     ASSEMBLY_AND_OPERATION_INFORMATION.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Mod history:  2009-05-05 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 2

⟨Page CM0002 22⟩
# Page 3
⟨Page CM0003 24⟩
# Page 4
⟨Page CM0004 25⟩
# Page 5
⟨Page CM0005 26⟩
# Page 6
⟨Page CM0006 28⟩
# Page 7
⟨Page CM0007 29⟩
```

```
# Page 8
```
⟨*Page CM0008* 30⟩
```
# Page 9
```
⟨*Page CM0009* 31⟩
```
# Page 10
```
⟨*Page CM0010* 32⟩
```
# Page 11
```
⟨*Page CM0011* 33⟩
```
# Page 12
```
⟨*Page CM0012* 35⟩
```
# Page 13
```
⟨*Page CM0013* 37⟩
```
# Page 14
```
⟨*Page CM0014* 38⟩
```
# Page 15
```
⟨*Page CM0015* 40⟩
```
# Page 16
```
⟨*Page CM0016* 42⟩
```
# Page 17
```
⟨*Page CM0017* 44⟩
```
# Page 18
```
⟨*Page CM0018* 45⟩
```
# Page 19
```
⟨*Page CM0019* 46⟩
```
# Page 20
```
⟨*Page CM0020* 48⟩
```
# Page 21
```
⟨*Page CM0021* 50⟩
```
# Page 22
```
⟨*Page CM0022* 51⟩
```
# Page 23
```
⟨*Page CM0023* 52⟩
```
# Page 24
```
⟨*Page CM0024* 54⟩
```
# Page 25
```
⟨*Page CM0025* 55⟩
```
# Page 26
```
⟨*Page CM0026* 56a⟩
```

This code is written to file `src/Comanche055/CM0002INFO.agc`.
```

A.12 ATTITUDE MANEUVER ROUTINE

2651 ⟨*src/Luminary099/ATTITUDE-MANEUVER-ROUTINE.agc* 2651⟩≡

```
# Copyright:    Public domain.
# Filename:     ATTITUDE_MANEUVER_ROUTINE.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        342-363
# Mod history:  2009-05-16 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 342
⟨Page LM0342 2152⟩
# Page 343
⟨Page LM0343 2154⟩
# Page 344
⟨Page LM0344 2156⟩
# Page 345
⟨Page LM0345 2158⟩
# Page 346
⟨Page LM0346 2160⟩
# Page 347
⟨Page LM0347 2162⟩
# Page 348
⟨Page LM0348 2164⟩
# Page 349
```

⟨*Page LM0349* 2165⟩
```
# Page 350
```
⟨*Page LM0350* 2166⟩
```
# Page 351
```
⟨*Page LM0351* 2167⟩
```
# Page 352
```
⟨*Page LM0352* 2169⟩
```
# Page 353
```
⟨*Page LM0353* 2171⟩
```
# Page 354
```
⟨*Page LM0354* 2173⟩
```
# Page 355
```
⟨*Page LM0355* 2174⟩
```
# Page 356
```
⟨*Page LM0356* 2175⟩
```
# Page 357
```
⟨*Page LM0357* 2177⟩
```
# Page 358
```
⟨*Page LM0358* 2179⟩
```
# Page 359
```
⟨*Page LM0359* 2181⟩
```
# Page 360
```
⟨*Page LM0360* 2183⟩
```
# Page 361
```
⟨*Page LM0361* 2185⟩
```
# Page 362
```
⟨*Page LM0362* 2187⟩
```
# Page 363
```
⟨*Page LM0363* 2188a⟩
```

This code is written to file `src/Luminary099/ATTITUDE-MANEUVER-ROUTINE.agc`.
```

A.13 AUTOMATIC MANEUVERS

2653 ⟨*src/Comanche055/AUTOMATIC-MANEUVERS.agc* 2653⟩≡

```
# Copyright:    Public domain.
# Filename:     AUTOMATIC_MANEUVERS.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1025-1036
# Mod history:  2009-05-13 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 1025
⟨Page CM1025 1434⟩
# Page 1026
⟨Page CM1026 1435⟩
# Page 1027
⟨Page CM1027 1436⟩
# Page 1028
⟨Page CM1028 1438⟩
# Page 1029
⟨Page CM1029 1439⟩
# Page 1030
⟨Page CM1030 1441⟩
# Page 1031
⟨Page CM1031 1443⟩
```

```
# Page 1032
```
⟨*Page CM1032* 1445⟩
```
# Page 1033
```
⟨*Page CM1033* 1447⟩
```
# Page 1034
```
⟨*Page CM1034* 1448⟩
```
# Page 1035
```
⟨*Page CM1035* 1449⟩
```
# Page 1036
```
⟨*Page CM1036* 1450a⟩

This code is written to file `src/Comanche055/AUTOMATIC-MANEUVERS.agc`.

A.14 BURN BABY BURN–MASTER IGNITION ROUTINE

2655 ⟨*src/Luminary099/BURN-BABY-BURN–MASTER-IGNITION-ROUTINE.agc* 2655⟩≡

```
# Copyright:    Public domain.
# Filename:     BURN_BABY_BURN--MASTER_IGNITION_ROUTINE.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        731-751
# Mod history:  2009-05-19 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#               2009-06-07 RSB  Corrected 3 typos.
#               2009-07-23 RSB  Added Onno's notes on the naming
#                               of this function, which he got from
#                               Don Eyles.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 731
⟨Page LM0731 2260⟩
# Page 732
⟨Page LM0732 2262⟩
# Page 733
⟨Page LM0733 2263⟩
# Page 734
⟨Page LM0734 2265⟩
# Page 735
```

⟨*Page LM0735* 2267⟩
```
# Page 736
```
⟨*Page LM0736* 2269⟩
```
# Page 737
```
⟨*Page LM0737* 2271⟩
```
# Page 738
```
⟨*Page LM0738* 2273⟩
```
# Page 739
```
⟨*Page LM0739* 2275⟩
```
# Page 740
```
⟨*Page LM0740* 2277⟩
```
# Page 741
```
⟨*Page LM0741* 2279⟩
```
# Page 742
```
⟨*Page LM0742* 2281⟩
```
# Page 743
```
⟨*Page LM0743* 2283⟩
```
# Page 744
```
⟨*Page LM0744* 2285⟩
```
# Page 745
```
⟨*Page LM0745* 2287⟩
```
# Page 746
```
⟨*Page LM0746* 2289⟩
```
# Page 747
```
⟨*Page LM0747* 2291⟩
```
# Page 748
```
⟨*Page LM0748* 2293⟩
```
# Page 749
```
⟨*Page LM0749* 2294⟩
```
# Page 750
```
⟨*Page LM0750* 2295⟩
```
# Page 751
```
⟨*Page LM0751* 2297⟩

This code is written to file `src/Luminary099/BURN-BABY-BURN--MASTER-IGNITION-ROUTINE.agc`.

A.15 CM BODY ATTITUDE

2657 ⟨*src/Comanche055/CM-BODY-ATTITUDE.agc* 2657⟩≡

```
# Copyright:    Public domain.
# Filename:     CM_BODY_ATTITUDE.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 883-889
# Contact:      Ron Burkey <info@sandroid.org>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-12 RSB  Adapted from Colossus249 file of the same
#                               name and Comanche 055 page images.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 883
⟨Page CM0883 1291⟩
# Page 884
⟨Page CM0884 1293⟩
# Page 885
⟨Page CM0885 1295⟩
# Page 886
⟨Page CM0886 1296⟩
# Page 887
⟨Page CM0887 1297⟩
# Page 888
⟨Page CM0888 1299⟩
# Page 889
```

⟨*Page CM0889* 1300a⟩

This code is written to file `src/Comanche055/CM-BODY-ATTITUDE.agc`.

A.16 CM ENTRY DIGITAL AUTOPILOT

2659 ⟨*src/Comanche055/CM-ENTRY-DIGITAL-AUTOPILOT.agc* 2659⟩≡

```
# Copyright:    Public domain.
# Filename:     CM_ENTRY_DIGITAL_AUTOPILOT.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1063-1092
# Mod history:  2009-05-13 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#               2009-05-20 RSB  Corrections: Removed an extraneous label
#                               EXDAPIN, added a missing instruction in
#                               COMPAT.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 1063
⟨Page CM1063 1481⟩
# Page 1064
⟨Page CM1064 1483⟩
# Page 1065
⟨Page CM1065 1484⟩
# Page 1066
⟨Page CM1066 1485⟩
# Page 1067
⟨Page CM1067 1486⟩
# Page 1068
```

⟨*Page CM1068* 1487⟩
Page 1069
⟨*Page CM1069* 1488⟩
Page 1070
⟨*Page CM1070* 1489⟩
Page 1071
⟨*Page CM1071* 1491⟩
Page 1072
⟨*Page CM1072* 1492⟩
Page 1073
⟨*Page CM1073* 1493⟩
Page 1074
⟨*Page CM1074* 1495⟩
Page 1075
⟨*Page CM1075* 1496⟩
Page 1076
⟨*Page CM1076* 1497⟩
Page 1077
⟨*Page CM1077* 1498⟩
Page 1078
⟨*Page CM1078* 1500⟩
Page 1079
⟨*Page CM1079* 1502⟩
Page 1080
⟨*Page CM1080* 1503⟩
Page 1081
⟨*Page CM1081* 1504⟩
Page 1082
⟨*Page CM1082* 1506⟩
Page 1083
⟨*Page CM1083* 1508⟩
Page 1084
⟨*Page CM1084* 1510⟩
Page 1085
⟨*Page CM1085* 1512⟩
Page 1086
⟨*Page CM1086* 1513⟩
Page 1087
⟨*Page CM1087* 1514⟩
Page 1088
⟨*Page CM1088* 1516⟩
Page 1089
⟨*Page CM1089* 1518⟩
Page 1090
⟨*Page CM1090* 1519⟩
Page 1091

⟨*Page CM1091* 1521⟩

```
# Page 1092
```

⟨*Page CM1092* 1522⟩

This code is written to file `src/Comanche055/CM-ENTRY-DIGITAL-AUTOPILOT.agc`.

A.17 CONIC SUBROUTINES

2662 ⟨*src/Comanche055/CONIC-SUBROUTINES.agc* 2662⟩≡

```
# Copyright:    Public domain.
# Filename:     CONIC_SUBROUTINES.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1262-1308
# Mod history:  2009-05-08 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#               2009-05-20 RSB  Corrected:  Fixed four interpreter
#                               instructions.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 1262
⟨Page CM1262 1712⟩
# Page 1263
⟨Page CM1263 1713⟩
# Page 1264
⟨Page CM1264 1714⟩
# Page 1265
⟨Page CM1265 1715⟩
# Page 1266
⟨Page CM1266 1716⟩
# Page 1267
⟨Page CM1267 1717⟩
```

```
# Page 1268
```
⟨*Page CM1268* 1718⟩
```
# Page 1269
```
⟨*Page CM1269* 1719⟩
```
# Page 1270
```
⟨*Page CM1270* 1720⟩
```
# Page 1271
```
⟨*Page CM1271* 1721⟩
```
# Page 1272
```
⟨*Page CM1272* 1722⟩
```
# Page 1273
```
⟨*Page CM1273* 1723⟩
```
# Page 1274
```
⟨*Page CM1274* 1724⟩
```
# Page 1275
```
⟨*Page CM1275* 1725⟩
```
# Page 1276
```
⟨*Page CM1276* 1726⟩
```
# Page 1277
```
⟨*Page CM1277* 1727⟩
```
# Page 1278
```
⟨*Page CM1278* 1729⟩
```
# Page 1279
```
⟨*Page CM1279* 1731⟩
```
# Page 1280
```
⟨*Page CM1280* 1733⟩
```
# Page 1281
```
⟨*Page CM1281* 1735⟩
```
# Page 1282
```
⟨*Page CM1282* 1736⟩
```
# Page 1283
```
⟨*Page CM1283* 1737⟩
```
# Page 1284
```
⟨*Page CM1284* 1738⟩
```
# Page 1285
```
⟨*Page CM1285* 1739⟩
```
# Page 1286
```
⟨*Page CM1286* 1740⟩
```
# Page 1287
```
⟨*Page CM1287* 1741⟩
```
# Page 1288
```
⟨*Page CM1288* 1742⟩
```
# Page 1289
```
⟨*Page CM1289* 1743⟩
```
# Page 1290
```
⟨*Page CM1290* 1744⟩
```
```

```
# Page 1291
```
⟨*Page CM1291* 1745⟩
```
# Page 1292
```
⟨*Page CM1292* 1746⟩
```
# Page 1293
```
⟨*Page CM1293* 1748⟩
```
# Page 1294
```
⟨*Page CM1294* 1750⟩
```
# Page 1295
```
⟨*Page CM1295* 1751⟩
```
# Page 1296
```
⟨*Page CM1296* 1752⟩
```
# Page 1297
```
⟨*Page CM1297* 1754⟩
```
# Page 1298
```
⟨*Page CM1298* 1756⟩
```
# Page 1299
```
⟨*Page CM1299* 1758⟩
```
# Page 1300
```
⟨*Page CM1300* 1759⟩
```
# Page 1301
```
⟨*Page CM1301* 1760⟩
```
# Page 1302
```
⟨*Page CM1302* 1762⟩
```
# Page 1303
```
⟨*Page CM1303* 1763⟩
```
# Page 1304
```
⟨*Page CM1304* 1764⟩
```
# Page 1305
```
⟨*Page CM1305* 1765⟩
```
# Page 1306
```
⟨*Page CM1306* 1767⟩
```
# Page 1307
```
⟨*Page CM1307* 1769⟩
```
# Page 1308
```
⟨*Page CM1308* 1770⟩
```

This code is written to file `src/Comanche055/CONIC-SUBROUTINES.agc`.
```

A.18 CONTRACT AND APPROVALS

2665 ⟨*src/Comanche055/CONTRACT-AND-APPROVALS.agc* 2665⟩≡

```
# Copyright:    Public domain.
# Filename:     CONTRACT_AND_APPROVALS.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Mod history:  2009-05-06 RSB  Transcribed from page image.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969

# Page 1
```

⟨*Page CM0001* 20⟩

This code is written to file `src/Comanche055/CONTRACT-AND-APPROVALS.agc`.

A.19 CONTROLLED CONSTANTS

2666 ⟨*src/Luminary099/CONTROLLED-CONSTANTS.agc* 2666⟩≡

```
# Copyright:    Public domain.
# Filename:     CONTROLLED_CONSTANTS.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
#
# Assembler:    yaYUL
# Contact:      Jim Lawton <jim.lawton@gmail.com>
# Website:      www.ibiblio.org/apollo.
# Pages:        038-053
# Mod history:  2009-05-16      JVL     Transcribed from page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#    Assemble revision 001 of AGC program LMY99 by NASA 2021112-061
#    16:27 JULY 14, 1969

# Page 38
⟨Page LM0038 2043⟩
# Page 39
⟨Page LM0039 2044⟩
# Page 40
⟨Page LM0040 2045⟩
# Page 41
⟨Page LM0041 2046⟩
# Page 42
⟨Page LM0042 2047⟩
# Page 43
⟨Page LM0043 2048⟩
# Page 44
⟨Page LM0044 2049⟩
# Page 45
⟨Page LM0045 2050⟩
# Page 46
```

⟨*Page LM0046* 2051⟩
```
# Page 47
```
⟨*Page LM0047* 2052⟩
```
# Page 48
```
⟨*Page LM0048* 2053⟩
```
# Page 49
```
⟨*Page LM0049* 2054⟩
```
# Page 50
```
⟨*Page LM0050* 2055⟩
```
# Page 51
```
⟨*Page LM0051* 2056⟩
```
# Page 52
```
⟨*Page LM0052* 2057a⟩
```
# Page 53
```
⟨*Page LM0053* 2057b⟩

This code is written to file `src/Luminary099/CONTROLLED-CONSTANTS.agc`.

A.20 CSM GEOMETRY

2668 ⟨*src/Comanche055/CSM-GEOMETRY.agc* 2668⟩≡

```
# Copyright:    Public domain.
# Filename:     CSM_GEOMETRY.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        285-296
# Mod history:  2009-05-08 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 285
⟨Page CM0285 481⟩
# Page 286
⟨Page CM0286 482⟩
# Page 287
⟨Page CM0287 483⟩
# Page 288
⟨Page CM0288 484⟩
# Page 289
⟨Page CM0289 485⟩
# Page 290
⟨Page CM0290 486⟩
# Page 291
⟨Page CM0291 487⟩
```

```
# Page 292
```
⟨*Page CM0292* 488⟩
```
# Page 293
```
⟨*Page CM0293* 489⟩
```
# Page 294
```
⟨*Page CM0294* 491⟩
```
# Page 295
```
⟨*Page CM0295* 492a⟩
```
# Page 296
```
⟨*Page CM0296* 492b⟩

This code is written to file `src/Comanche055/CSM-GEOMETRY.agc`.

A.21 DAPIDLER PROGRAM

2670 ⟨*src/Luminary099/DAPIDLER-PROGRAM.agc* 2670⟩≡

```
# Copyright:    Public domain.
# Filename:     DAPIDLER_PROGRAM.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1410-1420
# Mod history:  2009-05-10 SN   (Sergio Navarro).  Started adapting
#                               from the Luminary131/ file of the same
#                               name, using Luminary099 page images.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 1410
⟨Page LM1410 2504⟩
# Page 1411
⟨Page LM1411 2505⟩
# Page 1412
⟨Page LM1412 2507⟩
# Page 1413
⟨Page LM1413 2509⟩
# Page 1414
⟨Page LM1414 2510⟩
# Page 1415
⟨Page LM1415 2512⟩
# Page 1416
⟨Page LM1416 2513⟩
# Page 1417
```

⟨*Page LM1417* 2514⟩
```
# Page 1418
```
⟨*Page LM1418* 2515⟩
```
# Page 1419
```
⟨*Page LM1419* 2517⟩
```
# Page 1420
```
⟨*Page LM1420* 2518⟩

This code is written to file `src/Luminary099/DAPIDLER-PROGRAM.agc`.

A.22 DAP INTERFACE SUBROUTINES

2672 ⟨*src/Luminary099/DAP-INTERFACE-SUBROUTINES.agc* 2672⟩≡

```
# Copyright:    Public domain.
# Filename:     DAP_INTERFACE_SUBROUTINES.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1406-1409
# Mod history:  2009-05-10 SN   (Sergio Navarro).  Started adapting
#                               from the Luminary131/ file of the same
#                               name, using Luminary099 page images.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 1406
⟨Page LM1406 2499b⟩
# Page 1407
⟨Page LM1407 2500⟩
# Page 1408
⟨Page LM1408 2502⟩
# Page 1409
⟨Page LM1409 2503a⟩
```

This code is written to file `src/Luminary099/DAP-INTERFACE-SUBROUTINES.agc`.

A.23 DISPLAY INTERFACE ROUTINES

2673 ⟨*src/Comanche055/DISPLAY-INTERFACE-ROUTINES.agc* 2673⟩≡

```
# Copyright:    Public domain.
# Filename:     DISPLAY_INTERFACE_ROUTINES.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 1452-1484
# Contact:      Ron Burkey <info@sandroid.org>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-07 RSB  Adapted from Colossus249 file of the same
#                               name, and page images. Corrected various
#                               typos in the transcription of program
#                               comments, and these should be back-ported
#                               to Colossus249.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 1452
⟨Page CM1452 1949⟩
# Page 1453
⟨Page CM1453 1950⟩
# Page 1454
⟨Page CM1454 1951⟩
# Page 1455
⟨Page CM1455 1952⟩
# Page 1456
⟨Page CM1456 1953⟩
```

```
# Page 1457
```
⟨*Page CM1457* 1954⟩
```
# Page 1458
```
⟨*Page CM1458* 1955⟩
```
# Page 1459
```
⟨*Page CM1459* 1956⟩
```
# Page 1460
```
⟨*Page CM1460* 1957⟩
```
# Page 1461
```
⟨*Page CM1461* 1958⟩
```
# Page 1462
```
⟨*Page CM1462* 1959⟩
```
# Page 1463
```
⟨*Page CM1463* 1961⟩
```
# Page 1464
```
⟨*Page CM1464* 1962⟩
```
# Page 1465
```
⟨*Page CM1465* 1963⟩
```
# Page 1466
```
⟨*Page CM1466* 1965⟩
```
# Page 1467
```
⟨*Page CM1467* 1967⟩
```
# Page 1468
```
⟨*Page CM1468* 1969⟩
```
# Page 1469
```
⟨*Page CM1469* 1971⟩
```
# Page 1470
```
⟨*Page CM1470* 1973⟩
```
# Page 1471
```
⟨*Page CM1471* 1975⟩
```
# Page 1472
```
⟨*Page CM1472* 1977⟩
```
# Page 1473
```
⟨*Page CM1473* 1979⟩
```
# Page 1474
```
⟨*Page CM1474* 1981⟩
```
# Page 1475
```
⟨*Page CM1475* 1983⟩
```
# Page 1476
```
⟨*Page CM1476* 1985⟩
```
# Page 1477
```
⟨*Page CM1477* 1987⟩
```
# Page 1478
```
⟨*Page CM1478* 1989⟩
```
# Page 1479
```
⟨*Page CM1479* 1991⟩
```
```

```
# Page 1480
```
⟨*Page CM1480* 1993⟩
```
# Page 1481
```
⟨*Page CM1481* 1995⟩
```
# Page 1482
```
⟨*Page CM1482* 1997⟩
```
# Page 1483
```
⟨*Page CM1483* 1999⟩
```
# Page 1484
```
⟨*Page CM1484* 2000a⟩

This code is written to file `src/Comanche055/DISPLAY-INTERFACE-ROUTINES.agc`.

A.24 DOWNLINK LISTS

2676 ⟨*src/Comanche055/DOWNLINK-LISTS.agc* 2676⟩≡

```
# Copyright:    Public domain.
# Filename:     DOWNLINK_LISTS.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 170-180
# Contact:      Ron Burkey <info@sandroid.org>,
#               Fabrizio Bernardini <fabrizio@spacecraft.it>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  10/05/09 FB     Transcription of Batch FB-1 Assignment.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 170
⟨Page CM0170 294⟩
# Page 171
⟨Page CM0171 295⟩
# Page 172
⟨Page CM0172 297⟩
# Page 173
⟨Page CM0173 298⟩
# Page 174
⟨Page CM0174 299⟩
# Page 175
⟨Page CM0175 300⟩
# Page 176
```

⟨*Page CM0176* 301⟩
```
# Page 177
```
⟨*Page CM0177* 302⟩
```
# Page 178
```
⟨*Page CM0178* 303⟩
```
# Page 179
```
⟨*Page CM0179* 304⟩
```
# Page 180
```
⟨*Page CM0180* 305⟩

This code is written to file `src/Comanche055/DOWNLINK-LISTS.agc`.

A.25 DOWN TELEMETRY PROGRAM

2678 ⟨*src/Luminary099/DOWN–TELEMETRY-PROGRAM.agc* 2678⟩≡

```
# Copyright:    Public domain.
# Filename:     DOWN_TELEMETRY_PROGRAM.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        988-997
# Mod history:  2009-05-24 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 988
⟨Page LM0988 2461⟩
# Page 989 (empty page)⟨Page LM0989 2462⟩
# Page 990
⟨Page LM0990 2463⟩
# Page 991
⟨Page LM0991 2465⟩
# Page 992
⟨Page LM0992 2467⟩
# Page 993
⟨Page LM0993 2469⟩
# Page 994
⟨Page LM0994 2471⟩
# Page 995
⟨Page LM0995 2472⟩
```

```
# Page 996
```
⟨*Page LM0996* 2474⟩
```
# Page 997
```
⟨*Page LM0997* 2475a⟩

This code is written to file `src/Luminary099/DOWN--TELEMETRY-PROGRAM.agc`.

A.26 DOWN-TELEMETRY PROGRAM

2680 ⟨*src/Comanche055/DOWN-TELEMETRY-PROGRAM.agc* 2680⟩≡

```
# Copyright:    Public domain.
# Filename:     DOWN-TELEMETRY_PROGRAM.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 1093-1102
# Contact:      Ron Burkey <info@sandroid.org>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-08 RSB  Adapted from Colossus249/ file of same name
#                               and page images. Corrected various typos
#                               in the transcription of program comments,
#                               and these should be back-ported to
#                               Colossus249.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 1093
⟨Page CM1093 1524⟩
# Page 1094
⟨Page CM1094 1525⟩
# Page 1095
⟨Page CM1095 1526⟩
# Page 1096
⟨Page CM1096 1528⟩
# Page 1097
⟨Page CM1097 1530⟩
```

```
# Page 1098
```
⟨*Page CM1098* 1532⟩
```
# Page 1099
```
⟨*Page CM1099* 1534⟩
```
# Page 1100
```
⟨*Page CM1100* 1536⟩
```
# Page 1101
```
⟨*Page CM1101* 1538⟩
```
# Page 1102
```
⟨*Page CM1102* 1539a⟩

This code is written to file `src/Comanche055/DOWN-TELEMETRY-PROGRAM.agc`.

A.27 ENTRY LEXICON

2682 ⟨*src/Comanche055/ENTRY-LEXICON.agc* 2682⟩≡

```
# Copyright:    Public domain.
# Filename:     ENTRY_LEXICON.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 837-843
# Contact:      Ron Burkey <info@sandroid.org>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-12 RSB  Adapted from Colossus249 file of the same
#                               name and Comanche 055 page images.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 837
⟨Page CM0837 1245⟩
# Page 838
⟨Page CM0838 1247⟩
# Page 839
⟨Page CM0839 1248⟩
# Page 840
⟨Page CM0840 1250⟩
# Page 841
⟨Page CM0841 1252⟩
# Page 842
⟨Page CM0842 1254⟩
# Page 843
```

⟨*Page CM0843* 1255a⟩

This code is written to file `src/Comanche055/ENTRY-LEXICON.agc`.

A.28 ERASABLE ASSIGNMENTS

2684 ⟨*src/Comanche055/ERASABLE-ASSIGNMENTS.agc* 2684⟩≡

```
# Copyright:    Public domain.
# Filename:     ERASABLE_ASSIGNMENTS.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Mod history:  2009-05-06 RSB  Started adapting from the Colossus249/ file
#                               of the same name, using Comanche055 page
#                               images. Only through page 51 so far.
#               2009-05-07 RSB  Through page 92 so far.
#               2009-05-07 RSB  (Again!) First draft completed.
#               2009-05-20 RSB  Fixed some bugs uncovered in trial assemblies:
#                               EMDOT, STATEXIT, VGDISP, DVPREV, POSTCDH,
#                               RETROFLG not defined correctly, changed the
#                               typing of labels 9X9LOC1 and 9X9LOC2,
#                               R32FLBIT -> R31FLBIT.
#               2009-05-21 RSB  Corrected definition of DELBRTMP, which
#                               chained to quite a lot of off-by-one errors.
#                               Changed a +8 to a +8D.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A


# Page 37
```

⟨*Page CM0037* 78⟩

```
# Page 38
```

⟨*Page CM0038* 79⟩
Page 39
⟨*Page CM0039* 80⟩
Page 40
⟨*Page CM0040* 85⟩
Page 41
⟨*Page CM0041* 87⟩
Page 42
⟨*Page CM0042* 89⟩
Page 43
⟨*Page CM0043* 91⟩
Page 44
⟨*Page CM0044* 93⟩
Page 45
⟨*Page CM0045* 94⟩
Page 46
⟨*Page CM0046* 95⟩
Page 47
⟨*Page CM0047* 97⟩
Page 48
⟨*Page CM0048* 99⟩
Page 49
⟨*Page CM0049* 101⟩
Page 50
⟨*Page CM0050* 103⟩
Page 51
⟨*Page CM0051* 105⟩
Page 52
⟨*Page CM0052* 107⟩
Page 53
⟨*Page CM0053* 109⟩
Page 54
⟨*Page CM0054* 111⟩
Page 55
⟨*Page CM0055* 113⟩
Page 56
⟨*Page CM0056* 115⟩
Page 57
⟨*Page CM0057* 117⟩
Page 58
⟨*Page CM0058* 119⟩
Page 59
⟨*Page CM0059* 121⟩
Page 60
⟨*Page CM0060* 123⟩
Page 61

⟨*Page CM0061* 125⟩
Page 62
⟨*Page CM0062* 127⟩
Page 63
⟨*Page CM0063* 129⟩
Page 64
⟨*Page CM0064* 131⟩
Page 65
⟨*Page CM0065* 133⟩
Page 66
⟨*Page CM0066* 135⟩
Page 67
⟨*Page CM0067* 137⟩
Page 68
⟨*Page CM0068* 138⟩
Page 69
⟨*Page CM0069* 140⟩
Page 70
⟨*Page CM0070* 142⟩
Page 71
⟨*Page CM0071* 144⟩
Page 72
⟨*Page CM0072* 145⟩
Page 73
⟨*Page CM0073* 148⟩
Page 74
⟨*Page CM0074* 150⟩
Page 75
⟨*Page CM0075* 152⟩
Page 76
⟨*Page CM0076* 154⟩
Page 77
⟨*Page CM0077* 156⟩
Page 78
⟨*Page CM0078* 157⟩
Page 79
⟨*Page CM0079* 159⟩
Page 80
⟨*Page CM0080* 161⟩
Page 81
⟨*Page CM0081* 163⟩
Page 82
⟨*Page CM0082* 165⟩
Page 83
⟨*Page CM0083* 166⟩
Page 84

⟨*Page CM0084* 167⟩
Page 84
⟨*Page CM0085* 169⟩
Page 86
⟨*Page CM0086* 172⟩
Page 87
⟨*Page CM0087* 174⟩
Page 88
⟨*Page CM0088* 175⟩
Page 89
⟨*Page CM0089* 177⟩
Page 90
⟨*Page CM0090* 179⟩
Page 91
⟨*Page CM0091* 181⟩
Page 92
⟨*Page CM0092* 182⟩
Page 93
⟨*Page CM0093* 183⟩
Page 94
⟨*Page CM0094* 185⟩
Page 95
⟨*Page CM0095* 186⟩
Page 96
⟨*Page CM0096* 188⟩
Page 97
⟨*Page CM0097* 190⟩
Page 98
⟨*Page CM0098* 191⟩
Page 99
⟨*Page CM0099* 194⟩
Page 100
⟨*Page CM0100* 196⟩
Page 101
⟨*Page CM0101* 197⟩
Page 102
⟨*Page CM0102* 198⟩
#Page 103
⟨*Page CM0103* 200⟩
Page 104
⟨*Page CM0104* 202⟩
Page 105
⟨*Page CM0105* 204⟩
Page 106
⟨*Page CM0106* 206⟩
Page 107

⟨*Page CM0107* 208⟩
Page 108
⟨*Page CM0108* 209⟩
Page 109
⟨*Page CM0109* 211⟩
Page 110
⟨*Page CM0110* 213⟩
Page 111
⟨*Page CM0111* 214⟩
Page 112
⟨*Page CM0112* 216⟩
Page 113
⟨*Page CM0113* 218⟩
Page 114
⟨*Page CM0114* 219⟩
Page 115
⟨*Page CM0115* 221⟩
Page 116
⟨*Page CM0116* 223⟩
Page 117
⟨*Page CM0117* 224⟩
Page 118
⟨*Page CM0118* 226⟩
Page 119
⟨*Page CM0119* 229⟩
Page 120
⟨*Page CM0120* 231⟩
Page 121
⟨*Page CM0121* 232⟩
Page 122
⟨*Page CM0122* 234⟩
Page 123
⟨*Page CM0123* 236⟩
Page 124
⟨*Page CM0124* 238⟩
Page 125
⟨*Page CM0125* 239⟩
Page 126
⟨*Page CM0126* 240⟩
Page 127
⟨*Page CM0127* 241⟩
Page 128
⟨*Page CM0128* 243⟩
Page 129
⟨*Page CM0129* 244⟩
Page 130 ... is empty.

⟨*Page CM0130* 245a⟩

This code is written to file `src/Comanche055/ERASABLE-ASSIGNMENTS.agc`.

Uses `9X9LOC1` 183, `9X9LOC2` 183, `DELBRTMP` 206, `DVPREV` 244, `EMDOT` 138, `POSTCDH` 244, `R31FLBIT` 131, `RETROFLG` 113, `STATEXIT` 140, and `VGDISP` 231.

A.29 EXECUTIVE

2690 ⟨*src/Comanche055/EXECUTIVE.agc* 2690⟩≡

```
# Copyright:    Public domain.
# Filename:     EXECUTIVE.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1208-1220
# Mod history:  2009-05-14 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 1208
⟨Page CM1208 1649⟩
# Page 1209
⟨Page CM1209 1650⟩
# Page 1210
⟨Page CM1210 1651⟩
# Page 1211
⟨Page CM1211 1652⟩
# Page 1212
⟨Page CM1212 1653⟩
# Page 1213
⟨Page CM1213 1654⟩
# Page 1214
⟨Page CM1214 1655⟩
```

```
# Page 1215
```
⟨*Page CM1215* 1656⟩
```
# Page 1216
```
⟨*Page CM1216* 1657⟩
```
# Page 1217
```
⟨*Page CM1217* 1658⟩
```
# Page 1218
```
⟨*Page CM1218* 1659⟩
```
# Page 1219
```
⟨*Page CM1219* 1660⟩
```
# Page 1220
```
⟨*Page CM1220* 1661⟩

This code is written to file `src/Comanche055/EXECUTIVE.agc`.

A.30 EXTENDED VERBS

2692 ⟨*src/Comanche055/EXTENDED-VERBS.agc* 2692⟩≡

```
# Copyright:    Public domain.
# Filename:     EXTENDED_VERBS.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 236-267
# Contact:      Ron Burkey <info@sandroid.org>,
#               Fabrizio Bernardini <fabrizio@spacecraft.it>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-18 FB   Transcription Batch 3 Assignment.
#               2009-05-20 RSB  Corrections:  POODOO -> P00DOO,
#                               GOTOPOOH -> GOTOP00H, added a couple of
#                               missing instructions in Verb 96.
#               2009-05-23 RSB  In SYSTEST, corrected TC FLAGWRD1 to
#                               CA FLAGWRD1.  Added a variety of SBANK=
#                               statements prior to 2CADRs.  One day I'll
#                               have to figure out what yaYUL is doing
#                               wrong with those ....
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 236
⟨Page CM0236 405⟩
# Page 237
⟨Page CM0237 407⟩
# Page 238
```

⟨*Page CM0238* 408⟩
Page 239
⟨*Page CM0239* 409⟩
Page 240
⟨*Page CM0240* 410⟩
Page 241
⟨*Page CM0241* 411⟩
Page 242
⟨*Page CM0242* 412⟩
Page 243
⟨*Page CM0243* 414⟩
Page 244
⟨*Page CM0244* 416⟩
Page 245
⟨*Page CM0245* 417⟩
Page 246
⟨*Page CM0246* 418⟩
Page 247
⟨*Page CM0247* 419⟩
Page 248
⟨*Page CM0248* 420⟩
Page 249
⟨*Page CM0249* 421⟩
Page 250
⟨*Page CM0250* 423⟩
Page 251
⟨*Page CM0251* 424⟩
Page 252
⟨*Page CM0252* 425⟩
Page 253
⟨*Page CM0253* 426⟩
Page 254
⟨*Page CM0254* 428⟩
Page 255
⟨*Page CM0255* 430⟩
Page 256
⟨*Page CM0256* 431⟩
Page 257
⟨*Page CM0257* 432⟩
Page 258
⟨*Page CM0258* 433⟩
Page 259
⟨*Page CM0259* 434⟩
Page 260
⟨*Page CM0260* 436⟩
Page 261

⟨*Page CM0261* 437⟩
```
# Page 262
```
⟨*Page CM0262* 438⟩
```
# Page 263
```
⟨*Page CM0263* 440⟩
```
# Page 264
```
⟨*Page CM0264* 442⟩
```
# Page 265
```
⟨*Page CM0265* 444⟩
```
# Page 266
```
⟨*Page CM0266* 446⟩
```
# Page 267
```
⟨*Page CM0267* 448⟩

This code is written to file `src/Comanche055/EXTENDED-VERBS.agc`.
Uses `FLAGWRD1` 97 and `TC` 169.

A.31 FINDCDUW–GUIDAP INTERFACE

2695 ⟨*src/Luminary099/FINDCDUW–GUIDAP-INTERFACE.agc* 2695⟩≡

```
# Copyright:    Public domain.
# Filename:     FINDCDUW--GUIDAP_INTERFACE.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Hartmuth Gutsche <hgutsche@xplornet.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        908-925
# Mod history:  2009-05-28 HG   Transcribed from page images.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 908
⟨Page LM0908 2440⟩
# Page 909
⟨Page LM0909 2441⟩
# Page 910
⟨Page LM0910 2442⟩
# Page 911
⟨Page LM0911 2443⟩
# Page 912
⟨Page LM0912 2444⟩
# Page 913
⟨Page LM0913 2445⟩
# Page 914
⟨Page LM0914 2446⟩
# Page 915
⟨Page LM0915 2447⟩
# Page 916
```

⟨*Page LM0916* 2448⟩
Page 917
⟨*Page LM0917* 2450⟩
Page 918
⟨*Page LM0918* 2452⟩
Page 919
⟨*Page LM0919* 2453⟩
Page 920
⟨*Page LM0920* 2454⟩
Page 921
⟨*Page LM0921* 2455⟩
Page 922
⟨*Page LM0922* 2456⟩
Page 923
⟨*Page LM0923* 2457⟩
Page 924
⟨*Page LM0924* 2458⟩
Page 925
⟨*Page LM0925* 2459⟩

This code is written to file `src/Luminary099/FINDCDUW--GUIDAP-INTERFACE.agc`.

A.32 FIXED FIXED CONSTANT POOL

2697 ⟨*src/Comanche055/FIXED-FIXED-CONSTANT-POOL.agc* 2697⟩≡

```
# Copyright:    Public domain.
# Filename:     FIXED_FIXED_CONSTANT_POOL.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1200-1204
# Mod history:  2009-05-13 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 1200
⟨Page CM1200 1638⟩
# Page 1201
⟨Page CM1201 1640⟩
# Page 1202
⟨Page CM1202 1642⟩
# Page 1203
⟨Page CM1203 1643⟩
# Page 1204
⟨Page CM1204 1644⟩
```

This code is written to file `src/Comanche055/FIXED-FIXED-CONSTANT-POOL.agc`.

A.33 FLAGWORD ASSIGNMENTS

2698 ⟨*src/Luminary099/FLAGWORD-ASSIGNMENTS.agc* 2698⟩≡

```
# Copyright:    Public domain.
# Filename:     FLAGWORD_ASSIGNMENTS.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Onno Hommes <ohommes@cmu.edu>.
# Website:      www.ibiblio.org/apollo.
# Pages:        0061-0089
# Mod history:  2009-05-15 OH   Transcribed from page images.
#               2009-05-17 RSB  Extended to (blank) p. 89.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969


# Page 61
⟨Page LM0061 2066⟩
# Page 62
⟨Page LM0062 2068⟩
# Page63
⟨Page LM0063 2070⟩
# Page 64
⟨Page LM0064 2072⟩
# Page 65
⟨Page LM0065 2074⟩
# Page 66
⟨Page LM0066 2075⟩
# Page 67
⟨Page LM0067 2076⟩
# Page 68
```

⟨*Page LM0068* 2078⟩
```
# Page 69
```
⟨*Page LM0069* 2079⟩
```
# Page 70
```
⟨*Page LM0070* 2080⟩
```
# Page 71
```
⟨*Page LM0071* 2081⟩
```
# Page 72
```
⟨*Page LM0072* 2082⟩
```
# Page 73
```
⟨*Page LM0073* 2084⟩
```
# Page 74
```
⟨*Page LM0074* 2086⟩
```
# Page 75
```
⟨*Page LM0075* 2087⟩
```
# Page 76
```
⟨*Page LM0076* 2089⟩
```
# Page 77
```
⟨*Page LM0077* 2091⟩
```
# Page 78
```
⟨*Page LM0078* 2092⟩
```
# Page 79
```
⟨*Page LM0079* 2094⟩
```
# Page 80
```
⟨*Page LM0080* 2096⟩
```
# Page 81
```
⟨*Page LM0081* 2098⟩
```
# Page 82
```
⟨*Page LM0082* 2100⟩
```
# Page 83
```
⟨*Page LM0083* 2102⟩
```
# Page 84
```
⟨*Page LM0084* 2103⟩
```
# Page 85
```
⟨*Page LM0085* 2104⟩
```
# Page 86
```
⟨*Page LM0086* 2105⟩
```
# Page 87
```
⟨*Page LM0087* 2106⟩
```
# Page 88
```
⟨*Page LM0088* 2107a⟩
```
# Page 89 (nothing on this page)
```
⟨*Page LM0089* 2107b⟩
```
This code is written to file `src/Luminary099/FLAGWORD-ASSIGNMENTS.agc`.
```

A.34 FRESH START AND RESTART

2700 ⟨*src/Comanche055/FRESH-START-AND-RESTART.agc* 2700⟩≡

```
# Copyright:    Public domain.
# Filename:     FRESH_START_AND_RESTART.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 181-210
# Contact:      Ron Burkey <info@sandroid.org>,
#               Fabrizio Bernardini <fabrizio@spacecraft.it>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-16 FB   Transcription Batch 2 Assignment.
#               2009-05-20 RSB  Removed an extraneous "TC STARTSUB".
#               2009-05-21 RSB  Changed a "TC BANKCALL" to "TC STOPRATE"
#                               in INITSUB.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 181
⟨Page CM0181 307⟩
# Page 182
⟨Page CM0182 309⟩
# Page 183
⟨Page CM0183 311⟩
# Page 184
⟨Page CM0184 313⟩
# Page 185
⟨Page CM0185 315⟩
```

```
# Page 186
```
⟨*Page CM0186* 317⟩
```
# Page 187
```
⟨*Page CM0187* 319⟩
```
# Page 188
```
⟨*Page CM0188* 321⟩
```
# Page 189
```
⟨*Page CM0189* 323⟩
```
# Page 190
```
⟨*Page CM0190* 325⟩
```
# Page 191
```
⟨*Page CM0191* 327⟩
```
# Page 192
```
⟨*Page CM0192* 329⟩
```
# Page 193
```
⟨*Page CM0193* 330⟩
```
# Page 194
```
⟨*Page CM0194* 331⟩
```
# Page 195
```
⟨*Page CM0195* 332⟩
```
# Page 196
```
⟨*Page CM0196* 333⟩
```
# Page 197
```
⟨*Page CM0197* 335⟩
```
# Page 198
```
⟨*Page CM0198* 337⟩
```
# Page 199
```
⟨*Page CM0199* 339⟩
```
# Page 200
```
⟨*Page CM0200* 341⟩
```
# Page 201
```
⟨*Page CM0201* 343⟩
```
# Page 202
```
⟨*Page CM0202* 345⟩
```
# Page 203
```
⟨*Page CM0203* 347⟩
```
# Page 204
```
⟨*Page CM0204* 349⟩
```
# Page 205
```
⟨*Page CM0205* 351⟩
```
# Page 206
```
⟨*Page CM0206* 353⟩
```
# Page 207
```
⟨*Page CM0207* 355⟩
```
# Page 208
```
⟨*Page CM0208* 357⟩
```
```

```
# Page 209
⟨Page CM0209 359⟩
# Page 210
⟨Page CM0210 360⟩
```

This code is written to file `src/Comanche055/FRESH-START-AND-RESTART.agc`.
Uses `TC` 169.

A.35 GIMBAL LOCK AVOIDANCE

2702 ⟨*src/Comanche055/GIMBAL-LOCK-AVOIDANCE.agc* 2702⟩≡

```
# Copyright:    Public domain.
# Filename:     GIMBAL_LOCK_AVOIDANCE.agc
# Purpose:      Part of the source code for Comanche, build 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 412-413
# Contact:      Onno Hommes <ohommes@cmu.edu>.
# Website:      www.ibiblio.org/apollo.
# Mod history:  05/07/09 OH     Transcription Batch 1 Assignment
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further information.
# Please report any errors to info@sandroid.org.


# Page 412
⟨Page CM0412 682⟩
# Page 413
⟨Page CM0413 683a⟩
```

This code is written to file `src/Comanche055/GIMBAL-LOCK-AVOIDANCE.agc`.

A.36 GROUND TRACKING DETERMINATION PROGRAM

2703 ⟨*src/Comanche055/GROUND-TRACKING-DETERMINATION-PROGRAM.agc* 2703⟩≡

```
# Copyright:    Public domain.
# Filename:     GROUND_TRACKING_DETERMINATION_PROGRAM.agc
# Purpose:      Part of the source code for Comanche, build 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 456-459
# Contact:      Onno Hommes <ohommes@cmu.edu>.
# Website:      www.ibiblio.org/apollo.
# Mod history:  2009-05-07 OH   Transcription Batch 1 Assignment
#               2009-05-20 RSB  Corrected a couple of DIMOFLAG to DIMOFLAG.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further information.
# Please report any errors to info@sandroid.org.

# Page 456
⟨Page CM0456 745⟩
# Page 457
⟨Page CM0457 747⟩
# Page 458
⟨Page CM0458 749⟩
# Page 459
⟨Page CM0459 750⟩
```

This code is written to file `src/Comanche055/GROUND-TRACKING-DETERMINATION-PROGRAM.agc`.
Uses `DIMOFLAG` 109.

A.37 IMU CALIBRATION AND ALIGNMENT

2704 ⟨*src/Comanche055/IMU-CALIBRATION-AND-ALIGNMENT.agc* 2704⟩≡

```
# Copyright:    Public domain.
# Filename:     IMU_CALIBRATION_AND_ALIGNMENT.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 423-455
# Contact:      Onno Hommes <ohommes@cmu.edu>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-10 OH   Batch 1 Assignment Comanche Transcription
#               2009-05-20 RSB  Corrections: P00D00H -> P00DOOH, definition
#                               of 25DECML fixed.
#               2009-05-23 RSB  At SPECSTS, corrected to PRIO22.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 423
⟨Page CM0423 696⟩
# Page 424
⟨Page CM0424 698⟩
# Page 425
⟨Page CM0425 700⟩
# Page 426
⟨Page CM0426 702⟩
# Page 427
⟨Page CM0427 703⟩
# Page 428
```

⟨*Page CM0428* 704⟩
Page 429
⟨*Page CM0429* 705⟩
Page 430
⟨*Page CM0430* 706⟩
Page 431
⟨*Page CM0431* 708⟩
Page 432
⟨*Page CM0432* 710⟩
Page 433
⟨*Page CM0433* 711⟩
Page 434
⟨*Page CM0434* 712⟩
Page 435
⟨*Page CM0435* 713⟩
Page 436
⟨*Page CM0436* 714⟩
Page 437
⟨*Page CM0437* 716⟩
Page 438
⟨*Page CM0438* 717⟩
Page 439
⟨*Page CM0439* 718⟩
Page 440
⟨*Page CM0440* 720⟩
Page 441
⟨*Page CM0441* 722⟩
Page 442
⟨*Page CM0442* 724⟩
Page 443
⟨*Page CM0443* 725⟩
Page 444
⟨*Page CM0444* 727⟩
Page 445
⟨*Page CM0445* 729⟩
Page 446
⟨*Page CM0446* 731⟩
Page 447
⟨*Page CM0447* 732a⟩
Page 448
⟨*Page CM0448* 732b⟩
Page 449
⟨*Page CM0449* 733⟩
Page 450
⟨*Page CM0450* 735⟩
Page 451

⟨*Page CM0451* 737⟩
```
# Page 452
```
⟨*Page CM0452* 739⟩
```
# Page 453
```
⟨*Page CM0453* 741⟩
```
# Page 454
```
⟨*Page CM0454* 743⟩
```
# Page 455
```
⟨*Page CM0455* 744a⟩

This code is written to file `src/Comanche055/IMU-CALIBRATION-AND-ALIGNMENT.agc`.

A.38 IMU COMPENSATION PACKAGE

2707 ⟨*src/Comanche055/IMU-COMPENSATION-PACKAGE.agc* 2707⟩≡

```
# Copyright:    Public domain.
# Filename:     IMU_COMPENSATION_PACKAGE.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        297-306
# Mod history:  2009-05-08 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images/
#               2009-05-21 RSB  In IRIGZ, PRIO17 corrected to PRIO21.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 297
⟨Page CM0297 493⟩
# Page 298
⟨Page CM0298 494⟩
# Page 299
⟨Page CM0299 495⟩
# Page 300
⟨Page CM0300 496⟩
# Page 301
⟨Page CM0301 497⟩
# Page 302
⟨Page CM0302 498⟩
# Page 303
```

⟨*Page CM0303* 499⟩
```
# Page 304
```
⟨*Page CM0304* 501⟩
```
# Page 305
```
⟨*Page CM0305* 502⟩
```
# Page 303
```
⟨*Page CM0306* 503⟩

This code is written to file `src/Comanche055/IMU-COMPENSATION-PACKAGE.agc`.

A.39 IMU MODE SWITCHING ROUTINES

2709 ⟨*src/Comanche055/IMU-MODE-SWITCHING-ROUTINES.agc* 2709⟩≡

```
# Copyright:    Public domain.
# Filename:     IMU_MODE_SWITCHING_ROUTINES.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1420-1448
# Mod history:  2009-05-10 SN   (Sergio Navarro).  Started adapting from
#                               the Colossus249/ file of the same name,
#                               using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#    Assemble revision 055 of AGC program Comanche by NASA
#    2021113-051.  10:28 APR. 1, 1969
#
#    This AGC program shall also be referred to as
#            Colossus 2A

# Page 1420
⟨Page CM1420 1917⟩
# Page 1421
⟨Page CM1421 1918⟩
# Page 1422
⟨Page CM1422 1919⟩
# Page 1423
⟨Page CM1423 1920⟩
# Page 1424
⟨Page CM1424 1921⟩
# Page 1425
⟨Page CM1425 1922⟩
# Page 1426
```

⟨*Page CM1426* 1923⟩
```
# Page 1427
```
⟨*Page CM1427* 1924⟩
```
# Page 1428
```
⟨*Page CM1428* 1925⟩
```
# Page 1429
```
⟨*Page CM1429* 1926⟩
```
# Page 1430
```
⟨*Page CM1430* 1927⟩
```
# Page 1431
```
⟨*Page CM1431* 1928⟩
```
# Page 1432
```
⟨*Page CM1432* 1929⟩
```
# Page 1433
```
⟨*Page CM1433* 1930⟩
```
# Page 1434
```
⟨*Page CM1434* 1931⟩
```
# Page 1435
```
⟨*Page CM1435* 1932⟩
```
# Page 1436
```
⟨*Page CM1436* 1933a⟩
```
# Page 1437
```
⟨*Page CM1437* 1933b⟩
```
# Page 1438
```
⟨*Page CM1438* 1934⟩
```
# Page 1439
```
⟨*Page CM1439* 1935⟩
```
# Page 1440
```
⟨*Page CM1440* 1936⟩
```
# Page 1441
```
⟨*Page CM1441* 1937⟩
```
# Page 1442
```
⟨*Page CM1442* 1938⟩
```
# Page 1443
```
⟨*Page CM1443* 1939⟩
```
# Page 1444
```
⟨*Page CM1444* 1940a⟩
```
# Page 1445
```
⟨*Page CM1445* 1940b⟩
```
# Page 1446
```
⟨*Page CM1446* 1941⟩
```
# Page 1447.
```
⟨*Page CM1447* 1943⟩
```
# Page 1448
```
⟨*Page CM1448* 1944a⟩

This code is written to file `src/Comanche055/IMU-MODE-SWITCHING-ROUTINES.agc`.

A.40 IMU PERFORMANCE TEST 2

2711 ⟨*src/Luminary099/IMU-PERFORMANCE-TEST-2.agc* 2711⟩≡

```
# Copyright:    Public domain.
# Filename:     IMU_PERFORMANCE_TEST_2.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        373-381
# Mod history:  2009-05-17 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 373
⟨Page LM0373 2189⟩
# Page 374
⟨Page LM0374 2191⟩
# Page 375
⟨Page LM0375 2193⟩
# Page 376
⟨Page LM0376 2195⟩
# Page 377
⟨Page LM0377 2196⟩
# Page 378
⟨Page LM0378 2197⟩
# Page 379
⟨Page LM0379 2198⟩
# Page 380
```

⟨*Page LM0380* 2199⟩

```
# Page 381
```

⟨*Page LM0381* 2201⟩

This code is written to file `src/Luminary099/IMU-PERFORMANCE-TEST-2.agc`.

A.41 IMU PERFORMANCE TESTS 4

2713 ⟨*src/Luminary099/IMU-PERFORMANCE-TESTS-4.agc* 2713⟩≡

```
# Copyright:    Public domain.
# Filename:     IMU_PERFORMANCE_TESTS_4.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        382-389
# Mod history:  2009-05-17 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 382
⟨Page LM0382 2202b⟩
# Page 383
⟨Page LM0383 2203⟩
# Page 384
⟨Page LM0384 2204⟩
# Page 385
⟨Page LM0385 2205⟩
# Page 386
⟨Page LM0386 2207⟩
# Page 387
⟨Page LM0387 2209⟩
# Page 388
⟨Page LM0388 2211⟩
# Page 389
```

⟨*Page LM0389* 2212⟩

This code is written to file `src/Luminary099/IMU-PERFORMANCE-TESTS-4.agc`.

A.42 INFLIGHT ALIGNMENT ROUTINES

2715 ⟨*src/Comanche055/INFLIGHT-ALIGNMENT-ROUTINES.agc* 2715⟩≡

```
# Copyright:    Public domain.
# Filename:     INFLIGHT_ALIGNMENT_ROUTINES.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1355-1364
# Mod history:  2009-05-14 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 1355
⟨Page CM1355 1835⟩
# Page 1356
⟨Page CM1356 1836⟩
# Page 1357
⟨Page CM1357 1837⟩
# Page 1358
⟨Page CM1358 1838⟩
# Page 1359
⟨Page CM1359 1839⟩
# Page 1360
⟨Page CM1360 1840⟩
# Page 1361
⟨Page CM1361 1841⟩
```

```
# Page 1362
```
⟨*Page CM1362* 1842a⟩
```
# Page 1363
```
⟨*Page CM1363* 1842b⟩
```
# Page 1364 (empty page)
```
⟨*Page CM1364* 1843a⟩

This code is written to file `src/Comanche055/INFLIGHT-ALIGNMENT-ROUTINES.agc`.

A.43 INPUT OUTPUT CHANNEL BIT DESCRIPTIONS

2717 ⟨*src/Luminary099/INPUT-OUTPUT-CHANNEL-BIT-DESCRIPTIONS.agc* 2717⟩≡

```
# Copyright:    Public domain.
# Filename:     INPUT_OUTPUT_CHANNEL_BIT_DESCRIPTIONS.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Onno Hommes <ohommes@cmu.edu>.
# Website:      www.ibiblio.org/apollo.
# Pages:        0054-0060
# Mod history:  2009-05-14 OH   Transcribed from page images.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 54
⟨Page LM0054 2059⟩
# Page 55
⟨Page LM0055 2060⟩
# Page 56
⟨Page LM0056 2061⟩
# Page 57
⟨Page LM0057 2062⟩
# Page 58
⟨Page LM0058 2063⟩
# Page 59
⟨Page LM0059 2064a⟩
# Page 60
⟨Page LM0060 2064b⟩
```

This code is written to file `src/Luminary099/INPUT-OUTPUT-CHANNEL-BIT-DESCRIPTIONS.agc`.

A.44 INTEGRATION INITIALIZATION

2718 ⟨*src/Comanche055/INTEGRATION-INITIALIZATION.agc* 2718⟩≡

```
# Copyright:    Public domain.
# Filename:     INTEGRATION_INITIALIZATION.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1309-1333
# Mod history:  2009-05-15 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#               2009-05-20 RSB  Corrections:  fixed an interpreter instruction,
#                               fixed a SETLOC.
#               2009-05-23 RSB  In SETCOAST, corrected MOONTHIS to AMOONFLG.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 1309
⟨Page CM1309 1772⟩
# Page 1310
⟨Page CM1310 1774⟩
# Page 1311
⟨Page CM1311 1776⟩
# Page 1312
⟨Page CM1312 1778⟩
# Page 1313
⟨Page CM1313 1780⟩
# Page 1314
```

⟨*Page CM1314* 1782⟩
Page 1315
⟨*Page CM1315* 1784⟩
Page 1316
⟨*Page CM1316* 1786⟩
Page 1317
⟨*Page CM1317* 1788⟩
Page 1318
⟨*Page CM1318* 1790⟩
Page 1319
⟨*Page CM1319* 1792⟩
Page 1320
⟨*Page CM1320* 1794⟩
Page 1321
⟨*Page CM1321* 1796⟩
Page 1322
⟨*Page CM1322* 1797⟩
Page 1323
⟨*Page CM1323* 1798⟩
Page 1324
⟨*Page CM1324* 1800⟩
Page 1325
⟨*Page CM1325* 1802⟩
Page 1326
⟨*Page CM1326* 1803⟩
Page 1327
⟨*Page CM1327* 1804⟩
Page 1328
⟨*Page CM1328* 1805⟩
Page 1329
⟨*Page CM1329* 1806⟩
Page 1330
⟨*Page CM1330* 1808⟩
Page 1331
⟨*Page CM1331* 1810⟩
Page 1332
⟨*Page CM1332* 1812⟩
Page 1333
⟨*Page CM1333* 1813a⟩

This code is written to file `src/Comanche055/INTEGRATION-INITIALIZATION.agc`.
Uses `AMOONFLG` 97 and `MOONTHIS` 71.

A.45 INTER-BANK COMMUNICATION

2720 ⟨*src/Comanche055/INTER-BANK-COMMUNICATION.agc* 2720⟩≡

```
# Copyright:    Public domain.
# Filename:     INTER-BANK_COMMUNICATION.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 1103-1106
# Contact:      Ron Burkey <info@sandroid.org>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-08 RSB  Adapted from Colossus249/ file of same name
#                               and page images. Corrected various typos
#                               in the transcription of program comments,
#                               and these should be back-ported to
#                               Colossus249.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 1103
⟨Page CM1103 1540⟩
# Page 1104
⟨Page CM1104 1541⟩
# Page 1105
⟨Page CM1105 1542⟩
# Page 1106
⟨Page CM1106 1543⟩
```

This code is written to file `src/Comanche055/INTER-BANK-COMMUNICATION.agc`.

A.46 INTERPRETER

2721 ⟨*src/Comanche055/INTERPRETER.agc* 2721⟩≡

```
# Copyright:    Public domain.
# Filename:     INTERPRETER.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1107-1199
# Mod history:  2009-05-08 RSB  Adapted from the Luminary131/ file of the
#                               same name, using Comanche055 page images.
#               2009-05-20 RSB  Corrections:  P00D00 -> P00DOO, fixed a
#                               "Page N" reference.
#               2009-05-21 RSB  Corrected definition of 5B10, which overflowed
#                               integer arithmetic.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 1107
⟨Page CM1107 1546⟩
# Page 1108
⟨Page CM1108 1547⟩
# Page 1109
⟨Page CM1109 1548⟩
# Page 1110
⟨Page CM1110 1549⟩
# Page 1111
⟨Page CM1111 1550⟩
```

```
# Page 1112
```
⟨*Page CM1112* 1551⟩
```
# Page 1113
```
⟨*Page CM1113* 1552⟩
```
# Page 1114
```
⟨*Page CM1114* 1553a⟩
```
# Page 1115
```
⟨*Page CM1115* 1553b⟩
```
# Page 1116
```
⟨*Page CM1116* 1554⟩
```
# Page 1117
```
⟨*Page CM1117* 1555a⟩
```
# Page 1118
```
⟨*Page CM1118* 1555b⟩
```
# Page 1119
```
⟨*Page CM1119* 1556⟩
```
# Page 1120
```
⟨*Page CM1120* 1557⟩
```
# Page 1121
```
⟨*Page CM1121* 1558⟩
```
# Page 1122
```
⟨*Page CM1122* 1559⟩
```
# Page 1123
```
⟨*Page CM1123* 1560⟩
```
# Page 1124
```
⟨*Page CM1124* 1561⟩
```
# Page 1125
```
⟨*Page CM1125* 1562⟩
```
# Page 1126
```
⟨*Page CM1126* 1563⟩
```
# Page 1127
```
⟨*Page CM1127* 1564⟩
```
# Page 1128
```
⟨*Page CM1128* 1565⟩
```
# Page 1129
```
⟨*Page CM1129* 1566⟩
```
# Page 1130
```
⟨*Page CM1130* 1567⟩
```
# Page 1131
```
⟨*Page CM1131* 1568⟩
```
# Page 1132
```
⟨*Page CM1132* 1569⟩
```
# Page 1133
```
⟨*Page CM1133* 1570⟩
```
# Page 1134
```
⟨*Page CM1134* 1571a⟩
```
```

Page 1135
⟨*Page CM1135* 1571b⟩
Page 1136
⟨*Page CM1136* 1572⟩
Page 1137
⟨*Page CM1137* 1573⟩
Page 1138
⟨*Page CM1138* 1574⟩
Page 1139
⟨*Page CM1139* 1575⟩
Page 1140
⟨*Page CM1140* 1576⟩
Page 1141
⟨*Page CM1141* 1577⟩
Page 1142
⟨*Page CM1142* 1578a⟩
Page 1143
⟨*Page CM1143* 1578b⟩
Page 1144
⟨*Page CM1144* 1579⟩
Page 1145
⟨*Page CM1145* 1580⟩
Page 1146
⟨*Page CM1146* 1581⟩
Page 1147
⟨*Page CM1147* 1582⟩
Page 1148
⟨*Page CM1148* 1584⟩
Page 1149
⟨*Page CM1149* 1585⟩
Page 1150
⟨*Page CM1150* 1586⟩
Page 1151
⟨*Page CM1151* 1587⟩
Page 1152
⟨*Page CM1152* 1588⟩
Page 1153
⟨*Page CM1153* 1589⟩
Page 1154
⟨*Page CM1154* 1590⟩
Page 1155
⟨*Page CM1155* 1591⟩
Page 1156
⟨*Page CM1156* 1592⟩
Page 1157
⟨*Page CM1157* 1593⟩

```
# Page 1158
```
⟨*Page CM1158* 1594⟩
```
# Page 1159
```
⟨*Page CM1159* 1595⟩
```
# Page 1160
```
⟨*Page CM1160* 1596⟩
```
# Page 1161
```
⟨*Page CM1161* 1597⟩
```
# Page 1162
```
⟨*Page CM1162* 1598⟩
```
# Page 1163
```
⟨*Page CM1163* 1599⟩
```
# Page 1164
```
⟨*Page CM1164* 1600⟩
```
# Page 1165
```
⟨*Page CM1165* 1601⟩
```
# Page 1166
```
⟨*Page CM1166* 1602⟩
```
# Page 1167
```
⟨*Page CM1167* 1603⟩
```
# Page 1168
```
⟨*Page CM1168* 1604a⟩
```
# Page 1169
```
⟨*Page CM1169* 1604b⟩
```
# Page 1170
```
⟨*Page CM1170* 1605⟩
```
# Page 1171
```
⟨*Page CM1171* 1606⟩
```
# Page 1172
```
⟨*Page CM1172* 1607⟩
```
# Page 1173
```
⟨*Page CM1173* 1608⟩
```
# Page 1174
```
⟨*Page CM1174* 1609⟩
```
# Page 1175
```
⟨*Page CM1175* 1610⟩
```
# Page 1176
```
⟨*Page CM1176* 1611⟩
```
# Page 1177
```
⟨*Page CM1177* 1612⟩
```
# Page 1178
```
⟨*Page CM1178* 1613⟩
```
# Page 1179
```
⟨*Page CM1179* 1614⟩
```
# Page 1180
```
⟨*Page CM1180* 1615⟩
```
```

```
# Page 1181
```
⟨*Page CM1181* 1616⟩
```
# Page 1182
```
⟨*Page CM1182* 1618⟩
```
# Page 1183
```
⟨*Page CM1183* 1620⟩
```
# Page 1184
```
⟨*Page CM1184* 1621⟩
```
# Page 1185
```
⟨*Page CM1185* 1623⟩
```
# Page 1186
```
⟨*Page CM1186* 1624⟩
```
# Page 1187
```
⟨*Page CM1187* 1625⟩
```
# Page 1188
```
⟨*Page CM1188* 1626⟩
```
# Page 1189
```
⟨*Page CM1189* 1627⟩
```
# Page 1190
```
⟨*Page CM1190* 1628⟩
```
# Page 1191
```
⟨*Page CM1191* 1629⟩
```
# Page 1192
```
⟨*Page CM1192* 1630⟩
```
# Page 1193
```
⟨*Page CM1193* 1631⟩
```
# Page 1194
```
⟨*Page CM1194* 1632⟩
```
# Page 1195
```
⟨*Page CM1195* 1633⟩
```
# Page 1196
```
⟨*Page CM1196* 1634⟩
```
# Page 1197
```
⟨*Page CM1197* 1635⟩
```
# Page 1198
```
⟨*Page CM1198* 1636⟩
```
# Page 1199
```
⟨*Page CM1199* 1637a⟩
```

This code is written to file `src/Comanche055/INTERPRETER.agc`.
Uses `N` 206.
```

A.47 INTERPRETIVE CONSTANT

2726 ⟨*src/Luminary099/INTERPRETIVE-CONSTANT.agc* 2726⟩≡

```
# Copyright:    Public domain.
# Filename:     INTERPRETIVE_CONSTANT.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1100-1101
# Mod history:  2009-05-25 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 1100
⟨Page LM1100 2476⟩
# Page 1101
⟨Page LM1101 2477a⟩
```

This code is written to file `src/Luminary099/INTERPRETIVE-CONSTANT.agc`.

A.48 INTERPRETIVE CONSTANTS

2727 ⟨*src/Comanche055/INTERPRETIVE-CONSTANTS.agc* 2727⟩≡

```
# Copyright:    Public domain.
# Filename:     INTERPRETIVE_CONSTANTS.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1205-1206
# Mod history:  2009-05-13 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 1205
⟨Page CM1205 1645b⟩
# Page 1206
⟨Page CM1206 1646a⟩
```

This code is written to file `src/Comanche055/INTERPRETIVE-CONSTANTS.agc`.

A.49 INTERRUPT LEAD INS

2728 ⟨*src/Comanche055/INTERRUPT-LEAD-INS.agc* 2728⟩≡

```
# Copyright:    Public domain.
# Filename:     INTERRUPT_LEAD_INS.agc
# Purpose:      Part of the source code for Comanche, build 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 131-132
# Contact:      Ron Burkey <info@sandroid.org>,
#               Fabrizio Bernardini <fabrizio@spacecraft.it>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  09/05/09 FB     Transcription of Batch FB-1 Assignment.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 131
⟨Page CM0131 247⟩
# Page 132
⟨Page CM0132 249⟩
```

This code is written to file `src/Comanche055/INTERRUPT-LEAD-INS.agc`.

A.50 JET SELECTION LOGIC

2729 ⟨*src/Comanche055/JET-SELECTION-LOGIC.agc* 2729⟩≡

```
# Copyright:    Public domain.
# Filename:     JET_SELECTION_LOGIC.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1039-1062
# Mod history:  2009-05-13 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 1039
⟨Page CM1039 1453⟩
# Page 1040
⟨Page CM1040 1455⟩
# Page 1041
⟨Page CM1041 1456⟩
# Page 1042
⟨Page CM1042 1457⟩
# Page 1043
⟨Page CM1043 1458⟩
# Page 1044
⟨Page CM1044 1460⟩
# Page 1045
⟨Page CM1045 1461⟩
```

```
# Page 1046
```
⟨*Page CM1046* 1462⟩
```
# Page 1047
```
⟨*Page CM1047* 1463⟩
```
# Page 1048
```
⟨*Page CM1048* 1464⟩
```
# Page 1049
```
⟨*Page CM1049* 1465⟩
```
# Page 1050
```
⟨*Page CM1050* 1466⟩
```
# Page 1051
```
⟨*Page CM1051* 1467⟩
```
# Page 1052
```
⟨*Page CM1052* 1468⟩
```
# Page 1053
```
⟨*Page CM1053* 1469⟩
```
# Page 1054
```
⟨*Page CM1054* 1470a⟩
```
# Page 1055
```
⟨*Page CM1055* 1470b⟩
```
# Page 1056
```
⟨*Page CM1056* 1471⟩
```
# Page 1057
```
⟨*Page CM1057* 1473⟩
```
# Page 1058
```
⟨*Page CM1058* 1474⟩
```
# Page 1059
```
⟨*Page CM1059* 1475⟩
```
# Page 1060
```
⟨*Page CM1060* 1476⟩
```
# Page 1061
```
⟨*Page CM1061* 1477⟩
```
# Page 1062
```
⟨*Page CM1062* 1479⟩
```

This code is written to file `src/Comanche055/JET-SELECTION-LOGIC.agc`.
```

A.51 KALCMANU STEERING

2731 ⟨*src/Comanche055/KALCMANU-STEERING.agc* 2731⟩≡

```
# Copyright:    Public domain.
# Filename:     KALCMANU_STEERING.agc
# Purpose:      Part of the source code for Comanche, build 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 414-419
# Contact:      Onno Hommes <ohommes@cmu.edu>.
# Website:      www.ibiblio.org/apollo.
# Mod history:  05/07/09 OH     Transcription Batch 1 Assignment
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further information.
# Please report any errors to info@sandroid.org.

# Page 414
⟨Page CM0414 684⟩
# Page 415
⟨Page CM0415 686⟩
# Page 416
⟨Page CM0416 688⟩
# Page 417
⟨Page CM0417 689⟩
# Page 418
⟨Page CM0418 690⟩
# Page 419
⟨Page CM0419 691a⟩
```

This code is written to file `src/Comanche055/KALCMANU-STEERING.agc`.

A.52 KALMAN FILTER

2732 ⟨*src/Luminary099/KALMAN-FILTER.agc* 2732⟩≡

```
# Copyright:    Public domain.
# Filename:     KALMAN_FILTER.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1470-1471
# Mod history:  2009-05-27 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 1470
⟨Page LM1470 2572⟩
# Page 1471
⟨Page LM1471 2573⟩
```

This code is written to file `src/Luminary099/KALMAN-FILTER.agc`.

A.53 KEYRUPT UPRUPT

2733 ⟨*src/Comanche055/KEYRUPT-UPRUPT.agc* 2733⟩≡

```
# Copyright:    Public domain.
# Filename:     KEYRUPT_UPRUPT.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 1449-1451
# Contact:      Ron Burkey <info@sandroid.org>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-07 RSB  Adapted from Colossus249 file of the same
#                               name, and page images. Corrected various
#                               typos in the transcription of program
#                               comments, and these should be back-ported
#                               to Colossus249.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 1449
⟨Page CM1449 1945⟩
# Page 1450
⟨Page CM1450 1946⟩
# Page 1451
⟨Page CM1451 1947⟩
```

This code is written to file `src/Comanche055/KEYRUPT-UPRUPT.agc`.

A.54 LAMBERT AIMPOINT GUIDANCE

2734 ⟨*src/Luminary099/LAMBERT-AIMPOINT-GUIDANCE.agc* 2734⟩≡

```
# Copyright:    Public domain.
# Filename:     LAMBERT_AIMPOINT_GUIDANCE.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        651-653
# Mod history:  2009-05-18 RSB  Transcribed from Luminary 099
#                               page images.
#               2009-06-05 RSB  Corrected 4 typos.
#               2009-06-07 RSB  Fixed a typo.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

# Page 651
⟨Page LM0651 2254⟩
# Page 652
⟨Page LM0652 2256⟩
# Page 653
⟨Page LM0653 2258⟩
```

This code is written to file `src/Luminary099/LAMBERT-AIMPOINT-GUIDANCE.agc`.

A.55 LANDING ANALOG DISPLAYS

2735 ⟨*src/Luminary099/LANDING-ANALOG-DISPLAYS.agc* 2735⟩≡

```
# Copyright:    Public domain.
# Filename:     LANDING_ANALOG_DISPLAYS.agc
# Purpose:      Part of the source code for Luminary, build 099. It
#               is part of the source code for the Lunar Module's
#               (LM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 898-907
# Contact:      Ron Burkey <info@sandroid.org>,
#               Fabrizio Bernardini <fabrizio@spacecraft.it>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  05/06/09 FB     Transcription Batch 4 Assignment.
#
# The contents of the "Luminary099" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 001 of AGC program Luminary099 by NASA
#       2021112-061.  July 14, 1969.
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 898
⟨Page LM0898 2420⟩
# Page 899
⟨Page LM0899 2422⟩
# Page 900
⟨Page LM0900 2424⟩
# Page 901
⟨Page LM0901 2426⟩
# Page 902
⟨Page LM0902 2428⟩
# Page 903
⟨Page LM0903 2430⟩
# Page 904
⟨Page LM0904 2432⟩
# Page 905
```

⟨*Page LM0905* 2434⟩
```
# Page 906
```
⟨*Page LM0906* 2436⟩
```
# Page 907
```
⟨*Page LM0907* 2438⟩

This code is written to file `src/Luminary099/LANDING-ANALOG-DISPLAYS.agc`.

A.56 LATITUDE LONGITUDE SUBROUTINES

2737 ⟨*src/Comanche055/LATITUDE-LONGITUDE-SUBROUTINES.agc* 2737⟩≡

```
# Copyright:    Public domain.
# Filename:     LATITUDE_LONGITUDE_SUBROUTINES.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1236-1242
# Mod history:  2009-05-14 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 1236
⟨Page CM1236 1675⟩
# Page 1237
⟨Page CM1237 1676⟩
# Page 1238
⟨Page CM1238 1677⟩
# Page 1239
⟨Page CM1239 1679⟩
# Page 1240
⟨Page CM1240 1680⟩
# Page 1241
⟨Page CM1241 1681⟩
# Page 1242
⟨Page CM1242 1682⟩
```

This code is written to file src/Comanche055/LATITUDE-LONGITUDE-SUBROUTINES.agc.

A.57 LEM GEOMETRY

2738 ⟨*src/Luminary099/LEM-GEOMETRY.agc* 2738⟩≡

```
# Copyright:    Public domain.
# Filename:     LEM_GEOMETRY.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        320-325
# Mod history:  2009-05-16 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969
```

⟨*lem geometry* 2143⟩

This code is written to file src/Luminary099/LEM-GEOMETRY.agc.

A.58 LUNAR AND SOLAR EPHEMERIDES SUBROUTINES

2739 ⟨*src/Comanche055/LUNAR-AND-SOLAR-EPHEMERIDES-SUBROUTINES.agc* 2739⟩≡

```
# Copyright:    Public domain.
# Filename:     LUNAR_AND_SOLAR_EPHEMERIDES_SUBROUTINES.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 785-788
# Contact:      Ron Burkey <info@sandroid.org>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-12 RSB  Adapted from Colossus249 file of the same
#                               name and Comanche 055 page images.
#               2009-07-26 RSB  Added annotations related to computation
#                               of the ephemeral(?) polynomials.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.
```

⟨*lunar and solar ephemerides subroutines* 1194⟩

This code is written to file `src/Comanche055/LUNAR-AND-SOLAR-EPHEMERIDES-SUBROUTINES.agc`.

A.59 LUNAR LANDING GUIDANCE EQUATIONS

2740 ⟨*src/Luminary099/LUNAR-LANDING-GUIDANCE-EQUATIONS.agc* 2740⟩≡

```
# Copyright:    Public domain.
# Filename:     LUNAR_LANDING_GUIDANCE_EQUATIONS.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      HARTMUTH GUTSCHE <hgutsche@xplornet.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        798-828
# Mod history:  2009-05-23 HG   Transcribed from page images.
#               2009-06-05 RSB  Fixed a goofy thing that was apparently
#                               legal in GAP but not in yaYUL.  Eliminated
#                               a couple of lines of code that shouldn't
#                               have survived from Luminary 131 to here.
#               2009-06-07 RSB  Fixed a typo.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969
```

⟨*lunar landing guidance equations* 2311⟩

This code is written to file `src/Luminary099/LUNAR-LANDING-GUIDANCE-EQUATIONS.agc`.

A.60 LUNAR LANDMARK SELECTION FOR CM

2741 ⟨*src/Comanche055/LUNAR-LANDMARK-SELECTION-FOR-CM.agc* 2741⟩≡

```
# Copyright:    Public domain.
# Filename:     LUNAR_LANDMARK_SELECTION_FOR_CM.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Jim Lawton <jim.lawton@gmail.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        936
# Mod history:  2009-05-11 JVL  Adapted from the Colossus249/ file
#                               of the same name, using Comanche055 page
#                               images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#    Assemble revision 055 of AGC program Comanche by NASA
#    2021113-051.  10:28 APR. 1, 1969
#
#    This AGC program shall also be referred to as
#            Colossus 2A
```

⟨*lunar landmark selection for cm* 1346a⟩

This code is written to file `src/Comanche055/LUNAR-LANDMARK-SELECTION-FOR-CM.agc`.

A.61 MAIN

2742 ⟨*src/Comanche055/MAIN.agc* 2742⟩≡

```
# Copyright:    Public domain.
# Filename:     MAIN.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC) Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo
# Mod history:  2009-05-05 RSB  Adapted from Colossus249/MAIN.agc.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
#
# This file is a little different from the other Comanche055 files I'm providing,
# in that it doesn't represent anything that appears directly in the original source
# What I (RSB) have done for organizational purposes is to split the huge monolithic
# source code into smaller, more manageable chunks--i.e., into individual source
# files.  Those files are rejoined within this file as "includes".  It just makes
# it a little easier to work with.  The code chunks correspond to natural divisions
# into sub-programs.  In fact, these divisions are more-or-less specified by
# the source code itself.  Refer to the "SUBROUTINE CALLS" at the
# very beginning of the file ASSEMBLY_AND_OPERATION_INFORMATION.agc.
#
# It may be reasonably asked why tens of thousands of lines of source are joined by
# means of inclusion, rather than simply assembling the source files individually and
# then linking them to form the executable.  The answer is that the original
# development team had no linker.  The builds were monolithic just like this.
# There was a big emphasis on reusability of the code in the original project,
# apparently, but this reusability took the form of inserting your deck of
```

```
# punch-cards at the appropriate position in somebody else's deck of punch-cards.
# (Actually, I think the card-decks were turned into tape libraries, and the modules
# were mixed-and-matched from the tape libraries, but the principle is the same.)
# So, indeed, the method of file-inclusion is a very fair representation of the
# methods used in the original development ... with the improvement, of course,
# that you no longer have to worry about dropping the card deck.  On the other hand,
# I wasn't there at the time, so I may have no idea what I'm talking about.
#
# Finally, note that the original Apollo AGC assembler (called "YUL") is no longer
# available (as far as I can tell).  Actually, it had already been replaced by another
# assembler (called "GAP") by the time of Apollo 11, but GAP isn't available either.
# The replacement assembler yaYUL accepts a slightly different format for the source
# code from what YUL or GAP accepted, so the source code has been targeted for
# assembly with yaYUL.

# What follows is simply a bunch of file-includes for the individual code chunks.
# I've marked the page numbers to make proof-reading easier.  The page images also
# contain a lot of interesting tables (cross-referenced to page numbers) created by GAP,
# but not duplicated by yaYUL, so it's still valuable even if the source-files
# listed below are in hand.

$CONTRACT_AND_APPROVALS.agc                     # p. 1
$ASSEMBLY_AND_OPERATION_INFORMATION.agc         # pp. 2-26
$TAGS_FOR_RELATIVE_SETLOC.agc                   # pp. 27-35

                                                # p. 36 contains no code.
# COMERASE
$ERASABLE_ASSIGNMENTS.agc                       # pp. 37-130

# COMAID
$INTERRUPT_LEAD_INS.agc                         # pp. 131-132
$T4RUPT_PROGRAM.agc                             # pp. 133-169
$DOWNLINK_LISTS.agc                             # pp. 170-180
$FRESH_START_AND_RESTART.agc                    # pp. 181-210
$RESTART_TABLES.agc                             # pp. 211-221
$SXTMARK.agc                                    # pp. 222-235
$EXTENDED_VERBS.agc                             # pp. 236-267
$PINBALL_NOUN_TABLES.agc                        # pp. 268-284
$CSM_GEOMETRY.agc                               # pp. 285-296
$IMU_COMPENSATION_PACKAGE.agc                   # pp. 297-306
$PINBALL_GAME_BUTTONS_AND_LIGHTS.agc            # pp. 307-389
$R60_62.agc                                     # pp. 390-398
$ANGLFIND.agc                                   # pp. 399-411
$GIMBAL_LOCK_AVOIDANCE.agc                      # pp. 412-413
$KALCMANU_STEERING.agc                          # pp. 414-419
$SYSTEM_TEST_STANDARD_LEAD_INS.agc              # pp. 420-422
```

```
$IMU_CALIBRATION_AND_ALIGNMENT.agc              # pp. 423-455

# COMEKISS
$GROUND_TRACKING_DETERMINATION_PROGRAM.agc      # pp. 456-459
$P34-35_P74-75.agc                              # pp. 460-504
$R31.agc                                        # pp. 505-510
$P76.agc                                        # pp. 511-513
$R30.agc                                        # pp. 514-524
$STABLE_ORBIT.agc                               # pp. 525-532

# TROUBLE
$P11.agc                                        # pp. 533-550
$TPI_SEARCH.agc                                 # pp. 551-561
$P20-P25.agc                                    # pp. 562-634
$P30-P37.agc                                    # pp. 635-648
$P32-P33_P72-P73.agc                            # pp. 649-683
$P40-P47.agc                                    # pp. 684-736
$P51-P53.agc                                    # pp. 737-784
$LUNAR_AND_SOLAR_EPHEMERIDES_SUBROUTINES.agc    # pp. 785-788
$P61-P67.agc                                    # pp. 789-818
$SERVICER207.agc                                # pp. 819-836
$ENTRY_LEXICON.agc                              # pp. 837-843
$REENTRY_CONTROL.agc                            # pp. 844-882
$CM_BODY_ATTITUDE.agc                           # pp. 883-889
$P37_P70.agc                                    # pp. 890-933
$S-BAND_ANTENNA_FOR_CM.agc                      # pp. 934-935
$LUNAR_LANDMARK_SELECTION_FOR_CM.agc            # pp. 936

# TVCDAPS
$TVCINITIALIZE.agc                              # pp. 937-944
$TVCEXECUTIVE.agc                               # pp. 945-950
$TVCMASSPROP.agc                                # pp. 951-955
$TVCRESTARTS.agc                                # pp. 956-960
$TVCDAPS.agc                                    # pp. 961-978
$TVCSTROKETEST.agc                              # pp. 979-983
$TVCROLLDAP.agc                                 # pp. 984-998
$MYSUBS.agc                                     # pp. 999-1001
$RCS-CSM_DIGITAL_AUTOPILOT.agc                  # pp. 1002-1024
$AUTOMATIC_MANEUVERS.agc                        # pp. 1025-1036
$RCS-CSM_DAP_EXECUTIVE_PROGRAMS.agc             # pp. 1037-1038
$JET_SELECTION_LOGIC.agc                        # pp. 1039-1062
$CM_ENTRY_DIGITAL_AUTOPILOT.agc                 # pp. 1063-1092

# CHIEFTAN
$DOWN-TELEMETRY_PROGRAM.agc                     # pp. 1093-1102
$INTER-BANK_COMMUNICATION.agc                   # pp. 1103-1106
```

```
$INTERPRETER.agc                                # pp. 1107-1199
$FIXED_FIXED_CONSTANT_POOL.agc                  # pp. 1200-1204
$INTERPRETIVE_CONSTANTS.agc                     # pp. 1205-1206
$SINGLE_PRECISION_SUBROUTINES.agc               # p.  1207
$EXECUTIVE.agc                                  # pp. 1208-1220
$WAITLIST.agc                                   # pp. 1221-1235
$LATITUDE_LONGITUDE_SUBROUTINES.agc             # pp. 1236-1242
$PLANETARY_INERTIAL_ORIENTATION.agc             # pp. 1243-1251
$MEASUREMENT_INCORPORATION.agc                  # pp. 1252-1261
$CONIC_SUBROUTINES.agc                          # pp. 1262-1308
$INTEGRATION_INITIALIZATION.agc                 # pp. 1309-1333
$ORBITAL_INTEGRATION.agc                        # pp. 1334-1354
$INFLIGHT_ALIGNMENT_ROUTINES.agc                # pp. 1355-1364
$POWERED_FLIGHT_SUBROUTINES.agc                 # pp. 1365-1372
$TIME_OF_FREE_FALL.agc                          # pp. 1373-1388
$STAR_TABLES.agc                                # pp. 1389-1393
$AGC_BLOCK_TWO_SELF-CHECK.agc                   # pp. 1394-1403
$PHASE_TABLE_MAINTENANCE.agc                    # pp. 1404-1413
$RESTARTS_ROUTINE.agc                           # pp. 1414-1419
$IMU_MODE_SWITCHING_ROUTINES.agc                # pp. 1420-1448
$KEYRUPT_UPRUPT.agc                             # pp. 1449-1451
$DISPLAY_INTERFACE_ROUTINES.agc                 # pp. 1452-1484
$SERVICE_ROUTINES.agc                           # pp. 1485-1492
$ALARM_AND_ABORT.agc                            # pp. 1493-1496
$UPDATE_PROGRAM.agc                             # pp. 1497-1507
$RT8_OP_CODES.agc                               # pp. 1508-1516

                                                # pp. 1517-1751: GAP-generated tables.
```

This code is written to file `src/Comanche055/MAIN.agc`.
Uses `I` 206, `MYSUBS` 63, and `R31` 67.

A.62 MEASUREMENT INCORPORATION

2746 ⟨*src/Comanche055/MEASUREMENT-INCORPORATION.agc* 2746⟩≡

```
# Copyright:    Public domain.
# Filename:     MEASUREMENT_INCORPORATION.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1252-1261
# Mod history:  2009-05-14 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 1252
⟨Page CM1252 1693⟩
# Page 1253
⟨Page CM1253 1695⟩
# Page 1254
⟨Page CM1254 1697⟩
# Page 1255
⟨Page CM1255 1698⟩
# Page 1256
⟨Page CM1256 1699⟩
# Page 1257
⟨Page CM1257 1701⟩
# Page 1258
⟨Page CM1258 1703⟩
```

```
# Page 1259
```
⟨*Page CM1259* 1705⟩
```
# Page 1260
```
⟨*Page CM1260* 1707⟩
```
# Page 1261
```
⟨*Page CM1261* 1709⟩

This code is written to file `src/Comanche055/MEASUREMENT-INCORPORATION.agc`.

A.63 MYSUBS

2747 ⟨*src/Comanche055/MYSUBS.agc* 2747⟩≡

```
# Copyright:    Public domain.
# Filename:     MYSUBS.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        999-1001
# Mod history:  2009-05-13 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#               2009-05-20 RSB  Corrections: EBANK= changed from MPAC to KMPAC.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
```

⟨*mysubs code* 1409⟩

This code is written to file `src/Comanche055/MYSUBS.agc`.
Uses `EBANK` 80, `KMPAC` 209, `MPAC` 145, and `MYSUBS` 63.

A.64 ORBITAL INTEGRATION

2748 ⟨*src/Comanche055/ORBITAL-INTEGRATION.agc* 2748⟩≡

```
# Copyright:    Public domain.
# Filename:     ORBITAL_INTEGRATION.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1334-1354
# Mod history:  2009-05-14 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#               2009-05-20 RSB  Corrections:  DAT -> DAD in one place,
#                               BWM -> BMN, DEFEQCNT -> DIFEQCNT.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
```

⟨*orbital integration* 1813b⟩

This code is written to file `src/Comanche055/ORBITAL-INTEGRATION.agc`.
Uses `DIFEQCNT` 169.

A.65 P11

2749 ⟨*src/Comanche055/P11.agc* 2749⟩≡

```
# Copyright:    Public domain.
# Filename:     P11.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Hartmuth Gutsche <hgutsche@xplornet.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        533-550
# Mod history:  2009-05-13 HG   Started adapting from the Colossus249/ file
#                               of the same name, using Comanche055 page
#                               images 0533.jpg - 0550.jpg.
#               2009-05-20 RSB  Corrections: ERTHALT -> EARTHALT,
#                               STATSW -> SATSW.
#               2009-05-23 RSB  At end of RESCALES, corrected TC 0 to TC Q.
#                               Added an SBANK= prior to a 2CADR.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#    Assemble revision 055 of AGC program Comanche by NASA
#    2021113-051.  10:28 APR. 1, 1969
#
#    This AGC program shall also be referred to as
#            Colossus 2A
# Page 533
⟨Page CM0533 858⟩
# Page 534
⟨Page CM0534 860⟩
# Page 535
⟨Page CM0535 862⟩
# Page 536
⟨Page CM0536 864⟩
# Page 537
⟨Page CM0537 866⟩
```

```
# Page 538
```
⟨*Page CM0538* 868⟩
```
# Page 539
```
⟨*Page CM0539* 870⟩
```
#Page 540
```
⟨*Page CM0540* 872⟩
```
#Page 541
```
⟨*Page CM0541* 874⟩
```
#Page 542
```
⟨*Page CM0542* 876⟩
```
#Page 543
```
⟨*Page CM0543* 878⟩
```
# Page 544
```
⟨*Page CM0544* 880⟩
```
# Page 545
```
⟨*Page CM0545* 882⟩
```
# Page 546
```
⟨*Page CM0546* 884⟩
```
# Page 547
```
⟨*Page CM0547* 886⟩
```
#Page 548
```
⟨*Page CM0548* 888⟩
```
#Page 549
```
⟨*Page CM0549* 890⟩
```
#Page 550
```
⟨*Page CM0550* 891⟩

This code is written to file `src/Comanche055/P11.agc`.
Uses `Q` 80, `SATSW` 221, and `TC` 169.

A.66 P12

2751 ⟨*src/Luminary099/P12.agc* 2751⟩≡

```
# Copyright:    Public domain.
# Filename:     P12.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Hartmuth Gutsche <hgutsche@xplornet.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        838-842
# Mod history:  2009-05-23 HG   Transcribed from page images.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969
```

⟨*p12 routine* 2353⟩

This code is written to file `src/Luminary099/P12.agc`.

A.67 P20-P25

2752 ⟨*src/Comanche055/P20-P25.agc* 2752⟩≡

```
# Copyright:    Public domain.
# Filename:     P20-P25.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        562-534
# Mod history:  2009-05-10 RSB  Adapted from the Colossus249/ file
#                               of the same name, using Comanche055 page
#                               images.
#               2009-05-20 RSB  Corrections:  P20S -> P20S, STO -> STQ,
#                               GOTOP00H -> GOTOP00H, a duplicated EXTEND
#                               was fixed, P23.10 -> R23.10,
#                               S22B0X44 -> S22B0X44, S22SUBSCL -> 22SUBSCL,
#                               S22DPP -> S22DSPP, changed some instructions in
#                               P23.152.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 562
⟨Page CM0562 915⟩
# Page 563
⟨Page CM0563 917⟩
# Page 564
⟨Page CM0564 918⟩
# Page 565
```

⟨*Page CM0565* 919⟩
Page 566
⟨*Page CM0566* 921⟩
Page 567
⟨*Page CM0567* 923⟩
Page 568
⟨*Page CM0568* 925⟩
Page 569
⟨*Page CM0569* 926⟩
Page 570
⟨*Page CM0570* 927⟩
Page 571
⟨*Page CM0571* 929⟩
Page 572
⟨*Page CM0572* 930⟩
Page 573
⟨*Page CM0573* 932⟩
Page 574
⟨*Page CM0574* 934⟩
Page 575
⟨*Page CM0575* 936⟩
Page 576
⟨*Page CM0576* 937⟩
Page 577
⟨*Page CM0577* 938⟩
Page 578
⟨*Page CM0578* 939⟩
Page 579
⟨*Page CM0579* 941⟩
Page 580
⟨*Page CM0580* 943⟩
Page 581
⟨*Page CM0581* 945⟩
Page 582
⟨*Page CM0582* 947⟩
Page 583
⟨*Page CM0583* 949⟩
Page 584
⟨*Page CM0584* 951⟩
Page 585
⟨*Page CM0585* 953⟩
Page 586
⟨*Page CM0586* 955⟩
Page 587
⟨*Page CM0587* 957⟩
Page 588

⟨*Page CM0588* 959⟩
Page 589
⟨*Page CM0589* 960⟩
Page 590
⟨*Page CM0590* 961⟩
Page 591
⟨*Page CM0591* 963⟩
Page 592
⟨*Page CM0592* 965⟩
Page 593
⟨*Page CM0593* 967⟩
Page 594
⟨*Page CM0594* 969⟩
Page 595
⟨*Page CM0595* 971⟩
Page 596
⟨*Page CM0596* 973⟩
Page 597
⟨*Page CM0597* 975⟩
Page 598
⟨*Page CM0598* 977⟩
Page 599
⟨*Page CM0599* 979⟩
Page 600
⟨*Page CM0600* 981⟩
Page 601
⟨*Page CM0601* 983⟩
Page 602
⟨*Page CM0602* 985⟩
Page 603
⟨*Page CM0603* 987⟩
Page 604
⟨*Page CM0604* 989⟩
Page 605
⟨*Page CM0605* 991⟩
Page 606
⟨*Page CM0606* 993⟩
Page 607
⟨*Page CM0607* 995⟩
Page 608
⟨*Page CM0608* 997⟩
Page 609
⟨*Page CM0609* 999⟩
Page 610
⟨*Page CM0610* 1001⟩
Page 611

⟨*Page CM0611* 1003⟩
Page 612
⟨*Page CM0612* 1005⟩
Page 613
⟨*Page CM0613* 1007⟩
Page 614
⟨*Page CM0614* 1009⟩
Page 615
⟨*Page CM0615* 1010⟩
Page 616
⟨*Page CM0616* 1011⟩
Page 617
⟨*Page CM0617* 1013⟩
Page 618
⟨*Page CM0618* 1014⟩
Page 619
⟨*Page CM0619* 1015⟩
Page 620
⟨*Page CM0620* 1017⟩
Page 621
⟨*Page CM0621* 1019⟩
Page 622
⟨*Page CM0622* 1021⟩
Page 623
⟨*Page CM0623* 1023⟩
Page 624
⟨*Page CM0624* 1024⟩
Page 625
⟨*Page CM0625* 1025⟩
Page 626
⟨*Page CM0626* 1027⟩
Page 622
⟨*Page CM0627* 1029⟩
Page 628
⟨*Page CM0628* 1031⟩
Page 629
⟨*Page CM0629* 1033⟩
Page 630
⟨*Page CM0630* 1035⟩
Page 631
⟨*Page CM0631* 1037⟩
Page 632
⟨*Page CM0632* 1039⟩
Page 633
⟨*Page CM0633* 1041⟩
Page 634

⟨*Page CM0634* 1042a⟩
This code is written to file `src/Comanche055/P20-P25.agc`.
Uses `22SUBSCL` 190 and `P20S` 69.

A.68 P30 P37

2756 ⟨*src/Luminary099/P30–P37.agc* 2756⟩≡

```
# Copyright:    Public domain.
# Filename:     P30_P37.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        614-617
# Mod history:  2009-05-17 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#               2009-06-05 RSB  Removed 4 lines of code that shouldn't
#                               have survived from Luminary 131.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969
```

⟨*p30-p37 routines* 2218⟩
This code is written to file `src/Luminary099/P30--P37.agc`.

A.69 P30-P37

2757 ⟨*src/Comanche055/P30-P37.agc* 2757⟩≡

```
# Copyright:    Public domain.
# Filename:     P30-P37.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        635-648
# Mod history:  2009-05-10 RSB  Adapted from the Colossus249/ file
#                               of the same name, using Comanche055 page
#                               images.
#               2009-05-20 RSB  Corrected BDV -> BOV.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 635
⟨Page CM0635 1043⟩
# Page 636
⟨Page CM0636 1045⟩
# Page 637
⟨Page CM0637 1047⟩
# Page 638
⟨Page CM0638 1048⟩
# Page 639
⟨Page CM0639 1049⟩
# Page 640
⟨Page CM0640 1051⟩
```

```
# Page 641
```
⟨*Page CM0641* 1052⟩
```
# Page 642
```
⟨*Page CM0642* 1053⟩
```
# Page 643
```
⟨*Page CM0643* 1054⟩
```
# Page 644
```
⟨*Page CM0644* 1056⟩
```
# Page 645
```
⟨*Page CM0645* 1058⟩
```
# Page 646
```
⟨*Page CM0646* 1059⟩
```
# Page 641
```
⟨*Page CM0646a* 1060⟩
```
# Page 647
```
⟨*Page CM0647* 1061⟩
```
# Page 648
```
⟨*Page CM0648* 1062a⟩

This code is written to file `src/Comanche055/P30-P37.agc`.

A.70 P32-P33 P72-P73

2759 ⟨*src/Comanche055/P32-P33-P72-P73.agc* 2759⟩≡

```
# Copyright:    Public domain.
# Filename:     P32-P33_P72-P73.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        649-683
# Mod history:  2009-05-09 RSB  Adapted from the Luminary131/ file
#                               P32-P35_P72-P75.agc and Comanche055 page
#                               images.
#               2009-05-20 RSB  Corrected CSI/COM3 -> CSI/CDH3,
#                               CSI/CDHI -> CSI/CDH1, CDHTAB -> CDHTAG,
#                               changed a SETLOC from CSI/CDH to CSI/CDH1,
#                               a SETLOC CSI/CDH1 to CSIPROG.
#               2009-05-21 RSB  Changed a P32/P72D to P32/P72E in
#                               P32/P72D.  DP1/4TH changed to DP1/4 in
#                               CDHMVR.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
```

⟨*p32-p33 p72-p73 code* 1062b⟩

This code is written to file `src/Comanche055/P32-P33-P72-P73.agc`.
Uses `CDHTAG` 59, `CSI/CDH` 69, `CSI/CDH1` 57, `CSI/CDH3` 61, and `CSIPROG` 59.

A.71 P32-P35 P72-P75

2760 ⟨*src/Luminary099/P32-P35-P72-P75.agc* 2760⟩≡

```
# Copyright:    Public domain.
# Filename:     P32-P35_P72-P75.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        618-650
# Mod history:  2009-05-18 RSB  Adapted from the Luminary 131 file of the
#                               same name, as corrected from Luminary 099
#                               page images.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

⟨p32-p35 p72-p75 routines 2223⟩
```

This code is written to file `src/Luminary099/P32-P35-P72-P75.agc`.

A.72 P34-35 P74-75

2761 ⟨*src/Comanche055/P34-35-P74-75.agc* 2761⟩≡

```
# Copyright:    Public domain.
# Filename:     P34-35_P74-75.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 460-504
# Contact:      Onno Hommes <ohommes@cmu.edu>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-10 OH   Batch 2 Assignment Comanche Transcription
#               2009-05-23 RSB  In DISPLAYE, corrected a CADR GOFLASHR
#                               to CADR GOFLASH.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.


# Page 460
⟨Page CM0460 752⟩
# Page 461
⟨Page CM0461 753⟩
# Page 462
⟨Page CM0462 754⟩
# Page 463
⟨Page CM0463 756⟩
# Page 464
⟨Page CM0464 758⟩
# Page 465
```

⟨*Page CM0465* 759⟩
Page 466
⟨*Page CM0466* 760⟩
Page 467
⟨*Page CM0467* 761⟩
Page 468
⟨*Page CM0468* 762⟩
Page 469
⟨*Page CM0469* 763⟩
Page 470
⟨*Page CM0470* 765⟩
Page 471
⟨*Page CM0471* 767⟩
Page 472
⟨*Page CM0472* 769⟩
Page 473
⟨*Page CM0473* 770a⟩
Page 474
⟨*Page CM0474* 770b⟩
Page 475
⟨*Page CM0475* 771⟩
Page 476
⟨*Page CM0476* 772⟩
Page 477
⟨*Page CM0477* 773⟩
Page 478
⟨*Page CM0478* 774⟩
Page 479
⟨*Page CM0479* 775⟩
Page 480
⟨*Page CM0480* 777⟩
Page 481
⟨*Page CM0481* 779⟩
Page 482
⟨*Page CM0482* 780⟩
Page 483
⟨*Page CM0483* 781⟩
Page 484
⟨*Page CM0484* 782⟩
Page 485
⟨*Page CM0485* 783⟩
Page 486
⟨*Page CM0486* 784⟩
Page 487
⟨*Page CM0487* 786⟩
Page 488

⟨*Page CM0488* 788⟩
```
# Page 489
```
⟨*Page CM0489* 790⟩
```
# Page 490
```
⟨*Page CM0490* 792⟩
```
# Page 491
```
⟨*Page CM0491* 793⟩
```
# Page 492
```
⟨*Page CM0492* 794⟩
```
# Page 493
```
⟨*Page CM0493* 795⟩
```
# Page 494
```
⟨*Page CM0494* 796⟩
```
# Page 495
```
⟨*Page CM0495* 797⟩
```
# Page 496
```
⟨*Page CM0496* 798⟩
```
# Page 497
```
⟨*Page CM0497* 799⟩
```
# Page 498
```
⟨*Page CM0498* 800a⟩
```
# Page 499
```
⟨*Page CM0499* 800b⟩
```
# Page 500
```
⟨*Page CM0500* 801⟩
```
# Page 501
```
⟨*Page CM0501* 802⟩
```
# Page 502
```
⟨*Page CM0502* 804⟩
```
# Page 503
```
⟨*Page CM0503* 806⟩
```
# Page 504
```
⟨*Page CM0504* 808⟩

This code is written to file `src/Comanche055/P34-35-P74-75.agc`.

A.73 P37 P70

2764 ⟨*src/Comanche055/P37-P70.agc* 2764⟩≡

```
# Copyright:    Public domain.
# Filename:     P37_P70.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Jim Lawton <jim.lawton@gmail.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        890-933
# Mod history:  2009-05-11 JVL  Adapted from the Colossus249/ file
#                               of the same name, using Comanche055 page
#                               images.
#               2009-05-20 RSB  Added missing label V2T179.  Fixed P00D00 -> P00D00.
#               2009-05-23 RSB  In RTD18, corrected a STOVL DELVLVC to
#                               STODL DELVLVC and a STODL 02D to STORE 02D.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#    Assemble revision 055 of AGC program Comanche by NASA
#    2021113-051.  10:28 APR. 1, 1969
#
#    This AGC program shall also be referred to as
#            Colossus 2A
```

⟨*p37 p70 code* 1300b⟩

This code is written to file `src/Comanche055/P37-P70.agc`.
Uses `DELVLVC` 224.

A.74 P40-P47

2765 ⟨*src/Comanche055/P40-P47.agc* 2765⟩≡

```
# Copyright:    Public domain.
# Filename:     P40-P47.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        684-736
# Mod history:  2009-05-11 RSB  Adapted from the Colossus249/ file
#                               of the same name, using Comanche055 page
#                               images.
#               2009-05-20 RSB  In S20.1, a DMP DDV was corrected to DMPR DDV.
#               2009-05-22 RSB  In BESTTRIM, TC PACTOFF corrected to
#                               TS PACTOFF.
#               2009-05-23 RSB  Prior to the 2CADR at T5IDLDAP, added an
#                               SBANK.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
```

⟨*p40-p47 code* 1093⟩

This code is written to file `src/Comanche055/P40-P47.agc`.
Uses `PACTOFF` 198 and `TC` 169.

A.75 P51-P53

2766 ⟨*src/Comanche055/P51-P53.agc* 2766⟩≡

```
# Copyright:    Public domain.
# Filename:     P51-P53.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 737-784
# Contact:      Ron Burkey <info@sandroid.org>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-12 RSB  Adapted from Colossus249 file of the same
#                               name, and Comanche 055 page images.
#               2009-05-20 RSB  Corrections: SETI/PDT -> SET1/PDT,
#                               GOTOPOOH -> GOTOP00H, R33EXIT -> R53EXIT,
#                               V853 -> VB53, R56A -> R56A1 (some places
#                               only), added missing R56A1 label, added a
#                               missing CAF in COARSTYP, corrected a SETLOC
#                               from P50S to P50S3.
#               2009-05-21 RSB  In COARFINE, a TC BANKCALL was corrected to
#                               TC PHASCHNG.  In R53C, a CADR GOFLASHR was
#                               corrected to CADR GOFLASH.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.
```

⟨*p51-p53 code* 1146⟩

This code is written to file `src/Comanche055/P51-P53.agc`.
Uses `P50S` 61, `P50S3` 63, `R53EXIT` 224, and `TC` 169.

A.76 P61-P67

2767 ⟨*src/Comanche055/P61-P67.agc* 2767⟩≡

```
# Copyright:    Public domain.
# Filename:     P61-P67.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 789-818
# Contact:      Ron Burkey <info@sandroid.org>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-12 RSB  Adapted from Colossus249 file of the same
#                               name and Comanche 055 page images.
#               2009-05-20 RSB  Corrections:  V06N68 -> V06N74, added missing
#                               definition of V06N74, in several
#                               interpreter operands fixed stuff like
#                               N-M,1 to N -M,1
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.
```

⟨*p61-p67 code* 1199⟩

This code is written to file `src/Comanche055/P61-P67.agc`.
Uses `N` 206.

A.77 P70-P71

2768 ⟨*src/Luminary099/P70-P71.agc* 2768⟩≡

```
# Copyright:    Public domain.
# Filename:     P70-P71.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Hartmuth Gutsche <hgutsche@xplornet.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        829-837
# Mod history:  2009-05-23 HG   Transcribed from page images.
#               2009-06-05 RSB  Fixed a typo.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

⟨p70-p71 routines 2343⟩
```

This code is written to file `src/Luminary099/P70-P71.agc`.

A.78 P76

2769 ⟨*src/Comanche055/P76.agc* 2769⟩≡

```
# Copyright:    Public domain.
# Filename:     P76.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Hartmuth Gutsche <hgutsche@xplornet.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        pp  511-513
# Mod history:  2009-05-08 HG    Adapting from the Luminary131/ file
#               of the same name, using Comanche055 page
#               images 0511.jpg - 0513.jpg.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#    Assemble revision 055 of AGC program Comanche by NASA
#    2021113-051.  10:28 APR. 1, 1969
#
#    This AGC program shall also be referred to as
#            Colossus 2A

# Page 511
⟨Page CM0511 820⟩
# Page 512
⟨Page CM0512 822⟩
# Page 513
⟨Page CM0513 823⟩
```

This code is written to file `src/Comanche055/P76.agc`.

A.79 P-AXIS RCS AUTOPILOT

2770 ⟨*src/Luminary099/P-AXIS-RCS-AUTOPILOT.agc* 2770⟩≡

```
# Copyright:    Public domain.
# Filename:     P-AXIS_RCS_AUTOPILOT.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1421-1441
# Mod history:  2009-05-27 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#               2009-06-05 RSB  Corrected a relative jump from
#                               +8 to +8D.
#               2009-06-07 RSB  Corrected a typo.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969
```

⟨*p axis rcs autopilot* 2519⟩

This code is written to file `src/Luminary099/P-AXIS-RCS-AUTOPILOT.agc`.
Uses `P` 188.

A.80 PHASE TABLE MAINTENANCE

2771 ⟨*src/Comanche055/PHASE-TABLE-MAINTENANCE.agc* 2771⟩≡

```
# Copyright:    Public domain.
# Filename:     PHASE_TABLE_MAINTENANCE.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1404-1413
# Mod history:  2009-05-10 SN   (Sergio Navarro).  Started adapting
#                               from the Colossus249/ file of the same
#                               name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#    Assemble revision 055 of AGC program Comanche by NASA
#    2021113-051.  10:28 APR. 1, 1969
#
#    This AGC program shall also be referred to as
#            Colossus 2A

# Page 1404
⟨Page CM1404 1891⟩
# Page 1405
⟨Page CM1405 1892⟩
# Page 1406
⟨Page CM1406 1893⟩
# Page 1407
⟨Page CM1407 1894⟩
# Page 1408
⟨Page CM1408 1895⟩
# Page 1409
⟨Page CM1409 1896⟩
# Page 1410
```

⟨*Page CM1410* 1898⟩
```
# Page 1411
```
⟨*Page CM1411* 1900⟩
```
# Page 1412
```
⟨*Page CM1412* 1902⟩
```
# Page 1413
```
⟨*Page CM1413* 1903⟩

This code is written to file `src/Comanche055/PHASE-TABLE-MAINTENANCE.agc`.

A.81 PINBALL GAME BUTTONS AND LIGHTS

2773 ⟨*src/Comanche055/PINBALL-GAME-BUTTONS-AND-LIGHTS.agc* 2773⟩≡

```
# Copyright:    Public domain.
# Filename:     PINBALL_GAME_BUTTONS_AND_LIGHTS.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        307-389
# Mod history:  2009-05-08 RSB  Started adapting from the Colossus249/ file
#                               of the same name, using Comanche055 page
#                               images.  Finished through page 329.
#               2009-05-09 RSB  Finished first draft.
#               2009-05-20 RSB  Corrected a CHKPOOH to CHKPOOH.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 307
⟨Page CM0307 506⟩
# Page 308
⟨Page CM0308 508⟩
# Page 309
⟨Page CM0309 510⟩
# Page 310
⟨Page CM0310 512⟩
# Page 311
⟨Page CM0311 514⟩
# Page 312
```

⟨*Page CM0312* 515⟩
Page 313
⟨*Page CM0313* 517⟩
Page 314
⟨*Page CM0314* 518⟩
Page 315
⟨*Page CM0315* 519⟩
Page 316
⟨*Page CM0316* 521⟩
Page 317
⟨*Page CM0317* 523⟩
Page 318
⟨*Page CM0318* 525⟩
Page 319
⟨*Page CM0319* 527⟩
Page 320
⟨*Page CM0320* 529⟩
Page 321
⟨*Page CM0321* 531⟩
Page 322
⟨*Page CM0322* 533⟩
Page 323
⟨*Page CM0323* 535⟩
Page 324
⟨*Page CM0324* 537⟩
Page 325
⟨*Page CM0325* 539⟩
Page 326
⟨*Page CM0326* 540⟩
Page 327
⟨*Page CM0327* 541⟩
Page 328
⟨*Page CM0328* 543⟩
Page 329
⟨*Page CM0329* 544⟩
Page 330
⟨*Page CM0330* 545⟩
Page 331
⟨*Page CM0331* 547⟩
Page 332
⟨*Page CM0332* 549⟩
Page 333
⟨*Page CM0333* 551⟩
Page 334
⟨*Page CM0334* 553⟩
Page 335

⟨*Page CM0335* 555⟩
Page 336
⟨*Page CM0336* 557⟩
Page 337
⟨*Page CM0337* 559⟩
Page 338
⟨*Page CM0338* 561⟩
Page 339
⟨*Page CM0339* 563⟩
Page 340
⟨*Page CM0340* 565⟩
Page 341
⟨*Page CM0341* 567⟩
Page 342
⟨*Page CM0342* 568⟩
Page 343
⟨*Page CM0343* 569⟩
Page 344
⟨*Page CM0344* 571⟩
Page 345
⟨*Page CM0345* 573⟩
Page 346
⟨*Page CM0346* 575⟩
Page 347
⟨*Page CM0347* 577⟩
Page 348
⟨*Page CM0348* 579⟩
Page 349
⟨*Page CM0349* 581⟩
Page 350
⟨*Page CM0350* 583⟩
Page 351
⟨*Page CM0351* 585⟩
Page 352
⟨*Page CM0352* 587⟩
Page 353
⟨*Page CM0353* 589⟩
Page 354
⟨*Page CM0354* 590⟩
Page 355
⟨*Page CM0355* 591⟩
Page 356
⟨*Page CM0356* 593⟩
Page 357
⟨*Page CM0357* 595⟩
Page 358

⟨*Page CM0358* 596⟩
Page 359
⟨*Page CM0359* 597⟩
Page 360
⟨*Page CM0360* 599⟩
Page 361
⟨*Page CM0361* 601⟩
Page 362
⟨*Page CM0362* 603⟩
Page 363
⟨*Page CM0363* 605⟩
Page 364
⟨*Page CM0364* 607⟩
Page 365
⟨*Page CM0365* 609⟩
Page 366
⟨*Page CM0366* 611⟩
Page 367
⟨*Page CM0367* 612⟩
Page 368
⟨*Page CM0368* 613⟩
Page 369
⟨*Page CM0369* 615⟩
Page 370
⟨*Page CM0370* 617⟩
Page 371
⟨*Page CM0371* 619⟩
Page 372
⟨*Page CM0372* 621⟩
Page 373
⟨*Page CM0373* 623⟩
Page 374
⟨*Page CM0374* 625⟩
Page 375
⟨*Page CM0375* 627⟩
Page 376
⟨*Page CM0376* 629⟩
Page 377
⟨*Page CM0377* 630⟩
Page 378
⟨*Page CM0378* 631⟩
Page 379
⟨*Page CM0379* 633⟩
Page 380
⟨*Page CM0380* 635⟩
Page 381

⟨*Page CM0381* 637⟩
```
# Page 382
```
⟨*Page CM0382* 638⟩
```
# Page 383
```
⟨*Page CM0383* 639a⟩
```
# Page 384
```
⟨*Page CM0384* 639b⟩
```
# Page 385
```
⟨*Page CM0385* 640⟩
```
# Page 386
```
⟨*Page CM0386* 642⟩
```
# Page 387
```
⟨*Page CM0387* 643⟩
```
# Page 388
```
⟨*Page CM0388* 644⟩
```
# Page 389
```
⟨*Page CM0389* 645⟩

This code is written to file `src/Comanche055/PINBALL-GAME-BUTTONS-AND-LIGHTS.agc`.

A.82 PINBALL NOUN TABLES

2778 ⟨*src/Comanche055/PINBALL-NOUN-TABLES.agc* 2778⟩≡

```
# Copyright:    Public domain.
# Filename:     PINBALL_NOUN_TABLES.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 268-284
# Contact:      Ron Burkey <info@sandroid.org>,
#               Fabrizio Bernardini <fabrizio@spacecraft.it>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-18 FB   Transcription Batch 3 Assignment.
#               2009-05-23 RSB  In NNTYPTAB, corrected former 13 SPARE.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 268
⟨Page CM0268 450⟩
# Page 269
⟨Page CM0269 451⟩
# Page 270
⟨Page CM0270 452⟩
# Page 271
⟨Page CM0271 454⟩
# Page 272
⟨Page CM0272 456⟩
# Page 273
⟨Page CM0273 458⟩
```

```
# Page 274
```
⟨*Page CM0274* 460⟩
```
# Page 275
```
⟨*Page CM0275* 462⟩
```
# Page 276
```
⟨*Page CM0276* 464⟩
```
# Page 277
```
⟨*Page CM0277* 466⟩
```
# Page 278
```
⟨*Page CM0278* 468⟩
```
# Page 279
```
⟨*Page CM0279* 470⟩
```
# Page 280
```
⟨*Page CM0280* 472⟩
```
# Page 281
```
⟨*Page CM0281* 474⟩
```
# Page 282
```
⟨*Page CM0282* 476⟩
```
# Page 283
```
⟨*Page CM0283* 478⟩
```
# Page 284
```
⟨*Page CM0284* 479⟩
```

This code is written to file `src/Comanche055/PINBALL-NOUN-TABLES.agc`.
```

A.83 PLANETARY INERTIAL ORIENTATION

2780 ⟨*src/Comanche055/PLANETARY-INERTIAL-ORIENTATION.agc* 2780⟩≡

```
# Copyright:    Public domain.
# Filename:     PLANETARY_INERTIAL_ORIENTATION.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1243-1251
# Mod history:  2009-05-14 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
```

⟨*planetary inertial orientation* 1683⟩

This code is written to file `src/Comanche055/PLANETARY-INERTIAL-ORIENTATION.agc`.

A.84 POWERED FLIGHT SUBROUTINES

2781 ⟨*src/Comanche055/POWERED-FLIGHT-SUBROUTINES.agc* 2781⟩≡

```
# Copyright:    Public domain.
# Filename:     POWERED_FLIGHT_SUBROUTINES.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1365-1372
# Mod history:  2009-05-10 SN   (Sergio Navarro).  Started adapting
#                               from the Colossus249/ file of the same
#                               name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#    Assemble revision 055 of AGC program Comanche by NASA
#    2021113-051.  10:28 APR. 1, 1969
#
#    This AGC program shall also be referred to as
#            Colossus 2A
```

⟨*powered flight subroutines* 1843b⟩

This code is written to file `src/Comanche055/POWERED-FLIGHT-SUBROUTINES.agc`.

A.85 Q R-AXIS RCS AUTOPILOT

2782 ⟨*src/Luminary099/Q-R-AXIS-RCS-AUTOPILOT.agc* 2782⟩≡

```
# Copyright:    Public domain.
# Filename:     Q_R-AXIS_RCS_AUTOPILOT.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1442-1459
# Mod history:  2009-05-27 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#               2009-06-07 RSB  Corrected "DEC 96.0" to "DEC 96", since
#                               the former is not compatible with yaYUL.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969
```

⟨*q-r axis rcs autopilot* 2542⟩

This code is written to file `src/Luminary099/Q-R-AXIS-RCS-AUTOPILOT.agc`.

A.86 R30

2783 ⟨*src/Comanche055/R30.agc* 2783⟩≡

```
# Copyright:    Public domain.
# Filename:     R30.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Hartmuth Gutsche <hgutsche@xplornet.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        514-524
# Mod history:  2009-05-09 HG    Started adapting from the Colossus249/ file
#               of the same name, using Comanche055 page
#               images 0514.jpg - 0524.jpg.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#    Assemble revision 055 of AGC program Comanche by NASA
#    2021113-051.  10:28 APR. 1, 1969
#
#    This AGC program shall also be referred to as
#            Colossus 2A

# Page 514
⟨Page CM0514 825⟩
# Page 515
⟨Page CM0515 827⟩
# Page 516
⟨Page CM0516 829⟩
# Page 517
⟨Page CM0517 831⟩
# Page 518
⟨Page CM0518 833⟩
# Page 519
⟨Page CM0519 835⟩
# Page 520
```

⟨*Page CM0520* 836⟩
```
# Page 521
```
⟨*Page CM0521* 837⟩
```
# Page 522
```
⟨*Page CM0522* 839⟩
```
# Page 523
```
⟨*Page CM0523* 840a⟩
```
# Page 524
```
⟨*Page CM0524* 840b⟩

This code is written to file `src/Comanche055/R30.agc`.

A.87 R31

2785 ⟨*src/Comanche055/R31.agc* 2785⟩≡

```
# Copyright:    Public domain.
# Filename:     R31.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 505-510
# Contact:      Onno Hommes <ohommes@cmu.edu>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-11 OH   Batch 2 Assignment Comanche Transcription
#               2009-05-20 RSB  Corrected INSTALL -> INTSTALL
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.


# Page 505
⟨Page CM0505 810⟩
# Page 506
⟨Page CM0506 812⟩
# Page 507
⟨Page CM0507 813⟩
# Page 508
⟨Page CM0508 814⟩
# Page 509
⟨Page CM0509 816⟩
# Page 510
⟨Page CM0510 818⟩
```

This code is written to file `src/Comanche055/R31.agc`.
Uses `R31` 67.

A.88 R60 62

2787 ⟨*src/Comanche055/R60-62.agc* 2787⟩≡

```
# Copyright:    Public domain.
# Filename:     R60_62.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        390-398
# Mod history:  2009-05-09 RSB  Adapted from the Colossus249/ file
#                               of the same name, using Comanche055 page
#                               images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 390
⟨Page CM0390 647⟩
# Page 391
⟨Page CM0391 649⟩
# Page 392
⟨Page CM0392 650⟩
# Page 393
⟨Page CM0393 651⟩
# Page 394
⟨Page CM0394 653⟩
# Page 395
⟨Page CM0395 655⟩
# Page 396
```

⟨*Page CM0396* 657⟩
```
# Page 397
```
⟨*Page CM0397* 658a⟩
```
# Page 398
```
⟨*Page CM0398* 658b⟩

This code is written to file `src/Comanche055/R60-62.agc`.

A.89 R63

2788 ⟨*src/Luminary099/R63.agc* 2788⟩≡
```
# Copyright:    Public domain.
# Filename:     R63.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        338-341
# Mod history:  2009-05-16 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969
```

⟨*r63 routine* 2148⟩

This code is written to file `src/Luminary099/R63.agc`.

A.90 RADAR LEADIN ROUTINES

2789 ⟨*src/Luminary099/RADAR-LEADIN-ROUTINES.agc* 2789⟩≡

```
# Copyright:    Public domain.
# Filename:     RADAR_LEADIN_ROUTINES.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        490-491
# Mod history:  2009-05-17 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969
```

⟨*radar leadin routines* 2217⟩

This code is written to file `src/Luminary099/RADAR-LEADIN-ROUTINES.agc`.

A.91 RCS-CSM DAP EXECUTIVE PROGRAMS

2790 ⟨*src/Comanche055/RCS-CSM-DAP-EXECUTIVE-PROGRAMS.agc* 2790⟩≡

```
# Copyright:    Public domain.
# Filename:     RCS-CSM_DAP_EXECUTIVE_PROGRAMS.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1037-1038
# Mod history:  2009-05-13 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#               2009-05-20 RSB  A "Page N" comment was corrected.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
```

⟨*rcs-csm dap executive programs* 1450b⟩

This code is written to file `src/Comanche055/RCS-CSM-DAP-EXECUTIVE-PROGRAMS.agc`.
Uses `A` 80 and `N` 206.

A.92 RCS-CSM DIGITAL AUTOPILOT

2791 ⟨*src/Comanche055/RCS-CSM-DIGITAL-AUTOPILOT.agc* 2791⟩≡

```
# Copyright:    Public domain.
# Filename:     RCS-CSM_DIGITAL_AUTOPILOT.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1002-1024
# Mod history:  2009-05-13 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
```

⟨*rcs-csm digital autopilot* 1411⟩

This code is written to file `src/Comanche055/RCS-CSM-DIGITAL-AUTOPILOT.agc`.

A.93 RCS FAILURE MONITOR

2792 ⟨*src/Luminary099/RCS-FAILURE-MONITOR.agc* 2792⟩≡

```
# Copyright:    Public domain.
# Filename:     RCS_FAILURE_MONITOR.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Hartmuth Gutsche <hgutsche@xplornet.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        190-192
# Mod history:  2009-05-19 HG   Transcribed from page image.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969
```

⟨*rcs failure monitor* 2108⟩

This code is written to file `src/Luminary099/RCS-FAILURE-MONITOR.agc`.

A.94 REENTRY CONTROL

2793 ⟨*src/Comanche055/REENTRY-CONTROL.agc* 2793⟩≡

```
# Copyright:    Public domain.
# Filename:     REENTRY_CONTROL.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        844-882
# Mod history:  2009-05-08 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#               2009-05-23 RSB  In a couple of 2OCT statements, removed the
#                               space between the first and second octal words.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
```

⟨*reentry control* 1255b⟩

This code is written to file `src/Comanche055/REENTRY-CONTROL.agc`.

A.95 RESTARTS ROUTINE

2794 ⟨*src/Comanche055/RESTARTS-ROUTINE.agc* 2794⟩≡

```
# Copyright:    Public domain.
# Filename:     RESTARTS_ROUTINE.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 1414-1419
# Contact:      Ron Burkey <info@sandroid.org>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-07 RSB  Adapted from Colossus249 file of the same
#                               name, and page images. Corrected various
#                               typos in the transcription of program
#                               comments, and these should be back-ported
#                               to Colossus249.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 1414
⟨Page CM1414 1905⟩
# Page 1415
⟨Page CM1415 1907⟩
# Page 1416
⟨Page CM1416 1909⟩
# Page 1417
⟨Page CM1417 1911⟩
# Page 1418
⟨Page CM1418 1913⟩
```

```
# Page 1419
```

⟨*Page CM1419* 1915⟩

This code is written to file `src/Comanche055/RESTARTS-ROUTINE.agc`.

A.96 RESTART TABLES

2796 ⟨*src/Comanche055/RESTART-TABLES.agc* 2796⟩≡

```
# Copyright:    Public domain.
# Filename:     RESTART_TABLES.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 211-221
# Contact:      Ron Burkey <info@sandroid.org>,
#               Fabrizio Bernardini <fabrizio@spacecraft.it>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-16 FB   Transcription Batch 2 Assignment.
#               2009-05-20 RSB  Added a missing comment mark.  Corrected mismarked
#                               Page 217 -> 220.
#               2009-05-21 RSB  Fixed value of 5.21SPOT.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 211
⟨Page CM0211 362⟩
# Page 212
⟨Page CM0212 364⟩
# Page 213
⟨Page CM0213 366⟩
# Page 214
⟨Page CM0214 368⟩
# Page 215
⟨Page CM0215 370⟩
```

```
# Page 216
```
⟨*Page CM0216* 372⟩
```
# Page 217
```
⟨*Page CM0217* 374⟩
```
# Page 218
```
⟨*Page CM0218* 376⟩
```
# Page 219
```
⟨*Page CM0219* 377⟩
```
# Page 220
```
⟨*Page CM0220* 378⟩
```
# Page 221
```
⟨*Page CM0221* 380⟩

This code is written to file `src/Comanche055/RESTART-TABLES.agc`.

A.97 RT8 OP CODES

2798 ⟨*src/Comanche055/RT8-OP-CODES.agc* 2798⟩≡

```
# Copyright:    Public domain.
# Filename:     RT8_OP_CODES.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 1508-1516
# Contact:      Ron Burkey <info@sandroid.org>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-07 RSB  Adapted from Colossus249/RT8_OP_CODES.agc
#                               and page images.
#               2009-05-07 RSB  Oops! Left out the entire last page before.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.
```

⟨*rt8 op codes* 2027⟩

This code is written to file `src/Comanche055/RT8-OP-CODES.agc`.

A.98 RTB OP CODES

2799 ⟨*src/Luminary099/RTB-OP-CODES.agc* 2799⟩≡

```
# Copyright:    Public domain.
# Filename:     RTB_OP_CODES.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1397-1401
# Mod history:  2009-05-10 SN   (Sergio Navarro).  Started adapting
#                               from the Luminary131/ file of the same
#                               name, using Luminary099 page images.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969
```

⟨*rtb op codes* 2034⟩

This code is written to file `src/Luminary099/RTB-OP-CODES.agc`.

A.99 S-BAND ANTENNA FOR CM

2800 ⟨*src/Comanche055/S-BAND-ANTENNA-FOR-CM.agc* 2800⟩≡

```
# Copyright:    Public domain.
# Filename:     S-BAND_ANTENNA_FOR_CM.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Jim Lawton <jim.lawton@gmail.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        934-935
# Mod history:  2009-05-11 JVL  Adapted from the Colossus249/ file
#                               of the same name, using Comanche055 page
#                               images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#    Assemble revision 055 of AGC program Comanche by NASA
#    2021113-051.  10:28 APR. 1, 1969
#
#    This AGC program shall also be referred to as
#            Colossus 2A
```

⟨*s-band antenna for cm* 1343⟩

This code is written to file `src/Comanche055/S-BAND-ANTENNA-FOR-CM.agc`.

A.100 S-BAND ANTENNA FOR LM

2801 ⟨*src/Luminary099/S-BAND-ANTENNA-FOR-LM.agc* 2801⟩≡

```
# Copyright:    Public domain.
# Filename:     S-BAND_ANTENNA_FOR_LM.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        486-489
# Mod history:  2009-05-17 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#               2009-06-07 RSB  Corrected a misprint.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969
```

⟨*s band antenna for lm* 2213⟩

This code is written to file `src/Luminary099/S-BAND-ANTENNA-FOR-LM.agc`.

A.101 SERVICER207

2802 ⟨*src/Comanche055/SERVICER207.agc* 2802⟩≡

```
# Copyright:    Public domain.
# Filename:     SERVICER207.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 819-836
# Contact:      Ron Burkey <info@sandroid.org>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-12 RSB  Adapted from Colossus249 file of the same
#                               name and Comanche 055 page images.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.
```

⟨*servicer207 code* 1226⟩

This code is written to file `src/Comanche055/SERVICER207.agc`.

A.102 SERVICE ROUTINES

2803 ⟨*src/Comanche055/SERVICE-ROUTINES.agc* 2803⟩≡

```
# Copyright:    Public domain.
# Filename:     SERVICE_ROUTINES.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 1485-1492
# Contact:      Ron Burkey <info@sandroid.org>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-07 RSB  Adapted from Colossus249 file of the same
#                               name, and page images. Corrected various
#                               typos in the transcription of program
#                               comments, and these should be back-ported
#                               to Colossus249.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.
```

⟨*service routines* 2000b⟩

This code is written to file `src/Comanche055/SERVICE-ROUTINES.agc`.

A.103 SERVICER

2804 ⟨*src/Luminary099/SERVICER.agc* 2804⟩≡

```
# Copyright:    Public domain.
# Filename:     SERVICER.agc
# Purpose:      Part of the source code for Luminary, build 099. It
#               is part of the source code for the Lunar Module's
#               (LM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 857-897
# Contact:      Ron Burkey <info@sandroid.org>,
#               Fabrizio Bernardini <fabrizio@spacecraft.it>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-06-01 FB   Transcription Batch 4 Assignment.
#               2009-06-05 RSB  Fixed a couple of typos, plus a goofy relative
#                               label reference from the original source.
#
# The contents of the "Luminary099" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 001 of AGC program Luminary099 by NASA
#       2021112-061.  July 14, 1969.
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

⟨servicer routine 2382⟩
```

This code is written to file `src/Luminary099/SERVICER.agc`.

A.104 SINGLE PRECISION SUBROUTINES

2805 ⟨*src/Comanche055/SINGLE-PRECISION-SUBROUTINES.agc* 2805⟩≡

```
# Copyright:    Public domain.
# Filename:     SINGLE_PRECISION_SUBROUTINES.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1207
# Mod history:  2009-05-13 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
```

⟨*single precision subroutines* 1646b⟩

This code is written to file `src/Comanche055/SINGLE-PRECISION-SUBROUTINES.agc`.

A.105 SPS BACK-UP RCS CONTROL

2806 ⟨*src/Luminary099/SPS-BACK-UP-RCS-CONTROL.agc* 2806⟩≡

```
# Copyright:    Public domain.
# Filename:     SPS_BACK-UP_RCS_CONTROL.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1507-1510
# Mod history:  2009-05-27 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969
```

⟨*sps back up rcs control* 2625⟩

This code is written to file `src/Luminary099/SPS-BACK-UP-RCS-CONTROL.agc`.

A.106 STABLE ORBIT

2807 ⟨*src/Comanche055/STABLE-ORBIT.agc* 2807⟩≡

```
# Copyright:    Public domain.
# Filename:     STABLE_ORBIT.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Hartmuth Gutsche <hgutsche@xplornet.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        525-532
# Mod history:  2009-05-10 HG    Started adapting from the Colossus249/ file
#                of the same name, using Comanche055 page
#                images 0525.jpg - 0532.jpg.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#    Assemble revision 055 of AGC program Comanche by NASA
#    2021113-051.  10:28 APR. 1, 1969
#
#    This AGC program shall also be referred to as
#            Colossus 2A
# Page 525
⟨Page CM0525 842⟩
# Page 526
⟨Page CM0526 844⟩
# Page 527
⟨Page CM0527 846⟩
# Page 528
⟨Page CM0528 848⟩
# Page 529
⟨Page CM0529 850⟩
# Page 530
⟨Page CM0530 852⟩
# Page531
⟨Page CM0531 854⟩
```

```
# Page 532
```

⟨*Page CM0532* 856⟩

This code is written to file `src/Comanche055/STABLE-ORBIT.agc`.

A.107 STAR TABLES

2808 ⟨*src/Comanche055/STAR-TABLES.agc* 2808⟩≡

```
# Copyright:    Public domain.
# Filename:     STAR_TABLES.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1389-1393
# Mod history:  2009-05-10 SN   (Sergio Navarro).  Started adapting
#                               from the Colossus249/ file of the same
#                               name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#    Assemble revision 055 of AGC program Comanche by NASA
#    2021113-051.  10:28 APR. 1, 1969
#
#    This AGC program shall also be referred to as
#            Colossus 2A
```

⟨*star tables* 1867⟩

This code is written to file `src/Comanche055/STAR-TABLES.agc`.

A.108 SXTMARK

2809 ⟨*src/Comanche055/SXTMARK.agc* 2809⟩≡

```
# Copyright:    Public domain.
# Filename:     SXTMARK.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 222-235
# Contact:      Ron Burkey <info@sandroid.org>,
#               Fabrizio Bernardini <fabrizio@spacecraft.it>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  16/05/09 FB     Transcription Batch 2 Assignment.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 222
⟨Page CM0222 382⟩
# Page 223
⟨Page CM0223 384⟩
# Page 224
⟨Page CM0224 386⟩
# Page 225
⟨Page CM0225 388⟩
# Page 226
⟨Page CM0226 389⟩
# Page 227
⟨Page CM0227 390⟩
# Page 228
```

⟨*Page CM0228* 392⟩
```
# Page 229
```
⟨*Page CM0229* 394⟩
```
# Page 230
```
⟨*Page CM0230* 396⟩
```
# Page 231
```
⟨*Page CM0231* 397⟩
```
# Page 232
```
⟨*Page CM0232* 398⟩
```
# Page 233
```
⟨*Page CM0233* 400⟩
```
# Page 234
```
⟨*Page CM0234* 402⟩
```
# Page 235
```
⟨*Page CM0235* 403⟩

This code is written to file `src/Comanche055/SXTMARK.agc`.

A.109 SYSTEM TEST STANDARD LEAD INS

2811 ⟨*src/Comanche055/SYSTEM-TEST-STANDARD-LEAD-INS.agc* 2811⟩≡

```
# Copyright:    Public domain.
# Filename:     SYSTEM_TEST_STANDARD_LEAD_INS.agc
# Purpose:      Part of the source code for Comanche, build 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 420-422
# Contact:      Onno Hommes <ohommes@cmu.edu>.
# Website:      www.ibiblio.org/apollo.
# Mod history:  05/07/09 OH     Transcription Batch 1 Assignment
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further information.
# Please report any errors to info@sandroid.org.


# Page 420
⟨Page CM0420 692⟩
# Page 421
⟨Page CM0421 693⟩
# Page 422
⟨Page CM0422 694⟩
```

This code is written to file `src/Comanche055/SYSTEM-TEST-STANDARD-LEAD-INS.agc`.

A.110 T4RUPT PROGRAM

2812 ⟨*src/Comanche055/T4RUPT-PROGRAM.agc* 2812⟩≡

```
# Copyright:    Public domain.
# Filename:     T4RUPT_PROGRAM.agc
# Purpose:      Part of the source code for Comanche, build 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 133-169
# Contact:      Ron Burkey <info@sandroid.org>,
#               Fabrizio Bernardini <fabrizio@spacecraft.it>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  10/05/09 FB     Transcription of Batch FB-1 Assignment.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.

# Page 133
⟨Page CM0133 251⟩
# Page 134
⟨Page CM0134 252⟩
# Page 135
⟨Page CM0135 253⟩
# Page 136
⟨Page CM0136 254⟩
# Page 137
⟨Page CM0137 255⟩
# Page 138
⟨Page CM0138 256⟩
# Page 139
```

⟨*Page CM0139* 257⟩
Page 140
⟨*Page CM0140* 258⟩
Page 141
⟨*Page CM0141* 259⟩
Page 142
⟨*Page CM0142* 261⟩
Page 143
⟨*Page CM0143* 263⟩
Page 144
⟨*Page CM0144* 264⟩
Page 145
⟨*Page CM0145* 265⟩
Page 146
⟨*Page CM0146* 266⟩
Page 147
⟨*Page CM0147* 267⟩
Page 148
⟨*Page CM0148* 268⟩
Page 149
⟨*Page CM0149* 269⟩
Page 150
⟨*Page CM0150* 270⟩
Page 151
⟨*Page CM0151* 271⟩
Page 152
⟨*Page CM0152* 272⟩
Page 153
⟨*Page CM0153* 273⟩
Page 154
⟨*Page CM0154* 274⟩
Page 155
⟨*Page CM0155* 276⟩
Page 156
⟨*Page CM0156* 277⟩
Page 157
⟨*Page CM0157* 278⟩
Page 158
⟨*Page CM0158* 279⟩
Page 159
⟨*Page CM0159* 280⟩
Page 160
⟨*Page CM0160* 281⟩
Page 161
⟨*Page CM0161* 282⟩
Page 162

⟨*Page CM0162* 284⟩
```
# Page 163
```
⟨*Page CM0163* 285⟩
```
# Page 164
```
⟨*Page CM0164* 286⟩
```
# Page 165
```
⟨*Page CM0165* 287⟩
```
# Page 166
```
⟨*Page CM0166* 288⟩
```
# Page 167
```
⟨*Page CM0167* 290⟩
```
# Page 168
```
⟨*Page CM0168* 292⟩
```
# Page 169
```
⟨*Page CM0169* 293a⟩

This code is written to file `src/Comanche055/T4RUPT-PROGRAM.agc`.

A.111 T6-RUPT PROGRAMS

2815 ⟨*src/Luminary099/T6-RUPT-PROGRAMS.agc* 2815⟩≡

```
# Copyright:    Public domain.
# Filename:     T6-RUPT_PROGRAMS.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1403-1405
# Mod history:  2009-05-10 SN   (Sergio Navarro).  Started adapting
#                               from the Luminary131/ file of the same
#                               name, using Luminary099 page images.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969
```

⟨*t6 rupt programs* 2496⟩

This code is written to file `src/Luminary099/T6-RUPT-PROGRAMS.agc`.

A.112 TAGS FOR RELATIVE SETLOC

2816 ⟨*src/Comanche055/TAGS-FOR-RELATIVE-SETLOC.agc* 2816⟩≡

```
# Copyright:    Public domain.
# Filename:     TAGS_FOR_RELATIVE_SETLOC.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Mod history:  2009-05-05 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#               2009-05-20 RSB  Corrected R32 -> R31.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 27
⟨Page CM0027 57⟩
# Page 28

⟨Page CM0028 59⟩

# Page 29

⟨Page CM0029 61⟩

# Page 30

⟨Page CM0030 63⟩
```

```
# Page 31
```

⟨*Page CM0031* 65⟩

```
# Page 32
```

⟨*Page CM0032* 67⟩

```
# Page 33
```

⟨*Page CM0033* 69⟩

```
# Page 34
```

⟨*Page CM0034* 71⟩

```
# Page 35
```

⟨*Page CM0035* 73⟩

```
# Page 36
```

⟨*Page CM0036* 74a⟩

This code is written to file `src/Comanche055/TAGS-FOR-RELATIVE-SETLOC.agc`.
Uses `R31` 67.

A.113 THE LUNAR LANDING

2818 ⟨*src/Luminary099/THE-LUNAR-LANDING.agc* 2818⟩≡

```
# Copyright:    Public domain.
# Filename:     THE_LUNAR_LANDING.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Hartmuth Gutsche<hgutsche@xplornet.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        785-792
# Mod history:  2009-05-20 HG   Transcribed from page images.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

⟨the lunar landing 2299⟩
```

This code is written to file `src/Luminary099/THE-LUNAR-LANDING.agc`.

A.114 THROTTLE CONTROL ROUTINES

2819 ⟨*src/Luminary099/THROTTLE-CONTROL-ROUTINES.agc* 2819⟩≡

```
# Copyright:    Public domain.
# Filename:     THROTTLE_CONTROL_ROUTINES.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      HARTMUTH GUTSCHE <hgutsche@xplornet.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        793-797
# Mod history:  2009-05-20 HG   Transcribed from page images.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969
```

⟨*throttle control routines* 2306⟩

This code is written to file `src/Luminary099/THROTTLE-CONTROL-ROUTINES.agc`.

A.115 TIME OF FREE FALL

2820 ⟨*src/Comanche055/TIME-OF-FREE-FALL.agc* 2820⟩≡

```
# Copyright:    Public domain.
# Filename:     TIME_OF_FREE_FALL.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1373-1388
# Mod history:  2009-05-10 SN   (Sergio Navarro).  Started adapting
#                               from the Colossus249/ file of the same
#                               name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#    Assemble revision 055 of AGC program Comanche by NASA
#    2021113-051.  10:28 APR. 1, 1969
#
#    This AGC program shall also be referred to as
#            Colossus 2A
```

⟨*time of free fall* 1851⟩

This code is written to file `src/Comanche055/TIME-OF-FREE-FALL.agc`.

A.116 TJET LAW

2821 ⟨*src/Luminary099/TJET-LAW.agc* 2821⟩≡

```
# Copyright:    Public domain.
# Filename:     TJET_LAW.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1460-1469
# Mod history:  2009-05-27 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#               2009-06-06 RSB  Eliminated a stray instruction that had crept
#                               in somehow.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969
```

⟨*tjet law* 2561⟩

This code is written to file `src/Luminary099/TJET-LAW.agc`.

A.117 TPI SEARCH

2822 ⟨*src/Comanche055/TPI-SEARCH.agc* 2822⟩≡

```
# Copyright:    Public domain.
# Filename:     TPI_SEARCH.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        551-561
# Mod history:  2009-05-15 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#               2009-05-20 RSB  Corrections:  On p. 551, "SETLOC P17S" -> P17S1.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A

# Page 551
⟨Page CM0551 893⟩
# Page 552
⟨Page CM0552 895⟩
# Page 553
⟨Page CM0553 897⟩
# Page 554
⟨Page CM0554 899⟩
# Page 555
⟨Page CM0555 901⟩
# Page 556
⟨Page CM0556 903⟩
# Page 557
```

⟨*Page CM0557* 905⟩
```
# Page 558
```
⟨*Page CM0558* 907⟩
```
# Page 559
```
⟨*Page CM0559* 909⟩
```
# Page 560
```
⟨*Page CM0560* 911⟩
```
# Page 561
```
⟨*Page CM0561* 912⟩

This code is written to file `src/Comanche055/TPI-SEARCH.agc`.
Uses `P17S` 69 and `P17S1` 69.

A.118 TRIM GIMBAL CNTROL SYSTEM

2823 ⟨*src/Luminary099/TRIM-GIMBAL-CNTROL-SYSTEM.agc* 2823⟩≡
```
# Copyright:    Public domain.
# Filename:     TRIM_GIMBAL_CNTROL_SYSTEM.agc
# Purpose:      Part of the source code for Luminary 1A build 099.
#               It is part of the source code for the Lunar Module's (LM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1472-1485
# Mod history:  2009-05-27 RSB  Adapted from the corresponding
#                               Luminary131 file, using page
#                               images from Luminary 1A.
#
# This source code has been transcribed or otherwise adapted from
# digitized images of a hardcopy from the MIT Museum.  The digitization
# was performed by Paul Fjeld, and arranged for by Deborah Douglas of
# the Museum.  Many thanks to both.  The images (with suitable reduction
# in storage size and consequent reduction in image quality as well) are
# available online at www.ibiblio.org/apollo.  If for some reason you
# find that the images are illegible, contact me at info@sandroid.org
# about getting access to the (much) higher-quality images which Paul
# actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 001 of AGC program LMY99 by NASA 2021112-61
#       16:27 JULY 14, 1969

```
⟨*trim gimbal cntrol system* 2574⟩

This code is written to file `src/Luminary099/TRIM-GIMBAL-CNTROL-SYSTEM.agc`.

A.119 TVCDAPS

2824 ⟨*src/Comanche055/TVCDAPS.agc* 2824⟩≡

```
# Copyright:    Public domain.
# Filename:     TVCDAPS.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        961-978
# Mod history:  2009-05-13 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#               2009-05-20 RSB  Corrections:  Eliminated an extraneous EXTEND,
#                               added a missing instruction to PFORWARD.
#               2000-05-21 RSB  Wrong opcode was used with DELBRTMP and
#                               DELBRTMP +1 operands in 4 places.  Corrected
#                               an MP operation in 2CASFLTR.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
```

⟨*tvcdaps code* 1372⟩

This code is written to file `src/Comanche055/TVCDAPS.agc`.
Uses `DELBRTMP` 206.

A.120 TVCEXECUTIVE

2825 ⟨*src/Comanche055/TVCEXECUTIVE.agc* 2825⟩≡

```
# Copyright:    Public domain.
# Filename:     TVCEXECUTIVE.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        945-950
# Mod history:  2009-05-12 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#               2009-05-20 RSB  Corrections:  CAE -> CAF in one place.
#               2009-05-21 RSB  In 1SHOTCHK, a CAF SEVEN was corrected to
#                               CAF SIX.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
```

⟨*tvcexecutive code* 1355⟩

This code is written to file `src/Comanche055/TVCEXECUTIVE.agc`.

A.121 TVCINITIALIZE

2826 ⟨*src/Comanche055/TVCINITIALIZE.agc* 2826⟩≡

```
# Copyright:    Public domain.
# Filename:     TVCINITIALIZE.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Jim Lawton <jim.lawton@gmail.com>.
# Website:      www.ibiblio.org/apollo.
# Pages:        936-944
# Mod history:  2009-05-11 JVL  Adapted from the Colossus249/ file
#                               of the same name, using Comanche055 page
#                               images.
#               2009-05-20 RSB  Corrections:  +80 -> +8D, added 4 missing
#                               lines in TVCINIT1, changed the capitalization
#                               of a couple of the "Page N" comments,
#                               corrected a couple of lines in LOADCOEFF.
#               2009-05-22 RSB  In LOADCOEF, DXCH N10 +14D corrected to
#                               TS N10 +14D.  Also, various comment-marks
#                               were added to comments following this
#                               change.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#    Assemble revision 055 of AGC program Comanche by NASA
#    2021113-051.  10:28 APR. 1, 1969
#
#    This AGC program shall also be referred to as
#            Colossus 2A
```

⟨*tvcinitialize code* 1346d⟩

This code is written to file `src/Comanche055/TVCINITIALIZE.agc`.
Uses `N` 206 and `N10` 206.

A.122 TVCMASSPROP

2827 ⟨*src/Comanche055/TVCMASSPROP.agc* 2827⟩≡

```
# Copyright:    Public domain.
# Filename:     TVCMASSPROP.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        951-955
# Mod history:  2009-05-13 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
```

⟨*tvcmassprop code* 1361⟩

This code is written to file `src/Comanche055/TVCMASSPROP.agc`.

A.123 TVCRESTARTS

2828 ⟨*src/Comanche055/TVCRESTARTS.agc* 2828⟩≡

```
# Copyright:    Public domain.
# Filename:     TVCRESTARTS.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        956-960
# Mod history:  2009-05-13 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#               2009-05-20 RSB  Corrections:  TCF -> BZF in one place.
#               2009-05-21 RSB  In PHSCHK2, CS TVCPHASE corrected to
#                               CCS TVCPHASE and CCS 4 corrected to CCS A.
#                               Page 924 corrected to 961.  CORCOPY +2
#                               corrected to CORCOPY +1.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
```

⟨*tvcrestarts code* 1366⟩

This code is written to file `src/Comanche055/TVCRESTARTS.agc`.
Uses `A` 80 and `TVCPHASE` 204.

A.124 TVCROLLDAP

2829 ⟨*src/Comanche055/TVCROLLDAP.agc* 2829⟩≡

```
# Copyright:    Public domain.
# Filename:     TVCROLLDAP.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        984-998
# Mod history:  2009-05-13 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
```

⟨*tvcrolldap code* 1395⟩

This code is written to file `src/Comanche055/TVCROLLDAP.agc`.

A.125 TVCSTROKETEST

2830 ⟨*src/Comanche055/TVCSTROKETEST.agc* 2830⟩≡

```
# Copyright:    Public domain.
# Filename:     TVCSTROKETEST.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        979-983
# Mod history:  2009-05-13 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
```

⟨*tvcstroketest code* 1389⟩

This code is written to file `src/Comanche055/TVCSTROKETEST.agc`.

A.126 UPDATE PROGRAM

2831 ⟨*src/Comanche055/UPDATE-PROGRAM.agc* 2831⟩≡

```
# Copyright:    Public domain.
# Filename:     UPDATE_PROGRAM.agc
# Purpose:      Part of the source code for Comanche, build 055. It
#               is part of the source code for the Command Module's
#               (CM) Apollo Guidance Computer (AGC), Apollo 11.
# Assembler:    yaYUL
# Reference:    pp. 1497-1507
# Contact:      Ron Burkey <info@sandroid.org>
# Website:      http://www.ibiblio.org/apollo.
# Mod history:  2009-05-07 RSB  Adapted from Colossus249/UPDATE_PROGRAM.agc
#                               and page images. Corrected various typos
#                               in the transcription of program comments,
#                               and these should be back-ported to
#                               Colossus249.
#
# The contents of the "Comanche055" files, in general, are transcribed
# from scanned documents.
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  April 1, 1969.
#
#       This AGC program shall also be referred to as Colossus 2A
#
#       Prepared by
#                       Massachusetts Institute of Technology
#                       75 Cambridge Parkway
#                       Cambridge, Massachusetts
#
#       under NASA contract NAS 9-4065.
#
# Refer directly to the online document mentioned above for further
# information.  Please report any errors to info@sandroid.org.
```

⟨*update program* 2014⟩

This code is written to file `src/Comanche055/UPDATE-PROGRAM.agc`.

A.127 WAITLIST

2832 ⟨*src/Comanche055/WAITLIST.agc* 2832⟩≡

```
# Copyright:    Public domain.
# Filename:     WAITLIST.agc
# Purpose:      Part of the source code for Colossus 2A, AKA Comanche 055.
#               It is part of the source code for the Command Module's (CM)
#               Apollo Guidance Computer (AGC), for Apollo 11.
# Assembler:    yaYUL
# Contact:      Ron Burkey <info@sandroid.org>.
# Website:      www.ibiblio.org/apollo.
# Pages:        1221-1235
# Mod history:  2009-05-14 RSB  Adapted from the Colossus249/ file of the
#                               same name, using Comanche055 page images.
#
# This source code has been transcribed or otherwise adapted from digitized
# images of a hardcopy from the MIT Museum.  The digitization was performed
# by Paul Fjeld, and arranged for by Deborah Douglas of the Museum.  Many
# thanks to both.  The images (with suitable reduction in storage size and
# consequent reduction in image quality as well) are available online at
# www.ibiblio.org/apollo.  If for some reason you find that the images are
# illegible, contact me at info@sandroid.org about getting access to the
# (much) higher-quality images which Paul actually created.
#
# Notations on the hardcopy document read, in part:
#
#       Assemble revision 055 of AGC program Comanche by NASA
#       2021113-051.  10:28 APR. 1, 1969
#
#       This AGC program shall also be referred to as
#                       Colossus 2A
```

⟨*waitlist code* 1662⟩

This code is written to file `src/Comanche055/WAITLIST.agc`.

Appendix B

Miscellaneous Files

2833 ⟨*src/check.sh* 2833⟩≡

```
#!/bin/bash

orig=Luminary099/AGC_BLOCK_TWO_SELF_CHECK.agc; new=AGC-BLOCK-TWO-SELF-CHECK.agc; echo "XX $orig
orig=Comanche055/AGC_BLOCK_TWO_SELF-CHECK.agc; new=AGC-BLOCK-TWO-SELF-CHECK.agc; echo "XX $orig
orig=Luminary099/AGS_INITIALIZATION.agc; new=AGS-INITIALIZATION.agc; echo "XX $orig XX"; diff o
orig=Comanche055/ALARM_AND_ABORT.agc; new=ALARM-AND-ABORT.agc; echo "XX $orig XX"; diff origsrc
orig=Comanche055/ANGLFIND.agc; new=ANGLFIND.agc; echo "XX $orig XX"; diff origsrc/$orig src/Com
orig=Luminary099/AOSTASK_AND_AOSJOB.agc; new=AOSTASK-AND-AOSJOB.agc; echo "XX $orig XX"; diff o
orig=Luminary099/AOTMARK.agc; new=AOTMARK.agc; echo "XX $orig XX"; diff origsrc/$orig src/Lumin
orig=Luminary099/ASCENT_GUIDANCE.agc; new=ASCENT-GUIDANCE.agc; echo "XX $orig XX"; diff origsrc
orig=Comanche055/ASSEMBLY_AND_OPERATION_INFORMATION.agc; new=CM0002INFO.agc; echo "XX $orig XX"
orig=Luminary099/ATTITUDE_MANEUVER_ROUTINE.agc; new=ATTITUDE-MANEUVER-ROUTINE.agc; echo "XX $or
orig=Comanche055/AUTOMATIC_MANEUVERS.agc; new=AUTOMATIC-MANEUVERS.agc; echo "XX $orig XX"; diff
orig=Luminary099/BURN_BABY_BURN--MASTER_IGNITION_ROUTINE.agc; new=BURN-BABY-BURN--MASTER-IGNITI
orig=Comanche055/CM_BODY_ATTITUDE.agc; new=CM-BODY-ATTITUDE.agc; echo "XX $orig XX"; diff origs
orig=Comanche055/CM_ENTRY_DIGITAL_AUTOPILOT.agc; new=CM-ENTRY-DIGITAL-AUTOPILOT.agc; echo "XX $
orig=Comanche055/CONIC_SUBROUTINES.agc; new=CONIC-SUBROUTINES.agc; echo "XX $orig XX"; diff ori
orig=Comanche055/CONTRACT_AND_APPROVALS.agc; new=CONTRACT-AND-APPROVALS.agc; echo "XX $orig XX"
orig=Luminary099/CONTROLLED_CONSTANTS.agc; new=CONTROLLED-CONSTANTS.agc; echo "XX $orig XX"; di
orig=Comanche055/CSM_GEOMETRY.agc; new=CSM-GEOMETRY.agc; echo "XX $orig XX"; diff origsrc/$orig
orig=Luminary099/DAPIDLER_PROGRAM.agc; new=DAPIDLER-PROGRAM.agc; echo "XX $orig XX"; diff origs
orig=Luminary099/DAP_INTERFACE_SUBROUTINES.agc; new=DAP-INTERFACE-SUBROUTINES.agc; echo "XX $or
orig=Comanche055/DISPLAY_INTERFACE_ROUTINES.agc; new=DISPLAY-INTERFACE-ROUTINES.agc; echo "XX $
orig=Comanche055/DOWNLINK_LISTS.agc; new=DOWNLINK-LISTS.agc; echo "XX $orig XX"; diff origsrc/$
orig=Luminary099/DOWN_TELEMETRY_PROGRAM.agc; new=DOWN--TELEMETRY-PROGRAM.agc; echo "XX $orig XX
orig=Comanche055/DOWN-TELEMETRY_PROGRAM.agc; new=DOWN-TELEMETRY-PROGRAM.agc; echo "XX $orig XX"
orig=Comanche055/ENTRY_LEXICON.agc; new=ENTRY-LEXICON.agc; echo "XX $orig XX"; diff origsrc/$or
orig=Comanche055/ERASABLE_ASSIGNMENTS.agc; new=ERASABLE-ASSIGNMENTS.agc; echo "XX $orig XX"; di
orig=Comanche055/EXECUTIVE.agc; new=EXECUTIVE.agc; echo "XX $orig XX"; diff origsrc/$orig src/C
orig=Comanche055/EXTENDED_VERBS.agc; new=EXTENDED-VERBS.agc; echo "XX $orig XX"; diff origsrc/$
```

```
orig=Luminary099/FINDCDUW--GUIDAP_INTERFACE.agc; new=FINDCDUW--GUIDAP-INTERFACE.agc;
orig=Comanche055/FIXED_FIXED_CONSTANT_POOL.agc; new=FIXED-FIXED-CONSTANT-POOL.agc; ec
orig=Luminary099/FLAGWORD_ASSIGNMENTS.agc; new=FLAGWORD-ASSIGNMENTS.agc; echo "XX $or
orig=Comanche055/FRESH_START_AND_RESTART.agc; new=FRESH-START-AND-RESTART.agc; echo '
orig=Comanche055/GIMBAL_LOCK_AVOIDANCE.agc; new=GIMBAL-LOCK-AVOIDANCE.agc; echo "XX S
orig=Comanche055/GROUND_TRACKING_DETERMINATION_PROGRAM.agc; new=GROUND-TRACKING-DETER
orig=Luminary099/HeaderTemplate.agc; new=HeaderTemplate.agc; echo "XX $orig XX"; diff
orig=Comanche055/IMU_CALIBRATION_AND_ALIGNMENT.agc; new=IMU-CALIBRATION-AND-ALIGNMENT
orig=Comanche055/IMU_COMPENSATION_PACKAGE.agc; new=IMU-COMPENSATION-PACKAGE.agc; echo
orig=Comanche055/IMU_MODE_SWITCHING_ROUTINES.agc; new=IMU-MODE-SWITCHING-ROUTINES.agc
orig=Luminary099/IMU_PERFORMANCE_TEST_2.agc; new=IMU-PERFORMANCE-TEST-2.agc; echo "XX
orig=Luminary099/IMU_PERFORMANCE_TESTS_4.agc; new=IMU-PERFORMANCE-TESTS-4.agc; echo '
orig=Comanche055/INFLIGHT_ALIGNMENT_ROUTINES.agc; new=INFLIGHT-ALIGNMENT-ROUTINES.agc
orig=Luminary099/INPUT_OUTPUT_CHANNEL_BIT_DESCRIPTIONS.agc; new=INPUT-OUTPUT-CHANNEL-
orig=Comanche055/INTEGRATION_INITIALIZATION.agc; new=INTEGRATION-INITIALIZATION.agc;
orig=Comanche055/INTER-BANK_COMMUNICATION.agc; new=INTER-BANK-COMMUNICATION.agc; echo
orig=Comanche055/INTERPRETER.agc; new=INTERPRETER.agc; echo "XX $orig XX"; diff origs
orig=Luminary099/INTERPRETIVE_CONSTANT.agc; new=INTERPRETIVE-CONSTANT.agc; echo "XX S
orig=Comanche055/INTERPRETIVE_CONSTANTS.agc; new=INTERPRETIVE-CONSTANTS.agc; echo "XX
orig=Comanche055/INTERRUPT_LEAD_INS.agc; new=INTERRUPT-LEAD-INS.agc; echo "XX $orig X
orig=Comanche055/JET_SELECTION_LOGIC.agc; new=JET-SELECTION-LOGIC.agc; echo "XX $orig
orig=Comanche055/KALCMANU_STEERING.agc; new=KALCMANU-STEERING.agc; echo "XX $orig XX"
orig=Luminary099/KALMAN_FILTER.agc; new=KALMAN-FILTER.agc; echo "XX $orig XX"; diff o
orig=Comanche055/KEYRUPT_UPRUPT.agc; new=KEYRUPT-UPRUPT.agc; echo "XX $orig XX"; diff
orig=Luminary099/LAMBERT_AIMPOINT_GUIDANCE.agc; new=LAMBERT-AIMPOINT-GUIDANCE.agc; ec
orig=Luminary099/LANDING_ANALOG_DISPLAYS.agc; new=LANDING-ANALOG-DISPLAYS.agc; echo '
orig=Comanche055/LATITUDE_LONGITUDE_SUBROUTINES.agc; new=LATITUDE-LONGITUDE-SUBROUTIN
orig=Luminary099/LEM_GEOMETRY.agc; new=LEM-GEOMETRY.agc; echo "XX $orig XX"; diff ori
orig=Comanche055/LUNAR_AND_SOLAR_EPHEMERIDES_SUBROUTINES.agc; new=LUNAR-AND-SOLAR-EPH
orig=Luminary099/LUNAR_LANDING_GUIDANCE_EQUATIONS.agc; new=LUNAR-LANDING-GUIDANCE-EQU
orig=Comanche055/LUNAR_LANDMARK_SELECTION_FOR_CM.agc; new=LUNAR-LANDMARK-SELECTION-FO
orig=Comanche055/MAIN.agc; new=MAIN.agc; echo "XX $orig XX"; diff origsrc/$orig src/C
orig=Comanche055/MEASUREMENT_INCORPORATION.agc; new=MEASUREMENT-INCORPORATION.agc; ec
orig=Comanche055/MYSUBS.agc; new=MYSUBS.agc; echo "XX $orig XX"; diff origsrc/$orig s
orig=Comanche055/ORBITAL_INTEGRATION.agc; new=ORBITAL-INTEGRATION.agc; echo "XX $orig
orig=Comanche055/P11.agc; new=P11.agc; echo "XX $orig XX"; diff origsrc/$orig src/Com
orig=Luminary099/P12.agc; new=P12.agc; echo "XX $orig XX"; diff origsrc/$orig src/Lun
orig=Comanche055/P20-P25.agc; new=P20-P25.agc; echo "XX $orig XX"; diff origsrc/$orig
orig=Luminary099/P30_P37.agc; new=P30--P37.agc; echo "XX $orig XX"; diff origsrc/$ori
orig=Comanche055/P30-P37.agc; new=P30-P37.agc; echo "XX $orig XX"; diff origsrc/$orig
orig=Comanche055/P32-P33_P72-P73.agc; new=P32-P33-P72-P73.agc; echo "XX $orig XX"; di
orig=Luminary099/P32-P35_P72-P75.agc; new=P32-P35-P72-P75.agc; echo "XX $orig XX"; di
orig=Comanche055/P34-35_P74-75.agc; new=P34-35-P74-75.agc; echo "XX $orig XX"; diff o
orig=Comanche055/P37_P70.agc; new=P37-P70.agc; echo "XX $orig XX"; diff origsrc/$orig
orig=Comanche055/P40-P47.agc; new=P40-P47.agc; echo "XX $orig XX"; diff origsrc/$orig
orig=Comanche055/P51-P53.agc; new=P51-P53.agc; echo "XX $orig XX"; diff origsrc/$orig
```

```
orig=Comanche055/P61-P67.agc; new=P61-P67.agc; echo "XX $orig XX"; diff origsrc/$orig src/Coman
orig=Luminary099/P70-P71.agc; new=P70-P71.agc; echo "XX $orig XX"; diff origsrc/$orig src/Lumin
orig=Comanche055/P76.agc; new=P76.agc; echo "XX $orig XX"; diff origsrc/$orig src/Comanche055/$
orig=Luminary099/P-AXIS_RCS_AUTOPILOT.agc; new=P-AXIS-RCS-AUTOPILOT.agc; echo "XX $orig XX"; di
orig=Comanche055/PHASE_TABLE_MAINTENANCE.agc; new=PHASE-TABLE-MAINTENANCE.agc; echo "XX $orig X
orig=Comanche055/PINBALL_GAME_BUTTONS_AND_LIGHTS.agc; new=PINBALL-GAME-BUTTONS-AND-LIGHTS.agc;
orig=Comanche055/PINBALL_NOUN_TABLES.agc; new=PINBALL-NOUN-TABLES.agc; echo "XX $orig XX"; diff
orig=Comanche055/PLANETARY_INERTIAL_ORIENTATION.agc; new=PLANETARY-INERTIAL-ORIENTATION.agc; ec
orig=Comanche055/POWERED_FLIGHT_SUBROUTINES.agc; new=POWERED-FLIGHT-SUBROUTINES.agc; echo "XX $
orig=Luminary099/Q_R-AXIS_RCS_AUTOPILOT.agc; new=Q-R-AXIS-RCS-AUTOPILOT.agc; echo "XX $orig XX"
orig=Comanche055/R30.agc; new=R30.agc; echo "XX $orig XX"; diff origsrc/$orig src/Comanche055/$
orig=Comanche055/R31.agc; new=R31.agc; echo "XX $orig XX"; diff origsrc/$orig src/Comanche055/$
orig=Comanche055/R60_62.agc; new=R60-62.agc; echo "XX $orig XX"; diff origsrc/$orig src/Comanch
orig=Luminary099/R63.agc; new=R63.agc; echo "XX $orig XX"; diff origsrc/$orig src/Luminary099/$
orig=Luminary099/RADAR_LEADIN_ROUTINES.agc; new=RADAR-LEADIN-ROUTINES.agc; echo "XX $orig XX";
orig=Comanche055/RCS-CSM_DAP_EXECUTIVE_PROGRAMS.agc; new=RCS-CSM-DAP-EXECUTIVE-PROGRAMS.agc; ec
orig=Comanche055/RCS-CSM_DIGITAL_AUTOPILOT.agc; new=RCS-CSM-DIGITAL-AUTOPILOT.agc; echo "XX $or
orig=Luminary099/RCS_FAILURE_MONITOR.agc; new=RCS-FAILURE-MONITOR.agc; echo "XX $orig XX"; diff
orig=README.md; new=README.md; echo "XX $orig XX"; diff origsrc/$orig src/$new
orig=Comanche055/REENTRY_CONTROL.agc; new=REENTRY-CONTROL.agc; echo "XX $orig XX"; diff origsrc
orig=Comanche055/RESTARTS_ROUTINE.agc; new=RESTARTS-ROUTINE.agc; echo "XX $orig XX"; diff origs
orig=Comanche055/RESTART_TABLES.agc; new=RESTART-TABLES.agc; echo "XX $orig XX"; diff origsrc/$
orig=Comanche055/RT8_OP_CODES.agc; new=RT8-OP-CODES.agc; echo "XX $orig XX"; diff origsrc/$orig
orig=Luminary099/RTB_OP_CODES.agc; new=RTB-OP-CODES.agc; echo "XX $orig XX"; diff origsrc/$orig
orig=Comanche055/S-BAND_ANTENNA_FOR_CM.agc; new=S-BAND-ANTENNA-FOR-CM.agc; echo "XX $orig XX";
orig=Luminary099/S-BAND_ANTENNA_FOR_LM.agc; new=S-BAND-ANTENNA-FOR-LM.agc; echo "XX $orig XX";
orig=Comanche055/SERVICER207.agc; new=SERVICER207.agc; echo "XX $orig XX"; diff origsrc/$orig s
orig=Comanche055/SERVICE_ROUTINES.agc; new=SERVICE-ROUTINES.agc; echo "XX $orig XX"; diff origs
orig=Luminary099/SERVICER.agc; new=SERVICER.agc; echo "XX $orig XX"; diff origsrc/$orig src/Lum
orig=Comanche055/SINGLE_PRECISION_SUBROUTINES.agc; new=SINGLE-PRECISION-SUBROUTINES.agc; echo "
orig=Luminary099/SPS_BACK-UP_RCS_CONTROL.agc; new=SPS-BACK-UP-RCS-CONTROL.agc; echo "XX $orig X
orig=Comanche055/STABLE_ORBIT.agc; new=STABLE-ORBIT.agc; echo "XX $orig XX"; diff origsrc/$orig
orig=Comanche055/STAR_TABLES.agc; new=STAR-TABLES.agc; echo "XX $orig XX"; diff origsrc/$orig s
orig=Comanche055/SXTMARK.agc; new=SXTMARK.agc; echo "XX $orig XX"; diff origsrc/$orig src/Coman
orig=Comanche055/SYSTEM_TEST_STANDARD_LEAD_INS.agc; new=SYSTEM-TEST-STANDARD-LEAD-INS.agc; echo
orig=Comanche055/T4RUPT_PROGRAM.agc; new=T4RUPT-PROGRAM.agc; echo "XX $orig XX"; diff origsrc/$
orig=Luminary099/T6-RUPT_PROGRAMS.agc; new=T6-RUPT-PROGRAMS.agc; echo "XX $orig XX"; diff origs
orig=Comanche055/TAGS_FOR_RELATIVE_SETLOC.agc; new=TAGS-FOR-RELATIVE-SETLOC.agc; echo "XX $orig
orig=Luminary099/THE_LUNAR_LANDING.agc; new=THE-LUNAR-LANDING.agc; echo "XX $orig XX"; diff ori
orig=Luminary099/THROTTLE_CONTROL_ROUTINES.agc; new=THROTTLE-CONTROL-ROUTINES.agc; echo "XX $or
orig=Comanche055/TIME_OF_FREE_FALL.agc; new=TIME-OF-FREE-FALL.agc; echo "XX $orig XX"; diff ori
orig=Luminary099/TJET_LAW.agc; new=TJET-LAW.agc; echo "XX $orig XX"; diff origsrc/$orig src/Lum
orig=Comanche055/TPI_SEARCH.agc; new=TPI-SEARCH.agc; echo "XX $orig XX"; diff origsrc/$orig src
orig=Luminary099/TRIM_GIMBAL_CNTROL_SYSTEM.agc; new=TRIM-GIMBAL-CNTROL-SYSTEM.agc; echo "XX $or
orig=Comanche055/TVCDAPS.agc; new=TVCDAPS.agc; echo "XX $orig XX"; diff origsrc/$orig src/Coman
orig=Comanche055/TVCEXECUTIVE.agc; new=TVCEXECUTIVE.agc; echo "XX $orig XX"; diff origsrc/$orig
```

```
orig=Comanche055/TVCINITIALIZE.agc; new=TVCINITIALIZE.agc; echo "XX $orig XX"; diff o
orig=Comanche055/TVCMASSPROP.agc; new=TVCMASSPROP.agc; echo "XX $orig XX"; diff origs
orig=Comanche055/TVCRESTARTS.agc; new=TVCRESTARTS.agc; echo "XX $orig XX"; diff origs
orig=Comanche055/TVCROLLDAP.agc; new=TVCROLLDAP.agc; echo "XX $orig XX"; diff origsrc
orig=Comanche055/TVCSTROKETEST.agc; new=TVCSTROKETEST.agc; echo "XX $orig XX"; diff o
orig=Comanche055/UPDATE_PROGRAM.agc; new=UPDATE-PROGRAM.agc; echo "XX $orig XX"; diff
orig=Comanche055/WAITLIST.agc; new=WAITLIST.agc; echo "XX $orig XX"; diff origsrc/$or
```

This code is written to file `src/check.sh`.

Uses `DISPLAYS` 59, `INFLIGHT` 65, `KEYRUPT` 59, `LANDMARK` 190, `LATITUDE` 191, `MODE` 145, `MYSUBS` 63, `ORBITAL` 59, `P` 188, `Q` 80, `R31` 67, `REENTRY` 65, `RESTART` 57, and `STAR` 186.

2837 ⟨*src/export.sh* 2837⟩≡

```
#!/bin/bash

rm -r -f tmp
mkdir -p tmp/{Comanche055,Luminary099}

ex=Luminary099/AGC_BLOCK_TWO_SELF_CHECK.agc; in=Luminary099/AGC-BLOCK-TWO-SELF-CHECK.agc; echo
ex=Comanche055/AGC_BLOCK_TWO_SELF-CHECK.agc; in=Comanche055/AGC-BLOCK-TWO-SELF-CHECK.agc; echo
ex=Luminary099/AGS_INITIALIZATION.agc; in=Luminary099/AGS-INITIALIZATION.agc; echo "XX $ex XX";
ex=Comanche055/ALARM_AND_ABORT.agc; in=Comanche055/ALARM-AND-ABORT.agc; echo "XX $ex XX"; cp $i
ex=Comanche055/ANGLFIND.agc; in=Comanche055/ANGLFIND.agc; echo "XX $ex XX"; cp $in tmp/$ex
ex=Luminary099/AOSTASK_AND_AOSJOB.agc; in=Luminary099/AOSTASK-AND-AOSJOB.agc; echo "XX $ex XX";
ex=Luminary099/AOTMARK.agc; in=Luminary099/AOTMARK.agc; echo "XX $ex XX"; cp $in tmp/$ex
ex=Luminary099/ASCENT_GUIDANCE.agc; in=Luminary099/ASCENT-GUIDANCE.agc; echo "XX $ex XX"; cp $i
ex=Comanche055/ASSEMBLY_AND_OPERATION_INFORMATION.agc; in=Comanche055/CM0002INFO.agc; echo "XX
ex=Luminary099/ATTITUDE_MANEUVER_ROUTINE.agc; in=Luminary099/ATTITUDE-MANEUVER-ROUTINE.agc; ech
ex=Comanche055/AUTOMATIC_MANEUVERS.agc; in=Comanche055/AUTOMATIC-MANEUVERS.agc; echo "XX $ex XX
ex=Luminary099/BURN_BABY_BURN--MASTER_IGNITION_ROUTINE.agc; in=Luminary099/BURN-BABY-BURN--MAST
ex=Comanche055/CM_BODY_ATTITUDE.agc; in=Comanche055/CM-BODY-ATTITUDE.agc; echo "XX $ex XX"; cp
ex=Comanche055/CM_ENTRY_DIGITAL_AUTOPILOT.agc; in=Comanche055/CM-ENTRY-DIGITAL-AUTOPILOT.agc; e
ex=Comanche055/CONIC_SUBROUTINES.agc; in=Comanche055/CONIC-SUBROUTINES.agc; echo "XX $ex XX"; c
ex=Comanche055/CONTRACT_AND_APPROVALS.agc; in=Comanche055/CONTRACT-AND-APPROVALS.agc; echo "XX
ex=Luminary099/CONTROLLED_CONSTANTS.agc; in=Luminary099/CONTROLLED-CONSTANTS.agc; echo "XX $ex
ex=Comanche055/CSM_GEOMETRY.agc; in=Comanche055/CSM-GEOMETRY.agc; echo "XX $ex XX"; cp $in tmp/
ex=Luminary099/DAPIDLER_PROGRAM.agc; in=Luminary099/DAPIDLER-PROGRAM.agc; echo "XX $ex XX"; cp
ex=Luminary099/DAP_INTERFACE_SUBROUTINES.agc; in=Luminary099/DAP-INTERFACE-SUBROUTINES.agc; ech
ex=Comanche055/DISPLAY_INTERFACE_ROUTINES.agc; in=Comanche055/DISPLAY-INTERFACE-ROUTINES.agc; e
ex=Comanche055/DOWNLINK_LISTS.agc; in=Comanche055/DOWNLINK-LISTS.agc; echo "XX $ex XX"; cp $in
ex=Luminary099/DOWN_TELEMETRY_PROGRAM.agc; in=Luminary099/DOWN--TELEMETRY-PROGRAM.agc; echo "XX
ex=Comanche055/DOWN-TELEMETRY_PROGRAM.agc; in=Comanche055/DOWN-TELEMETRY-PROGRAM.agc; echo "XX
ex=Comanche055/ENTRY_LEXICON.agc; in=Comanche055/ENTRY-LEXICON.agc; echo "XX $ex XX"; cp $in tm
ex=Comanche055/ERASABLE_ASSIGNMENTS.agc; in=Comanche055/ERASABLE-ASSIGNMENTS.agc; echo "XX $ex
ex=Comanche055/EXECUTIVE.agc; in=Comanche055/EXECUTIVE.agc; echo "XX $ex XX"; cp $in tmp/$ex
ex=Comanche055/EXTENDED_VERBS.agc; in=Comanche055/EXTENDED-VERBS.agc; echo "XX $ex XX"; cp $in
ex=Luminary099/FINDCDUW--GUIDAP_INTERFACE.agc; in=Luminary099/FINDCDUW--GUIDAP-INTERFACE.agc; e
ex=Comanche055/FIXED_FIXED_CONSTANT_POOL.agc; in=Comanche055/FIXED-FIXED-CONSTANT-POOL.agc; ech
ex=Luminary099/FLAGWORD_ASSIGNMENTS.agc; in=Luminary099/FLAGWORD-ASSIGNMENTS.agc; echo "XX $ex
ex=Comanche055/FRESH_START_AND_RESTART.agc; in=Comanche055/FRESH-START-AND-RESTART.agc; echo "X
ex=Comanche055/GIMBAL_LOCK_AVOIDANCE.agc; in=Comanche055/GIMBAL-LOCK-AVOIDANCE.agc; echo "XX $e
ex=Comanche055/GROUND_TRACKING_DETERMINATION_PROGRAM.agc; in=Comanche055/GROUND-TRACKING-DETERM
ex=Luminary099/HeaderTemplate.agc; in=Luminary099/HeaderTemplate.agc; echo "XX $ex XX"; cp $in
ex=Comanche055/IMU_CALIBRATION_AND_ALIGNMENT.agc; in=Comanche055/IMU-CALIBRATION-AND-ALIGNMENT.
ex=Comanche055/IMU_COMPENSATION_PACKAGE.agc; in=Comanche055/IMU-COMPENSATION-PACKAGE.agc; echo
ex=Comanche055/IMU_MODE_SWITCHING_ROUTINES.agc; in=Comanche055/IMU-MODE-SWITCHING-ROUTINES.agc;
ex=Luminary099/IMU_PERFORMANCE_TEST_2.agc; in=Luminary099/IMU-PERFORMANCE-TEST-2.agc; echo "XX
ex=Luminary099/IMU_PERFORMANCE_TESTS_4.agc; in=Luminary099/IMU-PERFORMANCE-TESTS-4.agc; echo "X
```

```
ex=Comanche055/INFLIGHT_ALIGNMENT_ROUTINES.agc; in=Comanche055/INFLIGHT-ALIGNMENT-ROU
ex=Luminary099/INPUT_OUTPUT_CHANNEL_BIT_DESCRIPTIONS.agc; in=Luminary099/INPUT-OUTPUT
ex=Comanche055/INTEGRATION_INITIALIZATION.agc; in=Comanche055/INTEGRATION-INITIALIZAT
ex=Comanche055/INTER-BANK_COMMUNICATION.agc; in=Comanche055/INTER-BANK-COMMUNICATION.
ex=Comanche055/INTERPRETER.agc; in=Comanche055/INTERPRETER.agc; echo "XX $ex XX"; cp
ex=Luminary099/INTERPRETIVE_CONSTANT.agc; in=Luminary099/INTERPRETIVE-CONSTANT.agc; e
ex=Comanche055/INTERPRETIVE_CONSTANTS.agc; in=Comanche055/INTERPRETIVE-CONSTANTS.agc;
ex=Comanche055/INTERRUPT_LEAD_INS.agc; in=Comanche055/INTERRUPT-LEAD-INS.agc; echo "X
ex=Comanche055/JET_SELECTION_LOGIC.agc; in=Comanche055/JET-SELECTION-LOGIC.agc; echo
ex=Comanche055/KALCMANU_STEERING.agc; in=Comanche055/KALCMANU-STEERING.agc; echo "XX
ex=Luminary099/KALMAN_FILTER.agc; in=Luminary099/KALMAN-FILTER.agc; echo "XX $ex XX";
ex=Comanche055/KEYRUPT_UPRUPT.agc; in=Comanche055/KEYRUPT-UPRUPT.agc; echo "XX $ex XX
ex=Luminary099/LAMBERT_AIMPOINT_GUIDANCE.agc; in=Luminary099/LAMBERT-AIMPOINT-GUIDANC
ex=Luminary099/LANDING_ANALOG_DISPLAYS.agc; in=Luminary099/LANDING-ANALOG-DISPLAYS.ag
ex=Comanche055/LATITUDE_LONGITUDE_SUBROUTINES.agc; in=Comanche055/LATITUDE-LONGITUDE-
ex=Luminary099/LEM_GEOMETRY.agc; in=Luminary099/LEM-GEOMETRY.agc; echo "XX $ex XX"; c
ex=Comanche055/LUNAR_AND_SOLAR_EPHEMERIDES_SUBROUTINES.agc; in=Comanche055/LUNAR-AND-
ex=Luminary099/LUNAR_LANDING_GUIDANCE_EQUATIONS.agc; in=Luminary099/LUNAR-LANDING-GUI
ex=Comanche055/LUNAR_LANDMARK_SELECTION_FOR_CM.agc; in=Comanche055/LUNAR-LANDMARK-SEL
ex=Comanche055/MAIN.agc; in=Comanche055/MAIN.agc; echo "XX $ex XX"; cp $in tmp/$ex
ex=Comanche055/MEASUREMENT_INCORPORATION.agc; in=Comanche055/MEASUREMENT-INCORPORATIO
ex=Comanche055/MYSUBS.agc; in=Comanche055/MYSUBS.agc; echo "XX $ex XX"; cp $in tmp/$e
ex=Comanche055/ORBITAL_INTEGRATION.agc; in=Comanche055/ORBITAL-INTEGRATION.agc; echo
ex=Comanche055/P11.agc; in=Comanche055/P11.agc; echo "XX $ex XX"; cp $in tmp/$ex
ex=Luminary099/P12.agc; in=Luminary099/P12.agc; echo "XX $ex XX"; cp $in tmp/$ex
ex=Comanche055/P20-P25.agc; in=Comanche055/P20-P25.agc; echo "XX $ex XX"; cp $in tmp/
ex=Luminary099/P30_P37.agc; in=Luminary099/P30--P37.agc; echo "XX $ex XX"; cp $in tmp
ex=Comanche055/P30-P37.agc; in=Comanche055/P30-P37.agc; echo "XX $ex XX"; cp $in tmp/
ex=Comanche055/P32-P33_P72-P73.agc; in=Comanche055/P32-P33-P72-P73.agc; echo "XX $ex
ex=Luminary099/P32-P35_P72-P75.agc; in=Luminary099/P32-P35-P72-P75.agc; echo "XX $ex
ex=Comanche055/P34-35_P74-75.agc; in=Comanche055/P34-35-P74-75.agc; echo "XX $ex XX";
ex=Comanche055/P37_P70.agc; in=Comanche055/P37-P70.agc; echo "XX $ex XX"; cp $in tmp/
ex=Comanche055/P40-P47.agc; in=Comanche055/P40-P47.agc; echo "XX $ex XX"; cp $in tmp/
ex=Comanche055/P51-P53.agc; in=Comanche055/P51-P53.agc; echo "XX $ex XX"; cp $in tmp/
ex=Comanche055/P61-P67.agc; in=Comanche055/P61-P67.agc; echo "XX $ex XX"; cp $in tmp/
ex=Luminary099/P70-P71.agc; in=Luminary099/P70-P71.agc; echo "XX $ex XX"; cp $in tmp/
ex=Comanche055/P76.agc; in=Comanche055/P76.agc; echo "XX $ex XX"; cp $in tmp/$ex
ex=Luminary099/P-AXIS_RCS_AUTOPILOT.agc; in=Luminary099/P-AXIS-RCS-AUTOPILOT.agc; ech
ex=Comanche055/PHASE_TABLE_MAINTENANCE.agc; in=Comanche055/PHASE-TABLE-MAINTENANCE.ag
ex=Comanche055/PINBALL_GAME_BUTTONS_AND_LIGHTS.agc; in=Comanche055/PINBALL-GAME-BUTTO
ex=Comanche055/PINBALL_NOUN_TABLES.agc; in=Comanche055/PINBALL-NOUN-TABLES.agc; echo
ex=Comanche055/PLANETARY_INERTIAL_ORIENTATION.agc; in=Comanche055/PLANETARY-INERTIAL-
ex=Comanche055/POWERED_FLIGHT_SUBROUTINES.agc; in=Comanche055/POWERED-FLIGHT-SUBROUTI
ex=Luminary099/Q_R-AXIS_RCS_AUTOPILOT.agc; in=Luminary099/Q-R-AXIS-RCS-AUTOPILOT.agc;
ex=Comanche055/R30.agc; in=Comanche055/R30.agc; echo "XX $ex XX"; cp $in tmp/$ex
ex=Comanche055/R31.agc; in=Comanche055/R31.agc; echo "XX $ex XX"; cp $in tmp/$ex
```

```
ex=Comanche055/R60_62.agc; in=Comanche055/R60-62.agc; echo "XX $ex XX"; cp $in tmp/$ex
ex=Luminary099/R63.agc; in=Luminary099/R63.agc; echo "XX $ex XX"; cp $in tmp/$ex
ex=Luminary099/RADAR_LEADIN_ROUTINES.agc; in=Luminary099/RADAR-LEADIN-ROUTINES.agc; echo "XX $e
ex=Comanche055/RCS-CSM_DAP_EXECUTIVE_PROGRAMS.agc; in=Comanche055/RCS-CSM-DAP-EXECUTIVE-PROGRAM
ex=Comanche055/RCS-CSM_DIGITAL_AUTOPILOT.agc; in=Comanche055/RCS-CSM-DIGITAL-AUTOPILOT.agc; ech
ex=Luminary099/RCS_FAILURE_MONITOR.agc; in=Luminary099/RCS-FAILURE-MONITOR.agc; echo "XX $ex XX
ex=Comanche055/REENTRY_CONTROL.agc; in=Comanche055/REENTRY-CONTROL.agc; echo "XX $ex XX"; cp $i
ex=Comanche055/RESTARTS_ROUTINE.agc; in=Comanche055/RESTARTS-ROUTINE.agc; echo "XX $ex XX"; cp
ex=Comanche055/RESTART_TABLES.agc; in=Comanche055/RESTART-TABLES.agc; echo "XX $ex XX"; cp $in
ex=Comanche055/RT8_OP_CODES.agc; in=Comanche055/RT8-OP-CODES.agc; echo "XX $ex XX"; cp $in tmp/
ex=Luminary099/RTB_OP_CODES.agc; in=Luminary099/RTB-OP-CODES.agc; echo "XX $ex XX"; cp $in tmp/
ex=Comanche055/S-BAND_ANTENNA_FOR_CM.agc; in=Comanche055/S-BAND-ANTENNA-FOR-CM.agc; echo "XX $e
ex=Luminary099/S-BAND_ANTENNA_FOR_LM.agc; in=Luminary099/S-BAND-ANTENNA-FOR-LM.agc; echo "XX $e
ex=Comanche055/SERVICER207.agc; in=Comanche055/SERVICER207.agc; echo "XX $ex XX"; cp $in tmp/$e
ex=Comanche055/SERVICE_ROUTINES.agc; in=Comanche055/SERVICE-ROUTINES.agc; echo "XX $ex XX"; cp
ex=Luminary099/SERVICER.agc; in=Luminary099/SERVICER.agc; echo "XX $ex XX"; cp $in tmp/$ex
ex=Comanche055/SINGLE_PRECISION_SUBROUTINES.agc; in=Comanche055/SINGLE-PRECISION-SUBROUTINES.ag
ex=Luminary099/SPS_BACK-UP_RCS_CONTROL.agc; in=Luminary099/SPS-BACK-UP-RCS-CONTROL.agc; echo "X
ex=Comanche055/STABLE_ORBIT.agc; in=Comanche055/STABLE-ORBIT.agc; echo "XX $ex XX"; cp $in tmp/
ex=Comanche055/STAR_TABLES.agc; in=Comanche055/STAR-TABLES.agc; echo "XX $ex XX"; cp $in tmp/$e
ex=Comanche055/SXTMARK.agc; in=Comanche055/SXTMARK.agc; echo "XX $ex XX"; cp $in tmp/$ex
ex=Comanche055/SYSTEM_TEST_STANDARD_LEAD_INS.agc; in=Comanche055/SYSTEM-TEST-STANDARD-LEAD-INS.
ex=Comanche055/T4RUPT_PROGRAM.agc; in=Comanche055/T4RUPT-PROGRAM.agc; echo "XX $ex XX"; cp $in
ex=Luminary099/T6-RUPT_PROGRAMS.agc; in=Luminary099/T6-RUPT-PROGRAMS.agc; echo "XX $ex XX"; cp
ex=Comanche055/TAGS_FOR_RELATIVE_SETLOC.agc; in=Comanche055/TAGS-FOR-RELATIVE-SETLOC.agc; echo
ex=Luminary099/THE_LUNAR_LANDING.agc; in=Luminary099/THE-LUNAR-LANDING.agc; echo "XX $ex XX"; c
ex=Luminary099/THROTTLE_CONTROL_ROUTINES.agc; in=Luminary099/THROTTLE-CONTROL-ROUTINES.agc; ech
ex=Comanche055/TIME_OF_FREE_FALL.agc; in=Comanche055/TIME-OF-FREE-FALL.agc; echo "XX $ex XX"; c
ex=Luminary099/TJET_LAW.agc; in=Luminary099/TJET-LAW.agc; echo "XX $ex XX"; cp $in tmp/$ex
ex=Comanche055/TPI_SEARCH.agc; in=Comanche055/TPI-SEARCH.agc; echo "XX $ex XX"; cp $in tmp/$ex
ex=Luminary099/TRIM_GIMBAL_CNTROL_SYSTEM.agc; in=Luminary099/TRIM-GIMBAL-CNTROL-SYSTEM.agc; ech
ex=Comanche055/TVCDAPS.agc; in=Comanche055/TVCDAPS.agc; echo "XX $ex XX"; cp $in tmp/$ex
ex=Comanche055/TVCEXECUTIVE.agc; in=Comanche055/TVCEXECUTIVE.agc; echo "XX $ex XX"; cp $in tmp/
ex=Comanche055/TVCINITIALIZE.agc; in=Comanche055/TVCINITIALIZE.agc; echo "XX $ex XX"; cp $in tm
ex=Comanche055/TVCMASSPROP.agc; in=Comanche055/TVCMASSPROP.agc; echo "XX $ex XX"; cp $in tmp/$e
ex=Comanche055/TVCRESTARTS.agc; in=Comanche055/TVCRESTARTS.agc; echo "XX $ex XX"; cp $in tmp/$e
ex=Comanche055/TVCROLLDAP.agc; in=Comanche055/TVCROLLDAP.agc; echo "XX $ex XX"; cp $in tmp/$ex
ex=Comanche055/TVCSTROKETEST.agc; in=Comanche055/TVCSTROKETEST.agc; echo "XX $ex XX"; cp $in tm
ex=Comanche055/UPDATE_PROGRAM.agc; in=Comanche055/UPDATE-PROGRAM.agc; echo "XX $ex XX"; cp $in
ex=Comanche055/WAITLIST.agc; in=Comanche055/WAITLIST.agc; echo "XX $ex XX"; cp $in tmp/$ex
```

This code is written to file `src/export.sh`.

Uses `DISPLAYS` 59, `INFLIGHT` 65, `KEYRUPT` 59, `LANDMARK` 190, `LATITUDE` 191, `MODE` 145, `MYSUBS` 63, `ORBITAL` 59, `P` 188, `Q` 80, `R31` 67, `REENTRY` 65, `RESTART` 57, and `STAR` 186.

Appendix C

Notes, Bibliography and Indexes

C.1 Chunks

⟨*ags initialization* 2111⟩
⟨*alarm and abort* 2006⟩
⟨*anglfind code* 659⟩
⟨*aostask and aosjob* 2587⟩
⟨*aotmark routine* 2120⟩
⟨*ascent guidance* 2358⟩
⟨*assembly and operation information* 21⟩
⟨*attitude maneuver routine* 2151⟩
⟨*automatic maneuvers* 1433⟩
⟨*burn-baby-burn master ignition routine* 2259⟩
⟨*chieftan routines* 1523a⟩
⟨*cm agc block two self check* 1871⟩
⟨*cm body attitude* 1290⟩
⟨*cm entry digital autopilot* 1480⟩
⟨*comaid routines* 245b⟩
⟨*Comanche055.agc* 19a⟩
⟨*comekiss routines* 744b⟩
⟨*comerase routine* 74b⟩
⟨*conic subroutines* 1710⟩
⟨*contract and approvals* 19c⟩
⟨*controlled constants* 2042⟩
⟨*csm geometry* 480⟩
⟨*dap interface subroutines* 2499a⟩
⟨*dapidler program* 2503b⟩
⟨*display interface routines* 1948⟩
⟨*down-telemetry program* 1523b⟩

⟨*downlink lists* 293b⟩
⟨*entry lexicon* 1244⟩
⟨*erasable assignments* 75⟩
⟨*executive code* 1648⟩
⟨*extended verbs* 404⟩
⟨*findcduw-guidap interface* 2439⟩
⟨*fixed fixed constant pool* 1637b⟩
⟨*flagword assignments* 2065⟩
⟨*fresh start and restart* 306⟩
⟨*gimbal lock avoidance* 681b⟩
⟨*ground tracking determination program* 744c⟩
⟨*imu calibration and alignment* 695⟩
⟨*imu compensation package* 492c⟩
⟨*imu mode switching routines* 1916⟩
⟨*imu performance test 2* 2188b⟩
⟨*imu performance tests 4* 2202a⟩
⟨*inflight alignment routines* 1834⟩
⟨*input output channel bit descriptions* 2058⟩
⟨*integration initialization* 1771⟩
⟨*inter-bank communication* 1539b⟩
⟨*interpreter code* 1544⟩
⟨*interpretive constant* 2475b⟩
⟨*interpretive constants* 1645a⟩
⟨*interrupt lead ins* 246⟩
⟨*jet selection logic* 1452⟩
⟨*kalcmanu steering* 683b⟩
⟨*kalman filter* 2571⟩
⟨*keyrupt uprupt* 1944b⟩
⟨*lambert aimpoint guidance* 2253⟩
⟨*landing analog displays* 2419⟩
⟨*latitude longitude subroutines* 1674⟩
⟨*lem geometry* 2143⟩
⟨*lm agc block two self check* 2477b⟩
⟨*lm down-telemetry program* 2460⟩
⟨*lm rtb op codes* 2495b⟩
⟨*Luminary099.agc* 2041⟩
⟨*lunar and solar ephemerides subroutines* 1194⟩
⟨*lunar landing guidance equations* 2311⟩
⟨*lunar landmark selection for cm* 1346a⟩
⟨*main headers* 19b⟩
⟨*measurement incorporation* 1692⟩
⟨*mysubs code* 1409⟩
⟨*orbital integration* 1813b⟩
⟨*p axis rcs autopilot* 2519⟩
⟨*p11 code* 857b⟩
⟨*p12 routine* 2353⟩

⟨*p20 p25 code* 913⟩
⟨*p30 p37 code* 1042b⟩
⟨*p30-p37 routines* 2218⟩
⟨*p32-p33 p72-p73 code* 1062b⟩
⟨*p32-p35 p72-p75 routines* 2223⟩
⟨*p34-35 p74-75 code* 751⟩
⟨*p37 p70 code* 1300b⟩
⟨*p40-p47 code* 1093⟩
⟨*p51-p53 code* 1146⟩
⟨*p61-p67 code* 1199⟩
⟨*p70-p71 routines* 2343⟩
⟨*p76 code* 819⟩
⟨*Page CM0001* 20⟩
⟨*Page CM0002* 22⟩
⟨*Page CM0003* 24⟩
⟨*Page CM0004* 25⟩
⟨*Page CM0005* 26⟩
⟨*Page CM0006* 28⟩
⟨*Page CM0007* 29⟩
⟨*Page CM0008* 30⟩
⟨*Page CM0009* 31⟩
⟨*Page CM0010* 32⟩
⟨*Page CM0011* 33⟩
⟨*Page CM0012* 35⟩
⟨*Page CM0013* 37⟩
⟨*Page CM0014* 38⟩
⟨*Page CM0015* 40⟩
⟨*Page CM0016* 42⟩
⟨*Page CM0017* 44⟩
⟨*Page CM0018* 45⟩
⟨*Page CM0019* 46⟩
⟨*Page CM0020* 48⟩
⟨*Page CM0021* 50⟩
⟨*Page CM0022* 51⟩
⟨*Page CM0023* 52⟩
⟨*Page CM0024* 54⟩
⟨*Page CM0025* 55⟩
⟨*Page CM0026* 56a⟩
⟨*Page CM0027* 57⟩
⟨*Page CM0028* 59⟩
⟨*Page CM0029* 61⟩
⟨*Page CM0030* 63⟩
⟨*Page CM0031* 65⟩
⟨*Page CM0032* 67⟩
⟨*Page CM0033* 69⟩
⟨*Page CM0034* 71⟩

⟨*Page CM0035* 73⟩
⟨*Page CM0036* 74a⟩
⟨*Page CM0037* 78⟩
⟨*Page CM0038* 79⟩
⟨*Page CM0039* 80⟩
⟨*Page CM0040* 85⟩
⟨*Page CM0041* 87⟩
⟨*Page CM0042* 89⟩
⟨*Page CM0043* 91⟩
⟨*Page CM0044* 93⟩
⟨*Page CM0045* 94⟩
⟨*Page CM0046* 95⟩
⟨*Page CM0047* 97⟩
⟨*Page CM0048* 99⟩
⟨*Page CM0049* 101⟩
⟨*Page CM0050* 103⟩
⟨*Page CM0051* 105⟩
⟨*Page CM0052* 107⟩
⟨*Page CM0053* 109⟩
⟨*Page CM0054* 111⟩
⟨*Page CM0055* 113⟩
⟨*Page CM0056* 115⟩
⟨*Page CM0057* 117⟩
⟨*Page CM0058* 119⟩
⟨*Page CM0059* 121⟩
⟨*Page CM0060* 123⟩
⟨*Page CM0061* 125⟩
⟨*Page CM0062* 127⟩
⟨*Page CM0063* 129⟩
⟨*Page CM0064* 131⟩
⟨*Page CM0065* 133⟩
⟨*Page CM0066* 135⟩
⟨*Page CM0067* 137⟩
⟨*Page CM0068* 138⟩
⟨*Page CM0069* 140⟩
⟨*Page CM0070* 142⟩
⟨*Page CM0071* 144⟩
⟨*Page CM0072* 145⟩
⟨*Page CM0073* 148⟩
⟨*Page CM0074* 150⟩
⟨*Page CM0075* 152⟩
⟨*Page CM0076* 154⟩
⟨*Page CM0077* 156⟩
⟨*Page CM0078* 157⟩
⟨*Page CM0079* 159⟩
⟨*Page CM0080* 161⟩

⟨*Page CM0081* 163⟩
⟨*Page CM0082* 165⟩
⟨*Page CM0083* 166⟩
⟨*Page CM0084* 167⟩
⟨*Page CM0085* 169⟩
⟨*Page CM0086* 172⟩
⟨*Page CM0087* 174⟩
⟨*Page CM0088* 175⟩
⟨*Page CM0089* 177⟩
⟨*Page CM0090* 179⟩
⟨*Page CM0091* 181⟩
⟨*Page CM0092* 182⟩
⟨*Page CM0093* 183⟩
⟨*Page CM0094* 185⟩
⟨*Page CM0095* 186⟩
⟨*Page CM0096* 188⟩
⟨*Page CM0097* 190⟩
⟨*Page CM0098* 191⟩
⟨*Page CM0099* 194⟩
⟨*Page CM0100* 196⟩
⟨*Page CM0101* 197⟩
⟨*Page CM0102* 198⟩
⟨*Page CM0103* 200⟩
⟨*Page CM0104* 202⟩
⟨*Page CM0105* 204⟩
⟨*Page CM0106* 206⟩
⟨*Page CM0107* 208⟩
⟨*Page CM0108* 209⟩
⟨*Page CM0109* 211⟩
⟨*Page CM0110* 213⟩
⟨*Page CM0111* 214⟩
⟨*Page CM0112* 216⟩
⟨*Page CM0113* 218⟩
⟨*Page CM0114* 219⟩
⟨*Page CM0115* 221⟩
⟨*Page CM0116* 223⟩
⟨*Page CM0117* 224⟩
⟨*Page CM0118* 226⟩
⟨*Page CM0119* 229⟩
⟨*Page CM0120* 231⟩
⟨*Page CM0121* 232⟩
⟨*Page CM0122* 234⟩
⟨*Page CM0123* 236⟩
⟨*Page CM0124* 238⟩
⟨*Page CM0125* 239⟩
⟨*Page CM0126* 240⟩

⟨*Page CM0127* 241⟩
⟨*Page CM0128* 243⟩
⟨*Page CM0129* 244⟩
⟨*Page CM0130* 245a⟩
⟨*Page CM0131* 247⟩
⟨*Page CM0132* 249⟩
⟨*Page CM0133* 251⟩
⟨*Page CM0134* 252⟩
⟨*Page CM0135* 253⟩
⟨*Page CM0136* 254⟩
⟨*Page CM0137* 255⟩
⟨*Page CM0138* 256⟩
⟨*Page CM0139* 257⟩
⟨*Page CM0140* 258⟩
⟨*Page CM0141* 259⟩
⟨*Page CM0142* 261⟩
⟨*Page CM0143* 263⟩
⟨*Page CM0144* 264⟩
⟨*Page CM0145* 265⟩
⟨*Page CM0146* 266⟩
⟨*Page CM0147* 267⟩
⟨*Page CM0148* 268⟩
⟨*Page CM0149* 269⟩
⟨*Page CM0150* 270⟩
⟨*Page CM0151* 271⟩
⟨*Page CM0152* 272⟩
⟨*Page CM0153* 273⟩
⟨*Page CM0154* 274⟩
⟨*Page CM0155* 276⟩
⟨*Page CM0156* 277⟩
⟨*Page CM0157* 278⟩
⟨*Page CM0158* 279⟩
⟨*Page CM0159* 280⟩
⟨*Page CM0160* 281⟩
⟨*Page CM0161* 282⟩
⟨*Page CM0162* 284⟩
⟨*Page CM0163* 285⟩
⟨*Page CM0164* 286⟩
⟨*Page CM0165* 287⟩
⟨*Page CM0166* 288⟩
⟨*Page CM0167* 290⟩
⟨*Page CM0168* 292⟩
⟨*Page CM0169* 293a⟩
⟨*Page CM0170* 294⟩
⟨*Page CM0171* 295⟩
⟨*Page CM0172* 297⟩

⟨*Page CM0173* 298⟩
⟨*Page CM0174* 299⟩
⟨*Page CM0175* 300⟩
⟨*Page CM0176* 301⟩
⟨*Page CM0177* 302⟩
⟨*Page CM0178* 303⟩
⟨*Page CM0179* 304⟩
⟨*Page CM0180* 305⟩
⟨*Page CM0181* 307⟩
⟨*Page CM0182* 309⟩
⟨*Page CM0183* 311⟩
⟨*Page CM0184* 313⟩
⟨*Page CM0185* 315⟩
⟨*Page CM0186* 317⟩
⟨*Page CM0187* 319⟩
⟨*Page CM0188* 321⟩
⟨*Page CM0189* 323⟩
⟨*Page CM0190* 325⟩
⟨*Page CM0191* 327⟩
⟨*Page CM0192* 329⟩
⟨*Page CM0193* 330⟩
⟨*Page CM0194* 331⟩
⟨*Page CM0195* 332⟩
⟨*Page CM0196* 333⟩
⟨*Page CM0197* 335⟩
⟨*Page CM0198* 337⟩
⟨*Page CM0199* 339⟩
⟨*Page CM0200* 341⟩
⟨*Page CM0201* 343⟩
⟨*Page CM0202* 345⟩
⟨*Page CM0203* 347⟩
⟨*Page CM0204* 349⟩
⟨*Page CM0205* 351⟩
⟨*Page CM0206* 353⟩
⟨*Page CM0207* 355⟩
⟨*Page CM0208* 357⟩
⟨*Page CM0209* 359⟩
⟨*Page CM0210* 360⟩
⟨*Page CM0211* 362⟩
⟨*Page CM0212* 364⟩
⟨*Page CM0213* 366⟩
⟨*Page CM0214* 368⟩
⟨*Page CM0215* 370⟩
⟨*Page CM0216* 372⟩
⟨*Page CM0217* 374⟩
⟨*Page CM0218* 376⟩

⟨*Page CM0219* 377⟩
⟨*Page CM0220* 378⟩
⟨*Page CM0221* 380⟩
⟨*Page CM0222* 382⟩
⟨*Page CM0223* 384⟩
⟨*Page CM0224* 386⟩
⟨*Page CM0225* 388⟩
⟨*Page CM0226* 389⟩
⟨*Page CM0227* 390⟩
⟨*Page CM0228* 392⟩
⟨*Page CM0229* 394⟩
⟨*Page CM0230* 396⟩
⟨*Page CM0231* 397⟩
⟨*Page CM0232* 398⟩
⟨*Page CM0233* 400⟩
⟨*Page CM0234* 402⟩
⟨*Page CM0235* 403⟩
⟨*Page CM0236* 405⟩
⟨*Page CM0237* 407⟩
⟨*Page CM0238* 408⟩
⟨*Page CM0239* 409⟩
⟨*Page CM0240* 410⟩
⟨*Page CM0241* 411⟩
⟨*Page CM0242* 412⟩
⟨*Page CM0243* 414⟩
⟨*Page CM0244* 416⟩
⟨*Page CM0245* 417⟩
⟨*Page CM0246* 418⟩
⟨*Page CM0247* 419⟩
⟨*Page CM0248* 420⟩
⟨*Page CM0249* 421⟩
⟨*Page CM0250* 423⟩
⟨*Page CM0251* 424⟩
⟨*Page CM0252* 425⟩
⟨*Page CM0253* 426⟩
⟨*Page CM0254* 428⟩
⟨*Page CM0255* 430⟩
⟨*Page CM0256* 431⟩
⟨*Page CM0257* 432⟩
⟨*Page CM0258* 433⟩
⟨*Page CM0259* 434⟩
⟨*Page CM0260* 436⟩
⟨*Page CM0261* 437⟩
⟨*Page CM0262* 438⟩
⟨*Page CM0263* 440⟩
⟨*Page CM0264* 442⟩

⟨*Page CM0265* 444⟩
⟨*Page CM0266* 446⟩
⟨*Page CM0267* 448⟩
⟨*Page CM0268* 450⟩
⟨*Page CM0269* 451⟩
⟨*Page CM0270* 452⟩
⟨*Page CM0271* 454⟩
⟨*Page CM0272* 456⟩
⟨*Page CM0273* 458⟩
⟨*Page CM0274* 460⟩
⟨*Page CM0275* 462⟩
⟨*Page CM0276* 464⟩
⟨*Page CM0277* 466⟩
⟨*Page CM0278* 468⟩
⟨*Page CM0279* 470⟩
⟨*Page CM0280* 472⟩
⟨*Page CM0281* 474⟩
⟨*Page CM0282* 476⟩
⟨*Page CM0283* 478⟩
⟨*Page CM0284* 479⟩
⟨*Page CM0285* 481⟩
⟨*Page CM0286* 482⟩
⟨*Page CM0287* 483⟩
⟨*Page CM0288* 484⟩
⟨*Page CM0289* 485⟩
⟨*Page CM0290* 486⟩
⟨*Page CM0291* 487⟩
⟨*Page CM0292* 488⟩
⟨*Page CM0293* 489⟩
⟨*Page CM0294* 491⟩
⟨*Page CM0295* 492a⟩
⟨*Page CM0296* 492b⟩
⟨*Page CM0297* 493⟩
⟨*Page CM0298* 494⟩
⟨*Page CM0299* 495⟩
⟨*Page CM0300* 496⟩
⟨*Page CM0301* 497⟩
⟨*Page CM0302* 498⟩
⟨*Page CM0303* 499⟩
⟨*Page CM0304* 501⟩
⟨*Page CM0305* 502⟩
⟨*Page CM0306* 503⟩
⟨*Page CM0307* 506⟩
⟨*Page CM0308* 508⟩
⟨*Page CM0309* 510⟩
⟨*Page CM0310* 512⟩

⟨*Page CM0311* 514⟩
⟨*Page CM0312* 515⟩
⟨*Page CM0313* 517⟩
⟨*Page CM0314* 518⟩
⟨*Page CM0315* 519⟩
⟨*Page CM0316* 521⟩
⟨*Page CM0317* 523⟩
⟨*Page CM0318* 525⟩
⟨*Page CM0319* 527⟩
⟨*Page CM0320* 529⟩
⟨*Page CM0321* 531⟩
⟨*Page CM0322* 533⟩
⟨*Page CM0323* 535⟩
⟨*Page CM0324* 537⟩
⟨*Page CM0325* 539⟩
⟨*Page CM0326* 540⟩
⟨*Page CM0327* 541⟩
⟨*Page CM0328* 543⟩
⟨*Page CM0329* 544⟩
⟨*Page CM0330* 545⟩
⟨*Page CM0331* 547⟩
⟨*Page CM0332* 549⟩
⟨*Page CM0333* 551⟩
⟨*Page CM0334* 553⟩
⟨*Page CM0335* 555⟩
⟨*Page CM0336* 557⟩
⟨*Page CM0337* 559⟩
⟨*Page CM0338* 561⟩
⟨*Page CM0339* 563⟩
⟨*Page CM0340* 565⟩
⟨*Page CM0341* 567⟩
⟨*Page CM0342* 568⟩
⟨*Page CM0343* 569⟩
⟨*Page CM0344* 571⟩
⟨*Page CM0345* 573⟩
⟨*Page CM0346* 575⟩
⟨*Page CM0347* 577⟩
⟨*Page CM0348* 579⟩
⟨*Page CM0349* 581⟩
⟨*Page CM0350* 583⟩
⟨*Page CM0351* 585⟩
⟨*Page CM0352* 587⟩
⟨*Page CM0353* 589⟩
⟨*Page CM0354* 590⟩
⟨*Page CM0355* 591⟩
⟨*Page CM0356* 593⟩

⟨*Page CM0357* 595⟩
⟨*Page CM0358* 596⟩
⟨*Page CM0359* 597⟩
⟨*Page CM0360* 599⟩
⟨*Page CM0361* 601⟩
⟨*Page CM0362* 603⟩
⟨*Page CM0363* 605⟩
⟨*Page CM0364* 607⟩
⟨*Page CM0365* 609⟩
⟨*Page CM0366* 611⟩
⟨*Page CM0367* 612⟩
⟨*Page CM0368* 613⟩
⟨*Page CM0369* 615⟩
⟨*Page CM0370* 617⟩
⟨*Page CM0371* 619⟩
⟨*Page CM0372* 621⟩
⟨*Page CM0373* 623⟩
⟨*Page CM0374* 625⟩
⟨*Page CM0375* 627⟩
⟨*Page CM0376* 629⟩
⟨*Page CM0377* 630⟩
⟨*Page CM0378* 631⟩
⟨*Page CM0379* 633⟩
⟨*Page CM0380* 635⟩
⟨*Page CM0381* 637⟩
⟨*Page CM0382* 638⟩
⟨*Page CM0383* 639a⟩
⟨*Page CM0384* 639b⟩
⟨*Page CM0385* 640⟩
⟨*Page CM0386* 642⟩
⟨*Page CM0387* 643⟩
⟨*Page CM0388* 644⟩
⟨*Page CM0389* 645⟩
⟨*Page CM0390* 647⟩
⟨*Page CM0391* 649⟩
⟨*Page CM0392* 650⟩
⟨*Page CM0393* 651⟩
⟨*Page CM0394* 653⟩
⟨*Page CM0395* 655⟩
⟨*Page CM0396* 657⟩
⟨*Page CM0397* 658a⟩
⟨*Page CM0398* 658b⟩
⟨*Page CM0399* 660⟩
⟨*Page CM0400* 662⟩
⟨*Page CM0401* 664⟩
⟨*Page CM0402* 666⟩

⟨*Page CM0403* 667⟩
⟨*Page CM0404* 668⟩
⟨*Page CM0405* 670⟩
⟨*Page CM0406* 672⟩
⟨*Page CM0407* 674⟩
⟨*Page CM0408* 676⟩
⟨*Page CM0409* 678⟩
⟨*Page CM0410* 680⟩
⟨*Page CM0411* 681a⟩
⟨*Page CM0412* 682⟩
⟨*Page CM0413* 683a⟩
⟨*Page CM0414* 684⟩
⟨*Page CM0415* 686⟩
⟨*Page CM0416* 688⟩
⟨*Page CM0417* 689⟩
⟨*Page CM0418* 690⟩
⟨*Page CM0419* 691a⟩
⟨*Page CM0420* 692⟩
⟨*Page CM0421* 693⟩
⟨*Page CM0422* 694⟩
⟨*Page CM0423* 696⟩
⟨*Page CM0424* 698⟩
⟨*Page CM0425* 700⟩
⟨*Page CM0426* 702⟩
⟨*Page CM0427* 703⟩
⟨*Page CM0428* 704⟩
⟨*Page CM0429* 705⟩
⟨*Page CM0430* 706⟩
⟨*Page CM0431* 708⟩
⟨*Page CM0432* 710⟩
⟨*Page CM0433* 711⟩
⟨*Page CM0434* 712⟩
⟨*Page CM0435* 713⟩
⟨*Page CM0436* 714⟩
⟨*Page CM0437* 716⟩
⟨*Page CM0438* 717⟩
⟨*Page CM0439* 718⟩
⟨*Page CM0440* 720⟩
⟨*Page CM0441* 722⟩
⟨*Page CM0442* 724⟩
⟨*Page CM0443* 725⟩
⟨*Page CM0444* 727⟩
⟨*Page CM0445* 729⟩
⟨*Page CM0446* 731⟩
⟨*Page CM0447* 732a⟩
⟨*Page CM0448* 732b⟩

⟨*Page CM0449* 733⟩
⟨*Page CM0450* 735⟩
⟨*Page CM0451* 737⟩
⟨*Page CM0452* 739⟩
⟨*Page CM0453* 741⟩
⟨*Page CM0454* 743⟩
⟨*Page CM0455* 744a⟩
⟨*Page CM0456* 745⟩
⟨*Page CM0457* 747⟩
⟨*Page CM0458* 749⟩
⟨*Page CM0459* 750⟩
⟨*Page CM0460* 752⟩
⟨*Page CM0461* 753⟩
⟨*Page CM0462* 754⟩
⟨*Page CM0463* 756⟩
⟨*Page CM0464* 758⟩
⟨*Page CM0465* 759⟩
⟨*Page CM0466* 760⟩
⟨*Page CM0467* 761⟩
⟨*Page CM0468* 762⟩
⟨*Page CM0469* 763⟩
⟨*Page CM0470* 765⟩
⟨*Page CM0471* 767⟩
⟨*Page CM0472* 769⟩
⟨*Page CM0473* 770a⟩
⟨*Page CM0474* 770b⟩
⟨*Page CM0475* 771⟩
⟨*Page CM0476* 772⟩
⟨*Page CM0477* 773⟩
⟨*Page CM0478* 774⟩
⟨*Page CM0479* 775⟩
⟨*Page CM0480* 777⟩
⟨*Page CM0481* 779⟩
⟨*Page CM0482* 780⟩
⟨*Page CM0483* 781⟩
⟨*Page CM0484* 782⟩
⟨*Page CM0485* 783⟩
⟨*Page CM0486* 784⟩
⟨*Page CM0487* 786⟩
⟨*Page CM0488* 788⟩
⟨*Page CM0489* 790⟩
⟨*Page CM0490* 792⟩
⟨*Page CM0491* 793⟩
⟨*Page CM0492* 794⟩
⟨*Page CM0493* 795⟩
⟨*Page CM0494* 796⟩

⟨*Page CM0495* 797⟩
⟨*Page CM0496* 798⟩
⟨*Page CM0497* 799⟩
⟨*Page CM0498* 800a⟩
⟨*Page CM0499* 800b⟩
⟨*Page CM0500* 801⟩
⟨*Page CM0501* 802⟩
⟨*Page CM0502* 804⟩
⟨*Page CM0503* 806⟩
⟨*Page CM0504* 808⟩
⟨*Page CM0505* 810⟩
⟨*Page CM0506* 812⟩
⟨*Page CM0507* 813⟩
⟨*Page CM0508* 814⟩
⟨*Page CM0509* 816⟩
⟨*Page CM0510* 818⟩
⟨*Page CM0511* 820⟩
⟨*Page CM0512* 822⟩
⟨*Page CM0513* 823⟩
⟨*Page CM0514* 825⟩
⟨*Page CM0515* 827⟩
⟨*Page CM0516* 829⟩
⟨*Page CM0517* 831⟩
⟨*Page CM0518* 833⟩
⟨*Page CM0519* 835⟩
⟨*Page CM0520* 836⟩
⟨*Page CM0521* 837⟩
⟨*Page CM0522* 839⟩
⟨*Page CM0523* 840a⟩
⟨*Page CM0524* 840b⟩
⟨*Page CM0525* 842⟩
⟨*Page CM0526* 844⟩
⟨*Page CM0527* 846⟩
⟨*Page CM0528* 848⟩
⟨*Page CM0529* 850⟩
⟨*Page CM0530* 852⟩
⟨*Page CM0531* 854⟩
⟨*Page CM0532* 856⟩
⟨*Page CM0533* 858⟩
⟨*Page CM0534* 860⟩
⟨*Page CM0535* 862⟩
⟨*Page CM0536* 864⟩
⟨*Page CM0537* 866⟩
⟨*Page CM0538* 868⟩
⟨*Page CM0539* 870⟩
⟨*Page CM0540* 872⟩

⟨*Page CM0541* 874⟩
⟨*Page CM0542* 876⟩
⟨*Page CM0543* 878⟩
⟨*Page CM0544* 880⟩
⟨*Page CM0545* 882⟩
⟨*Page CM0546* 884⟩
⟨*Page CM0547* 886⟩
⟨*Page CM0548* 888⟩
⟨*Page CM0549* 890⟩
⟨*Page CM0550* 891⟩
⟨*Page CM0551* 893⟩
⟨*Page CM0552* 895⟩
⟨*Page CM0553* 897⟩
⟨*Page CM0554* 899⟩
⟨*Page CM0555* 901⟩
⟨*Page CM0556* 903⟩
⟨*Page CM0557* 905⟩
⟨*Page CM0558* 907⟩
⟨*Page CM0559* 909⟩
⟨*Page CM0560* 911⟩
⟨*Page CM0561* 912⟩
⟨*Page CM0562* 915⟩
⟨*Page CM0563* 917⟩
⟨*Page CM0564* 918⟩
⟨*Page CM0565* 919⟩
⟨*Page CM0566* 921⟩
⟨*Page CM0567* 923⟩
⟨*Page CM0568* 925⟩
⟨*Page CM0569* 926⟩
⟨*Page CM0570* 927⟩
⟨*Page CM0571* 929⟩
⟨*Page CM0572* 930⟩
⟨*Page CM0573* 932⟩
⟨*Page CM0574* 934⟩
⟨*Page CM0575* 936⟩
⟨*Page CM0576* 937⟩
⟨*Page CM0577* 938⟩
⟨*Page CM0578* 939⟩
⟨*Page CM0579* 941⟩
⟨*Page CM0580* 943⟩
⟨*Page CM0581* 945⟩
⟨*Page CM0582* 947⟩
⟨*Page CM0583* 949⟩
⟨*Page CM0584* 951⟩
⟨*Page CM0585* 953⟩
⟨*Page CM0586* 955⟩

⟨*Page CM0587* 957⟩
⟨*Page CM0588* 959⟩
⟨*Page CM0589* 960⟩
⟨*Page CM0590* 961⟩
⟨*Page CM0591* 963⟩
⟨*Page CM0592* 965⟩
⟨*Page CM0593* 967⟩
⟨*Page CM0594* 969⟩
⟨*Page CM0595* 971⟩
⟨*Page CM0596* 973⟩
⟨*Page CM0597* 975⟩
⟨*Page CM0598* 977⟩
⟨*Page CM0599* 979⟩
⟨*Page CM0600* 981⟩
⟨*Page CM0601* 983⟩
⟨*Page CM0602* 985⟩
⟨*Page CM0603* 987⟩
⟨*Page CM0604* 989⟩
⟨*Page CM0605* 991⟩
⟨*Page CM0606* 993⟩
⟨*Page CM0607* 995⟩
⟨*Page CM0608* 997⟩
⟨*Page CM0609* 999⟩
⟨*Page CM0610* 1001⟩
⟨*Page CM0611* 1003⟩
⟨*Page CM0612* 1005⟩
⟨*Page CM0613* 1007⟩
⟨*Page CM0614* 1009⟩
⟨*Page CM0615* 1010⟩
⟨*Page CM0616* 1011⟩
⟨*Page CM0617* 1013⟩
⟨*Page CM0618* 1014⟩
⟨*Page CM0619* 1015⟩
⟨*Page CM0620* 1017⟩
⟨*Page CM0621* 1019⟩
⟨*Page CM0622* 1021⟩
⟨*Page CM0623* 1023⟩
⟨*Page CM0624* 1024⟩
⟨*Page CM0625* 1025⟩
⟨*Page CM0626* 1027⟩
⟨*Page CM0627* 1029⟩
⟨*Page CM0628* 1031⟩
⟨*Page CM0629* 1033⟩
⟨*Page CM0630* 1035⟩
⟨*Page CM0631* 1037⟩
⟨*Page CM0632* 1039⟩

⟨*Page CM0633* 1041⟩
⟨*Page CM0634* 1042a⟩
⟨*Page CM0635* 1043⟩
⟨*Page CM0636* 1045⟩
⟨*Page CM0637* 1047⟩
⟨*Page CM0638* 1048⟩
⟨*Page CM0639* 1049⟩
⟨*Page CM0640* 1051⟩
⟨*Page CM0641* 1052⟩
⟨*Page CM0642* 1053⟩
⟨*Page CM0643* 1054⟩
⟨*Page CM0644* 1056⟩
⟨*Page CM0645* 1058⟩
⟨*Page CM0646* 1059⟩
⟨*Page CM0646a* 1060⟩
⟨*Page CM0647* 1061⟩
⟨*Page CM0648* 1062a⟩
⟨*Page CM0649* 1063⟩
⟨*Page CM0684* 1094⟩
⟨*Page CM0737* 1147⟩
⟨*Page CM0785* 1195⟩
⟨*Page CM0789* 1200⟩
⟨*Page CM0819* 1227⟩
⟨*Page CM0837* 1245⟩
⟨*Page CM0838* 1247⟩
⟨*Page CM0839* 1248⟩
⟨*Page CM0840* 1250⟩
⟨*Page CM0841* 1252⟩
⟨*Page CM0842* 1254⟩
⟨*Page CM0843* 1255a⟩
⟨*Page CM0844* 1256⟩
⟨*Page CM0883* 1291⟩
⟨*Page CM0884* 1293⟩
⟨*Page CM0885* 1295⟩
⟨*Page CM0886* 1296⟩
⟨*Page CM0887* 1297⟩
⟨*Page CM0888* 1299⟩
⟨*Page CM0889* 1300a⟩
⟨*Page CM0890* 1301⟩
⟨*Page CM0934* 1344⟩
⟨*Page CM0936* 1346b⟩
⟨*Page CM0937* 1347⟩
⟨*Page CM0945* 1356⟩
⟨*Page CM0951* 1362⟩
⟨*Page CM0956* 1367⟩
⟨*Page CM0961* 1373⟩

⟨*Page CM0979* 1390⟩
⟨*Page CM0984* 1396⟩
⟨*Page CM0999* 1410⟩
⟨*Page CM1002* 1412⟩
⟨*Page CM1025* 1434⟩
⟨*Page CM1026* 1435⟩
⟨*Page CM1027* 1436⟩
⟨*Page CM1028* 1438⟩
⟨*Page CM1029* 1439⟩
⟨*Page CM1030* 1441⟩
⟨*Page CM1031* 1443⟩
⟨*Page CM1032* 1445⟩
⟨*Page CM1033* 1447⟩
⟨*Page CM1034* 1448⟩
⟨*Page CM1035* 1449⟩
⟨*Page CM1036* 1450a⟩
⟨*Page CM1037* 1451⟩
⟨*Page CM1039* 1453⟩
⟨*Page CM1040* 1455⟩
⟨*Page CM1041* 1456⟩
⟨*Page CM1042* 1457⟩
⟨*Page CM1043* 1458⟩
⟨*Page CM1044* 1460⟩
⟨*Page CM1045* 1461⟩
⟨*Page CM1046* 1462⟩
⟨*Page CM1047* 1463⟩
⟨*Page CM1048* 1464⟩
⟨*Page CM1049* 1465⟩
⟨*Page CM1050* 1466⟩
⟨*Page CM1051* 1467⟩
⟨*Page CM1052* 1468⟩
⟨*Page CM1053* 1469⟩
⟨*Page CM1054* 1470a⟩
⟨*Page CM1055* 1470b⟩
⟨*Page CM1056* 1471⟩
⟨*Page CM1057* 1473⟩
⟨*Page CM1058* 1474⟩
⟨*Page CM1059* 1475⟩
⟨*Page CM1060* 1476⟩
⟨*Page CM1061* 1477⟩
⟨*Page CM1062* 1479⟩
⟨*Page CM1063* 1481⟩
⟨*Page CM1064* 1483⟩
⟨*Page CM1065* 1484⟩
⟨*Page CM1066* 1485⟩
⟨*Page CM1067* 1486⟩

⟨*Page CM1068* 1487⟩
⟨*Page CM1069* 1488⟩
⟨*Page CM1070* 1489⟩
⟨*Page CM1071* 1491⟩
⟨*Page CM1072* 1492⟩
⟨*Page CM1073* 1493⟩
⟨*Page CM1074* 1495⟩
⟨*Page CM1075* 1496⟩
⟨*Page CM1076* 1497⟩
⟨*Page CM1077* 1498⟩
⟨*Page CM1078* 1500⟩
⟨*Page CM1079* 1502⟩
⟨*Page CM1080* 1503⟩
⟨*Page CM1081* 1504⟩
⟨*Page CM1082* 1506⟩
⟨*Page CM1083* 1508⟩
⟨*Page CM1084* 1510⟩
⟨*Page CM1085* 1512⟩
⟨*Page CM1086* 1513⟩
⟨*Page CM1087* 1514⟩
⟨*Page CM1088* 1516⟩
⟨*Page CM1089* 1518⟩
⟨*Page CM1090* 1519⟩
⟨*Page CM1091* 1521⟩
⟨*Page CM1092* 1522⟩
⟨*Page CM1093* 1524⟩
⟨*Page CM1094* 1525⟩
⟨*Page CM1095* 1526⟩
⟨*Page CM1096* 1528⟩
⟨*Page CM1097* 1530⟩
⟨*Page CM1098* 1532⟩
⟨*Page CM1099* 1534⟩
⟨*Page CM1100* 1536⟩
⟨*Page CM1101* 1538⟩
⟨*Page CM1102* 1539a⟩
⟨*Page CM1103* 1540⟩
⟨*Page CM1104* 1541⟩
⟨*Page CM1105* 1542⟩
⟨*Page CM1106* 1543⟩
⟨*Page CM1107* 1546⟩
⟨*Page CM1108* 1547⟩
⟨*Page CM1109* 1548⟩
⟨*Page CM1110* 1549⟩
⟨*Page CM1111* 1550⟩
⟨*Page CM1112* 1551⟩
⟨*Page CM1113* 1552⟩

⟨*Page CM1114* 1553a⟩
⟨*Page CM1115* 1553b⟩
⟨*Page CM1116* 1554⟩
⟨*Page CM1117* 1555a⟩
⟨*Page CM1118* 1555b⟩
⟨*Page CM1119* 1556⟩
⟨*Page CM1120* 1557⟩
⟨*Page CM1121* 1558⟩
⟨*Page CM1122* 1559⟩
⟨*Page CM1123* 1560⟩
⟨*Page CM1124* 1561⟩
⟨*Page CM1125* 1562⟩
⟨*Page CM1126* 1563⟩
⟨*Page CM1127* 1564⟩
⟨*Page CM1128* 1565⟩
⟨*Page CM1129* 1566⟩
⟨*Page CM1130* 1567⟩
⟨*Page CM1131* 1568⟩
⟨*Page CM1132* 1569⟩
⟨*Page CM1133* 1570⟩
⟨*Page CM1134* 1571a⟩
⟨*Page CM1135* 1571b⟩
⟨*Page CM1136* 1572⟩
⟨*Page CM1137* 1573⟩
⟨*Page CM1138* 1574⟩
⟨*Page CM1139* 1575⟩
⟨*Page CM1140* 1576⟩
⟨*Page CM1141* 1577⟩
⟨*Page CM1142* 1578a⟩
⟨*Page CM1143* 1578b⟩
⟨*Page CM1144* 1579⟩
⟨*Page CM1145* 1580⟩
⟨*Page CM1146* 1581⟩
⟨*Page CM1147* 1582⟩
⟨*Page CM1148* 1584⟩
⟨*Page CM1149* 1585⟩
⟨*Page CM1150* 1586⟩
⟨*Page CM1151* 1587⟩
⟨*Page CM1152* 1588⟩
⟨*Page CM1153* 1589⟩
⟨*Page CM1154* 1590⟩
⟨*Page CM1155* 1591⟩
⟨*Page CM1156* 1592⟩
⟨*Page CM1157* 1593⟩
⟨*Page CM1158* 1594⟩
⟨*Page CM1159* 1595⟩

⟨*Page CM1160* 1596⟩
⟨*Page CM1161* 1597⟩
⟨*Page CM1162* 1598⟩
⟨*Page CM1163* 1599⟩
⟨*Page CM1164* 1600⟩
⟨*Page CM1165* 1601⟩
⟨*Page CM1166* 1602⟩
⟨*Page CM1167* 1603⟩
⟨*Page CM1168* 1604a⟩
⟨*Page CM1169* 1604b⟩
⟨*Page CM1170* 1605⟩
⟨*Page CM1171* 1606⟩
⟨*Page CM1172* 1607⟩
⟨*Page CM1173* 1608⟩
⟨*Page CM1174* 1609⟩
⟨*Page CM1175* 1610⟩
⟨*Page CM1176* 1611⟩
⟨*Page CM1177* 1612⟩
⟨*Page CM1178* 1613⟩
⟨*Page CM1179* 1614⟩
⟨*Page CM1180* 1615⟩
⟨*Page CM1181* 1616⟩
⟨*Page CM1182* 1618⟩
⟨*Page CM1183* 1620⟩
⟨*Page CM1184* 1621⟩
⟨*Page CM1185* 1623⟩
⟨*Page CM1186* 1624⟩
⟨*Page CM1187* 1625⟩
⟨*Page CM1188* 1626⟩
⟨*Page CM1189* 1627⟩
⟨*Page CM1190* 1628⟩
⟨*Page CM1191* 1629⟩
⟨*Page CM1192* 1630⟩
⟨*Page CM1193* 1631⟩
⟨*Page CM1194* 1632⟩
⟨*Page CM1195* 1633⟩
⟨*Page CM1196* 1634⟩
⟨*Page CM1197* 1635⟩
⟨*Page CM1198* 1636⟩
⟨*Page CM1199* 1637a⟩
⟨*Page CM1200* 1638⟩
⟨*Page CM1201* 1640⟩
⟨*Page CM1202* 1642⟩
⟨*Page CM1203* 1643⟩
⟨*Page CM1204* 1644⟩
⟨*Page CM1205* 1645b⟩

⟨*Page CM1206* 1646a⟩
⟨*Page CM1207* 1647⟩
⟨*Page CM1208* 1649⟩
⟨*Page CM1209* 1650⟩
⟨*Page CM1210* 1651⟩
⟨*Page CM1211* 1652⟩
⟨*Page CM1212* 1653⟩
⟨*Page CM1213* 1654⟩
⟨*Page CM1214* 1655⟩
⟨*Page CM1215* 1656⟩
⟨*Page CM1216* 1657⟩
⟨*Page CM1217* 1658⟩
⟨*Page CM1218* 1659⟩
⟨*Page CM1219* 1660⟩
⟨*Page CM1220* 1661⟩
⟨*Page CM1221* 1663⟩
⟨*Page CM1236* 1675⟩
⟨*Page CM1237* 1676⟩
⟨*Page CM1238* 1677⟩
⟨*Page CM1239* 1679⟩
⟨*Page CM1240* 1680⟩
⟨*Page CM1241* 1681⟩
⟨*Page CM1242* 1682⟩
⟨*Page CM1243* 1684⟩
⟨*Page CM1252* 1693⟩
⟨*Page CM1253* 1695⟩
⟨*Page CM1254* 1697⟩
⟨*Page CM1255* 1698⟩
⟨*Page CM1256* 1699⟩
⟨*Page CM1257* 1701⟩
⟨*Page CM1258* 1703⟩
⟨*Page CM1259* 1705⟩
⟨*Page CM1260* 1707⟩
⟨*Page CM1261* 1709⟩
⟨*Page CM1262* 1712⟩
⟨*Page CM1263* 1713⟩
⟨*Page CM1264* 1714⟩
⟨*Page CM1265* 1715⟩
⟨*Page CM1266* 1716⟩
⟨*Page CM1267* 1717⟩
⟨*Page CM1268* 1718⟩
⟨*Page CM1269* 1719⟩
⟨*Page CM1270* 1720⟩
⟨*Page CM1271* 1721⟩
⟨*Page CM1272* 1722⟩
⟨*Page CM1273* 1723⟩

⟨*Page CM1274* 1724⟩
⟨*Page CM1275* 1725⟩
⟨*Page CM1276* 1726⟩
⟨*Page CM1277* 1727⟩
⟨*Page CM1278* 1729⟩
⟨*Page CM1279* 1731⟩
⟨*Page CM1280* 1733⟩
⟨*Page CM1281* 1735⟩
⟨*Page CM1282* 1736⟩
⟨*Page CM1283* 1737⟩
⟨*Page CM1284* 1738⟩
⟨*Page CM1285* 1739⟩
⟨*Page CM1286* 1740⟩
⟨*Page CM1287* 1741⟩
⟨*Page CM1288* 1742⟩
⟨*Page CM1289* 1743⟩
⟨*Page CM1290* 1744⟩
⟨*Page CM1291* 1745⟩
⟨*Page CM1292* 1746⟩
⟨*Page CM1293* 1748⟩
⟨*Page CM1294* 1750⟩
⟨*Page CM1295* 1751⟩
⟨*Page CM1296* 1752⟩
⟨*Page CM1297* 1754⟩
⟨*Page CM1298* 1756⟩
⟨*Page CM1299* 1758⟩
⟨*Page CM1300* 1759⟩
⟨*Page CM1301* 1760⟩
⟨*Page CM1302* 1762⟩
⟨*Page CM1303* 1763⟩
⟨*Page CM1304* 1764⟩
⟨*Page CM1305* 1765⟩
⟨*Page CM1306* 1767⟩
⟨*Page CM1307* 1769⟩
⟨*Page CM1308* 1770⟩
⟨*Page CM1309* 1772⟩
⟨*Page CM1310* 1774⟩
⟨*Page CM1311* 1776⟩
⟨*Page CM1312* 1778⟩
⟨*Page CM1313* 1780⟩
⟨*Page CM1314* 1782⟩
⟨*Page CM1315* 1784⟩
⟨*Page CM1316* 1786⟩
⟨*Page CM1317* 1788⟩
⟨*Page CM1318* 1790⟩
⟨*Page CM1319* 1792⟩

⟨*Page CM1320* 1794⟩
⟨*Page CM1321* 1796⟩
⟨*Page CM1322* 1797⟩
⟨*Page CM1323* 1798⟩
⟨*Page CM1324* 1800⟩
⟨*Page CM1325* 1802⟩
⟨*Page CM1326* 1803⟩
⟨*Page CM1327* 1804⟩
⟨*Page CM1328* 1805⟩
⟨*Page CM1329* 1806⟩
⟨*Page CM1330* 1808⟩
⟨*Page CM1331* 1810⟩
⟨*Page CM1332* 1812⟩
⟨*Page CM1333* 1813a⟩
⟨*Page CM1334* 1814⟩
⟨*Page CM1355* 1835⟩
⟨*Page CM1356* 1836⟩
⟨*Page CM1357* 1837⟩
⟨*Page CM1358* 1838⟩
⟨*Page CM1359* 1839⟩
⟨*Page CM1360* 1840⟩
⟨*Page CM1361* 1841⟩
⟨*Page CM1362* 1842a⟩
⟨*Page CM1363* 1842b⟩
⟨*Page CM1364* 1843a⟩
⟨*Page CM1365* 1844⟩
⟨*Page CM1373* 1852⟩
⟨*Page CM1389* 1868⟩
⟨*Page CM1394* 1872⟩
⟨*Page CM1395* 1874⟩
⟨*Page CM1396* 1876⟩
⟨*Page CM1397* 1878⟩
⟨*Page CM1398* 1880⟩
⟨*Page CM1399* 1882⟩
⟨*Page CM1400* 1884⟩
⟨*Page CM1401* 1886⟩
⟨*Page CM1402* 1888⟩
⟨*Page CM1403* 1889⟩
⟨*Page CM1404* 1891⟩
⟨*Page CM1405* 1892⟩
⟨*Page CM1406* 1893⟩
⟨*Page CM1407* 1894⟩
⟨*Page CM1408* 1895⟩
⟨*Page CM1409* 1896⟩
⟨*Page CM1410* 1898⟩
⟨*Page CM1411* 1900⟩

⟨*Page CM1412* 1902⟩
⟨*Page CM1413* 1903⟩
⟨*Page CM1414* 1905⟩
⟨*Page CM1415* 1907⟩
⟨*Page CM1416* 1909⟩
⟨*Page CM1417* 1911⟩
⟨*Page CM1418* 1913⟩
⟨*Page CM1419* 1915⟩
⟨*Page CM1420* 1917⟩
⟨*Page CM1421* 1918⟩
⟨*Page CM1422* 1919⟩
⟨*Page CM1423* 1920⟩
⟨*Page CM1424* 1921⟩
⟨*Page CM1425* 1922⟩
⟨*Page CM1426* 1923⟩
⟨*Page CM1427* 1924⟩
⟨*Page CM1428* 1925⟩
⟨*Page CM1429* 1926⟩
⟨*Page CM1430* 1927⟩
⟨*Page CM1431* 1928⟩
⟨*Page CM1432* 1929⟩
⟨*Page CM1433* 1930⟩
⟨*Page CM1434* 1931⟩
⟨*Page CM1435* 1932⟩
⟨*Page CM1436* 1933a⟩
⟨*Page CM1437* 1933b⟩
⟨*Page CM1438* 1934⟩
⟨*Page CM1439* 1935⟩
⟨*Page CM1440* 1936⟩
⟨*Page CM1441* 1937⟩
⟨*Page CM1442* 1938⟩
⟨*Page CM1443* 1939⟩
⟨*Page CM1444* 1940a⟩
⟨*Page CM1445* 1940b⟩
⟨*Page CM1446* 1941⟩
⟨*Page CM1447* 1943⟩
⟨*Page CM1448* 1944a⟩
⟨*Page CM1449* 1945⟩
⟨*Page CM1450* 1946⟩
⟨*Page CM1451* 1947⟩
⟨*Page CM1452* 1949⟩
⟨*Page CM1453* 1950⟩
⟨*Page CM1454* 1951⟩
⟨*Page CM1455* 1952⟩
⟨*Page CM1456* 1953⟩
⟨*Page CM1457* 1954⟩

⟨*Page CM1458* 1955⟩
⟨*Page CM1459* 1956⟩
⟨*Page CM1460* 1957⟩
⟨*Page CM1461* 1958⟩
⟨*Page CM1462* 1959⟩
⟨*Page CM1463* 1961⟩
⟨*Page CM1464* 1962⟩
⟨*Page CM1465* 1963⟩
⟨*Page CM1466* 1965⟩
⟨*Page CM1467* 1967⟩
⟨*Page CM1468* 1969⟩
⟨*Page CM1469* 1971⟩
⟨*Page CM1470* 1973⟩
⟨*Page CM1471* 1975⟩
⟨*Page CM1472* 1977⟩
⟨*Page CM1473* 1979⟩
⟨*Page CM1474* 1981⟩
⟨*Page CM1475* 1983⟩
⟨*Page CM1476* 1985⟩
⟨*Page CM1477* 1987⟩
⟨*Page CM1478* 1989⟩
⟨*Page CM1479* 1991⟩
⟨*Page CM1480* 1993⟩
⟨*Page CM1481* 1995⟩
⟨*Page CM1482* 1997⟩
⟨*Page CM1483* 1999⟩
⟨*Page CM1484* 2000a⟩
⟨*Page CM1485* 2001⟩
⟨*Page CM1493* 2007⟩
⟨*Page CM1494* 2009⟩
⟨*Page CM1495* 2011⟩
⟨*Page CM1496* 2013⟩
⟨*Page CM1497* 2015⟩
⟨*Page LM0038* 2043⟩
⟨*Page LM0039* 2044⟩
⟨*Page LM0040* 2045⟩
⟨*Page LM0041* 2046⟩
⟨*Page LM0042* 2047⟩
⟨*Page LM0043* 2048⟩
⟨*Page LM0044* 2049⟩
⟨*Page LM0045* 2050⟩
⟨*Page LM0046* 2051⟩
⟨*Page LM0047* 2052⟩
⟨*Page LM0048* 2053⟩
⟨*Page LM0049* 2054⟩
⟨*Page LM0050* 2055⟩

⟨*Page LM0051* 2056⟩
⟨*Page LM0052* 2057a⟩
⟨*Page LM0053* 2057b⟩
⟨*Page LM0054* 2059⟩
⟨*Page LM0055* 2060⟩
⟨*Page LM0056* 2061⟩
⟨*Page LM0057* 2062⟩
⟨*Page LM0058* 2063⟩
⟨*Page LM0059* 2064a⟩
⟨*Page LM0060* 2064b⟩
⟨*Page LM0061* 2066⟩
⟨*Page LM0062* 2068⟩
⟨*Page LM0063* 2070⟩
⟨*Page LM0064* 2072⟩
⟨*Page LM0065* 2074⟩
⟨*Page LM0066* 2075⟩
⟨*Page LM0067* 2076⟩
⟨*Page LM0068* 2078⟩
⟨*Page LM0069* 2079⟩
⟨*Page LM0070* 2080⟩
⟨*Page LM0071* 2081⟩
⟨*Page LM0072* 2082⟩
⟨*Page LM0073* 2084⟩
⟨*Page LM0074* 2086⟩
⟨*Page LM0075* 2087⟩
⟨*Page LM0076* 2089⟩
⟨*Page LM0077* 2091⟩
⟨*Page LM0078* 2092⟩
⟨*Page LM0079* 2094⟩
⟨*Page LM0080* 2096⟩
⟨*Page LM0081* 2098⟩
⟨*Page LM0082* 2100⟩
⟨*Page LM0083* 2102⟩
⟨*Page LM0084* 2103⟩
⟨*Page LM0085* 2104⟩
⟨*Page LM0086* 2105⟩
⟨*Page LM0087* 2106⟩
⟨*Page LM0088* 2107a⟩
⟨*Page LM0089* 2107b⟩
⟨*Page LM0206* 2112⟩
⟨*Page LM0207* 2114⟩
⟨*Page LM0208* 2116⟩
⟨*Page LM0209* 2118⟩
⟨*Page LM0210* 2119⟩
⟨*Page LM0244* 2121⟩
⟨*Page LM0245* 2122⟩

⟨*Page LM0246* 2123⟩
⟨*Page LM0247* 2124⟩
⟨*Page LM0248* 2125⟩
⟨*Page LM0249* 2126⟩
⟨*Page LM0250* 2128⟩
⟨*Page LM0251* 2129⟩
⟨*Page LM0252* 2130⟩
⟨*Page LM0253* 2132⟩
⟨*Page LM0254* 2134⟩
⟨*Page LM0255* 2136⟩
⟨*Page LM0256* 2137⟩
⟨*Page LM0257* 2138⟩
⟨*Page LM0258* 2139⟩
⟨*Page LM0259* 2140⟩
⟨*Page LM0260* 2141⟩
⟨*Page LM0261* 2142⟩
⟨*Page LM0342* 2152⟩
⟨*Page LM0343* 2154⟩
⟨*Page LM0344* 2156⟩
⟨*Page LM0345* 2158⟩
⟨*Page LM0346* 2160⟩
⟨*Page LM0347* 2162⟩
⟨*Page LM0348* 2164⟩
⟨*Page LM0349* 2165⟩
⟨*Page LM0350* 2166⟩
⟨*Page LM0351* 2167⟩
⟨*Page LM0352* 2169⟩
⟨*Page LM0353* 2171⟩
⟨*Page LM0354* 2173⟩
⟨*Page LM0355* 2174⟩
⟨*Page LM0356* 2175⟩
⟨*Page LM0357* 2177⟩
⟨*Page LM0358* 2179⟩
⟨*Page LM0359* 2181⟩
⟨*Page LM0360* 2183⟩
⟨*Page LM0361* 2185⟩
⟨*Page LM0362* 2187⟩
⟨*Page LM0363* 2188a⟩
⟨*Page LM0373* 2189⟩
⟨*Page LM0374* 2191⟩
⟨*Page LM0375* 2193⟩
⟨*Page LM0376* 2195⟩
⟨*Page LM0377* 2196⟩
⟨*Page LM0378* 2197⟩
⟨*Page LM0379* 2198⟩
⟨*Page LM0380* 2199⟩

⟨*Page LM0381* 2201⟩
⟨*Page LM0382* 2202b⟩
⟨*Page LM0383* 2203⟩
⟨*Page LM0384* 2204⟩
⟨*Page LM0385* 2205⟩
⟨*Page LM0386* 2207⟩
⟨*Page LM0387* 2209⟩
⟨*Page LM0388* 2211⟩
⟨*Page LM0389* 2212⟩
⟨*Page LM0624* 2219⟩
⟨*Page LM0651* 2254⟩
⟨*Page LM0652* 2256⟩
⟨*Page LM0653* 2258⟩
⟨*Page LM0731* 2260⟩
⟨*Page LM0732* 2262⟩
⟨*Page LM0733* 2263⟩
⟨*Page LM0734* 2265⟩
⟨*Page LM0735* 2267⟩
⟨*Page LM0736* 2269⟩
⟨*Page LM0737* 2271⟩
⟨*Page LM0738* 2273⟩
⟨*Page LM0739* 2275⟩
⟨*Page LM0740* 2277⟩
⟨*Page LM0741* 2279⟩
⟨*Page LM0742* 2281⟩
⟨*Page LM0743* 2283⟩
⟨*Page LM0744* 2285⟩
⟨*Page LM0745* 2287⟩
⟨*Page LM0746* 2289⟩
⟨*Page LM0747* 2291⟩
⟨*Page LM0748* 2293⟩
⟨*Page LM0749* 2294⟩
⟨*Page LM0750* 2295⟩
⟨*Page LM0751* 2297⟩
⟨*Page LM0843* 2359⟩
⟨*Page LM0844* 2360⟩
⟨*Page LM0845* 2361⟩
⟨*Page LM0846* 2363⟩
⟨*Page LM0847* 2365⟩
⟨*Page LM0848* 2367⟩
⟨*Page LM0849* 2369⟩
⟨*Page LM0850* 2371⟩
⟨*Page LM0851* 2373⟩
⟨*Page LM0852* 2375⟩
⟨*Page LM0853* 2377⟩
⟨*Page LM0854* 2379⟩

⟨*Page LM0855* 2380⟩
⟨*Page LM0856* 2381⟩
⟨*Page LM0898* 2420⟩
⟨*Page LM0899* 2422⟩
⟨*Page LM0900* 2424⟩
⟨*Page LM0901* 2426⟩
⟨*Page LM0902* 2428⟩
⟨*Page LM0903* 2430⟩
⟨*Page LM0904* 2432⟩
⟨*Page LM0905* 2434⟩
⟨*Page LM0906* 2436⟩
⟨*Page LM0907* 2438⟩
⟨*Page LM0908* 2440⟩
⟨*Page LM0909* 2441⟩
⟨*Page LM0910* 2442⟩
⟨*Page LM0911* 2443⟩
⟨*Page LM0912* 2444⟩
⟨*Page LM0913* 2445⟩
⟨*Page LM0914* 2446⟩
⟨*Page LM0915* 2447⟩
⟨*Page LM0916* 2448⟩
⟨*Page LM0917* 2450⟩
⟨*Page LM0918* 2452⟩
⟨*Page LM0919* 2453⟩
⟨*Page LM0920* 2454⟩
⟨*Page LM0921* 2455⟩
⟨*Page LM0922* 2456⟩
⟨*Page LM0923* 2457⟩
⟨*Page LM0924* 2458⟩
⟨*Page LM0925* 2459⟩
⟨*Page LM0988* 2461⟩
⟨*Page LM0989* 2462⟩
⟨*Page LM0990* 2463⟩
⟨*Page LM0991* 2465⟩
⟨*Page LM0992* 2467⟩
⟨*Page LM0993* 2469⟩
⟨*Page LM0994* 2471⟩
⟨*Page LM0995* 2472⟩
⟨*Page LM0996* 2474⟩
⟨*Page LM0997* 2475a⟩
⟨*Page LM1100* 2476⟩
⟨*Page LM1101* 2477a⟩
⟨*Page LM1284* 2478⟩
⟨*Page LM1285* 2480⟩
⟨*Page LM1286* 2482⟩
⟨*Page LM1287* 2484⟩

⟨*Page LM1288* 2486⟩
⟨*Page LM1289* 2488⟩
⟨*Page LM1290* 2490⟩
⟨*Page LM1291* 2492⟩
⟨*Page LM1292* 2494⟩
⟨*Page LM1293* 2495a⟩
⟨*Page LM1397* 2035⟩
⟨*Page LM1406* 2499b⟩
⟨*Page LM1407* 2500⟩
⟨*Page LM1408* 2502⟩
⟨*Page LM1409* 2503a⟩
⟨*Page LM1410* 2504⟩
⟨*Page LM1411* 2505⟩
⟨*Page LM1412* 2507⟩
⟨*Page LM1413* 2509⟩
⟨*Page LM1414* 2510⟩
⟨*Page LM1415* 2512⟩
⟨*Page LM1416* 2513⟩
⟨*Page LM1417* 2514⟩
⟨*Page LM1418* 2515⟩
⟨*Page LM1419* 2517⟩
⟨*Page LM1420* 2518⟩
⟨*Page LM1470* 2572⟩
⟨*Page LM1471* 2573⟩
⟨*Page LM1485* 2588⟩
⟨*Page LM1486* 2590⟩
⟨*Page LM1487* 2592⟩
⟨*Page LM1488* 2594⟩
⟨*Page LM1489* 2596⟩
⟨*Page LM1490* 2598⟩
⟨*Page LM1491* 2599⟩
⟨*Page LM1492* 2600⟩
⟨*Page LM1493* 2601⟩
⟨*Page LM1494* 2603⟩
⟨*Page LM1495* 2605⟩
⟨*Page LM1496* 2606⟩
⟨*Page LM1497* 2607⟩
⟨*Page LM1498* 2609⟩
⟨*Page LM1499* 2611⟩
⟨*Page LM1500* 2613⟩
⟨*Page LM1501* 2615⟩
⟨*Page LM1502* 2617⟩
⟨*Page LM1503* 2619⟩
⟨*Page LM1504* 2621⟩
⟨*Page LM1505* 2623⟩
⟨*Page LM1506* 2624⟩

⟨*phase table maintenance* 1890⟩
⟨*pinball game buttons and lights* 504⟩
⟨*pinball noun tables* 449⟩
⟨*planetary inertial orientation* 1683⟩
⟨*powered flight subroutines* 1843b⟩
⟨*q-r axis rcs autopilot* 2542⟩
⟨*r30 code* 824⟩
⟨*r31 code* 809⟩
⟨*r60-62 code* 646⟩
⟨*r63 routine* 2148⟩
⟨*radar leadin routines* 2217⟩
⟨*rcs failure monitor* 2108⟩
⟨*rcs-csm dap executive programs* 1450b⟩
⟨*rcs-csm digital autopilot* 1411⟩
⟨*reentry control* 1255b⟩
⟨*restart tables* 361⟩
⟨*restarts routine* 1904⟩
⟨*rt8 op codes* 2027⟩
⟨*rtb op codes* 2034⟩
⟨*s band antenna for lm* 2213⟩
⟨*s-band antenna for cm* 1343⟩
⟨*service routines* 2000b⟩
⟨*servicer routine* 2382⟩
⟨*servicer207 code* 1226⟩
⟨*single precision subroutines* 1646b⟩
⟨*sps back up rcs control* 2625⟩
⟨*src/check.sh* 2833⟩
⟨*src/Comanche055/AGC-BLOCK-TWO-SELF-CHECK.agc* 2636⟩
⟨*src/Comanche055/ALARM-AND-ABORT.agc* 2640⟩
⟨*src/Comanche055/ANGLFIND.agc* 2641⟩
⟨*src/Comanche055/AUTOMATIC-MANEUVERS.agc* 2653⟩
⟨*src/Comanche055/CM-BODY-ATTITUDE.agc* 2657⟩
⟨*src/Comanche055/CM-ENTRY-DIGITAL-AUTOPILOT.agc* 2659⟩
⟨*src/Comanche055/CM0002INFO.agc* 2649⟩
⟨*src/Comanche055/CONIC-SUBROUTINES.agc* 2662⟩
⟨*src/Comanche055/CONTRACT-AND-APPROVALS.agc* 2665⟩
⟨*src/Comanche055/CSM-GEOMETRY.agc* 2668⟩
⟨*src/Comanche055/DISPLAY-INTERFACE-ROUTINES.agc* 2673⟩
⟨*src/Comanche055/DOWN-TELEMETRY-PROGRAM.agc* 2680⟩
⟨*src/Comanche055/DOWNLINK-LISTS.agc* 2676⟩
⟨*src/Comanche055/ENTRY-LEXICON.agc* 2682⟩
⟨*src/Comanche055/ERASABLE-ASSIGNMENTS.agc* 2684⟩
⟨*src/Comanche055/EXECUTIVE.agc* 2690⟩
⟨*src/Comanche055/EXTENDED-VERBS.agc* 2692⟩
⟨*src/Comanche055/FIXED-FIXED-CONSTANT-POOL.agc* 2697⟩
⟨*src/Comanche055/FRESH-START-AND-RESTART.agc* 2700⟩

⟨*src/Comanche055/GIMBAL-LOCK-AVOIDANCE.agc* 2702⟩
⟨*src/Comanche055/GROUND-TRACKING-DETERMINATION-PROGRAM.agc* 2703⟩
⟨*src/Comanche055/IMU-CALIBRATION-AND-ALIGNMENT.agc* 2704⟩
⟨*src/Comanche055/IMU-COMPENSATION-PACKAGE.agc* 2707⟩
⟨*src/Comanche055/IMU-MODE-SWITCHING-ROUTINES.agc* 2709⟩
⟨*src/Comanche055/INFLIGHT-ALIGNMENT-ROUTINES.agc* 2715⟩
⟨*src/Comanche055/INTEGRATION-INITIALIZATION.agc* 2718⟩
⟨*src/Comanche055/INTER-BANK-COMMUNICATION.agc* 2720⟩
⟨*src/Comanche055/INTERPRETER.agc* 2721⟩
⟨*src/Comanche055/INTERPRETIVE-CONSTANTS.agc* 2727⟩
⟨*src/Comanche055/INTERRUPT-LEAD-INS.agc* 2728⟩
⟨*src/Comanche055/JET-SELECTION-LOGIC.agc* 2729⟩
⟨*src/Comanche055/KALCMANU-STEERING.agc* 2731⟩
⟨*src/Comanche055/KEYRUPT-UPRUPT.agc* 2733⟩
⟨*src/Comanche055/LATITUDE-LONGITUDE-SUBROUTINES.agc* 2737⟩
⟨*src/Comanche055/LUNAR-AND-SOLAR-EPHEMERIDES-SUBROUTINES.agc* 2739⟩
⟨*src/Comanche055/LUNAR-LANDMARK-SELECTION-FOR-CM.agc* 2741⟩
⟨*src/Comanche055/MAIN.agc* 2742⟩
⟨*src/Comanche055/MEASUREMENT-INCORPORATION.agc* 2746⟩
⟨*src/Comanche055/MYSUBS.agc* 2747⟩
⟨*src/Comanche055/ORBITAL-INTEGRATION.agc* 2748⟩
⟨*src/Comanche055/P11.agc* 2749⟩
⟨*src/Comanche055/P20-P25.agc* 2752⟩
⟨*src/Comanche055/P30-P37.agc* 2757⟩
⟨*src/Comanche055/P32-P33-P72-P73.agc* 2759⟩
⟨*src/Comanche055/P34-35-P74-75.agc* 2761⟩
⟨*src/Comanche055/P37-P70.agc* 2764⟩
⟨*src/Comanche055/P40-P47.agc* 2765⟩
⟨*src/Comanche055/P51-P53.agc* 2766⟩
⟨*src/Comanche055/P61-P67.agc* 2767⟩
⟨*src/Comanche055/P76.agc* 2769⟩
⟨*src/Comanche055/PHASE-TABLE-MAINTENANCE.agc* 2771⟩
⟨*src/Comanche055/PINBALL-GAME-BUTTONS-AND-LIGHTS.agc* 2773⟩
⟨*src/Comanche055/PINBALL-NOUN-TABLES.agc* 2778⟩
⟨*src/Comanche055/PLANETARY-INERTIAL-ORIENTATION.agc* 2780⟩
⟨*src/Comanche055/POWERED-FLIGHT-SUBROUTINES.agc* 2781⟩
⟨*src/Comanche055/R30.agc* 2783⟩
⟨*src/Comanche055/R31.agc* 2785⟩
⟨*src/Comanche055/R60-62.agc* 2787⟩
⟨*src/Comanche055/RCS-CSM-DAP-EXECUTIVE-PROGRAMS.agc* 2790⟩
⟨*src/Comanche055/RCS-CSM-DIGITAL-AUTOPILOT.agc* 2791⟩
⟨*src/Comanche055/REENTRY-CONTROL.agc* 2793⟩
⟨*src/Comanche055/RESTART-TABLES.agc* 2796⟩
⟨*src/Comanche055/RESTARTS-ROUTINE.agc* 2794⟩
⟨*src/Comanche055/RT8-OP-CODES.agc* 2798⟩
⟨*src/Comanche055/S-BAND-ANTENNA-FOR-CM.agc* 2800⟩

⟨*src/Comanche055/SERVICE-ROUTINES.agc* 2803⟩
⟨*src/Comanche055/SERVICER207.agc* 2802⟩
⟨*src/Comanche055/SINGLE-PRECISION-SUBROUTINES.agc* 2805⟩
⟨*src/Comanche055/STABLE-ORBIT.agc* 2807⟩
⟨*src/Comanche055/STAR-TABLES.agc* 2808⟩
⟨*src/Comanche055/SXTMARK.agc* 2809⟩
⟨*src/Comanche055/SYSTEM-TEST-STANDARD-LEAD-INS.agc* 2811⟩
⟨*src/Comanche055/T4RUPT-PROGRAM.agc* 2812⟩
⟨*src/Comanche055/TAGS-FOR-RELATIVE-SETLOC.agc* 2816⟩
⟨*src/Comanche055/TIME-OF-FREE-FALL.agc* 2820⟩
⟨*src/Comanche055/TPI-SEARCH.agc* 2822⟩
⟨*src/Comanche055/TVCDAPS.agc* 2824⟩
⟨*src/Comanche055/TVCEXECUTIVE.agc* 2825⟩
⟨*src/Comanche055/TVCINITIALIZE.agc* 2826⟩
⟨*src/Comanche055/TVCMASSPROP.agc* 2827⟩
⟨*src/Comanche055/TVCRESTARTS.agc* 2828⟩
⟨*src/Comanche055/TVCROLLDAP.agc* 2829⟩
⟨*src/Comanche055/TVCSTROKETEST.agc* 2830⟩
⟨*src/Comanche055/UPDATE-PROGRAM.agc* 2831⟩
⟨*src/Comanche055/WAITLIST.agc* 2832⟩
⟨*src/export.sh* 2837⟩
⟨*src/Luminary099/AGC-BLOCK-TWO-SELF-CHECK.agc* 2638⟩
⟨*src/Luminary099/AGS-INITIALIZATION.agc* 2639⟩
⟨*src/Luminary099/AOSTASK-AND-AOSJOB.agc* 2643⟩
⟨*src/Luminary099/AOTMARK.agc* 2645⟩
⟨*src/Luminary099/ASCENT-GUIDANCE.agc* 2647⟩
⟨*src/Luminary099/ATTITUDE-MANEUVER-ROUTINE.agc* 2651⟩
⟨*src/Luminary099/BURN-BABY-BURN–MASTER-IGNITION-ROUTINE.agc* 2655⟩
⟨*src/Luminary099/CONTROLLED-CONSTANTS.agc* 2666⟩
⟨*src/Luminary099/DAP-INTERFACE-SUBROUTINES.agc* 2672⟩
⟨*src/Luminary099/DAPIDLER-PROGRAM.agc* 2670⟩
⟨*src/Luminary099/DOWN–TELEMETRY-PROGRAM.agc* 2678⟩
⟨*src/Luminary099/FINDCDUW–GUIDAP-INTERFACE.agc* 2695⟩
⟨*src/Luminary099/FLAGWORD-ASSIGNMENTS.agc* 2698⟩
⟨*src/Luminary099/HeaderTemplate.agc* 2635⟩
⟨*src/Luminary099/IMU-PERFORMANCE-TEST-2.agc* 2711⟩
⟨*src/Luminary099/IMU-PERFORMANCE-TESTS-4.agc* 2713⟩
⟨*src/Luminary099/INPUT-OUTPUT-CHANNEL-BIT-DESCRIPTIONS.agc* 2717⟩
⟨*src/Luminary099/INTERPRETIVE-CONSTANT.agc* 2726⟩
⟨*src/Luminary099/KALMAN-FILTER.agc* 2732⟩
⟨*src/Luminary099/LAMBERT-AIMPOINT-GUIDANCE.agc* 2734⟩
⟨*src/Luminary099/LANDING-ANALOG-DISPLAYS.agc* 2735⟩
⟨*src/Luminary099/LEM-GEOMETRY.agc* 2738⟩
⟨*src/Luminary099/LUNAR-LANDING-GUIDANCE-EQUATIONS.agc* 2740⟩
⟨*src/Luminary099/P-AXIS-RCS-AUTOPILOT.agc* 2770⟩
⟨*src/Luminary099/P12.agc* 2751⟩

⟨*src/Luminary099/P30–P37.agc* 2756⟩
⟨*src/Luminary099/P32-P35-P72-P75.agc* 2760⟩
⟨*src/Luminary099/P70-P71.agc* 2768⟩
⟨*src/Luminary099/Q-R-AXIS-RCS-AUTOPILOT.agc* 2782⟩
⟨*src/Luminary099/R63.agc* 2788⟩
⟨*src/Luminary099/RADAR-LEADIN-ROUTINES.agc* 2789⟩
⟨*src/Luminary099/RCS-FAILURE-MONITOR.agc* 2792⟩
⟨*src/Luminary099/RTB-OP-CODES.agc* 2799⟩
⟨*src/Luminary099/S-BAND-ANTENNA-FOR-LM.agc* 2801⟩
⟨*src/Luminary099/SERVICER.agc* 2804⟩
⟨*src/Luminary099/SPS-BACK-UP-RCS-CONTROL.agc* 2806⟩
⟨*src/Luminary099/T6-RUPT-PROGRAMS.agc* 2815⟩
⟨*src/Luminary099/THE-LUNAR-LANDING.agc* 2818⟩
⟨*src/Luminary099/THROTTLE-CONTROL-ROUTINES.agc* 2819⟩
⟨*src/Luminary099/TJET-LAW.agc* 2821⟩
⟨*src/Luminary099/TRIM-GIMBAL-CNTROL-SYSTEM.agc* 2823⟩
⟨*src/README.md* 2633⟩
⟨*stable orbit* 841⟩
⟨*star tables* 1867⟩
⟨*sxtmark code* 381⟩
⟨*system test standard lead ins* 691b⟩
⟨*t4rupt program* 250⟩
⟨*t6 rupt programs* 2496⟩
⟨*tags for relative setloc* 56b⟩
⟨*the lunar landing* 2299⟩
⟨*throttle control routines* 2306⟩
⟨*time of free fall* 1851⟩
⟨*tjet law* 2561⟩
⟨*tmpline line 66 of AOTMARK.agc* 15⟩
⟨*tpi search* 892⟩
⟨*trim gimbal cntrol system* 2574⟩
⟨*trouble routines* 857a⟩
⟨*tvcdaps code* 1372⟩
⟨*tvcdaps routines* 1346c⟩
⟨*tvcexecutive code* 1355⟩
⟨*tvcinitialize code* 1346d⟩
⟨*tvcmassprop code* 1361⟩
⟨*tvcrestarts code* 1366⟩
⟨*tvcrolldap code* 1395⟩
⟨*tvcstroketest code* 1389⟩
⟨*update program* 2014⟩
⟨*waitlist code* 1662⟩

C.2 Index

+MGA: 40, 234, 357, 472, 754, 761, 779, 794, 795, 842, 850, 852, 919, 1043, 1045, 1048, 1063, 1301, 2219, 2223, 2258
-AYO: 172, 860, 1029, 1675, 1684
-COSB: 186
-DELAIG: 214, 1481, 1489, 1491
-DELAMG: 214, 1481, 1489, 1491
-DELAOG: 214, 1481, 1491
-PHASE1: 152, 315, 321, 343, 378, 380, 1902, 2269, 2343, 2382
-PHASE2: 152, 315, 335, 341, 343, 378, 2271, 2382
-PHASE3: 152, 315, 862, 2271, 2311, 2343, 2382
-PHASE4: 152, 315, 335, 343, 1094, 2269, 2279, 2291, 2343, 2382
-PHASE5: 152, 315, 378, 862, 1227, 2382
-PHASE6: 152, 315, 1094, 2015, 2285, 2343, 2382
-TPER: 38, 179, 456, 827, 831, 833, 837, 840a
-VREL: 226, 1250, 1255a, 1256, 1291
-VT/180: 216, 1504, 1506, 1508, 1510, 1512
-VT/180E: 218, 1508
.05GBIT: 121
.05GSW: 91, 121, 1250, 1256, 1487, 1495
1-CSTH: 188, 1718, 1752, 1754, 1767
1/CONACC: 204, 1347, 1356, 1373, 1396
1/PIPADT: 156, 493, 498, 501, 503, 696, 725, 868, 1147, 1227, 2382
1SECXT: 196, 2203, 2204
1SECXT1: 196, 696, 714, 725
21/22REG: 140, 519, 613, 644
22DSPBIT: 103
22DSPFLG: 89, 103, 981, 991
22SUBSCL: 190, 925, 977, 2752
26P50S: 65, 1147
3/4LOWDP: 71
3AXISBIT: 115, 2074, 2086
3AXISFLG: 89, 115, 347, 425, 438, 649, 658b, 934, 1011, 1013, 1021, 2074, 2086, 2148
504LM: 175, 745, 1684, 1814
60GENRET: 223, 1200, 1256
8KK: 190, 923, 925, 977, 981, 989
8NN: 190, 304, 921, 977, 989, 995
9X9LOC1: 183, 197, 2684
9X9LOC2: 183, 197, 2684
A: 38, 40, 42, 46, 48, 50, 55, 78, 79, 80, 95, 117, 148, 152, 165, 183, 186, 209, 224, 239, 243, 244, 251, 254, 257, 258, 259, 261, 263, 264, 265, 266, 267, 268, 269, 270, 272, 274, 276, 277, 278, 281, 282, 287, 288, 290, 292, 294, 307, 309, 311, 313, 315, 317, 319, 321, 323, 331, 333, 335, 337, 339, 341, 343, 345, 347, 362, 378, 380, 382, 384, 386, 388, 389, 390, 394, 396, 397, 398, 400, 403, 405,

407, 410, 414, 416, 421, 423, 425, 426, 430, 446, 448, 451, 452, 454, 481, 482, 483, 487, 497, 498, 501, 506, 508, 510, 512, 515, 517, 519, 521, 523, 525, 529, 531, 535, 539, 541, 545, 547, 549, 551, 553, 555, 557, 559, 561, 563, 567, 573, 575, 577, 579, 581, 583, 585, 587, 590, 591, 596, 597, 599, 601, 603, 605, 607, 611, 613, 615, 617, 619, 623, 625, 627, 631, 633, 635, 637, 638, 644, 645, 647, 649, 651, 655, 657, 662, 668, 674, 676, 678, 681a, 682, 688, 692, 693, 694, 696, 698, 710, 716, 717, 724, 725, 731, 732a, 741, 747, 752, 753, 760, 765, 784, 794, 797, 802, 804, 806, 808, 814, 820, 829, 833, 835, 842, 850, 858, 870, 874, 876, 882, 888, 893, 899, 921, 925, 927, 936, 941, 963, 967, 969, 997, 1031, 1033, 1035, 1045, 1063, 1094, 1147, 1195, 1200, 1227, 1256, 1291, 1299, 1301, 1347, 1356, 1362, 1367, 1373, 1390, 1396, 1410, 1412, 1434, 1441, 1445, 1447, 1453, 1455, 1456, 1457, 1458, 1460, 1461, 1463, 1465, 1466, 1470b, 1471, 1473, 1474, 1475, 1481, 1483, 1484, 1487, 1489, 1491, 1495, 1497, 1498, 1500, 1502, 1504, 1506, 1508, 1513, 1514, 1516, 1518, 1521, 1522, 1524, 1526, 1528, 1530, 1532, 1534, 1536, 1538, 1539a, 1540, 1541, 1542, 1547, 1548, 1549, 1550, 1552, 1553a, 1553b, 1554, 1556, 1557, 1558, 1560, 1561, 1563, 1565, 1566, 1570, 1572, 1574, 1575, 1576, 1577, 1578a, 1584, 1585, 1588, 1589, 1590, 1592, 1593, 1594, 1595, 1596, 1597, 1600, 1601, 1602, 1603, 1604a, 1604b, 1608, 1609, 1610, 1612, 1613, 1616, 1618, 1620, 1621, 1623, 1625, 1627, 1629, 1632, 1633, 1635, 1636, 1637a, 1647, 1649, 1651, 1652, 1653, 1654, 1655, 1657, 1659, 1660, 1661, 1663, 1679, 1681, 1684, 1693, 1697, 1698, 1712, 1713, 1714, 1715, 1716, 1717, 1719, 1720, 1722, 1723, 1724, 1725, 1772, 1774, 1778, 1788, 1792, 1794, 1796, 1798, 1800, 1802, 1804, 1806, 1810, 1812, 1814, 1838, 1841, 1844, 1852, 1872, 1874, 1878, 1880, 1882, 1886, 1891, 1893, 1894, 1895, 1896, 1898, 1900, 1902, 1903, 1905, 1907, 1909, 1911, 1915, 1918, 1921, 1923, 1925, 1926, 1927, 1928, 1929, 1931, 1932, 1934, 1935, 1936, 1937, 1939, 1941, 1943, 1946, 1947, 1949, 1950, 1951, 1952, 1953, 1955, 1956, 1957, 1958, 1959, 1961, 1962, 1963, 1965, 1967, 1969, 1971, 1973, 1975, 1977, 1983, 1985, 1987, 1989, 1991, 1993, 1995, 1997, 2001, 2007, 2009, 2011, 2015, 2027, 2035, 2043, 2044, 2059, 2061, 2062, 2064a, 2075, 2082, 2098, 2106, 2108, 2112, 2114, 2116, 2118, 2121, 2122, 2128, 2132, 2134, 2136, 2138, 2139, 2140, 2142, 2143, 2152, 2154, 2156, 2158, 2160, 2162, 2164, 2165, 2175, 2181, 2183, 2185, 2189, 2191, 2202b, 2204, 2217, 2219, 2223, 2254, 2260, 2267, 2269, 2277, 2283, 2285, 2287, 2289, 2291, 2293, 2295, 2297, 2299, 2306, 2311, 2343, 2353, 2367, 2369, 2371, 2375, 2377, 2382, 2420, 2422, 2424, 2428, 2430, 2438, 2440, 2441, 2442, 2443, 2445, 2448, 2453, 2454, 2455, 2456, 2457, 2458, 2461, 2463, 2465, 2467, 2469, 2471, 2472, 2474, 2475a, 2478, 2480, 2484, 2486, 2488, 2492, 2496, 2499b, 2500, 2502, 2503a, 2504, 2505, 2510, 2512, 2514, 2517, 2519, 2542, 2561, 2574, 2588, 2590, 2594, 2596, 2600, 2601, 2603, 2606, 2607, 2611, 2613, 2615, 2623, 2625, 2790, 2828

`A0`: 145, 874, 1245, 1256

`A1`: 229, 1147, 1245, 1256, 1506, 1508, 1512, 1522

`ACCWD`: 194, 720, 2207, 2209

`ACORBD`: 211, 1094, 1458, 1471, 1473

`ACTCENT`: 40, 183, 472, 771

`ADB`: 213, 1094, 1439, 1441, 1443, 1445

ADBVEL: 209, 1441, 1445, 1447
ADDRWD: 140, 515, 1546, 1548, 1549, 1550, 1552, 1556, 1558, 1559, 1561, 1562, 1563, 1565, 1566, 1568, 1570, 1571a, 1571b, 1572, 1574, 1575, 1579, 1581, 1582, 1585, 1586, 1587, 1594, 1596, 1597, 1616, 1844, 2455
ADIAX: 169, 495
ADIAY: 169, 495
ADIAZ: 169, 496
ADOT: 209, 223, 297, 1412, 1441
ADOT1: 209, 1412
ADOT2: 209, 1412
ADSRAX: 169, 495
ADSRAY: 169, 495
ADSRAZ: 169, 495, 496
ADVTKBIT: 127
ADVTRK: 89, 127, 1147
AERR: 209, 1441, 1445, 1447
AERRVEL: 209, 1441, 1443, 1445
AHOOKDV: 226, 229, 1245, 1256
AIG: 214, 977, 1293, 1481, 2382
AIG/PIP: 214, 1293
AINLA: 194, 196
AK: 200, 218, 297, 302, 376, 421, 423, 876, 880, 882, 886, 891, 1256, 1356, 1396, 1412, 1436, 1441, 2509, 2510, 2512, 2513, 2514, 2515, 2517
AK1: 200, 218, 297, 302, 876, 882, 891, 1373, 1412, 1436, 1495, 2510, 2514, 2515
AK2: 200, 218, 297, 302, 876, 882, 884, 891, 1373, 1412, 1436, 1495, 1500, 2510, 2514, 2515
ALDK: 194, 718, 720, 2205, 2207
ALFA/180: 214, 302, 1295, 1299, 1486, 1493
ALFA/PIP: 214, 1299
ALFACOM: 216, 1200, 1486, 1495, 1498
ALFAPAD: 198, 1200
ALFDK: 181, 182, 718, 2205
ALK: 194, 196, 718, 720, 729, 2207
ALMCADR: 38, 165, 454, 1876, 2007, 2009, 2011, 2013, 2482
ALP: 229, 1245, 1252, 1256
ALPHAM: 177, 1675, 1676, 1814
ALPHAV: 177, 749, 923, 977, 981, 995, 997, 1029, 1056, 1147, 1200, 1256, 1301, 1675, 1676, 1677, 1679, 1682, 1814, 2299
ALT: 33, 35, 40, 157, 305, 458, 470, 745, 749, 750, 837, 866, 872, 903, 921, 923, 925, 926, 932, 951, 977, 995, 997, 1001, 1015, 1049, 1051, 1052, 1054, 1147, 1200, 1254, 1256, 1675, 1676, 1677, 1679, 2219, 2382, 2420, 2422, 2424, 2453
ALTI: 42, 231, 474, 862, 872, 884
ALTIM: 194, 714, 716, 2204
ALTIMS: 194, 716, 718, 2204, 2205
ALTVAR: 166, 951

ALX1S: 194, 712, 718, 724, 2203, 2205, 2212
AM: 219, 662, 682, 2152, 2154, 2169, 2171
AMG: 214, 977, 1227, 1293, 1481, 1489, 1491, 2382
AMG/PIP: 214, 1227, 1293
AMGB1: 211, 1412, 1436, 1451
AMGB4: 211, 213, 1412, 1436, 1451
AMGB5: 213, 1412, 1436, 1451
AMGB7: 213, 1412, 1436, 1451
AMGB8: 213, 1412, 1436, 1451
AMOONBIT: 97
AMOONFLG: 89, 97, 835, 884, 1804, 1805, 1808, 2718
ANGX: 194, 720, 722, 2209, 2211
ANGY: 194, 722, 2211
ANGZ: 194, 722, 2211
AOG: 214, 229, 357, 364, 370, 372, 374, 376, 870, 977, 1200, 1227, 1256, 1293, 1297, 1299, 1300a, 1481, 1483, 1485, 1487, 1489, 1492, 1498, 1516, 2382, 2430
AOG/PIP: 214, 1227, 1293, 1481
AOPTIME: 181, 1147
APOPERI: 63, 798
APSESBIT: 127, 2066, 2094
APSESW: 89, 127, 1722, 1723, 1760, 1762, 1769, 2066, 2094
ARUPT: 80, 247, 249, 1663, 2496, 2519, 2542
ASKEP: 223, 229, 1245, 1256
ASP1: 223, 229, 1245, 1256
ASP3: 223, 229, 1245, 1256
ASPDWN: 229, 1245, 1256
ASPS: 223, 229, 1256
ASPS(TM): 223, 1256
ASPUP: 223, 229, 1245, 1256
ASTNBIT: 123, 2066, 2091, 2273
ASTNFLAG: 89, 123, 1094, 2066, 2091, 2271, 2273, 2277, 2289
ATIGINC: 175, 762, 852, 2209
ATOPOTH: 71, 823
ATOPTHIS: 71
ATTCADR: 163, 329, 690, 1938
ATTCHBIT: 125
ATTCHFLG: 89, 125
ATTKALMN: 211, 1412, 1453, 1455
ATTPRIO: 163, 690, 1938
ATTSEC: 211, 1412
AVEGBIT: 101, 339
AVEGEXIT: 159, 1094, 1200, 1291, 1487, 2260, 2269, 2279
AVEGFLAG: 89, 101, 827, 1200, 1227, 2066, 2092, 2382
AVEMDBIT: 133, 2066, 2098
AVEMIDSW: 89, 133, 485, 1796, 1805, 2066, 2098, 2143
AVFLAG: 89, 105, 794, 795, 800a, 854, 901, 909, 1053, 1062a, 1094, 2066, 2079,

2223
AVFLBIT: 105, 2066, 2079
AVGEXIT: 159, 858, 868, 1227, 2275, 2277, 2343, 2382
AXISCODE: 234, 236
AXO: 172, 860, 1029, 1675, 1677, 1684
AZIMUTH: 28, 31, 33, 191, 407, 420, 456, 698, 710, 714, 733, 735, 739, 858, 868, 874, 878, 2063, 2124, 2125, 2126, 2189, 2191, 2209
AZO: 172, 860, 1675, 1677, 1684
BANKALRM: 85, 2007
BANKRUPT: 80, 251, 388, 890, 891, 959, 1094, 1347, 1367, 1373, 1396, 1412, 1453, 1477, 1493, 1528, 1663, 1945, 1946, 2134, 2311, 2465, 2496, 2505, 2519
BANKSET: 145, 1542, 1546, 1547, 1556, 1565, 1566, 1567, 1651, 1654, 1656, 1657, 1959, 1999, 2007, 2588
BASEOTP: 177, 814, 816
BASEOTV: 177, 814, 816
BASETHP: 177, 814
BASETHV: 177, 814, 816
BASETIME: 179, 814, 816
BBANK: 80, 145, 247, 249, 617, 625, 692, 953, 1542, 1546, 1547, 1565, 1567, 1649, 1650, 1651, 1654, 1656, 1657, 1661, 1663, 1788, 1876, 1891, 1898, 1900, 1938, 1977, 2001, 2007, 2295, 2311, 2482
BCDU: 214, 219, 653, 660, 681a, 682, 684, 686, 688, 689, 1938, 2167, 2175, 2177, 2188a
BDT: 238, 1094
BESTI: 145, 298, 357, 370, 1015, 1019, 1147
BESTJ: 145, 298, 1147
BETA/180: 214, 302, 1227, 1295, 1299, 1487, 1493, 1495, 1500, 1502
BETA/PIP: 214, 1227, 1299
BETA1: 241, 1301
BETA12: 231, 241, 1301
BETACOM: 216, 1200, 1495, 1498, 1500, 1502
BETADOT: 214, 1493, 1498, 1500, 1502
BETAM: 177, 1814
BETAV: 177, 1814
BIAS: 46, 101, 119, 167, 211, 493, 555, 557, 583, 682, 688, 690, 882, 927, 1094, 1252, 1412, 1436, 1438, 1441, 1457, 1463, 1465, 1497, 1502, 1693, 2046, 2078, 2277, 2441
BIAS1: 211, 688, 690, 1412, 1436, 1438
BIAS2: 211, 688, 690, 1412, 1436, 1438
BIASAK: 221, 882, 884
BIASTEMP: 219, 682, 688
BLANKRET: 140, 2213
BLAST: 200, 1412, 1469, 1471, 1473, 1475, 1476, 1477, 1479
BLAST1: 200, 1412, 1466, 1467, 1470b, 1475, 1476, 1477, 1479
BLAST2: 200, 1412, 1468, 1474, 1475, 1476, 1477, 1479
BMAGX: 80

BMAGY: 80
BMAGZ: 80
BODY1: 221, 862
BODY2: 221, 862
BODY3: 221, 372, 862, 864, 872, 890, 891
BODYATT: 69, 1291
BOOSTEMP: 221, 880, 884, 886
BRATE: 219, 682, 688
BRUPT: 80, 2011, 2343, 2519, 2542
BUF: 142, 493, 495, 497, 498, 499, 501, 503, 515, 547, 551, 625, 627, 1570, 1574, 1585, 1586, 1598, 1599, 1600, 1601, 1603, 1604a, 1604b, 1605, 1606, 1607, 1608, 1612, 1616, 1620, 1623, 1656, 1658, 1659, 1660, 1844, 2027, 2035, 2306, 2311, 2381, 2382
BUF2: 142, 144, 515, 649, 692, 1540, 1541, 1579, 1600, 1607, 1608, 1626, 1627, 1628, 1844, 1928, 1936, 1937, 1938, 2009, 2121, 2122, 2217, 2382, 2590
BUNKER: 206, 1390
BVECTOR: 232, 937, 945, 949, 951, 977, 991, 1009, 1025, 1693, 1695
BZERO: 208, 321, 1347, 1356, 1362, 1373, 1396
C/DO: 229, 1245, 1256
CADDY: 206, 1390
CADRFLSH: 150, 297, 302, 1959, 1981, 1987, 1993, 1995
CADRMARK: 150
CADRSTOR: 154, 329, 508, 519, 537, 593, 613, 623, 629, 637, 638, 1959, 1989, 1991
CALC2BIT: 105, 2066, 2080
CALCDIR: 191
CALCMAN2: 89, 105, 682, 684, 2066, 2080
CALFA: 216, 1493, 1498, 1500, 1506, 1519
CAM: 219, 662, 664, 2169, 2171
CAPSI: 213, 1451
CARD: 78, 206, 1390
CDHTAG: 59, 1063, 2759
CDHTAG1: 65
CDHTAG2: 67, 1063
CDHTAG3: 69, 1063
CDHTAGS: 61, 1063
CDUANG: 194
CDUCHKWD: 165, 400, 402
CDUFLAG: 191
CDUIND: 169, 261, 263, 268, 319, 1918, 1920, 1921, 1922, 1924, 1927, 1932
CDULIMIT: 191
CDUNDX: 194
CDUREADF: 191
CDUREADI: 191
CDUS: 44, 52, 80, 264, 285, 286, 288, 290, 297, 377, 388, 390, 412, 476, 818, 961, 963, 1147, 1227, 1373, 1412, 1918, 2027, 2128, 2132, 2134, 2136, 2382,

2504, 2514, 2519
CDUSCMD: 85
CDUSPOT: 152, 743, 880, 1844, 2128, 2132, 2382
CDUSPOTX: 152, 1094, 2382, 2443
CDUSPOTY: 152, 1094, 2382, 2443
CDUSPOTZ: 152, 1094, 2382, 2443
CDUT: 44, 80, 286, 290, 292, 295, 388, 390, 476, 818, 1147, 1487, 1488
CDUTCMD: 85, 292, 2438
CDUTIMEF: 191
CDUTIMEI: 191
CDUX: 38, 80, 297, 388, 390, 403, 416, 454, 670, 691a, 702, 722, 866, 874, 876, 880, 882, 930, 932, 963, 965, 967, 1094, 1147, 1227, 1293, 1347, 1356, 1373, 1396, 1412, 1436, 1438, 1451, 1481, 1844, 1917, 1919, 1920, 1921, 2134, 2139, 2152, 2177, 2196, 2209, 2382, 2443, 2454, 2502, 2507, 2510, 2513, 2519
CDUXCMD: 80, 272, 888, 890, 1412, 1921, 2514, 2515, 2517
CDUXD: 213, 686, 690, 691a, 963, 965, 971, 1412, 2152, 2169, 2441, 2443, 2446, 2448, 2496, 2499b, 2502, 2519, 2542
CDUY: 80, 297, 388, 390, 691a, 866, 874, 880, 930, 932, 1094, 1147, 1293, 1373, 1412, 1436, 1481, 1844, 1917, 1919, 2128, 2134, 2139, 2382, 2443, 2454, 2502, 2510, 2512, 2513, 2519, 2542
CDUYCMD: 80, 272, 888, 890, 1412, 2514, 2515
CDUYD: 213, 691a, 965, 971, 1412, 2152, 2441, 2443, 2502, 2519, 2542
CDUZ: 80, 267, 295, 307, 388, 390, 416, 670, 691a, 866, 874, 876, 880, 882, 930, 932, 1094, 1147, 1293, 1373, 1412, 1436, 1438, 1451, 1481, 1844, 1917, 1919, 2134, 2139, 2177, 2382, 2443, 2454, 2502, 2507, 2510, 2512, 2519, 2542
CDUZCMD: 85, 272, 888, 890, 1412, 2514, 2515
CDUZD: 213, 691a, 965, 971, 1412, 2152, 2441, 2443, 2448, 2502, 2519, 2542
CFPA: 241, 1301
CGF: 219
CH31TEMP: 211, 1412, 2519, 2542
CHAN: 191, 257, 266, 281, 400, 579, 642, 644, 645, 1933b, 2108
CHAN12: 87, 263, 264, 267, 270, 272, 279, 282, 284, 285, 288, 293a, 311, 313, 386, 421, 642, 884, 890, 1094, 1367, 1412, 1918, 1919, 1920, 1922, 1923, 1924, 1925, 1932, 2060, 2299, 2382, 2424, 2438, 2509, 2515, 2519, 2574, 2598
CHAN13: 87, 311, 325, 640, 642, 644, 955, 957, 1396, 1412, 1453, 1479, 1528, 1532, 1941, 1943, 2061, 2311, 2465, 2467, 2475a, 2496, 2519, 2542
CHAN14: 87, 272, 293a, 311, 1094, 1367, 1373, 1390, 1412, 1922, 1923, 1927, 1929, 1931, 1932, 1933b, 2061, 2279, 2306, 2343, 2420, 2422, 2438, 2515, 2517
CHAN30: 87, 257, 281, 287, 423, 731, 876, 2293, 2311, 2343, 2424, 2443, 2504, 2588
CHAN31: 87, 649, 891, 967, 1094, 1412, 1434, 1453, 2311, 2443, 2504, 2519, 2542
CHAN32: 87, 254, 1434, 2108, 2382
CHAN33: 87, 265, 281, 317, 959, 2064a, 2299, 2382
CHANTEMP: 211, 1412, 1434

CHAR: 140, 142, 514, 517, 519, 521, 523, 531, 533, 535, 537, 565, 597, 599, 601, 603, 609, 1946
CLPASS: 154, 329, 508, 521, 527, 529, 531, 535, 537, 573, 619, 621, 645
CM/DSBIT: 121
CM/DSTBY: 89, 121, 1200, 1227, 1481, 1483, 1487, 1488, 1518
CM/GYMDT: 216, 377, 1227, 1481, 1487
CM/SAVE: 218, 1493, 1521
CMDAPARM: 89, 117, 1486, 1487, 1492
CMDAPMOD: 214, 216, 302, 1200, 1256, 1485, 1495, 1496, 1498, 1500, 1506, 1518, 1519
CMDARMBIT: 119
CMDTMP: 206, 208, 1373
CMOONBIT: 125, 2066, 2094
CMOONFLG: 71, 89, 125, 315, 775, 796, 820, 919, 959, 979, 983, 985, 995, 997, 999, 1024, 1027, 1035, 1063, 1776, 1784, 1804, 1805, 2066, 2094, 2223
CMPX1: 194, 718, 2207
CMTMTIME: 145, 1521
CNTR: 200, 272, 1094, 1347, 1356, 1367, 1373, 2130
CNTRTMP: 206, 1347, 1356
CODE: 30, 33, 35, 52, 55, 56a, 80, 140, 148, 150, 152, 154, 161, 179, 251, 277, 294, 309, 330, 341, 388, 389, 450, 451, 454, 456, 458, 474, 506, 508, 510, 512, 517, 519, 521, 527, 529, 533, 535, 545, 549, 565, 597, 599, 601, 603, 605, 607, 609, 615, 617, 619, 623, 625, 627, 629, 637, 745, 820, 835, 844, 846, 893, 911, 1147, 1502, 1503, 1514, 1516, 1526, 1528, 1530, 1532, 1539a, 1546, 1547, 1549, 1552, 1553b, 1554, 1555b, 1556, 1557, 1558, 1565, 1616, 1634, 1636, 1637a, 1642, 1720, 1723, 1778, 1844, 1939, 1945, 1946, 1947, 1951, 1952, 1979, 2009, 2013, 2027, 2035, 2061, 2062, 2112, 2123, 2382, 2463, 2465, 2467, 2475a, 2519, 2542
COEFFADR: 206, 1347
COF: 219, 651, 653, 655, 657, 662, 664, 666, 667, 674, 676, 678, 682, 2152, 2154, 2164, 2169, 2171, 2173, 2174, 2181, 2183, 2185, 2311
COFSKEW: 218, 219, 662, 666, 667, 2169, 2173, 2174
COGAFBIT: 127, 2066, 2096
COGAFLAG: 89, 127, 1720, 1723, 1743, 1769, 2066, 2094
COLREG: 157, 1814
COMGEOM1: 65, 481
COMGEOM2: 59, 485
COMMAND: 35, 85, 169, 272, 290, 292, 293a, 307, 421, 458, 460, 658b, 691a, 888, 1094, 1200, 1248, 1254, 1256, 1356, 1373, 1412, 1460, 1468, 1504, 1518, 1917, 1920, 1921, 1922, 1927, 1930, 1931, 1932, 1933b, 2060, 2061, 2063, 2064a, 2106, 2281, 2306, 2420, 2440, 2441, 2509, 2515, 2519, 2542, 2590, 2592
COMMANDO: 161, 290, 292, 293a
COMPNUMB: 145, 302, 2015
COMPTBIT: 115
COMPUTER: 71, 89, 115, 254, 259, 412, 418, 485, 506, 615, 794, 795, 965, 1147, 1195, 1245, 1250, 1252, 1449, 1524, 1661, 1872, 1940b, 2015, 2059, 2061,

2062, 2063, 2143, 2461, 2478
CONICS: 61, 159, 181, 188, 240, 241, 1301, 1726, 1743, 1746, 1852
CONICS1: 57, 1742, 1743, 1765, 2050
CONICX1: 241, 1301
COSCDU: 150, 482, 1147, 1844
COSCDUX: 150, 880, 882, 1147, 1373, 2441, 2450
COSCDUY: 150, 1147, 1844
COSCDUZ: 150, 880, 1147, 1373, 1844, 2448, 2450
COSG/2: 229, 1245, 1256
COSM: 216, 1489, 1491
COSO: 216, 1489, 1491
COSOCOSM: 216, 1489
COSTH: 148, 483, 899, 1295, 1676, 1680, 1835, 1836, 1837, 1839, 2143
COUNT: 24, 57, 142, 148, 247, 251, 252, 288, 290, 292, 294, 311, 331, 335, 341, 359, 364, 380, 382, 402, 405, 418, 419, 426, 428, 452, 481, 485, 487, 493, 519, 521, 533, 535, 555, 561, 565, 567, 569, 581, 587, 591, 595, 597, 601, 603, 605, 607, 609, 611, 617, 621, 625, 627, 629, 631, 638, 640, 644, 647, 653, 658b, 660, 670, 674, 684, 692, 694, 708, 712, 718, 724, 727, 733, 735, 739, 741, 743, 747, 756, 762, 786, 795, 798, 804, 810, 820, 827, 839, 844, 862, 878, 880, 890, 893, 907, 909, 915, 919, 927, 930, 934, 937, 941, 951, 965, 967, 977, 1013, 1015, 1039, 1043, 1045, 1049, 1054, 1059, 1063, 1094, 1147, 1195, 1200, 1227, 1256, 1291, 1301, 1344, 1347, 1356, 1362, 1367, 1373, 1390, 1396, 1410, 1412, 1434, 1451, 1453, 1481, 1484, 1485, 1489, 1528, 1530, 1534, 1540, 1546, 1555b, 1556, 1588, 1590, 1591, 1593, 1594, 1595, 1596, 1597, 1598, 1601, 1606, 1610, 1612, 1613, 1621, 1624, 1630, 1638, 1642, 1645b, 1646a, 1647, 1649, 1652, 1661, 1663, 1675, 1684, 1693, 1697, 1699, 1707, 1727, 1742, 1743, 1746, 1765, 1780, 1804, 1812, 1814, 1835, 1844, 1852, 1868, 1874, 1891, 1896, 1900, 1903, 1905, 1907, 1911, 1913, 1917, 1918, 1939, 1941, 1943, 1945, 1963, 2001, 2007, 2009, 2011, 2015, 2027, 2035, 2043, 2044, 2045, 2046, 2047, 2048, 2049, 2050, 2051, 2052, 2056, 2057a, 2108, 2112, 2121, 2126, 2128, 2129, 2142, 2143, 2148, 2167, 2189, 2201, 2203, 2213, 2217, 2219, 2223, 2256, 2260, 2279, 2281, 2283, 2293, 2294, 2295, 2299, 2306, 2311, 2343, 2353, 2359, 2361, 2373, 2375, 2379, 2380, 2382, 2420, 2442, 2465, 2467, 2471, 2476, 2477a, 2480, 2496, 2499b, 2504, 2510, 2519, 2542, 2561, 2572, 2574, 2590, 2607, 2625
COUNTPL: 194
COZY4: 234, 236, 786, 788, 792
CPHI: 157, 425, 647, 658b, 660, 690, 691a, 963, 965, 973, 1200, 1412, 2148, 2152, 2156, 2165, 2167, 2169, 2441, 2446, 2510, 2513
CPHIBIT: 95
CPHIFLAG: 89, 95, 1200, 1840
CPHIX: 28, 38, 44, 45, 95, 163, 405, 416, 454, 478, 973, 975, 1412
CPSI: 157, 647, 653, 691a, 965, 973, 2148, 2152, 2156, 2165, 2167, 2510, 2512
CSI/CDH: 69, 756, 771, 783, 1063, 2223, 2759
CSI/CDH1: 57, 1063, 2223, 2759
CSI/CDH2: 61, 1063
CSI/CDH3: 61, 1063, 2759

CSIALRM: 244, 1063, 2223
CSIPROG: 59, 1063, 2759
CSIPROG2: 61, 1063
CSIPROG3: 63, 1063
CSIPROG4: 65, 1063
CSIPROG5: 61, 1063
CSIPROG6: 59, 1063
CSIPROG7: 65, 1063
CSIPROG8: 59, 1063
CSIPROG9: 67, 1063
CSMMASS: 40, 200, 297, 302, 337, 372, 472, 1094, 1347, 1356, 1362, 2590, 2592, 2603
CSMPOS: 161, 945, 949, 951, 977, 981, 991, 993, 995, 997, 999
CSTEER: 238, 295, 1094
CSTH: 188, 758, 854, 897, 899, 1063, 1301, 1718, 1719, 1724, 1745, 1746, 1750, 1752, 1754, 1758, 1762, 1767, 2223
CSTH-RHO: 188, 1718, 1754, 1767
CTHETA: 157, 647, 658b, 691a, 965, 973, 1412, 2148, 2152, 2156, 2165, 2167, 2510, 2512, 2513
CULTBIT: 107, 2066, 2081
CULTFLAG: 89, 107, 484, 1147, 2066, 2081
CULTRIX: 186, 1147
CXOFF: 190, 925, 977, 981, 995
CYL: 80, 523, 591, 601, 603, 631, 633, 1624, 1884, 1959, 2490
CYR: 80, 345, 603, 631, 1547, 1548, 1549, 1550, 1551, 1552, 1553a, 1553b, 1557, 1560, 1588, 1590, 1591, 1597, 1632, 1633, 1634, 1884, 1909, 2490
CZERO: 208
D: 20, 38, 40, 42, 44, 45, 46, 198, 226, 229, 331, 335, 474, 670, 752, 790, 820, 839, 842, 925, 965, 973, 979, 981, 983, 985, 989, 1054, 1063, 1094, 1200, 1227, 1245, 1247, 1248, 1250, 1252, 1254, 1256, 1362, 1412, 1456, 1457, 1463, 1465, 1491, 1492, 1497, 1502, 1519, 1526, 1536, 1605, 1684, 1780, 1852, 1872, 1894, 2001, 2044, 2057b, 2059, 2164, 2177, 2223, 2311, 2343, 2365, 2367, 2369, 2382, 2463, 2472, 2478, 2514, 2519, 2542, 2561, 2574, 2596, 2603, 2605, 2606, 2633
D0: 229, 1245, 1252, 1256, 2363
D21: 219, 1373, 2365, 2367
D6OR9BIT: 109, 2068, 2081
D6OR9FLG: 89, 109, 955, 979, 989, 1001, 1780, 1782, 1792, 1805, 1814, 2068, 2081
DAP1: 204, 1373
DAP1BIT: 117
DAP2: 204, 1373
DAP2BIT: 117
DAP3: 204, 1373
DAPBIT1: 89, 117, 1094, 1485
DAPBIT2: 89, 117, 1094, 1485

DAPDATR1: 40, 200, 297, 302, 337, 351, 357, 364, 368, 370, 372, 424, 426, 428, 472, 886, 888, 1094, 1347, 1356, 1362, 1373, 1390, 1412, 1453, 1485
DAPDATR2: 40, 200, 297, 302, 426, 472, 1094, 1412
DAPMASS: 59, 1362
DAPROLL: 63, 1356, 1367, 1396
DAPS1: 63, 1485, 2504, 2519, 2572, 2574
DAPS2: 63, 1373, 1390, 2496, 2542, 2561
DAPS3: 63, 1094, 1412, 1434, 2047, 2048, 2499b, 2510, 2590, 2607
DAPS4: 63, 1453, 2574, 2625
DAPS5: 63, 1477
DAPS6: 63, 1094
DAPS7: 63, 1094, 1347
DAPS8: 63, 1451
DAPS9: 57
DATAPL: 194, 700, 702, 704, 705, 2193, 2195, 2198
DATATEST: 232, 249
DCDU: 211, 216, 686, 963, 967, 969, 971, 973, 1844
DECBRNCH: 152, 521, 523, 527, 529, 533, 535, 537, 573, 577, 579, 590, 609, 645
DECOUNT: 140, 541, 551, 553, 559, 565, 573, 575, 577, 579, 585
DECRET: 140, 577, 579, 581
DECTEM: 140, 551
DEL: 232, 651, 653, 655, 674, 676, 678, 682, 684, 773, 1256, 1297, 1396, 1852, 2154, 2162, 2164, 2181, 2183, 2574
DELAYLOC: 157, 327, 329, 2001
DELAYNUM: 73, 2001
DELBRTMP: 206, 1373, 2684, 2824
DELCDUX: 211, 684, 690, 915, 961, 963, 965, 971, 1412, 2441, 2452, 2502, 2519
DELCDUY: 211, 690, 915, 965, 973, 1412, 2502, 2519
DELCDUZ: 211, 690, 915, 965, 973, 1412, 2502, 2519
DELDEP: 188, 1739, 1740, 1769, 1770
DELDV: 244, 1063, 2223
DELEL: 234, 763, 767, 769
DELLT4: 224, 295, 300, 771, 784, 788, 792, 901, 1052, 1053, 1094, 2254, 2256
DELM: 194, 718, 720, 2207
DELOGA: 206, 1396
DELOGART: 206, 1396
DELPBAR: 204, 1094, 1347, 1356, 1373
DELRSPL1: 67, 1054
DELT: 35, 188, 458, 1715, 1731, 1767, 1814, 2452, 2459
DELTACSM: 172, 951, 999, 1035
DELTALEM: 172, 951
DELTAQ: 232, 937, 949, 991, 1027, 1693, 1697, 1698
DELTAR: 40, 183, 295, 300, 472, 842, 848, 2382
DELTAT: 241, 243, 362, 493, 495, 496, 498, 501, 503, 1094, 1663
DELTAX: 161, 947, 993, 1009, 1027, 1693, 1698, 1699, 1705
DELTEEO: 234, 769

DELTEMPX: 209, 1412
DELTEMPY: 209, 1412
DELTEMPZ: 209, 1412
DELTTIME: 183, 842, 848
DELV: 159, 197, 224, 232, 295, 303, 1045, 1049, 1051, 1052, 1227, 1245, 1256, 1484, 2046, 2047, 2219, 2382, 2426, 2444
DELVCSI: 244, 1063, 2223
DELVCTL: 238, 1094
DELVEE: 185, 899, 901, 905
DELVEET1: 197, 295, 1063, 2223
DELVEET2: 244, 295, 1063, 2223
DELVEET3: 236, 300, 754, 759, 761, 772, 773, 777, 786, 792, 793, 850, 901, 1053, 1094, 2258
DELVEO: 185, 901, 905
DELVIMU: 44, 238, 368, 476, 1094
DELVLVC: 44, 224, 476, 754, 761, 772, 773, 777, 794, 795, 852, 1052, 1053, 1063, 1094, 1301, 2223, 2258, 2764
DELVOV: 44, 234, 476, 822
DELVREF: 224, 1094, 1227, 1256, 2382
DELVSAB: 236, 1063, 1094, 2219, 2223
DELVSIN: 236, 777, 779, 850, 1045, 1048, 1049, 1051, 1063, 1094, 1301, 2219, 2223, 2258
DELVSLV: 224, 300, 1049, 1051, 2219
DELVSUM: 208, 1094
DELVSUMP: 208, 1094
DELVTPF: 42, 183, 300, 472, 754, 759, 844, 850
DELVTPI: 40, 183, 472, 754, 759, 844, 850
DELVX: 159, 493, 495, 496, 712, 716, 717, 1227, 2203, 2204, 2205, 2382
DELVY: 159, 495, 716, 1227, 2204, 2382
DELVZ: 159, 495, 496, 716, 1227, 2204, 2382
DELX: 188, 1715, 1731, 1733, 1735, 1767
DELYBAR: 204, 1094, 1347, 1356, 1373
DEPREV: 188, 1739, 1769, 1770
DESOPMOD: 163, 281, 285
DESOPTS: 159, 191, 290, 292, 412, 739, 1147
DESOPTT: 159, 191, 290, 292, 412, 741, 1147
DEX1: 144, 1844
DEX2: 144
DEXDEX: 144, 1844
DEXI: 144, 1844
DFT: 209, 1412, 1466, 1469, 1471, 1473
DFT1: 209, 1412, 1466, 1467
DFT2: 209, 1412, 1468
DHOOK: 226, 1245, 1256
DIFEQCNT: 169, 1784, 1786, 1814, 2748
DIFF: 226, 967, 1147, 1245, 1256, 1396, 1944a, 2574

DIFFALT: 42, 197, 300, 474, 1063, 2223
DIFFOLD: 226, 1245, 1256
DIMOBIT: 109, 2081
DIMOFLAG: 89, 109, 360, 747, 749, 915, 917, 943, 955, 979, 989, 1001, 1023, 1778, 1780, 1782, 1788, 1790, 1792, 1805, 1808, 1814, 2081, 2703
DISPDEX: 165, 779, 780, 2223, 2267, 2269, 2271, 2275, 2277, 2281, 2283, 2285, 2287, 2289, 2291, 2343
DISPLAYS: 59, 113, 161, 253, 329, 438, 451, 506, 519, 551, 559, 567, 599, 601, 603, 607, 612, 613, 647, 711, 753, 760, 860, 874, 927, 936, 1011, 1015, 1045, 1063, 1147, 1200, 1256, 1412, 1616, 1852, 1872, 1874, 1949, 1950, 1951, 1955, 1956, 1957, 1958, 1959, 1961, 1962, 1963, 1979, 1983, 1989, 2009, 2084, 2091, 2094, 2148, 2213, 2223, 2254, 2275, 2281, 2293, 2311, 2371, 2382, 2420, 2422, 2424, 2432, 2478, 2480, 2509, 2542, 2833, 2837
DISTEM: 140, 547
DLAYJOB: 57, 2001
DLEWD: 226, 1245, 1256
DMENFBIT: 115, 2066, 2086
DMENFLG: 115, 947, 981, 989, 991, 1027, 1693, 1695, 1698, 1699, 1701, 1703, 1707, 2066, 2086
DMPNTEMP: 142, 1578a
DNLSTADR: 148, 1524, 1528, 2461, 2465
DNLSTCOD: 148, 311, 341, 864, 1200, 1530, 2015, 2116, 2467
DNQ: 148, 1524, 1534, 2461, 2471
DNRNGERR: 42, 229, 474, 1200, 1254, 1256
DNTM1: 87, 1534, 2471
DNTM2: 87, 1534, 2471
DNTMBUFF: 148, 249, 294, 295, 298, 300, 302, 304, 1524, 1528, 1532, 1534, 1538, 2461, 2465, 2469, 2471, 2474
DNTMGOTO: 148, 325, 436, 1524, 1528, 1536, 1538, 2461, 2465, 2472, 2474, 2475a
DOTINC: 142, 514, 1574, 1578b, 1579
DOTRET: 142, 514, 1574, 1620
DOWNTELM: 59, 294, 1528, 2465
DPIPAY: 194, 717, 718, 727, 2205
DPIPAZ: 194, 717, 2205
DPNDX: 209, 1412, 1441
DRCON: 241, 1301
DRFTBIT: 101, 2066, 2078, 2382
DRHO: 209, 1412
DRHO1: 209, 211, 1412
DRHO2: 211, 1412
DRIFTFLG: 89, 101, 1147, 1227, 2066, 2078, 2382
DRIFTI: 194, 700, 2193
DRIFTO: 194, 703, 2196
DRIFTT: 194, 696, 702, 2195
DSALMOUT: 87, 269, 272, 278, 279, 311, 321, 325, 335, 613, 633, 635, 639a, 640, 642, 644, 969, 1094, 1227, 1347, 1356, 1656, 1661, 1934, 1946, 1989, 2015,

2059, 2273, 2343, 2382
DSEXIT: 140, 603, 605
DSKYBIT: 113
DSKYFLAG: 89, 113, 2066, 2084
DSMAG: 142, 605
DSPCNT: 152, 253, 329
DSPCOUNT: 142, 152, 254, 329, 508, 514, 517, 521, 523, 525, 527, 529, 531, 533, 535, 537, 539, 543, 544, 547, 551, 553, 559, 561, 563, 565, 567, 573, 579, 593, 596, 597, 599, 601, 603, 607, 609, 612, 617, 619, 623, 625, 627, 629, 1945
DSPLIST: 154, 329, 508, 593, 613, 623, 629, 637, 638, 639a, 1959
DSPLOCK: 154, 329, 508, 519, 591, 593, 613, 615, 617, 625, 629, 638, 639a, 640, 644, 1995
DSPMMTEM: 142, 629
DSPTAB: 154, 252, 253, 268, 279, 287, 294, 297, 298, 311, 313, 319, 327, 508, 512, 517, 533, 603, 605, 619, 640, 642, 644, 645, 1918, 1923, 1925, 2001, 2009
DSPTEM1: 38, 40, 45, 154, 398, 400, 418, 454, 456, 470, 478, 596, 611, 733, 739, 743, 747, 750, 844, 846, 977, 1147, 1959, 2189, 2191
DSPTEM2: 38, 45, 154, 418, 454, 478, 700, 702, 703, 708, 2193, 2195, 2196, 2201
DSPTEMX: 38, 154, 454, 804, 808, 2114
DSPWDRET: 142, 597
DSREL: 142, 603, 605
DSRUPTEM: 138, 253
DSRUPTSW: 161, 249, 251, 253, 255, 256, 311, 327
DT/2: 177, 179, 1256, 1798, 1800, 1814
DT21PR: 241, 1301
DTEAROT: 226, 489, 491, 1200, 1250, 1256
DTHETASM: 211, 961, 963, 965, 967, 969, 1844
DUMPCNT: 148, 1536, 1538, 2472, 2474
DUMPLOC: 148, 1536, 1538, 2472, 2474
DV: 52, 103, 241, 961, 969, 981, 1063, 1094, 1227, 1256, 1301, 1396, 1443, 1506, 1512, 1513, 1586, 1603, 1604b, 1623, 2001, 2043, 2044, 2092, 2223, 2281, 2285, 2306, 2311, 2343, 2353, 2382, 2422, 2426, 2428, 2448, 2452, 2455, 2456, 2458, 2519, 2561, 2574, 2594, 2601, 2605, 2609, 2621
DV47TEMP: 238, 1094
DVCNTR: 73, 224, 374, 376, 864, 1200, 1227, 2273, 2275, 2277, 2279, 2281, 2294, 2299, 2311, 2343, 2353, 2359, 2382
DVL: 229, 1245, 1256
DVLOS: 42, 183, 185, 197, 472, 754, 761, 773, 777
DVNORMCT: 142, 1598, 1601, 1606, 1607, 1608
DVPREV: 244, 1063, 2223, 2684
DVSIGN: 142, 1598, 1599, 1604b, 1606, 1608, 1614
DVTHRESH: 166, 1094
DVTOTAL: 40, 44, 224, 470, 476, 1094, 1227, 2263, 2382
E/PROG: 59, 694
E/PROG1: 61, 692
E2: 236, 895, 897, 987, 1200, 1256, 1800, 1882, 2118, 2488

E32C31RM: 174, 1814
E3J22R2M: 174, 2027
EBANK: 73, 80, 167, 169, 175, 183, 188, 190, 191, 197, 198, 221, 224, 226, 229, 232, 234, 239, 241, 244, 249, 254, 261, 263, 264, 268, 285, 294, 311, 317, 319, 321, 325, 329, 337, 345, 347, 349, 351, 355, 357, 359, 364, 366, 368, 370, 372, 374, 376, 377, 382, 384, 390, 392, 394, 396, 397, 400, 402, 405, 412, 419, 420, 421, 423, 424, 425, 426, 430, 432, 433, 434, 436, 437, 438, 442, 444, 446, 448, 487, 491, 493, 497, 508, 537, 541, 553, 571, 577, 579, 593, 595, 617, 625, 627, 631, 640, 642, 647, 653, 658b, 660, 681a, 682, 684, 686, 688, 689, 692, 694, 696, 698, 700, 711, 712, 714, 716, 722, 747, 756, 762, 804, 810, 820, 827, 829, 833, 835, 844, 862, 864, 866, 868, 870, 872, 890, 891, 893, 911, 915, 917, 918, 919, 927, 929, 930, 934, 936, 953, 965, 977, 1013, 1015, 1037, 1039, 1043, 1062a, 1063, 1094, 1147, 1195, 1200, 1227, 1256, 1291, 1297, 1299, 1300a, 1301, 1344, 1347, 1356, 1362, 1367, 1373, 1390, 1396, 1410, 1412, 1434, 1450a, 1451, 1453, 1475, 1481, 1483, 1485, 1487, 1488, 1489, 1492, 1498, 1516, 1521, 1526, 1528, 1532, 1534, 1536, 1538, 1549, 1550, 1557, 1558, 1565, 1566, 1585, 1632, 1655, 1657, 1661, 1663, 1675, 1693, 1727, 1780, 1782, 1788, 1806, 1810, 1835, 1844, 1876, 1878, 1880, 1882, 1889, 1891, 1898, 1900, 1905, 1917, 1918, 1920, 1924, 1927, 1930, 1932, 1938, 1941, 1945, 1959, 1961, 1962, 1967, 1977, 1979, 1983, 1989, 1997, 1999, 2001, 2007, 2015, 2027, 2035, 2108, 2112, 2121, 2132, 2141, 2143, 2148, 2167, 2175, 2177, 2188a, 2189, 2191, 2193, 2202b, 2203, 2204, 2209, 2211, 2213, 2217, 2219, 2223, 2256, 2260, 2262, 2265, 2267, 2271, 2273, 2275, 2277, 2279, 2285, 2289, 2291, 2294, 2295, 2299, 2306, 2311, 2343, 2353, 2359, 2375, 2377, 2382, 2420, 2430, 2442, 2452, 2463, 2465, 2469, 2471, 2472, 2474, 2482, 2484, 2486, 2488, 2495a, 2496, 2499b, 2500, 2502, 2503a, 2504, 2505, 2509, 2510, 2514, 2518, 2519, 2542, 2561, 2572, 2574, 2588, 2590, 2600, 2607, 2625, 2747
EBANKSAV: 156, 1959, 1967, 1979, 1999
EBANKTEM: 156, 313, 341, 1959, 1962, 1973, 1983, 1997, 1999
EBDVCNT: 73, 864
EBDVCNTR: 73
EBMARKDO: 73
EBMRKBUF: 73
EBP4OTMP: 73
EBQPLACE: 73, 864
EBRN1: 73
EBUF2: 148, 692, 693
ECC: 188, 797, 1063, 1726, 1760, 1763, 1769, 1852, 2223
ECSTEER: 224, 300, 1062a, 1094, 1301
EDOP: 80, 595, 619, 1542, 1546, 1547, 1884, 2490
EDOT: 209, 1441, 1445, 1447, 1448, 2542, 2561, 2625
EDOTVEL: 209, 1441, 1443, 1445
EDRIVEX: 200, 221, 1412, 2514, 2515, 2517
EDRIVEY: 200, 221, 1412, 2514, 2515
EDRIVEZ: 202, 221, 1412, 2514, 2515
EGFLGBIT: 119

EGRESS: 179, 927, 929, 937, 938, 939, 955, 1693, 1698, 1699, 1707, 1804, 1805
EGSW: 89, 91, 93, 119, 1250, 1256
EK1VAL: 174, 1094
EK2VAL: 174, 1094
EK3VAL: 174, 1094
EKPRIME: 198, 1347
EKTLX/I: 198, 1347
EMATRIX: 183, 1003, 1005, 1007
EMDOT: 138, 1094, 1301, 1347, 2684
EMSALT: 175, 1200, 1254, 1344
EMSD: 85
END-DELV: 224, 232
END-E3: 174
END-E4: 182
END-E5: 197
END-E6: 223
END-E7: 244, 372, 1195
END-IN/M: 236, 241
END-KALC: 224, 232, 234
END-P30S: 238, 239
END-SVCR: 224, 226
END-UE: 166
END-W: 183, 186, 188, 190
ENDBUF: 145, 226, 229, 1519, 1521
ENDSPBIT: 117
ENG2BIT: 99
ENG2FLAG: 91, 99, 1094
ENGONBIT: 115, 319, 2068, 2086, 2273, 2343, 2447
ENGONFLG: 91, 115, 347, 1094, 2068, 2086, 2273, 2343
ENTRET: 142, 527, 535, 593, 595, 607, 617, 619
ENTRYDSP: 117, 1200, 1250, 1256, 1487
ENTRYVN: 117, 161, 1200, 1256
EPHEM: 65, 175, 1195, 2056
EPSILONT: 165, 1731, 1769, 1770
ERADFBIT: 99, 2068, 2076
ERADFLAG: 91, 99, 749, 862, 866, 919, 923, 981, 995, 1024, 1056, 1147, 1200, 1256, 1301, 1675, 1677, 1682, 2068, 2076
ERADM: 177, 977, 983, 985, 995, 999, 1200, 1676, 1677, 1679, 1682
ERASFILL: 140
ERASID: 73, 1536, 1538, 2472, 2474
ERCNT: 140, 640, 644, 645
ERCOMP: 196, 731, 732a, 866, 2195, 2199
ERCOMP1: 196, 702, 706, 729, 737
ERCOUNT: 165, 311, 1876, 2482
ERECTIM1: 196, 727, 729, 731
ERECTIME: 196, 712

EREPFRAC: 198, 1094, 1347, 1356
ERESTORE: 165, 311, 317, 1876, 1880, 1882, 2482, 2486, 2488
ERRBTMP: 206, 208, 1094, 1347, 1373
ERRORX: 211, 218, 297, 302, 1412, 1436, 1438, 1441
ERRORY: 211, 218, 297, 1094, 1347, 1412, 1436, 1438
ERRORZ: 211, 297, 1347, 1412, 1436, 1438, 1506
ERVECTOR: 191, 702, 706, 2196, 2199
ESCAPE: 142, 1627, 1628, 1629
ESCAPE2: 142, 1627, 1628
ESTROKER: 198, 357, 364, 915, 1390
ETDECAY: 198, 1094
ETPIFLAG: 91, 93, 103, 105, 756, 758, 769, 2068, 2070, 2079
ETRYDAP: 61, 1481, 1484, 1489
EXECTEM1: 138, 1649, 1651, 1652, 1657
EXECTEM2: 138, 1652, 1653, 1657
EXITEM: 140, 575, 577
EXTVBACT: 154, 313, 329, 382, 384, 392, 407, 810, 812, 813, 833, 835, 836, 927, 1200, 1344, 1963, 2001, 2121, 2123, 2213
EXTVBS: 71, 426, 1094
EXTVERBS: 71, 405, 428, 890, 2015
F: 46, 221, 236, 238, 544, 545, 596, 621, 637, 989, 1063, 1094, 1200, 1227, 1248, 1549, 1663, 1684, 1814, 1911, 1913, 2223, 2459, 2519, 2590, 2592, 2600, 2603, 2606
F2RTE: 91, 97, 1301
F2RTEBIT: 97
FACT1: 226, 1247, 1256
FACT2: 226, 1247, 1256
FACTOR: 140, 167, 221, 226, 514, 545, 557, 797, 961, 963, 1245, 1247, 1250, 1252, 1256, 1301, 1362, 1578a, 1713, 1714, 1715, 1716, 1717, 1718, 1719, 1720, 1721, 1722, 1723, 1724, 1725, 1726, 1814, 2027, 2035, 2059, 2118, 2299, 2382, 2420, 2455, 2542, 2574
FAILREG: 38, 150, 297, 302, 311, 454, 645, 1874, 2007, 2009, 2480
FANG: 174, 1094
FBANK: 80, 294, 623, 638, 692, 782, 1540, 1541, 1542, 1546, 1549, 1550, 1553a, 1553b, 1556, 1565, 1566, 1585, 1586, 1642, 1649, 1651, 1663, 1844, 1936, 2001, 2059, 2297, 2600
FCSTART: 67
FFTAG1: 57, 380, 1891, 1892, 1903, 2001
FFTAG10: 57, 331, 335
FFTAG12: 57, 251, 1063
FFTAG13: 57, 2011
FFTAG2: 57, 1039, 1907, 1911
FFTAG3: 57, 1917
FFTAG4: 57, 1963, 2001
FFTAG5: 57, 2045
FFTAG6: 57, 1663, 2001, 2295, 2542

FFTAG7: 57, 2007, 2011
FFTAG8: 57, 595
FFTAG9: 57, 2496
FILDELV: 194
FILDELV1: 196, 727
FINALBIT: 105, 2068, 2079
FINALFLG: 91, 105, 777, 779, 780, 796, 846, 850, 852, 1063, 1301, 2068, 2079, 2223, 2258
FIRSTBIT: 103
FIRSTFLG: 91, 93, 103, 1094
FIXLOC: 140, 444, 818, 886, 963, 971, 973, 1147, 1297, 1549, 1550, 1558, 1565, 1566, 1610, 1612, 1615, 1618, 1630, 1632, 1634, 1649, 1653, 1654, 1740, 1796, 1802, 2027, 2035, 2123, 2124, 2130, 2175, 2311, 2382, 2454, 2455, 2588, 2624
FLAGWRD0: 89, 95, 297, 335, 341, 343, 345, 347, 416, 432, 434, 1227, 1412, 2001, 2068, 2074, 2116, 2343, 2424, 2428, 2438, 2510
FLAGWRD1: 89, 97, 313, 335, 339, 341, 343, 419, 432, 434, 649, 724, 741, 930, 967, 1094, 1227, 1412, 1923, 2068, 2075, 2311, 2424, 2438, 2692
FLAGWRD2: 89, 101, 325, 333, 335, 337, 341, 501, 780, 1094, 1227, 1486, 1663, 1923, 2068, 2078, 2277, 2311, 2382
FLAGWRD3: 89, 105, 313, 315, 698, 1923, 2068, 2080, 2112, 2191, 2382
FLAGWRD4: 89, 109, 329, 407, 649, 650, 1959, 1961, 1963, 1965, 1967, 1969, 1971, 1973, 1975, 1983, 1985, 1989, 1991, 1995, 1997, 2068, 2081
FLAGWRD5: 89, 113, 253, 307, 319, 423, 647, 732a, 1094, 1945, 2015, 2068, 2084, 2217, 2273, 2275, 2343, 2382, 2447, 2542
FLAGWRD6: 89, 117, 319, 321, 335, 424, 426, 437, 876, 890, 1094, 1347, 1356, 1367, 1373, 1451, 2068, 2087, 2311, 2382
FLAGWRD7: 89, 121, 339, 1094, 1227, 1946, 1947, 2011, 2015, 2068, 2091, 2273, 2275, 2277, 2291, 2343, 2382, 2420
FLAGWRD8: 89, 125, 315, 2068, 2092, 2139, 2275, 2311, 2371, 2382
FLGWRD10: 133, 2068, 2070, 2098, 2100, 2269, 2293, 2343, 2382, 2542, 2590
FLGWRD11: 135, 2068, 2102, 2343, 2382
FRANDRES: 59, 311, 2048
FREEFBIT: 97, 2068, 2075
FREEFLAG: 91, 97, 1147, 2068, 2075
FREERET: 142
FV: 177, 1814
FX: 226, 1245, 1247, 1248, 1250, 1256
G21: 219
GAMA: 216, 1296, 1297
GAMDIFSW: 91, 119, 1200, 1297, 1485, 1487
GAMDOT: 119, 216, 1297, 1483, 1491, 1492
GAMMA: 35, 232, 458, 1054, 1063, 1200, 1245, 1252, 1254, 1256, 1675, 1677, 1679, 1681, 1693, 1697, 1699, 1743, 2223
GAMMAEI: 42, 229, 231, 300, 302, 472, 1200, 1254, 1301
GAMMAL: 229, 1245, 1247, 1252, 1256
GAMMAL1: 229, 1247, 1252, 1256

GAMMASB: 40, 179, 472, 1344
GAMPREV: 244, 1063, 2223
GBIASX: 167
GCOMP: 169, 497, 498, 499, 503, 712, 1147, 2203
GCOMPSW: 169, 493, 495, 497, 498, 501, 502, 503, 712, 2203
GDT/2: 159, 1094, 1227, 1245, 2299, 2311, 2382, 2426, 2428
GDT1/2: 159, 1227, 2353, 2361, 2382
GENPL: 191, 194
GENRET: 221, 223, 934, 936
GEOCOMP1: 196, 696, 712, 717, 725
GEOCOMPS: 196, 2204, 2205
GEOMSGN: 188, 790, 1716, 1721, 1724, 1743, 1745, 1754, 1767
GEOSAVE1: 196, 716, 729, 731
GEOSAVED: 194
GLOKFAIL: 91, 105, 698, 1840, 2068, 2080, 2191
GLOKFBIT: 105, 698, 2068, 2080
GMAX: 33, 42, 229, 458, 472, 1200, 1252, 1256
GMDIFBIT: 119
GMODE: 177
GOBL/2: 159, 1094, 1227
GOBL1/2: 159, 161, 1227
GONBYBIT: 123
GONEBIT: 119
GONEBY: 91, 123, 1250, 1256
GONEPAST: 91, 119, 1250, 1256, 1852
GOTOADDR: 226, 1200, 1250, 1256
GRAD: 226, 1250, 1256
GRP2SVQ: 232, 234, 1813a
GRRBKBIT: 115, 423, 732a
GRRBKFLG: 91, 115, 436
GTSOPNDZ: 196
GTSWTLT1: 196, 712, 714, 716
GTSXTLST: 196
GUESSBIT: 101, 2068, 2078
GUESSW: 91, 101, 786, 790, 1094, 1716, 1717, 1754, 1767, 2068, 2078
GYMDIBIT: 121
GYMDIFSW: 91, 121, 1481, 1483, 1487
GYROCMD: 80, 272, 1923, 1932, 1933a, 1933b
GYROCTR: 80
GYTOBETQ: 191
H: 20, 35, 38, 40, 42, 44, 46, 177, 458, 858, 872, 901, 909, 911, 1063, 1094, 1200, 1439, 1443, 1445, 1663, 1814, 1852, 2223, 2306, 2343, 2361, 2371, 2382, 2561, 2633
HAFPA1: 244, 1063, 2223
HALFY: 156
HAPO: 40, 181, 430, 470, 825, 829, 835, 837, 839, 1049, 1051, 1052, 2219, 2256,

2258
HAPOX: 40, 181, 298, 430, 470, 825, 827, 837, 839
HBD11/2: 198
HBD12: 198
HBD21/2: 198
HBD22: 198
HBD31/2: 200
HBD32: 200
HBN10: 198, 1347
HBN11/2: 198
HBN12: 198
HBN20: 198
HBN21/2: 198
HBN22: 198
HBN30: 198
HBN31/2: 198
HBN32: 198
HDISP: 221
HDOT: 35, 42, 231, 458, 474, 858, 862, 872, 884, 1094, 1254, 2382
HDOTDISP: 221, 2311, 2382
HEADSUP: 42, 216, 472, 1200, 1248, 1256, 1485, 1486
HI6ZEROS: 71, 840a, 866, 872, 901, 1001, 1003, 1005, 1007, 1054, 1056, 1094, 1200, 1256, 1344, 1684, 1835, 1852, 2213, 2299, 2353, 2365, 2367, 2369
HIDP1/4: 71, 1200, 1256, 1344, 1852
HIDPHALF: 71, 491, 657, 732a, 921, 983, 997, 1056, 1200, 1256, 1684, 1837, 2213
HIND: 91, 119, 1250, 1256
HINDBIT: 121
HISCALAR: 87, 708, 1568, 2059, 2201
HITEMIN: 140, 142, 514, 587, 589
HITEMOUT: 152, 512, 561, 565, 567
HIUNITX: 71, 482, 657, 1344, 2213
HIUNITY: 71, 482, 1344, 2213
HIUNITZ: 71, 482, 1344, 2213
HOLDFLAG: 163, 295, 298, 300, 302, 304, 662, 684, 688, 915, 918, 963, 965, 973, 1094, 1412, 1434, 1436, 1438, 1441
HOLDW: 190, 1701, 1703
HORIZALT: 166, 1029
HORIZON: 35, 42, 95, 166, 190, 458, 474, 1015, 1017, 1019, 1301, 2311
HP: 185, 850, 899, 901, 903, 905, 907
HPER: 40, 181, 430, 470, 825, 829, 831, 835, 837, 839, 840a, 1049, 1051, 1052, 2219, 2256, 2258
HPERMIN: 179, 827, 829, 831, 835, 837, 839, 840a, 903, 905, 911
HPERX: 40, 181, 430, 470, 472, 825, 837, 840a
HPO: 185, 901, 903, 905
I: 30, 78, 135, 138, 140, 145, 148, 157, 159, 161, 165, 166, 172, 174, 175, 177,

179, 181, 182, 183, 185, 186, 188, 190, 196, 197, 198, 202, 204, 206, 208, 219, 221, 223, 224, 229, 232, 234, 236, 238, 239, 240, 241, 243, 244, 276, 339, 357, 405, 419, 428, 482, 583, 647, 653, 655, 657, 893, 897, 961, 967, 977, 981, 983, 989, 993, 1001, 1003, 1005, 1007, 1009, 1045, 1147, 1200, 1347, 1396, 1412, 1436, 1449, 1524, 1526, 1536, 1543, 1616, 1625, 1628, 1651, 1684, 1774, 1935, 1936, 1946, 1947, 2001, 2087, 2104, 2116, 2152, 2156, 2158, 2162, 2311, 2424, 2461, 2463, 2472, 2496, 2515, 2519, 2561, 2596, 2609, 2742
IAVG: 200, 428, 1094, 1347, 1356, 1362, 1412
IAVG/TLX: 200, 428, 1347, 1356, 1362
IDAD1TEM: 144, 452, 515, 541, 559, 577
IDAD2TEM: 144, 452, 515
IDAD3TEM: 144, 452, 515
IDADDTEM: 142
IDLEBIT: 101
IDLEFAIL: 91, 101, 347, 1094
IDOFLMK: 190
IGC: 186, 298, 866, 874, 880, 1147, 1835, 1840
IGNFLAG: 91, 123, 1094, 2068, 2091, 2271, 2273, 2277
IGNFLBIT: 123, 2068, 2091, 2273, 2291
IMODES30: 163, 257, 258, 259, 261, 263, 267, 268, 269, 270, 271, 272, 274, 276, 278, 279, 297, 302, 313, 319, 335, 642, 644, 1147, 1918, 1919, 1923, 1925, 1926, 1934, 1939
IMODES33: 163, 254, 263, 265, 266, 267, 274, 277, 278, 279, 280, 287, 297, 302, 313, 319, 640, 642, 644, 1412, 1481, 1918, 1919, 1923, 1924, 1925, 2343, 2420, 2422, 2424, 2426, 2438, 2504
IMPULBIT: 103, 2068, 2079, 2277
IMPULSW: 91, 103, 347, 1094, 2068, 2079
IMU/OPT: 191
IMUCADR: 163, 329, 1663, 1934, 2116
IMUCAL: 69, 696, 706, 712, 735, 739, 741
IMUCAL1: 57, 737
IMUCAL2: 59
IMUCAL3: 67, 706
IMUCOMP: 59, 493
IMUSE: 91, 95, 341, 345, 434, 703, 1940a, 1941, 2068, 2075, 2116, 2196, 2211
IMUSEBIT: 97, 2068, 2075, 2116
IMUSUPER: 67, 419
INCORBIT: 115
INCORFLG: 91, 115, 943, 945, 947, 949, 991, 993
INCORPEX: 177, 872, 1675, 1676, 1677, 1679
INDEXLOC: 142, 1550, 1630, 1631, 1632
INFINBIT: 127, 2068, 2094
INFINFLG: 91, 127, 1718, 1720, 1723, 1743, 1748, 1751, 1756, 1769, 2068, 2094
INFLIGHT: 24, 65, 710, 1835, 2138, 2139, 2141, 2143, 2833, 2837
INLINK: 80, 329, 1946, 1947
INREL: 142, 523, 525, 527, 529, 531, 533

INRLBIT: 121
INRLSW: 91, 121, 1250, 1256
INTB15+: 140, 514, 2624
INTBIT15: 140, 514, 1546, 1549, 1550
INTFLAG: 91, 133, 2068, 2100
INTFLBIT: 133, 319, 1802, 2068, 2100
INTIME: 236, 759, 762, 771, 784, 792, 848, 901
INTINIT: 61, 359, 1780, 1794, 1806, 2051
INTINIT1: 61, 1794
INTINIT2: 69, 1804
INTPRET1: 65, 1645b, 2476
INTPRET2: 57, 1646a, 2477a
INTTEMP: 202, 209
INTVAR: 182, 947
INTVEC: 194
INTVEC1: 196, 727
INTVEL: 61, 786
INTWAK1Q: 145, 1812
INTY: 194, 718, 720, 2205, 2207
INTYBIT: 109
INTYPFLG: 91, 107, 747, 775, 792, 816, 818, 820, 822, 955, 1001, 1301, 1772, 1780, 1782, 1788, 1790, 1792, 1794, 1808, 2068, 2081, 2299
INTZ: 194
IOGARATE: 206, 1396
IRETURN: 177, 1790, 1792, 1794, 1796
IRETURN1: 157, 1806, 1808, 1810
IT: 73, 78, 79, 185, 221, 257, 259, 261, 263, 265, 267, 270, 274, 276, 278, 288, 313, 317, 329, 333, 341, 353, 362, 378, 384, 386, 400, 402, 419, 420, 421, 423, 430, 434, 446, 451, 482, 487, 508, 510, 521, 527, 531, 541, 549, 551, 553, 559, 567, 569, 575, 591, 595, 596, 597, 599, 601, 607, 609, 611, 612, 613, 615, 617, 621, 623, 625, 627, 629, 631, 635, 637, 638, 640, 644, 655, 693, 710, 729, 825, 831, 837, 870, 872, 876, 884, 886, 893, 895, 897, 899, 927, 932, 947, 995, 1063, 1094, 1147, 1195, 1200, 1227, 1256, 1347, 1367, 1390, 1396, 1412, 1436, 1470b, 1524, 1526, 1530, 1532, 1534, 1536, 1538, 1541, 1543, 1547, 1548, 1556, 1563, 1565, 1577, 1580, 1584, 1586, 1598, 1602, 1603, 1618, 1625, 1635, 1638, 1644, 1652, 1663, 1693, 1712, 1714, 1739, 1772, 1774, 1780, 1804, 1814, 1844, 1852, 1876, 1893, 1894, 1896, 1898, 1902, 1903, 1905, 1907, 1911, 1913, 1915, 1924, 1925, 1934, 1935, 1939, 1943, 1947, 1949, 1957, 1961, 1973, 1975, 1987, 1989, 1995, 1997, 2001, 2007, 2015, 2027, 2035, 2089, 2103, 2108, 2132, 2134, 2137, 2139, 2142, 2143, 2152, 2154, 2156, 2202b, 2223, 2260, 2265, 2269, 2271, 2281, 2283, 2287, 2289, 2297, 2299, 2306, 2311, 2353, 2382, 2448, 2455, 2457, 2461, 2463, 2465, 2467, 2469, 2471, 2472, 2474, 2482, 2496, 2500, 2510, 2519, 2542, 2561, 2574, 2590, 2611, 2617, 2621
ITCTR: 236, 786, 788, 792
ITEMP1: 138, 290, 292, 349, 351, 390, 394, 396, 397, 965, 1227, 1844, 1900, 1920, 1921, 1922, 1927, 1930, 1931, 1932, 1933a, 2001, 2007, 2009, 2134,

2139, 2295, 2297, 2382, 2428, 2430, 2509, 2512, 2513, 2519
ITEMP2: 138, 349, 351, 394, 1227, 1844, 1900, 1931, 1932, 2001, 2295, 2297, 2428, 2430, 2574
ITEMP3: 138, 1900, 2001, 2134, 2139, 2297, 2428, 2430, 2574
ITEMP4: 138, 1900, 1930, 1931, 1933b, 2134, 2139, 2295, 2297, 2430
ITEMP5: 138, 1900, 2134, 2139, 2426, 2428, 2432, 2434, 2436, 2438
ITEMP6: 138, 279, 1900, 2432, 2434, 2574
ITSWBIT: 123, 2068, 2091
ITSWICH: 91, 121, 756, 758, 763, 899, 903, 1063, 2068, 2091, 2223
IXX: 200, 428, 1094, 1347, 1356, 1362, 1412, 2596
J/M: 211, 1094, 1449
J/M1: 211, 1094, 1449
J/M2: 211, 1094, 1449
JETAG: 214, 1483, 1485, 1496, 1500, 1504, 1506, 1510, 1513, 1518
JETEM: 216, 1483, 1484, 1487, 1489, 1491, 1492, 1495, 1497, 1500
JETEM2: 218, 1497
JJ: 40, 44, 50, 229, 1250, 1256
JNDX: 216, 1504, 1508, 1510, 1512, 1514
JNDX1: 216, 218, 1508, 1510, 1512, 1514, 1516
JSWCHBIT: 95, 2068, 2074
JSWITCH: 95, 1814, 2068, 2074
JZERO: 208
K2ROLL: 226, 1248, 1256
KALCMON1: 63, 660, 674, 682, 684, 691a, 2167, 2177
KALCMON2: 63, 670, 2175
KALCMON3: 63, 690
KAT: 229, 1248, 1256
KBIT: 97
KDPNDX: 219, 684, 686
KEPRTN: 177, 1714, 1735, 1736, 1814
KEYRUPT: 24, 59, 515, 1945, 2833, 2837
KEYTEMP1: 138, 249, 1945, 1946
KEYTEMP2: 150, 1946
KFLAG: 91, 97, 895, 897, 899, 903, 907, 909, 911
KLAT: 226, 1248, 1252, 1256
KMJ: 211, 1094, 1412
KMJ1: 211, 1094
KMJ2: 211, 1094
KMPAC: 209, 357, 1410, 1412, 1434, 1445, 1447, 1448, 1449, 1450a, 1451, 1453, 1475, 2747
KMPTEMP: 209, 1410
KNOWNBIT: 119
KNOWNFLG: 91, 93, 119, 921, 925, 981
KPRIMEDT: 204, 1094, 1347
KSPNDX: 219, 684, 686
KT: 181, 357, 762, 852, 1256, 1522, 2363

KTLX/I: 204, 1347
KV1: 219
KV2: 219
KV3: 219
L: 30, 40, 42, 44, 48, 80, 87, 198, 226, 229, 265, 282, 287, 288, 290, 292, 302, 321, 329, 331, 341, 345, 378, 380, 382, 384, 410, 418, 452, 493, 497, 498, 503, 529, 533, 535, 537, 539, 541, 543, 545, 549, 551, 555, 563, 575, 587, 590, 596, 601, 603, 612, 617, 621, 623, 627, 629, 637, 638, 688, 692, 693, 705, 708, 733, 747, 784, 794, 797, 802, 804, 808, 831, 833, 840a, 858, 872, 874, 876, 882, 929, 936, 937, 939, 957, 963, 977, 1025, 1049, 1052, 1054, 1094, 1147, 1200, 1227, 1247, 1248, 1250, 1252, 1256, 1297, 1299, 1300a, 1301, 1347, 1356, 1362, 1373, 1396, 1410, 1412, 1434, 1471, 1473, 1484, 1487, 1491, 1492, 1497, 1498, 1500, 1502, 1504, 1506, 1508, 1512, 1513, 1516, 1518, 1530, 1534, 1538, 1539a, 1540, 1541, 1542, 1567, 1570, 1573, 1575, 1577, 1578a, 1584, 1589, 1595, 1602, 1603, 1610, 1612, 1615, 1623, 1625, 1635, 1649, 1650, 1654, 1659, 1661, 1663, 1675, 1677, 1679, 1681, 1682, 1684, 1693, 1699, 1717, 1720, 1723, 1726, 1776, 1778, 1780, 1782, 1784, 1790, 1792, 1800, 1802, 1842a, 1844, 1880, 1884, 1886, 1889, 1891, 1893, 1894, 1907, 1909, 1913, 1920, 1931, 1936, 1939, 1943, 1959, 1977, 1979, 1985, 1989, 2001, 2007, 2009, 2013, 2015, 2027, 2035, 2059, 2074, 2075, 2076, 2079, 2080, 2081, 2086, 2089, 2091, 2092, 2094, 2096, 2098, 2100, 2102, 2103, 2108, 2130, 2139, 2156, 2198, 2201, 2219, 2269, 2285, 2291, 2295, 2297, 2306, 2311, 2343, 2361, 2363, 2365, 2367, 2382, 2438, 2446, 2448, 2452, 2453, 2455, 2456, 2458, 2467, 2471, 2474, 2475a, 2486, 2490, 2492, 2494, 2495a, 2496, 2499b, 2500, 2502, 2503a, 2510, 2514, 2517, 2519, 2542, 2561, 2572, 2573, 2574, 2588, 2594, 2596, 2600, 2601, 2607, 2613, 2615, 2621, 2623, 2625
L/D: 198, 226, 229, 1054, 1200, 1247, 1248, 1250, 1252, 1256, 1491, 1492, 1502
L/D1: 226, 302, 1248, 1256
L/DCALC: 229, 1256
L/DCMINR: 226, 1248, 1256
LAD: 226, 1248, 1256
LADPAD: 198, 1200, 1248, 1256
LANDALT: 44, 181, 476, 1001
LANDLAT: 44, 157, 476, 923, 1001
LANDLONG: 44, 181, 476, 923, 1001
LANDMARK: 28, 35, 37, 42, 99, 119, 190, 304, 357, 366, 382, 446, 448, 458, 460, 474, 919, 921, 925, 927, 977, 1015, 1017, 1024, 1147, 1693, 2833, 2837
LASTMASP: 202
LASTXCMD: 163
LASTYCMD: 163
LAT: 40, 42, 107, 157, 175, 224, 300, 302, 305, 470, 472, 474, 722, 745, 747, 749, 750, 866, 921, 923, 925, 926, 977, 995, 997, 1001, 1015, 1054, 1147, 1200, 1254, 1256, 1301, 1675, 1676, 1677, 1679, 1681, 2080, 2299
LAT(SPL): 42, 224, 300, 302, 472, 722, 1054, 1200, 1256, 1301
LATANG: 229, 302, 1248, 1254, 1256
LATITUDE: 24, 33, 35, 37, 191, 456, 458, 460, 696, 706, 710, 739, 860, 866,

1147, 1248, 1254, 1256, 1301, 1675, 1677, 2189, 2191, 2199, 2833, 2837
LATLONG: 61, 1675
LATSW: 91, 121, 1250, 1256, 1487, 1488, 1504
LATSWBIT: 121
LAUNCHAZ: 194, 298, 710, 729, 731, 743, 868, 874, 878
LCHAN: 87, 254, 257, 265, 278, 281, 287, 290, 321, 1412, 1500, 1502, 1568, 2001, 2015, 2130, 2140, 2283, 2510, 2519
LCX/360: 216, 1504, 1506, 1508, 1510, 1512
LDATALST: 148, 1524, 1534, 2461, 2471
LEMMASS: 40, 200, 297, 302, 472, 1347, 1362, 2590, 2592, 2603, 2605
LEMONM: 85
LEMPOS: 161, 945, 949, 951, 1009
LENGTHOT: 191, 696, 700, 702, 710, 712, 714, 722, 725, 729, 731, 2193, 2195, 2202b, 2204, 2209, 2211
LEQ: 226, 1200, 1248, 1256, 1297, 1852
LEWD: 226, 1245, 1248, 1252, 1256
LGYRO: 161, 329, 729, 1927, 1928, 1929, 1930, 1932
LIFTTEMP: 161, 862, 870
LMOONBIT: 125, 2068, 2094
LMOONFLG: 73, 91, 125, 315, 959, 1776, 1786, 2068, 2094
LNG(SPL): 42, 224, 300, 302, 472, 1200, 1301
LO6ZEROS: 71, 1094, 1742, 2125, 2126, 2143
LOADDAP: 65
LOADSTAT: 154, 573, 611, 612, 621, 629
LOC: 138, 145, 183, 190, 191, 224, 232, 236, 238, 349, 364, 380, 597, 599, 603, 609, 615, 617, 625, 629, 638, 693, 694, 891, 989, 1063, 1094, 1367, 1504, 1540, 1542, 1546, 1547, 1548, 1550, 1553a, 1556, 1563, 1565, 1566, 1567, 1575, 1637a, 1649, 1651, 1653, 1654, 1655, 1656, 1657, 1658, 1661, 1684, 1852, 1935, 1950, 1957, 1959, 1963, 1989, 1995, 1999, 2007, 2009, 2139, 2223, 2311, 2382, 2574
LOCALARM: 85, 2007
LOCCTR: 138, 629, 694, 1652, 1653, 1657, 1802, 1935, 1945, 1961, 1977, 1981, 1989
LOD: 198, 226, 1248, 1256
LODP1/4: 71, 1680
LODPAD: 198, 1200, 1248, 1256
LODPHALF: 71, 1094, 1762, 2143
LONG: 40, 42, 107, 157, 175, 305, 370, 470, 474, 745, 747, 749, 750, 866, 921, 923, 925, 926, 977, 995, 997, 1001, 1015, 1147, 1200, 1227, 1254, 1256, 1301, 1460, 1616, 1675, 1676, 1677, 1681, 1931, 1961, 2080, 2299, 2542, 2561
LONGBASE: 157, 1893, 1894, 1896, 1902, 1913
LONGCADR: 157, 1663
LONGEXIT: 167, 1663
LONGTIME: 157, 1663, 1913
LOOPCT: 244, 1063, 2223
LOPC: 67

LOS1: 191
LOS2: 191
LOSCALAR: 87, 708, 2059, 2201, 2542
LOSVEC: 191, 702, 722, 735, 737, 2196, 2209, 2375
LOTEMIN: 140, 514
LOTEMOUT: 152, 512, 561, 563, 565, 567
LOUNITX: 71
LOUNITY: 71
LOUNITZ: 71
LOWSUPER: 67, 71, 430, 438, 479, 630, 645, 698, 747, 808, 890, 1042a, 1094, 1147, 1344, 1889, 2015, 2119, 2143, 2213
LRUPT: 80
LST1: 167, 249, 311, 325, 330, 1663, 1876, 1898, 1905, 2482
LST2: 167, 325, 327, 1663, 2295, 2297
LSTPTR: 142
LUNABIT: 107, 2070, 2080
LUNAFLAG: 91, 107, 749, 919, 921, 923, 983, 995, 997, 1017, 1029, 1035, 1147, 1200, 1256, 1301, 1675, 1677, 1681, 1682, 2070, 2080, 2299
LUNCHAZ1: 196, 725
LV: 37, 85, 121, 460, 753, 762, 794, 795, 820, 850, 854, 1045, 1049, 1052, 1063, 1094, 1301, 1610, 1612, 2219, 2223
LVSQUARE: 85, 1610, 1615
MAGVEC2: 188, 1721, 1724, 1726, 1744, 1745, 1752, 1759, 1767, 1769
MAGVTPI: 185, 901
MAMAX1: 241, 1301
MAMAX2: 241, 1301
MANUSTUF: 63, 686, 690
MANUVER: 65, 647, 658a
MANUVER1: 65, 657
MARK2DWN: 224, 298, 1147
MARK2PAC: 156, 1961, 1983, 1985
MARKCTR: 157, 820, 823
MARKDATA: 161, 224, 939, 941, 981, 1021, 1023
MARKDOWN: 73, 239, 298, 300, 392, 939, 1023, 1147
MARKEBAN: 156, 1959, 1999
MARKINDX: 145, 357, 921, 926, 1015, 1147
MARKNV: 150, 1959, 1967, 1969, 1985
MARKSTAT: 15, 163, 329, 382, 384, 386, 390, 392, 394, 396, 397, 398, 400, 448, 741, 743, 921, 929, 977, 979, 1021, 1147, 2121, 2122, 2123, 2130, 2134, 2136, 2138, 2139, 2140, 2141, 2142
MARKTIME: 161, 300, 917, 941, 943, 955, 957, 1021, 1023, 1024, 2139
MASKREG: 194
MASS: 20, 200, 428, 1094, 1227, 1347, 1356, 1362, 1712, 1716, 2044, 2048, 2306, 2311, 2343, 2382, 2588, 2590, 2592, 2594, 2596, 2601, 2605, 2633
MASSTMP: 206, 337, 1094, 1347, 1356
MATINC: 142, 514, 1578b, 1579

MAXDVSW: 142, 1598, 1600, 1602, 1608, 1612
MCDUYDOT: 204, 1373
MCDUZDOT: 204, 206, 1373
MDT: 204
MEASINC: 69, 1693
MEASINC1: 69, 1699
MEASINC2: 61, 1707
MEASINC3: 69, 1707
MERRORX: 209, 1412
MERRORY: 209, 1412
MERRORZ: 209, 1412
MFI: 232, 653, 660, 662, 664, 2154, 2167, 2169, 2171
MFISYM: 219, 662, 664, 666, 667, 2154, 2169, 2171, 2173, 2174
MFS: 232, 653, 655, 660, 2154, 2167
MGC: 186, 298, 866, 874, 880, 1147, 1835, 1836, 1839
MGLVFBIT: 117, 2070, 2087
MGLVFLAG: 91, 117, 794, 795, 2070, 2087
MID1FBIT: 131, 2098
MID1FLAG: 91, 131, 1806, 1808, 1810, 2070, 2098
MIDAVBIT: 133, 2070, 2098
MIDAVFLG: 91, 131, 1796, 1808, 1814, 2070, 2098
MIDDGIM: 59, 795
MIDFLAG: 91, 95, 359, 1772, 1774, 1776, 1778, 1780, 1794, 1798, 1814, 2070, 2074
MIDFLBIT: 95, 2070, 2074
MINDEX: 152, 335, 339, 345
MIS: 219, 651, 653, 655, 657, 660, 684, 2154, 2167
MIXBR: 142, 452, 537, 549, 551, 553, 559, 567, 575, 577, 579, 585
MIXTEMP: 142, 514, 531, 541
MKCDUS: 148, 388, 394, 400
MKCDUT: 148, 388, 394, 400
MKCDUX: 148, 388, 394, 400, 402
MKCDUY: 148, 388, 394, 400, 402
MKCDUZ: 148, 388, 394, 400, 402
MKNDX: 148, 402
MKOVBIT: 113, 2070, 2084
MKOVFLAG: 91, 113, 2070, 2084
MKT2T1: 148, 388, 392, 394, 400
MM: 42, 50, 226, 335, 337, 339, 345, 355, 357, 384, 398, 407, 419, 420, 446, 535, 607, 609, 629, 694, 698, 712, 731, 733, 737, 864, 1147, 1200, 1227, 1250, 1256, 1844, 1949, 1993, 1997, 2189
MMNUMBER: 152, 335, 337, 341, 343, 2343
MNKEYIN: 87, 325, 1945, 2062
MODCHG2: 61, 2027
MODCHG3: 61, 2027
MODE: 24, 26, 52, 54, 56a, 85, 97, 127, 145, 152, 154, 163, 181, 267, 281, 284,

307, 321, 323, 331, 333, 335, 351, 353, 355, 378, 382, 386, 388, 390, 396, 405, 411, 414, 430, 493, 497, 508, 510, 512, 517, 540, 607, 615, 619, 627, 629, 647, 711, 794, 825, 836, 837, 858, 860, 876, 888, 934, 963, 967, 991, 1049, 1052, 1094, 1147, 1200, 1256, 1301, 1347, 1356, 1373, 1390, 1412, 1481, 1486, 1495, 1500, 1502, 1524, 1536, 1547, 1552, 1553b, 1559, 1561, 1562, 1563, 1567, 1573, 1578b, 1580, 1581, 1586, 1587, 1588, 1595, 1597, 1615, 1616, 1618, 1663, 1684, 1714, 1717, 1720, 1723, 1726, 1852, 1891, 1919, 1920, 1924, 1934, 1935, 1936, 1938, 1959, 1999, 2015, 2027, 2035, 2063, 2064a, 2094, 2096, 2104, 2105, 2106, 2108, 2143, 2156, 2177, 2219, 2275, 2293, 2295, 2311, 2371, 2382, 2420, 2422, 2424, 2443, 2461, 2472, 2496, 2499b, 2504, 2507, 2519, 2542, 2561, 2625, 2833, 2837

MODECADR: 163, 414, 416, 1935, 1936, 1937

MODESW: 59, 1918

MODREG: 154, 313, 323, 333, 335, 343, 345, 437, 619, 627, 629, 642, 650, 731, 782, 831, 836, 1094, 1147, 1800, 1891, 2015, 2306, 2311, 2343, 2382

MONSAVE: 154, 329, 508, 512, 591, 593, 595

MONSAVE1: 154, 329, 508, 512, 591, 593, 595, 613, 617, 621, 625, 638, 639a, 1961

MONSAVE2: 154, 591, 595, 617

MOONBIT: 95, 2070, 2074

MOONFLAG: 91, 95, 749, 775, 790, 816, 820, 822, 823, 1301, 1772, 1774, 1776, 1778, 1780, 1784, 1786, 1788, 1792, 1796, 1812, 1814, 2027, 2070, 2074, 2299

MOONOTH: 73, 442, 444

MOONTHIS: 71, 442, 444, 816, 949, 1705, 2718

MOVATHIS: 73, 1804

MPAC: 145, 321, 323, 327, 335, 337, 339, 347, 351, 390, 405, 407, 418, 440, 481, 487, 489, 495, 496, 497, 498, 501, 503, 506, 515, 519, 523, 525, 539, 543, 549, 551, 553, 555, 557, 559, 561, 563, 565, 567, 577, 579, 581, 583, 585, 587, 589, 590, 591, 593, 595, 597, 599, 601, 609, 611, 615, 619, 621, 627, 629, 635, 649, 651, 670, 674, 678, 714, 716, 717, 720, 733, 739, 743, 749, 763, 765, 786, 788, 792, 794, 795, 804, 812, 820, 822, 839, 840a, 876, 886, 911, 919, 921, 923, 934, 939, 947, 953, 957, 961, 963, 965, 967, 969, 971, 973, 975, 983, 985, 991, 1001, 1019, 1021, 1025, 1029, 1031, 1049, 1056, 1063, 1094, 1147, 1195, 1200, 1227, 1256, 1296, 1297, 1299, 1301, 1546, 1547, 1554, 1555b, 1556, 1559, 1561, 1562, 1563, 1565, 1567, 1568, 1570, 1571a, 1571b, 1572, 1573, 1574, 1575, 1576, 1577, 1578a, 1578b, 1579, 1580, 1581, 1582, 1584, 1585, 1586, 1587, 1588, 1589, 1590, 1591, 1592, 1593, 1594, 1595, 1596, 1598, 1599, 1600, 1601, 1602, 1603, 1604a, 1604b, 1605, 1606, 1607, 1608, 1609, 1610, 1612, 1613, 1614, 1615, 1616, 1618, 1620, 1621, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1633, 1649, 1651, 1653, 1654, 1675, 1677, 1679, 1680, 1684, 1697, 1714, 1717, 1720, 1723, 1724, 1726, 1729, 1733, 1737, 1740, 1743, 1745, 1746, 1752, 1756, 1763, 1767, 1796, 1798, 1803, 1806, 1808, 1814, 1835, 1837, 1844, 1852, 1905, 1915, 1927, 1928, 1941, 1943, 1944a, 1945, 1959, 1962, 1963, 1967, 1977, 1983, 1985, 1987, 1991, 1993, 1997, 1999, 2000a, 2015, 2027, 2035, 2114, 2118, 2142, 2143, 2148, 2158, 2160, 2164, 2175, 2177, 2181, 2185, 2189, 2205, 2209, 2219, 2223, 2265, 2283, 2285, 2299, 2306, 2311, 2359, 2365, 2367,

2375, 2381, 2382, 2441, 2442, 2444, 2446, 2454, 2588, 2590, 2592, 2594, 2596, 2598, 2600, 2603, 2605, 2606, 2624, 2747
MPTEMP: 142, 515, 635, 1541, 1572, 1577, 1588, 1589, 1590, 1591, 1592, 1593, 1594, 1595, 1596, 1597, 1610, 1612, 1613, 1614, 1616, 1621, 1624, 1627, 1629, 2382
MRKIDBIT: 109, 2070, 2082
MRKIDFLG: 91, 109, 2070, 2082
MRKNVBIT: 111, 2070, 2082
MRKNVFLG: 91, 111, 1985, 2070, 2082
MRKRTMP: 200, 1094
MRUPTBIT: 111, 2070, 2084
MRUPTFLG: 91, 111, 2070, 2084
MSGSCAN1: 67
MWAITBIT: 111, 2070, 2082
MWAITFLG: 91, 109, 2070, 2082
MYSUBS: 24, 63, 1410, 2742, 2747, 2833, 2837
N: 20, 42, 48, 78, 154, 206, 231, 317, 390, 424, 430, 438, 487, 489, 508, 512, 527, 585, 593, 599, 635, 637, 638, 640, 642, 651, 745, 788, 804, 825, 827, 829, 893, 909, 915, 930, 934, 941, 969, 989, 993, 1003, 1005, 1007, 1009, 1011, 1013, 1054, 1147, 1195, 1200, 1254, 1301, 1347, 1373, 1390, 1412, 1456, 1481, 1498, 1526, 1538, 1575, 1576, 1640, 1663, 1852, 1872, 1874, 1932, 1939, 1961, 2001, 2132, 2141, 2148, 2154, 2219, 2258, 2293, 2299, 2311, 2382, 2463, 2472, 2474, 2478, 2480, 2519, 2633, 2721, 2767, 2790, 2826
N10: 206, 208, 1347, 1373, 1951, 2826
N2217BIT: 131
N22ORN17: 91, 131, 416, 417, 1412
N49DISP: 40, 232, 472, 947, 949, 953, 993, 1027
NAVKEYIN: 87, 323, 389, 2062, 2134, 2136
NBDX: 167, 493, 495, 497, 501, 1227, 1663, 2382
NBDY: 167, 495, 501
NBDZ: 169, 496, 501
NBRCYCLP: 208, 1094
NBRCYCLS: 208, 1094
NCDU: 219, 684, 686
NDXCTR: 191, 696, 698, 700, 702, 2189, 2191, 2193, 2195
NEEDLBIT: 95, 2070, 2075, 2512
NEEDLFLG: 91, 95, 416, 2070, 2075, 2510
NEWAZ1: 196, 725
NEWAZMTH: 194, 731, 743
NEWIBIT: 125, 2070, 2094
NEWIFLG: 91, 125, 1792, 1794, 1800, 2070, 2094
NEWJOB: 138, 327, 351, 704, 835, 1256, 1547, 1653, 1654, 1655, 1656, 1660, 1661, 1878, 1888, 1889, 2197, 2484, 2494, 2495a, 2590, 2623
NEWLOC: 138, 351, 1649, 1651, 1653, 1657
NEWLOC+1: 138
NEWPRIO: 138, 345, 351, 690, 1649, 1651, 1652, 1653, 1657, 1658, 1977

NEXTIME: 219, 688, 689
NJETSBIT: 97, 2070, 2076
NJETSFLG: 91, 97, 1094, 1301, 2070, 2076
NN: 241, 244, 454, 456, 460, 462, 470, 478, 756, 771, 846, 1063, 2223
NN1: 40, 241, 472, 907
NN1A: 241, 1301
NN2: 241, 1301
NNADTEM: 144, 452, 537, 541, 543, 549, 551, 579
NNTYPTEM: 144, 452, 551, 575, 577
NOBITS: 191
NODOBIT: 105, 337, 341, 2070, 2080
NODOFLAG: 91, 105, 333, 341, 360, 1200, 1486, 1782, 1941, 1944a, 2013, 2070, 2080, 2114, 2116
NODOPO1: 93, 99, 313, 419, 864
NOMTIG: 224, 1094
NOMTPI: 35, 181, 460, 758, 769, 775, 1063, 2223
NOPO1BIT: 99, 313, 419, 724
NORFBIT: 95
NORFHOR: 93, 95, 1019, 1033
NORMEX: 165, 763, 765, 770a, 773, 774, 781, 786, 793, 798, 800a, 895, 897, 1063, 2223
NORMGAM: 177, 1697, 1701, 1703, 1709
NORMSBIT: 123, 2070, 2091
NORMSW: 93, 123, 788, 1047, 1094, 1301, 1717, 1721, 1724, 1726, 1743, 1745, 1767, 2070, 2091
NORMTEM1: 154, 1147, 1975, 1979
NOSWBIT: 119
NOSWITCH: 93, 119, 1256
NOUNADD: 144, 537, 539, 541, 543, 547, 551, 561, 567, 569, 571, 573, 577, 585, 589, 595, 631
NOUNCADR: 154, 512, 537, 539, 543, 551, 577, 579, 591, 595, 596, 621, 631
NOUNREG: 152, 329, 409, 452, 508, 525, 527, 543, 569, 591, 595, 609, 619, 629, 1961, 1997
NOUNTEM: 140, 541
NOUT: 154, 253, 255, 329, 508, 533, 605, 619, 640
NPJETS: 209, 1456, 1466, 1467
NRJETS: 209, 1460, 1461, 1462, 1469, 1471, 1473
NRMIDBIT: 109, 2070, 2082
NRMIDFLG: 93, 109, 2070, 2082
NRMNVBIT: 111, 2070, 2082
NRMNVFLG: 93, 111, 1987, 2070, 2082
NRUPTBIT: 113, 2070, 2084
NRUPTFLG: 93, 113, 2070, 2084
NUJET: 216, 1516
NUVCSM: 172, 1035, 1774
NUVLEM: 172

NVBNKTEM: 154, 512, 617
NVQTEM: 154, 512, 617
NVSAVE: 150, 313, 1959, 1989, 1997
NVTEMP: 140, 617, 619, 625, 627, 638
NVWORD: 150, 1959, 1977, 1981, 1985, 1987, 1997, 2287
NVWORD1: 157, 1043, 1094, 1989, 2287
NWAITBIT: 111, 2070, 2082
NWAITFLG: 93, 111, 2070, 2082
NYJETS: 209, 1457, 1468
OGA: 206, 680, 1200, 1356, 1396, 1839, 2187
OGAD: 200, 1094, 1356, 1396
OGAERR: 206, 1356, 1396
OGANOW: 206, 329, 1347, 1356, 1396
OGAPAST: 206, 1356, 1396
OGARATE: 208, 297, 1396
OGC: 44, 186, 298, 368, 405, 414, 476, 708, 722, 737, 866, 874, 880, 1147, 1835, 1836, 1839, 1840, 2201, 2202b, 2211
OLDAZ1: 196
OLDAZMTH: 194, 725, 729, 731
OLDBODY1: 221
OLDBODY2: 221
OLDBODY3: 221
OLDBT1: 156, 1227
OLDELP: 214, 1483, 1491
OLDELQ: 214, 1483, 1489
OLDELR: 214, 1483, 1491
OLDUYA: 226, 1255a, 1291
OMEGA: 232, 905, 963, 969, 971, 1693, 1697, 1698, 1699, 2452, 2519, 2574
OMEGAB: 202, 208, 297
OMEGAC: 202, 297, 302, 1094
OMEGAES: 177, 1195
OMEGAM1: 190, 1699, 1701
OMEGAM2: 190, 1699, 1701
OMEGAM3: 190, 1699, 1703
OMEGAXB: 202
OMEGAXC: 202, 1094
OMEGAYB: 202, 1373
OMEGAYC: 202, 1347, 1373
OMEGAZB: 202, 1373
OMEGAZC: 202, 1373
OPTCADR: 163, 329, 412, 1147
OPTDRV: 59, 288
OPTIND: 52, 161, 281, 284, 285, 288, 290, 292, 293a, 313, 347, 386, 412, 434, 650, 741, 1094, 1147
OPTION1: 38, 157, 454, 844, 1013, 1301, 1951, 1959, 1979, 2148
OPTION2: 157, 474, 747, 844, 846, 911, 1147, 1301

OPTIONX: 38, 154, 454, 804, 827, 829, 2148
OPTIONY: 179, 804, 806
OPTMODES: 163, 264, 281, 282, 285, 286, 287, 288, 295, 298, 300, 302, 304, 313, 319, 386, 642, 644, 2001
OPTNREG: 191
OPTNSW: 91, 93, 105, 846, 848, 2070, 2079
OPTX: 80
OPTXCMD: 85
OPTY: 80, 163
OPTYCMD: 85
ORBITAL: 24, 59, 107, 359, 360, 754, 784, 820, 822, 823, 825, 827, 831, 835, 836, 837, 842, 919, 921, 943, 977, 1015, 1200, 1256, 1713, 1714, 1772, 1778, 1788, 1814, 1852, 2015, 2081, 2299, 2833, 2837
ORBITAL1: 59, 1814
ORBITAL2: 61, 1814, 2051
ORBWFBIT: 107, 2070, 2081
ORBWFLAG: 93, 107, 360, 440, 943, 977, 979, 981, 989, 1009, 1015, 1023, 1041, 1804, 1812, 1814, 2070, 2081
ORDERBIT: 127, 2070, 2094
ORDERSW: 93, 127, 1718, 1739, 1740, 1769, 2070, 2094
ORIGEX: 177, 1814
OTHPREC: 71, 428, 745, 806, 820, 825, 829
OUT0: 87, 252, 253, 255, 256, 517, 2059
OUTTAG: 216, 1516, 1518
OVFIND: 140, 491, 559, 585, 635, 653, 1200, 1256, 1301, 1568, 1570, 1571b, 1573, 1574, 1590, 1598, 1610, 1620, 1633, 1653, 1654, 1655, 1695, 1713, 1714, 1717, 1720, 1723, 1726, 1762, 1852, 2311, 2588
P: 40, 42, 44, 48, 95, 117, 188, 214, 241, 243, 353, 355, 405, 416, 493, 752, 760, 784, 797, 806, 874, 876, 878, 880, 1001, 1003, 1005, 1009, 1062a, 1063, 1094, 1200, 1301, 1367, 1396, 1489, 1491, 1495, 1498, 1502, 1503, 1514, 1516, 1521, 1627, 1717, 1718, 1721, 1724, 1726, 1744, 1746, 1748, 1750, 1754, 1756, 1759, 1760, 1762, 1763, 1767, 1776, 1788, 1814, 1844, 1852, 2059, 2075, 2107a, 2108, 2154, 2156, 2165, 2213, 2223, 2254, 2293, 2500, 2509, 2512, 2513, 2519, 2542, 2561, 2574, 2588, 2590, 2592, 2607, 2609, 2619, 2625, 2770, 2833, 2837
P(T1): 241, 1301
P/RPRE: 243, 1301
P05P06: 65, 1941
P11FOUR: 65, 890
P11ONE: 69, 862, 880
P11TWO: 69, 878
P17S: 69, 895, 2822
P17S1: 69, 893, 909, 2822
P20S: 69, 747, 915, 921, 927, 1638, 2752
P20S1: 67, 919, 921
P20S2: 65, 936, 1009
P20S3: 69, 941

P20S4: 69, 965, 1013
P20S6: 67, 977, 1001
P21: 22, 52, 56a, 103, 179, 219, 221, 244, 359, 745, 747
P21ALT: 42, 244, 474, 749
P21BASER: 244, 747, 749
P21BASEV: 244, 749
P21BIT: 103
P21FLAG: 93, 103, 325, 347, 747, 749, 2070, 2074
P21GAM: 42, 244, 474, 749
P21ORIG: 244, 749
P21TIME: 179, 438, 747, 749, 750, 965, 967, 969, 973, 1013
P21VEL: 42, 244, 474, 749
P22MKBIT: 107
P22MKFLG: 93, 107, 919, 979
P22S: 67, 999
P23S: 57
P23S1: 63, 1037
P30/31RT: 239, 1047, 1048
P30/RET: 157, 1047
P30S: 69, 238, 239, 1054, 2219
P30S1: 69, 1043, 2219
P30S1A: 67, 1049
P30SUBS: 57, 782, 1062a
P37RANGE: 223, 1301
P39/79SW: 93, 127, 846, 850, 852, 2070, 2094
P39SWBIT: 127, 2070, 2094
P40S: 65, 370, 1094, 2043, 2045, 2260, 2281, 2294
P40S1: 61, 1094, 2043, 2049, 2295
P40S2: 67, 1094, 2293
P40S3: 67, 1094, 2279
P40S5: 63, 1094
P40TMP: 73, 238, 357, 370, 372, 1094
P50S: 61, 1147, 2128, 2766
P50S1: 61, 1147, 2050
P50S2: 63, 1147
P50S3: 63, 1147, 2766
P60S: 65, 1200
P60S1: 65, 1200
P60S2: 65, 1200
P60S3: 65, 1200
P60S4: 59, 1200
P60S5: 67, 1200
P63FLAG: 216, 1200, 1485, 1498, 1500
P76LOC: 61, 820
PAC: 44, 186, 412, 476, 482, 483, 484, 741, 1147
PACTOFF: 40, 198, 295, 298, 351, 368, 370, 372, 374, 437, 472, 1094, 1347, 1356,

1367, 2765
PACTTMP: 206, 1356
PADLONG: 161, 860, 866
PAXERR: 218, 1519
PAXERR1: 214, 302, 1485, 1502, 1506, 1519
PBIASX: 167, 2311
PBIASY: 167, 2311
PBIASZ: 167, 2311
PBODY: 177, 444, 1705, 1784, 1788, 1792, 1798, 1814
PCDUYPST: 204, 1373
PCDUZPST: 204, 1373
PCMD: 204, 295, 1347, 1367, 1373
PCON: 241, 1301
PDA: 148, 483, 2181
PDELOFF: 204, 1347, 1356, 1373
PDSPFBIT: 109, 959, 2070, 2082
PDSPFLAG: 93, 109, 649, 936, 959, 2070, 2082
PERFDLAY: 196, 698, 725, 2191
PERRB: 204, 1347, 1373
PFRATBIT: 105, 2070, 2079
PFRATFLG: 93, 105, 1094, 1147, 2070, 2079
PGNCSALT: 161, 860, 866
PHASE1: 152, 315, 321, 323, 343, 349, 378, 380, 712, 1412, 1453, 1475, 1902, 1903, 2269, 2343, 2382
PHASE2: 152, 315, 335, 341, 343, 378, 1412, 2271, 2382
PHASE3: 152, 315, 862, 1412, 1450a, 2271, 2311, 2343, 2382
PHASE4: 152, 315, 335, 343, 378, 1094, 2269, 2279, 2291, 2343, 2382
PHASE5: 152, 315, 378, 862, 870, 1094, 1227, 2271, 2382
PHASE6: 152, 315, 1094, 2015, 2281, 2285, 2343, 2382
PHASETAB: 59, 1891, 1900
PHASETMP: 208, 1347
PHI2: 241, 1301
PHI333: 202, 1362
PHIDOT: 214, 1493, 1495, 1519
PHIV: 177, 1814
PHSBB1: 167
PHSBB2: 167
PHSBB3: 167
PHSBB4: 167
PHSBB5: 167
PHSBB6: 167
PHSNAME1: 167, 349, 1900, 1903, 1905, 1909
PHSNAME2: 167, 2311
PHSNAME3: 167, 2311
PHSNAME4: 167
PHSNAME5: 167, 1299, 2382

PHSNAME6: 167
PHSPRDT1: 154, 1898, 1903, 1907, 1909, 1913
PHSPRDT2: 154, 341, 941, 1015, 2343
PHSPRDT3: 154, 351
PHSPRDT4: 154, 345
PHSPRDT5: 154, 1256
PHSPRDT6: 154, 1043
PINBALL1: 71, 519
PINBALL2: 71, 535
PINBALL3: 71, 452, 561
PINBALL4: 57, 627
PINBRBIT: 111, 2070, 2084
PINBRFLG: 93, 111, 1985, 1989, 2070, 2084
PINDEX: 209, 1455, 1456
PINSUPER: 69, 416, 424, 437, 446, 890, 1094
PIPABIAS: 167, 493
PIPAGE: 159, 1227, 2382
PIPASCF: 167, 493
PIPASCFX: 167
PIPASCFY: 167
PIPASCFZ: 167
PIPAX: 38, 80, 297, 454, 493, 495, 496, 498, 499, 700, 704, 712, 716, 1227, 1926, 2027, 2193, 2197, 2198, 2203, 2204, 2311, 2382, 2426
PIPAY: 80, 297, 493, 495, 496, 498, 499, 712, 716, 1227, 1926, 2027, 2203, 2204, 2311, 2382, 2426
PIPAZ: 80, 297, 493, 495, 496, 498, 499, 712, 716, 1227, 1926, 2027, 2203, 2204, 2311, 2382, 2428
PIPCTR: 159, 1227, 1250, 2343, 2382, 2420
PIPINDEX: 191, 700, 704, 2193, 2195, 2197, 2198
PIPTIME: 133, 159, 295, 485, 814, 818, 1054, 1094, 1200, 1227, 1256, 1481, 1487, 1804, 1805, 2098, 2143, 2299, 2306, 2311, 2371, 2373, 2375, 2382, 2426
PIPTIME1: 159, 295, 303, 503, 1094, 1200, 1227, 1806, 1808, 2265, 2299, 2311, 2382
PLANTIN: 65, 1684
PLANVEC: 183, 1147
PMANNDX: 213, 891, 1412, 1434
POINTEX: 159, 955, 1023, 1024
POINTVSM: 219, 651, 653, 973, 1013, 1021, 1094, 2148, 2165, 2299
POLISH: 140, 514, 1553a, 1565, 1566, 1575, 1576, 1618, 1630, 1631, 1632, 1633, 1635, 1636, 1637a
POLYCNT: 142, 1575, 1576
POLYLOC: 219, 886
POLYNUM: 219, 860, 862, 876
POLYRET: 142, 1575, 1576
POLYSTOP: 221, 858, 860, 874, 876
POSEXIT: 216, 1200, 1256, 1299

POSITON: 191, 696, 698, 700, 702, 708, 2189, 2191, 2193, 2195, 2201
POSNV: 194, 720, 2207, 2209
POSTCDH: 244, 1063, 2223, 2684
POSTCSI: 244, 1063, 2223
POSTTPI: 40, 183, 472, 754, 759, 844, 850, 907
POWFLIT1: 65, 1844
POWFLIT2: 65, 487
POWFLITE: 65, 1844
PRECIBIT: 107, 2070, 2081
PRECIFLG: 93, 107, 360, 1790, 1792, 1796, 1800, 2070, 2081
PREDANG: 229, 1248, 1254, 1256
PREL: 214, 302, 1491, 1493, 1495, 1498, 1504, 1521
PREMTRX1: 196, 725
PREMTRXC: 194, 729, 731, 743
PRFTRBIT: 115
PRFTRKAT: 93, 115, 440, 915, 975, 1147
PRIODBIT: 109, 2070, 2082
PRIODFLG: 93, 109, 2070, 2082
PRIORITY: 31, 109, 111, 113, 140, 145, 327, 335, 345, 349, 353, 355, 362, 364, 382, 419, 424, 425, 426, 430, 432, 446, 508, 573, 609, 613, 633, 647, 649, 650, 732a, 825, 860, 936, 953, 1094, 1547, 1649, 1651, 1652, 1653, 1654, 1656, 1657, 1658, 1659, 1660, 1872, 1894, 1895, 1896, 1898, 1903, 1909, 1915, 1938, 1949, 1950, 1957, 1959, 1961, 1962, 1973, 1977, 1983, 1993, 1995, 2015, 2082, 2084, 2152, 2154, 2287, 2289, 2311, 2382, 2478, 2496
PRIOTIME: 157, 1959, 1973, 1993
PRONVBIT: 111, 2070, 2084
PRONVFLG: 93, 111, 1987, 2070, 2082
PSI333: 202, 1362
PSIV: 177, 1814
PTIGINC: 175, 762, 852
PTMP1: 202, 1347, 1373
PTMP2: 202, 1373
PTMP3: 202, 1373
PTMP4: 202, 1373
PTMP5: 202, 204, 1373
PTMP6: 204, 1373
PUSHLOC: 145, 489, 784, 797, 991, 1200, 1301, 1552, 1562, 1563, 1585, 1618, 1653, 1654, 1655, 1684, 1852, 2130, 2311, 2382
PWORD1: 200, 1412, 1456, 1470b, 1475, 1477
PWORD2: 200, 1412, 1470b, 1475, 1479
PYJETS: 87, 1484, 1496, 2059
Q: 40, 42, 48, 80, 87, 167, 181, 214, 239, 253, 257, 278, 279, 282, 286, 287, 292, 315, 317, 325, 329, 380, 382, 388, 403, 407, 409, 423, 437, 452, 493, 497, 503, 525, 527, 529, 531, 533, 541, 543, 547, 549, 551, 555, 557, 559, 565, 567, 575, 577, 585, 587, 589, 590, 597, 599, 601, 603, 605, 609, 617, 621, 623, 625, 627, 631, 633, 635, 638, 639a, 649, 655, 686, 690, 691a, 692, 705, 708, 714, 716,

732a, 747, 782, 794, 802, 886, 934, 1047, 1094, 1147, 1227, 1299, 1300a, 1347, 1362, 1373, 1390, 1410, 1412, 1479, 1484, 1489, 1492, 1497, 1498, 1510, 1512, 1521, 1526, 1528, 1532, 1538, 1540, 1541, 1542, 1543, 1559, 1567, 1570, 1572, 1573, 1575, 1577, 1578a, 1584, 1589, 1595, 1603, 1604b, 1608, 1609, 1614, 1620, 1621, 1623, 1632, 1633, 1635, 1636, 1637a, 1647, 1649, 1651, 1660, 1663, 1788, 1802, 1812, 1814, 1876, 1878, 1886, 1891, 1896, 1898, 1900, 1902, 1917, 1923, 1925, 1930, 1934, 1939, 1945, 1946, 1947, 1959, 1963, 1967, 1979, 1989, 1995, 2001, 2007, 2011, 2013, 2015, 2027, 2035, 2059, 2108, 2134, 2139, 2198, 2201, 2217, 2283, 2285, 2295, 2297, 2306, 2311, 2343, 2382, 2422, 2455, 2456, 2457, 2458, 2463, 2465, 2469, 2474, 2482, 2484, 2492, 2496, 2500, 2502, 2509, 2512, 2513, 2514, 2517, 2518, 2519, 2542, 2561, 2572, 2573, 2574, 2594, 2598, 2600, 2601, 2621, 2625, 2749, 2833, 2837

`Q2`: 229, 1248, 1252, 1256, 1852

`Q611`: 239, 965, 967, 973

`Q6111`: 239, 965, 969, 971, 973, 975

`Q7`: 42, 223, 474, 1200, 1248, 1252, 1256

`QAXERR`: 218, 1495, 1500

`QCHAN`: 87, 1636

`QMAJ`: 145, 1147, 2299

`QMIN`: 186, 197, 918, 1147, 2542

`QPLAC`: 191, 739, 741, 743

`QPLACE`: 191, 357, 419, 694, 704, 705, 708, 725, 2197, 2198, 2201

`QPLACES`: 73, 191, 706, 866, 2199

`QPRET`: 85, 382, 384, 390, 394, 396, 397, 398, 400, 444, 489, 741, 823, 827, 837, 893, 921, 1042a, 1049, 1054, 1094, 1147, 1200, 1555a, 1555b, 1565, 1618, 1633, 1634, 1649, 1651, 1707, 1794, 1796, 1802, 1814, 1844, 1852, 2219, 2343

`QREL`: 214, 302, 1489, 1492, 1493, 1495, 1498, 1500

`QRUPT`: 80, 251, 388, 890, 891, 959, 1094, 1347, 1367, 1373, 1412, 1453, 1477, 1493, 1528, 1663, 1945, 1946, 2134, 2311, 2465, 2496, 2505, 2519

`QSAVED`: 181, 779, 780, 911

`QTEMP`: 236, 897, 907, 1049, 1051, 1052, 1053, 1094, 1200, 2219

`QTEMP1`: 238, 1094

`QUITBIT`: 131, 2070, 2098

`QUITFLAG`: 93, 131, 407, 446, 1780, 1782, 1798, 2070, 2098

`R(T1)`: 241, 1301

`R(T1)/`: 241, 1301

`R(T2)/`: 241, 1301

`R-OTHER`: 172, 297, 442, 485, 486, 2143

`R/APRE`: 243, 1301

`R02`: 52, 59, 198, 1939, 2219, 2299

`R1A`: 188, 1063, 1301, 1718, 1721, 1724, 1726, 1744, 1746, 1748, 1750, 1751, 1754, 1756, 1760, 1763, 1769, 2223

`R1SAVE`: 156, 329, 1959, 1961, 1991, 1993, 1999

`R1VEC`: 188, 786, 788, 790, 1716, 1717, 1718, 1743, 1745, 1752, 1767, 1769

`R2`: 26, 56a, 152, 188, 200, 241, 244, 327, 426, 428, 430, 438, 450, 510, 512, 517, 518, 523, 527, 529, 531, 539, 540, 567, 599, 625, 627, 747, 804, 825, 844,

846, 858, 860, 872, 911, 919, 929, 1011, 1019, 1094, 1718, 1721, 1724, 1741, 1752, 1769, 1874, 1951, 1952, 1953, 1955, 1956, 1961, 1963, 1975, 1979, 1997, 2114, 2148, 2480
R21BIT: 103
R21MARK: 93, 103, 325, 341, 930, 932
R22CABIT: 131
R22CAFLG: 93, 131
R22S1: 67, 953
R23BIT: 99, 432, 930
R23FLG: 93, 99, 432, 930, 945
R2VEC: 188, 788, 792, 1716, 1717, 1718, 1752, 1767
R30LOC: 65, 827, 2049
R31: 22, 28, 67, 131, 177, 407, 430, 431, 810, 812, 2742, 2785, 2816, 2833, 2837
R31FLAG: 93, 131, 810, 812
R31FLBIT: 131, 430, 431, 2684
R34: 28, 67, 131, 431, 810, 812, 818, 2091
R35: 28, 67
R35A: 67
R36CM: 63, 802
R36CM1: 71, 806
R36LM: 71, 804, 808
R36LM1: 71, 804
R53EXIT: 224, 1147, 2766
R53FLAG: 93, 97, 1147
R53FLBIT: 97
R57BIT: 119
R57FLAG: 89, 91, 93, 119, 1015, 1021
R60FLAG: 93, 115, 915
R60FLBIT: 115
R61CNTR: 223, 915, 918, 934, 936, 955, 969
RACFAIL: 211, 1094, 1455, 1458, 1461, 1470b, 1471
RACT1: 197, 1063, 2223
RACT2: 197, 1063, 2223
RACT3: 234, 759, 763, 765, 769, 770b, 771, 772, 773, 775, 800a, 850, 893, 895, 897, 901, 903, 905, 1051, 1063, 2223
RAD: 127, 219, 221, 876, 878, 961, 975, 1094, 1200, 1252, 1254, 1675, 1684, 1780, 1852, 2049, 2057a, 2057b, 2087, 2450, 2452, 2512, 2513, 2519, 2542, 2561, 2574, 2601, 2605, 2606, 2611, 2624
RADCADR: 163, 329
RANGE: 28, 29, 33, 35, 40, 44, 119, 127, 131, 159, 179, 229, 239, 300, 407, 430, 442, 456, 458, 472, 476, 555, 583, 802, 806, 810, 812, 943, 957, 959, 1042a, 1054, 1056, 1195, 1200, 1245, 1248, 1252, 1254, 1256, 1301, 1506, 1550, 1553a, 1623, 1627, 1676, 1680, 1852, 2046, 2064a, 2064b, 2094, 2103, 2105, 2311, 2353, 2382, 2420, 2428, 2430, 2590
RAPREC: 236, 763, 769
RASFLAG: 133, 319, 321, 820, 1800, 1802, 2070, 2098

RATEINDX: 157, 313, 682, 688, 1094, 1412, 2165
RAXERR: 218, 1495, 1500, 1502
RBDFAIL: 211, 1094, 1456, 1460, 1461, 1473, 1474
RCL: 161, 991, 993
RCLP: 232, 937, 945, 949, 977, 991, 993
RCNORM: 188, 1715, 1735, 1736, 1767
RCON: 241, 1301
RCSFLAGS: 200, 297, 302, 688, 690, 868, 872, 884, 890, 1094, 1347, 1412, 1434, 1438, 1447, 1475, 1477, 1485, 2504, 2505, 2507, 2510, 2514, 2515, 2517, 2519, 2542, 2574
RCV: 169, 485, 749, 775, 792, 816, 822, 1301, 1705, 1714, 1735, 1736, 1765, 1774, 1778, 1788, 1798, 1804, 1812, 1814, 2143, 2299
RCVCSM: 172, 951, 999, 1035
RCVLEM: 172, 951
RD: 241, 1301, 2452
RDESIRED: 127, 188, 1301, 1722, 1723, 1724, 1760, 1769, 2094, 2223
RDOT: 35, 42, 229, 302, 458, 474, 814, 816, 818, 1200, 1245, 1248, 1250, 1252, 1256, 1504, 1776, 2046, 2353, 2363, 2365, 2375
RDOTREF: 159, 1248, 1250, 1256
RDOTV: 244, 1063, 2223
RDSP: 194
REDOCTR: 157, 297, 302, 311, 317
REENTRY: 22, 33, 54, 65, 145, 181, 223, 226, 231, 241, 458, 1200, 1256, 1301, 2833, 2837
REENTRY1: 65, 1256
REFSMBIT: 107, 2072, 2080, 2112
REFSMFLG: 93, 107, 779, 862, 868, 918, 955, 1015, 1017, 1147, 1301, 1939, 2072, 2080, 2112
REFSMMAT: 52, 56a, 107, 172, 272, 274, 295, 298, 315, 795, 812, 858, 860, 866, 868, 919, 939, 955, 961, 965, 969, 973, 977, 1021, 1094, 1147, 1200, 1227, 1293, 1295, 1344, 1923, 2015, 2080, 2112, 2114, 2116, 2118, 2148, 2213, 2265, 2299, 2311, 2353, 2382
REINTBIT: 135, 1802, 2072, 2100
REINTFLG: 93, 135, 823, 1701, 1794, 1814, 2013, 2015, 2072, 2100
RELDELV: 185, 901, 905, 907
RELRET: 142, 639a
RELVBIT: 119
RELVELSW: 93, 119, 1250, 1256
RENDEZ: 69, 930
RENDGUID: 65, 794
RENDWBIT: 117, 2072, 2087
RENDWFLG: 93, 117, 360, 407, 438, 917, 919, 943, 945, 979, 1015, 1023, 1041, 1804, 1812, 1814, 2072, 2087, 2359
REPFRAC: 204, 1094, 1347, 1356
REQRET: 154, 329, 508, 527, 531, 535, 543, 595, 607, 609, 612, 619, 621, 623, 625

RESO: 175, 177, 1195
RESTARPT: 194, 714
RESTART: 22, 28, 57, 103, 150, 157, 167, 185, 206, 208, 223, 249, 257, 259, 265, 267, 269, 270, 272, 274, 277, 285, 307, 309, 317, 319, 321, 323, 331, 333, 335, 341, 343, 345, 362, 364, 366, 368, 374, 376, 405, 425, 434, 436, 446, 508, 644, 649, 710, 712, 714, 717, 864, 870, 959, 979, 1094, 1147, 1200, 1227, 1256, 1299, 1347, 1356, 1367, 1373, 1412, 1481, 1485, 1487, 1489, 1493, 1504, 1524, 1536, 1774, 1802, 1872, 1874, 1880, 1882, 1893, 1894, 1896, 1905, 1907, 1909, 1911, 1913, 1936, 1941, 1949, 1950, 1962, 1995, 2009, 2015, 2059, 2064a, 2064b, 2076, 2107a, 2108, 2265, 2267, 2269, 2273, 2275, 2281, 2285, 2289, 2291, 2311, 2382, 2461, 2472, 2478, 2480, 2486, 2488, 2504, 2505, 2519, 2588, 2590, 2833, 2837
RESTREG: 150, 313, 335, 1959, 1962, 1975, 1983
RESULTCT: 194, 700, 702, 704, 705, 2193, 2195, 2198
RETROBIT: 113
RETROFLG: 113, 1301, 2684
REVS: 206, 241, 750, 874, 961, 963, 965, 971, 975, 1094, 1147, 1301, 1356, 1373, 1390, 1675, 1676, 1677, 1684, 2057b, 2128
RGEXIT: 181, 182, 1043
RHO: 188, 211, 985, 999, 1412, 1718, 1754, 1767, 1814
RHO1: 211, 1412
RHO2: 211, 1412
RHOSB: 40, 179, 423, 472, 1344
RINDEX: 209, 1458, 1461
RINIT: 234, 236, 772, 784, 786, 788, 790, 794, 795, 901, 1094, 2219, 2254, 2256
RLS: 99, 175, 304, 799, 831, 835, 884, 921, 923, 925, 926, 997, 1147, 1682, 1786, 2299, 2353
RM: 239, 300, 957, 959, 1147, 1682, 2098
RMAG: 174, 1200, 1227, 1852
RMANNDX: 213, 891, 1412, 1434
RMAX: 175, 947
RN: 133, 159, 295, 442, 485, 814, 818, 835, 858, 884, 1094, 1200, 1227, 1245, 1256, 1804, 1805, 1852, 2098, 2143, 2299, 2382
RN1: 73, 159, 866, 1200, 1227, 1808, 2382
RNDVZBIT: 97, 343, 345, 432, 434, 2072, 2075
RNDVZFLG: 93, 97, 434, 915, 917, 919, 1015, 1147, 1941, 2072, 2075, 2299, 2353
RNGSCFLG: 115, 1013, 1014, 2072, 2086, 2382
RNRAD: 80, 959
ROLL/180: 214, 1227, 1295, 1297, 1299, 1486, 1491, 1495, 1502, 1504, 1518
ROLL/PIP: 214, 1227, 1297
ROLLC: 42, 214, 216, 229, 302, 474, 1200, 1248, 1254, 1256, 1486, 1498, 1504, 1506, 1518, 1519
ROLLFIRE: 204, 1396
ROLLHOLD: 214, 216, 1256, 1486, 1502, 1518
ROLLJETS: 87, 1484, 1500, 1502, 1518, 2059
ROLLTM: 214, 302, 1495, 1518

ROLLWORD: 204, 1396
RONE: 179, 810, 812, 814, 816, 818, 827, 829, 835, 837, 839, 1056, 1200, 1852, 2148
ROOTRET: 156
RPADTEM: 179, 827, 829, 831, 835, 837, 839, 840a
RPASS1: 244, 1063, 2223
RPASS2: 197, 1063, 2223
RPASS3: 234, 758, 763, 765, 769, 770b, 771, 800a, 854, 895, 897, 1063, 2223
RPASS36: 179, 446, 804, 806
RPASS4: 236, 901, 905, 907
RPPREC: 236, 763, 769
RPQFLAG: 93, 125, 1792, 1794, 1814, 2072, 2092
RPQFLBIT: 125, 2072, 2092
RPQV: 177, 1814
RPRE: 241, 243, 1301
RPRE': 241, 1301
RPSTART: 221, 858, 860, 874, 876
RPSV: 177, 1814
RPVAR: 175, 985
RQVV: 177, 1778
RRATE: 40, 44, 179, 300, 472, 476, 802, 806, 812, 1042a
RRECT: 169, 822, 1713, 1727, 1765, 1782, 1784, 1786, 1796, 1804, 1812, 1814
RRECT1: 169
RRECTCSM: 169, 172, 359, 366, 1774, 1776, 1780, 1782, 1784, 1788, 2353
RRECTHIS: 172, 442, 444, 1782
RRECTLEM: 169, 172, 1786
RRECTOTH: 172, 442, 444
RREL: 214, 302, 1491, 1492, 1493, 1495, 1498, 1500, 1521
RSBBQ: 167, 297, 302, 317
RSP-RREC: 40, 181, 472, 827, 1054, 1056
RT: 182, 226, 489, 491, 987, 1054, 1200, 1245, 1250, 1256, 1301, 1852
RT23: 67, 1015
RT53: 61, 1037, 1147
RTARG: 224, 234, 295, 300, 754, 761, 771, 773, 784, 786, 788, 793, 901, 1045, 1052, 1094, 1301, 2254
RTARG1: 234, 786, 788, 792, 793
RTBCODE1: 63
RTBCODES: 63, 2027, 2035
RTE: 67, 1245, 1301, 1412
RTE1: 69, 1301
RTE2: 63, 1301
RTE3: 67, 1301
RTEAST: 226, 489, 491, 1245, 1256
RTECON: 69
RTECON1: 69, 1301
RTED1: 166, 1301

RTEDVD: 40, 241, 472, 1301
RTEGAM2D: 40, 241, 472, 1301
RTENCKEX: 241, 1301
RTGO: 35, 42, 229, 231, 458, 474, 1200
RTGON64: 42, 229, 474
RTGON67: 42, 231, 474, 1256
RTHETA: 40, 44, 179, 300, 472, 476, 802, 808, 812, 814, 816, 818, 1042a
RTIG: 236, 1045, 1049, 1051, 1052, 1063, 1094, 2219, 2223, 2256, 2258
RTINIT: 226, 372, 489, 491, 1200, 1245, 1250, 1256, 1291
RTNAPSE: 188, 1726, 1763, 1769
RTNLAMB: 188, 1718, 1752, 1758, 1759, 1767, 1769
RTNORM: 226, 489, 491, 1245, 1256
RTNPRM: 188, 1721, 1724, 1726, 1743, 1744, 1769
RTNSAVER: 144, 1844
RTNTR: 188, 1760, 1769
RTNTT: 188, 1721, 1724, 1743, 1769
RTRN: 181, 775, 782, 854, 856, 911, 1063, 2223
RTRNLOC: 208, 1347
RUN: 191, 412, 593, 694, 722, 733, 860, 1362, 1390, 1657, 2076, 2154, 2209, 2382
RUPTAGN: 150, 515, 959, 1663
RUPTREG1: 138, 251, 255, 257, 258, 265, 266, 281, 382, 384, 390, 1227, 1891, 1900, 1930, 1931, 1933b, 2001, 2136, 2139, 2311, 2420, 2428, 2430, 2432, 2500, 2502
RUPTREG2: 138, 258, 266, 269, 390, 1900, 1930, 1931, 1933b, 1935, 1936, 1937, 1995, 2139, 2311, 2502, 2503a, 2574
RUPTREG3: 138, 388, 390, 402, 694, 1542, 1900, 1935, 1959, 1977, 1979, 2311, 2434, 2436, 2438, 2574
RUPTREG4: 138, 390, 1542, 1900, 1945, 1959
RUPTSTOR: 138, 388, 390, 402
RUTMXTEM: 144, 452, 575
RVAR: 198, 951
RVARMIN: 198, 947
RVEC: 188, 758, 797, 798, 854, 897, 903, 1063, 1147, 1301, 1719, 1721, 1722, 1724, 1725, 1726, 1743, 1760, 1763, 1769, 2223
RVSW: 93, 123, 758, 854, 897, 1063, 1301, 1719, 1720, 1723, 1724, 1743, 1769, 2072, 2091, 2223
RVSWBIT: 123, 2072, 2091
RWORD1: 200, 1412, 1458, 1460, 1461, 1462, 1473, 1475, 1477
RWORD2: 200, 1412, 1471, 1473, 1475, 1479
RZC: 232, 1024, 1029, 1035
S1: 85, 483, 484, 670, 678, 680, 717, 939, 959, 963, 969, 977, 979, 983, 985, 993, 1003, 1007, 1035, 1041, 1056, 1058, 1147, 1195, 1200, 1291, 1301, 1631, 1684, 1693, 1697, 1701, 1703, 1814, 1841, 1844, 1852, 1876, 1884, 2160, 2177, 2185, 2187, 2205, 2482, 2490
S2: 85, 706, 733, 735, 837, 839, 840a, 866, 999, 1041, 1042a, 1147, 1200, 1682, 1684, 1693, 1697, 1698, 1701, 1703, 1739, 1746, 1782, 1784, 1786, 1814, 1835,

1836, 1839, 1840, 1841, 1852, 1876, 1884, 2143, 2199, 2482, 2490, 2574, 2609, 2615, 2621, 2623, 2624
S22EORM: 239, 977, 979, 989, 991, 993, 999
S22LOC: 190, 977, 981, 989, 1001
S22RTNEX: 239, 977, 997
S22TOFF: 239, 923, 925, 977, 989, 995, 997
S22TPRIM: 239, 977, 989
S22WSUBL: 175, 993
S22WUNL: 239, 244
S32.1F1: 135, 1063, 2072, 2087, 2223
S32.1F2: 135, 1063, 2072, 2087, 2223
S32.1F3A: 135, 1063, 2072, 2087, 2223
S32.1F3B: 135, 1063, 2072, 2087, 2223
S3229T3B: 137
S32BIT1: 135, 2072, 2087
S32BIT2: 135, 2072, 2087
S32BIT3A: 135, 2072, 2087
S3435LOC: 69, 770b
S52/2: 61, 1147
S52/3: 61
S61DT: 223, 370, 1200
SAC: 44, 186, 412, 476, 482, 483, 484, 739, 1147
SALFA: 216, 1493, 1502
SAMPTIME: 42, 80, 388, 474, 635, 2112, 2114
SATRATE: 221, 891
SATRLRT: 219, 221, 868, 874, 878, 886
SATSCALE: 221, 886
SATSW: 221, 872, 876, 882, 884, 2749
SAVBNK: 221, 934, 936
SAVE: 142, 157, 167, 181, 185, 191, 218, 219, 221, 239, 241, 257, 258, 265, 294, 335, 339, 380, 394, 452, 493, 498, 514, 519, 537, 561, 565, 617, 625, 627, 629, 638, 649, 653, 692, 710, 747, 749, 773, 777, 804, 806, 831, 839, 876, 895, 897, 899, 901, 905, 934, 957, 959, 967, 969, 973, 989, 991, 993, 997, 1017, 1094, 1147, 1200, 1227, 1256, 1291, 1293, 1344, 1347, 1390, 1412, 1487, 1493, 1495, 1497, 1502, 1504, 1506, 1510, 1516, 1518, 1521, 1528, 1530, 1532, 1534, 1538, 1540, 1541, 1542, 1556, 1572, 1574, 1576, 1579, 1581, 1584, 1591, 1609, 1610, 1620, 1623, 1652, 1656, 1663, 1675, 1684, 1709, 1812, 1852, 1876, 1878, 1891, 1905, 1907, 1909, 1927, 1928, 1937, 1938, 1973, 1975, 1977, 1983, 2001, 2009, 2013, 2015, 2108, 2143, 2148, 2269, 2283, 2295, 2382, 2420, 2424, 2426, 2442, 2448, 2453, 2465, 2467, 2469, 2471, 2474, 2482, 2484, 2500, 2502, 2503a, 2512, 2519, 2542, 2561, 2574, 2590, 2600, 2607, 2609, 2611, 2613, 2615, 2617, 2621
SAVECBIT: 131
SAVEDCDU: 221, 223, 963, 965, 967, 969, 971, 973
SAVEPOS: 239, 240, 965, 969, 973
SAVQR52: 183, 1147

SAX: 186, 1147
SBAND: 71, 1344, 2051, 2213
SCALSAVE: 157, 1941, 1943
SCAXIS: 219, 651, 653, 655, 657, 973, 975, 1013, 1021, 1094, 2125, 2126, 2128, 2129, 2148, 2165, 2299
SCOUNT: 165, 1878, 1884, 2484, 2490
SECMAX: 234, 763, 767
SELFCHEC: 71, 1874, 2480
SELFERAS: 165, 166
SELFRET: 165, 329, 440, 1661, 1876, 1878, 2482, 2484
SELFSUPR: 71
SEPMNRET: 142, 567
SEPSCRET: 142, 565, 567
SERVICES: 69, 1227, 2044, 2046, 2049, 2382
SFAIL: 165, 645, 1876, 1878, 2482, 2484
SFCONST1: 191
SFTEMP1: 140, 452, 454, 514, 547, 549, 553, 555, 557, 559, 579, 581, 583, 585
SFTEMP2: 140, 452, 454, 514, 553, 555, 557, 579, 583, 585, 587
SGNOFF: 140, 527, 529
SGNON: 140, 527, 529
SGNRDOT: 188, 1301, 1722, 1723, 1760
SGNRT: 206, 1396
SHAFTA: 191
SIGNRET: 142
SINB: 186
SINCDU: 150, 482, 1147, 1844
SINCDUX: 150, 882, 1147, 1373, 2441, 2450
SINCDUY: 150, 1147, 1844
SINCDUZ: 150, 880, 1147, 1844, 2448, 2450
SINM: 216, 1491, 1504
SINO: 216, 1489, 1491
SINOCOSM: 216, 1489, 1491
SINTH: 148, 483, 899, 1295, 1676, 1680, 1835, 1836, 1837, 1839, 1840, 2143
SKEEP1: 165, 440, 1876, 1878, 1884, 1886, 1889, 2482, 2484, 2490, 2492, 2495a
SKEEP2: 165, 440, 1880, 1882, 1884, 1886, 2486, 2488, 2490, 2492
SKEEP3: 165, 440, 1880, 1882, 1884, 1886, 1888, 2484, 2486, 2488, 2490, 2492, 2494
SKEEP4: 165, 317, 1878, 1880, 1882, 1884, 1888, 1889, 2484, 2486, 2488, 2490, 2494, 2495a
SKEEP5: 165, 317, 1876, 1878, 1880, 1882, 1884, 1886, 1888, 2482, 2484, 2486, 2488, 2490, 2492, 2494
SKEEP6: 165, 317, 440, 1878, 1880, 1884, 1888, 1889, 2484, 2486, 2490, 2494, 2495a
SKEEP7: 165, 317, 1876, 1878, 1880, 1882, 1884, 1886, 1888, 2482, 2484, 2486, 2488, 2490, 2492, 2494
SKIPVBIT: 103, 325, 959

SKIPVHF: 93, 103, 325, 957, 959
SLOPE: 213, 241, 1063, 1362, 1390, 1396, 1412, 1439, 1443, 1445, 1447, 2223
SLOPEBIT: 101, 2072, 2078
SLOPESW: 93, 101, 1718, 1739, 1752, 2072, 2078
SLOWBIT: 113
SLOWFLG: 113, 1301
SMODE: 38, 165, 311, 440, 454, 1872, 1874, 1876, 1878, 2478, 2480, 2482, 2484
SNTH: 188, 758, 854, 897, 899, 1063, 1301, 1718, 1719, 1724, 1745, 1746, 1750, 1752, 1754, 1762, 1767, 2223
SOLNSBIT: 117, 2072, 2087
SOLNSW: 93, 115, 1717, 1718, 1723, 1724, 1758, 1759, 1762, 1769, 2072, 2087
SOURCBIT: 131, 951
SOURCFLG: 93, 131, 941, 945, 947, 949, 953, 957
SOUTHDR: 191, 700, 702, 2193, 2195
SPNDX: 209, 216, 1412, 1441, 1447, 1449
SPOLYARG: 221, 862, 876, 878
SPRTETIG: 243, 1301
SPRTEX: 241, 1301
SQ: 50, 156, 182, 953, 985, 987, 999, 1063, 1200, 1227, 1256, 1347, 1362, 1396, 1483, 1492, 1493, 1521, 1647, 1814, 1852, 2223, 2382
SQRARG: 156
SR: 80, 144, 152, 448, 533, 567, 575, 603, 682, 796, 905, 947, 991, 993, 995, 1029, 1031, 1035, 1063, 1094, 1195, 1256, 1301, 1491, 1492, 1493, 1504, 1506, 1508, 1510, 1521, 1588, 1590, 1591, 1594, 1596, 1602, 1623, 1624, 1684, 1738, 1744, 1752, 1754, 1756, 1814, 1838, 1844, 1852, 1884, 1889, 1911, 2223, 2299, 2343, 2353, 2363, 2457, 2490, 2495a, 2574
SR52/1: 61, 1147
SRRETURN: 232, 1029, 1033
STAR: 24, 35, 99, 107, 185, 186, 339, 370, 382, 390, 458, 482, 483, 484, 739, 937, 1015, 1017, 1019, 1037, 1147, 1868, 2052, 2053, 2054, 2055, 2056, 2081, 2123, 2125, 2128, 2129, 2130, 2132, 2833, 2837
STARAD: 186, 735, 1147, 1841, 1842a, 2125, 2132
STARALGN: 150
STARCODE: 42, 150, 474, 735, 737, 1017, 1019, 1147
STARIND: 145, 357, 1015, 1147, 2289
STARM: 148, 481, 1147
STARSAV1: 185, 1147
STARSAV2: 185, 1019, 1037, 1147, 2132
STARSAV3: 239, 476, 1037, 1147
STARTAB: 61, 1868, 2052
STATE: 28, 29, 32, 54, 56a, 89, 95, 97, 99, 101, 105, 107, 109, 113, 117, 121, 123, 125, 129, 133, 135, 138, 159, 169, 172, 241, 254, 257, 263, 264, 265, 268, 270, 274, 294, 295, 297, 298, 300, 302, 304, 311, 313, 315, 317, 359, 360, 390, 392, 396, 405, 407, 428, 430, 436, 438, 442, 444, 456, 485, 613, 625, 627, 682, 753, 760, 784, 802, 810, 814, 820, 825, 827, 829, 831, 835, 837, 893, 909, 915, 917, 918, 937, 941, 949, 959, 961, 973, 977, 1011, 1015, 1023, 1048, 1063,

1094, 1147, 1200, 1227, 1250, 1256, 1301, 1396, 1557, 1635, 1636, 1693, 1699, 1703, 1705, 1707, 1713, 1719, 1720, 1722, 1723, 1725, 1772, 1774, 1778, 1780, 1788, 1796, 1804, 1806, 1812, 1814, 1852, 1937, 1939, 2001, 2015, 2068, 2074, 2075, 2076, 2078, 2080, 2081, 2084, 2087, 2091, 2092, 2094, 2096, 2100, 2102, 2104, 2106, 2108, 2112, 2114, 2143, 2148, 2154, 2156, 2164, 2165, 2219, 2223, 2256, 2299, 2311, 2353, 2382, 2519, 2561, 2590, 2625
STATEBIT: 107, 2072, 2081
STATEFLG: 93, 107, 955, 1001, 1772, 1778, 1780, 1782, 1792, 1794, 1798, 1814, 2011, 2072, 2081
STATEST: 73
STATEXIT: 140, 2684
STBLEORB: 59, 844
STEERBIT: 103, 2072, 2079, 2311, 2382
STEERSW: 93, 103, 347, 1094, 2072, 2079, 2311, 2382, 2441
STIKBIT: 99, 967
STIKFLAG: 93, 99, 339, 423, 915, 967, 969, 1412
STOPRAT: 57, 690
STOREPL: 191
STRKTIME: 206, 1347
STRKTTMP: 206
STROKER: 204, 424, 1367, 1373, 1390
STRULBIT: 117
STRULLSW: 93, 117, 347, 1094
SUBEXIT: 181, 357, 430, 756, 771, 772, 777, 779, 810, 844, 848, 907, 909, 1062a, 1063, 2223, 2256
SUPERBNK: 87, 317, 416, 617, 623, 625, 957, 1541, 1543, 1640, 1654, 1656, 1661, 1663, 1898, 1975, 1977, 2007, 2059
SURFFBIT: 127, 2072, 2094, 2382
SURFFLAG: 93, 127, 360, 448, 814, 816, 1776, 1786, 1805, 2072, 2094, 2132, 2139, 2299, 2359
SVMRKDAT: 232, 304, 977, 979
SW/NDX: 145, 1487, 1513, 1519, 1521
SWBIT: 142, 1635, 1636, 1637a
SWSAMPLE: 163, 281, 282, 284, 285, 288, 412, 1147
SWWORD: 142, 1635, 1636
SXTMARK1: 59, 402
SXTMARKE: 59, 382
SXTOPTN: 191
T-OTHER: 172, 297, 485, 2143
T-TO-ADD: 238, 1806, 1808, 1810
T1: 241, 418, 870, 1033, 1094, 1301, 1475, 1663, 1941, 1943, 1944a
T12: 241, 243, 1301
T1BITS: 218, 1514
T1TOT2: 42, 197, 474, 1063, 2223
T2: 241, 243, 870, 1301, 1475, 1663, 1941, 1943, 1944a, 2363
T2BITS: 216, 1514, 1516

T2TOT3: 42, 244, 474, 1063, 2223
T3TOT4: 38, 185, 456, 1301
T4RUP: 59, 251, 252
T5LOC: 163, 249, 313, 319, 437, 890, 891, 1094, 1347, 1367, 1373, 1412, 1450a, 1475, 1485, 1488, 1492, 1521
T5PHASE: 200, 1094, 1412, 1475
T5TEMP: 200, 1412, 1436, 1441, 1443, 1445, 1453, 1460, 1461, 2514, 2517
T5TIME: 211, 1412, 1453
T5TVCDT: 204, 424, 1347, 1373
T6ADR: 163, 2496
T6LOC: 163, 247, 1396, 1412, 1485
TARG1/2: 191, 739
TARG1BIT: 99
TARG1FLG: 93, 99, 649, 915, 918, 921, 926, 1015, 1147
TARG2BIT: 99
TARG2FLG: 94, 99, 921, 926, 1015, 1147
TARGTIME: 183, 848, 852, 854
TAU: 177, 211, 1412, 1434, 1449, 1450a, 1458, 1460, 1461, 1466, 1469, 1714, 1715, 1729, 1731, 1733, 1765, 1796, 1814, 2045, 2311, 2367
TAU.: 177, 1714, 1715, 1729, 1731, 1733, 1765, 1796, 1814
TAU1: 211, 1412, 1434, 1449, 1450a, 1455, 1466, 1467
TAU2: 211, 1412, 1435, 1449, 1450a, 1456, 1468
TAZEL1: 191, 733, 735
TBASE1: 154, 378, 380, 649, 650, 1902, 1907, 2269
TBASE2: 154, 378, 1802, 2382, 2420
TBASE3: 154, 1894, 1896
TBASE4: 154, 351, 378, 1893, 2269, 2283, 2285
TBASE5: 154, 378, 782, 870, 2382
TBASE6: 154, 1094, 1227, 1487, 2285
TBITS: 216, 1514, 1516
TC: 169, 252, 253, 254, 255, 256, 258, 261, 263, 264, 266, 267, 268, 269, 270, 272, 274, 276, 277, 278, 279, 281, 282, 284, 285, 286, 287, 288, 292, 293a, 309, 311, 313, 315, 317, 319, 321, 323, 325, 329, 331, 333, 335, 337, 339, 341, 343, 345, 347, 349, 351, 364, 378, 380, 382, 384, 386, 389, 392, 394, 396, 397, 398, 400, 402, 403, 405, 407, 408, 409, 410, 411, 412, 414, 416, 417, 418, 419, 420, 421, 423, 424, 425, 426, 428, 430, 431, 432, 433, 434, 436, 437, 438, 440, 442, 444, 446, 448, 452, 481, 487, 495, 496, 497, 498, 499, 501, 503, 519, 521, 523, 525, 527, 529, 531, 533, 535, 537, 539, 541, 543, 544, 547, 549, 551, 553, 555, 557, 559, 561, 563, 565, 567, 568, 569, 571, 573, 575, 577, 579, 581, 583, 585, 587, 589, 590, 591, 593, 595, 596, 597, 599, 601, 603, 605, 607, 609, 611, 612, 613, 615, 617, 619, 621, 623, 625, 627, 629, 630, 631, 633, 635, 637, 638, 639a, 640, 642, 644, 645, 647, 649, 650, 658b, 660, 662, 681a, 684, 686, 688, 689, 690, 691a, 692, 693, 694, 696, 698, 700, 702, 703, 704, 705, 706, 708, 712, 713, 714, 716, 717, 722, 724, 725, 729, 731, 732a, 733, 735, 737, 739, 741, 743, 747, 750, 756, 758, 759, 762, 777, 779, 780, 781, 782, 804, 808, 810, 818, 820, 822, 823, 825, 827, 829, 831, 833, 835, 836, 844, 846, 850, 852, 856,

864, 866, 868, 870, 872, 876, 882, 884, 886, 888, 890, 891, 909, 911, 912, 915, 917, 918, 919, 921, 923, 925, 926, 927, 929, 930, 932, 934, 936, 941, 951, 953, 955, 957, 959, 967, 969, 973, 979, 989, 993, 995, 997, 1013, 1014, 1015, 1017, 1019, 1021, 1023, 1025, 1027, 1029, 1037, 1039, 1042a, 1043, 1045, 1047, 1048, 1062a, 1063, 1094, 1147, 1200, 1227, 1256, 1291, 1297, 1299, 1300a, 1301, 1344, 1347, 1356, 1362, 1367, 1373, 1390, 1410, 1412, 1434, 1441, 1449, 1451, 1477, 1479, 1481, 1483, 1484, 1485, 1486, 1487, 1489, 1491, 1492, 1493, 1495, 1496, 1497, 1498, 1500, 1502, 1504, 1506, 1508, 1510, 1512, 1516, 1518, 1519, 1521, 1528, 1530, 1532, 1538, 1539a, 1540, 1541, 1542, 1543, 1546, 1557, 1559, 1567, 1568, 1569, 1570, 1572, 1573, 1574, 1575, 1576, 1577, 1578a, 1578b, 1579, 1580, 1581, 1582, 1584, 1585, 1588, 1589, 1590, 1591, 1592, 1593, 1594, 1595, 1596, 1598, 1601, 1604b, 1606, 1607, 1608, 1609, 1610, 1612, 1614, 1615, 1616, 1618, 1620, 1621, 1623, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1637a, 1647, 1652, 1653, 1659, 1660, 1661, 1663, 1699, 1701, 1703, 1707, 1714, 1731, 1733, 1735, 1736, 1737, 1740, 1748, 1764, 1765, 1772, 1780, 1782, 1784, 1786, 1788, 1794, 1796, 1802, 1808, 1810, 1812, 1813a, 1814, 1840, 1844, 1852, 1876, 1878, 1880, 1882, 1884, 1886, 1888, 1889, 1891, 1893, 1894, 1896, 1905, 1907, 1909, 1913, 1917, 1918, 1919, 1920, 1921, 1922, 1923, 1924, 1925, 1926, 1927, 1929, 1932, 1934, 1935, 1936, 1937, 1938, 1939, 1940a, 1941, 1943, 1944a, 1945, 1946, 1947, 1950, 1951, 1952, 1953, 1954, 1955, 1956, 1957, 1958, 1959, 1962, 1963, 1965, 1967, 1969, 1971, 1973, 1975, 1977, 1979, 1981, 1983, 1985, 1987, 1989, 1991, 1993, 1995, 1997, 2001, 2007, 2009, 2011, 2013, 2015, 2027, 2035, 2108, 2114, 2116, 2121, 2122, 2123, 2124, 2130, 2132, 2134, 2136, 2137, 2138, 2139, 2141, 2142, 2143, 2148, 2156, 2167, 2177, 2188a, 2189, 2191, 2193, 2195, 2196, 2197, 2198, 2199, 2201, 2203, 2204, 2205, 2209, 2211, 2213, 2217, 2219, 2223, 2256, 2258, 2263, 2265, 2267, 2269, 2271, 2273, 2275, 2277, 2279, 2281, 2283, 2285, 2287, 2289, 2291, 2293, 2295, 2299, 2306, 2311, 2343, 2353, 2359, 2371, 2375, 2377, 2379, 2381, 2382, 2420, 2422, 2424, 2428, 2438, 2443, 2444, 2446, 2448, 2452, 2453, 2454, 2455, 2456, 2457, 2458, 2465, 2467, 2469, 2474, 2475a, 2482, 2484, 2486, 2488, 2490, 2492, 2494, 2495a, 2496, 2499b, 2500, 2502, 2503a, 2505, 2509, 2512, 2513, 2514, 2517, 2518, 2519, 2542, 2561, 2574, 2588, 2590, 2596, 2598, 2599, 2600, 2601, 2605, 2607, 2609, 2611, 2613, 2615, 2617, 2621, 2625, 2641, 2692, 2700, 2749, 2765, 2766

`TCCSM`: 172, 1774, 1776

`TCDH`: 38, 197, 244, 300, 454, 1063, 2223

`TCLEM`: 172

`TCSI`: 38, 197, 454, 1063, 2223

`TDEC`: 131, 157, 747, 1794, 1796, 1798, 1800, 1808, 1810, 1814, 2098

`TDEC2`: 183, 800a, 2223

`TDELTAV`: 169, 485, 1705, 1788, 1792, 1812, 1814, 2143

`TDESIRED`: 188, 788, 1716, 1717, 1752, 1756, 1758, 1767

`TDPOS`: 190

`TDVEL`: 190

`TEM1`: 142, 514, 1610, 1985, 2454, 2455, 2457, 2458

`TEM1B`: 226, 1250, 1256

TEM2: 142, 144, 514, 1844, 2027, 2035, 2446, 2452, 2453, 2456
TEM3: 142, 144, 514, 1844, 2453, 2456
TEM4: 142, 144, 515, 559, 561, 2456
TEM5: 142, 144, 515, 2454, 2455
TEMK: 156, 1483, 1492, 1493, 1521, 1647
TEMP: 140, 142, 144, 152, 169, 179, 191, 221, 229, 257, 258, 269, 325, 407, 452, 512, 514, 515, 525, 531, 591, 611, 619, 621, 640, 642, 788, 925, 945, 965, 969, 985, 995, 1007, 1049, 1063, 1094, 1147, 1227, 1248, 1396, 1502, 1512, 1684, 1695, 1701, 1703, 1804, 1852, 1872, 2015, 2059, 2075, 2219, 2223, 2382, 2478, 2590, 2623
TEMP333: 202, 1362
TEMPADD: 191
TEMPALFA: 223, 1299
TEMPBETA: 223, 1299
TEMPDAP: 200, 1356
TEMPFLSH: 150, 339, 343, 1021, 1959, 1983
TEMPOR1: 161, 937, 953, 977, 989
TEMPR60: 157, 647, 649, 1094, 2293, 2353
TEMPROLL: 223, 1299
TEMPTIME: 191, 706, 2199
TEMPVAR: 161, 1695, 1697
TEMREG: 204, 1396
TEMX: 159, 1227, 2311, 2382
TEMY: 159, 1227, 2311, 2382
TEMZ: 159, 1227, 2311, 2382
TENMDOT: 204, 1347, 1356
TEPHEM: 172, 174, 294, 366, 377, 858, 860, 862, 864, 870, 1195, 1675, 1677, 1684, 2015
TEPHEM1: 161, 862, 864
TERM1TMP: 144, 1844
TERMIBIT: 121
TERMIFLG: 94, 121, 1147
TERRLAMB: 188, 1718, 1756, 1758, 1770
TESTLEAD: 67, 694
TET: 38, 169, 424, 456, 485, 749, 775, 792, 816, 822, 1301, 1774, 1778, 1780, 1788, 1796, 1797, 1798, 1800, 1804, 1810, 1814, 2143, 2299
TET1: 169
TETCSM: 172, 360, 1774, 2015
TETLEM: 172, 2015, 2223
TETOTHER: 172
TETTHIS: 172, 822
TEVENT: 163, 295, 298, 1094, 2273, 2343
TFF: 33, 40, 125, 179, 240, 430, 456, 470, 472, 825, 827, 829, 831, 833, 835, 836, 837, 840a, 860, 1054, 1200, 1256, 1852, 2051, 2092
TFFSW: 94, 125, 1852, 2072, 2092
TFFSWBIT: 125, 2072, 2092

TFI: 33, 185, 899
TFO: 185, 899
TGO: 224, 295, 366, 1094, 2273, 2291, 2343, 2353, 2363, 2365, 2367, 2375, 2377
THETA: 33, 52, 123, 148, 179, 181, 430, 458, 670, 672, 674, 678, 680, 812, 893, 899, 969, 1054, 1056, 1147, 1200, 1248, 1256, 1412, 1680, 1719, 1720, 1837, 1852, 2027, 2091, 2179, 2181, 2185, 2187, 2515, 2574
THETA(1): 179, 181, 1054, 1056
THETAD: 28, 38, 95, 157, 159, 229, 297, 302, 410, 423, 454, 704, 967, 975, 1013, 1094, 1147, 1200, 1839, 1840, 1920, 1921, 2027, 2197
THETADX: 211, 218, 297, 302, 1094, 1412, 1436, 1438
THETADY: 211, 297, 1094, 1412, 1436
THETADZ: 211, 223, 297, 1412, 1436, 1438
THETAH: 229, 302, 1200, 1248, 1254, 1256
THETAN: 194, 866
THETAN1: 196, 727, 729
THETAX: 194
THETAX1: 196, 714, 716, 729
THETZERO: 42, 185, 474, 897
THISAXIS: 73, 812
THISPREC: 73, 428, 745, 806, 825, 829, 831, 1049, 1094
THRUST: 50, 85, 166, 174, 238, 451, 468, 470, 651, 653, 1094, 1227, 1301, 1367, 1508, 1510, 1512, 1804, 2043, 2044, 2045, 2061, 2062, 2079, 2152, 2279, 2306, 2343, 2382, 2440, 2441, 2444, 2445, 2453, 2459, 2496, 2596
TIG: 30, 32, 38, 54, 123, 224, 241, 243, 295, 298, 300, 357, 368, 370, 372, 374, 376, 377, 454, 456, 752, 754, 756, 759, 761, 762, 773, 820, 822, 842, 844, 846, 848, 852, 854, 1043, 1045, 1049, 1052, 1053, 1063, 1094, 1227, 1301, 1810, 2091, 2219, 2223, 2254, 2256, 2260, 2263, 2265, 2267, 2269, 2271, 2273, 2275, 2283, 2285, 2287, 2289, 2299, 2343, 2353
TIME/RTO: 226, 1250, 1256
TIME1: 80, 249, 295, 298, 300, 302, 304, 377, 378, 380, 388, 390, 501, 688, 712, 714, 716, 860, 870, 876, 878, 930, 965, 1094, 1147, 1248, 1487, 1504, 1514, 1521, 1536, 1538, 1663, 1902, 1909, 1941, 1943, 1944a, 1973, 1993, 2015, 2027, 2035, 2114, 2154, 2269, 2285, 2306, 2382, 2420, 2426, 2472, 2474
TIME2: 38, 80, 294, 295, 298, 300, 302, 304, 377, 388, 390, 418, 456, 635, 686, 688, 862, 870, 876, 930, 932, 957, 965, 967, 1094, 1147, 1227, 1248, 1528, 1530, 1663, 1808, 1902, 1913, 1941, 1943, 1944a, 2015, 2027, 2035, 2114, 2134, 2154, 2273, 2275, 2283, 2285, 2287, 2311, 2343, 2382, 2465, 2467
TIME2SAV: 157, 159, 357, 1941, 1944a
TIME3: 80, 309, 325, 1514, 1663
TIME4: 80, 253, 255, 309, 325
TIME5: 80, 247, 309, 325, 890, 891, 1094, 1347, 1367, 1373, 1412, 1453, 1492, 2343, 2382, 2507, 2519, 2574
TIME6: 80, 1396, 1412, 1453, 1477, 1479, 2496, 2507, 2542, 2561
TIMEMO: 175, 1195
TIMER: 194, 2287
TIMRBIT: 123

TIMRFLAG: 94, 123, 1043, 1094
TIMSUBO: 174, 1684
TINT: 185, 236, 842, 846, 848
TINTSOI: 183, 846, 848
TITER: 239, 244, 763, 765, 767
TLIFTOFF: 163, 860, 862, 864, 866, 870
TM: 145, 159, 214, 218, 219, 223, 226, 229, 277, 330, 682, 686, 688, 1200, 1227, 1256, 1487, 1495, 1500, 1506, 1513, 1519, 1521
TMARK: 191, 706, 729, 2199
TMFI: 219, 660, 662, 664, 2169, 2171
TMINDEX: 148, 1524, 1532, 1534, 2461, 2469, 2471
TMIS: 219, 660, 2167
TMODULO: 165, 1715
TMP1: 206, 1373
TMP2: 206, 1373
TMP3: 206, 1373
TMP4: 206, 1373
TMP5: 206, 1373
TMP6: 206, 1373
TNIT: 234, 1094
TNITPREV: 234, 1094
TNUV: 169, 485, 486, 1705, 1788, 1792, 1812, 1814, 2143
TOF-FF: 65, 1852
TOF-FF1: 65, 1852, 2051
TOFF: 216, 1513, 1514, 1516
TOLDAZ1: 196
TOLDAZMT: 196
TON1: 218, 1510, 1512, 1513, 1514, 1516
TON2: 216, 1510, 1512, 1513, 1514, 1516
TORQNDX: 194, 696, 702, 714, 722, 2189, 2196, 2203, 2209, 2211
TPASS4: 236, 244, 300, 754, 759, 761, 771, 773, 852, 1045, 1052, 1053, 1094, 1301, 2256
TPREV: 188, 1718, 1756, 1758, 1770
TRACKBIT: 101, 432, 434, 2072, 2078
TRACKFLG: 94, 101, 434, 756, 762, 820, 844, 852, 915, 917, 955, 1047, 1062a, 1147, 2072, 2078, 2219, 2223
TRANSM1: 181, 182, 720, 2207
TRIPA: 161, 1695, 1697
TRKMKCNT: 157, 313, 754, 761, 779, 842, 850, 852, 915, 945, 951, 1063, 1227, 1301, 1804, 2219, 2223, 2258, 2279, 2353
TRMO3BIT: 101, 741
TRMO3FLG: 94, 101, 398, 737
TRUNA: 191
TRUNBIAS: 165, 929, 1025
TRUNBIT: 97
TRUNFLAG: 94, 97, 1147

TRUNION: 37, 119, 165, 190, 290, 460, 484, 1021, 1025, 1147
TRUNX: 232, 244
TSIGHT: 183, 1147, 2139
TSTART82: 179, 827, 829, 831, 833, 1056, 2148
TSTRT: 239, 762
TTE: 42, 229, 303, 458, 474, 1200, 1254
TTE1: 229, 231, 1200
TTEMP: 219, 686
TTMP1: 204, 208, 1347, 1356, 1373
TTMP2: 204, 208, 1373
TTOGO: 38, 40, 44, 236, 376, 456, 470, 472, 476, 754, 761, 779, 842, 850, 852, 1043, 1063, 1094, 1301, 2219, 2223, 2258, 2265, 2267, 2271, 2285, 2287, 2289, 2363, 2375
TTPI: 236, 238, 300, 456, 754, 756, 758, 759, 769, 895, 899, 901, 909, 911, 1063, 2223
TTPIO: 197, 1063, 2223
TUSED: 214, 1504, 1513, 1514, 1516
TVCEXPHS: 206, 1094, 1356, 1367
TVCPHASE: 204, 1094, 1347, 1367, 1373, 2828
TVCPITCH: 85, 1094, 1367, 1373, 1390
TVCRCS: 202, 209
TVCTMP1: 202
TVCYAW: 85, 1094, 1367, 1373
TX789: 232, 1705, 1707
U2: 188, 1675, 1718, 1721, 1724, 1726, 1745, 1760, 1762, 1767
UBAR0: 232, 1029, 1033
UBAR1: 232, 1029
UBAR2: 232, 1029
UBX/2: 226, 1255a, 1293, 1295
UBY/2: 226, 1255a, 1293, 1295
UBZ/2: 226, 1255a, 1295
UCL: 161, 937, 945
UCLSTAR: 232, 1025
UH/: 243, 1301
ULOS: 183, 763, 770b, 773
UM: 161, 937, 939, 945, 977, 981, 983, 985, 989, 991, 995, 999
UN: 188, 763, 765, 767, 788, 1291, 1616, 1627, 1717, 1721, 1724, 1726, 1745, 1759, 1762, 1767, 1804, 2311
UNI: 226, 1200, 1245, 1256
UNITR: 174, 1200, 1227, 1250, 1256, 1291, 1295
UNITV: 226, 1063, 1250, 1256, 2223
UNITW: 172, 489, 491, 868, 1200, 1227, 1245, 1256, 1291
UNP36: 179, 806
UNRM: 183, 765, 767, 770b, 771, 773, 775, 1051
UNVEC: 244, 1063, 2223
UP1: 197, 1063, 2223

UPBUFF: 145, 148, 294, 302, 1487, 1513, 1521, 2015
UPCOUNT: 145, 302, 2015
UPDATBIT: 101, 959, 2072, 2076
UPDATE1: 67
UPDATE2: 67, 1810, 2015
UPDATFLG: 94, 99, 434, 756, 762, 777, 780, 844, 846, 850, 852, 909, 911, 912, 915, 917, 955, 1045, 1047, 1062a, 1063, 1147, 2072, 2076, 2219, 2223, 2256
UPDATRET: 140, 543, 544
UPLOCBIT: 125, 2072, 2092
UPLOCKFL: 94, 125, 1946, 2072, 2092
UPOLDMOD: 145, 302, 2015
UPSVFLAG: 169, 311, 1812, 1813a
UPTEMP: 145, 2015
UPVERB: 145, 302, 2015
UPVERBSV: 145, 2015
UR1: 188, 241, 1301, 1718, 1721, 1724, 1726, 1727, 1741, 1745, 1759, 1760, 1762, 1767
UR1/: 241, 1301
URH: 226, 1200
URONE: 181, 1200
URRECT: 188, 1715, 1727, 1735, 1736, 1767
US: 185, 937, 1019, 1025, 1029, 1147, 1344, 1528, 2465
USSTAR: 232, 1025
USTAR: 161, 937, 945, 977, 991
UT: 238, 1094
UV1/: 241, 243, 1301
UXA/2: 226, 1200, 1255a, 1256, 1291, 1295
UYA/2: 226, 1200, 1255a, 1291, 1295
UZA/2: 226, 1200, 1255a, 1291, 1295, 1296
V: 28, 33, 37, 52, 121, 154, 161, 172, 179, 224, 229, 236, 241, 297, 331, 390, 405, 418, 420, 438, 442, 456, 458, 460, 485, 486, 508, 510, 512, 527, 635, 637, 638, 640, 642, 678, 710, 749, 752, 753, 754, 760, 761, 762, 773, 777, 795, 802, 804, 806, 820, 822, 827, 829, 833, 842, 844, 850, 854, 858, 868, 882, 909, 919, 930, 941, 963, 965, 969, 971, 983, 991, 993, 1011, 1013, 1045, 1049, 1054, 1056, 1058, 1060, 1063, 1094, 1147, 1200, 1245, 1248, 1250, 1252, 1256, 1291, 1301, 1344, 1486, 1504, 1508, 1510, 1512, 1552, 1554, 1578b, 1580, 1586, 1606, 1607, 1608, 1727, 1814, 1852, 1872, 1874, 1961, 2086, 2087, 2132, 2141, 2143, 2148, 2160, 2162, 2185, 2213, 2219, 2223, 2265, 2299, 2311, 2343, 2353, 2361, 2377, 2382, 2426, 2428, 2478, 2480, 2500, 2519, 2542, 2561, 2588, 2594, 2605, 2609, 2615, 2617, 2619, 2623, 2624, 2625
V(T1)/: 241, 1301
V(T2)/: 241, 1301
V-OTHER: 172, 297, 442, 485, 486, 2143
V1: 145, 458, 858, 901, 1248, 1256, 1301
V2(T1)/: 241, 1301
V37FLAG: 94, 123, 814, 1056, 1227, 2074, 2092, 2382

V37FLBIT: 123, 339, 2011, 2074, 2092
V59FLAG: 94, 113, 347, 392, 927, 929
V59FLBIT: 113
V82FLAGS: 179, 181, 827, 829, 833
V97VCNTR: 200, 372, 1094, 1347, 1356
VAC1: 150
VAC1USE: 150, 327, 330, 384, 1652, 2121
VAC2: 150
VAC2USE: 150, 327, 384, 1652, 2121
VAC3: 150
VAC3USE: 150, 327, 384, 1652, 2121
VAC4: 150
VAC4USE: 150, 327, 384, 1652, 2121
VAC5: 150, 349, 351, 1915
VAC5LOC: 63, 349
VAC5USE: 150, 327, 384, 1652, 2121
VACT1: 244, 1063, 2223
VACT2: 197, 244, 1063, 2223
VACT3: 234, 244, 763, 765, 769, 770b, 772, 773, 800a, 901, 1063, 2223
VACT4: 244, 1063, 2223
VACX: 177
VACY: 177
VACZ: 177
VAPREC: 236, 763, 769
VARIANCE: 166, 182, 232, 945, 947, 951, 953, 977, 991, 1027, 1663, 1693, 1695
VARK: 204, 1347, 1356, 1373
VARST0: 202, 1362
VARST5: 202, 1362
VBARS: 229, 1248, 1256
VBUF: 140, 142, 497, 501, 514, 1553b, 1575, 1576, 1579, 1582, 1584, 1606, 1608, 1610, 1612, 1613, 1844, 2623
VCNTR: 204, 1094, 1347, 1356
VCNTRTMP: 206, 1094, 1356
VCV: 169, 485, 486, 749, 775, 792, 816, 822, 1301, 1705, 1714, 1736, 1765, 1774, 1778, 1788, 1812, 1814, 2143, 2299
VCVCSM: 172, 1035, 1776
VCVLEM: 172
VDISP: 221
VDT/180: 218, 1510, 1512, 1513, 1518
VEARTH: 186, 1147
VECOEM: 175, 1195
VECPT: 67, 651, 653
VECQTEMP: 218, 651, 653, 657
VECTAB: 177, 1814
VEHUPBIT: 99, 2072, 2076
VEHUPFLG: 94, 99, 436, 915, 917, 943, 945, 949, 959, 991, 1027, 1699, 1705,

2072, 2076
VEL: 35, 169, 172, 177, 197, 224, 226, 234, 236, 241, 244, 458, 464, 474, 485, 749, 770b, 771, 814, 858, 949, 965, 1147, 1245, 1248, 1252, 1256, 2047, 2064b, 2103, 2143, 2212, 2353, 2382, 2438
VEL/C: 224, 1147
VERB37: 57, 331, 335, 351, 357
VERBNOUN: 181, 241, 782, 856, 911, 1063, 2223
VERBREG: 152, 329, 333, 398, 508, 523, 525, 527, 531, 537, 539, 541, 543, 544, 547, 591, 595, 607, 619, 629, 1961, 1991
VERBSAVE: 154, 537, 590, 607
VERIFBIT: 125, 2072, 2092
VERIFLAG: 94, 125, 2015, 2072, 2092
VESO: 177, 1025, 1195
VFLAG: 94, 107, 1147, 2072, 2080
VFLAGBIT: 107, 2072, 2080
VG: 33, 37, 54, 103, 231, 234, 238, 244, 456, 460, 754, 761, 1063, 1094, 2079, 2223, 2256, 2311, 2363
VGBODY: 44, 238, 294, 476, 1094, 2343, 2363
VGDISP: 40, 44, 231, 470, 476, 1045, 1049, 1051, 1052, 1053, 1094, 1301, 2256, 2258, 2684
VGPREV: 238, 1094
VGTEMP: 236, 1094
VGTIG: 238, 295, 298, 1094
VHFCNT: 40, 157, 300, 313, 470, 823, 915, 945, 951, 1227, 1301
VHFRANGE: 161, 949, 957, 959
VHFRBIT: 131
VHFRFLAG: 94, 131, 341, 442, 943
VHFTIME: 159, 300, 941, 943, 957
VINIT: 234, 236, 772, 784, 786, 788, 792, 794, 795, 901, 1094, 2219, 2256
VINTFBIT: 109, 2072, 2081
VINTFLAG: 94, 109, 359, 360, 747, 915, 917, 943, 949, 955, 1001, 1780, 1788, 1790, 1792, 1794, 1805, 1814, 2072, 2081
VIO: 35, 42, 226, 229, 303, 458, 474, 1200, 1254
VIPRIME: 234, 236, 759, 786, 790, 792, 793, 850, 901, 907, 1052, 1094, 2258
VL: 35, 42, 229, 458, 474, 961, 969, 1200, 1245, 1247, 1248, 1252, 1254, 1256
VLAUN: 194, 718, 720, 2207, 2209
VLAUNS: 194
VMAGI: 42, 229, 474, 872, 884, 1254, 1299
VMAX: 175, 947, 2382
VMOON: 186, 1147, 2213
VN: 133, 159, 161, 295, 332, 400, 411, 412, 414, 418, 428, 440, 442, 485, 499, 619, 650, 708, 733, 737, 739, 743, 750, 783, 804, 808, 813, 814, 818, 829, 835, 856, 858, 884, 886, 912, 921, 929, 932, 953, 1009, 1014, 1037, 1042a, 1048, 1063, 1094, 1147, 1200, 1227, 1245, 1256, 1291, 1299, 1301, 1344, 1640, 1804, 1805, 1852, 1999, 2000a, 2015, 2098, 2118, 2132, 2141, 2143, 2148, 2201, 2213, 2219, 2223, 2260, 2262, 2263, 2294, 2299, 2311, 2379, 2380, 2382, 2426

VN1: 159, 868, 1200, 1227, 1806, 1808, 2267, 2382
VNSTORE: 241, 1301
VONE: 179, 182, 812, 814, 816, 818, 827, 829, 835, 837, 839, 1200, 1852
VONE': 182, 1852
VPASS1: 244, 1063, 2223
VPASS2: 197, 1063, 2223
VPASS3: 234, 758, 763, 765, 769, 771, 800a, 854, 895, 897, 1063, 2223
VPASS4: 236, 759, 771, 850, 901, 907
VPPREC: 236, 763, 769
VPRED: 35, 42, 229, 231, 300, 303, 458, 472, 1200, 1254, 1301
VRECT: 169, 1714, 1727, 1735, 1736, 1765, 1796, 1812, 1814
VRECT1: 169
VRECTCSM: 172, 1774, 1776, 2353
VRECTLEM: 172
VREF: 159, 1248, 1256
VRPREV: 234, 1094
VS1: 229, 1245, 1248, 1256
VSQ/4API: 216, 1508, 1510
VSQUARE: 226, 1248, 1256
VSUN: 186, 1147
VTARGET: 188, 792, 1717, 1718, 1759, 1767
VTARGTAG: 188, 786, 790, 792, 1717, 1759, 1767
VTEMP: 161, 941
VTIG: 236, 1045, 1049, 1051, 1063, 1094, 2219, 2223, 2256
VTPRIME: 234, 236, 759, 786, 792, 793, 850, 901, 905
VVEC: 188, 759, 790, 797, 798, 854, 897, 903, 907, 1063, 1301, 1717, 1718, 1719, 1721, 1722, 1724, 1725, 1726, 1741, 1743, 1759, 1760, 1763, 1769, 2223
VZC: 232, 1025, 1035
W: 29, 52, 95, 107, 109, 115, 117, 131, 133, 183, 186, 188, 190, 197, 198, 360, 405, 448, 485, 491, 802, 820, 874, 917, 943, 947, 955, 960, 977, 979, 981, 983, 985, 987, 989, 991, 993, 995, 997, 999, 1003, 1005, 1007, 1009, 1015, 1023, 1041, 1094, 1147, 1356, 1449, 1536, 1663, 1693, 1695, 1697, 1699, 1701, 1703, 1746, 1750, 1772, 1774, 1778, 1780, 1788, 1804, 1805, 1808, 1814, 1852, 1893, 2074, 2081, 2086, 2087, 2091, 2098, 2143, 2306, 2382, 2472, 2499b
WAITADR: 138, 1663
WAITBANK: 138, 1663
WAITEXIT: 138, 515, 1663, 2001
WAITTEMP: 138, 1663
WANGI: 194, 696, 2191
WANGO: 194, 696, 2191
WANGT: 194
WBODY: 209, 223, 297, 302, 688, 690, 915, 963, 965, 969, 971, 1412, 1438, 1441
WBODY1: 209, 688, 690, 915, 965, 971, 1412, 1438
WBODY2: 209, 688, 690, 915, 965, 971, 1412, 1438
WDCNT: 142, 597, 599, 601, 603
WDRET: 140, 597, 599, 601, 603

WEIGHT/G: 200, 1094, 1301, 1362
WHOCARES: 244, 357, 368, 1039, 1094, 1977, 2213
WIXA: 161, 1699, 1701, 1703
WIXB: 161, 1699, 1701, 1703
WMIDPOS: 198, 1023, 1041
WMIDVEL: 198, 1041
WORBPOS: 175, 981, 1039
WORBVEL: 175, 981, 1039
WPLATI: 194
WPLATO: 194
WRDRET: 140
WRENDPOS: 175, 943, 1039
WRENDVEL: 175, 943, 1039
WTEMP: 209, 1412, 1443, 1445
WTOPTION: 163, 282, 284, 286, 311
X(T1): 241, 1301
X(T2): 241, 243, 1301
X(T2)PRE: 243, 1301
X1: 85, 481, 678, 722, 735, 758, 767, 790, 797, 810, 818, 848, 897, 901, 903, 907, 909, 937, 939, 945, 969, 971, 991, 1035, 1056, 1058, 1063, 1094, 1147, 1195, 1200, 1227, 1291, 1301, 1550, 1558, 1582, 1623, 1630, 1631, 1632, 1684, 1697, 1709, 1714, 1716, 1719, 1723, 1725, 1729, 1731, 1735, 1738, 1739, 1741, 1744, 1746, 1748, 1750, 1751, 1752, 1754, 1759, 1760, 1763, 1776, 1788, 1790, 1814, 1841, 1852, 2027, 2035, 2130, 2158, 2160, 2185, 2209, 2223, 2311, 2343, 2382
X2: 50, 85, 485, 735, 749, 792, 799, 823, 829, 831, 903, 947, 985, 1063, 1094, 1195, 1200, 1227, 1301, 1344, 1558, 1582, 1623, 1632, 1697, 1701, 1703, 1731, 1735, 1739, 1776, 1812, 1814, 1841, 1844, 1852, 2143, 2158, 2160, 2213, 2223, 2382
X789: 172, 977, 983, 989, 991, 993, 995, 997, 999, 1705, 1707
XANG: 59, 907
XD/360: 216, 1510, 1512
XDC: 186, 874, 878, 880, 1147, 1835, 1841, 1842a
XDELVBIT: 103, 2074, 2079
XDELVFLG: 94, 103, 754, 761, 777, 850, 1047, 1063, 1094, 1301, 2074, 2079, 2219, 2223, 2256, 2258
XDSPBIT: 113, 2074, 2084
XDSPFLAG: 94, 113, 2074, 2084, 2114
XKEP: 169, 188, 1731, 1765, 1767, 1812, 1814
XKEPCSM: 172, 1776
XKEPLEM: 172
XKEPNEW: 177, 1714, 1729, 1814
XMODULO: 165, 1715
XNB: 186, 483, 698, 708, 1147, 1200, 1839, 2027, 2035, 2189, 2201
XNB1: 183, 482, 483, 2027
XNDX1: 209, 1453, 1455, 1456, 1470b

XNDX2: 209, 1453, 1455, 1457, 1474
XOLDBUF: 223, 1227
XPIPBUF: 223, 1227, 1250
XPREV: 188, 1714, 1731, 1736, 1765, 1767
XREG: 38, 152, 454, 512, 521, 525, 529, 531, 551, 571, 577, 587
XREGLP: 152, 521, 525, 533, 577, 587
XRNGERR: 42, 229, 474, 1200, 1254, 1256
XSCD: 224
XSCREF: 148, 1094
XSM: 31, 186, 370, 374, 376, 420, 456, 692, 700, 702, 706, 708, 710, 711, 712, 717, 722, 725, 729, 735, 866, 1147, 1200, 1835, 1839, 1840, 2143, 2193, 2199, 2201, 2202b, 2203, 2204, 2205, 2211
XSMD: 148, 1147
XTRANS: 211, 1094, 1455, 2542
XXXALT: 234, 797, 798
YACTOFF: 40, 198, 295, 298, 472, 1094, 1347, 1356, 1367
YACTTMP: 206, 1356
YCMD: 204, 295, 1347, 1367, 1373
YDC: 186, 874, 878, 880, 1147, 1835, 1836, 1842a
YDELOFF: 204, 1347, 1356, 1373
YERRB: 204, 1347, 1373
YINDEX: 209, 1456, 1457
YMANNDX: 213, 219, 891, 1412, 1434
YNB: 186, 483, 698, 1147, 1200, 1839, 2191, 2311
YNB1: 183, 482, 483
YNDX: 209, 1453, 1455, 1458, 1461, 1471
YOLDBUF: 223, 1227
YPIPBUF: 223, 1227, 1250
YREG: 152, 512, 521, 525, 529, 531, 571, 587
YREGLP: 152, 512, 521, 587
YSCD: 224
YSCREF: 148, 1094
YSM: 186, 725, 1200, 1839
YSMD: 148, 1147
YTMP1: 204, 1373
YTMP2: 204, 1373
YTMP3: 204, 1373
YTMP4: 204, 1373
YTMP5: 204, 1373
YTMP6: 204, 1373
YV: 157, 1814
YWORD1: 200, 1412, 1457, 1474, 1475, 1477
YWORD2: 200, 1412, 1474, 1475, 1479
YZERO: 208
Z: 78, 80, 142, 302, 438, 452, 454, 482, 501, 514, 531, 537, 543, 553, 569, 571, 573, 579, 651, 655, 688, 710, 725, 775, 779, 780, 858, 874, 878, 880, 961, 963,

965, 1011, 1094, 1147, 1200, 1227, 1250, 1373, 1453, 1458, 1460, 1461, 1463, 1465, 1469, 1471, 1473, 1574, 1580, 1581, 1582, 1591, 1595, 1607, 1612, 1618, 1620, 1663, 1699, 1814, 1835, 1836, 1844, 1852, 1868, 1891, 1929, 2011, 2015, 2027, 2052, 2053, 2054, 2055, 2056, 2062, 2063, 2102, 2126, 2128, 2143, 2148, 2152, 2160, 2162, 2164, 2195, 2213, 2275, 2277, 2281, 2289, 2311, 2361, 2363, 2371, 2382, 2420, 2428, 2430, 2440, 2441, 2445, 2448, 2453, 2454, 2512, 2519, 2542, 2596, 2600, 2606
ZDC: 186, 874, 878, 880, 1147, 1835, 1836, 1842a
ZERONDX: 196, 704, 2189, 2197, 2198, 2203
ZERONDX1: 196, 696, 705, 712, 725
ZI: 190, 1693, 1695, 1697, 1699, 1701, 1707, 1709
ZIXA: 161, 1699, 1701, 1703
ZIXB: 161, 1699, 1701, 1703
ZMEASBIT: 95
ZMEASURE: 95, 1023, 1035
ZNB: 186, 483, 484, 698, 710, 1094, 1147, 1200, 1839, 2191, 2445
ZNB1: 183, 482, 483, 484
ZNDX: 209, 1453, 1455, 1458, 1460, 1461, 1471, 1473
ZOLDBUF: 223, 1227
ZONE: 163, 286, 288, 290, 754, 761, 1497, 1508, 1518, 2152, 2154, 2561, 2574, 2588, 2625
ZOPTCNT: 163, 282, 284, 285
ZPIPBUF: 223, 1227, 1250
ZPRIME: 148, 1835, 1836, 2448
ZREG: 152, 512, 521, 525, 529, 531, 537, 571, 589
ZREGLP: 152, 512, 521, 589
ZRUPT: 80, 2519, 2542
ZSCD: 224
ZSCREF: 148, 1094
ZSM: 186, 725, 1200, 1839
ZSMD: 148, 1147
ZV: 157, 1814