

ΕΘΝΙΚΟ ΜΕΤΣΟΒΙΟ ΠΟΛΥΤΕΧΝΕΙΟ

ΣΧΟΛΗ ΗΛΕΚΤΡΟΛΟΓΩΝ ΜΗΧΑΝΙΚΩΝ ΚΑΙ ΜΗΧΑΝΙΚΩΝ ΥΠΟΛΟΓΙΣΤΩΝ ΤΟΜΕΑΣ ΤΕΧΝΟΛΟΓΙΑΣ ΠΛΗΡΟΦΟΡΙΚΗΣ ΚΑΙ ΥΠΟΛΟΓΙΣΤΩΝ ΕΡΓΑΣΤΗΡΙΟ ΜΙΚΡΟΫΠΟΛΟΓΙΣΤΩΝ ΚΑΙ ΨΗΦΙΑΚΩΝ ΣΥΣΤΗΜΑΤΩΝ ΑΚΑΔ. ΕΤΟΣ 2022-2023

Αναφορά

5η ΕΡΓΑΣΤΗΡΙΑΚΗ ΑΣΚΗΣΗ ΓΙΑ ΤΟ ΜΑΘΗΜΑ "Εργαστήριο Μικροϋπολογιστών"

Χρήση εξωτερικών Θυρών Επέκτασης στον ΑVR

Ομάδα 1

Ξανθόπουλος Παναγιώτης (03119084)

Παπαναστάσης Αθανάσιος (03113197)

Ζήτημα 5.1

Στην άσκηση αυτή χρησιμοποιούμε το ολοκληρωμένο επέκτασης θυρών PCA9555. Συνδέουμε με καλώδια τους ακροδέκτες IOO_0 και IOO_1 του κονέκτορα P18 με τους ακροδέκτες LED_PD0 και LED_PD1 του κονέκτορα J18 αντίστοιχα, όπως αναφέρεται στην εκφώνηση.

Στο κύριο πρόγραμμα, θέτουμε την PORTB ως είσοδο ώστε να μπορούμε να βλέπουμε ποια κουμπιά έχουν πατηθεί. Καλούμε την twi_init() ώστε να αρχικοποιήσει το Port Expander στην κατάλληλη ταχύτητα ρολογιού και θέτουμε την θύρα 0 του PCA9555 ως έξοδο.

Στη συνέχεια, σε έναν βρόχο while(1), υπολογίζουμε κάθε φορά το F0 και το F1. Αυτά αποθηκεύονται στο LSB 2 global μεταβλητών F0 και F1. Κάνουμε αριστερή ολίσθηση στο F1, το προσθέτουμε με το F0 και με την συνάρτηση PCA9555_0_write, στέλνουμε το αποτέλεσμα στην θύρα 0. Επειδή έχουμε συνδέσει τα 2 LSB της με τα 2 LED, το αποτέλεσμα φαίνεται στα LED.

(Σημείωση: Όταν πατάμε κάποιο κουμπί, θεωρούμε ότι η αντίστοιχη μεταβλητή γίνεται 1. Αντιστρέφουμε το PINB κάθε φορά ώστε να ακυρώσουμε την αντίστροφη λογική των κουμπιών.)

```
#define F_CPU 1600000UL
#include<avr/io.h>
#include<avr/interrupt.h>
#include<util/delay.h>
#define PCA9555_0_ADDRESS 0x40 //A0=A1=A2=0 by hardware
#define TWI READ 1 // reading from twi device
#define TWI WRITE 0 // writing to twi device
#define SCL CLOCK 100000L // twi clock in Hz
//Fscl=Fcpu/(16+2*TWBR0 VALUE*PRESCALER VALUE)
#define TWBRO_VALUE ((F_CPU/SCL_CLOCK)-16)/2
// PCA9555 REGISTERS
typedef enum {
 REG INPUT 0 = 0,
 REG_INPUT_1 = 1,
 REG_OUTPUT_0 = 2,
 REG_OUTPUT_1 = 3,
 REG_POLARITY_INV_0 = 4,
 REG POLARITY INV 1 = 5,
 REG CONFIGURATION 0 = 6,
 REG CONFIGURATION 1 = 7,
} PCA9555 REGISTERS;
//----- Master Transmitter/Receiver -----
#define TW_START 0x08
#define TW REP START 0x10
```

```
//----- Master Transmitter -----
#define TW MT SLA ACK 0x18
#define TW_MT_SLA_NACK 0x20
#define TW_MT_DATA_ACK 0x28
//----- Master Receiver -----
#define TW MR SLA ACK 0x40
#define TW MR SLA NACK 0x48
#define TW_MR_DATA_NACK 0x58
#define TW_STATUS_MASK 0b11111000
#define TW_STATUS (TWSR0 & TW_STATUS_MASK)
//initialize TWI clock
void twi_init(void)
  TWSR0 = 0; // PRESCALER_VALUE=1
  TWBR0 = TWBR0_VALUE; // SCL_CLOCK 100KHz
// Read one byte from the twi device (request more data from device)
unsigned char twi readAck(void)
  TWCR0 = (1<<TWINT) | (1<<TWEN) | (1<<TWEA);
 while(!(TWCR0 & (1<<TWINT)));
  return TWDR0;
// Read one byte from the twi device (dont request more data from device)
unsigned char twi_readNak(void)
  TWCR0 = (1<<TWINT) | (1<<TWEN);
  while(!(TWCR0 & (1<<TWINT)));
  return TWDR0;
}
// Issues a start condition and sends address and transfer direction.
// return 0 = device accessible, 1= failed to access device
unsigned char twi_start(unsigned char address)
{
  uint8_t twi_status;
  // send START condition
  TWCR0 = (1<<TWINT) | (1<<TWSTA) | (1<<TWEN);
  // wait until transmission completed
  while(!(TWCR0 & (1<<TWINT)));
  // check value of TWI Status Register.
  twi_status = TW_STATUS & 0xF8;
  if ( (twi_status != TW_START) && (twi_status != TW_REP_START)) return 1;
  // send device address
  TWDR0 = address;
  TWCR0 = (1<<TWINT) | (1<<TWEN);
```

```
// wail until transmission completed and ACK/NACK has been received
  while(!(TWCR0 & (1<<TWINT)));
  // check value of TWI Status Register.
  twi_status = TW_STATUS & 0xF8;
  if ( (twi_status != TW_MT_SLA_ACK) && (twi_status != TW_MR_SLA_ACK) )
    return 1;
  return 0;
// Send start condition, address, transfer direction.
// Use ack polling to wait until device is ready
void twi_start_wait(unsigned char address)
  uint8_t twi_status;
  while (1)
    // send START condition
    TWCR0 = (1<<TWINT) | (1<<TWSTA) | (1<<TWEN);
    // wait until transmission completed
    while(!(TWCR0 & (1<<TWINT)));
    // check value of TWI Status Register.
    twi status = TW STATUS & 0xF8;
    if ( (twi_status != TW_START) && (twi_status != TW_REP_START)) continue;
    // send device address
    TWDR0 = address;
    TWCR0 = (1<<TWINT) | (1<<TWEN);
    // wail until transmission completed
    while(!(TWCR0 & (1<<TWINT)));
    // check value of TWI Status Register.
    twi status = TW STATUS & 0xF8;
    if ( (twi_status == TW_MT_SLA_NACK ) | | (twi_status == TW_MR_DATA_NACK) )
      /* device busy, send stop condition to terminate write operation */
      TWCR0 = (1<<TWINT) | (1<<TWEN) | (1<<TWSTO);
      // wait until stop condition is executed and bus released
      while(TWCR0 & (1<<TWSTO));
      continue;
    break;
// Send one byte to twi device, Return 0 if write successful or 1 if write failed
unsigned char twi_write( unsigned char data )
  // send data to the previously addressed device
  TWDR0 = data;
  TWCR0 = (1<<TWINT) | (1<<TWEN);
  // wait until transmission completed
  while(!(TWCR0 & (1<<TWINT)));
  if( (TW_STATUS & 0xF8) != TW_MT_DATA_ACK) return 1;
  return 0;
}
```

```
// Send repeated start condition, address, transfer direction
//Return: 0 device accessible
// 1 failed to access device
unsigned char twi_rep_start(unsigned char address)
  return twi start( address );
}
// Terminates the data transfer and releases the twi bus
void twi_stop(void)
{
  // send stop condition
  TWCR0 = (1<<TWINT) | (1<<TWEN) | (1<<TWSTO);
  // wait until stop condition is executed and bus released
  while(TWCR0 & (1<<TWSTO));
void PCA9555_0_write(PCA9555_REGISTERS reg, uint8_t value)
  twi_start_wait(PCA9555_0_ADDRESS + TWI_WRITE);
  twi_write(reg);
  twi_write(value);
  twi_stop();
uint8_t PCA9555_0_read(PCA9555_REGISTERS reg)
  uint8_t ret_val;
  twi_start_wait(PCA9555_0_ADDRESS + TWI_WRITE);
  twi_write(reg);
  twi_rep_start(PCA9555_0_ADDRESS + TWI_READ);
  ret val = twi readNak();
  twi_stop();
  return ret_val;
static volatile uint8_t A;
static volatile uint8 tB;
static volatile uint8 t C;
static volatile uint8 t D;
static volatile uint8_t F0;
static volatile uint8_t F1;
// if a button is pressed, it is represented by logical 1
// for the outputs, logical 1 is represented by LED
void computeF0(void) {
  A = (^{PINB}) \& 0x01;
  B = ((^{\sim}PINB) \& 0x02) >> 1;
  C = ((^{\sim}PINB) \& 0x04) >> 2;
  D = ((\sim PINB) \& 0x08) >> 3;
  uint8 t notA = ^{\sim}A;
  uint8_t notB = ^B;
  uint8 t help1 = notA & B;
  uint8_t help2 = notB & C & D;
  F0 = ^(help1 \mid help2);
}
```

```
void computeF1(void) {
  // A,B,C,D have already been read because computeF1 is always called after computeF0
  // also, if the buttons change between the calls, we don't want inconsistent values between F0 and
F1
  uint8 t help1 = A \& C;
  uint8 t help2 = B \mid D;
  F1 = help1 & help2;
}
int main(void) {
  DDRB = 0x00;
  twi init():
  PCA9555_0_write(REG_CONFIGURATION_0, 0x00); //Set EXT_PORT0 as output
  while(1)
  {
    computeF0();
    computeF1();
    F0 \&= 0x01;
    F1 \&= 0x01;
    F1 = F1 << 1;
    uint8 t F = F0 \mid F1;
    PCA9555_0_write(REG_OUTPUT_0, F);
//
      _delay_ms(100);
 }
}
```

Ζήτημα 5.2

Στην άσκηση αυτή, συνδέουμε με καλώδια τους ακροδέκτες IOO_0 έως IOO_3 του κονέκτορα P18 με τους ακροδέκτες LED_PD0 έως LED_PD3 του κονέκτορα J18 αντίστοιχα, όπως αναφέρεται στην εκφώνηση.

Στο κυρίως πρόγραμμα, αρχικά καλούμε την συνάρτηση αρχικοποίησης twi_init(). Στη συνέχεια, ορίζουμε τη θύρα επέκτασης 0 ως έξοδο, και από τη θύρα 1 τους ακροδέκτες IO1_0 έως IO1_3 ως εξόδους, ενώ τους ακροδέκτες IO1_4 έως IO1_7 ως εισόδους.

Σε έναν βρόχο while(1), αρχικά στέλνουμε 0 στην θύρα 1 του PCA. Αυτό σημαίνει ότι οι ακροδέκτες που ορίστηκαν ως έξοδοι, θα βγάζουν λογικό 0. Όταν πατηθεί κάποιο κουμπί, ο αντίστοιχος ακροδέκτης εκ των IO1_4 έως IO1_7 θα γίνει 0. Οπότε, διαβάζουμε την θύρα 1. Αν έχει πατηθεί το κουμπί «*», θα λάβουμε την τιμή 1110 XXXX (τα X αντιστοιχούν στους ακροδέκτες εξόδου). Κάνουμε OR με το 0x0F ώστε τα X να γίνουν 1, παίρνουμε το συμπλήρωμα (γιατί τα LED δε λειτουργούν με αντίστροφη λογική), κάνουμε 4 shift right (ώστε τα 4 MSB ηα έρθουν στα 4 LSB) και δίνουμε το αποτέλεσμα στην έξοδο. Επειδή έχουμε συνδέσει τα καλώδια, το αποτέλεσμα φαίνεται στα LED_PD0 έως LED_PD3.

```
#define F CPU 1600000UL
#include<avr/io.h>
#include<avr/interrupt.h>
#include<util/delay.h>
#define PCA9555 0 ADDRESS 0x40 //A0=A1=A2=0 by hardware
#define TWI READ 1 // reading from twi device
#define TWI_WRITE 0 // writing to twi device
#define SCL_CLOCK 100000L // twi clock in Hz
//Fscl=Fcpu/(16+2*TWBR0_VALUE*PRESCALER_VALUE)
#define TWBR0_VALUE ((F_CPU/SCL_CLOCK)-16)/2
// PCA9555 REGISTERS
typedef enum {
 REG_INPUT_0 = 0,
 REG_INPUT_1 = 1,
 REG_OUTPUT_0 = 2,
 REG_OUTPUT_1 = 3,
 REG POLARITY INV 0 = 4,
 REG_POLARITY_INV_1 = 5,
 REG CONFIGURATION 0 = 6,
 REG_CONFIGURATION_1 = 7,
} PCA9555_REGISTERS;
//----- Master Transmitter/Receiver -----
#define TW START 0x08
#define TW_REP_START 0x10
//----- Master Transmitter -----
#define TW_MT_SLA_ACK 0x18
#define TW MT SLA NACK 0x20
#define TW_MT_DATA_ACK 0x28
//----- Master Receiver -----
#define TW MR SLA ACK 0x40
#define TW_MR_SLA_NACK 0x48
#define TW_MR_DATA_NACK 0x58
#define TW STATUS MASK 0b11111000
#define TW_STATUS (TWSRO & TW_STATUS_MASK)
//initialize TWI clock
void twi_init(void)
 TWSR0 = 0; // PRESCALER VALUE=1
 TWBR0 = TWBR0_VALUE; // SCL_CLOCK 100KHz
// Read one byte from the twi device (request more data from device)
unsigned char twi_readAck(void)
 TWCR0 = (1<<TWINT) | (1<<TWEN) | (1<<TWEA);
 while(!(TWCR0 & (1<<TWINT)));
 return TWDR0;
}
```

```
// Read one byte from the twi device (dont request more data from device)
unsigned char twi readNak(void)
{
  TWCR0 = (1<<TWINT) | (1<<TWEN);
  while(!(TWCR0 & (1<<TWINT)));
  return TWDR0;
// Issues a start condition and sends address and transfer direction.
// return 0 = device accessible, 1= failed to access device
unsigned char twi_start(unsigned char address)
{
  uint8 t twi status;
  // send START condition
  TWCR0 = (1<<TWINT) | (1<<TWSTA) | (1<<TWEN);
  // wait until transmission completed
  while(!(TWCR0 & (1<<TWINT)));
  // check value of TWI Status Register.
  twi_status = TW_STATUS & 0xF8;
  if ( (twi_status != TW_START) && (twi_status != TW_REP_START)) return 1;
  // send device address
  TWDR0 = address;
  TWCR0 = (1<<TWINT) | (1<<TWEN);
  // wail until transmission completed and ACK/NACK has been received
  while(!(TWCR0 & (1<<TWINT)));
  // check value of TWI Status Register.
  twi status = TW STATUS & 0xF8;
  if ( (twi_status != TW_MT_SLA_ACK) && (twi_status != TW_MR_SLA_ACK) )
    return 1;
  }
  return 0;
// Send start condition, address, transfer direction.
// Use ack polling to wait until device is ready
void twi_start_wait(unsigned char address)
  uint8_t twi_status;
  while (1)
  {
    // send START condition
    TWCR0 = (1<<TWINT) | (1<<TWSTA) | (1<<TWEN);
    // wait until transmission completed
    while(!(TWCR0 & (1<<TWINT)));
    // check value of TWI Status Register.
    twi status = TW STATUS & 0xF8;
    if ( (twi_status != TW_START) && (twi_status != TW_REP_START)) continue;
    // send device address
    TWDR0 = address;
    TWCR0 = (1<<TWINT) | (1<<TWEN);
```

```
// wait until transmission completed
    while(!(TWCR0 & (1<<TWINT)));
    // check value of TWI Status Register.
    twi_status = TW_STATUS & 0xF8;
    if ( (twi_status != TW_START) && (twi_status != TW_REP_START)) continue;
    // send device address
    TWDR0 = address;
    TWCR0 = (1<<TWINT) | (1<<TWEN);
    // wail until transmission completed
    while(!(TWCR0 & (1<<TWINT)));
    // check value of TWI Status Register.
    twi_status = TW_STATUS & 0xF8;
    if ((twi status == TW MT SLA NACK)||(twi status == TW MR DATA NACK))
      /* device busy, send stop condition to terminate write operation */
      TWCR0 = (1<<TWINT) | (1<<TWEN) | (1<<TWSTO);
      // wait until stop condition is executed and bus released
      while(TWCR0 & (1<<TWSTO));
      continue;
    break;
}
// Send one byte to twi device, Return 0 if write successful or 1 if write failed
unsigned char twi write( unsigned char data )
  // send data to the previously addressed device
  TWDR0 = data;
  TWCR0 = (1<<TWINT) | (1<<TWEN);
  // wait until transmission completed
  while(!(TWCR0 & (1<<TWINT)));
  if( (TW STATUS & 0xF8) != TW MT DATA ACK) return 1;
  return 0;
}
// Send repeated start condition, address, transfer direction
//Return: 0 device accessible
// 1 failed to access device
unsigned char twi_rep_start(unsigned char address)
  return twi_start( address );
// Terminates the data transfer and releases the twi bus
void twi stop(void)
  // send stop condition
  TWCR0 = (1<<TWINT) | (1<<TWEN) | (1<<TWSTO);
  // wait until stop condition is executed and bus released
  while(TWCR0 & (1<<TWSTO));
```

```
void PCA9555 0 write(PCA9555 REGISTERS reg, uint8 t value)
  twi_start_wait(PCA9555_0_ADDRESS + TWI_WRITE);
  twi_write(reg);
  twi_write(value);
  twi_stop();
uint8_t PCA9555_0_read(PCA9555_REGISTERS reg)
  uint8_t ret_val;
  twi_start_wait(PCA9555_0_ADDRESS + TWI_WRITE);
  twi_write(reg);
  twi_rep_start(PCA9555_0_ADDRESS + TWI_READ);
  ret_val = twi_readNak();
  twi_stop();
  return ret_val;
int main(void) {
  twi_init();
  PCA9555_0_write(REG_CONFIGURATION_0, 0x00);
  PCA9555_0_write(REG_CONFIGURATION_1, 0xF0);
// PCA9555_0_write(REG_OUTPUT_0, 0x00);
  while(1) {
    PCA9555_0_write(REG_OUTPUT_1, 0x00);
    uint8_t temp = (0x0F | PCA9555_0_read(REG_INPUT_1));
    temp = ~temp;
    temp = (temp >> 4);
    PCA9555_0_write(REG_OUTPUT_0, temp);
  }
}
```