Kinematic controller

Generated by Doxygen 1.9.8

1 Namespace Index	1
1.1 Namespace List	. 1
2 Hierarchical Index	3
2.1 Class Hierarchy	. 3
3 Data Structure Index	5
3.1 Data Structures	. 5
4 File Index	7
4.1 File List	. 7
5 Namespace Documentation	9
5.1 commands Namespace Reference	. 9
5.1.1 Variable Documentation	. 9
5.1.1.1 CLOSE_GRIPPER	. 9
5.1.1.2 EMPTY	. 9
5.1.1.3 HOME_GRIPPER	. 9
5.1.1.4 HOME_PRESSER	. 10
5.1.1.5 NEW_TEST	. 10
5.1.1.6 PREPARE_PRESSING	. 10
5.1.1.7 PRESS_ALLERGEN	. 10
5.1.1.8 RESPONSE	. 10
5.2 communication Namespace Reference	. 10
5.2.1 Variable Documentation	. 11
5.2.1.1 com_test	. 11
5.2.1.2 SERIAL_COMMUNICATION_UNKNOWN_RESPONSE_ERROR_MSG	. 11
5.3 gui Namespace Reference	. 11
5.3.1 Variable Documentation	. 11
5.3.1.1 test	
5.4 main Namespace Reference	. 11
5.4.1 Function Documentation	. 12
5.4.1.1 communication_multi_thread()	. 12
5.4.2 Variable Documentation	. 12
5.4.2.1 ALLERGEN_AMOUNT	. 12
5.4.2.2 BOTH	. 12
5.4.2.3 END_EFFECTOR_TILT_PLACE	. 12
5.4.2.4 END_EFFECTOR_TILT_TAKE	
5.4.2.5 main	
5.4.2.6 PATCH_TEST_CORNER_COORDINATES	
5.4.2.7 performing_command	
5.4.2.8 SIMULATING	
5.4.2.9 SPEED	
5.4.2.10 STORAGE_OFFSET_X	
5.112.10 5.10.11.0251.10E1_X	0

5.4.2.11 STRINGE_COORDINATES	. 14
5.4.2.12 SYRINGE_MOVEMENT_Z	. 14
5.4.2.13 SYRINGE_OFFSET_X	. 14
5.4.2.14 Z_OFFSET	. 14
5.5 robot_controller Namespace Reference	. 14
5.6 robot_movement Namespace Reference	. 14
5.6.1 Function Documentation	. 15
5.6.1.1 best_end_joint()	. 15
5.6.1.2 get_rot_x_matrix()	. 16
5.6.1.3 get_rot_y_matrix()	. 16
5.6.1.4 get_rot_z_matrix()	. 17
5.6.1.5 joint_matrix()	. 17
5.6.1.6 orientation_degree_to_radians()	. 18
5.6.1.7 radians_to_degree()	. 18
5.6.1.8 radians_to_degree_list()	. 18
5.6.1.9 transform_list_into_range()	. 19
5.6.2 Variable Documentation	. 19
5.6.2.1 COORDINATE_SYNTAX_ERROR_MSG	. 19
5.6.2.2 INVALID_TIME_INCREASE_ERROR_MSG	. 19
5.6.2.3 JOINT_SYNTAX_ERROR_MSG	. 19
5.6.2.4 MAX_ANGLE_LINK_1_5	. 20
5.6.2.5 MAX_ANGLE_LINK_6	. 20
5.6.2.6 MIN_ANGLE_LINK_1_5	. 20
5.6.2.7 MIN_ANGLE_LINK_6	. 20
5.6.2.8 MOVE_NOT_POSSIBLE_ERROR_MSG	. 20
5.6.2.9 robot_cartesian_position	. 20
5.6.2.10 robot_joint_position	. 20
5.6.2.11 TAKES_ONLY_TWO_COORDINATES_ERROR_MSG	. 21
5.7 test Namespace Reference	. 21
5.7.1 Function Documentation	. 21
5.7.1.1 mySqrt()	. 21
5.7.2 Variable Documentation	. 22
5.7.2.1 testVal	. 22
6 Data Structure Documentation	23
6.1 communication.CommunicationProtocol Class Reference	
6.1.1 Detailed Description	
6.1.2 Constructor & Destructor Documentation	
6.1.2.1init()	
6.1.3 Member Function Documentation	
6.1.3.1 send_command()	
6.1.4 Field Documentation	
Control Documentation Control	. 47

6.1.4.1 baudrate	24
6.1.4.2 com	24
6.1.4.3 connection	24
6.1.4.4 timeout	24
6.2 communication.SerialCommunicationUnknownResponse Class Reference	25
6.2.1 Detailed Description	25
6.3 gui.GUI Class Reference	26
6.3.1 Detailed Description	26
6.3.2 Constructor & Destructor Documentation	26
6.3.2.1init()	26
6.3.3 Member Function Documentation	27
6.3.3.1 both_pressed()	27
6.3.3.2 robot_pressed()	27
6.3.3.3 run()	27
6.3.3.4 simulation_pressed()	28
6.3.3.5 start_pressed()	28
6.3.3.6 stop_pressed()	28
6.3.3.7 stop_pressed_init()	29
6.3.4 Field Documentation	29
6.3.4.1 button_SELECT_BOTH	29
6.3.4.2 button_SELECT_ROBOT	29
6.3.4.3 button_SELECT_SIMULATION	29
6.3.4.4 button_START	30
6.3.4.5 button_STOP	30
6.3.4.6 light_SELECT_BOTH	30
6.3.4.7 light_SELECT_ROBOT	30
6.3.4.8 light_SELECT_SIMULATION	30
6.3.4.9 mode	30
6.3.4.10 pressed_buttons	31
6.3.4.11 root	31
6.3.4.12 running	31
6.3.4.13 title	31
6.4 gui.Light Class Reference	32
6.4.1 Detailed Description	32
6.4.2 Constructor & Destructor Documentation	33
6.4.2.1init()	33
6.4.3 Member Function Documentation	33
6.4.3.1 turn_off()	33
6.4.3.2 turn_on()	33
6.4.3.3 turn_ready()	33
6.4.4 Field Documentation	34
6.4.4.1 oval id	34

6.5 main.Main Class Reference	34
6.5.1 Detailed Description	34
6.5.2 Constructor & Destructor Documentation	34
6.5.2.1init()	34
6.5.3 Member Function Documentation	35
6.5.3.1 create_gui()	35
6.5.3.2 dispense_allergen()	35
6.5.3.3 place_allergen()	35
6.5.3.4 run()	36
6.5.3.5 set_mode()	37
6.5.3.6 take_allergen()	38
6.5.4 Field Documentation	38
6.5.4.1 communication	38
6.5.4.2 gui	38
6.5.4.3 gui_created	38
6.5.4.4 gui_thread	39
6.5.4.5 patch_test_config	39
6.5.4.6 robot	39
6.6 robot_controller.RobotControllerSettings Class Reference	39
6.6.1 Detailed Description	39
6.6.2 Constructor & Destructor Documentation	40
6.6.2.1init()	40
6.6.3 Field Documentation	40
6.6.3.1 dh_values	40
6.6.3.2 linear_frequency	40
6.6.3.3 update_frequency	40
6.7 robot_movement.CoordinateSyntaxError Class Reference	41
6.7.1 Detailed Description	41
6.8 robot_movement.InvalidTimeIncrease Class Reference	42
6.8.1 Detailed Description	42
6.8.2 Field Documentation	43
6.8.2.1 suppress	43
6.9 robot_movement.JointSyntaxError Class Reference	43
6.9.1 Detailed Description	44
6.10 robot_movement.Kinematics Class Reference	44
6.10.1 Detailed Description	45
6.10.2 Constructor & Destructor Documentation	45
6.10.2.1init()	45
6.10.3 Member Function Documentation	45
6.10.3.1 get_joint_values()	45
6.10.3.2 kin_calculate_theta_1()	46
6.10.3.3 kin_calculate_theta_2_3()	47

6.10.3.4 kin_calculate_theta_4()	48
6.10.3.5 kin_calculate_theta_5()	48
6.10.3.6 kin_calculate_theta_6()	49
6.10.4 Field Documentation	49
6.10.4.1 dh_value_a	49
6.10.4.2 dh_value_alpha	49
6.10.4.3 dh_value_d	49
6.10.4.4 dh_value_theta	50
6.10.4.5 robot_controller_settings	50
6.11 robot_movement.MoveJ Class Reference	50
6.11.1 Detailed Description	51
6.11.2 Constructor & Destructor Documentation	51
6.11.2.1init()	51
6.11.3 Member Function Documentation	52
6.11.3.1 convert_coordinates_to_joint_movements()	52
6.11.3.2 move_joint()	53
6.11.4 Field Documentation	53
6.11.4.1 joint_matrix	53
6.11.4.2 pos_w_time	53
6.11.4.3 robot	54
6.11.4.4 start_joint_values	54
6.12 robot_movement.MoveL Class Reference	54
6.12.1 Detailed Description	56
6.12.2 Constructor & Destructor Documentation	56
6.12.2.1init()	56
6.12.3 Member Function Documentation	56
6.12.3.1 get_linear_via_points()	56
6.12.4 Field Documentation	57
6.12.4.1 move_time	57
6.12.4.2 pos_w_time	57
6.12.4.3 pos_w_time_linear	57
6.12.4.4 robot	57
6.12.4.5 start_pos_cartesian	57
6.13 robot_movement.MoveNotPossible Class Reference	58
6.13.1 Detailed Description	58
6.14 robot_movement.Robot Class Reference	58
6.14.1 Detailed Description	59
6.14.2 Constructor & Destructor Documentation	59
6.14.2.1init()	59
6.14.3 Member Function Documentation	59
6.14.3.1 set_joints()	59
6.14.4 Field Documentation	60

Index	87
7.14 test.py	84
7.13 test.py File Reference	84
7.12 robot_movement.py	75
7.11 robot_movement.py File Reference	74
7.10 robot_controller.py	73
7.9 robot_controller.py File Reference	73
7.8 main.py	70
7.7 main.py File Reference	69
7.6 gui.py	67
7.5 gui.py File Reference	66
7.4 communication.py	66
7.3 communication.py File Reference	65
7.2 commands.py	65
7.1 commands.py File Reference	65
7 File Documentation	65
6.17.1 Detailed Description	64
6.17 robot_movement.TakesOnlyTwoCoordinates Class Reference	63
6.16.4.2 robo_link	63
6.16.4.1 rdk_link	63
6.16.4 Field Documentation	63
6.16.3.1 set_joints()	62
6.16.3 Member Function Documentation	62
6.16.2.1init()	62
6.16.2 Constructor & Destructor Documentation	62
6.16.1 Detailed Description	62
6.16 robot_movement.RobotMyCobotAndSim Class Reference	62
6.15.4.1 robo_link	61
6.15.4 Field Documentation	61
6.15.3.1 set_joints()	61
6.15.3 Member Function Documentation	61
6.15.2.1init()	61
6.15.2 Constructor & Destructor Documentation	61
6.15.1 Detailed Description	61
6.15 robot_movement.RobotMyCobot Class Reference	60
6.14.4.5 time_between_move	60
6.14.4.4 robot_settings	60
6.14.4.3 rdk_link	60
6.14.4.2 prev_position	60
6.14.4.1 max_joint_speed	60

# **Namespace Index**

## 1.1 Namespace List

Here is a list of all namespaces with brief descriptions:

commands	 																	. 9
communication	 																	. 10
gui	 																	. 11
main	 																	. 11
robot_controller	 																	. 14
robot_movement .	 																	. 14
test	 																	. 21

2 Namespace Index

## **Hierarchical Index**

## 2.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

Canvas	
gui.Light	32
communication.CommunicationProtocol	23
Exception	
communication.SerialCommunicationUnknownResponse	25
robot_movement.CoordinateSyntaxError	41
robot_movement.InvalidTimeIncrease	42
robot_movement.JointSyntaxError	43
robot_movement.MoveNotPossible	58
robot_movement.TakesOnlyTwoCoordinates	63
gui.GUI	26
main.Main	34
robot_controller.RobotControllerSettings	39
robot_movement.Kinematics	44
robot movement.MoveJ	50
robot movement.MoveL	
robot movement.Robot	
robot_movement.RobotMyCobot	
robot_movement.RobotMyCobotAndSim	
1000L HOVEHIEHL.NODOLIVIV-ODOLAHGƏHL	02

4 Hierarchical Index

## **Data Structure Index**

### 3.1 Data Structures

Here are the data structures with brief descriptions:

communication.CommunicationProtocol .		 	 23
communication.SerialCommunicationUnkner	ownResponse	 	 25
gui.GUI			26
gui.Light		 	 32
main.Main		 	 34
robot_controller.RobotControllerSettings .		 	 39
$robot\_movement. Coordinate Syntax Error \ .$			41
robot_movement.InvalidTimeIncrease		 	 42
robot_movement.JointSyntaxError			43
robot_movement.Kinematics		 	 44
robot_movement.MoveJ			50
robot_movement.MoveL			54
robot_movement.MoveNotPossible		 	 58
robot_movement.Robot		 	 58
robot_movement.RobotMyCobot		 	 60
$robot\_movement. Robot My Cobot And Sim \ .$		 	 62
robot movement. Takes Only Two Coordinate	es	 	 63

6 Data Structure Index

## **File Index**

### 4.1 File List

Here is a list of all files with brief descriptions:

commands.py																					65
communication.py .																					65
gui.py																					66
main.py																					69
robot_controller.py																					73
robot_movement.py																					74
test.pv																					. 84

8 File Index

## **Namespace Documentation**

### 5.1 commands Namespace Reference

#### **Variables**

```
str HOME_GRIPPER = "home -g"
str CLOSE_GRIPPER = "close"
str HOME_PRESSER = "home -p"
str PREPARE_PRESSING = "prepare pressing"
str PRESS_ALLERGEN = "press -"
str NEW_TEST = "new test"
str RESPONSE = "b'Done"
str EMPTY = "b""
```

#### 5.1.1 Variable Documentation

#### 5.1.1.1 CLOSE\_GRIPPER

```
str commands.CLOSE_GRIPPER = "close"
Definition at line 2 of file commands.py.
```

#### 5.1.1.2 EMPTY

```
str commands.EMPTY = "b''"
```

Definition at line 11 of file commands.py.

#### 5.1.1.3 HOME\_GRIPPER

```
str commands.HOME_GRIPPER = "home -g"
```

Definition at line 1 of file commands.py.

#### 5.1.1.4 HOME\_PRESSER

```
str commands.HOME_PRESSER = "home -p"
```

Definition at line 4 of file commands.py.

#### 5.1.1.5 NEW\_TEST

```
str commands.NEW_TEST = "new test"
```

Definition at line 8 of file commands.py.

#### 5.1.1.6 PREPARE\_PRESSING

```
str commands.PREPARE_PRESSING = "prepare pressing"
```

Definition at line 5 of file commands.py.

#### 5.1.1.7 PRESS\_ALLERGEN

```
str commands.PRESS_ALLERGEN = "press -"
```

Definition at line 6 of file commands.py.

#### **5.1.1.8 RESPONSE**

```
str commands.RESPONSE = "b'Done'"
```

Definition at line 10 of file commands.py.

## 5.2 communication Namespace Reference

#### **Data Structures**

- · class CommunicationProtocol
- · class SerialCommunicationUnknownResponse

#### **Variables**

- str SERIAL\_COMMUNICATION\_UNKNOWN\_RESPONSE\_ERROR\_MSG = "SerialCommunication ← UnknownResponse: The received serial response was not valid."
- com\_test = CommunicationProtocol("COM3", 9600, 0.1)

#### 5.2.1 Variable Documentation

#### 5.2.1.1 com test

```
communication.com_test = CommunicationProtocol("COM3", 9600, 0.1)
```

Definition at line 40 of file communication.py.

#### 5.2.1.2 SERIAL\_COMMUNICATION\_UNKNOWN\_RESPONSE\_ERROR\_MSG

```
str communication. SERIAL\_COMMUNICATION\_UNKNOWN\_RESPONSE\_ERROR\_MSG = "SerialCommunication \leftarrow UnknownResponse: The received serial response was not valid."
```

Definition at line 6 of file communication.py.

### 5.3 gui Namespace Reference

#### **Data Structures**

- class GUI
- class Light

#### **Variables**

• test = GUI()

#### 5.3.1 Variable Documentation

#### 5.3.1.1 test

```
gui.test = GUI()
```

Definition at line 198 of file gui.py.

### 5.4 main Namespace Reference

#### **Data Structures**

• class Main

#### **Functions**

• communication\_multi\_thread (communicator, command)

#### **Variables**

```
• bool BOTH = True
```

- bool SIMULATING = False
- int Z\_OFFSET = 0
- int STORAGE\_OFFSET\_X = 30
- int SYRINGE OFFSET X = -18
- int SYRINGE\_MOVEMENT\_Z = 25
- int SPEED = 1/0.5
- ALLERGEN\_AMOUNT = str(150)
- int END\_EFFECTOR\_TILT\_TAKE = 85
- int END EFFECTOR TILT PLACE = 89
- list PATCH TEST CORNER COORDINATES = [-215, -265, 215]
- list SYRINGE\_COORDINATES
- bool performing\_command = False
- main = Main()

#### 5.4.1 Function Documentation

#### 5.4.1.1 communication multi thread()

Executes a command on the arduino using multi\_threading :param communicator: instance of the communication class :param command: command to execute.

Definition at line 46 of file main.py.

#### 5.4.2 Variable Documentation

#### 5.4.2.1 ALLERGEN AMOUNT

```
main.ALLERGEN_AMOUNT = str(150)
```

Definition at line 21 of file main.py.

#### 5.4.2.2 BOTH

```
bool main.BOTH = True
```

Definition at line 14 of file main.py.

#### 5.4.2.3 END\_EFFECTOR\_TILT\_PLACE

```
int main.END_EFFECTOR_TILT_PLACE = 89
```

Definition at line 23 of file main.py.

#### 5.4.2.4 END\_EFFECTOR\_TILT\_TAKE

```
int main.END_EFFECTOR_TILT_TAKE = 85
```

Definition at line 22 of file main.py.

#### 5.4.2.5 main

```
main.main = Main()
```

Definition at line 250 of file main.py.

#### 5.4.2.6 PATCH\_TEST\_CORNER\_COORDINATES

```
list main.PATCH_TEST_CORNER_COORDINATES = [-215, -265, 215]
```

Definition at line 26 of file main.py.

#### 5.4.2.7 performing\_command

bool main.performing\_command = False

Definition at line 43 of file main.py.

#### 5.4.2.8 SIMULATING

```
bool main.SIMULATING = False
```

Definition at line 15 of file main.py.

#### 5.4.2.9 SPEED

```
int main.SPEED = 1/0.5
```

Definition at line 20 of file main.py.

#### 5.4.2.10 STORAGE\_OFFSET\_X

```
int main.STORAGE_OFFSET_X = 30
```

Definition at line 17 of file main.py.

#### 5.4.2.11 SYRINGE\_COORDINATES

list main.SYRINGE\_COORDINATES

#### Initial value:

Definition at line 29 of file main.py.

#### 5.4.2.12 SYRINGE\_MOVEMENT\_Z

```
int main.SYRINGE_MOVEMENT_Z = 25
```

Definition at line 19 of file main.py.

#### 5.4.2.13 SYRINGE\_OFFSET\_X

```
int main.SYRINGE_OFFSET_X = -18
```

Definition at line 18 of file main.py.

#### 5.4.2.14 Z\_OFFSET

```
int main.Z_OFFSET = 0
```

Definition at line 16 of file main.py.

### 5.5 robot\_controller Namespace Reference

#### **Data Structures**

· class RobotControllerSettings

### 5.6 robot movement Namespace Reference

#### **Data Structures**

- class CoordinateSyntaxError
- · class InvalidTimeIncrease
- class JointSyntaxError
- class Kinematics
- · class MoveJ
- · class MoveL
- class MoveNotPossible
- class Robot
- class RobotMyCobot
- class RobotMyCobotAndSim
- · class TakesOnlyTwoCoordinates

#### **Functions**

- joint\_matrix (alpha, a, d, theta)
- get\_rot\_x\_matrix (angle)
- get rot y matrix (angle)
- get\_rot\_z\_matrix (angle)
- · orientation\_degree\_to\_radians (orientation)
- radians\_to\_degree (angle)
- radians\_to\_degree\_list (list\_radians)
- transform list into range (untransformed list, min value, max value, adjuster)
- best end joint (current joint, joints)

#### **Variables**

- int MIN\_ANGLE\_LINK\_1\_5 = -165 / 180 \* m.pi
- int MAX\_ANGLE\_LINK\_1\_5 = 165 / 180 \* m.pi
- int MIN ANGLE LINK 6 = -175 / 180 \* m.pi
- int MAX ANGLE LINK 6 = 175 / 180 \* m.pi
- str MOVE\_NOT\_POSSIBLE\_ERROR\_MSG = "MoveNotPossible: The given movement command can not be
  executed by the program. Please make sure that it dies not result in a singularity"
- str JOINT\_SYNTAX\_ERROR\_MSG = "JointSyntaxError: The syntax must be [Joint1, joint2, joint3, joint4, joint5, joint6] for a joint"
- str TAKES\_ONLY\_TWO\_COORDINATES\_ERROR\_MSG = "TakesOnlyTwoCoordinates: This class takes only two coordinates."
- str COORDINATE\_SYNTAX\_ERROR\_MSG = "CoordinateSyntaxError: The syntax must be: [x, y, z, alpha, beta, gamma, time] for a coordinate."
- str INVALID\_TIME\_INCREASE\_ERROR\_MSG = "InvalidTimeIncrease: Later coordinates must have a higher time than those before or the robot will not be able to move to the given point."
- list robot\_joint\_position = [107.38158881112184, 46.157985403753784, 103.3563681945703, 30. ← 485646401675925, 107.38158881112184, 135.0]
- list robot\_cartesian\_position = [280, 132, 74, -90, 135, -90]

#### 5.6.1 Function Documentation

#### 5.6.1.1 best end joint()

Takes the current joint position and a list containing of possible joint positions and returns the closest positions current\_joint: The current position of the robots joint.
:param joints: The possible joint positions for a point.
:return: The closest joint position to the current joint position

Definition at line 195 of file robot\_movement.py.

Referenced by robot\_movement.MoveJ.convert\_coordinates\_to\_joint\_movements().



#### 5.6.1.2 get\_rot\_x\_matrix()

Definition at line 91 of file robot\_movement.py.

Referenced by robot\_movement.Kinematics.get\_joint\_values().

Here is the caller graph for this function:



#### 5.6.1.3 get\_rot\_y\_matrix()

Definition at line 105 of file robot\_movement.py.

Referenced by robot\_movement.Kinematics.get\_joint\_values().



#### 5.6.1.4 get\_rot\_z\_matrix()

Definition at line 119 of file robot\_movement.py.

Referenced by robot\_movement.Kinematics.get\_joint\_values().

Here is the caller graph for this function:



#### 5.6.1.5 joint\_matrix()

Definition at line 73 of file robot movement.py.

Referenced by robot\_movement.Kinematics.get\_joint\_values(), and robot\_movement.Kinematics.kin\_calculate\_theta\_1().



#### 5.6.1.6 orientation\_degree\_to\_radians()

Definition at line 133 of file robot\_movement.py.

Referenced by robot movement. Kinematics.get joint values().

Here is the caller graph for this function:



#### 5.6.1.7 radians\_to\_degree()

Definition at line 145 of file robot\_movement.py.

#### 5.6.1.8 radians\_to\_degree\_list()

Definition at line 156 of file robot\_movement.py.

Referenced by robot\_movement.Kinematics.get\_joint\_values().



robot\_movement.transform\_list\_into\_range (

#### 5.6.1.9 transform\_list\_into\_range()

```
untransformed_list,
    min_value,
    max_value,
    adjuster)

Takes a list containing angles and checks if they are in a given range.
:param untransformed_list: List containing angles
:param min_value: Min value in range
:param max_value: Max value in range
:param adjuster: How much the values may be adjusted
:return: Transformed list. Some of the elements may have been changed to False if the given value is not in the
```

Definition at line 170 of file robot movement.py.

Referenced by robot\_movement.Kinematics.get\_joint\_values().

Here is the caller graph for this function:



#### 5.6.2 Variable Documentation

#### 5.6.2.1 COORDINATE\_SYNTAX\_ERROR\_MSG

```
 str\ robot\_movement.COORDINATE\_SYNTAX\_ERROR\_MSG = "CoordinateSyntaxError: The \ syntax \ must \ be: \\ [x, y, z, alpha, beta, gamma, time] \ for a \ coordinate."
```

Definition at line 17 of file robot\_movement.py.

#### 5.6.2.2 INVALID\_TIME\_INCREASE\_ERROR\_MSG

str robot\_movement.INVALID\_TIME\_INCREASE\_ERROR\_MSG = "InvalidTimeIncrease: Later coordinates must have a higher time than those before or the robot will not be able to move to the given point."

Definition at line 18 of file robot movement.py.

#### 5.6.2.3 JOINT\_SYNTAX\_ERROR\_MSG

```
str robot_movement.JOINT_SYNTAX_ERROR_MSG = "JointSyntaxError: The syntax must be [Joint1,
joint2, joint3, joint4, joint5, joint6] for a joint"
```

Definition at line 15 of file robot\_movement.py.

#### 5.6.2.4 MAX\_ANGLE\_LINK\_1\_5

```
int robot_movement.MAX_ANGLE_LINK_1_5 = 165 / 180 * m.pi
```

Definition at line 10 of file robot\_movement.py.

#### 5.6.2.5 MAX\_ANGLE\_LINK\_6

```
int robot_movement.MAX_ANGLE_LINK_6 = 175 / 180 * m.pi
```

Definition at line 12 of file robot\_movement.py.

#### 5.6.2.6 MIN\_ANGLE\_LINK\_1\_5

```
int robot_movement.MIN_ANGLE_LINK_1_5 = -165 / 180 * m.pi
```

Definition at line 9 of file robot movement.py.

#### 5.6.2.7 MIN ANGLE LINK 6

```
int robot_movement.MIN_ANGLE_LINK_6 = -175 / 180 * m.pi
```

Definition at line 11 of file robot\_movement.py.

#### 5.6.2.8 MOVE\_NOT\_POSSIBLE\_ERROR\_MSG

str robot\_movement.MOVE\_NOT\_POSSIBLE\_ERROR\_MSG = "MoveNotPossible: The given movement command can not be executed by the program. Please make sure that it dies not result in a singularity"

Definition at line 14 of file robot movement.py.

#### 5.6.2.9 robot\_cartesian\_position

```
list robot_movement.robot_cartesian_position = [280, 132, 74, -90, 135, -90]
```

Definition at line 22 of file robot movement.py.

#### 5.6.2.10 robot\_joint\_position

```
list robot_movement.robot_joint_position = [107.38158881112184, 46.157985403753784, 103.↔ 3563681945703, 30.485646401675925, 107.38158881112184, 135.0]
```

Definition at line 21 of file robot\_movement.py.

#### 5.6.2.11 TAKES\_ONLY\_TWO\_COORDINATES\_ERROR\_MSG

```
\verb| str robot_movement.TAKES_ONLY_TWO_COORDINATES_ERROR_MSG = "TakesOnlyTwoCoordinates: This class takes only two coordinates." \\
```

Definition at line 16 of file robot\_movement.py.

### 5.7 test Namespace Reference

#### **Functions**

• mySqrt (number, guess, step, tol)

#### **Variables**

• int testVal = 9

#### 5.7.1 Function Documentation

#### 5.7.1.1 mySqrt()

Definition at line 1 of file test.py.

References mySqrt().

Referenced by mySqrt().

Here is the call graph for this function:





### 5.7.2 Variable Documentation

#### 5.7.2.1 testVal

```
int test.testVal = 9
```

Definition at line 24 of file test.py.

## **Data Structure Documentation**

### 6.1 communication.CommunicationProtocol Class Reference

#### **Public Member Functions**

- \_\_init\_\_ (self, com, baudrate, timeout)
- send\_command (self, command)

#### **Data Fields**

- com
- baudrate
- timeout
- connection

#### 6.1.1 Detailed Description

Definition at line 18 of file communication.py.

#### 6.1.2 Constructor & Destructor Documentation

Definition at line 19 of file communication.py.

#### 6.1.3 Member Function Documentation

#### 6.1.3.1 send\_command()

```
\begin{tabular}{ll} communication. Communication Protocol. send\_command ( \\ self, \\ command ) \end{tabular}
```

Definition at line 25 of file communication.py.

References communication.CommunicationProtocol.connection.

#### 6.1.4 Field Documentation

#### 6.1.4.1 baudrate

communication.CommunicationProtocol.baudrate

Definition at line 21 of file communication.py.

#### 6.1.4.2 com

communication.CommunicationProtocol.com

Definition at line 20 of file communication.py.

#### 6.1.4.3 connection

communication.CommunicationProtocol.connection

Definition at line 23 of file communication.py.

 $Referenced \ by \ communication. Communication Protocol. send\_command ().$ 

#### 6.1.4.4 timeout

communication.CommunicationProtocol.timeout


Definition at line 22 of file communication.py.

The documentation for this class was generated from the following file:


· communication.py

# 6.2 communication.SerialCommunicationUnknownResponse Class Reference

Inheritance diagram for communication. Serial Communication Unknown Response:



Collaboration diagram for communication. Serial Communication Unknown Response:



#### 6.2.1 Detailed Description

Used for error handling. Also the reason for the inheritance of Exception. The following error is described as SerialCommunicationUnknownResponse: The received serial response was not valid.

Definition at line 9 of file communication.py.

The documentation for this class was generated from the following file:

· communication.py

### 6.3 gui.GUI Class Reference

#### **Public Member Functions**

- \_\_init\_\_ (self)
- start pressed (self)
- stop\_pressed\_init (self)
- stop\_pressed (self)
- robot\_pressed (self)
- simulation\_pressed (self)
- both\_pressed (self)
- run (self)

#### **Data Fields**

- root
- pressed\_buttons
- mode
- running
- button START
- button STOP
- button\_SELECT\_ROBOT
- button\_SELECT\_SIMULATION
- button\_SELECT\_BOTH
- light\_SELECT\_ROBOT
- light\_SELECT\_SIMULATION
- light\_SELECT\_BOTH
- title

#### 6.3.1 Detailed Description

```
Main class for the GUI
```

Definition at line 36 of file gui.py.

#### 6.3.2 Constructor & Destructor Documentation

#### 6.3.2.1 \_\_init\_\_()

Definition at line 40 of file gui.py.

#### 6.3.3 Member Function Documentation

#### 6.3.3.1 both\_pressed()

```
gui.GUI.both_pressed ( self \ ) Button method for when clicking on the 'Execute program on robot and in simulation'
```

Definition at line 174 of file gui.py.

References gui.GUI.button\_SELECT\_BOTH, gui.GUI.button\_SELECT\_ROBOT, gui.GUI.button\_SELECT\_SIMULATION, gui.GUI.button\_START, gui.GUI.button\_STOP, gui.GUI.light\_SELECT\_BOTH, gui.GUI.light\_SELECT\_ROBOT, gui.GUI.light\_SELECT\_SIMULATION, and gui.GUI.pressed\_buttons.

#### 6.3.3.2 robot pressed()

```
gui.GUI.robot_pressed ( self \ ) Button method for when clicking on the 'Execute program on robot'
```

Definition at line 142 of file gui.py.

References gui.GUI.button\_SELECT\_BOTH, gui.GUI.button\_SELECT\_ROBOT, gui.GUI.button\_SELECT\_SIMULATION, gui.GUI.button\_START, gui.GUI.button\_STOP, gui.GUI.light\_SELECT\_BOTH, gui.GUI.light\_SELECT\_ROBOT, gui.GUI.light\_SELECT\_SIMULATION, and gui.GUI.pressed\_buttons.

#### 6.3.3.3 run()

```
gui.GUI.run ( self\ ) Runs the program
```

Definition at line 190 of file gui.py.

References gui.GUI.root.

Referenced by main.Main.set mode().



#### 6.3.3.4 simulation\_pressed()

```
gui.GUI.simulation_pressed ( self \ ) Button method for when clicking on the 'Execute program in simulation'
```

Definition at line 158 of file gui.py.

References gui.GUI.button\_SELECT\_BOTH, gui.GUI.button\_SELECT\_ROBOT, gui.GUI.button\_SELECT\_SIMULATION, gui.GUI.button\_START, gui.GUI.button\_STOP, gui.GUI.light\_SELECT\_BOTH, gui.GUI.light\_SELECT\_ROBOT, gui.GUI.light\_SELECT\_SIMULATION, and gui.GUI.pressed buttons.

#### 6.3.3.5 start\_pressed()

```
gui.GUI.start_pressed ( self \; ) Button method for when clicking on the start button
```

Definition at line 79 of file gui.py.

References gui.GUI.button\_SELECT\_BOTH, gui.GUI.button\_SELECT\_ROBOT, gui.GUI.button\_SELECT\_SIMULATION, gui.GUI.button\_START, gui.GUI.button\_STOP, gui.GUI.light\_SELECT\_BOTH, gui.GUI.light\_SELECT\_ROBOT, gui.GUI.light\_SELECT\_SIMULATION, gui.GUI.mode, gui.GUI.pressed\_buttons, and gui.GUI.running.

#### 6.3.3.6 stop\_pressed()

```
gui.GUI.stop_pressed ( self )
```

Button method for when the program has run the stop command and the buttons should be clickable again.

Definition at line 132 of file gui.py.

References gui.GUI.button\_SELECT\_BOTH, gui.GUI.button\_SELECT\_ROBOT, gui.GUI.button\_SELECT\_SIMULATION, gui.GUI.button\_START, and gui.GUI.button\_STOP.

Referenced by gui.GUI.stop\_pressed\_init().



### 6.3.3.7 stop\_pressed\_init()

```
gui.GUI.stop_pressed_init ( self \ ) Button method for when clicking on the stop button
```

Definition at line 109 of file gui.py.

References gui.GUI.button\_SELECT\_BOTH, gui.GUI.button\_SELECT\_ROBOT, gui.GUI.button\_SELECT\_SIMULATION, gui.GUI.button\_START, gui.GUI.button\_STOP, gui.GUI.light\_SELECT\_BOTH, gui.GUI.light\_SELECT\_ROBOT, gui.GUI.light\_SELECT\_SIMULATION, gui.GUI.mode, gui.GUI.pressed\_buttons, gui.GUI.running, and gui.GUI.stop\_pressed().

Here is the call graph for this function:



#### 6.3.4 Field Documentation

### 6.3.4.1 button\_SELECT\_BOTH

```
gui.GUI.button_SELECT_BOTH
```

Definition at line 58 of file gui.py.

Referenced by gui.GUI.both\_pressed(), gui.GUI.robot\_pressed(), gui.GUI.simulation\_pressed(), gui.GUI.start\_pressed(), gui.GUI.stop\_pressed(), and gui.GUI.stop\_pressed\_init().

## 6.3.4.2 button\_SELECT\_ROBOT

```
gui.GUI.button_SELECT_ROBOT
```

Definition at line 54 of file gui.py.

Referenced by gui.GUI.both\_pressed(), gui.GUI.robot\_pressed(), gui.GUI.simulation\_pressed(), gui.GUI.start\_pressed(), gui.GUI.stop\_pressed(), and gui.GUI.stop\_pressed\_init().

# 6.3.4.3 button\_SELECT\_SIMULATION

```
gui.GUI.button_SELECT_SIMULATION
```

Definition at line 56 of file gui.py.

Referenced by gui.GUI.both\_pressed(), gui.GUI.robot\_pressed(), gui.GUI.simulation\_pressed(), gui.GUI.start\_pressed(), gui.GUI.stop\_pressed(), and gui.GUI.stop\_pressed\_init().

## 6.3.4.4 button\_START

gui.GUI.button\_START

Definition at line 50 of file gui.py.

Referenced by gui.GUI.both\_pressed(), gui.GUI.robot\_pressed(), gui.GUI.simulation\_pressed(), gui.GUI.start\_pressed(), gui.GUI.stop\_pressed(), and gui.GUI.stop\_pressed\_init().

#### 6.3.4.5 button\_STOP

gui.GUI.button\_STOP

Definition at line 52 of file gui.py.

Referenced by gui.GUI.both\_pressed(), gui.GUI.robot\_pressed(), gui.GUI.simulation\_pressed(), gui.GUI.start\_pressed(), gui.GUI.stop\_pressed(), and gui.GUI.stop\_pressed\_init().

#### 6.3.4.6 light SELECT BOTH

gui.GUI.light\_SELECT\_BOTH

Definition at line 73 of file gui.py.

Referenced by gui.GUI.both\_pressed(), gui.GUI.robot\_pressed(), gui.GUI.simulation\_pressed(), gui.GUI.start\_pressed(), and gui.GUI.stop\_pressed\_init().

## 6.3.4.7 light\_SELECT\_ROBOT

gui.GUI.light\_SELECT\_ROBOT

Definition at line 67 of file gui.py.

# 6.3.4.8 light\_SELECT\_SIMULATION

gui.GUI.light\_SELECT\_SIMULATION

Definition at line 70 of file gui.py.

Referenced by gui.GUI.both\_pressed(), gui.GUI.robot\_pressed(), gui.GUI.simulation\_pressed(), gui.GUI.start\_pressed(), and gui.GUI.stop\_pressed\_init().

### 6.3.4.9 mode

gui.GUI.mode

Definition at line 47 of file gui.py.

Referenced by gui.GUI.start\_pressed(), and gui.GUI.stop\_pressed\_init().

## 6.3.4.10 pressed\_buttons

```
gui.GUI.pressed_buttons
```

Definition at line 45 of file gui.py.

Referenced by gui.GUI.both\_pressed(), gui.GUI.robot\_pressed(), gui.GUI.simulation\_pressed(), gui.GUI.start\_pressed(), and gui.GUI.stop\_pressed\_init().

#### 6.3.4.11 root

```
gui.GUI.root
```

Definition at line 44 of file gui.py.

Referenced by gui.GUI.run().

# 6.3.4.12 running

```
gui.GUI.running
```

Definition at line 48 of file gui.py.

Referenced by gui.GUI.start\_pressed(), and gui.GUI.stop\_pressed\_init().

# 6.3.4.13 title

```
gui.GUI.title
```


Definition at line 76 of file gui.py.

The documentation for this class was generated from the following file:


gui.py

# 6.4 gui.Light Class Reference

Inheritance diagram for gui.Light:



Collaboration diagram for gui.Light:



## **Public Member Functions**

- \_\_init\_\_ (self, master, \*\*kwargs)
- turn\_on (self)
- turn\_off (self)
- turn\_ready (self)

# **Data Fields**

oval\_id

# 6.4.1 Detailed Description

Class to construct an  $\operatorname{oval}$  element in the  $\operatorname{GUI}$ 

Definition at line 4 of file gui.py.

# 6.4.2 Constructor & Destructor Documentation

# 6.4.2.1 \_\_init\_\_()

Definition at line 8 of file gui.py.

# 6.4.3 Member Function Documentation

# 6.4.3.1 turn\_off()

```
gui.Light.turn_off ( self \; ) Changes the color of the oval to gray
```

Definition at line 23 of file gui.py.

References gui.Light.oval\_id.

# 6.4.3.2 turn\_on()

```
gui.Light.turn_on ( self \; ) Changes the color of the oval to green
```

Definition at line 17 of file gui.py.

References gui.Light.oval\_id.

# 6.4.3.3 turn\_ready()

```
gui.Light.turn_ready ( self \ ) Changes the color of the oval to red
```

Definition at line 29 of file gui.py.

References gui.Light.oval\_id.

# 6.4.4 Field Documentation

#### 6.4.4.1 oval id

```
gui.Light.oval_id
```

Definition at line 15 of file gui.py.

Referenced by gui.Light.turn\_off(), gui.Light.turn\_on(), and gui.Light.turn\_ready().

The documentation for this class was generated from the following file:

• gui.py

# 6.5 main.Main Class Reference

#### **Public Member Functions**

- \_\_init\_\_ (self)
- create\_gui (self)
- set mode (self, mode)
- run (self)
- dispense\_allergen (self, index)
- take\_allergen (self, index)
- place\_allergen (self, index)

### **Data Fields**

- · communication
- · patch\_test\_config
- robot
- gui\_created
- gui\_thread
- gui

# 6.5.1 Detailed Description

```
Main class containing the whole program.
```

Definition at line 59 of file main.py.

# 6.5.2 Constructor & Destructor Documentation

# 6.5.2.1 \_\_init\_\_()

Connecting to ROBODK or MyCobot.

Definition at line 63 of file main.py.

# 6.5.3 Member Function Documentation

## 6.5.3.1 create\_gui()

```
main.Main.create_gui ( self \ ) Creates the GUI
```

Definition at line 90 of file main.py.

## 6.5.3.2 dispense\_allergen()

Definition at line 171 of file main.py.

 $References\ main. Main. communication,\ main. Main. robot\_movement. Move J. robot\_move J. robot\_movement. Move J. robot\_move J. ro$ 

Referenced by main.Main.run().

Here is the caller graph for this function:



### 6.5.3.3 place allergen()

Definition at line 224 of file main.py.

References main.Main.communication, main.Main.robot, robot\_movement.MoveJ.robot, and robot\_movement.MoveL.robot.

Referenced by main.Main.run().

Here is the caller graph for this function:



## 6.5.3.4 run()


Runs the whole program sequence

Definition at line 131 of file main.py.

References main.Main.communication, main.Main.dispense\_allergen(), main.Main.gui, main.Main.patch\_test\_config, main.Main.place\_allergen(), main.Main.robot, robot\_movement.MoveJ.robot, robot\_movement.MoveL.robot, main.Main.set\_mode(), and main.Main.take\_allergen().

Referenced by main.Main.set\_mode().

Here is the call graph for this function:



Here is the caller graph for this function:




# 6.5.3.5 set\_mode()

Definition at line 100 of file main.py.

References main.Main.robot, robot\_movement.MoveJ.robot, robot\_movement.MoveL.robot, gui.GUI.run(), and main.Main.run().

Referenced by main.Main.run().

Here is the call graph for this function:



Here is the caller graph for this function:



## 6.5.3.6 take\_allergen()

Definition at line 195 of file main.py.

References main.Main.communication, main.Main.robot, robot\_movement.MoveJ.robot, and robot\_movement.MoveL.robot.

Referenced by main.Main.run().

Here is the caller graph for this function:



## 6.5.4 Field Documentation

#### 6.5.4.1 communication

main.Main.communication

Definition at line 67 of file main.py.

Referenced by main.Main.dispense\_allergen(), main.Main.place\_allergen(), main.Main.run(), and main.Main.take\_allergen().

## 6.5.4.2 gui

main.Main.gui

Definition at line 94 of file main.py.

Referenced by main.Main.run().

## 6.5.4.3 gui\_created

main.Main.gui\_created

Definition at line 78 of file main.py.

#### 6.5.4.4 gui\_thread

main.Main.gui\_thread

Definition at line 79 of file main.py.

# 6.5.4.5 patch\_test\_config

main.Main.patch\_test\_config

Definition at line 70 of file main.py.

Referenced by main.Main.run().

#### 6.5.4.6 robot

main.Main.robot

Definition at line 76 of file main.py.

Referenced by main.Main.dispense\_allergen(), robot\_movement.MoveJ.move\_joint(), main.Main.place\_allergen(), main.Main.run(), main.Main.set mode(), and main.Main.take allergen().

The documentation for this class was generated from the following file:

• main.py

# 6.6 robot\_controller.RobotControllerSettings Class Reference

## **Public Member Functions**

\_\_init\_\_ (self)

# **Data Fields**

- · update frequency
- linear\_frequency
- · dh\_values

# 6.6.1 Detailed Description

Robot controller settings class

Definition at line 4 of file robot\_controller.py.

# 6.6.2 Constructor & Destructor Documentation

# 6.6.2.1 \_\_init\_\_()

```
{\tt robot\_controller.RobotControllerSettings.\_init\_\_\ (} {\tt self\ )} Settings for the robot controller
```

Definition at line 8 of file robot\_controller.py.

## 6.6.3 Field Documentation

## 6.6.3.1 dh\_values

```
{\tt robot\_controller.RobotControllerSettings.dh\_values}
```

Definition at line 15 of file robot\_controller.py.

# 6.6.3.2 linear\_frequency

```
robot_controller.RobotControllerSettings.linear_frequency
```

Definition at line 13 of file robot\_controller.py.

## 6.6.3.3 update\_frequency

```
robot_controller.RobotControllerSettings.update_frequency
```


Definition at line 12 of file robot\_controller.py.

The documentation for this class was generated from the following file:


robot\_controller.py

# 6.7 robot\_movement.CoordinateSyntaxError Class Reference

 $Inheritance\ diagram\ for\ robot\_movement. Coordinate Syntax Error:$ 



Collaboration diagram for robot\_movement.CoordinateSyntaxError:



# 6.7.1 Detailed Description

Used for error handling. Also the reason for the inheritance of Exception. The following error is described as CoordinateSyntaxError: The syntax must be: [x, y, z, alpha, beta, gamma, time] for a coordinate.


Definition at line 52 of file robot\_movement.py.

The documentation for this class was generated from the following file:


robot\_movement.py

# 6.8 robot\_movement.InvalidTimeIncrease Class Reference

 $Inheritance\ diagram\ for\ robot\_movement. Invalid Time Increase:$ 



Collaboration diagram for robot\_movement.InvalidTimeIncrease:



## **Static Public Attributes**

suppress

# 6.8.1 Detailed Description

Used for error handling. Also the reason for the inheritance of Exception. The following error is described as InvalidTimeIncrease: Later coordinates must have a higher time than those before or the robot will not be able

Definition at line 61 of file robot\_movement.py.

# 6.8.2 Field Documentation

## **6.8.2.1 suppress**

robot\_movement.InvalidTimeIncrease.suppress [static]


Definition at line 70 of file robot\_movement.py.

The documentation for this class was generated from the following file:


robot\_movement.py

# 6.9 robot\_movement.JointSyntaxError Class Reference

Inheritance diagram for robot\_movement.JointSyntaxError:



Collaboration diagram for robot\_movement.JointSyntaxError:



# 6.9.1 Detailed Description

Used for error handling. Also the reason for the inheritance of Exception. The following error is described as JointSyntaxError: The syntax must be [Joint1, joint2, joint3, joint4, joint5, joint6] for a joint


Definition at line 34 of file robot\_movement.py.

The documentation for this class was generated from the following file:

robot movement.py

# 6.10 robot\_movement.Kinematics Class Reference

Inheritance diagram for robot\_movement.Kinematics:



## **Public Member Functions**

- \_\_init\_\_ (self)
- get\_joint\_values (self, coordinate, orientation)
- kin\_calculate\_theta\_1 (self, T\_link0\_link6)
- kin\_calculate\_theta\_2\_3 (self, T\_link2\_link3)
- kin\_calculate\_theta\_4 (self, rot\_matrix, theta\_5)
- kin\_calculate\_theta\_5 (self, rot\_matrix)
- kin\_calculate\_theta\_6 (self, rot\_matrix, theta\_5)

## **Data Fields**

- robot\_controller\_settings
- dh\_value\_alpha
- dh\_value\_a
- dh\_value\_d
- dh\_value\_theta

# 6.10.1 Detailed Description

```
Class to compute the inverse kinematics.
```

Definition at line 221 of file robot\_movement.py.

#### 6.10.2 Constructor & Destructor Documentation

## 6.10.2.1 \_\_init\_\_()

Reimplemented in robot\_movement.MoveJ, and robot\_movement.MoveL.

Definition at line 225 of file robot\_movement.py.

#### 6.10.3 Member Function Documentation


#### 6.10.3.1 get joint values()

Definition at line 235 of file robot movement.py.

References robot\_movement.Kinematics.dh\_value\_a, robot\_movement.Kinematics.dh\_value\_alpha, robot\_movement.Kinematics.dh\_value\_theta, robot\_movement.get\_rot\_x\_matrix(), robot\_movement.get\_rot\_y\_matrix(), robot\_movement.get\_rot\_z\_matrix(), robot\_movement.Kinematics.kin\_calculate\_theta\_1(), robot\_movement.Kinematics.kin\_calculate\_theta\_2(), robot\_movement.Kinematics.kin\_calculate\_theta\_2(), robot\_movement.Kinematics.kin\_calculate\_theta\_5(), robot\_movement.Kinematics.kin\_calculate\_theta\_6(), robot\_movement.orientation\_degree\_to\_radians(), robot\_movement.radians\_to\_degree\_list(), and robot\_movement.transform\_list\_in

Referenced by robot\_movement.MoveJ.convert\_coordinates\_to\_joint\_movements().

Here is the call graph for this function:



Here is the caller graph for this function:



# 6.10.3.2 kin\_calculate\_theta\_1()

Definition at line 369 of file robot\_movement.py.

References robot\_movement.Kinematics.dh\_value\_d, and robot\_movement.joint\_matrix().

Referenced by robot\_movement.Kinematics.get\_joint\_values().

Here is the call graph for this function:



Here is the caller graph for this function:



# 6.10.3.3 kin\_calculate\_theta\_2\_3()

Definition at line 387 of file robot\_movement.py.

References robot movement. Kinematics.dh value a.

Referenced by robot\_movement.Kinematics.get\_joint\_values().

Here is the caller graph for this function:



## 6.10.3.4 kin\_calculate\_theta\_4()

Definition at line 419 of file robot\_movement.py.

References robot\_movement.Kinematics.dh\_value\_theta.

Referenced by robot\_movement.Kinematics.get\_joint\_values().

Here is the caller graph for this function:



#### 6.10.3.5 kin\_calculate\_theta\_5()

Definition at line 432 of file robot\_movement.py.

Referenced by robot\_movement.Kinematics.get\_joint\_values().

Here is the caller graph for this function:



#### 6.10.3.6 kin\_calculate\_theta\_6()

Definition at line 444 of file robot movement.py.

Referenced by robot\_movement.Kinematics.get\_joint\_values().

Here is the caller graph for this function:



#### 6.10.4 Field Documentation

### 6.10.4.1 dh\_value\_a

```
robot_movement.Kinematics.dh_value_a
```

Definition at line 231 of file robot\_movement.py.

Referenced by robot\_movement.Kinematics.get\_joint\_values(), and robot\_movement.Kinematics.kin\_calculate\_theta\_2\_3().

## 6.10.4.2 dh\_value\_alpha

```
robot_movement.Kinematics.dh_value_alpha
```

Definition at line 230 of file robot\_movement.py.

Referenced by robot\_movement.Kinematics.get\_joint\_values().

#### 6.10.4.3 dh\_value\_d

```
robot_movement.Kinematics.dh_value_d
```

Definition at line 232 of file robot\_movement.py.

Referenced by robot\_movement.Kinematics.get\_joint\_values(), and robot\_movement.Kinematics.kin\_calculate\_theta\_1().

### 6.10.4.4 dh\_value\_theta

robot\_movement.Kinematics.dh\_value\_theta

Definition at line 233 of file robot\_movement.py.

 $Referenced \ by \ robot\_movement. Kinematics.get\_joint\_values(), \ and \ robot\_movement. Kinematics.kin\_calculate\_theta\_4().$ 

# 6.10.4.5 robot\_controller\_settings

robot\_movement.Kinematics.robot\_controller\_settings

Definition at line 229 of file robot\_movement.py.


Referenced by robot\_movement.MoveL.get\_linear\_via\_points(), and robot\_movement.MoveJ.move\_joint().

The documentation for this class was generated from the following file:


robot\_movement.py

# 6.11 robot\_movement.MoveJ Class Reference

Inheritance diagram for robot\_movement.MoveJ:



Collaboration diagram for robot movement. MoveJ:



#### **Public Member Functions**

- init (self, robot pointer, positions with time)
- convert\_coordinates\_to\_joint\_movements (self)
- move\_joint (self)

## Public Member Functions inherited from robot movement. Kinematics

- get\_joint\_values (self, coordinate, orientation)
- kin\_calculate\_theta\_1 (self, T\_link0\_link6)
- kin\_calculate\_theta\_2\_3 (self, T\_link2\_link3)
- kin\_calculate\_theta\_4 (self, rot\_matrix, theta\_5)
- kin\_calculate\_theta\_5 (self, rot\_matrix)
- kin\_calculate\_theta\_6 (self, rot\_matrix, theta\_5)

#### **Data Fields**

- robot
- · pos\_w\_time
- start\_joint\_values
- · joint matrix

## Data Fields inherited from robot movement. Kinematics

- robot\_controller\_settings
- dh\_value\_alpha
- dh value a
- dh\_value\_d
- dh\_value\_theta

#### 6.11.1 Detailed Description

```
Class for moving in joint space
```

Definition at line 456 of file robot\_movement.py.

## 6.11.2 Constructor & Destructor Documentation

## 6.11.2.1 \_\_init\_\_()

Reimplemented from robot\_movement.Kinematics.

 $Reimplemented \ in \ robot\_movement. Move L.$ 

Definition at line 460 of file robot\_movement.py.

## 6.11.3 Member Function Documentation

# 6.11.3.1 convert\_coordinates\_to\_joint\_movements()

```
{\tt robot\_movement.MoveJ.convert\_coordinates\_to\_joint\_movements} \ \ ( {\tt self} \ )
```


Method that converts the coordinates into joint degrees for each via point and end position. :return: Returns the transformed matrix.

Definition at line 488 of file robot\_movement.py.

References robot\_movement.best\_end\_joint(), robot\_movement.Kinematics.get\_joint\_values(), robot\_movement.MoveJ.pos\_w\_time, robot\_movement.MoveJ.start\_joint\_values.

Referenced by robot\_movement.MoveJ.move\_joint().

Here is the call graph for this function:



Here is the caller graph for this function:



### 6.11.3.2 move\_joint()


```
{\tt robot\_movement.MoveJ.move\_joint \ (} \\ self \ )
```

Method for moving the robot in the joint space thrugh the different via points.

Definition at line 517 of file robot\_movement.py.

References robot\_movement.MoveJ.convert\_coordinates\_to\_joint\_movements(), robot\_movement.MoveJ.joint\_matrix, robot\_movement.MoveJ.pos\_w\_time, robot\_movement.MoveL.pos\_w\_time, main.Main.robot, robot\_movement.MoveJ.robot, robot\_movement.MoveL.robot, and robot\_movement.Kinematics.robot\_controller\_settings.

Here is the call graph for this function:



### 6.11.4 Field Documentation

# 6.11.4.1 joint\_matrix

robot\_movement.MoveJ.joint\_matrix

Definition at line 486 of file robot\_movement.py.

Referenced by robot\_movement.MoveJ.move\_joint().

# 6.11.4.2 pos\_w\_time

robot\_movement.MoveJ.pos\_w\_time

Definition at line 467 of file robot\_movement.py.

Referenced by robot\_movement.MoveJ.convert\_coordinates\_to\_joint\_movements(), and robot\_movement.MoveJ.move\_joint().

## 6.11.4.3 robot

robot\_movement.MoveJ.robot

Definition at line 466 of file robot\_movement.py.

Referenced by main.Main.dispense\_allergen(), robot\_movement.MoveJ.move\_joint(), main.Main.place\_allergen(), main.Main.run(), main.Main.set\_mode(), and main.Main.take\_allergen().

# 6.11.4.4 start\_joint\_values

robot\_movement.MoveJ.start\_joint\_values

Definition at line 468 of file robot\_movement.py.


Referenced by robot\_movement.MoveJ.convert\_coordinates\_to\_joint\_movements().

The documentation for this class was generated from the following file:


· robot\_movement.py

# 6.12 robot\_movement.MoveL Class Reference

Inheritance diagram for robot\_movement.MoveL:



Collaboration diagram for robot\_movement.MoveL:



#### **Public Member Functions**

- \_\_init\_\_ (self, robot\_pointer, positions\_with\_time)
- get\_linear\_via\_points (self)

# Public Member Functions inherited from robot\_movement.MoveJ

- convert\_coordinates\_to\_joint\_movements (self)
- move\_joint (self)

# Public Member Functions inherited from robot\_movement.Kinematics

- get\_joint\_values (self, coordinate, orientation)
- kin\_calculate\_theta\_1 (self, T\_link0\_link6)
- kin\_calculate\_theta\_2\_3 (self, T\_link2\_link3)
- kin\_calculate\_theta\_4 (self, rot\_matrix, theta\_5)
- kin\_calculate\_theta\_5 (self, rot\_matrix)
- kin\_calculate\_theta\_6 (self, rot\_matrix, theta\_5)

#### **Data Fields**

- robot
- pos\_w\_time\_linear
- move\_time
- start\_pos\_cartesian
- pos\_w\_time

# Data Fields inherited from robot\_movement.MoveJ

- robot
- pos\_w\_time
- start\_joint\_values
- joint\_matrix

## Data Fields inherited from robot movement. Kinematics

- robot\_controller\_settings
- dh\_value\_alpha
- dh\_value\_a
- dh\_value\_d
- dh\_value\_theta

## 6.12.1 Detailed Description

```
Class for moving in cartesian space.
```

Definition at line 583 of file robot\_movement.py.

#### 6.12.2 Constructor & Destructor Documentation

## 6.12.2.1 \_\_init\_\_()

Reimplemented from robot\_movement.MoveJ.

Definition at line 587 of file robot\_movement.py.

## 6.12.3 Member Function Documentation

# 6.12.3.1 get\_linear\_via\_points()

```
robot\_movement.MoveL.get\_linear\_via\_points \; ($self )$ Method for getting all via points on the path, the robot moves on. :return: Returns the coordinates which will be used as via points in the joint movement.
```

Definition at line 618 of file robot\_movement.py.

References robot\_movement.MoveL.move\_time, robot\_movement.MoveL.pos\_w\_time\_linear, robot\_movement.Kinematics.robot\_composed and robot\_movement.MoveL.start\_pos\_cartesian.

## 6.12.4 Field Documentation

#### 6.12.4.1 move time

robot\_movement.MoveL.move\_time

Definition at line 595 of file robot\_movement.py.

Referenced by robot\_movement.MoveL.get\_linear\_via\_points().

## 6.12.4.2 pos\_w\_time

```
robot_movement.MoveL.pos_w_time
```

Definition at line 616 of file robot\_movement.py.

Referenced by robot\_movement.MoveJ.convert\_coordinates\_to\_joint\_movements(), and robot\_movement.MoveJ.move\_joint().

### 6.12.4.3 pos\_w\_time\_linear

```
robot_movement.MoveL.pos_w_time_linear
```

Definition at line 594 of file robot\_movement.py.

Referenced by robot movement. MoveL.get linear via points().

#### 6.12.4.4 robot

```
robot_movement.MoveL.robot
```

Definition at line 593 of file robot movement.py.

Referenced by main.Main.dispense\_allergen(), robot\_movement.MoveJ.move\_joint(), main.Main.place\_allergen(), main.Main.run(), main.Main.set\_mode(), and main.Main.take\_allergen().

### 6.12.4.5 start\_pos\_cartesian

```
robot_movement.MoveL.start_pos_cartesian
```

Definition at line 613 of file robot movement.py.


Referenced by robot\_movement.MoveL.get\_linear\_via\_points().

The documentation for this class was generated from the following file:


· robot\_movement.py

# 6.13 robot movement. MoveNotPossible Class Reference

Inheritance diagram for robot\_movement.MoveNotPossible:



Collaboration diagram for robot\_movement.MoveNotPossible:



# 6.13.1 Detailed Description

Used for error handling. Also the reason for the inheritance of Exception. The following error is described as MoveNotPossible: The given movement command can not be executed by the program. Please make sure that it dies

Definition at line 25 of file robot\_movement.py.

The documentation for this class was generated from the following file:

robot\_movement.py

# 6.14 robot\_movement.Robot Class Reference

#### **Public Member Functions**

- \_\_init\_\_ (self, rdk\_link)
- set\_joints (self, position, robot\_speed=100)

#### **Data Fields**

- robot\_settings
- rdk\_link
- prev position
- time\_between\_move
- max\_joint\_speed

# 6.14.1 Detailed Description

```
Robot class used to talk with RoboDK and the correct robot
```

Definition at line 651 of file robot movement.py.

## 6.14.2 Constructor & Destructor Documentation

#### 6.14.2.1 init ()

Definition at line 655 of file robot\_movement.py.

## 6.14.3 Member Function Documentation

# 6.14.3.1 set\_joints()

Definition at line 666 of file robot\_movement.py.

References robot\_movement.Robot.max\_joint\_speed, robot\_movement.Robot.prev\_position, robot\_movement.Robot.rdk\_link, robot\_movement.RobotMyCobotAndSim.rdk\_link, and robot\_movement.Robot.time\_between\_move.

## 6.14.4 Field Documentation

## 6.14.4.1 max\_joint\_speed

```
robot_movement.Robot.max_joint_speed
```

Definition at line 664 of file robot\_movement.py.

Referenced by robot movement.Robot.set joints().

## 6.14.4.2 prev\_position

```
robot_movement.Robot.prev_position
```

Definition at line 662 of file robot\_movement.py.

Referenced by robot\_movement.Robot.set\_joints().

## 6.14.4.3 rdk\_link

```
robot_movement.Robot.rdk_link
```

Definition at line 661 of file robot\_movement.py.

Referenced by robot movement.Robot.set joints(), and robot movement.RobotMyCobotAndSim.set joints().

## 6.14.4.4 robot\_settings

```
robot_movement.Robot.robot_settings
```

Definition at line 659 of file robot\_movement.py.

#### 6.14.4.5 time\_between\_move

```
robot_movement.Robot.time_between_move
```

Definition at line 663 of file robot\_movement.py.

Referenced by robot\_movement.Robot.set\_joints().

The documentation for this class was generated from the following file:

· robot\_movement.py

# 6.15 robot\_movement.RobotMyCobot Class Reference

# **Public Member Functions**

- \_\_init\_\_ (self, robo\_link)
- set\_joints (self, position, robot\_speed=100)

#### **Data Fields**

· robo link

# 6.15.1 Detailed Description

```
Robot class used to talk with MyCobot 320 PI
```

Definition at line 684 of file robot\_movement.py.

#### 6.15.2 Constructor & Destructor Documentation

# 6.15.2.1 \_\_init\_\_()

Definition at line 688 of file robot\_movement.py.

#### 6.15.3 Member Function Documentation

#### 6.15.3.1 set\_joints()

Definition at line 694 of file robot\_movement.py.

References robot\_movement.RobotMyCobot.robo\_link, and robot\_movement.RobotMyCobotAndSim.robo\_link.

# 6.15.4 Field Documentation

### 6.15.4.1 robo\_link

```
robot_movement.RobotMyCobot.robo_link
```

Definition at line 692 of file robot\_movement.py.

Referenced by robot\_movement.RobotMyCobot.set\_joints(), and robot\_movement.RobotMyCobotAndSim.set\_joints().

The documentation for this class was generated from the following file:

robot\_movement.py

# 6.16 robot\_movement.RobotMyCobotAndSim Class Reference

#### **Public Member Functions**

- \_\_init\_\_ (self, robo\_link, rdk\_link)
- set\_joints (self, position, robot\_speed=100)

#### **Data Fields**

- rdk link
- robo\_link

# 6.16.1 Detailed Description

```
Robot class used to talk with MyCobot 320 PI and RoboDK
```

Definition at line 709 of file robot\_movement.py.

#### 6.16.2 Constructor & Destructor Documentation

```
6.16.2.1 init ()
```

Definition at line 713 of file robot\_movement.py.

### 6.16.3 Member Function Documentation

## 6.16.3.1 set\_joints()

Definition at line 720 of file robot\_movement.py.

 $References\ robot\_movement. Robot. rdk\_link,\ robot\_movement. RobotMyCobotAndSim.rdk\_link,\ robot\_movement. RobotMyCobotAndSim.robo\_link.$ 

## 6.16.4 Field Documentation

## 6.16.4.1 rdk\_link

robot\_movement.RobotMyCobotAndSim.rdk\_link

Definition at line 717 of file robot\_movement.py.

Referenced by robot\_movement.Robot.set\_joints(), and robot\_movement.RobotMyCobotAndSim.set\_joints().

#### 6.16.4.2 robo\_link

robot\_movement.RobotMyCobotAndSim.robo\_link

Definition at line 718 of file robot\_movement.py.


Referenced by robot\_movement.RobotMyCobot.set\_joints(), and robot\_movement.RobotMyCobotAndSim.set\_joints().

The documentation for this class was generated from the following file:


· robot movement.py

# 6.17 robot\_movement.TakesOnlyTwoCoordinates Class Reference

Inheritance diagram for robot\_movement.TakesOnlyTwoCoordinates:



 $Collaboration\ diagram\ for\ robot\_movement. Takes Only Two Coordinates:$ 



# 6.17.1 Detailed Description

Used for error handling. Also the reason for the inheritance of Exception. The following error is described as TakesOnlyTwoCoordinates: This class takes only two coordinates.

Definition at line 43 of file robot\_movement.py.

The documentation for this class was generated from the following file:

robot\_movement.py

# **Chapter 7**

# **File Documentation**

### 7.1 commands.py File Reference

### **Namespaces**

· namespace commands

#### **Variables**

```
• str commands.HOME GRIPPER = "home -g"
```

- str commands.CLOSE\_GRIPPER = "close"
- str commands.HOME PRESSER = "home -p"
- str commands.PREPARE\_PRESSING = "prepare pressing"
- str commands.PRESS\_ALLERGEN = "press -"
- str commands.NEW\_TEST = "new test"
- str commands.RESPONSE = "b'Done'"
- str commands.EMPTY = "b""

## 7.2 commands.py

#### Go to the documentation of this file.

```
00001 HOME_GRIPPER = "home -g"
00002 CLOSE_GRIPPER = "close"
00003
00004 HOME_PRESSER = "home -p"
00005 PREPARE_PRESSING = "prepare pressing"
00006 PRESS_ALLERGEN = "press -"
00007
00008 NEW_TEST = "new test"
00009
00010 RESPONSE = "b'Done'"
00011 EMPTY = "b""
```

# 7.3 communication.py File Reference

### **Data Structures**

- · class communication.SerialCommunicationUnknownResponse
- class communication.CommunicationProtocol

### **Namespaces**

· namespace communication

#### **Variables**

- str communication.SERIAL\_COMMUNICATION\_UNKNOWN\_RESPONSE\_ERROR\_MSG = "Serial ← CommunicationUnknownResponse: The received serial response was not valid."
- communication.com test = CommunicationProtocol("COM3", 9600, 0.1)

### 7.4 communication.py

### Go to the documentation of this file.

```
00001 import serial 00002 import commands as cmd
00003 import time as t
00006 SERIAL_COMMUNICATION_UNKNOWN_RESPONSE_ERROR_MSG = "SerialCommunicationUnknownResponse: The received
      serial response was not valid."
00007
00008
00009 class SerialCommunicationUnknownResponse(Exception):
00010
00011
          Used for error handling. Also the reason for the inheritance of Exception. The following error is
      described as the following:
00012
00013
          SerialCommunicationUnknownResponse: The received serial response was not valid.
00014
00015
00016
00017
00018 class CommunicationProtocol:
00019
        def __init__(self, com, baudrate, timeout):
    self.com = com
00020
              self.baudrate = baudrate
00022
              self.timeout = timeout
00023
              self.connection = serial.Serial(port=self.com, baudrate=self.baudrate, timeout=self.timeout)
00024
         def send command(self, command):
00025
00026
              self.connection.write(bytes(command, 'utf-8'))
00027
00028
              while True:
00029
                 resp = str(self.connection.readline())
00030
                  print (resp)
00031
00032
                  if resp == cmd.RESPONSE:
00033
00035
                  if resp != cmd.EMPTY:
00036
     SerialCommunicationUnknownResponse(SERIAL_COMMUNICATION_UNKNOWN_RESPONSE_ERROR_MSG)
00037
00038
00039 if __name__ == "__main__":
00040
          com_test = CommunicationProtocol("COM3", 9600, 0.1)
00041
00042
          com_test.send_command(cmd.HOME_PRESSER)
00043
          com test.send command(cmd.HOME GRIPPER)
00044
          com_test.send_command(cmd.CLOSE_GRIPPER)
          t.sleep(5)
00046
          com_test.send_command(cmd.PREPARE_PRESSING)
          com_test.send_command(cmd.PRESS_ALLERGEN + "2500")
00047
00048
```

# 7.5 gui.py File Reference

### **Data Structures**

- · class gui.Light
- · class gui.GUI

7.6 gui.py 67

### **Namespaces**

· namespace gui

#### **Variables**

• gui.test = GUI()

### 7.6 gui.py

```
00001 from tkinter import ,
00003
00004 class Light (Canvas):
00005
           Class to construct an oval element in the GUI
00006
00007
00008
          def __init__(self, master, **kwargs):
00009
00010
               initializer
00011
               :param master: the root of the tkinter menu
               :param kwargs: possible arguments for the canvas.
00012
00013
               Canvas.__init__(self, master, width=50, height=50, **kwargs)
self.oval_id = self.create_oval(2, 2, 50, 50, fill='gray')
00014
00016
00017
           def turn_on(self):
00018
               Changes the color of the oval to green
00019
00020
00021
               self.itemconfig(self.oval_id, fill='green')
00022
00023
           def turn_off(self):
00024
00025
               Changes the color of the oval to gray
00026
00027
               self.itemconfig(self.oval_id, fill='gray')
00028
00029
           def turn_ready(self):
00030
00031
               Changes the color of the oval to red
00032
00033
               self.itemconfig(self.oval_id, fill='yellow')
00034
00035
00036 class GUI:
00037
00038
          Main class for the GUI
00039
00040
          def __init__(self):
00041
00042
               Initializer for tkinter menu
00043
00044
               self.root = Tk()
00045
               self.pressed buttons = set()
00046
00047
               self.mode = None
00048
               self.running = False
00049
               self.button_START = Button(self.root, text="START", padx=150, pady=50, state=DISABLED,
00050
      command=self.start_pressed, fg="black",
                                   bg="green")
00051
00052
               self.button_STOP = Button(self.root, text="STOP", padx=140, pady=50, state=NORMAL,
      00053
      self.button_SELECT_ROBOT = Button(self.root, text="Execute program on robot", padx=150, pady=50, state=NORMAL, command=self.robot_pressed, fg="white",
00054
00055
                                    bg="black")
               self.button_SELECT_SIMULATION = Button(self.root, text="Execute program in simulation",
      padx=150, pady=50, state=NORMAL, command=self.simulation_pressed,
      fg="white", bg="black")
self.button_SELECT_BOTH = Button(self.root, text="Execute program on robot and in simulation",
padx=100, pady=50, state=NORMAL, command=self.both_pressed,
00057
00058
00059
                                    fg="white", bg="black")
00060
```

```
self.button_START.grid(row=0, column=0, padx=10, pady=10)
00062
                self.button_STOP.grid(row=0, column=2, padx=10, pady=10)
                self.button_SELECT_ROBOT.grid(row=1, column=0, padx=10, pady=10) self.button_SELECT_SIMULATION.grid(row=1, column=1, padx=10, pady=10)
00063
00064
00065
                self.button_SELECT_BOTH.grid(row=1, column=2, padx=10, pady=10)
00066
                self.light_SELECT_ROBOT = Light(self.root)
00068
                self.light_SELECT_ROBOT.grid(row=2, column=0, padx=10, pady=10)
00069
                self.light_SELECT_SIMULATION = Light(self.root)
00070
00071
                self.light_SELECT_SIMULATION.grid(row=2, column=1, padx=10, pady=10)
00072
00073
                self.light_SELECT_BOTH = Light(self.root)
00074
                self.light_SELECT_BOTH.grid(row=2, column=2, padx=10, pady=10)
00075
00076
                self.title = Label(self.root, text="Patch test preparer")
00077
                self.title.grid(row=0, column=1)
00078
00079
            def start_pressed(self):
00080
00081
                Button method for when clicking on the start button
00082
                self.button_START["state"] = NORMAL
self.button_STOP["state"] = NORMAL
self.button_SELECT_ROBOT["state"] = DISABLED
self.button_SELECT_SIMULATION["state"] = DISABLED
00083
00084
00085
00086
00087
                self.button_SELECT_BOTH["state"] = DISABLED
00088
00089
                if "Robot" in self.pressed_buttons:
                     self.light_SELECT_ROBOT.turn_on()
self.mode = "robot"
00090
00091
00092
                else:
00093
                    self.light_SELECT_ROBOT.turn_off()
00094
                if "Simulation" in self.pressed_buttons:
    self.light_SELECT_SIMULATION.turn_on()
00095
00096
00097
                     self.mode = "simulation"
00098
00099
                     self.light_SELECT_SIMULATION.turn_off()
00100
                if "Robot and Simulation" in self.pressed_buttons:
00101
                     self.light_SELECT_BOTH.turn_on()
self.mode = "both"
00102
00103
00104
                else:
00105
                     self.light_SELECT_BOTH.turn_off()
00106
00107
                self.running = True
00108
           def stop_pressed_init(self):
00109
00110
00111
                Button method for when clicking on the stop button
00112
00113
                self.mode = None
00114
                self.button_START["state"] = DISABLED
00115
                self.button_STOP["state"] = DISABLED
self.button_SELECT_ROBOT["state"] = DISABLED
00116
00118
                self.button_SELECT_SIMULATION["state"] = DISABLED
00119
                self.button_SELECT_BOTH["state"] = DISABLED
00120
                self.light_SELECT_ROBOT.turn_off()
00121
                self.light_SELECT_SIMULATION.turn_off()
00122
00123
                self.light_SELECT_BOTH.turn_off()
00124
00125
                self.pressed_buttons.clear()
00126
00127
                if self.running:
                     self.running = False
00128
00129
                else:
00130
                    self.stop_pressed()
00131
           def stop_pressed(self):
00132
00133
                Button method for when the program has run the stop command and the buttons should be
00134
      clickable again.
00135
00136
                self.button_START["state"] = DISABLED
                self.button_STOP["state"] = NORMAL
self.button_SELECT_ROBOT["state"] = NORMAL
self.button_SELECT_SIMULATION["state"] = NORMAL
self.button_SELECT_BOTH["state"] = NORMAL
00137
00138
00139
00140
00141
00142
            def robot_pressed(self):
00143
00144
                Button method for when clicking on the 'Execute program on robot'
00145
00146
                self.pressed buttons.add("Robot")
```

```
00148
                self.button_START["state"] = NORMAL
               self.button_STOP["state"] = NORMAL
self.button_SELECT_ROBOT["state"] = NORMAL
self.button_SELECT_SIMULATION["state"] = DISABLED
00149
00150
00151
               self.button_SELECT_BOTH["state"] = DISABLED
00152
00153
00154
                self.light_SELECT_ROBOT.turn_ready()
00155
                self.light_SELECT_SIMULATION.turn_off()
00156
                self.light_SELECT_BOTH.turn_off()
00157
00158
           def simulation_pressed(self):
00159
00160
                Button method for when clicking on the 'Execute program in simulation'
00161
00162
                self.pressed_buttons.add("Simulation")
00163
                self.button_START["state"] = NORMAL
00164
               self.button_STOP["state"] = NORMAL
00165
               self.button_SELECT_ROBOT["state"] = DISABLED self.button_SELECT_SIMULATION["state"] = NORMAL
00166
00167
                self.button_SELECT_BOTH["state"] = DISABLED
00168
00169
               self.light_SELECT_ROBOT.turn_off()
self.light_SELECT_SIMULATION.turn_ready()
00170
00171
00172
                self.light_SELECT_BOTH.turn_off()
00173
00174
           def both_pressed(self):
00175
00176
                Button method for when clicking on the 'Execute program on robot and in simulation'
00177
00178
               self.pressed_buttons.add("Robot and Simulation")
00179
00180
                self.button_START["state"] = NORMAL
               self.button_STOP["state"] = NORMAL
self.button_SELECT_ROBOT["state"] = DISABLED
self.button_SELECT_SIMULATION["state"] = DISABLED
00181
00182
00183
00184
               self.button_SELECT_BOTH["state"] = NORMAL
00185
00186
               self.light_SELECT_ROBOT.turn_off()
00187
                self.light_SELECT_SIMULATION.turn_off()
               self.light_SELECT_BOTH.turn_ready()
00188
00189
00190
           def run(self):
00191
00192
                Runs the program
00193
00194
               self.root.mainloop()
00195
00196
00199
           test.run()
```

### 7.7 main.py File Reference

### **Data Structures**

· class main.Main

### **Namespaces**

· namespace main

### **Functions**

• main.communication\_multi\_thread (communicator, command)

#### **Variables**

```
• bool main.BOTH = True
```

- bool main.SIMULATING = False
- int main.Z OFFSET = 0
- int main.STORAGE\_OFFSET\_X = 30
- int main.SYRINGE OFFSET X = -18
- int main.SYRINGE\_MOVEMENT\_Z = 25
- int main.SPEED = 1/0.5
- main.ALLERGEN AMOUNT = str(150)
- int main.END\_EFFECTOR\_TILT\_TAKE = 85
- int main.END EFFECTOR TILT PLACE = 89
- list main.PATCH\_TEST\_CORNER\_COORDINATES = [-215, -265, 215]
- list main.SYRINGE\_COORDINATES
- bool main.performing\_command = False
- main.main = Main()

### 7.8 main.py

```
00001 from robot_movement import MoveJ, MoveL, Robot, Kinematics, RobotMyCobot, RobotMyCobotAndSim
00002 from gui import GUI
00003 from robodk.robolink import *
00004 from pymycobot.mycobot import MyCobot
00005 from communication import CommunicationProtocol
00006
00007
00008 import threading
00009 import commands as cmd
00010 import time as t
00011 import math as \ensuremath{\text{m}}
00012
00013
00014 BOTH = True
00015 SIMULATING = False
00016 Z_OFFSET = 0
00017 STORAGE_OFFSET_X = 30
00018 SYRINGE_OFFSET_X = -18
00019 SYRINGE_MOVEMENT_Z = 25
00020 SPEED = 1/0.5
00021 ALLERGEN_AMOUNT = str(150)
00022 END_EFFECTOR_TILT_TAKE = 85
00023 END_EFFECTOR_TILT_PLACE = 89
00024
00025
00026 PATCH_TEST_CORNER_COORDINATES = [-215, -265, 215]
00027
00028
00029 SYRINGE_COORDINATES = [
          [305, 169.5+5, 153.5+5],
[310, 94.5, 153.5+5],
[310, 19.5, 153.5+5],
[310, -65.5, 153.5+5],
00030
00031
00032
           [305, -140.5, 153.5+5],
[310, 132+5, 78],
00034
00035
           [310, 57, 76],
[310, -28-5, 76],
[310, -106-5, 76],
[310, -184-5, 78]
00036
00037
00038
00039
00040 ]
00041
00042
00043 performing_command = False
00044
00045
00046 def communication_multi_thread(communicator, command):
00047
00048
           Executes a command on the arduino using multi\_threading
00049
           :param communicator: instance of the communication class
00050
           :param command: command to execute. """
00051
00052
           global performing_command
```

7.8 main.py 71

```
00053
00054
          performing_command = True
00055
          communicator.send_command(command)
00056
          performing\_command = False
00057
00058
00059 class Main:
00060
00061
          Main class containing the whole program.
00062
          def __init__(self):
00063
00064
00065
               Connecting to ROBODK or MyCobot.
00066
00067
               self.communication = CommunicationProtocol("COM3", 9600, 0.1)
00068
               t.sleep(5)
00069
00070
               self.patch_test_config = [0, 1,
00071
                                          2, 3,
00072
                                          4, 5,
00073
00074
                                             9]
00075
00076
              self.robot = None
00077
00078
              self.gui_created = False
00079
              self.gui_thread = threading.Thread(target=self.create_gui)
00080
              self.gui_thread.start()
00081
00082
              while not self.qui_created:
00083
00084
00085
               while not self.gui.running:
00086
00087
00088
              self.set_mode(self.gui.mode)
00089
          def create_gui(self):
00091
00092
               Creates the GUI
00093
              self.gui = GUI()
00094
00095
00096
              self.gui_created = True
00097
00098
               self.gui.run()
00099
00100
          def set_mode(self, mode):
00101
00102
              Sets the mode for how the robot should run
              :param mode: either "both", "simulation", "robot".
00103
00104
00105
               if mode == "both":
                  RDK = Robolink()
00106
                   rdk_link = RDK.Item('My Mechanism')
00107
                  my_cobot = MyCobot('COM4', 115200)
00108
00110
                   self.robot = RobotMyCobotAndSim(my_cobot, rdk_link)
00111
                   self.robot.set_joints([0, 0, 0, 0, 0], robot_speed=20)
00112
                   \verb|#self.communication.send_command(cmd.HOME_PRESSER)|
00113
                   #self.communication.send_command(cmd.PREPARE_PRESSING)
00114
                   #self.communication.send_command(cmd.HOME_GRIPPER)
00115
                   #self.communication.send_command(cmd.CLOSE_GRIPPER)
00116
              elif mode == "simulation":
00117
00118
                  RDK = Robolink()
                  rdk_link = RDK.Item('My Mechanism')
self.robot = Robot(rdk_link)
00119
00120
00121
00122
              elif mode == "robot":
00123
                  my_cobot = MyCobot('COM4', 115200)
00124
00125
                   my\_cobot.set\_free\_mode(0)
00126
                   self.robot = RobotMyCobot (my_cobot)
                   self.robot.set_joints([0, 0, 0, 0, 0, 0], robot_speed=20)
00127
00128
00129
              self.run()
00130
00131
          def run(self):
00132
00133
              Runs the whole program sequence
00134
00135
               # Homing sekvens
00136
00137
               self.communication.send_command(cmd.HOME_PRESSER)
00138
               self.communication.send_command(cmd.HOME_GRIPPER)
00139
```

```
00140
              self.communication.send_command(cmd.NEW_TEST)
00141
              self.robot.set_joints([107.38158881112184, 46.157985403753784, 103.3563681945703,
00142
      30.485646401675925, 107.38158881112184, 135.0], robot_speed=20)
00143
00144
              t.sleep(5)
00145
              for patch_text_index_number in range(len(self.patch_test_config)):
00146
00147
00148
                  self.take allergen(self.patch test config[patch text index number])
00149
                 MoveL(self.robot, [[260, -132-37.5, 153.5-Z OFFSET, -90, 90, -90, 1.75 *
00150
      SPEED]]).move joint()
00151
                  MoveJ(self.robot, [[0, -350, PATCH_TEST_CORNER_COORDINATES[2]-Z_OFFSET, -90, 90, 135+45,
      0.5 * SPEED], [PATCH_TEST_CORNER_COORDINATES[0], PATCH_TEST_CORNER_COORDINATES[1],
      PATCH_TEST_CORNER_COORDINATES[2]-Z_OFFSET, -90, 90, 135, 1 * SPEED]]).move_joint()
00152
00153
                  self.dispense allergen(patch text index number)
00154
                  MoveJ(self.robot, [[0, -350, PATCH_TEST_CORNER_COORDINATES[2]-Z_OFFSET, -90, 90, 135+45,
00155
      0.5 * SPEED], [260, -132-37.5, 153.5-Z_OFFSET, -90, 90, -90, 1 * SPEED]]).move_joint()
00156
00157
                  self.place_allergen(self.patch_test_config[patch_text_index_number])
00158
00159
                  if not self.gui.running:
00160
00161
00162
              self.gui.running = False
00163
              self.gui.stop_pressed()
00164
00165
              # Waiting on a new start
00166
              while not self.gui.running:
00167
00168
00169
              self.set_mode(self.gui.mode)
00170
00171
          def dispense_allergen(self, index):
00172
00173
              Runs the movements needed to dispense allergen onto a patch test
00174
              :param index: What index the position on the patch test has
              :return: None
00175
00176
00177
              x \text{ offset} = (index % 2) * 20.5
00178
              y_{offset} = m.floor(index / 2) * 20.5
00179
00180
              MoveL(self.robot, [[PATCH_TEST_CORNER_COORDINATES[0] - x_offset,
      PATCH_TEST_CORNER_COORDINATES[1] + y_offset, PATCH_TEST_CORNER_COORDINATES[2]-Z_OFFSET, -90, 90, 135,
      1 * SPEED]]).move_joint()
              MoveL(self.robot, [[PATCH_TEST_CORNER_COORDINATES[0] - x_offset,
00181
      PATCH_TEST_CORNER_COORDINATES[1] + y_offset, PATCH_TEST_CORNER_COORDINATES[2]-Z_offset-10, -90, 90,
      135, 0.5 * SPEED]]).move_joint()
00182
00183
              while performing_command:
00184
00185
00186
              self.communication.send command(cmd.PRESS ALLERGEN + ALLERGEN AMOUNT)
              MoveL(self.robot, [[PATCH_TEST_CORNER_COORDINATES[0] - x_offset,
00188
      PATCH_TEST_CORNER_COORDINATES[1] + y_offset, PATCH_TEST_CORNER_COORDINATES[2]-Z_OFFSET, -90, 90, 135,
      0.5 * SPEED]]).move_joint()
00189
              thread = threading.Thread(target=communication_multi_thread, args=(self.communication,
00190
     cmd.HOME_PRESSER))
00191
              thread.start()
00192
00193
              MoveL(self.robot, [[PATCH_TEST_CORNER_COORDINATES[0], PATCH_TEST_CORNER_COORDINATES[1],
     PATCH_TEST_CORNER_COORDINATES[2]-Z_OFFSET, -90, 90, 135, 1 * SPEED]]).move_joint()
00194
00195
          def take_allergen(self, index):
00196
00197
              Takes an allergen from the storage
00198
              :param index: Index for the allergen in the storage system
              :return: None
00199
00200
00201
              x = SYRINGE_COORDINATES[index][0]
00202
00203
              y = SYRINGE_COORDINATES[index][1]
00204
              z = SYRINGE_COORDINATES[index][2]
00205
              MoveL(self.robot, [[x + SYRINGE_OFFSET_X - STORAGE_OFFSET_X, y, z - Z_OFFSET, 0,
00206
     END_EFFECTOR_TILT_TAKE, 0,
00207
                                   1.75 * SPEED]]).move_joint()
00208
00209
              MoveL(self.robot, [[x + SYRINGE_OFFSET_X, y, z - Z_OFFSET, 0, END_EFFECTOR_TILT_TAKE, 0,
00210
                                   0.75 * SPEED]]).move_joint()
00211
00212
              self.communication.send command(cmd.CLOSE GRIPPER)
```

```
00213
              thread = threading.Thread(target=communication_multi_thread, args=(self.communication,
      cmd.PREPARE_PRESSING))
00215
            thread.start()
00216
00217
             MoveL(self.robot, [
                 [x + SYRINGE_OFFSET_X, y, z + SYRINGE_MOVEMENT_Z - Z_OFFSET, 0, END_EFFECTOR_TILT_TAKE, 0,
00219
                   0.75 * SPEED]]).move_joint()
             MoveL(self.robot,
00220
                 [x + SYRINGE_OFFSET_X - STORAGE_OFFSET_X, y, z + SYRINGE_MOVEMENT_Z - Z_OFFSET, 0,
00221
     END_EFFECTOR_TILT_TAKE, 0,
00222
                   0.75 * SPEED]]).move_joint()
00223
00224
          def place_allergen(self, index):
00225
00226
              Places an allergen in storage
00227
              :param index: Index for storage place
             :return: None
00228
00230
00231
             x = SYRINGE_COORDINATES[index][0]
00232
             y = SYRINGE_COORDINATES[index][1]
00233
             z = SYRINGE_COORDINATES[index][2]
00234
              MoveL(self.robot, [[x + SYRINGE_OFFSET_X - STORAGE_OFFSET_X, y, z + SYRINGE_MOVEMENT_Z -
00235
     Z_OFFSET, 0, END_EFFECTOR_TILT_PLACE, 0, 1.75 * SPEED]]).move_joint()
MoveL(self.robot, [[x + SYRINGE_OFFSET_X, y, z + SYRINGE_MOVEMENT_Z - Z_OFFSET, 0,
00236
     END_EFFECTOR_TILT_PLACE, 0, 0.75 * SPEED]]).move_joint()
00237
             MoveL(self.robot, [[x + SYRINGE_OFFSET_X, y, z - Z_OFFSET, 0, END_EFFECTOR_TILT_PLACE, 0, 0.75
      * SPEED]]).move_joint()
00238
00239
              while performing_command:
00240
00241
00242
             self.communication.send_command(cmd.HOME_GRIPPER)
00243
              MoveL(self.robot, [[x + SYRINGE_OFFSET_X - STORAGE_OFFSET_X, y, z - Z_OFFSET, 0,
00244
     END_EFFECTOR_TILT_PLACE, 0, 0.75 * SPEED]]).move_joint()
00245
00246
t.sleep(2)
00248
00249
00250
         main = Main()
```

## 7.9 robot\_controller.py File Reference

### **Data Structures**

· class robot\_controller.RobotControllerSettings

### Namespaces

· namespace robot controller

### 7.10 robot\_controller.py

```
00001 import math as m
00002
00003
00004 class RobotControllerSettings:
00005 """
00006 Robot controller settings class
00007 """
00008 def __init__(self):
00009 """
00010 Settings for the robot controller
```

### 7.11 robot\_movement.py File Reference

### **Data Structures**

- class robot\_movement.MoveNotPossible
- · class robot\_movement.JointSyntaxError
- class robot movement.TakesOnlyTwoCoordinates
- · class robot\_movement.CoordinateSyntaxError
- · class robot movement.InvalidTimeIncrease
- · class robot\_movement.Kinematics
- class robot\_movement.MoveJ
- class robot\_movement.MoveL
- class robot\_movement.Robot
- class robot movement.RobotMyCobot
- class robot\_movement.RobotMyCobotAndSim

#### **Namespaces**

namespace robot\_movement

### **Functions**

- · robot movement.joint matrix (alpha, a, d, theta)
- robot\_movement.get\_rot\_x\_matrix (angle)
- robot\_movement.get\_rot\_y\_matrix (angle)
- robot\_movement.get\_rot\_z\_matrix (angle)
- robot\_movement.orientation\_degree\_to\_radians (orientation)
- robot movement.radians to degree (angle)
- robot\_movement.radians\_to\_degree\_list (list\_radians)
- robot\_movement.transform\_list\_into\_range (untransformed\_list, min\_value, max\_value, adjuster)
- robot\_movement.best\_end\_joint (current\_joint, joints)

#### **Variables**

- int robot\_movement.MIN\_ANGLE\_LINK\_1\_5 = -165 / 180 \* m.pi
- int robot\_movement.MAX\_ANGLE\_LINK\_1\_5 = 165 / 180 \* m.pi
- int robot\_movement.MIN\_ANGLE\_LINK\_6 = -175 / 180 \* m.pi
- int robot\_movement.MAX\_ANGLE\_LINK\_6 = 175 / 180 \* m.pi
- str robot\_movement.MOVE\_NOT\_POSSIBLE\_ERROR\_MSG = "MoveNotPossible: The given movement command can not be executed by the program. Please make sure that it dies not result in a singularity"
- str robot\_movement.JOINT\_SYNTAX\_ERROR\_MSG = "JointSyntaxError: The syntax must be [Joint1, joint2, joint3, joint4, joint5, joint6] for a joint"
- str robot\_movement.TAKES\_ONLY\_TWO\_COORDINATES\_ERROR\_MSG = "TakesOnlyTwoCoordinates
   : This class takes only two coordinates."
- str robot\_movement.COORDINATE\_SYNTAX\_ERROR\_MSG = "CoordinateSyntaxError: The syntax must be: [x, y, z, alpha, beta, gamma, time] for a coordinate."
- str robot\_movement.INVALID\_TIME\_INCREASE\_ERROR\_MSG = "InvalidTimeIncrease: Later coordinates must have a higher time than those before or the robot will not be able to move to the given point."
- list robot\_movement.robot\_joint\_position = [107.38158881112184, 46.157985403753784, 103. ← 3563681945703, 30.485646401675925, 107.38158881112184, 135.0]
- list robot movement.robot cartesian position = [280, 132, 74, -90, 135, -90]

### 7.12 robot\_movement.py

```
00001 import math as m
00002 import time as t
00003 import numpy as np
00004 import random as r
00005
00006 from robot_controller import RobotControllerSettings
00007 from numpy.linalg import inv
80000
00009 MIN_ANGLE_LINK_1_5 = -165 / 180 * m.pi
00010 MAX_ANGLE_LINK_1_5 = 165 /
00011 MIN_ANGLE_LINK_6 = -175 / 180 * m.pi
00012 MAX_ANGLE_LINK_6 = 175 / 180 * m.pi
00013
00014 MOVE_NOT_POSSIBLE_ERROR_MSG = "MoveNotPossible: The given movement command can not be executed by the
program. Please make sure that it dies not result in a singularity"
00015 JOINT_SYNTAX_ERROR_MSG = "JointSyntaxError: The syntax must be [Joint1, joint2, joint3, joint4,
       joint5, joint6] for a joint"
00016 TAKES_ONLY_TWO_COORDINATES_ERROR_MSG = "TakesOnlyTwoCoordinates: This class takes only two
      coordinates."
00017 COORDINATE_SYNTAX_ERROR_MSG = "CoordinateSyntaxError: The syntax must be: [x, y, z, alpha, beta,
      gamma, time] for a coordinate."
00018 INVALID_TIME_INCREASE_ERROR_MSG = "InvalidTimeIncrease: Later coordinates must have a higher time than
      those before or the robot will not be able to move to the given point."
00019
00020
00021 robot_joint_position = [107.38158881112184, 46.157985403753784, 103.3563681945703, 30.485646401675925,
      107.38158881112184, 135.01
00022 robot_cartesian_position = [280, 132, 74, -90, 135, -90]
00024
00025 class MoveNotPossible(Exception):
00026
          Used for error handling. Also the reason for the inheritance of Exception. The following error is
00027
      described as the following:
          MoveNotPossible: The given movement command can not be executed by the program. Please make sure
      that it dies not result in a singularity
00030
          pass
00031
00032
00033
00034 class JointSyntaxError(Exception):
00035
00036
          Used for error handling. Also the reason for the inheritance of Exception. The following error is
      described as the following:
00037
00038
          JointSyntaxError: The syntax must be [Joint1, joint2, joint3, joint4, joint5, joint6] for a joint
00039
```

```
00040
00041
00042
00043 class TakesOnlyTwoCoordinates(Exception):
00044
         Used for error handling. Also the reason for the inheritance of Exception. The following error is
00045
     described as the following:
00046
00047
          TakesOnlyTwoCoordinates: This class takes only two coordinates.
00048
00049
00050
00051
00052 class CoordinateSyntaxError(Exception):
00053
00054
         Used for error handling. Also the reason for the inheritance of Exception. The following error is
     described as the following:
00055
00056
          CoordinateSyntaxError: The syntax must be: [x, y, z, alpha, beta, gamma, time] for a coordinate.
00057
00058
00059
00060
00061 class InvalidTimeIncrease(Exception):
00062
00063
          Used for error handling. Also the reason for the inheritance of Exception. The following error is
     described as the following:
00064
00065
          InvalidTimeIncrease: Later coordinates must have a higher time than those before or the robot will
     not be able to move to the given point.
00066
00067
00068
00069
00070 np.set_printoptions(suppress=True)
00071
00072
00073 def joint_matrix(alpha, a, d, theta):
00074
00075
          Function to create transformation matrix.
00076
00077
          :param alpha: alpha value from David Hartenberg parameters.
00078
          :param a: a value from David Hartenberg parameters.
00079
          :param d: d value from David Hartenberg parameters.
          :param theta: theta value from David Hartenberg parameters.
00080
          :return: returns a 4x4 matrix containing the transformation matrix for the given parameters.
00081
00082
         00083
00084
      -m.sin(alpha) * dl.
00085
                              [m.sin(theta) * m.sin(alpha), m.cos(theta) * m.sin(alpha), m.cos(alpha),
     m.cos(alpha) * d],
00086
                              [0, 0, 0, 1]])
00087
00088
          return matrix
00089
00090
00091 def get_rot_x_matrix(angle):
00092
00093
          Get rotation matrix around \boldsymbol{x} axis.
          :param angle: Angle the rotation matrix should rotate an object.
00094
00095
          :return: Returns the rotation matrix.
00096
00097
          rot_x_matrix = np.matrix([[1, 0, 0, 0],
00098
                                    [0, m.cos(angle), -m.sin(angle), 0],
00099
                                    [0, m.sin(angle), m.cos(angle), 0],
00100
                                    [0, 0, 0, 1]])
00101
00102
          return rot x matrix
00103
00104
00105 def get_rot_y_matrix(angle):
00106 """
          Get rotation matrix around y axis.
00107
          :param angle: Angle the rotation matrix should rotate an object.
00108
          return: Returns the rotation matrix.
00109
00110
00111
          rot_y_matrix = np.matrix([[m.cos(angle), 0, m.sin(angle), 0],
00112
                                    [0, 1, 0, 0],
                                    [-m.sin(angle), 0, m.cos(angle), 0],
00113
00114
                                    [0, 0, 0, 111)
00115
00116
          return rot_y_matrix
00117
00118
00119 def get_rot_z_matrix(angle):
00120
```

```
Get rotation matrix around z axis.
          :param angle: Angle the rotation matrix should rotate an object.
00122
00123
           :return: Returns the rotation matrix.
00124
00125
          rot_z_matrix = np.matrix([[m.cos(angle), -m.sin(angle), 0, 0],
00126
                                      [m.sin(angle), m.cos(angle), 0, 0],
                                      [0, 0, 1, 0],
[0, 0, 0, 1]])
00127
00128
00129
00130
          return rot_z_matrix
00131
00132
00133 def orientation_degree_to_radians(orientation):
00134
00135
          Converts angle from degree to radians
00136
           :param orientation: Angle in degree.
00137
           :return: Angle in radians
00138
00139
          for angle_index in range(len(orientation)):
00140
              orientation[angle_index] = orientation[angle_index] / 180 * m.pi
00141
00142
          return orientation
00143
00144
00145 def radians_to_degree(angle):
00146
00147
          Converts angle from radians to degree.
00148
          :param angle: Angle in radians.
00149
           :return: Angle in degree.
00150
00151
          angle = angle / m.pi * 180
00152
00153
          return angle
00154
00155
00156 def radians_to_degree_list(list_radians):
00157
00158
          Converts radians in a list to degree
00159
          :param list_radians: List containing angles in radians
          :return: List containing angles in degrees
00160
00161
00162
          response = []
00163
00164
          for angle in list_radians:
              response.append(angle / m.pi * 180)
00165
00166
00167
          return response
00168
00169
00170 def transform_list_into_range(untransformed_list, min_value, max_value, adjuster):
00172
          Takes a list containing angles and checks if they are in a given range.
00173
           :param untransformed_list: List containing angles
00174
           :param min_value: Min value in range
00175
          :param max_value: Max value in range
00176
          :param adjuster: How much the values may be adjusted
          return: Transformed list. Some of the elements may have been changed to False if the given value
      is not in the range.
00178
00179
          for element_index in range(len(untransformed_list)):
              if not untransformed_list[element_index]:
00180
00181
00182
00183
              while untransformed_list[element_index] < min_value:</pre>
00184
                  untransformed_list[element_index] += adjuster
                  if untransformed_list[element_index] > max_value:
00185
                       untransformed_list[element_index] = False
00186
00187
00188
              while untransformed list[element index] > max value:
00189
                  untransformed_list[element_index] -= adjuster
00190
                   if untransformed_list[element_index] < min_value:</pre>
00191
                       untransformed_list[element_index] = False
00192
          return untransformed_list
00193
00194
00195 def best_end_joint(current_joint, joints):
00196
00197
          Takes the current joint position and a list containing of possible joint positions and returns the
      closest possible joint position.
          :param current_joint: The current position of the robots joint. :param joints: The possible joint positions for a point.
00198
00199
          :return: The closest joint position to the current joint position
00201
00202
          lowest_score_joint = []
00203
          lowest_score_value = -1
00204
00205
          if len(joints) == 0:
```

```
raise MoveNotPossible (MOVE_NOT_POSSIBLE_ERROR_MSG)
00207
00208
          for joint in joints:
00209
              angle\_difference = 0
00210
00211
              for angle_index in range(len(joint)):
                   angle_difference += abs(current_joint[angle_index] - joint[angle_index])
00212
00213
00214
              if angle_difference < lowest_score_value or lowest_score_value < 0:</pre>
00215
                   lowest_score_value = angle_difference
                  lowest_score_joint = joint
00216
00217
00218
          return lowest score joint
00219
00220
00221 class Kinematics:
00222
00223
          Class to compute the inverse kinematics.
00224
00225
          def __init__(self):
00226
00227
              Constructor for class
00228
              self.robot_controller_settings = RobotControllerSettings()
00229
00230
              self.dh_value_alpha = self.robot_controller_settings.dh_values["alpha"]
              self.dh_value_a = self.robot_controller_settings.dh_values["a"]
00231
              self.dh_value_d = self.robot_controller_settings.dh_values["d"]
00232
00233
               self.dh_value_theta = self.robot_controller_settings.dh_values["theta"]
00234
00235
          def get_joint_values(self, coordinate, orientation):
00236
00237
              Method for getting the joint values from a coordinate and orientation.
00238
               :param coordinate: Coordinate in the format [x, y, z].
00239
               :param orientation: Orientation in the format [roll, pitch, yaw].
               :return: Returns a list containing all possible joint configurations for the robot.
00240
00241
00242
              orientation = orientation degree to radians(orientation)
00243
00244
              rot_x_matrix = get_rot_x_matrix(orientation[0])
00245
               rot_y_matrix = get_rot_y_matrix(orientation[1])
00246
               rot_z_matrix = get_rot_z_matrix(orientation[2])
00247
00248
              wrist_rot_x_matrix = get_rot_x_matrix(0)
              wrist_rot_y_matrix = get_rot_y_matrix(0)
00249
              wrist_rot_z_matrix = get_rot_z_matrix(0)
00250
00251
00252
              wrist = wrist_rot_z_matrix * wrist_rot_y_matrix * wrist_rot_x_matrix
00253
              wrist[0, 3] = 0
00254
              wrist[1, 3] = 0

wrist[2, 3] = 66
00255
00256
00257
00258
               T_link0_wrist = rot_z_matrix * rot_y_matrix * rot_x_matrix
              T_link0_wrist[0, 3] = coordinate[0]
T_link0_wrist[1, 3] = coordinate[1]
00259
00260
00261
              T link0 wrist[2, 3] = coordinate[2]
00262
00263
              T link0 link6 = T link0 wrist * inv(wrist)
00264
00265
              theta_1 = self.kin_calculate_theta_1(T_link0_link6) # Contains two angles
00266
              # For calculating theta_4, theta_5 and theta_6 a rotation matrix consisting of theta_1 and the
00267
     other angles is needed. This is created:
00268
              rot_z_matrix_theta_1_1 = get_rot_z_matrix(theta_1[0] + self.dh_value_theta[0])
00269
               rot_z_matrix_theta_1_2 = get_rot_z_matrix(theta_1[1] + self.dh_value_theta[0])
00270
00271
              rot_matrix_alpha_link_1 = get_rot_x_matrix(self.dh_value_alpha[0])
              rot_matrix_alpha_link_2 = get_rot_x_matrix(self.dh_value_alpha[1])
00272
              rot_matrix_alpha_link_3 = get_rot_x_matrix(self.dh_value_alpha[2])
00273
00274
              rot_matrix_theta_link_2 = get_rot_z_matrix(self.dh_value_theta[1])
rot_matrix_theta_link_3 = get_rot_z_matrix(self.dh_value_theta[2])
00275
00276
00277
              \verb|rot_matrix_link_1_theta_1_1_inv| = \verb|inv(rot_matrix_alpha_link_1 * \verb|rot_z_matrix_theta_1_1|)|
00278
00279
              rot_matrix_link_1_theta_1_2_inv = inv(rot_matrix_alpha_link_1 * rot_z_matrix_theta_1_2)
              rot_matrix_link_2_inv = inv(rot_matrix_alpha_link_2 * rot_matrix_theta_link_2)
00280
              rot_matrix_link_3_inv = inv(rot_matrix_alpha_link_3 * rot_matrix_theta_link_3)
00281
00282
00283
              rot_matrix_link_1_to_link_3_theta_1_1_inv = rot_matrix_link_3_inv * rot_matrix_link_2_inv *
     rot_matrix_link_1_theta_1_1_inv
00284
              rot_matrix_link_1_to_link_3_theta_1_2_inv = rot_matrix_link_3_inv * rot_matrix_link_2_inv *
      rot_matrix_link_1_theta_1_2_inv
00285
00286
              rot_matrix_theta_1_1 = rot_matrix_link_1_to_link_3_theta_1_1_inv * rot_z_matrix * rot_y_matrix
      * rot_x_matrix
00287
              rot_matrix_theta_1_2 = rot_matrix_link_1_to_link_3_theta_1_2_inv * rot_z_matrix * rot_y_matrix
      * rot x matrix
```

```
00288
00289
              # Based on the rotational matrix, it is possible to get the angle theta5 using the inverse
      cosinus to field
00290
              # (3,3) in the matrix. However due to the nature of cosinus to a point, it will not be
     possible to estimate if
00291
              # the angle is positive or negative.
00292
00293
              theta_5 = self.kin_calculate_theta_5(rot_matrix_theta_1_1) +
      self.kin_calculate_theta_5(rot_matrix_theta_1_2)
00294
00295
              theta_6_theta_1_1 = [self.kin_calculate_theta_6(rot_matrix_theta_1_1, theta_5[0]),
              self.kin_calculate_theta_6(rot_matrix_theta_1_1, theta_5[1])]
theta_6_theta_1_2 = [self.kin_calculate_theta_6(rot_matrix_theta_1_2, theta_5[2]),
00296
00297
00298
                                    self.kin_calculate_theta_6(rot_matrix_theta_1_2, theta_5[3])]
00299
              theta_6 = theta_6_theta_1_1 + theta_6_theta_1_2
00300
00301
              # Moving the
00302
00303
              pre_theta_4_theta_1_1 = [self.kin_calculate_theta_4(rot_matrix_theta_1_1, theta_5[0]),
00304
                                        self.kin_calculate_theta_4(rot_matrix_theta_1_1, theta_5[1])]
00305
              pre_theta_4_theta_1_2 = [self.kin_calculate_theta_4(rot_matrix_theta_1_2, theta_5[2]),
00306
                                        self.kin_calculate_theta_4(rot_matrix_theta_1_2, theta_5[3])]
00307
              pre_theta_4 = pre_theta_4_theta_1_1 + pre_theta_4_theta_1_2
00308
              # Currently theta5 and theta6 consists of 4 different angles whereas theta1 consists of 2
00309
     angles.
00310
              # To get each angle to match in the angle, thetal will be defined as:
00311
00312
              theta_1 = [theta_1[0], theta_1[0], theta_1[1], theta_1[1]]
00313
00314
              # This gives the possibility to make a loop of 4 as each array will consist of this:
00315
00316
              inverse_kinematics_list = []
00317
              theta_1 = transform_list_into_range(theta_1, MIN_ANGLE_LINK_1_5, MAX_ANGLE_LINK_1_5, 2 * m.pi)
              theta_5 = transform_list_into_range(theta_5, MIN_ANGLE_LINK_1_5, MAX_ANGLE_LINK_1_5, 2 * m.pi)
00318
              theta_6 = transform_list_into_range(theta_6, MIN_ANGLE_LINK_6, MAX_ANGLE_LINK_6, 2 * m.pi)
00319
00320
              for i in range(4):
00322
                  # Checking if any of them are out of range (Joint space more specifically).
00323
                   if not theta_1[i] or not theta_5[i] or not theta_6[i]:
00324
00325
                  T link0 link1 rotation = joint matrix(self.dh value alpha[0], self.dh value a[0],
00326
     self.dh_value_d[0],
00327
                                                          self.dh_value_theta[0] + theta_1[i])
00328
                  T_link4_rotation_link4 = joint_matrix(0, 0, self.dh_value_d[3], 0)
00329
                  T_link4_link5 = joint_matrix(self.dh_value_alpha[4], self.dh_value_a[4],
      self.dh_value_d[4],
00330
                                                self.dh_value_theta[4] + theta_5[i])
                  T_link5_link6 = joint_matrix(self.dh_value_alpha[5], self.dh_value_a[5],
00331
      self.dh_value_d[5],
00332
                                                self.dh_value_theta[5] + theta_6[i])
00333
00334
                  T_link1_link3 = inv(T_link0_link1_rotation) * T_link0_link6 * inv(T_link5_link6) *
      inv(T_link4_link5) * inv(
00335
                      T link4 rotation link4)
00336
00337
                  # Sorting points which are further away than the robot can reach.
                  if m.sqrt(T_link1_link3[0, 3] ** 2 + T_link1_link3[2, 3] ** 2) > self.dh_value_a[2] +
     self.dh_value_a[3]:
00339
00340
00341
                  theta_2_theta_3 = self.kin_calculate_theta_2_3(T_link1_link3)
00342
00343
                  theta_2_untransformed = theta_2_theta_3[0]
00344
                  theta_3_untransformed = theta_2_theta_3[1]
00345
00346
                  theta 2 = transform list into range (theta 2 untransformed, MIN ANGLE LINK 1 5,
     MAX_ANGLE_LINK_1_5, 2 * m.pi)
00347
                  theta_3 = transform_list_into_range(theta_3_untransformed, MIN_ANGLE_LINK_1_5,
     MAX_ANGLE_LINK_1_5, 2 * m.pi)
00348
00349
                  theta_4_untransformed = [False, False]
00350
00351
                  for angle index in range(2):
                      if theta_2[angle_index] and theta_3[angle_index]:
00352
00353
                          theta_4_untransformed[angle_index] = pre_theta_4[i] - theta_2[angle_index] -
00354
00355
                  theta_4 = transform_list_into_range(theta_4_untransformed, MIN_ANGLE_LINK_1_5,
     MAX_ANGLE_LINK_1_5, 2 * m.pi)
00356
00357
                  # Creates the list.
00358
                  for j in range(2):
00359
                      \# Checking if any of them are out of range (Joint space more specifically).
00360
                       if not theta_2[j] or not theta_3[j] or not theta_4[j]:
00361
```

```
00362
00363
                                    inverse_kinematics_list.append(
00364
                                           radians_to_degree_list([theta_1[i], theta_2[j], theta_3[j], theta_4[j],
         theta_5[i], theta_6[i]]))
00365
00366
                       return inverse kinematics list
00367
00368
                 # Returns two angles.
                def kin_calculate_theta_1(self, T_link0_link6):
00369
00370
                       Calculates theta 1
00371
00372
                       :param T link0 link6: Transformation matrix from link 1 to link 6.
                       :return: Returns the two possible values for theta 1
00373
00374
00375
                       T_link6_rotation_link6 = joint_matrix(0, 0, self.dh_value_d[5], 0)
00376
                       T link0 link6 rotation = T link0 link6 * inv(T link6 rotation link6)
00377
00378
00379
                       x_6 = T_{link0_link6_rotation[0, 3]}
00380
                      y_6 = T_{link0_link6_rotation[1, 3]
00381
                       00382
00383
00384
00385
                       return [theta_1_1, theta_1_2]
00386
00387
                def kin_calculate_theta_2_3(self, T_link2_link3):
00388
00389
                       Calculates theta 2 and 3
                       :param T_link2_link3: Transformation matrix from link 2 to link 3
00390
00391
                       :return: Returns the possible configurations for theta 2 and theta 3.
00392
00393
                       x = abs(T_link2_link3.item((0, 3)))
00394
                       z = T_{link2_{link3.item((2, 3))}}
00395
                       mirror_angle_length = m.sqrt(x ** 2 + z ** 2)
00396
00397
00398
                       direction = -1 * abs(T_link2_link3.item((0, 3))) / T_link2_link3.item((0, 3))
00399
00400
                       theta_2_1 = direction * (m.acos(z / mirror_angle_length) + m.acos(
00401
                              (self.dh\_value\_a[3] \ ** \ 2 \ - \ self.dh\_value\_a[2] \ ** \ 2 \ - \ mirror\_angle\_length \ ** \ 2) \ / \ (self.dh\_value\_a[3] \ ** \ 2 \ - \ mirror\_angle\_length \ ** \ 2) \ / \ (self.dh\_value\_a[3] \ ** \ 2 \ - \ mirror\_angle\_length \ ** \ 2) \ / \ (self.dh\_value\_a[3] \ ** \ 2 \ - \ mirror\_angle\_length \ ** \ 2) \ / \ (self.dh\_value\_a[3] \ ** \ 2 \ - \ mirror\_angle\_length \ ** \ 2) \ / \ (self.dh\_value\_a[3] \ ** \ 2 \ - \ mirror\_angle\_length \ ** \ 2) \ / \ (self.dh\_value\_a[3] \ ** \ 2 \ - \ mirror\_angle\_length \ ** \ 2) \ / \ (self.dh\_value\_a[3] \ ** \ 2 \ - \ mirror\_angle\_length \ ** \ 2) \ / \ (self.dh\_value\_a[3] \ ** \ 2 \ - \ mirror\_angle\_length \ ** \ 2) \ / \ (self.dh\_value\_a[3] \ ** \ 2 \ - \ mirror\_angle\_length \ ** \ 2) \ / \ (self.dh\_value\_a[3] \ ** \ 2 \ - \ mirror\_angle\_length \ ** \ 2) \ / \ (self.dh\_value\_a[3] \ ** \ 2 \ - \ mirror\_angle\_length \ ** \ 2) \ / \ (self.dh\_value\_a[3] \ ** \ 2 \ - \ mirror\_angle\_length \ ** \ 2 \ - \ mir
                                         2 * self.dh_value_a[2] * mirror_angle_length)) + m.pi)
00402
                       theta_3_1 = direction * (
00403
00404
                             m.acos((mirror_angle_length ** 2 - self.dh_value_a[3] ** 2 - self.dh_value_a[2] ** 2) / (
                                           2 * self.dh_value_a[2] * self.dh_value_a[3])))
00405
00406
00407
                       \label{eq:cos}  \mbox{theta\_2\_2 = direction} \  \  \star \  \  \mbox{(m.acos(z / mirror\_angle\_length) - m.acos()} 
                              (self.dh_value_a[3] ** 2 - self.dh_value_a[2] ** 2 - mirror_angle_length ** 2) / (
00408
                                          2 * self.dh_value_a[2] * mirror_angle_length)) - m.pi)
00409
                       theta_3_2 = -1 * direction * (
00410
00411
                            m.acos((mirror_angle_length ** 2 - self.dh_value_a[3] ** 2 - self.dh_value_a[2] ** 2) / (
00412
                                           2 * self.dh_value_a[2] * self.dh_value_a[3])))
00413
                       theta_2 = [theta_2_1, theta_2_2]
theta_3 = [theta_3_1, theta_3_2]
00414
00415
00416
                       return theta_2, theta_3
00418
00419
                def kin_calculate_theta_4(self, rot_matrix, theta_5):
00420
00421
                       Calculates theta 4
                       :param rot_matrix: Rotation matrix describing rotation from link 4 to link 6.
00422
00423
                       :param theta_5: Value for theta 5
                       :return: Returns the value for theta 4
00424
00425
00426
                       \# -self.dh_value_theta[3] is subtracted due to the calculated angle is based on
         theta2+theta3+theta4+self.dh_value\_theta4 = calculated angle.
00427
                       theta_4 = m.atan2(rot_matrix.item((1, 2)) * <math>m.sin(theta_5), rot_matrix.item((0, 2)) *
         m.sin(theta_5)) - \
00428
                                        self.dh_value_theta[3]
00429
00430
                       return theta_4
00431
                def kin_calculate_theta_5(self, rot_matrix):
00432
00433
00434
                       Calculates theta 5
00435
                       :param rot_matrix: Rotation matrix describing rotation from link 4 to link 6.
                       return: Returns the two values for theta 5
00436
00437
00438
                       theta 5 unsigned = m.acos(rot matrix.item((2, 2)))
00439
00440
                       theta_5 = [theta_5_unsigned, -theta_5_unsigned]
00441
00442
                       return theta_5
00443
00444
                def kin_calculate_theta_6(self, rot_matrix, theta_5):
00445
```

```
00446
               Calculates theta 6
00447
               :param rot_matrix: Rotation matrix describing rotation from link 4 to link 6.
00448
                :param theta_5: Value for theta 5
               :return: Returns the value for theta 6
00449
00450
00451
              theta 6 = m.atan2(rot matrix.item((2, 1)) * m.sin(theta 5), -1 * rot matrix.item((2, 0)) *
     m.sin(theta_5))
00452
00453
              return theta_6
00454
00455
00456 class MoveJ(Kinematics):
00457
00458
          Class for moving in joint space
00459
          def __init__(self, robot_pointer, positions_with_time):
00460
00461
              Constructor for the MoveJ class. Takes the robot and position.
00462
              :param robot_pointer: A pointer to the robot class for the robot
00463
              :param positions_with_time: The position with time.
00464
00465
00466
              self.robot = robot_pointer
00467
              self.pos_w_time = positions_with_time
              self.start_joint_values = robot_joint_position
00468
00469
00470
              start time = 0
00471
00472
              if not len(self.start_joint_values) == 6:
00473
                  raise JointSyntaxError(JOINT_SYNTAX_ERROR_MSG)
00474
00475
              for coordinate in self.pos_w_time:
    if not len(coordinate) == 7:
00476
00477
                      raise CoordinateSyntaxError(COORDINATE_SYNTAX_ERROR_MSG)
00478
00479
                  if coordinate[6] <= start_time:</pre>
                       raise InvalidTimeIncrease(INVALID_TIME_INCREASE_ERROR_MSG)
00480
00481
00482
                  start_time = coordinate[6]
00483
00484
              super().__init__()
00485
00486
              self.joint_matrix = self.convert_coordinates_to_joint_movements()
00487
00488
          def convert_coordinates_to_joint_movements(self):
00489
00490
              Method that converts the coordinates into joint degrees for each via point and end position.
              :return: Returns the transformed matrix.
00491
00492
00493
              start_joint = self.start_joint_values
00494
              joint_values = []
00495
00496
              for position_index in range(len(self.pos_w_time)):
00497
                  position = self.pos_w_time[position_index]
00498
                  coordinate = position[0:3]
orientation = position[3:6]
time_val = position[6]
00499
00500
00501
00502
00503
                   joints = self.get_joint_values(coordinate, orientation)
00504
00505
                   if position index == 0:
00506
                       joint_values.append([start_joint, 0])
00507
00508
                       start_joint = best_end_joint(start_joint, joints)
00509
                       joint_values.append([start_joint, time_val])
00510
00511
                       start_joint = best_end_joint(start_joint, joints)
00512
00513
                       joint_values.append([start_joint, time_val])
00514
00515
              return joint_values
00516
00517
          def move_joint(self):
00518
              Method for moving the robot in the joint space thrugh the different via points.
00519
00520
00521
              global robot_joint_position, robot_cartesian_position
00522
00523
              self.joint_matrix = self.convert_coordinates_to_joint_movements()
00524
00525
              end_joint_position = []
00526
00527
              for move_index in range(
00528
                       len(self.joint_matrix) - 1): # The reason for -1 is because the function is indexing
      1 ahead.
00529
                  time_val = self.joint_matrix[move_index][1]
00530
                  time_val_plus_1 = self.joint_matrix[move_index + 1][1]
```

```
00532
                 joint movement time = time val plus 1 - time val
00533
00534
                 joint_function_values = []
00535
00536
                 for joint index in range(len(self.joint matrix[move index][0])):
                     v_start = 0
00538
00539
00540
                     joint_val = self.joint_matrix[move_index][0][joint_index]
00541
                     joint_val_plus_1 = self.joint_matrix[move_index + 1][0][joint_index]
00542
00543
                     if not move index == 0:
00544
                         joint_val_minus_1 = self.joint_matrix[move_index - 1][0][joint_index]
00545
                         time_val_minus_1 = self.joint_matrix[move_index - 1][1]
00546
                        00547
00548
00549
00550
                     if not move_index == len(self.joint_matrix) - 2:
00551
                         joint_val_plus_2 = self.joint_matrix[move_index + 2][0][joint_index]
                         time_val_plus_2 = self.joint_matrix[move_index + 2][1]
00552
00553
                        00554
00555
     time_val_plus_1))) / 2
00556
00557
                     a_0 = joint_val
00558
                     a_1 = v_start
                     00559
00560
     joint_movement_time * v_end
00561
                    a_3 = (-2) / (joint_movement_time ** 3) * (joint_val_plus_1 - joint_val) + 1 / (
00562
                                joint_movement_time ** 2) * (v_end + v_start)
00563
00564
                     joint_function_values.append([a_0, a_1, a_2, a_3])
00565
00566
                 for freq in range(round(joint_movement_time *
     self.robot_controller_settings.update_frequency)):
00567
                     joints_value = []
                     for fp in joint_function_values: # fp: function parameters
    x = freq / self.robot_controller_settings.update_frequency
00568
00569
00570
00571
                         function_value = fp[0] + fp[1] * x + fp[2] * x ** 2 + fp[3] * x ** 3
00572
                         joints_value.append(function_value)
00573
00574
                     self.robot.set_joints(joints_value)
00575
                     end_joint_position = joints_value
                     t.sleep(1 / self.robot_controller_settings.update_frequency)
00576
00577
00578
             robot_joint_position = end_joint_position
00579
             robot_cartesian_position = self.pos_w_time[-1][:6]
00580
00581
00582 # IKKE OPDATERET UD FRA NYESTE EXCEPTIONS!
00583 class MoveL(MoveJ):
00584
00585
         Class for moving in cartesian space.
00586
00587
         def __init__(self, robot_pointer, positions_with_time):
00588
00589
             Constructor for MoveL class
00590
             :param robot_pointer: Pointer to robot controller
             :param positions_with_time: Position for where the robot should move to.
00591
00592
00593
             self.robotrobot = robot_pointer
00594
             self.pos_w_time_linear = positions_with_time
             self.move_time = self.pos_w_time_linear[0][6]
00595
00596
00597
             super().__init__(self.robotrobot, self.pos_w_time_linear)
00598
00599
             if not len(positions_with_time) == 1:
00600
                 raise TakesOnlyTwoCoordinates(TAKES_ONLY_TWO_COORDINATES_ERROR_MSG)
00601
00602
             start time = 0
00603
00604
             for coordinate in self.pos_w_time_linear:
00605
                 if not len(coordinate) == 7:
00606
                     raise CoordinateSyntaxError (COORDINATE_SYNTAX_ERROR_MSG)
00607
00608
                 if coordinate[6] <= start time:</pre>
00609
                     raise InvalidTimeIncrease(INVALID_TIME_INCREASE_ERROR_MSG)
00610
00611
                 start_time = coordinate[6]
00612
00613
             self.start_pos_cartesian = robot_cartesian_position
00614
```

```
00615
               self.pos_w_time_linear = self.get_linear_via_points()
               self.pos_w_timepos_w_time = self.pos_w_time_linear
00616
00617
00618
          def get_linear_via_points(self):
00619
               Method for getting all via points on the path, the robot moves on.
00620
               return: Returns the coordinates which will be used as via points in the joint movement.
00621
00622
00623
               linear_movement_coords_w_time = []
00624
00625
               function_values = []
00626
               for i in range(6):
00627
00628
                   a_0 = self.start_pos_cartesian[i]
                   a_1 = 0
00629
00630
                   a_2 = 3 / (self.move_time ** 2) * (self.pos_w_time_linear[0][i] -
      self.start_pos_cartesian[i])
    a_3 = (-2) / (self.move_time ** 3) * (self.pos_w_time_linear[0][i] -
00631
      self.start_pos_cartesian[i])
00632
00633
                   function_values.append([a_0, a_1, a_2, a_3])
00634
00635
              for i in range(1, round(self.move_time * self.robot_controller_settings.linear_frequency +
      1)):
00636
00637
                   coordinate = []
00638
00639
                   x = i / self.robot_controller_settings.linear_frequency
00640
00641
                   for j in range(6):
      coordinate.append(function_values[j][0] + function_values[j][1] * x + function_values[j][2] * x ** 2 + function_values[j][3] * x ** 3)
00642
00643
00644
                   coordinate.append(x)
00645
00646
                   linear_movement_coords_w_time.append(coordinate)
00647
00648
              return linear_movement_coords_w_time
00649
00650
00651 class Robot:
00652
00653
          Robot class used to talk with RoboDK and the correct robot
00654
00655
          def __init__(self, rdk_link):
00656
00657
               Constructor for class
00658
               self.robot settings = RobotControllerSettings()
00659
00660
00661
               self.rdk_link = rdk_link
               self.prev_position = [0, 0, 0, 0, 0, 0]
self.time_between_move = 1 / self.robot_settings.update_frequency
00662
00663
00664
               self.max_joint_speed = 180
00665
          def set_joints(self, position, robot_speed=100):
00666
00667
00668
               Sets the joint values for the robot
00669
               :param position: Position in joint space.
00670
               :param robot_speed: Not used due to it not being neccessary, but has to be there in order to
      use the class together with other classes.'
00671
00672
00673
               # Prints if one of the joins exceed maximum speed.
00674
               for index in range(6):
00675
                   speed = abs((position[index] - self.prev_position[index]) / self.time_between_move)
00676
                   if speed > self.max_joint_speed:
                       print(f"Joint {index+1} exceeded max speed in simulation at {position}")
00677
00678
               self.prev_position = position
00680
00681
               self.rdk_link.setJoints(position)
00682
00683
00684 class RobotMyCobot:
00685
00686
          Robot class used to talk with MyCobot 320 PI
00687
00688
          def __init__(self, robo_link):
00689
00690
               Constructor for class
00691
00692
               self.robo_link = robo_link
00693
00694
          def set_joints(self, position, robot_speed=100):
00695
               Sets the joint values for the robot
00696
```

```
:param position: Position in joint space.
              :param robot_speed: Value between 0-100 setting the robot's speed.
00698
00699
              encoder_val = []
encoder_dir = [1, 1, -1, 1, 1, 1]
00700
00701
00702
00703
              for joint_val_index in range(len(position)):
00704
                   encoder_val.append(round(2048 - position[joint_val_index] / 90 * 1024 *
      encoder_dir[joint_val_index]))
00705
00706
              self.robo_link.set_encoders(encoder_val, robot_speed)
00707
00708
00709 class RobotMyCobotAndSim:
00710
00711
          Robot class used to talk with MyCobot 320 PI and RoboDK
00712
          def __init__(self, robo_link, rdk_link):
00713
00715
              Constructor for class
00716
00717
00718
              self.rdk_link = rdk_link
              self.robo_link = robo_link
00719
00720
          def set_joints(self, position, robot_speed=100):
00721
00722
              Sets the joint values for the robot
00723
              :param position: Position in joint space.
              :param robot_speed: Value between 0-100 setting the robot's speed.
00724
00725
00726
              encoder val = []
00727
              encoder_dir = [1, 1, -1, 1, 1, 1]
00728
00729
              for joint_val_index in range(len(position)):
00730
                   encoder_val.append(round(2048 - position[joint_val_index] / 90 \star 1024 \star
     encoder_dir[joint_val_index]))
00731
00732
              self.robo_link.set_encoders(encoder_val, robot_speed)
00733
00734
              self.rdk_link.setJoints(position)
00735
```

### 7.13 test.py File Reference

### **Namespaces**

· namespace test

### **Functions**

• test.mySqrt (number, guess, step, tol)

### **Variables**

• int test.testVal = 9

### 7.14 test.py

7.14 test.py 85

```
if (number > 1): # If we have numbers larger than one, we can safely guess half as the sqrt guess = 0.5 \star number
00010
00011
                   else:
00012
                       guess = number \star 2 \# If we have numbers smaller than one, we need to double our guess
00013
             tmp = guess * guess # Now compute the square of our guess
if ((tmp - number) < tol): # Check if the (guess^2 - number) is lower than our tolerance level</pre>
00014
00016
                   return guess
             else:
    if (tmp > number): # If our guess was too high, then iterate by calling ourselves again with
00017
00018
       a slightly lower guess
                   return mySqrt(number, (1 - step) * guess, step, tol)
else: # Else, our guess was too small, we need to increase the guess for our next call
return mySqrt(number, (1 + step) * guess, step, tol)
00019
00020
00021
00022
00023
00024 testVal = 9
00025 print('Squareroot of ' + str(testVal) + ' is ')
00026 print(mySqrt(testVal, 0, 0.001, 0.001))
```

# Index

```
init
                                                   commands.py, 65
    communication.CommunicationProtocol, 23
                                                   communication, 10
    gui.GUI, 26
                                                        com test, 11
    gui.Light, 33
                                                        main.Main, 38
                                                        SERIAL_COMMUNICATION_UNKNOWN_RESPONSE_ERROR_MS
    main.Main, 34
    robot_controller.RobotControllerSettings, 40
    robot movement. Kinematics, 45
                                                   communication.CommunicationProtocol, 23
    robot movement. MoveJ, 51
                                                         _init___, 23
                                                        baudrate, 24
    robot_movement.MoveL, 56
    robot movement.Robot, 59
                                                        com, 24
    robot movement.RobotMyCobot, 61
                                                        connection, 24
    robot movement.RobotMyCobotAndSim, 62
                                                        send command, 24
                                                        timeout, 24
ALLERGEN AMOUNT
                                                   communication.py, 65
    main, 12
                                                   communication.SerialCommunicationUnknownResponse,
baudrate
                                                   communication_multi_thread
    communication.CommunicationProtocol, 24
                                                        main, 12
best end joint
                                                   connection
    robot movement, 15
                                                        communication.CommunicationProtocol, 24
BOTH
                                                   convert coordinates to joint movements
    main, 12
                                                        robot movement. MoveJ, 52
both_pressed
                                                   COORDINATE SYNTAX ERROR MSG
    gui.GUI, 27
                                                        robot movement, 19
button SELECT BOTH
                                                   create gui
    gui.GUI, 29
                                                        main.Main, 35
button_SELECT_ROBOT
    gui.GUI, 29
                                                   dh value a
button_SELECT_SIMULATION
                                                        robot movement. Kinematics, 49
    gui.GUI, 29
                                                   dh value alpha
button_START
                                                        robot_movement.Kinematics, 49
    gui.GUI, 29
                                                   dh value d
button_STOP
                                                        robot movement. Kinematics, 49
    gui.GUI, 30
                                                   dh value theta
                                                        robot movement. Kinematics, 49
CLOSE_GRIPPER
                                                   dh values
    commands, 9
                                                        robot controller.RobotControllerSettings, 40
                                                   dispense_allergen
    communication.CommunicationProtocol, 24
                                                        main.Main, 35
com test
    communication, 11
                                                   EMPTY
commands, 9
                                                        commands, 9
    CLOSE GRIPPER, 9
                                                   END_EFFECTOR_TILT_PLACE
    EMPTY, 9
                                                        main, 12
    HOME_GRIPPER, 9
                                                   END_EFFECTOR_TILT_TAKE
    HOME PRESSER, 9
                                                        main, 12
    NEW TEST, 10
    PREPARE PRESSING, 10
                                                   get joint values
    PRESS ALLERGEN, 10
                                                        robot movement. Kinematics, 45
    RESPONSE, 10
                                                   get linear via points
```

88 INDEX

robot_movement.MoveL, 56 get_rot_x_matrix	robot_movement.Kinematics, 46 kin_calculate_theta_2_3
robot_movement, 15	robot_movement.Kinematics, 47
get_rot_y_matrix robot_movement, 16	kin_calculate_theta_4 robot_movement.Kinematics, 47
get_rot_z_matrix	kin calculate theta 5
robot_movement, 16	robot_movement.Kinematics, 48
gui, 11	kin_calculate_theta_6
main.Main, 38	robot movement.Kinematics, 48
test, 11	<del>-</del>
gui.GUI, 26	light_SELECT_BOTH
init, 26	gui.GUI, 30
both_pressed, 27	light_SELECT_ROBOT
button_SELECT_BOTH, 29	gui.GUI, 30
button_SELECT_ROBOT, 29	light_SELECT_SIMULATION
button_SELECT_SIMULATION, 29	gui.GUI, 30 linear frequency
button_START, 29	robot controller.RobotControllerSettings, 40
button_STOP, 30 light SELECT BOTH, 30	Tobot_controller. Tobot Controller Cettings, 40
light_SELECT_ROBOT, 30	main, 11
light_SELECT_SIMULATION, 30	ALLERGEN_AMOUNT, 12
mode, 30	BOTH, 12
pressed_buttons, 30	communication_multi_thread, 12
robot_pressed, 27	END_EFFECTOR_TILT_PLACE, 12
root, 31	END_EFFECTOR_TILT_TAKE, 12
run, 27	main, 13
running, 31	PATCH_TEST_CORNER_COORDINATES, 13
simulation_pressed, 27	performing_command, 13
start_pressed, 28	SIMULATING, 13 SPEED, 13
stop_pressed, 28	STORAGE_OFFSET_X, 13
stop_pressed_init, 28	SYRINGE COORDINATES, 13
title, 31	SYRINGE MOVEMENT Z, 14
gui.Light, 32	SYRINGE_OFFSET_X, 14
init, 33 oval_id, 34	Z_OFFSET, 14
turn_off, 33	main.Main, 34
turn_on, 33	init, 34
turn_ready, 33	communication, 38
gui.py, 66	create_gui, 35
gui_created	dispense_allergen, 35
main.Main, 38	gui, 38
gui_thread	gui_created, 38
main.Main, 38	gui_thread, 38
HOME ORIDRED	patch_test_config, 39 place_allergen, 35
HOME_GRIPPER	robot, 39
commands, 9	run, 36
HOME_PRESSER commands, 9	set_mode, 37
Commands, 9	take_allergen, 37
INVALID_TIME_INCREASE_ERROR_MSG	main.py, 69
robot movement, 19	MAX_ANGLE_LINK_1_5
	robot_movement, 19
joint_matrix	MAX_ANGLE_LINK_6
robot_movement, 17	robot_movement, 20
robot_movement.MoveJ, 53	max_joint_speed
JOINT_SYNTAX_ERROR_MSG	robot_movement.Robot, 60
robot_movement, 19	MIN_ANGLE_LINK_1_5
kin_calculate_theta_1	robot_movement, 20
	MIN_ANGLE_LINK_6

INDEX 89

robot_movement, 20	robot_movement, 20
mode	robot_controller, 14
gui.GUI, 30	robot_controller.py, 73
move_joint	robot_controller.RobotControllerSettings, 39
robot_movement.MoveJ, 52	init, 40
MOVE_NOT_POSSIBLE_ERROR_MSG	dh_values, 40
robot_movement, 20	linear_frequency, 40
move_time	update_frequency, 40
robot_movement.MoveL, 57	robot_controller_settings
mySqrt	robot_movement.Kinematics, 50
test, 21	robot_joint_position
NEW TECT	robot_movement, 20
NEW_TEST	robot_movement, 14
commands, 10	best_end_joint, 15
aviantation decreas to redicus	COORDINATE_SYNTAX_ERROR_MSG, 19
orientation_degree_to_radians	get_rot_x_matrix, 15
robot_movement, 17	get_rot_y_matrix, 16
oval_id	get_rot_z_matrix, 16
gui.Light, 34	INVALID TIME INCREASE ERROR MSG, 19
	joint_matrix, 17
patch_test_config	JOINT_SYNTAX_ERROR_MSG, 19
main.Main, 39	MAX ANGLE LINK 1 5, 19
PATCH_TEST_CORNER_COORDINATES	MAX_ANGLE_LINK_6, 20
main, 13	MIN ANGLE LINK 1 5, 20
performing_command	MIN_ANGLE_LINK_6, 20
main, 13	
place_allergen	MOVE_NOT_POSSIBLE_ERROR_MSG, 20
main.Main, 35	orientation_degree_to_radians, 17
pos_w_time	radians_to_degree, 18
robot_movement.MoveJ, 53	radians_to_degree_list, 18
robot_movement.MoveL, 57	robot_cartesian_position, 20
pos_w_time_linear	robot_joint_position, 20
robot_movement.MoveL, 57	TAKES_ONLY_TWO_COORDINATES_ERROR_MSG
PREPARE_PRESSING	20
commands, 10	transform_list_into_range, 18
PRESS_ALLERGEN	robot_movement.CoordinateSyntaxError, 41
	robot_movement.InvalidTimeIncrease, 42
commands, 10	suppress, 43
pressed_buttons	robot_movement.JointSyntaxError, 43
gui.GUI, 30	robot_movement.Kinematics, 44
prev_position	init , 45
robot_movement.Robot, 60	dh_value_a, 49
and the state of t	dh_value_alpha, 49
radians_to_degree	dh value d, 49
robot_movement, 18	dh_value_theta, 49
radians_to_degree_list	get_joint_values, 45
robot_movement, 18	kin calculate theta 1,46
rdk_link	kin calculate theta 2 3, 47
robot_movement.Robot, 60	
robot_movement.RobotMyCobotAndSim, 63	kin_calculate_theta_4, 47
RESPONSE	kin_calculate_theta_5, 48
commands, 10	kin_calculate_theta_6, 48
robo_link	robot_controller_settings, 50
robot_movement.RobotMyCobot, 61	robot_movement.MoveJ, 50
robot_movement.RobotMyCobotAndSim, 63	init, 51
robot	convert_coordinates_to_joint_movements, 52
main.Main, 39	joint_matrix, 53
robot_movement.MoveJ, 53	move_joint, 52
robot_movement.MoveL, 57	pos_w_time, 53
robot_cartesian_position	robot, 53
1000t_cartoolari_poolitori	

90 INDEX

start_joint_values, 54	start_pos_cartesian
robot_movement.MoveL, 54	robot_movement.MoveL, 57
init, 56	start_pressed
get_linear_via_points, 56	gui.GUI, 28
move_time, 57	stop_pressed
pos_w_time, 57	gui.GUI, 28
pos_w_time_linear, 57	stop_pressed_init
robot, 57	gui.GUI, 28
start_pos_cartesian, 57	STORAGE_OFFSET_X
robot_movement.MoveNotPossible, 58	main, 13
robot_movement.py, 74	suppress
robot_movement.Robot, 58	robot_movement.InvalidTimeIncrease, 43
init, 59	SYRINGE_COORDINATES
max_joint_speed, 60	main, 13
prev_position, 60	SYRINGE_MOVEMENT_Z
rdk_link, 60	main, 14
robot_settings, 60	SYRINGE_OFFSET_X
set_joints, 59	main, 14
time_between_move, 60	
	take_allergen
robot_movement.RobotMyCobot, 60	main.Main, 37
init, 61	
robo_link, 61	TAKES_ONLY_TWO_COORDINATES_ERROR_MSG
set_joints, 61	robot_movement, 20
robot_movement.RobotMyCobotAndSim, 62	test, 21
init, 62	gui, 11
rdk_link, 63	mySqrt, 21
robo_link, 63	testVal, 22
set_joints, 62	test.py, 84
robot_movement.TakesOnlyTwoCoordinates, 63	testVal
	test, 22
robot_pressed	
gui.GUI, 27	time_between_move
robot_settings	robot_movement.Robot, 60
robot_movement.Robot, 60	timeout
root	communication.CommunicationProtocol, 24
gui.GUI, 31	title
run	gui.GUI, 31
gui.GUI, 27	transform_list_into_range
main.Main, 36	robot_movement, 18
	turn off
running	gui.Light, 33
gui.GUI, 31	
send_command	turn_on
	gui.Light, 33
communication.CommunicationProtocol, 24	turn_ready
SERIAL_COMMUNICATION_UNKNOWN_RESPONSE_	ERROB <u>uMbg</u> At, 33
communication, 11	
set_joints	update_frequency
robot_movement.Robot, 59	robot_controller.RobotControllerSettings, 40
robot_movement.RobotMyCobot, 61	
robot movement.RobotMyCobotAndSim, 62	Z_OFFSET
set mode	main, 14
_	·
main.Main, 37	
SIMULATING	
main, 13	
simulation_pressed	
gui.GUI, 27	
SPEED	
main, 13	
start_joint_values	
robot_movement.MoveJ, 54	
<del>-</del>	