



STATUS UPDATE

SÜSS MICROTEC HBD SYSTEM 2020-01-23 +DECISIONS

SLIDING + DOCKING

CONTENT




- Overview of current Sliding/Docking/Leveling
- Degrees of Freedom
- Way of working current Sliding/Docking/Leveling
 - Pulling out Chamber module
 - Pushing in Chamber module
- Concept 1
- Concept 2A
- Concept 2B

DECISION P357-DM-31 FRONT LOADING IS OUT


DECISION P357-DM-32
EXHAUST COUPLING OF CHAMBER
MODULE IS RESPONSIBILITY OF
SÜSS

OVERVIEW SLIDING/DOCKING/LEVELLING




DEGREES OF FREEDOM

CURRENT MAIN PROCESS TOOL




6 DOF to fixate Chamber module:


- X, Y, Z
- Rx, Ry, Rz




PULLING OUT CHAMBER MODULE

CURRENT WAY OF WORKING (TOP VIEW)









- 1. Unlock doors
- 2. Remove lower panel
- 3. Remove cosmetic strip
- 4. Remove Support strips (2x)
- 5. Open Chamber lower door and
- 6. Loosen drains
- 7. Loosen Exhaust pipe
- Mount rail extension frame
- 9. Loosen 4 leveling bolt (alternately)
- Pull out Chamber module on 4 ball bushings

PUSHING IN CHAMBER MODULE

CURRENT WAY OF WORKING (TOP VIEW)






- . Push in Chamber module on 4 ball bushings
- Alignment search of 4 holes with the 4 leveling bolts
- 3. Pull up the Chamber module with the 4 leveling bolts to touch the 8 set screws as end stop (alternately)
- 4. Remove rail extension frame
- 5. Connect Drains
- 6. Connect Exhaust pipe
- 7. Close Chamber lower door
- 8. Mount support strips (2x)
- 9. Mount cosmetic strip
- 10. Mount lower panel

11. Lock doors

•







- 1. Push in Chamber module on 4 ball bushings
- 2. Push centering balls in V-groove
- 3. Pull up the Chamber module with the 4 leveling bolts to touch the 8 set screws as end stop (alternately)
- 4. Remove rail extension frame
- 5. Connect Drains
- 6. Connect Exhaust pipe
- Close Chamber lower door
- 8. Mount support strips (see slide 6)
- 9. Mount cosmetic strip (see slide 6)
- 10. Mount lower panel (see slide 6)
- 11. Lock doors (see slide 6)

8

CONCEPT 2A

PUSHING IN CHAMBER MODULE







Top view

- 1. Push in Chamber module on 4 ball bushings
- Lower rail with Z-stroke
- Centering balls rest in V-groove
- Remove rail extension frame
- **Connect Drains**
- Connect Exhaust pipe
- Close Chamber lower door
- Mount support strips (see slide 6)
 - Mount cosmetic strip (see slide 6)
- 10. Mount lower panel (see slide 6)
- 11. Lock doors (see slide 6)

CONCEPT 2B

PUSHING IN CHAMBER MODULE





balls

Top view

- Push in Chamber module on Lifting car
- Lower Chamber module by lowering Lifting car
 - Centering balls rest in V-groove move Lifting car
 - t Drains
- ct Exhaust pipe
- Close Chamber lower door
- Mount support strips (see slide 6)
- Mount cosmetic strip (see slide 6)
- 10. Mount lower panel (see slide 6)
- 11. Lock doors (see slide 6)

DECISIONS



OVERVIEW NEW

KMME				
			SüSS HBD system Decision tracker	
ID#	Made b 🔻	Agreed by 🔻	DECISION	Start .T
P357-DM-31	Manfred	SÜSS team	Front loading is out	23-1-2020
P357-DM-32	Manfred	SÜSS team	Coupling exhaust is responsibility of SÜSS	23-1-2020

