## avsd\_opamp Circuit Netlist

## - R.V.Rohinth Ram

\* SPICE3 file created from avsd\_opamp\_layout.ext - technology: sky130A

.lib "sky130 fd pr/models/sky130.lib.spice" tt

C3 vdd vss 125.23fF

X0 a\_181\_n17# in1 a\_n28\_306# vss sky130\_fd\_pr\_\_nfet\_01v8 w=1.79 l=1.00
X1 vss a\_n675\_n1020# out2 vss sky130\_fd\_pr\_\_nfet\_01v8 w=62.89 l=1.00
X2 vss a\_n675\_n1020# a\_n675\_n1020# vss sky130\_fd\_pr\_\_nfet\_01v8 w=10.01 l=1.00
X3 out2 a\_582\_n17# vdd vdd sky130\_fd\_pr\_\_pfet\_01v8 w=62.89 l=1.00
X4 a\_n1220\_n998# a\_n1049\_1511# vss sky130\_fd\_pr\_\_res\_generic\_nd w=27 l=2492
X5 a\_582\_n17# a\_n28\_306# vdd vdd sky130\_fd\_pr\_\_pfet\_01v8 w=10.01 l=1.00
X6 a\_n1220\_n998# vdd vss sky130\_fd\_pr\_\_res\_generic\_nd w=27 l=2492
X7 a\_n883\_n1009# a\_n1049\_1511# vss sky130\_fd\_pr\_\_res\_generic\_nd w=27 l=2492
X8 vdd a\_n28\_306# a\_n28\_306# vdd sky130\_fd\_pr\_\_pfet\_01v8 w=10.01 l=1.00
X9 a\_582\_n17# in2 a\_181\_n17# vss sky130\_fd\_pr\_\_nfet\_01v8 w=1.79 l=1.00
X10 a\_n675\_n1020# a\_n883\_n1009# vss sky130\_fd\_pr\_\_res\_generic\_nd w=26 l=2494
X11 vss a\_n675\_n1020# a\_181\_n17# vss sky130\_fd\_pr\_\_nfet\_01v8 w=20.02 l=1.00
C0 vss vss 5.09fF
C1 a\_n675\_n1020# vss 5.61fF
C2 a\_n883\_n1009# vss 3.88fF