/set/ADM/(2)f Vorher Admin-Rechte setzen getestet -> ok (ein Muss zum Auslesen, ohne kommt nichts) liefert Status Motorventil Rückmeldung: {"getAB":"1"} für geschlossen {"getAB":"2"} für offen /get/ab liefert Gesamtvolumen (seit Installation) Rückmeldung {"getVOL":"Vol[L]443"} (Werte vom 21.03. 21.00 Uhr) /get/vol /get/all liefert alle anderen Daten ff. (diese gehen nicht einzeln abzufragen) System "getSRN":"0000xxxx" Ser.Nr. "getVER": "PontosBaseV1.29" Firmware Version "getTYP":"140" Typ "getCNO": "RDGX62CXxxxxx" Codenummer "getMAC":"0c:73:xxxxxxx" Mac Adresse Profile "getPRF":"1" aktiviertes Profil: hier Anwesend "getPRN":"5" Standardprofile "getPN1": Anwesend Leckage "getPV1": "300" "getPB1":"1" "getPN2": Abwesend Leckage "getPV2":"30" "getPB2":"1" "getPN3": Urlaub Leckage "getPV3":"5" "aetPT3":"5" "aetPB3":"0" "getPN4": ErhoehterVerbrauch" Leckage "getPV4": "5000" "qetPT4":"300" "qetPF4":"5000" "qetPM4":"1" "qetPR4":"0" "aetPB4":"1" "getPN5": MaximalerVerbrauch" Leckage "getPV5":"0" "getPB5":"0" "getPN6":"" "getPV6":"300" "getPT6":"60" "getPF6":"3000" "getPM6":"1" "getPR6":"0" "qetPB6":"1" "getPN7":"" "getPV7":"300" "getPT7":"60" "getPF7":"3000" "getPM7":"1" "getPB7":"1" "getPR7":"0" "getPN8":"" "getPV8":"300" "getPT8":"60" "getPF8":"3000" "getPM8":"1" "getPR8":"0" "getPB8":"1"

Variablen

"getTMP": 0		
"getVLV": 10 Ventil zu / 20 offen	siehe auch: getAB 1 oder 2	

"getCEL": 113			
"getBAR": 6300 mbar	Wasserdruck		
"getNPS": 304			
"getALA": FF			
"getALM": Alarms:->AD FF FF FF FF FF FF			
"getDMA": 1			
"getAVO": 0mL			
"getVOL": Vol[L]196	Gesamtvolumen in Liter		
"get71": 0			
"getBAT": 9,66	Batteriespannung in V		
"getNET": 12,45	Wassertemperatur ?		
"getBUZ": 1			
"getDBD": 10			
"getDBT": 15			
"getDST": 180			
"getDCM": 3		"getWFS": 2	
"getDOM": 60		"getWFR": 4	
"getDPL": 10		"getRTC": 1647548861	Linux Timestamp
"getDTC": 3		"getIDS": 1	
"getDRP": 1		"getTMZ": 4	

Werte setzen: http://192.168.1.xxx:5333/pontos-base/set/

Motorventil

Profil ändern

Profil 1 Anwesend /set/prf/1 nicht getestet
Profil 2 Abwesend /set/prf/2 nicht getestet
Profil 3 Urlaub /set/prf/3 nicht getestet
Profil 4 ErhöhterVerbrauch /set/prf/4 nicht getestet
Profil 5 MaximalerVerbrauch /set/prf/5 nicht getestet

Leckagestufen

```
Profil 1 Anwesend /set/pv1/Wert in Liter geht prinzipiell
Profil 2 Abwesend /set/pv2/
Profil 3 Urlaub /set/pv3/
Profil 4 ErhöhterVerbrauch /set/pv4/
Profil 5 MaximalerVerbrauch /set/pv5/
```

Alarmstatus zurücksetzen /set/clr/ala

/set/ADM/(2)f getestet -> ok (ein Muss zum Auslesen, ohne kommt nichts)

Beispielhafte Auslesewerte vom 21.03., Rot sind die Werte, die sich (kontinuierlich) verändern,

```
Ventil geschlossen
                                         Ventil offen
                                                                                     Ventil offen
[qetTMP] => 0
                                         [qetTMP] => 0
                                                                                     [qetTMP] => 0
    [getVLV] => 10
                                             [getVLV] => 20
                                                                                         [qetVLV] => 20
    [getCEL] => 102
                                             [getCEL] => 106
                                                                                         [getCEL] => 110
    [qetBAR] => 6100 mbar
                                             [getBAR] => 6100 mbar
                                                                                         [qetBAR] => 6300 mbar
                                             [getNPS] => 4
    [qetNPS] => 75
                                                                                         [qetNPS] => 143
    [getALA] => FF
                                             [getALA] => FF
                                                                                         [getALA] => FF
    [getALM] => Alarms:->AD FF FF FF
                                             [getALM] => Alarms:->AD FF FF FF
                                                                                         [getALM] => Alarms:->AD FF FF FF
FF FF FF FF
                                         पप पप पप
                                                                                     पप पप पप
    [qetDMA] => 1
                                             [qetDMA] => 1
                                                                                         [qetDMA] => 1
    [qetAVO] => 0mL
                                             [qetAVO] => 0mL
                                                                                         [qetAVO] => 0mL
    [getVOL] => Vol[L]413
                                             [getVOL] => Vol[L]413
                                                                                         [getVOL] => Vol[L]466
    [get71] => 0
                                                                                         [get71] => 0
                                             [qet71] => 0
    [qetBAT] => 9,57
                                             [qetBAT] => 9,55
                                                                                         [qetBAT] => 9,58
    [getNET] \Rightarrow 12,42
                                             [qetNET] \Rightarrow 12,44
                                                                                         [getNET] => 12,45
    [qetBUZ] => 1
                                             [qetBUZ] => 1
                                                                                         [qetBUZ] => 1
    [qetDBD] => 10
                                             [qetDBD] => 10
                                                                                         [qetDBD] => 10
    [getDBT] => 15
                                             [getDBT] => 15
                                                                                         [getDBT] => 15
    [getDST] => 180
                                             [qetDST] => 180
                                                                                         [qetDST] => 180
    [qetDCM] => 3
                                             [qetDCM] => 3
                                                                                         [getDCM] => 3
    [getDOM] => 60
                                             [qetDOM] => 60
                                                                                         [qetDOM] => 60
    [getDPL] => 10
                                             [getDPL] => 10
                                                                                         [qetDPL] => 10
    [qetDTC] => 3
                                             [qetDTC] => 3
                                                                                         [getDTC] => 3
    [qetDRP] => 1
                                             [qetDRP] => 1
                                                                                         [qetDRP] => 1
    [qetWFS] => 2
                                             [qetWFS] => 2
                                                                                         [qetWFS] => 2
    [getWFR] => 4
                                             [getWFR] => 4
                                                                                         [getWFR] => 4
    [getRTC] => 1647880929
                                             [getRTC] => 1647881147
                                                                                         [qetRTC] => 1647898960
    [qetIDS] => 1
                                             [qetIDS] => 1
                                                                                         [qetIDS] => 1
    [qetTMZ] => 4
                                             [qetTMZ] => 4
                                                                                         [qetTMZ] => 4
```

Syr-Safe ist nicht (immer) komaptibel mit der Pontos-Base!!!!

Ausgänge SYR: (setzen) <VirtualOut Title="Syr Safe Tech Ausgänge" Comment="" Address="http://10.0.0.40:5333" CmdInit="" CloseAfterSend="true"</pre> <VirtualOutCmd Title="Motorventil" Comment="" CmdOnMethod="GET" CmdOffMethod="GET" CmdOn="/safe-tec/set/ab/1" CmdOnHTTP="" CmdOnPost="" CmdOff="/safe-tec/set/ab/2" CmdOffHTTP="" CmdOffPost="" Analog="false" Repeat="0" RepeatRate="0"/> <VirtualOutCmd Title="Profil 1 Anwesend" Comment="" CmdOnMethod="GET" CmdOffMethod="GET" CmdOn="/safe-tec/set/prf/1"</pre> CmdOnHTTP="" CmdOnPost="" CmdOff="" CmdOffHTTP="" CmdOffPost="" Analog="true" Repeat="0" RepeatRate="0"/> <VirtualOutCmd Title="Profil 2 Abwesend" Comment="" CmdOnMethod="GET" CmdOffMethod="GET" CmdOn="/safe-tec/set/prf/2"</pre> CmdOnHTTP="" CmdOnPost="" CmdOff="" CmdOffHTTP="" CmdOffPost="" Analog="true" Repeat="0" RepeatRate="0"/> <VirtualOutCmd Title="Profil 3 Großverbrauch" Comment="" CmdOnMethod="GET" CmdOffMethod="GET" CmdOn="/safetec/set/prf/3" CmdOnHTTP="" CmdOnPost="" CmdOff="" CmdOffHTTP="" CmdOffPost="" Analog="true" Repeat="0" RepeatRate="0"/> <VirtualOutCmd Title="Leckagestufe Profil 3" Comment="" CmdOnMethod="GET" CmdOffMethod="GET" CmdOnHTTP="/safe-</pre> tec/set/pv3/<v>" CmdOnPost="" CmdOff="" CmdOffHTTP="" CmdOffPost="" Analog="true" Repeat="0" RepeatRate="0"/> <VirtualOutCmd Title="Leckagestufe Profil 2" Comment="" CmdOnMethod="GET" CmdOffMethod="GET" CmdOn="" CmdOnHTTP="/safetec/set/pv2/<v&qt; "CmdOnPost=""CmdOff=""CmdOffHTTP=""CmdOffPost=""Analog="true"Repeat="0"RepeatRate="0"/> <VirtualOutCmd Title="Leckagestufe Profil 1" Comment="" CmdOnMethod="GET" CmdOffMethod="GET" CmdOn="aktivieren" CmdOnHTTP="/safe-tec/set/pv1/<v>" CmdOnPost="" CmdOff="" CmdOffHTTP="" CmdOffPost="" Analog="true" Repeat="0" RepeatRate="0"/> <VirtualOutCmd Title="Alarm löschen" Comment="" CmdOnMethod="GET" CmdOffMethod="GET" CmdOn="/safe-tec/set/clr/ala"</pre> CmdOnHTTP="" CmdOnPost="" CmdOff="" CmdOffHTTP="" CmdOffPost="" Analog="false" Repeat="0" RepeatRate="0"/> <VirtualOutCmd Title="Admin Rechte setzen" Comment="" CmdOnMethod="GET" CmdOffMethod="GET" CmdOn="/safetec/set/ADM/(2)f" CmdOnHTTP="" CmdOnPost="" CmdOff="" CmdOffHTTP="" CmdOffPost="" Analog="false" Repeat="0" RepeatRate="0"/> </VirtualOut>

Eingänge SYR: (auslesen)

<VirtualInHttp Title="Syr Safe Tech Eingänge" Comment="" Address="http://10.0.0.40:5333/safe-tec/get/all" PollingTime="10">

<VirtualInHttpCmd Title="Status Motorventil" Comment="" Check=""getAB":"\v" Signed="true" Analog="true"
SourceValLow="1" DestValLow="1" SourceValHigh="0" DestValHigh="0" MinVal="-10000" MaxVal="10000"/>

<VirtualInHttpCmd Title="Leitwertsensor" Comment="" Check=""getCND":"\v" Signed="true" Analog="true"
SourceValLow="0" DestValLow="0" SourceValHigh="100" DestValHigh="100" DefVal="0" MinVal="-10000" MaxVal="10000"/>

```
<VirtualInHttpCmd Title="Aktueller Durchfluss" Comment="" Check="&quot;qetFLO&quot;:&quot;\v" Signed="true"
Analog="true" SourceValLow="0" DestValLow="0" SourceValHigh="100" DestValHigh="100" DefVal="0" MinVal="-10000" MaxVal="10000"/>
       <VirtualInHttpCmd Title="Gesamtvolumen" Comment="" Check="&quot;getVOL&quot;:&quot;Vol[L]\v" Signed="true" Analog="true"
SourceValLow="0" DestValLow="0" SourceValHigh="100" DestValHigh="100" DefVal="0" MinVal="-10000" MaxVal="10000"/>
       <VirtualInHttpCmd Title="aktiviertes Profil" Comment="" Check="&quot;getPRF&quot;: &quot;\v" Signed="true" Analog="true"
SourceValLow="0" DestValLow="0" SourceValHigh="100" DestValHigh="100" DefVal="0" MinVal="-10000" MaxVal="10000"/>
       <VirtualInHttpCmd Title="Systemtemperatur" Comment="" Check="&guot;getCEL&guot; \v" Signed="true" Analog="true"
SourceValLow="0" DestValLow="0" SourceValHigh="100" DestValHigh="10" DefVal="0" MinVal="-10000" MaxVal="10000"/>
       <VirtualInHttpCmd Title="WiFi RSSI" Comment="" Check="&quot;qetWFR&quot;: &quot; \v" Signed="true" Analog="true"
SourceValLow="0" DestValLow="0" SourceValHigh="100" DestValHigh="100" DefVal="0" MinVal="-10000" MaxVal="10000"/>
       <VirtualInHttpCmd Title="Wasserdruck" Comment="" Check="&quot;qetBAR&quot;:&quot;\v" Signed="true" Analog="true"
SourceValLow="0" DestValLow="0" SourceValHigh="100" DestValHigh="0.1" DefVal="0" MinVal="-10000" MaxVal="10000"/>
       <VirtualInHttpCmd Title="Batteriespannung" Comment="" Check="&quot;getBAT&quot;:&quot;\v" Signed="true" Analog="true"</pre>
SourceValLow="0" DestValLow="0" SourceValHigh="100" DestValHigh="100" DefVal="0" MinVal="-10000" MaxVal="10000"/>
       <VirtualInHttpCmd Title="letzte Entnahme" Comment="" Check="&quot;getLTV&quot;: &quot; \v" Signed="true" Analog="true"
SourceValLow="0" DestValLow="0" SourceValHigh="100" DestValHigh="100" DefVal="0" MinVal="-10000" MaxVal="10000"/>
       <VirtualInHttpCmd Title="Aktueller Alarm Stelle 1" Comment="" Check="&quot;qetALA&quot;: &quot; \1" Signed="true"
Analog="true" SourceValLow="0" DestValLow="0" SourceValHigh="100" DestValHigh="100" DefVal="0" MinVal="-10000" MaxVal="10000"/>
       <VirtualInHttpCmd Title="Aktueller Alarm Stelle 2" Comment="" Check="&quot;qetALA&quot;:&quot;\s1\1" Signed="true"
Analog="true" SourceValLow="0" DestValLow="0" SourceValHigh="100" DestValHigh="100" DefVal="0" MinVal="-10000" MaxVal="10000"/>
```

</VirtualInHttp>