



TITLE:

**Engineering Progress
Measurement in EPC Projects:
Moving Beyond Subjective
Percentages**

Athor:

**Behzad Mousavi, MSc in Industrial Engineering
Planning & Project Control Specialist**

Abstract

Engineering progress is the foundation of any EPC project, yet it remains the most difficult phase to measure accurately. Traditional methods relying on subjective "% complete" estimates often lead to inflated progress reports, delayed procurement, and costly rework during construction. This article presents a rigorous, rule-based framework for measuring engineering progress in industrial oil, gas, and petrochemical projects. Drawing on 25+ years of field experience in Iran's energy sector, we introduce the Weighted Milestone Method, discipline-specific measurement rules, and integration techniques with Primavera P6 and Excel-based tools. Whether managing FEED, detailed design, or as-built documentation, this guide provides the blueprint for transforming engineering tracking from an art into a science—ensuring accurate forecasting, reliable cash flow, and seamless handover to construction.

1. Introduction: The Illusion of Engineering Progress

In industrial EPC contracting, engineering is not merely a preliminary phase; it is the driver of all downstream activities. Procurement cannot issue POs without approved datasheets. Construction cannot erect steel without released drawings. Commissioning cannot begin without P&IDs and loop diagrams. Yet, despite its criticality, engineering progress is frequently measured using flawed methodologies.

The most common pitfall is the "Gut Feeling" Approach: asking lead engineers "How far along are you?" and accepting answers like "About 70%." This subjective method ignores complexity variations—a simple pipe support drawing may take 2 hours, while a complex compressor package datasheet may require 3 weeks of vendor coordination. Treating them equally distorts reality.

Another widespread error is the "Document Count" Fallacy: assuming that issuing 70 out of 100 drawings equals 70% progress. This ignores review cycles, inter-discipline checks, client approval delays, and the fact that some documents carry exponentially more weight than others.

These inaccuracies compound over time, creating a "progress bubble" that bursts when construction teams arrive on site to find missing deliverables. In high-stakes environments like South Pars or Assaluyeh, where schedule slippage triggers liquidated damages, such illusions are financially catastrophic.

This article moves beyond vague percentages to establish a quantitative, auditable, and contract-compliant measurement system. Our focus is on creating transparency that protects margins, enables accurate forecasting, and builds trust with clients.

2. The Gold Standard: Weighted Milestone Method (WMM)

For industrial projects, the Weighted Milestone Method is universally recognized as best practice (endorsed by CII, AACE, and major oil companies). Unlike time-phased or document-count methods, WMM ties progress to tangible, verifiable completion points within each deliverable's lifecycle.

How It Works:

Each engineering deliverable (drawing, calculation, specification) is broken down into discrete milestones, each assigned a pre-defined weight reflecting effort and value. Typical milestones include:

Milestone

Description

Typical Weight Range

Verification Criteria

M1

Issued for Internal Review (IFR)

10-15%

Document uploaded to DMS; internal check sheet completed

M2

Issued for Client Review (ICR)

20-25%

Transmittal sent; client acknowledgment received

M3

Approved / Code A

30-40%

Client approval stamp; no outstanding comments

M4

Issued for Construction (IFC)

20-25%

Final revision released; construction team notified

M5

As-Built / Closeout

5-10%

Redlines incorporated; final archive completed

Critical Insight: Weights must be calibrated per discipline and document type. A P&ID might have M3=35%, while a civil foundation detail might have M3=25%. Never apply uniform weights across all deliverables.

Why WMM Outperforms Alternatives:

Objectivity: Progress is binary (milestone achieved or not)—no interpretation needed.

Cash Flow Alignment: Milestones can be mapped to payment terms (e.g., 25% upon ICR, 50% upon Approval).

Early Warning: Stalled documents at M2 immediately flag bottlenecks before they impact construction.

Auditability: Every % claim is backed by transmittals, approvals, or DMS timestamps.

3. Discipline-Specific Measurement Rules

Industrial projects involve multiple engineering disciplines, each with unique workflows. Generic rules fail; tailored approaches succeed.

Process Engineering

Focus on data maturity and approval gates:

PFDs: 40% upon client approval; 60% upon HAZOP closure.

P&IDs: 30% IFR → 30% ICR → 30% Approved → 10% As-Built.

Line Lists: 50% upon freeze; 50% upon incorporation into P&IDs.

Piping Engineering

Driven by model maturity and deliverable issuance:

3D Model: 20% Clash-Free → 30% Stress Analysis Complete → 30% ISO Generation → 20% IFC.

Isometrics: 40% Draft → 30% Check → 30% Release.

Material Take-Off (MTO): 100% only after model freeze—not before.

Civil & Structural

Tied to constructability and permitting:

Foundation Designs: 50% upon geotech report integration; 50% upon structural calc approval.

Steel Details: 60% upon connection design sign-off; 40% upon fabrication drawing release.

Underground Utilities: 100% only after clash detection with piping/electrical.

Electrical & Instrumentation

Linked to equipment procurement and loop integrity:

Cable Schedules: 70% upon equipment datasheet approval; 30% upon routing confirmation.

Loop Diagrams: 100% only after field verification—not just desk completion.

Load Lists: 50% preliminary; 50% final after motor sizing confirmation.

⚠ Pro Tip: Create a "Measurement Rule Matrix" for each discipline during project setup. Get client approval upfront to prevent disputes during progress certification.

4. Integrating Engineering Measurement with Project Controls

Engineering progress doesn't exist in isolation. It must feed directly into scheduling, cost control, and procurement.

Schedule Integration (Primavera P6)

Assign WMM milestones as activity steps or separate activities with FS relationships.

Use activity codes to filter by discipline, milestone status, or approval code.

Link engineering completion to procurement start dates (e.g., "Pump Datasheet Approved" → "Issue RFQ").

Cost & Earned Value Integration

Map WMM weights to budgeted costs per deliverable.

Calculate EV automatically: $EV = \text{Budget} \times \% \text{ Complete (from WMM)}$.

Track CPI/SPI specifically for engineering—don't blend with construction metrics.

Procurement Trigger Points

Define "Procurement Ready" criteria explicitly (e.g., "Datasheet Code A + Requisition Approved").

Monitor engineering-to-procurement lag weekly; >2-week delay = red flag.

Use engineering progress dashboards to forecast material arrival dates realistically.

5. Common Pitfalls & Mitigation Strategies

Even well-designed systems fail due to human factors. Here are top failures observed in Iranian EPC projects:

Pitfall

Consequence

Mitigation Strategy

Backdating Approvals

Inflated progress; false sense of security

Enforce real-time DMS logging; audit transmittal dates vs. claimed dates

Ignoring Review Cycles

Documents stuck in "Code B/C" counted as complete

Only count "Code A" as full milestone; track rejection rates separately

Overlooking Inter-Discipline Checks

Rework during construction due to clashes

Mandate IDC sign-off as prerequisite for IFC milestone

Manual Tracking Spreadsheets

Version conflicts; delayed updates

Implement macro-enabled Excel tools or integrated PMS software

Client Approval Delays Ignored

Progress stalled but not reported

Track "Pending Client Action" as separate KPI; escalate weekly

💡 Golden Rule: If it isn't documented in the DMS or transmittal log, it didn't happen. No exceptions.

6. Digital Enablement: Automating Engineering Tracking

Manual WMM tracking is unsustainable for large projects. Prioritize automation for:

DMS Integration: Auto-update milestone status when documents reach specific workflow states.

Progress Calculation Engines: Apply weights automatically based on document type and milestone achievement.

Dashboard Visualization: Show real-time % complete by discipline, overdue approvals, and procurement readiness.

Alert Systems: Notify leads when documents exceed review cycle SLAs.

Every hour saved on manual tracking is an hour gained for quality assurance and interdisciplinary coordination.

7. Case Study: Fixing Engineering Visibility on a Petrochemical Plant

On a \$600M ethylene plant in Bandar Abbas, engineering progress was tracked via monthly engineer surveys. Result: reported 85% complete at month 18, but construction found 40% of critical path drawings missing or unapproved.

Intervention:

Implemented WMM with discipline-specific weights approved by client.

Deployed macro-enabled Excel tool integrating DMS exports with P6 schedule.

Established weekly "Engineering Health Check" meetings focused solely on milestone aging.

Linked engineering progress to procurement trigger points in dashboard.

Results After 6 Months:

Reported progress aligned with physical reality within $\pm 3\%$.

Overdue approvals reduced by 70% through proactive escalation.

Procurement delays decreased by 45% due to earlier visibility.

Client trust restored; progress payments certified without dispute.

This transformation wasn't about new software—it was about disciplined application of objective measurement principles enabled by purpose-built tools.

8. Conclusion: Engineering Progress as a Leading Indicator

Engineering progress measurement is not administrative overhead; it is your earliest warning system for project health. Accurate tracking enables proactive intervention, reliable forecasting, and confident stakeholder communication.

Adopt the Weighted Milestone Method. Calibrate rules per discipline. Integrate with schedule and cost systems. And remember: the goal isn't perfect reporting—it's preventing surprises.

Your engineering measurement system is your project's early radar. Make it precise, make it trusted, and make it actionable.

9. Elevate Your Engineering Control Today

Developing a robust engineering measurement system from scratch requires significant expertise and calibration. Why start from zero when proven solutions exist?

For more technical articles, training materials, and professional resources, visit our page in GitHub as a link below:

- <https://sbmousavices.github.io/industrial-Tools>

Copyright Notice: © 2026 Behzad Mousavi. All rights reserved. This article may be shared for educational purposes with proper attribution. Commercial use requires written permission from the author.