

Ashley's Murphy bed - store shopping list

Queen horizontal bed (86-3/4 in) + left bookcase (30 in). Check each box as it goes in the cart.

Planning quantities from the project bill of materials. Confirm the slide model, pull centers and shelf pins against the build guide before buying hardware.

LUMBER - buy full sheets; the sheet layout assumes full 4 x 8 ft sheets

- | | |
|---|--|
| ☐ 6 sheets 3/4 in plywood, 4 x 8 ft | Cabinet-grade, veneer core. No MDF, particleboard or melamine. |
| ☐ 1 project panel 1/2 in plywood, 2 x 4 ft | For the drawer box. Cabinet-grade. |
| ☐ 1 sheet 1/4 in plywood, 4 x 8 ft | Bookcase back and drawer bottom. |

HARDWARE

- | | |
|--|---|
| ☐ 1 pair 14 in drawer slides | Full-extension, side-mount, ball-bearing; needs 1/2 in per side. |
| ☐ 20 shelf pins, 5 mm | Steel, flat or spoon style. 12 needed + spares. |
| ☐ 3 black bar pulls, about 6 in centers | Two for the bed doors, one for the drawer. Check screws are included. |
| ☐ 1 furniture anti-tip kit | For the bookcase, rated for wood studs. Extra to the bed anchors. |
| ☐ Optional: 4 connector bolt sets | Joins bed and bookcase sides (about 1-1/2 in total). Not a wall anchor. |

FASTENERS, GLUE & SHIMS

- | | |
|--|--|
| ☐ 100 #8 x 2 in wood screws | Wood or cabinet screws, not drywall screws. |
| ☐ 100 fluted dowels, 3/8 x 1-1/2 in | Hardwood. 22 for the bed, 28 for the bookcase, rest spare. |
| ☐ 25 #8 x 1-1/4 in wood screws | Permanent stop. |
| ☐ 50 #6 x 1-1/4 in wood screws | Drawer box corners. |
| ☐ 25 #8 x 1 in washer-head wood screws | Drawer face. |
| ☐ 100 #6 x 3/4 in pan or washer-head screws | Bookcase back into its rabbet; drawer bottom. |
| ☐ 1 bottle wood glue, 16 oz | Interior PVA. |
| ☐ 1 small bottle removable threadlocker | Blue / removable strength. |
| ☐ 1 pack hard cabinet shims | Plastic or composite, not soft wood. |

PAINT & FINISHING

- | | |
|---|---|
| ☐ 1 quart paintable wood filler | Sandable; for plywood edges and screw holes. |
| ☐ 1 gallon primer | Suited to plywood and the enamel you choose. |
| ☐ 2 gallons navy cabinet enamel | Match #182B49; check a dried sample first. |
| ☐ Optional: 1 quart clear water-based finish | Drawer box only. |
| ☐ 3 packs sandpaper: 120, 180, 220 grit | Match your sander. |
| ☐ Painting supplies | Brushes/rollers, tray liners, masking tape, drop cloth, rags. |

TOOLS - only if you do not already have them or cannot borrow them

- | | |
|---|---|
| ☐ 8 mm Allen key | Drives the threaded inserts. The kit does not include this size. |
| ☐ 3/8 in doweling jig + dowel centers | Self-centering jig for edge holes; a set of dowel centers to mark the mating faces. |
| ☐ Drill bits | 3/8 brad-point with depth collar; 5/64, 1/8, 5/32, 3/16, 13/64, 5/16, 27/64 in; #8 countersink. |
| ☐ Plywood blade, straightedge, rabbeting bit | 40-tooth+ circular saw blade; 8 ft straightedge or track; bearing-guided 3/8 in rabbeting bit. |
| ☐ 4 bar or pipe clamps, 36 in+ | Bookcase glue-up. Plus square, level, stud finder. Do not use an impact driver. |

NOT FROM THIS STORE

- | | |
|--|--|
| ☐ Rockler I-Semble HORIZONTAL QUEEN bed kit | Rockler only. Not a vertical kit. |
| ☐ Queen mattress (you supply) | 60 x 80 in, 10 in thick max, 132 lb max, not foam or very light. |

BEFORE CHECKOUT

- | |
|--|
| ☐ Sheets lie flat, faces have no dents or splits, and edges show no large voids. |
| ☐ Measure one sheet of each thickness with calipers and write it down; it sets final joinery and fit. |
| ☐ Pulls and slides: check the screws are in the package before leaving. |