```
标签: arm,uboot,启动,bootloader
【原创】uboot-2009.01——lowleve_init.S分析
        lowleve_init.S分析
* Memory Setup stuff - taken from blob memsetup.S
* Copyright (C) 1999 2000 2001 Erik Mouw (J.A.K.Mouw@its.tudelft.nl) and
           Jan-Derk Bakker (J.D.Bakker@its.tudelft.nl)
* Modified for the Samsung SMDK2410 by
* (C) Copyright 2002
* David Mueller, ELSOFT AG, <d.mueller@elsoft.ch>
* See file CREDITS for list of people who contributed to this
* project.
* This program is free software; you can redistribute it and/or
* modify it under the terms of the GNU General Public License as
* published by the Free Software Foundation; either version 2 of
* the License, or (at your option) any later version.
* This program is distributed in the hope that it will be useful,
* but WITHOUT ANY WARRANTY; without even the implied warranty of
* MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
* GNU General Public License for more details.
* You should have received a copy of the GNU General Public License
* along with this program; if not, write to the Free Software
* Foundation, Inc., 59 Temple Place, Suite 330, Boston,
* MA 02111-1307 USA
*/
#include <config.h>
#include <version.h>
/* some parameters for the board */
* Taken from linux/arch/arm/boot/compressed/head-s3c2410.S
* Copyright (C) 2002 Samsung Electronics SW.LEE <hitchcar@sec.samsung.com>
*/
@我的开发板上的SDRAM为:HY57V561620FTP-H,4Mx16bitx4Banks,两片接成32bit,64MB,接在BANK6上,地址范围为:[0x3000
0000-0x33ffffff]
@(还没搞清楚SDRAM的结构,为什么要分成Banks,改天看下相关的文档研究一下)
```

```
@对于SDRAM的初始化是要配置13个寄存器,好像多采用循环方式。
#define BWSCON 0x48000000
@BWSCON寄存器地址,控制每个总线
/* BWSCON */
#define DW8 (0x0)
#define DW16 (0x1)
#define DW32 (0x2)
@将用来设置位宽的三个宏
#define WAIT (0x1<<2)
#define UBLB (0x1<<3)
@将用来设置wait和ublb的宏
#define B1_BWSCON (DW32)
#define B2_BWSCON (DW16)
#define B3_BWSCON (DW16 + WAIT + UBLB)
#define B4_BWSCON (DW16)
#define B5_BWSCON (DW16)
@BANK2、BANK3、BANK4、BANK5为什么配成16bit总线宽度,而且BANK3还要加上WAIT和UBLB属性没有搞明白,感觉如果没用
到的话可以配成默认值的吧?
#define B6_BWSCON (DW32)
#define B7_BWSCON (DW32)
@我板子的SDRAM接在BANK6, 所以配成32bit位宽, BANK7按datasheet的要求配置的和BANK6相同
@分别配置每个BANK的BANKCON寄存器,这里应该根据SRAM的手册来配置相应的BANK,BANK0~5主要是配置一些时序参数
/* BANK0CON */
#define B0 Tacs 0x0 /* 0clk */
#define B0_Tcos 0x0 /* 0clk */
#define B0_Tacc 0x7 /* 14clk */
#define B0_Tcoh 0x0 /* 0clk */
#define B0_Tah 0x0 /* 0clk */
#define B0 Tacp 0x0
#define B0_PMC 0x0 /* normal */
/* BANK1CON */
#define B1_Tacs 0x0 /* 0clk */
#define B1_Tcos 0x0 /* 0clk */
#define B1_Tacc 0x7 /* 14clk */
#define B1_Tcoh 0x0 /* 0clk */
#define B1_Tah 0x0 /* 0clk */
#define B1_Tacp 0x0
#define B1_PMC 0x0
#define B2_Tacs 0x0
#define B2_Tcos 0x0
#define B2_Tacc 0x7
#define B2_Tcoh 0x0
#define B2 Tah 0x0
#define B2_Tacp 0x0
#define B2_PMC 0x0
```

```
@这里BANK3CON不为默认值,是因为在SMDK2410上BANK3上应该接了ROM
@根据我自己的板子,我把这里换成了默认值(根据vivi上的默认值修改的),不过要不是默认值的话应该也没有影响的吧?我的板子这
里接了DM9000A
#define B3 Tacs 0x0 /* 0clk */
#define B3_Tcos 0x3 /* 4clk */
#define B3_Tacc 0x7 /* 14clk */
#define B3_Tcoh 0x1 /* 1clk */
#define B3_Tah 0x0 /* 0clk */
#define B3_Tacp 0x3 /* 6clk */
#define B3_PMC 0x0 /* normal */
#define B4_Tacs 0x0 /* 0clk */
#define B4_Tcos 0x0 /* 0clk */
#define B4_Tacc 0x7 /* 14clk */
#define B4_Tcoh 0x0 /* 0clk */
#define B4_Tah 0x0 /* 0clk */
#define B4_Tacp 0x0
#define B4 PMC 0x0 /* normal */
#define B5 Tacs 0x0 /* 0clk */
#define B5_Tcos 0x0 /* 0clk */
#define B5_Tacc 0x7 /* 14clk */
#define B5 Tcoh 0x0 /* 0clk */
#define B5_Tah 0x0 /* 0clk */
#define B5_Tacp 0x0
#define B5_PMC 0x0 /* normal */
@配置SDRAM的参数,BANK6和BANK7要配置成同样的值,需要查看SDRAM的datasheet
@当内存为ROM或SRAM时需要配置所有位, 当为SDRAM时只要配置[0~3]
#define B6_MT 0x3 /* SDRAM */
@内存类型,默认为SDRAM
#define B6_Trcd 0x1
@RAS到CAS的延时
#define B6_SCAN 0x1 /* 9bit */
@列扫描数,在SDRAM手册上,有一句: C0~C8即为9列
#define B7_MT 0x3 /* SDRAM */
#define B7 Trcd 0x1 /* 3clk */
#define B7_SCAN 0x1 /* 9bit */
/* REFRESH parameter */
@SDRAM刷新参数,这个很重要,移植时要更改
#define REFEN 0x1 /* Refresh enable */
@默认为允许刷新
#define TREFMD 0x0 /* CBR(CAS before RAS)/Auto refresh */
@据说下面三个时间参数多是根据经验来设置
#define Trp 0x0 /* 2clk */
@RAS precharge Time
#define Trc 0x3 /* 7clk */
@根据S3C2440的datasheet为: Trc=Tsrc+Trp, 但寄存器中要填入的是Tsrc, 这里仿佛应该设为10个时钟才对?
```

```
#define Tchr 0x2 /* 3clk */
@SDRAM手册上没有找到这个时钟的定义
#define REFCNT 1113 /* period="15".6us, HCLK="60Mhz", (2048+1-15.6*60) */
@SDRAM刷新计数值,这个值比较重要,根据SDRAM的datasheet, (我使用的这款芯片在datasheet写着8192Refresh cycle/64ms,
所以一个刷新周期为64ms/8192=7.8125us,取7.9的话REFCNT的值就为1259)
/**************************/
_TEXT_BASE:
.word TEXT_BASE
@这里开始lowlevel_init函数了,通过循环连续初始化13个寄存器
.globl lowlevel_init
lowlevel_init:
/* memory control configuration */
/* make r0 relative the current location so that it */
/* reads SMRDATA out of FLASH rather than memory! */
ldr r0, =SMRDATA
ldr r1, _TEXT_BASE
@r1放代码段的开始位置
sub r0, r0, r1
 //计算SMRDATA的相对地址保存到R0中
 //SMRDATA为虚拟地址,而TEXT_BASE为虚拟地址的起始地址
 //而现在Uboot的起始地址并不为虚拟地址
 //TEXT_BASE为0x33F8 0000,SMRDATA为0x33F8 06C8
 //而现在程序运行在起始地址为0x0000 0000的地方
 //所以需要计算以0x0000 0000为标准的相对地址
(参考uboot-1.3.0-rc3引导启动学习笔记,这一段确实要好好理解)
ldr r1, =BWSCON /* Bus Width Status Controller */
add r2, r0, #13*4
@13个寄存器,每个寄存器占4个字节
@读取一个值存入寄存器中,然后循环,直到读完13个寄存器
0:
ldr r3, [r0], #4
str r3, [r1], #4
cmp r2, r0
bne
/* everything is fine now */
mov pc, Ir
@程序返回到cpu_init_crit中
.ltorg
/* the literal pools origin */
SMRDATA:
 .word (0+(B1_BWSCON<<4)+(B2_BWSCON<<8)+(B3_BWSCON<<12)+(B4_BWSCON<<16)+(B5_BWSCON<<20)+(B6_BWSCON
N<<24)+(B7_BWSCON<<28))
@设置每个BWSCON,注意BANKO由硬件连线决定了。
 .word \ ((B0\_Tacs<<13) + (B0\_Tcos<<11) + (B0\_Tacc<<8) + (B0\_Tcoh<<6) + (B0\_Tah<<4) + (B0\_Tacp<<2) + (B0\_PMC))
 .word ((B1_Tacs<<13)+(B1_Tcos<<11)+(B1_Tacc<<8)+(B1_Tcoh<<6)+(B1_Tah<<4)+(B1_Tacp<<2)+(B1_PMC))
```

```
.word \ ((B2\_Tacs<<13) + (B2\_Tacs<<11) + (B2\_Tacc<<8) + (B2\_Tach<<6) + (B2\_Tah<<4) + (B2\_Tacp<<2) + (B2\_PMC))
 .word \; ((B3\_Tacs<<13) + (B3\_Tacs<<11) + (B3\_Tacc<<8) + (B3\_Tach<<6) + (B3\_Tach<<4) + (B3\_Tacp<<2) + (B3\_PMC)) \\
 .word \; ((B4\_Tacs<<13) + (B4\_Tacs<<11) + (B4\_Tacc<<8) + (B4\_Tach<<6) + (B4\_Tach<<4) + (B4\_Tacp<<2) + (B4\_PMC)) \\
  .word ((B5_Tacs<<13)+(B5_Tcos<<11)+(B5_Tacc<<8)+(B5_Tcoh<<6)+(B5_Tah<<4)+(B5_Tacp<<2)+(B5_PMC))
@设置BANKCON0~BANKCON5
 .word ((B6_MT<<15)+(B6_Trcd<<2)+(B6_SCAN))
 .word ((B7_MT<<15)+(B7_Trcd<<2)+(B7_SCAN))
@ 设置BANKCON6~BANKCON7
 .word ((REFEN<<23)+(TREFMD<<22)+(Trp<<20)+(Trc<<18)+(Tchr<<16)+REFCNT)
@设置REFRESH,在S3C2440中11~17位是保留的,也即(Tchr<<16)无意义
  .word 0x32
@设置BANKSIZE,对于容量可以设置大写,多出来的空内存会被自动检测出来。没有搞明白突发模式操作是什么意思!
 .word 0x30
@设置MRSRB6
 .word 0x30
@设置MRSRB7
系统分类: ARM | 用户分类: 嵌入式 | 来源: 无分类 | 【推荐给朋友】 | 【添加到收藏夹】
该用户于2009/7/11 12:25:23编辑过该文章
```