ECE 3731: Microproc & Embedded Sys Lab

Lab 5: External Interrupts Parallel



July 26th, 2018

Summer 2018

Honor Code: I have neither given nor received unauthorized assistance on this graded report.

x Brian Vera-Burgos x Srinivas Simhan

Table of Contents

Objective	3
Equipment Used	3
Pre-Lab	4
Pre-Lab Question 1	4
Pre-Lab Question 2	4
Flowchart for Pre-Labs	5
Procedure/ Full Code	6
Part A: User presses PTH3	6
Part A Full Code	6
Part B: User presses PTH2	13
Part B Full Code	14
Post-Lab	22
Question 1	22
Question 2	22
Question 3	22
Question 4	22
Question 5	23
Conclusion	25
Pre-Lab	25
In-Lab	25
Post-I ah	25

Objective

- To become familiar with CodeWarrior
- To become familiar with HCS Dragon12-Light
- To become familiar with setting up interrupts to be controlled by PORTH
- To become familiar with "polling" interrupt flags
- To understand and create flowcharts to be used in explanations in terms of documentation for our code

Equipment Used

- CodeWarrior
- HCS Dragon12-Light

Pre-Lab

1. Pre-Lab Question 1

a. The purpose of question 1 of the Pre-Lab was to write a program which flashes the Blue LED 10 times with on time of 0.25 seconds and an off time of 0.25 seconds. When the user pushes PH0, the code clear the RBG value, then sets it to blue, then delays it for 250ms, then clears it again, then delays for 250ms, then checks a counter set by register A, and repeats accordingly.

```
i. Main Code for Part 1:
```

```
;-----BLINK BLUE 10 FUNCTION------
PH0FCN
LDAA #$A
REPEAT:
bclr PTP, RED+GREEN+BLUE
bset PTP, BLUE
jsr DELAY_250_MS ; delay for 250 milisecods
bclr PTP, RED+GREEN+BLUE ; clear all
jsr DELAY_250_MS ; delay for 250 milisecods
DECA
CMPA #0
BNE REPEAT
JSR DELAY_1_S
RTS
```

2. Pre-Lab Question 2

a. The purpose of question 2 of the Pre-Lab was to write a program that decrements a 4-bit counter on PORTB, and when the value of zero is reached and the counter is decremented, it becomes a 1111. When the user pushes PH1, the code loads the value of #\$Finto register A and sets that to PORTB, then delays by 250ms, then decreases the value until it hits 0, and if that happens it then reloads the A register with #\$F, and repeats accordingly.


```
i. Main Code for Part 2:
```

```
;-----Decrement 4-bit counter on PORTB------
PH1FCN
    LDAA #$F ;decrement
YOLO
    STAA PORTB
    JSR DELAY_250_MS
    DECA
    BNE YOLO

BRA PH1FCN
```

3. Flowchart for Pre-Labs

a.



Procedure/ Full Code

- Part A: User presses PTH3
 - Explanation of Code:
 - The Mainloop of the program continuously calls a subroutine that will blink the green RGB 10 times before restarting
- 1) If the first interrupt is called then the program will call a subroutine to look at the four dip switches and store their position (Up or down) on PORTB. It checks the position of the dip switches using the election subroutine from class. The program will also use the LCD on the dragon-12 board to print out "SW0 is Pressed".
- 2) If the second interrupt is called then the program will call a subroutine to increment PORTB by one and then blink the blue RGB 4 times with a 250 ms delay. The program will overflow to zero if it increments 1111. The program will also use the LCD on the dragon-12 board to print out "SW1 is Pressed".
- 3) If the third interrupt is called then the program will call a subroutine to decrement PORTB by one and then blink the RED RGB 5 times with a 200 ms delay. The program will overflow to 1111 if it decrements on 0000. The program will also use the LCD on the dragon-12 board to print out "SW2 is Pressed".
- 4) If the fourth interrupt is called then the program will call a subroutine that will print out the multiplication table of 5 up to 5*10 onto the terminal. The program will also use the LCD on the dragon-12 board to print out "SW4 is Pressed".

Part A Full Code

```
ORG RAMStart ; loc $1000 (RAMEnd = $3FFF)
; Insert here your data definitions here
SWOPROMPT dc.b $0A, $0D ; CR LF
      dc.b "SW0 is Pressed"
      dc.b 0 ; using zero terminated strings
SW1PROMPT dc.b $0A, $0D ; CR LF
      dc.b "SW1 is Pressed"
      dc.b 0 ; using zero terminated strings
SW2PROMPT dc.b $0A, $0D; CR LF
      dc.b "SW2 is Pressed"
      dc.b 0 ; using zero terminated strings
SW3PROMPT dc.b $0A, $0D ; CR LF
      dc.b "SW3 is Pressed"
      dc.b 0 ; using zero terminated strings
;These are the variables used in the fourth button
INPUT_NUM dc.b $35 ;Permenant storage of users input number
COUNT_NUM dc.b $0 ;Temperary storage for count number
MULT_NUM dc.b $0 ;Starting value for multiplication
TENS_VAL dc.b $0 ;Temperary storage for the tens place decimal value in DEC_PRINT
ONES_VAL dc.b $0 ;Temperary storage for the once place decimal value in DEC_PRINT
   INCLUDE 'utilities.inc'
   INCLUDE 'LCD.inc'
; Code Section
      ORG ROMStart; loc $2000
Entry:
_Startup:
      ; remap the RAM & amp; EEPROM here. See EB386.pdf
ifdef _HCS12_SERIALMON
      ; set registers at $0000
      CLR $11
                       ; INITRG= $0
      ; set ram to end at $3FFF
      LDAB #$39
      STAB $10
                       ; INITRM= $39
      ; set eeprom to end at $0FFF
      LDAA #$9
      STAA $12
                       ; INITEE= $9
      JSR PLL_init ; initialize PLL
 endif
; Insert your code here
;-----
    LDS #ROMStart; load stack pointer
* Port H interrupt program for Dragon12
* Lights LED 0 (and clears LED1) when sw5 is pressed (PH0)
* Lights LED 1 (and clears LED0) when sw4 is pressed (PH1)
     jsr led_enable ;Initialize LEDS
```

```
jsr TermInit ;Initialize the code warrior terminal
    bset DDRM, 4 ; make PM2 an output
    bclr PTM, 4 ; make PM2 low to enable RGB
    bset DDRP, RED+GREEN+BLUE; make pp4-pp6 outputs
; note Port H is all inputs after reset
    jsr lcd_init ; initialize LCD (must be done first)
    BCLR PPSH, #$0F; set Port H pins 0-1 for falling edge
    MOVB #$0F, PIFH ; clear interrupt flags initially
    BSET PIEH, $0F; enable interrupts on Port H pins 0-1
    CLI
                ; enable interrupts
RESTRARTGRN
    JSR Flash Green Led
    BRA RESTRARTGRN
                            ; endless loop waiting for reset (and for interrupts)
; Note: main program is an endless loop and subroutines follow
; (Must press reset to quit.)
; ISR must test to see which button was pressed, because there ;is only one ISR for the two enabled buttons
PTHISR: ; the interrupt service routine
    BRSET PIFH, %00000001, PUSHBTN0 ; test btn0 IF flag
    BRSET PIFH, %00000010, PUSHBTN1; test btn1 IF flag
    BRSET PIFH, %00000100, PUSHBTN2; test btn2 IF flag
    BRSET PIFH, %00001000, PUSHBTN3; test btn3 IF flag
; NOTE: Flags are tested -not the switches
   JMP DONE
:-----INTERRUPTS
PUSHBTN0:
    bclr PTP, RED+GREEN+BLUE; clear all
    LDD #SW0PROMPT ;Load LCD Prompt
    JSR clear lcd ;Clear anything else off of LCD
    JSR Icd_prtstrg;Print LCD prompt
    JSR ELECTION
    jsr DELAY_1_S ; delay for 1 second
    JMP DONE
PUSHBTN1:
    bclr PTP, RED+GREEN+BLUE; clear all
    LDD #SW1PROMPT ;Load LCD Prompt
    JSR clear_lcd ;Clear anything else off of LCD
    JSR Icd_prtstrg;Print LCD prompt
    JSR INCPORT ;Call INCPORT subroutine
    JMP DONE
PUSHBTN2:
    bclr PTP, RED+GREEN+BLUE; clear all
```

```
bset PTP, RED; turn on RED
    LDD #SW2PROMPT ;Load LCD Prompt
    JSR clear_lcd ;Clear anything else off of LCD
     JSR lcd_prtstrg;Print LCD prompt
     JSR DECPORT ;Call DECPORT Subroutinr
     JMP DONE
PUSHBTN3:
    bclr PTP, RED+GREEN+BLUE; clear all
    LDD #SW3PROMPT ;Load LCD Prompt
    JSR clear lcd ;Clear anything else off of LCD
    JSR Icd prtstrg;Print LCD prompt
     JSR PRINT5MULT
DONE
    MOVB #$0F, PIFH ; clear Port H interrupt flags
;-----FUNCTIONS
Flash_Green_Led
    LDAA #10; This will flash the green LED 10 times
GREENLOOP
    bset PTP, GREEN ; turn on blue
    jsr DELAY_250_MS ; delay for .25 second
    bclr PTP, RED+GREEN+BLUE; clear all
    jsr DELAY_250_MS ; delay for .25 second
    DECA ;Decrement the count of GREENLOOP
    BNE GREENLOOP; If it hasnt flashed 10 times then go to GREENLOOP
    RTS
PRINT5MULT
    LDAA #$1 ;Count for the table loop
TABLE LOOP
    LDAB #$A ;Load Newline
    JSR putchar ;Print Newline
    LDAB #$0D
    JSR putchar
    LDAB #$05 ;load in input number
     JSR out2hex ;print input number
    LDAB #$20 ;Load a space
    JSR putchar ;print the space
    LDAB #$58 ;Load in X
    JSR putchar ;Print X
     CMPA #$A ;Check if the count has reached 10, if so we need to do a special Print_count to print 10
     BLO PRINT_COUNT;If < 9 then skip this
    LDAB #$10 ;Load a $10
     JSR out2hex
    BRA AFTER COUNT
PRINT COUNT
     STAA COUNT_NUM; Store into COUNT_NUM
    LDAB COUNT_NUM ;Pull from COUNT_NUM
```

```
JSR out2hex ;Print COUNT NUM
AFTER_COUNT
     LDAB #$20 ;Load a space
     JSR putchar ;print the space
     LDAB #$3D ;Load an = sign
     JSR putchar ;Print the = sign
     LDAB #$20 ;Load a space
     JSR putchar ;print the space
     STAA COUNT NUM; Store current count for later
     LDAB INPUT NUM ;load the input number
     ADDB #$D0 ;subtract 30 so that the value is one digit
     STAB MULT_NUM ;store value for use in multiplication
     LDAB #$0
     LDAA #$1
MULT LOOP
     ADDB MULT NUM ;add stored value to zero
     CMPA COUNT_NUM ; check if enough additions have happened
     INCA
     BLO MULT_LOOP ;Add again if not finished
     JSR HEX2DEC ;go to hex to decimal function
     LDAA COUNT_NUM ;reload the count number to do the next number on the table
                ;increment to the next number on the table
     INCA
     CMPA #$B ;check if we have reached 10 yet
     BLO TABLE LOOP ;if not go back to TABLE LOOP to finish the table
     RTS
HEX2DEC
    LDAA #0 ;load zero in for the tens place
LOOP
    CMPB #$0A ;check if value is already less than 10
    BLO DEC PRINT ; if so go to dec print
    ADDB #$F6 ;subtract 10
            ;increase tens place
    INCA
    CMPB #$0A ;check if its below 10 now
    BHS LOOP ; if not go back to loop
DEC PRINT
    STAB ONES_VAL ;store ones value
    STAA TENS_VAL ;store tens value
    LDAB TENS VAL ;obtain tens value
    ADDB #$30 ;add $30 so the ascii value lines up
    JSR putchar ;print tens value
    LDAB ONES_VAL ;load ones value
    ADDB #$30 ;add $30 so the ascii value lines up
    JSR putchar ;print ones value
    JSR DELAY_1_S
    RTS
```

;*<This function will check the dip switches and set turn on either the red or green LED depending on whether more are high or low>

```
ELECTION
     LDAA #0
     STAA PORTB
     BRCLR PTH,%10000000,L1 ;Check if first Dip switch is low
     BSET PORTB, %00001000 ;Set fifth portb led to high
L1
     BRCLR PTH,%01000000,L2 ;check if second dip switch is low
     BSET PORTB, %00000100 ;set sixth portb LED to high
L2
     BRCLR PTH,%00100000,L3 ;check if third dip switch is low
     BSET PORTB, %00000010 ;set seventh portb LED to high
L3
     BRCLR PTH,%00010000,L4 ;check if fourth dit switch is low
     BSET PORTB, %00000001 ;set eighth portb LED to high
L4
     RTS
DECPORT
     LDAA PORTB
     DECA
     CMPA #%11111111
     BNE NOTSET2
     LDAA #%00001111
NOTSET2
     STAA PORTB
     ;This is 5 blinks at 2 HZ
     bset PTP, RED ; turn on red
     jsr DELAY_250_MS ; delay for .25 second
     bclr PTP, RED+GREEN+BLUE; clear all
     jsr DELAY_250_MS ; delay for .25 second
     bset PTP, RED; turn on red
     jsr DELAY 250 MS; delay for .25 second
     bclr PTP, RED+GREEN+BLUE; clear all
     jsr DELAY_250_MS ; delay for .25 second
     bset PTP, RED; turn on red
     jsr DELAY_250_MS ; delay for .25 second
     bclr PTP, RED+GREEN+BLUE; clear all
     jsr DELAY_250_MS ; delay for .25 second
     bset PTP, RED; turn on red
     jsr DELAY_250_MS ; delay for .25 second
     bclr PTP, RED+GREEN+BLUE; clear all
     jsr DELAY_250_MS ; delay for .25 second
     bset PTP, RED; turn on red
     jsr DELAY_250_MS ; delay for .25 second
     bclr PTP, RED+GREEN+BLUE; clear all
     jsr DELAY_250_MS ; delay for .25 second
     RTS
INCPORT
     LDAA PORTB
     INCA
     CMPA #%00010000
     BNE NOTSET
     LDAA #%00000000
NOTSET
     STAA PORTB
```

;This is 4 blinks at 1 HZ

```
bset PTP, BLUE; turn on blue
    jsr DELAY_250_MS ; delay for .25 second
    jsr DELAY_250_MS ; delay for .25 second
     bclr PTP, RED+GREEN+BLUE; clear all
    jsr DELAY_250_MS ; delay for .25 second
    jsr DELAY_250_MS ; delay for .25 second
    bset PTP, BLUE ; turn on blue
    jsr DELAY 250 MS; delay for .2 second
    jsr DELAY 250 MS ; delay for .5 second
    bclr PTP, RED+GREEN+BLUE; clear all
    jsr DELAY_250_MS ; delay for .2 second
    jsr DELAY 250 MS; delay for .5 second
    bset PTP, BLUE ; turn on blue
    jsr DELAY_250_MS ; delay for .2 second
    jsr DELAY_250_MS ; delay for .5 second
    bclr PTP, RED+GREEN+BLUE; clear all
    jsr DELAY_250_MS ; delay for .2 second
    jsr DELAY_250_MS ; delay for .5 second
    bset PTP, BLUE ; turn on blue
    jsr DELAY_250_MS ; delay for .2 second
    jsr DELAY_250_MS ; delay for .5 second
    bclr PTP, RED+GREEN+BLUE; clear all
    jsr DELAY_250_MS ; delay for .2 second
    jsr DELAY_250_MS ; delay for .5 second
    RTS
;*<This function will run a simple program 6000 times to delay for 1 millisecond>
DELAY_1_MS
    LDY #$1770 ;load in 6000
LOOP 1 MS
    DEY
               ;Decrement y
     CPY #$0
     BNE LOOP 1 MS ;
    RTS
·_____
;*<This function will call the 1 millisecond delay to delay for 1000 milliseconds>
DELAY 1 S
    LDX #$03E8
                 ;load in 1000
LOOP_1_S
     JSR DELAY_1_MS ;call delay 1 milisecond
     DEX
                ;decrease X
     CPX #$0
     BNE LOOP_1_S ; branch until X = 0
;*<This function will call the 1 millisecond delay to delay for 200 milliseconds>
DELAY_200_MS
     LDX #$00C8
                   ;load in 200
LOOP_200_MS
     JSR DELAY_1_MS ;call delay 1 milisecond
     DEX
                ;decrease X
     CPX #$0
    BNE LOOP_200_MS ; branch until X = 0
    RTS ;return
```

```
;*<This function will call the 1 millisecond delay to delay for 250 milliseconds>
DELAY_250_MS
    LDX #$00FA ;load in 250
LOOP_250_MS
    JSR DELAY_1_MS ;call delay 1 milisecond
            ;decrease X
    DEX
    CPX #$0
    BNE LOOP 250 MS ; branch until X = 0
    RTS ;return
     Interrupt Vectors
.****************
    ORG Vreset
    DC.W Entry ; Reset Vector
.*****************
     ORG Vporth ; setup Port H interrupt Vector
     DC.W PTHISR
```

Part B: User presses PTH2

- Explanation of Code:
 - The Mainloop of the program continuously calls a subroutine that will blink the green RGB 10 times before restarting. This time however the global interrupt is disabled
- 1) If the first interrupt flag is set high, then the program will call a subroutine to look at the four dip switches and store their position (Up or down) on PORTB. It checks the position of the dip switches using the election subroutine from class. The program will also use the LCD on the dragon-12 board to print out "SW0 is Pressed".
- 2) If the second interrupt flag is set high, then the program will call a subroutine to increment PORTB by one and then blink the blue RGB 4 times with a 250 ms delay. The program will overflow to zero if it increments 1111. The program will also use the LCD on the dragon-12 board to print out "SW1 is Pressed".
- 3) If the third interrupt flag is set high, then the program will call a subroutine to decrement PORTB by one and then blink the RED RGB 5 times with a 200 ms delay. The program will overflow to 1111 if it decrements on 0000. The program will also use the LCD on the dragon-12 board to print out "SW2 is Pressed".

4) If the fourth interrupt flag is set high then the program will call a subroutine that will print out the multiplication table of 5 up to 5*10 onto the terminal. The program will also use the LCD on the dragon-12 board to print out "SW4 is Pressed".

Part B Full Code

```
.*********************
;* KeyWakeup.ASM
; export symbols
     XDEF Entry, _Startup ; export 'Entry' symbol
     ABSENTRY Entry ; for absolute assembly: mark this as application entry point
; Include derivative-specific definitions
INCLUDE 'derivative.inc'
; Equates Section
ROMStart EQU $2000; absolute address to place my code
RED: EQU $10 ; PP4
BLUE: EQU $20 ; PP5
GREEN: EQU $40 ; PP6
; Variable/Data Section
      ORG RAMStart ; loc $1000 (RAMEnd = $3FFF)
; Insert here your data definitions here
SWOPROMPT dc.b $0A, $0D; CR LF
      dc.b "SW0 is Pressed"
      dc.b 0 ; using zero terminated strings
SW1PROMPT dc.b $0A, $0D; CR LF
      dc.b "SW1 is Pressed"
      dc.b 0 ; using zero terminated strings
SW2PROMPT dc.b $0A, $0D ; CR LF
      dc.b "SW2 is Pressed"
      dc.b 0 ; using zero terminated strings
SW3PROMPT dc.b $0A, $0D ; CR LF
      dc.b "SW3 is Pressed"
      dc.b 0 ; using zero terminated strings
;These are the variables used in the fourth button
INPUT_NUM dc.b $35 ;Permenant storage of users input number
COUNT_NUM dc.b $0 ;Temperary storage for count number
MULT_NUM dc.b $0 ;Starting value for multiplication
TENS_VAL dc.b $0 ;Temperary storage for the tens place decimal value in DEC_PRINT
ONES_VAL dc.b $0 ;Temperary storage for the once place decimal value in DEC_PRINT
```

INCLUDE 'utilities.inc'

INCLUDE 'LCD.inc'

```
; Code Section
      ORG ROMStart; loc $2000
Entry:
_Startup:
      ; remap the RAM & amp; EEPROM here. See EB386.pdf
ifdef_HCS12_SERIALMON
      ; set registers at $0000
      CLR $11 ; INITRG= $0
      : set ram to end at $3FFF
      LDAB #$39
      STAB $10
                       ; INITRM= $39
      ; set eeprom to end at $0FFF
      LDAA #$9
      STAA $12 ; INITEE= $9
      JSR PLL_init ; initialize PLL
 endif
; Insert your code here
    LDS #ROMStart; load stack pointer
* Port H interrupt program for Dragon12
* Lights LED 0 (and clears LED1) when sw5 is pressed (PH0)
* Lights LED 1 (and clears LED0) when sw4 is pressed (PH1)
     jsr led_enable ;Initialize LEDS
     jsr TermInit ;Initialize the code warrior terminal
     bset DDRM, 4 ; make PM2 an output
     bclr PTM, 4; make PM2 low to enable RGB
     bset DDRP, RED+GREEN+BLUE; make pp4-pp6 outputs
; note Port H is all inputs after reset
     jsr lcd_init ; initialize LCD (must be done first)
     BCLR PPSH, #$0F; set Port H pins 0-1 for falling edge
     MOVB #$0F, PIFH ; clear interrupt flags initially
     BSET PIEH, $0F; enable interrupts on Port H pins 0-1
     SEI
                   ;Disable Interrupts
RESTRARTGRN
     JSR Flash_Green_Led
POLL
     BRCLR PIFH, %0000001, CLEAR
     JSR PUSHBTN0
CLEAR
     BRCLR PIFH, %00000010, CLEAR1
     JSR PUSHBTN1
CLEAR1
     BRCLR PIFH, %00000100, CLEAR2
     JSR PUSHBTN2
CLEAR2
     BRCLR PIFH, %00001000, CLEAR3
     JSR PUSHBTN3
CLEAR3
```

BRA RESTRARTGRN ; endless loop waiting for reset (and for interrupts)

```
; Note: main program is an endless loop and subroutines follow
; (Must press reset to quit.)
; ISR must test to see which button was pressed, because there ;is only one ISR for the two enabled buttons
PTHISR: ; the interrupt service routine
   BRSET PIFH, %00000001, PUSHBTN0; test btn0 IF flag
   BRSET PIFH, %00000010, PUSHBTN1; test btn1 IF flag
   BRSET PIFH, %00000100, PUSHBTN2; test btn2 IF flag
   BRSET PIFH, %00001000, PUSHBTN3; test btn3 IF flag
; NOTE: Flags are tested -not the switches
   JMP DONE
;-----INTERRUPTS
-----
PUSHBTN0:
    bclr PTP, RED+GREEN+BLUE; clear all
    LDD #SW0PROMPT ;Load LCD Prompt
    JSR clear_lcd ;Clear anything else off of LCD
    JSR lcd_prtstrg;Print LCD prompt
    JSR ELECTION
    jsr DELAY 1 S ; delay for 1 second
    JMP DONE
bclr PTP, RED+GREEN+BLUE; clear all
    LDD #SW1PROMPT ;Load LCD Prompt
    JSR clear_lcd ;Clear anything else off of LCD
    JSR Icd prtstrg;Print LCD prompt
    JSR INCPORT ;Call INCPORT subroutine
   JMP DONE
-----
PUSHBTN2:
    bclr PTP, RED+GREEN+BLUE; clear all
    bset PTP, RED; turn on RED
    LDD #SW2PROMPT ;Load LCD Prompt
    JSR clear_lcd ;Clear anything else off of LCD
    JSR lcd_prtstrg;Print LCD prompt
    JSR DECPORT ;Call DECPORT Subroutinr
    JMP DONE
PUSHBTN3:
    bclr PTP, RED+GREEN+BLUE; clear all
    LDD #SW3PROMPT ;Load LCD Prompt
    JSR clear_lcd ;Clear anything else off of LCD
    JSR lcd_prtstrg;Print LCD prompt
```

JSR PRINT5MULT

```
DONE
    MOVB #$0F, PIFH ; clear Port H interrupt flags
;-----FUNCTIONS
Flash_Green_Led
     LDAA #10 ;This will flash the green LED 10 times
GREENLOOP
     bset PTP, GREEN ; turn on blue
     jsr DELAY_250_MS ; delay for .25 second
     bclr PTP, RED+GREEN+BLUE; clear all
     jsr DELAY 250 MS ; delay for .25 second
     DECA ;Decrement the count of GREENLOOP
     BNE GREENLOOP; If it hasnt flashed 10 times then go to GREENLOOP
     RTS
PRINT5MULT
     LDAA #$1 ;Count for the table loop
TABLE_LOOP
     LDAB #$A ;Load Newline
     JSR putchar ;Print Newline
     LDAB #$0D
     JSR putchar
     LDAB #$05 ;load in input number
     JSR out2hex ;print input number
     LDAB #$20 ;Load a space
     JSR putchar ;print the space
     LDAB #$58 :Load in X
     JSR putchar ;Print X
     CMPA #$A ;Check if the count has reached 10, if so we need to do a special Print count to print 10
     BLO PRINT COUNT; If < 9 then skip this
     LDAB #$10 ;Load a $10
     JSR out2hex
     BRA AFTER COUNT
PRINT_COUNT
     STAA COUNT NUM; Store into COUNT NUM
     LDAB COUNT_NUM ;Pull from COUNT_NUM
     JSR out2hex ;Print COUNT_NUM
AFTER_COUNT
     LDAB #$20 ;Load a space
     JSR putchar ;print the space
     LDAB #$3D ;Load an = sign
     JSR putchar ;Print the = sign
     LDAB #$20 ;Load a space
     JSR putchar ;print the space
     STAA COUNT_NUM; Store current count for later
```

LDAB INPUT_NUM ;load the input number

```
ADDB #$D0 ;subtract 30 so that the value is one digit
     STAB MULT_NUM ;store value for use in multiplication
     LDAB #$0
     LDAA #$1
MULT_LOOP
     ADDB MULT_NUM ;add stored value to zero
     CMPA COUNT NUM ; check if enough additions have happened
     INCA
     BLO MULT_LOOP ;Add again if not finished
     JSR HEX2DEC ;go to hex to decimal function
     LDAA COUNT_NUM ;reload the count number to do the next number on the table
                ;increment to the next number on the table
     CMPA #$B ;check if we have reached 10 yet
     BLO TABLE_LOOP ;if not go back to TABLE_LOOP to finish the table
     RTS
HEX2DEC
    LDAA #0 ;load zero in for the tens place
LOOP
    CMPB #$0A ;check if value is already less than 10
    BLO DEC_PRINT ;if so go to dec_print
    ADDB #$F6 ;subtract 10
    INCA
           ;increase tens place
    CMPB #$0A ;check if its below 10 now
    BHS LOOP ;if not go back to loop
DEC PRINT
    STAB ONES VAL ;store ones value
    STAA TENS_VAL ;store tens value
    LDAB TENS_VAL ;obtain tens value
    ADDB #$30 ;add $30 so the ascii value lines up
    JSR putchar ;print tens value
    LDAB ONES_VAL ;load ones value
    ADDB #$30 ;add $30 so the ascii value lines up
    JSR putchar ;print ones value
    JSR DELAY_1_S ;Delay 1 second between lines
    RTS
*<This function will check the dip switches and set turn on either the red or green LED depending on whether more are
high or low>
ELECTION
     LDAA #0
     STAA PORTB
     BRCLR PTH,%10000000,L1 ;Check if first Dip switch is low
     BSET PORTB, %00001000 ;Set fifth portb led to high
L1
     BRCLR PTH,%01000000,L2 ;check if second dip switch is low
     BSET PORTB, %00000100 ;set sixth portb LED to high
L2
     BRCLR PTH,%00100000,L3 ;check if third dip switch is low
     BSET PORTB, %00000010 ;set seventh portb LED to high
L3
     BRCLR PTH,%00010000,L4 ;check if fourth dit switch is low
```

```
BSET PORTB, %00000001 ;set eighth portb LED to high
L4
     RTS
DECPORT
    LDAA PORTB
    DECA
     CMPA #%11111111
     BNE NOTSET2
    LDAA #%00001111
NOTSET2
     STAA PORTB
     :This is 5 blinks at 2 HZ
     bset PTP, RED ; turn on red
    jsr DELAY_250_MS ; delay for .25 second
    bclr PTP, RED+GREEN+BLUE; clear all
    jsr DELAY_250_MS ; delay for .25 second
    bset PTP, RED; turn on red
    jsr DELAY_250_MS ; delay for .25 second
    bclr PTP, RED+GREEN+BLUE; clear all
    jsr DELAY_250_MS ; delay for .25 second
    bset PTP, RED; turn on red
    jsr DELAY_250_MS ; delay for .25 second
    bclr PTP, RED+GREEN+BLUE; clear all
    jsr DELAY_250_MS ; delay for .25 second
    bset PTP, RED; turn on red
    jsr DELAY_250_MS ; delay for .25 second
    bclr PTP, RED+GREEN+BLUE; clear all
    jsr DELAY_250_MS ; delay for .25 second
    bset PTP, RED ; turn on red
    jsr DELAY 250 MS; delay for .25 second
    bclr PTP, RED+GREEN+BLUE; clear all
    jsr DELAY_250_MS ; delay for .25 second
    RTS
INCPORT
    LDAA PORTB
     INCA
     CMPA #%00010000
     BNE NOTSET
    LDAA #%00000000
NOTSET
     STAA PORTB
     ;This is 4 blinks at 1 HZ
     bset PTP, BLUE ; turn on blue
    jsr DELAY_250_MS ; delay for .25 second
    jsr DELAY_250_MS ; delay for .25 second
    bclr PTP, RED+GREEN+BLUE; clear all
    jsr DELAY_250_MS ; delay for .25 second
    jsr DELAY_250_MS ; delay for .25 second
    bset PTP, BLUE ; turn on blue
    jsr DELAY_250_MS ; delay for .2 second
    jsr DELAY_250_MS ; delay for .5 second
    bclr PTP, RED+GREEN+BLUE; clear all
    jsr DELAY 250 MS ; delay for .2 second
    jsr DELAY_250_MS ; delay for .5 second
    bset PTP, BLUE ; turn on blue
```

```
jsr DELAY 250 MS ; delay for .2 second
     jsr DELAY_250_MS ; delay for .5 second
     bclr PTP, RED+GREEN+BLUE; clear all
     jsr DELAY_250_MS ; delay for .2 second
     jsr DELAY_250_MS ; delay for .5 second
     bset PTP, BLUE ; turn on blue
     jsr DELAY_250_MS ; delay for .2 second
     jsr DELAY 250 MS; delay for .5 second
     bclr PTP, RED+GREEN+BLUE; clear all
     jsr DELAY_250_MS ; delay for .2 second
     jsr DELAY_250_MS ; delay for .5 second
     RTS
;*<This function will run a simple program 6000 times to delay for 1 millisecond>
DELAY 1 MS
     LDY #$1770 ;load in 6000
LOOP_1_MS
     DEY
               ;Decrement y
     CPY #$0
     BNE LOOP_1_MS ;
     RTS
;*<This function will call the 1 millisecond delay to delay for 1000 milliseconds>
DELAY_1_S
     LDX #$03E8
                  ;load in 1000
LOOP_1_S
     JSR DELAY_1_MS ;call delay 1 milisecond
     DEX
              ;decrease X
     CPX #$0
     BNE LOOP 1 S ; branch until X = 0
     RTS ;return
;*<This function will call the 1 millisecond delay to delay for 200 milliseconds>
DELAY_200_MS
     LDX #$00C8 ;load in 200
LOOP_200_MS
     JSR DELAY_1_MS ;call delay 1 milisecond
     DEX
               ;decrease X
     CPX #$0
     BNE LOOP_200_MS ; branch until X = 0
     RTS ;return
;*<This function will call the 1 millisecond delay to delay for 250 milliseconds>
DELAY_250_MS
     LDX #$00FA ;load in 250
LOOP_250_MS
     JSR DELAY_1_MS ;call delay 1 milisecond
     DEX
                ;decrease X
     CPX #$0
     BNE LOOP 250 MS ; branch until X = 0
     RTS ;return
```

Post-Lab

1. Question 1

a. The push buttons can briefly stop the green led by calling an interrupt. They can do this by changing the interrupt flag status. In our program it is impossible to stop the green light permanently by holding the button down because the flag is set by falling edge logic.

2. Question 2

- a. The push buttons use falling edge logic. This means that when you push the push button the signal goes from 1 to 0. It is at the instant of this change that the interrupt flag bit is modified. Staying at 1 or at 0 will have no effect on the interrupt flag bit.
- b. BCLR PPSH, #\$0F; set Port H pins 0-1 for falling edgeIf you wanted to set it to rising edge you could use BSET instead of BCLR


3. Question 3


a. If the interrupt flag bit is not cleared at the end of the interrupt then that interrupt will be called immediately after the interrupt ends, this will happen an infinite number of times.

4. Question 4

a. It is impossible to set the interrupt flag bits directly using software, these bits are handled by hard wired logic.

5. Question 5





Conclusion

- Pre-Lab
 - o In the prelab we practiced blinking a blue light on the RGB and using our time delay functions to control the frequency of the blinks (PTH0). We also wrote a subroutine that would be used to increment the 4 rightmost bits on porth including an overflow scenario (PTH1).
- In-Lab
 - o Part A (PTH 3)
 - We learned how to use interrupts to control the interruption (for lack of a better word) of a green LED and perform various subroutines from other labs.
 - o Part B (PTH 2)
 - We learned how to "poll" the interrupt flag bits and use them as a determining factor on calling various subroutines.
- Post-Lab
 - The Postlab pointed out that our code had the interrupt flag triggering off of falling edge logic, as well as exploring what happens if you don't clear your interrupt bits.