Goose Solid/V is coPlastic Hardening Linear Elastic

T.W.J. de Geus

*Contact: tom@geus.me - www.geus.me - https://github.com/tdegeus/GooseSolid

Abstract

History dependent elasto-visco-plastic material. The elasticity is governed by a linear relationship between the Cauchy stress σ and the elastic strain ε_e . The material deforms elastically up to a certain yield stress (which hardens due to plasticity through a power-law). Thereafter the material deforms through a combination of elasticity and plasticity. The elastic strain depends on the strain ε (which is the symmetric part of the displacement gradient), and the history.

The model is implemented in 3-D, hence it can directly be used for either 3-D or 2-D plane strain problems.

Keywords: visco-plasticity; linear elasticity

Contents

1	Constitutive model	2
2	Numerical implementation: implicit 2.1 Elastic predictor	3
3	2.4 Consistent tangent operator	4
A	Nomenclature	7
В	Stress measures	7
C	Constitutive model in one-dimension	7

1 Constitutive model

The model consists of the following ingredients (de Souza Neto et al., 2008, Chapter 11). To start it might be a good idea to study the one-dimensional equivalent, for completeness listed in Appendix C.

(i) The strain, ε , is additively split in an elastic part, $\varepsilon_{\rm e}$, and a plastic plastic, $\varepsilon_{\rm p}$. I.e.

$$\varepsilon = \varepsilon_{\rm e} + \varepsilon_{\rm p}$$
 (1)

(ii) The stress, σ , is set by to the elastic strain, ε_e , through the following linear relation:

$$\sigma = \mathbb{C}_{e} : \varepsilon_{e}$$
 (2)

wherein \mathbb{C}_{e} is the elastic stiffness, which reads:

$$\mathbb{C}_{e} = KI \otimes I + 2G(\mathbb{I}_{s} - \frac{1}{3}I \otimes I)$$
(3)

$$= K\mathbf{I} \otimes \mathbf{I} + 2G \mathbb{I}_{d} \tag{4}$$

with K and G the bulk and shear modulus respectively. See Appendix A for nomenclature.

(iii) The elastic domain is bounded by the following yield function

$$\Phi(\boldsymbol{\sigma}, \varepsilon_{\mathrm{p}}) = \sigma_{\mathrm{eq}} - \sigma_{\mathrm{y}}(\varepsilon_{\mathrm{p}}) \le 0 \tag{5}$$

where $\sigma_{\rm eq}$ the equivalent stress (see Appendix B), and $\sigma_{\rm y}$ the yield stress which is a non-linear function of the equivalent plastic strain $\varepsilon_{\rm p}$. The implementation is based on power-law hardening:

$$\sigma_{\mathbf{y}}(\varepsilon_{\mathbf{p}}) = \sigma_{\mathbf{y}0} + H\varepsilon_{\mathbf{p}}^{m} \tag{6}$$

where σ_{v0} is the initial yield stress, H is the hardening modulus, and m is the hardening exponent.

(iv) Plasticity is governed by Norton's flow rule:

$$\dot{\varepsilon}_{p} = \dot{\gamma} \frac{\partial \Phi}{\partial \sigma} = \dot{\gamma} \frac{3}{2} \frac{\sigma_{d}}{\sigma_{eq}} = \dot{\gamma} N$$
 (7)

wherein $\dot{\varepsilon}_{\rm p}$ is the plastic strain rate. The ratio of the stress deviator, $\sigma_{\rm d}$, and it's equivalent value, $\sigma_{\rm eq}$, determines the direction of plastic flow (the symbol N is used to emphasize that only determines a direction, not an amplitude). The evolution of the plastic multiplier, $\dot{\gamma}$, is finally defined as follows:

$$\frac{\dot{\gamma}}{\dot{\gamma}_0} = \left(\frac{\sigma_{\rm eq}}{\sigma_{\rm y}}\right)^{1/n} - 1\tag{8}$$

wherein $\dot{\gamma}_0$ and the exponent n are material parameters (in addition of course to the initial yield stress σ_{y0} , the hardening modulus H, and the hardening exponent m, contained in the yield stress σ_y). Note that when $\Phi < 0$ then $\dot{\gamma} = 0$.

Following the definition in (7), the equivalent plastic strain can be simply defined as follows:

$$\varepsilon_{\mathbf{p}} = \int_0^t \dot{\gamma} \, \mathrm{d}\tau \tag{9}$$

which corresponds to

$$\dot{\varepsilon}_{\mathrm{D}} = \dot{\gamma}$$
 (10)

2 Numerical implementation: implicit

For the numerical implementation, first of all a numerical time integration scheme has to be selected. Here, an implicit time discretization is used, which has the favorable property of being unconditionally stable. To this end, the commonly used return-map algorithm is used. An increment in strain is first assumed fully elastic (elastic predictor). Then, if needed, a return-map is utilized to return to a physically admissible state (plastic corrector). The benefit of this scheme as that (i) the evolution of the plasticity (the state variable) can be determined by solving a single, albeit non-linear, equation; and that (ii) the linearization to obtain the consistent tangent operator is relatively straightforward.

3

2.1 Elastic predictor

Given an increment in strain

$$\varepsilon_{\Delta} = \varepsilon^{(t+\Delta t)} - \varepsilon^{(t)} \tag{11}$$

and the state variables, the elastic trial state reads:

$$^{\star}\varepsilon_{\rm e} = \varepsilon_{\rm e}^{(t)} + \varepsilon_{\Delta} \tag{12}$$

$$^{\star}\boldsymbol{\sigma} = \mathbb{C}_{e} : ^{\star}\boldsymbol{\varepsilon}_{e} \tag{13}$$

$$^{\star}\varepsilon_{\mathbf{p}} = \varepsilon_{\mathbf{p}}^{(t)} \tag{14}$$

$${}^{\star}\Phi = \Phi({}^{\star}\sigma, {}^{\star}\varepsilon_{p}) = {}^{\star}\sigma_{eq} - \sigma_{y}({}^{\star}\varepsilon_{p})$$

$$(15)$$

where the notation (.) has been used to denote a trial value for $(.)^{(t+\Delta t)}$.

2.2 Trial state: elastic

If the trial state is within or on the (current) yield surface, i.e. when

$$^{\star}\Phi \leq 0$$
 (16)

the trial state coincides with the actual state, and:

$$\varepsilon_{\mathbf{e}}^{(t+\Delta t)} = {}^{\star}\varepsilon_{\mathbf{e}} = \varepsilon_{\mathbf{e}}^{(t)} + \varepsilon_{\Delta} \tag{17}$$

$$\varepsilon_{\mathbf{p}}^{(t+\Delta t)} = {}^{\star}\varepsilon_{\mathbf{p}} = \varepsilon_{\mathbf{p}}^{(t)}$$
 (18)

$$\sigma^{(t+\Delta t)} = {}^{\star}\sigma \tag{19}$$

2.3 Trial state elasto-plastic: return-map

If the trial state is outside the (current) yield surface, i.e. when

$$^*\Phi > 0$$
 (20)

plastic flow occurs in the increment. A return-map is needed to return to the admissible state. It has to satisfy the following system of equations:

$$\begin{cases}
\varepsilon_{\mathbf{e}}^{(t+\Delta t)} &= {}^{\star} \varepsilon_{\mathbf{e}} - \Delta \gamma \, \mathbf{N}^{(t+\Delta t)} \\
\varepsilon_{\mathbf{p}}^{(t+\Delta t)} &= \varepsilon_{\mathbf{p}}^{(t)} + \Delta \gamma \\
\Phi^{(t+\Delta t)} &= \sigma_{\mathbf{eq}}^{(t+\Delta t)} - \sigma_{\mathbf{y}} (\varepsilon_{\mathbf{p}}^{(t)} + \Delta \gamma) = 0
\end{cases}$$
(21)

This can be reduced by using that

$$\boldsymbol{\sigma}_{\mathrm{d}}^{(t+\Delta t)} = {}^{\star}\boldsymbol{\sigma}_{\mathrm{d}} - 2G\Delta\gamma \, \boldsymbol{N}^{(t+\Delta t)} \tag{22}$$

$$= {}^{\star}\boldsymbol{\sigma}_{\mathrm{d}} - 3G\Delta\gamma \, \frac{\boldsymbol{\sigma}_{\mathrm{d}}^{(t+\Delta t)}}{\boldsymbol{\sigma}_{\mathrm{eq}}^{(t+\Delta t)}} \tag{23}$$

i.e. the trial and updated deviatoric stresses are co-linear. This implies that

$$\frac{\sigma_{\mathbf{d}}^{(t+\Delta t)}}{\sigma_{\mathrm{eq}}^{(t+\Delta t)}} = \frac{{}^{\star}\!\sigma_{\mathbf{d}}}{{}^{\star}\!\sigma_{\mathrm{eq}}} \quad \text{or} \quad \mathbf{N}^{(t+\Delta t)} = {}^{\star}\!\mathbf{N}$$
(24)

This allows the reorganization of the above to

$$\boldsymbol{\sigma}_{\mathrm{d}}^{(t+\Delta t)} = \left(1 - \frac{3G \,\Delta \gamma}{{}^{\star}\boldsymbol{\sigma}_{\mathrm{eq}}}\right) {}^{\star}\boldsymbol{\sigma}_{\mathrm{d}} \tag{25}$$

from which it also follows that

$$\sigma_{\rm eq}^{(t+\Delta t)} = {}^{\star}\sigma_{\rm eq} - 3G\,\Delta\gamma\tag{26}$$

Substitution into (8) yields:

$$\frac{\Delta \gamma}{\Delta t \, \dot{\gamma}_0} + 1 = \left(\frac{{}^*\!\sigma_{\rm eq} - 3G \, \Delta \gamma}{\sigma_{\rm y}(\varepsilon_{\rm p}^{(t)} + \Delta \gamma)}\right)^{1/n} \tag{27}$$

which can be re-arranged into a numerical more stable form:

$$({}^{\star}\sigma_{\rm eq} - 3G\,\Delta\gamma) \left(\frac{\Delta t}{\Delta\gamma/\dot{\gamma}_0 + \Delta t}\right)^n - \sigma_{\rm y}(\varepsilon_{\rm p}^{(t)} + \Delta\gamma) = 0 \tag{28}$$

which has to be solved by Newton-Raphson for $\Delta \gamma$.

Finally, the trial state is updated:

· The updated stress tensor

$$\boldsymbol{\sigma}^{(t+\Delta t)} = \sigma_{\mathrm{m}}^{(t+\Delta t)} \boldsymbol{I} + \boldsymbol{\sigma}_{\mathrm{d}}^{(t+\Delta t)} \tag{29}$$

with

$$\sigma_{\rm m}^{(t+\Delta t)} = {}^{\star}\!\sigma_{\rm m} \tag{30}$$

$$\boldsymbol{\sigma}_{\mathrm{d}}^{(t+\Delta t)} = \left(1 - \frac{3G\Delta\gamma}{{}^{\star}\boldsymbol{\sigma}_{\mathrm{eq}}}\right){}^{\star}\boldsymbol{\sigma}_{\mathrm{d}} \tag{31}$$

• The updated elastic strain tensor

$$\varepsilon_{\mathbf{e}}^{(t+\Delta t)} = \frac{1}{2G} \sigma_{\mathbf{d}}^{(t+\Delta t)} + \frac{1}{3} \operatorname{tr}({}^{\star} \varepsilon_{\mathbf{e}}) \mathbf{I}$$
(32)

• The updated equivalent plastic strain:

$$\varepsilon_{\mathbf{p}}^{(t+\Delta t)} = \varepsilon_{\mathbf{p}}^{(t)} + \Delta \gamma \tag{33}$$

2.4 Consistent tangent operator

The consistent constitutive tangent operator is defined as

$$\mathbb{C}_{\text{ep}} = \frac{\partial \, \boldsymbol{\sigma}^{(t+\Delta t)}}{\partial \, \boldsymbol{\varepsilon}^{(t+\Delta t)}} \tag{34}$$

For the case that the trail state coincides with the actual state (i.e. $^*\Phi \leq 0$), $\mathbb{C}_{\mathrm{ep}} = \mathbb{C}_{\mathrm{e}}$. Otherwise, it can be obtained from 1

$$\mathbb{C}_{\mathrm{ep}} = \frac{\partial \, \boldsymbol{\sigma}^{(t+\Delta t)}}{\partial \, \boldsymbol{\varepsilon}^{(t+\Delta t)}} = \frac{\partial \, \boldsymbol{\sigma}^{(t+\Delta t)}}{\partial \, {}^*\boldsymbol{\varepsilon}_{\mathrm{e}}} : \frac{\partial \, {}^*\boldsymbol{\varepsilon}_{\mathrm{e}}}{\partial \, \boldsymbol{\varepsilon}^{(t+\Delta t)}} = \frac{\partial \, \boldsymbol{\sigma}^{(t+\Delta t)}}{\partial \, {}^*\boldsymbol{\varepsilon}_{\mathrm{e}}} : \mathbb{I} = \frac{\partial \, \boldsymbol{\sigma}^{(t+\Delta t)}}{\partial \, {}^*\boldsymbol{\varepsilon}_{\mathrm{e}}}$$
(35)

¹To show this one has to employ (11,12) and realize that $\varepsilon^{(t)}$ and $\varepsilon^{(t)}_{\rm e}$ are constant during the increment. I.e. $\frac{\partial^{\star} \varepsilon_{\rm e}}{\partial \varepsilon^{(t+\Delta t)}} = \frac{\partial^{\star} \varepsilon^{(t+\Delta t)}}{\partial \varepsilon^{(t+\Delta t)}} = \mathbb{I}$.

To proceed, the first step is write an explicit relation between the (actual) stress $\sigma^{(t+\Delta t)}$ and the trial elastic strain ε_e :

$$\boldsymbol{\sigma}^{(t+\Delta t)} = \sigma_{\mathbf{m}}^{(t+\Delta t)} \boldsymbol{I} + \boldsymbol{\sigma}_{\mathbf{d}}^{(t+\Delta t)}$$
(36)

$$= {}^{\star}\sigma_{\rm m} \mathbf{I} + \left(1 - \frac{3G\Delta\gamma}{{}^{\star}\sigma_{\rm eq}}\right) {}^{\star}\sigma_{\rm d} \tag{37}$$

$$= {}^{\star}\sigma_{\rm m}\mathbf{I} + \left(1 - \frac{3G\Delta\gamma}{{}^{\star}\sigma_{\rm eq}}\right) 2G {}^{\star}\varepsilon_{\rm e}^{d} \tag{38}$$

$$= \left[\mathbb{C}_{e} - \frac{6G^{2}\Delta\gamma}{^{\star}\sigma_{eq}} \mathbb{I}_{d} \right] : {^{\star}\varepsilon_{e}}$$
(39)

The tangent then follows from

$$\mathbb{C}_{\text{ep}} = \frac{\partial \, \boldsymbol{\sigma}^{(t+\Delta t)}}{\partial \,^{\star} \boldsymbol{\varepsilon}_{\text{e}}} = \mathbb{C}_{\text{e}} - \frac{6G^{2} \Delta \gamma}{\,^{\star} \boldsymbol{\sigma}_{\text{eq}}} \mathbb{I}^{d} - \frac{6G^{2}}{\,^{\star} \boldsymbol{\sigma}_{\text{eq}}} \left(\frac{\partial \Delta \gamma}{\partial \,^{\star} \boldsymbol{\varepsilon}_{\text{e}}} \right) \otimes \,^{\star} \boldsymbol{\varepsilon}_{\text{e}}^{\text{d}} + \frac{6G^{2} \Delta \gamma}{\,^{\star} \boldsymbol{\sigma}_{\text{eq}}^{2}} \left(\frac{\partial \,^{\star} \boldsymbol{\sigma}_{\text{eq}}}{\partial \,^{\star} \boldsymbol{\varepsilon}_{\text{e}}} \right) \otimes \,^{\star} \boldsymbol{\varepsilon}_{\text{e}}^{\text{d}}$$

$$(40)$$

Now apply the following:

· Equivalent stress

$$\frac{\partial \sigma_{\text{eq}}}{\partial \boldsymbol{\sigma}} = \frac{\partial \sigma_{\text{eq}}}{\partial \boldsymbol{\sigma}_{\text{d}}} = \frac{\partial}{\partial \boldsymbol{\sigma}_{\text{d}}} \left(\sqrt{\frac{3}{2} \boldsymbol{\sigma}_{\text{d}} : \boldsymbol{\sigma}_{\text{d}}} \right) = \frac{1}{2 \sigma_{\text{eq}}} \frac{\partial}{\partial \boldsymbol{\sigma}_{\text{d}}} \left(\frac{3}{2} \boldsymbol{\sigma}_{\text{d}} : \boldsymbol{\sigma}_{\text{d}} \right) = \frac{3}{2} \frac{\boldsymbol{\sigma}_{\text{d}}}{\sigma_{\text{eq}}} = \boldsymbol{N} = {}^{\star} \boldsymbol{N}$$
(41)

Hence:

$$\frac{\partial^{\star} \sigma_{\text{eq}}}{\partial^{\star} \varepsilon_{e}} = 2G^{\star} \mathbf{N}$$
(42)

· Plastic multiplier

$$\frac{\partial \Delta \gamma}{\partial {}^{\star} \varepsilon_{e}} = \left(\frac{\partial {}^{\star} \sigma_{eq}}{\partial \Delta \gamma}\right)^{-1} \left(\frac{\partial {}^{\star} \sigma_{eq}}{\partial {}^{\star} \varepsilon_{e}}\right) \tag{43}$$

The non-linear relation in (27,28) can be rearranged as follows

$$^{\star}\sigma_{\rm eq} = 3G \,\Delta\gamma + \left(\frac{\Delta t}{\Delta\gamma/\dot{\gamma}_0 + \Delta t}\right)^{-n} \sigma_{\rm y}(\varepsilon_{\rm p}) \tag{44}$$

where the simplified notation $\varepsilon_{\rm p}=\varepsilon_{\rm p}^{(t+\Delta t)}=\varepsilon_{\rm p}^{(t)}+\Delta\gamma$ has been used. To simply notation in the proceeding, additionally

$$\tilde{H} = \frac{\partial \sigma_{y}}{\partial \Delta \gamma} \bigg|_{\varepsilon_{p}} = \frac{\partial \sigma_{y}}{\partial \varepsilon_{p}} \bigg|_{\varepsilon_{p}} = mH(\varepsilon_{p})^{m-1}$$
(45)

The derivative then follows as:

$$\frac{\partial^* \sigma_{\text{eq}}}{\partial \Delta \gamma} = 3G + \tilde{H} \left(\frac{\Delta t}{\Delta \gamma / \dot{\gamma}_0 + \Delta t} \right)^{-n} + \sigma_{\text{y}} (\varepsilon_{\text{p}}) \frac{\partial}{\partial \Delta \gamma} \left\{ \left(\frac{\Delta t}{\Delta \gamma / \dot{\gamma}_0 + \Delta t} \right)^{-n} \right\}$$
(46)

$$=3G+\tilde{H}\left(\frac{\Delta t}{\Delta \gamma/\dot{\gamma}_0+\Delta t}\right)^{-n}+\underbrace{\sigma_{\rm y}(\varepsilon_{\rm p})\left(\frac{\Delta t}{\Delta \gamma/\dot{\gamma}_0+\Delta t}\right)^{-n}}_{(1+\Delta)}\underbrace{\frac{n}{\dot{\gamma}_0(\Delta \gamma/\dot{\gamma}_0+\Delta t)}}$$
(47)

$$=3G + \tilde{H} \left(\frac{\Delta t}{\Delta \gamma / \dot{\gamma}_0 + \Delta t}\right)^{-n} + \frac{n \,\sigma_{\text{eq}}^{(t+\Delta t)}}{\dot{\gamma}_0 \left(\Delta \gamma / \dot{\gamma}_0 + \Delta t\right)} \tag{48}$$

The final result then reads:

$$\mathbb{C}_{\text{ep}} = \mathbb{C}_{\text{e}} - \frac{6G^2 \Delta \gamma}{^*\sigma_{\text{eq}}} \mathbb{I}_{\text{d}} + 4G^2 \left[\frac{\Delta \gamma}{^*\sigma_{\text{eq}}} - \left[3G + \tilde{H} \left(\frac{\Delta t}{\Delta \gamma / \dot{\gamma}_0 + \Delta t} \right)^{-n} + \frac{n \sigma_{\text{eq}}^{(t+\Delta t)}}{\dot{\gamma}_0 \left(\Delta \gamma / \dot{\gamma}_0 + \Delta t \right)} \right]^{-1} \right] ^* \mathcal{N} \otimes^* \mathcal{N}$$
 (49)

3 Numerical examples

3.1 Parameter variations

The meaning of the parameters is illustrated using a parameter variation in Figure 1.




Figure 1. Effect of different parameter variations.

A Nomenclature

• Dyadic tensor product

$$\mathbb{C} = A \otimes B \tag{50}$$

$$C_{ijkl} = A_{ij} B_{kl} (51)$$

• Double tensor contraction

$$C = A : B \tag{52}$$

$$=A_{ij}B_{ji} \tag{53}$$

• Deviatoric projection tensor

$$\mathbb{I}_{\mathbf{d}} = \mathbb{I}_{\mathbf{s}} - \frac{1}{3} \mathbf{I} \otimes \mathbf{I} \tag{54}$$

B Stress measures

• Mean stress

$$\sigma_{\rm m} = \frac{1}{3}\operatorname{tr}(\boldsymbol{\sigma}) = \frac{1}{3}\boldsymbol{\sigma}: \boldsymbol{I} \tag{55}$$

· Stress deviator

$$\sigma_{\rm d} = \sigma - \sigma_{\rm m} I = \mathbb{I}_{\rm d} : \sigma \tag{56}$$

• Von Mises equivalent stress

$$\sigma_{\rm eq} = \sqrt{\frac{3}{2}\,\boldsymbol{\sigma}_{\rm d}:\boldsymbol{\sigma}_{\rm d}} = \sqrt{3J_2(\boldsymbol{\sigma})}$$
 (57)

where the second-stress invariant

$$J_2 = \frac{1}{2} || \boldsymbol{\sigma}_{d} ||^2 = \frac{1}{2} \boldsymbol{\sigma}_{d} : \boldsymbol{\sigma}_{d}$$
 (58)

C Constitutive model in one-dimension

(i) Elasto-plastic decomposition

$$\varepsilon = \varepsilon_{\rm e} + \varepsilon_{\rm p} \tag{59}$$

(ii) Linear elasticity

$$\sigma = E \,\varepsilon_{\rm e} \tag{60}$$

(iii) Yield function

$$\Phi(\sigma, \sigma_{\mathbf{y}}) = |\sigma| - \sigma_{\mathbf{y}} \tag{61}$$

Elastic domain

$$\mathcal{E} = \left\{ \sigma \mid \Phi(\sigma, \sigma_{y}) < 0 \right\} \tag{62}$$

(iv) Plastic flow rule

$$\dot{\varepsilon}_{\mathbf{p}} = \dot{\gamma} \operatorname{sign}(\sigma) \tag{63}$$

where

$$\dot{\gamma} = \begin{cases} \dot{\gamma}_0 \left[\left(\frac{|\sigma|}{\sigma_y} \right)^{1/n} - 1 \right] & \text{if } \Phi(\sigma, \sigma_y) \ge 0\\ 0 & \text{if } \Phi(\sigma, \sigma_y) < 0 \end{cases}$$
(64)

(v) Hardening law

$$\sigma_{\rm y} = \sigma_{\rm y0} + H\varepsilon_{\rm p}^m \tag{65}$$

$$\dot{\varepsilon}_{\rm p} = \dot{\gamma} \tag{66}$$

References

de Souza Neto, E., Perić, D., and Owen, D. (2008). Computational Methods for Plasticity. John Wiley & Sons, Ltd.