General AGC Notes

The current versions of Power System Toolbox (PST) does not have any AGC (automatic generation control) or area related models. Previous AGC work from PSLTDSim (Power system long-term dynamic simulator) may be a good starting point for adding AGC to PST.

The central computational task behind AGC is the calculation and distribution of an area control error (ACE) value. At the most basic level, this requires knowing an area's actual net interchange, scheduled net interchange, and frequency. The standard NERC reported ACE (RACE) calculation is

$$RACE = (NI_A - NI_S) - 10B(F_A - F_S) - I_{ME} + I_{ATEC}$$
 (1)

With variables defined as:

- NI_A Actual net interchange
- NI_S Scheduled net interchange
- B Fixed frequency bias
- F_A Actual system frequency
- F_S Scheduled system frequency
- I_{ME} Meter error
- I_{ATEC} Area time error correction

 I_{ME} and I_{ATEC} are often ignored, or set to zero, for simulation purposes.

An optional variable frequency bias B_V that replaces/enhances the standard frequency bias B may be calculated as

$$B_V = B \left(1 + K_B |\Delta\omega| \right) \tag{2}$$

Where

$$\Delta\omega = \omega_{rated} - \omega. \tag{3}$$

It should be noted that frequency bias is a negative number and has units of MW/0.1Hz.

By convention, ACE, or RACE is measured in MW and a positive value indicates a general over-generation condition while a negative value is representative of an under-generation situation.

PST possibilities

To accommodate AGC, PST would require an 'area_con' data structure that lists each bus associated with a particular area. Code will have to be written to calculate and log area interchange based on power flow through lines that connect areas. These calculations are already included with PST in the line_pq function, but used only in the linearization of systems and after a non-linear simulation.

Some kind of center of inertia combined frequency (from Sam's phd work) may be used to estimate area or system frequency used in ACE calculations. This would also require area generator buses to be defined in the area con.

An 'agc_con' will also have to be created to define the parameters and options associated with AGC such as frequency bias, action time, filter parameters, integration parameters, gains, etc. A list of AGC controlled generators (with participation factors) would also be required.

Instead of using the previous 'array' based definitions that PST has historically employed for system parameterization, a structured array approach may be used i.e.

```
agc_con(1).actTime = 30; % AGC action time for AGC 1
...
agc_con(2).ctrlGens = [2,3,4]; % list of AGC gens for AGC 2
agc_con(2).genPF = [0.25, 0.25, 0.5]; % participation factor for AGC2
...
```

For reference, the AGC model in PSLTDSim is created using code similar to:

```
mirror.sysBA = {
    'BA1':{
        'Area':1,
        'B': "1.0 : permax", # MW/0.1 Hz
        'BVgain': 500.0, # variable frequency bias gain
        'AGCActionTime': 30.00, # seconds
        'ACEgain': 2.0,
        'AGCType':'TLB : 0', # Tie-Line Bias
        'IncludeIACE' : True,
        'IACEwindow' : 30, # seconds - size of window - 0 for non window
        'IACEscale' : 1/10,
        'ACEFiltering': 'PI : 0.04 0.0001'
        'CtrlGens': [
            'gen 1 : 0.5 : rampA',
            'gen 2 1 : 0.5 : rampA', ]
        },
    }
```

PSLTDSim AGC model

The AGC model from PSLTDSim contains basic and optional control blocks.




Figure 1: Block diagram of ACE calculation and manipulation.

The conditional summing block contains logic that may be used to collect error values that are deemed internal to an area to more efficiently respond to events. This was done by comparing the sign of the error signal to the sign of frequency deviation.

A moving window integrator with a user defined time range was used in the PSLTDSim AGC model. This seems possible in PST, but will require some extra considerations when dealing with variable time steps.

In simulations carried out by PSLTDSim, the most useful optional filter was the proportional-integral (PI) type shown below.




Figure 2: Block diagrams of optional ACE filters (Low pass, Integral, PI).

ACE signals distributed to participating generators acted as a relative ramp on a the associated governor P_{REF} value (or P_{mech} for un-governed units). A low pass filter with a large time constant $\approx 1/4$ AGC action time may be an easier implementation for PST.

Plant controllers (similar to GDACS) were not created in PSLTDSim due to time constraints and may be overly detailed for this project.