

Modelling of Iodine induced Stress Corrosion Cracking (I-SCC) of zirconium alloys with MFRONT

11th MFront User Meeting – 2025-11-20

Le Boulch David, Helfer Thomas

Outline

1. Context

Pellet Cladding Interaction (PCI)

Iodine induced Stress Corrosion Cracking (I-SCC)

2. Laboratory experiments

Inner pressure tests in iodine vapor

3. Implementation in MFRONT

One element in tension

Cyclic behavior

4. Applications

Inner Pressure tests

Polycrystalline simulations

5. Conclusions and Perspectives



1. Context

Pellet Cladding Interaction (PCI)

Iodine Induced Stress Corrosion Cracking (I-SCC)


Context

Fuel cladding and Pellet-Cladding Interaction (PCI)


- Zirconium alloys are widely used in the nuclear industry as **fuel cladding material** due to their good properties. They are the primary containment barrier for fuel pellets and fission products in pressurised water reactors (PWR).
- During incidental power transients in the reactor, the fuel pellets increase in temperature and expand. Each pellet exerts a high stress on the fuel cladding, and this phenomenon is known as **Pellet-Cladding Interaction (PCI)**.

Iodine-Induced Stress Corrosion Cracking (ISCC)

- During large power variations or incidental situations, the combination of **the mechanical load imposed** on the cladding and **the corrosive environment** could lead to a risk of **Iodine-Induced Stress Corrosion Cracking (ISCC)**



Scheme of Pressurized Water Reactor fuel assembly




Fuel partitioning in the fuel pellet (radial cracks) and ISCC crack [Davies, 1977].



Context

Iodine-Induced Stress Corrosion Cracking (ISCC)


- The initiation of an ISCC crack is mainly intergranular
- The propagation is mainly transgranular
 - Quasi-clavage on basal-planes
 - Fluting on pyramidal planes




Tenckhoff 2005; Linga Murty et Charit 2006

Essai en rampe au GETR
d'une gaine de Zircaloy-2
(Davies 1977)


Intergranular




Transgranular



Essai de laboratoire sur Zy-4 RX
(Frégonèse 1999)



Quasi-clavage



Fluting



2. Laboratory tests


Inner Pressure tests in iodine vapor





Laboratory tests (example)

Inner Pressure tests with iodine vapor

- Inner Pressure P experimentally controlled
- At PWR's temperature of the inner wall of the cladding (320°C-420°C)
- On smooth specimen → initiation of I-SCC cracks
- On pre-cracked specimen → Propagation of I-SCC cracks



Influence de la contrainte tangentielle sur le temps de rupture pour différentes nuances de Zr (Une 1983)



$$\sigma_{\theta\theta} = P \cdot \frac{(R_{out} + R_{in})}{2 \cdot e}$$

$$pI_2 \approx 300\,000 \text{ Pa}$$



3. I-SCC modelling

Kachanov's damage law



KACHANOV's damage law (1/2)



- Coupled to viscoplastic models presented after
- KACHANOV's law suits well for brittle time-dependent failure modes.
 - The parameters depend on the local Iodine quantity.
 - It defines a local isotropic damage variable D to simulate the initiation and the propagation of an I-SCC crack

$$\dot{D} = A(I) \cdot e^{-\frac{Q}{T}} \cdot \left(\frac{\sigma_D}{1 - D} - \sigma_0(I) \right)^B$$

$$\sigma_D = \sqrt{<\sigma_{\theta\theta}>^2 + \beta(\sigma_{R\theta}^2 + \sigma_{Z\theta}^2)}$$

- A cracking strain is added ε_f to apply a cracking energy $G_C(I)$ in the calculations
 - The cracking strain is added to the other strains of the material (viscoplasticity, thermal dilatancy, ...).
 - Is defined with the opening u of the crack and a parameter with is the local size of the element of the mesh $L0$
 - It allows to define a critical opening $u_c(I)$ of the I-SCC crack

$$\varepsilon_f = \frac{u}{L0}; D = \frac{u}{u_c(I)} \quad G_C(I) = \frac{1}{2} \cdot \sigma_0(I) \cdot u_c(I)$$






KACHANOV's damage law (2/3)

- Kachanov's model with embrittlement functions according to the iodine content
- Embrittlement functions according iodine content "I":
 - When "I" is lower than a threshold of iodine content "IC1", there is no embrittlement of the material. The Kachanov's model is supposed to model the damage of the material under an inert environment.
 - When "I" is higher than a saturation iodine content "IC2", the I-SCC susceptibility of the material does not change.
 - The local iodine content "I" and the parameters IC1 and IC2 can be physical quantities or dimensionless quantities.

$$\dot{D} = A(I) \cdot e^{-\frac{Q}{T}} \cdot \left(\frac{\sigma_\theta}{1 - D} - \sigma_0(I) \right)^B$$



$$G_0(I) = \frac{1}{2} \cdot \sigma_0(I) \cdot u_c(I)$$





KACHANOV's damage law (3/3)

- The local iodine content “I” is assumed to follow I-SCC Miller’s model
 - Based on Fick’s law (diffusion)
 - Assuming that iodine does not diffuse in the zirconium, except in the I-SCC crack or at the tip of a crack, the Fick’s law can be written, in 2D-Rθ, as:
- τ is a period of time characteristic of the diffusion of iodine in the crack and the tip of a crack, in the zirconium.
- External iodine load “ I_{EXT} ” and the local iodine content “I” are fields of values defined on all the elements of the mesh in the FE simulations.
 - I_{EXT} is 0 everywhere, except in the crack or at the tip of the crack.
 - I_{EXT} is updated after each step of calculation in CAST3M according to the updated position of the I-SCC crack.





Viscoplastic behavior's law (1/3)

- Cladding's viscoplastic model for PCI conditions
 - Implemented in MFRONT
 - Zy-4 (Annie SONIAK, 1996) and M5 (Annie SONIAK, 2001)
 - Primary and secondary orthotropic viscoplastic creep strain combined

- $\dot{\varepsilon}_{eq}^{vp} = V_s + (V_p - V_s) \cdot \exp\left(-\frac{\dot{\varepsilon}_{eq}^{vp}}{\epsilon_0}\right)$

- $V_p = V_{p0}(\sigma_{Hill}, T) \cdot V_{pf}(\phi_t)$

$$V_{p0}(\sigma_{Hill}, T) = VP00 \cdot \exp\left(-\frac{Q_{p0}}{T}\right) \cdot \sinh\left(\frac{\sigma_{Hill}}{\sigma_{p0}}\right)$$

$$V_{pf}(\phi_t) = VPF1 \cdot \exp\left(-\frac{\phi_t}{PHI1}\right) + (1 - VPF1) \cdot \exp\left(-\frac{\phi_t}{PHI2}\right)$$

- $V_s = V_{s0}(\sigma_{Hill}, T) \cdot V_{sf}(\phi_t)$



$$V_{s0}(\sigma_{Hill}, T) = VS00 \cdot \exp\left(-\frac{Q_{s0}}{T}\right) \cdot \sinh\left(\frac{\sigma_{Hill}}{\sigma_{s0}}\right)$$

$$V_{sf}(\phi_t) = VSF1 + (1 - VSF1) \cdot \exp\left(-\frac{\phi_t}{PHI1}\right)$$



Viscoplastic behavior's law (2/3)

- Claddings' viscoplastic models for Reactivity Injection Accident (RIA)
 - Implemented in MFRONT
 - ZY4 (Matthieu LE SAUX, CEA, 2008) and CROCORIA (Elodie BOSSO, EDF, 2015)
 - Orthotropic Lemaître's law
 - $\dot{\varepsilon}_{eq}^{vp} = \left(\frac{\sigma_{Hill}}{K.L(\varepsilon_{eq}^{vp})} \right)^{1/m}$





Viscoplastic behavior's law (3/3)

- Effective stress

- $\sigma_{Hill}^{eff} = \frac{\sigma_{Hill}}{1-D}$

- Viscoplastic models coupled to Kachanov's law

- The effective stress acts on the material

- $\dot{\varepsilon}_{eq}^{vp} = (1 - D) \left(\frac{\sigma_{Hill}^{eff}}{K.L(\dot{\varepsilon}_{eq}^{vp})} \right)^{1/m}$

- Assuming $\sigma_{Hill}^{eff} \cdot \dot{\varepsilon}_{eq}^{eff} = \sigma_{Hill} \cdot \dot{\varepsilon}_{eq}^{vp}$ it allows to define an effective equivalent strain $\dot{\varepsilon}_{eq}^{eff} = (1 - D) \cdot \dot{\varepsilon}_{eq}^{vp}$

- $\dot{\varepsilon}_{eq}^{eff} = (1 - D) \left(\frac{\sigma_{Hill}^{eff}}{K.L(\dot{\varepsilon}_{eq}^{eff})} \right)^{1/m}$



3. Implementation in MFRONT

Strain rate and cyclic behavior



Implementation




- Damage allowed in the Radial-Axial plane of the cladding only
 - To avoid rotations of the principal stress coordinate system that are un-usefull for our needs
- Solved by Newton-Raphson in MFRONT
 - θ -method with $\theta=0,5$.
 - Jacobian calculated
 - Jacobian validated with the CompareToNumericalJacobian compilation option of MFRONT

$$[J] = \begin{bmatrix} \frac{\partial f_{eel}}{\partial \Delta eel} & \frac{\partial f_{eel}}{\partial \Delta p} & \frac{\partial f_{eel}}{\partial \Delta D} & \frac{\partial f_{eel}}{\partial \Delta I} \\ \frac{\partial f_{vp}}{\partial \Delta eel} & \frac{\partial f_{vp}}{\partial \Delta p} & \frac{\partial f_{vp}}{\partial \Delta D} & \frac{\partial f_{vp}}{\partial \Delta I} \\ \frac{\partial \Delta eel}{\partial f_{eel}} & \frac{\partial \Delta p}{\partial f_{eel}} & \frac{\partial \Delta D}{\partial f_{eel}} & \frac{\partial \Delta I}{\partial f_{eel}} \\ \frac{\partial f_D}{\partial \Delta eel} & \frac{\partial f_D}{\partial \Delta p} & \frac{\partial f_D}{\partial \Delta D} & \frac{\partial f_D}{\partial \Delta I} \\ \frac{\partial \Delta eel}{\partial f_D} & \frac{\partial \Delta p}{\partial f_D} & \frac{\partial \Delta D}{\partial f_D} & \frac{\partial \Delta I}{\partial f_D} \\ \frac{\partial f_I}{\partial \Delta eel} & \frac{\partial f_I}{\partial \Delta p} & \frac{\partial f_I}{\partial \Delta D} & \frac{\partial f_I}{\partial \Delta I} \\ \frac{\partial \Delta eel}{\partial f_I} & \frac{\partial \Delta p}{\partial f_I} & \frac{\partial \Delta D}{\partial f_I} & \frac{\partial \Delta I}{\partial f_I} \end{bmatrix}$$



Example on 1-element (1/3)




- Viscoplastic model + KACHANOV
- Comparison of the solution calculated with MFRONT compared to an analytical solution
 - One element loaded in constant strain rate in 3D (tested in pure shear too).
- The « Mini.Theor » solution is the theoretical solution obtained with the KACHANOV's law for an infinitely slow applied strain rate.
 - This solution defines an minimal mechanical energy required to lead the material to failure.
 - This solution is recalled on all the figures.





Validation de KACHANOV sur un élément (2/3)

- Viscoplastic model + KACHANOV
- Comparison of the solution calculated with MFRONT compared to an analytical solution
 - One element loaded in constant strain rate in 3D (tested in pure shear too).
- The « Mini.Theor » solution is the theoretical solution obtained with the KACHANOV's law for an infinitely slow applied strain rate.
 - This solution defines an minimal mechanical energy required to lead the material to failure.
 - This solution is recalled on all the figures.






Cyclic behavior(3/3)

■ Example of cyclic behavior

1. Elasto-viscoplastic load in traction
2. Progressive damage to final failure
3. Un-load of the failed element
4. Elastic re-load in compression
 1. From the cracking-deformation-to-failure and the viscoplastic déformation (negligible in this example)
5. Viscoplastic déformation in compression
6. Compressive elastic un-load
7. Elastic load of the failed element in tension







4. Examples of application

Inner Pressure tests, polycrystalline simulations



Inner Pressure Tests



Results presented at OECD-NEA - PCI WORKSHOP – 22-24 june 2016 – Lucca,



24/11/2025

21




Polycrystalline simulations

- To simulate the intergranular initiation of an I-SCC crack.
 - The KACHANOV-MILLER model has been implemented in the Grain-Boundaries of a polycrystalline mesh
 - Orthotropic viscoplastic models in the grains.
 - Constant resulting force F applied at the upper and lower boundaries of the box



I-SCC intergranular crack at 4h27mn




Local vertical stress at 4h27mn





Example on a plate and a tube

- Plate in tension a 2D



- Portion of cladding in inner pressure in 3D
 - Miller's diffusion law generalised to 3D

$$\dot{I} = \left(\frac{n_R}{\tau_R} + \frac{n_Z}{\tau_Z} \right) (I_{\text{EXT}} - I)$$





4. Conclusions

Perspectives





Conclusions and perspectives

- KACHANOV implemented in MFRONT
 - KACHANOV was implemented in MISTRAL before
 - MISTRAL is a catalogue of behavior's law. It pre-allocates 99 parameters and 99 inner variables in the computer's memory whatever the behavior's law of the catalogue
 - KACHANOV works faster with MFRONT
- Coupled to a simplified diffusion of iodine to simulate the initiation and the propagation of an I-SCC crack
 - At a macroscopic scale (in the frame of homogeneous and continuous media)
 - At a polycrystalline scale (to simulate the intergranular initiation)
- Perspectives
 - Replacing the MILLER's simplified diffusion model by a physical diffusion model.
 - $$\frac{\partial I}{\partial t} = -D_{Zr} \cdot \left(\nabla I + \frac{IQ^*}{RT^2} \nabla T - \frac{IV}{RT} \nabla P \right)$$
 - The implementation in MFRONT makes it possible to simulate the transgranular propagation at the polycrystalline scale
 - Using the model, coupled with an orthotropic model, in each grains


$$\sigma_D = \sqrt{<\sigma_{\theta\theta}>^2 + \beta(\sigma_{R\theta}^2 + \sigma_{Z\theta}^2)}$$

Quasi-clivage Fluting





isas



Thank you

CEA SACLAY
91191 Gif-sur-Yvette Cedex
France
David.leboulch@cea.fr
Standard. + 33 1 69 08 60 00



Laboratory tests (example)

Inner Pressure tests with iodine vapor


- Inner Pressure P experimentally controlled
- At PWR's temperature of the inner wall of the cladding (320°C-420°C)
- pI_2 is very big in these tests and pO_2 is not controlled !!!
 - Difficult to go lower in iodine content

$$pI_2 \approx 3 \text{ bars} = 3.10^5 \text{ Pa}$$

$$\frac{nI_2}{n_{\text{Argon}}} \approx 1 \%$$

pO_2 evaluated to 3000 Pa (Jezequel, 2017)

$$\frac{nO_2}{n_{\text{Argon}}} \approx 0,01 \%$$



$$\sigma_{\theta\theta} = P \cdot \frac{(R_{\text{out}} + R_{\text{in}})}{2 \cdot e}$$



$$P \approx 300 \text{ bars}$$

$$\sigma_{\theta\theta} \sim 300 \text{ MPa}$$





New laboratory tests

- To better simulate the PWR physico-chemical environment in laboratory



Wilczynska, 2020

$$P \approx 1 \text{ bar} = 10^5 \text{ Pa}$$



- Device in quartz to avoid chemical interactions with iodine
 - Low pO_2 controlled (above 1-10 Pa)
 - Possibility to go lower under study
 - Low pI_2 controlled (above 1-10 Pa)
 - Possible to go lower
 - Temperature controlled

$$\frac{nI_2}{n_{Argon}} \approx 0,01 \% \quad \frac{nO_2}{n_{Argon}} \approx 0,01 \%$$



PWR simulations (ALCYONE)

- The polycrystalline scale is better to study PCI/I-SCC failures in PWR ?
 - No experimental device to study that scale, under vapor iodine, today → Simulations instead ?

