

Linear Expansion on Materials

Authors: Maddx Nguyen, Jesus Saldana, Marcos Manjarrez, Alan Calvillo, Tyler Wilcox, and
Tyler Gamel

Keywords: expansion, materials, thermal, temperature, vibrations, machining

Abstract: The purpose of this study was to evaluate the importance of linear expansion on different materials. The stability of materials is fundamental to Modern-Day Manufacturing and can cause significant shifts that may prevent the materials from being used properly. A substantial component of material stability is the Linear Thermal Expansion (LTE), which is the change in the materials length over a period of time due to temperature. The basis of linear expansion is determined with the strength in bond order of metallic, ionic or covalent bonds and how the spacing of each bond increases as the temperature begins to rise. Although the change in temperature has a great factor on the LTE, the difference in crystal structure and microstructure may lead materials to expand or contract at tremendously different rates. When restructuring a material, it is important to look at not just the material being made, but also the machine itself as the heat can affect alignment and distort components. While tooling materials at high speeds, they must withstand the thermal gradient from high to low without losing geometry. In certain cases, LTE becomes an advantage rather than a limitation; shrink fits, thermally assisted assemblies, and hybrid metal-ceramic designs all rely on controlled expansion and contraction.

Table of Contents

1. Introduction
 - 1.1 Importance of dimensional stability in manufacturing
 - 1.2 Overview of linear thermal expansion as a materials property
 - 1.3 Objectives of this paper
2. Materials Science Basis of Linear Thermal Expansion
 - 2.1 Understanding bonding and thermal vibrations
 - 2.2 Interatomic potential and anharmonicity explanation
 - 2.3 Relationship between bonding strength and CTE
 - 2.4 Effect of crystal structure (FCC, BCC, HCP) on thermal expansion
3. Comparing Coefficients of Thermal Expansions
 - 3.1 Metals and alloys
 - 3.2 Ceramics
 - 3.3 Composites and polymers
 - 3.4 Temperature dependence of CTE
4. Impact of LTE in Manufacturing
 - 4.1 Part expansion and specific material distortion
 - 4.2 Machine tool materials
 - 4.3 Tooling materials: HSS, carbide, ceramics, CBN
 - 4.4 Aluminum vs Titanium machining tolerance
5. Using LTE for benefit
 - 5.1 Shrink fit and assemblies interference in metal parts
 - 5.2 Thermal Expansion in ceramics vs metallic applications
 - 5.3 Controlled heating/cooling for assembly and disassembly
6. Material Selection for Tolerances
 - 6.1 Low-expansion alloys (Invar, Super-Invar)
 - 6.2 Heat treatment effects on expansion
 - 6.3 Engineering Trade-off: Machinability vs Expansion properties
7. Conclusion

1. Introduction

1.1. Importance of Dimensional Stability in Manufacturing

“Measure twice, cut once.” Preached across all of modern manufacturing, this statement highlights the importance of precision, accuracy, and reliability. Principles of which form the foundation of every engineering process. In an age of extremely tight tolerances and modern technology, even the smallest dimensional deviations could determine whether a part functions flawlessly or fails prematurely. Making dimensional stability essential to maintaining part accuracy under variable thermal conditions encountered during production.

Linear thermal expansion (LTE) is one of the most important material properties that are affecting dimensional stability. It describes how materials change in size with temperature, governing whether a part will retain its designed geometry when subjected to heat from machining, ambient conditions, or operational environments such as a CNC warehouse. In CNC machining, where both the workpiece/material and the tooling, such as a tooling bit, experience significant localized heating, LTE can alter final dimensions, alignment, and surface finish—sometimes by several inches over short time intervals. Understanding and compensating for this behavior is a cornerstone of precision manufacturing and crucial to engineering as a whole.

1.2 Overview of Linear Thermal Expansion as a Materials Property

Linear thermal expansion is defined as “the proportional change in a material’s length per unit temperature change” and is mathematically expressed as:

$$\Delta L = \alpha L_0 \Delta T \quad (\text{Equation 1})$$

where ΔL is the change in length, L_0 is the original length, ΔT is the temperature difference, and α denotes the coefficient of linear thermal expansion (CTE). This coefficient shows the extent at which atomic spacing within a material increases or decreases with temperature.

As temperature increases, the atoms in a solid begin to vibrate more intensely around their normal positions. These vibrations aren’t perfectly balanced, making the average spacing between atoms grow slightly, causing the material to expand. Because the amount of expansion depends on how the atoms are bonded and how the crystal structure is arranged. Metals will usually expand more because their metallic bonds are relatively flexible and their electrons can move freely, while ceramics, that are held together by stronger ionic or covalent bonds, tend to expand much less under the same conditions.

In manufacturing, these atomic-scale variability can have macroscopic consequences. Variations in CTE among materials can influence assembly, it can cause tool or part warping, and even alter machine calibration. Thermal expansion thus serves not merely as a materials science concept but as a practical engineering challenge that directly determines precision and reliability.

1.3 Objectives of This Paper

The objective of this paper, explores linear thermal expansion and its factor in CNC machining accuracy as well as manufacturing quality. We will begin by looking at the atomic and theoretical parts of LTE, then explore how interatomic bonding, vibrational energy, and crystal structure define expansion behavior, with additional sections comparing the coefficients of thermal expansion across some of the major material classes, including metals, ceramics, polymers, and composite, followed by evaluating the specific implications for machining processes and dimensional control. Finally, this paper will explore how engineers can utilize or mitigate LTE effects through material selection, heat treatment, and controlled thermal fitting.

2. Materials Science Basis of Linear Thermal Expansion

2.1 Understanding Bonding and Thermal Vibrations

To understand linear thermal expansion we must start at the atomic level, since all solids are built from atoms held together by bonds such as metallic, ionic, or covalent. These bonds determine how strong an atom's resistance is to motion. As we previously discussed, as temperature increases on a solid, their atoms move/vibrate faster around their equilibrium positions, these vibrations grow in amplitude and the average spacing between atoms increases. When this effect accumulates throughout the crystal lattice, it produces a measurable change in the materials length and/or volume.

Overall, thermal expansion reflects how atoms respond to heat energy. The stronger the bonding between them, the less movement/vibration will occur. In other words, the weaker the bonding, the more freely they expand.

2.2 Interatomic Potential and Anharmonicity

Typical interatomic Potential




Figure 1. Typical interatomic potential showing equilibrium bond distance r_0 and the shift in average spacing with increasing temperature.

At the atomic level, the behavior behind expansion can be visualized using an interatomic potential energy curve, often represented by a Morse or Lennard-Jones potential (Figure 1). At low temperatures, atoms vibrate near the bottom of this curve, close to their equilibrium bond distance, r_0 . While as temperature increases, these vibrations become slightly more unbalanced, with atoms spending more time on the right side of the curve than on the compression side. This asymmetry is known as anharmonicity.

This in turn, shifts the average bond length outward, resulting in a small but measurable expansion of the material. If the potential were perfectly symmetrical, no net change in bond length would occur. However, because real materials are anharmonic, their atomic spacing and their overall dimensions increase as temperature rises.

2.3 Relationship Between Bonding Strength and CTE

The strength of atomic bonds directly influences the coefficient of thermal expansion (CTE). Materials with strong bonds, such as ceramics, expand very little, while those with weaker metallic bonds expand more. For instance, silicon carbide and alumina have CTEs near $8 \times 10^{-6} K^{-1}$, while aluminum reaches about $23 \times 10^{-6} K^{-1}$. This difference explains why metals tend to shift more under thermal loads.

In tight tolerance manufacturing situations, this relationship is critical. A low expansion ceramic may maintain perfect alignment in an optical device, whereas a high-expansion metal could distort a machined component by several micrometers if not compensated for in the part design.

2.4 Effect of Crystal Structure on Thermal Expansion

A material's crystal structure, or the way its atoms are arranged, also affects its expansion behavior. Metals commonly form face-centered cubic (FCC), body-centered cubic (BCC), or hexagonal close-packed (HCP) structures.

FCC metals such as aluminum and copper are tightly packed and expand fairly evenly in all directions. BCC metals, including many steels, have more open structures, which can lead to higher and less uniform expansion. HCP metals like titanium and magnesium expand differently along various directions in the lattice, resulting in anisotropic expansion. Phase changes, such as the BCC to FCC transformation in steel, can also cause sudden shifts in CTE values. These must be managed carefully during heat treatment or precision machining to prevent dimensional distortion.

3. Comparing Coefficients of Thermal Expansions

3.1 Metals and Alloys

Metals are the most widely used materials in machining, and their coefficients of thermal expansion (CTE) vary significantly depending on bonding type, alloy composition, and crystal structure. Among common metals, aluminum exhibits one of the highest CTE values at roughly $23 \times 10^{-6} K^{-1}$. This makes it more susceptible to dimensional changes during heating and cooling, which can affect surface accuracy if temperature control is not maintained.

Steel, depending on its composition and heat treatment, generally falls in the range of $10 \times 10^{-6} K^{-1}$ to $14 \times 10^{-6} K^{-1}$. This moderate expansion allows steels to retain dimensional accuracy better than aluminum but still requires temperature management during precision operations. Titanium alloys have even lower CTEs, typically around $8 \times 10^{-6} K^{-1}$, making them ideal for aerospace engineering, which demands minimal deformation under heat.

Nickel based alloys such as, inconel, are designed for high-temperature performance, with CTEs that are comparable to steels, but their strength retention and resistance to creep at elevated temperatures make them highly stable in thermal cycling environments. In machining, these differences dictate not only how parts respond to temperature but also how cutting tools and fixtures must compensate for expansion to maintain tight tolerances.

3.2 Ceramics

Ceramics are characterized by strong ionic or covalent bonds, which give them a low CTE value as well as excellent dimensional stability. Alumina and silicon carbide have CTEs in the range of

$4 \times 10^{-6} K^{-1}$ to $8 \times 10^{-6} K^{-1}$, while a lesser stabilized zirconia can range from about $8 \times 10^{-6} K^{-1}$ to about $11 \times 10^{-6} K^{-1}$.

This low expansion means ceramics keep precise geometries even under rapid temperature changes, which is one reason they are used for cutting tools, heat shields, and precision components in electronics. However, “their brittleness limits their use in large structural parts” (Duong) that experience thermal shock or mechanical stress.

In manufacturing, ceramics are valuable in applications where stability outweighs toughness. For example, ceramic tool inserts used in CNC machining remain dimensionally consistent under high cutting temperatures, allowing for consistent surface finishes and extended tool life.

3.3 Composites and Polymers

Composites and polymers behave differently because their structure combines multiple materials with varying expansion rates. Carbon fiber reinforced polymers (CFRPs) are engineered to achieve very low or even near-zero CTEs along the fiber direction, sometimes as low as almost zero to around $2 \times 10^{-6} K^{-1}$. This makes them ideal for high-precision aerospace and automotive applications where lightweight stability is essential.

In contrast, common polymers and plastics such as polyethylene and epoxy resins have much higher CTEs, often between $50 \times 10^{-6} K^{-1}$ to $150 \times 10^{-6} K^{-1}$. Their molecular chains expand significantly with temperature, which can lead to warping, softening, or dimensional changes if not stabilized.

Composite materials allow engineers and manufacturers to tailor to expansion properties by adjusting fiber orientation, matrix composition, or filler content. This ability to modify the material has made them increasingly attractive for precision assemblies that must withstand wide temperature ranges without distortion.

3.4 Temperature Dependence of CTE

However, it's important to note that the coefficient of thermal expansion is not constant across all temperatures. At lower temperatures, atomic vibrations are smaller and expansion rates remain nearly linear. As temperature rises, anharmonic effects become stronger, causing CTE to increase nonlinearly.

For instance, the increase for metals can be moderate, yet still significant enough to influence precision machining, especially when components heat unevenly. Compared to ceramics, with their stronger bonds, which maintain a relatively stable CTE over a wide range, however still, can show abrupt changes near phase transitions or when approaching their melting points. Polymers exhibit the most

dramatic changes, especially around their glass transition temperature, where expansion can spike as the material softens.

Understanding these temperature-dependent behaviors allows engineers to anticipate how materials will behave in manufacturing. Machining aluminum at elevated temperatures requires real-time thermal compensation, while processing titanium or ceramic materials demands less adjustment due to their lower thermal response. Predicting and managing these effects ensures that the dimensional accuracy of parts remains within specified tolerances under any operational condition.

4. Impact of LTE in Manufacturing


4.1 Part Expansion and Specific Material Distortion

When a component and/or part is machined, both the workpiece (material being cut) and the surrounding environment (both the machine and the surrounding temperature) experience temperature fluctuations. This is due to the cutting/drilling processes, which create localized heat builds up at the tooling, leading to expansion of the material. If the heat is unevenly distributed, expansion occurs nonuniformly, causing warping, dimensional drift, or even residual stress after cooling. Sometimes the part may even melt during this process.

The magnitude of distortion depends on the coefficient of thermal expansion of the material and the geometry of the part. A thin walled or asymmetrical component is especially prone to bending, twisting, leaving a warped part or surface that may be unusable in a tight tolerance case. For example, aluminum parts, with their higher CTE, tend to expand more rapidly than steel or titanium, often requiring dimensional offsets or in-process temperature compensation. In comparison to a low expansion materials such as ceramics or certain composites, maintain geometry better but can still experience cracking if rapid temperature changes occur.

4.2 Machine Tool Materials

The structural parts of CNC machines themselves, containing things such as the bed, spindle and column which are also subject to thermal expansion (Figure 2). As these components heat up during operation, even small changes in dimension can alter tool paths and cutting accuracy. For example, a few micrometers of spindle elongation can translate into measurable deviations on the finished surface.



To counteract this, machine tool frames are typically constructed from low-expansion alloys or cast iron, which combine good damping capacity with moderate CTE values. Advanced systems may employ granite or polymer–concrete bases for enhanced thermal stability, some high-precision machines even integrate active temperature control systems or compensating algorithms that adjust positioning in real time, however, even these algorithms can malfunction, leaving the engineers and machinists left to ensure this failure doesn’t occur. Managing the LTE behavior of the machine itself is just as critical as compensating for that of the workpiece. This is why many “shops” where CNC machining is done, especially in aerospace manufacturing, have operators, running every machine, following what’s called a workbook—made by the engineers— to constantly check positions, materials, and temperatures.

4.3 Tooling Materials: HSS, Carbide, Ceramics, and CBN

Cutting tools experience extreme and localized temperature increases during machining. Tool materials must therefore not only resist wear but also maintain dimensional stability under heat. High-speed steels, HSS for short, have moderate hot hardness and relatively high CTEs. This can cause minor size variations during extended cutting cycles. Cemented carbides on the other hand, offer lower thermal expansion and greater heat resistance. Making them the “industry standard” for most precision applications.

Ceramic and cubic boron nitride (CBN) tools exhibit excellent thermal stability with very low CTEs, allowing them to retain sharpness and geometry even at elevated temperatures. However, ceramics are brittle and require controlled cutting conditions to prevent fracture. CBN tools, while costly, are favored for hard turning operations where maintaining dimensional accuracy under high heat is essential. With conditions like the ones put on the tooling and parts, ensuring that picking the right material is key to the success of machining.

4.4 Aluminum vs. Titanium Machining Tolerance

Aluminum and titanium present contrasting challenges in CNC machining due to their vastly different thermal expansion behaviors. Aluminum, with its high CTE and excellent thermal conductivity, heats and expands rapidly during cutting. This can result in oversized features or misaligned surfaces if temperature effects are not compensated. Machinists often use real time offsets, coolant systems, and environmental control to counteract these changes.

Titanium, conversely, has a much lower CTE but poor thermal conductivity, meaning heat tends to concentrate near the cutting zone. This localized heating can lead to tool wear or microstructural alteration rather than bulk expansion. Maintaining tight tolerances when machining titanium relies more on controlling tool temperature and managing cutting forces than on expansion compensation.

By understanding how each material reacts thermally, engineers can tailor cutting speeds, feeds, and coolant strategies to maintain dimensional precision across varying production environments.

5. Using LTE for Benefit

5.1 Shrink Fit and Assemblies Interference in Metal Parts

Although LTE is commonly viewed as a limitation, there have been several ways found that can exploit its properties to help decrease any of these limitations. One option that has been used is shrink fitting. Shrink fitting relies on the predictable expansion and contraction of metals to create tight, permanent joints without the need for adhesives or complex fasteners. Through this process, one component, normally a collar, bearing, or bushing, is heated to expand its inner diameter, while the mating shaft or insert is cooled to slightly contract its outer diameter. When the two parts are assembled and allowed to return to ambient temperature, the differential expansion locks them securely together, forming a strong interference fit. It is good to be careful with this method, as it requires precise control of temperature. Too much heat can permanently damage some components and should be avoided if applicable.

This technique is used in turbine construction, press-fitted gears, and high-speed rotating assemblies where mechanical reliability is critical. The joint ends up being extremely strong and keeps the parts aligned even under heavy operational stress. By calculating the required temperature difference and material CTEs, engineers can achieve precise fits that stay stable for years of operation in real systems.

5.2 Thermal Expansion in Ceramics vs. Metallic Applications

The difference in thermal expansion behavior between metals and ceramics allows strengths of both materials to be combined through hybrid designs. Metals, which have higher CTE values, expand and contract more easily when under temperature changes, while ceramics maintain dimensional stability and hardness even at higher temperatures.

In applications such as cutting tools, turbine blades, or electronic packages, ceramic inserts are often bonded or mechanically clamped into metallic housings. By being aware of thermal expansion throughout the design process, it is easier to control the outcome as the metal expands. To avoid this, the metal grips the ceramic element more tightly, therefore improving thermal contact and mechanical stability in the system. Alternatively, during cooling, the differential contraction can be controlled to permit disassembly or component replacement without inducing fracture or stress in the ceramic element. Properly balancing these expansion characteristics results in the making of a much more durable, high-precision assembly that can perform in much more broad temperature changes reliably.

5.3 Controlled Heating and Cooling for Assembly and Disassembly

Beyond assembly, controlled thermal expansion also simplifies disassembly and maintenance of complex components. Heating a press-fit or interference joint causes the outer member to expand, which releases any internal stresses while also loosening the fit. This principle is widely used for removing gears, bearings, and sleeves from shafts without unwanted mechanical force or damage to surrounding parts.

Similarly, localized cooling using cryogenic methods can temporarily contract a component, allowing it to be withdrawn or replaced with much more ease. During any required maintenance, such as turbine repair or aerospace assembly, engineers are able to carefully regulate temperature gradients to ensure predictable expansion and avoid residual stresses. The ability to use heat or cold selectively provides a safe and efficient way to assemble, adjust, or separate tightly fitted components.

In using LTE strategically, manufacturers transform a potential thermal limitation into a reliable design advantage, in turn, making temperature itself a method for achieving high-performance, strong, and precise mechanical systems.

6. Material Selection for Tolerances

6.1 Low-Expansion Alloys (Invar, Super-Invar)

Achieving tight dimensional tolerances depends heavily on selecting materials with stable thermal expansion characteristics. Among the most well-known low-expansion materials are Invar and Super-Invar, both iron-nickel alloys engineered for minimal dimensional change under temperature fluctuations.

Invar, containing approximately 36% nickel, has a remarkably low coefficient of thermal expansion of about $1.2 \times 10^{-6} K^{-1}$. This near zero expansion results from magnetic ordering effects that counteract thermal lattice vibrations within a specific temperature range. Super-Invar, which incorporates

additional cobalt, exhibits an even lower and more stable CTE, making it ideal for critical precision instruments such as optical mounts, gauge blocks, and aerospace measuring systems.

While these alloys provide exceptional dimensional control, they are not without trade-offs. Their unique microstructures make them more challenging to machine than conventional steels. They can also lose stability if subjected to mechanical deformation or heat beyond their designed range, requiring strict process control during fabrication. Despite these challenges, low-expansion alloys remain essential when tolerance demands exceed the limits of standard metals.

6.2 Heat Treatment Effects on Expansion

Heat treatment offers another method to control thermal expansion. By altering microstructure, residual stresses, and atomic ordering, heat treatment can either reduce or stabilize expansion behavior. In steels, processes such as quenching and tempering modify internal stresses and lattice defects, which in turn influence the CTE. Precipitation-hardened aluminum alloys experience similar effects, where controlled heat cycling stabilizes expansion characteristics before final machining.

Annealing is often used to relieve internal stress in components that might otherwise warp under thermal cycling. For precision parts, especially those used in metrology or optics, stress-relief treatments ensure uniform expansion throughout the material. This consistency minimizes distortion and ensures predictable behavior during both machining and service conditions.

6.3 Engineering Trade-Off: Machinability vs. Expansion Properties

The selection of a material with ideal expansion characteristics often comes with trade-offs in machinability, cost, and performance. Materials with low CTEs, such as Invar or certain ceramics, may provide superior dimensional stability but are more difficult to cut, grind, or polish. These materials also tend to have lower thermal conductivity, which can increase tool wear and reduce cutting efficiency.

Conversely, materials that are easy to machine, like aluminum, expand more readily and require strict temperature management during production. Engineers must weigh the importance of dimensional precision against manufacturing efficiency, cost, and durability. In most cases, design tolerances are established by balancing these opposing factors.

Modern machining strategies address this trade-off through thermal compensation systems that predict and adjust for expansion in real time. By integrating sensors and temperature models into CNC controls, manufacturers can use higher-expansion materials without sacrificing dimensional accuracy. This approach allows both efficient processing and consistent results, combining material science with adaptive engineering.

7. Conclusion

In this essay, we looked at linear thermal expansion from both the theoretical side and how it shows up in real manufacturing. We started at the atomic level, then moved through different material classes, machine behavior, tooling choices, and finally how engineers can either fight against LTE or use it to their advantage.

The main idea is simple: parts do not stay the same size when the temperature changes and ignoring that fact is how you end up with bad fits, warped components, and blown tolerances which can lose a company millions of dollars. Whether it is an aluminum bracket growing under cutting heat, a spindle stretching a few micrometers, or a composite structure staying stable where metal would move, LTE is always in the background of every machining decision.

At the same time, thermal expansion is not only a problem to fix. When it is understood and planned for, it becomes a useful tool—shrink fits, thermally assisted assemblies, and carefully chosen low-expansion alloys all depend on it. Good engineering here is less about “stopping” expansion and more about knowing how much will happen, where it will happen, and designing around it.

In the end, understanding LTE is part of what separates guessing from real precision. If an engineer can predict how a material or machine will react to temperature, they can make parts that are accurate, repeatable, and reliable in actual working conditions—not just on paper.

Acknowledgements:

Abstract - Jesus Saldana

Introduction 1.1-1.3 - Marcos Manjarrez.

Materials Science Basics of Linear Thermal Expansion 2.1-2.4 - Maddx Nguyen

Comparing Coefficients of Thermal Expansion 3.1-3.4 - Jesus Saldana

Impact of LTE in Manufacturing 4.1-4.4 - Alan Calvillo

Using LTE for benefit 5.1-5.3 - Tyler Wilcox

Material Selection for Tolerance 6.1-6.3 - Tyler Gamel

Conclusion: Maddx Nguyen

Editor: Maddx Nguyen

References:

- [1] Collins, J.G., 1963. On the calculation of the temperature variation of the coefficient of thermal expansion for materials of cubic structure. *Philosophical Magazine*, 8(86), pp.323-332.
- [2] Zhang, J., Cui, J., Yang, Z. and Yu, Y., 2019. Heat capacity and thermal expansion of metal crystalline materials based on dynamic thermal vibration. *Computational Mechanics*, 63(5), pp.971-984.
- [3] Müser, M.H., Sukhomlinov, S.V. and Pastewka, L., 2023. Interatomic potentials: Achievements and challenges. *Advances in Physics: X*, 8(1), p.2093129.
- [4] Knoop, F., Purcell, T.A., Scheffler, M. and Carbogno, C., 2020. Anharmonicity measure for materials. *Physical Review Materials*, 4(8), p.083809.
- [5] Tilley, R.J., 2020. *Crystals and crystal structures*. John Wiley & Sons.
- [6] Huber, T., Degischer, H.P., Lefranc, G. and Schmitt, T., 2006. Thermal expansion studies on aluminium-matrix composites with different reinforcement architecture of SiC particles. *Composites Science and Technology*, 66(13), pp.2206-2217.
- [7] Chen, Y., Ye, L. and Dong, H., 2023. Lightweight 3D carbon fibre reinforced composite lattice structures of high thermal-dimensional stability. *Composite Structures*, 304, p.116471.
- [8] Taylor, C.A., Wayne, M.F. and Chiu, W.K., 2003. Heat treatment of thin carbon films and the effect on residual stress, modulus, thermal expansion and microstructure. *Carbon*, 41(10), pp.1867-1875.
- [9] Vöhringer, O., 1987. Relaxation of residual stresses by annealing or mechanical treatment. *Advances in surface treatments*, 4, pp.367-96.
- [10] Wang, J., Chen, C., Zhou, Y., Wu, Z., Gao, X., Zhao, B., Zhang, L. and Wang, H., Understanding the Invar Effect in the Fe–Ni–Co System: An In-Situ High-Throughput Study. *Available at SSRN 4638411*.
- [11] Ruffa, A.R., 1980. Thermal expansion in insulating materials. *Journal of Materials Science*, 15(9), pp.2258-2267.
- [12] Roy, R., Agrawal, D.K. and McKinstry, H.A., 1989. Very low thermal expansion coefficient materials. *Annual Review of Materials Science*, 19(1), pp.59-81.
- [13] Takenaka, K., 2012. Negative thermal expansion materials: technological key for control of thermal expansion. *Science and technology of advanced materials*, 13(1), p.013001.
- [14] Takezawa, A. and Kobashi, M., 2017. Design methodology for porous composites with tunable thermal expansion produced by multi-material topology optimization and additive manufacturing. *Composites Part B: Engineering*, 131, pp.21-29.
- [15] Fransson, E., Eriksson, F. and Erhart, P., 2020. Efficient construction of linear models in materials modeling and applications to force constant expansions. *npj Computational Materials*, 6(1), p.135.

- [16] Lopes, S.C., Pagnano, V.O., Rollo, J.M.D.D.A., Leal, M.B. and Bezzon, O.L., 2009. Correlation between metal-ceramic bond strength and coefficient of linear thermal expansion difference. *Journal of applied oral science*, 17, pp.122-128
- [17] Fei, Y.B., Lu, J.H., Li, H.J., Guo, L.J. and Chen, Z.S., 2014. Influence of heat treatment temperature on microstructure and thermal expansion properties of 2D carbon/carbon composites. *Vacuum*, 102, pp.51-53.
- [18] Wang, S., Zhou, B., Fang, C. and Sun, S., 2017. Research on thermal deformation of large CNC gear profile grinding machine tools. *The International Journal of Advanced Manufacturing Technology*, 91(1), pp.577-587.
- [19] Park, S.C., Bang, H.S. and Seong, W.J., 2020. Effects of material properties on angular distortion in wire arc additive manufacturing: experimental and computational analyses. *Materials*, 13(6), p.1399.
- [20] Davidovits, J. and Davidovics, M., 1991. Geopolymer: ultra-high temperature tooling material for the manufacture of advanced composites. *How Concept Becomes Reality*, 36, pp.1939-1949.
- [21] Jochym, Paweł T., et al. "Influence of Anharmonicity on the Negative Thermal Expansion of α -Sn." *Physical Review Materials*, vol. 6, no. 11, 2022, p. 113601.
- [22] Sun, Y., L. Wang, and C. Wang. "Anharmonicity and Lattice Thermal Conductivity of Negative Thermal Expansion Materials $\text{Zn}(\text{CN})_2$ and $\text{Cd}(\text{CN})_2$ by First-Principles Calculations." *Dalton Transactions*, vol. 54, 2025, pp. 764–773.
- [23] Yun, H., Zou, B., Wang, J., Huang, C., Xing, H., Shi, Z. and Xue, K., 2020. Design and fabrication of graded cBN tool materials through high temperature high pressure method. *Journal of Alloys and Compounds*, 832, p.154937.
- [24] Pimenov, D.Y., Kiran, M., Khanna, N., Pintaude, G., Vasco, M.C., da Silva, L.R.R. and Giasin, K., 2023. Review of improvement of machinability and surface integrity in machining on aluminum alloys. *The International Journal of Advanced Manufacturing Technology*, 129(11), pp.4743-4779.
- [25] Hirata, Y., 2015. Theoretical analyses of thermal shock and thermal expansion coefficients of metals and ceramics. *Ceramics International*, 41(1), pp.1145-1153.
- [26] Wu, Q., He, B., Song, T., Gao, J. and Shi, S., 2016. Cluster expansion method and its application in computational materials science. *Computational Materials Science*, 125, pp.243-254.
- [27] Ho, C.Y. and Taylor, R.E. eds., 1998. *Thermal expansion of solids* (Vol. 4). ASM international.
- [28] Schapery, R.A., 1968. Thermal expansion coefficients of composite materials based on energy principles. *Journal of Composite materials*, 2(3), pp.380-404.
- [29] Johnson, R.R., Kural, M.H. and Mackey, G.B., 1981. *Thermal Expansion Properties of Composite Materials* (No. NASACR165632).

[30] Liu, Z., Gao, Q., Chen, J., Deng, J., Lin, K. and Xing, X., 2018. Negative thermal expansion in molecular materials. *Chemical Communications*, 54(41), pp.5164-5176.