Data map of RICOH SP112 cartridge chip's memory

	0x00	0x01	0x02	0x03	0x04	0x05	0x06	0x07
0x00	\mathbf{M}^1	CV^2	\mathbf{B}^3	Region ⁴	Cartridge type ⁵ 0x0			0x00
0x08	IT^{6}	0x00	EDP code (407166)					
0x10	Cartridge serial number							
0x18	0x00				Control number			
0x20	Printer serial number							
0x28					PT^7	OW ⁸	0x	00
0x30	0.00							
0x38	0x 0 0							
0x40	Number of pages printed				0x00			
0x48	000							
0x50	0x 0 0							
0x58	Control number				0x00			
0x60	0x00							
0x68	C	C^9		0x00				
0x70	Amount of toner used				0x	00	WT^{10}	BF^{11}
0x78	0x00							

- Model 1
- Cartridge version
- 3
- Region of destination of the cartridge (e.g. Europe)
 Cartridge type (0x01,0x01,0x03 starter, 0x03,0x01,0x01 standard) 5
- The initial amount of toner in percent 6
- 7 The percentage of toner remaining
- 8 OPC drum wear
- Number of cartridge cleaning cycles 9
- 10 The percentage filling level of the waste toner container
- 11 Bit field (cardridge status)