

Full digitally controlled Power Supply design

Olivier Monnier
TI Business Development Manager, C2000 DSP Controllers

Agenda

- ◆ The Digital Vision: Why DSP?
- ◆ Digital world: FACTS and FIGURES
- ◆ Digital AC/DC Rectifier challenges
- ◆ Software Strategy
- ◆ Implementation
- ◆ Next Steps


Agenda

- ◆ The Digital Vision: Why DSP?
- ◆ Digital world: FACTS and FIGURES
- ◆ Digital AC/DC Rectifier challenges
- ◆ Software Strategy
- ◆ Next Steps


The Digital Vision

- ◆ Why Digital Approach for Power Supplies?
- ◆ Why DSP Controllers?


Typical Analog based AC/DC rectifier




Digital approach with Single Device example for AC/DC Rectifier




- 1000W / 48 V
- F2810 DSP based
- 2 Phase PFC-IL
- Phase shifted ZVS-FB
- 200 KHz PWM (DC/DC)
- 100 KHz PWM (PFC)




Typical 'Control' System On A Chip



Why DSP for Power Supplies?



	Analog Controller	Digital Controller
+	<ul style="list-style-type: none"> ◆ High bandwidth ◆ High resolution ◆ Easy to understand / use ◆ "relatively' low cost ?? 	<ul style="list-style-type: none"> ◆ Insensitive to environment (temp, drift,...) ◆ High reliability ◆ S/w programmable / flexible solution ◆ Precise / predictable behaviour ◆ Advanced control possible (non-linear, multi-variable) ◆ Can perform multiple loops and "other" functions
-	<ul style="list-style-type: none"> ◆ Component drift and aging / unstable ◆ Component tolerances ◆ Hardwired / not flexible ◆ Limited to classical control theory only ◆ Large parts count for complex systems 	<ul style="list-style-type: none"> ◆ Bandwidth limitations (sampling loop) ◆ PWM frequency and resolution limits ◆ Numerical problems (quantisation, rounding,...) ◆ AD / DA boundary (resolution, speed, cost) ◆ CPU performance limitations ◆ System cost



DSP Controllers value-Proposition

- ◆ Integration
- ◆ Flexibility
- ◆ Ease of differentiation
- ◆ System cost optimization

- ◆ Two Main Power Supply domains targeted
 - Industrial power supplies above 1kW
 - Multi-phase DC/DC loops requiring synchronization

Agenda

- ◆ The Digital Vision: Why DSP?
- ◆ Digital world: FACTS and FIGURES
- ◆ Digital AC/DC Rectifier challenges
- ◆ Software Strategy
- ◆ Next Steps

Controller Considerations for Digital Power Supplies

- ◆ Ease of Use
- ◆ SW *Fear factor !*
- ◆ Reliability
- ◆ CPU Performance
- ◆ PWM resolution
- ◆ Low Interrupt Latency
- ◆ Fast Sample Rate
- ◆ Numeric Considerations
- ◆ Cost
- ◆ Technical Support


Fully Digital System

- ◆ Some Facts, Figures and Capabilities


Technology for Innovators™



The Digital Domain.....



Processor capability



Inst. vs Algorithm

S/W algorithm	clks
Controller (2 pole / 2 zero)	26
Controller (3 pole / 3 zero)	36
PFC current command	30
PFC OVP	25
BiQuad Filter	46
ZVSFB PWM driver	14
PFC2PHIL PWM driver	26

Instructions vs PWM

PWM freq. (KHz)	PWM per. (uS)	Processor MIPS		
		40	100	150
50	20.0	800	2000	3000
100	10.0	400	1000	1500
200	5.0	200	500	750
250	4.0	160	400	600
300	3.3	133	333	500
500	2.0	80	200	300
750	1.3	53	133	200
1000	1.0	40	100	150

MIPS = Million Instruction Per Second

Typical Power Stage Switching Frequencies

Freq. (KHz)	Typ. Application	Power stage
10 ~ 35	Motor Control	3 Phase Inverter
50 ~ 120	UPS	Boost / Buck / ??
80 ~ 160	PFC + boost AC/DC – Rectifier	Single / Multi-phase Interleaved
120 ~ 240	DC/DC (isolated) AC/DC – Rectifier	H-bridge / Full-Bridge / FB-ZVS
200 ~ 1000	DC/DC (non-isol.) DPA-Enterprise	Single phase Buck / Multi-phase Interleaved
1 ~ 4 MHz	DC/DC (non-isol.) DPA / Bricks	Single phase Buck / Multi-phase Interleaved


Benefits of higher frequencies

- 1) Higher power density
- 2) Smaller magnetics
- 3) Lighter Power supplies
- 4) Faster transient response
- 5) Smaller ripple amplitude


Agenda

- ◆ The Digital Vision: Why DSP?
- ◆ Digital world: FACTS and FIGURES
- ◆ Digital AC/DC Rectifier challenges
- ◆ Software Strategy
- ◆ Next Steps

Digital approach with Single Device example for AC/DC Rectifier



- 1000W / 48 V
- F2810 DSP based
- 2 Phase PFC-IL
- Phase shifted ZVS-FB
- 200 KHz PWM (DC/DC)
- 100 KHz PWM (PFC)



Digital Control Design Steps

- ◆ Choose the topology for each power stage.
- ◆ Choose the location for the microprocessor: primary side or secondary side.
- ◆ Define the gate drive circuits.
- ◆ Define the ADC signal conditioning circuits.
- ◆ Choose the configuration of the timing hardware that implements the PWM signals, ADC strobe and interrupt service routine (ISR) timing.
- ◆ Architect the firmware: time critical interrupts versus background
- ◆ Implement the SW
- ◆ Closing the loop digitally offers several advantages when bringing up a system for debug.
- ◆ Each stage can be enabled separately.
- ◆ Loops can easily be run open-loop, usually by commenting out a line of code.
- ◆ Compensation parameters are quickly changed with a few keystrokes.
- ◆ Sophisticated diagnostics are possible, such as a circular buffers or complex event triggers.

Digital Control Design Steps

- ◆ Choose the topology for each power stage.
- ◆ Choose the location for the microprocessor: primary side or secondary side.
- ◆ Define the gate drive circuits.
- ◆ Define the ADC signal conditioning circuits.
- ◆ Choose the configuration of the timing hardware that implements the PWM signals, ADC strobe and interrupt service routine (ISR) timing.
- ◆ Architect the firmware: time critical interrupts versus background
- ◆ Implement the SW
- ◆ Closing the loop digitally offers several advantages when bringing up a system for debug.
- ◆ Each stage can be enabled separately.
- ◆ Loops can easily be run open-loop, usually by commenting out a line of code.
- ◆ Compensation parameters are quickly changed with a few keystrokes.
- ◆ Sophisticated diagnostics are possible, such as a circular buffers or complex event triggers.

Agenda

- ◆ The Digital Vision: Why DSP?
- ◆ Digital world: FACTS and FIGURES
- ◆ Digital AC/DC Rectifier challenges
- ◆ Software Strategy
- ◆ Next Steps


Software

**Modularity, re-use
efficiency.....**

Software - is key in Digital Power !


Software playing a more significant role in AC/DC rectifier applications

Traditionally



Analog controlled power stage
S/W role: Supervisory + Monitoring + Comms
8 / 16 bit MCU based

Digital Power



Digitally controlled power stage
S/W role: Supervisory + Monitoring + Comms + **Closed loop control**
16 / 32 bit DSP based

“Opposing” approaches to Software development

1. “Conservative approach”

- Strictly High level language (e.g. C / C++)
- Conventional function calling / parameter passing
- Real-time OS as needed



Wait for release of appropriate device
e.g. 200-300 MIP device @ \$5-\$10

2. “getting your performance entitlement”

- Combination C / ASM
- “flat” in-line coding
- non-conventional function calling / parameter passing
- simple single ISR structure



Push perf. envelope on existing devices
e.g. 100-150 MIP devices @ \$5-\$10

Defining “GOOD” Software


- **Modularity** – blocks with well defined inputs / outputs (“cause and effect”)
- Multiple instantiation of same module or function
- De-lineation (separation) between code and device peripherals or target h/w i.e. use of **peripheral (h/w) drivers**
- Re-useable / Re-targetable (maximize return on investment)
- **Efficient & high performance** – code execution in minimal time
- Easy to use / read / interpret / debug / modify i.e. **friendly!**

Exploring Modularity

- Function or object with well defined boundaries
- Clear relationship between inputs / outputs (“cause / effect”)
- Used multiple times, while maintaining a single source
 - “Multiple Instantiation”
- Re-entrant (i.e. supports “nesting of itself”)
- “trust for now, explore / understand later”

Module example 1

- Single In / Single out
- Non-configurable
- No History
- Multiple Instantiation




Exploring Modularity

Module example 2


- Single In / Single out
- Configurable
- m, b , Constant ?
or Variable ?
- No History
- Multiple Instantiation

$$f(x) = mx + b$$




Module example 3

- Single In / Single out
- Non-Configurable
- History
- Multiple Instantiation




$$f(x) = (x_n + x_{n-1} + x_{n-2} + x_{n-3}) / 4$$




Module Types


Application Indep. /
Peripheral Indep.




Application Config. /
Peripheral Indep.



Application Config. /
Peripheral Depend.
("Peripheral Driver")



Peripheral Drivers



Q-Math Representation

Fixed point format – S I . F (Sign / Integer . Fraction)

Q15	S.FFF FFFF FFFF FFFF	- 1 < N < +0.99999...
Q14	SI.FF FFFF FFFF FFFF	- 2 < N < +1.99999...
Q13	SII.F FFFF FFFF FFFF	- 4 < N < +3.99999...
Q12	SIII. FFFF FFFF FFFF	- 8 < N < +7.99999...
Q0	SIII IIII IIII IIII	- 32,768 < N < +32,767

$Q_n \times Q_m = Q_{n+m}$, e.g. $Q15 \times Q14 = Q29$

SSI.F FFFF FFFF FFFF FFFF FFFF FFFF FFFF (32 bit format)

SI.FF FFFF FFFF FFFF (adjusted for Q14, 16 bit format)

e.g. $Q15 \times Q15 = Q30$

SS.FF FFFF FFFF FFFF FFFF FFFF FFFF FFFF (32 bit format)


S.FFF FFFF FFFF FFFF (adjusted for Q15, 16 bit format)

Exploring Ideas / Methods for “Good” software

1. System Framework – Background loop (“C”) + one ISR (“ASM”) with Time-Slicing for control loop
2. In-line coding for the ISR
3. Assembly Macros for the control loop modules
4. Indirect or “pointer based” parameter passing / data flow
5. “Signal Net” based Module connectivity → for the analog guys!

Exploring Ideas / Methods

1. System Framework



- Good choice for addressing many power systems (even complex ones)
- Simple to use and understand
- Efficient (incurs only 1 ISR context save/restore)
- Deterministic (all events synchronous and submultiples of ISR freq.)
- High degree of visibility during debug and development

Back-ground loop (BG)

- C / C++, large code, complex, feature rich, key customer differentiator
- System intelligence / personality, heavy in “if then else”

Interrupt Service Routine (ISR) – Main control loop

- “lean and mean” in-line assembly (ASM) results in a very small footprint.
- Typically “Math function” type code (very few “if then else” branches or loops)
- Once developed, changes very little. Low maintenance burden.

Exploring Ideas / Methods

2. In-line assembly ISR

How complex ?

Fear factor !

How much code development ?

How much maintenance burden ?

How wasteful on memory ?

Number of Instructions / cycles (words)

PWM (KHz)	MIPS	
	100	150
200	500	750
250	400	600
300	333	500
350	286	429
400	250	375
500	200	300

3. ASM Macros – great for modularity !

Modern compilers support:

- Macro parameter passing
- Macro variable & lable substitution

Benefits:

- No call/return overhead (save 8 cycles/call)
- Can easily build self contained modules (modular!)
- Supports multiple instantiation
- Supports “Re-entrancy”
- Re-useable


% impact per 10 instructions

PWM (KHz)	MIPS	
	100	150
200	2.0%	1.3%
250	2.5%	1.7%
300	3.0%	2.0%
350	3.5%	2.3%
400	4.0%	2.7%
500	5.0%	3.3%

Exploring Ideas / Methods

4. Pointer based parameter passing (data flow)


Conventional approach



Pseudo code

move ?, In1A	(2)
move ?, In1B	(2)
call f1	(8)
move ?, In2A	(2)
call f2	(8)
move Out1, In3A	(2)
move Out2, In3B	(2)
call f3	(8)
move Out3, ?	(2)

Pointer based approach



Pseudo code (without macros)


call f1	(8)
call f2	(8)
call f3	(8)

Pseudo code (with macros)

call f1	(zero)
call f2	(zero)
call f3	(zero)

Exploring Ideas / Methods

5. “Signal Net” based module connectivity



Initialization time (“C”)


```
// pointer & Net declarations
Int *In1A, *In1B, *Out1, *In2A,...
Int Net1, Net2, Net3, Net4, ...

// "connect" the modules
In1A=&Net1; In1B=&Net2; Out1=&Net5;
In2A=&Net3; Out2=&Net6;
In3A=&Net4; Out3=&Net7;
In4A=&Net5; In4B=&Net6; In4C=&Net7; Out4=&Net8;
In5A=&Net7; Out5=&Net9;
```


Run time (ASM macros)

; Execute the code	
	f1
	f2
	f3
	f4
	f5


Digitally controlled AC/DC rectifier – an example




- 1000W
- F2810 DSP based
- 2 phase interleaved PFC
- Phase shifted ZVS-FB
- 200 KHz PWM (DC/DC)
- 100 KHz PWM (PFC)



PFC (2PHIL) Software control flow




DC-DC (ZVSFB) Software control flow



CPU Bandwidth utilization

MIPS = 100	# inst / uS =	100	PWM(KHz) =	200
# TS = 4	# inst / time slice =	500	PWM(bits) =	9.0
S. rate = 200	Sampling period =	5.0		
ISR	Rate	Function / Activity	# Cyc	Tot. Cyc.
All	200KHz	Context Save / Restore	32	292
	200KHz	ISR Call / Return / Ack	24	58%
	200KHz	Time slice Mgmt	12	
	200KHz	ADCSEQ2_DRV	14	
	200KHz	CNTL_2P2Z 1 (V loop)	36	
	200KHz	CNTL_2P2Z 2 (I loop)	36	
	200KHz	I_FOLD_BACK	25	
	200KHz	ZVSFB_DRV	14	
	200KHz	ADCSEQ1_DRV	57	
	200KHz	FILT_2P2Z	35	
	200KHz	AC_LINE_RECT	7	
TS1	100KHz	PFC_OVP	25	117
	100KHz	PFC_ICMD	30	82%
	100KHz	CNTL_2P2Z 4 (I loop)	36	#Cyc. Rem.
	100KHz	PFC2PHIL_DRV	26	91
TS2	50KHz	BOXCAR_AVG 1	42	145
	50KHz	BOXCAR_AVG 2	42	87%
	100 Hz	PFC_ISHARE	15	#Cyc. Rem.
	50KHz	Execution Pre-scaler(1:50)	10	63
	1KHz	CNTL_2P2Z 3 (V loop)	36	
TS3	100KHz	PFC_OVP	25	117
	100KHz	PFC_ICMD	30	82%
	100KHz	CNTL_2P2Z 4 (I loop)	36	#Cyc. Rem.
	100KHz	PFC2PHIL_DRV	26	91
TS4	50KHz	FILT_BIQUAD	46	124
	50KHz	INV_SQR	78	83%
				#Cyc. Rem.
				84
BG	Function / Activity	# inst.	Tot.Cyc.	Stats
	Comms + Supervisory	400	434	
	+ Soft-Start + Other ?			
	SLEW_LIMIT 1	17		
	SLEW_LIMIT 2	17		
% ISR utilization =			87%	
Spare ISR MIPS =			12.6	
BG loop rate (KHz) / (uS) =			29.0	34.4




Experimental results

Technology for Innovators™




Interleaved Boost PFC




- ◆ 2 Interleaved boost converters
- ◆ MOSFET Rds_{on} current sense
- ◆ Excellent current sharing between modules

Phase Shifted Full Bridge



- ◆ DC-DC Phased-Shifted Full-Bridge operates off PFC boost
- ◆ V_{ds} of Q6/Q7

Zero Voltage Switching




- ◆ ZVS of the PSFB
- ◆ Bottom trace is Vgs top trace is Vds.
- ◆ Vds falls to 0V before Vgs turns on MOSFET


Technology for Innovators™

 TEXAS INSTRUMENTS

DSP Controlled PFC Controller



**Input Current,
Po = 860W**




**Input Current,
Po = 580W**

DSP Controlled PFC Controller



PFC MOSFETs
Drain-Source Voltages




DC Bus Voltage
Transient Response,
Step load = 250W

Technology for Innovators™

 TEXAS INSTRUMENTS

DC/DC Stage Transient Response



- ◆ Load step = 230 W (580W → 350W → 580W)
- ◆ Voltage deviation = 1.6% @ 48V
- ◆ Settling time to within 1% = 250uS

Technology for Innovators™

 TEXAS INSTRUMENTS

Digital Rectifier Summary

- ◆ Digital control allows:

- Sophisticated fault detection.
- Supports wide voltage and load range (DCM and CCM).
- Soft start and bring up sequence completely programmable.
- Long timeframe load sharing and deadband control loops easily implemented.
- Diagnostic data logging.
- Single processor for communication and control.

- ◆ Performance very similar to best analog designs.

Agenda

- ◆ The Digital Vision: Why DSP?
- ◆ Digital world: FACTS and FIGURES
- ◆ Digital AC/DC Rectifier challenges
- ◆ Software Strategy
- ◆ Next Steps


Real-Time debug

- ❑ RTDebug is a Non-intrusive debug scheme supported via on-chip H/W (utilizes spare / dead cycles in CPU buses)
- ❑ Allows user full interaction while application runs un-disturbed (at speed)
- ❑ Can interrogate / modify any memory, register, variable, ..etc
- ❑ Supports Single step / Break point in back-ground code while ISR (time critical loops + PWM) continues to run at speed.
- ❑ Clock / cycle profiling allows time critical code analysis.

Agenda

- ◆ The Digital Vision: Why DSP?
- ◆ Digital world: FACTS and FIGURES
- ◆ Digital AC/DC Rectifier challenges
- ◆ Software Strategy
- ◆ Implementation
- ◆ Next Steps


C2000™ Roadmap



How to get Started today?

Tools	<ul style="list-style-type: none">▪ F2812 eZdsp™ & R2812 eZdsp developer's kit (\$495)▪ F2808 eZdsp kit in 1Q05 (\$495)
Software	<ul style="list-style-type: none">▪ Code Composer StudioTM IDE for C2000TM (\$495 today)▪ Application specific libraries▪ Math functions▪ Communications drivers▪ Pre-bundled system solutions
Training and Support	<ul style="list-style-type: none">▪ Control developers seminar▪ DMC workshop▪ One-day technical introduction to C28x™▪ Multi-day get started developing C28x™ workshop
High-Performance Analog	Numerous data converter and power management products designed for motor control
Third Party Network	<ul style="list-style-type: none">▪ Development boards and emulation tools▪ Large consultant network▪ Increasing range of application software

TI Provides the Systems Expertise, Silicon, Software and Support for Control Applications




Technology for Innovators™

ti TEXAS INSTRUMENTS

Modular Software Development for Digital Control Systems

All Modules Available in C/C++ Environment



<http://www.ti.com/c2000appsw>
<http://www.ti.com/c2000sigproclib>

The Foundation: Software Libraries



Motor Control Specific SW Modules

Forward and Inverse Clarke/Park Transforms,, BLDC Specific PWM Drivers, Leg Current Measurement Drivers, BLDC Commutation triggers, ACI Speed and Rotor Position Estimators, PID Controllers, Extended Precision PID Controllers.

Peripheral & Communication Drivers

SCI (UART) Packet Driver, Virtual SPI Drivers, Virtual I2C Drivers, Serial EEPROM Drivers, GPIO Driver.

Fixed Point Trigonometric and Log Routines

Fixed Point Sine, Cosine, Tangent routines, Square Root, Logarithm Functions. Reciprocal calculation.

IQ Math 32-Bit Virtual Floating Point Library

Multiply, Divide, Multiply with Rounding, Multiply with Rounding and Saturation, Square Root, Sine and Cosine, routines.

Signal Processing Functions

FIR (Generic order), FIR (10th order), FIR(20th order), FIR using circular buffers. 128, 256, and 512 point complex and real FFTs.








Signal Generator Functions

Sinewave generators, Ramp Generators, Trapezoidal Profile generators




Power Conversion Related Functions

RMS computation, real power and apparent power computation, THD computation, PFC controllers.




Digital Power Modules – Some Examples

Symbol	Descr.	# Cycles	Symbol	Descr.	# Cycles
	Controller, 2 pole / 2 zero	36		PFC 2-phase Interleaved PWM s/w driver	26
	Biquad digital filter	46		Zero Voltage Switched Full Bridge PWM s/w driver	14
	Inverse square function	78		Analog / Digital conv. Sequencer s/w driver	57
	PFC Current Command function	30		Multi-phase3 Interleaved PWM s/w driver	15
	Slew rate Limiter function	17			
	PFC over- voltage monitor	25			

S/W driver module – ZVSFB



S/W driver module – PFC2PHIL



Digital Power Supplies: collaterals


- ◆ First version of the Digital Power Supply Library has been released

Digital Power System Solutions for C2808, C2806, C2802 and C2801		
System	Description	Part Number
DC-DC Buck Converter	DC-DC Buck Converter using High Resolution ePWM	SPRC229
High Resolution ePWM	Demonstrates HRPWM Capabilities for Digital Power Applications	SPRC227
Standard ePWM	Demonstrates ePWM Capabilities for Digital Power Applications	SPRC228

- ◆ Check out: www.ti.com/c2000appsw
- ◆ Digital Power Theory application note: **SPRAAB3**

Graphical Ease of Development

Visual Solutions
INCORPORATED




Hardware-in-the-Loop



Modeling the Future

- ◆ Pure simulation plus DSP-in-loop simulation and block level monitoring gives rapid feedback of controller response



Test DSP based controller against virtual plant on PC using JTAG HotLink


- ◆ Inject plant failure modes to test controller response
- ◆ High/Low watermark on fixed-point blocks gives numerical "headroom" safety factor
- ◆ Interactive DSP utilization gives continuous CPU load factor
- ◆ Interactively Change DSP controller gains from VisSim and plot DSP response.

Conclusion

- ◆ Digital Power is the future
- ◆ One of the Traditional Fear Factors industry is SW complexity
- ◆ TI is enabling Digital Power with the Digital Power Supply Library
- ◆ 28x has the right set of peripherals for Digital Power Supply
- ◆ Tools, Documentation are in place to start today
- ◆ TI can support for a complete design with Analog and Digital products

Control Made Easy

DIGITAL CONTROL & HIGH PERFORMANCE
ANALOG SOLUTIONS



Thank you

Visit us
Stand 134, Hall 12

Meet our experts and
discover our expanded
range of products

Third parties exhibiting at TI booth:

Active DSP

Visual Solutions

INCORPORATED

Modeling the Future



TECHNOSOFT

Technology for Innovators™



TEXAS INSTRUMENTS