```
module DisplayControlUnit (
    input wire clock500Hz, reset,

    input wire[7:0] phrase,

    output reg[4:0] char_index,

    output reg RS,RW,
    output wire E,
    output reg[7:0] DB
);

    assign E = clock500Hz;

    // Estados
    parameter
        FS1 = 4'd0,
      FS2 = 4'd1,
        FS3 = 4'd2,
        FS4 = 4'd3,
        ClearDisplay = 4'd4,
        DisplayControl = 4'd5,
        EntryMode = 4'd6,
        ReturnHome = 4'd7,
        SetAddress = 4'd8,
        WriteChar = 4'd9;

    reg[3:0] PresentState,NextState;

    // Bloco sequencial - Estados
     always @(posedge reset or posedge clock500Hz) begin
        if(reset) begin
            PresentState <= FS1;
            char_index <= 5'd0;
        end
        else begin
            PresentState <= NextState;
            if(PresentState == WriteChar) begin
                char_index <= char_index + 5'd1;
            end
            if(NextState == ReturnHome) begin
                char_index <= 5'd0;
            end

        end
    end

    // Bloco Combinacional - Estados
    always @(*) begin
        case(PresentState)

            default: begin
                RS = 1'b0;
                RW = 1'b0;
                DB = 8'b00111000;
                NextState = FS1;
            end

            FS1: begin
                RS = 1'b0;
                RW = 1'b0;
                DB = 8'b00111000;
                NextState = FS2;
            end

            FS2: begin
                RS = 1'b0;
                RW = 1'b0;
                DB = 8'b00111000;
                NextState = FS3;
            end

            FS3: begin
                RS = 1'b0;
                RW = 1'b0;
                DB = 8'b00111000;
                NextState = FS4;
            end

            FS4: begin
                RS = 1'b0;
```

```
                    RW = 1'b0;
                    DB = 8'b00111000;
                    NextState = ClearDisplay;
                end

                ClearDisplay: begin
                    RS = 1'b0;
                    RW = 1'b0;
                    DB = 8'b00000001;
                    NextState = DisplayControl;
                end

                DisplayControl: begin
                    RS = 1'b0;
                    RW = 1'b0;
                    DB = 8'b00001100;
                    NextState = EntryMode;
                end

                EntryMode: begin
                    RS = 1'b0;
                    RW = 1'b0;
                    DB = 8'b00000110;
                    NextState = WriteChar;
                end

                ReturnHome: begin
                    RS = 1'b0;
                    RW = 1'b0;
                    DB = 8'b10000000;
                    NextState = WriteChar;
                end

                SetAddress: begin
                    RS = 1'b0;
                    RW = 1'b0;
                    DB = 8'b11000000;
                    NextState = WriteChar;
                end

                WriteChar: begin
                    RS = 1'b1;
                    RW = 1'b0;
                    DB = phrase;


                    if (char_index == 5'd15) begin
                        NextState = SetAddress;
                    end
                    else if (char_index == 5'd31) begin
                        NextState = ReturnHome;
                    end
                    else begin
                        NextState = WriteChar;
                    end
                end
            endcase
        end

    endmodule
```

```
1   module PhraseBank(
2       input wire clock,
3       input wire[4:0] DisplayAddr,
4
5       input wire[3:0] AddressIn, DataIn, KeypadDataIn,
6       input wire[1:0] PresentStateFlag,
7
8       output reg[7:0] Phrase
9   );
10
11      wire[7:0] OutPadrao;
12      wire[3:0] AddressInUnit, AddressInTens, DataInUnit, DataInTens, KeypadDataInUnit,
    KeypadDataInTens;
13
14      Deconcatener inst00(AddressIn, DataIn, KeypadDataIn, AddressInUnit, AddressInTens,
    DataInUnit, DataInTens, KeypadDataInUnit, KeypadDataInTens);
15      RomPadrao inst01 (clock,DisplayAddr, OutPadrao);
16
17      reg[7:0] Numbers [0:9];
18      initial begin
19          Numbers[0] = "0";
20          Numbers[1] = "1";
21          Numbers[2] = "2";
22          Numbers[3] = "3";
23          Numbers[4] = "4";
24          Numbers[5] = "5";
25          Numbers[6] = "6";
26          Numbers[7] = "7";
27          Numbers[8] = "8";
28          Numbers[9] = "9";
29      end
30
31      reg[7:0] RomState [0:2];
32      initial begin
33          RomState[0] = "I";
34          RomState[1] = "W";
35          RomState[2] = "R";
36      end
37
38      always @(*) begin
39
40          if(DisplayAddr == 5'd4) Phrase = Numbers[AddressInTens];
41          else if(DisplayAddr == 5'd5) Phrase = Numbers[AddressInUnit];
42
43          else if(DisplayAddr == 5'd14) Phrase = RomState[PresentStateFlag];
44
45          else if(DisplayAddr == 5'd20) Phrase = Numbers[KeypadDataInTens];
46          else if(DisplayAddr == 5'd21) Phrase = Numbers[KeypadDataInUnit];
47
48          else if(DisplayAddr == 5'd29) Phrase = Numbers[DataInTens];
49          else if(DisplayAddr == 5'd30) Phrase = Numbers[DataInUnit];
50
51          else Phrase = OutPadrao;
52      end
53
54  endmodule
```

```
1   module RomPadrao (
2       input wire clock,
3       input wire[4:0] addr,
4
5       output reg[7:0] dataOut
6   );
7
8       reg[7:0] phrase [0:31];
9       initial begin
10          phrase[0]  = "A";
11          phrase[1]  = "i";
12          phrase[2]  = "n";
13          phrase[3]  = ":";
14          phrase[4]  = "X";      // Dezena Address
15          phrase[5]  = "X";      // Unidade Address
16          phrase[6]  = " ";
17          phrase[7]  = " ";
18          phrase[8]  = "S";
19          phrase[9]  = "t";
20          phrase[10] = "a";
21          phrase[11] = "t";
22          phrase[12] = "e";
23          phrase[13] = ":";
24          phrase[14] = "Y";      // R ou W
25          phrase[15] = " ";
26
27
28
29          phrase[16] = "D";
30          phrase[17] = "i";
31          phrase[18] = "n";
32          phrase[19] = ":";
33          phrase[20] = "X";      // Dezena DataTeclado
34          phrase[21] = "X";      // Unidade DataTeclado
35          phrase[22] = " ";
36          phrase[23] = " ";
37          phrase[24] = "D";
38          phrase[25] = "o";
39          phrase[26] = "u";
40          phrase[27] = "t";
41          phrase[28] = ":";
42          phrase[29] = "Y";      // Dezena DataMemoria
43          phrase[30] = "Y";      // Unidade DataMemoria
44          phrase[31] = " ";
45      end
46
47
48      always @(posedge clock ) begin
49          dataOut <= phrase[addr];
50      end
51
52  endmodule
```

```
1   module Deconcatener (
2       input wire[3:0] AddressIn, DataIn, KeypadDataIn,
3
4       output wire[3:0] AddressInUnit, AddressInTens, DataInUnit, DataInTens,
    KeypadDataInUnit, KeypadDataInTens
5   );
6
7   assign AddressInUnit = AddressIn % 10;
8   assign AddressInTens = AddressIn / 10;
9
10  assign DataInUnit = DataIn % 10;
11  assign DataInTens = DataIn / 10;
12
13  assign KeypadDataInUnit = KeypadDataIn % 10;
14  assign KeypadDataInTens = KeypadDataIn / 10;
15
16  endmodule
```

```
1   module Saida (
2       input wire clock50MHz, clock500Hz, reset,
3
4      input wire[3:0] AddressIn, DataIn, KeypadDataIn,
5      input [1:0] PresentStateFlag,
6
7       output wire RS,RW,
8       output wire E,
9       output wire[7:0] DB,
10      output wire LCD_Blon, LCD_On
11  );
12
13  assign LCD_Blon = 1'b1;
14  assign LCD_On = 1'b1;
15
16  wire[4:0] DisplayAddr;
17  wire[7:0] Phrase;
18  PhraseBank inst01 (clock50MHz, DisplayAddr, AddressIn, DataIn, KeypadDataIn,
    PresentStateFlag, Phrase);
19
20  DisplayControlUnit inst02 (clock500Hz, reset, Phrase, DisplayAddr, RS, RW, E, DB);
21
22  endmodule
```


1'h1
LCD_Blon
1'h1
LCD_On
DisplayControlUnit:inst02
clock500Hz
reset
PhraseBank:inst01
AddressIn[3..0]
DataIn[3..0]
KeypadDataIn[3..0]
PresentStateFlag[1..0]
clock50MHz
clock500Hz
phrase[7..0]
reset
DB[7..0]
E
RS
RW
char_index[4..0]
AddressIn[3..0]
DataIn[3..0]
KeypadDataIn[3..0]
DisplayAddr[4..0]
PresentStateFlag[1..0]
clock
Phrase[7..0]
DB[7..0]
E
RS
RW

Simulation Waveform Editor - C:/Users/welly/Documents/GitHub/LT39A/pratica05/pratica05 - pratica05 - [pratica05_20240823180757.sim.vwf (Read-Only)]

File Edit View Simulation Help

Search altera.com

Master Time Bar: 0 ps | Pointer: 370.63 ns | Interval: 370.63 ns | Start: | End:

Name	Value at 0 ps
AddressIn	U 0
DB	U 56
DataIn	U 0
E	U 0
Keypad...	U 2
LCD_Blon	U 1
LCD_On	U 1
Present...	U 0
RS	U 0
RW	U 0
clock50...	U 0
clock50...	U 0
reset	U 1