LSP中enbale了swap functionality.

CONFIG_SWAP = y

与CONFIG_SWAP相关的file (in mm/)

obj-\$(CONFIG_SWAP) += page_io.o swap_state.o swapfile.o
obj-y += swap.o

CONFIG ZSWAP是对swap contents进行压缩的。

与swap functionality相关的system call是 swapon and swapoff , 在mm/swapfile.c中实现。

所以如果disable swap functionality,这两个system call也应该不能使用。

其实LSP这样的为embedded system设计的系统根本用不上swap functionality,完全可以 disable,

这样kernel的footprint也可以缩小。

build swap function disable kernel and startup.

```
1.
      root@granite2:~# dd if=/dev/zero of=./swapfile bs=1024 count=1024
 2.
      1024+0 records in
 3.
      1024+0 records out
      root@granite2:~# ls -1
 4.
                                       701994 Aug 8 10:48 strace
 5.
      -rwxr-xr-x
                  1 root
                            root
                              root 1048576 Aug 8 10:47 swapfile
 6.
      -rw-r--r-- 1 root
      root@granite2:~# mkswap swapfile
 7.
 8.
      Setting up swapspace version 1, size = 1020 KiB
 9.
      no label, UUID=18ceae8e-7a24-454c-be76-53e2311ef3ba
      root@granite2:~# swapon swapfile
10.
11.
      swapon: /home/root/swapfile: insecure permissions 0644, 0600 suggested.
      swapon: swapfile: swapon failed: Function not implemented
12.
13.
      root@granite2:~# strace swapon swapfile
14.
      execve("/sbin/swapon", ["swapon", "swapfile"], [/* 14 vars */]) = 0
15.
      brk(0)
                                             = 0x18000
      uname({sys="Linux", node="granite2", ...}) = 0
16.
17.
      mmap2(NULL, 4096, PROT_READ|PROT_WRITE, MAP_PRIVATE|MAP_ANONYMOUS, -1, 0) =
      0xb6f49000
      access("/etc/ld.so.preload", R OK) = -1 ENOENT (No such file or directo
18.
      ry)
19.
      open("/etc/ld.so.cache", O_RDONLY|O_CLOEXEC) = 3
      fstat64(3, {st_mode=S_IFREG|0644, st_size=19287, ...}) = 0
20.
21.
      mmap2(NULL, 19287, PROT_READ, MAP_PRIVATE, 3, 0) = 0xb6f44000
22.
23.
      open("/lib/libmount.so.1", O_RDONLY|O_CLOEXEC) = 3
      24.
      512) = 512
25.
      fstat64(3, {st mode=S IFREG | 0755, st size=258588, ...}) = 0
      mmap2(0x46f10000, 237120, PROT READ|PROT EXEC, MAP PRIVATE|MAP DENYWRITE, 3,
26.
       0) = 0x46f10000
27.
      mmap2(0x46f48000, 4096, PROT READ|PROT WRITE, MAP PRIVATE|MAP FIXED|MAP DENY
      WRITE, 3, 0x38000) = 0x46f48000
28.
      mmap2(0x46f49000, 3648, PROT_READ|PROT_WRITE, MAP_PRIVATE|MAP_FIXED|MAP_ANON
      YMOUS, -1, 0) = 0x46f49000
29.
      close(3)
      open("/lib/libsmartcols.so.1", O_RDONLY|O_CLOEXEC) = 3
30.
      read(3, "177ELF\1\1\1\0\0\0\0\0\0\0\0\0\0\1\0\0\0\10\274\350F4\0\0\0".
31.
      .., 512) = 512
32.
      fstat64(3, {st_mode=S_IFREG|0755, st_size=122240, ...}) = 0
33.
      mmap2(0x46e88000, 143132, PROT_READ|PROT_EXEC, MAP_PRIVATE|MAP_DENYWRITE, 3,
      0) = 0x46e88000
34.
      mprotect(0x46ea2000, 28672, PROT_NONE) = 0
      mmap2(0x46ea9000, 4096, PROT_READ|PROT_WRITE, MAP_PRIVATE|MAP_FIXED|MAP_DENY
35.
      WRITE, 3, 0x19000) = 0x46ea9000
36.
      mmap2(0x46eaa000, 3868, PROT_READ|PROT_WRITE, MAP_PRIVATE|MAP_FIXED|MAP_ANON
      YMOUS, -1, 0) = 0x46eaa000
37.
      close(3)
                                             = 0
      open("/lib/tls/v7l/neon/vfp/libc.so.6", O_RDONLY|O_CLOEXEC) = -1 ENOENT (No
38.
      such file or directory)
      stat64("/lib/tls/v71/neon/vfp", 0xbe82c4a8) = -1 ENOENT (No such file or dir
39.
40.
      open("/lib/tls/v7l/neon/libc.so.6", O_RDONLY|O_CLOEXEC) = -1 ENOENT (No such
      file or directory)
```

```
41. stat64("/lib/tls/v7l/neon", 0xbe82c4a8) = -1 ENOENT (No such file or directory)
```

- open("/lib/tls/v7l/vfp/libc.so.6", O_RDONLY|O_CLOEXEC) = -1 ENOENT (No such file or directory)
- 43. stat64("/lib/tls/v7l/vfp", 0xbe82c4a8) = -1 ENOENT (No such file or directory)
- open("/lib/tls/v7l/libc.so.6", O_RDONLY|O_CLOEXEC) = -1 ENOENT (No such file or directory)
- 45. stat64("/lib/tls/v71", 0xbe82c4a8) = -1 ENOENT (No such file or directory)
- open("/lib/tls/neon/vfp/libc.so.6", O_RDONLY|O_CLOEXEC) = -1 ENOENT (No such file or directory)
- 47. stat64("/lib/tls/neon/vfp", 0xbe82c4a8) = -1 ENOENT (No such file or directory)
- open("/lib/tls/neon/libc.so.6", O_RDONLY|O_CLOEXEC) = -1 ENOENT (No such file or directory)
- 49. stat64("/lib/tls/neon", 0xbe82c4a8) = -1 ENOENT (No such file or directory)
- open("/lib/tls/vfp/libc.so.6", O_RDONLY|O_CLOEXEC) = -1 ENOENT (No such file
 or directory)
- 51. stat64("/lib/tls/vfp", 0xbe82c4a8) = -1 ENOENT (No such file or directo ry)
- open("/lib/tls/libc.so.6", O_RDONLY|O_CLOEXEC) = -1 ENOENT (No such file or directory)
- stat64("/lib/tls", 0xbe82c4a8) = -1 ENOENT (No such file or directo ry)
- open("/lib/v7l/neon/vfp/libc.so.6", O_RDONLY|O_CLOEXEC) = -1 ENOENT (No such file or directory)
- stat64("/lib/v7l/neon/vfp", 0xbe82c4a8) = -1 ENOENT (No such file or directory)
- open("/lib/v7l/neon/libc.so.6", O_RDONLY|O_CLOEXEC) = -1 ENOENT (No such fil e or directory)
- 57. stat64("/lib/v7l/neon", 0xbe82c4a8) = -1 ENOENT (No such file or directory)
- open("/lib/v7l/vfp/libc.so.6", O_RDONLY|O_CLOEXEC) = -1 ENOENT (No such file
 or directory)
- 59. stat64("/lib/v7l/vfp", 0xbe82c4a8) = -1 ENOENT (No such file or directory)
- open("/lib/v7l/libc.so.6", O_RDONLY|O_CLOEXEC) = -1 ENOENT (No such file or directory)
- stat64("/lib/v71", 0xbe82c4a8) = -1 ENOENT (No such file or directo
 ry)
- open("/lib/neon/vfp/libc.so.6", O_RDONLY|O_CLOEXEC) = -1 ENOENT (No such file or directory)
- 63. stat64("/lib/neon/vfp", 0xbe82c4a8) = -1 ENOENT (No such file or directory)
- open("/lib/neon/libc.so.6", O_RDONLY|O_CLOEXEC) = -1 ENOENT (No such file or directory)
- 65. stat64("/lib/neon", 0xbe82c4a8) = -1 ENOENT (No such file or directo rv)
- open("/lib/vfp/libc.so.6", O_RDONLY|O_CLOEXEC) = -1 ENOENT (No such file or directory)
- 67. stat64("/lib/vfp", 0xbe82c4a8) = -1 ENOENT (No such file or directory)

```
68.
       open("/lib/libc.so.6", O RDONLY O CLOEXEC) = 3
 69.
       read(3, "\177ELF\1\1\1\0\0\0\0\0\0\0\0\0\0\1\0\0\0\330\202\326F4\0\0\0"
       \dots, 512) = 512
 70.
      fstat64(3, {st_mode=S_IFREG|0755, st_size=1346356, ...}) = 0
 71.
      mmap2(0x46d50000, 1259864, PROT READ|PROT EXEC, MAP PRIVATE|MAP DENYWRITE, 3
       0) = 0x46d50000
      mprotect(0x46e76000, 32768, PROT_NONE) = 0
 72.
      mmap2(0x46e7e000, 16384, PROT_READ|PROT_WRITE, MAP_PRIVATE|MAP_FIXED|MAP_DEN
 73.
      YWRITE, 3, 0x126000) = 0x46e7e000
 74.
      mmap2(0x46e82000, 6488, PROT_READ|PROT_WRITE, MAP_PRIVATE|MAP_FIXED|MAP_ANON
      YMOUS, -1, 0) = 0x46e82000
 75.
      close(3)
      open("/lib/libblkid.so.1", O_RDONLY|O_CLOEXEC) = 3
 76.
 77.
      read(3, "\177ELF\1\1\1\0\0\0\0\0\0\0\0\0\1\0\0\0\200M\354F4\0\0\"...
       , 512) = 512
 78.
       fstat64(3, {st_mode=S_IFREG|0755, st_size=227436, ...}) = 0
 79.
      mmap2(NULL, 4096, PROT_READ|PROT_WRITE, MAP_PRIVATE|MAP_ANONYMOUS, -1, 0) =
      0xb6f43000
 80.
      mmap2(0x46ec0000, 237260, PROT READ|PROT EXEC, MAP PRIVATE|MAP DENYWRITE, 3,
       0) = 0x46ec0000
 81.
      mprotect(0x46eef000, 32768, PROT NONE) = 0
      mmap2(0x46ef7000, 8192, PROT READ|PROT WRITE, MAP PRIVATE|MAP FIXED|MAP DENY
 82.
      WRITE, 3, 0x2f000) = 0x46ef7000
 83.
      mmap2(0x46ef9000, 3788, PROT_READ|PROT_WRITE, MAP_PRIVATE|MAP_FIXED|MAP_ANON
      YMOUS, -1, 0) = 0x46ef9000
 84.
      close(3)
 85.
      open("/lib/libuuid.so.1", O RDONLY O CLOEXEC) = 3
 86.
      .., 512) = 512
       fstat64(3, {st_mode=S_IFREG|0755, st_size=16652, ...}) = 0
 87.
 88.
      mmap2(0x46f00000, 44928, PROT READ|PROT EXEC, MAP PRIVATE MAP DENYWRITE, 3,
      0) = 0x46f00000
 89.
      mprotect(0x46f03000, 28672, PROT_NONE) = 0
 90.
      mmap2(0x46f0a000, 4096, PROT_READ|PROT_WRITE, MAP_PRIVATE|MAP_FIXED|MAP_DENY
      WRITE, 3, 0x2000) = 0x46f0a000
 91.
      close(3)
                                              = 0
 92.
      mmap2(NULL, 4096, PROT READ | PROT WRITE, MAP PRIVATE | MAP ANONYMOUS, -1, 0) =
      0xb6f42000
 93.
      set_tls(0xb6f424c0, 0xb6f42bf8, 0x46d47050, 0xb6f424c0, 0x46d47050) = 0
 94.
      mprotect(0x46e7e000, 8192, PROT READ) = 0
 95.
      mprotect(0x46d46000, 4096, PROT_READ)
                                              = 0
 96.
      munmap(0xb6f44000, 19287)
                                              = 0
 97.
      brk(0)
                                              = 0x18000
 98.
      brk(0x39000)
                                              = 0x39000
 99.
      getcwd("/home/root", 4096)
100.
      lstat64("/home/root/swapfile", {st_mode=S_IFREG|0644, st_size=1048576, ...})
101.
      stat64("/home/root/swapfile", {st_mode=S_IFREG|0644, st_size=1048576, ...})
102.
      write(2, "swapon: ", 8swapon: )
                                                      = 8
103.
      write(2, "/home/root/swapfile: insecure pe"..., 63/home/root/swapfile: insec
       ure permissions 0644, 0600 suggested.) = 63
104.
      write(2, "\n", 1
105.
                              = 1
```

```
open("/home/root/swapfile", O RDONLY|O LARGEFILE) = 3
106.
107.
      ., 65536) = 65536
108.
      close(3)
      swapon("/home/root/swapfile", 0) = -1 ENOSYS (Function not implemente
109.
      write(2, "swapon: ", 8swapon: )
110.
                                               = 8
111.
      write(2, "swapfile: swapon failed", 23swapfile: swapon failed) = 23
      write(2, ": ", 2: )
112.
      write(2, "Function not implemented\n", 25Function not implemented
113.
114.
      ) = 25
115.
     close(1)
                                        = 0
116.
     close(2)
                                        = 0
      exit_group(-1)
                                        = ?
117.
118.
      +++ exited with 255 +++
```

① create storage for the swap file

create swap file. swap file是有一定的format的, mkswap generate the information.

③ enable the swap file

4

swapon utility invoke "swapon" system call.由于CONFIG_SWAP is disabled, "swapon" system call根本没实现,所以这里返回 ENOSYS (Function not implemented)