



CSE411

Real-Time and Embedded Systems Design

Power window control system

Name	ID		
Abdelrahman Khaled Sallam	20P8307		
Ahmed Taha Abdelrahman	20P5437		
Anas Ahmed Hussein	20P5726		
Donia Ahmed Nasr	20P9451		
Mariam Wahdan Allam	20P5500		
Yahia Ahmed Zaki	20P6091		

Contents

Project description	3
Contributions	3
List of Components	4
Circuit Wiring	4
System Layout	5
System Flowchart	6
• Tasks Code	7
> vDriverDirections	7
> Driver Clockwise Direction (Manual Control)	
> Driver Clockwise Direction (Automatic Control)	8
> Driver Anti-Clockwise Direction (Manual Control)	9
> Driver Anti-Clockwise Direction (Automatic Control)	
> vClockWise	11
> vClockWise (Manual Control)	11
> vClockWise (Automatic Control)	
> vAntiClockWise	
> vAntiClockWise (Manual Control)	13
> vAntiClockWise (Automatic Control)	
Problem Faced	
List of figures	
Figure 1:Project Circuit	4
Figure 2:Breadboard Components	5
Figure 3: Main Components	
Figure 4:Manual control for driver clockwise Figure 5:Automatic control for driver clockwise	
Figure 6:Manual control for driver clockwise	
Figure 7:Automatic control for driver anti-clockwise	
Figure 8:Manual control for passenger clockwise	
Figure 9:Automatic control for passenger clockwise	
Figure 10:Manual control for passenger anti-clockwise	13
Figure 11:Automatic control for passenger anti-clockwise	14

Project description

The Integrated Power Window Control System project aims to develop a sophisticated solution for the front passenger door window, enabling seamless operation through both passenger and driver control panels. Leveraging FreeRTOS for real-time functionality, the system will incorporate essential features such as manual open/close, one-touch auto open/close, window lock, and jam protection. Implementation will include one limit switch to lock window when limit is reached and 4 push buttons to constrain the window motor's movement for passenger and driver and 2 push buttons for the stop and start of the passenger windows, while obstacle detection will be facilitated by a push button. Through meticulous hardware and software integration, this project seeks to enhance vehicle occupants' convenience and safety by delivering an intuitive, reliable, and comprehensive power window control system.

Contributions

1. Abdelrahman Khaled

 Develop drivers for hardware components and connect them to appropriate ports on the Tiva C microcontroller and the L298N motor driver.

2. Ahmed Taha

 Work on designing the logic flow of the project and independently test components to ensure their proper functionality.

3. Donia Ahmed

 Study how the L298N motor driver works and connect the DC motor to it, ensuring proper understanding and functionality.

4. Mariam Wahdan

 Work on integrating interrupts with the system and understand how they synchronize tasks to ensure smooth operation.

5. Anas Ahmed Hussein

• Study the functionality of the limit switch and understand how to implement it to lock the window when the limit is reached.

6. Yahia Ahmed Zaki

Learn about Pulse Width Modulation (PWM) and assist in wiring its configuration, ensuring proper control
of motor speed and direction

• List of Components

Name	Quantity	Price(EGP)
TivaC123GH6PM Microcontroller	1	1700
220 Ohm Resistors	4	1
Pushbuttons	6	6
Limit Switch	2	50
DC Motor	1	40
L298n Motor Driver	1	100
	Total	1,897

• Circuit Wiring







Figure 1:Project Circuit

System Layout





System Flowchart



Tasks Code

vDriverDirections

Driver Clockwise Direction (Manual Control)




Figure 4:Manual control for driver clockwise

The "vDriverDirections" task holds the utmost priority among all other tasks. Its primary function is to manage the driver's control buttons, specifically Button 6 (connected to pin 6 on port B for clockwise rotation) and Button 3 (linked to pin 3 on port B for counterclockwise rotation).

Upon execution, this task first checks the status of a semaphore. If the semaphore is empty, it waits until it's signaled by the Interrupt Service Routine (ISR) triggered by Button 6.

Once the semaphore is given, the task assesses if the button has been pressed for an extended duration, indicating manual window control. In such cases, the motor rotates until either the button is released or the limit switch is activated. If the limit switch is triggered, rotation halts, and the task is blocked. Conversely, if the limit is not reached but the button is released, motor rotation ceases.

While the DC motor is in motion, a flag is toggled to "false" to ensure that when the passenger accesses the same resource after the driver, the driver must initiate control by pressing the start button

Driver Clockwise Direction (Automatic Control)




Figure 5: Automatic control for driver clockwise

Alternatively, if Button 6 is pressed only once, it signifies the driver's preference for automatic control. This mode initiates motor rotation until either the limit is reached or Button 3 (anti-clockwise button) is pressed. If the limit switch is triggered, rotation halts, and the task is blocked. Conversely, if Button 3 is pressed, the motor reverses its direction of rotation.

Driver Anti-Clockwise Direction (Manual Control)




Figure 6:Manual control for driver anti-clockwise

If the triggered ISR was due to Button 3, we check if the button has been pressed for an extended duration, indicating manual window control. In such cases, the motor rotates until either the button is released or the limit switch is activated. If the limit switch is triggered, rotation halts, and the task is blocked. Conversely, if the limit is not reached but the button is released, motor rotation ceases and task is blocked on the semaphore.

While the DC motor is in motion, a flag is toggled to "false" to ensure that when the passenger accesses the same resource after the driver, the driver must initiate control for the passenger by pressing the start button

Driver Anti-Clockwise Direction (Automatic Control)




Figure 7: Automatic control for driver anti-clockwise

Alternatively, if Button 3 is pressed only once, it signifies the driver's preference for automatic control. This mode initiates motor rotation until either the limit is reached or Button 6 (clockwise button) is pressed. If the limit switch is triggered, rotation halts, and the task is blocked. Conversely, if Button 6 is pressed, the motor reverses its direction of rotation, additionally if the protection button is pressed the rotation stops to prevent problems and the task is blocked on the semaphore

vClockWise

vClockWise (Manual Control)




Figure 8:Manual control for passenger clockwise

The "vClockWise" task holds a priority lower than that of the driver task, yet it is initialized prior to the "vAntiClockWise" task, ensuring its execution precedence. Upon initialization, "vClockWise" waits for a semaphore to be signaled from the ISR triggered by pressing Button 7 (connected to pin 7 on port B for clockwise rotation). Upon receiving the semaphore, the task begins execution.

Initially, it checks if Button 7 is still pressed and if the flag is set to true (indicating that the passenger has control over the window), and verifies that the limit switch is not activated. If these conditions are met, it indicates the passenger's intent to utilize manual control. In such cases, the motor rotates until the button is released, the limit switch is triggered, or control is taken by the driver due to their higher priority.

If the limit switch is triggered, rotation halts, and the task is blocked. Conversely, if the flag is false, indicating that the driver has assumed control, rotation ceases, and the task is once again blocked on the semaphore, awaiting further task execution.

vClockWise (Automatic Control)




Figure 9:Automatic control for passenger clockwise

Alternatively, if Button 7 is pressed only once, it signifies the passenger's preference for automatic control. This mode initiates motor rotation until either the limit is reached or driver wanted to take control. If the limit switch is triggered, rotation halts, and the task is blocked. Conversely, if driver took control, the motor stops rotation, and the task is blocked on the semaphore again waiting for other tasks

vAntiClockWise

vAntiClockWise (Manual Control)




Figure 10:Manual control for passenger anti-clockwise

The "vAntiClockWise" task is executed when the semaphore is taken from the ISR due to the interrupt triggered due to pressing on button 6 (pin 6 port B for anti-clockwise direction)

Initially, the task checks if Button 6 is still pressed and if the flag is set to true (indicating that the passenger has control over the window), and verifies that the limit switch is not activated. If these conditions are met, it indicates the passenger's intent to utilize manual control. In such cases, the motor rotates until the button is released, the limit switch is triggered, or control is taken by the driver due to their higher priority.

If the limit switch is triggered, rotation halts, and the task is blocked. Conversely, if the flag is false, indicating that the driver has assumed control, rotation ceases, and the task is once again blocked on the semaphore, awaiting further task execution.

vAntiClockWise (Automatic Control)




Figure 11: Automatic control for passenger anti-clockwise

Alternatively, if Button 6 is pressed only once, it signifies the passenger's preference for automatic control. This mode initiates motor rotation until either the limit is reached or driver wanted to take control. If the limit switch is triggered, rotation halts, and the task is blocked. Conversely, if driver took control, the motor stops rotation, additionally if the protection button is pressed the rotation stops to prevent problems and the task is blocked on the semaphore

Problem Faced

Synchronizing Tasks with Interrupts:

One significant challenge we faced was synchronizing tasks with interrupts effectively. Integrating interruptdriven events seamlessly into the task flow while ensuring critical tasks were not interrupted inappropriately required careful planning and synchronization strategies.

Learning PWM Configuration:

Learning how to configure Pulse Width Modulation (PWM) posed a notable challenge. PWM is critical for controlling the speed and direction of motors, but understanding its principles and configuring it correctly required dedicated effort and experimentation.

Connecting 12V to the H-Bridge Safely:

We encountered apprehension when learning how to connect the 12V power source to the H-bridge without damaging components. Fear of damaging components due to incorrect wiring or voltage fluctuations prompted thorough research and cautious implementation strategies to ensure the system's safety and integrity.

Video Link

https://drive.google.com/drive/folders/1KjXtM09nYYOyMdihWa51Z-vKL5bM O3e?usp=drive link