1 Placement Optimization

In this section, we describe the placement optimization for the patches in the quantum processor. Numerical results are shown in Section ??.

1.1 Mapping the Circuit to the Graph

We consider placement optimization based on the number of surgery operations in the quantum circuit. Firstly, we count the number of surgery operations, e.g., multi-body Pauli measurements or CNOT gates, in the circuit. Then, we construct a graph G(V, E) as follows:

Definition 1. Let V represent the nodes and E represent the edges in the graph G(V, E). Each patch in the quantum processor and each two-qubit operation are mapped to V and E, respectively. Additionally, each edge has a weight w, which corresponds to the number of operations associated with the edge.

Particularly, we denote the patch used to implement T gates as MAGIC_NODE in the graph. We assume that when performing a T gate on a qubit, we execute a two-qubit operation between the qubit and MAGIC_NODE instead of performing the T gate directly on the qubit. Now, we present an example of mapping a small circuit. In Table 1, the names of the qubits are shown in the first column, and the instruction numbers, control qubits, target qubits, and weights are shown in the second column. And the result of the mapping Table 1 is shown in Fig.1. The coordinates of the qubits are on the grid. MAGIC_NODE is fixed at the certain place where magic state factories exists.




Fig. 1

Table 1

qubits (nodes)	instruction_number control target weight (edges)
MAGIC_NODE	1 system_1_1 control_ancilla_4_th_0 9
control_0_th_0	2 control_ancilla_0_th_0 control_1_th_0 2
control_1_th_0	3 control_ancilla_2_th_0 control_3_th_0 5
control_2_th_0	4 system_1_0 control_ancilla_4_th_0 9
control_3_th_0	5 control_ancilla_3_th_0 control_4_th_0 9
control_4_th_0	6 control_ancilla_4_th_0 control_4_th_0 9
control_ancilla_0_th_0	7 control_ancilla_1_th_0 control_1_th_0 2
control_ancilla_1_th_0	8 MAGIC_NODE control_ancilla_2_th_0 12
control_ancilla_2_th_0	9 control_ancilla_3_th_0 control_ancilla_2_th_0 14
control_ancilla_3_th_0	10 system_0_1 control_ancilla_4_th_0 9
control_ancilla_4_th_0	11 control_ancilla_2_th_0 control_2_th_0 3
system_0_0	12 MAGIC_NODE control_ancilla_3_th_0 20
system_0_1	13 system_0_0 control_ancilla_4_th_0 9
system_1_0	14 control_ancilla_2_th_0 control_ancilla_1_th_0 8
system_1_1	15 control_ancilla_1_th_0 control_2_th_0 3
	16 control_ancilla_4_th_0 control_ancilla_3_th_0 27
	17 control_ancilla_0_th_0 control_0_th_0 2
	18 control_ancilla_3_th_0 control_3_th_0 5
	19 control_ancilla_1_th_0 control_ancilla_0_th_0 5
	20 MAGIC_NODE control_ancilla_4_th_0 36
	21 MAGIC_NODE control_ancilla_1_th_0 8

1.2 Potential Energy Model

In this subsection, we introduce the potential model applied to the graph and allocate the qubits on the grid. Assume that there exists an edge between qubit 1 and qubit 2, with coordinates denoted as (x_1, y_1) and (x_2, y_2) on the grid. The distance between qubit 1 and qubit 2 is defined as $d = |x_1 - x_2| + |y_1 - y_2|$, representing the Manhattan distance. Thus, the potential energy p(w, d) is defined using the weight of the edge and the distance.

Definition 2. Assume that w is the weight of an edge in the graph G(V, E) and d is the Manhattan distance between the two qubits. Thus, the potential energy p(w, d) between the two qubits is defined as:

$$p(w,d) = wd^2. (1)$$

From Definition 2, we can calculate the total potential energy P for all edges in the graph. Thus, the following equation holds:

$$P = \sum_{i \in \text{edges}} p_i(w, d). \tag{2}$$

The procedure for updating the allocation of qubits is as follows. First, select a qubit based on the descending order of the total weight of edges associated with each qubit. Second, randomly choose another qubit within a Manhattan distance of l from the first qubit to consider for exchange. If the total potential energy decreases as a result of the exchange, perform the swap of these qubits. Otherwise, retain their current positions without exchanging them and return to the first step. This procedure continues until the potential energy becomes sufficiently small. In Fig. 2, the results obtained by reordering the qubits as shown in Fig. 1 and using the potential energy defined in Eq. 2 are presented.




Fig. 2

This scheme can be expanded to three dimensions by redefining the distance metric d as: $d = |x_1 - x_2| + |y_1 - y_2| + |z_1 - z_2|$, where the coordinates of qubits are denoted by (x, y, z).