

FWD Design Project


Name: Ahmed Sherif Mohamed

Contents

System Schematic	3
ECU 1 API.....	4
ECU 2 API.....	8
ECU 1 Typedefs used.....	12
ECU 2 Typedefs	13
ECU 1 Layered Architecture	14
ECU 2 Layered Architecture	15
ECU 1 Folder Structure.....	16
ECU 2 Folder Structure.....	17
ECU 1 State Machine.....	18
ECU 2 State Machine.....	19
ECU 1 Sequence Diagram.....	20
ECU 2 Sequence Diagram.....	21
CPU Load	22
Bus Load Calculation	23

Static Design

System Schematic



ECU 1 API

ECU Name	ECU 1
Module name	DIO
API Name	DIO_Init
API Description	Intializes the DIO Module
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	Configuration : Struct
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 1
Module name	DIO
API Name	DIO_Read
API Description	Gets Pin Value
Sync/Async	Synchronous
Reentrancy	Reentrant
Parameters(in)	PortNum : uint8, pinNumber : uint8
Parameters (out)	pinValue : bool
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 1
Module name	DIO
API Name	DIO_Write
API Description	Writes Pin Value
Sync/Async	Synchronous
Reentrancy	Reentrant
Parameters(in)	PortNum : uint8, pinNumber : uint8, value : bool
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 1
Module name	RCC
API Name	RCC_Init
API Description	Intializes the RCC Module
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	Configuration : Struct
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 1
Module name	RCC
API Name	RCC_Enable
API Description	Enables the RCC On a periphral
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	Periphral : enum
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 1
Module name	Door
API Name	DoorSensor_SendState
API Description	Send door data to ecu2
Sync/Async	Asynchronous
Reentrancy	None
Parameters(in)	None
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 1
Module name	Speed
API Name	SpeedSensor_SendState
API Description	send speed data to ecu2
Sync/Async	Asynchronous
Reentrancy	None
Parameters(in)	None
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 1
Module name	Light
API Name	LightSwitch_SendState
API Description	send switch data to ecu2
Sync/Async	Asynchronous
Reentrancy	None
Parameters(in)	None
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 1
Module name	BCM
API Name	BCM_Init
API Description	intialize bcm module
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	Configuration : Struct
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 1
Module name	BCM
API Name	BCM_SendMessage
API Description	send messege through bcm
Sync/Async	Asynchronous
Reentrancy	Reentrant
Parameters(in)	MessageId : uint8, Message : uint 32
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 1
Module name	Canif
API Name	CanIf_Init
API Description	intitalize the canif
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	Configuration : Struct
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 1
Module name	Canif
API Name	CanIf_Transmit
API Description	transmit through the canif
Sync/Async	Asynchronous
Reentrancy	None
Parameters(in)	ID : uint16, data : uint32
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 1
Module name	Canif
API Name	CanIf_SetTrcvMode
API Description	sets the transceivers mode
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	Mode : uint8
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 1
Module name	Can
API Name	Can_Init
API Description	initialize can module
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	Configuration : Struct
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 1
Module name	Can
API Name	Can_Write
API Description	write through the can
Sync/Async	Asynchronous
Reentrancy	Reentrant
Parameters(in)	ID : uint16, data : uint32
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU 2 API

ECU Name	ECU 2
Module name	Switch
API Name	LightSwitch_ReciveState
API Description	recive switch data to ecu2
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	None
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 2
Module name	Buzzer
API Name	Buzzer_Control
API Description	sends buzzer data to ecu2
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	None
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 2
Module name	Light
API Name	Light_Control
API Description	sends light data to ecu2
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	None
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 2
Module name	DIO
API Name	DIO_Init
API Description	Intializes the DIO Module
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	Configuration : Struct
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 2
Module name	DIO
API Name	DIO_Read
API Description	Gets Pin Value
Sync/Async	Synchronous
Reentrancy	Reentrent
Parameters(in)	PortNum : uint8, pinNumber : uint8
Parameters (out)	pinValue : bool
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 2
Module name	DIO
API Name	DIO_Write
API Description	Writes Pin Value
Sync/Async	Synchronous
Reentrancy	Reentrent
Parameters(in)	PortNum : uint8, pinNumber : uint8, value : bool
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 2
Module name	RCC
API Name	RCC_Init
API Description	Intializes the RCC Module
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	Configuration : Struct
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 2
Module name	RCC
API Name	RCC_Enable
API Description	Enables the RCC On a peripheral
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	Peripheral : enum
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 2
Module name	BCM
API Name	BCM_Init
API Description	intialize bcm module
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	Configuration : Struct
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 2
Module name	BCM
API Name	BCM_SendMessage
API Description	send messege through bcm
Sync/Async	Asynchronous
Reentrancy	Reentrant
Parameters(in)	MessageId : uint8, Message : uint 32
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 2
Module name	Canif
API Name	CanIf_Init
API Description	intitalize the canif
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	Configuration : Struct
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 2
Module name	Canif
API Name	CanIf_Transmit
API Description	transmit throught the canif
Sync/Async	Asynchronous
Reentrancy	None
Parameters(in)	ID : uint16, data : uint32
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 2
Module name	Canif
API Name	CanIf_SetTrcvMode
API Description	sets the treanceivers mode
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	Mode : uint8
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 2
Module name	Can
API Name	Can_Init
API Description	intialize can module
Sync/Async	Synchronous
Reentrancy	None
Parameters(in)	Configuration : Struct
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t

ECU Name	ECU 2
Module name	Can
API Name	Can_Write
API Description	write throught the can
Sync/Async	Asynchronous
Reentrancy	Reentrent
Parameters(in)	ID : uint16, data : uint32
Parameters (out)	None
Parameters(in/out)	None
Return Type	errorr_t


ECU 1 Typedefs used

typedef	DoorStatus	uint8
typedef	SpeedValue	uint16
typedef	DioChannelType	uint11
typedef	DioChannelType	uint8


ECU 2 Typedefs

```
typedef      DioChannelType  uint8
typedef      LightLevelType  uint9
typedef      BuzzerLevelType uint10
typedef      DioChannelType  uint11
```

ECU 1 Layered Architecture




ECU 2 Layered Architecture



ECU 1 Folder Structure


- ✓ ECU-1
 - ✓ 1- Application\SWC-1
 - > inc
 - > src
 - ✓ 2- RTE
 - > inc
 - > src
 - ✓ 3- ECUAL
 - > CAN_Transceiver
 - > Door_Sensor
 - > Left_Light
 - > Speed_Sensor
 - ✓ 4- MCAL
 - > CAN
 - > DIO
 - > I2C
- > ECU-2

ECU 2 Folder Structure




Dynamic Design


ECU 1 State Machine




ECU 2 State Machine




ECU 1 Sequence Diagram



ECU 2 Sequence Diagram



CPU Load



Bus Load Calculation

Bus Load = Total bits / 12500 = 32 / 125000 = 0.000256 = 0.0256%