

<document classification>

---

# Mode Management Function

*Scade model description*

## **Summary:**

Generated documentation from the Scade model of Mode Management Function.

**Company:** Systemrel

**Authors:** Marielle Petit-Doche

**Reference:** openETCS - WP3

**Index:** <index>

**Date:** 20/02/2015

---

**Distribution List:** <distribution list>

# Table Of Contents

<b>1. General Project Description.....</b>	<b>14</b>
<b>2. Software Architecture .....</b>	<b>15</b>
2.1. Project Architecture .....	15
2.2. Call Graph .....	15
<b>3. Modes Project .....</b>	<b>17</b>
3.1. Root Elements .....	17
3.1.1. <i>Open Packages</i> .....	17
3.1.2. <i>ComputeModesConditions Operator</i> .....	17
3.1.2.1. Interface .....	17
3.1.2.2. Locals .....	20
3.1.2.3. Operator Hierarchy .....	22
3.1.2.4. Graphical and Textual Diagrams .....	22
3.1.3. <i>ManageModes Operator</i> .....	23
3.1.3.1. Comments and Information .....	23
3.1.3.2. Interface .....	23
3.1.3.3. Operator Hierarchy .....	24
3.1.3.4. Graphical and Textual Diagrams .....	24
3.1.4. <i>Merge_Conditions Operator</i> .....	24
3.1.4.1. Interface .....	25
3.1.4.2. Operator Hierarchy .....	26
3.1.4.3. Graphical and Textual Diagrams .....	27
3.1.5. <i>SwitchModes Operator</i> .....	27
3.1.5.1. Interface .....	27
3.1.5.2. Locals .....	28
3.1.5.3. Operator Hierarchy .....	29
3.1.5.4. Graphical and Textual Diagrams .....	30
3.2. Conditions Package.....	30
3.2.1. <i>ToFullSupervision Operator</i> .....	30
3.2.1.1. Comments and Information .....	30
3.2.1.2. Interface .....	30
3.2.1.3. Locals .....	31
3.2.1.4. Operator Hierarchy .....	31
3.2.1.5. Graphical and Textual Diagrams .....	32
3.2.2. <i>ToIsolate Operator</i> .....	32
3.2.2.1. Comments and Information .....	32
3.2.2.2. Interface .....	33
3.2.2.3. Operator Hierarchy .....	33
3.2.2.4. Graphical and Textual Diagrams .....	33
3.2.3. <i>ToNonLeading Operator</i> .....	33
3.2.3.1. Comments and Information .....	33
3.2.3.2. Interface .....	33
3.2.3.3. Operator Hierarchy .....	33
3.2.3.4. Graphical and Textual Diagrams .....	34

3.2.4.	<i>ToNoPower Operator</i> .....	34
3.2.4.1.	Comments and Information .....	34
3.2.4.2.	Interface .....	34
3.2.4.3.	Operator Hierarchy .....	34
3.2.4.4.	Graphical and Textual Diagrams .....	34
3.2.5.	<i>ToPassiveShunting Operator</i> .....	34
3.2.5.1.	Comments and Information .....	34
3.2.5.2.	Interface .....	35
3.2.5.3.	Operator Hierarchy .....	35
3.2.5.4.	Graphical and Textual Diagrams .....	35
3.2.6.	<i>ToShunting Operator</i> .....	35
3.2.6.1.	Interface .....	35
3.2.6.2.	Operator Hierarchy .....	36
3.2.6.3.	Graphical and Textual Diagrams .....	37
3.2.7.	<i>ToSleeping Operator</i> .....	37
3.2.7.1.	Comments and Information .....	37
3.2.7.2.	Interface .....	38
3.2.7.3.	Operator Hierarchy .....	38
3.2.7.4.	Graphical and Textual Diagrams .....	38
3.2.8.	<i>ToStaffResponsible Operator</i> .....	38
3.2.8.1.	Interface .....	38
3.2.8.2.	Locals .....	39
3.2.8.3.	Operator Hierarchy .....	39
3.2.8.4.	Graphical and Textual Diagrams .....	39
3.2.9.	<i>ToStandBy Operator</i> .....	39
3.2.9.1.	Comments and Information .....	40
3.2.9.2.	Interface .....	40
3.2.9.3.	Operator Hierarchy .....	41
3.2.9.4.	Graphical and Textual Diagrams .....	41
3.2.10.	<i>ToSystemFailure Operator</i> .....	41
3.2.10.1.	Comments and Information .....	41
3.2.10.2.	Interface .....	42
3.2.10.3.	Operator Hierarchy .....	42
3.2.10.4.	Graphical and Textual Diagrams.....	42
3.2.11.	<i>ToSystemNational Operator</i> .....	42
3.2.11.1.	Comments and Information .....	42
3.2.11.2.	Interface .....	42
3.2.11.3.	Operator Hierarchy .....	42
3.2.11.4.	Graphical and Textual Diagrams.....	43
3.2.12.	<i>ToTrip Operator</i> .....	43
3.2.12.1.	Interface .....	43
3.2.12.2.	Locals .....	44
3.2.12.3.	Operator Hierarchy .....	45
3.2.12.4.	Graphical and Textual Diagrams.....	45
3.2.13.	<i>ToUnfitted Operator</i> .....	46
3.2.13.1.	Comments and Information .....	46
3.2.13.2.	Interface .....	46
3.2.13.3.	Operator Hierarchy .....	46
3.2.13.4.	Graphical and Textual Diagrams.....	46
3.3.	Interfaces Package .....	46
3.3.1.	<i>InputDMI Operator</i> .....	46
3.3.1.1.	Interface .....	46
3.3.1.2.	Operator Hierarchy .....	47
3.3.1.3.	Graphical and Textual Diagrams .....	47

3.3.2.	<i>InputF2Functions Operator</i> .....	48
3.3.2.1.	Interface .....	48
3.3.2.2.	Operator Hierarchy .....	48
3.3.2.3.	Graphical and Textual Diagrams .....	48
3.3.3.	<i>InputLocalisation Operator</i> .....	49
3.3.3.1.	Interface .....	49
3.3.3.2.	Operator Hierarchy .....	49
3.3.3.3.	Graphical and Textual Diagrams .....	49
3.3.4.	<i>InputSpeedAndSupervision Operator</i> .....	49
3.3.4.1.	Interface .....	50
3.3.4.2.	Operator Hierarchy .....	50
3.3.4.3.	Graphical and Textual Diagrams .....	50
3.3.5.	<i>InputSTM Operator</i> .....	51
3.3.5.1.	Interface .....	51
3.3.5.2.	Operator Hierarchy .....	51
3.3.5.3.	Graphical and Textual Diagrams .....	51
3.3.6.	<i>InputTIUManagement Operator</i> .....	51
3.3.6.1.	Comments and Information .....	51
3.3.6.2.	Interface .....	51
3.3.6.3.	Locals .....	52
3.3.6.4.	Operator Hierarchy .....	52
3.3.6.5.	Graphical and Textual Diagrams .....	53
3.3.7.	<i>InputTrackManagement Operator</i> .....	53
3.3.7.1.	Interface .....	54
3.3.7.2.	Operator Hierarchy .....	54
3.3.7.3.	Graphical and Textual Diagrams .....	55
3.3.8.	<i>Output_To_BG_Management Operator</i> .....	55
3.3.8.1.	Interface .....	55
3.3.8.2.	Operator Hierarchy .....	55
3.3.8.3.	Graphical and Textual Diagrams .....	56
3.3.9.	<i>Output_To_DMI Operator</i> .....	56
3.3.9.1.	Interface .....	56
3.3.9.2.	Operator Hierarchy .....	57
3.3.9.3.	Graphical and Textual Diagrams .....	57
3.3.10.	<i>OutputManagement Operator</i> .....	57
3.3.10.1.	Interface .....	57
3.3.10.2.	Operator Hierarchy .....	58
3.3.10.3.	Graphical and Textual Diagrams .....	59
3.4.	<b>Librairies Package</b> .....	59
3.4.1.	<i>Mode_Profile_Calculations Operator</i> .....	59
3.4.1.1.	Interface .....	59
3.4.1.2.	Locals .....	60
3.4.1.3.	Operator Hierarchy .....	60
3.4.1.4.	Graphical and Textual Diagrams .....	61
3.4.2.	<i>Position_In_Ack_Area Operator</i> .....	61
3.4.2.1.	Interface .....	61
3.4.2.2.	Operator Hierarchy .....	62
3.4.2.3.	Graphical and Textual Diagrams .....	62
3.4.3.	<i>Position_In_Area Operator</i> .....	62
3.4.3.1.	Interface .....	62
3.4.3.2.	Operator Hierarchy .....	62
3.4.3.3.	Graphical and Textual Diagrams .....	63
3.4.4.	<i>Reversing_Calculations Operator</i> .....	63

3.4.4.1.	Interface .....	63
3.4.4.2.	Locals .....	63
3.4.4.3.	Operator Hierarchy .....	63
3.4.4.4.	Graphical and Textual Diagrams .....	64
3.5.	PriorityManagement Package .....	64
3.5.1.	<i>From_FS Operator</i> .....	64
3.5.1.1.	Interface .....	64
3.5.1.2.	Locals .....	65
3.5.1.3.	Operator Hierarchy .....	65
3.5.1.4.	Graphical and Textual Diagrams .....	66
3.5.2.	<i>From_LS Operator</i> .....	67
3.5.2.1.	Interface .....	67
3.5.2.2.	Locals .....	68
3.5.2.3.	Operator Hierarchy .....	68
3.5.2.4.	Graphical and Textual Diagrams .....	69
3.5.3.	<i>From_NL Operator</i> .....	70
3.5.3.1.	Interface .....	70
3.5.3.2.	Operator Hierarchy .....	70
3.5.3.3.	Graphical and Textual Diagrams .....	71
3.5.4.	<i>From_NP Operator</i> .....	71
3.5.4.1.	Interface .....	71
3.5.4.2.	Operator Hierarchy .....	72
3.5.4.3.	Graphical and Textual Diagrams .....	72
3.5.5.	<i>From_OS Operator</i> .....	72
3.5.5.1.	Interface .....	72
3.5.5.2.	Locals .....	73
3.5.5.3.	Operator Hierarchy .....	73
3.5.5.4.	Graphical and Textual Diagrams .....	75
3.5.6.	<i>From_PS Operator</i> .....	76
3.5.6.1.	Interface .....	76
3.5.6.2.	Operator Hierarchy .....	76
3.5.6.3.	Graphical and Textual Diagrams .....	77
3.5.7.	<i>From_PT Operator</i> .....	78
3.5.7.1.	Interface .....	78
3.5.7.2.	Locals .....	78
3.5.7.3.	Operator Hierarchy .....	78
3.5.7.4.	Graphical and Textual Diagrams .....	79
3.5.8.	<i>From_RV Operator</i> .....	80
3.5.8.1.	Interface .....	80
3.5.8.2.	Operator Hierarchy .....	80
3.5.8.3.	Graphical and Textual Diagrams .....	81
3.5.9.	<i>From_SB Operator</i> .....	81
3.5.9.1.	Interface .....	81
3.5.9.2.	Locals .....	82
3.5.9.3.	Operator Hierarchy .....	82
3.5.9.4.	Graphical and Textual Diagrams .....	84
3.5.10.	<i>From_SF Operator</i> .....	85
3.5.10.1.	Interface .....	85
3.5.10.2.	Operator Hierarchy .....	85
3.5.10.3.	Graphical and Textual Diagrams .....	86
3.5.11.	<i>From_SH Operator</i> .....	86
3.5.11.1.	Interface .....	86
3.5.11.2.	Locals .....	87
3.5.11.3.	Operator Hierarchy .....	87

3.5.11.4.	Graphical and Textual Diagrams.....	88
3.5.12.	<i>From_SL Operator .....</i>	<i>88</i>
3.5.12.1.	Interface .....	89
3.5.12.2.	Operator Hierarchy.....	89
3.5.12.3.	Graphical and Textual Diagrams.....	89
3.5.13.	<i>From_SN Operator.....</i>	<i>90</i>
3.5.13.1.	Interface .....	90
3.5.13.2.	Locals .....	90
3.5.13.3.	Operator Hierarchy.....	91
3.5.13.4.	Graphical and Textual Diagrams.....	92
3.5.14.	<i>From_SR Operator .....</i>	<i>93</i>
3.5.14.1.	Interface .....	93
3.5.14.2.	Locals .....	94
3.5.14.3.	Operator Hierarchy.....	94
3.5.14.4.	Graphical and Textual Diagrams.....	95
3.5.15.	<i>From_TR Operator .....</i>	<i>96</i>
3.5.15.1.	Interface .....	96
3.5.15.2.	Operator Hierarchy.....	96
3.5.15.3.	Graphical and Textual Diagrams.....	97
3.5.16.	<i>From_UN Operator.....</i>	<i>98</i>
3.5.16.1.	Interface .....	98
3.5.16.2.	Locals .....	98
3.5.16.3.	Operator Hierarchy.....	98
3.5.16.4.	Graphical and Textual Diagrams.....	100
3.6.	Procedures Package.....	101
3.6.1.	<i>Procedure_LimitedSupervision Operator.....</i>	<i>101</i>
3.6.1.1.	Comments and Information .....	101
3.6.1.2.	Interface .....	101
3.6.1.3.	Locals .....	102
3.6.1.4.	Operator Hierarchy .....	102
3.6.1.5.	Graphical and Textual Diagrams .....	102
3.6.2.	<i>Procedure_OnSight Operator.....</i>	<i>102</i>
3.6.2.1.	Interface .....	103
3.6.2.2.	Locals .....	103
3.6.2.3.	Operator Hierarchy .....	103
3.6.2.4.	Graphical and Textual Diagrams .....	104
3.6.3.	<i>Procedure_SH_Initiated_By_Driver Operator.....</i>	<i>104</i>
3.6.3.1.	Comments and Information .....	104
3.6.3.2.	Interface .....	104
3.6.3.3.	Locals .....	105
3.6.3.4.	Operator Hierarchy .....	105
3.6.3.5.	Graphical and Textual Diagrams .....	106
3.6.4.	<i>Procedure_SH_Ordered_By_Track Operator .....</i>	<i>107</i>
3.6.4.1.	Comments and Information .....	107
3.6.4.2.	Interface .....	107
3.6.4.3.	Locals .....	107
3.6.4.4.	Operator Hierarchy .....	107
3.6.4.5.	Graphical and Textual Diagrams .....	108
3.6.5.	<i>Procedure_Start_L1_L2_L3 Operator.....</i>	<i>108</i>
3.6.5.1.	Interface .....	108
3.6.5.2.	Locals .....	109
3.6.5.3.	Operator Hierarchy .....	109
3.6.5.4.	Graphical and Textual Diagrams .....	110
3.6.6.	<i>Procedure_StartOfMission Operator.....</i>	<i>112</i>

3.6.6.1.	Interface .....	113
3.6.6.2.	Operator Hierarchy .....	114
3.6.6.3.	Graphical and Textual Diagrams .....	115
<b>3.6.7.</b>	<b><i>Procedure_Train_Reversing Operator .....</i></b>	<b>118</b>
3.6.7.1.	Interface .....	118
3.6.7.2.	Locals .....	118
3.6.7.3.	Operator Hierarchy .....	119
3.6.7.4.	Graphical and Textual Diagrams .....	119
<b>3.6.8.</b>	<b><i>Procedure_Train_Trip Operator .....</i></b>	<b>120</b>
3.6.8.1.	Comments and Information .....	120
3.6.8.2.	Interface .....	121
3.6.8.3.	Locals .....	122
3.6.8.4.	Operator Hierarchy .....	122
3.6.8.5.	Graphical and Textual Diagrams .....	123
<b>3.6.9.</b>	<b><i>Procedure_With_Mode_Profile Operator .....</i></b>	<b>125</b>
3.6.9.1.	Interface .....	125
3.6.9.2.	Locals .....	126
3.6.9.3.	Operator Hierarchy .....	126
3.6.9.4.	Graphical and Textual Diagrams .....	127
<b>3.6.10.</b>	<b><i>SH_Initiated_By_Driver_On Operator .....</i></b>	<b>132</b>
3.6.10.1.	Interface .....	132
3.6.10.2.	Locals .....	132
3.6.10.3.	Operator Hierarchy .....	132
3.6.10.4.	Graphical and Textual Diagrams .....	133

## List Of Figures

Figure 1: View of diagram_ComputeModesConditions_1 (ComputeModesConditions) .....	22
Figure 2: View of diagram_ManageModes_1 (ManageModes) .....	24
Figure 3: View of diagram_Operator44_1 (Merge_Conditions) .....	27
Figure 4: View of diagram_SwitchModes_1 (SwitchModes) .....	30
Figure 5: View of diagram_ToFullSupervision_1 (ToFullSupervision) .....	32
Figure 6: View of diagram_ToIsolate_1 (ToIsolate) .....	33
Figure 7: View of diagram_ToNonLeading_1 (ToNonLeading) .....	34
Figure 8: View of diagram_ToNoPower_1 (ToNoPower) .....	34
Figure 9: View of diagram_ToPassiveShunting_1 (ToPassiveShunting) .....	35
Figure 10: View of diagram_ToShunting_1 (ToShunting) .....	37
Figure 11: View of diagram_ToSleeping_1 (ToSleeping) .....	38
Figure 12: View of diagram_ToOnSight1_1 (ToStaffResponsible) .....	39
Figure 13: View of diagram_ToStandBy_1 (ToStandBy) .....	41
Figure 14: View of diagram_ToSystemFailure_1 (ToSystemFailure) .....	42
Figure 15: View of diagram_ToSystemNational1_1 (ToSystemNational) .....	43
Figure 16: View of diagram_ToTrip_1 (ToTrip) .....	45
Figure 17: View of diagram_ToUnfitted_1 (ToUnfitted) .....	46
Figure 18: View of diagram_Operator5_1 (InputDMI) .....	47
Figure 19: View of diagram_InputF2Functions_1 (InputF2Functions) .....	48
Figure 20: View of diagram_InputSpeedAndSupervision1_1 (InputLocalisation) ..	49
Figure 21: View of diagram_InputSpeedAndSupervision_1 (InputSpeedAndSupervision) .....	50
Figure 22: View of diagram_InputSTM_1 (InputSTM) .....	51
Figure 23: View of diagram_InputTIUManagement_1 (InputTIUManagement) ..	53
Figure 24: View of diagram_InputTrackManagement_1 (InputTrackManagement) .....	55
Figure 25: View of diagram_Output_To_BG_Management_1 (Output_To_BG_Management) .....	56
Figure 26: View of diagram_Output_To_DMI_1 (Output_To_DMI) .....	57
Figure 27: View of diagram_Operator48_1 (OutputManagement) .....	59
Figure 28: View of diagram_Operator7_1 (Mode_Profile_Calculations) .....	61
Figure 29: View of diagram_Position_In_Ack_Area_1 (Position_In_Ack_Area) ..	62
Figure 30: View of diagram_Position_In_Area_1 (Position_In_Area) .....	63
Figure 31: View of diagram_Operator7_1 (Reversing_Calculations) .....	64
Figure 32: View of diagram_From_FS (From_FS) .....	66
Figure 33: View of diagram_From_LS (From_LS) .....	69
Figure 34: View of diagram_From_NL (From_NL) .....	71
Figure 35: View of diagram_From_NP (From_NP) .....	72
Figure 36: View of diagram_From_OS (From_OS) .....	75
Figure 37: View of diagram_From_PS (From_PS) .....	77
Figure 38: View of diagram_From_PT (From_PT) .....	79
Figure 39: View of diagram_From_RV (From_RV) .....	81
Figure 40: View of diagram_From_SB (From_SB) .....	84
Figure 41: View of diagram_From_SF (From_SF) .....	86
Figure 42: View of diagram_From_SH (From_SH) .....	88
Figure 43: View of diagram_From_SL (From_SL) .....	89
Figure 44: View of diagram_From_SN (From_SN) .....	92
Figure 45: View of diagram_From_SR (From_SR) .....	95



Figure 46: View of diagram_From_TR (From_TR) .....	97
Figure 47: View of diagram_From_UN (From_UN) .....	100
Figure 48: View of diagram_Procedure_LimitedSupervision_1 (Procedure_LimitedSupervision) .....	102
Figure 49: View of diagram_Procedure_OnSight_1 (Procedure_OnSight) .....	104
Figure 50: View of diagram_Procedure_SH_Initiated_By_Driver_1 (Procedure_SH_Initiated_By_Driver) .....	106
Figure 51: View of diagram_Procedure_SH_Ordered_By_Track_1 (Procedure_SH_Ordered_By_Track) .....	108
Figure 52: View of diagram_Procedure_Start_L1_L2_L3_1 (Procedure_Start_L1_L2_L3) .....	110
Figure 53: View of diagram_Procedure_StartOfMission_1 (Procedure_StartOfMission) .....	115
Figure 54: View of diagram_Procedure_Train_Reversing_1 (Procedure_Train_Reversing) .....	119
Figure 55: View of diagram_Procedure_Train_Trip_1 (Procedure_Train_Trip) ..	123
Figure 56: View of diagram_Procedure_With_Mode_Profile_1 (Procedure_With_Mode_Profile) .....	127
Figure 57: View of diagram_SH_Initiated_By_Driver_On_1 (SH_Initiated_By_Driver_On) .....	133

## List Of Tables

Table 1: Inputs of ComputeModesConditions.....	17
Table 2: Outputs of ComputeModesConditions .....	19
Table 3: Locals of ComputeModesConditions .....	20
Table 4: Inputs of ManageModes .....	23
Table 5: Outputs of ManageModes .....	23
Table 6: Inputs of Merge_Conditions.....	25
Table 7: Outputs of Merge_Conditions .....	26
Table 8: Inputs of SwitchModes .....	27
Table 9: Outputs of SwitchModes .....	28
Table 10: Locals of SwitchModes .....	28
Table 11: Inputs of ToFullSupervision .....	30
Table 12: Outputs of ToFullSupervision .....	31
Table 13: Locals of ToFullSupervision.....	31
Table 14: Inputs of ToIsolate .....	33
Table 15: Outputs of ToIsolate.....	33
Table 16: Inputs of ToNonLeading .....	33
Table 17: Outputs of ToNonLeading .....	33
Table 18: Inputs of ToNoPower .....	34
Table 19: Outputs of ToNoPower .....	34
Table 20: Inputs of ToPassiveShunting.....	35
Table 21: Outputs of ToPassiveShunting .....	35
Table 22: Inputs of ToShunting .....	35
Table 23: Outputs of ToShunting.....	36
Table 24: Inputs of ToSleeping .....	38
Table 25: Outputs of ToSleeping .....	38
Table 26: Inputs of ToStaffResponsible .....	38
Table 27: Outputs of ToStaffResponsible .....	38
Table 28: Locals of ToStaffResponsible.....	39
Table 29: Inputs of ToStandBy.....	40
Table 30: Outputs of ToStandBy.....	40
Table 31: Inputs of ToSystemFailure.....	42
Table 32: Outputs of ToSystemFailure .....	42
Table 33: Inputs of ToSystemNational .....	42
Table 34: Outputs of ToSystemNational .....	42
Table 35: Inputs of ToTrip .....	43
Table 36: Outputs of ToTrip .....	44
Table 37: Locals of ToTrip .....	44
Table 38: Inputs of ToUnfitted .....	46
Table 39: Outputs of ToUnfitted .....	46
Table 40: Inputs of InputDMI.....	46
Table 41: Outputs of InputDMI.....	47
Table 42: Inputs of InputF2Functions.....	48
Table 43: Outputs of InputF2Functions .....	48
Table 44: Inputs of InputLocalisation .....	49
Table 45: Outputs of InputLocalisation .....	49
Table 46: Inputs of InputSpeedAndSupervision .....	50
Table 47: Outputs of InputSpeedAndSupervision .....	50
Table 48: Inputs of InputSTM .....	51
Table 49: Outputs of InputSTM .....	51

Table 50: Inputs of InputTIUManagement .....	51
Table 51: Outputs of InputTIUManagement .....	52
Table 52: Locals of InputTIUManagement.....	52
Table 53: Inputs of InputTrackManagement.....	54
Table 54: Outputs of InputTrackManagement .....	54
Table 55: Inputs of Output_To_BG_Management .....	55
Table 56: Outputs of Output_To_BG_Management .....	55
Table 57: Inputs of Output_To_DMI.....	56
Table 58: Outputs of Output_To_DMI .....	56
Table 59: Inputs of OutputManagement .....	57
Table 60: Outputs of OutputManagement .....	58
Table 61: Inputs of Mode_Profile_Calculations .....	59
Table 62: Outputs of Mode_Profile_Calculations .....	59
Table 63: Locals of Mode_Profile_Calculations.....	60
Table 64: Conditional Blocks of diagram_Operator7_1 .....	61
Table 65: Actions of diagram_Operator7_1 .....	61
Table 66: Inputs of Position_In_Ack_Area .....	61
Table 67: Outputs of Position_In_Ack_Area .....	62
Table 68: Inputs of Position_In_Area .....	62
Table 69: Outputs of Position_In_Area .....	62
Table 70: Inputs of Reversing_Calculations .....	63
Table 71: Outputs of Reversing_Calculations .....	63
Table 72: Locals of Reversing_Calculations .....	63
Table 73: Inputs of From_FS .....	64
Table 74: Outputs of From_FS .....	65
Table 75: Locals of From_FS.....	65
Table 76: Conditional Blocks of diagram_From_FS.....	66
Table 77: Actions of diagram_From_FS .....	66
Table 78: Inputs of From_LS .....	67
Table 79: Outputs of From_LS .....	68
Table 80: Locals of From_LS.....	68
Table 81: Conditional Blocks of diagram_From_LS.....	69
Table 82: Actions of diagram_From_LS .....	69
Table 83: Inputs of From_NL .....	70
Table 84: Outputs of From_NL .....	70
Table 85: Conditional Blocks of diagram_From_NL .....	71
Table 86: Actions of diagram_From_NL.....	71
Table 87: Inputs of From_NP .....	71
Table 88: Outputs of From_NP.....	71
Table 89: Conditional Blocks of diagram_From_NP .....	72
Table 90: Actions of diagram_From_NP.....	72
Table 91: Inputs of From_OS.....	72
Table 92: Outputs of From_OS.....	73
Table 93: Locals of From_OS .....	73
Table 94: Conditional Blocks of diagram_From_OS .....	75
Table 95: Actions of diagram_From_OS .....	75
Table 96: Inputs of From_PS .....	76
Table 97: Outputs of From_PS .....	76
Table 98: Conditional Blocks of diagram_From_PS.....	77
Table 99: Actions of diagram_From_PS .....	77
Table 100: Inputs of From_PT.....	78
Table 101: Outputs of From_PT.....	78

Table 102: Locals of From_PT .....	78
Table 103: Conditional Blocks of diagram_From_PT .....	80
Table 104: Actions of diagram_From_PT .....	80
Table 105: Inputs of From_RV .....	80
Table 106: Outputs of From_RV .....	80
Table 107: Conditional Blocks of diagram_From_RV.....	81
Table 108: Actions of diagram_From_RV .....	81
Table 109: Inputs of From_SB .....	81
Table 110: Outputs of From_SB .....	82
Table 111: Locals of From_SB.....	82
Table 112: Conditional Blocks of diagram_From_SB.....	84
Table 113: Actions of diagram_From_SB .....	84
Table 114: Inputs of From_SF.....	85
Table 115: Outputs of From_SF .....	85
Table 116: Conditional Blocks of diagram_From_SF .....	86
Table 117: Actions of diagram_From_SF .....	86
Table 118: Inputs of From_SH .....	86
Table 119: Outputs of From_SH .....	87
Table 120: Locals of From_SH .....	87
Table 121: Conditional Blocks of diagram_From_SH .....	88
Table 122: Actions of diagram_From_SH.....	88
Table 123: Inputs of From_SL.....	89
Table 124: Outputs of From_SL.....	89
Table 125: Conditional Blocks of diagram_From_SL .....	89
Table 126: Actions of diagram_From_SL .....	90
Table 127: Inputs of From_SN .....	90
Table 128: Outputs of From_SN .....	90
Table 129: Locals of From_SN.....	90
Table 130: Conditional Blocks of diagram_From_SN .....	92
Table 131: Actions of diagram_From_SN.....	92
Table 132: Inputs of From_SR .....	93
Table 133: Outputs of From_SR .....	94
Table 134: Locals of From_SR.....	94
Table 135: Conditional Blocks of diagram_From_SR.....	95
Table 136: Actions of diagram_From_SR .....	95
Table 137: Inputs of From_TR .....	96
Table 138: Outputs of From_TR .....	96
Table 139: Conditional Blocks of diagram_From_TR.....	97
Table 140: Actions of diagram_From_TR .....	97
Table 141: Inputs of From_UN .....	98
Table 142: Outputs of From_UN .....	98
Table 143: Locals of From_UN .....	98
Table 144: Conditional Blocks of diagram_From_UN .....	100
Table 145: Actions of diagram_From_UN.....	100
Table 146: Inputs of Procedure_LimitedSupervision .....	101
Table 147: Outputs of Procedure_LimitedSupervision.....	101
Table 148: Locals of Procedure_LimitedSupervision .....	102
Table 149: Inputs of Procedure_OnSight .....	103
Table 150: Outputs of Procedure_OnSight .....	103
Table 151: Locals of Procedure_OnSight .....	103
Table 152: Inputs of Procedure_SH_Initiated_By_Driver .....	104
Table 153: Outputs of Procedure_SH_Initiated_By_Driver .....	105

Table 154: Locals of Procedure_SH_Initiated_By_Driver.....	105
Table 155: State Machines of diagram_Procedure_SH_Initiated_By_Driver_1 ..	106
Table 156: States of diagram_Procedure_SH_Initiated_By_Driver_1.....	106
Table 157: Transitions of diagram_Procedure_SH_Initiated_By_Driver_1 .....	106
Table 158: Inputs of Procedure_SH_Ordered_By_Track .....	107
Table 159: Outputs of Procedure_SH_Ordered_By_Track .....	107
Table 160: Locals of Procedure_SH_Ordered_By_Track.....	107
Table 161: Inputs of Procedure_Start_L1_L2_L3 .....	108
Table 162: Outputs of Procedure_Start_L1_L2_L3 .....	108
Table 163: Locals of Procedure_Start_L1_L2_L3.....	109
Table 164: State Machines of diagram_Procedure_Start_L1_L2_L3_1 .....	110
Table 165: States of diagram_Procedure_Start_L1_L2_L3_1 .....	110
Table 166: Transitions of diagram_Procedure_Start_L1_L2_L3_1 .....	111
Table 167: Inputs of Procedure_StartOfMission .....	113
Table 168: Outputs of Procedure_StartOfMission .....	113
Table 169: State Machines of diagram_Procedure_StartOfMission_1 .....	115
Table 170: States of diagram_Procedure_StartOfMission_1 .....	116
Table 171: Transitions of diagram_Procedure_StartOfMission_1 .....	116
Table 172: Inputs of Procedure_Train_Reversing.....	118
Table 173: Outputs of Procedure_Train_Reversing.....	118
Table 174: Locals of Procedure_Train_Reversing .....	118
Table 175: State Machines of diagram_Procedure_Train_Reversing_1.....	119
Table 176: States of diagram_Procedure_Train_Reversing_1 .....	119
Table 177: Transitions of diagram_Procedure_Train_Reversing_1.....	120
Table 178: Inputs of Procedure_Train_Trip .....	121
Table 179: Outputs of Procedure_Train_Trip .....	121
Table 180: Locals of Procedure_Train_Trip .....	122
Table 181: State Machines of diagram_Procedure_Train_Trip_1 .....	123
Table 182: States of diagram_Procedure_Train_Trip_1 .....	123
Table 183: Transitions of diagram_Procedure_Train_Trip_1 .....	124
Table 184: Inputs of Procedure_With_Mode_Profile .....	125
Table 185: Outputs of Procedure_With_Mode_Profile .....	125
Table 186: Locals of Procedure_With_Mode_Profile.....	126
Table 187: Signals of Procedure_With_Mode_Profile .....	126
Table 188: Counter (#8) hidden inputs assignment of diagram_Procedure_With_Mode_Profile_1 .....	127
Table 189: State Machines of diagram_Procedure_With_Mode_Profile_1 .....	127
Table 190: States of diagram_Procedure_With_Mode_Profile_1.....	128
Table 191: Transitions of diagram_Procedure_With_Mode_Profile_1 .....	129
Table 192: Conditional Blocks of diagram_Procedure_With_Mode_Profile_1 ...	131
Table 193: Actions of diagram_Procedure_With_Mode_Profile_1 .....	131
Table 194: Inputs of SH_Initiated_By_Driver_On .....	132
Table 195: Outputs of SH_Initiated_By_Driver_On .....	132
Table 196: Locals of SH_Initiated_By_Driver_On.....	132
Table 197: State Machines of diagram_SH_Initiated_By_Driver_On_1 .....	133
Table 198: States of diagram_SH_Initiated_By_Driver_On_1.....	133
Table 199: Transitions of diagram_SH_Initiated_By_Driver_On_1 .....	133

# **1. General Project Description**

<description>

## 2. Software Architecture

### 2.1. Project Architecture

This section displays the package hierarchy of projects.

Project Modes

- Conditions
- Interfaces
- Librairies
- PriorityManagement
- Procedures

### 2.2. Call Graph

This Call Graph displays the dependency tree of model operators.

#### 1. ManageModes

##### 1.1. ComputeModesConditions

- 1.1.1. Conditions::ToFullSupervision
- 1.1.2. Conditions::ToIsolate
- 1.1.3. Conditions::ToNonLeading
- 1.1.4. Conditions::ToNoPower
- 1.1.5. Conditions::ToPassiveShunting
- 1.1.6. Conditions::ToShunting
  - 1.1.6.1. Procedures::Procedure\_SH\_Initiated\_By\_Driver
    - 1.1.6.1.1. Procedures::SH\_Initiated\_By\_Driver\_On
  - 1.1.6.2. Procedures::Procedure\_SH\_Ordered\_By\_Track
    - 1.1.6.2.1. Procedures::Procedure\_With\_Mode\_Profile
      - 1.1.6.2.1.1. Librairies::Mode\_Profile\_Calculations
        - 1.1.6.2.1.1.1. Librairies::Position\_In\_Ack\_Area
        - 1.1.6.2.1.1.2. Librairies::Position\_In\_Area
      - 1.1.6.2.1.2. pwlinear::Counter
- 1.1.7. Conditions::ToSleeping
- 1.1.8. Conditions::ToStaffResponsible
- 1.1.9. Conditions::ToStandBy
- 1.1.10. Conditions::ToSystemFailure
- 1.1.11. Conditions::ToSystemNational
- 1.1.12. Conditions::ToTrip
- 1.1.13. Conditions::ToUnfitted
- 1.1.14. Merge\_Conditions
- 1.1.15. Procedures::Procedure\_LimitedSupervision
  - 1.1.15.1. Librairies::Mode\_Profile\_Calculations
    - 1.1.15.1.1. Librairies::Position\_In\_Ack\_Area
    - 1.1.15.1.2. Librairies::Position\_In\_Area
  - 1.1.15.2. Procedures::Procedure\_With\_Mode\_Profile
    - 1.1.15.2.1. Librairies::Mode\_Profile\_Calculations
      - 1.1.15.2.1.1. Librairies::Position\_In\_Ack\_Area
      - 1.1.15.2.1.2. Librairies::Position\_In\_Area
    - 1.1.15.2.2. pwlinear::Counter
- 1.1.16. Procedures::Procedure\_OnSight

- 1.1.16.1. Librairies::Mode\_Profile\_Calculations
  - 1.1.16.1.1. Librairies::Position\_In\_Ack\_Area
  - 1.1.16.1.2. Librairies::Position\_In\_Area
- 1.1.16.2. Procedures::Procedure\_With\_Mode\_Profile
  - 1.1.16.2.1. Librairies::Mode\_Profile\_Calculations
    - 1.1.16.2.1.1. Librairies::Position\_In\_Ack\_Area
    - 1.1.16.2.1.2. Librairies::Position\_In\_Area
  - 1.1.16.2.2. pwlinear::Counter
- 1.1.17. Procedures::Procedure\_StartOfMission
  - 1.1.17.1. Procedures::Procedure\_Start\_L1\_L2\_L3
  - 1.1.17.2. Procedures::SH\_Initiated\_By\_Driver\_On
- 1.1.18. Procedures::Procedure\_Train\_Reversing
  - 1.1.18.1. Librairies::Reversing\_Calculations
    - 1.1.18.1.1. Librairies::Position\_In\_Area
- 1.1.19. Procedures::Procedure\_Train\_Trip
  - 1.1.19.1. Procedures::Procedure\_Start\_L1\_L2\_L3
  - 1.1.19.2. Procedures::SH\_Initiated\_By\_Driver\_On
- 1.2. Interfaces::InputDMI
- 1.3. Interfaces::InputF2Functions
- 1.4. Interfaces::InputLocalisation
- 1.5. Interfaces::InputSpeedAndSupervision
- 1.6. Interfaces::InputSTM
- 1.7. Interfaces::InputTIUManagement
- 1.8. Interfaces::InputTrackManagement
- 1.9. Interfaces::OutputManagement
  - 1.9.1. Interfaces::Output\_To\_BG\_Management
  - 1.9.2. Interfaces::Output\_To\_DMI
- 1.10. SwitchModes
  - 1.10.1. PriorityManagement::From\_FS
  - 1.10.2. PriorityManagement::From\_LS
  - 1.10.3. PriorityManagement::From\_NL
  - 1.10.4. PriorityManagement::From\_NP
  - 1.10.5. PriorityManagement::From\_OS
  - 1.10.6. PriorityManagement::From\_PS
  - 1.10.7. PriorityManagement::From\_PT
  - 1.10.8. PriorityManagement::From\_RV
  - 1.10.9. PriorityManagement::From\_SB
  - 1.10.10. PriorityManagement::From\_SF
  - 1.10.11. PriorityManagement::From\_SH
  - 1.10.12. PriorityManagement::From\_SL
  - 1.10.13. PriorityManagement::From\_SN
  - 1.10.14. PriorityManagement::From\_SR
  - 1.10.15. PriorityManagement::From\_TR
  - 1.10.16. PriorityManagement::From\_UN



## 3. Modes Project

### 3.1. Root Elements

#### 3.1.1. Open Packages

- TrainPosition\_Types\_Pck

#### 3.1.2. ComputeModesConditions Operator

Declared as **public node**

##### 3.1.2.1. Interface

**Table 1: Inputs of ComputeModesConditions**

Name	Type	Properties		Comments and Information
Current_Level	M_LEVEL	last	M_LEVEL_Level_0	
Current_Mode	Level_And_Mode_Types_Pkg::T_Mode			
Train_Permitted_NL	bool			
Train_Permitted_PS	bool			
Train_Req_SL	bool			
All_Desks_Closed	bool			
Desk_Open	bool			
OnBoard_Powered	bool			
Valid_Train_Data_Stored	bool			
Driver_Ack_LS	bool			
Driver_Ack_OS	bool			
Driver_Ack_RV	bool			
Driver_Ack_SH	bool			
Driver_Ack_SN	bool			
Driver_Ack_SR	bool			
Driver_Ack_TR	bool			
Driver_Ack_UN	bool			
Driver_Req_Exit_SH	bool			
Driver_Req_NL	bool			
Driver_Req_Override	bool			
Driver_Req_SH	bool			
Driver_Req_Start	bool			
ETCS_Isolated	bool			
MA_SSP_Gradient_Available	bool			
Mode_Profile_On_Board	Level_And_Mode_Types_Pkg::T_Mode_Profile			

Name	Type	Properties		Comments and Information
Shunting_Granted_By_RBC	bool			
Trip_Order_Given_By_Balise	bool			
List_BG_Related_To_SR_Empty	bool			
Stop_If_In_Shunting	bool			
Stop_If_In_SR	bool			
RBC_Ack_And_EB_Revoked	bool			
RBC_Authorized_SR	bool			
Reversing_Data	Level_And_Mode_Types_Pkg::T_Reversing_Data			
Emergency_Stop_Message_Received	bool			
Estimated_Front_End_Overpass_SR_Distance	bool			
Estimated_Front_End_Rear_Location_SSP_Or_Gradient	bool			
Override_Function_Active	bool	last	false	
Train_Overpass_EOA_Antenna	bool	last	false	
Train_Overpass_EOA_Front_End	bool			
Train_Speed_Under_Override_Limit	bool			
BG_In_Expected_List_In_SR	bool			
BG_In_Expected_List_In_SH	bool			
Linked_BG_Pased_In_Wrong_Direction	bool			
Train_Position	TrainPosition_Types_Pkg::trainPosition_T			
Train_Speed	Obu_BasicTypes_Pkg::Speed_T			
Train_Standstill	bool			
Interface_To_National_System	bool			
National_Trip_Order	bool			
T_NVCONTACT_Overpass	bool			
Error_BG_System_Version	bool			
Failure_Occured	bool	last	false	
Continue_Shunting_Function_Active	bool			
Stop_Shunting_Stored	bool			
Linking_Reaction_To_Trip	bool			

Name	Type	Properties	Comments and Information
TripModeFromLevel	bool		

**Table 2: Outputs of ComputeModesConditions**

Name	Type	Properties	Comments and Information
Condition1	bool		
Condition2	bool		
Condition3	bool		
Condition4	bool		
Condition5	bool		
Condition6	bool		
Condition7	bool		
Condition8	bool		
Condition10	bool		
Condition13	bool		
Condition14	bool		
Condition15	bool		
Condition19	bool		
Condition21	bool		
Condition22	bool		
Condition23	bool		
Condition25	bool		
Condition26	bool		
Condition27	bool		
Condition28	bool		
Condition29	bool		
Condition30	bool		
Condition31	bool		
Condition32	bool		
Condition34	bool		
Condition37	bool		
Condition40	bool		
Condition44	bool		
Condition45	bool		
Condition46	bool		
Condition47	bool		
Condition50	bool		
Condition51	bool		
Condition56	bool		
Condition58	bool		
Condition59	bool		

Name	Type	Properties		Comments and Information
Condition60	bool			
Condition61	bool			
Condition62	bool			
Condition63	bool			
Condition68	bool			
Condition70	bool			
Condition71	bool			
Condition72	bool			
Condition73	bool			
Condition74	bool			
Condition_Trip	bool			
Ack_LS_Req_To_Driver	bool			
Ack_OS_Req_To_Driver	bool			
Ack_RV_Req_To_Driver	bool			
Ack_SH_Req_To_Driver	bool			
Ack_SN_Req_To_Driver	bool			
Ack_SR_Req_To_Driver	bool			
Ack_TR_Req_To_Driver	bool			
Ack_UN_Req_To_Driver	bool			
Clean_BG_List_SH_Area	bool			
EB_Requested	bool			
End_Of_Mission_Procedure_Req	bool	last	true	
MA_Req_To_RBC	bool			
Request_For_SH_To_RBC	bool			
Service_Brake_Command	bool			
SH_Refused_By_RBC_To_DMI	bool			

### 3.1.2.2. Locals

**Table 3: Locals of ComputeModesConditions**

Name	Type	Properties		Comments and Information
Condition_to_Trip	bool			
Loc_Ack_LS_Req_To_Driver_LS	bool			
Loc_Ack_LS_Req_To_Driver_SoM	bool			

Name	Type	Properties	Comments and Information
Loc_Ack_LS_Req_To_Driver_TR	bool		
Loc_Ack_OS_Req_To_Driver_OS	bool		
Loc_Ack_OS_Req_To_Driver_SoM	bool		
Loc_Ack_OS_Req_To_Driver_TR	bool		
Loc_Ack_SH_Req_To_Driver_SH	bool		
Loc_Ack_SH_Req_To_Driver_SoM	bool		
Loc_Ack_SH_Req_To_Driver_TR	bool		
Loc_Ack_SR_Req_To_Driver_SoM	bool		
Loc_Ack_SR_Req_To_Driver_TR	bool		
Loc_Clean_BG_List_Of_SoM	bool		
Loc_Clean_BG_List_SH_Area_SH	bool		
Loc_Clean_BG_List_SH_Area_TR	bool		
Loc_Cond_15_OS	bool		
Loc_Cond_15_SoM	bool		
Loc_Cond_15_TR	bool		
Loc_Cond_31_FS	bool		
Loc_Cond_31_TR	bool		
Loc_Cond_46_NL	bool		
Loc_Cond_46_SoM	bool		
Loc_Cond_50_SH	bool		
Loc_Cond_50_SoM	bool		
Loc_Cond_50_TR	bool		
Loc_Cond_5_SH	bool		
Loc_Cond_5_SoM	bool		
Loc_Cond_5_TR	bool		
Loc_Cond_6_SH	bool		
Loc_Cond_6_SoM	bool		
Loc_Cond_6_TR	bool		
Loc_Cond_70_LS	bool		
Loc_Cond_70_SoM	bool		
Loc_Cond_70_TR	bool		
Loc_Cond_8_SoM	bool		
Loc_Cond_8_TR	bool		
Loc_End_Of_Mission_Procedure_Req_SB	bool		


Name	Type	Properties		Comments and Information
Loc_End_Of_Mission_Procedure_Req_SH	bool			
Loc_End_Of_Mission_Procedure_Req_SoM	bool			
Loc_End_Of_Mission_Procedure_Req_TR	bool			
Loc_MA_Req_To_RBC_SoM	bool			
Loc_MA_Req_To_RBC_TR	bool			
Loc_Request_For_SH_To_RBC_SH	bool			
Loc_Request_For_SH_To_RBC_SoM	bool			
Loc_Request_For_SH_To_RBC_TR	bool			
Loc_Service_Brake_Command_LS	bool			
Loc_Service_Brake_Command_OS	bool			
Loc_Service_Brake_Command_SH	bool			
Loc_SH_Refused_By_RBC_To_DMI_SH	bool			
Loc_SH_Refused_By_RBC_To_DMI_SoM	bool			
Loc_SH_Refused_By_RBC_To_DMI_TR	bool			
On_Going_Mission	bool	last	false	

### 3.1.2.3. Operator Hierarchy

diagram : diagram\_ComputeModesConditions\_1

### 3.1.2.4. Graphical and Textual Diagrams

#### 3.1.2.4.1. View of diagram\_ComputeModesConditions\_1 (ComputeModesConditions)



**Figure 1: View of diagram\_ComputeModesConditions\_1 (ComputeModesConditions)**

### 3.1.3. ManageModes Operator

Declared as **public node**

#### 3.1.3.1. Comments and Information

##### **ManageModes Comments:**

Root operator shared in for parts :

- the inputs management
- Computation of Mode conditions: this part covers the computation of conditions according to subset 26 §4.6.3 and procedure related to mode mangement in § 5. Computation of conditions are organized by procedure and mode to reach (by line of of table in §4.6.2)
- SwitchMode: this part selects the new mode according conditions and priorities given in §4.6.2 : from each mode, the new mode is calculated (by column of table 4.6.2).
- the outputs management

#### 3.1.3.2. Interface

**Table 4: Inputs of ManageModes**

Name	Type	Comments and Information
Current_Level	M_LEVEL	
Cab	TIU_Types_Pkg::cab_ID_T	
Data_From_DMI	Level_And_Mode_Types_Pkg::T_Data_From_DMI	
Data_From_F2_Functions	Level_And_Mode_Types_Pkg::T_Data_From_F2_functions	
Data_From_Localisation	Level_And_Mode_Types_Pkg::T_Data_From_Localisation	
Data_From_Speed_and_Supervision	Level_And_Mode_Types_Pkg::T_Data_From_Speed_Supervision	
Data_From_STM	Level_And_Mode_Types_Pkg::T_Data_From_STM	
Data_From_TIU	TIU_Types_Pkg::Message_Train_Interface_to_EVC_T	
Data_From_Track	Level_And_Mode_Types_Pkg::T_Data_From_Track_To_Mode	
TripModeFromLevel	bool	

**Table 5: Outputs of ManageModes**

Name	Type	Properties	Comments and Information
currentMode	Level_And_Mode_Types_Pkg::T_Mode	default	Level_And_Mode_Types_Pkg::SB

Name	Type	Properties		Comments and Information
		last	Level_And_Mode_Types_Pkg::SB	
EB_Requested	bool			
Service_Brake_Command	bool			
Data_To_DMI	Level_And_Mode_Types_Pkg::T_Data_To_DMI			
Data_To_BG_Management	Level_And_Mode_Types_Pkg::T_Data_To_BG_Management			

### 3.1.3.3. Operator Hierarchy

diagram : diagram\_ManageModes\_1

### 3.1.3.4. Graphical and Textual Diagrams

#### 3.1.3.4.1. View of diagram\_ManageModes\_1 (ManageModes)




Figure 2: View of diagram\_ManageModes\_1 (ManageModes)

### 3.1.4. Merge\_Conditions Operator

Declared as **public function**



### 3.1.4.1. Interface

**Table 6: Inputs of Merge\_Conditions**

Name	Type	Comments and Information
SH_Ref_SH	bool	
SH_Ref_SoM	bool	
SH_ref_TR	bool	
Ack_LS_LS	bool	
Ack_LS_SoM	bool	
Ack_LS_TR	bool	
Ack_OS_OS	bool	
Ack_OS_SoM	bool	
Ack_OS_TR	bool	
Ack_SH_SH	bool	
Ack_SH_SoM	bool	
Ack_SH_TR	bool	
Ack_SR_SoM	bool	
Ack_SR_TR	bool	
Clean_BG_SoM	bool	
Clean_BG_SH	bool	
Clean_BG_TR	bool	
EoM_SB	bool	
EoM_SH	bool	
EoM_SoM	bool	
EoM_TR	bool	
MA_SoM	bool	
MA_TR	bool	
Req_SH_SH	bool	
Req_SH_SoM	bool	
Req_SH_TR	bool	
SB_LS	bool	
SB_OS	bool	
SB_SH	bool	
C15_OS	bool	
C15_SoM	bool	
C15_TR	bool	
C31_FS	bool	
C31_TR	bool	
C46_NL	bool	
C46_SoM	bool	
C50_SH	bool	
C50_SoM	bool	

Name	Type	Comments and Information
C50_TR	bool	
C5_SH	bool	
C5_SoM	bool	
C5_TR	bool	
C6_SH	bool	
C6_SoM	bool	
C6_TR	bool	
C70_LS	bool	
C70_SoM	bool	
C70_TR	bool	
C8_SoM	bool	
C8_TR	bool	

**Table 7: Outputs of Merge\_Conditions**

Name	Type	Comments and Information
SH_Refused_By_RBC_To_DMI	bool	
Ack_LS_Req_To_Driver	bool	
Ack_OS_Req_To_Driver	bool	
Ack_SH_Req_To_Driver	bool	
Ack_SR_Req_To_Driver	bool	
Clean_BG_List_SH_Area	bool	
End_Of_Mission_Procedure_Req	bool	
MA_Req_To_RBC	bool	
Request_For_SH_To_RBC	bool	
Service_Brake_Command	bool	
Condition15	bool	
Condition31	bool	
Condition46	bool	
Condition50	bool	
Condition5	bool	
Condition6	bool	
Condition70	bool	
Condition8	bool	

### 3.1.4.2. Operator Hierarchy

diagram : diagram\_Operator44\_1

### 3.1.4.3. Graphical and Textual Diagrams

#### 3.1.4.3.1. View of diagram\_Operator44\_1 (Merge\_Conditions)




Figure 3: View of diagram\_Operator44\_1 (Merge\_Conditions)

### 3.1.5. SwitchModes Operator

Declared as **public node**

#### 3.1.5.1. Interface

Table 8: Inputs of SwitchModes

Name	Type	Comments and Information
Condition1	bool	
Condition2	bool	
Condition3	bool	
Condition4	bool	
Condition5	bool	
Condition6	bool	
Condition7	bool	
Condition8	bool	
Condition10	bool	
Condition13	bool	
Condition14	bool	
Condition15	bool	
Condition19	bool	
Condition21	bool	
Condition22	bool	
Condition23	bool	
Condition25	bool	
Condition26	bool	
Condition27	bool	
Condition28	bool	

Name	Type	Comments and Information
Condition29	bool	
Condition30	bool	
Condition31	bool	
Condition32	bool	
Condition34	bool	
Condition37	bool	
Condition40	bool	
Condition44	bool	
Condition45	bool	
Condition46	bool	
Condition47	bool	
Condition50	bool	
Condition51	bool	
Condition56	bool	
Condition58	bool	
Condition59	bool	
Condition60	bool	
Condition61	bool	
Condition62	bool	
Condition63	bool	
Condition68	bool	
Condition70	bool	
Condition71	bool	
Condition72	bool	
Condition73	bool	
Condition74	bool	
ConditionTrip	bool	

**Table 9: Outputs of SwitchModes**

Name	Type	Properties	Comments and Information
currentMode	Level_And_Mode_Type s_Pkg::T_Mode	default	Level_And_Mode_Types_Pkg::SB
		last	Level_And_Mode_Types_Pkg::SB

### 3.1.5.2. Locals

**Table 10: Locals of SwitchModes**

Name	Type	Properties	Comments and Information
FromFS	Level_And_Mode_Type s_Pkg::T_Mode		

Name	Type	Properties		Comments and Information
FromLS	Level_And_Mode_Type s_Pkg::T_Mode			
FromNL	Level_And_Mode_Type s_Pkg::T_Mode			
FromNP	Level_And_Mode_Type s_Pkg::T_Mode			
FromOS	Level_And_Mode_Type s_Pkg::T_Mode			
FromPS	Level_And_Mode_Type s_Pkg::T_Mode			
FromPT	Level_And_Mode_Type s_Pkg::T_Mode			
FromRV	Level_And_Mode_Type s_Pkg::T_Mode			
FromSB	Level_And_Mode_Type s_Pkg::T_Mode			
FromSF	Level_And_Mode_Type s_Pkg::T_Mode			
FromSH	Level_And_Mode_Type s_Pkg::T_Mode			
FromSL	Level_And_Mode_Type s_Pkg::T_Mode			
FromSN	Level_And_Mode_Type s_Pkg::T_Mode			
FromSR	Level_And_Mode_Type s_Pkg::T_Mode			
FromTR	Level_And_Mode_Type s_Pkg::T_Mode			
FromUN	Level_And_Mode_Type s_Pkg::T_Mode			
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	default	Level_And_M ode_Types_P kg::SB	

### 3.1.5.3. Operator Hierarchy

diagram : diagram\_SwitchModes\_1

### 3.1.5.4. Graphical and Textual Diagrams

#### 3.1.5.4.1. View of diagram\_SwitchModes\_1 (SwitchModes)




Figure 4: View of diagram\_SwitchModes\_1 (SwitchModes)

## 3.2. Conditions Package

### 3.2.1. ToFullSupervision Operator

Declared as **public node**

#### 3.2.1.1. Comments and Information

##### ToFullSupervision Comments:

SRS-26 §4.6.3 C25 : "(ERTMS/ETCS level switches to 1,2 or 3) AND (MA+SSP+gradient are on-board) AND (no specific mode is required by a Mode Profile)"

SRS-26 §4.6.3 C31 : "(MA+SSP+gradient are on-board) AND (no specific mode is required by a Mode Profile) AND (ERTMS/ETCS level is 2 or 3)"

SRS-26 §4.6.3 C32 : "(MA+SSP+gradient are on-board) AND (no specific mode is required by a Mode Profile) AND (ERTMS/ETCS level is 1) AND (no trip order is given by balise)"

#### 3.2.1.2. Interface

Table 11: Inputs of ToFullSupervision

Name	Type	Properties		Comments and Information
Current_Level	M_LEVEL	last	M_LEVEL_Level_0	
Trip_Order_Given_By_Balise	bool			
Mode_Profile_On_Board	Level_And_Mode_Types_Pkg::T_Mode_Profile			
MA_SSP_Gradient_Available	bool			

**Table 12: Outputs of ToFullSupervision**

Name	Type	Comments and Information
Condition25	bool	
Condition31	bool	
Condition32	bool	

### 3.2.1.3. Locals

**Table 13: Locals of ToFullSupervision**

Name	Type	Comments and Information
FS_Data_Condition	bool	

### 3.2.1.4. Operator Hierarchy

diagram : diagram\_ToFullSupervision\_1

### 3.2.1.5. Graphical and Textual Diagrams

#### 3.2.1.5.1. View of diagram\_ToFullSupervision\_1 (ToFullSupervision)




Figure 5: View of diagram\_ToFullSupervision\_1 (ToFullSupervision)

### 3.2.2. ToIsolate Operator

Declared as **public function**

#### 3.2.2.1. Comments and Information

##### ToIsolate Comments:

§4.6.3 : Condition 1 : "The driver isolates the ERTMS/ETCS on-board equipment".



### 3.2.2.2. Interface

**Table 14: Inputs of ToIsolate**

Name	Type	Comments and Information
ETCS_Isolation_Status	bool	

**Table 15: Outputs of ToIsolate**


Name	Type	Comments and Information
Condition1	bool	

### 3.2.2.3. Operator Hierarchy

diagram : diagram\_ToIsolate\_1

### 3.2.2.4. Graphical and Textual Diagrams

#### 3.2.2.4.1. View of diagram\_ToIsolate\_1 (ToIsolate)



**Figure 6: View of diagram\_ToIsolate\_1 (ToIsolate)**

### 3.2.3. ToNonLeading Operator

Declared as **public function**

#### 3.2.3.1. Comments and Information

**ToNonLeading Comments:**

§4.6.3 : Condition 46 " Driver selects non-leading AND train is at standstill AND non-leading input signal received

### 3.2.3.2. Interface

**Table 16: Inputs of ToNonLeading**

Name	Type	Comments and Information
Train_Permitted_NL	bool	
Train_Standstill	bool	
Driver_Req_NL	bool	

**Table 17: Outputs of ToNonLeading**

Name	Type	Comments and Information
Condition46	bool	

### 3.2.3.3. Operator Hierarchy

diagram : diagram\_ToNonLeading\_1

### 3.2.3.4. Graphical and Textual Diagrams

#### 3.2.3.4.1. View of diagram\_ToNonLeading\_1 (ToNonLeading)




Figure 7: View of diagram\_ToNonLeading\_1 (ToNonLeading)

### 3.2.4. ToNoPower Operator

Declared as **public function**

#### 3.2.4.1. Comments and Information

##### ToNoPower Comments:

§4.6.3 : Condition 29 : "The ERTMS/ETCS on -board equipment is not powered".

#### 3.2.4.2. Interface

Table 18: Inputs of ToNoPower

Name	Type	Comments and Information
OnBoard_Powered	bool	

Table 19: Outputs of ToNoPower

Name	Type	Comments and Information
Condition29	bool	

#### 3.2.4.3. Operator Hierarchy

diagram : diagram\_ToNoPower\_1

### 3.2.4.4. Graphical and Textual Diagrams

#### 3.2.4.4.1. View of diagram\_ToNoPower\_1 (ToNoPower)




Figure 8: View of diagram\_ToNoPower\_1 (ToNoPower)

### 3.2.5. ToPassiveShunting Operator

Declared as **public function**

#### 3.2.5.1. Comments and Information

##### ToPassiveShunting Comments:

§4.6.3 : Condition 26 : "desks are closed AND "continue shunting on desk closure" function is active AND the "passive shunting" input signal is active"

### 3.2.5.2. Interface

**Table 20: Inputs of ToPassiveShunting**

Name	Type	Comments and Information
Train_Permitted_PS	bool	
Continue_Shunting_Function_Active	bool	
Desks_Closed	bool	

**Table 21: Outputs of ToPassiveShunting**


Name	Type	Comments and Information
Condition26	bool	

### 3.2.5.3. Operator Hierarchy

diagram : diagram\_ToPassiveShunting\_1

### 3.2.5.4. Graphical and Textual Diagrams

#### 3.2.5.4.1. View of diagram\_ToPassiveShunting\_1 (ToPassiveShunting)



**Figure 9: View of diagram\_ToPassiveShunting\_1 (ToPassiveShunting)**

### 3.2.6. ToShunting Operator

Declared as **public node**

#### 3.2.6.1. Interface

**Table 22: Inputs of ToShunting**

Name	Type	Comments and Information
Current_Level	M_LEVEL	
Current_Mode	Level_And_Mode_Type s_Pkg::T_Mode	
Desk_Open	bool	
Driver_Ack_SH	bool	
Driver_Req_SH	bool	
Mode_Profile_On_Board	Level_And_Mode_Type s_Pkg::T_Mode_Profile	
On_Going_Mission	bool	
Shunting_Granted_By_RBC	bool	

Name	Type	Comments and Information
Stop_Shunting_Stored	bool	
Train_Position	TrainPosition_Types_Pck::trainPosition_T	
Train_Speed	Obu_BasicTypes_Pkg::Speed_T	
Train_Standstill	bool	

**Table 23: Outputs of ToShunting**

Name	Type	Comments and Information
Condition5	bool	
Condition6	bool	
Condition23	bool	
Condition50	bool	
Condition51	bool	
Condition61	bool	
Ack_SH_Req_To_Driver	bool	
Clean_BG_List_SH_Area	bool	
End_Of_Mission_Procedure_Req	bool	
Request_For_SH_To_RBC	bool	
Service_Brake_Command	bool	
SH_refused_By_RBC_To_DMI	bool	

### 3.2.6.2. Operator Hierarchy

diagram : diagram\_ToShunting\_1

### 3.2.6.3. Graphical and Textual Diagrams

#### 3.2.6.3.1. View of diagram\_ToShunting\_1 (ToShunting)





Figure 10: View of diagram\_ToShunting\_1 (ToShunting)

### 3.2.7. ToSleeping Operator

Declared as **public function**

#### 3.2.7.1. Comments and Information

##### ToSleeping Comments:

§4.6.3 : Condition 14 : "The sleeping input signal is received AND train is at standstill AND all desks connected to the ERTMS/ETCS on-board equipment are closed

### 3.2.7.2. Interface

**Table 24: Inputs of ToSleeping**

Name	Type	Comments and Information
All_Desks_Closed	bool	
Train_Standstill	bool	
Train_Req_SL	bool	

**Table 25: Outputs of ToSleeping**


Name	Type	Comments and Information
Condition14	bool	

### 3.2.7.3. Operator Hierarchy

diagram : diagram\_ToSleeping\_1

### 3.2.7.4. Graphical and Textual Diagrams

#### 3.2.7.4.1. View of diagram\_ToSleeping\_1 (ToSleeping)



**Figure 11: View of diagram\_ToSleeping\_1 (ToSleeping)**

### 3.2.8. ToStaffResponsible Operator

Declared as **public node**

#### 3.2.8.1. Interface

**Table 26: Inputs of ToStaffResponsible**

Name	Type	Properties		Comments and Information
Current_Level	M_LEVEL	last	M_LEVEL_Level_0	
Driver_Req_Override	bool			
Train_Speed_Under_Override_Limit	bool			
Override_Function_Active	bool			
Emergency_Stop_Message_Received	bool			

**Table 27: Outputs of ToStaffResponsible**

Name	Type	Comments and Information
Condition44	bool	
Condition45	bool	

Name	Type	Comments and Information
Condition37	bool	

### 3.2.8.2. Locals

**Table 28: Locals of ToStaffResponsible**


Name	Type	Comments and Information
Level_L1	bool	
Level_L2_L3	bool	
Level_prev_L0_LNTC	bool	

### 3.2.8.3. Operator Hierarchy

diagram : diagram\_ToOnSight1\_1

### 3.2.8.4. Graphical and Textual Diagrams

#### 3.2.8.4.1. View of diagram\_ToOnSight1\_1 (ToStaffResponsible)



**Figure 12: View of diagram\_ToOnSight1\_1 (ToStaffResponsible)**

### 3.2.9. ToStandBy Operator

Declared as **public function**

### 3.2.9.1. Comments and Information

#### **ToStandBy Comments:**

SRS-026 § 4.6.2 : C2 "(a desk is open)"

SRS-026 § 4.6.2 : C3 "(no "go sleeping" input signal is received any more) AND (train is at standstill)"

SRS-026 § 4.6.2 : C4 "The ERTMS/ETCS on-board equipment is powered."

SRS-026 § 4.6.2 : C19 "(driver selects "exit Shunting") AND (train is at standstill)."

SRS-026 § 4.6.2 : C22 "(a desk is open) AND ("Stop Shunting on desk opening" information is stored onboard)"

SRS-026 § 4.6.2 : C27 "(desks are closed) AND ("Continue Shunting on desk closure" function is not active)"

SRS-026 § 4.6.2 : C28 "(desks are closed) "

SRS-026 § 4.6.2 : C30 "(desks are closed) AND (no "passive shunting" input signal is received)"

SRS-026 § 4.6.2 : C47 "(no "non leading" input signal is received any more) AND (train is at standstill)"

### 3.2.9.2. Interface

**Table 29: Inputs of ToStandBy**

Name	Type	Comments and Information
Desk_Open	bool	
All_Desks_Closed	bool	
Train_Standstill	bool	
Train_Req_SL	bool	
OnBoard_Powered	bool	
Train_Permitted_PS	bool	
Train_Permitted_NL	bool	
Continue_Shunting_function_Active	bool	
Driver_Req_Exit_SH	bool	
Stop_Shunting_Stored	bool	
On_Going_Mission	bool	

**Table 30: Outputs of ToStandBy**

Name	Type	Properties	Comments and Information
Condition2	bool		
Condition3	bool		
Condition4	bool		
Condition19	bool		
Condition22	bool		
Condition27	bool		
Condition28	bool		
Condition30	bool		



Name	Type	Properties		Comments and Information
Condition47	bool			
End_Of_Mission_Procedure_Req	bool	default	false	

### 3.2.9.3. Operator Hierarchy

diagram : diagram\_ToStandBy\_1

### 3.2.9.4. Graphical and Textual Diagrams

#### 3.2.9.4.1. View of diagram\_ToStandBy\_1 (ToStandBy)




Figure 13: View of diagram\_ToStandBy\_1 (ToStandBy)

### 3.2.10. ToSystemFailure Operator

Declared as **public function**

#### 3.2.10.1. Comments and Information

##### ToSystemFailure Comments:

§4.6.3 : Condition 13 : "The ERTMS/ETCS on-board equipment detects a fault that affects safety".

### 3.2.10.2. Interface

**Table 31: Inputs of ToSystemFailure**

Name	Type	Comments and Information
Safety_Failure_Occured	bool	

**Table 32: Outputs of ToSystemFailure**


Name	Type	Comments and Information
Condition13	bool	

### 3.2.10.3. Operator Hierarchy

diagram : diagram\_ToSystemFailure\_1

### 3.2.10.4. Graphical and Textual Diagrams

#### 3.2.10.4.1. View of diagram\_ToSystemFailure\_1 (ToSystemFailure)



**Figure 14: View of diagram\_ToSystemFailure\_1 (ToSystemFailure)**

### 3.2.11. ToSystemNational Operator

Declared as **public node**

#### 3.2.11.1. Comments and Information

**ToSystemNational Comments:**

SRS-026 § 4.6.2 : C56 "(the ERTMS/ETCS level switches to "NTC")"

### 3.2.11.2. Interface

**Table 33: Inputs of ToSystemNational**

Name	Type	Properties		Comments and Information
Current_Level	M_LEVEL	last	M_LEVEL_Level_0	

**Table 34: Outputs of ToSystemNational**


Name	Type	Comments and Information
Condition56	bool	

### 3.2.11.3. Operator Hierarchy

diagram : diagram\_ToSystemNational1\_1

### 3.2.11.4. Graphical and Textual Diagrams

#### 3.2.11.4.1. View of diagram\_ToSystemNational1\_1 (ToSystemNational)



**Figure 15: View of diagram\_ToSystemNational1\_1 (ToSystemNational)**

### 3.2.12. ToTrip Operator

Declared as **public node**

#### 3.2.12.1. Interface

**Table 35: Inputs of ToTrip**

Name	Type	Properties		Comments and Information
BG_In_Expected_List_In_SH	bool			
BG_In_Expected_List_In_SR	bool			
Current_Level	M_LEVEL	last	M_LEVEL_Level_0	
Current_Mode	Level_And_Mode_Types_Pkg::T_Mode			
Driver_Select_SH	bool			
Emergency_Stop_Message_Received	bool			
Error_BG_System_Version	bool			
Estimated_Front_End_Overpass_SR_Distance	bool			
Estimated_Front_End_Rear_Location_SSP_Or_Gradient	bool			
Interface_To_National_System	bool			
Linked_BG_Pased_In_Wrong_Direction	bool			
Linking_Reaction_To_Trip	bool			
List_BG_Related_To_SR_Empty	bool			
MA_Available	bool			
National_Trip_Order	bool			
Override_Function_Active	bool			
Override_Function_Former_Active	bool			
Stop_If_In_Shunting	bool			
Stop_If_In_SR	bool			

Name	Type	Properties	Comments and Information
T_NVCONTACT_Overpass	bool		
Train_Overpass_EOA_Antenna	bool		
Train_Overpass_EOA_Front_End	bool		
Train_Overpass_Former_EOA_Antenna	bool		
Trip_Order_Given_By_Balise	bool		
TripModeFromLevel	bool		

**Table 36: Outputs of ToTrip**

Name	Type	Comments and Information
Condition2Trip	bool	

### 3.2.12.2. Locals

**Table 37: Locals of ToTrip**

Name	Type	Comments and Information
Condition12	bool	
Condition16	bool	
Condition17	bool	
Condition18	bool	
Condition20	bool	
Condition35	bool	
Condition36	bool	
Condition38	bool	
Condition39	bool	
Condition41	bool	
Condition42	bool	
Condition43	bool	
Condition49	bool	
Condition52	bool	
Condition54	bool	
Condition65	bool	
Condition66	bool	
Condition67	bool	
Condition69	bool	
Level_L1	bool	
Level_L1_L2_L3	bool	
Level_L2_L3	bool	
Level_LNTC	bool	
Level_prev_L0_LNTC	bool	

Name	Type	Comments and Information
Level_prev_L1	bool	
Mode_FS_LS_OS	bool	
Mode_SH	bool	
Mode_SN	bool	
Mode_SR	bool	
Mode_UN	bool	

### 3.2.12.3. Operator Hierarchy

diagram : diagram\_ToTrip\_1

### 3.2.12.4. Graphical and Textual Diagrams

#### 3.2.12.4.1. View of diagram\_ToTrip\_1 (ToTrip)




Figure 16: View of diagram\_ToTrip\_1 (ToTrip)

### 3.2.13. ToUnfitted Operator

Declared as **public node**

#### 3.2.13.1. Comments and Information

##### ToUnfitted Comments:

SRS-026 § 4.6.2 : C21 "(the ERTMS/ETCS level switches to 0"

#### 3.2.13.2. Interface

**Table 38: Inputs of ToUnfitted**

Name	Type	Properties		Comments and Information
Current_Level	M_LEVEL	last	M_LEVEL_Level_0	

**Table 39: Outputs of ToUnfitted**


Name	Type	Comments and Information
Condition21	bool	

#### 3.2.13.3. Operator Hierarchy

diagram : diagram\_ToUnfitted\_1

#### 3.2.13.4. Graphical and Textual Diagrams

##### 3.2.13.4.1. View of diagram\_ToUnfitted\_1 (ToUnfitted)



**Figure 17: View of diagram\_ToUnfitted\_1 (ToUnfitted)**

## 3.3. Interfaces Package

### 3.3.1. InputDMI Operator

Declared as **public function**

#### 3.3.1.1. Interface

**Table 40: Inputs of InputDMI**

Name	Type	Comments and Information
Data_From_DMI	Level_And_Mode_Type s_Pkg::T_Data_From_DMI	

**Table 41: Outputs of InputDMI**

Name	Type	Comments and Information
Driver_Ack_LS	bool	
Driver_Ack_OS	bool	
Driver_Ack_RV	bool	
Driver_Ack_SH	bool	
Driver_Ack_SN	bool	
Driver_Ack_SR	bool	
Driver_Ack_TR	bool	
Driver_Ack_UN	bool	
Driver_Req_Exit_SH	bool	
Driver_Req_NL	bool	
Driver_Req_Override	bool	
Driver_Req_SH	bool	
Driver_Req_Start	bool	
ETCS_Isolated	bool	

### 3.3.1.2. Operator Hierarchy

diagram : diagram\_Operator5\_1

### 3.3.1.3. Graphical and Textual Diagrams

#### 3.3.1.3.1. View of diagram\_Operator5\_1 (InputDMI)



**Figure 18: View of diagram\_Operator5\_1 (InputDMI)**

### 3.3.2. InputF2Functions Operator

Declared as **public function**

#### 3.3.2.1. Interface

**Table 42: Inputs of InputF2Functions**

Name	Type	Comments and Information
Data_From_F2_Functions	Level_And_Mode_Types_Pkg::T_Data_From_F2_functions	

**Table 43: Outputs of InputF2Functions**


Name	Type	Comments and Information
T_NVCONTACT_Overpass	bool	
Error_BG_System_Version	bool	
Failure_Occured	bool	
Continue_Shunting_Function_Active	bool	
Stop_Shunting_Stored	bool	
Linking_Reaction_To_Trip	bool	

#### 3.3.2.2. Operator Hierarchy

diagram : diagram\_InputF2Functions\_1

#### 3.3.2.3. Graphical and Textual Diagrams

##### 3.3.2.3.1. View of diagram\_InputF2Functions\_1 (InputF2Functions)



**Figure 19: View of diagram\_InputF2Functions\_1 (InputF2Functions)**



### 3.3.3. InputLocalisation Operator

Declared as **public function**

#### 3.3.3.1. Interface

**Table 44: Inputs of InputLocalisation**

Name	Type	Comments and Information
Data_From_Localisation	Level_And_Mode_Type s_Pkg::T_Data_From_Localisation	

**Table 45: Outputs of InputLocalisation**


Name	Type	Comments and Information
BG_In_Expected_List_In_SR	bool	
BG_In_Expected_List_In_SH	bool	
Linked_BG_Pased_In_Wrong_Direction	bool	
Train_Position	TrainPosition_Types_Pc k::trainPosition_T	
Train_Speed	Obu_BasicTypes_Pkg:: Speed_T	
Train_Standstill	bool	

#### 3.3.3.2. Operator Hierarchy

diagram : diagram\_InputSpeedAndSupervision1\_1

#### 3.3.3.3. Graphical and Textual Diagrams

##### 3.3.3.3.1. View of diagram\_InputSpeedAndSupervision1\_1 (InputLocalisation)



**Figure 20: View of diagram\_InputSpeedAndSupervision1\_1 (InputLocalisation)**

### 3.3.4. InputSpeedAndSupervision Operator

Declared as **public function**

### 3.3.4.1. Interface

**Table 46: Inputs of InputSpeedAndSupervision**

Name	Type	Comments and Information
Data_From_Speed_and_Supervision	Level_And_Mode_Type s_Pkg::T_Data_From_Speed_Supervision	

**Table 47: Outputs of InputSpeedAndSupervision**


Name	Type	Comments and Information
Estimated_Front_End_Overpass_SR_Distance	bool	
Estimated_Front_End_Rear_Location_SSP_Or_Gradient	bool	
Override_Function_Active	bool	
Train_Overpass_EOA_Antenna	bool	
Train_Overpass_EOA_Front_End	bool	
Train_Speed_Under_Override_Limit	bool	

### 3.3.4.2. Operator Hierarchy

diagram : diagram\_InputSpeedAndSupervision\_1

### 3.3.4.3. Graphical and Textual Diagrams

#### 3.3.4.3.1. View of diagram\_InputSpeedAndSupervision\_1 (InputSpeedAndSupervision)



**Figure 21: View of diagram\_InputSpeedAndSupervision\_1 (InputSpeedAndSupervision)**

### 3.3.5. InputSTM Operator

Declared as **public function**

#### 3.3.5.1. Interface

**Table 48: Inputs of InputSTM**

Name	Type	Comments and Information
Data_From_STM	Level_And_Mode_Type s_Pkg::T_Data_From_ STM	

**Table 49: Outputs of InputSTM**


Name	Type	Comments and Information
Interface_To_National_ System	bool	
National_Trip_Order	bool	

#### 3.3.5.2. Operator Hierarchy

diagram : diagram\_InputSTM\_1

#### 3.3.5.3. Graphical and Textual Diagrams

##### 3.3.5.3.1. View of diagram\_InputSTM\_1 (InputSTM)



**Figure 22: View of diagram\_InputSTM\_1 (InputSTM)**

### 3.3.6. InputTIUManagement Operator

Declared as **public function**

#### 3.3.6.1. Comments and Information

**InputTIUManagement Comments:**

What are the default values for the location if the train position is not valid ?  
Do we use the last value or a default value ?

#### 3.3.6.2. Interface

**Table 50: Inputs of InputTIUManagement**

Name	Type	Comments and Information
Data_from_TIU	TIU_Types_Pkg::Messa ge_Train_Interface_to_ EVC_T	

Name	Type	Comments and Information
Cab	TIU_Types_Pkg::cab_ID_T	

**Table 51: Outputs of InputTIUManagement**

Name	Type	Comments and Information
Train_Permitted_NL	bool	
Train_Permitted_PS	bool	
Train_Req_SL	bool	
All_Desks_Closed	bool	
Desk_Open	bool	
OnBoard_Powered	bool	
Valid_Train_Data_Stored	bool	

### 3.3.6.3. Locals

**Table 52: Locals of InputTIUManagement**

Name	Type	Comments and Information
Loc_Cab_ST	TIU_Types_Pkg::M_cab_signal_status_T	
Loc_NL_ST	TIU_Types_Pkg::M_noleading_signal_status_T	
Loc_PS_ST	TIU_Types_Pkg::M_passiveshunting_signal_status_T	
Loc_Sleeping_ST	TIU_Types_Pkg::M_sleeping_signal_status_T	

### 3.3.6.4. Operator Hierarchy

diagram : diagram\_InputTIUManagement\_1

### 3.3.6.5. Graphical and Textual Diagrams

#### 3.3.6.5.1. View of diagram\_InputTIUManagement\_1 (InputTIUManagement)




Figure 23: View of diagram\_InputTIUManagement\_1 (InputTIUManagement)

### 3.3.7. InputTrackManagement Operator Declared as **public function**

### 3.3.7.1. Interface

**Table 53: Inputs of InputTrackManagement**

Name	Type	Comments and Information
Data_From_Track	Level_And_Mode_Type s_Pkg::T_Data_From_Track_To_Mode	

**Table 54: Outputs of InputTrackManagement**

Name	Type	Comments and Information
MA_SSP_Gradient_Available	bool	
Mode_Profile_On_Board	Level_And_Mode_Type s_Pkg::T_Mode_Profile	
Shunting_Granted_By_RBC	bool	
Trip_Order_Given_By_Balise	bool	
List_BG_Related_To_S R_Empty	bool	
Stop_If_In_Shunting	bool	
Stop_If_In_SR	bool	
RCB_Ack_And_EB_Revoked	bool	
RBC_Authorized_SR	bool	
Reversing_Data	Level_And_Mode_Type s_Pkg::T_Reversing_Data	
Emergency_Stop_Message_Received	bool	

### 3.3.7.2. Operator Hierarchy

diagram : diagram\_InputTrackManagement\_1

### 3.3.7.3. Graphical and Textual Diagrams

#### 3.3.7.3.1. View of diagram\_InputTrackManagement\_1 (InputTrackManagement)




Figure 24: View of diagram\_InputTrackManagement\_1 (InputTrackManagement)

### 3.3.8. Output\_To\_BG\_Management Operator

Declared as **public function**

#### 3.3.8.1. Interface

Table 55: Inputs of Output\_To\_BG\_Management

Name	Type	Comments and Information
End_Of_Mission_Procedure_Req	bool	
Clean_BG_List_SH_Area	bool	
MA_Req_To_RBC	bool	
Request_For_SH_To_RBC	bool	

Table 56: Outputs of Output\_To\_BG\_Management

Name	Type	Comments and Information
Data_To_BG_Management	Level_And_Mode_Types_Pkg::T_Data_To_BG_Management	

#### 3.3.8.2. Operator Hierarchy

diagram : diagram\_Output\_To\_BG\_Management\_1

### 3.3.8.3. Graphical and Textual Diagrams

#### 3.3.8.3.1. View of diagram\_Output\_To\_BG\_Management\_1 (Output\_To\_BG\_Management)




Figure 25: View of diagram\_Output\_To\_BG\_Management\_1 (Output\_To\_BG\_Management)

### 3.3.9. Output\_To\_DMI Operator

Declared as **public function**

#### 3.3.9.1. Interface

Table 57: Inputs of Output\_To\_DMI

Name	Type	Comments and Information
Ack_LS_Req_To_Driver	bool	
Ack_OS_Req_To_Driver	bool	
Ack_RV_Req_To_Driver	bool	
Ack_SH_Req_To_Driver	bool	
Ack_SN_Req_To_Driver	bool	
Ack_SR_Req_To_Driver	bool	
Ack_TR_Req_To_Driver	bool	
Ack_UN_Req_To_Driver	bool	
SH_Refused_By_RBC_To_DMI	bool	

Table 58: Outputs of Output\_To\_DMI

Name	Type	Comments and Information
Data_To_DMI	Level_And_Mode_Type s_Pkg::T_Data_To_DM I	



### 3.3.9.2. Operator Hierarchy

diagram : diagram\_Output\_To\_DMI\_1

### 3.3.9.3. Graphical and Textual Diagrams

#### 3.3.9.3.1. View of diagram\_Output\_To\_DMI\_1 (Output\_To\_DMI)



Figure 26: View of diagram\_Output\_To\_DMI\_1 (Output\_To\_DMI)

### 3.3.10. OutputManagement Operator

Declared as **public function**

#### 3.3.10.1. Interface

Table 59: Inputs of OutputManagement

Name	Type	Comments and Information
current_Mode	Level_And_Mode_Type s_Pkg::T_Mode	
Ack_LS_Req_To_Driver	bool	
Ack_OS_Req_To_Driver	bool	
Ack_RV_Req_To_Driver	bool	
Ack_SH_Req_To_Driver	bool	
Ack_SN_Req_To_Driver	bool	
Ack_SR_Req_To_Driver	bool	
Ack_TR_Req_To_Driver	bool	
Ack_UN_Req_To_Driver	bool	
Clean_BG_List_SH_Area	bool	
EB_requested	bool	

Name	Type	Comments and Information
End_Of_Mission_Procedure_Req	bool	
MA_Req_to_RBC	bool	
Request_For_SH_To_RBC	bool	
service_brake_Command	bool	
SH_Refused_by_RBC_To_DMI	bool	

**Table 60: Outputs of OutputManagement**

Name	Type	Comments and Information
Data_To_DMI	Level_And_Mode_Types_Pkg::T_Data_To_DMI	
Data_To_BG_Management	Level_And_Mode_Types_Pkg::T_Data_To_BG_Management	
EB_Requested	bool	
Service_Brake_Command	bool	
newMode	Level_And_Mode_Types_Pkg::T_Mode	

### 3.3.10.2. Operator Hierarchy

diagram : diagram\_Operator48\_1

### 3.3.10.3. Graphical and Textual Diagrams

#### 3.3.10.3.1. View of diagram\_Operator48\_1 (OutputManagement)




Figure 27: View of diagram\_Operator48\_1 (OutputManagement)

## 3.4. Libraries Package

### 3.4.1. Mode\_Profile\_Calculations Operator

Declared as **public function**

#### 3.4.1.1. Interface

Table 61: Inputs of Mode\_Profile\_Calculations

Name	Type	Comments and Information
Selected_Mode	Level_And_Mode_Type s_Pkg::T_Mode	
Mode_Profile_On_Board	Level_And_Mode_Type s_Pkg::T_Mode_Profile	
Profile_Mode	Level_And_Mode_Type s_Pkg::T_MA	
Train_Speed	Obu_BasicTypes_Pkg:: Speed_T	
Train_Position	TrainPosition_Types_Pc k::trainPosition_T	

Table 62: Outputs of Mode\_Profile\_Calculations

Name	Type	Comments and Information
Max_Safe_Front_In_Mode_Profile	bool	
Supervision_Condition_In_Mode_Profile	bool	

Name	Type	Comments and Information
Awaited_Mode_Profile	bool	
Estimated_front_End_In_Ack_Area	bool	

#### 3.4.1.2. Locals

**Table 63: Locals of Mode\_Profile\_Calculations**

Name	Type	Comments and Information
Condition_Loc	bool	
Condition_Ok	bool	
Estimated_Front_End	Obu_BasicTypes_Pkg::Location_T	
Loc_MP_Distance	Obu_BasicTypes_Pkg::Location_T	
Loc_MP_Length	Obu_BasicTypes_Pkg::Location_T	
Loc_MP_Length_Ack	Obu_BasicTypes_Pkg::Location_T	
Loc_MP_Mode	Level_And_Mode_Types_Pkg::T_MA	
Loc_MP_Speed	Obu_BasicTypes_Pkg::Speed_T	
Max_Safe_Front_End	Obu_BasicTypes_Pkg::Location_T	
Valid_Train_Position	bool	

#### 3.4.1.3. Operator Hierarchy

diagram : diagram\_Operator7\_1

```
    activate if : IfBlock2
      branch : then
      branch : else
        branch : then
        branch : else
          branch : then
          branch : else
```

### 3.4.1.4. Graphical and Textual Diagrams

#### 3.4.1.4.1. View of diagram\_Operator7\_1 (Mode\_Profile\_Calculations)




Figure 28: View of diagram\_Operator7\_1 (Mode\_Profile\_Calculations)

Table 64: Conditional Blocks of diagram\_Operator7\_1

Conditional Block	Comments and Information
IfBlock2	

Table 65: Actions of diagram\_Operator7\_1

Conditional Block Action	Comments and Information
IfBlock2:then	
IfBlock2:else:then	
IfBlock2:else:else:then	
IfBlock2:else:else:else	

### 3.4.2. Position\_In\_Ack\_Area Operator

Declared as **public function**

#### 3.4.2.1. Interface

Table 66: Inputs of Position\_In\_Ack\_Area

Name	Type	Comments and Information
Position	Obu_BasicTypes_Pkg::Location_T	
D_Area	Obu_BasicTypes_Pkg::Location_T	
L_Ack_Area	Obu_BasicTypes_Pkg::Location_T	

**Table 67: Outputs of Position\_In\_Ack\_Area**


Name	Type	Comments and Information
Position_In_Ack_Area	bool	

### 3.4.2.2. Operator Hierarchy

diagram : diagram\_Position\_In\_Ack\_Area\_1

### 3.4.2.3. Graphical and Textual Diagrams

#### 3.4.2.3.1. View of diagram\_Position\_In\_Ack\_Area\_1 (Position\_In\_Ack\_Area)



**Figure 29: View of diagram\_Position\_In\_Ack\_Area\_1 (Position\_In\_Ack\_Area)**

### 3.4.3. Position\_In\_Area Operator

Declared as **public function**

#### 3.4.3.1. Interface

**Table 68: Inputs of Position\_In\_Area**

Name	Type	Comments and Information
Position	Obu_BasicTypes_Pkg::Location_T	
D_Area	Obu_BasicTypes_Pkg::Location_T	
L_Area	Obu_BasicTypes_Pkg::Location_T	

**Table 69: Outputs of Position\_In\_Area**

Name	Type	Comments and Information
Position_In_Area	bool	

### 3.4.3.2. Operator Hierarchy

diagram : diagram\_Position\_In\_Area\_1

### 3.4.3.3. Graphical and Textual Diagrams

#### 3.4.3.3.1. View of diagram\_Position\_In\_Area\_1 (Position\_In\_Area)




Figure 30: View of diagram\_Position\_In\_Area\_1 (Position\_In\_Area)

### 3.4.4. Reversing\_Calculations Operator

Declared as **public function**

#### 3.4.4.1. Interface

Table 70: Inputs of Reversing\_Calculations

Name	Type	Comments and Information
Reversing_Data	Level_And_Mode_Type s_Pkg::T_Reversing_Data	
Train_Position	TrainPosition_Types_Pc k::trainPosition_T	

Table 71: Outputs of Reversing\_Calculations

Name	Type	Comments and Information
Max_Safe_Front_In_Re verse_Area	bool	
RV_Data_Available	bool	

#### 3.4.4.2. Locals

Table 72: Locals of Reversing\_Calculations

Name	Type	Comments and Information
Loc_RV_Available	bool	
Loc_RV_Dist_Start	Obu_BasicTypes_Pkg:: Location_T	
Loc_RV_Length	Obu_BasicTypes_Pkg:: Location_T	
Max_Safe_Front_End	Obu_BasicTypes_Pkg:: Location_T	
Valid_Train_Position	bool	

#### 3.4.4.3. Operator Hierarchy

diagram : diagram\_Operator7\_1

### 3.4.4.4. Graphical and Textual Diagrams

#### 3.4.4.4.1. View of diagram\_Operator7\_1 (Reversing\_Calculations)



Figure 31: View of diagram\_Operator7\_1 (Reversing\_Calculations)

## 3.5. PriorityManagement Package

### 3.5.1. From\_FS Operator

Declared as **public function**

#### 3.5.1.1. Interface

Table 73: Inputs of From\_FS

Name	Type	Comments and Information
Condition1	bool	
Condition5	bool	
Condition6	bool	
Condition13	bool	
Condition15	bool	
Condition21	bool	
Condition28	bool	
Condition29	bool	
Condition37	bool	
Condition40	bool	
Condition46	bool	
Condition50	bool	
Condition51	bool	
Condition56	bool	
Condition59	bool	
Condition70	bool	
Condition72	bool	
ConditionFS2TR	bool	
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	



Table 74: Outputs of From\_FS

Name	Type	Comments and Information
FromFS_To_NewMode	Level_And_Mode_Type s_Pkg::T_Mode	

### 3.5.1.2. Locals

Table 75: Locals of From\_FS

Name	Type	Comments and Information
Condition2LS	bool	
Condition2OS	bool	
Condition2SH	bool	

### 3.5.1.3. Operator Hierarchy

diagram : diagram\_From\_FS

*activate if* : IfBlock1

        branch : then

        branch : else

            branch : then

            branch : else

                branch : then

                branch : else

                    branch : then

                    branch : else

                        branch : then

                        branch : else

                            branch : then

                            branch : else

                                branch : then

                                branch : else

                                    branch : then

                                    branch : else

  branch : then

  branch : else

  branch : then

  branch : else

  branch :

then

branch :

else

branch : then

branch : else

branch : then

branch : else

### 3.5.1.4. Graphical and Textual Diagrams

#### 3.5.1.4.1. View of diagram\_From\_FS (From\_FS)



Figure 32: View of diagram\_From\_FS (From\_FS)

Table 76: Conditional Blocks of diagram\_From\_FS

Conditional Block	Comments and Information
IfBlock1	

Table 77: Actions of diagram\_From\_FS

Conditional Block Action	Comments and Information
IfBlock1:then	
IfBlock1:else:then	
IfBlock1:else:else:then	
IfBlock1:else:else:else:then	
IfBlock1:else:else:else:else:then	
IfBlock1:else:else:else:else:else:then	

Conditional Block Action	Comments and Information
IfBlock1:else:else:else:else:else:else:the n	
IfBlock1:else:else:else:else:else:else:else :then	
IfBlock1:else:else:else:else:else:else:else :else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:else:else:else	

### 3.5.2. From\_LS Operator

Declared as **public function**

#### 3.5.2.1. Interface

**Table 78: Inputs of From\_LS**

Name	Type	Comments and Information
Condition1	bool	
Condition5	bool	
Condition6	bool	
Condition13	bool	
Condition15	bool	
Condition21	bool	
Condition28	bool	
Condition29	bool	
Condition31	bool	
Condition32	bool	
Condition37	bool	
Condition46	bool	
Condition50	bool	
Condition51	bool	
Condition56	bool	
Condition59	bool	
Condition73	bool	
ConditionLS2TR	bool	
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	

**Table 79: Outputs of From\_LS**

Name	Type	Comments and Information
FromLS_To_NewMode	Level_And_Mode_Type s_Pkg::T_Mode	

### 3.5.2.2. Locals

**Table 80: Locals of From\_LS**

Name	Type	Comments and Information
Condition2FS	bool	
Condition2OS	bool	
Condition2SH	bool	

### 3.5.2.3. Operator Hierarchy

diagram : diagram\_From\_LS

*activate if* : IfBlock1

branch : then

branch : else

branch : then

branch : else

branch : then

branch : else

branch : then

branch : else

branch : then

branch : else

branch : then

branch : else

branch : then

branch : else

branch : then

branch : else

branch : then

branch : else

branch : then

branch : else

branch :

then

branch :

else

branch : then

branch : else

branch : then

branch : else

### 3.5.2.4. Graphical and Textual Diagrams

#### 3.5.2.4.1. View of diagram\_From\_LS (From\_LS)




Figure 33: View of diagram\_From\_LS (From\_LS)

Table 81: Conditional Blocks of diagram\_From\_LS

Conditional Block	Comments and Information
IfBlock1	

Table 82: Actions of diagram\_From\_LS

Conditional Block Action	Comments and Information
IfBlock1:then	
IfBlock1:else:then	
IfBlock1:else:else:then	
IfBlock1:else:else:else:then	
IfBlock1:else:else:else:else:then	
IfBlock1:else:else:else:else:else:then	

Conditional Block Action	Comments and Information
IfBlock1:else:else:else:else:else:else:the n	
IfBlock1:else:else:else:else:else:else:else :then	
IfBlock1:else:else:else:else:else:else:else :else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:else:else:else	

### 3.5.3. From\_NL Operator

Declared as **public function**

#### 3.5.3.1. Interface

**Table 83: Inputs of From\_NL**

Name	Type	Comments and Information
Condition1	bool	
Condition28	bool	
Condition29	bool	
Condition47	bool	
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	

**Table 84: Outputs of From\_NL**

Name	Type	Comments and Information
FromNL_To_NewMode	Level_And_Mode_Type s_Pkg::T_Mode	

#### 3.5.3.2. Operator Hierarchy

diagram : diagram\_From\_NL

```

activate if : IfBlock1
  branch : then
  branch : else
    branch : then
    branch : else
      branch : then
      branch : else

```

### 3.5.3.3. Graphical and Textual Diagrams

#### 3.5.3.3.1. View of diagram\_From\_NL (From\_NL)




Figure 34: View of diagram\_From\_NL (From\_NL)

Table 85: Conditional Blocks of diagram\_From\_NL

Conditional Block	Comments and Information
IfBlock1	

Table 86: Actions of diagram\_From\_NL

Conditional Block Action	Comments and Information
IfBlock1:then	
IfBlock1:else:then	
IfBlock1:else:else:then	
IfBlock1:else:else:else	

### 3.5.4. From\_NP Operator

Declared as **public function**

#### 3.5.4.1. Interface

Table 87: Inputs of From\_NP

Name	Type	Comments and Information
Condition1	bool	
Condition4	bool	
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	

Table 88: Outputs of From\_NP

Name	Type	Comments and Information
FromNP_To_NewMode	Level_And_Mode_Type s_Pkg::T_Mode	

### 3.5.4.2. Operator Hierarchy

diagram : diagram\_From\_NP

activate if : IfBlock1

branch : then

branch : else

branch : then

branch : else

### 3.5.4.3. Graphical and Textual Diagrams

#### 3.5.4.3.1. View of diagram\_From\_NP (From\_NP)




Figure 35: View of diagram\_From\_NP (From\_NP)

Table 89: Conditional Blocks of diagram\_From\_NP

Conditional Block	Comments and Information
IfBlock1	

Table 90: Actions of diagram\_From\_NP

Conditional Block Action	Comments and Information
IfBlock1:then	
IfBlock1:else:then	
IfBlock1:else:else	

### 3.5.5. From\_OS Operator

Declared as **public function**

#### 3.5.5.1. Interface

Table 91: Inputs of From\_OS

Name	Type	Comments and Information
Condition1	bool	
Condition5	bool	
Condition6	bool	
Condition13	bool	



Name	Type	Comments and Information
Condition21	bool	
Condition28	bool	
Condition29	bool	
Condition31	bool	
Condition32	bool	
Condition37	bool	
Condition46	bool	
Condition50	bool	
Condition51	bool	
Condition56	bool	
Condition59	bool	
Condition70	bool	
Condition74	bool	
ConditionOS2TR	bool	
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	

**Table 92: Outputs of From\_OS**

Name	Type	Comments and Information
FromOS_To_NewMode	Level_And_Mode_Type s_Pkg::T_Mode	

### 3.5.5.2. Locals

**Table 93: Locals of From\_OS**

Name	Type	Comments and Information
Condition2FS	bool	
Condition2LS	bool	
Condition2SH	bool	

### 3.5.5.3. Operator Hierarchy

diagram : diagram\_From\_OS

activate if : IfBlock1

branch : then

branch : else

branch : then

branch : else

branch : then

branch : else

branch : then

branch : else

branch : then

branch : else

branch : then

branch : else

```

                                branch : then
                                branch : else
                                    branch : then
                                    branch : else
                                        branch : then
                                        branch : else
                                            branch :
then
                                branch :
else
                                branch :
branch : then
branch : else
branch : then
branch : else
```

### 3.5.5.4. Graphical and Textual Diagrams

#### 3.5.5.4.1. View of diagram\_From\_OS (From\_OS)





Figure 36: View of diagram\_From\_OS (From\_OS)

Table 94: Conditional Blocks of diagram\_From\_OS

Conditional Block	Comments and Information
IfBlock1	

Table 95: Actions of diagram\_From\_OS

Conditional Block Action	Comments and Information
IfBlock1:then	

Conditional Block Action	Comments and Information
IfBlock1:else:then	
IfBlock1:else:else:then	
IfBlock1:else:else:else:then	
IfBlock1:else:else:else:else:then	
IfBlock1:else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:the n	
IfBlock1:else:else:else:else:else:else:else :then	
IfBlock1:else:else:else:else:else:else:else :else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:else:else:else	

### 3.5.6. From\_PS Operator

Declared as **public function**

#### 3.5.6.1. Interface

**Table 96: Inputs of From\_PS**

Name	Type	Comments and Information
Condition1	bool	
Condition13	bool	
Condition14	bool	
Condition22	bool	
Condition23	bool	
Condition29	bool	
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	

**Table 97: Outputs of From\_PS**

Name	Type	Comments and Information
FromPS_To_NewMode	Level_And_Mode_Type s_Pkg::T_Mode	

#### 3.5.6.2. Operator Hierarchy

diagram : diagram\_From\_PS

activate if : IfBlock1

branch : then

```

branch : else
  branch : then
  branch : else
    branch : then
    branch : else
      branch : then
      branch : else
        branch : then
        branch : else

```

### 3.5.6.3. Graphical and Textual Diagrams

#### 3.5.6.3.1. View of diagram\_From\_PS (From\_PS)




Figure 37: View of diagram\_From\_PS (From\_PS)

Table 98: Conditional Blocks of diagram\_From\_PS

Conditional Block	Comments and Information
IfBlock1	

Table 99: Actions of diagram\_From\_PS

Conditional Block Action	Comments and Information
IfBlock1:then	
IfBlock1:else:then	
IfBlock1:else:else:then	
IfBlock1:else:else:else:then	
IfBlock1:else:else:else:else:then	
IfBlock1:else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else	

### 3.5.7. From\_PT Operator

Declared as **public function**

#### 3.5.7.1. Interface

**Table 100: Inputs of From\_PT**

Name	Type	Comments and Information
Condition1	bool	
Condition5	bool	
Condition6	bool	
Condition8	bool	
Condition13	bool	
Condition15	bool	
Condition28	bool	
Condition29	bool	
Condition31	bool	
Condition37	bool	
Condition50	bool	
Condition70	bool	
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	

**Table 101: Outputs of From\_PT**

Name	Type	Comments and Information
FromPT_To_NewMode	Level_And_Mode_Type s_Pkg::T_Mode	

#### 3.5.7.2. Locals

**Table 102: Locals of From\_PT**

Name	Type	Comments and Information
Condition2SH	bool	
Condition2SR	bool	

#### 3.5.7.3. Operator Hierarchy

diagram : diagram\_From\_PT

*activate if* : IfBlock1

        branch : then

        branch : else

            branch : then

            branch : else

                branch : then

                branch : else

                    branch : then

                    branch : else

                        branch : then


```

branch : else
  branch : then
    branch : else
      branch : then
        branch : else
          branch : then
            branch : else

```

### 3.5.7.4. Graphical and Textual Diagrams

#### 3.5.7.4.1. View of diagram\_From\_PT (From\_PT)



**Figure 38: View of diagram\_From\_PT (From\_PT)**

**Table 103: Conditional Blocks of diagram\_From\_PT**

Conditional Block	Comments and Information
IfBlock1	

**Table 104: Actions of diagram\_From\_PT**

Conditional Block Action	Comments and Information
IfBlock1:then	
IfBlock1:else:then	
IfBlock1:else:else:then	
IfBlock1:else:else:else:then	
IfBlock1:else:else:else:else:then	
IfBlock1:else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:the n	
IfBlock1:else:else:else:else:else:else:else :then	
IfBlock1:else:else:else:else:else:else:else :else:then	
IfBlock1:else:else:else:else:else:else:else :else:else	

### 3.5.8. From\_RV Operator

Declared as **public function**

#### 3.5.8.1. Interface

**Table 105: Inputs of From\_RV**

Name	Type	Comments and Information
Condition1	bool	
Condition13	bool	
Condition28	bool	
Condition29	bool	
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	

**Table 106: Outputs of From\_RV**

Name	Type	Comments and Information
FromRV_To_NewMode	Level_And_Mode_Type s_Pkg::T_Mode	

#### 3.5.8.2. Operator Hierarchy

diagram : diagram\_From\_RV

*activate if* : IfBlock1

        branch : then

        branch : else

            branch : then

            branch : else



branch : then  
branch : else  
branch : then  
branch : else

### 3.5.8.3. Graphical and Textual Diagrams

#### 3.5.8.3.1. View of diagram\_From\_RV (From\_RV)




Figure 39: View of diagram\_From\_RV (From\_RV)

Table 107: Conditional Blocks of diagram\_From\_RV

Conditional Block	Comments and Information
IfBlock1	

Table 108: Actions of diagram\_From\_RV

Conditional Block Action	Comments and Information
IfBlock1:then	
IfBlock1:else:then	
IfBlock1:else:else:then	
IfBlock1:else:else:else:then	
IfBlock1:else:else:else:else	

### 3.5.9. From\_SB Operator

Declared as **public function**

#### 3.5.9.1. Interface

Table 109: Inputs of From\_SB

Name	Type	Comments and Information
Condition1	bool	
Condition5	bool	
Condition6	bool	
Condition8	bool	
Condition10	bool	

Name	Type	Comments and Information
Condition13	bool	
Condition14	bool	
Condition15	bool	
Condition29	bool	
Condition37	bool	
Condition46	bool	
Condition50	bool	
Condition58	bool	
Condition60	bool	
Condition70	bool	
ConditionSB2TR	bool	
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	

**Table 110: Outputs of From\_SB**

Name	Type	Comments and Information
FromSB_To_NewMode	Level_And_Mode_Type s_Pkg::T_Mode	

### 3.5.9.2. Locals

**Table 111: Locals of From\_SB**

Name	Type	Comments and Information
Condition2SH	bool	
Condition2SR	bool	

### 3.5.9.3. Operator Hierarchy

diagram : diagram\_From\_SB

*activate if* : IfBlock1

        branch : then

        branch : else

            branch : then

            branch : else

                branch : then

                branch : else

                    branch : then

                    branch : else

                        branch : then

                        branch : else

                            branch : then

                            branch : else

                                branch : then

                                branch : else

                                    branch : then

                                    branch : else

  branch : then

then

else

branch : then

branch : else

branch : then

branch : else

branch : else  
branch : then  
branch : else  
branch :  
  
branch :

### 3.5.9.4. Graphical and Textual Diagrams

#### 3.5.9.4.1. View of diagram\_From\_SB (From\_SB)





Figure 40: View of diagram\_From\_SB (From\_SB)

Table 112: Conditional Blocks of diagram\_From\_SB

Conditional Block	Comments and Information
IfBlock1	

Table 113: Actions of diagram\_From\_SB

Conditional Block Action	Comments and Information
IfBlock1:then	
IfBlock1:else:then	
IfBlock1:else:else:then	
IfBlock1:else:else:else:then	
IfBlock1:else:else:else:else:then	
IfBlock1:else:else:else:else:else:then	

Conditional Block Action	Comments and Information
IfBlock1:else:else:else:else:else:else:the n	
IfBlock1:else:else:else:else:else:else:else :then	
IfBlock1:else:else:else:else:else:else:else :else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:else:else:else	

### 3.5.10. From\_SF Operator

Declared as **public function**

#### 3.5.10.1. Interface

**Table 114: Inputs of From\_SF**

Name	Type	Comments and Information
Condition1	bool	
Condition29	bool	
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	

**Table 115: Outputs of From\_SF**

Name	Type	Comments and Information
FromSF_To_NewMode	Level_And_Mode_Type s_Pkg::T_Mode	

#### 3.5.10.2. Operator Hierarchy

diagram : diagram\_From\_SF

```

activate if : IfBlock1
  branch : then
  branch : else
    branch : then
    branch : else

```

### 3.5.10.3. Graphical and Textual Diagrams

#### 3.5.10.3.1. View of diagram\_From\_SF (From\_SF)




Figure 41: View of diagram\_From\_SF (From\_SF)

Table 116: Conditional Blocks of diagram\_From\_SF

Conditional Block	Comments and Information
IfBlock1	

Table 117: Actions of diagram\_From\_SF

Conditional Block Action	Comments and Information
IfBlock1:then	
IfBlock1:else:then	
IfBlock1:else:else	

### 3.5.11. From\_SH Operator

Declared as **public function**

#### 3.5.11.1. Interface

Table 118: Inputs of From\_SH

Name	Type	Comments and Information
Condition1	bool	
Condition13	bool	
Condition19	bool	
Condition26	bool	
Condition27	bool	
Condition29	bool	
Condition30	bool	
Condition46	bool	
ConditionSH2TR	bool	
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	

**Table 119: Outputs of From\_SH**

Name	Type	Comments and Information
FromSH_To_NewMode	Level_And_Mode_Type s_Pkg::T_Mode	

### 3.5.11.2. Locals

**Table 120: Locals of From\_SH**

Name	Type	Comments and Information
Condition2SB	bool	

### 3.5.11.3. Operator Hierarchy

diagram : diagram\_From\_SH

*activate if* : IfBlock1

        branch : then

        branch : else

            branch : then

            branch : else

                branch : then

                branch : else

                    branch : then

                    branch : else

                        branch : then

                        branch : else

                            branch : then

                            branch : else

                                branch : then

                                branch : else

### 3.5.11.4. Graphical and Textual Diagrams

#### 3.5.11.4.1. View of diagram\_From\_SH (From\_SH)




Figure 42: View of diagram\_From\_SH (From\_SH)

Table 121: Conditional Blocks of diagram\_From\_SH

Conditional Block	Comments and Information
IfBlock1	

Table 122: Actions of diagram\_From\_SH

Conditional Block Action	Comments and Information
IfBlock1:then	
IfBlock1:else:then	
IfBlock1:else:else:then	
IfBlock1:else:else:else:then	
IfBlock1:else:else:else:else:then	
IfBlock1:else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:the n	
IfBlock1:else:else:else:else:else:else:else	

### 3.5.12. From\_SL Operator

Declared as **public function**



### 3.5.12.1. Interface

**Table 123: Inputs of From\_SL**

Name	Type	Comments and Information
Condition1	bool	
Condition3	bool	
Condition2	bool	
Condition29	bool	
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	

**Table 124: Outputs of From\_SL**

Name	Type	Comments and Information
FromSL_To_NewMode	Level_And_Mode_Type s_Pkg::T_Mode	

### 3.5.12.2. Operator Hierarchy

diagram : diagram\_From\_SL


```

activate if : IfBlock1
  branch : then
  branch : else
    branch : then
    branch : else
      branch : then
      branch : else
        branch : then
        branch : else

```

### 3.5.12.3. Graphical and Textual Diagrams

#### 3.5.12.3.1. View of diagram\_From\_SL (From\_SL)



**Figure 43: View of diagram\_From\_SL (From\_SL)**

**Table 125: Conditional Blocks of diagram\_From\_SL**

Conditional Block	Comments and Information
IfBlock1	

**Table 126: Actions of diagram\_From\_SL**

Conditional Block Action	Comments and Information
IfBlock1:then	
IfBlock1:else:then	
IfBlock1:else:else:then	
IfBlock1:else:else:else:then	
IfBlock1:else:else:else:else	

### 3.5.13. From\_SN Operator

Declared as **public function**

#### 3.5.13.1. Interface

**Table 127: Inputs of From\_SN**

Name	Type	Comments and Information
Condition1	bool	
Condition5	bool	
Condition13	bool	
Condition21	bool	
Condition25	bool	
Condition28	bool	
Condition29	bool	
Condition34	bool	
Condition44	bool	
Condition45	bool	
Condition61	bool	
Condition71	bool	
ConditionSN2TR	bool	
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	

**Table 128: Outputs of From\_SN**

Name	Type	Comments and Information
FromSN_To_NewMode	Level_And_Mode_Type s_Pkg::T_Mode	

#### 3.5.13.2. Locals

**Table 129: Locals of From\_SN**

Name	Type	Comments and Information
Condition2SH	bool	
Condition2SR	bool	

### 3.5.13.3. Operator Hierarchy

diagram : diagram\_From\_SN

*activate if* : IfBlock1

        branch : then

        branch : else

            branch : then

            branch : else

                branch : then

                branch : else

                    branch : then

                    branch : else

                        branch : then

                        branch : else

                            branch : then

                            branch : else

                                branch : then

                                branch : else

                                    branch : then

                                    branch : else

  branch : then

  branch : else

  branch : then

  branch : else

  branch :

then

branch :

else

### 3.5.13.4. Graphical and Textual Diagrams

#### 3.5.13.4.1. View of diagram\_From\_SN (From\_SN)




Figure 44: View of diagram\_From\_SN (From\_SN)

Table 130: Conditional Blocks of diagram\_From\_SN

Conditional Block	Comments and Information
IfBlock1	

Table 131: Actions of diagram\_From\_SN

Conditional Block Action	Comments and Information
IfBlock1:then	
IfBlock1:else:then	

Conditional Block Action	Comments and Information
IfBlock1:else:else:then	
IfBlock1:else:else:else:then	
IfBlock1:else:else:else:else:then	
IfBlock1:else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:the n	
IfBlock1:else:else:else:else:else:else:else :then	
IfBlock1:else:else:else:else:else:else:else :else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:else	

### 3.5.14. From\_SR Operator

Declared as **public function**

#### 3.5.14.1. Interface

**Table 132: Inputs of From\_SR**

Name	Type	Comments and Information
Condition1	bool	
Condition5	bool	
Condition6	bool	
Condition13	bool	
Condition21	bool	
Condition28	bool	
Condition29	bool	
Condition31	bool	
Condition32	bool	
Condition40	bool	
Condition46	bool	
Condition51	bool	
Condition56	bool	
Condition59	bool	
Condition72	bool	
ConditionSR2TR	bool	
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	

**Table 133: Outputs of From\_SR**

Name	Type	Comments and Information
FromSR_To_NewMode	Level_And_Mode_Type s_Pkg::T_Mode	

#### 3.5.14.2. Locals

**Table 134: Locals of From\_SR**

Name	Type	Comments and Information
Condition2FS	bool	
Condition2SH	bool	

#### 3.5.14.3. Operator Hierarchy

diagram : diagram\_From\_SR

*activate if* : IfBlock1

        branch : then

        branch : else

            branch : then

            branch : else

                branch : then

                branch : else

                    branch : then

                    branch : else

                        branch : then

                        branch : else

                            branch : then

                            branch : else

                                branch : then

                                branch : else

                                    branch : then

                                    branch : else

  branch : then

  branch : else

  branch : then

  branch : else

  branch :

then

branch :

else

branch : then

branch : else

branch : then

branch : else

### 3.5.14.4. Graphical and Textual Diagrams

#### 3.5.14.4.1. View of diagram\_From\_SR (From\_SR)





Figure 45: View of diagram\_From\_SR (From\_SR)

Table 135: Conditional Blocks of diagram\_From\_SR

Conditional Block	Comments and Information
IfBlock1	

Table 136: Actions of diagram\_From\_SR

Conditional Block Action	Comments and Information
IfBlock1:then	
IfBlock1:else:then	
IfBlock1:else:else:then	
IfBlock1:else:else:else:then	
IfBlock1:else:else:else:else:then	

Conditional Block Action	Comments and Information
IfBlock1:else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:the n	
IfBlock1:else:else:else:else:else:else:else :then	
IfBlock1:else:else:else:else:else:else:else :else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:else :else:else:else:else:else:else	

### 3.5.15. From\_TR Operator

Declared as **public function**

#### 3.5.15.1. Interface

**Table 137: Inputs of From\_TR**

Name	Type	Comments and Information
Condition1	bool	
Condition7	bool	
Condition13	bool	
Condition29	bool	
Condition62	bool	
Condition63	bool	
Condition68	bool	
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	

**Table 138: Outputs of From\_TR**

Name	Type	Comments and Information
FromTR_To_NewMode	Level_And_Mode_Type s_Pkg::T_Mode	

#### 3.5.15.2. Operator Hierarchy

diagram : diagram\_From\_TR

```

activate if : IfBlock1
  branch : then
  branch : else
    branch : then
    branch : else
      branch : then

```



```

branch : else
  branch : then
    branch : else
      branch : then
        branch : else
          branch : then
            branch : else
              branch : then
                branch : else

```

### 3.5.15.3. Graphical and Textual Diagrams

#### 3.5.15.3.1. View of diagram\_From\_TR (From\_TR)




Figure 46: View of diagram\_From\_TR (From\_TR)

Table 139: Conditional Blocks of diagram\_From\_TR

Conditional Block	Comments and Information
IfBlock1	

Table 140: Actions of diagram\_From\_TR

Conditional Block Action	Comments and Information
IfBlock1:then	
IfBlock1:else:then	
IfBlock1:else:else:then	
IfBlock1:else:else:else:then	
IfBlock1:else:else:else:else:then	
IfBlock1:else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:the n	
IfBlock1:else:else:else:else:else:else:else	

### 3.5.16. From\_UN Operator

Declared as **public function**

#### 3.5.16.1. Interface

**Table 141: Inputs of From\_UN**

Name	Type	Comments and Information
Condition1	bool	
Condition5	bool	
Condition13	bool	
Condition25	bool	
Condition28	bool	
Condition29	bool	
Condition34	bool	
Condition44	bool	
Condition45	bool	
Condition56	bool	
Condition61	bool	
Condition71	bool	
ConditionUN2TR	bool	
previousMode_Loc	Level_And_Mode_Type s_Pkg::T_Mode	

**Table 142: Outputs of From\_UN**

Name	Type	Comments and Information
FromUN_To_NewMode	Level_And_Mode_Type s_Pkg::T_Mode	

#### 3.5.16.2. Locals

**Table 143: Locals of From\_UN**

Name	Type	Comments and Information
Condition2SH	bool	
Condition2SR	bool	

#### 3.5.16.3. Operator Hierarchy

diagram : diagram\_From\_UN

```
    activate if : IfBlock1
      branch : then
      branch : else
        branch : then
        branch : else
          branch : then
          branch : else
            branch : then
            branch : else
```

```

                                branch : then
                                branch : else
                                  branch : then
                                  branch : else
                                    branch : then
                                    branch : else
                                      branch : then
                                      branch : else
                                        branch : then
                                        branch : else
                                          branch : then
                                          branch : else
                                            branch :
then
                                branch :
else
```

### 3.5.16.4. Graphical and Textual Diagrams

#### 3.5.16.4.1. View of diagram\_From\_UN (From\_UN)





Figure 47: View of diagram\_From\_UN (From\_UN)

Table 144: Conditional Blocks of diagram\_From\_UN

Conditional Block	Comments and Information
IfBlock1	

Table 145: Actions of diagram\_From\_UN

Conditional Block Action	Comments and Information
IfBlock1:then	
IfBlock1:else:then	
IfBlock1:else:else:then	

Conditional Block Action	Comments and Information
IfBlock1:else:else:else:then	
IfBlock1:else:else:else:else:then	
IfBlock1:else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:else:else:else:else:then	
IfBlock1:else:else:else:else:else:else:else:else:else:else:else:then	

## 3.6. Procedures Package

### 3.6.1. Procedure\_LimitedSupervision Operator

Declared as **public node**

#### 3.6.1.1. Comments and Information

##### **Procedure\_LimitedSupervision Comments:**

Case of starting mode is SB or PT is covered by the start of mission procedure and the train-trip procedure.

#### 3.6.1.2. Interface

**Table 146: Inputs of Procedure\_LimitedSupervision**

Name	Type	Comments and Information
Current_Mode	Level_And_Mode_Type s_Pkg::T_Mode	
Driver_Ack_LS	bool	
Mode_Profile_On_Board	Level_And_Mode_Type s_Pkg::T_Mode_Profile	
Train_Position	TrainPosition_Types_Pc k::trainPosition_T	
Train_Speed	Obu_BasicTypes_Pkg:: Speed_T	

**Table 147: Outputs of Procedure\_LimitedSupervision**

Name	Type	Comments and Information
Condition70	bool	
Condition71	bool	
Condition72	bool	

Name	Type	Comments and Information
Condition74	bool	<b>Comments:</b> §4.6.3 : Condition 74 : "(A Mode Profile defining a Limited Supervision area is on-board) AND (The max safe front end of the train is inside the Limited Supervision area) AND (The estimated front end of the train is not inside an OS acknowledgement area)"
Ack_LS_Req_To_Driver	bool	
Service_Brake_Command	bool	

### 3.6.1.3. Locals

**Table 148: Locals of Procedure\_LimitedSupervision**


Name	Type	Comments and Information
Loc_Condition_74	bool	
Loc_Procedure_Possible	bool	
Loc_Supervision_Mode	bool	

### 3.6.1.4. Operator Hierarchy

diagram : diagram\_Procedure\_LimitedSupervision\_1

### 3.6.1.5. Graphical and Textual Diagrams

#### 3.6.1.5.1. View of diagram\_Procedure\_LimitedSupervision\_1 (Procedure\_LimitedSupervision)



**Figure 48: View of diagram\_Procedure\_LimitedSupervision\_1 (Procedure\_LimitedSupervision)**

### 3.6.2. Procedure\_OnSight Operator

Declared as **public node**

### 3.6.2.1. Interface

**Table 149: Inputs of Procedure\_OnSight**

Name	Type	Comments and Information
Current_Mode	Level_And_Mode_Type s_Pkg::T_Mode	
Driver_Ack_OS	bool	
Mode_Profile_On_Board	Level_And_Mode_Type s_Pkg::T_Mode_Profile	
Train_Position	TrainPosition_Types_Pc k::trainPosition_T	
Train_Speed	Obu_BasicTypes_Pkg:: Speed_T	

**Table 150: Outputs of Procedure\_OnSight**

Name	Type	Comments and Information
Condition15	bool	
Condition34	bool	
Condition40	bool	
Condition73	bool	
Ack_OS_Req_To_Driver	bool	
Service_Brake_Command	bool	

### 3.6.2.2. Locals

**Table 151: Locals of Procedure\_OnSight**

Name	Type	Comments and Information
Loc_Condition_73	bool	
Loc_Procedure_Possible	bool	
Loc_Supervision_Mode	bool	

### 3.6.2.3. Operator Hierarchy

diagram : diagram\_Procedure\_OnSight\_1

### 3.6.2.4. Graphical and Textual Diagrams

#### 3.6.2.4.1. View of diagram\_Procedure\_OnSight\_1 (Procedure\_OnSight)




Figure 49: View of diagram\_Procedure\_OnSight\_1 (Procedure\_OnSight)

### 3.6.3. Procedure\_SH\_Initiated\_By\_Driver Operator

Declared as **public node**

#### 3.6.3.1. Comments and Information

##### Procedure\_SH\_Initiated\_By\_Driver Comments:

From SRS-026 v3.3.0, §5.6 Shunting Initiated by Driver.

Assumptions:

- A030 and National Trip occurrence is covered by Trip conditions and procedures with higher priority.
- Communication with RBC is out of the scope of this function ( repetition of message to RBC, waiting for acknowledgement,...)

#### 3.6.3.2. Interface

Table 152: Inputs of Procedure\_SH\_Initiated\_By\_Driver

Name	Type	Comments and Information
Current_Level	M_LEVEL	
Current_Mode	Level_And_Mode_Type s_Pkg::T_Mode	
Driver_Req_SH	bool	
On_Going_Mission	bool	
Shunting_Granted_By_RBC	bool	
Train_Standstill	bool	



**Table 153: Outputs of Procedure\_SH\_Initiated\_By\_Driver**

Name	Type	Properties		Comments and Information
Condition5	bool	default	false	
Condition6	bool	default	false	
Clean_BG_List_SH_Area	bool	default	false	
End_Of_Mission_Procedure_Req	bool	default	false	
Request_For_SH_To_RBC	bool	default	false	
SH_Refused_By_RBC_To_DMI	bool	default	false	

### 3.6.3.3. Locals

**Table 154: Locals of Procedure\_SH\_Initiated\_By\_Driver**

Name	Type	Comments and Information
Loc_Procedure_Possible	bool	

### 3.6.3.4. Operator Hierarchy

diagram : diagram\_Procedure\_SH\_Initiated\_By\_Driver\_1

*state-machine* : SH\_Initiated\_By\_Driver

state : S0\_SH\_initiated\_by\_driver\_procedure\_on

state : SH\_initiated\_by\_driver\_procedure\_off

### 3.6.3.5. Graphical and Textual Diagrams

#### 3.6.3.5.1. View of diagram\_Procedure\_SH\_Initiated\_By\_Driver\_1 (Procedure\_SH\_Initiated\_By\_Driver)




Figure 50: View of diagram\_Procedure\_SH\_Initiated\_By\_Driver\_1 (Procedure\_SH\_Initiated\_By\_Driver)

Table 155: State Machines of diagram\_Procedure\_SH\_Initiated\_By\_Driver\_1

State Machine	Comments and Information
SH_Initiated_By_Driver	

Table 156: States of diagram\_Procedure\_SH\_Initiated\_By\_Driver\_1

State	Comments and Information
SH_Initiated_By_Driver:S0_SH_initiated_by_driver_procedure_on	<b>Comments:</b> SRS § 5.6 state S0
SH_Initiated_By_Driver:SH_initiated_by_driver_procedure_off	

Table 157: Transitions of diagram\_Procedure\_SH\_Initiated\_By\_Driver\_1

Source/Target	#	Conditions/Actions	Comments and Information
<b>Source:</b> SH_Initiated_By_Driver:S0_SH_initiated_by_driver_procedure_on <b>Target:</b> SH_Initiated_By_Driver:SH_initiated_by_driver_procedure_off	1	<b>Condition:</b> not Loc_Procedure_Possible or not Train_Standstill <b>Actions:</b>	<b>Comments:</b> Condition to manage the procedure are no more available : train is moving or mode change (for example to Trip mode)
<b>Source:</b> SH_Initiated_By_Driver:SH_initiated_by_driver_procedure_off <b>Target:</b> SH_Initiated_By_Driver:S0_SH_initiated_by_driver_procedure_on	1	<b>Condition:</b> Loc_Procedure_Possible and Train_Standstill <b>Actions:</b>	<b>Comments:</b> S0 : start of procedure is possible

### 3.6.4. Procedure\_SH\_Ordered\_By\_Track Operator

Declared as **public node**

#### 3.6.4.1. Comments and Information

**Procedure\_SH\_Ordered\_By\_Track Comments:**

From SRS-026 v3.3.0, §5.7 Shunting Order from trackside

Assumptions:

- Driver acknowledgement not possible in mode SR, UN and SN see table 4.7.2.1.4 and tables 4.6.2 and 4.6.3 condition 51 and 61
- 

#### 3.6.4.2. Interface

**Table 158: Inputs of Procedure\_SH\_Ordered\_By\_Track**

Name	Type	Comments and Information
Current_Mode	Level_And_Mode_Types_Pkg::T_Mode	
Driver_Ack_SH	bool	
Mode_Profile_On_Board	Level_And_Mode_Types_Pkg::T_Mode_Profile	
Train_Position	TrainPosition_Types_Pkg::trainPosition_T	
Train_Speed	Obu_BasicTypes_Pkg::Speed_T	

**Table 159: Outputs of Procedure\_SH\_Ordered\_By\_Track**

Name	Type	Comments and Information
Condition50	bool	
Condition51	bool	
Condition61	bool	
Ack_SH_Req_To_Driver	bool	
Service_Brake_Command	bool	

#### 3.6.4.3. Locals

**Table 160: Locals of Procedure\_SH\_Ordered\_By\_Track**


Name	Type	Comments and Information
Loc_Procedure_Possible	bool	
Loc_Supervision_Mode	bool	

#### 3.6.4.4. Operator Hierarchy

diagram : diagram\_Procedure\_SH\_Ordered\_By\_Track\_1

#### 3.6.4.5. Graphical and Textual Diagrams

3.6.4.5.1. View of diagram\_Procedure\_SH\_Ordered\_By\_Track\_1  
(Procedure\_SH\_Ordered\_By\_Track)



**Figure 51: View of diagram\_Procedure\_SH\_Ordered\_By\_Track\_1  
(Procedure\_SH\_Ordered\_By\_Track)**

### 3.6.5. Procedure\_Start L1 L2 L3 Operator

Declared as public node

### 3.6.5.1. Interface

**Table 161: Inputs of Procedure\_Start\_L1\_L2\_L3**

Name	Type	Comments and Information
Current_Level	M_LEVEL	
Driver_Ack_LS	bool	
Driver_Ack_OS	bool	
Driver_Ack_SH	bool	
Driver_Ack_SR	bool	
Driver_Req_Start	bool	
MA_SSP_Gradient_Available	bool	
Mode_Profile_On_Board	Level_And_Mode_Types_Pkg::T_Mode_Profile	
RBC_Authorizes_SR	bool	

**Table 162: Outputs of Procedure\_Start\_L1\_L2\_L3**

Name	Type	Properties		Comments and Information
Ack_LS_Req_To_Driver	bool	default	false	
Ack_OS_Req_To_Driver	bool	default	false	
Ack_SH_Req_To_Driver	bool	default	false	

Name	Type	Properties		Comments and Information
Ack_SR_Req_To_Driver	bool	default	false	
Condition_8	bool	default	false	
Condition_10_31	bool	default	false	
Condition_15	bool	default	false	
Condition_50	bool	default	false	
Condition_70	bool	default	false	
MA_Req_To_RBC	bool	default	false	

### 3.6.5.2. Locals

**Table 163: Locals of Procedure\_Start\_L1\_L2\_L3**

Name	Type	Comments and Information
Loc_Mode_Profile	Level_And_Mode_Types_Pkg::T_MA	

### 3.6.5.3. Operator Hierarchy

diagram : diagram\_Procedure\_Start\_L1\_L2\_L3\_1

*state-machine* : SM\_Start\_L1\_L2\_L3

state : FS\_Mode

state : Level\_1

state : Level\_2\_3

state : LS\_Mode

state : OS\_Mode

state : SH\_Mode

state : SR\_Mode

state : Wait\_For\_LS

state : Wait\_For\_OS

state : Wait\_For\_SH

state : Waiting\_Driver\_Starting\_Command

### 3.6.5.4. Graphical and Textual Diagrams

#### 3.6.5.4.1. View of diagram\_Procedure\_Start\_L1\_L2\_L3\_1 (Procedure\_Start\_L1\_L2\_L3)




Figure 52: View of diagram\_Procedure\_Start\_L1\_L2\_L3\_1 (Procedure\_Start\_L1\_L2\_L3)

Table 164: State Machines of diagram\_Procedure\_Start\_L1\_L2\_L3\_1

State Machine	Comments and Information
SM_Start_L1_L2_L3	

Table 165: States of diagram\_Procedure\_Start\_L1\_L2\_L3\_1

State	Comments and Information
SM_Start_L1_L2_L3:FS_Mode	<b>Comments:</b> SRS § 4.6.3 C10:“(valid Train Data is stored on board) AND (MA + SSP +gradient are on-board) AND (no specific mode is required by a Mode Profile)” SRS § 4.6.3 C31: “(MA+SSP+gradient are on-board) AND (no specific mode is required by a Mode Profile) AND (ERTMS/ETCS level is 2 or 3)”
SM_Start_L1_L2_L3:Level_1	<b>Comments:</b> SRS § 5.4 state S24 SRS § 5.11 state S160
SM_Start_L1_L2_L3:Level_2_3	<b>Comments:</b> SRS § 5.4 state S21 SRS § 5.11 state S150

State	Comments and Information
SM_Start_L1_L2_L3:LS_Mode	<b>Comments:</b> SRS § 4.6.3 C70 : "(An ackn. request for Limited Supervision is displayed to the driver) AND (the driver acknowledges) " {7} The request to acknowledge Limited Supervision is displayed to the driver only if certain conditions are fulfilled. These conditions are not specified here. See the "Limited Supervision" procedure" of SRS-§5 (for transitions from FS/OS/UN to LS) and the "Start of mission" procedure (for transition from SB to LS).
SM_Start_L1_L2_L3:OS_Mode	<b>Comments:</b> SRS § 4.6.3 C15: "(An ackn. request for On Sight is displayed to the driver) AND (the driver acknowledges) " {1} The request to acknowledge On Sight is displayed to the driver only if certain conditions are fulfilled. These conditions are not specified here. See the "On Sight" procedure" of SRS-§5 (for transitions from FS/LS/UN to OS) and the "Start of mission" procedure (for transition from SB to OS).
SM_Start_L1_L2_L3:SH_Mode	<b>Comments:</b> SRS § 4.6.3 C50: "(An ackn. request for Shunting is displayed to the driver) AND (the driver acknowledges) " {5} The request to acknowledge Shunting is displayed to the driver only if certain conditions are fulfilled. These conditions are not specified here. See the "Entry in Shunting" procedure and the "Start Of Mission" procedure of SRS-§5.
SM_Start_L1_L2_L3:SR_Mode	<b>Comments:</b> SRS § 4.6.3 C8 "StaffResponsible Mode is proposed o the driver AND the driver acknowledges"
SM_Start_L1_L2_L3:Wait_For_LS	<b>Comments:</b> SRS § 5.4 state S25 SRS § 5.11 state S170
SM_Start_L1_L2_L3:Wait_For_OS	<b>Comments:</b> SRS § 5.4 state S25 SRS § 5.11 state S170
SM_Start_L1_L2_L3:Wait_For_SH	<b>Comments:</b> SRS § 5.4 state S25 SRS § 5.11 state S170
SM_Start_L1_L2_L3:Waiting_Driver_Start ing_Command	<b>Comments:</b> SRS § 5.4 state S20 SRS § 5.11 state S140

Table 166: Transitions of diagram\_Procedure\_Start\_L1\_L2\_L3\_1

Source/Target	#	Conditions/Actions	Comments and Information
<b>Source:</b> SM_Start_L1_L2_L3:Level_1 <b>Target:</b> SM_Start_L1_L2_L3:SR_Mode	1	<b>Condition:</b> Driver_Ack_SR	<b>Comments:</b> SRS § 5.4 state E32 SRS § 5.11 state E160
<b>Source:</b> SM_Start_L1_L2_L3:Level_2_3 <b>Target:</b> SM_Start_L1_L2_L3:Level_1	1	<b>Condition:</b> RBC_Authorizes_SR	<b>Comments:</b> SRS § 5.4 state E26 SRS § 5.11 state E26

Source/Target	#	Conditions/ Actions	Comments and Information
<b>Source:</b> SM_Start_L1_L2_L3:Level_2_3 <b>Target:</b> SM_Start_L1_L2_L3:FS_Mode	2	<b>Condition:</b> MA_SSP_Gradient_Available and Loc_Mode_Profile = Level_And_Mode_Type s_Pkg::No_Profile	<b>Comments:</b> SRS § 5.4 state E29 SRS § 5.11 state E170
<b>Source:</b> SM_Start_L1_L2_L3:Level_2_3 <b>Target:</b> SM_Start_L1_L2_L3:Wait_For_OS	3	<b>Condition:</b> Loc_Mode_Profile = Level_And_Mode_Type s_Pkg::Profile_OS <b>Actions:</b>	<b>Comments:</b> SRS § 5.4 state E27 SRS § 5.11 state E175
<b>Source:</b> SM_Start_L1_L2_L3:Level_2_3 <b>Target:</b> SM_Start_L1_L2_L3:Wait_For_SH	4	<b>Condition:</b> Loc_Mode_Profile = Level_And_Mode_Type s_Pkg::Profile_SH <b>Actions:</b>	<b>Comments:</b> SRS § 5.4 state E27 SRS § 5.11 state E175
<b>Source:</b> SM_Start_L1_L2_L3:Level_2_3 <b>Target:</b> SM_Start_L1_L2_L3:Wait_For_LS	5	<b>Condition:</b> Loc_Mode_Profile = Level_And_Mode_Type s_Pkg::Profile_LS <b>Actions:</b>	<b>Comments:</b> SRS § 5.4 state E27 SRS § 5.11 state E175
<b>Source:</b> SM_Start_L1_L2_L3:Wait_For_LS <b>Target:</b> SM_Start_L1_L2_L3:LS_Mode	1	<b>Condition:</b> Driver_Ack_LS	<b>Comments:</b> SRS § 5.4 state E33 SRS § 5.11 state E185
<b>Source:</b> SM_Start_L1_L2_L3:Wait_For_OS <b>Target:</b> SM_Start_L1_L2_L3:OS_Mode	1	<b>Condition:</b> Driver_Ack_OS	<b>Comments:</b> SRS § 5.4 state E33 SRS § 5.11 state E185
<b>Source:</b> SM_Start_L1_L2_L3:Wait_For_SH <b>Target:</b> SM_Start_L1_L2_L3:SH_Mode	1	<b>Condition:</b> Driver_Ack_SH	<b>Comments:</b> SRS § 5.4 state E33 SRS § 5.11 state E185
<b>Source:</b> SM_Start_L1_L2_L3:Waiting_Driver_Starting_Command <b>Target:</b> SM_Start_L1_L2_L3:Level_1	1	<b>Condition:</b> Driver_Req_Start	
	1	<b>Condition:</b> Current_Level = M_LEVEL_Level_1 <b>Actions:</b>	<b>Comments:</b> SRS § 5.4 state E22 SRS § 5.11 state E150
<b>Source:</b> SM_Start_L1_L2_L3:Waiting_Driver_Starting_Command <b>Target:</b> SM_Start_L1_L2_L3:Level_2_3	1	<b>Condition:</b> Driver_Req_Start	
	2	<b>Condition:</b> Current_Level = M_LEVEL_Level_2 or Current_Level = M_LEVEL_Level_3 <b>Actions:</b>	<b>Comments:</b> SRS § 5.4 state E24 SRS § 5.11 state E155

### 3.6.6. Procedure\_StartOfMission Operator

Declared as **public node**



### 3.6.6.1. Interface

**Table 167: Inputs of Procedure\_StartOfMission**

Name	Type	Comments and Information
Current_Level	M_LEVEL	
Current_Mode	Level_And_Mode_Types_Pkg::T_Mode	
Desk_Open	bool	
Driver_Ack_LS	bool	
Driver_Ack_OS	bool	
Driver_Ack_SH	bool	
Driver_Ack_SN	bool	
Driver_Ack_SR	bool	
Driver_Ack_UN	bool	
Driver_Req_NL	bool	
Driver_Req_SH	bool	
Driver_Req_Start	bool	
MA_SSP_Gradient_Available	bool	
Mode_Profile_On_Board	Level_And_Mode_Types_Pkg::T_Mode_Profile	
RBC_Authorizes_SR	bool	
Shunting_Granted_By_RBC	bool	
Train_Permitted_NL	bool	
Train_Standstill	bool	
Valid_Train_Data_Stored	bool	

**Table 168: Outputs of Procedure\_StartOfMission**

Name	Type	Properties		Comments and Information
Ack_LS_Req_To_Driver	bool	default	false	
Ack_OS_Req_To_Driver	bool	default	false	
Ack_SH_Req_To_Driver	bool	default	false	
Ack_SN_Req_To_Driver	bool	default	false	
Ack_SR_Req_To_Driver	bool	default	false	
Ack_UN_Req_To_Driver	bool	default	false	
Clean_BG_List_SH_Area	bool	default	false	
Condition_5	bool	default	false	
Condition_6	bool	default	false	
Condition_8	bool	default	false	
Condition_10	bool	default	false	

Name	Type	Properties		Comments and Information
Condition_15	bool	default	false	
Condition_46	bool	default	false	
Condition_50	bool	default	false	
Condition_58	bool	default	false	
Condition_60	bool	default	false	
Condition_70	bool	default	false	
EB_Requested	bool	default	false	
End_Of_Mission_Procedure_Req	bool	default	false	
MA_Req_To_RBC	bool	default	false	
Request_For_SH_To_RBC	bool	default	false	
SH_Refused_By_RBC_To_DMI	bool	default	false	

### 3.6.6.2. Operator Hierarchy

diagram : diagram\_Procedure\_StartOfMission\_1

*state-machine* : SM\_StartOfMissionProcedure

state : EB\_Requested

state : Procedure\_Off

state : Procedure\_On

*state-machine* : SM\_SoM\_On

state : Level\_0

state : Level\_NTC

state : NL\_Mode

state : Procedure\_SH\_Initiated\_By\_Driver

state : SN\_Mode

state : UN\_Mode


state : Waiting\_Driver\_Command

state : Waiting\_Driver\_Selection

state : Waiting\_Driver\_Strating\_Command

### 3.6.6.3. Graphical and Textual Diagrams

#### 3.6.6.3.1. View of diagram\_Procedure\_StartOfMission\_1 (Procedure\_StartOfMission)



**Figure 53: View of diagram\_Procedure\_StartOfMission\_1 (Procedure\_StartOfMission)**

**Table 169: State Machines of diagram\_Procedure\_StartOfMission\_1**

State Machine	Comments and Information
SM_StartOfMissionProcedure	
SM_StartOfMissionProcedure: Procedure On:SM SoM On	

**Table 170: States of diagram\_Procedure\_StartOfMission\_1**

State	Comments and Information
SM_StartOfMissionProcedure:EB_Requested	
SM_StartOfMissionProcedure:Procedure_Off	<b>Comments:</b> SRS § 5.4 state S0
SM_StartOfMissionProcedure:Procedure_On	
SM_StartOfMissionProcedure:Procedure_On:SM_SoM_On:Level_0	<b>Comments:</b> SRS § 5.4 state S23
SM_StartOfMissionProcedure:Procedure_On:SM_SoM_On:Level_NTC	<b>Comments:</b> SRS § 5.4 state S22
SM_StartOfMissionProcedure:Procedure_On:SM_SoM_On:NL_Mode	<b>Comments:</b> SRS § 4.6.3 C46 : "(Driver selects NON LEADING) AND (train is at standstill) AND (The "non leading" input signal is received)"
SM_StartOfMissionProcedure:Procedure_On:SM_SoM_On:Procedure_SH_Initiated_By_Driver	
SM_StartOfMissionProcedure:Procedure_On:SM_SoM_On:SN_Mode	<b>Comments:</b> SRS § 4.6.3 C58 : "(the ERTMS/ETCS level is "NTC") AND (an acknowledgement request for SN mode is displayed to the driver) AND (the driver acknowledges) "
SM_StartOfMissionProcedure:Procedure_On:SM_SoM_On:UN_Mode	<b>Comments:</b> SRS § 4.6.3 C60 : " (an acknowledgement request for UN mode is displayed to the driver) AND (the driver acknowledges)"
SM_StartOfMissionProcedure:Procedure_On:SM_SoM_On:Waiting_Driver_Command	<b>Comments:</b> SRS § 5.4 state S11
SM_StartOfMissionProcedure:Procedure_On:SM_SoM_On:Waiting_Driver_Selection	<b>Comments:</b> SRS § 5.4 state S20
SM_StartOfMissionProcedure:Procedure_On:SM_SoM_On:Waiting_Driver_Strating_Command	<b>Comments:</b> SRS § 5.4 state S20

**Table 171: Transitions of diagram\_Procedure\_StartOfMission\_1**

Source/Target	#	Conditions/Actions	Comments and Information
<b>Source:</b> SM_StartOfMissionProcedure:EB_Requested <b>Target:</b> SM_StartOfMissionProcedure:Procedure_Off	1	<b>Condition:</b> Train_Standstill	
<b>Source:</b> SM_StartOfMissionProcedure:Procedure_Off <b>Target:</b> SM_StartOfMissionProcedure:Procedure_On	1	<b>Condition:</b> Current_Mode = Level_And_Mode_Types_Pkg::SB and Train_Standstill and Desk_Open	

Source/Target	#	Conditions/ Actions	Comments and Information
<b>Source:</b> SM_StartOfMissionProcedure:Proce dure_On <b>Target:</b> SM_StartOfMissionProcedure:EB_R equested	1	<b>Condition:</b> Current_Mode = Level_And_Mode_Type s_Pkg::SB and not Train_Standstill <b>Actions:</b>	
<b>Source:</b> SM_StartOfMissionProcedure:Proce dure_On <b>Target:</b> SM_StartOfMissionProcedure:Proce dure_Off	2	<b>Condition:</b> not (Current_Mode = Level_And_Mode_Type s_Pkg::SB) or not Desk_Open	
<b>Source:</b> SM_StartOfMissionProcedure:Proce dure_On:SM_SoM_On:Level_0 <b>Target:</b> SM_StartOfMissionProcedure:Proce dure_On:SM_SoM_On:UN_Mode	1	<b>Condition:</b> Driver_Ack_UN	<b>Comments:</b> SRS § 5.4 state E31
<b>Source:</b> SM_StartOfMissionProcedure:Proce dure_On:SM_SoM_On:Level_NTC <b>Target:</b> SM_StartOfMissionProcedure:Proce dure_On:SM_SoM_On:SN_Mode	1	<b>Condition:</b> Driver_Ack_SN	<b>Comments:</b> SRS § 5.4 state E30
<b>Source:</b> SM_StartOfMissionProcedure:Proce dure_On:SM_SoM_On:Waiting_Driv er_Command <b>Target:</b> SM_StartOfMissionProcedure:Proce dure_On:SM_SoM_On:NL_Mode	1	<b>Condition:</b> Driver_Req_NL and Train_Permitted_NL	<b>Comments:</b> SRS § 5.4 state E10
<b>Source:</b> SM_StartOfMissionProcedure:Proce dure_On:SM_SoM_On:Waiting_Driv er_Command <b>Target:</b> SM_StartOfMissionProcedure:Proce dure_On:SM_SoM_On:Procedure_S H_Initiated_By_Driver	2	<b>Condition:</b> Driver_Req_SH	<b>Comments:</b> SRS § 5.4 state E12
<b>Source:</b> SM_StartOfMissionProcedure:Proce dure_On:SM_SoM_On:Waiting_Driv er_Command <b>Target:</b> SM_StartOfMissionProcedure:Proce dure_On:SM_SoM_On:Waiting_Driv er_Strating_Command	3	<b>Condition:</b> Valid_Train_Data_Stor ed	<b>Comments:</b> SRS § 5.4 state E14
<b>Source:</b> SM_StartOfMissionProcedure:Proce dure_On:SM_SoM_On:Waiting_Driv er_Strating_Command <b>Target:</b> SM_StartOfMissionProcedure:Proce dure_On:SM_SoM_On:Waiting_Driv er_Selection	1	<b>Condition:</b> Current_Level = M_LEVEL_Level_1 or Current_Level = M_LEVEL_Level_2 or Current_Level = M_LEVEL_Level_3	
<b>Source:</b> SM_StartOfMissionProcedure:Proce	2	<b>Condition:</b> Driver_Req_Start	

Source/Target	#	Conditions/ Actions	Comments and Information
dure_On:SM_SoM_On:Waiting_Driver_Strating_Command <b>Target:</b> SM_StartOfMissionProcedure:Proce dure_On:SM_SoM_On:Level_0	1	<b>Condition:</b> Current_Level = M_LEVEL_Level_0 <b>Actions:</b>	<b>Comments:</b> SRS § 5.4 state E21
<b>Source:</b> SM_StartOfMissionProcedure:Proce dure_On:SM_SoM_On:Waiting_Driver_Strating_Command <b>Target:</b> SM_StartOfMissionProcedure:Proce dure_On:SM_SoM_On:Level_NTC	2	<b>Condition:</b> Driver_Req_Start	
	2	<b>Condition:</b> Current_Level = M_LEVEL_Level_NTC_s pecified_by_NID_NTC <b>Actions:</b>	<b>Comments:</b> SRS § 5.4 state E20

### 3.6.7. Procedure\_Train\_Reversing Operator

Declared as **public node**

#### 3.6.7.1. Interface

**Table 172: Inputs of Procedure\_Train\_Reversing**

Name	Type	Comments and Information
Driver_Ack_RV	bool	
Train_Standstill	bool	
Train_Position	TrainPosition_Types_Pck::trainPosition_T	
Current_Mode	Level_And_Mode_Type s_Pkg::T_Mode	
Reversing_Data	Level_And_Mode_Type s_Pkg::T_Reversing_D ata	

**Table 173: Outputs of Procedure\_Train\_Reversing**

Name	Type	Properties	Comments and Information
Condition_59	bool	default false	
Ack_RV_Req_To_Driver	bool	default false	

#### 3.6.7.2. Locals

**Table 174: Locals of Procedure\_Train\_Reversing**

Name	Type	Comments and Information
Loc_Cond_Procedure_On	bool	
Loc_Max_Safe_Front_In_RV_Area	bool	
Loc_RV_Data_Available	bool	

### 3.6.7.3. Operator Hierarchy

diagram : diagram\_Procedure\_Train\_Reversing\_1

state-machine : SM\_Train\_Reversing

state : Reversing\_Condition

state : Reversing\_Data\_Available

state : Reversing\_Procedure\_Off

state : RV\_Mode

### 3.6.7.4. Graphical and Textual Diagrams

#### 3.6.7.4.1. View of diagram\_Procedure\_Train\_Reversing\_1 (Procedure\_Train\_Reversing)




Figure 54: View of diagram\_Procedure\_Train\_Reversing\_1 (Procedure\_Train\_Reversing)

Table 175: State Machines of diagram\_Procedure\_Train\_Reversing\_1

State Machine	Comments and Information
SM_Train_Reversing	

Table 176: States of diagram\_Procedure\_Train\_Reversing\_1

State	Comments and Information
SM_Train_Reversing:Reversing_Condition	<b>Comments:</b> SRS § 5.4 state S24 SRS § 5.11 state S160
SM_Train_Reversing:Reversing_Data_Available	<b>Comments:</b> SRS § 5.4 state S25 SRS § 5.11 state S170
SM_Train_Reversing:Reversing_Procedure_Off	<b>Comments:</b> SRS § 5.4 state S20 SRS § 5.11 state S140
SM_Train_Reversing:RV_Mode	<b>Comments:</b> SRS § 4.6.3 C8 "StaffResponsible Mode is proposed o the driver AND the driver acknowledges"

**Table 177: Transitions of diagram\_Procedure\_Train\_Reversing\_1**

Source/Target	#	Conditions/Actions	Comments and Information
<b>Source:</b> SM_Train_Reversing:Reversing_Co ndition <b>Target:</b> SM_Train_Reversing:RV_Mode	1	<b>Condition:</b> Driver_Ack_RV	<b>Comments:</b> SRS § 5.4 state E32 SRS § 5.11 state E160
<b>Source:</b> SM_Train_Reversing:Reversing_Co ndition <b>Target:</b> SM_Train_Reversing:Reversing_Pro cedure_Off	2	<b>Condition:</b> not Loc_Cond_Procedure_ On	
<b>Source:</b> SM_Train_Reversing:Reversing_Co ndition <b>Target:</b> SM_Train_Reversing:Reversing_Dat a_Available	3	<b>Condition:</b> not (Train_Standstill and Loc_Max_Safe_Front_I n_RV_Area)	
<b>Source:</b> SM_Train_Reversing:Reversing_Dat a_Available <b>Target:</b> SM_Train_Reversing:Reversing_Co ndition	1	<b>Condition:</b> Train_Standstill and Loc_Max_Safe_Front_I n_RV_Area	
<b>Source:</b> SM_Train_Reversing:Reversing_Dat a_Available <b>Target:</b> SM_Train_Reversing:Reversing_Pro cedure_Off	2	<b>Condition:</b> not Loc_Cond_Procedure_ On	
<b>Source:</b> SM_Train_Reversing:Reversing_Pro cedure_Off <b>Target:</b> SM_Train_Reversing:Reversing_Dat a_Available	1	<b>Condition:</b> Loc_Cond_Procedure_ On	

### 3.6.8. Procedure\_Train\_Trip Operator

Declared as **public node**

#### 3.6.8.1. Comments and Information

##### **Procedure\_Train\_Trip Comments:**

SRS-026 §4.6.3 C7 :“(the driver acknowledges the train trip) AND (the train is at standstill) AND (the ERTMS/ETCS level is different from 0, NTC)”

SRS-026 §4.6.3 C62 :“(the driver acknowledges the train trip) AND (the train is at standstill) AND (the ERTMS/ETCS level is 0) AND (valid Train Data is on-board)”

SRS-026 §4.6.3 C63:“(the driver acknowledges the train trip) AND (the train is at standstill) AND (the ERTMS/ETCS level is NTC) AND (valid Train Data is on-board)”

SRS-026 §4.6.3 C68 :“(the driver acknowledges the train trip) AND (the train is at standstill) AND (the ERTMS/ETCS level is 0 or NTC) AND (no valid Train Data is on-board)”



### 3.6.8.2. Interface

**Table 178: Inputs of Procedure\_Train\_Trip**

Name	Type	Comments and Information
Condition_To_Trip	bool	
Current_Level	M_LEVEL	
Current_Mode	Level_And_Mode_Type s_Pkg::T_Mode	
Driver_Ack_LS	bool	
Driver_Ack_OS	bool	
Driver_Ack_SH	bool	
Driver_Ack_SR	bool	
Driver_Ack_TR	bool	
Driver_Req_SH	bool	
Driver_Req_Start	bool	
MA_SSP_Gradient_Available	bool	
Mode_Profile_On_Board	Level_And_Mode_Type s_Pkg::T_Mode_Profile	
On_Going_Mission	bool	
RCB_Ack_And_EB_Revoked	bool	
RBC_Authorizes_SR	bool	
Shunting_Granted_By_RBC	bool	
Train_Standstill	bool	
Valid_Train_Data_Stored	bool	

**Table 179: Outputs of Procedure\_Train\_Trip**

Name	Type	Properties		Comments and Information
Ack_LS_Req_To_Driver	bool	default	false	
Ack_OS_Req_To_Driver	bool	default	false	
Ack_SH_Req_To_Driver	bool	default	false	
Ack_SR_Req_To_Driver	bool	default	false	
Ack_TR_Req_To_Driver	bool	default	false	
Clean_BG_List_SH_Area	bool	default	false	
Condition_Trip	bool	default	false	
Condition_5	bool	default	false	
Condition_6	bool	default	false	
Condition_7	bool	default	false	

Name	Type	Properties		Comments and Information
Condition_8	bool	default	false	
Condition_31	bool	default	false	
Condition_15	bool	default	false	
Condition_50	bool	default	false	
Condition_62	bool	default	false	
Condition_63	bool	default	false	
Condition_68	bool	default	false	
Condition_70	bool	default	false	
End_Of_Mission_Procedure_Req	bool	default	false	
MA_Req_To_RBC	bool	default	false	
Request_For_SH_To_RBC	bool	default	false	
SH_Refused_By_RBC_To_DMI	bool	default	false	

### 3.6.8.3. Locals

**Table 180: Locals of Procedure\_Train\_Trip**

Name	Type	Comments and Information
Loc_Procedure_Possible	bool	

### 3.6.8.4. Operator Hierarchy

diagram : diagram\_Procedure\_Train\_Trip\_1

*state-machine* : SM\_Train\_Trip

state : Post\_Trip\_Mode

state : Procedure\_SH\_Initiated\_By\_Driver

state : SH\_Mode

state : SN\_Mode

state : Train\_Trip\_procedure\_off

state : Trip\_Mode

state : Trip\_Mode\_Waiting\_Ack

state : UN\_Mode

state : Wait\_RBC\_Ack

state : Waiting\_Driver\_Selection

### 3.6.8.5. Graphical and Textual Diagrams

#### 3.6.8.5.1. View of diagram\_Procedure\_Train\_Trip\_1 (Procedure\_Train\_Trip)




Figure 55: View of diagram\_Procedure\_Train\_Trip\_1 (Procedure\_Train\_Trip)

Table 181: State Machines of diagram\_Procedure\_Train\_Trip\_1

State Machine	Comments and Information
SM_Train_Trip	

Table 182: States of diagram\_Procedure\_Train\_Trip\_1

State	Comments and Information
SM_Train_Trip:Post_Trip_Mode	
SM_Train_Trip:Procedure_SH_Initiated_By_Driver	
SM_Train_Trip:SH_Mode	
SM_Train_Trip:SN_Mode	
SM_Train_Trip:Train_Trip_procedure_off	
SM_Train_Trip:Trip_Mode	
SM_Train_Trip:Trip_Mode_Waiting_Ack	
SM_Train_Trip:UN_Mode	
SM_Train_Trip:Wait_RBC_Ack	
SM_Train_Trip:Waiting_Driver_Selection	

**Table 183: Transitions of diagram\_Procedure\_Train\_Trip\_1**

Source/Target	#	Conditions/Actions	Comments and Information
<b>Source:</b> SM_Train_Trip:Post_Trip_Mode <b>Target:</b> SM_Train_Trip:Waiting_Driver_Selection	1	<b>Condition:</b> Current_Level = M_LEVEL_Level_1	
<b>Source:</b> SM_Train_Trip:Post_Trip_Mode <b>Target:</b> SM_Train_Trip:Wait_RBC_Ack	2	<b>Condition:</b> Current_Level = M_LEVEL_Level_2 or Current_Level = M_LEVEL_Level_3	
<b>Source:</b> SM_Train_Trip:Post_Trip_Mode <b>Target:</b> SM_Train_Trip:Procedure_SH_Initialized_By_Driver	3	<b>Condition:</b> Driver_Req_SH	
<b>Source:</b> SM_Train_Trip:Train_Trip_procedure_off <b>Target:</b> SM_Train_Trip:Trip_Mode	1	<b>Condition:</b> Loc_Procedure_Possible and Condition_To_Trip <b>Actions:</b>	<b>Comments:</b> S0 : start of procedure is possible
<b>Source:</b> SM_Train_Trip:Trip_Mode <b>Target:</b> SM_Train_Trip:Trip_Mode_Waiting_Ack	1	<b>Condition:</b> Train_Standstill <b>Actions:</b>	
<b>Source:</b> SM_Train_Trip:Trip_Mode_Waiting_Ack <b>Target:</b> SM_Train_Trip:Post_Trip_Mode	1	<b>Condition:</b> Driver_Ack_TR	
	1	<b>Condition:</b> Current_Level = M_LEVEL_Level_1 or Current_Level = M_LEVEL_Level_2 or Current_Level = M_LEVEL_Level_3	
<b>Source:</b> SM_Train_Trip:Trip_Mode_Waiting_Ack <b>Target:</b> SM_Train_Trip:SH_Mode	1	<b>Condition:</b> Driver_Ack_TR	
	2	<b>Condition:</b> not Valid_Train_Data_Stored and (Current_Level = M_LEVEL_Level_0 or Current_Level = M_LEVEL_Level_NTC_specified_by_NID_NTC)	
<b>Source:</b> SM_Train_Trip:Trip_Mode_Waiting_Ack <b>Target:</b> SM_Train_Trip:UN_Mode	1	<b>Condition:</b> Driver_Ack_TR	
	3	<b>Condition:</b> Valid_Train_Data_Stored <b>Actions:</b>	
	1	<b>Condition:</b> Current_Level = M_LEVEL_Level_0 <b>Actions:</b>	

Source/Target	#	Conditions/ Actions	Comments and Information
<b>Source:</b> SM_Train_Trip:Trip_Mode_Waiting_Ack <b>Target:</b> SM_Train_Trip:SN_Mode	1	<b>Condition:</b> Driver_Ack_TR	
	3	<b>Condition:</b> Valid_Train_Data_Stored <b>Actions:</b>	
	2	<b>Condition:</b> Current_Level = M_LEVEL_Level_NTC_specified_by_NID_NTC <b>Actions:</b>	
<b>Source:</b> SM_Train_Trip:Wait_RBC_Ack <b>Target:</b> SM_Train_Trip:Waiting_Driver_Selection	1	<b>Condition:</b> RCB_Ack_And_EB_Revoked	
<b>Source:</b> SM_Train_Trip:Waiting_Driver_Selection <b>Target:</b> SM_Train_Trip:Procedure_SH_Initiated_By_Driver	1	<b>Condition:</b> Driver_Req_SH <b>Actions:</b>	

### 3.6.9. Procedure\_With\_Mode\_Profile Operator

Declared as **public node**

#### 3.6.9.1. Interface

**Table 184: Inputs of Procedure\_With\_Mode\_Profile**

Name	Type	Comments and Information
Current_Mode	Level_And_Mode_Types_Pkg::T_Mode	
Driver_Ack_Mode_Profile	bool	
Mode_Profile_On_Board	Level_And_Mode_Types_Pkg::T_Mode_Profile	
Procedure_Possible	bool	
Profile_Mode	Level_And_Mode_Types_Pkg::T_MA	
Selected_Mode	Level_And_Mode_Types_Pkg::T_Mode	
Supervision_Modes	bool	
Train_Position	TrainPosition_Types_Pkg::trainPosition_T	
Train_Speed	Obu_BasicTypes_Pkg::Speed_T	

**Table 185: Outputs of Procedure\_With\_Mode\_Profile**

Name	Type	Properties	Comments and Information
Condition_15_50_70	bool	default false	

Name	Type	Properties		Comments and Information
Condition_34_61_71	bool	default	false	
Condition_40_51_72	bool	default	false	
Condition_73_74	bool	default	false	
Service_Brake_Command	bool	default	false	
Ack_Req_To_Driver	bool			

### 3.6.9.2. Locals

**Table 186: Locals of Procedure\_With\_Mode\_Profile**

Name	Type	Properties		Comments and Information
Loc_Confirmation	bool	default	true	
		last	true	
Loc_Mode_Available	bool			
Loc_Mode_Profile_Condition	bool			
Loc_Supervision_Condition_Covered	bool			
Loc_Timer	int	default	0	
		last	0	

**Table 187: Signals of Procedure\_With\_Mode\_Profile**

Name	Comments and Information
Loc_Ack_Req_To_Driver	

### 3.6.9.3. Operator Hierarchy

diagram : diagram\_Procedure\_With\_Mode\_Profile\_1

*state-machine* : SM\_Mode\_Profile\_By\_Trackside

state : Current\_Location

*state-machine* : SM\_Current\_Location

state : Ack\_Not\_Received

state : Req\_Current\_Location

state : Switch\_Autorized\_Waiting\_Ack

*activate if* : IfBlock1

branch : then

branch : else

branch : then

branch : else

state : Switch\_Mode\_Confirmed

state : Waiting\_Ack

state : Futher\_location

*state-machine* : SM\_Futher\_Location

state : Req\_Futher\_Location

state : Start\_Supervision

state : Switch\_Mode\_Confirmed

state : Waiting\_Ack  
state : Procedure\_Off

3.6.9.4. Graphical and Textual Diagrams

3.6.9.4.1. View of diagram\_Procedure\_With\_Mode\_Profile\_1  
(Procedure\_With\_Mode\_Profile)




Figure 56: View of diagram\_Procedure\_With\_Mode\_Profile\_1 (Procedure\_With\_Mode\_Profile)

Table 188: Counter (#8) hidden inputs assignment of diagram\_Procedure\_With\_Mode\_Profile\_1

Rank	Name	Value
1	Reset	wired (_L4)

Table 189: State Machines of diagram\_Procedure\_With\_Mode\_Profile\_1

State Machine	Comments and Information
SM_Mode_Profile_By_Tracksi de	
SM_Mode_Profile_By_Tracksi de:Current_Location:SM_Cur rent_Location	
SM_Mode_Profile_By_Tracksi de:Futther_location:SM_Futhe r_Location	

**Table 190: States of diagram\_Procedure\_With\_Mode\_Profile\_1**

State	Comments and Information
SM_Mode_Profile_By_Trackside:Current_Location	
SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location:Ack_Not_Received	<b>Comments:</b> SRS § 5.7.2.4, 5.9.2.4, 5.19.2.4 SRS § 5.7.3.7, 5.9.3.8, 5.19.3.8
SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location:Req_Current_Location	
SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location:Switch_Authorized_Waiting_Ack	<b>Comments:</b> SRS § 5.7.2.3, 5.9.2.3, 5.19.2.3 §4.6.3 : Condition 34 : "(An ackn. request for On Sight is displayed to the driver) AND (the driver acknowledges) see {1} here under" §4.6.3 : Condition 61 : "(An ackn. request for Shunting is displayed to the driver) AND (the driver acknowledges) see {5} here under" §4.6.3 : Condition 71 : "(A Mode Profile defining a Limited Supervision area is on-board) AND (The max safe front end of the train is inside the Limited Supervision area) AND (The ERTMS/ETCS level switches to 1,2 or 3)" §4.6.3 : Condition 40 : "(An ackn. request for On Sight is displayed to the driver) AND (the driver acknowledges) see {1} here under" §4.6.3 : Condition 51 : "(A Mode Profile defining the entry of a Shunting area is used on-board) AND (The max safe front end of the train is inside the Shunting area)" §4.6.3 : Condition 72 : "(A Mode Profile defining a Limited Supervision area is on-board) AND (The max safe front end of the train is inside the Limited Supervision area)." §4.6.3 : Condition 73 : "(A Mode Profile defining an On Sight area is on-board) AND (The max safe front end of the train is inside the On Sight area) AND (The estimated front end of the train is not inside an LS acknowledgement area)" §4.6.3 : Condition 74 : "(A Mode Profile defining a Limited Supervision area is on-board) AND (The max safe front end of the train is inside the Limited Supervision area) AND (The estimated front end of the train is not inside an OS acknowledgement area)"
SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location:Switch_Mode_Confirmed	<b>Comments:</b> §4.6.3 : Condition 15 : "(An ackn. request for On Sight is displayed to the driver) AND (the driver acknowledges) see {1} here under" §4.6.3 : Condition 50 : "(An ackn. request for Shunting is displayed to the driver) AND (the driver acknowledges) see {5} here under" §4.6.3 : Condition 70 : "(An ackn. request for Limited Supervision is displayed to the driver) AND (the driver acknowledges) see {7} here under"
SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location:Waiting_Ack	<b>Comments:</b> SRS § 5.7.4.1, 5.9.5.1, 5.19.5.1
SM_Mode_Profile_By_Trackside:Futher_Location	



State	Comments and Information
SM_Mode_Profile_By_Trackside:Futher_Location:SM_Futher_Location:Req_Futher_Location	
SM_Mode_Profile_By_Trackside:Futher_Location:SM_Futher_Location:Start_Supervision	
SM_Mode_Profile_By_Trackside:Futher_Location:SM_Futher_Location:Switch_Mode_Confirmed	<b>Comments:</b> SRS § 5.7.3.5, 5.9.3.6, 5.19.3.6 §4.6.3 : Condition 15 : "(An ackn. request for On Sight is displayed to the driver) AND (the driver acknowledges) see {1} here under" §4.6.3 : Condition 50 : "(An ackn. request for Shunting is displayed to the driver) AND (the driver acknowledges) see {5} here under" §4.6.3 : Condition 70 : "(An ackn. request for Limited Supervision is displayed to the driver) AND (the driver acknowledges) see {7} here under"
SM_Mode_Profile_By_Trackside:Futher_Location:SM_Futher_Location:Waiting_Ack	<b>Comments:</b> SRS § 5.7.3.3,, 5.9.3.5, 5.19.3.5
SM_Mode_Profile_By_Trackside:Procedur e_Off	

**Table 191: Transitions of diagram\_Procedure\_With\_Mode\_Profile\_1**

Source/Target	#	Conditions/Actions	Comments and Information
<b>Source:</b> SM_Mode_Profile_By_Trackside:Current_Location <b>Target:</b> SM_Mode_Profile_By_Trackside:Procedur e_Off	1	<b>Condition:</b> not Procedure_Possible and last 'Loc_Confirmation	
<b>Source:</b> SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location :Ack_Not_Received <b>Target:</b> SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location :Switch_Mode_Confirmed	1	<b>Condition:</b> Driver_Ack_Mode_Profile <b>Actions:</b>	
<b>Source:</b> SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location :Req_Current_Location <b>Target:</b> SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location :Switch_Autorized_Waiting_Ack	1	<b>Condition:</b> Current_Mode = Level_And_Mode_Type s_Pkg::UN or Current_Mode = Level_And_Mode_Type s_Pkg::SN or Current_Mode = Level_And_Mode_Type s_Pkg::SR or Supervision_Modes <b>Actions:</b> emit 'Loc_Ack_Req_To_Driver;	

Source/Target	#	Conditions/ Actions	Comments and Information
<b>Source:</b> SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location:Req_Current_Location <b>Target:</b> SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location:Waiting_Ack	2	<b>Condition:</b> Current_Mode = Level_And_Mode_Type s_Pkg::SB or Current_Mode = Level_And_Mode_Type s_Pkg::PT <b>Actions:</b> emit 'Loc_Ack_Req_To_Driver';	
<b>Source:</b> SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location:Switch_Autorized_Waiting_Ack <b>Target:</b> SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location:Switch_Mode_Confirmed	1	<b>Condition:</b> Driver_Ack_Mode_Profile <b>Actions:</b>	
<b>Source:</b> SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location:Switch_Autorized_Waiting_Ack <b>Target:</b> SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location:Ack_Not_Received	2	<b>Condition:</b> last 'Loc_Timer > Level_And_Mode_Type s_Pkg::C_Driver_Ack_Delay <b>Actions:</b>	
<b>Source:</b> SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location:Waiting_Ack <b>Target:</b> SM_Mode_Profile_By_Trackside:Current_Location:SM_Current_Location:Switch_Mode_Confirmed	1	<b>Condition:</b> Driver_Ack_Mode_Profile <b>Actions:</b>	<b>Comments:</b> SRS § 5.7.4.2, 5.9.5.2, 5.19.5.2
<b>Source:</b> SM_Mode_Profile_By_Trackside:Futther_location <b>Target:</b> SM_Mode_Profile_By_Trackside:Procedure_Off	1	<b>Condition:</b> not Procedure_Possible <b>Actions:</b>	
<b>Source:</b> SM_Mode_Profile_By_Trackside:Futther_location <b>Target:</b> SM_Mode_Profile_By_Trackside:Current_Location	2	<b>Condition:</b> Loc_Mode_Profile_Condition	<b>Comments:</b> SRS § 5.7.3.6,, 5.9.3.7, 5.19.3.7
<b>Source:</b> SM_Mode_Profile_By_Trackside:Futther_location:SM_Futther_Location:Req_Futther_Location <b>Target:</b> SM_Mode_Profile_By_Trackside:Futther_location:SM_Futther_Location:Start_Supervision	1	<b>Condition:</b> Supervision_Modes <b>Actions:</b>	<b>Comments:</b> SRS § 5.7.3.2,, 5.9.3.2, 5.19.3.2

Source/Target	#	Conditions/ Actions	Comments and Information
<b>Source:</b> SM_Mode_Profile_By_Trackside:Fut her_location:SM_Futher_Location:S tart_Supervision <b>Target:</b> SM_Mode_Profile_By_Trackside:Fut her_location:SM_Futher_Location: Waiting_Ack	1	<b>Condition:</b> Loc_Supervision_Condi tion_Covered <b>Actions:</b>	<b>Comments:</b> SRS § 5.7.3.2,, 5.9.3.2, 5.19.3.2
<b>Source:</b> SM_Mode_Profile_By_Trackside:Fut her_location:SM_Futher_Location: Waiting_Ack <b>Target:</b> SM_Mode_Profile_By_Trackside:Fut her_location:SM_Futher_Location:S witch_Mode_Confirmed	1	<b>Condition:</b> Driver_Ack_Mode_Profi le <b>Actions:</b>	
<b>Source:</b> SM_Mode_Profile_By_Trackside:Pro cedure_Off <b>Target:</b> SM_Mode_Profile_By_Trackside:Fut her_location	1	<b>Condition:</b> Procedure_Possible <b>Actions:</b>	
	1	<b>Condition:</b> Loc_Mode_Available and not Loc_Mode_Profile_Con dition	
<b>Source:</b> SM_Mode_Profile_By_Trackside:Pro cedure_Off <b>Target:</b> SM_Mode_Profile_By_Trackside:Cur rent_Location	1	<b>Condition:</b> Procedure_Possible <b>Actions:</b>	
	2	<b>Condition:</b> Loc_Mode_Available and Loc_Mode_Profile_Con dition	

**Table 192: Conditional Blocks of diagram\_Procedure\_With\_Mode\_Profile\_1**

Conditional Block	Comments and Information
SM_Mode_Profile_By_Tracksi de:Current_Location:SM_Cur rent_Location:Switch_Autoriz ed_Waiting_Ack:IfBlock1	

**Table 193: Actions of diagram\_Procedure\_With\_Mode\_Profile\_1**

Conditional Block Action	Comments and Information
SM_Mode_Profile_By_Trackside:Current_ Location:SM_Current_Location:Switch_Au torized_Waiting_Ack:IfBlock1:then	
SM_Mode_Profile_By_Trackside:Current_ Location:SM_Current_Location:Switch_Au torized_Waiting_Ack:IfBlock1:else:then	
SM_Mode_Profile_By_Trackside:Current_ Location:SM_Current_Location:Switch_Au torized_Waiting_Ack:IfBlock1:else:else	

### 3.6.10. SH\_Initiated\_By\_Driver\_On Operator

Declared as **public node**

#### 3.6.10.1. Interface

**Table 194: Inputs of SH\_Initiated\_By\_Driver\_On**

Name	Type	Comments and Information
Current_Level	M_LEVEL	
Driver_Req_SH	bool	
On_Going_Mission	bool	
Shunting_Granted_By_RBC	bool	

**Table 195: Outputs of SH\_Initiated\_By\_Driver\_On**

Name	Type	Properties		Comments and Information
Clean_BG_List_SH_Area	bool	default	false	
Condition5	bool	default	false	
Condition6	bool	default	false	
End_Of_Mission_Procedure_Req	bool	default	false	
SH_Refused_By_RBC_To_DMI	bool	default	false	
Request_For_SH_To_RBC	bool	default	false	

#### 3.6.10.2. Locals

**Table 196: Locals of SH\_Initiated\_By\_Driver\_On**

Name	Type	Comments and Information
Loc_Level_2_3	bool	

#### 3.6.10.3. Operator Hierarchy

diagram : diagram\_SH\_Initiated\_By\_Driver\_On\_1  
    *state-machine* : SM\_SH\_Initiated\_By\_Driver  
        state : Issue\_SH\_Request\_L2\_L3  
        state : SH\_Authorized\_L0\_L1\_LNTC  
        state : SH\_Authorized\_L2\_L3  
        state : SH\_procedure\_possible

### 3.6.10.4. Graphical and Textual Diagrams

#### 3.6.10.4.1. View of diagram\_SH\_Initiated\_By\_Driver\_On\_1 (SH\_Initiated\_By\_Driver\_On)




Figure 57: View of diagram\_SH\_Initiated\_By\_Driver\_On\_1 (SH\_Initiated\_By\_Driver\_On)

Table 197: State Machines of diagram\_SH\_Initiated\_By\_Driver\_On\_1

State Machine	Comments and Information
SM_SH_Initiated_By_Driver	

Table 198: States of diagram\_SH\_Initiated\_By\_Driver\_On\_1

State	Comments and Information
SM_SH_Initiated_By_Driver:Issue_SH_Request_L2_L3	<b>Comments:</b> SRS § 5.6 state A045 : Issue SH request
SM_SH_Initiated_By_Driver:SH_Authorized_L0_L1_LNTC	<b>Comments:</b> SRS § 5.6 state A050: Transition to SH SRS § 5.5.2.3 : Entry in SH mode as End Of Mission §4.6.3 : Condition 5 : "Train is at standstill AND ERTMS/ETCS level is 0 or NTC or 1 AND driver selects Shunting Mode"
SM_SH_Initiated_By_Driver:SH_Authorized_L2_L3	<b>Comments:</b> SRS § 5.6 state A050: Transition to SH SRS § 5.6 state D040: On going Mission SRS § 5.5.2.3 : Entry in SH mode as End Of Mission §4.6.3 : Condition 6 : "Train is at standstill AND ERTMS/ETCS level is 2 or 3 AND reception of the information "Shunting granted by RBC", due to a shunting request from the driver"
SM_SH_Initiated_By_Driver:SH_procedure_possible	<b>Comments:</b> SRS § 5.6 state S0

Table 199: Transitions of diagram\_SH\_Initiated\_By\_Driver\_On\_1

Source/Target	#	Conditions/Actions	Comments and Information
<b>Source:</b> SM_SH_Initiated_By_Driver:Issue_SH_Request_L2_L3 <b>Target:</b> SM_SH_Initiated_By_Driver:SH_Authorized_L2_L3	1	<b>Condition:</b> Shunting_Granted_By_RBC <b>Actions:</b>	<b>Comments:</b> SRS § 5.6 state E09 : SH Authorized

Source/Target	#	Conditions/ Actions	Comments and Information
<b>Source:</b> SM_SH_Initiated_By_Driver:Issue_SH_Request_L2_L3 <b>Target:</b> SM_SH_Initiated_By_Driver:SH_procedure_possible	2	<b>Condition:</b> not Shunting_Granted_By_RBC <b>Actions:</b> SH_Refused_By_RBC_To_DMI = true;	<b>Comments:</b> SRS § 5.6 state E215 : transition SH refused
<b>Source:</b> SM_SH_Initiated_By_Driver:SH_procedure_possible <b>Target:</b> SM_SH_Initiated_By_Driver:SH_Authorized_L0_L1_LNTC	1	<b>Condition:</b> Driver_Req_SH <b>Actions:</b>	<b>Comments:</b> SRS § 5.6 state E015 transition : Driver selects shunting
	1	<b>Condition:</b> not Loc_Level_2_3 <b>Actions:</b>	
<b>Source:</b> SM_SH_Initiated_By_Driver:SH_procedure_possible <b>Target:</b> SM_SH_Initiated_By_Driver:Issue_SH_Request_L2_L3	1	<b>Condition:</b> Driver_Req_SH <b>Actions:</b>	<b>Comments:</b> SRS § 5.6 state E015 transition : Driver selects shunting
	2	<b>Condition:</b> Loc_Level_2_3 <b>Actions:</b>	<b>Comments:</b> D020 : Level 2 or 3

End of document.