

Table 58 Input data, *.OPT, for "MAINSETUP" for the **unstiffened** equivalent ellipsoidal shell. This file is called "egellipse.unstiffened.OPT". Change the case name from "egellipse.unstiffened" to "egellipse" before processing.

```
=====
n      $ Do you want a tutorial session and tutorial output?
0      $ Choose an analysis you DON'T want (1, 2,...), IBEHAV
0      $ Choose an analysis you DON'T want (1, 2,...), IBEHAV
0      $ NPRINT= output index (0=GOOD, 1=ok, 2=debug, 3=too much)
1      $ Choose type of analysis (1=opt., 2=fixed, 3=sensit.) ITYPE
5      $ How many design iterations in this run (3 to 25)?
n      $ Take "shortcuts" for perturbed designs (Y or N)?
2      $ Choose 1 or 2 or 3 or 4 or 5 for IDESIGN
1      $ Choose 1 or 2 or 3 or 4 or 5 for move limits, IMOVE
y      $ Do you want default (RATIO=10) for initial move limit jump?
y      $ Do you want the default perturbation (dx/x = 0.05)?
y      $ Do you want to have dx/x modified by GENOPT?
n      $ Do you want to reset total iterations to zero (Type H)?
=====
```

NOTES:

1. The input line for IBEHAV is repeated NCASES times, where NCASES = the number of load sets. In this case there are two load sets, the first corresponding to shells with +mode 1 and +mode 2 axisymmetric imperfection shapes and the second corresponding to shells with -mode 1 and -mode 2 axisymmetric imperfection shapes.

2. For definitions of IDESIGN, IMOVE, and RATIO see the file URPROMPT.DAT, which is listed in Table a24 of the appendix.