


## The map of Call of Duty: Mobile

### Group-21



## IP Address Table:

Network	Port	IP Address	Subnet Masks
Shipment	FA0/0	192.168.0.1	255.255.255.240
	S0/0/0	192.168.0.157	255.255.255.252
	S0/1/0	192.168.0.161	255.255.255.252
	S0/3/1	192.168.0.138	255.255.255.252
Farm	FA0/0	192.168.0.49	255.255.255.240
	S0/0/0	192.168.0.165	255.255.255.252
	S0/1/0	192.168.0.130	255.255.255.252
	S0/1/1	192.168.0.134	255.255.255.252
	S0/3/0	192.168.0.141	255.255.255.252
	S0/3/1	192.168.0.137	255.255.255.252
Seaside	FA0/0	192.168.0.17	255.255.255.240
	S0/1/0	192.168.0.129	255.255.255.252
	S0/1/1	192.168.0.169	255.255.255.252
Nuketown	FA0/0	192.168.0.33	255.255.255.240
	S0/1/1	192.168.0.133	255.255.255.252
	S0/2/0	192.168.0.173	255.255.255.252
NuclearPlant	FA0/0	192.168.0.97	255.255.255.240
	S0/3/0	192.168.0.177	255.255.255.252
	S0/3/1	192.168.0.154	255.255.255.252
Countdown	FA0/0	192.168.0.65	255.255.255.240
	S0/1/1	192.168.0.146	255.255.255.252
	S0/3/1	192.168.0.181	255.255.255.252
Sakura	FA0/0	192.168.0.81	255.255.255.240
	S0/1/0	192.168.0.150	255.255.255.252
	S0/2/1	192.168.0.185	255.255.255.252
Launch	FA0/0	192.168.0.113	255.255.255.240
	S0/0/0	192.168.0.158	255.255.255.252
	S0/0/1	192.168.0.189	255.255.255.252
	S0/1/0	192.168.0.149	255.255.255.252
	S0/1/1	192.168.0.145	255.255.255.252
	S0/3/0	192.168.0.142	255.255.255.252
	S0/3/1	192.168.0.153	255.255.255.252
Center	S0/0/0	192.168.0.166	255.255.255.252
	S0/0/1	192.168.0.190	255.255.255.252
	S0/1/0	192.168.0.162	255.255.255.252
	S0/1/1	192.168.0.170	255.255.255.252
	S0/2/0	192.168.0.174	255.255.255.252
	S0/2/1	192.168.0.186	255.255.255.252
	S0/3/0	192.168.0.178	255.255.255.252
	S0/3/1	192.168.0.182	255.255.255.252

## Network Address Table:

Network	IP Address	Subnet masks
Topology	192.168.0.0	255.255.255.0
Shipment	192.168.0.0	255.255.255.240
Seaside	192.168.0.16	255.255.255.240
Nuketown	192.168.0.32	255.255.255.240
Farm	192.168.0.48	255.255.255.240
Countdown	192.168.0.64	255.255.255.240
Sakura	192.168.0.80	255.255.255.240
Nuclear Plant	192.168.0.96	255.255.255.240
Launch	192.168.0.112	255.255.255.240
Seaside – Farm	192.168.0.128	255.255.255.252
Nuketown – Farm	192.168.0.132	255.255.255.252
Shipment – Farm	192.168.0.136	255.255.255.252
Launch – Farm	192.168.0.140	255.255.255.252
Countdown – Launch	192.168.0.144	255.255.255.252
Sakura – Launch	192.168.0.148	255.255.255.252
Nuclear Plant - Launch	192.168.0.152	255.255.255.252
Shipment - Launch	192.168.0.156	255.255.255.252
Shipment-Center	192.168.0.160	255.255.255.252
Farm-Center	192.168.0.164	255.255.255.252
Seaside-Center	192.168.0.168	255.255.255.252
Nuketown-Center	192.168.0.172	255.255.255.252
Nuclear Plant-Center	192.168.0.176	255.255.255.252
Countdown-Center	192.168.0.180	255.255.255.252
Sakura-Center	192.168.0.184	255.255.255.252
Launch-Center	192.168.0.188	255.255.255.252

## The Configuration of all Routers:

### Launch:

Router>enable

Router#config t

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#ip route 192.168.0.96 255.255.255.240 s0/3/1

Router(config)#ip route 192.168.0.80 255.255.255.240 s0/1/0

```
Router(config)#ip route 192.168.0.80 255.255.255.240 s0/1/0
Router(config)#ip route 192.168.0.64 255.255.255.240 s0/1/1
Router(config)#ip route 192.168.0.140 255.255.255.252 s0/3/0
Router(config)#ip route 192.168.0.48 255.255.255.240 192.168.0.140
Router(config)#ip route 0.0.0.0 0.0.0.0 s0/3/0
Router(config)#ip route 0.0.0.0 0.0.0.0 s0/0/1 5
Router(config)#
```

### **NuclearPlant:**

```
Router>enable
Router#config t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#ip route 192.168.0.112 255.255.255.240 s0/3/1
Router(config)#ip route 192.168.0.80 255.255.255.240 192.168.0.152
Router(config)#ip route 192.168.0.64 255.255.255.240 192.168.0.152
Router(config)#
Router(config)#
Router>enable
Router#config t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#ip route 0.0.0.0 0.0.0.0 s0/3/1
Router(config)#ip route 0.0.0.0 0.0.0.0 s0/3/0 5
```

### **Sakura:**

```
Router>enable
Router#config t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#ip route 192.168.0.112 255.255.255.240 s0/1/0
Router(config)#ip route 192.168.0.64 255.255.255.240 192.168.0.148
Router(config)#ip route 192.168.0.96 255.255.255.240 192.168.0.148
Router(config)#
```

Router>enable

Router#config t

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#ip route 0.0.0.0 0.0.0.0 s0/1/0

Router(config)#ip route 0.0.0.0 0.0.0.0 s0/2/1 5

## Countdown:

Router>enable

Router#config t

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#ip route 192.168.0.112 255.255.255.240 s0/1/1

Router(config)#ip route 192.168.0.80 255.255.255.240 192.168.0.144

Router(config)#ip route 192.168.0.96 255.255.255.240 192.168.0.144

Router(config)#

Router>enable

Router#config t

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#ip route 0.0.0.0 0.0.0.0 s0/1/1

Router(config)#ip route 0.0.0.0 0.0.0.0 s0/3/1 5

## Shipment:

Router>enable

Router#config t

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#router rip

Router(config-router)#version 2

Router(config-router)#no auto

Router(config-router)#no auto-summary

Router(config-router)#network 192.168.0.0

Router(config-router)#network 192.168.0.136

```
//Router(config-router)#passive-interface fa0/0
Router(config-router)#default-information originate
^
% Invalid input detected at '^' marker.
Router(config-router)#default-information originate
Router(config-router)#end
Router#
```

%SYS-5-CONFIG\_I: Configured from console by console

Router#copy run start

Destination filename [startup-config]?

Building configuration...

[OK]

Router#

Router>enable

Router#config t

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#ip route 0.0.0.0 0.0.0.0 s0/3/1

Router(config)#ip route 0.0.0.0 0.0.0.0 s0/1/0 5

## Seaside:

Router>enable

Router#config t

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#router rip

Router(config-router)#version 2

Router(config-router)#no auto

Router(config-router)#no auto-summary

Router(config-router)#network 192.168.0.16

Router(config-router)#network 192.168.0.128

//Router(config-router)#passive-interface fa0/0

```
Router(config-router)#default-information originate
Router(config-router)#end
Router#
%SYS-5-CONFIG_I: Configured from console by console
Router#copy run strat
^
% Invalid input detected at '^' marker.
Router#copy run start
Destination filename [startup-config]?
Building configuration...
[OK]
Router#
Router>enable
Router#config t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#ip route 0.0.0.0 0.0.0.0 s0/1/0
Router(config)#ip route 0.0.0.0 0.0.0.0 s0/1/1 5
```

## **Nuketown:**

```
Router>enable
Router#config t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#router rip
Router(config-router)#version 2
Router(config-router)#no auto
Router(config-router)#no auto-summary
Router(config-router)#network 192.168.0.32
Router(config-router)#network 192.168.0.132
//Router(config-router)#passive-interface fa0/0
Router(config-router)#default-information originate
Router(config-router)#end
```

```
Router#
%SYS-5-CONFIG_I: Configured from console by console
Router#copy run start
Destination filename [startup-config]?
Building configuration...
[OK]
Router#
Router>enable
Router#config t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#ip route 0.0.0.0 0.0.0.0 s0/1/1
Router(config)#ip route 0.0.0.0 0.0.0.0 s0/2/0 5
```

## **Farm:**

```
Router>enable
Router#config t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#router rip
Router(config-router)#version 2
Router(config-router)#no auto
Router(config-router)#no auto-summary
Router(config-router)#network 192.168.0.48
Router(config-router)#network 192.168.0.132
Router(config-router)#network 192.168.0.128
Router(config-router)#network 192.168.0.136
Router(config-router)#network 192.168.0.140
Router(config-router)#network 192.168.0.112
Router(config-router)#network 192.168.0.140
//Router(config-router)#passive-interface fa0/0
Router(config-router)#default-information originate
Router(config-router)#end
```



Router#

%SYS-5-CONFIG\_I: Configured from console by console

Router#copy run start

Destination filename [startup-config]?

Building configuration...

[OK]

Router#

Router>enable

Router#config t

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#ip route 0.0.0.0 0.0.0.0 s0/3/0

Router(config)#ip route 0.0.0.0 0.0.0.0 s0/0/0 5

## **Center:**

Router(config)#ip route 0.0.0.0 0.0.0.0 s0/1/0 5

Router(config)#ip route 0.0.0.0 0.0.0.0 s0/0/0 5

Router(config)#ip route 0.0.0.0 0.0.0.0 s0/1/1 5

Router(config)#ip route 0.0.0.0 0.0.0.0 s0/2/0 5

Router(config)#ip route 0.0.0.0 0.0.0.0 s0/3/0 5

Router(config)#ip route 0.0.0.0 0.0.0.0 s0/3/1 5

Router(config)#ip route 0.0.0.0 0.0.0.0 s0/2/1 5

Router(config)#ip route 0.0.0.0 0.0.0.0 s0/0/1 5