

OpenCockpits A320 Chronometer Module

Hidls result:

Device Found

```
Vendor id:    0000
Product id:   001c
Device path:  /dev/hidraw0
Serial_number:
Manufacturer: Opencockpits
Product:      IOCard-Chrono320
```

Initialization string: AA AA AA AA AA AA AA 0F
(i.e. blank off all display digits and decimal points)

- Buttons and switches (reported in single 8-byte packet, every 10-11 seconds!):

- Idle state (every 10-11 seconds): 1 1 0 0 . 1 1 1 1 1 1 1 C70B

- PushButtons (values Off = 0, On = 1):

```
RST      byte 6 bit 3  . . . . . . . . 1 . . . C70A
CLK_CHR  byte 7 bit 0  . . . . . . . 0 . . . . C60B
CLK_DATE byte 6 bit 0  . . . . . . . . . . . 1 C70A
```

- Encoder (turning right, 4 steps): B 9 D F C70X

```
UTC      byte 6 bit 2-1 . 0 1 . | . 0 0 . | . 1 0 . | . 1 1 .
```

- Switches (normally 0; 1 when selected):

```
GPS_OFF  byte 7 bit 7-6 1 1 . . . . . . . . C70B
GPS_INT  byte 7 bit 7-6 1 0 . . . . . . . . 870B
GPS_SET  byte 7 bit 7-6 0 1 . . . . . . . . 470B
RUN_OFF  byte 7 bit 2-1 . . . . . 1 1 . . . . C70B
RUN_STP  byte 7 bit 2-1 . . . . . 1 0 . . . . C50B
RUN_RST  byte 7 bit 2-1 . . . . . 0 1 . . . . C30B
```

- (Bytes 5 - 0 always 0)

- Displays (encoded in single 8bit output buffer):

```
CL_CHR   bytes 7 - 6
CL_UTC   bytes 5 - 3
CL_ET    bytes 2 - 1
DOT_CHR  byte 0 bit 4
DOT_UTC1 byte 0 bit 6
DOT_UTC2 byte 0 bit 5
DOT_ET   byte 0 bit 7
```

- (byte 0 bits 3 - 0 always 1)

OpenCockpits A320 Chronometer Module

X-Plane datarefs / commands:

RST	Clock_timer_reset	sim/instruments/timer_reset
CHR	Clock_timer_start_s	sim/instruments/timer_start_stop
SET	Clock_date_time	sim/instruments/timer_show_date
RUN	Clock_ET_StartStop	AirbusFBW/ClockETSwitch
	Clock_timer_minutes	sim/cockpit2/clock_timer/elapsed_time_minutes
	Clock_timer_seconds	sim/cockpit2/clock_timer/elapsed_time_seconds
	Clock_UTC_year	-nothing; all zeroes!-
	Clock_UTC_month	sim/cockpit2/clock_timer/current_month
	Clock_UTC_day	sim/cockpit2/clock_timer/current_day
	Clock_UTC_hours	sim/cockpit2/clock_timer/zulu_time_hours
	Clock_UTC_minutes	sim/cockpit2/clock_timer/zulu_time_minutes
	Clock_UTC_seconds	sim/cockpit2/clock_timer/zulu_time_seconds
	Clock_ET_hours	AirbusFBW/ClockETHours
	Clock_ET_minutes	AirbusFBW/ClockETMinutes

Available in X-Plane 10.41:

%sim/instruments/timer_cycle		Timer start-stop-reset.
%sim/instruments/timer_is_GMT		Timer is GMT.
%sim/instruments/timer_mode		Timer/Clock mode for chronos.
%sim/instruments/timer_reset		Reset the timer.
%sim/instruments/timer_show_date		Show date on the chrono.
%sim/instruments/timer_start_stop		Start or stop the timer.
sim/cockpit2/clock_timer/current_day	day	Numeric day of month
sim/cockpit2/clock_timer/current_month	month	Numeric month of the year
sim/cockpit2/clock_timer/date_is_showing	boolean	True if date is showing (date button pressed recently)
sim/cockpit2/clock_timer/elapsed_time_hours	hours	Elapsed time on the timer, hours
sim/cockpit2/clock_timer/elapsed_time_minutes	minutes	Elapsed time on the timer, minutes
sim/cockpit2/clock_timer/elapsed_time_seconds	seconds	Elapsed time on the timer, seconds
sim/cockpit2/clock_timer/hobbs_time_hours	hours	Hobbs meter time, hours
sim/cockpit2/clock_timer/hobbs_time_minutes	minutes	Hobbs meter time, minutes
sim/cockpit2/clock_timer/hobbs_time_seconds	seconds	Hobbs meter time, seconds
sim/cockpit2/clock_timer/local_time_hours	hours	Local time, hours
sim/cockpit2/clock_timer/local_time_minutes	minutes	Local time, minutes
sim/cockpit2/clock_timer/local_time_seconds	seconds	Local time, seconds
sim/cockpit2/clock_timer/timer_is_GMT	boolean	True if time shown is GMT
sim/cockpit2/clock_timer/timer_mode	enum	TODO
sim/cockpit2/clock_timer/timer_running	boolean	True if timer is running
sim/cockpit2/clock_timer/zulu_time_hours	hours	Zulu time, hours
sim/cockpit2/clock_timer/zulu_time_minutes	minutes	Zulu time, minutes
sim/cockpit2/clock_timer/zulu_time_seconds	seconds	Zulu time, seconds

(Not all of these are actually used...)

Hans Jansen 2020-06-10