
Misc

[Jump to bottom](#)

tagyoureit edited this page on Jan 17, 2017 · 1 revision

Miscellaneous

🔗 Circuit bitmask

The Pentair bus sends many packets in bitmask form. One of these you will find is the [Circuits/Features](#) bits 7, 8, 9. Each binary bit is an on/off signal for a circuit.

0x00000001 = 1 = Only 1st circuit is on

0x00000010 = 2 = Only 2nd circuit is on

...

0x0010101 = 21 = Circuits 1, 3, and 5 are on

Bit 7 is for circuits 1-8, Bit 8 is for 9-16 and Bit 9 is for 17-24.

Spa Pool Heat Mode

Seen in Action = 8 [Temp/Heat status](#) and Action = Pentair controller sends the pool and spa heat status as a 4 digit binary byte from 0000 (0) to 1111 (15). The left two (xx__) is for the spa and the right two (__xx) are for the pool. EG 1001 (9) would mean 10xx = 2 (Spa mode Solar Pref) and xx01 = 1 (Pool mode Heater)

Day of week

In the [Time Clock Broadcast](#) this is (Sun=1, Mon=2, Tue=4, Wed=8, Thu=16, Fri=32, Sat=64)

Sunday = 0x00000001

Monday = 0x00000010

Tuesday = 0x00000100

Wednesday = 0x00001000

Thursday = 0x00010000

Friday = 0x00100000

Saturday = 0x01000000

However, this is different in the [Configuration schedules](#) Bitmask 0x00000000; 181 = Tu,Th,Fri,Sun; 145 = Thu,Sun; 255 = Every day; Need to do more research but it seems like 0x01 is always active and 128=Sun; 16=Thu... need to just do some testing.

▼ Pages 12

[Home](#)

[Addresses](#)

[Broadcast](#)

[Chlorinator](#)

[Circuit Names](#)

[Configuration](#)

[How to capture all packets for issue resolution](#)

[Integrations in 2.0](#)

[Misc](#)

[Pool Packet Capture Guide for Dummies](#)

[Pumps](#)

[RS 485 Adapter Details](#)

Clone this wiki locally

<https://github.com/tagyoureit/nodejs-poolController.wiki.git>

