

Analysis Report for: 935CEE80F3AA1E309823914D3553573B.exe.c

Overall Functionality

This C code appears to be a DLL (Dynamic Link Library) that acts as a wrapper or intermediary for a CAN (Controller Area Network) device driver. It loads multiple CAN driver instances from different DLLs, manages their lifecycle (opening, closing, initialization), and provides a unified interface to access their functionalities (reading/writing data, getting status, etc.). The code also incorporates custom memory management, possibly to avoid using the standard C heap allocation functions. The heavy use of function pointers suggests dynamic loading and dispatching of CAN-related operations. The error handling is rudimentary, primarily setting an error code in `dword_1000BE20`.

Function Summaries

***DIIMain(HINSTANCE hinstDLL, DWORD fdwReason, LPVOID lpvReserved)** The DLL entry point. Initializes the library on process attach (`fdwReason == 1`) and cleans up on process detach (`fdwReason == 0`). Returns `TRUE` for success, `FALSE` for failure.

***sub_10001060(char *Str)** Initializes internal data structures based on the path of the DLL. Loads configuration from an INI file ("kernel.dll.ini"). Returns `TRUE` for success, `FALSE` otherwise.

***sub_100012E0)** Cleans up resources, freeing allocated memory and unloading loaded CAN driver DLLs.

***sub_100013F0)** Reads the number of CAN devices from the configuration INI file. Returns the number of devices.

***sub_10001450(unsigned int Value, LPSTR lpReturnedString)** Retrieves the path to a specific CAN driver DLL from the INI file based on `Value` (device index). Writes the path to `lpReturnedString`. Returns `0` for success, `1` if the string was found in the file, and sets `dword_1000BE20`.

***sub_10001530(int a1)** Sets the error code in `dword_1000BE20`. Returns `a1`.

***sub_10001540(unsigned int Value)** Loads a specific CAN driver DLL and retrieves function pointers to its exported CAN functions. Returns `TRUE` on success, `FALSE` otherwise.

***VCI_OpenDevice(unsigned int Value, int a2, int a3)** Opens a CAN device. Uses function pointers obtained from `sub_10001540`. Returns the result of the underlying driver's `VCI_OpenDevice` call or an error code.

***VCI_CloseDevice(unsigned int a1, int a2)** Closes a CAN device. Similar to `VCI_OpenDevice`, using function pointers.

***VCI_InitCAN(unsigned int a1, int a2, int a3, int a4)** Initializes a CAN channel.

***VCI_ReadBoardInfo(unsigned int a1, int a2, int a3)** Reads board information.

***VCI_ReadErrInfo(unsigned int a1, int a2, int a3, _DWORD *a4)** Reads error information.

***VCI_ReadCANStatus(unsigned int a1, int a2, int a3, _DWORD *a4)** Reads CAN status.

***VCI_GetReference(unsigned int a1, int a2, int a3, int a4, int a5)** Gets a reference.

***VCI_SetReference(unsigned int a1, int a2, int a3, int a4, int a5)** Sets a reference.

***VCI_GetReceiveNum(unsigned int a1, int a2, int a3)** Gets the number of received CAN messages.

***VCI_ClearBuffer(unsigned int a1, int a2, int a3)** Clears the CAN receive buffer.

***VCI_StartCAN(unsigned int a1, int a2, int a3)** Starts CAN communication.

***VCI_Transmit(unsigned int a1, int a2, int a3, int a4, int a5)** Transmits CAN messages.

***VCI_Receive(unsigned int a1, int a2, int a3, int a4, int a5, int a6)** Receives CAN messages.

***sub_10001E27(LPVOID lpMem)** Wrapper for memory deallocation (`sub_10002286`).

***sub_1000218A(unsigned int a1)** Custom memory allocation function.

***sub_10002286(LPVOID lpMem)** Custom memory deallocation function.

***sub_1000253C(FILE *File, char *a2, int a3)** Complex function that seems to handle formatted output, potentially to a log file. Its intricate logic involving various data types and conditional branches makes it difficult to fully summarize concisely.

***sub_10003787(int a1)** Determines the heap type used by the application.

***sub_100037B4)** Detects the OS version and heap selection method (global or per-process).

***sub_100038FC(int a1)** Initializes the custom heap manager.

***sub_10003959():** Destroys the custom heap.

***sub_10003A3A(DWORD NumberOfBytesWritten):** Handles error reporting, possibly writing to the console or displaying a message box.

***sub_10003C1B(_DWORD *a1, int a2):** A complex function related to the custom memory manager's free operation.

***sub_100043F9():** Allocates and initializes the custom heap's data structures.

***sub_1000453D(LPVOID *lpMem):** Frees a block in the custom heap.

***sub_10004593(int a1):** Frees multiple blocks from the custom heap.

***sub_10004655(unsigned int a1, _DWORD *a2, unsigned int *a3):** Finds a block in the custom heap.

***sub_100046AC(int a1, int a2, _BYTE *a3):** Updates usage counters in the custom heap.

***sub_100046F1(unsigned int a1):** Allocates a block in the custom heap.

***sub_100048F9(int a1, unsigned int a2, unsigned int a3):** A helper function for heap allocation, possibly for splitting a block.

***sub_1000541D(int a1, int a2):** Allocates memory using a custom scheme, potentially utilizing a custom heap.

***sub_10006698(unsigned int a1):** Maps error codes.

***sub_1000696A():** Calls a function ('flsall') which is likely involved in thread-local storage cleanup.

****Control Flow****

The control flow is largely determined by function calls and conditional checks on function success or error codes ('dword_1000BE20'). The 'VCI_*' functions all follow a similar pattern: check for valid device index and whether the device is open; then call the corresponding function from the loaded driver. 'sub_1000253C' and the custom memory management functions ('sub_1000218A', 'sub_10002286', 'sub_10004655', 'sub_100046AC', 'sub_100046F1', 'sub_1000453D', 'sub_10004593', 'sub_100048F9', 'sub_1000541D') have complex control flow due to their role in managing data and memory.

****Data Structures****

The code uses several arrays and pointers to manage loaded DLL handles, function pointers, and custom heap data structures. The custom heap appears to be implemented as a linked list of free blocks. The structure's details are obscured by the decompiler, but the functions suggest it involves block sizes, pointers to next free blocks and allocated blocks. 'dword_1000B984' and 'dword_1000BAE8' appear to be lookup tables for error codes.

****Malware Family Suggestion****

Given its functionality as a CAN bus driver wrapper with custom memory management, and dynamic library loading, this code exhibits characteristics that could be associated with ****rootkit**** or ****driver-based malware****. The custom memory allocation and deallocation routines could be used to hide its presence or operations from standard system tools. The loading of multiple CAN drivers based on a configuration file could enable it to adapt to different environments and evade detection. The obfuscated nature of the decompiled code further suggests an intention for stealth. A thorough analysis of the functions and their behavior with respect to the CAN bus would be needed to make a definitive determination. A malicious version could utilize CAN to perform actions undetected and might be designed to target industrial control systems (ICS) for attacks.