


NOW WHAT

How to get the encrypted firmware?

Header Config specifies BURSTCMDA/B Registers

- these control how the SoC talks to the SPI flash
- reconfigure to use single mode (0x03)



Modified FW

50	70	00	20	00	00	00	20	00	00	03	00	00	00	00	00	Pp.
00	00	AA	11	04	00	01	00	02	07	05	8F	FF	FF	FF	FF	.. ^a ÿÿÿÿ
FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	ÿÿÿÿÿÿÿÿÿÿÿÿÿÿÿÿ
FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	ÿÿÿÿÿÿÿÿÿÿÿÿÿÿÿÿ

PROGRESS

Slowing down the target to Single SPI allows capture, showing the SoC accessing the payload at 0x1d4744

CMD	ADDRESS	DATA
NORMAL READ(0X03)	1D 47 44	00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF
NORMAL READ(0X03)	1D 47 60	00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF 00 BF