


UI 示意圖



就是上方的灰色按鈕(暫定名稱 Pen Tip to get FW and GID)被按下後，會去呼叫 Batch file (裏頭會去執行 USIRW.EXE 和接參數)。

例如，會去依序呼叫 2 個 Batch file -- GetFWVersion.bat 和 GetBATTERY.bat

取得 FW 版本資料

下圖這是執行 GetFWVersion.bat 過程。可看到最終印出的

0x6a 0x01 0x1a 0x00 0x5c 0x02 0x44 0x48 0x74 0xc6 0x06 0x00 0x04 0x00

上述紅色這一串才是我們需要的。

```
Microsoft Windows [版本 10.0.18363.1379]
(c) 2019 Microsoft Corporation. 著作權所有，並保留一切權利。

D:\USI\USIRW>USIRW -w=0x6d 0x1
'USIRW' 不是內部或外部命令、可執行的程式或批次檔。

D:\USI\USIRW>USIRW.exe -w=0x6d 0x1
Open path : \\?\hid#vid_0457&pid_1901&col04#6&2f0d3453&0&0003#{4d1e55b2-f16f-11cf-88cb-001111000030}
do w=0x6d 0x1
0x6d 0x1
HID Set Feature succeed.

D:\USI\USIRW>USIRW.exe -r=0x6a 14
Open path : \\?\hid#vid_0457&pid_1901&col04#6&2f0d3453&0&0003#{4d1e55b2-f16f-11cf-88cb-001111000030}
do r=0x6a 14
0x6a 14
HID Get Feature succeed.
0x6a 0x01 0x1a 0x00 0x5c 0x02 0x44 0x48 0x74 0xc6 0x06 0x00 0x04 0x00

D:\USI\USIRW>
```

參照 USI_HID_Cmd_Table_SOP_181120_v03.XLSX 檔，可知 0x6a 0x01 分別為 RptID 和 ID。

後面接的資料 **0x1a 0x00 0x5c 0x02 0x44 0x48 0x74 0xc6 0x06 0x00 0x04 0x00** 才是 FW 版本資料等資料。

根據 USI_Stylus_and_Device_Specification_v1.pdf 第 81 頁

收到的前面 8 Bytes 可區分為 GID0, GID1, GID2, GID3。

然後我們定義這些資料的欄位如下表：

| | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|------|---------------------------|----|----|----|-------------|------------|---|------------------------|---|-------------|---|---|--------------|---------|---|---|
| GID0 | Hour[3:0] | | | | Minute[5:0] | | | | | Second[5:0] | | | | | | |
| GID1 | Year[5:0] | | | | | Month[3:0] | | | | Day[4:0] | | | | Hour[4] | | |
| GID2 | Stylus Integrator ID[7:0] | | | | | | | Stylus Product ID[7:0] | | | | | | | | |
| GID3 | Stylus Vendor ID[11:0] | | | | | | | | | | | | Line ID[3:0] | | | |

GID0 和 GID1 可以直接顯示其日期時間。

GID2 和 GID3 可先直接印出其 16 進制數值即可。

電池電量

Get 到的資料中的第 2byte 的 bit0~bit6 就是 Battery 的值。

```
D:\USI\USIRW>USIRW.exe -w=0x68 0xcc 0x0f 0x08 0x00 0x00 0x00 0x00
Open path : \\?\hid#vid_0457&pid_1901&col04#6&2f0d3453&0&0003#{4d1e55b2-f16f-11cf-88cb-001111000030}
do w=0x68 0xcc 0x0f 0x08 0x00 0x00 0x00 0x00 0x00
0x68 0xcc 0x0f 0x08 0x00 0x00 0x00 0x00 0x00
HID Set Feature succeed.

D:\USI\USIRW>USIRW.exe -w=0x6d 0x01
Open path : \\?\hid#vid_0457&pid_1901&col04#6&2f0d3453&0&0003#{4d1e55b2-f16f-11cf-88cb-001111000030}
do w=0x6d 0x01
0x6d 0x01
HID Set Feature succeed.

D:\USI\USIRW>USIRW.exe -r=0x68 9
Open path : \\?\hid#vid_0457&pid_1901&col04#6&2f0d3453&0&0003#{4d1e55b2-f16f-11cf-88cb-001111000030}
do r=0x68 9
0x68 9
HID Get Feature succeed.
0x68 0x4E 0x00 0x00 0x00 0x00 0x00 0x00 0x00
```

根據 USI_Stylus_and_Device_Specification_v1.pdf 第 78 頁。Get Battery 後取得的資料中，第 2 個 Byte 的 Bit0-Bit6 為電量百分比。Bit7 如果有數值表示電量過低或電池問題需更換電池。

Table 6-14 Stylus Data Fields for the C.GetBattery(...) response

| | | | | | | | | | | | | | | | | |
|----------------------------------|--------------------|----|----|----|----|----|---|---|-----|---------------|---|---|---|---|---|---|
| Response Name: S.GetBattery(...) | | | | | | | | | | | | | | | | |
| | Stylus data fields | | | | | | | | | | | | | | | |
| READ-FLAGS[n]=1 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| n=0 | - | - | - | - | - | - | - | - | Low | StateOfCharge | | | | | | |
| n=1-8 | Reserved | | | | | | | | | | | | | | | |

- **StateOfCharge (SOC):** If available, this field should be used to report the state of charge in the stylus, as a percentage of full charge.
- **Low:**
 0: Stylus power source is ok
 1: Stylus power source is critically low and should be replaced/re-charged