



## CCSP Provisioning and Management Overview

☒ **Draft**

☐ Baselined for Estimates

Author	
Authorized by	
Version	0.1
Date	May 16, 2014

### CONFIDENTIALITY STATEMENT

The information contained herein is proprietary to Comcast and may not be used, reproduced or disclosed to others except as specifically permitted in writing by Comcast. The recipient of this document, by its retention and use, agrees to protect the information contained herein.

## Table of Contents

1	P&M Overview .....	2
2	P&M Component Definitions .....	3
2.1	P&M Architecture.....	3
3	Functional Structure .....	5
3.1	CCSP Message Bus APIs .....	5
3.2	CCSP Message Bus APIs required from other components.....	5
4	P&M System Flow.....	7
4.1	Parameter set/get flow in P&M .....	7
4.2	P&M boot-up flow .....	8
4.3	Instance Number Operation Flow .....	9
5	Glossary .....	9

## List of Figures

**Figure 1 P&M Overview**

**Figure 2 P&M Architecture Overview**


**Figure 3 Parameter Get Flow**

**Figure 4 Parameter Set Flow**

**Figure 5 P&M boot-up flow**

# 1 P&M Overview

P&M is a CCSP component that implements provisioning and management functionality of the device, supporting TR-181 (TR-157, TR-143) along with CCSP specific extensions.



**Figure 1 P&M Overview**

P&M module tracks any changes in the system for the attributes configured by service provider and sends upstream notifications. Any changes to these attributes will be reported to service provider using PA.

## 2 P&M Component Definitions

### 2.1 P&M Architecture

This is the architecture of P&M component:




Figure 2 P&M Architecture Overview



P&M consist three layers:

### 1) Access Layer

Access Layer interfaces with the CCSP message bus and receives any set or get calls and passes them onto the DML layer to manage the data which is in request.

### 2) Data Model Management Layer

- Goal is to support a large number of data model objects for good scalability
- Data Model Management Layer loads all data model access APIs through a pre-defined XML file which contains description of data model objects and parameters.
- The data model implementation in shared library interfaces HAL Integration (backend) Layer by calling backend integration APIs.

### 3) P&M HAL Integration (backend) Layer, a.k.a, component specific HAL

This is the layer making calls to underlying Linux system calls/commands, third party modules, open source modules and other CCSP components to execute the requests. This layer will be more component specific and will be providing APIs to CCSP so as to manage a particular hardware module of the system.

The implementation of APIs is responsible to convert the user space calls into Device IOCTL (kernel space) accordingly.



## **3 Functional Structure**

### **3.1 CCSP Message Bus APIs**

P&M DBUS object path is “/com/cisco/spvtg/ccsp/pam”.

P&M supports following CCSP Message Bus APIs:

- 1) initialize
- 2) finalize
- 3) getParameterNames
- 4) getParameterValues
- 5) setParameterValues
- 6) setCommit
- 7) setParameterAttributes
- 8) getParameterAttributes
- 9) AddTblRow
- 10) DeleteTblRow
- 11) busCheck

### **3.2 CCSP Message Bus APIs required from other components**

P&M requires following CCSP Message Bus APIs.

From CR:

- 1) registerCapabilities
- 2) unregisternamespace
- 3) unregisterComponent
- 4) discComponentSupportingNamespace
- 5) checkNamespaceDataType
- 6) SendDeviceProfileChangeSignal



From PA:


- 7) SendParameterValueChangeSignal

From PSM:


- 8) getParameterValues
- 9) setParameterValues
- 10) getParameterNames

## 4 P&M System Flow

### 4.1 Parameter set/get flow in P&M




**Figure 3 Parameter Get Flow**



**Figure 4 Parameter Set Flow**



## 4.2 P&M boot-up flow



**Figure 5 P&M boot-up flow**

### 4.3 Instance Number Operation Flow

Object instance number is used to uniquely identify the object, even across reboots. It is a special value P&M has to maintain, though it is not shown as a parameter. Instance number is generated when a new object is added, or during initialization, if no existing instance number is found. Generated instance number is saved in persistent configuration. Once the object is removed, the instance number is usually not reused.

Instance Number Operation Flow, when system boots up:

- Data Model Access Layer Starts and Loads DM adapter. DM adapter initialize its backend API
- DM adapter calls CosaDmlXyzGetEntry() to retrieve each object
- Backend reads saved configuration from persistent storage
- DM adapter checks, if Instance Number/Alias exists
  - If exists then get saved configuration from persistent storage
  - If not fund
    - DM adapter generates Instance Number/Alias
    - DM adapter calls CosaDmlXyzSetValues()
    - Backend saves Instance Number/Alias into persistent storage

When an object is added during runtime:

- DMM receives ACS RPC to add an object. DM adapter creates an object internally and set the parameters with default values. DM adapter picks a unique instance number (and alias).
- DMM returns the instance number. DMM receives Set with filled parameters.
- DM adapter calls backend API to Add Entry. Instance Number and Alias (if any) are filled in.
- Backend saves the configuration, including Instance Number and Alias, and take respective actions.

## 5 Glossary

The following list describes acronyms and definitions for terms used throughout this document:

- **CCSP: Common Component Software Platform**
- **P&M: Provisioning and Management**
- **PA: Protocol Agent**
- **CR: Component Registrar**
- **PSM: Persistent Storage Manager**
- **TDM: Test and Diagnostics Manager**