



## Crack rslogix 5000 v20

Integrated electronics (Quaid-e-Awam University of Engineering Science & Technology)



Scan to open on Studeersnel

After installing RSLogix5000 V20 and FTV activation V3.40, you need to put your computer into safe mode, by restarting windows and hit F8 key? dependent on Op system and tap down and highlight "start in safe mode" in the Dos start up.

Alrighty... just got mine activated. I run a Windows XP SP3 32 bits on a VirtualBox. I recommend you do the same, since most of the program is 16bits.

Here is what you do:

1) Download a Hex Editor if you don't have one. I use HexEdit.

2) Go to 'Start>Run...' and type "services.msc". Find FactoryTalk Activation Service, 'right click>stop'.

3) Go to 'C:\Program Files\Rockwell Software\FactoryTalk Activation' open 'flexsvr.exe' on HexEdit. Search for "55 8B EC 83 E4 F8 81 EC" on Address D150. Really important that you find this exact line. Change it to "33 C0 40 89 45 FC 48 C3". Make sure that the previous value is erased. Save it.

4) Search for "rsl5kcp.dll". Found mine at "C:\Program Files\Rockwell Software\RSLogix 5000\ENU\v20\Bin". Open it with HexEdit. Search for 34 02. You MUST find it at Address FBD19. Change it to 30 90. Save it.

5) Find "ftasystem" in your Activations folder. Mine was at "C:\Documents and Settings\All Users\Documents\Rockwell Automation\Activations". "Right Click>Properties" untick Read Only. Click OK. Double click and add the following:

```
FEATURE RS5K_700.exe flexsvr 1.0 permanent 10 VENDOR_STRING=99999999 \
HOSTID=ANY vendor_info="PRODUCT_NAME:RS5K_700.exe" SN=0000000001 \
SIGN="0034 5678 90AB CDEF 1122 3344 5566 7700 FFFF FFFF FFFF \
FFFF FFFF FFFF FFFF"
```

Save. "Right Click>Properties" tick again Read Only. Click OK.

6) At "services.msc" Find FactoryTalk Activation Service, 'right click>start'. Find FactoryTalk Activation Manager, go to advanced, click refresh. It will turn yellow, then green, if you did everything right. Go to Manage Activations and click Refresh Activations. You must see RS5k\_700.exe at Available Activations.

7) Start RSLogix 5000 v20 and see if it worked.

8) Si tenemos problemas al busca el dato 34 02 en la dirección FBD19, podemos activar la V19 y tomar el archive "rsl5kcp.dll" para hacer el cambio.