

X16 High 26 pin beige

#	High X16		Low	
1	Airbag	BL/SW	-	
2	CCM	WS/GN	-	
3	CCM LCM Comp	WS/BR	-	
4	CCM	WS/BL	-	
5	Charge indicator control	BL	X16 / 9	
6	Oil pressure indicator control	BR/GN	X16 / 5	
7	Terminal 15 power Fuse	GN/RT	X16 / 16.25 F17 7.5A	
8	ASC	SW/VI/WS	-	
9	Oil temp (M5)	BR/VI	-	
10	Ground, brake pad signal	GE	X13060 / 10	
11	Traller turn signal indicator	WS/RT	X16 / 24	
12	Terminal 30 power	RT/GE	X16 / 21	
13	Terminal 30 power	RT/GE	X16 / 21	
14	Not used	-	-	
15	Brake fluid warning	BR/GN/GE	X16 / 3	
16	SIA reset	WS/GN	X16 / 8	
17	Ti signal for fuel economy	WS/SW	X16 / 20	
18	TD signal for tachometer	SW	X16 / 26	
19	Not used	-	-	
20	ABS indicator control	GR/SW/GE	X16 / 2	
21	Airbag indicator power	VI	-	
22	High beam indicator power	WS	X16 / 23	
23	Data line CCM Comp	BL/BR/GE	-	
24	Temperature sensor ground	BR/GE	-	
25	Brake pad warning	GE	X13060 / 9	
26	Temperature gauge signal	BR/VI	X16 / 4	

X17 6pin brown

#	High X17		Low	
1	Ground	BR/OR	X1306 / 11	
2	RxD diagnosis	WS/GE	X16 / 12	
3	Terminal R power	VI/GE	X16 / 22	
4	Cluster programming		-	
5	Cluster programming		-	
6	Cluster programming		-	
7	Cluster programming		-	
8	Cluster programming		-	
9	Cluster programming		-	
10	Cluster programming		-	
11	Cluster programming		-	
12	Cluster programming		-	
13	Ground	BR/OR	X16 / 18	
14	TxD	WS/VI	X16 / 1	
15	Terminal R power	0.5 VI/GE	X16 / 22	
16	Cluster programming		-	
17	Cluster programming		-	
18	Cluster programming		-	
19	Cluster programming		-	
20	Cluster programming		-	
21	Cluster programming		-	
22	Cluster programming		-	
23	Cluster programming		-	
24	Cluster programming		-	

X271 12 pin Gray

#	High X271		Low	
1	Not used	-	-	
2	Fuel level warning signal	SW/RT/GE	X13060 / 3	
3	Not used	-	-	
4	Fuel level signal	BR/VI	X13060 / 14	
5	Not used	-	-	
6	Not used	-	-	
7	Park brake indicator control	0.5 bl/br	X13060 / 24	
8	Vehicle speed input (+)	BR/RT	X13060 / 13	
9	Not used	-	-	
10	Vehicle speed input (-)	BR	X13060 / 2	
11	Not used	-	-	
12	Not used	-	-	

X502 26pin White

#	High X502		Low	
1	Fog light indicator control LCM	GE/BR	X13060 / 8	
2	Sound tone signal	SW/RT	-	
3	Check engine indicator control	GR	-	
4	Gear range signal	BR/SW	-	
5	Gear range signal	BL/SW	-	
6	Gear range signal	BL/WS	-	
7	Not used	-	-	
8	Transmission EGS	GE/BL	-	
9	Transmission EGS	GE/WS	-	
10	Not used	-	-	
11	Gear range signal	???	-	
12	Not used	-	-	
13	Not used	-	-	
14	Instrument illumination power	GR/RT	X13060 / 1	
15	Not used	-	-	
16	EML	GR/GN	-	
17	EML	GR/GN	-	
18	Vehicle speed signal output	SW/WS	X13060 / 12	
19	Not used	-	-	
20	Not used	-	-	
21	Not used	-	-	
22	Not used	-	-	
23	Check control reset signal Comp	WS/GR	-	
24	Not used	-	-	
25	Left turn indicator control	BL/GN	X13060 / 20	
26	Right turn indicator control	BL/BR	X13060 / 19	