

Message Name	Resp	Client/ Reader	Description
ENABLE_EVENTS_- AND_REPORTS	N	C	A message generated by the client to enable the RO_ACCESS_REPORT and READER_EVENT_NOTIFICATION. Only required by client when using the <i>HoldEventsAndReports</i> feature of LLRP.
ENABLE_ROSPEC	Y	C	Enables an <i>ROSpec</i> on the Reader
ERROR_MESSAGE	N	R	A message generated by the Reader when it is unable to properly decode and respond to a client message.
GET_ACCESS_SPECS	Y	C	Gets the Reader's currently configured <i>AccessSpecs</i>
GET_READER_- CAPABILITIES	Y	C	Gets the Readers capabilities
GET_READER_- CONFIG	Y	C	Gets the Readers configuration
GET_REPORT	N	C	A message sent by the client to trigger a report to be generated from the Reader. This is in addition to any report triggers configured in the <i>ROSpec</i> or <i>AccessSpec</i> .
GET_ROSPECS	Y	C	Gets the Reader's currently configured <i>ROSpecs</i>
KEEP_ALIVE	Y	R	Reader periodically generates this message (when configured by the client). The response to this message generated by the client is called a KEEP_ALIVE_ACK (as opposed to the normal response nomenclature of LLRP)
READER_EVENT_- NOTIFICATION	N	R	A message generated by the reader to post asynchronous reader events (as opposed to tag events) to the client.
RO_ACCESS_REPORT	A	R	The report containing tag inventory and access data
SET_READER_CONFIG	Y	C	Sets the Reader configuration
START_ROSPEC	Y	C	Starts (activate) and <i>ROSpec</i> on the Reader
STOP_ROSPEC	Y	C	Stops (deactivates) an <i>ROSpec</i> on the Reader